

QFX10008 Switch Quick Start Guide

Published
2023-10-20

RELEASE

Table of Contents

Quick Start Description

Step 1–Preparing the Site for the QFX10008

Rack-Mounting Requirements | 2

Clearance Requirements | 2

Cooling and Airflow Requirements | 3

Step 2–Unpacking the QFX10008

Step 3–Mounting the Switch Chassis

Installing the Mounting Hardware | 7

Mounting the QFX10008 Using a Mechanical Lift | 9

Manually Mounting a QFX10008 | 12

Step 4–Installing Line Cards

Step 5–Installing the Front Panel

Step 6–Connecting Power to the Chassis

Ground the Chassis | 22

Install AC Power Supplies | 23

Install DC Power Supplies | 27

Step 7–Connecting to the Network

Step 8–Performing Initial Configuration

Safety Warnings Summary

Quick Start Description

This Quick Start contains information you need to install and configure the QFX10008 switch. For complete installation instructions, see the *QFX10008 Switch Hardware Guide* at <https://www.juniper.net/documentation/>.



WARNING: This guide contains a subset of QFX10008 safety information. For the complete list of safety warnings for the QFX10008, see *QFX10008 Switch Hardware Guide* at <https://www.juniper.net/documentation/>.



Use the following steps to install a QFX10008.

Step 1—Preparing the Site for the QFX10008

IN THIS SECTION

- [Rack-Mounting Requirements | 2](#)
- [Clearance Requirements | 2](#)
- [Cooling and Airflow Requirements | 3](#)

The QFX10008 is a rigid sheet-metal switch-chassis that houses the other hardware components such as control boards, switch interface boards (SIBs), power supplies, fan trays, and line cards. The switch chassis ships in a cardboard box that has a two-layer wooden pallet base. The switch chassis is bolted to the pallet base. You can install a QFX10008 switch in a standard 19 in. (483 mm) equipment rack by using the supplied rack-mounting kit and the front-mounting bracket that is attached to the chassis.

Before you install the QFX10008, make sure the site meets all of the power, cooling, and clearance requirements. See the site preparation guidelines and power requirements in the *QFX10008 Switch Hardware Guide*.

Rack-Mounting Requirements

The QFX10008 switch chassis is designed to be installed in standard 19-in. wide four-post racks that are spaced at 1 U (1.75 in. or 4.45 cm) increments.


You can stack three QFX10008 chassis in a four-post rack if:

- The rack is 42 U or greater.
- The rack meets the strength requirements to support the weight.
- The facility can provide adequate power and cooling.
- Ensure that the rack rails are spaced widely enough to accommodate the switch chassis' external dimensions. The outer edges of the front-mounting brackets extend the chassis width to 19 in. (48.26 cm).
- Ensure that the rack is strong enough to support the weight of the switch and cabling.
- Ensure that the spacing of rails and adjacent racks allows for proper clearance around the switch and rack.

Clearance Requirements

For the cooling system to function properly, the airflow around the chassis must be unrestricted. You must allow sufficient clearance around the installed chassis for cooling and maintenance (see [Figure 1 on page 3](#)).

Figure 1: Clearance Requirements for Airflow and Hardware Maintenance for a QFX10008




If you are mounting a QFX10008 in a rack with other equipment, ensure that the exhaust from other equipment does not blow into the intake vents of the chassis.

Cooling and Airflow Requirements

The cooling system in a QFX10008 chassis consists of dual fan trays and dual fan tray controllers. There is no air filter in a QFX10008.

The air intake to cool the chassis is located on the port (line card) side of the chassis. Air flows into the chassis from the ports in the control boards and line cards, through the switch interface boards (SIBs), and exits from the fan trays and the power supplies. This airflow is called port-to-FRU cooling or airflow out (AFO). See [Figure 2 on page 4](#).

Figure 2: Airflow Through a QFX10008



Follow these guidelines:

- For the cooling system to function properly, the airflow around the chassis must be unrestricted.
- If you are mounting a QFX10008 in a rack with other equipment, ensure that the exhaust from other equipment does not blow into the intake vents of the chassis.
- Leave at least 24 in. (61 cm) both in front of and behind the QFX10008 for service personnel to remove and install hardware components. To be NEBS GR-63 compliant, allow at least 30 in. (76.2 cm) in front of the rack and 24 in. (61 cm) behind the rack.

Step 2—Unpacking the QFX10008

NOTE: The chassis is maximally protected inside the shipping box. Do not unpack it until you are ready to begin installation.

Ensure that you have the following parts and tools available to unpack the QFX10008:


- A 13/32 in. (10 mm) open-end or socket wrench to remove the bracket bolts from the shipping pallet
- A box cutter or packing knife to slice open the nylon straps and tape that seal the crate and boxes

The chassis ships in a cardboard box that has a two-layer wooden pallet base with foam cushioning between the layers. The switch chassis is bolted to the pallet base.

The shipper has the option to either ship the front panel separately or to ship along with the chassis. If the front panel arrives with the chassis, set aside the front panel box until you are ready to verify the contents of the order.

To unpack the chassis (see [Figure 3 on page 5](#)):


Figure 3: Shipping Crate and Accessory Box



1. Move the shipping box to a staging area as close to the installation site as possible. While the chassis is bolted to the pallet, you can use a forklift or pallet jack to move it. Make sure there is enough space to remove components from the chassis.
2. Position the shipping box with the arrows pointing up.
3. Slice the nylon straps with the box cutter that hold the shipping boxes to the pallet.
4. Lift the shipping box off the chassis.

5. Remove the cardboard accessory box.
6. Remove the foam padding from the top of the box.
7. Remove the plastic cover from the switch chassis.
8. Use a 13/32 in. (10 mm) open-end or socket wrench to remove the four sets of bracket bolts that secure the chassis to the shipping pallet (see [Figure 4 on page 6](#)).

Figure 4: Bracket Bolt Removal



9. Unpack the accessory box and lay out the contents so that they are ready for use.
10. Verify that your order includes all appropriate parts.
11. Store the brackets and bolts inside the accessory box.
12. Save the shipping box and packing materials in case you need to move or ship the switch at a later time.

Step 3–Mounting the Switch Chassis

IN THIS SECTION

- [Installing the Mounting Hardware | 7](#)
- [Mounting the QFX10008 Using a Mechanical Lift | 9](#)
- [Manually Mounting a QFX10008 | 12](#)

To install the QFX10008, first install the mounting hardware and then perform one of these two procedures:

Installing the Mounting Hardware

Ensure that you have the following parts and tools available to install the mounting brackets:

- A Phillips (+) screwdriver, number 1, 2, or 3, depending on the size of your rack-mounting screws
- A Phillips (+) screwdriver, number 2, to install the screws that connect the rear-mounting and front-mounting brackets
- 16 mounting screws appropriate for your rack to attach the 4 mounting bracket pieces to the rack

Install the mounting hardware on the rack before installing the switch. The QFX10008 comes with a four-piece set of mounting brackets that supports the chassis in the rack.

NOTE: Two-post installation racks are not supported.

The four mounting bracket pieces are:

- 1 left front mounting bracket. The bracket is labeled “LEFT FRONT” on the side of the bracket that faces the interior of the rack, near the holes for attaching the bracket to the rack.
- 1 right front mounting bracket. The bracket is labeled “RIGHT FRONT” on the side of the bracket that faces the interior of the rack, near the holes for attaching the bracket to the rack.


- 2 rear mounting brackets. These brackets are labeled “REAR” on the side of the bracket that faces the interior of the rack, near the holes for attaching the bracket to the rack. The rear brackets are interchangeable; you can use either of the rear brackets with the right or left front-mounting bracket.

When you install the mounting brackets, the adjustable portion of the brackets overlap. Use the overlap area to adjust the total bracket length to fit any of the four standard rack sizes: 19 in. (483 mm), 23.62 in. (600 mm), 30 in. (762 mm), or 31.5 in. (800 mm).

To install the mounting brackets in a four-post rack:

1. Remove the mounting brackets from the accessory box.
2. Decide where to place the chassis in the rack. If the rack is empty, mount the switch in the lowest possible location. See ["Clearance Requirements" on page 2](#).
3. Position the left front adjustable mounting bracket at the desired position in the left side of the rack and line up its front screw holes with the holes in the rack. Use four mounting screws appropriate for your rack to attach the left front bracket to the rack.
4. Position one of the rear brackets at the left rear of the rack on the same level as the left front bracket, so that the rear bracket overlaps with the left front bracket. The screw holes for connecting the front and rear brackets should overlap. Use four mounting screws appropriate for your rack to attach the rear bracket to the rack.
5. Connect left front and rear brackets (see [Figure 5 on page 9](#)):
 - a. Insert six of the screws provided with the mounting brackets into the overlapping bracket holes.
 - b. Hand-tighten the screws fully (to 12–16 in.-lb torque) using a number 2 Phillips screwdriver.

Figure 5: Mounting Brackets for 4-Post Rack Installation



1– Front adjustable mounting brackets

2– Rear adjustable mounting brackets

6. Position the right front adjustable mounting bracket at the desired position in the right side of the rack opposite the installed left front bracket, so that it is on the same rack level as the left bracket. If the right and left front brackets are not on the same level, the chassis will rest at an angle in the rack instead of resting flat and level. Line up the right bracket's front screw holes with the holes in the rack. Use four mounting screws appropriate for your rack to attach the right front bracket to the rack.
7. Position the other rear bracket at the right rear of the rack on the same level as the right front bracket, so that the rear bracket overlaps with the right front bracket. The screw holes for connecting the front and rear brackets should overlap. Use four mounting screws appropriate for your rack to attach the rear bracket to the rack.
8. Connect the right front and rear brackets (see [Figure 5 on page 9](#)):
 - a. Insert six of the screws provided with the mounting brackets into the overlapping bracket holes.
 - b. Hand-tighten the screws fully (to 12–16 in.-lb torque) using a number 2 Phillips screwdriver.

Mounting the QFX10008 Using a Mechanical Lift

Ensure that you have the following parts and tools available to install the switch:

- A mechanical lift rated for 500 lbs. (226.8 kg)
- 14 mounting screws appropriate for your rack

- A Phillips (+) screwdriver, number 2 or number 3, depending on the size of your rack-mounting screws

Because of the switch's size and weight, we strongly recommend using a mechanical lift to install the QFX10008.



CAUTION: Do not install line cards in the chassis until after you mount the chassis securely on a rack or cabinet.



CAUTION: Before front-mounting the switch on a rack or cabinet, have a qualified technician verify that the rack or cabinet is strong enough to support the switch's weight and is adequately supported at the installation site.



CAUTION: If you are installing more than one switch in a rack or cabinet, install the first switch at the bottom of the rack.

To install the switch using a mechanical lift (see [Figure 6 on page 11](#)):


1. Ensure that the rack or cabinet is placed in its permanent location and is secured to the building. Ensure that the installation site allows adequate clearance for both airflow and maintenance. For details, see "[Clearance Requirements](#)" on page 2.
2. Load the switch onto the lift, making sure it rests securely on the lift platform.

Figure 6: Loading the QFX10008 into a Rack Using a Mechanical Lift



3. Using the lift, align the switch in front of the rack, centering it in front of the mounting brackets.
4. Lift the chassis approximately 0.75 in. (1.9 cm) above the surface of the mounting brackets. Align the chassis as close as possible to the mounting brackets.
5. Carefully slide the chassis onto the adjustable mounting brackets until the front-mounting brackets attached to the chassis contact the rack rails. The mounting brackets ensure that the holes in the front-mounting brackets align with the holes in the rack rails. See [Figure 7 on page 12](#).

Figure 7: Attaching Front-Mounting Brackets



6. Move the lift away from the rack.
7. Install a mounting screw into each of the open front-mounting holes aligned with the rack, starting from the bottom.
8. Visually inspect the alignment of the switch. If the switch is installed properly in the rack, all the mounting screws on one side of the rack are aligned with the mounting screws on the opposite side and the switch is level.
9. After ensuring that the switch is aligned properly, tighten the screws.

Manually Mounting a QFX10008

Before you install the switch, remove all components except the two fan tray controllers from the chassis. For details on how to remove switch components, such as control boards, fan trays, power supplies, and SIBs, see *QFX10008 Switch Hardware Guide* at <https://www.juniper.net/documentation/>.

Ensure that you have the following parts and tools available to install the switch:

- 14 mounting screws appropriate for your rack
- A Phillips (+) screwdriver, number 2 or number 3, depending on the size of your rack-mounting screws

If you cannot use a mechanical lift to install the switch (the preferred method), you can install it manually.



CAUTION: The chassis weighs approximately 145 lb (66 kg) with only the fan tray controllers installed. Lifting the chassis and mounting it in a rack or cabinet requires at least three people. Make sure the chassis is empty (contains only the backplane) before you lift it.

The chassis has two handles that are designed for subtle positioning of the chassis. Do not lift the chassis by the handles.



CAUTION: Before front-mounting the switch in a rack, have a qualified technician verify that the rack is strong enough to support the switch's weight and is adequately supported at the installation site.

To install the switch in the rack or cabinet:




CAUTION: If you are installing more than one switch in a rack or cabinet, install the first one at the bottom of the rack. Do not attempt to install a switch manually in an upper position in a rack or cabinet.

1. Ensure that the rack or cabinet is placed in its permanent location and is secured to the building.
2. Align the switch in front of the rack or cabinet, centering it in front of the adjustable mounting brackets. Use a pallet jack if one is available.
3. With one person on each side and one person in the rear, hold the bottom of the chassis and carefully lift it onto the adjustable mounting brackets installed in a four-post rack. See [Figure 8 on page 14](#).




WARNING: To prevent injury, keep your back straight and lift with your legs, not your back. Do not twist your body as you lift. Balance the load evenly and be sure that your footing is firm.

Figure 8: Lifting the QFX10008 Without Using a Mechanical Lift



4. Carefully slide the switch onto the mounting brackets until the front-mounting brackets attached to the chassis contact the rack rails. The mounting brackets ensure that the holes in the front-mounting brackets attached to the chassis align with the holes in the rack rails.
5. Install a mounting screw into each of the open front-mounting holes aligned with the rack, starting from the bottom.
6. Visually inspect the alignment of the chassis. If the chassis is installed properly in the rack, all the mounting screws on one side of the rack are aligned with the mounting screws on the opposite side and the switch is level.
7. After ensuring that the switch is aligned properly, tighten the screws.

Figure 9: Installing a QFX10008 in a 4-Post Rack



After you install the mounting screws and securely bolt the chassis to the rack, reinstall the components in the chassis. For information on how to install switch components, see *QFX10008 Switch Hardware Guide* at <https://www.juniper.net/documentation/>.

Step 4—Installing Line Cards


QFX10000 line cards are field-replaceable units (FRUs) that can be installed in any of the line card slots on the front of the chassis. The line cards are hot-insertable and hot-removable: You can remove and replace them without powering off the switch or disrupting switch functions.

- Ensure that you have the following parts and tools available to install a line card in the switch:
 - ESD grounding strap
 - Phillips (+) screwdriver, number 2

To install a line card in the switch chassis:


1. Attach the ESD grounding strap to your bare wrist and connect the strap to the ESD point on the switch chassis. The ESD point is located above the status LED panel on the front of the switch chassis. See [Figure 10 on page 16](#).

Figure 10: ESD Point on Chassis Front




2. Remove the cover panel by grasping the handles and pulling straight out to expose the slot for the line card. See [Figure 11 on page 16](#).

Figure 11: Removing the Cover Panel for a Line Card



CAUTION: Do not lift the line card by holding the edge connectors or the handles on the faceplate. Neither the handles or the edge connectors can support the weight of the line card. Lifting the line card by the handles or edge connectors might bend them, which would prevent the line cards from being properly seated in the chassis. See [Figure 12 on page 17](#).


Figure 12: Line Card Connectors



1– Connectors

3. Remove the line card from the electrostatic bag and inspect it for any damage before installing it into the chassis.
4. Grasp and lift the line card by the sides.
5. Slide the line card all the way into the slot until the handle holes align. See [Figure 13 on page 17](#).

Figure 13: Inserting a Line Card into the Slot and Rotating the Handles



6. Screw the line card into the chassis by rotating the handles until the card is fully seated and the handles are vertical.
7. Bring the line card online:

```
user@switch>
request chassis fpc slot slot-number online
```

You can install the optional cable management kit after the card is installed.

Step 5–Installing the Front Panel

The front panel is required on the QFX10008 to protect fiber optic cabling and to provide additional protection from electromagnetic interference (EMI). The front panel can be installed with or without the optional cable management system.


Ensure you have the following tools and parts before you begin:

- A Phillips (+) screwdriver, number 2
- Front panel (provided with the switch chassis)
- Right base bracket (provided)
- Left base bracket (provided)
- 2 interchangeable latch brackets (provided)
- 8 Phillips flat head mounting screws (provided)

To install the front panel:

1. Remove the plastic bag that is taped to the front panel, which holds the brackets and screws.
2. Use the Phillips screwdriver to attach two mounting screws to the left base bracket at the bottom left side of the chassis frame. The base brackets are larger than the latch brackets.

NOTE: The right and left base bracket cannot be interchanged (see [Figure 14 on page 19](#)).

Figure 14: Front Panel Mounting Hardware


1– Latch brackets

3– Left base bracket

2– Right base bracket


3. Use the Phillips screwdriver to attach two mounting screws to the right base bracket at the bottom right side of the chassis frame.
4. Use the Phillips screwdriver to attach two mounting screws to the latch bracket at the top left of the chassis frame (see [Figure 15 on page 20](#)).

Figure 15: Attaching Front Panel Brackets



5. Use the final two mounting screws to attach a latch bracket to the top right of the chassis frame so there are brackets on all four corners of the front of the chassis.
6. Lift the front panel and rest it on the two bottom brackets.
7. Slide the panel back on the bracket glides until it engages on the two ramps.
8. Tilt the panel towards the chassis until it is vertical with the chassis. The blue release buttons on the side of the panel click into place (see [Figure 16 on page 21](#)).

Figure 16: Front Panel Installation



Step 6—Connecting Power to the Chassis

IN THIS SECTION

- [Ground the Chassis | 22](#)
- [Install AC Power Supplies | 23](#)
- [Install DC Power Supplies | 27](#)

Before supplying power to the QFX10008, complete ensure you complete these tasks:

Ground the Chassis

To meet safety and electromagnetic interference (EMI) requirements and to ensure proper operation, you must connect the QFX10008 to earth ground before you connect it to power.

For installations that require a separate grounding conductor to the chassis, you must attach a protective earthing terminal bracket on the QFX10008. There are mounting holes for the terminal bracket on the left-rear side of the chassis to connect to the earth ground (see [Figure 18 on page 23](#)).

Before you connect earth ground to the protective earthing terminal of a QFX10008, ensure that a licensed electrician has attached an appropriate grounding lug to the grounding cable.



CAUTION: Using a grounding cable with an incorrectly attached lug can damage the switch.

Ensure that you have the following parts and tools available:


- An electrostatic discharge (ESD) grounding strap (provided).
- Protective earthing terminal bracket (provided).
- Grounding cable for your QFX10008 (not provided)—The grounding cable must be 6 AWG (13.3 mm²), minimum 90° C wire, or as permitted by the local code.
- Grounding lug for your grounding cable (provided)—This bracket attaches to the lower left corner of the QFX10008 switch chassis next to PSU 5, providing a protective earthing terminal for the switch. The grounding lug required is a Panduit LCD6-10A-L or equivalent.
- A Phillips screwdriver to tighten the two screws that are mounted on the chassis.

An AC-powered QFX10008 gains additional grounding when you plug the power supply in the switch into a grounded AC power outlet by using an AC power cord appropriate for your geographical location.

To connect earth ground to a QFX10008:


1. Verify that a licensed electrician has attached the cable lug (provided in the accessory kit) to the grounding cable.
2. Connect the other end of the grounding cable to a proper earth ground, such as the rack in which the switch is mounted.
3. Attach an ESD grounding strap to your bare wrist, and connect the strap to the ESD grounding point next to the earthing posts (see [Figure 17 on page 23](#)).

Figure 17: ESD Point for Chassis Rear



4. Remove the two screws on the chassis using a Phillips screwdriver.
5. Place the chassis grounding lug and cable over the PEM nuts with the cable connection pointing to the left. See [Figure 18 on page 23](#).

Figure 18: Connecting a Grounding Cable to the QFX10008



6. Place the two screws over the grounding lug and grounding cable.
7. Tighten the two screws using a Phillips screwdriver.
8. Dress the grounding cable and ensure that it does not touch or block access to other device components and that it does not drape where people can trip over it.

Install AC Power Supplies

QFX10008 power supplies are hot-insertable and are field-replaceable units (FRUs). You can install up to six power supplies in a QFX10008. The power supplies install in the rear of the chassis in the slots provided along the left side.



CAUTION: Do not mix AC and DC power supplies in the same chassis.


Before you install an AC power supply in the switch, ensure that you have the following parts and tools available to install an AC power supply in a QFX10008:

- Electrostatic discharge (ESD) grounding strap
- Phillips (+) screwdriver, number 1
- Power cords appropriate for your geographical location.
- Power cord retainer clips

To install an AC power supply in a QFX10008 :

1. Attach the electrostatic discharge (ESD) grounding strap to your bare wrist, and connect the strap to the ESD point on the chassis. There is an ESD point located next to the protective earthing terminal and below **PSU 5** on the rear panel .
2. If the power supply slot has a cover panel on it, insert your thumb and forefinger into the finger holes, squeeze and pull the cover out of the slot. Save the cover panel for later use. See [Figure 19 on page 24](#).

Figure 19: Removing the PSU Cover Panel




3. Taking care not to touch power supply connections, remove the power supply from its bag.
4. Peel back and remove the protective plastic wrap that covers all four sides of the power supply.

5. Ensure the power switch is set to the standby (O) position. This switch turns off the output voltage; it does not interrupt AC.
6. Unscrew the captive screw in the counterclockwise direction by using the Phillips (+) screwdriver, number 1.
7. Rotate the captive screw away from the faceplate of the power supply to release the latch.

NOTE: You can install the power supplies in any slot labeled **PSU 0** through **PSU 5** (top to bottom).


8. Using both hands, place the power supply in the power supply slot on the rear of the system. Slide the power supply straight into the chassis until the power supply is fully seated in the slot. Ensure the power supply faceplate is flush with any adjacent power supply faceplates or power supply cover panels (see [Figure 20 on page 26](#)).
9. Push the captive screw into the power supply faceplate. Ensure that the screw is seated inside the corresponding hole on the faceplate.
10. Tighten the captive screw by turning it clockwise by using the Phillips (+) screwdriver, number 1. When the screw is completely tight, the latch locks into the switch chassis.

Figure 20: Installing a QFX10008 AC Power Supply



11. Locate two power cords shipped with the switch; the cords have plugs appropriate for your geographical location.
12. Attach each power cord to a dedicated AC power source outlet.
13. Squeeze the two sides of the power cord retainer clip and insert the ends of the clip into the holes in the bracket on each side of the AC appliance inlets on the AC power supply faceplate. See [Figure 21 on page 27](#).
14. Insert the power cord coupler into the power supply.
Each AC power supply has two independent 16 A rated AC inlets on the faceplate. Each inlet must be connected to a dedicated AC power feed to achieve 2N source redundancy. A single connection can be used if redundancy is not a requirement.
15. Fasten the cord retainer by lowering the clip over the cord and pushing the cord into the adjustment nut of the cord retainer. Rotate the nut until it is tight against the base of the cord. See [Figure 21 on page 27](#).

Figure 21: Power Cord and Retainer Clip

1– Enable switch for **INP1**2– Enable switch for **INP2**

WARNING: Ensure that the power cords do not block access to switch components or drape where people can trip on them.

16. If the AC power source outlets have a power switch, set them to the on (I) position.
17. Move the enable switches for input 1 and input 2 to the **ON** position.
18. Verify that the **INP1** and **INP2** LEDs on the power supply faceplate are lit and are on steadily.
19. Press the power switch to the on (I) position.

Install DC Power Supplies

QFX10008 power supplies are hot-insertable and are field-replaceable units (FRUs). You can install up to six power supplies in a QFX10008. The power supplies install in the rear of the chassis in the slots provided along the left side.



CAUTION: Do not mix AC and DC power supplies in the same chassis.

1. Before you install a DC power supply in the chassis, ensure that you have followed all safety warnings and cautions:



WARNING: Before performing DC power procedures, ensure that power is removed from the DC circuit. To ensure that all power is off, locate the circuit breaker on the panel board that services the DC circuit, switch the circuit breaker to the OFF position, and tape the switch handle of the circuit breaker in the OFF position.



CAUTION: Before you connect power to the switch, a licensed electrician must attach a cable lug to the grounding and power cables that you supply. A cable with an incorrectly attached lug can damage the switch (for example, by causing a short circuit).



CAUTION: To meet safety and electromagnetic interference (EMI) requirements and to ensure proper operation, you must connect QFX10008 switches to earth ground before you connect them to power. For installations that require a separate grounding conductor to the chassis, use the protective earthing terminal on the switch chassis to connect to earth ground. For instructions on connecting a QFX10008 switch to ground using a separate grounding conductor, see ["Ground the Chassis" on page 22](#).

2. Ensure that you have the following parts and tools available to install a DC power supply in a QFX10008:

- Electrostatic discharge (ESD) grounding strap
- DC power source cables (not provided) with the cable lugs (provided) attached

The provided terminal lugs in a QFX10008 are sized for 4 AWG (21.1 mm²) power source cables. The DC power source cables that you provide must be 4 AWG (21.1 mm²), minimum 60°C wire. We recommend that you install heat-shrink tubing insulation around the power cables and lugs.

- 13/32 in. (10 mm) nut driver or socket wrench
- Phillips (+) screwdrivers, numbers 1 and 2
- Multimeter

To install a DC power supply in a QFX10008 (see [Figure 24 on page 32](#)):

1. Attach the electrostatic discharge (ESD) grounding strap to your bare wrist, and connect the strap to the ESD point on the chassis. There is an ESD point located next to the protective earthing terminal and below **PSU 5** on the rear panel .

2. Taking care not to touch power supply components, pins, leads, or solder connections, remove the power supply from its bag.
3. Peel back and remove the protective plastic wrap that covers all four sides of the power supply.
4. Ensure the power switch is set to the standby (O) position. This switch turns off the output voltage; it does not interrupt DC.
5. Remove the plastic cable cover from the DC power input terminals by using the Phillips (+) screwdriver, number 2, to loosen the screws.
6. Remove the nuts from each DC power input terminal, using the 13/32 in. (10 mm) nut driver or socket wrench to loosen the nuts.
7. Ensure that the power source circuit breaker is open so that the voltage across the DC power source cable leads is 0 V and that the cable leads do not become active while you are connecting DC power.
8. Verify that the DC power cables are correctly labeled before making connections to the power supply. In a typical power distribution scheme where the return is connected to chassis ground at the battery plant, you can use a multimeter to verify the resistance of the *-48V* and *RTN* DC cables to chassis ground:
 - The cable with very high resistance (indicating an open circuit) to chassis ground is negative (-) and will be installed on the *-48V*(input) DC power input terminal.
 - The cable with very low resistance (indicating a closed circuit) to chassis ground is positive (+) and will be installed on the *RTN*(return) DC power input terminal.




CAUTION: You must ensure that power connections maintain the proper polarity. The power source cables might be labeled (+) and (-) to indicate their polarity. There is no standard color coding for DC power cables.

9. Install each power cable lug on the DC power input terminal, securing it with the nut (see [Figure 22 on page 30](#)). Apply between 24 in.-lb (2.7 Nm) and 25 in.-lb (2.8 Nm) of torque to each nut. [Use the 13/32 in. (10 mm) nut driver or socket wrench.]
 - a. Secure each positive (+) DC source power cable lug to the *RTN*(return) DC power input terminal.
 - b. Secure each negative (-) DC source power cable lug to the *-48V*(input) DC power input terminal.


Each power supply has two independent sets of DC power input terminals (**INPUT 1: RTN -48V/-60V**; and **INPUT 2: RTN -48V/-60V**). For feed redundancy, each power supply must be powered by dedicated power feeds derived from feed *INPUT 1* and feed *INPUT 2*. This configuration provides the commonly deployed *INPUT 1 / INPUT 2* feed redundancy for the switch.

Figure 22: Connecting the DC Power Supply Cables to a QFX10008



10. Install the plastic cable cover over each set of power cables by using the Phillips (+) screwdriver, number 2, to tighten the screw.
11. If the power supply slot on the chassis has a cover panel on it, insert your thumb and forefinger into the finger holes, squeeze, and pull the cover out of the slot. Save the cover panel for later use (see [Figure 23 on page 31](#)).

Figure 23: Removing the PSU Cover Panel




12. Unscrew the captive screw in the counterclockwise direction by using the Phillips (+) screwdriver, number 1.
13. Pull the captive screw away from the faceplate of the power supply to release the latch.

NOTE: You can install the power supplies in any slot labeled **PSU 0** through **PSU 5** (top to bottom).

14. Using both hands, place the power supply in the power supply slot on the rear of the switch. Slide the power supply straight into the chassis until the power supply is fully seated in the slot. Ensure the power supply faceplate is flush with any adjacent power supply faceplates or power supply cover panels (see [Figure 24 on page 32](#)).
15. Push the captive screw into the power supply faceplate. Ensure that the screw is seated inside the corresponding hole on the faceplate.
16. Tighten the captive screw by turning it clockwise by using the Phillips (+) screwdriver, number 1. When the screw is completely tight, the latch locks into the switch chassis.

Figure 24: Installing a QFX10008 DC Power Supply



1– Source input 1 enable switch

2– Source input 2 enable switch

17.




WARNING: Ensure that the power cords do not block access to switch components or drape where people can trip on them.

18. Set the enable switches for input 1 and input 2 (see [Figure 25 on page 33](#)).

Set both enable switches to the | (on) position when using both source inputs. When not using source redundancy, set the unused source to the O (off) position. The LED turns red and indicates an error if a source input is not in use and the enable switch is | (on).

Figure 25: Setting the Enable Switches for the Power Source



1– Source input 1

2– Source input 2

19. Verify that the input 1 and 2 LEDs on the power supply faceplate are lit and are on steadily.
20. Press the power switch to the on (I) position.

Step 7–Connecting to the Network

You can configure and manage the QFX10008 by using a dedicated console. Every control board has a console port with an RJ-45 connector. Use the console port to connect the device to the management console or to a console server. The console port accepts a cable with an RJ-45 connector.

Ensure that you have an RJ-45 cable and an RJ-45 to DB-9 serial port adapter.

NOTE: We no longer include a DB-9 to RJ-45 cable or a DB-9 to RJ-45 adapter with a CAT5E copper cable as part of the device package. If you require a console cable, you can order it separately with the part number JNP-CBL-RJ45-DB9 (DB-9 to RJ-45 adapter with a CAT5E copper cable).

NOTE: If your laptop or PC does not have a DB-9 male connector pin and you want to connect your laptop or PC directly to the device, use a combination of the RJ-45 to DB-9 female adapter and a USB to DB-9 male adapter. You must provide the USB to DB-9 male adapter.

You can configure and manage the QFX10008 by using a dedicated console. Every control board has a console port with an RJ-45 connector. Use the console port to connect the device to the management console or to a console server. The console port accepts a cable with an RJ-45 connector.

To connect the QFX10008 to the network using the console port:

1. Connect one end of the Ethernet cable into the console port labeled **CON** on the control board.
2. Connect the other end of the Ethernet cable into the console server.

Figure 26: Connecting a Switch to a Management Console Through a Console Server




Figure 27: Connecting a Switch Directly to a Management Console



Step 8—Performing Initial Configuration

Before you begin connecting and configuring the switch, set the following parameter values on the console server or PC:

- Baud Rate—9600
- Flow Control—None
- Data—8
- Parity—None
- Stop Bits—1

- DCD State—Disregard

You must perform the initial configuration of a QFX10008 switch through the console port using the command-line interface (CLI).

To connect and configure the switch from the console:

1. Connect the console port to a laptop or PC using the RJ-45 cable and RJ-45 to DB-9 adapter. The console (**CON**) port is located on the port panel of the switch.
2. Log in as **root**. There is no password. If the software booted before you connected to the console port, you might need to press the Enter key for the prompt to appear.

```
login: root
```

3. Start the CLI.

```
root@% cli
```

4. Enter configuration mode.

```
root> configure
```

5. Add a password to the root administration user account.

```
[edit]  
root@# set system root-authentication plain-text-password  
New password: password  
Retype new password: password
```

6. (Optional) Configure the name of the switch. If the name includes spaces, enclose the name in quotation marks (" ").

```
[edit]  
root@# set system host-name host-name
```

7. Configure the default gateway.

```
[edit]
root@# set routing-options static route default next-hop address
```

8. Configure the IP address and prefix length for the switch management interface.

```
[edit]
root@# set interfaces em0 unit 0 family inet address address/prefix-length
```



CAUTION: Although the CLI permits you to configure two management Ethernet interfaces within the same subnet, only one interface is usable and supported.

NOTE: The management ports, `em0` (**MGMT** for RJ-45 connections) and `em1` (also labeled **MGMT** for fiber connections) are found on each of the control boards of the QFX10008.

9. (Optional) Configure the static routes to remote prefixes with access to the management port.

```
[edit]
root@# set routing-options static route remote-prefix next-hop destination-ip retain no-readvertise
```

10. Enable Telnet service.

```
[edit]
root@# set system services telnet
```

NOTE: When Telnet is enabled, you cannot log in to a QFX10000 through Telnet using root credentials. Root login is allowed only for SSH access.

11. Commit the configuration to activate it on the switch.

```
[edit]  
root@# commit
```

Safety Warnings Summary

IN THIS SECTION

- [Power Cable Warning \(Japanese\) | 38](#)

This is a summary of safety warnings. For a complete list of warnings, including translations, see *QFX10008 Switch Hardware Guide* at <https://www.juniper.net/documentation/>.



WARNING: Failure to observe these safety warnings can result in personal injury or death.

- Permit only trained and qualified personnel to install or replace switch components.
- Perform only the procedures described in this quick start and the QFX10008 switch documentation. Other services must be performed only by authorized service personnel.
- Before installing the switch, read the planning instructions in the QFX10008 switch documentation to make sure that the site meets power, environmental, and clearance requirements for the switch.
- Before connecting the switch to a power source, read the installation instructions in the QFX10008 switch documentation.
- A base AC configuration is 280 lb (127 kg) and redundant AC configurations can weigh 322 lb (146.06 kg). Installing the QFX10008 switch in a rack or cabinet requires either a mechanical lift or three people to lift the switch and another person to secure it to the rack. To prevent injury, keep your back straight and lift with your legs, not your back.
- If the rack or cabinet has stabilizing devices, install them in the rack before mounting or servicing the switch in the rack or cabinet.

- Before installing or after removing an electrical component, always place it component-side up on a flat antistatic mat or in an electrostatic bag.
- Do not work on the switch or connect or disconnect cables during electrical storms.
- Before working on equipment that is connected to power lines, remove jewelry, including rings, necklaces, and watches. Metal objects heat up when connected to power and ground and can cause serious burns or become welded to the terminals.



CAUTION: Do not place a copper transceiver in an access port directly above or below another copper transceiver. Damage to the access ports will occur.

Power Cable Warning (Japanese)

The attached power cable is only for this product. Do not use this cable for another product. Contacting Juniper Networks For technical support, see <https://www.juniper.net/support/requesting-support.html>.

注意

附属の電源コードセットはこの製品専用です。
他の電気機器には使用しないでください。

#140300

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners. Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice. Copyright © 2023 Juniper Networks, Inc. All rights reserved.