

Chapter 6

Control the CLI Environment

To configure the command-line interface (CLI) environment, use the operational-mode CLI set command:

```
user@host> set cli ?
Possible completions:
  complete-on-space Toggle word completion on space
  idle-timeout      Set the cli maximum idle time
  prompt            Set the cli command prompt string
  restart-on-upgrade Set cli to prompt for restart after a software upgrade
  screen-length     Set number of lines on screen
  screen-width      Set number of characters on a line
  terminal           Set terminal type
```

When you use ssh to log in to the router, or log in from the console when its terminal type is already configured (as described in “Configure Console and Auxiliary Port Properties” on page 398), your terminal type, screen length, and screen width are already set, so you do not need to change them.

This chapter discusses the following topics:

Set the Terminal Type on page 150

Set the Screen Length on page 150

Set the Screen Width on page 150

Set the CLI Prompt on page 150

Set the Idle Timeout on page 150

Set the CLI to Prompt after a Software Upgrade on page 151

Set Command Completion on page 151

Display CLI Settings on page 151

Example: Control the CLI Environment on page 152

Set the Terminal Type

To set the terminal type, use the set cli terminal command:

```
user@host> set cli terminal terminal-type
```

The *terminal-type* can be one of the following: ansi, vt100, small-xterm, or xterm.

Set the Screen Length

The default CLI screen length is 24 lines. To change the length, use the set cli screen-length command:

```
user@host> set cli screen-length length
```

Setting the screen length to 0 lines disables the display of output one screen at a time. Disabling this UNIX more-type interface can be useful when you are issuing CLI commands from scripts.

Set the Screen Width

The default CLI screen width is 80 columns. To change the width, use the set cli screen-width command:

```
user@host> set cli screen-width width
```

Set the CLI Prompt

The default CLI prompt is user@host>. To change this prompt, use the set cli prompt command. If the prompt string contains spaces, enclose the string in quotation marks (" ").

```
user@host> set cli prompt string
```

Set the Idle Timeout

By default, an individual CLI session never times out after extended times, unless the idle-timeout statement has been included in the user's login class configuration. To set the maximum time an individual session can be idle before the user is logged off the router, use the set cli idle-timeout command:

```
user@host> set cli idle-timeout timeout
```

timeout can be 0 through 100,000 minutes. Setting *timeout* to 0 disables the timeout.

Set the CLI to Prompt after a Software Upgrade

By default, the CLI prompts you to restart after a software upgrade. To disable the prompt for an individual session, use the `set cli restart-on-upgrade off` command:

```
user@host> set cli restart-on-upgrade off
```

To re-enable the prompt, use the `set cli restart-on-upgrade on` command:

```
user@host> set cli restart-on-upgrade on
```

Set Command Completion

By default, you can press the spacebar or tab key to have the CLI complete a command.

To have the CLI allow only a tab to complete a command, use the `set cli complete-on-space off` command:

```
user@host> set cli complete-on-space off  
Disabling complete-on-space  
user@host>
```

To re-enable the use of both spaces and tabs for command completion, use the `set cli complete-on-space on` command:

```
user@host> set cli complete-on-space on  
Enabling complete-on-space  
user@host>
```

Display CLI Settings

To display the current CLI settings, use the `show cli` command:

```
user@host> show cli  
CLI screen length set to 24  
CLI screen width set to 80  
CLI complete-on-space set to on
```

Example: Control the CLI Environment

Change the default CLI environment:

```
user@host> set cli screen-length 66  
Screen length set to 66  
user@host> set cli screen-width 40  
Screen width set to 40  
user@host> set cli prompt "router1-san-jose > "  
router1-san-jose > show cli  
CLI complete-on-space set to on  
CLI idle-timeout disabled  
CLI restart-on-upgrade set to on  
CLI screen length set to 66  
CLI screen width set to 40  
CLI terminal is 'xterm'  
router1-san-jose >
```