

port-mode

Syntax	port-mode <i>mode</i> ;
Hierarchy Level	[edit interfaces <i>ge-chassis/slot/port</i> unit <i>logical-unit-number</i> family mpls ethernet-switching]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches.
Description	Configure whether an interface on the switch operates in access or trunk mode.
Default	All switch interfaces are in access mode.
Options	<p>access—Have the interface operate in access mode. In this mode, the interface can be in a single VLAN only. Access interfaces typically connect to network devices such as PCs, printers, IP telephones, and IP cameras.</p> <p>trunk—Have the interface operate in trunk mode. In this mode, the interface can be in multiple VLANs and can multiplex traffic between different VLANs. Trunk interfaces typically connect to other switches and to routers on the LAN.</p>
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Configuring Gigabit Ethernet Interfaces (CLI Procedure)■ Configuring Gigabit Ethernet Interfaces (J-Web Procedure)■ <i>JUNOS Software Network Interfaces Configuration Guide</i> at http://www.juniper.net/techpubs/software/junos/junos90/index.html■ Example: Connecting an Access Switch to a Distribution Switch

