

Monitoring CoS Rewrite Rules

Purpose Use the monitoring functionality to display information about CoS value rewrite rules, which are based on the forwarding class and loss priority.

Action To monitor CoS rewrite rules in the J-Web interface, select **Monitor > Class of Service > Rewrite Rules**.

To monitor CoS rewrite rules in the CLI, enter the following command:

```
show class-of-service rewrite-rules
```

Meaning Table 1 summarizes key output fields for CoS rewrite rules.

Table 1: Summary of Key CoS Rewrite Rules Output Fields

Field	Values	Additional Information
Rewrite Rule Name	Names of rewrite rules.	
CoS Value Type	Rewrite rule type: <ul style="list-style-type: none">■ dscp—For IPv4 DiffServ traffic.■ ieee-802.1—For Layer 2 traffic.■ inet-precedence—For IPv4 traffic.	To display forwarding classes, loss priorities, and rewritten CoS values, click the plus sign (+).
Index	Internal index for this particular rewrite rule.	
Forwarding Class	Forwarding class that is used to determine CoS values for rewriting in combination with loss priority.	Rewrite rules are applied to CoS values in outgoing packets based on forwarding class and loss priority setting.
Loss Priority	Loss priority that is used to determine CoS values for rewriting in combination with forwarding class.	
Rewrite CoS Value To	Value that the CoS value is rewritten to.	

- Related Topics**
- Defining CoS Rewrite Rules (CLI Procedure)
 - Defining CoS Rewrite Rules (J-Web Procedure)
 - Example: Configuring CoS on EX-series Switches

