

Configuring T1 Data Inversion

By default, data inversion is disabled. To enable data inversion at the HDLC level, include the `invert-data` statement at the `[edit interfaces interface-name t1-options]` hierarchy level:

```
[edit interfaces interface-name t1-options]
invert-data;
```

When you enable data inversion, all data bits in the data stream are transmitted inverted; that is, zeroes are transmitted as ones and ones as zeroes. Data inversion is normally used only in AMI mode to guarantee ones density in the transmitted stream.

