

routing-instance-name

Syntax routing-instance-name;

Hierarchy Level [edit forwarding-options dhcp-relay authentication username-include],
[edit forwarding-options dhcp-relay group *group-name* authentication username-include],
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay authentication username-include],
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay group *group-name* authentication username-include],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* forwarding-options dhcp-relay authentication username-include],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* forwarding-options dhcp-relay group *group-name* authentication username-include],
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay authentication username-include],
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay group *group-name* authentication username-include]

Release Information Statement introduced in JUNOS Release 9.1.

Description Specify that the routing instance name is concatenated with the username during the subscriber authentication process. No routing instance name is concatenated if the configuration is in the default routing instance.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics ■ Using External AAA Authentication Services with DHCP

Published: 2009-07-16