

## Chapter 14

# Configuring System Time on C-Series Controllers with the SRC CLI

This chapter discusses how to configure the system time zone and the system date from the CLI on a C-series Controller. Topics include:

- Setting the Time Zone with the SRC CLI on page 111
- *Setting the System Date with the SRC CLI* on page 112

## Setting the Time Zone with the SRC CLI

---

You can set the time zone on a Solaris platform or on a C-series Controller with the SRC CLI. Use one of the following formats:

- (Recommended) Continent or nation with major city or province.

To see a list of entries in this format, use the ? help at the CLI:

```
[edit system]
user@host# set time-zone ?
Possible completions:
  Africa/Abidjan
  Africa/Accra
  Africa/Addis_Ababa
  Africa/Algiers
  Africa/Asmera
  Africa/Bamako
  Africa/Bangui
  Africa/Banjul
  . . .
```

- GMT offset to set the time zone relative to UTC (GMT) time in the format `/Etc/GMToffset`. Time zone files are stored in the `/Etc` directory.
- A common zone such as UTC, MDT, or EST.

To modify the local time zone:

1. In configuration mode at the [edit system] hierarchy level, set the time zone.

```
[edit system]
user@host# set time-zone time-zone
```

For example, to set the time zone for New York:

```
[edit system]
user@host# set system time-zone America/New_York
```

2. Verify the configuration. For example:

```
[edit system]
user@host# show
time-zone America/New_York;
```

3. For the time zone change to take effect for all processes running on the system, reboot the system.

## Related Topics

- *Setting the System Date with the SRC CLI* on page 112
- *NTP Support on C-series Controllers* on page 113

## Setting the System Date with the SRC CLI

---

If you need to set the date and time on the system and NTP is not configured, you can use the **set date** command. This command is available only if NTP is not running on the system.

To set the system date and time:

- In operational mode, set the date and time in the format YYYYMMDDhhmm.ss.

```
user@host> set date date
```

For example, to set the date and time to 1:05 PM on February 21, 2007:

```
user@host> set date 200702211305:00
```

## Related Topics

- *Setting the Time Zone with the SRC CLI* on page 111
- *NTP Support on C-series Controllers* on page 113