



SRC-PE Software

CLI Command Reference, Volume 2

Release 3.0.x

Juniper Networks, Inc.

1194 North Mathilda Avenue
Sunnyvale, CA 94089

USA

408-745-2000

www.juniper.net

Part Number: 530-026636-01, Revision 01

This product includes the following software: Fontconfig, X FreeType library, X Render extension headers, and X Render extension library, copyright © 2001, 2003 Keith Packard.

Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of Keith Packard not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission. Keith Packard makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

KEITH PACKARD DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL KEITH PACKARD BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Juniper Networks, the Juniper Networks logo, JUNOS, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. JUNOS is a trademark of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

SRC-PE Software CLI Command Reference, Volume 2
Release 3.0.x
Copyright © 2008, Juniper Networks, Inc.
All rights reserved. Printed in USA.

Writing: Linda Creed, Justine Kangas, Betty Lew
Editing: Fran Mues
Cover Design: Edmonds Design

Revision History
15 August 2008—Revision 1

The information in this document is current as of the date listed in the revision history.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. The JUNOS software has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

SOFTWARE LICENSE

The terms and conditions for using this software are described in the software license contained in the acknowledgment to your purchase order or, to the extent applicable, to any reseller agreement or end-user purchase agreement executed between you and Juniper Networks. By using this software, you indicate that you understand and agree to be bound by those terms and conditions.

Generally speaking, the software license restricts the manner in which you are permitted to use the software and may contain prohibitions against certain uses. The software license may state conditions under which the license is automatically terminated. You should consult the license for further details.

For complete product documentation, please see the Juniper Networks Web site at www.juniper.net/techpubs.

END USER LICENSE AGREEMENT

READ THIS END USER LICENSE AGREEMENT ("AGREEMENT") BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE. BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. The Parties. The parties to this Agreement are Juniper Networks, Inc. and its subsidiaries (collectively "Juniper"), and the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software ("Customer") (collectively, the "Parties").

2. The Software. In this Agreement, "Software" means the program modules and features of the Juniper or Juniper-supplied software, and updates and releases of such software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller. "Embedded Software" means Software which Juniper has embedded in the Juniper equipment.

3. License Grant. Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

- a. Customer shall use the Embedded Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller.
- b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees; provided, however, with respect to the Steel-Belted Radius or Odyssey Access Client software only, Customer shall use such Software on a single computer containing a single physical random access memory space and containing any number of processors. Use of the Steel-Belted Radius software on multiple computers requires multiple licenses, regardless of whether such computers are physically contained on a single chassis.

- c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer's use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, realms, devices, links, ports or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. In addition, such limits may restrict the use of the Software to managing certain kinds of networks or require the Software to be used only in conjunction with other specific Software. Customer's use of the Software shall be subject to all such limitations and purchase of all applicable licenses.
- d. For any trial copy of the Software, Customer's right to use the Software expires 30 days after download, installation or use of the Software. Customer may operate the Software after the 30-day trial period only if Customer pays for a license to do so. Customer may not extend or create an additional trial period by re-installing the Software after the 30-day trial period.
- e. The Global Enterprise Edition of the Steel-Belted Radius software may be used by Customer only to manage access to Customer's enterprise network. Specifically, service provider customers are expressly prohibited from using the Global Enterprise Edition of the Steel-Belted Radius software to support any commercial network access services.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. Use Prohibitions. Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any 'locked' or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use the Embedded Software on non-Juniper equipment; (j) use the Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. Audit. Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. Confidentiality. The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. Ownership. Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. Warranty, Limitation of Liability, Disclaimer of Warranty. The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. Termination. Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. Taxes. All license fees for the Software are exclusive of taxes, withholdings, duties, or levies (collectively "Taxes"). Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software.

11. Export. Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. Commercial Computer Software. The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14(ALT III) as applicable.

13. Interface Information. To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. Third Party Software. Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License

("GPL") or the GNU Library General Public License ("LGPL")). Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. Miscellaneous. This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).

About This Guide

- SRC Guides and Release Notes on page v
- Audience on page v
- Documentation Conventions on page v
- Related Juniper Networks Documentation on page vii
- Obtaining Documentation on page ix
- Documentation Feedback on page ix
- Requesting Technical Support on page ix

SRC Guides and Release Notes

If the information in the latest *SRC Release Notes* differs from the information in the SRC guides, follow the *SRC Release Notes*.

Audience

This guide is intended for experienced system and network specialists working with JUNOS routers and JUNOS routing platforms in an Internet access environment. We assume that readers know how to use the routing platforms, directories, and RADIUS servers that they will deploy in their SRC networks.

If you are using the SRC software in a cable network environment, we assume that you are familiar with the PacketCable Multimedia Specification (PCMM) as defined by Cable Television Laboratories, Inc. (CableLabs) and with the Data-over-Cable Service Interface Specifications (DOCSIS) 1.1 protocol. We also assume that you are familiar with operating a multiple service operator (MSO) multimedia-managed IP network.

Documentation Conventions

Table 1 on page xviii defines the notice icons used in this guide. Table 2 on page xviii defines text conventions used throughout this documentation.

Table 1: Notice Icons





Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2: Text Conventions

Convention	Description	Examples
Bold text like this	<ul style="list-style-type: none"> ■ Represents keywords, scripts, and tools in text. ■ Represents a GUI element that the user selects, clicks, checks, or clears. 	<ul style="list-style-type: none"> ■ Specify the keyword exp-msg. ■ Run the install.sh script. ■ Use the pkgadd tool. ■ To cancel the configuration, click Cancel.
Bold text like this	Represents text that the user must type.	<code>user@host# set cache-entry-age cache-entry-age</code>
Fixed-width text like this	Represents information as displayed on your terminal's screen, such as CLI commands in output displays.	<pre>nic-locators { login { resolution { resolver-name /realms/ login/A1; key-type LoginName; value-type SaeId; } } }</pre>
Regular sans serif typeface	<ul style="list-style-type: none"> ■ Represents configuration statements. ■ Indicates SRC CLI commands and options in text. ■ Represents examples in procedures. ■ Represents URLs. 	<ul style="list-style-type: none"> ■ <code>system ldap server{ stand-alone;</code> ■ Use the <code>request sae modify device failover</code> command with the <code>force</code> option ■ <code>user@host# . . .</code> ■ <code>http://www.juniper.net/techpubs/software/management/src/api-index.html</code>
<i>Italic sans serif typeface</i>	Represents variables in SRC CLI commands.	<code>user@host# set local-address local-address</code>
Angle brackets	In text descriptions, indicate optional keywords or variables.	Another runtime variable is <code>< gfwif ></code> .
Key name	Indicates the name of a key on the keyboard.	Press Enter.

Table 2: Text Conventions (*continued*)

Key names linked with a plus sign (+)	Indicates that you must press two or more keys simultaneously.	Press Ctrl + b.
<i>Italic typeface</i>	<ul style="list-style-type: none"> ■ Emphasizes words. ■ Identifies book names. ■ Identifies distinguished names. ■ Identifies files, directories, and paths in text but not in command examples. 	<ul style="list-style-type: none"> ■ There are two levels of access: <i>user</i> and <i>privileged</i>. ■ <i>SRC-PE Getting Started Guide</i> ■ <i>o = Users, o = UMC</i> ■ The <i>/etc/default.properties</i> file.
Backslash	At the end of a line, indicates that the text wraps to the next line.	Plugin.radiusAcct-1.class = \net.juniper.srmt.sae.plugin\RADIUSTrackingPluginEvent
Words separated by the symbol	Represent a choice to select one keyword or variable to the left or right of this symbol. (The keyword or variable may be either optional or required.)	diagnostic line

Related Juniper Networks Documentation

With each SRC software release, we provide the *SRC Documentation CD*, which contains the documentation described in Table 3 on page xix.

A complete list of abbreviations used in this document set, along with their spelled-out terms, is provided in the *SRC —PE Getting Started Guide*.

Table 3: Juniper Networks C-series and SRC Technical Publications

Document	Description
Core Documentation Set	
<i>C2000 and C4000 Hardware Guide</i>	Describes the hardware platforms and how to install, maintain, replace, and troubleshoot them. The guide also includes specifications.
<i>C2000 and C4000 Quick Start Guide</i>	Describes how to get the C-series Controller up and running quickly. Intended for experienced installers who want to expedite the installation process.
<i>SRC-PE Getting Started Guide</i>	Describes the SRC software, how to set up an initial software configuration, how to integrate RADIUS servers, and how to upgrade the SRC software. It also explains how to manage a C-series Controller. The guide describes how to set up and start the SRC CLI and the C-Web interface, as well as other SRC configuration tools. It includes reference material for the SRC documentation.
<i>SRC-PE CLI User Guide</i>	Describes how to use the SRC CLI, configure and monitor the platform with the CLI, and control the CLI environment. The guide also describes how to manage SRC components with the CLI.

Table 3: Juniper Networks C-series and SRC Technical Publications *(continued)*

Document	Description
<i>SRC-PE Network Guide: SAE, Juniper Networks Routers, NIC, and SRC-ACP</i>	Describes how to use and configure the SAE, the NIC, and the SRC-ACP (Admission Control Plug-In) application. This guide also provides detailed information about using JUNOSe routers, JUNOS routing platforms, and other network devices in the SRC network.
<i>SRC-PE Services and Policies Guide</i>	Describes how to work with services and policies. The guide provides an overview, configuration procedures, and management information. The guide also provides information about the SRC tools for configuring policies.
<i>SRC-PE Subscribers and Subscriptions Guide</i>	Describes how to work with residential and enterprise subscribers and subscriptions. The guide provides an overview, configuration procedures, and management information. This guide also provides information about the enterprise service portals, including the Enterprise Manager Portal.
<i>SRC-PE Monitoring and Troubleshooting Guide</i>	Describes how to use logging, the SNMP agent, the SRC CLI, and the C-Web interface to monitor and troubleshoot SRC components. This guide also describes the SNMP traps.
<i>SRC-PE Solutions Guide</i>	Provides high-level instructions for SRC implementations. The guide documents the following scenarios: managing QoS services on JUNOSe routers; managing subscribers in a wireless roaming environment; providing voice over IP (VoIP) services; integrating the SRC software in a PCMM environment, including the use of the Juniper Policy Server (JPS); and mirroring subscriber traffic on JUNOSe routers.
<i>SRC-PE CLI Command Reference, Volume 1</i> <i>SRC-PE CLI Command Reference, Volume 2</i>	Together constitute information about command and statement syntax; descriptions of commands, configuration statements, and options; editing level of statement options; and a history of when a command was added to the documentation.
<i>SRC-PE NETCONF API Guide</i>	Describes how to use the NETCONF application programming interface (API) to configure or request information from the NETCONF server on a C-series Controller that runs the SRC software.
<i>SRC-PE XML API Configuration Reference</i>	Describes the tag elements in the SRC Extensible Markup Language (XML) application programming interface (API) that are equivalent to configuration statements in the SRC command-line interface (SRC CLI).
<i>SRC-PE XML API Operational Reference</i>	Describes the tag elements in the SRC Extensible Markup Language (XML) application programming interface (API) that are equivalent to operational commands in the SRC command-line interface (SRC CLI).
Application Library	
<i>SRC Application Library Guide</i>	Describes how to install and work with applications that you can use to extend the capabilities of the SRC software. The guide documents the following applications: SRC-SG (SOAP Gateway) Web applications, an application to provide threat mitigation, an application to provide tracking and QoS control at the application level by integrating the SRC software with the Ellacoya deep packet inspection (DPI) platform, and an application to control volume usage .
Release Notes	

Table 3: Juniper Networks C-series and SRC Technical Publications *(continued)*

Document	Description
<i>SRC-PE Release Notes</i>	In the <i>Release Notes</i> , you will find the latest information about features, changes, known problems, resolved problems, supported platforms and network devices (such as Juniper Networks routers and CMTS devices), and third-party software. If the information in the <i>Release Notes</i> differs from the information found in the documentation set, follow the <i>Release Notes</i> .
<i>SRC Application Library Release Notes</i>	
Release notes are available on the Web.	

Obtaining Documentation

To obtain the most current version of all Juniper Networks technical documentation, see the products documentation page on the Juniper Networks Web site at <http://www.juniper.net/>.

To order a documentation CD, which contains this guide, contact your sales representative.

Copies of the Management Information Bases (MIBs) available in a software release are included on the documentation CDs and at <http://www.juniper.net/>.

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at <http://www.juniper.net/techpubs/docbug/docbugreport.html>. If you are using e-mail, be sure to include the following information with your comments:

- Document name
- Document part number
- Page number
- Software release version (not required for *Network Operations Guides [NOGs]*)

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the JTAC User Guide located at <http://www.juniper.net/customers/support/downloads/710059.pdf>.

- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC Hours of Operation —The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum: <http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Manager: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool located at <https://tools.juniper.net/SerialNumberEntitlementSearch/>.

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Manager tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

SRC CLI

This document summarizes the SRC command-line interface (SRC CLI).

Configuration statements and operational commands are listed in alphabetical order for the following components in the *SRC-PE CLI Command Reference, Volume 1*:

- CLI and System
- Juniper Networks Database
- SAE
- Network Information Collector (NIC)
- SNMP Agent
- Juniper Policy Server (JPS)

Configuration statements and operational commands are listed in alphabetical order for the following components in the *SRC-PE CLI Command Reference, Volume 2*:

- Service CLI
- Policy CLI
- Subscriber CLI
- Redirect Server
- External Subscriber Monitor
- SRC Admission Control Plug-In (SRC-ACP)
- Dynamic Service Activator
- DIAMETER Application

Service CLI

The following table summarizes the SRC command-line interface (SRC CLI) for configuring services. Configuration statements are listed in alphabetical order.

Service CLI Configuration Statements
services global mutex-group
services global schedule
services global schedule name event
services global schedule name event name action
services global schedule name event name action name attribute
services global schedule name event name except
services global schedule name event name except name from
services global schedule name event name except name to
services global schedule name event name from
services global schedule name event name to
services global service
services global service name admission-control
services global service name admission-control congestion-point-classification
services global service name aggregate fragment
services global service name parameter
services global service name script
services scope
services scope name mutex-group
services scope name schedule
services scope name schedule name event
services scope name schedule name event name action

<u>services scope name schedule name event name action name attribute</u>
<u>services scope name schedule name event name except</u>
<u>services scope name schedule name event name except name from</u>
<u>services scope name schedule name event name except name to</u>
<u>services scope name schedule name event name from</u>
<u>services scope name schedule name event name to</u>
<u>services scope name service</u>
<u>services scope name service name admission-control</u>
<u>services scope name service name admission-control congestion-point-classification</u>
<u>services scope name service name aggregate fragment</u>
<u>services scope name service name parameter</u>
<u>services scope name service name script</u>

services global mutex-group

Syntax

```
services global mutex-group name {
    auto-deactivate (yes | no);
    description description;
    services [services...];
}
```

Hierarchy Level

```
[edit services global mutex-group]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a mutex group. A mutex group is a collection of services that are mutually exclusive—services that the SAE cannot simultaneously activate for a particular subscriber.

Options

name *name*— Name of the mutex group.

Value— Text

auto-deactivate (yes | no)— Specify whether to allow activation of a service if another service is already active.

Value

- *yes*— For any one subscriber, the SAE deactivates a service in the group before activating another service in the group.
- *no*— The SAE refuses access to a requested service if the subscriber is already using another service in this group.

Default— Yes

Editing Level—Basic

`description` *description*—(Optional) Description of the mutex group.

Value— Text

Default— No value

Editing Level—Basic

`services` [*services...*]—(Optional) List of services in the mutex group.

Value— List of services

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule

Syntax

```
services global schedule name {
    description description;
}
```

Hierarchy Level

```
[edit services global schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

`name name`— Name of service schedule.

Value—Text

`description description`—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event

Syntax

```
services global schedule name event name ...
```

Hierarchy Level

```
[edit services global schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name name— Name of the scheduling event.

Value—Text

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* action

Syntax

```
services global schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit services global schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.
- *deny-deactivate*— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to

services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution. . .]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* action *name* attribute

Syntax

```
services global schedule name event name action name attribute (sessionName |
sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit services global schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* except

Syntax

```
services global schedule name event name except name ...
```

Hierarchy Level

```
[edit services global schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name *name*— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* except *name* from

Syntax

```
services global schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services global schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* except *name* to

Syntax

```
services global schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services global schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+|-) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* from

Syntax

```
services global schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services global schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE

- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *
Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global schedule *name* event *name* to

Syntax

```
services global schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services global schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23
Default— *
Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31
Default— *
Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global service

Syntax

```
services global service name {
    description description;
    type (normal | aggregate | script | infrastructure);
    category category;
    url url;
    policy-group policy-group;
    authentication-required;
    authorization-plug-in [authorization-plug-in...];
    tracking-plug-in [tracking-plug-in...];
    session-timeout session-timeout;
    idle-timeout idle-timeout;
    accounting-interim-interval accounting-interim-interval;
    radius-class radius-class;
    status (inactive | active);
    activate-only;
    permanent;
    available;
    secret;
    shared-service-name shared-service-name;
}
```

Hierarchy Level

```
[edit services global service]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service.

Options

name *name*— Name of the service.

Value— Text

description *description*—(Optional) Description of the service.

Value— Text

Default— No value

Editing Level—Basic

`type (normal | aggregate | script | infrastructure)`— Type of service.

Value

- `normal`— Individual service that a subscriber activates and deactivates. A normal service provisions a set of policies when activated.
- `aggregate`— Group of services that a subscriber activates and deactivates as a unit. An aggregate service contains other services (called fragments) that are managed by the aggregate service. The aggregate service is responsible for activating, deactivating, and monitoring the fragments.
- `script`— Service into which you insert or reference a script. You can use the script to manage third-party devices, provision layer 2 devices, such as DSLAMs, or set up network connections such as MPLS tunnels.
- `infrastructure`— Service that can be provisioned only once and then activated a number of times across network devices.

Default— Normal

Editing Level—Basic

`category category`—(Optional) The service category is not used by SRC directly. You can use it, for example, to group related services in an SRC application such as a portal. For example, in the residential portal, it is the text that appears in the set of tabs that categorize services.

Value— Text

Default— No value

Editing Level—Basic

`url url`—(Optional) The service URL is not used by SRC directly. You can use it in applications such as a portal to provide a link to a service provider or to the Web page that a subscriber sees after activating a service.

Value— URL

Default— No value

Editing Level—Basic

`policy-group policy-group`—(Optional) Policy group that is applied when the service is activated. The policy engine does not allow the activation of a normal service without an associated policy group.

Value— Policy group

Default— No value

Editing Level—Basic

`authentication-required`—(Optional) Determines whether activation of the service requires authentication with a username and password that are specific to this service. The service authentication-required flag is not used by the SRC software directly. You can use it, for example, to request a name and password when the service is activated by an SRC application such as a portal.

Default— Disabled

Editing Level—Basic

`authorization-plug-in [authorization-plug-in...]`—(Optional) Name of the plug-ins that authorize this service. The authorization plug-ins are called when the service is activated.

Value— Single authorization plug-in or a list of authorization plug-ins.

Default— No value

Editing Level—Basic

`tracking-plug-in [tracking-plug-in...]`—(Optional) Name of the plug-ins that track this service. The tracking plug-ins are called when a service is activated and deactivated, as well as for interim updates.

Value— Single tracking plug-in or a list of tracking plug-ins.

Default— No value

Editing Level—Basic

`session-timeout session-timeout`—(Optional) Time after which the service session is deactivated.

Changes to the session timeout take effect immediately if the new value is lower than the remaining time for a session or if you specify that no session timeout applies. Other changes apply only to services that are activated after you make the change.

The session timeout can also be controlled dynamically for each service session by a plug-in.

Value— Number of seconds in the range 0–2147483647

Default— No value

Editing Level—Basic

`idle-timeout` *idle-timeout*—(Optional) Idle time after which the SAE deactivates service. To decide whether a service is idle, the SAE collects accounting information for the service, which means that the service activation policy must specify an accounting rule. The idle timeout is the minimum time the service must be idle before it is deactivated. A service is considered idle if the volume accounting data does not change between interim updates. The actual deactivation time depends on the length of the accounting interval.

The idle timeout can also be dynamically updated per service session by an authorization plug-in.

Value— Number of seconds in the range 0–2147483647

Default— No value

Editing Level—Basic

`accounting-interim-interval` *accounting-interim-interval*—(Optional) Time between interim accounting messages for this service. The accounting interim interval can also be controlled dynamically for each service session by a plug-in.

Value— Number of seconds in the range 0–2147483647. Setting the value to 0 turns off interim accounting.

Default— No value

Editing Level—Basic

`radius-class` *radius-class*—(Optional) Default value used in the RADIUS class attribute in RADIUS accounting messages. If RADIUS authenticates the service session, the class attribute received in the RADIUS Access-Accept response from the server overrides this value. You can use this option to set the RADIUS attribute to 25.

The RADIUS class can also be dynamically for each service session by a plug-in.

Value— Text

Default— Name of the service

Editing Level—Basic

`status` (`inactive` | `active`)—(Optional) Status of the service.

Value

- `inactive`— Service does not accept new subscriptions.
- `active`— Service accepts new subscriptions.

Default— `active`

Editing Level—Basic

`activate-only`—(Optional) A service that is marked activate only cannot be directly deactivated. It can be deactivated indirectly through a mutex group or a session timeout.

Default— Disabled

Editing Level—Basic

`permanent`—(Optional) Specifies whether the SAE maintains permanent activation of this service for a subscriber. A service that is marked as permanent is automatically activated as soon as a subscriber subscribes to it.

Default— Disabled

Editing Level—Basic

`available`—(Optional) Specifies whether a subscriber can activate a service. To be activated, the service must be available in the currently selected scope.

Default— Enabled

Editing Level—Basic

`secret`—(Optional) Secret services are visible only to administrators who have permission to see secret information. You can use this flag to hide services from subscribers and unprivileged administrators.

Editing Level—Basic

`shared-service-name` *shared-service-name*—(Optional) For infrastructure services, the name of the service to be shared.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global service *name* admission-control

Syntax

```
services global service name admission-control {
    required-downstream-bandwidth required-downstream-bandwidth;
    required-upstream-bandwidth required-upstream-bandwidth;
    congestion-points [congestion-points...];
}
```

Hierarchy Level

```
[edit services global service name admission-control]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure upstream and downstream bandwidths for services that ACP manages.

Options

required-downstream-bandwidth required-downstream-bandwidth—
(Optional) Downstream bandwidth to the subscriber required for the service.

Value— Number of bps

Default— No value

Editing Level—Basic

required-upstream-bandwidth required-upstream-bandwidth—(Optional)
Upstream bandwidth from the subscriber required for the service.

Value— Number of bps

Default— No value

Editing Level—Basic

congestion-points [congestion-points...]—(Optional) Congestion points for this service.

Value—

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global service *name* admission-control congestion-point-classification

Syntax

```
services global service name admission-control congestion-point-classification
{
    script script;
    expression [expression...];
}
```

Hierarchy Level

```
[edit services global service name admission-control congestion-point-
classification]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Congestion point classification for this service. It overrides expressions defined with congestion-point attribute.

Options

`script script`—(Optional) Congestion point classification script in python. Functions or variables defined in the script can be referred in congestion point classification expressions.

Value—Multi-line text

Editing Level—Basic

`expression [expression...]`—Congestion point classification expressions for this service.

Value—

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global service *name* aggregate fragment

Syntax

```
services global service name aggregate fragment name {
    expression expression;
    service service;
    mandatory;
    redundancy-group redundancy-group;
    subscription-required;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit services global service name aggregate fragment]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure service fragments for an aggregate service.

Options

name name— Name for service fragment. The fragment name is not stored and is re-created every time the object is read.

Value— Text

expression expression— Subscriber reference expression that identifies the remote subscriber session that will host the fragment. The remote subscriber session is an assigned IP subscriber. If the remote SAE manages the specified interface, the SAE creates an assigned IP subscriber session if necessary.

Value— Valid expressions are:

- current
- address = "A.B.C.D"
- vr = "vrName", interfaceName = "ifName"
- vr = "vrName", interfaceName = "ifName", address = "A.B.C.D"
- vr = "vrName", ifIndex = "1234"

- `vr = "vrName",login_name = "user@domain"`
- `vr = "vrName",primary_user_name = "user@domain"`
- `dn = "uniqueId = ..."`
- `login_name = "user@domain"`
- `primary_user_name = "user@domain"`
- `ref = "rdn/rdn"`

The `rdn/rdn` identifies the hierarchy of directory objects below the LDAP object `o= aggregateService`. The final object contains the attribute `subscriberRefExpr` to identify the subscriber session. A forward slash (/) separates the objects in the path.

You can also use a substitution or a Python expression that represents any of the literal values listed above. For a substitution or Python expression, type `< -` before the expression and type `- >` after it; for example, `< -ifAlias- >`. For a list and description of the fields that you can use to compose Python expressions, see *Managing Services for the SRC CLI* in the *SRC-PE Services and Policies Guide*.

Examples of valid expressions are:

- `current`
- `address = "10.10.10.1"`
- `vr = "< -substitution.serviceVr- > ",interfaceName = "< -substitution.serviceInterface- > "`
- `dn = "uniqueId = < -ifAlias- > , < -userDn- > "`
- `vr = < -["vr1","vr2"]- > ,loginName = < -["joe@abc","jane@abc"]- > .`

When you include lists, fragment services are created for all combinations of values in the list. For example, `vr = < -["vr1","vr2"]- > , loginName = < -["joe@abc","jane@abc"]- >` would cause four fragments to be created with the following expressions:

- `vr = "vr1",loginName = "joe@abc"`
- `vr = "vr1",loginName = "jane@abc"`
- `vr = "vr2",loginName = "joe@abc"`
- `vr = "vr2",loginName = "jane@abc"`

Default— No value

Editing Level—Basic

`service service`— Name of the service to be included in the aggregate service as a fragment service.

Value— Name of a service

Default— No value

Editing Level—Basic

mandatory—(Optional) Specifies whether the fragment service must be active for the aggregate service to become active.

Default— Mandatory

Editing Level—Basic

redundancy-group *redundancy-group*—(Optional) Group name to be applied to each fragment service that is to be part of a redundancy group. The fragment services that have the same group name provide redundancy for each other.

Value— Text

Default— No value

Editing Level—Basic

subscription-required—(Optional) Specifies whether a remote subscriber session must be subscribed to the fragment service for it to become active.

Enabling **subscription-required** can be used to limit the services that can be activated as fragments. Enabling this option lets you control which services can be used as fragments. For example, for an aggregate service that supports VoIP to push a policy to the caller and the callee, you can require that both subscribers sign up for VoIP services. If you disable the option, only one party needs to subscribe to the aggregate service; the policy service sessions are created automatically.

Default— Disabled

Editing Level—Basic

substitution [*substitution...*]—(Optional) List of substitutions that are used as arguments for the fragment to become active. If a parameter does not acquire a value, the associated fragment service does not become active.

Value— One or more of the following:

- **< parameter-name >** —The parameter name is defined to have the same value in the fragment service session as in the aggregate service session.
- **< parameter-name > = < substitution-expression >** —The parameter name on the left side of the equals sign is defined for the fragment service session. This parameter name is the result of the evaluation of the expression (in the aggregate service session) on the right side of the equals sign.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global service *name* parameter

Syntax

```
services global service name parameter {
    gateway-ip-address gateway-ip-address;
    service-ip-address service-ip-address;
    service-ip-mask service-ip-mask;
    service-port service-port;
    substitution [substitution...];
    session-volume-quota session-volume-quota;
}
```

Hierarchy Level

```
[edit services global service name parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure parameter values for services. The policy engine substitutes parameters in policies associated with this service with the values that you specify in this parameter configuration.

Options

`gateway-ip-address gateway-ip-address`—(Optional) Actual IP address of the gateway router. This value is substituted for the policy global parameter called `gateway_ipAddress`.

Value— IP address

Default— No value

Editing Level—Basic

`service-ip-address service-ip-address`—(Optional) Actual IP address of the host(s) that provides the service. This value is substituted for the policy global parameter called `service_ipAddress`.

Value— IP address

Default— No value

Editing Level—Basic

`service-ip-mask` *service-ip-mask*—(Optional) Actual IP mask for the service. This value is substituted for the policy global parameter called `service_ipMask`.

Value— IP address

Default— No value

Editing Level—Basic

`service-port` *service-port*—(Optional) Actual port for the service. This value is substituted for the policy global parameter called `service_port`.

Value— TCP or UDP port number in the range 0–65535

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for other parameters. These values are substituted for the parameters that you specify.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

`session-volume-quota` *session-volume-quota*—(Optional) Upstream and downstream volume quota for the service session.

The SAE does not directly use this value. It is used by applications that implement tracking plug-ins. The value of a service session can be defined at runtime either through an authorization plug-in or a call to the SAE API. If the Session Volume Quota attribute is defined in more than one place, which value is used depends on where the value is defined. The SRC software searches for the value in the following order:

1. Value set in a call to the SAE
2. Value set in an authorization plug-in
3. Value set in a service definition

Value— Volume quota in the format "downstream-quota:upstream-quota"

where

- Downstream quota is the number of bytes available for transmitting data from the network to the subscriber.
- Upstream quota is the number of bytes available for transmitting data from the subscriber to the network.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services global service *name* script

Syntax

```
services global service name script {
    script-type (url | python | java-class | java-archive);
    class-name class-name;
    file file;
    filename filename;
}
```

Hierarchy Level

```
[edit services global service name script]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the script service.

Options

`script-type (url | python | java-class | java-archive)`— Type of script service. Determines how the contents of the "file" attribute will be interpreted.

Value

- `url`— The value of attribute "file" is a URL that specifies where to find a Java archive (.jar file) containing the script service implementation.
- `python`— The value of attribute "file" is Python code.
- `java-class`— The value of attribute "file" is the binary contents of a compiled Java class file (.class file).
- `java-archive`— The value of attribute "file" is the binary contents of a Java archive file (.jar file).

Default— No value

Editing Level—Basic

`class-name` *class-name*— Name of the Java or Python class that implements the script service. The SAE instantiates the named class when it starts the script service.

Value— Name of the class

Default— No value

Editing Level—Basic

`file` *file*— If the script type is "URL", this attribute contains the URL of a Java archive (.jar) file containing the script service implementation. Otherwise, this attribute contains the script service implementation itself (i.e. python code, the binary contents of a compiled .class file, or the binary contents of a .jar file).

Value— The script itself, or a URL pointing to a .jar file containing the script

Default— No value

Editing Level—Basic

`filename` *filename*—(Optional) The file needs to exist locally. Its content will be read and loaded into the "file" attribute.

Value—Text

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope

Syntax

```
services scope name {
    precedence precedence;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit services scope]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service scope. Service scopes let you customize which services are delivered to specific organizations or locales.

Options

name *name*— Name of a service scope.

Value— Text

precedence *precedence*—(Optional) If multiple scopes are selected for the same subscriber session, they are sorted by their precedence level.

Value— Positive integer; the lower the precedence value, the higher the ranking of the service scope.

Default— No value

Editing Level—Basic

substitution [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form < parameter name > = < value > . For example, bandwidth = 1000000.

Default— No value
Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* mutex-group

Syntax

```
services scope name mutex-group name {
    auto-deactivate (yes | no);
    description description;
    services [services...];
}
```

Hierarchy Level

```
[edit services scope name mutex-group]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a mutex group. A mutex group is a collection of services that are mutually exclusive—services that the SAE cannot simultaneously activate for a particular subscriber.

Options

name *name*— Name of the mutex group.

Value— Text

auto-deactivate (yes | no)— Specify whether to allow activation of a service if another service is already active.

Value

- *yes*— For any one subscriber, the SAE deactivates a service in the group before activating another service in the group.
- *no*— The SAE refuses access to a requested service if the subscriber is already using another service in this group.

Default— Yes

Editing Level—Basic

`description` *description*—(Optional) Description of the mutex group.

Value— Text

Default— No value

Editing Level—Basic

`services` [*services...*]—(Optional) List of services in the mutex group.

Value— List of services

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule

Syntax

```
services scope name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit services scope name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event

Syntax

```
services scope name schedule name event name ...
```

Hierarchy Level

```
[edit services scope name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name*— Name of the scheduling event.

Value—Text

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* action

Syntax

```
services scope name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit services scope name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.
- *deny-deactivate*— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to

services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* action *name* attribute

Syntax

```
services scope name schedule name event name action name attribute (sessionName |
sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit services scope name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* except

Syntax

```
services scope name schedule name event name except name ...
```

Hierarchy Level

```
[edit services scope name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* except *name* from

Syntax

```
services scope name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services scope name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

`hour hour`—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute minute`—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month day-of-month`—(Optional) Day of the month in which to schedule the

event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* except *name* to

Syntax

```
services scope name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services scope name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* from

Syntax

```
services scope name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services scope name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE

- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* schedule *name* event *name* to

Syntax

```
services scope name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit services scope name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23
Default— *
Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31
Default— *
Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* service

Syntax

```
services scope name service name {
    description description;
    type (normal | aggregate | script | infrastructure);
    category category;
    url url;
    policy-group policy-group;
    authentication-required;
    authorization-plug-in [authorization-plug-in...];
    tracking-plug-in [tracking-plug-in...];
    session-timeout session-timeout;
    idle-timeout idle-timeout;
    accounting-interim-interval accounting-interim-interval;
    radius-class radius-class;
    status (inactive | active);
    activate-only;
    permanent;
    available;
    secret;
    shared-service-name shared-service-name;
}
```

Hierarchy Level

```
[edit services scope name service]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service.

Options

name *name*— Name of the service.

Value— Text

description *description*—(Optional) Description of the service.

Value— Text**Default**— No value**Editing Level**—Basic

`type (normal | aggregate | script | infrastructure)`— Type of service.

Value

- `normal`— Individual service that a subscriber activates and deactivates. A normal service provisions a set of policies when activated.
- `aggregate`— Group of services that a subscriber activates and deactivates as a unit. An aggregate service contains other services (called fragments) that are managed by the aggregate service. The aggregate service is responsible for activating, deactivating, and monitoring the fragments.
- `script`— Service into which you insert or reference a script. You can use the script to manage third-party devices, provision layer 2 devices, such as DSLAMs, or set up network connections such as MPLS tunnels.
- `infrastructure`— Service that can be provisioned only once and then activated a number of times across network devices.

Default— Normal**Editing Level**—Basic

`category category`—(Optional) The service category is not used by SRC directly. You can use it, for example, to group related services in an SRC application such as a portal. For example, in the residential portal, it is the text that appears in the set of tabs that categorize services.

Value— Text**Default**— No value**Editing Level**—Basic

`url url`—(Optional) The service URL is not used by SRC directly. You can use it in applications such as a portal to provide a link to a service provider or to the Web page that a subscriber sees after activating a service.

Value— URL**Default**— No value**Editing Level**—Basic

`policy-group` *policy-group*—(Optional) Policy group that is applied when the service is activated. The policy engine does not allow the activation of a normal service without an associated policy group.

Value— Policy group

Default— No value

Editing Level—Basic

`authentication-required`—(Optional) Determines whether activation of the service requires authentication with a username and password that are specific to this service. The service authentication-required flag is not used by the SRC software directly. You can use it, for example, to request a name and password when the service is activated by an SRC application such as a portal.

Default— Disabled

Editing Level—Basic

`authorization-plug-in` [*authorization-plug-in...*]—(Optional) Name of the plug-ins that authorize this service. The authorization plug-ins are called when the service is activated.

Value— Single authorization plug-in or a list of authorization plug-ins.

Default— No value

Editing Level—Basic

`tracking-plug-in` [*tracking-plug-in...*]—(Optional) Name of the plug-ins that track this service. The tracking plug-ins are called when a service is activated and deactivated, as well as for interim updates.

Value— Single tracking plug-in or a list of tracking plug-ins.

Default— No value

Editing Level—Basic

`session-timeout` *session-timeout*—(Optional) Time after which the service session is deactivated.

Changes to the session timeout take effect immediately if the new value is lower than the remaining time for a session or if you specify that no session timeout applies. Other changes apply only to services that are activated after you make the change.

The session timeout can also be controlled dynamically for each service session by a plug-in.

Value— Number of seconds in the range 0–2147483647

Default— No value

Editing Level—Basic

`idle-timeout` *idle-timeout*—(Optional) Idle time after which the SAE deactivates service. To decide whether a service is idle, the SAE collects accounting information for the service, which means that the service activation policy must specify an accounting rule. The idle timeout is the minimum time the service must be idle before it is deactivated. A service is considered idle if the volume accounting data does not change between interim updates. The actual deactivation time depends on the length of the accounting interval.

The idle timeout can also be dynamically updated per service session by an authorization plug-in.

Value— Number of seconds in the range 0–2147483647

Default— No value

Editing Level—Basic

`accounting-interim-interval` *accounting-interim-interval*—(Optional) Time between interim accounting messages for this service. The accounting interim interval can also be controlled dynamically for each service session by a plug-in.

Value— Number of seconds in the range 0–2147483647. Setting the value to 0 turns off interim accounting.

Default— No value

Editing Level—Basic

`radius-class` *radius-class*—(Optional) Default value used in the RADIUS class attribute in RADIUS accounting messages. If RADIUS authenticates the service session, the class attribute received in the RADIUS Access-Accept response from the server overrides this value. You can use this option to set the RADIUS attribute to 25.

The RADIUS class can also be dynamically for each service session by a plug-in.

Value— Text

Default— Name of the service

Editing Level—Basic

`status` (`inactive` | `active`)—(Optional) Status of the service.

Value

- `inactive`— Service does not accept new subscriptions.
- `active`— Service accepts new subscriptions.

Default— `active`

Editing Level—Basic

`activate-only`—(Optional) A service that is marked activate only cannot be directly deactivated. It can be deactivated indirectly through a mutex group or a session timeout.

Default— Disabled

Editing Level—Basic

`permanent`—(Optional) Specifies whether the SAE maintains permanent activation of this service for a subscriber. A service that is marked as permanent is automatically activated as soon as a subscriber subscribes to it.

Default— Disabled

Editing Level—Basic

`available`—(Optional) Specifies whether a subscriber can activate a service. To be activated, the service must be available in the currently selected scope.

Default— Enabled

Editing Level—Basic

`secret`—(Optional) Secret services are visible only to administrators who have permission to see secret information. You can use this flag to hide services from subscribers and unprivileged administrators.

Editing Level—Basic

`shared-service-name` *shared-service-name*—(Optional) For infrastructure services, the name of the service to be shared.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* service *name* admission-control

Syntax

```
services scope name service name admission-control {
    required-downstream-bandwidth required-downstream-bandwidth;
    required-upstream-bandwidth required-upstream-bandwidth;
    congestion-points [congestion-points...];
}
```

Hierarchy Level

```
[edit services scope name service name admission-control]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure upstream and downstream bandwidths for services that ACP manages.

Options

required-downstream-bandwidth required-downstream-bandwidth—
(Optional) Downstream bandwidth to the subscriber required for the service.

Value— Number of bps

Default— No value

Editing Level—Basic

required-upstream-bandwidth required-upstream-bandwidth—(Optional)
Upstream bandwidth from the subscriber required for the service.

Value— Number of bps

Default— No value

Editing Level—Basic

congestion-points [congestion-points...]—(Optional) Congestion points for
this service.

Value—

Default— No value
Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* service *name* admission-control congestion-point-classification

Syntax

```
services scope name service name admission-control congestion-point-
classification {
    script script;
    expression [expression...];
}
```

Hierarchy Level

```
[edit services scope name service name admission-control congestion-point-
classification]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Congestion point classification for this service. It overrides expressions defined with congestion-point attribute.

Options

`script script`—(Optional) Congestion point classification script in python. Functions or variables defined in the script can be referred in congestion point classification expressions.

Value—Multi-line text

Editing Level—Basic

`expression [expression...]`—Congestion point classification expressions for this service.

Value—

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* service *name* aggregate fragment

Syntax

```
services scope name service name aggregate fragment name {
    expression expression;
    service service;
    mandatory;
    redundancy-group redundancy-group;
    subscription-required;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit services scope name service name aggregate fragment]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure service fragments for an aggregate service.

Options

name name— Name for service fragment. The fragment name is not stored and is re-created every time the object is read.

Value— Text

expression expression— Subscriber reference expression that identifies the remote subscriber session that will host the fragment. The remote subscriber session is an assigned IP subscriber. If the remote SAE manages the specified interface, the SAE creates an assigned IP subscriber session if necessary.

Value— Valid expressions are:

- current
- address = "A.B.C.D"
- vr = "vrName", interfaceName = "ifName"
- vr = "vrName", interfaceName = "ifName", address = "A.B.C.D"
- vr = "vrName", ifIndex = "1234"

- `vr = "vrName",login_name = "user@domain"`
- `vr = "vrName",primary_user_name = "user@domain"`
- `dn = "uniqueId = ..."`
- `login_name = "user@domain"`
- `primary_user_name = "user@domain"`
- `ref = "rdn/rdn"`

The `rdn/rdn` identifies the hierarchy of directory objects below the LDAP object `o= aggregateService`. The final object contains the attribute `subscriberRefExpr` to identify the subscriber session. A forward slash (/) separates the objects in the path.

You can also use a substitution or a Python expression that represents any of the literal values listed above. For a substitution or Python expression, type `< -` before the expression and type `- >` after it; for example, `< -ifAlias- >`. For a list and description of the fields that you can use to compose Python expressions, see *Managing Services for the SRC CLI* in the *SRC-PE Services and Policies Guide*.

Examples of valid expressions are:

- `current`
- `address = "10.10.10.1"`
- `vr = "< -substitution.serviceVr- > ",interfaceName = "< -substitution.serviceInterface- > "`
- `dn = "uniqueId = < -ifAlias- > , < -userDn- > "`
- `vr = < -["vr1","vr2"]- > ,loginName = < -["joe@abc","jane@abc"]- > .`

When you include lists, fragment services are created for all combinations of values in the list. For example, `vr = < -["vr1","vr2"]- > , loginName = < -["joe@abc","jane@abc"]- >` would cause four fragments to be created with the following expressions:

- `vr = "vr1",loginName = "joe@abc"`
- `vr = "vr1",loginName = "jane@abc"`
- `vr = "vr2",loginName = "joe@abc"`
- `vr = "vr2",loginName = "jane@abc"`

Default— No value

Editing Level—Basic

`service service`— Name of the service to be included in the aggregate service as a fragment service.

Value— Name of a service

Default— No value

Editing Level—Basic

mandatory—(Optional) Specifies whether the fragment service must be active for the aggregate service to become active.

Default—Mandatory

Editing Level—Basic

redundancy-group *redundancy-group*—(Optional) Group name to be applied to each fragment service that is to be part of a redundancy group. The fragment services that have the same group name provide redundancy for each other.

Value—Text

Default—No value

Editing Level—Basic

subscription-required—(Optional) Specifies whether a remote subscriber session must be subscribed to the fragment service for it to become active.

Enabling **subscription-required** can be used to limit the services that can be activated as fragments. Enabling this option lets you control which services can be used as fragments. For example, for an aggregate service that supports VoIP to push a policy to the caller and the callee, you can require that both subscribers sign up for VoIP services. If you disable the option, only one party needs to subscribe to the aggregate service; the policy service sessions are created automatically.

Default—Disabled

Editing Level—Basic

substitution [*substitution...*]—(Optional) List of substitutions that are used as arguments for the fragment to become active. If a parameter does not acquire a value, the associated fragment service does not become active.

Value—One or more of the following:

- **< parameter-name >** —The parameter name is defined to have the same value in the fragment service session as in the aggregate service session.
- **< parameter-name > = < substitution-expression >** —The parameter name on the left side of the equals sign is defined for the fragment service session. This parameter name is the result of the evaluation of the expression (in the aggregate service session) on the right side of the equals sign.

Default—No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* service *name* parameter

Syntax

```
services scope name service name parameter {
    gateway-ip-address gateway-ip-address;
    service-ip-address service-ip-address;
    service-ip-mask service-ip-mask;
    service-port service-port;
    substitution [substitution...];
    session-volume-quota session-volume-quota;
}
```

Hierarchy Level

```
[edit services scope name service name parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure parameter values for services. The policy engine substitutes parameters in policies associated with this service with the values that you specify in this parameter configuration.

Options

`gateway-ip-address gateway-ip-address`—(Optional) Actual IP address of the gateway router. This value is substituted for the policy global parameter called `gateway_ipAddress`.

Value— IP address

Default— No value

Editing Level—Basic

`service-ip-address service-ip-address`—(Optional) Actual IP address of the host(s) that provides the service. This value is substituted for the policy global parameter called `service_ipAddress`.

Value— IP address

Default— No value

Editing Level—Basic

`service-ip-mask` *service-ip-mask*—(Optional) Actual IP mask for the service. This value is substituted for the policy global parameter called `service_ipMask`.

Value— IP address

Default— No value

Editing Level—Basic

`service-port` *service-port*—(Optional) Actual port for the service. This value is substituted for the policy global parameter called `service_port`.

Value— TCP or UDP port number in the range 0–65535

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for other parameters. These values are substituted for the parameters that you specify.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

`session-volume-quota` *session-volume-quota*—(Optional) Upstream and downstream volume quota for the service session.

The SAE does not directly use this value. It is used by applications that implement tracking plug-ins. The value of a service session can be defined at runtime either through an authorization plug-in or a call to the SAE API. If the Session Volume Quota attribute is defined in more than one place, which value is used depends on where the value is defined. The SRC software searches for the value in the following order:

1. Value set in a call to the SAE
2. Value set in an authorization plug-in
3. Value set in a service definition

Value— Volume quota in the format "downstream-quota:upstream-quota"

where

- Downstream quota is the number of bytes available for transmitting data from the network to the subscriber.
- Upstream quota is the number of bytes available for transmitting data from the subscriber to the network.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

services scope *name* service *name* script

Syntax

```
services scope name service name script {
    script-type (url | python | java-class | java-archive);
    class-name class-name;
    file file;
    filename filename;
}
```

Hierarchy Level

```
[edit services scope name service name script]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the script service.

Options

`script-type (url | python | java-class | java-archive)`— Type of script service. Determines how the contents of the "file" attribute will be interpreted.

Value

- `url`— The value of attribute "file" is a URL that specifies where to find a Java archive (.jar file) containing the script service implementation.
- `python`— The value of attribute "file" is Python code.
- `java-class`— The value of attribute "file" is the binary contents of a compiled Java class file (.class file).
- `java-archive`— The value of attribute "file" is the binary contents of a Java archive file (.jar file).

Default— No value

Editing Level—Basic

`class-name` *class-name*— Name of the Java or Python class that implements the script service. The SAE instantiates the named class when it starts the script service.

Value— Name of the class

Default— No value

Editing Level—Basic

`file` *file*— If the script type is "URL", this attribute contains the URL of a Java archive (.jar) file containing the script service implementation. Otherwise, this attribute contains the script service implementation itself (i.e. python code, the binary contents of a compiled .class file, or the binary contents of a .jar file).

Value— The script itself, or a URL pointing to a .jar file containing the script

Default— No value

Editing Level—Basic

`filename` *filename*—(Optional) The file needs to exist locally. Its content will be read and loaded into the "file" attribute.

Value—Text

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

Policy CLI

The following table summarizes the SRC command-line interface (CLI) for configuring policies. Configuration statements are listed in alphabetical order.

Policy CLI Configuration Statements
policies_folder
policies_global-parameters
policies_group
policies_group_name_list
policies_group_name_list_name_rule
policies_group_name_list_name_rule_name_color
policies_group_name_list_name_rule_name_docsis-best-effort
policies_group_name_list_name_rule_name_docsis-down-stream
policies_group_name_list_name_rule_name_docsis-non-real-time
policies_group_name_list_name_rule_name_docsis-parameter
policies_group_name_list_name_rule_name_docsis-real-time
policies_group_name_list_name_rule_name_docsis-unsolicited-grant-ad
policies_group_name_list_name_rule_name_docsis-unsolicited-grant
policies_group_name_list_name_rule_name_exception-application
policies_group_name_list_name_rule_name_filter
policies_group_name_list_name_rule_name_flow-spec
policies_group_name_list_name_rule_name_forward
policies_group_name_list_name_rule_name_forwarding-class
policies_group_name_list_name_rule_name_gate-spec
policies_group_name_list_name_rule_name_http-redirect
policies_group_name_list_name_rule_name_loss-priority

<u>policies_group_name_list_name_rule_name_mark</u>
<u>policies_group_name_list_name_rule_name_mark_name_info</u>
<u>policies_group_name_list_name_rule_name_nat</u>
<u>policies_group_name_list_name_rule_name_nat_name_ip-network_group-network</u>
<u>policies_group_name_list_name_rule_name_nat_name_port</u>
<u>policies_group_name_list_name_rule_name_next-hop</u>
<u>policies_group_name_list_name_rule_name_next-interface</u>
<u>policies_group_name_list_name_rule_name_next-rule</u>
<u>policies_group_name_list_name_rule_name_policer</u>
<u>policies_group_name_list_name_rule_name_policer_name_packet-action</u>
<u>policies_group_name_list_name_rule_name_policer_name_packet-action_name_filter</u>
<u>policies_group_name_list_name_rule_name_policer_name_packet-action_name_forwarding-class</u>
<u>policies_group_name_list_name_rule_name_policer_name_packet-action_name_loss-priority</u>
<u>policies_group_name_list_name_rule_name_policer_name_packet-action_name_parameter</u>
<u>policies_group_name_list_name_rule_name_qos-attach</u>
<u>policies_group_name_list_name_rule_name_qos-condition</u>
<u>policies_group_name_list_name_rule_name_rate-limit</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_committed-action_filter</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_committed-action_forward</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_committed-action_mark_mark-info</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_committed-action_parameter</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_conformed-action_filter</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_conformed-action_forward</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_conformed-action_mark_mark-info</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_conformed-action_parameter</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_exceed-action_filter</u>

<u>policies_group_name_list_name_rule_name_rate-limit_name_exceed-action_forward</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_exceed-action_mark_mark-info</u>
<u>policies_group_name_list_name_rule_name_rate-limit_name_exceed-action_parameter</u>
<u>policies_group_name_list_name_rule_name_reject</u>
<u>policies_group_name_list_name_rule_name_routing-instance</u>
<u>policies_group_name_list_name_rule_name_scheduler-action</u>
<u>policies_group_name_list_name_rule_name_scheduler-action_name_drop-profile</u>
<u>policies_group_name_list_name_rule_name_service-class-name</u>
<u>policies_group_name_list_name_rule_name_stateful-firewall</u>
<u>policies_group_name_list_name_rule_name_stateful-firewall_name_packet-action_filter</u>
<u>policies_group_name_list_name_rule_name_stateful-firewall_name_packet-action_forward</u>
<u>policies_group_name_list_name_rule_name_stateful-firewall_name_packet-action_parameter</u>
<u>policies_group_name_list_name_rule_name_stateful-firewall_name_packet-action_reject</u>
<u>policies_group_name_list_name_rule_name_template-activation</u>
<u>policies_group_name_list_name_rule_name_template-activation_name_variables</u>
<u>policies_group_name_list_name_rule_name_traffic-class</u>
<u>policies_group_name_list_name_rule_name_traffic-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_application-protocol-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_application-protocol-condition_name_proto-attr</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_application-protocol-condition_name_proto-attr_destination-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_application-protocol-condition_name_proto-attr_source-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_destination-network_group-network</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_destination-network_network</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_icmp-condition</u>

<u>policies_group_name_list_name_rule_name_traffic-condition_name_igmp-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_ipsec-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_parameter-protocol-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_parameter-protocol-condition_proto-attr</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_parameter-protocol-condition_proto-attr_destination-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_parameter-protocol-condition_proto-attr_source-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_protocol-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_protocol-port-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_protocol-port-condition_destination-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_protocol-port-condition_source-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_source-network_group-network</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_source-network_network</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_tcp-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_tcp-condition_destination-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_tcp-condition_source-port_port</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_tos</u>
<u>policies_group_name_list_name_rule_name_traffic-condition_name_traffic-match-condition</u>
<u>policies_group_name_list_name_rule_name_traffic-mirror</u>
<u>policies_group_name_list_name_rule_name_traffic-shape</u>
<u>policies_group_name_list_name_rule_name_user-packet-class</u>
<u>policies_group_name_local-parameters</u>

policies folder

Syntax

```
policies folder name {
    description description;
}
```

Hierarchy Level

```
[edit policies folder]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a policy folder, which is a collection of policies.

Options

`name name`— Name for a policy folder, which is a collection of policy folders or groups.

Value— Text

`description description`—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies global-parameters

Syntax

```
policies global-parameters name {
    description description;
    default-value default-value;
    type type;
}
```

Hierarchy Level

```
[edit policies global-parameters]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Defines a global parameter. A global parameter is available for use in any policy. With global parameters, you can define parameters once and then reuse them in many policies. Typically, you would use global parameters if the parameter does not need to change often. If parameters require changes, use local parameters.

Options

`name name`— Name of the parameter

Value— Text

`description description`—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

`default-value default-value`—(Optional) Value that the policy engine uses if no other values are provided during the parameter value acquisition process. If other values are provided to the policy engine but problems are encountered, the default value for the parameter is not used. The policy engine generates an error message.

Value— Valid value for the parameter type. See the policy documentation in the *SRC-PE Services and Policies Guide* for valid values for each parameter type.

Default— No value

Editing Level—Basic

`type type`—(Optional) Type of attribute for which you can use the parameter. The parameter type determines where you can use the parameter.

Value— See the policy documentation in the *SRC-PE Services and Policies Guide* for a list of parameter types, where each type of parameter is used, and what each parameter is used to specify.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group

Syntax

```
policies group name {
    description description;
}
```

Hierarchy Level

```
[edit policies group]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a policy group, which is a collection of policy lists.

Options

name *name*— Name for a collection of policy lists.

Value— Text

description *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list

Syntax

```
policies group name list name {
    role (junos | junose-ipv4 | junose-ipv6 | pcmm | aaa);
    applicability (input | output | both | secondary-input);
    description description;
}
```

Hierarchy Level

```
[edit policies group name list]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a policy list that holds a collection of policy rules.

Options

name *name*— Name for a collection of policy rules.

Value— Text

role (junos | junose-ipv4 | junose-ipv6 | pcmm | aaa)— Platform for which the policy list is created. The selection that you make controls the type of policy rules that you can add to the policy list. You must configure the role before you can configure the policy rule.

Value

- junos— JUNOS routing platform
- junose-ipv4— JUNOSe router that is running IPv4
- junose-ipv6— JUNOSe router that is running IPv6
- pcmm— PCMM platform
- aaa— AAA supporting platforms

Default— No value

Editing Level—Basic

`applicability (input | output | both | secondary-input)`—Indicates where the policy is applied on the router or, for PCMM policies, indicates whether the policy applies to the upstream or downstream channel.

For JUNOS routing platforms, applicability determines the types of policy rules that you can create:

- JUNOS ASP—Applicability must be both.
- JUNOS FILTER—Applicability must be input or output.
- JUNOS POLICER—Applicability must be input or output.
- JUNOS SCHEDULER—Applicability must be both.
- JUNOS SHAPING—Applicability must be both.

Value

- `input`— Policy is applied to the input (ingress) side of the router interface. For PCMM policies, the policy is provisioned on upstream service flows (from the cable modem to the CMTS device).
- `output`— Policy is applied to the output (egress) side of the router interface. For PCMM policies, the policy is provisioned on the downstream channel (from the CMTS device to the cable modem).
- `both`— Policy is applied to both the input (ingress) and output (egress) side of the interface, or it is attached implicitly to the interface without indicating direction. The both value is not valid for PCMM or JUNOSe policies.

In the case of JUNOS ASP policy rules, the policy is attached to both sides of the interface; for JUNOS scheduler policy rules, the policy is attached implicitly to the interface without indicating direction.

- `secondary-input`— Policy is applied to the secondary input attachment point of the router interface. Valid for JUNOSe devices.

Editing Level—Basic

`description description`—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule

Syntax

```
policies group name list name rule name {
    type type;
    precedence precedence;
    accounting;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a policy rule, which is a collection of conditions and actions.

Options

name name— Name for a policy rule, which is a collection of conditions and actions.

Value— Text

type type— Policy rule type, which is based on the applicability and the role of the policy.

Value— The type of policy rule that you can create depends on the role and applicability of the policy list in which you create the policy rule.

- For JUNOS policy lists, there is only one type—*junose*.
- For PCMM policy lists, there is only one type—*pcmm*.
- For AAA policy lists, there is only one type—*aaa*.
- For JUNOS policy lists, you can create the following policy rule types:
 - JUNOS ASP—Applicability of policy list must be both input and output.
 - JUNOS FILTER—Applicability of policy list must be input or output.

- JUNOS POLICER—Applicability of policy list must be input or output.
- JUNOS SCHEDULER—Applicability of policy list must be both.
- JUNOS SHAPING—Applicability of policy list must be both.

Default— No value

Editing Level—Basic

`precedence` *precedence*—(Optional) Order in which the policy manager applies policy rules. Rules are evaluated from lowest to highest precedence value. Precedence has meaning only if two rules have different classifiers and if those classifiers overlap. If this is the case and a packet is received that satisfies both classifiers, then only the action of the rule with the lower precedence value is performed.

- For JUNOSe policies, rules with equal precedence are evaluated in the order of creation.
- For JUNOS policies, rules with equal precedence are evaluated in random order. Precedence is not a factor for JUNOS SCHEDULER and JUNOS POLICER policy rules.

Value— One of the following:

- For JUNOS and JUNOSe policies, integer in the range 0–32767
- For PCMM policies, integer in the range 64–191
- Parameter of type `prPrecedence`

Default— 100

Editing Level—Basic

`accounting`—(Optional) Specifies whether accounting data is collected for the actions specified in the rule.

If you specify that accounting data is collected, the SAE begins collecting accounting information when a service that uses the policy rule is activated. When the service is deactivated, the SAE sends the accounting records to the RADIUS accounting server or to a plug-in.

When you specify multiple actions for accounting, the SAE adds the accounting data for individual actions together to obtain a summary accounting record for that interface direction.

Accounting is not available for all actions. For example, the NAT action does not provide accounting.

Value— One of the following:

- true—Accounting data is collected.
- false—Accountding data is not collected.

Default— false

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* color

Syntax

```
policies group name list name rule name color name {
    color color;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name color]
```

Release Information

Statement introduced in SRC Release 2.0.0

Description

Configure a color action. Use this action to specify the color that is applied to a packet when it passes through the router. You can configure color actions for JUNOS policy rules.

Options

`name name`— Name for the color action.

Value— Text

`color color`—(Optional) Color that is applied to a packet when it passes through the router.

Value— One of the following:

- Integer in the range 1–3
 - 1—green
 - 2—yellow
 - 3—red
- Parameter of type color

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-best-effort

Syntax

```
policies group name list name rule name docsis-best-effort name {
    traffic-priority traffic-priority;
    request-transmission-policy request-transmission-policy;
    maximum-sustained-rate maximum-sustained-rate;
    maximum-traffic-burst maximum-traffic-burst;
    minimum-reserved-rate minimum-reserved-rate;
    assumed-minimum-res-packet-size assumed-minimum-res-packet-size;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-best-effort]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action that is set to best-effort service flow scheduling type. DOCSIS actions are for PCMM policy rules.

Options

name *name*— Name of a DOCSIS action that is set to best-effort service flow scheduling type.

Value— Text

traffic-priority *traffic-priority*—(Optional) Priority for the service flow. If two traffic flows are identical in all QoS parameters except priority, the higher-priority service flow is given preference.

Value— One of the following:

- Number in the range 0–7, where 0 is the lowest priority and 7 is the highest priority
- Parameter of type trafficPriority

Default— No value

Editing Level—Basic

`request-transmission-policy request-transmission-policy`—(Optional)
Interval usage code that the cable modem uses for upstream transmission requests and packet transmissions for this service flow. Specifies whether requests can be piggybacked with data. Also, for data packets transmitted on this service flow, specifies whether packets can be concatenated, fragmented, or have their payload headers suppressed. For UGS flows, this option also specifies how to treat packets that do not fit into the UGS grant.

Value— One of the following:

- 4-byte bit field; the valid range is 0–511
- Parameter of type `requestTransmissionPolicy`

Default— No value

Editing Level—Basic

`maximum-sustained-rate maximum-sustained-rate`—(Optional) Maximum sustained rate at which traffic can operate over the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 0–4294967295
- Numeric expression
- Parameter of type `rate`

Default— No value

Editing Level—Basic

`maximum-traffic-burst maximum-traffic-burst`—(Optional) Maximum burst size for the service flow. This parameter has no effect unless you configure a nonzero value for the maximum sustained rate.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 1522–4294967295
- Numeric expression
- Parameter of type `burst`

Default— No value

Editing Level—Basic

`minimum-reserved-rate` *minimum-reserved-rate*—(Optional) Guaranteed minimum rate that is reserved for the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295; a value of 0 means that no bandwidth is reserved for the service flow
- Numeric expression
- Parameter of type `rate`

Default— No value

Editing Level—Basic

`assumed-minimum-res-packet-size` *assumed-minimum-res-packet-size*—(Optional) Assumed minimum packet size for which the minimum reserved traffic rate is provided. If a packet is smaller than the assumed minimum packet size, the software treats the packet as if its size is equal to the value specified in this option.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type `packetLength`

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-down-stream

Syntax

```
policies group name list name rule name docsis-down-stream name {
    traffic-priority traffic-priority;
    maximum-latency maximum-latency;
    maximum-sustained-rate maximum-sustained-rate;
    maximum-traffic-burst maximum-traffic-burst;
    minimum-reserved-rate minimum-reserved-rate;
    assumed-minimum-res-packet-size assumed-minimum-res-packet-size;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-down-stream]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action that is set to downstream service flow scheduling type. DOCSIS actions are for PCMM policy rules.

Options

name *name*— Name of a DOCSIS action that is set to downstream service flow scheduling type.

Value— Text

traffic-priority *traffic-priority*—(Optional) Priority for the service flow. If two traffic flows are identical in all QoS parameters except priority, the higher-priority service flow is given preference.

Value— One of the following:

- Number in the range 0–7, where 0 is the lowest priority and 7 is the highest priority
- Parameter of type trafficPriority

Default— No value

Editing Level—Basic

`maximum-latency` *maximum-latency*—(Optional) Maximum latency for downstream service flows. It is the maximum latency for a packet that passes through the CMTS device, from the time that the CMTS device's network side interface receives the packet until the CMTS device forwards the packet on its radio frequency (RF) interface.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type maxLatency

Default— No value

Editing Level—Basic

`maximum-sustained-rate` *maximum-sustained-rate*—(Optional) Maximum sustained rate at which traffic can operate over the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 0–4294967295
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`maximum-traffic-burst` *maximum-traffic-burst*—(Optional) Maximum burst size for the service flow. This parameter has no effect unless you configure a nonzero value for the maximum sustained rate.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 1522–4294967295
- Numeric expression
- Parameter of type burst

Default— No value

Editing Level—Basic

`minimum-reserved-rate` *minimum-reserved-rate*—(Optional) Guaranteed minimum rate that is reserved for the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295; a value of 0 means that no bandwidth is reserved for the service flow
- Numeric expression
- Parameter of type `rate`

Default— No value

Editing Level—Basic

`assumed-minimum-res-packet-size` *assumed-minimum-res-packet-size*—(Optional) Assumed minimum packet size for which the minimum reserved traffic rate is provided. If a packet is smaller than the assumed minimum packet size, the software treats the packet as if its size is equal to the value specified in this option.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type `packetLength`

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-non-real-time

Syntax

```
policies group name list name rule name docsis-non-real-time name {
    traffic-priority traffic-priority;
    request-transmission-policy request-transmission-policy;
    maximum-sustained-rate maximum-sustained-rate;
    maximum-traffic-burst maximum-traffic-burst;
    minimum-reserved-rate minimum-reserved-rate;
    assumed-minimum-res-packet-size assumed-minimum-res-packet-size;
    nominal-polling-interval nominal-polling-interval;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-non-real-time]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action that is set to non-real-time service flow scheduling type. DOCSIS actions are for PCMM policy rules.

Options

name *name*— Name of a DOCSIS action that is set to non-real-time service flow scheduling type.

Value— Text

traffic-priority *traffic-priority*—(Optional) Priority for the service flow. If two traffic flows are identical in all QoS parameters except priority, the higher-priority service flow is given preference.

Value— One of the following:

- Number in the range 0–7, where 0 is the lowest priority and 7 is the highest priority

- Parameter of type trafficPriority

Default— No value

Editing Level—Basic

`request-transmission-policy request-transmission-policy`—(Optional) Interval usage code that the cable modem uses for upstream transmission requests and packet transmissions for this service flow. Specifies whether requests can be piggybacked with data. Also, for data packets transmitted on this service flow, specifies whether packets can be concatenated, fragmented, or have their payload headers suppressed. For UGS flows, this option also specifies how to treat packets that do not fit into the UGS grant.

Value— One of the following:

- 4-byte bit field; the valid range is 0–511
- Parameter of type requestTransmissionPolicy

Default— No value

Editing Level—Basic

`maximum-sustained-rate maximum-sustained-rate`—(Optional) Maximum sustained rate at which traffic can operate over the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 0–4294967295
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`maximum-traffic-burst maximum-traffic-burst`—(Optional) Maximum burst size for the service flow. This parameter has no effect unless you configure a nonzero value for the maximum sustained rate.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 1522–4294967295

- Numeric expression
- Parameter of type burst

Default— No value

Editing Level—Basic

`minimum-reserved-rate` *minimum-reserved-rate*—(Optional) Guaranteed minimum rate that is reserved for the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295; a value of 0 means that no bandwidth is reserved for the service flow
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`assumed-minimum-res-packet-size` *assumed-minimum-res-packet-size*—(Optional) Assumed minimum packet size for which the minimum reserved traffic rate is provided. If a packet is smaller than the assumed minimum packet size, the software treats the packet as if its size is equal to the value specified in this option.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`nominal-polling-interval` *nominal-polling-interval*—(Optional) Nominal interval between successive unicast request opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-parameter

Syntax

```
policies group name list name rule name docsis-parameter name {
    service-flow-type service-flow-type;
    traffic-priority traffic-priority;
    request-transmission-policy request-transmission-policy;
    maximum-sustained-rate maximum-sustained-rate;
    maximum-traffic-burst maximum-traffic-burst;
    minimum-reserved-rate minimum-reserved-rate;
    assumed-minimum-res-packet-size assumed-minimum-res-packet-size;
    maximum-latency maximum-latency;
    nominal-polling-interval nominal-polling-interval;
    tolerated-poll-jitter tolerated-poll-jitter;
    grant-size grant-size;
    grants-per-interval grants-per-interval;
    tolerated-grant-jitter tolerated-grant-jitter;
    nominal-grant-interval nominal-grant-interval;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action with the service flow scheduling type set to a parameter. The parameter is a trafficProfileType parameter.

Options

name name— Name of a DOCSIS action that is set to the trafficProfileType parameter as the service flow scheduling type.

Value— Text

service-flow-type service-flow-type— Parameter that is used to determine the

service flow scheduling type.

Value— Parameter of type `trafficProfileType`. You must enter a parameter that has been created and has been committed.

Default— No value

Editing Level—Basic

`traffic-priority traffic-priority`—(Optional) Priority for the service flow. If two traffic flows are identical in all QoS parameters except priority, the higher-priority service flow is given preference.

Value— One of the following:

- Number in the range 0–7, where 0 is the lowest priority and 7 is the highest priority
- Parameter of type `trafficPriority`

Default— No value

Editing Level—Basic

`request-transmission-policy request-transmission-policy`—(Optional) Interval usage code that the cable modem uses for upstream transmission requests and packet transmissions for this service flow. Specifies whether requests can be piggybacked with data. Also, for data packets transmitted on this service flow, specifies whether packets can be concatenated, fragmented, or have their payload headers suppressed. For UGS flows, this option also specifies how to treat packets that do not fit into the UGS grant.

Value— One of the following:

- 4-byte bit field; the valid range is 0–511
- Parameter of type `requestTransmissionPolicy`

Default— No value

Editing Level—Basic

`maximum-sustained-rate maximum-sustained-rate`—(Optional) Maximum sustained rate at which traffic can operate over the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 0–4294967295
- Numeric expression

- Parameter of type rate

Default— No value

Editing Level—Basic

`maximum-traffic-burst` *maximum-traffic-burst*—(Optional) Maximum burst size for the service flow. This parameter has no effect unless you configure a nonzero value for the maximum sustained rate.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 1522–4294967295
- Numeric expression
- Parameter of type burst

Default— No value

Editing Level—Basic

`minimum-reserved-rate` *minimum-reserved-rate*—(Optional) Guaranteed minimum rate that is reserved for the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295; a value of 0 means that no bandwidth is reserved for the service flow
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`assumed-minimum-res-packet-size` *assumed-minimum-res-packet-size*—(Optional) Assumed minimum packet size for which the minimum reserved traffic rate is provided. If a packet is smaller than the assumed minimum packet size, the software treats the packet as if its size is equal to the value specified in this option.

Value— One of the following:

- Number of bytes in the range 0–65535

- Numeric expression
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`maximum-latency` *maximum-latency*—(Optional) Maximum latency for downstream service flows. It is the maximum latency for a packet that passes through the CMTS device, from the time that the CMTS device's network side interface receives the packet until the CMTS device forwards the packet on its radio frequency (RF) interface.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type maxLatency

Default— No value

Editing Level—Basic

`nominal-polling-interval` *nominal-polling-interval*—(Optional) Nominal interval between successive unicast request opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`tolerated-poll-jitter` *tolerated-poll-jitter*—(Optional) Maximum amount of time that unicast request intervals can be delayed beyond the nominal polling interval. Delaying requests allows the service flow scheduler to fit as much data as possible in an upstream packet, thereby reducing fragmentation.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type jitter

Default— No value

Editing Level—Basic

`grant-size` *grant-size*—(Optional) Size of the individual data grants provided to the service flow.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type `grantSize`

Default— No value

Editing Level—Basic

`grants-per-interval` *grants-per-interval*—(Optional) Actual number of data grants given to the service flow during each nominal grant interval.

Value— One of the following:

- Integer in the range 0–127
- Numeric expression
- Parameter of type `interval`

Default— No value

Editing Level—Basic

`tolerated-grant-jitter` *tolerated-grant-jitter*—(Optional) Maximum amount of time that the transmission opportunities can be delayed beyond the nominal grant interval. A jitter buffer can stop latency, but an improperly sized buffer can cause additional latency.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type `jitter`

Default— No value

Editing Level—Basic

`nominal-grant-interval` *nominal-grant-interval*—(Optional) Nominal interval between successive unsolicited data grant opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-real-time

Syntax

```
policies group name list name rule name docsis-real-time name {
    request-transmission-policy request-transmission-policy;
    maximum-sustained-rate maximum-sustained-rate;
    maximum-traffic-burst maximum-traffic-burst;
    minimum-reserved-rate minimum-reserved-rate;
    assumed-minimum-res-packet-size assumed-minimum-res-packet-size;
    nominal-polling-interval nominal-polling-interval;
    tolerated-poll-jitter tolerated-poll-jitter;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-real-time]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action that is set to real-time service flow scheduling type. DOCSIS actions are for PCMM policy rules.

Options

name *name*— Name of a DOCSIS action that is set to real-time service flow scheduling type.

Value— Text

request-transmission-policy *request-transmission-policy*—(Optional)
Interval usage code that the cable modem uses for upstream transmission requests and packet transmissions for this service flow. Specifies whether requests can be piggybacked with data. Also, for data packets transmitted on this service flow, specifies whether packets can be concatenated, fragmented, or have their payload headers suppressed. For UGS flows, this option also specifies how to treat packets that do not fit into the UGS grant.

Value— One of the following:

- 4-byte bit field; the valid range is 0–511
- Parameter of type requestTransmissionPolicy

Default— No value

Editing Level—Basic

`maximum-sustained-rate` *maximum-sustained-rate*—(Optional) Maximum sustained rate at which traffic can operate over the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 0–4294967295
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`maximum-traffic-burst` *maximum-traffic-burst*—(Optional) Maximum burst size for the service flow. This parameter has no effect unless you configure a nonzero value for the maximum sustained rate.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bytes in the range 1522–4294967295
- Numeric expression
- Parameter of type burst

Default— No value

Editing Level—Basic

`minimum-reserved-rate` *minimum-reserved-rate*—(Optional) Guaranteed minimum rate that is reserved for the service flow.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295; a value

- of 0 means that no bandwidth is reserved for the service flow
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`assumed-minimum-res-packet-size` *assumed-minimum-res-packet-size*—(Optional) Assumed minimum packet size for which the minimum reserved traffic rate is provided. If a packet is smaller than the assumed minimum packet size, the software treats the packet as if its size is equal to the value specified in this option.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`nominal-polling-interval` *nominal-polling-interval*—(Optional) Nominal interval between successive unicast request opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`tolerated-poll-jitter` *tolerated-poll-jitter*—(Optional) Maximum amount of time that unicast request intervals can be delayed beyond the nominal polling interval. Delaying requests allows the service flow scheduler to fit as much data as possible in an upstream packet, thereby reducing fragmentation.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type jitter

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-unsolicited-grant-ad

Syntax

```
policies group name list name rule name docsis-unsolicited-grant-ad name {
    request-transmission-policy request-transmission-policy;
    nominal-polling-interval nominal-polling-interval;
    grant-size grant-size;
    grants-per-interval grants-per-interval;
    tolerated-grant-jitter tolerated-grant-jitter;
    nominal-grant-interval nominal-grant-interval;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-unsolicited-grant-ad]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action that is set to unsolicited grant service with activity detection (UGS-AD) service flow scheduling type. DOCSIS actions are for PCMM policy rules.

Options

name *name*— Name of a DOCSIS action that is set to unsolicited grant service with activity detection (UGS-AD) service flow scheduling type.

Value— Text

request-transmission-policy *request-transmission-policy*—(Optional)
Interval usage code that the cable modem uses for upstream transmission requests and packet transmissions for this service flow. Specifies whether requests can be piggybacked with data. Also, for data packets transmitted on this service flow, specifies whether packets can be concatenated, fragmented, or have their payload headers suppressed. For UGS flows, this option also specifies how to treat packets that do not fit into the UGS grant.

Value— One of the following:

- 4-byte bit field; the valid range is 0–511
- Parameter of type requestTransmissionPolicy

Default— No value

Editing Level—Basic

`nominal-polling-interval` *nominal-polling-interval*—(Optional) Nominal interval between successive unicast request opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`grant-size` *grant-size*—(Optional) Size of the individual data grants provided to the service flow.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type grantSize

Default— No value

Editing Level—Basic

`grants-per-interval` *grants-per-interval*—(Optional) Actual number of data grants given to the service flow during each nominal grant interval.

Value— One of the following:

- Integer in the range 0–127
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`tolerated-grant-jitter` *tolerated-grant-jitter*—(Optional) Maximum amount of time that the transmission opportunities can be delayed beyond the nominal grant interval. A jitter buffer can stop latency, but an improperly sized buffer can cause additional latency.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type jitter

Default— No value

Editing Level—Basic

`nominal-grant-interval` *nominal-grant-interval*—(Optional) Nominal interval between successive unsolicited data grant opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* docsis-unsolicited-grant

Syntax

```
policies group name list name rule name docsis-unsolicited-grant name {
    request-transmission-policy request-transmission-policy;
    grant-size grant-size;
    grants-per-interval grants-per-interval;
    tolerated-grant-jitter tolerated-grant-jitter;
    nominal-grant-interval nominal-grant-interval;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name docsis-unsolicited-grant]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a DOCSIS action that is set to unsolicited grant (UGS) service flow scheduling type. DOCSIS actions are for PCMM policy rules.

Options

name *name*— Name of a DOCSIS action that is set to UGS service flow scheduling type.

Value— Text

request-transmission-policy *request-transmission-policy*—(Optional)
Interval usage code that the cable modem uses for upstream transmission requests and packet transmissions for this service flow. Specifies whether requests can be piggybacked with data. Also, for data packets transmitted on this service flow, specifies whether packets can be concatenated, fragmented, or have their payload headers suppressed. For UGS flows, this option also specifies how to treat packets that do not fit into the UGS grant.

Value— One of the following:

- 4-byte bit field; the valid range is 0–511

- Parameter of type requestTransmissionPolicy

Default— No value

Editing Level—Basic

`grant-size` *grant-size*—(Optional) Size of the individual data grants provided to the service flow.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type grantSize

Default— No value

Editing Level—Basic

`grants-per-interval` *grants-per-interval*—(Optional) Actual number of data grants given to the service flow during each nominal grant interval.

Value— One of the following:

- Integer in the range 0–127
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`tolerated-grant-jitter` *tolerated-grant-jitter*—(Optional) Maximum amount of time that the transmission opportunities can be delayed beyond the nominal grant interval. A jitter buffer can stop latency, but an improperly sized buffer can cause additional latency.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type jitter

Default— No value

Editing Level—Basic

`nominal-grant-interval` *nominal-grant-interval*—(Optional) Nominal interval between successive unsolicited data grant opportunities for this service flow.

Value— One of the following:

- Number of microseconds in the range 0–4294967295
- Numeric expression
- Parameter of type interval

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* exception-application

Syntax

```
policies group name list name rule name exception-application name {
    application-type application-type;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name exception-application]
```

Release Information

Statement introduced in SRC Release 2.1.0

Description

Specify exceptions to a policy rule to identify the client application that is a destination for packets Use this action in policy rules for JUNOSe routers.

Options

name *name*— Name for the exception application action.

Value— Text

application-type *application-type*— Specify the type of application to receive packets to which the exception action applies.

Value—

Default— http

Editing Level—Basic

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* filter

Syntax

```
policies group name list name rule name filter name {
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name filter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a filter action. Use this action to discard packets. You can configure filter actions for JUNOS filters and JUNOS policy rules.

Options

`name name`— Name for the filter action.

Value— Text

`description description`—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* flow-spec

Syntax

```
policies group name list name rule name flow-spec name {
    service-type service-type;
    token-bucket-rate token-bucket-rate;
    token-bucket-size token-bucket-size;
    peak-data-rate peak-data-rate;
    minimum-policed-unit minimum-policed-unit;
    maximum-packet-size maximum-packet-size;
    rate rate;
    slack-term slack-term;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name flow-spec]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a FlowSpec action, which uses an RSVP-style FlowSpec to specify a traffic profile. A FlowSpec is made up of two parts, a traffic specification (TSpec) and a service request specification (RSpec). The TSpec describes the traffic requirements for the flow, and the RSpec specifies resource requirements for the desired service. You can configure FlowSpec actions for PCMM policy rules.

Options

name *name*— Name of the FlowSpec action.

Value— Text

service-type *service-type*—(Optional) Type of FlowSpec service.

Value— One of the following:

- 2—guaranteed_service, which provides both bandwidth and latency and delay guarantees. A guaranteed service can contain

- both TSpec and RSpec parameters.
- 5—controlled_load_service, which provides minimum bandwidth guarantees, but not latency and delay guarantees. A controlled-load service can contain only TSpec token-bucket parameters, and not RSpec parameters.
- Parameter of type serviceNumber

Default— No value

Editing Level—Basic

`token-bucket-rate` *token-bucket-rate*—(Optional) Guaranteed minimum rate that is reserved for the service flow. Token bucket rate is a TSpec parameter.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`token-bucket-size` *token-bucket-size*—(Optional) Maximum burst size for the service flow. Token bucket size is a TSpec parameter.

Value— One of the following:

- Number of bits per second in the range 1522–4294967295
- Numeric expression
- Parameter of type tokenBucketSize

Default— No value

Editing Level—Basic

`peak-data-rate` *peak-data-rate*—(Optional) Amount of bandwidth over the committed rate that is allocated to accommodate excess traffic flow over the committed rate. Peak data rate is a TSpec parameter.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the

speed of the subscriber's DOCSIS interface

- Number of bits per second in the range 0–4294967295
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`minimum-policed-unit` *minimum-policed-unit*—(Optional) Assumed minimum-reserved-rate packet size. If a packet is smaller than the minimum policed unit, the software treats the packet as if its size is equal to the value specified in this option. Minimum policed unit is a TSpec parameter.

Value— One of the following:

- Number of bytes in the range 0–65535
- Numeric expression
- Parameter of type policedUnit

Default— No value

Editing Level—Basic

`maximum-packet-size` *maximum-packet-size*—(Optional) Maximum packet size for the FlowSpec. Maximum packet size is a TSpec parameter.

Value— One of the following:

- Number of bytes in the range 0–4294967295
- Numeric expression
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`rate` *rate*—(Optional) Average rate. Rate is an RSpec parameter.

Value— One of the following:

- Predefined global parameter `interface_speed`—Speed of the subscriber's DOCSIS interface
- Number of bits per second in the range 0–4294967295
- Numeric expression
- Parameter of type rate

Default— No value

Editing Level—Basic

`slack-term` *slack-term*—(Optional) Amount of slack in the bandwidth reservation that can be used without redefining the reservation. Slack is the difference between the desired delay and the actual delay obtained with the current bandwidth reservation. It allows some flexibility in bandwidth reservations. Slack term is an RSpec parameter.

Value— One of the following:

- Integer in the range 0–4294967295
- Numeric expression
- Parameter of type slackTerm

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* forward

Syntax

```
policies group name list name rule name forward name {
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name forward]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a forward action. Use this action to forward packets, such as packets that are sent by means of a routing table. You can configure forward actions for JUNOS filters and JUNOS policy rules.

Options

name *name*— Name for the forward action.

Value— Text

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* forwarding-class

Syntax

```
policies group name list name rule name forwarding-class name {
    forwarding-class forwarding-class;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name forwarding-class]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a forwarding class action. The forwarding class action causes the router to assign a forwarding class to packets that match the associated classify-traffic condition. You can configure forwarding class actions for JUNOS filter policy rules.

Options

name name— Name of the forwarding class action.

Value— Text

forwarding-class forwarding-class—(Optional) Name of the forwarding class assigned to packets.

Value— One of the following:

- String expression that matches a forwarding class that is configured on the router. Be sure to include quotation marks. For example:
 - "assured-forwarding"
 - "best-effort"
 - "expedited-forwarding"
 - "network-control"
- Parameter of type forwardingClass

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* gate-spec

Syntax

```
policies group name list name rule name gate-spec name {
    session-class-id-priority session-class-id-priority;
    session-class-id-preemption session-class-id-preemption;
    session-class-id-configurable session-class-id-configurable;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name gate-spec]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a GateSpec action. Use the GateSpec action to specify the session class ID for a gate. You can configure GateSpec actions for PCMM policy rules.

The session class ID provides a way for the application manager and the policy server to group gates into classes with different authorization characteristics. A CMTS device can perform authorization based not only on the requested QoS and the gate's authorized flow specification (FlowSpec), but also on the session class ID specified in the GateSpec. For example, you could use the session class ID to represent a prioritization scheme that allows either the policy server or the CMTS device to preempt a preauthorized gate in favor of allowing a new gate with a higher priority to be authorized.

Options

name name— Name of the GateSpec action.

Value— Text

session-class-id-priority session-class-id-priority—(Optional) Priority bits in the session class ID. The priority field describes the relative importance of the session as compared with other sessions generated by the same policy decision point.

Value— One of the following:

- Number in the range 0–7, where 0 is low priority and 7 is high priority
- String expression
- Parameter of type `sessionClassIdPriority`

Default— No value

Editing Level—Basic

`session-class-id-preemption` *session-class-id-preemption*—(Optional)

Preemption bit in the session class ID. Use the preemption bit to allocate bandwidth to lower-priority sessions.

Value— One of the following:

- 0—Enables preemption
- 1—Disables preemption
- String expression
- Parameter of type `sessionClassIdPreemption`

Default— No value

Editing Level—Basic

`session-class-id-configurable` *session-class-id-configurable*—

(Optional) Configurable bit in the session class ID. Application managers that provide novel services may use this value to specify new session classes. Use this option if your policy server supports configurable policies based on this value or if your CMTS device implements a novel session class based on this value.

Value— One of the following:

- Number in the range 0–15
- String expression
- Parameter of type `sessionClassIdConfigurable`

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* http-redirect

Syntax

```
policies group name list name rule name http-redirect name {
    subscriber-url subscriber-url;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name http-redirect]
```

Release Information

Statement introduced in SRC Release 2.1.0

Description

Specify a destination URL to which subscriber traffic is redirected. Use this action in policy rules for JUNOSe routers.

Options

name *name*— Name for the HTTP redirect action.

Value— Text

subscriber-url *subscriber-url*—(Optional) Destination URL for redirected Web traffic.

You can use the exception-application action to specify exceptions to a rule to identify the client, in this case HTTP, application that is a destination for packets.

Value— Literal string or parameter of type url

Default— No value

Editing Level—Basic

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value
Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* loss-priority

Syntax

```
policies group name list name rule name loss-priority name {
    loss-priority loss-priority;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name loss-priority]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a loss priority action. The loss priority action causes the router to assign a packet loss priority to packets that match the associated classify-traffic condition. You can configure loss priority actions for JUNOS filter policy rules.

Options

name name— Name of the loss priority action.

Value— Text

loss-priority loss-priority—(Optional) Packet loss priority.

Value— One of the following:

- Predefined global parameter:
 - *any_priority*—Sets the packet loss priority to "any." Do not select this value for loss priority actions. In this context, a value of *any_priority* is not valid.
 - *high_priority*—Sets the packet loss priority to high
 - *low_priority*—Sets the packet loss priority to low
- String expression that matches valid values on the router; for example, "high" or "low"
- Parameter of type `packetLossPriority`

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* mark

Syntax

```
policies group name list name rule name mark name {
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name mark]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a mark action. Use this action to mark packets. You can configure mark actions for JUNOS and PCMM policy rules.

Options

name *name*— Name for the mark action.

Value— Text

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* mark *name* info

Syntax

```
policies group name list name rule name mark name info {
    value value;
    mask mask;
}
```

Hierarchy Level

```
[edit policies group name list name rule name mark name info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the mark value and mark mask for mark actions.

Options

value value—(Optional) For IPv4 packets, sets the ToS field in the IP header. For IPv6 packets, sets the traffic-class field in the IP header.

Value— One of the following:

- Integer in the range 0–255
- Parameter of type tosByteMask

Default— 0

Editing Level—Basic

mask mask—(Optional) Mask associated with the mark value.

Value— One of the following:

- Integer values of 224, 252, 255

For IPv4:

- 255 (tos)—Specifies the use of the whole 8 bits of the ToS byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the ToS byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the ToS byte; tos-byte range is 0–7.

For IPv6:

- 255 (tcfield)—Specifies the use of the whole 8 bits of the traffic-class byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the traffic-class byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the traffic-class byte; tos-byte range is 0–7.
- Parameter of type tosByteMask

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* nat

Syntax

```
policies group name list name rule name nat name {
    translation-type translation-type;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name nat]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a NAT action. You can configure NAT actions for JUNOS ASP policy rules.

Options

`name name`— Name for the NAT action.

Value— Text

`translation-type translation-type`—(Optional) Type of network address translation that is used.

Value— One of the following:

- String expression that matches a NAT type on the router; for example:
 - "destination static"—Implements address translation for destination traffic without port translation; makes selected private servers accessible
 - "source dynamic"—Implements address translation for source traffic with port translation
 - "source static"—Implements address translation for source traffic without port mapping
- Parameter of type natTranslationType

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* nat *name* ip-network group-network

Syntax

```
policies group name list name rule name nat name ip-network group-network {
    network-specifier network-specifier;
}
```

Hierarchy Level

```
[edit policies group name list name rule name nat name ip-network group-network]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configuration of the network specifier for the NAT action.

Options

`network-specifier network-specifier`—(Optional) Specifies an IP address and mask.

Value— Specify the subnet in one of the following formats:

- [not] < address > / < mask > or < address > / < prefix length >
 - Include *not* to indicate that the condition matches every address that is not in the specified subnet.
 - < prefix length > is a number in the range 0–32, and specifies how many of the first bits in the address specify the network
- For JUNOS ASP policies, you must enter network in the format: < address > / < prefix length >

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* nat *name* port

Syntax

```
policies group name list name rule name nat name port {
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name nat name port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the port range for the NAT action.

Options

from-port from-port—(Optional) Port range to restrict port translation when NAT is configured in dynamic-source mode.

Value— One of the following:

- *service_port*—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–64000
- Numeric expression that indicates a range of ports; for example, 2010..2020
- 0..65535—Provides the same effect as the automatic option. JUNOS routing platforms support a port option called automatic, which means that it is a router-assigned port.
- Parameter of type port

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* next-hop

Syntax

```
policies group name list name rule name next-hop name {
    next-hop-address next-hop-address;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name next-hop]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a next-hop action. Use this action for the ingress side of the interface to specify the next IP address where the classified packets should go. You can configure next-hop actions for JUNOS filters and JUNOS policy rules.

Options

`name name`— Name for the next-hop action.

Value— Text

`next-hop-address next-hop-address`—(Optional) Address of next hop through which to send traffic.

Value— One of the following:

- IP address
- Predefined global parameter:
 - gateway_ipAddress—IP address of the gateway as specified by the service object
 - interface_ipAddress—IP address of the router interface
 - service_ipAddress—IP address of the service as specified by the service object
 - user_ipAddress—IP address of the subscriber
 - virtual_ipAddress—Virtual portal address of the SAE

- that is used in redundant redirect server installations
- Parameter of type address

Default— 0

Editing Level—Basic

description description—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* next-interface

Syntax

```
policies group name list name rule name next-interface name {
    interface-specifier interface-specifier;
    next-hop-address next-hop-address;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name next-interface]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a next-interface action. Use this action to forward packets to a particular interface and/or a next-hop address. You can configure next-interface actions for JUNOS filters and JUNOS policy rules. On JUNOS routers, you can use this action for both ingress and egress sides of the interface.

Options

name name— Name for the next-interface action.

Value— Text

interface-specifier interface-specifier— IP interface to be used as the next interface for packets.

Value— One of the following:

- For JUNOS interfaces, enter interface specifiers in the format:

```
'< type of specifier > = < value > '
```

where < type of specifier > is the interface name, alias, description, or UID.

For example: `name = 'fastEthernet3/0'`

For lists of valid interface specifiers for JUNOS routers, see "Interface Types and Specifiers" in the JUNOS Command Reference Guides.

- For JUNOS interfaces, enter interface specifiers in the format:

`'name = < mediatype > - < slot > / < pic > / < port > . < unit > '`

For example: `'name = AT-0/1/0.0'`

- Predefined global parameter:
 - `bfwIf` (interface that leads to the bronze firewall server)
 - `gfwIf` (interface that leads to gold firewall server).
- Parameter of type `interfaceSpec`

Default— No value

Editing Level—Basic

`next-hop-address` *next-hop-address*—(Optional) Address of next hop through which to send traffic.

Value— One of the following:

- IP address
- Predefined global parameter:
 - `gateway_ipAddress`—IP address of the gateway as specified by the service object
 - `interface_ipAddress`—IP address of the router interface
 - `service_ipAddress`—IP address of the service as specified by the service object
 - `user_ipAddress`—IP address of the subscriber
 - `virtual_ipAddress`—Virtual portal address of the SAE that is used in redundant redirect server installations
- Parameter of type `address`

Default— 0

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text
Default— No value
Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* next-rule

Syntax

```
policies group name list name rule name next-rule name {
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name next-rule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a next-rule action. If a packet matches the classify-traffic condition, the next-rule action causes the router to continue to the next rule in the policy list for evaluation. You can configure next-rule actions for JUNOS filter policy rules.

Options

name *name*— Name of the next-rule action.

Value— Text

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* policer

Syntax

```
policies group name list name rule name policer name {
    bandwidth-limit bandwidth-limit;
    bandwidth-limit-unit bandwidth-limit-unit;
    burst burst;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name policer]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a policer action. The policer action specifies rate and burst size limits and the action taken if a packet exceeds those limits. You can create policer actions in JUNOS policer and JUNOS filter policy rules.

Options

name name— Name of the policer action.

Value—Text

bandwidth-limit bandwidth-limit—(Optional) Traffic rate, that if exceeded, causes the router to take the indicated packet action.

Value— One of the following:

- Predefined global parameter *interface_speed*, which is the speed of the subscriber's router interface.
- Bits per second in the range 32000–320000000000
- Percentage of bandwidth (1–100)
- Numeric expression
- Parameter of type rate

Default— No value**Editing Level**—Basic

`bandwidth-limit-unit` *bandwidth-limit-unit*—(Optional) Indicates the type of value that you entered for bandwidth limit.

Value— One of the following:

- Predefined global parameter:
 - `bps`—Value entered for bandwidth limit is bps
 - `percent`—Value entered for bandwidth limit is a percentage of the port speed
- String expression
- Parameter of type `bandwidthSizeUnit`

Default— No value**Editing Level**—Basic

`burst` *burst*—(Optional) Maximum burst size. The minimum recommended value is the maximum transmission unit (MTU) of the IP packets being policed.

Value— One of the following:

- Number of bytes
- Numeric expression; for example `8*64000`
- Parameter of type `burst`

Default— No value**Editing Level**—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text**Default**— No value**Editing Level**—Basic**Required Privilege Level**

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* policer *name* packet-action

Syntax

```
policies group name list name rule name policer name packet-action name ...
```

Hierarchy Level

```
[edit policies group name list name rule name policer name packet-action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the action taken on a packet.

Options

name *name*— Name for the action that is taken on packets that exceed the rate and burst size limits specified in the policer action.

Value— Text

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* policer *name* packet-action *name* filter

Syntax

```
policies group name list name rule name policer name packet-action name filter
{
}
```

Hierarchy Level

```
[edit policies group name list name rule name policer name packet-
action name filter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the bandwidth and burst rate limits, the packet is dropped.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* policer *name* packet-action *name* forwarding-class

Syntax

```
policies group name list name rule name policer name packet-
action name forwarding-class {
    forwarding-class forwarding-class;
}
```

Hierarchy Level

```
[edit policies group name list name rule name policer name packet-
action name forwarding-class]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the bandwidth and burst rate limits, it is assigned to a forwarding class.

Options

`forwarding-class forwarding-class`—(Optional) Name of the forwarding class assigned to packets.

Value— One of the following:

- String expression that matches a forwarding class that is configured on the router. Be sure to include quotation marks. For example:
 - "assured-forwarding"
 - "best-effort"
 - "expedited-forwarding"
 - "network-control"
- Parameter of type forwardingClass

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* policer *name* packet-action *name* loss-priority

Syntax

```
policies group name list name rule name policer name packet-action name loss-
priority {
    loss-priority loss-priority;
}
```

Hierarchy Level

```
[edit policies group name list name rule name policer name packet-
action name loss-priority]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

For a policer action, set the loss priority level as the action taken on a packet that exceeds its rate limit.

Options

loss-priority loss-priority—(Optional) Packet loss priority.

Value— One of the following:

- Predefined global parameter:
 - *any_priority*—Sets the packet loss priority to "any." Do not select this value for loss priority actions. In this context, a value of *any_priority* is not valid.
 - *high_priority*—Sets the packet loss priority to high
 - *low_priority*—Sets the packet loss priority to low
- String expression that matches valid values on the router; for example, "high" or "low"
- Parameter of type packetLossPriority

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* policer *name* packet-action *name* parameter

Syntax

```
policies group name list name rule name policer name packet-
action name parameter {
    action action;
}
```

Hierarchy Level

```
[edit policies group name list name rule name policer name packet-
action name parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the bandwidth and burst rate limits, the action specified by the parameter is applied.

Options

`action action`—(Optional) Parameter that specifies the action to take on traffic.

Value— Parameter of type packetOperation.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* qos-attach

Syntax

```
policies group name list name rule name qos-attach name {
    qos-profile qos-profile;
    qos-parameters qos-parameters;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name qos-attach]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a QoS attachment action. Use this action to specify the name of the QoS profile and the QoS parameters list to attach to the router interface when this action is taken. You can configure QoS profile attachment actions for JUNOS policy rules.

Options

name name— Name for the QoS profile attachment action.

Value— Text

qos-profile qos-profile— Name of the QoS profile to attach to the JUNOS interface when this action is taken.

Value— One of the following:

- Name of a QoS profile that is configured on the router. Enclose the name in quotation marks. For example: "qp-vod-1024".
- Parameter of type qosProfileSpec.

Default— No value

Editing Level—Basic

`qos-parameters` *qos-parameters*—(Optional) Name-value pairs of the QoS parameters to attach to the interface when this action is taken. The parameters are configured on the JUNOS router and referenced in the scheduler profiles referred to by the QoS profile.

Value— One of the following:

- Name-value pair that defines QoS parameter; map expressions define multiple QoS parameters.

Maps are a list of `parameterName = parameterValue` pairs separated by commas and enclosed in curly brackets. For example, the map `{max-bw = 512000, shape-rate = 1000000}` supplies two QoS parameters.

- Parameter of type map.

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* qos-condition

Syntax

```
policies group name list name rule name qos-condition name {
    forwarding-class forwarding-class;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name qos-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a QoS condition. You can create QoS conditions within JUNOS scheduler policy rules.

Options

`name name`— Name for the QoS condition.

Value— Text

`forwarding-class forwarding-class`—(Optional) Matches packets based on forwarding class

Value— One of the following:

- String expression that matches forwarding classes that are configured on the router. Be sure to include quotation marks. For example:
 - "assured-forwarding"
 - "best-effort"
 - "expedited-forwarding"
 - "network-control"
- Parameter of type forwardingClass

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit

Syntax

```
policies group name list name rule name rate-limit name {
    type type;
    committed-rate committed-rate;
    committed-burst committed-burst;
    peak-rate peak-rate;
    peak-burst peak-burst;
    excess-burst excess-burst;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a rate-limit action. Use this action to define the quality of service. You can configure rate-limit actions for JUNOS policy rules.

Options

name *name*— Name for the rate-limit action.

Value— Text

type *type*— Specify that the rate-limit profile is either one rate or two rate. The one-rate rate-limit profile provides a hard-limit rate limiter or a TCP-friendly rate limiter. The two-rate rate-limit profile provides a two-rate, three-color marking mechanism.

Value— One of the following:

- *one_rate*—Uses a single-rate committed rate with two burst parameters: committed burst and excess burst; supports a TCP-friendly rate limiter
- *two_rate*—Uses committed rate and peak rate, each with a

- burst parameter
- Parameter of type `rateLimitType`

Default— No value

Editing Level—Basic

`committed-rate` *committed-rate*—(Optional) Target rate for the traffic that the policy covers.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the speed of the subscriber's router interface
- Number of bits per second in the range 0–4294967295
- Parameter of type `rate`

Default— 0

Editing Level—Basic

`committed-burst` *committed-burst*—(Optional) Amount of bandwidth allocated to burst traffic in bytes.

Value— One of the following:

- Number of bytes in the range 8192–4294967295
- Numeric expression.
- Parameter of type `burst`

For example, `max(qos*0.1/8, 16384)` sets the burst size to the maximum of 100-ms burst at committed rate (`qos*0.1`) in bytes (/8) or 16384

where `qos` is a local parameter that represents the committed rate

Default— 16384

Editing Level—Basic

`peak-rate` *peak-rate*—(Optional) For two-rate rate-limit profiles, specifies the amount of bandwidth allocated to excess traffic flow over the committed rate.

Value— One of the following:

- Predefined global parameter `interface_speed`, which is the

- speed of the subscriber's router interface
- Number of bits per second in the range 0–4294967295
- Numeric expression
- Parameter of type rate

For example, $\text{qos} * 1.5$ sets the peak rate to 1.5 times the committed rate

where *qos* is a local parameter that represents the committed rate

Default— 0

Editing Level—Basic

peak-burst *peak-burst*—(Optional) For two-rate rate-limit profiles, specifies the amount of bandwidth allocated to burst traffic in excess of the peak rate.

Value— One of the following:

- Number of bytes in the range 8192–4294967295
- Numeric expression
- Parameter of type burst

For example, $\text{max}(\text{qos} * 1.5 * 0.1/8, 16384)$

where *qos* is a local parameter that represents the committed rate

Default— 16384

Editing Level—Basic

excess-burst *excess-burst*—(Optional) For one-rate rate-limit profiles, specifies the amount of bandwidth allocated to accommodate burst traffic.

Value— One of the following:

- Number of bytes in the range $< 0 \mid [\text{committed-burst} + 1, 4294967295] >$
- Numeric expression
- Parameter of type burst

Default— No value

Editing Level—Basic

description *description*—(Optional) Description of the object that you are

configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* committed-action filter

Syntax

```
policies group name list name rule name rate-limit name committed-  
action filter {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name committed-  
action filter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow does not exceed the committed rate, the packet is dropped.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* committed-action forward

Syntax

```
policies group name list name rule name rate-limit name committed-  
action forward {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name committed-  
action forward]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow does not exceed the committed rate, the packet is forwarded.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* committed-action mark mark-info

Syntax

```
policies group name list name rule name rate-limit name committed-
action mark mark-info {
    value value;
    mask mask;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name committed-
action mark mark-info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the mark value and the mark mask.

Options

value value—(Optional) For IPv4 packets, sets the ToS field in the IP header. For IPv6 packets, sets the traffic-class field in the IP header.

Value— Integer in the range 0–255

Default— 0

Editing Level—Basic

mask mask—(Optional) Mask associated with the mark value.

Value— Integer values of 224, 252, 255 for JUNOS; values of 224, 252 for JUNOS

For IPv4:

- 255 (tos)—Specifies the use of the whole 8 bits of the ToS byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the ToS

byte; tos-byte range is 0–63.

- 224 (precedence)—Specifies the use of the upper 3 bits of the ToS byte; tos-byte range is 0–7.

For IPv6:

- 255 (tcfield)—Specifies the use of the whole 8 bits of the traffic-class byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the traffic-class byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the traffic-class byte; tos-byte range is 0–7.

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* committed-action parameter

Syntax

```
policies group name list name rule name rate-limit name committed-
action parameter {
    action action;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name committed-
action parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow does not exceed the committed rate, the action specified by the parameter is applied.

Options

`action action`—(Optional) Parameter that specifies the action to take on traffic.

Value— Parameter of type packetOperation.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* conformed-action filter

Syntax

```
policies group name list name rule name rate-limit name conformed-  
action filter {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name conformed-  
action filter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the committed rate but remains below the peak rate, the packet is dropped.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* conformed-action forward

Syntax

```
policies group name list name rule name rate-limit name conformed-  
action forward {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name conformed-  
action forward]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the committed rate but remains below the peak rate, the packet is forwarded.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* conformed-action mark mark-info

Syntax

```
policies group name list name rule name rate-limit name conformed-
action mark mark-info {
    value value;
    mask mask;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name conformed-
action mark mark-info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the mark value and the mark mask.

Options

value value—(Optional) For IPv4 packets, sets the ToS field in the IP header. For IPv6 packets, sets the traffic-class field in the IP header.

Value— Integer in the range 0–255

Default— 0

Editing Level—Basic

mask mask—(Optional) Mask associated with the mark value.

Value— Integer values of 224, 252, 255 for JUNOS; values of 224, 252 for JUNOS

For IPv4:

- 255 (tos)—Specifies the use of the whole 8 bits of the ToS byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the ToS

byte; tos-byte range is 0–63.

- 224 (precedence)—Specifies the use of the upper 3 bits of the ToS byte; tos-byte range is 0–7.

For IPv6:

- 255 (tcfield)—Specifies the use of the whole 8 bits of the traffic-class byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the traffic-class byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the traffic-class byte; tos-byte range is 0–7.

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* conformed-action parameter

Syntax

```
policies group name list name rule name rate-limit name conformed-
action parameter {
    action action;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name conformed-
action parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the committed rate but remains below the peak rate, the action specified by the parameter is applied.

Options

action action—(Optional) Parameter that specifies the action to take on traffic.

Value— Parameter of type packetOperation.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* exceed-action filter

Syntax

```
policies group name list name rule name rate-limit name exceed-action filter {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name exceed-  
action filter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the peak rate, the packet is dropped.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* exceed-action forward

Syntax

```
policies group name list name rule name rate-limit name exceed-action forward {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name exceed-  
action forward]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the peak rate, the packet is forwarded.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* exceed-action mark mark-info

Syntax

```
policies group name list name rule name rate-limit name exceed-
action mark mark-info {
    value value;
    mask mask;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name exceed-
action mark mark-info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the mark value and the mark mask.

Options

value value—(Optional) For IPv4 packets, sets the ToS field in the IP header. For IPv6 packets, sets the traffic-class field in the IP header.

Value— Integer in the range 0–255

Default— 0

Editing Level—Basic

mask mask—(Optional) Mask associated with the mark value.

Value— Integer values of 224, 252, 255 for JUNOS; values of 224, 252 for JUNOS

For IPv4:

- 255 (tos)—Specifies the use of the whole 8 bits of the ToS byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the ToS

byte; tos-byte range is 0–63.

- 224 (precedence)—Specifies the use of the upper 3 bits of the ToS byte; tos-byte range is 0–7.

For IPv6:

- 255 (tcfield)—Specifies the use of the whole 8 bits of the traffic-class byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the traffic-class byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the traffic-class byte; tos-byte range is 0–7.

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* rate-limit *name* exceed-action parameter

Syntax

```
policies group name list name rule name rate-limit name exceed-
action parameter {
    action action;
}
```

Hierarchy Level

```
[edit policies group name list name rule name rate-limit name exceed-
action parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify that if traffic flow exceeds the peak rate, the action specified by the parameter is applied.

Options

`action action`—(Optional) Parameter that specifies the action to take on traffic.

Value— Parameter of type packetOperation.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* reject

Syntax

```
policies group name list name rule name reject name {
    message-type message-type;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name reject]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a reject action. The reject action causes the router to discard a packet and send an ICMP destination unreachable message. You can configure reject actions for JUNOS filter policy rules.

Options

name name— Name of the reject action.

Value— Text

message-type message-type—(Optional) Type of ICMP destination unreachable message sent to the client.

Value— One of the following:

- String expression that matches a type of ICMP destination unreachable message supported on the router; for example:
 - "administratively-prohibited"
 - "bad-host-tos"
 - "bad-network-tos"
 - "host-prohibited"
 - "host-unknown"
 - "host-unreachable"
 - "network-prohibited"
 - "network-unknown"
 - "network-unreachable"

- "port-unreachable"
 - "precedence-cutoff"
 - "precedence-violation"
 - "protocol-unreachable"
 - "source-host-isolated"
 - "source-route-failed"
 - "tcp-reset"—If you specify tcp-reset, a TCP reset message is sent if the packet is a TCP packet. Otherwise, nothing is sent.
- Parameter of type messageType

Default— No value

Editing Level—Basic

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* routing-instance

Syntax

```
policies group name list name rule name routing-instance name {
    routing-instance routing-instance;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name routing-instance]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a routing instance action. Use routing instance actions for filter-based forwarding to direct traffic to a specific routing instance configured on the router. You can configure routing instance actions for JUNOS filter policy rules.

Options

name name— Name of the routing instance action.

Value— Text

routing-instance routing-instance—(Optional) Routing instance on the router to which packets are forwarded.

Value— One of the following:

- String expression that matches the name of a routing instance configured on the router; for example "isp2-route-table"
- Parameter of type routingInstance

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* scheduler-action

Syntax

```
policies group name list name rule name scheduler-action name {
    buffer-size buffer-size;
    buffer-size-unit buffer-size-unit;
    priority priority;
    transmit-rate transmit-rate;
    transmit-rate-unit transmit-rate-unit;
    exact exact;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name scheduler-action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduler action. You use scheduler actions along with QoS conditions and traffic-shape actions to configure transmission scheduling and rate control. Schedulers define the priority, bandwidth, delay buffer size, rate control status, and random early detection (RED) drop profiles to be applied to a particular class of traffic. You can create scheduler actions in JUNOS scheduler policy rules.

Options

name *name*— Name for the scheduler action.

Value— Text

buffer-size *buffer-size*—(Optional) Queue transmission buffer size.

Value— One of the following:

- Integer that represents the number of microseconds or a percentage of total buffer size.
- "remainder"—Uses available buffer that is not assigned to other queues.

- Expression
- Parameter of type `schedulerBufferSize`

Default— No value

Editing Level—Basic

`buffer-size-unit` *buffer-size-unit*—(Optional) Type of value that you entered for buffer size.

Value— One of the following:

- Predefined global parameter:
 - `buffer_size_percentage`—The value is a percentage of the total buffer.
 - `buffer_size_remainder`—The value is the remaining buffer available.
 - `temporal`—The value is temporal, in microseconds.
- String expression; for example, "percent"
- Parameter of type `schedulerBufferSizeMode`

Default— No value

Editing Level—Basic

`priority` *priority*—(Optional) Packet-scheduling priority. The priority determines the order in which an output interface transmits traffic from the queues.

Value— One of the following:

- Predefined global parameter:
 - `low`
 - `medium_low`
 - `medium_high`
 - `high`—Assigning high priority to a queue prevents the queue from being starved by traffic in a strict high-priority queue
 - `strict_high`—Configures a high-priority queue with unlimited transmission bandwidth available to it. As long as it has traffic to send, the strict high-priority queue receives precedence over low, medium-low, and medium-high priority queues, but not high-priority queues. You can configure strict high-priority on only one queue per interface.
- String expression—For example, "strict-high"
- Parameter of type `schedulerPriority`

Default— No value

Editing Level—Basic

`transmit-rate` *transmit-rate*—(Optional) Transmit rate.

Value— One of the following:

- Integer that represents the rate in bps or a percentage of bandwidth
- "remainder"—Uses remaining rate available
- Numeric expression
- Parameter of type schedulerTransmitRate

Default— No value

Editing Level—Basic

`transmit-rate-unit` *transmit-rate-unit*—(Optional) Type of value that you entered for transmit rate.

Value—Text

Default— No value

Editing Level—Basic

`exact` *exact*—(Optional) Specifies whether or not to enforce the exact transmission rate. Under sustained congestion, a rate-controlled queue that goes into negative credit fills up and eventually drops packets.

Value— True or false

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* scheduler-action *name* drop-profile

Syntax

```
policies group name list name rule name scheduler-action name drop-
profile name {
    loss-priority loss-priority;
    protocol protocol;
    drop-probability drop-probability;
    drop-profile-type drop-profile-type;
    queue-threshold queue-threshold;
}
```

Hierarchy Level

```
[edit policies group name list name rule name scheduler-action name drop-
profile]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a drop profile. The scheduler drop profile defines the drop probabilities across the range of delay-buffer occupancy, thereby supporting the RED process. For a packet to be dropped, it must match the drop profile. When a packet arrives, RED checks the queue fill level. If the fill level corresponds to a nonzero drop probability, the RED algorithm determines whether to drop the arriving packet. Depending on the drop probabilities, RED might drop packets aggressively long before the buffer becomes full, or it might drop only a few packets even if the buffer is almost full.

In drop profiles you configure queue threshold (fill level) and drop probability as paired values. The values can be either percentage values (segmented) or data points (interpolated). These two alternatives enable you to configure each drop probability at up to 64 queue threshold/drop-probability paired values, or to configure a profile represented as a series of line segments. For more information about configuring fill level and drop probabilities, see the JUNOS routing platform documentation.

Options

name name— Name for the drop profile.

Value— Text

`loss-priority` *loss-priority*— Packet loss priority.

Value—Text

Default— No value

Editing Level—Basic

`protocol` *protocol*— Protocol type for the drop profile map. The protocol type is ignored for priority levels greater than 2.

Value—Text

Default— No value

Editing Level—Basic

`drop-probability` *drop-probability*— Probability that a packet will be dropped.

Value— One of the following:

- If the drop profile type is segmented, specify the drop probability as a percentage. A value of 0 means that a packet will never be dropped, and a value of 100 means that all packets will be dropped. The range is 0–100.
- If the drop profile type is interpolated, specify a data point for packet drop probability in the range 0–100.
- Predefined parameter:
 - `fwEnterpriseMaxPriority`
 - `fwEnterpriseMinPriority`
 - `fwMaxPriority`
 - `fwMinPriority`
- Parameter of type percent

Default— No value

Editing Level—Basic

`drop-profile-type` *drop-profile-type*— Relationship between the queue threshold (fill level) and drop probability.

Value— One of the following:

- Predefined global parameter:
 - `interpolated`—Specifies values for interpolating relationship between queue fill level and drop probability
 - `segmented`—Specifies fill level and drop probability as percentages
- Parameter of type `dropProfileType`

Default— No value

Editing Level—Basic

`queue-threshold` *queue-threshold*— Fill level of the queue.

Value— One of the following:

- If the drop profile type is segmented, specify how full the queue is as a percentage.
- If the drop profile type is interpolated, specify a data point for mapping the queue fill percentage in the range 0–100.
- Parameter of type percent

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* service-class-name

Syntax

```
policies group name list name rule name service-class-name name {
    service-class-name service-class-name;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name service-class-name]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service class name action. You can configure service class name actions for PCMM policy rules.

Options

name *name*— Name of the service class name action.

Value— Text

service-class-name *service-class-name*—(Optional) Name of a service class on the CMTS device that specifies QoS parameters for a service flow.

Value— One of the following:

- Name of a service class
- String expression
- Parameter of type serviceClassName

Default— No value

Editing Level—Basic

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* stateful-firewall

Syntax

```
policies group name list name rule name stateful-firewall name {
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name stateful-firewall]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a stateful firewall action. Stateful firewall actions specify the action to take on packets that match the classify-traffic condition. You can configure stateful firewall actions for JUNOS ASP policy rules.

Options

`name name`— Name for the stateful firewall action.

Value— Text

`description description`—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* stateful-firewall *name* packet-action filter

Syntax

```
policies group name list name rule name stateful-firewall name packet-  
action filter {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name stateful-firewall name packet-  
action filter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Set the packet action for a stateful firewall to filter. The packet is not accepted and is not processed further.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* stateful-firewall *name* packet-action forward

Syntax

```
policies group name list name rule name stateful-firewall name packet-  
action forward {  
}
```

Hierarchy Level

```
[edit policies group name list name rule name stateful-firewall name packet-  
action forward]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Set the packet action for a stateful firewall to forward.

Options

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* stateful-firewall *name* packet-action parameter

Syntax

```
policies group name list name rule name stateful-firewall name packet-
action parameter {
    action action;
}
```

Hierarchy Level

```
[edit policies group name list name rule name stateful-firewall name packet-
action parameter]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Set the packet action for a stateful firewall to parameter. The action specified in the parameter is applied.

Options

`action action`—(Optional) Parameter that specifies the action to take on traffic.

Value— Parameter of type packetOperation.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* stateful-firewall *name* packet-action reject

Syntax

```
policies group name list name rule name stateful-firewall name packet-
action reject {
    message-type message-type;
}
```

Hierarchy Level

```
[edit policies group name list name rule name stateful-firewall name packet-
action reject]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Set the action for a stateful firewall to reject. The packet is not accepted, and a rejection message is returned; UDP sends an ICMP unreachable code, and TCP sends RST Reject action in stateful firewall.

Options

`message-type message-type`—(Optional) Type of ICMP destination unreachable message sent to the client.

Value— One of the following:

- String expression that matches a type of ICMP destination unreachable message supported on the router; for example:
 - "administratively-prohibited"
 - "bad-host-tos"
 - "bad-network-tos"
 - "host-prohibited"
 - "host-unknown"
 - "host-unreachable"
 - "network-prohibited"
 - "network-unknown"
 - "network-unreachable"
 - "port-unreachable"
 - "precedence-cutoff"
 - "precedence-violation"

- "protocol-unreachable"
- "source-host-isolated"
- "source-route-failed"
- "tcp-reset"—If you specify tcp-reset, a TCP reset message is sent if the packet is a TCP packet. Otherwise, nothing is sent.
- Parameter of type messageType

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* template-activation

Syntax

```
policies group name list name rule name template-activation name {
    template-name template-name;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name template-activation]
```

Release Information

Statement introduced in SRC Release 2.2.0

Description

Configure a template activation action. Use this action for CoA supporting devices.

Options

`name name`— Name for the template activation action.

Value— Text

`template-name template-name`—

Value—

Default— No value

Editing Level—Basic

`description description`—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* template-activation *name* variables

Syntax

```
policies group name list name rule name template-
activation name variables name {
    value value;
    type type;
}
```

Hierarchy Level

```
[edit policies group name list name rule name template-
activation name variables]
```

Release Information

Statement introduced in SRC Release 2.2.0

Options

name *name*—

Value— Text

value *value*—(Optional) Provide a value for a variable.

Value—

Default— No value

Editing Level—Basic

type *type*—(Optional) The variable type determines where you can use the variable.

Value— See the policy documentation in the *SRC-PE Services and Policies Guide* for a list of parameter types, where each type of parameter is used, and what each parameter is used to specify. Variable types are mapped to parameters types.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-class

Syntax

```
policies group name list name rule name traffic-class name {
    traffic-class traffic-class;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-class]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a traffic-class action. Use this action to put packets in a particular traffic class. You can configure traffic-class actions for JUNOS policy rules.

Options

`name name`— Name for the traffic-class action.

Value— Text

`traffic-class traffic-class`— Name of the traffic-class profile that is applied to a packet when it passes through the router.

Value— One of the following:

- Name of a traffic-class profile that is configured on the router
- Parameter of type trafficClassSpec

Default— No value

Editing Level—Basic

`description description`—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition

Syntax

```
policies group name list name rule name traffic-condition name {
    match-direction match-direction;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a classify-traffic condition. A classify-traffic condition contains values or fields that a packet must contain. If a policy rule does not contain a match condition, all packets are considered to match.

You can create classify-traffic conditions in JUNOS policy rules, in JUNOS ASP and JUNOS filter policy rules, and in PCMM policy rules.

Options

`name name`— Name for the classify-traffic condition.

Value— Text

`match-direction match-direction`—(Optional) Applies only to JUNOS ASP policy rules. Matches packets based on the direction of the packet flow. For stateful firewall actions, this value is used in place of the **policies group list *name* applicability** statement.

Value— One of the following:

- input
- output
- both (Both is invalid for NAT actions.)
- String expression
- Parameter of type matchDirection

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* application-protocol-condition

Syntax

```
policies group name list name rule name traffic-condition name application-
protocol-condition name {
    protocol protocol;
    application-protocol application-protocol;
    idle-timeout idle-timeout;
    dce-rpc-uuid dce-rpc-uuid;
    rpc-program-number rpc-program-number;
    snmp-command snmp-command;
    ttl-threshold ttl-threshold;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-
condition name application-protocol-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure application protocols for stateful firewall and NAT services to use in match condition rules. An application protocol defines application parameters by using information from network layer 3 and above. Examples of such applications are FTP and H.323.

Options

name name— Name for the application protocol condition.

Value— Text

protocol protocol—(Optional) Protocol matched by this classifier list.

Value— One of the following:

- Predefined parameter of type protocol

- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression

Default— No value

Editing Level—Basic

`application-protocol` *application-protocol*—(Optional) Application protocol to match.

Value— One of the following:

- Predefined global parameter:
 - `bootp`—BOOTP protocol
 - `dce_rpc`—DCE RPC protocol
 - `dce_rpc_portmap`—DCE RPC portmap
 - `dns`—DNS protocol
 - `exec`—Exec protocol
 - `ftp`—FTP protocol
 - `h323`—H.323 protocol
 - `icmp_app`—ICMP protocol
 - `iiop`—Internet Inter-ORB Protocol, a TCP protocol
 - `netbios`—NetBIOS protocol
 - `netshow`—NetShow protocol
 - `realaudio`—RealAudio protocol
 - `rpc`—RPC UDP or TCP protocols
 - `rpc_portmap`—RPC portmap protocol
 - `rtsp`—Real-Time Streaming Protocol
 - `shell`—Shell protocol
 - `snmp`—SNMP protocol
 - `sqlnet`—SQLNet protocol
 - `tftp`—Trivial File Transfer Protocol
 - `traceroute`—Traceroute protocol
 - `winframe`—WinFrame protocol
- String expression that matches an application protocol name supported on the router
- Map expression—You can use a map expression to define multiple attributes with one command. Maps are a list of `attributeName = value` pairs separated by commas and enclosed in curly brackets.

For example, the map `{applicationProtocol = "ftp", sourcePort = 123, inactivityTimeout = 60}` supplies the application protocol, source port, and inactivity timeout in one command. Another map `{applicationProtocol = "tcp", inactivityTimeout = 60, destinationPort = 80}` supplies the protocol, inactivity timeout, and destination port.

- Parameter of type `applicationProtocol`—You can add a map expression as the default value of the parameter.

Default— No value

Editing Level—Basic

`idle-timeout` *idle-timeout*—(Optional) Length of time the application is inactive before it times out.

Value— One of the following:

- Number of seconds in the range 4–65535
- Numeric expression
- Parameter of type `timeout`

Default— Unspecified; the router's default value is used

Editing Level—Basic

`dce-rpc-uuid` *dce-rpc-uuid*—(Optional) For the DCE RPC application protocol, specifies the universal unique identifier (UUID). For information about UUIDs, see <http://www.opengroup.org/onlinepubs/9629399/apdx.htm>.

Value— One of the following:

- Hex digits in the format `xxxxxxxx-xxxx-xxxx-xxxx-xxxxxxxxxxxx`
- Numeric expression
- Parameter of type `dceRpcUuid`

Default— `dceRpcUuid`

Editing Level—Basic

`rpc-program-number` *rpc-program-number*—(Optional) For the remote procedure call (RPC) application protocol, specifies an RPC program number.

Value— One of the following:

- Integer—RPC or DCE program number in the range 100000–400000
- Numeric expression
- Parameter of type `rpcProgramNumber`

Default— No value**Editing Level**—Basic

`snmp-command` *snmp-command*—(Optional) SNMP command for packet matching.

Value— One of the following:

- Predefined parameter:
 - `get`
 - `get_next`
 - `set`
 - `trap`
- String expression that matches an SNMP command supported on the router
- Parameter of type `snmpCommand`

Default— No value**Editing Level**—Basic

`ttl-threshold` *ttl-threshold*—(Optional) For the traceroute application protocol, specifies the traceroute time-to-live (TTL) threshold value. This value sets the acceptable level of network penetration for trace routing.

Value— One of the following:

- Integer in the range 0–255
- Numeric expression
- Parameter of type `traceRouteTtlThreshold`

Default— No value**Editing Level**—Basic**Required Privilege Level**

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* application-protocol-condition *name* proto-attr

Syntax

```
policies group name list name rule name traffic-condition name application-
protocol-condition name proto-attr {
    icmp-type icmp-type;
    icmp-code icmp-code;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-
condition name application-protocol-condition name proto-attr]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure ICMP packet type and code.

Options

`icmp-type icmp-type`—(Optional) ICMP packet type.

Value— One of the following:

- Integer in the range 0–255 that represents an ICMP packet type supported on the router
- Numeric expression
- Parameter of type icmpType

Default— No value

Editing Level—Basic

`icmp-code icmp-code`—(Optional) ICMP code

Value— One of the following:

- Integer in the range 0–255 that represents an ICMP code supported on the router
- Numeric expression
- Parameter of type icmpCode

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* application-protocol-condition *name* proto-attr destination-port port

Syntax

```
policies group name list name rule name traffic-condition name application-protocol-condition name proto-attr destination-port port {
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name application-protocol-condition name proto-attr destination-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching destination ports.

Options

from-port from-port—(Optional) Destination port

Value— One of the following:

- *service_port*—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* application-protocol-condition *name* proto-attr source-port port

Syntax

```
policies group name list name rule name traffic-condition name application-
protocol-condition name proto-attr source-port port {
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-
condition name application-protocol-condition name proto-attr source-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching source ports.

Options

from-port from-port—(Optional) Source port

Value— One of the following:

- *service_port*—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* destination-network group-network

Syntax

```
policies group name list name rule name traffic-condition name destination-
network group-network {
    network-specifier network-specifier;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-
condition name destination-network group-network]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify the destination network to match using a network specifier. For JUNOS ASP and JUNOSe IPv6 policy rules, you must specify destination networks in the network specifier format.

Options

`network-specifier network-specifier`—(Optional) Specifies an IP address and mask.

Value— Specify the subnet in one of the following formats:

- [not] < address > / < mask > or < address > / < prefix length >
 - Include *not* to indicate that the condition matches every address that is not in the specified subnet.
 - < prefix length > is a number in the range 0–32, and specifies how many of the first bits in the address specify the network
- For JUNOS ASP policies, you must enter network in the format: < address > / < prefix length >

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* destination-network network

Syntax

```
policies group name list name rule name traffic-condition name destination-
network network {
    ip-address ip-address;
    ip-mask ip-mask;
    ip-operation ip-operation;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-
condition name destination-network network]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify the destination network in IP address and mask format. You also use this statement to specify whether the software matches or does not match the IP address and mask.

Options

`ip-address ip-address`—(Optional) IP address of the source or destination network or host.

Value— One of the following:

- IP address
- Predefined global parameter:
 - `gateway_ipAddress`—IP address of the gateway as specified by the service object
 - `interface_ipAddress`—IP address of the router interface
 - `service_ipAddress`—IP address of the service as specified by the service object
 - `user_ipAddress`—IP address of the subscriber
 - `virtual_ipAddress`—Virtual portal address of the SAE that is used in redundant redirect server installations
- Expression—For NAT actions, you can enter a range of

- addresses; for example, 10.10.13.1..10.10.13.100
- Parameter of type address

Default— 0.0.0.0

Editing Level—Basic

`ip-mask` *ip-mask*—(Optional) IP address mask applied to the IP address.

Value— One of the following:

- IP address mask
- Predefined global parameter:
 - `interface_ipMask`—IP mask of the interface
 - `service_ipMask`—IP mask of the service as specified by the service object
 - `user_ipMask`—IP mask of the subscriber
- Parameter of type addressMask

Default— 255.255.255.255

Editing Level—Basic

`ip-operation` *ip-operation*—(Optional) Matches packets with an IP address and mask that either is equal or is not equal to the specified address and mask.

Value— One of the following:

- `is`—Matches the specified IP address and mask
- `is_not`—Matches any IP address and mask except the specified address and mask
- Parameter of type networkOperation

Default— `is`

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* icmp-condition

Syntax

```
policies group name list name rule name traffic-condition name icmp-condition {
    protocol protocol;
    protocol-operation protocol-operation;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
    icmp-type icmp-type;
    icmp-code icmp-code;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name icmp-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for the ICMP protocol.

`protocol protocol`— Protocol matched by this classifier list.

Value— One of the following:

- Predefined global parameter—Use a ? at the command line to see a list of valid protocols.
- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression
- Parameter of type protocol

Default— No value

Editing Level—Basic

`protocol-operation protocol-operation`—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - `is`—Matches packets that are equal to the specified protocol
 - `is_not`—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, `is_not` is not a valid option.
- Boolean expression:
 - `1`—`is`
 - `0`—`is_not`
- Parameter of type `protocolOperation`

Default— 1

Editing Level—Basic

`ip-flags ip-flags`—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type `ipFlags`

Default— 0

Editing Level—Basic

`ip-flags-mask ip-flags-mask`—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type `ipFlagsMask`

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOS routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression
- Parameter of type fragOffset

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`icmp-type` *icmp-type*—(Optional) Matches ICMP packet type.

Value— One of the following:

- Integer in the range 0–255 that represents an ICMP packet type supported on the router or CMTS device
- Numeric expression
- Parameter of type icmpType

Default— 255

Editing Level—Basic

`icmp-code` *icmp-code*—(Optional) Matches ICMP code

Value— One of the following:

- Integer in the range 0–255 that represents an ICMP code supported on the router or CMTS device
- Numeric expression
- Parameter of type icmpCode

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* igmp-condition

Syntax

```
policies group name list name rule name traffic-condition name igmp-condition {
    protocol protocol;
    protocol-operation protocol-operation;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
    igmp-type igmp-type;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name igmp-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for the IGMP protocol.

`protocol protocol`—Protocol matched by this classifier list.

Value— One of the following:

- Predefined global parameter—Use a ? at the command line to see a list of valid protocols.
- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression
- Parameter of type protocol

Default— No value

Editing Level—Basic

`protocol-operation protocol-operation`—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - `is`—Matches packets that are equal to the specified protocol
 - `is_not`—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, `is_not` is not a valid option.
- Boolean expression:
 - `1`—`is`
 - `0`—`is_not`
- Parameter of type `protocolOperation`

Default— 1

Editing Level—Basic

`ip-flags ip-flags`—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type `ipFlags`

Default— 0

Editing Level—Basic

`ip-flags-mask ip-flags-mask`—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type `ipFlagsMask`

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOSe routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression
- Parameter of type fragOffset

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`igmp-type` *igmp-type*—(Optional) IGMP packets that can be filtered by IGMP packet type or message name.

Value— One of the following:

- Integer in the range 1–255
- Numeric expression
- Parameter of type igmpType

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* ipsec-condition

Syntax

```
policies group name list name rule name traffic-condition name ipsec-condition
{
    spi spi;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
    protocol protocol;
    protocol-operation protocol-operation;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name ipsec-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for the IPSec protocol.

Options

spi spi—(Optional) For IPSec classifiers, specifies the authentication header (AH) or the encapsulating security payload (ESP) security parameter index (SPI). This option appears only in JUNOS policy rules.

Value— One of the following:

- Integer in the range 0–255
- Parameter of type ipSecSpi

Default— No value

Editing Level—Basic

`ip-flags` *ip-flags*—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type `ipFlags`

Default— 0

Editing Level—Basic

`ip-flags-mask` *ip-flags-mask*—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type `ipFlagsMask`

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOSe routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression
- Parameter of type `fragOffset`

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

`protocol protocol`— Protocol matched by this classifier list.

Value— One of the following:

- Predefined global parameter—Use a ? at the command line to see a list of valid protocols.
- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression
- Parameter of type protocol

Default— No value

Editing Level—Basic

`protocol-operation protocol-operation`—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - `is`—Matches packets that are equal to the specified protocol
 - `is_not`—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, `is_not` is not a valid option.
- Boolean expression:
 - 1—`is`
 - 0—`is_not`
- Parameter of type protocolOperation

Default— 1

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* parameter-protocol-condition

Syntax

```
policies group name list name rule name traffic-condition name parameter-
protocol-condition {
    protocol protocol;
    protocol-operation protocol-operation;
    tcp-flags tcp-flags;
    tcp-flags-mask tcp-flags-mask;
    spi spi;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name parameter-
protocol-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure protocol conditions that contain a parameter value for the protocol.

Options

`protocol protocol`—Parameter that is used to determine the protocol that this classifier matches.

Value—Parameter of type protocol. You must enter a parameter that has been created and has been committed.

Default—No value

Editing Level—Basic

`protocol-operation protocol-operation`—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - *is*—Matches packets that are equal to the specified protocol
 - *is_not*—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, *is_not* is not a valid option.
- Boolean expression:
 - 1—*is*
 - 0—*is_not*
- Parameter of type `protocolOperation`

Default— 1

Editing Level—Basic

`tcp-flags` *tcp-flags*—(Optional) Value of the TCP flags field in the IP header.

Value— One of the following:

- Integer in the range 0–63
- Numeric expression
- Parameter of type `tcpFlags`

Default— 0

Editing Level—Basic

`tcp-flags-mask` *tcp-flags-mask*—(Optional) Mask associated with TCP flags.

Value— One of the following:

- Integer in the range 0–63
- Numeric expression
- Parameter of type `tcpFlagsMask`

Default— 0

Editing Level—Basic

`spi` *spi*—(Optional) For IPSec classifiers, specifies the authentication header (AH) or the encapsulating security payload (ESP) security parameter index (SPI). This option appears only in JUNOS policy rules.

Value— One of the following:

- Integer in the range 0–255
- Parameter of type ipSecSpi

Default— No value

Editing Level—Basic

`ip-flags` *ip-flags*—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type ipFlags

Default— 0

Editing Level—Basic

`ip-flags-mask` *ip-flags-mask*—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type ipFlagsMask

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOS routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression

- Parameter of type fragOffset

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* parameter-protocol-condition proto-attr

Syntax

```
policies group name list name rule name traffic-condition name parameter-
protocol-condition proto-attr {
    icmp-type icmp-type;
    icmp-code icmp-code;
    igmp-type igmp-type;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name parameter-
protocol-condition proto-attr]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure ICMP packet type and code and IGMP type.

Options

`icmp-type icmp-type`—(Optional) ICMP packet type

Value— One of the following:

- Integer in the range 0–255 that represents an ICMP packet type supported on the router
- Numeric expression
- Parameter of type icmpType

Default— No value

Editing Level—Basic

`icmp-code icmp-code`—(Optional) ICMP code

Value— One of the following:

- Integer in the range 0–255 that represents an ICMP code supported on the router
- Numeric expression
- Parameter of type icmpCode

Default— No value

Editing Level—Basic

`igmp-type igmp-type`—(Optional) IGMP packets that can be filtered by IGMP packet type or message name.

Value— One of the following:

- Integer in the range 1–255
- Numeric expression
- Parameter of type igmpType

Default— 255

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* parameter-protocol-condition proto-attr destination-port port

Syntax

```
policies group name list name rule name traffic-condition name parameter-
protocol-condition proto-attr destination-port port {
    port-operation port-operation;
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name parameter-
protocol-condition proto-attr destination-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for ports.

Options

`port-operation port-operation`—(Optional) Matches packets with a port that is either equal or not equal to the specified port.

Value— One of the following:

- Predefined global parameter:
 - `eq`—Matches packets that contain the specified port number
 - `neq`—Matches any packet except those that contain the specified port number
- String
- Parameter of type `portOperation`

Default— No value

Editing Level—Basic

`from-port` *from-port*—(Optional) Source or destination port.

Value— One of the following:

- `service_port`—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

One of the following:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Note that PCMM IO2 classifiers do not support port ranges. If you are using PCMM IO2 and you enter a range of port numbers, the software cannot translate the port, and it throws an exception.

PCMM IO3 classifiers do support port ranges.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* parameter-protocol-condition proto-attr source-port port

Syntax

```
policies group name list name rule name traffic-condition name parameter-
protocol-condition proto-attr source-port port {
    port-operation port-operation;
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name parameter-
protocol-condition proto-attr source-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for ports.

Options

`port-operation port-operation`—(Optional) Matches packets with a port that is either equal or not equal to the specified port.

Value— One of the following:

- Predefined global parameter:
 - `eq`—Matches packets that contain the specified port number
 - `neq`—Matches any packet except those that contain the specified port number
- String
- Parameter of type `portOperation`

Default— No value

Editing Level—Basic

`from-port` *from-port*—(Optional) Source or destination port.

Value— One of the following:

- `service_port`—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

One of the following:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Note that PCMM IO2 classifiers do not support port ranges. If you are using PCMM IO2 and you enter a range of port numbers, the software cannot translate the port, and it throws an exception.

PCMM IO3 classifiers do support port ranges.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* protocol-condition

Syntax

```
policies group name list name rule name traffic-condition name protocol-
condition {
    protocol protocol;
    protocol-operation protocol-operation;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name protocol-
condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure protocol conditions that do not include port conditions.

`protocol protocol`— Protocol matched by this classifier list.

Value— One of the following:

- Predefined global parameter—Use a ? at the command line to see a list of valid protocols.
- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression
- Parameter of type protocol

Default— No value

Editing Level—Basic

`protocol-operation protocol-operation`—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - `is`—Matches packets that are equal to the specified protocol
 - `is_not`—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, `is_not` is not a valid option.
- Boolean expression:
 - `1`—`is`
 - `0`—`is_not`
- Parameter of type `protocolOperation`

Default— 1

Editing Level—Basic

`ip-flags ip-flags`—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type `ipFlags`

Default— 0

Editing Level—Basic

`ip-flags-mask ip-flags-mask`—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type `ipFlagsMask`

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOSe routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression
- Parameter of type fragOffset

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* protocol-port-condition

Syntax

```
policies group name list name rule name traffic-condition name protocol-port-
condition {
    protocol protocol;
    protocol-operation protocol-operation;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name protocol-
port-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for protocols and ports.

protocol protocol— Protocol matched by this classifier list.

Value— One of the following:

- Predefined global parameter—Use a ? at the command line to see a list of valid protocols.
- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression
- Parameter of type protocol

Default— No value

Editing Level—Basic

`protocol-operation protocol-operation`—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - `is`—Matches packets that are equal to the specified protocol
 - `is_not`—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, `is_not` is not a valid option.
- Boolean expression:
 - `1`—`is`
 - `0`—`is_not`
- Parameter of type `protocolOperation`

Default— 1

Editing Level—Basic

`ip-flags ip-flags`—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type `ipFlags`

Default— 0

Editing Level—Basic

`ip-flags-mask ip-flags-mask`—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type `ipFlagsMask`

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOSe routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression
- Parameter of type fragOffset

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* protocol-port-condition destination-port port

Syntax

```
policies group name list name rule name traffic-condition name protocol-port-
condition destination-port port {
    port-operation port-operation;
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name protocol-
port-condition destination-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for ports.

Options

`port-operation port-operation`—(Optional) Matches packets with a port that is either equal or not equal to the specified port.

Value— One of the following:

- Predefined global parameter:
 - `eq`—Matches packets that contain the specified port number
 - `neq`—Matches any packet except those that contain the specified port number
- String
- Parameter of type `portOperation`

Default— No value

Editing Level—Basic

`from-port` *from-port*—(Optional) Source or destination port.

Value— One of the following:

- `service_port`—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

One of the following:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Note that PCMM IO2 classifiers do not support port ranges. If you are using PCMM IO2 and you enter a range of port numbers, the software cannot translate the port, and it throws an exception.

PCMM IO3 classifiers do support port ranges.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* protocol-port-condition source-port port

Syntax

```
policies group name list name rule name traffic-condition name protocol-port-
condition source-port port {
    port-operation port-operation;
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name protocol-
port-condition source-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for ports.

Options

`port-operation port-operation`—(Optional) Matches packets with a port that is either equal or not equal to the specified port.

Value— One of the following:

- Predefined global parameter:
 - `eq`—Matches packets that contain the specified port number
 - `neq`—Matches any packet except those that contain the specified port number
- String
- Parameter of type `portOperation`

Default— No value

Editing Level—Basic

`from-port` *from-port*—(Optional) Source or destination port.

Value— One of the following:

- `service_port`—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

One of the following:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Note that PCMM IO2 classifiers do not support port ranges. If you are using PCMM IO2 and you enter a range of port numbers, the software cannot translate the port, and it throws an exception.

PCMM IO3 classifiers do support port ranges.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* source-network group-network

Syntax

```
policies group name list name rule name traffic-condition name source-
network group-network {
    network-specifier network-specifier;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name source-
network group-network]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify the source network to match using a network specifier. For JUNOS ASP and JUNOSe IPv6 policy rules, you must specify source networks in the network specifier format.

Options

`network-specifier network-specifier`—(Optional) Specifies an IP address and mask.

Value— Specify the subnet in one of the following formats:

- [not] < address > / < mask > or < address > / < prefix length >
 - Include *not* to indicate that the condition matches every address that is not in the specified subnet.
 - < prefix length > is a number in the range 0–32, and specifies how many of the first bits in the address specify the network
- For JUNOS ASP policies, you must enter network in the format: < address > / < prefix length >

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* source-network network

Syntax

```
policies group name list name rule name traffic-condition name source-
network network {
    ip-address ip-address;
    ip-mask ip-mask;
    ip-operation ip-operation;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name source-
network network]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Specify the source network in IP address and mask format. You also use this statement to specify whether the software matches or does not match the IP address and mask.

Options

`ip-address ip-address`—(Optional) IP address of the source or destination network or host.

Value— One of the following:

- IP address
- Predefined global parameter:
 - `gateway_ipAddress`—IP address of the gateway as specified by the service object
 - `interface_ipAddress`—IP address of the router interface
 - `service_ipAddress`—IP address of the service as specified by the service object
 - `user_ipAddress`—IP address of the subscriber
 - `virtual_ipAddress`—Virtual portal address of the SAE that is used in redundant redirect server installations
- Expression—For NAT actions, you can enter a range of

- addresses; for example, 10.10.13.1..10.10.13.100
- Parameter of type address

Default— 0.0.0.0

Editing Level—Basic

`ip-mask` *ip-mask*—(Optional) IP address mask applied to the IP address.

Value— One of the following:

- IP address mask
- Predefined global parameter:
 - `interface_ipMask`—IP mask of the interface
 - `service_ipMask`—IP mask of the service as specified by the service object
 - `user_ipMask`—IP mask of the subscriber
- Parameter of type addressMask

Default— 255.255.255.255

Editing Level—Basic

`ip-operation` *ip-operation*—(Optional) Matches packets with an IP address and mask that either is equal or is not equal to the specified address and mask.

Value— One of the following:

- `is`—Matches the specified IP address and mask
- `is_not`—Matches any IP address and mask except the specified address and mask
- Parameter of type networkOperation

Default— `is`

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* tcp-condition

Syntax

```
policies group name list name rule name traffic-condition name tcp-condition {
    tcp-flags tcp-flags;
    tcp-flags-mask tcp-flags-mask;
    protocol protocol;
    protocol-operation protocol-operation;
    ip-flags ip-flags;
    ip-flags-mask ip-flags-mask;
    fragment-offset fragment-offset;
    packet-length packet-length;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name tcp-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for the TCP protocol.

Options

`tcp-flags tcp-flags`—(Optional) Value of the TCP flags field in the IP header.

Value— One of the following:

- Integer in the range 0–63
- Numeric expression
- Parameter of type tcpFlags

Default— 0

Editing Level—Basic

`tcp-flags-mask` *tcp-flags-mask*—(Optional) Mask associated with TCP flags.

Value— One of the following:

- Integer in the range 0–63
- Numeric expression
- Parameter of type `tcpFlagsMask`

Default— 0

Editing Level—Basic

`protocol` *protocol*— Protocol matched by this classifier list.

Value— One of the following:

- Predefined global parameter—Use a ? at the command line to see a list of valid protocols.
- Protocol number in the range 0–257
- For PCMM classifiers, there are two special protocol values:
 - 256 matches traffic that has any IP protocol value
 - 257 matches both TCP and UDP traffic
- String expression
- Parameter of type `protocol`

Default— No value

Editing Level—Basic

`protocol-operation` *protocol-operation*—(Optional) Matches packets with the protocol that is either equal or not equal to the specified protocol.

Value— One of the following:

- Predefined global parameter:
 - `is`—Matches packets that are equal to the specified protocol
 - `is_not`—Matches any packets except those that are equal to the specified protocol. If you are configuring an ICMP, IGMP, IPSec, or TCP classifier, `is_not` is not a valid option.
- Boolean expression:
 - 1—`is`
 - 0—`is_not`
- Parameter of type `protocolOperation`

Default— 1

Editing Level—Basic

`ip-flags` *ip-flags*—(Optional) Value of the IP flags field in the IP header.

Value— One of the following:

- 0—Reserved
- 1—Do not fragment
- 2—More fragments
- Numeric expression
- Parameter of type `ipFlags`

Default— 0

Editing Level—Basic

`ip-flags-mask` *ip-flags-mask*—(Optional) Mask that is associated with the IP flag.

Value— One of the following:

- Integer in the range 0–7
- Numeric expression
- Parameter of type `ipFlagsMask`

Default— 0

Editing Level—Basic

`fragment-offset` *fragment-offset*—(Optional) Value of the fragment offset field.

Value— One of the following:

- For JUNOS routers:
 - 0—Equal to 0
 - 1—Equal to 1
 - 2..8191
- For JUNOS routing platforms, integer in the range 0–8191
- Numeric expression
- Parameter of type `fragOffset`

Default— No value

Editing Level—Basic

`packet-length` *packet-length*—(Optional) Matches on length of the packet. The

length refers only to the IP packet, including the packet header, and does not include any layer 2 encapsulation overhead. This option is available only in JUNOS policy rules.

Value— One of the following:

- Number of bytes; all positive numbers and 0 are valid
- Parameter of type packetLength

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* tcp-condition destination-port port

Syntax

```
policies group name list name rule name traffic-condition name tcp-
condition destination-port port {
    port-operation port-operation;
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name tcp-
condition destination-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for ports.

Options

port-operation port-operation—(Optional) Matches packets with a port that is either equal or not equal to the specified port.

Value— One of the following:

- Predefined global parameter:
 - eq—Matches packets that contain the specified port number
 - neq—Matches any packet except those that contain the specified port number
- String
- Parameter of type portOperation

Default— No value

Editing Level—Basic

`from-port` *from-port*—(Optional) Source or destination port.

Value— One of the following:

- `service_port`—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

One of the following:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Note that PCMM IO2 classifiers do not support port ranges. If you are using PCMM IO2 and you enter a range of port numbers, the software cannot translate the port, and it throws an exception.

PCMM IO3 classifiers do support port ranges.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* tcp-condition source-port port

Syntax

```
policies group name list name rule name traffic-condition name tcp-
condition source-port port {
    port-operation port-operation;
    from-port from-port;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name tcp-
condition source-port port]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure matching conditions for ports.

Options

port-operation port-operation—(Optional) Matches packets with a port that is either equal or not equal to the specified port.

Value— One of the following:

- Predefined global parameter:
 - eq—Matches packets that contain the specified port number
 - neq—Matches any packet except those that contain the specified port number
- String
- Parameter of type portOperation

Default— No value

Editing Level—Basic

`from-port` *from-port*—(Optional) Source or destination port.

Value— One of the following:

- `service_port`—A predefined global parameter that is the port of the service as specified by the service object
- Integer in the range 0–65535
- Expression—A range of port numbers; for example, 10..20
- Parameter of type port

Use a range of ports to specify port numbers that are greater than or less than a specified port number. For example:

One of the following:

- To set a range of ports that is greater than 10, use 11..65535.
- To set a range of ports that is less than 200, use 0..199.

Note that PCMM IO2 classifiers do not support port ranges. If you are using PCMM IO2 and you enter a range of port numbers, the software cannot translate the port, and it throws an exception.

PCMM IO3 classifiers do support port ranges.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* tos

Syntax

```
policies group name list name rule name traffic-condition name tos {
    tos-byte tos-byte;
    tos-byte-mask tos-byte-mask;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name tos]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Define a particular traffic flow to the service's network for the DA IP field in the IP packet. The CoS feature on JUNOS routing platforms supports DiffServ as well as six-bit IP header ToS byte settings. The DiffServ protocol uses the ToS byte in the IP header. The most significant six bits of this byte form the Differentiated Services code point (DSCP). The CoS feature uses DSCPs to determine the forwarding class associated with each packet. It also uses the ToS byte and ToS byte mask to determine IP precedence.

`tos-byte tos-byte`—(Optional) For IPv4 packets, matches the value of the ToS field in the IP packet header. For IPv6 packets, matches the traffic-class field in the IP packet header.

Value— One of the following:

- Integer in the range 0–255; uses whole 8 bits of the ToS byte
- Numeric expression
- Parameter of type `tosByte`

Default— 0

Editing Level—Basic

`tos-byte-mask tos-byte-mask`—(Optional) Mask associated with the ToS byte.

Value— One of the following:

- Integer values of 224, 252, 255 for JUNOS; values of 224, 252 for JUNOS

For IPv4:

- 255 (tos)—Specifies the use of the whole 8 bits of the ToS byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the ToS byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the ToS byte; tos-byte range is 0–7.

For IPv6:

- 255 (tcfield)—Specifies the use of the whole 8 bits of the traffic-class byte; tos-byte range is 0–255.
- 252 (dsfield)—Specifies the use of the upper 6 bits of the traffic-class byte; tos-byte range is 0–63.
- 224 (precedence)—Specifies the use of the upper 3 bits of the traffic-class byte; tos-byte range is 0–7.
- Numeric expression
- Parameter of type tosByteMask

Default— 0

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-condition *name* traffic-match-condition

Syntax

```
policies group name list name rule name traffic-condition name traffic-match-
condition {
    forwarding-class forwarding-class;
    interface-group interface-group;
    source-class source-class;
    destination-class destination-class;
    allow-ip-options allow-ip-options;
    traffic-class traffic-class;
    color color;
    user-packet-class user-packet-class;
    destination-local-interface destination-local-interface;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-condition name traffic-
match-condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure match conditions for a classify-traffic condition.

Options

`forwarding-class forwarding-class`—(Optional) Matches packets based on the name of a forwarding class

Value— One of the following:

- String expression that matches a forwarding class on the router; for example, "assured-forwarding," "best-effort," "expedited-forwarding," or "network-control"
- Parameter of type forwardingClass
- Predefined runtime parameter: fc_assured, fc_besteffort, fc_expedited

Default— No value

Editing Level—Basic

`interface-group` *interface-group*—(Optional) Matches packets based on the interface group on which the packet was received.

Value— One of the following:

- Integer in the range 0–4294967295
- Numeric expression
- Parameter of type `interfaceGroup`

Default— No value

Editing Level—Basic

`source-class` *source-class*—(Optional) Matches packets based on source class. For JUNOS filter policies, a source class is a set of source prefixes grouped together and given a class name. You would usually match source and destination classes for output firewall filters. Note that you cannot match on both source class and destination class at the same time. You must choose one or the other. For JUNOSe policies, a source class classifies on packets associated with a route class based on the packet's source address.

Value— One of the following:

- For JUNOS policies, string expression that matches a source class that is configured on the router; for example, "gold-class"
- For JUNOSe policies, route-class in the range 0-255.
- Parameter of type `trafficClassSpec`

Default— No value

Editing Level—Basic

`destination-class` *destination-class*—(Optional) Matches packets based on destination class. For JUNOS filter policies, a destination class is a set of destination prefixes grouped together and given a class name. You would usually match source and destination classes for output firewall filters. Note that you cannot match on both source class and destination class at the same time. You must choose one or the other. For JUNOSe policies, a destination class classifies on packets associated with a route class based on the packet's destination address.

Value— One of the following:

- For JUNOS policies, string expression that matches a

destination class that is configured on the router; for example, "gold-class"

- For JUNOS policies, route-class in the range 0-255.
- Parameter of type trafficClassSpec

Default— No value

Editing Level—Basic

`allow-ip-options` *allow-ip-options*—(Optional) Matches on IP options.

Value— One of the following:

- Numeric value of the IP option
- String expression that matches a text synonym of an IP option on the router; for example, "loose-source-route," "record-route," "router-alert," "strict-source-route," or "timestamp"
- Parameter of type allowIpOptions

Default— No value

Editing Level—Basic

`traffic-class` *traffic-class*—(Optional) Matches packets based on traffic class.

Value—Text

Default— No value

Editing Level—Basic

`color` *color*—(Optional) Matches packets based on packet color. Matches packets based on packet color for JUNOS policy rules.

Value— One of the following:

- Integer in the range 1-3
 - 1—green
 - 2—yellow
 - 3—red
- Parameter of type color

One of the following:

- Integer in the range 1-3
 - 1—green
 - 2—yellow
 - 3—red

- Parameter of type color

Default— No value No value

Editing Level—Basic

`user-packet-class` *user-packet-class*—(Optional) Matches packets based on the user packet class action number.

Value— One of the following:

- Integer in the range 0–15
- Parameter of type userPacketClass

Default— No value

Editing Level—Basic

`destination-local-interface` *destination-local-interface*—(Optional)
Matches packets based on whether the destination interface is local.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-mirror

Syntax

```
policies group name list name rule name traffic-mirror name {
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-mirror]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a traffic-mirror action. Use this action to mirror traffic from a destination to a source or from a source to a destination. You can configure traffic-mirror actions for JUNOS input policy rules.

Before you use traffic-mirror actions, you must configure forwarding options on JUNOS routing platforms for port mirroring and next-hop group. For information about these features, see the *JUNOS Policy Framework Configuration Guide*.

The policy rule that contains a traffic-mirror action must comply with these conditions:

- It must be combined with forward actions in the same rule. One of the forward actions must accept the traffic if the source and/or destination IP addresses do not match the conditions.
- It contains either no classify-traffic condition or only one classify-traffic condition.
- It can be marked for accounting.

Options

name *name*— Name of the traffic-mirror action.

Value— Text

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* traffic-shape

Syntax

```
policies group name list name rule name traffic-shape name {
    rate rate;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name traffic-shape]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a traffic-shape action. Traffic-shape actions specify the maximum rate of traffic transmitted on an interface. You can create traffic-shape actions in JUNOS shaping policy rules.

Options

`name name`— Name of the traffic-shape action.

Value— Text

`rate rate`—(Optional) Maximum transmission rate.

Value— One of the following:

- Predefined global parameter `interface_speed`—Speed of the subscriber's router interface
- Bits per second in the range 1000–320000000000
- Numeric expression
- Parameter of type `rate`

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* list *name* rule *name* user-packet-class

Syntax

```
policies group name list name rule name user-packet-class name {
    user-packet-class user-packet-class;
    description description;
}
```

Hierarchy Level

```
[edit policies group name list name rule name user-packet-class]
```

Release Information

Statement introduced in SRC Release 2.0.0

Description

Configure a user packet class action. Use this action to put packets in a particular user packet class. You can configure user packet class actions for JUNOS policy rules.

Options

name *name*— Name for the user packet class action.

Value— Text

user-packet-class *user-packet-class*—(Optional) User packet class that is applied to a packet when it passes through the router.

Value— One of the following:

- Integer in the range 0–15
- Parameter of type `userPacketClass`

Default— No value

Editing Level—Basic

description *description*—(Optional) Description of the object that you are configuring.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

policies group *name* local-parameters

Syntax

```
policies group name local-parameters name {
    description description;
    default-value default-value;
    type type;
}
```

Hierarchy Level

```
[edit policies group name local-parameters]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Define a local parameter. Local parameters are available only for the policy group in which the parameter is defined.

Options

name *name*— Name of the parameter

Value— Text

description *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

default-value *default-value*—(Optional) Value that the policy engine uses if no other values are provided during the parameter value acquisition process. If other values are provided to the policy engine but problems are encountered, the default value for the parameter is not used. The policy engine generates an error message.

Value— Valid value for the parameter type. See the policy

documentation in the *SRC-PE Services and Policies Guide* for valid values for each parameter type.

Default— No value

Editing Level—Basic

`type type`—(Optional) Type of attribute for which you can use the parameter. The parameter type determines where you can use the parameter.

Value— See the policy documentation in the *SRC-PE Services and Policies Guide* for a list of parameter types, where each type of parameter is used, and what each parameter is used to specify.

Default— No value

Editing Level—Basic

Required Privilege Level

service

Required Editing Level

Basic

Subscriber CLI

The following table summarizes the SRC command-line interface (SRC CLI) for configuring subscribers. Configuration statements are listed in alphabetical order.

Subscriber CLI Configuration Statements
subscribers retailer
subscribers retailer name info
subscribers retailer name manager
subscribers retailer name schedule
subscribers retailer name schedule name event
subscribers retailer name schedule name event name action
subscribers retailer name schedule name event name action name attribute
subscribers retailer name schedule name event name except
subscribers retailer name schedule name event name except name from
subscribers retailer name schedule name event name except name to
subscribers retailer name schedule name event name from
subscribers retailer name schedule name event name to
subscribers retailer name subscriber-folder
subscribers retailer name subscriber-folder folder-name device
subscribers retailer name subscriber-folder folder-name device device-name manager
subscribers retailer name subscriber-folder folder-name device device-name schedule
subscribers retailer name subscriber-folder folder-name device device-name schedule name event
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name action
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name action name attribute

<u>subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name device device-name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name device device-name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name device device-name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name admission-control</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name manager</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name action</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name from</u>

<u>subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name access name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name manager</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name action</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name device device-name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name info</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name manager</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name action</u>

<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name admission-control</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name manager</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name action</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name from</u>

<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name access name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name manager</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name action</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name manager</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name action</u>

<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name site name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name enterprise name vpn</u>
<u>subscribers retailer name subscriber-folder folder-name manager</u>
<u>subscribers retailer name subscriber-folder folder-name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name action</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name admission-control</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name info</u>

<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name action</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name action name attribute</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except name from</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except name to</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name from</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name to</u>
<u>subscribers retailer name subscriber-folder folder-name subscriber name subscription</u>
<u>subscribers retailer name subscriber-folder folder-name subscription</u>
<u>subscribers retailer name subscription</u>
<u>subscribers retailer name vpn</u>

subscribers retailer

Syntax

```
subscribers retailer name {
    domain-name [domain-name...];
    authentication-plug-in [authentication-plug-in...];
    dhcp-authentication-plug-in [dhcp-authentication-plug-in...];
    tracking-plug-in [tracking-plug-in...];
    maximum-login maximum-login;
    session-timeout session-timeout;
    scope [scope...];
    imported-extranet [imported-extranet...];
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a retailer subscriber.

Options

name *name*— Name of the retailer.

Value— Text

domain-name [*domain-name...*]— Domain names associated with the retailer.

Value— Domain name in the format `domainName.domainExtension`.
For example: `virneo.com`.

Default— No value

Editing Level—Basic

authentication-plug-in [*authentication-plug-in...*]—(Optional) Single

authentication plug-in or a list of plug-ins used to authenticate subscribers who log in to the domains specified for this retailer. If you do not specify a plug-in for the retailer, the SAE uses the default retailer authentication plug-in.

Value— Single authentication plug-in or a list of plug-ins

Default— No value

Editing Level—Basic

`dhcp-authentication-plug-in [dhcp-authentication-plug-in...]`—(Optional) Single authentication plug-in or a list of plug-ins used to authenticate DHCP address requests for subscribers who log in to the domains specified for this retailer. If you do not specify a plug-in for the retailer, the SAE uses the default retailer DHCP authentication plug-in.

Value— Single authentication plug-in or a list of plug-ins

Default— No value

Editing Level—Basic

`tracking-plug-in [tracking-plug-in...]`—(Optional) Single tracking plug-in or a list of tracking plug-ins used to track subscriber sessions associated with this retailer. If you do not specify a plug-in for the retailer, the SAE uses the global subscriber tracking plug-in.

Value— Single tracking plug-in or a list of tracking plug-ins

Default— No value

Editing Level—Basic

`maximum-login maximum-login`—(Optional) Maximum number of concurrent logins for subscribers associated with this object. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Integer in the range 0–2147483647

Default— No value

Editing Level—Basic

`session-timeout session-timeout`—(Optional) Timeout for subscriber sessions. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Number of seconds in the range 0–2147483647

Default— No value

Editing Level—Basic

`scope [scope...]`—(Optional) Service scope(s) assigned to subscribers. By default, this

value is inherited from parent objects. However, if you specify a value here, it overrides the default for this subscriber and all subordinate objects.

Value— Single service or a list of scopes

Default— No value

Editing Level—Basic

`imported-extranet [imported-extranet . . .]`—(Optional) Extranet exported by another retailer or enterprise.

Value— DN of the extranet

Default— No value

Editing Level—Basic

`substitution [substitution . . .]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* info

Syntax

```
subscribers retailer name info {
    contact contact;
    e-mail e-mail;
    url url;
}
```

Hierarchy Level

```
[edit subscribers retailer name info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure contact information for the retailer.

Options

`contact contact`—(Optional) Name of the contact person at the retailer.

Value— Text

Default— No value

Editing Level—Basic

`e-mail e-mail`—(Optional) E-mail address of the contact person at the retailer.

Value— E-mail address

Default— No value

Editing Level—Basic

`url url`—(Optional) URL of the retailer.

Value— URL

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* manager

Syntax

```
subscribers retailer name manager name {
    role [(administrator | subscription | substitution | activation |
vpn)...];
    encrypted-password encrypted-password;
    plain-text-password;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation | vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a privilege level, the manager has read-only access to associated objects.

Value

- *administrator*— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.
- *subscription*— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- *substitution*— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and

accesses.

- `activation`— Activation managers can activate and deactivate subscriptions.
- `vpn`— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- `crypt`—Style is `/etc/passwd`
- `sha`—Secure hash algorithm
- `md5`—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule

Syntax

```
subscribers retailer name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event

Syntax

```
subscribers retailer name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name*— Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* action

Syntax

```
subscribers retailer name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.
- *deny-deactivate*— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to

services that have an authorization plug-in configured.

Default— No value
Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text
Default— No value
Editing Level—Basic

`substitution [substitution. . .]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name schedule name event name action name attribute (sessionName |
sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- **sessionName**— Name of the service session.
- **sessionTag**— Tag that can be used for accounting purposes.
- **sessionTimeout**— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- **downStreamBandwidth**— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- **upStreamBandwidth**— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* except

Syntax

```
subscribers retailer name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

`hour hour`—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute minute`—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month day-of-month`—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* from

Syntax

```
subscribers retailer name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE

- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* schedule *name* event *name* to

Syntax

```
subscribers retailer name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated **from** or **to** time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23
Default— *
Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31
Default— *
Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder

Syntax

```
subscribers retailer name subscriber-folder folder-name {
    maximum-login maximum-login;
    session-timeout session-timeout;
    scope [scope...];
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a subscriber folder. You can create subscriber folders for retailers, existing subscriber folders, enterprises, and sites. You must create a subscriber folder in a retailer object before you can add other types of subscribers.

Options

folder-name folder-name— Name of the subscriber folder.

Value— Text

maximum-login maximum-login—(Optional) Maximum number of concurrent logins for subscribers associated with this object. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Integer in the range 0–2147483647

Default— No value

Editing Level—Basic

session-timeout session-timeout—(Optional) Timeout for subscriber sessions. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Number of seconds in the range 0–2147483647

Default— No value

Editing Level—Basic

`scope [scope . . .]`—(Optional) Service scope(s) assigned to subscribers. By default, this value is inherited from parent objects. However, if you specify a value here, it overrides the default for this subscriber and all subordinate objects.

Value— Single service or a list of scopes

Default— No value

Editing Level—Basic

`substitution [substitution . . .]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value > .` For example, `bandwidth = 1000000.`

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name {
    display-name display-name;
    maximum-login maximum-login;
    accounting-user-id accounting-user-id;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a device subscriber for subscriber sessions that manage the forwarding interface on JUNOS routing platforms and the router pseudo-subscriber on JUNOSe routers.

Options

device-name device-name— Name of the device subscriber.

Value— Text

display-name display-name—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

maximum-login maximum-login—(Optional) Maximum number of concurrent logins for subscribers associated with this object. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Integer in the range 0–2147483647

Default— No value

Editing Level—Basic

`accounting-user-id` *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name manager name {
    role [(administrator | subscription | substitution | activation | vpn)...];
    encrypted-password encrypted-password;
    plain-text-password;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation | vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name* — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.

- `deny-deactivate`— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31
Default— *
Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)

- *hh*—Hour of the day in the range of 0–23
- *mm*—Minutes past the hour in the range of 0–59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23
Default— *
Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31
Default— *
Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

`hour` *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* device *device-name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name device device-name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name device device-name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name {
    display-name display-name;
    accounting-user-id accounting-user-id;
    description description;
    scope [scope...];
    imported-extranet [imported-extranet...];
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an enterprise subscriber.

Options

name *name*— Name of the enterprise subscriber

Value— Text

display-name *display-name*—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

accounting-user-id *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the

same ID.

Value— Text
Default— No value
Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text
Default— No value
Editing Level—Basic

`scope` [*scope . . .*]—(Optional) Service scope(s) assigned to subscribers. By default, this value is inherited from parent objects. However, if you specify a value here, it overrides the default for this subscriber and all subordinate objects.

Value— Single service or a list of scopes
Default— No value
Editing Level—Basic

`imported-extranet` [*imported-extranet . . .*]—(Optional) Extranet exported by another retailer or enterprise.

Value— DN of the extranet
Default— No value
Editing Level—Basic

`substitution` [*substitution . . .*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form < parameter name > = < value > . For example, `bandwidth = 1000000`.
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name access name {
    routing-protocol routing-protocol;
    interface-alias interface-alias;
    interface-description interface-description;
    interface-name interface-name;
    unique-id unique-id;
    port-id port-id;
    device-name device-name;
    display-name display-name;
    accounting-user-id accounting-user-id;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name access]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an access. You can configure an access for an enterprise or for a site. An access determines the way that the enterprise or site accesses Internet services, and specifies a set of services that are available to the enterprise or site.

Options

name name— Name of the access.

Value— Text

routing-protocol routing-protocol—(Optional) Routing protocol used at the enterprise or site. If you build a custom enterprise manager application, you can access this information through the enterprise portal APIs.

Value— Routing protocol

Default— No value

Editing Level—Basic

`interface-alias` *interface-alias*—(Optional) Description of the router interface. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— Interface description that is configured on the router.

Default— No value

Editing Level—Basic

`interface-description` *interface-description*—(Optional) Name of the interface that SNMP uses. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— One of the following:

- For JUNOSe routers, the format of the description is `ip < slot > / < port > . < subinterface >`
- On the JUNOS routing platform, interface description is the same as `interfaceName`

Default— No value

Editing Level—Basic

`interface-name` *interface-name*—(Optional) Name of the interface. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— One of the following:

- Name of the interface in your router CLI syntax.
- `FORWARDING_INTERFACE` for routing instance (used by traffic mirroring).

Default— No value

Editing Level—Basic

`unique-id` *unique-id*—(Optional) Unique identifier of the router. You can use this option to allow subscriber classification scripts to match interfaces reported from the

network to be matched with the corresponding access.

Value— Index of the router in the SNMP table for all interfaces.

Default— No value

Editing Level—Basic

`port-id` *port-id*—(Optional) NAS port ID reported by the JUNOS router through COPS. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— Includes the interface name and additional layer 2 information.

Default— No value

Editing Level—Basic

`device-name` *device-name*—(Optional) Name of the router or other device.

Value— Name of the device

Default— No value

Editing Level—Basic

`display-name` *display-name*—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

`accounting-user-id` *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* admission-control

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name access name admission-control {
    downstream-provisioned-rate downstream-provisioned-rate;
    upstream-provisioned-rate upstream-provisioned-rate;
    downstream-sync-rate downstream-sync-rate;
    upstream-sync-rate upstream-sync-rate;
    congestion-points [congestion-points...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name access name admission-control]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure bandwidths for subscribers that the SRC-ACP manages.

Options

downstream-provisioned-rate downstream-provisioned-rate—(Optional)
Provisioned downstream bandwidth. This rate is used if the subscriber bandwidth settings are not provided by the API for ACP or by the downstream-sync-rate option.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

upstream-provisioned-rate upstream-provisioned-rate—(Optional)
Provisioned upstream bandwidth. This rate is used if the subscriber bandwidth settings are not provided by the API for ACP or by the upstream-sync-rate option.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`downstream-sync-rate downstream-sync-rate`—(Optional) Actual downstream bandwidth for the current subscriber session. If you do not set this value and it is not provided by the API for ACP, the value of the downstream-provisioned-rate option is used.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`upstream-sync-rate upstream-sync-rate`—(Optional) Actual upstream bandwidth for the current subscriber session. If you do not set this value and it is not provided by the API for ACP, the value of the upstream-provisioned-rate option is used.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`congestion-points [congestion-points . . .]`—(Optional) Congestion points for the subscriber.

Value— DN of interface associated with congestion point

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name access name manager name {  
    role [(administrator | subscription | substitution | activation |  
vpn)...];  
    encrypted-password encrypted-password;  
    plain-text-password;  
    description description;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name access name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation |
vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a
privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name name — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- activate— Activate service at the time specified in the entry schedule.
- deactivate— Deactivate service at the time specified in the entry schedule.
- deny— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plug-in configured.
- deny-deactivate— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value
Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text
Default— No value
Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute
Default— No value
Editing Level— Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

- Value**— One of the following values:
- *—Local time zone of the SAE
 - An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name access name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name access name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0-153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

`hour` *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* access *name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name access name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name access name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name device device-name {
    display-name display-name;
    maximum-login maximum-login;
    accounting-user-id accounting-user-id;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name device]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a device subscriber for subscriber sessions that manage the forwarding interface on JUNOS routing platforms and the router pseudo-subscriber on JUNOSe routers.

Options

device-name device-name— Name of the device subscriber.

Value— Text

display-name display-name—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

maximum-login maximum-login—(Optional) Maximum number of concurrent logins for subscribers associated with this object. By default, all subordinate objects use this

value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Integer in the range 0–2147483647

Default— No value

Editing Level—Basic

`accounting-user-id` *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name device device-name manager name {
    role [(administrator | subscription | substitution | activation |
vpn)...];
    encrypted-password encrypted-password;
    plain-text-password;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name device device-name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation | vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name device device-name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name device device-name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name name — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This

value applies only to services that have an authorization plug-in configured.

- **deny-deactivate**— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downstreamBandwidth | upstreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- `sessionName`— Name of the service session.
- `sessionTag`— Tag that can be used for accounting purposes.
- `sessionTimeout`— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- `downstreamBandwidth`— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- `upstreamBandwidth`— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name device device-name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name—Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name device device-
name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name device device-
name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23

- *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name device device-
name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name device device-
name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name device device-name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name device device-name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective *effective*—(Optional) Interval after the associated **from** or **to** time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name device device-name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name device device-name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* device *device-name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name device device-name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name device device-name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* info

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name info {
    phone phone;
    fax fax;
    po-box po-box;
    city city;
    street street;
    state state;
    postal-code postal-code;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure additional information about the enterprise subscriber.

Options

phone *phone*—(Optional) Telephone number for the subscriber.

Value— Telephone number

Default— No value

Editing Level—Basic

fax *fax*—(Optional) Fax number for the subscriber.

Value— Fax number

Default— No value

Editing Level—Basic

`po-box` *po-box*—(Optional) Post office box for the subscriber.

Value— Post office box

Default— No value

Editing Level—Basic

`city` *city*—(Optional) City name for the subscriber.

Value— City name

Default— No value

Editing Level—Basic

`street` *street*—(Optional) Street address for the subscriber.

Value— Street address

Default— No value

Editing Level—Basic

`state` *state*—(Optional) State or province for the subscriber.

Value— State or province

Default— No value

Editing Level—Basic

`postal-code` *postal-code*—(Optional) Postal code for the subscriber.

Value— Postal code

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name manager {
    role [(administrator | subscription | substitution | activation | vpn)...];
    encrypted-password encrypted-password;
    plain-text-password;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation | vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name schedule name {  
    description description;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name* — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name schedule name event name action name {  
    type (activate | deactivate | deny | deny-deactivate);  
    service service;  
    substitution [substitution...];  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.

- `deny-deactivate`— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {  
    value;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- **sessionName**— Name of the service session.
- **sessionTag**— Tag that can be used for accounting purposes.
- **sessionTimeout**— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- **downStreamBandwidth**— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- **upStreamBandwidth**— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute minute—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59**Default**— ***Editing Level**—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31**Default**— ***Editing Level**—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week**Default**— ***Editing Level**—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12**Default**— ***Editing Level**—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year**Default**— ***Editing Level**—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

`hour` *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name {
    network [network...];
    display-name display-name;
    accounting-user-id accounting-user-id;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an enterprise site.

Options

name name— Name of the site.

Value— Text

network [network...]—(Optional) Network used at the enterprise or site. If you build a custom enterprise manager application, you can access this information through the enterprise portal APIs.

Value— Network

Default— No value

Editing Level—Basic

display-name display-name—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text
Default— No value
Editing Level—Basic

accounting-user-id *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text
Default— No value
Editing Level—Basic

description *description*—(Optional) Description of the object that you are configuring.

Value— Text
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name access name {
    routing-protocol routing-protocol;
    interface-alias interface-alias;
    interface-description interface-description;
    interface-name interface-name;
    unique-id unique-id;
    port-id port-id;
    device-name device-name;
    display-name display-name;
    accounting-user-id accounting-user-id;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name access]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an access. You can configure an access for an enterprise or for a site. An access determines the way that the enterprise or site accesses Internet services, and specifies a set of services that are available to the enterprise or site.

Options

name name— Name of the access.

Value— Text

routing-protocol routing-protocol—(Optional) Routing protocol used at the enterprise or site. If you build a custom enterprise manager application, you can access this information through the enterprise portal APIs.

Value— Routing protocol

Default— No value

Editing Level—Basic

`interface-alias` *interface-alias*—(Optional) Description of the router interface. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— Interface description that is configured on the router.

Default— No value

Editing Level—Basic

`interface-description` *interface-description*—(Optional) Name of the interface that SNMP uses. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— One of the following:

- For JUNOSe routers, the format of the description is `ip < slot > / < port > . < subinterface >`
- On the JUNOS routing platform, interface description is the same as `interfaceName`

Default— No value

Editing Level—Basic

`interface-name` *interface-name*—(Optional) Name of the interface. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— One of the following:

- Name of the interface in your router CLI syntax.
- `FORWARDING_INTERFACE` for routing instance (used by traffic mirroring).

Default— No value

Editing Level—Basic

`unique-id` *unique-id*—(Optional) Unique identifier of the router. You can use this option to allow subscriber classification scripts to match interfaces reported from the

network to be matched with the corresponding access.

Value— Index of the router in the SNMP table for all interfaces.

Default— No value

Editing Level—Basic

`port-id` *port-id*—(Optional) NAS port ID reported by the JUNOSe router through COPS. You can use this option to allow subscriber classification scripts to match interfaces reported from the network to be matched with the corresponding access.

Value— Includes the interface name and additional layer 2 information.

Default— No value

Editing Level—Basic

`device-name` *device-name*—(Optional) Name of the router or other device.

Value— Name of the device

Default— No value

Editing Level—Basic

`display-name` *display-name*—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

`accounting-user-id` *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* admission-control

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name admission-control {
    downstream-provisioned-rate downstream-provisioned-rate;
    upstream-provisioned-rate upstream-provisioned-rate;
    downstream-sync-rate downstream-sync-rate;
    upstream-sync-rate upstream-sync-rate;
    congestion-points [congestion-points...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name admission-control]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure bandwidths for subscribers that the SRC-ACP manages.

Options

downstream-provisioned-rate downstream-provisioned-rate—(Optional)
Provisioned downstream bandwidth. This rate is used if the subscriber bandwidth settings are not provided by the API for ACP or by the downstream-sync-rate option.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

upstream-provisioned-rate upstream-provisioned-rate—(Optional)
Provisioned upstream bandwidth. This rate is used if the subscriber bandwidth settings are not provided by the API for ACP or by the upstream-sync-rate option.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`downstream-sync-rate` *downstream-sync-rate*—(Optional) Actual downstream bandwidth for the current subscriber session. If you do not set this value and it is not provided by the API for ACP, the value of the downstream-provisioned-rate option is used.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`upstream-sync-rate` *upstream-sync-rate*—(Optional) Actual upstream bandwidth for the current subscriber session. If you do not set this value and it is not provided by the API for ACP, the value of the upstream-provisioned-rate option is used.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`congestion-points` [*congestion-points...*]—(Optional) Congestion points for the subscriber.

Value— DN of interface associated with congestion point

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name access name manager name {  
    role [(administrator | subscription | substitution | activation |  
vpn)...];  
    encrypted-password encrypted-password;  
    plain-text-password;  
    description description;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name access name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation |
vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a
privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name access name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name access name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name name— Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plug-in configured.
- *deny-deactivate*— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

service service— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

substitution [*substitution . . .*]—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name access name schedule name event name action name attribute (sessionName | sessionTag  
| sessionTimeout | downStreamBandwidth | upStreamBandwidth) {  
    value;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name access name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23
Default— *
Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31
Default— *
Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year year`—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone time-zone`—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute minute—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name access name schedule name event name to {  
    effective effective;  
    hour hour;  
    minute minute;  
    day-of-month day-of-month;  
    day-of-week day-of-week;  
    month month;  
    year year;  
    time-zone time-zone;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name access name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0-153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute minute—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31
Default— *
Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* access *name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name access name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name access name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-name {
    display-name display-name;
    maximum-login maximum-login;
    accounting-user-id accounting-user-id;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a device subscriber for subscriber sessions that manage the forwarding interface on JUNOS routing platforms and the router pseudo-subscriber on JUNOSe routers.

Options

device-name device-name— Name of the device subscriber.

Value— Text

display-name display-name—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

maximum-login maximum-login—(Optional) Maximum number of concurrent logins for subscribers associated with this object. By default, all subordinate objects use this

value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Integer in the range 0–2147483647

Default— No value

Editing Level—Basic

`accounting-user-id` *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text

Default— No value

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-name manager name {
    role [(administrator | subscription | substitution | activation |
vpn)...];
    encrypted-password encrypted-password;
    plain-text-password;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation | vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name name— Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name action name {
    type (activate | deactivate | deny | deny-deactivate);
    service service;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- activate— Activate service at the time specified in the entry schedule.
- deactivate— Deactivate service at the time specified in the entry schedule.

- **deny**— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plug-in configured.
- **deny-deactivate**— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name device device-  
name schedule name event name action name attribute (sessionName | sessionTag  
| sessionTimeout | downStreamBandwidth | upStreamBandwidth) {  
    value;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name device device-  
name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name device device-  
name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name device device-  
name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23

- *mm*—Minutes past the hour in the range of 0–59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-
name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name device device-name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+|-) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* device *device-name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name device device-name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name *subscription-name*— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- active— The subscriber can activate the subscription.
- suspended— The subscriber cannot activate the subscription,

although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name manager name {  
    role [(administrator | subscription | substitution | activation |  
vpn)...];  
    encrypted-password encrypted-password;  
    plain-text-password;  
    description description;  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation |
vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a
privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.

- **subscription**— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.
- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name* — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-  
name enterprise name site name schedule name event name action name {  
    type (activate | deactivate | deny | deny-deactivate);  
    service service;  
    substitution [substitution...];  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name enterprise name site name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- activate— Activate service at the time specified in the entry schedule.
- deactivate— Deactivate service at the time specified in the entry schedule.
- deny— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plug-in configured.
- deny-deactivate— Deny new activation requests during the

time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value
Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text
Default— No value
Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- *sessionName*— Name of the service session.
- *sessionTag*— Tag that can be used for accounting purposes.
- *sessionTimeout*— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- *downStreamBandwidth*— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- *upStreamBandwidth*— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23
Default— *
Editing Level—Basic

minute minute—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59
Default— *
Editing Level—Basic

day-of-month day-of-month—(Optional) Day of the month in which to schedule the event or exclusion.
 If you specify both *day-of-month* and *day-of-week*, *day-of-month* is used.

Value— 1-31
Default— *
Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week
Default— *
Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12
Default— *
Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year
Default— *
Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23**Default**— ***Editing Level**—Basic

`minute` *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59**Default**— ***Editing Level**—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31**Default**— ***Editing Level**—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— ***Editing Level**—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12**Default**— ***Editing Level**—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year**Default**— ***Editing Level**—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name site name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* site *name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name site name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name site name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name enterprise name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name enterprise name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* enterprise *name* vpn

Syntax

```
subscribers retailer name subscriber-folder folder-
name enterprise name vpn vpn-id {
    extranet-client [extranet-client...];
    display-name display-name;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name enterprise name vpn]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Add a VPN to the subscriber configuration.

Options

vpn-id *vpn-id*— Name of the routing instance on a JUNOS routing platform that implements the VPN.

Value— Text

extranet-client [*extranet-client...*]—(Optional) DN of a retailer or an enterprise that is an extranet client of this VPN.

Value— DN

Default— No value

Editing Level—Basic

display-name *display-name*—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text
Default— No value
Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* manager

Syntax

```
subscribers retailer name subscriber-folder folder-name manager name {
    role [(administrator | subscription | substitution | activation |
vpn)...];
    encrypted-password encrypted-password;
    plain-text-password;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name manager]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a manager account.

Options

name *name*— Name of the manager account.

Value— Text

role [(administrator | subscription | substitution | activation | vpn) . . .]— Privilege level of the enterprise manager account. If you do not specify a privilege level, the manager has read-only access to associated objects.

Value

- administrator— Administrators have all privileges of the subscription, substitution, activation, and vpn roles. Additionally, administrators can create, delete, and modify other enterprise manager objects.
- subscription— Subscription managers can create, delete, modify, activate, and deactivate subscriptions.

- **substitution**— Substitution managers can modify policy parameters provided by subscriptions, enterprises, sites, and accesses.
- **activation**— Activation managers can activate and deactivate subscriptions.
- **vpn**— VPN managers can modify, export, and cancel the export of VPNs.

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- **crypt**—Style is `/etc/passwd`
- **sha**—Secure hash algorithm
- **md5**—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name* — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-  
name schedule name event name action name {  
    type (activate | deactivate | deny | deny-deactivate);  
    service service;  
    substitution [substitution...];  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.

- `deny-deactivate`— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- `sessionName`— Name of the service session.
- `sessionTag`— Tag that can be used for accounting purposes.
- `sessionTimeout`— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- `downStreamBandwidth`— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- `upStreamBandwidth`— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name—Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the

event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective *effective*—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name {
    common-name common-name;
    surname surname;
    given-name given-name;
    initials initials;
    anonymous;
    ip-address ip-address;
    interface-name interface-name;
    maximum-login-group maximum-login-group;
    display-name display-name;
    encrypted-password encrypted-password;
    plain-text-password;
    maximum-login maximum-login;
    session-timeout session-timeout;
    accounting-user-id accounting-user-id;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a residential subscriber. The SRC software uses the information in the subscriber definition to create a subscriber profile.

Options

name *name*— Name of the residential subscriber

Value— Text

common-name *common-name*— Name that defines the subscriber in the directory. The

value is not used directly by the SRC software, but it is not optional because it is required by the LDAP schema. The common name is available through SRC APIs.

Value— Text. Typically in the format firstName lastName or lastname
firstName

Default— No value

Editing Level—Basic

surname *surname*— Subscriber's last name. The surname is not directly used by the SRC software, but it is not optional because it is required by the LDAP schema. The surname is available through SRC APIs.

Value— Text

Default— No value

Editing Level—Basic

given-name *given-name*—(Optional) Subscriber's given name. The given name is not used directly by the SRC software, but it is available through SRC APIs.

Value— Text

Default— No value

Editing Level—Basic

initials *initials*—(Optional) Subscriber's initials. The initials are not used directly by the SRC software but are available through SRC APIs.

Value— Text

Default— No value

Editing Level—Basic

anonymous—(Optional) A flag that marks the subscriber profile as a shared profile. Shared profiles can be used by multiple subscriber sessions. The SAE API prevents subscribers from making changes to their profile if the profile is marked as anonymous.

Default— Disabled

Editing Level—Basic

ip-address *ip-address*—(Optional) IP address for subscribers who have fixed addresses, and for whom the SRC does not learn addresses through its management of routers or through calls to its notification API.

Value— IP address

Default— No value

Editing Level—Basic

`interface-name` *interface-name*—(Optional) Type and specifier of the router interface and virtual router that manage this subscriber. Use this option when you want the subscriber classification script to identify the subscriber entry in the directory based on the interface name received from the router.

Value— Interface as configured on the router. For example:

- For JUNOS routers:
"fastethernet6/0.1@vrName@routerName"
- For JUNOS routing platforms: "fe-0/10.0@vrName@routerName"

Default— No value

Editing Level—Basic

`maximum-login-group` *maximum-login-group*—(Optional) Maximum number of concurrent logins for this subscriber and all subordinate objects; typically the maximum number of concurrent logins for a household.

Value— Integer in the range 0–2147483647

Default— No value

Editing Level—Basic

`display-name` *display-name*—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

`encrypted-password` *encrypted-password*—(Optional) Login password and type of encryption.

Value— Enter a password, and select an encryption method that your directory supports.

- crypt—Style is /etc/passwd
- sha—Secure hash algorithm
- md5—Message digest #5

Default— No value

Editing Level—Basic

`plain-text-password`—(Optional) Plain text password. The password is encrypted using the algorithm defined in `system services editor password-encryption`.

Value— Text
Default— No value
Editing Level—Basic

`maximum-login` *maximum-login*—(Optional) Maximum number of concurrent logins for subscribers associated with this object. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Integer in the range 0–2147483647
Default— No value
Editing Level—Basic

`session-timeout` *session-timeout*—(Optional) Timeout for subscriber sessions. By default, all subordinate objects use this value. However, if you specify this value for a subordinate object, that object and its subordinate objects will use the subordinate's value.

Value— Number of seconds in the range 0–2147483647
Default— No value
Editing Level—Basic

`accounting-user-id` *accounting-user-id*—(Optional) Value that identifies the subscriber in accounting records. For a household subscriber, all subordinate subscribers generally use the same ID. For an enterprise, all parts of the enterprise generally use the same ID.

Value— Text
Default— No value
Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* admission-control

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name admission-control {
    downstream-provisioned-rate downstream-provisioned-rate;
    upstream-provisioned-rate upstream-provisioned-rate;
    downstream-sync-rate downstream-sync-rate;
    upstream-sync-rate upstream-sync-rate;
    congestion-points [congestion-points...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name admission-control]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure bandwidths for subscribers that the SRC-ACP manages.

Options

downstream-provisioned-rate downstream-provisioned-rate—(Optional)
Provisioned downstream bandwidth. This rate is used if the subscriber bandwidth settings are not provided by the API for ACP or by the downstream-sync-rate option.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

upstream-provisioned-rate upstream-provisioned-rate—(Optional)
Provisioned upstream bandwidth. This rate is used if the subscriber bandwidth settings are not provided by the API for ACP or by the upstream-sync-rate option.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`downstream-sync-rate` *downstream-sync-rate*—(Optional) Actual downstream bandwidth for the current subscriber session. If you do not set this value and it is not provided by the API for ACP, the value of the downstream-provisioned-rate option is used.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`upstream-sync-rate` *upstream-sync-rate*—(Optional) Actual upstream bandwidth for the current subscriber session. If you do not set this value and it is not provided by the API for ACP, the value of the upstream-provisioned-rate option is used.

Value— Number of bps in the range 0–9223372036854775807

Default— No value

Editing Level—Basic

`congestion-points` [*congestion-points . . .*]—(Optional) Congestion points for the subscriber.

Value— DN of interface associated with congestion point

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* info

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name info {
    home-phone home-phone;
    additional-phone additional-phone;
    fax fax;
    e-mail e-mail;
    city city;
    street street;
    postal-code postal-code;
    language language;
    job job;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name info]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure administrative information about the subscriber. The additional subscriber information is not used directly by the SRC software.

Options

home-phone *home-phone*—(Optional) Home telephone number of the subscriber.

Value— Telephone number

Default— No value

Editing Level—Basic

additional-phone *additional-phone*—(Optional) Additional telephone number for the subscriber.

Value— Telephone number

Default— No value

Editing Level—Basic

fax *fax*—(Optional) Fax number for the subscriber.

Value— Fax number

Default— No value

Editing Level—Basic

e-mail *e-mail*—(Optional) E-mail address for the subscriber.

Value— E-mail address

Default— No value

Editing Level—Basic

city *city*—(Optional) City name for the subscriber.

Value— City name

Default— No value

Editing Level—Basic

street *street*—(Optional) Street address for the subscriber.

Value— Street address

Default— No value

Editing Level—Basic

postal-code *postal-code*—(Optional) Postal code for the subscriber.

Value— Postal code

Default— No value

Editing Level—Basic

language *language*—(Optional) Preferred language for the subscriber.

Value— Language name

Default— No value

Editing Level—Basic

job *job*—(Optional) Job or business category for the subscriber.

Value— Job or business category
Default— No value
Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text
Default— No value
Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule

Syntax

```
subscribers retailer name subscriber-folder folder-
name subscriber name schedule name {
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name subscriber name schedule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service schedule.

Options

name *name*— Name of service schedule.

Value—Text

description *description*—(Optional) Description of the service schedule.

Value—Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name schedule name event]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a scheduling event.

Options

name *name* — Name of the scheduling event.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* action

Syntax

```
subscribers retailer name subscriber-folder folder-  
name subscriber name schedule name event name action name {  
    type (activate | deactivate | deny | deny-deactivate);  
    service service;  
    substitution [substitution...];  
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-  
name subscriber name schedule name event name action]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure actions to perform for the scheduled event.

Options

name name— Arbitrary identifier for action.

Value—Text

type (activate | deactivate | deny | deny-deactivate)— Type of action.

Value

- *activate*— Activate service at the time specified in the entry schedule.
- *deactivate*— Deactivate service at the time specified in the entry schedule.
- *deny*— Deny new activation requests during the time specified in the entry schedule; current sessions are not affected. This value applies only to services that have an authorization plugin configured.

- `deny-deactivate`— Deny new activation requests during the time specified in the entry schedule; current sessions are deactivated at the specified time. This value applies only to services that have an authorization plug-in configured.

Default— No value

Editing Level—Basic

`service service`— Name of service affected by this action.

Value—Text

Default— No value

Editing Level—Basic

`substitution [substitution...]`—(Optional) Substitutions to be used when activating the service. Substitutions apply only to service activations.

Value— An entry in valid substitution format. See the *SRC-PE Services and Policies Guide*.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* action *name* attribute

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name action name attribute (sessionName | sessionTag | sessionTimeout | downStreamBandwidth | upStreamBandwidth) {
    value;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name action name attribute]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure subscription attributes. Subscription attributes apply only to service activations.

Options

Value

- **sessionName**— Name of the service session.
- **sessionTag**— Tag that can be used for accounting purposes.
- **sessionTimeout**— Session timeout to be used when the service is activated. The service session is deactivated when this timeout expires.
- **downStreamBandwidth**— Attribute used by SRC Admission Control Plug-In (SRC-ACP) to specify the rate of traffic between the network and the subscriber.
- **upStreamBandwidth**— Attribute used by SRC-ACP to specify the rate of traffic between the subscriber and the network.

value— Value of the specified subscription attribute.

Value— Depends on the specified subscription attribute

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* except

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except name ...
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure an exclusion for the event.

Options

name name— Arbitrary identifier for exclusion rule.

Value—Text

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* except *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name subscriber name schedule name event name except name from {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name subscriber name schedule name event name except name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31

Default— *

Editing Level—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* except *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except name to {
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name schedule name event name except name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time of the exclusion. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59**Default**— ***Editing Level**—Basic

`day-of-month` *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 1-31**Default**— ***Editing Level**—Basic

`day-of-week` *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both `day-of-month` and `day-of-week`, `day-of-month` is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— ***Editing Level**—Basic

`month` *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12**Default**— ***Editing Level**—Basic

`year` *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year**Default**— ***Editing Level**—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0-23
 - *mm*—Minutes past the hour in the range of 0-59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* from

Syntax

```
subscribers retailer name subscriber-folder folder-
name subscriber name schedule name event name from {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name subscriber name schedule name event name from]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the start time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour hour—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

time-zone *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* schedule *name* event *name* to

Syntax

```
subscribers retailer name subscriber-folder folder-
name subscriber name schedule name event name to {
    effective effective;
    hour hour;
    minute minute;
    day-of-month day-of-month;
    day-of-week day-of-week;
    month month;
    year year;
    time-zone time-zone;
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-
name subscriber name schedule name event name to]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the end time for the event. For guidelines about entering time values, see the *SRC-PE Services and Policies Guide*.

These values apply only to services that have an authorization plug-in configured. If an authorization plug-in is not configured for the service associated with the schedule, these values are ignored.

Options

effective effective—(Optional) Interval after the associated *from* or *to* time during which the scheduled action can be initiated by a subscriber who is logging in to a subscriber session.

Value— Number of minutes in the range 0–153722867280912

Default— *

Editing Level—Basic

hour *hour*—(Optional) Hour of the day in the indicated month in which to schedule the event or exclusion.

Value— 0-23

Default— *

Editing Level—Basic

minute *minute*—(Optional) Minutes past the indicated hour in which to schedule the event or exclusion.

Value— 0-59

Default— *

Editing Level—Basic

day-of-month *day-of-month*—(Optional) Day of the month in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 1-31

Default— *

Editing Level—Basic

day-of-week *day-of-week*—(Optional) Day of the week in which to schedule the event or exclusion. If you specify both day-of-month and day-of-week, day-of-month is used.

Value— 0-6, with 0 representing Sunday and each subsequent number representing the next day of the week

Default— *

Editing Level—Basic

month *month*—(Optional) Month of the year in which to schedule the event or exclusion.

Value— 1-12

Default— *

Editing Level—Basic

year *year*—(Optional) Year in which to schedule the event or exclusion.

Value— Four integers that indicate the year

Default— *

Editing Level—Basic

`time-zone` *time-zone*—(Optional) Name of the time zone to use in the schedule.

Value— One of the following values:

- *—Local time zone of the SAE
- An offset to GMT in the format: GMT (+ | -) (*hh:mm* | *hh mm* | *hh*)
 - *hh*—Hour of the day in the range of 0–23
 - *mm*—Minutes past the hour in the range of 0–59

Default— *

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscriber *name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name subscriber name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscriber name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.

- **hidden**— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation (manual | automatically-on-login)`— Specify how the service is activated.

Value

- **manual**— Subscriber must manually activate the service.
- **automatically-on-login**— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order activation-order`—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution [substitution...]`—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscriber-folder *folder-name* subscription

Syntax

```
subscribers retailer name subscriber-folder folder-name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscriber-folder folder-name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name subscription-name— Name of the service optionally followed by "*%subscription-id*". Use "*%subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.
- *hidden*— Service is not available through a portal and cannot

be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation` (`manual` | `automatically-on-login`)— Specify how the service is activated.

Value

- `manual`— Subscriber must manually activate the service.
- `automatically-on-login`— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order` *activation-order*—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* subscription

Syntax

```
subscribers retailer name subscription subscription-name {
    status (active | suspended | hidden);
    activation (manual | automatically-on-login);
    activation-order activation-order;
    substitution [substitution...];
}
```

Hierarchy Level

```
[edit subscribers retailer name subscription]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a service subscription.

Options

subscription-name *subscription-name*— Name of the service optionally followed by "%*subscription-id*". Use "%*subscription-id*" to subscribe subscribers to the same service multiple times with different subscription attributes.

Value— Text

status (active | suspended | hidden)— Status of the service subscription.

Value

- *active*— The subscriber can activate the subscription.
- *suspended*— The subscriber cannot activate the subscription, although it may be visible through the portal. If you change the status of the subscription to suspended while the subscription is active, the service is deactivated.
- *hidden*— Service is not available through a portal and cannot be activated automatically when the subscribers log in. If you change the status of the subscription to hidden while the subscription is active, the service is not deactivated.

Default— Active

Editing Level—Basic

`activation` (`manual` | `automatically-on-login`)— Specify how the service is activated.

Value

- `manual`— Subscriber must manually activate the service.
- `automatically-on-login`— Service is activated automatically when the subscriber logs in.

Default— Manual activation

Editing Level—Basic

`activation-order` *activation-order*—(Optional) Order in which subscriptions are automatically activated on login relative to the subscriber's other subscriptions that are configured to activate on login. Review all subscriptions that are configured to activate on login for the subscriber, and review the activation order for subscriptions of the parent subscribers. Assign the lowest number to the subscription that you want to activate first. Assign higher numbers to the other subscriptions in the order that you want the SAE to activate them. If you assign the same number to multiple subscriptions, the SAE activates them in an unspecified order.

Value— Integer in the range 0–2147486367

Default— 10000

Editing Level—Basic

`substitution` [*substitution...*]—(Optional) Actual values for parameters associated with this object. The policy engine substitutes parameters in policies associated with this object with the values that you specify in the substitution configuration.

Value— Substitution in the form `< parameter name > = < value >` . For example, `bandwidth = 1000000`.

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

subscribers retailer *name* vpn

Syntax

```
subscribers retailer name vpn vpn-id {
    extranet-client [extranet-client...];
    display-name display-name;
    description description;
}
```

Hierarchy Level

```
[edit subscribers retailer name vpn]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Add a VPN to the subscriber configuration.

Options

vpn-id *vpn-id*— Name of the routing instance on a JUNOS routing platform that implements the VPN.

Value— Text

extranet-client [*extranet-client...*]—(Optional) DN of a retailer or an enterprise that is an extranet client of this VPN.

Value— DN

Default— No value

Editing Level—Basic

display-name *display-name*—(Optional) Subscriber's name as it appears in portal applications. If you do not specify a display name, the value of the name option is used.

Value— Text

Default— No value

Editing Level—Basic

`description` *description*—(Optional) Description of the object that you are configuring.

Value— Text

Default— No value

Editing Level—Basic

Required Privilege Level

subscriber

Required Editing Level

Basic

Redirect Server

The following table summarizes the SRC command-line interface (SRC CLI) for the Redirect Server. Configuration statements and operational commands are listed in alphabetical order.

Redirect Server
Configuration Statements
redirect-server
redirect-server dns
redirect-server ip-redirect
redirect-server ldap
redirect-server monitor
Operational Commands
show redirect-server statistics

redirect-server

Syntax

```
redirect-server {
    tcp-port tcp-port;
    destination-url destination-url;
    proxy-support;
    proxy-destination-url proxy-destination-url;
    refresh;
    refresh-document refresh-document;
    request-rate request-rate;
    request-burst-size request-burst-size;
    client-rate client-rate;
    client-burst-size client-burst-size;
    check-file-extensions;
    file-extensions [file-extensions...];
    redundancy;
}
```

Hierarchy Level

```
[edit redirect-server]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure redirect server properties. The redirect server redirects HTTP requests to a captive portal page.

Options

`tcp-port tcp-port`—(Optional) TCP port number on which the redirect server listens for requests. Use any valid TCP port number.

Value—Integer in the range 1–65535

Default—8800

Editing Level—Basic

`destination-url destination-url`—URL sent as a response to redirect requests. Typically, this URL is the URL of the captive portal.

The URL can contain the special strings "%(url)s" and "%(proxy)s." If the HTTP request is sent to a proxy, the "%(url)s" string is replaced with the originally requested URL, and the "%(proxy)s" string is replaced with the proxy's "< ipAddress > : < port > ". If the request is sent directly, the string is replaced with "None."

If the `proxy-destination-url` option is not configured, this URL is used for both proxy and nonproxy requests.

Value— `http://< serverHost > /accessDenied.do?url = %(url)s` where
`< serverHost >` is a valid URL; a string of ASCII characters.

Editing Level—Basic

`proxy-support`—(Optional) Enable proxy support. If you do not enable proxy support, the redirect server handles proxy requests in the same manner as direct requests.

Editing Level—Basic

`proxy-destination-url` *proxy-destination-url*—(Optional) URL sent as a response to proxy requests. If you do not configure a value, then the URL defaults to the value for the `destination-url` option. You can use this option to send proxy requests to a page different from the page specified by the `destination-url` option.

Value— Valid URL; string of ASCII characters in URL string format

Editing Level—Basic

`refresh`—(Optional) Specify that the redirect server send an HTTP 200 OK response with an HTML document that includes the `< HTTP-Equiv = "Refresh" >` header to a subscriber's browser in response to a captured request. If not set, the redirect server sends a 302 Found response to the client. If the client is not a Web browser, typically it does not follow the URL included in the `refresh` option.

Editing Level—Basic

`refresh-document` *refresh-document*—(Optional)

Directory path to a local HTML file that the redirect server returns to a subscriber's browser in response to a captured HTTP request.

If you enter an invalid path, the redirect server uses a default file. This file can contain the string "%(url)s" which is replaced with the URL of the local HTML file to be returned to the subscriber's browser.

Value— Path to HTML file

Editing Level—Basic

`request-rate` *request-rate*—(Optional) Number of requests that the redirect server can accept per minute from all clients (global sustained rate).

Value— Integer in the range 0–2147483647

Default— 12000

Editing Level—Basic

`request-burst-size` *request-burst-size*—(Optional) Maximum number of requests that the redirect server can accept from all clients (burst size). This value should exceed value set by the `request-rate` option. If the number of requests exceeds this value, the redirect server drops the excess requests.

Value— Integer in the range 0–2147483647

Default— 18000

Editing Level—Basic

`client-rate` *client-rate*—(Optional) Number of requests that the redirect server can accept per minute for a single client (per client sustained rate).

Value— Integer in the range 0–2147483647

Default— 25

Editing Level—Basic

`client-burst-size` *client-burst-size*—(Optional) Maximum number of requests that the redirect server can accept for a single client (per client burst size). This value should exceed the value set by the `client-rate` option. If at any time the number of requests from one client exceeds this value, the redirect server drops the excess requests.

Value— Integer in the range 0–2147483647

Default— 50

Editing Level—Basic

`check-file-extensions`—(Optional) Check file extension of requested URLs and accept only URLs that point to files that have standard file extensions— < empty > , .asp, .htm, .html, .jsp, .php, .shtml, .shtm and .xml, and extensions specified by the `file-extensions` option. If a URL does not have a standard extension, the redirect server returns an HTTP 403 Forbidden message.

If not set, the redirect server accepts all file extensions.

Default—false

Editing Level—Basic

`file-extensions [file-extensions . . .]`—(Optional) List of file extensions that augments the standard list of extensions. Entries for extensions are case-sensitive and are preceded by a period.

Value— Text string of file extensions.

Editing Level—Basic

`redundancy`—(Optional) Enable redundancy for the redirect server on this system, which then monitors a redundant redirect server and configures static routes in the managed JUNOSe routers to facilitate failover.

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

redirect-server dns

Syntax

```
redirect-server dns {
    enable;
    tcp-port tcp-port;
    udp-port udp-port;
    forwarder [forwarder...];
    error-ip-address error-ip-address;
}
```

Hierarchy Level

```
[edit redirect-server dns]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure properties for the DNS server included with the redirect server.

Options

enable—(Optional) Enable the DNS server included with the redirect server.

A DNS server is required to support HTTP proxies to resolve the name of any HTTP proxy, even if the name is valid only in the private domain of the client. You can use an external DNS server or the DNS server that is included with the redirect for this purpose.

Editing Level—Basic

tcp-port *tcp-port*— TCP port on which the DNS server listens. You can disable the TCP port by entering 0.

Value—Integer in the range 0–65535

Default—8853

Editing Level—Basic

udp-port *udp-port*— UDP port on which the DNS server listens. You can disable the

UDP port by entering 0.

Value—Integer in the range 0–65535

Default—8853

Editing Level—Basic

`forwarder [forwarder . . .]`—(Optional) DNS servers to which requests are forwarded.

If you specify DNS servers for this option, incoming requests are forwarded to one of these servers. If you do not specify servers, the DNS server will resolve incoming requests using the normal DNS method.

Value— List of fully qualified IP address of DNS servers.

Editing Level—Basic

`error-ip-address error-ip-address`—(Optional) IP address that is returned when a DNS request results in an unknown name (NXDOMAIN) error.

Value— Fully qualified IP address

Default—192.168.254.2

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

redirect-server ip-redirect

Syntax

```
redirect-server ip-redirect {
    interface [interface...];
    port [port...];
}
```

Hierarchy Level

```
[edit redirect-server ip-redirect]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure IP redirection.

Options

`interface [interface...]`—(Optional) Interface on a C-series platform that forwards traffic to be redirected. If you do not specify one or more interface names, the redirect server accepts specified traffic from all interfaces.

Value— Interface name

Editing Level—Basic

`port [port...]`—(Optional) Port number that identifies traffic destined for this port to be redirected to another URL.

Value—Integer in the range 1–65535

Default— 80

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

redirect-server ldap

Syntax

```
redirect-server ldap {
    url [url...];
    bind-dn bind-dn;
    bind-password bind-password;
    base-dn base-dn;
}
```

Hierarchy Level

```
[edit redirect-server ldap]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure directories employed by the redirect server.

Options

`url [url...]`— List of the URLs for directories employed by the redirect server.

Value— URL in the format `ldap:// <host> : <portNumber>` , where
 < host > is the IP address or name of the host that supports the
 directory, and < portNumber > is the number of the TCP port. Example
 — `ldap://localhost ldap://1.2.3.4:389`

Editing Level—Basic

`bind-dn bind-dn`— DN that the redirect server uses to authorize connections to the
 directory. The DN must have read and write access to *o= Network, < baseDN>* , where
 < baseDN> is the root of the SDX directory tree.

Value— DN

Editing Level—Basic

`bind-password bind-password`— Password used to authorize connections to the
 directory.

Value— Text string in LDAP format
Editing Level—Basic

`base-dn` *base-dn*—(Optional) Base DN that is the root of the SDX directory tree. The redirect server can store information at any DN subordinate to the base DN that you specify.

Value— DN
Default—`o = umc`
Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

redirect-server monitor

Syntax

```
redirect-server monitor {
    redundant-host-ip-address redundant-host-ip-address;
    virtual-ip-address virtual-ip-address;
    real-ip-address real-ip-address;
    primary-server;
    check-interval check-interval;
    virtual-routers [virtual-routers...];
}
```

Hierarchy Level

```
[edit redirect-server monitor]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure redundancy for the redirect server. With redundancy configured, a pair of redirect servers monitor each other. If one server detects that the other server is not responding, it reconfigures all managed JUNOS virtual routers with a static route that points to a virtual IP address to the active redirect server.

Options

`redundant-host-ip-address redundant-host-ip-address`— IP address of the redundant redirect server.

Value— Fully qualified IP address

Editing Level—Basic

`virtual-ip-address virtual-ip-address`— Virtual IP address of the redirect server. Do not specify a hostname.

You can configure the primary and redundant redirect servers to share this address under a common name in the DNS. Each redirect server dynamically sets up and maintains a static route on managed JUNOS routers. The static route directs client traffic destined for the virtual IP address to the real IP address of the active redirect server.

Value— Fully qualified IP address

Default—192.168.254.1

Editing Level—Basic

`real-ip-address` *real-ip-address*— Real IP address of the redirect server. Do not specify a hostname.

Each redirect server dynamically sets up and maintains a static route on managed JUNOS routers. The static route directs client traffic that is destined for the virtual IP address to the real IP address of the active redirect server.

Value— Fully qualified IP address

Editing Level—Basic

`primary-server`—(Optional) Set this redirect server as the primary server. When the primary redirect server is started, it configures a static route for the virtual IP address.

If not enabled for this redirect server, this server becomes the redundant one.

Default—false

Editing Level—Basic

`check-interval` *check-interval*—(Optional) Interval at which the primary redirect server polls the redundant redirect server.

A shorter interval leads to faster detection of problems and results in higher consumption of CPU resources.

Value— Number of seconds in the range 60/clientRate–2147483647, where clientRate is the number of requests per minute that the redirect server accepts from one client.

Default—30

Editing Level—Basic

`virtual-routers` [*virtual-routers...*]— List of virtual routers to which the redirect server connects.

Value— Identifier for the virtual router in the format `< vrName > @ < routerName >`, where `< vrName >` is the name of the virtual router, and `< routerName >` is the name of the router on which the virtual router is configured.

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

show redirect-server statistics

Syntax

```
show redirect-server statistics < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display statistics for redirect server.

Options

(Optional) Output style.

Value

- `brief`— Display brief information.

Default—normal

Required Privilege Level

view

External Subscriber Monitor

The following table summarizes the SRC command-line interface (SRC CLI) for External Subscriber Monitor. Configuration statements and operational commands are listed in alphabetical order.

External Subscriber Monitor
Configuration Statements
slot number external-subscriber-monitor
slot number external-subscriber-monitor event-notification
slot number external-subscriber-monitor initial
slot number external-subscriber-monitor initial directory-connection
slot number external-subscriber-monitor initial directory-eventing
slot number external-subscriber-monitor logger
slot number external-subscriber-monitor logger name file
slot number external-subscriber-monitor logger name syslog
slot number external-subscriber-monitor nic-proxy-configuration radius-accounting-nic cache
slot number external-subscriber-monitor nic-proxy-configuration radius-accounting-nic nic-host-selection
slot number external-subscriber-monitor nic-proxy-configuration radius-accounting-nic nic-host-selection blacklisting
slot number external-subscriber-monitor nic-proxy-configuration radius-accounting-nic resolution
slot number external-subscriber-monitor nic-proxy-configuration radius-authorization-nic cache
slot number external-subscriber-monitor nic-proxy-configuration radius-authorization-nic nic-host-selection
slot number external-subscriber-monitor nic-proxy-configuration radius-authorization-nic nic-host-selection blacklisting
slot number external-subscriber-monitor nic-proxy-configuration radius-authorization-nic resolution
slot number external-subscriber-monitor radius-accounting

slot number external-subscriber-monitor radius-accounting client
slot number external-subscriber-monitor radius-attribute-extraction default interface-name
slot number external-subscriber-monitor radius-attribute-extraction default virtual-router-name
slot number external-subscriber-monitor radius-authorization
slot number external-subscriber-monitor radius-authorization client
slot number external-subscriber-monitor radius-authorization ldap cached-dhcp-profile
slot number external-subscriber-monitor radius-authorization ldap cached-dhcp-profile directory-connection
slot number external-subscriber-monitor radius-authorization ldap subscriber-data
slot number external-subscriber-monitor radius-authorization ldap subscriber-data directory-connection
Operational Commands
show external-subscriber-monitor statistics event-notifications
show external-subscriber-monitor statistics process
show external-subscriber-monitor statistics radius-accounting
show external-subscriber-monitor statistics radius-authorization

slot *number* external-subscriber-monitor

Syntax

```
slot number external-subscriber-monitor {
    java-heap-size java-heap-size;
    java-garbage-collection-options java-garbage-collection-options;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the local properties for External Subscriber Monitor.

Options

`java-heap-size java-heap-size`— Maximum Java heap (memory) size available to the JRE. Changes take effect only after you restart External Subscriber Monitor.

Value— Number of megabytes in the format *integer*m

Default— 160m

Editing Level—Basic

`java-garbage-collection-options java-garbage-collection-options`— (Optional) Garbage collection functionality of the Java Virtual Machine.

Value—

Default— -Xbatch -XX: + UseConcMarkSweepGC -XX:

CMSInitiatingOccupancyFraction = 80 -XX: + UseParNewGC -XX:

SurvivorRatio = 1 -XX:InitialTenuringThreshold = 8 -XX:

MaxTenuringThreshold = 10 -XX:TargetSurvivorRatio = 90 -XX:

+ UseCMSCompactAtFullCollection -XX:

CMSFullGCsBeforeCompaction = 0 -XX: + CMSClassUnloadingEnabled -

XX: + CMSParallelRemarkEnabled

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor event-notification

Syntax

```
slot number external-subscriber-monitor event-notification {
    event-threads event-threads;
    event-thread-idle-timeout event-thread-idle-timeout;
    event-retry-timeout event-retry-timeout;
    event-retry-interval event-retry-interval;
    session-timeout session-timeout;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor event-notification]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure event notification. This is mandatory if radius-accounting is on.

Options

`event-threads event-threads`—(Optional) Maximum number of concurrent threads in a pool for event handler.

Value—Integer in the range 1-2147483648

Default— 8

Editing Level—Advanced

`event-thread-idle-timeout event-thread-idle-timeout`—(Optional) Time to keep an event handler alive for reuse.

Value—Integer in the range 1-2147483648 second

Default— 300

Editing Level—Advanced

`event-retry-timeout event-retry-timeout`—(Optional) Maximum time to wait before discarding failed events.

Value—Integer in the range 1–2147483648 second

Default— 300

Editing Level—Advanced

`event-retry-interval` *event-retry-interval*—(Optional) Time to wait before retrying failed events.

Value—Integer in the range 1–2147483648 second

Default— 30

Editing Level—Advanced

`session-timeout` *session-timeout*—(Optional) Keepalive time for a RADIUS subscriber or service. This value should be larger than the interim update interval. We recommend twice the interim update interval. Setting the session timeout less than or equal to zero means the subscriber session never expires.

Value—Integer in the range -2147483648–2147483647 second

Default— 1800

Editing Level—Normal

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor initial

Syntax

```
slot number external-subscriber-monitor initial {
    dynamic-dn dynamic-dn;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor initial]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure initial properties for SRC components.

Options

`dynamic-dn dynamic-dn`—(Optional) Location of programmatically defined configuration data in the directory.

Value—Text

Default—ou = dynamicConfiguration,ou = Configuration,
o = Management,o = umc

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor initial directory-connection

Syntax

```
slot number external-subscriber-monitor initial directory-connection {
    url url;
    backup-urls [backup-urls...];
    principal principal;
    credentials credentials;
    protocol (ldaps);
    timeout timeout;
    check-interval check-interval;
    blacklist;
    snmp-agent;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor initial directory-connection]
```

Description

Configure properties for the directory connection.

Options

`url url`—(Optional) URL that identifies the location of the primary directory server.

Value— URL

Default—`ldap://127.0.0.1:389`

Editing Level—Basic

`backup-urls [backup-urls...]`—(Optional) URLs that identify the locations of backup directory servers. Backup servers are used if the primary directory server is not accessible.

Value— List of URLs

Editing Level—Basic

`principal principal`— DN that the SRC component uses for authentication to access the directory.

Value— DN.

When you specify the DN, you can use < base > to indicate the base DN.

Editing Level—Basic

`credentials` *credentials*— Password with which the SRC component accesses the directory.

Value— Password

Editing Level—Basic

`protocol` (`ldaps`)—(Optional) Security protocol used to connect to the directory. If you do not configure a security protocol, plain socket is used.

Value

- `ldaps`— LDAPS that uses SSL.

Editing Level—Expert

`timeout` *timeout*—(Optional) Maximum amount of time during which the directory must respond to a connection request.

Value—Integer in the range 1–2147483647 s

Default—10

Editing Level—Expert

`check-interval` *check-interval*—(Optional) Time interval at which the directory monitoring system verifies its connection to the directory. If the directory connection fails after this interval, the directory monitoring system initiates a connection to another directory.

Value—Integer in the range 15–2147483647 s

Default—60

Editing Level—Expert

`blacklist`—(Optional) Specifies whether the directory monitoring system prevents connection to a directory if the directory fails to respond during 10 polling intervals.

Default—false

Editing Level—Basic

`snmp-agent` —(Optional) Specifies whether the SDX SNMP agent exports MIBs for this directory connection.

Default—false

Editing Level—Expert

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor initial directory-eventing

Syntax

```
slot number external-subscriber-monitor initial directory-eventing {
    eventing;
    signature-dn signature-dn;
    polling-interval polling-interval;
    event-base-dn event-base-dn;
    dispatcher-pool-size dispatcher-pool-size;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor initial directory-eventing]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Change configuration for directory eventing properties. In most cases, you can use the default configuration for these properties.

Options

eventing—(Optional) Enable an SRC component to poll the directory for changes.

Default—true

Editing Level—Normal

signature-dn *signature-dn*—(Optional) DN of the directory entry that specifies the usedDirectory attribute for the SRC CLI. The usedDirectory attribute identifies the vendor of the directory server.

Value— DN

Default—o = umc

Editing Level—Expert

polling-interval *polling-interval*—(Optional) Interval at which an SRC

component polls the directory to check for directory changes.

Value—Integer in the range 15–2147483647 s

Default—30

Editing Level—Normal

`event-base-dn` *event-base-dn*—(Optional)

DN of an entry superior to the data associated with an SRC component in the directory.

If you are storing non-SRC data in the directory, and that data changes frequently whereas the SRC data does not, you may need to adjust the default value to improve performance. For optimal performance, set the value to the DN of an entry superior to both the SRC data and the changing non-SRC data.

Value— DN

Default—o = UMC

Editing Level—Expert

`dispatcher-pool-size` *dispatcher-pool-size*—(Optional) Number of directory change notifications that can be sent simultaneously to the SRC component.

Value—Integer in the range 0–2147483647

Default—1

Editing Level—Expert

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor logger

Syntax

```
slot number external-subscriber-monitor logger name ...
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor logger]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the logging destination.

Options

name *name*— Name used to group parameters for the logging destination.

Value— Text

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor logger *name* file

Syntax

```
slot number external-subscriber-monitor logger name file {
    filter filter;
    filename filename;
    rollover-filename rollover-filename;
    maximum-file-size maximum-file-size;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor logger name file]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the logging destination for file-based logging.

Options

filter filter—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default— The default value is different for each type of component.

Editing Level—Basic

filename filename— Absolute path of the filename that contains the current logs.

Note: Make sure that the user under which the J2EE application server or Web application server runs has write access to this folder. If this user does not have write access to the default folder, configure the component or application to write logs in folders to which the user has write access.

Value— Filename

Default— By default, SRC components and applications write log files in the folder in which the component or application is started.

Editing Level—Basic

`rollover-filename` *rollover-filename*—(Optional) Absolute path of the filename that contains the log history. When the log file reaches the maximum size, the software closes the log file and renames it with the name you specify for the rollover file. If a previous rollover file exists, the software overwrites it. The software then reopens the log file and continues to save event messages in it.

Value— Path of filename

Example—`/opt/UMC/sae/var/log/sae.alt`

Default— The default value is different for each type of component.

Editing Level—Normal

`maximum-file-size` *maximum-file-size*—(Optional) Maximum size of the log file and the rollover file.

Do not set the maximum file size to a value greater than the available disk space.

Value—Integer in the range 0–2147483647 kbytes

Default— 1000000

Editing Level—Normal

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor logger *name* syslog

Syntax

```
slot number external-subscriber-monitor logger name syslog {
    filter filter;
    host host;
    facility facility;
    format format;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor logger name syslog]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the logging destination for syslog-based logging.

Options

filter filter—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default— The default value is different for each type of component.

Editing Level—Basic

host host— IP address or name of a host that collects event messages by means of a standard system logging daemon.

Value— IP address or hostname

Default—loghost

Editing Level—Basic

facility facility—(Optional) Type of system log in accordance with the system logging protocol.

Value—Integer in the range 0–23

Default— 3

Editing Level—Advanced

`format` *format*—(Optional) MessageFormat string that specifies how the information in an event message is printed. (The strings {#} are replaced with the log information [...]).

Value— MessageFormat string as specified in <http://java.sun.com/j2se/1.4.2/docs/api/java/text/MessageFormat.html>.

The fields available for events are:

- 0—Time and date of the event
- 1—Name of the thread generating the event
- 2—Text message of the event
- 3—Category of the event
- 4—Priority of the event

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor nic-proxy-configuration radius-accounting-nic cache

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic cache {
    cache-size cache-size;
    cache-cleanup-interval cache-cleanup-interval;
    cache-entry-age cache-entry-age;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic cache]
```

Description

Configure the NIC Proxy cache properties. You can modify cache properties for the NIC proxy to optimize the resolution performance for your network configuration and system resources. Typically, you can use the default settings for the cache properties.

Options

`cache-size cache-size`—(Optional) Maximum size of the cache in which the NIC proxy retains data. If you decrease the cache size or disable the cache while the NIC proxy is running, the NIC proxy removes entries in order of descending age until the cache size meets the new limit.

Value— Integer in the range 0–2147483647

Default— 10000

Editing Level—Advanced

`cache-cleanup-interval cache-cleanup-interval`— Time interval at which the NIC proxy removes expired entries from its cache.

Value— Number of seconds in the range 5–2147483

Default— 15

Editing Level—Advanced

`cache-entry-age cache-entry-age`—(Optional) Maximum time that the NIC proxy can cache an entry. The NIC proxy compares this property with the life expectancy of each

entry and uses the lower value to determine when to remove the entry.

Value— Number of seconds in the range 0–4294967295

- 0 or unspecified—Life expectancy of the data, which determines expiration of data
- Other values—Actual time that the NIC proxy caches entries

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Advanced

slot *number* external-subscriber-monitor nic-proxy-configuration radius-accounting-nic nic-host-selection

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic nic-host-selection {
    groups [groups...];
    selection-criteria (roundRobin | randomPick | priorityList);
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic nic-host-selection]
```

Description

Configure the mechanism that a NIC proxy uses to select NIC system if multiple systems are available. You use NIC host selection when you use NIC replication.

Options

`groups [groups...]`—(Optional) List of groups of NIC hosts that the NIC proxy can contact for resolution requests.

Value— Names of groups.

Default— No value

Editing Level—Advanced

`selection-criteria (roundRobin | randomPick | priorityList)`—
Selection criteria that the NIC proxy uses to determine which NIC host to contact. Configure selection criteria if you configure more than one group.

Value— One of the following criteria:

- `roundRobin`—NIC proxy selects NIC hosts in a fixed, cyclic order. The NIC proxy always selects the next host in the list.
- `randomPick`—NIC proxy selects NIC hosts randomly from the list.
- `priorityList`—NIC proxy selects NIC hosts according to their assigned priorities in the list. If the host with the highest priority in the list is not available, the NIC proxy tries the host with the next-highest priority, and so on.

Use round-robin or random pick to distribute resolution requests among NIC hosts. Use priority list if you prefer to use a particular NIC host; for example, you may reduce operating cost by using a local NIC host.

Default—roundRobin

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Advanced

slot *number* external-subscriber-monitor nic-proxy-configuration radius-accounting-nic nic-host-selection blacklisting

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic nic-host-selection blacklisting {
    try-next-system-on-error;
    number-of-retries-before-blacklisting number-of-retries-before-
blacklisting;
    blacklist-retry-interval blacklist-retry-interval;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic nic-host-selection blacklisting]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure how to handle nonresponsive NIC hosts. When a NIC host does not respond, it is blacklisted which means that other NIC hosts are contacted until the blacklisted host becomes available again.

Options

try-next-system-on-error—(Optional) Specifies whether or not the NIC proxy should contact the next specified NIC host if a NIC host is determined to be unavailable. Configure this property only if you configure more than one group.

Default—true

Editing Level—Advanced

number-of-retries-before-blacklisting *number-of-retries-before-blacklisting*— Number of times the NIC proxy tries to communicate with a NIC host before the NIC proxy stops communicating with the NIC host for a period of time.

Value—Integer in the range 0–2147483647

Default—3

Editing Level—Advanced

`blacklist-retry-interval` *blacklist-retry-interval*—Interval at which the NIC proxy attempts to connect to an unavailable NIC host.

Value—Integer in the range 15–2147483647 s

Default—15

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor nic-proxy-configuration radius-accounting-nic resolution

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic resolution {
    resolver-name resolver-name;
    constraints constraints;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
accounting-nic resolution]
```

Description

Configure properties for a NIC proxy (NIC locator), the NIC component that requests information on behalf of an application.

Options

`resolver-name resolver-name`— NIC resolver that the NIC proxy uses. This resolver must be the same as one that is configured on the NIC host.

Value— Path to the NIC resolver.

Example—/realms/ip/A1

Default— No value

Editing Level—Normal

`constraints constraints`—(Optional) Data type that a resolver uses during the resolution process. A constraint represents a condition that must or may be satisfied before the next stage of the resolution process can proceed.

Configure a constraint only if the constraint will be provided by the application in the resolution request. Typically, you do not need to configure constraints.

Value— Data types of constraints specified for the NIC resolution.
Separate data types with commas.

Default— No value
Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor nic-proxy-configuration radius-authorization-nic cache

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic cache {
    cache-size cache-size;
    cache-cleanup-interval cache-cleanup-interval;
    cache-entry-age cache-entry-age;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic cache]
```

Description

Configure the NIC Proxy cache properties. You can modify cache properties for the NIC proxy to optimize the resolution performance for your network configuration and system resources. Typically, you can use the default settings for the cache properties.

Options

`cache-size cache-size`—(Optional) Maximum size of the cache in which the NIC proxy retains data. If you decrease the cache size or disable the cache while the NIC proxy is running, the NIC proxy removes entries in order of descending age until the cache size meets the new limit.

Value— Integer in the range 0–2147483647

Default— 10000

Editing Level—Advanced

`cache-cleanup-interval cache-cleanup-interval`— Time interval at which the NIC proxy removes expired entries from its cache.

Value— Number of seconds in the range 5–2147483

Default— 15

Editing Level—Advanced

`cache-entry-age cache-entry-age`—(Optional) Maximum time that the NIC proxy can cache an entry. The NIC proxy compares this property with the life expectancy of each

entry and uses the lower value to determine when to remove the entry.

Value— Number of seconds in the range 0–4294967295

- 0 or unspecified—Life expectancy of the data, which determines expiration of data
- Other values—Actual time that the NIC proxy caches entries

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Advanced

slot *number* external-subscriber-monitor nic-proxy-configuration radius-authorization-nic nic-host-selection

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic nic-host-selection {
    groups [groups...];
    selection-criteria (roundRobin | randomPick | priorityList);
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic nic-host-selection]
```

Description

Configure the mechanism that a NIC proxy uses to select NIC system if multiple systems are available. You use NIC host selection when you use NIC replication.

Options

groups [*groups...*]—(Optional) List of groups of NIC hosts that the NIC proxy can contact for resolution requests.

Value— Names of groups.

Default— No value

Editing Level—Advanced

selection-criteria (roundRobin | randomPick | priorityList)—
Selection criteria that the NIC proxy uses to determine which NIC host to contact. Configure selection criteria if you configure more than one group.

Value— One of the following criteria:

- roundRobin—NIC proxy selects NIC hosts in a fixed, cyclic order. The NIC proxy always selects the next host in the list.
- randomPick—NIC proxy selects NIC hosts randomly from the list.
- priorityList—NIC proxy selects NIC hosts according to their assigned priorities in the list. If the host with the highest priority in the list is not available, the NIC proxy tries the host with the next-highest priority, and so on.

Use round-robin or random pick to distribute resolution requests among NIC hosts. Use priority list if you prefer to use a particular NIC host; for example, you may reduce operating cost by using a local NIC host.

Default—roundRobin

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Advanced

slot *number* external-subscriber-monitor nic-proxy-configuration radius-authorization-nic nic-host-selection blacklisting

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic nic-host-selection blacklisting {
    try-next-system-on-error;
    number-of-retries-before-blacklisting number-of-retries-before-
blacklisting;
    blacklist-retry-interval blacklist-retry-interval;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic nic-host-selection blacklisting]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure how to handle nonresponsive NIC hosts. When a NIC host does not respond, it is blacklisted which means that other NIC hosts are contacted until the blacklisted host becomes available again.

Options

try-next-system-on-error—(Optional) Specifies whether or not the NIC proxy should contact the next specified NIC host if a NIC host is determined to be unavailable. Configure this property only if you configure more than one group.

Default—true

Editing Level—Advanced

number-of-retries-before-blacklisting *number-of-retries-before-blacklisting*— Number of times the NIC proxy tries to communicate with a NIC host before the NIC proxy stops communicating with the NIC host for a period of time.

Value—Integer in the range 0–2147483647

Default—3

Editing Level—Advanced

`blacklist-retry-interval` *blacklist-retry-interval*—Interval at which the NIC proxy attempts to connect to an unavailable NIC host.

Value—Integer in the range 15–2147483647 s

Default—15

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor nic-proxy-configuration radius-authorization-nic resolution

Syntax

```
slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic resolution {
    resolver-name resolver-name;
    constraints constraints;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor nic-proxy-configuration radius-
authorization-nic resolution]
```

Description

Configure properties for a NIC proxy (NIC locator), the NIC component that requests information on behalf of an application.

Options

resolver-name *resolver-name*— NIC resolver that the NIC proxy uses. This resolver must be the same as one that is configured on the NIC host.

Value— Path to the NIC resolver.

Example—/realms/ip/A1

Default— No value

Editing Level—Normal

constraints *constraints*—(Optional) Data type that a resolver uses during the resolution process. A constraint represents a condition that must or may be satisfied before the next stage of the resolution process can proceed.

Configure a constraint only if the constraint will be provided by the application in the resolution request. Typically, you do not need to configure constraints.

Value— Data types of constraints specified for the NIC resolution.
Separate data types with commas.

Default— No value
Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor radius-accounting

Syntax

```
slot number external-subscriber-monitor radius-accounting {
    port port;
    include-mac-address;
    include-interface-name;
    service-type (all | login | framed | callback-login | callback-framed |
outbound | administrative | nas-prompt | authenticate-only | callback-nas-
prompt | callback-check | callback-administrative);
    allow [allow...];
    deny [deny...];
    maximum-queue-length maximum-queue-length;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-accounting]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the pseudo-RADIUS server. If not configured, no pseudo-RADIUS service is started.

Options

port port—Listening port for RADIUS accounting requests.

Value—Integer in the range 1–65535

Default— 1813

Editing Level—Normal

include-mac-address—(Optional) Specify whether the MAC address is included in the event notification.

NOTE: Do not configure if you are not extracting RADIUS attributes with the pseudo-RADIUS server.

Default— false

Editing Level—Normal

`include-interface-name`—(Optional) Specify whether the interface name is included in the event notification.

NOTE: Do not configure if you are not extracting RADIUS attributes with the pseudo-RADIUS server.

Default— false

Editing Level—Normal

`service-type (all | login | framed | callback-login | callback-framed | outbound | administrative | nas-prompt | authenticate-only | callback-nas-prompt | callback-check | callback-administrative)`—(Optional) Service type of RADIUS packets that will be forwarded.

Value

- `all`— Forward all packets
- `login`— Forward packets with type of Login
- `framed`— Forward packets with type of Framed
- `callback-login`— Forward packets with type of Callback Login
- `callback-framed`— Forward packets with type of Callback Framed
- `outbound`— Forward packets with type of Outbound
- `administrative`— Forward packets with type of Administrative
- `nas-prompt`— Forward packets with type of NAS Prompt
- `authenticate-only`— Forward packets with type of Authenticate Only
- `callback-nas-prompt`— Forward packets with type of Callback NAS Prompt
- `callback-check`— Forward packets with type of Callback Check
- `callback-administrative`— Forward packets with type of Callback Administrative

Default— framed

Editing Level—Advanced

`allow [allow . . .]`—(Optional) List of hosts that filters which packets are forwarded. If both the allow and deny lists are empty, forward all packets. If the allow list has entries and the deny list is empty, forward packets from the listed hosts and ignore all others. If the allow list is empty and the deny list has entries, forward all packets except those from the listed hosts in the deny list. If both the allow and deny lists have entries, forward packets from the listed hosts in the allow list and ignore the deny list entries.

Value— Entries are delimited by spaces in the format ID = < regular expression > or IP = < regular expression >

Example—allow = ID = C2000.*

Default— Empty list

Editing Level—Advanced

deny [*deny*. . .]—(Optional) List of hosts that filters which packets are forwarded. If both the allow and deny lists are empty, forward all packets. If the allow list has entries and the deny list is empty, forward packets from the listed hosts and ignore all others. If the allow list is empty and the deny list has entries, forward all packets except those from the listed hosts in the deny list. If both the allow and deny lists have entries, forward packets from the listed hosts in the allow list and ignore the deny list entries.

Value— Entries are delimited by spaces in the format ID = < regular expression > or IP = < regular expression >

Example—deny = ID = SAE.*

Default— Empty list

Editing Level—Advanced

maximum-queue-length *maximum-queue-length*— Maximum number of unacknowledged RADIUS messages received from the RADIUS server before it discards new messages. 0 or negative number means infinite number of messages are allowed.

Value— Integer in the range 0–2147483647

Default— 10000

Editing Level—Normal

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor radius-accounting client

Syntax

```
slot number external-subscriber-monitor radius-accounting client client-address {
    secret secret;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-accounting client]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the shared secret between the RADIUS server and its clients.

Options

client-address client-address— Address of the specific RADIUS client.

Value— Address in dot format. Currently, only IPv4 addresses are supported.

secret secret— Shared secret of a specific RADIUS client.

Value—Secret text

Editing Level—Basic

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor radius-attribute-extraction default interface-name

Syntax

```
slot number external-subscriber-monitor radius-attribute-
extraction default interface-name {
    regular-expression [regular-expression...];
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-attribute-
extraction default interface-name]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the interface name attribute value extraction. By default, the interface-name attribute value is extracted from standard RADIUS attribute id = 87(RADIUS, 87) with RADIUS attribute type of chars.

Options

regular-expression [*regular-expression...*]—(Optional) The regular expression of the radius attribute, A multivalue can be specified. If no regular expression is specified, the whole value would be considered the valid value; if any regular expression is present, Only the first group of regular expression is considered the valid value. Note that if type is raw-byte, the regular expression should be described hexadecimal format.

Value—Text

Default—None

Editing Level—Basic

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor radius-attribute-extraction default virtual-router-name

Syntax

```
slot number external-subscriber-monitor radius-attribute-
extraction default virtual-router-name {
    id id;
    vsa;
    vsa-id vsa-id;
    regular-expression [regular-expression...];
    type (raw-byte | chars);
    prefix prefix;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-attribute-
extraction default virtual-router-name]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the virtual router name attribute value extraction.

Options

id id— Specifies RADIUS attribute ID

Value—Integer in the range 0–2147483647

Editing Level—Basic

vsa—(Optional) Indicate if this attribute is vendor specific

Default— false

Editing Level—Basic

vsa-id vsa-id—(Optional) Specifies radius vendor specific identifier

Value—Integer in the range 0–2147483647

Editing Level—Basic

`regular-expression [regular-expression...]`—(Optional) The regular expression of the radius attribute. A multivalued value can be specified. If no regular expression is specified, the whole value would be considered the valid value; if any regular expression is present, only the first group of regular expression is considered the valid value. Note that if type is raw-byte, the regular expression should be described in hexadecimal format.

Value—Text

Default—None

Editing Level—Basic

`type (raw-byte | chars)`—(Optional) The value type of this radius attribute. Currently only supports two types: 'r' (raw bytes) and 's' (string). By default, the type is raw type, 'r'.

Value

- `raw-byte`—Set type as raw byte
- `chars`—Set type as a sequence of characters

Default—r

Editing Level—Basic

`prefix prefix`—(Optional) The prefix that is to be appended to radius attribute's value.

Value—Text

Default—None

Editing Level—Basic

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor radius-authorization

Syntax

```
slot number external-subscriber-monitor radius-authorization {
    port port;
    local-address local-address;
    check-lease-limit-with-sae;
    query-cached-dhcp-profile;
    default-lease-limit default-lease-limit;
    invalid-pool-name invalid-pool-name;
    lease-time-limit lease-time-limit;
    cleanup-interval cleanup-interval;
    maximum-age maximum-age;
    minimum-pool-size minimum-pool-size;
    maximum-queue-length maximum-queue-length;
    service-type (all | login | framed | callback-login | callback-framed |
outbound | administrative | nas-prompt | authenticate-only | callback-nas-
prompt | callback-check | callback-administrative);
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-authorization]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the pseudo-RADIUS authorization server.

Options

`port port`—Listening port for RADIUS access requests.

Value—Integer in the range 1–65535

Default— 1812

Editing Level—Normal

`local-address local-address`—(Optional) Address to bind to pseudo-RADIUS authorization server. Absence of this attribute means binding the server to a wildcard (*) address. Currently, only IPV4 addresses are supported.

Value—Text
Editing Level—Advanced

`check-lease-limit-with-sae`—(Optional) Specify whether to query the SAE for the number of active subscribers for a given interface. If set to true, the response to the RADIUS access request depends on the comparison between the number of active subscriber sessions and the lease limit for the interface. If the number of active subscriber sessions is less than the lease limit, the response is RADIUS access accept message without the lease limit RADIUS attribute; otherwise, the response is RADIUS access deny message. If set to false, the response is RADIUS access accept message with the lease limit RADIUS attribute.

Default— false
Editing Level—Normal

`query-cached-dhcp-profile`—(Optional) Specify whether to search for a cached DHCP profile in the o = AuthCache directory based on the MAC address.

If set to true, you must configure a directory connection to the cached DHCP profiles, and the following conditions apply:

- If a cached DHCP profile is found, the RADIUS response message includes the RADIUS attributes for framed IP address, pool name, service bundle, and RADIUS class attributes.
- If the `check-lease-limit-with-sae` option is set to true and the number of active subscriber sessions is less than the lease limit, the RADIUS access accept message includes the cached DHCP profile.
- If the `check-lease-limit-with-sae` option is set to false, the RADIUS response always includes the cached DHCP profile.

If set to false, the cached DHCP profile information is not included in the RADIUS response.

Default— false
Editing Level—Normal

`default-lease-limit` *default-lease-limit*—(Optional) Default lease limit for all interfaces.

Value—Integer in the range -2147483648–2147483647
Default— 1
Editing Level—Normal

`invalid-pool-name` *invalid-pool-name*—(Optional) Invalid pool name returned when number of active subscriber sessions exceeds the lease limit.

Value—None empty pool name
Editing Level—Normal

`lease-time-limit` *lease-time-limit*—(Optional) Timeout of a cached authenticated request.

Value—Integer in the range 1–9223372036854775807 ms
Default— 60000
Editing Level—Advanced

`cleanup-interval` *cleanup-interval*—(Optional) Time to wait before cleaning up cached RADIUS access requests that have been authenticated or accepted.

Value—Integer in the range 1–9223372036854775807 ms
Default— 3600000
Editing Level—Advanced

`maximum-age` *maximum-age*—(Optional) Maximum age of an unacknowledged request packet cached in memory. We recommend a value slightly greater than the RADIUS packet retry interval.

Value—Integer in the range 1–9223372036854775807 ms
Default— 60000
Editing Level—Basic

`minimum-pool-size` *minimum-pool-size*—(Optional) Number of concurrent threads processing RADIUS messages subtasks.

Value—Integer in the range 1–2147483647
Default— 8
Editing Level—Basic

`maximum-queue-length` *maximum-queue-length*— Maximum number of unacknowledged RADIUS messages received from the RADIUS server before it discards new messages. 0 or negative number means infinite number of messages are allowed.

Value— Integer in the range 0–2147483647
Default— 10000
Editing Level—Normal

`service-type` (all | login | framed | callback-login | callback-framed | outbound | administrative | nas-prompt | authenticate-only | callback-nas-prompt | callback-check | callback-

administrative) —(Optional) Service type of RADIUS packets that will be forwarded.

Value

- all— Forward all packets
- login— Forward packets with type of Login
- framed— Forward packets with type of Framed
- callback-login— Forward packets with type of Callback Login
- callback-framed— Forward packets with type of Callback Framed
- outbound— Forward packets with type of Outbound
- administrative— Forward packets with type of Administrative
- nas-prompt— Forward packets with type of NAS Prompt
- authenticate-only— Forward packets with type of Authenticate Only
- callback-nas-prompt— Forward packets with type of Callback NAS Prompt
- callback-check— Forward packets with type of Callback Check
- callback-administrative— Forward packets with type of Callback Administrative

Default— framed

Editing Level—Advanced

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor radius-authorization client

Syntax

```
slot number external-subscriber-monitor radius-authorization client client-address {
    secret secret;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-authorization client]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the shared secret between the RADIUS server and its clients.

Options

client-address client-address— Address of the specific RADIUS client.

Value— Address in dot format. Currently, only IPv4 addresses are supported.

secret secret— Shared secret of a specific RADIUS client.

Value—Secret text
Editing Level—Basic

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor radius-authorization ldap cached-dhcp-profile

Syntax

```
slot number external-subscriber-monitor radius-authorization ldap cached-dhcp-profile {
    base base;
    base-dn base-dn;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-authorization ldap cached-dhcp-profile]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the connection to the directory in which the cached DHCP profile data is stored.

Options

base base—(Optional) Top level or base or directory DN

Value— DN. You can use *< base >* to refer to the globally configured base DN. The string *< base >* is replaced with the directory base DN.

Default— *< base >*

Editing Level—Advanced

base-dn base-dn—(Optional) Subtree in the directory in which authCache profile data is stored.

Value— DN. You can use *< base >* to refer to the globally configured base DN. The string *< base >* is replaced with the directory base DN.

Default— *o = authCache, < base >*

Editing Level—Normal

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor radius-authorization ldap cached-dhcp-profile directory-connection

Syntax

```
slot number external-subscriber-monitor radius-authorization ldap cached-dhcp-
profile directory-connection {
    url url;
    principal principal;
    credentials credentials;
    protocol (ldaps);
    backup-urls [backup-urls...];
    timeout timeout;
    check-interval check-interval;
    blacklist;
    snmp-agent;
    signature-dn signature-dn;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-authorization ldap cached-
dhcp-profile directory-connection]
```

Description

Configure properties for the directory connection.

Options

`url url`—(Optional) URL that identifies the location of the primary directory server.

Value— URL

Default—`ldap://127.0.0.1:389`

Editing Level—Basic

`principal principal`— DN that the SRC component uses for authentication to access the directory.

Value— DN.

When you specify the DN, you can use `< base >` to indicate the base DN.

Editing Level—Basic

`credentials credentials`—Password with which the SRC component accesses the directory.

Value— Password

Editing Level—Basic

`protocol (ldaps)`—(Optional) Security protocol used to connect to the directory. If you do not configure a security protocol, plain socket is used.

Value

- `ldaps`— LDAPS which uses SSL.

Editing Level—Expert

`backup-urls [backup-urls...]`—(Optional) URLs that identify the locations of backup directory servers. Backup servers are used if the primary directory server is not accessible.

Value— List of URLs

Editing Level—Basic

`timeout timeout`—(Optional) Maximum amount of time during which the directory must respond to a connection request.

Value—Integer in the range 1–2147483647 s

Default—10

Editing Level—Expert

`check-interval check-interval`—(Optional) Time interval at which the directory monitoring system verifies its connection to the directory. If the directory connection fails after this interval, the directory monitoring system initiates a connection to another directory.

Value—Integer in the range 15–2147483647 s

Default—60

Editing Level—Expert

`blacklist`—(Optional) Specifies whether the directory monitoring system prevents

connection to a directory if the directory fails to respond during 10 polling intervals.

Default—false

Editing Level—Basic

`snmp-agent`—(Optional) Enable the SDX SNMP agent to export MIBs for this directory connection.

Default—false

Editing Level—Expert

`signature-dn` *signature-dn*—(Optional) DN of the directory entry that specifies the `usedDirectory` attribute for the SRC CLI. The `usedDirectory` attribute identifies the vendor of the directory server.

Value— DN

Default—o = umc

Editing Level—Expert

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

slot *number* external-subscriber-monitor radius-authorization ldap subscriber-data

Syntax

```
slot number external-subscriber-monitor radius-authorization ldap subscriber-
data {
    base base;
    base-dn base-dn;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-
authorization ldap subscriber-data]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the connection to the directory in which subscriber data is stored.

Options

base base—(Optional) Top level or base or directory DN.

Value— DN. You can use < base > to refer to the globally configured base DN. The string < base > is replaced with the directory base DN.

Default— < base >

Editing Level—Advanced

base-dn base-dn—(Optional) Subtree in the directory in which subscriber data is stored.

Value— DN. You can use < base > to refer to the globally configured base DN. The string < base > is replaced with the directory base DN.

Default— o = Users, < base >

Editing Level—Normal

Required Privilege Level

No specific privilege required.

Required Editing Level

Normal

slot *number* external-subscriber-monitor radius-authorization ldap subscriber-data directory-connection

Syntax

```
slot number external-subscriber-monitor radius-authorization ldap subscriber-
data directory-connection {
    url url;
    principal principal;
    credentials credentials;
    protocol (ldaps);
    backup-urls [backup-urls...];
    timeout timeout;
    check-interval check-interval;
    blacklist;
    snmp-agent;
    signature-dn signature-dn;
}
```

Hierarchy Level

```
[edit slot number external-subscriber-monitor radius-
authorization ldap subscriber-data directory-connection]
```

Description

Configure properties for the directory connection.

Options

`url url`—(Optional) URL that identifies the location of the primary directory server.

Value— URL

Default—`ldap://127.0.0.1:389`

Editing Level—Basic

`principal principal`— DN that the SRC component uses for authentication to access the directory.

Value— DN.

When you specify the DN, you can use `< base >` to indicate the base DN.

Editing Level—Basic

`credentials` *credentials*—Password with which the SRC component accesses the directory.

Value— Password

Editing Level—Basic

`protocol` (`ldaps`)—(Optional) Security protocol used to connect to the directory. If you do not configure a security protocol, plain socket is used.

Value

- `ldaps`— LDAPS which uses SSL.

Editing Level—Expert

`backup-urls` [*backup-urls...*]—(Optional) URLs that identify the locations of backup directory servers. Backup servers are used if the primary directory server is not accessible.

Value— List of URLs

Editing Level—Basic

`timeout` *timeout*—(Optional) Maximum amount of time during which the directory must respond to a connection request.

Value—Integer in the range 1–2147483647 s

Default—10

Editing Level—Expert

`check-interval` *check-interval*—(Optional) Time interval at which the directory monitoring system verifies its connection to the directory. If the directory connection fails after this interval, the directory monitoring system initiates a connection to another directory.

Value—Integer in the range 15–2147483647 s

Default—60

Editing Level—Expert

`blacklist`—(Optional) Specifies whether the directory monitoring system prevents

connection to a directory if the directory fails to respond during 10 polling intervals.

Default—false

Editing Level—Basic

`snmp-agent`—(Optional) Enable the SDX SNMP agent to export MIBs for this directory connection.

Default—false

Editing Level—Expert

`signature-dn` *signature-dn*—(Optional) DN of the directory entry that specifies the `usedDirectory` attribute for the SRC CLI. The `usedDirectory` attribute identifies the vendor of the directory server.

Value— DN

Default—o = umc

Editing Level—Expert

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

show external-subscriber-monitor statistics event-notifications

Syntax

```
show external-subscriber-monitor statistics event-notifications
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display statistics about event notifications, including the number of ipUp and ipDown notifications sent.

Required Privilege Level

view

show external-subscriber-monitor statistics process

Syntax

```
show external-subscriber-monitor statistics process
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display process information for External Subscriber Monitor, including up time and memory usage.

Required Privilege Level

view

show external-subscriber-monitor statistics radius-accounting

Syntax

```
show external-subscriber-monitor statistics radius-accounting <client-address
client-address> < (brief) >
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display RADIUS accounting statistics for External Subscriber Monitor.

Options

`client-address client-address`—(Optional) IP address of a RADIUS accounting client. If you do not specify a valid client address, statistics for all clients are displayed.

Value—Text

Default— No value

(Optional) Output style

Value

- `brief`— Display only total number of RADIUS packets sent or received.

Default— Detail

Required Privilege Level

view

show external-subscriber-monitor statistics radius-authorization

Syntax

```
show external-subscriber-monitor statistics radius-authorization <client-  
address client-address> < (brief) >
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display RADIUS authorization statistics for External Subscriber Monitor.

Options

client-address client-address—(Optional) IP address of a RADIUS authorization client. If you do not specify a valid client address, statistics for all clients are displayed.

Value—Text

Default— No value

(Optional) Output style

Value

- **brief**— Display only total number of RADIUS packets sent or received.

Default— Detail

Required Privilege Level

view

SRC Admission Control Plug-In (SRC-ACP)

The following table summarizes the SRC command-line interface (SRC CLI) for providing admission control. Configuration statements and operational commands are listed in alphabetical order.

SRC-ACP
Configuration Statements
shared acp configuration acp-options
shared acp configuration corba
shared acp configuration ldap service-data
shared acp configuration ldap subscriber-data
shared acp configuration logger
shared acp configuration logger name file
shared acp configuration logger name syslog
shared acp configuration nic-proxy-configuration
shared acp configuration nic-proxy-configuration name cache
shared acp configuration nic-proxy-configuration name nic-host-selection
shared acp configuration nic-proxy-configuration name nic-host-selection blacklisting
shared acp configuration nic-proxy-configuration name resolution
shared acp configuration nic-proxy-configuration name test-nic-bindings
shared acp configuration nic-proxy-configuration name test-nic-bindings key-values
shared acp configuration redundancy
shared acp configuration scripts-and-classification
shared acp congestion-point-classifier rule
shared acp congestion-point-classifier rule name condition
shared acp group
shared admission-control device

shared admission-control device name interface
shared congestion-points congestion-point-profile
shared congestion-points profile
slot number acp
slot number acp initial
slot number acp initial directory-connection
slot number acp initial directory-eventing
Operational Commands
request acp reorganize-backup-database
show acp backbone congestion-point congestion-point-expression
show acp backbone congestion-point dn
show acp backbone service
show acp edge congestion-point dn
show acp edge congestion-point subscriber-session-id
show acp edge subscriber
show acp remote-update congestion-point dn
show acp remote-update congestion-point name
show acp remote-update subscriber
show acp statistics device
show acp statistics directory
show acp statistics general

shared acp configuration acp-options

Syntax

```
shared acp configuration acp-options {
    backup-directory backup-directory;
    mode (edge | backbone | dual);
    event-cache-size event-cache-size;
    overload-method overload-method;
    reservation-timeout reservation-timeout;
    congestion-point-auto-completion;
    tuning-factor tuning-factor;
    subscriber-bandwidth-exceed-message subscriber-bandwidth-exceed-message;
    network-bandwidth-exceed-message network-bandwidth-exceed-message;
    backup-database-maximum-size backup-database-maximum-size;
    remote-update-database-index-keys remote-update-database-index-keys;
    interface-tracking-filter interface-tracking-filter;
    state-sync-bulk-size state-sync-bulk-size;
}
```

Hierarchy Level

```
[edit shared acp configuration acp-options]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure SRC-ACP operation.

Options

`backup-directory backup-directory`— Folder that stores backup information about subscribers, services, and congestion points.

Value—Text

Default— var/backup

Editing Level—Expert

`mode (edge | backbone | dual)`— Regions of the network that SRC-ACP manages.

Value— One of the following regions:

- **edge**—SRC-ACP operates in the edge region of network only
- **backbone**—SRC-ACP operates in the backbone region of the network only
- **dual**—SRC-ACP operates in both the edge and backbone regions of network

Default— dual

Editing Level—Basic

`event-cache-size` *event-cache-size*— Number of plug-in events from the SAE that SRC-ACP can store in its cache. Specifying a large number increases the efficiency of SRC-ACP, and minimizes the use of CPU resources; however, the amount of memory available for the cache will depend on the host's resources.

Value—Integer in the range 0-2147483647

Default— 1000

Editing Level—Expert

`overload-method` *overload-method*— Specifies how SRC-ACP deals with situations where the components exceed the allocated bandwidth because the service was activated after the authorization was granted.

Value— Integer in the range -1-2147483647

- **-1**—SRC-ACP ignores overload
- Integer greater than or equal to 0—Bandwidth (in bps) by which the maximum may be exceeded

Default— 0

Editing Level—Basic

`reservation-timeout` *reservation-timeout*—(Optional) Time to wait until a bandwidth reservation expires. The reserved bandwidth is reclaimed by SRC-ACP when the reservation expires.

Value—Integer in the range 0-2147483647 ms

Default— 10000

Editing Level—Basic

`congestion-point-auto-completion`—(Optional) Specifies whether SRC-ACP uses the information acquired from the router to determine the congestion points.

Editing Level—Basic

`tuning-factor` *tuning-factor*—(Optional) Specifies factors that compensate for actual use of bandwidth, as opposed to allocated bandwidth.

Value— List of tuning factors, separated by commas; each tuning factor is a floating number in the range 0–1

Editing Level—Basic

`subscriber-bandwidth-exceed-message` *subscriber-bandwidth-exceed-message*— Error message that SRC-ACP sends when the subscriber exceeds the allocated bandwidth.

Value—Text

Default— Subscriber bandwidth exceeded

Editing Level—Basic

`network-bandwidth-exceed-message` *network-bandwidth-exceed-message*— Error message that SRC-ACP sends when traffic flow exceeds the allocated bandwidth on an interface between the subscriber and the router.

Value—Text

Default— Network bandwidth exceeded

Editing Level—Basic

`backup-database-maximum-size` *backup-database-maximum-size*— Value by which the sum of the sizes of the files that contain SRC-ACP data can increment before SRC-ACP reorganizes the files. Reorganizing the files reduces their size. Choose a value that is significantly lower than the capacity of the machine's hard disk.

Value— Text string in the format *numberm* or *numberg*

- *numberm*—Size of database in megabytes
- *numberg*—Size of database in gigabytes

Default— 100m

Editing Level—Basic

`remote-update-database-index-keys` *remote-update-database-index-keys*— Values to look for in the configuration data. Specifying index keys can improve performance by filtering the data. For information about the values you can specify, see the documentation that describes how to configure SRC-ACP operation.

Value— List of attributes, separated by commas

Default— interfaceName, routerName, portId

Editing Level—Basic

`interface-tracking-filter` *interface-tracking-filter*— A filter specifying the interfaces to be tracked by SRC-ACP. Filtering the interface tracking events can improve performance and can reduce the amount of memory required for keeping the congestion points updated. For information about the values you can specify, see the documentation that describes how to configure SRC-ACP operation.

Value— Filter strings in the format of a list of < attribute > = < value > pairs; that can be contained within query operations. For example: (&(interfaceName = *)(interfaceSpeed = 1000000))

Editing Level—Basic

`state-sync-bulk-size` *state-sync-bulk-size*—(Optional) Number of events the SAE sends to SRC-ACP in a single method call during state synchronization.

Value—Integer in the range 1–1000

Default— 100

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration corba

Syntax

```
shared acp configuration corba {
    acp-ior acp-ior;
    remote-update-ior remote-update-ior;
}
```

Hierarchy Level

```
[edit shared acp configuration corba]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure CORBA interfaces.

Options

acp-ior acp-ior— Object reference for SRC-ACP that is exported through either a local file or a Common Object Services (COS) naming service.

Value— One of the following references:

- *file://path*—Exports object reference through a local file where *path* is the absolute path to local file
- *corbaname::cosNameServer#KEY*—Exports object reference through COS naming services
 - *cosNameServer*—IP address or Domain Name System (DNS) name of COS naming server
 - *KEY*—Object reference of SRC-ACP
- *corbaname:rir#KEY*—Exports object reference through COS naming service; resolve-initial-references (rir) function finds DNS name of COS naming server

Default— *file:///var/acp/acp.ior*

Editing Level—Basic

remote-update-ior remote-update-ior—(Optional) Object reference for the SRC-

ACP external interface.

Value— One of the following references:

- `file://path`—Exports object reference through a local file where *path* is the absolute path to local file
- `corbaname::cosNameServer#KEY`—Exports object reference through COS naming services
 - *cosNameServer*—IP address or Domain Name System (DNS) name of COS naming server
 - *KEY*—Object reference of SRC-ACP
- `corbaname:rir#KEY`—Exports object reference through COS naming service; resolve-initial-references (rir) function finds DNS name of COS naming server

Default— `file:///var/acp/sra.ior`

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration ldap service-data

Syntax

```
shared acp configuration ldap service-data {
    edge-congestion-point-dn edge-congestion-point-dn;
    backbone-congestion-point-dn backbone-congestion-point-dn;
    reload-congestion-points;
    congestion-points-eventing;
    server-address server-address;
    server-port server-port;
    dn dn;
    principal principal;
    password password;
    event-dn event-dn;
    directory-eventing;
    polling-interval polling-interval;
    secured-ldap-protocol (ldaps);
}
```

Hierarchy Level

```
[edit shared acp configuration ldap service-data]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure SRC-ACP connection to the directory that stores information about services.

Options

edge-congestion-point-dn edge-congestion-point-dn— DN of the directory that contains information about network interfaces for edge congestion points.

Value— DN

Default— o = AdmissionControl, o = umc

Editing Level—Expert

backbone-congestion-point-dn backbone-congestion-point-dn— DN of the directory that contains information about network interfaces for backbone congestion point objects.

Value— DN

Default— o = CongestionPoints, o = umc

Editing Level—Expert

`reload-congestion-points`—(Optional) Specifies whether SRC-ACP detects changes in the backbone congestion point for a service while SRC-ACP is operative.

Enable only when you want to modify a congestion point. Disable when you have modified the congestion point.

Editing Level—Basic

`congestion-points-eventing`—(Optional) Enables directory eventing for congestion points.

Editing Level—Basic

`server-address` *server-address*— List of primary and redundant servers that manage data.

Value— List of IP addresses or hostnames separated by spaces

Default— 127.0.0.1

Editing Level—Normal

`server-port` *server-port*— TCP port for the directory.

Value—Integer in the range 0–65535

Default— 389

Editing Level—Normal

`dn` *dn*— DN of the root of the directory.

Value— List of attribute = value pairs separated by commas

Editing Level—Advanced

`principal` *principal*— DN used to authorize connections to the directory.

Value— List of attribute = value pairs separated by commas

Default— cn = umcadmin, o = umc

Editing Level—Advanced

`password` *password*— Password used to authorize connections to the directory.

Value— Secret text

Default— `admin123`

Editing Level— Advanced

`event-dn` *event-dn*— DN of the directory that contains event information.

Value— DN

Editing Level— Expert

`directory-eventing`— (Optional) Enable directory eventing.

Editing Level— Advanced

`polling-interval` *polling-interval*— Time interval at which the SRC component polls the directory.

Value— Number of seconds in the range 15–86400

Default— 30

Editing Level— Advanced

`secured-ldap-protocol` (`ldaps`)— (Optional) Secured LDAP protocol

Value

- `ldaps`—

Editing Level— Advanced

Required Privilege Level

system

Required Editing Level

Normal

shared acp configuration ldap subscriber-data

Syntax

```
shared acp configuration ldap subscriber-data {
    congestion-points-eventing;
    server-address server-address;
    server-port server-port;
    dn dn;
    principal principal;
    password password;
    event-dn event-dn;
    directory-eventing;
    polling-interval polling-interval;
    secured-ldap-protocol (ldaps);
}
```

Hierarchy Level

```
[edit shared acp configuration ldap subscriber-data]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure SRC-ACP connection to the directory that stores subscriber information.

Options

`congestion-points-eventing`—(Optional) Enables directory eventing for congestion points.

Editing Level—Basic

`server-address` *server-address*— List of primary and redundant servers that manage data.

Value— List of IP addresses or hostnames separated by spaces

Default— 127.0.0.1

Editing Level—Normal

`server-port` *server-port*— TCP port for the directory.

Value—Integer in the range 0–65535

Default— 389

Editing Level—Normal

`dn` *dn*— DN of the root of the directory.

Value— List of attribute = value pairs separated by commas

Editing Level—Advanced

`principal` *principal*— DN used to authorize connections to the directory.

Value— List of attribute = value pairs separated by commas

Default— cn = umcadmin, o = umc

Editing Level—Advanced

`password` *password*— Password used to authorize connections to the directory.

Value—Secret text

Default— admin123

Editing Level—Advanced

`event-dn` *event-dn*— DN of the directory that contains event information.

Value— DN

Editing Level—Expert

`directory-eventing`—(Optional) Enable directory eventing.

Editing Level—Advanced

`polling-interval` *polling-interval*— Time interval at which the SRC component polls the directory.

Value— Number of seconds in the range 15–86400

Default— 30

Editing Level—Advanced

`secured-ldap-protocol` (*ldaps*)—(Optional) Secured LDAP protocol

Value

- ldaps—

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Normal

shared acp configuration logger

Syntax

shared acp configuration logger *name* ...

Hierarchy Level

[edit shared acp configuration logger]

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the logging destination.

Options

name *name*— Name of logging destination.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration logger *name* file

Syntax

```
shared acp configuration logger name file {
    filter filter;
    filename filename;
    rollover-filename rollover-filename;
    maximum-file-size maximum-file-size;
}
```

Hierarchy Level

```
[edit shared acp configuration logger name file]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure logging of messages to a file.

Options

filter filter—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default— The default value is different for each type of component.

Editing Level—Basic

filename filename— Absolute path of the filename that contains the current logs.

Note: Make sure that the user under which the J2EE application server or Web application server runs has write access to this folder. If this user does not have write access to the default folder, configure the component or application to write logs in folders to which the user has write access.

Value— Filename

Default— No value

Editing Level—Basic

`rollover-filename rollover-filename`—(Optional) Absolute path of the filename that contains the log history. When the log file reaches the maximum size, the software closes the log file and renames it with the name you specify for the rollover file. If a previous rollover file exists, the software overwrites it. The software then reopens the log file and continues to save event messages in it.

Value— Path of filename

Example—`/opt/UMC/sae/var/log/sae.alt`

Default— The default value is different for each type of component.

Editing Level—Normal

`maximum-file-size maximum-file-size`—(Optional) Maximum size of the log file and the rollover file.

Do not set the maximum file size to a value greater than the available disk space.

Value—Integer in the range 0–2147483647 kbytes

Default— 1000000

Editing Level—Normal

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration logger *name* syslog

Syntax

```
shared acp configuration logger name syslog {
    filter filter;
    host host;
    facility facility;
    format format;
}
```

Hierarchy Level

```
[edit shared acp configuration logger name syslog]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure logging of messages to system logging.

Options

filter filter—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default—/error-

Editing Level—Basic

host host— IP address or name of a host that collects event messages by means of a standard system logging daemon.

Value— IP address or hostname

Default—loghost

Editing Level—Basic

facility facility—(Optional) Type of system log in accordance with the system logging protocol.

Value—Integer in the range 0–23

Default— 3

Editing Level—Advanced

`format` *format*—(Optional) MessageFormat string that specifies how the information in an event message is printed. (The strings {#} are replaced with the log information [...]).

Value— MessageFormat string as specified in <http://java.sun.com/j2se/1.4.2/docs/api/java/text/MessageFormat.html>.

The fields available for events are:

- 0—Time and date of the event
- 1—Name of the thread generating the event
- 2—Text message of the event
- 3—Category of the event
- 4—Priority of the event

Default— None

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration nic-proxy-configuration

Syntax

```
shared acp configuration nic-proxy-configuration name {  
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration]
```

Options

name name—

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration nic-proxy-configuration *name* cache

Syntax

```
shared acp configuration nic-proxy-configuration name cache {
    cache-size cache-size;
    cache-cleanup-interval cache-cleanup-interval;
    cache-entry-age cache-entry-age;
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration name cache]
```

Description

Configure the NIC Proxy cache properties. You can modify cache properties for the NIC proxy to optimize the resolution performance for your network configuration and system resources. Typically, you can use the default settings for the cache properties.

Options

`cache-size cache-size`—(Optional) Maximum size of the cache in which the NIC proxy retains data. If you decrease the cache size or disable the cache while the NIC proxy is running, the NIC proxy removes entries in order of descending age until the cache size meets the new limit.

Value— Integer in the range 0–2147483647

Default— 10000

Editing Level—Advanced

`cache-cleanup-interval cache-cleanup-interval`— Time interval at which the NIC proxy removes expired entries from its cache.

Value— Number of seconds in the range 5–2147483

Default— 15

Editing Level—Advanced

`cache-entry-age cache-entry-age`—(Optional) Maximum time that the NIC proxy can cache an entry. The NIC proxy compares this property with the life expectancy of each entry and uses the lower value to determine when to remove the entry.

Value— Number of seconds in the range 0–4294967295

- 0 or unspecified—Life expectancy of the data, which determines expiration of data
- Other values—Actual time that the NIC proxy caches entries

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Advanced

shared acp configuration nic-proxy-configuration *name* nic-host-selection

Syntax

```
shared acp configuration nic-proxy-configuration name nic-host-selection {
    groups [groups...];
    selection-criteria (roundRobin | randomPick | priorityList);
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration name nic-host-selection]
```

Description

Configure the mechanism that a NIC proxy uses to select NIC system if multiple systems are available. You use NIC host selection when you use NIC replication.

Options

`groups [groups...]`—(Optional) List of groups of NIC hosts that the NIC proxy can contact for resolution requests.

Value— Names of groups.

Default— No value

Editing Level—Advanced

`selection-criteria (roundRobin | randomPick | priorityList)`— Selection criteria that the NIC proxy uses to determine which NIC host to contact. Configure selection criteria if you configure more than one group.

Value— One of the following criteria:

- `roundRobin`—NIC proxy selects NIC hosts in a fixed, cyclic order. The NIC proxy always selects the next host in the list.
- `randomPick`—NIC proxy selects NIC hosts randomly from the list.
- `priorityList`—NIC proxy selects NIC hosts according to their assigned priorities in the list. If the host with the highest priority in the list is not available, the NIC proxy tries the host with the next-highest priority, and so on.

Use round-robin or random pick to distribute resolution requests among

NIC hosts. Use priority list if you prefer to use a particular NIC host; for example, you may reduce operating cost by using a local NIC host.

Default—round-

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Advanced

shared acp configuration nic-proxy-configuration *name* nic-host-selection blacklisting

Syntax

```
shared acp configuration nic-proxy-configuration name nic-host-
selection blacklisting {
    try-next-system-on-error;
    number-of-retries-before-blacklisting number-of-retries-before-
blacklisting;
    blacklist-retry-interval blacklist-retry-interval;
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration name nic-host-
selection blacklisting]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure how to handle nonresponsive NIC hosts. When a NIC host does not respond, it is blacklisted which means that other NIC hosts are contacted until the blacklisted host becomes available again.

Options

try-next-system-on-error—(Optional) Specifies whether or not the NIC proxy should contact the next specified NIC host if a NIC host is determined to be unavailable. Configure this property only if you configure more than one group.

Default—true

Editing Level—Advanced

number-of-retries-before-blacklisting *number-of-retries-before-blacklisting*— Number of times the NIC proxy tries to communicate with a NIC host before the NIC proxy stops communicating with the NIC host for a period of time.

Value—Integer in the range 0–2147483647

Default—3

Editing Level—Advanced

`blacklist-retry-interval` *blacklist-retry-interval*—Interval at which the NIC proxy attempts to connect to an unavailable NIC host.

Value—Integer in the range 15–2147483647 s

Default—15

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration nic-proxy-configuration *name* resolution

Syntax

```
shared acp configuration nic-proxy-configuration name resolution {
    resolver-name resolver-name;
    key-type key-type;
    value-type value-type;
    expect-multiple-values;
    constraints constraints;
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration name resolution]
```

Description

Configure properties for a NIC proxy (NIC locator), the NIC component that requests information on behalf of an application.

Options

`resolver-name resolver-name`— NIC resolver that the NIC proxy uses. This resolver must be the same as one that is configured on the NIC host.

Value— Path to the NIC resolver.

Example—`/realms/ip/A1,/realms/dn/A1`.

Default— No value

Editing Level—Basic

`key-type key-type`— Type of data used that the key provides for the NIC resolution. You can provide a qualifier to a data type to distinguish between different instances of a data type in a resolution scenario, or to provide information about a data type to clarify the use of that data type in a resolution.

Value— One of the following types:

- `Ip` —Subscriber's IP address

- Vr—Virtual router
- Interface—Name of router's interface
- InterfaceId—Identifier of an interface on the router
- Dn—LDAP distinguished name for subscriber
- LoginName—Subscriber login ID
- AnyString—Other information

To qualify data types, enter a qualifier within parentheses.

Example—LoginName(username).

Default— No value

Editing Level—Basic

`value-type value-type`— Type of value to be returned in the resolution. The value type varies according to the application that uses the NIC proxy.

Value— One of the following types:

- SaeId—SAE server ID
- LoginName—Subscriber login ID
- AnyString—Other information

To qualify data types, enter a qualifier within parentheses.

Example—LoginName(username).

Default— No value

Editing Level—Basic

`expect-multiple-values`—(Optional) Specifies whether or not the key can have multiple corresponding values.

Editing Level—Basic

`constraints constraints`—(Optional) Data type that a resolver uses during the resolution process. A constraint represents a condition that must or may be satisfied before the next stage of the resolution process can proceed.

Configure a constraint only if the constraint will be provided by the application in the resolution request. Typically, you do not need to configure constraints.

Value— Data types of constraints specified for the NIC resolution.

Separate data types with commas.

Default— No value

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Normal

shared acp configuration nic-proxy-configuration *name* test-nic-bindings

Syntax

```
shared acp configuration nic-proxy-configuration name test-nic-bindings {
    use-test-bindings;
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration name test-nic-bindings]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure key-value mappings to be used to test a NIC resolution.

Options

`use-test-bindings`—(Optional) Test the NIC resolutions without having to configure or run a NIC host. The values returned are those configured in the key-values property.

Default—false

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration nic-proxy-configuration *name* test-nic-bindings key-values

Syntax

```
shared acp configuration nic-proxy-configuration name test-nic-bindings key-
values name {
    value;
}
```

Hierarchy Level

```
[edit shared acp configuration nic-proxy-configuration name test-nic-
bindings key-values]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure keys and associated values to use for testing. Define all of values to be returned for specified keys.

Options

name *name*—

Value—Text

value—

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Advanced

shared acp configuration redundancy

Syntax

```
shared acp configuration redundancy {
    enable-redundancy;
    local-ior local-ior;
    remote-ior remote-ior;
    ignore-user-tracking-out-of-sync;
    community-heartbeat community-heartbeat;
    community-acquire-timeout community-acquire-timeout;
    community-blackout-timeout community-blackout-timeout;
    redundant-naming-service redundant-naming-service;
}
```

Hierarchy Level

```
[edit shared acp configuration redundancy]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure redundancy and state synchronization for SRC-ACP.

Options

`enable-redundancy`—(Optional) Enables SRC-ACP redundancy.

Editing Level—Basic

`local-ior local-ior`— In a redundant SRC-ACP configuration, exports the object reference for this SRC-ACP (local interface) through a Common Object Services (COS) naming service.

Value— One of the following references:

- `corbaname::cosNameServer#KEY`—Exports object reference through COS naming services
 - `cosNameServer`—IP address or Domain Name System (DNS) name of COS naming server
 - `KEY`—Object reference of SRC-ACP

- `corbaname:rir#KEY`—Exports object reference through COS naming service; resolve-initial-references (rir) function finds DNS name of COS naming server

For example: `corbaname::coshost#acp.redundancy.primary`

Editing Level—Basic

`remote-ior remote-ior`—In a redundant SRC-ACP configuration, resolves the object reference for the other SRC-ACP (remote interface) through a Common Object Services (COS) naming service. For redundancy, the remote IOR value of one SRC-ACP must match the local IOR value of the other SRC-ACP.

Value— One of the following references:

- `corbaname::cosNameServer#KEY`—Exports object reference through COS naming services
 - `cosNameServer`—IP address or Domain Name System (DNS) name of COS naming server
 - `KEY`—Object reference of SRC-ACP
- `corbaname:rir#KEY`—Exports object reference through COS naming service; resolve-initial-references (rir) function finds DNS name of COS naming server

For example: `corbaname::coshost#acp.redundancy.backup`

Editing Level—Basic

`ignore-user-tracking-out-of-sync`—(Optional) Specifies whether user tracking events should be ignored when they raise an OutOfSync exception to the SAE when state synchronization is enabled. SRC-ACP raises an OutOfSync exception when SRC-ACP handles service tracking or authentication events without receiving a user start event first.

Default— false

Editing Level—Basic

`community-heartbeat community-heartbeat`—(Optional) Time interval for community members to check each other's availability when both redundancy and state synchronization are enabled.

Value—Integer in the range 0–2147483647 s

Default— 30

Editing Level—Basic

`community-acquire-timeout community-acquire-timeout`—(Optional) Time to wait before trying to reacquire the distributed lock when both redundancy and state synchronization are enabled.

Value—Integer in the range 0–2147483647 s

Default— 15

Editing Level—Basic

`community-blackout-timeout` *community-blackout-timeout*—(Optional)
Time to wait before regaining control when both redundancy and state synchronization are enabled.

Value—Integer in the range 0–2147483647 s

Default— 30

Editing Level—Basic

`redundant-naming-service` *redundant-naming-service*—(Optional) In a redundant SRC-ACP configuration, exports the object reference for the backup naming service through a local file or COS naming service. The primary SRC-ACP registers the IOR and redundancy IOR to both naming services, while the secondary SRC-ACP registers the redundancy IOR to both naming services.

Value— One of the following references:

- `file://path`—Exports object reference through a local file where *path* is the absolute path to local file
- `corbaname::cosNameServer#KEY`—Exports object reference through COS naming services
 - *cosNameServer*—IP address or Domain Name System (DNS) name of COS naming server
 - *KEY*—Object reference of SRC-ACP
- `corbaname:rir#KEY`—Exports object reference through COS naming service; resolve-initial-references (rir) function finds DNS name of COS naming server

Default— None

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared acp configuration scripts-and-classification

Syntax

```
shared acp configuration scripts-and-classification {
    script-factory-class script-factory-class;
    classification-factory-class classification-factory-class;
    classification-script classification-script;
    congestion-point-profile-script congestion-point-profile-script;
    extension-path extension-path;
}
```

Hierarchy Level

```
[edit shared acp configuration scripts-and-classification]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure SRC-ACP scripts and classification.

Options

`script-factory-class script-factory-class`— Script factory class name.

Value—Text

Default— net.juniper.smgmt.acp.classify.ScriptFactory

Editing Level—Expert

`classification-factory-class classification-factory-class`—
Congestion point classifier factory class name.

Value—Text

Default— net.juniper.smgmt.acp.classify.ClassifyCPFactory

Editing Level—Expert

`classification-script classification-script`— Class name for congestion
point classification.

Value—Text
Default— cpClassify
Editing Level—Expert

`congestion-point-profile-script` *congestion-point-profile-script*—
Class name for generating the congestion point DN by using the congestion point profile.

Value—Text
Default— cpProfile
Editing Level—Expert

`extension-path` *extension-path*— Extension class path for classes not located in
the `/opt/UMC/acp/lib` directory.

Value—Text
Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Advanced

shared acp congestion-point-classifier rule

Syntax

```
shared acp congestion-point-classifier rule name {
    target target;
    script script;
}
```

Hierarchy Level

```
[edit shared acp congestion-point-classifier rule]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure a congestion point classification script.

Options

name name— Name of a congestion point classification script.

Value—Text

target target—(Optional) Result of the classification script. The result is the DN of a congestion point in the directory or an LDAP query that uniquely identifies a congestion point entry in the directory.

Value—Text

Editing Level—Basic

script script—(Optional) Script target. A script that can contain definitions of custom functions that can be called during the matching process. The complete content of the script is interpreted when the classifier is initially loaded. Because you can insert code into a script target, you can use the classification script to perform various tasks.

Value— Script enclosed in quotation marks.

Default— No value

Editing Level—Basic

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

shared acp congestion-point-classifier rule *name* condition

Syntax

```
shared acp congestion-point-classifier rule name condition criteria ...
```

Hierarchy Level

```
[edit shared acp congestion-point-classifier rule name condition]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure classification criteria that is used to find a target.

Options

criteria criteria— Classification criteria. For information about configuring classification criteria, see *Classifying Congestion Points* in the *SRC-PE Network Guide*.

Value— Classification criteria are organized by putting one criterion per line. A criterion is joined with the previous criterion by:

- OR if the line does not contain a prefix or if it is prefixed with a | (pipe) character. A criterion joined by OR is examined only if the previous conditions have not produced a positive match. If any of the criteria joined by OR matches, the target is selected.
- AND if the line is prefixed with an & (ampersand) character. A criterion joined by AND is examined only if the previous condition matches.

You can use glob or regular expression matching to configure each target's criteria.

Required Privilege Level

No specific privilege required.

Required Editing Level

Basic

shared acp group

Syntax

```
shared acp group name ...
```

Hierarchy Level

```
[edit shared acp group]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure group of SRC-ACP configuration properties.

Options

`name name`— Name of an SRC-ACP configuration.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared admission-control device

Syntax

```
shared admission-control device name {
    description description;
}
```

Hierarchy Level

```
[edit shared admission-control device]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the locations of congestion points in the directory.

Options

`name name`— Network device name.

Value—Text

`description description`—(Optional) Network device description.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared admission-control device *name* interface

Syntax

```
shared admission-control device name interface name {
    description description;
    upstream-provisioned-rate upstream-provisioned-rate;
    downstream-provisioned-rate downstream-provisioned-rate;
    upstream-background-bandwidth [upstream-background-bandwidth...];
    downstream-background-bandwidth [downstream-background-bandwidth...];
    action-type (url | python | java-class | java-archive);
    action-class-name action-class-name;
    action-file-url action-file-url;
    action-parameters [action-parameters...];
    action-file-name action-file-name;
    detect-link-rate;
}
```

Hierarchy Level

```
[edit shared admission-control device name interface]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure the network interfaces that represent locations of congestion points in the directory.

Options

name *name*—Interface name.

Value—Text

description *description*—(Optional) Network interface description.

Value—Text

Editing Level—Basic

upstream-provisioned-rate *upstream-provisioned-rate*—(Optional)

Upstream provisioned rate.

Value—Integer in the range 0–9223372036854775807 bps

Editing Level—Basic

`downstream-provisioned-rate` *downstream-provisioned-rate*—(Optional)

Downstream provisioned rate.

Value—Integer in the range 0–9223372036854775807 bps

Editing Level—Basic

`upstream-background-bandwidth` [*upstream-background-bandwidth...*]—(Optional) Upstream background bandwidth.

Value—Integer in the range 0–9223372036854775807 bps

Editing Level—Basic

`downstream-background-bandwidth` [*downstream-background-bandwidth...*]—(Optional) Downstream background bandwidth.

Value—Integer in the range 0–9223372036854775807 bps

Editing Level—Basic

`action-type` (`url` | `python` | `java-class` | `java-archive`)—(Optional)
Type of action congestion point. Determines how the contents of the "action-file-url" attribute will be interpreted.

Value

- `url`— The value of attribute "action-file-url" is a URL that specifies where to find a Java archive (.jar file) containing the script service implementation.
- `python`— The value of attribute "action-file-url" is Python code.
- `java-class`— The value of attribute "action-file-url" is the binary contents of a compiled Java class file (.class file).
- `java-archive`— The value of attribute "action-file-url" is the binary contents of a Java archive file (.jar file).

Editing Level—Basic

`action-class-name` *action-class-name*—(Optional) Name of Java or Python class

implementing the action congestion point. The ACP instantiates the named class.

Value—Text

Editing Level—Basic

`action-file-url` *action-file-url*—(Optional) If the action type is "URL", this attribute contains the URL of a Java archive (.jar) file containing the action congestion point implementation. Otherwise, this attribute contains the action congestion point implementation itself (i.e. python code, the binary contents of a compiled .class file, or the binary contents of a .jar file).

Editing Level—Basic

`action-parameters` [*action-parameters...*]—(Optional) Parameters used by the action congestion point.

Value— Text string in the format of a list of < attribute > = < value > pairs

Editing Level—Basic

`action-file-name` *action-file-name*—(Optional) The file needs to exist locally. Its content will be read and loaded into the "action-file-url" attribute.

Value—Text

Editing Level—Basic

`detect-link-rate`—(Optional) To identify the possibility of getting the actual link rate information for a congestion point via L2C or other solutions developed later. By default , it is false for the sake of backward compatibility.

Default—false

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared congestion-points congestion-point-profile

Syntax

```
shared congestion-points congestion-point-profile name {
    expression [expression...];
}
```

Hierarchy Level

```
[edit shared congestion-points congestion-point-profile]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure congestion point profile.

Options

name *name*— Congestion point profile name.

Value—Text

expression [*expression...*]—(Optional) Congestion point expression.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared congestion-points profile

Syntax

```
shared congestion-points profile name {
    interface [interface...];
}
```

Hierarchy Level

```
[edit shared congestion-points profile]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure congestion point.

Options

name *name*— Congestion point name.

Value—Text

interface [*interface...*]—(Optional) Congestion point reference.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

slot *number* acp

Syntax

```
slot number acp {
    java-runtime-environment java-runtime-environment;
    java-heap-size java-heap-size;
    java-garbage-collection-options java-garbage-collection-options;
    base-dn base-dn;
    snmp-agent;
    shared shared;
}
```

Hierarchy Level

```
[edit slot number acp]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure local properties for SRC-ACP.

Options

`java-runtime-environment java-runtime-environment`— Path to the Java Runtime Environment (JRE). The SRC software requires a JRE that conforms to the Java 2 specification.

Value—Text

Default— `../jre/bin/java`

Editing Level—Expert

`java-heap-size java-heap-size`— Maximum amount of Java heap (memory) available to the JRE.

Value— Number of megabytes in the format *integer*m

Default— 64m

Editing Level—Advanced

`java-garbage-collection-options java-garbage-collection-options`—

Garbage collection functionality of the Java Virtual Machine.

Value—

Default— -Xbatch -XX: + UseConcMarkSweepGC -XX:

CMSInitiatingOccupancyFraction = 80 -XX:NewRatio = 5 -XX:

+ UseParNewGC -XX:SurvivorRatio = 1 -XX:

InitialTenuringThreshold = 8 -XX:MaxTenuringThreshold = 10 -XX:

TargetSurvivorRatio = 90 -XX: + UseCMSCompactAtFullCollection -XX:

CMSFullGCsBeforeCompaction = 0 -XX: + CMSClassUnloadingEnabled -

XX: + CMSParallelRemarkEnabled

Editing Level—Advanced

`base-dn` *base-dn*— DN of the root of the SDX data in the directory.

If you are storing non-SDX data in the directory, and that data changes frequently whereas the SDX data does not, you may need to adjust the default value to improve performance. For optimal performance, set the value to the DN of an entry superior to both the SDX data and the changing non-SDX data.

Value— DN

Editing Level—Advanced

`snmp-agent`—(Optional) Enables SRC-ACP to communicate with the SNMP agent.

Editing Level—Basic

`shared` *shared*— Shared configuration object that holds most of the SRC-ACP specific configuration.

Value— Name of the object in the format `" / < path > "`. If the `< path >` contains multiple levels, the levels are separated by a slash (`/`). The effective configuration is combined by all configuration objects in the path, with more specific configuration in the lower levels of the path.

Default— `/config`

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

slot *number* acp initial

Syntax

```
slot number acp initial {
    static-dn static-dn;
    dynamic-dn dynamic-dn;
}
```

Hierarchy Level

```
[edit slot number acp initial]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure initial properties for SRC components.

Options

`static-dn static-dn`—(Optional) Location of administrator-defined configuration data in the directory.

Value—Text

Default—ou = staticConfiguration,ou = Configuration,o = Management,
o = umc

Editing Level—Expert

`dynamic-dn dynamic-dn`—(Optional) Location of programmatically-defined configuration data in the directory.

Value—Text

Default—ou = dynamicConfiguration,ou = Configuration,
o = Management,o = umc

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

slot *number* acp initial directory-connection

Syntax

```
slot number acp initial directory-connection {
    url url;
    backup-urls [backup-urls...];
    principal principal;
    credentials credentials;
    protocol (ldaps);
    timeout timeout;
    check-interval check-interval;
    blacklist;
    snmp-agent;
}
```

Hierarchy Level

```
[edit slot number acp initial directory-connection]
```

Description

Configure properties for the directory connection.

Options

`url url`—(Optional) URL that identifies the location of the primary directory server.

Value— URL

Default—`ldap://127.0.0.1:389`

Editing Level—Basic

`backup-urls [backup-urls...]`—(Optional) URLs that identify the locations of backup directory servers. Backup servers are used if the primary directory server is not accessible.

Value— List of URLs

Editing Level—Basic

`principal principal`— DN that the SRC component uses for authentication to access the directory.

Value— DN.

When you specify the DN, you can use `< base >` to indicate the base DN.

Editing Level—Basic

`credentials credentials`—Password with which the SRC component accesses the directory.

Value— Password

Editing Level—Basic

`protocol (ldaps)`—(Optional) Security protocol used to connect to the directory. If you do not configure a security protocol, plain socket is used.

Value

- `ldaps`— LDAPS which uses SSL.

Editing Level—Expert

`timeout timeout`—(Optional) Maximum amount of time during which the directory must respond to a connection request.

Value—Integer in the range 1–2147483647 s

Default— 10

Editing Level—Expert

`check-interval check-interval`—(Optional) Time interval at which the directory monitoring system verifies its connection to the directory. If the directory connection fails after this interval, the directory monitoring system initiates a connection to another directory.

Value—Integer in the range 15–2147483647 s

Default—60

Editing Level—Expert

`blacklist`—(Optional) Specifies whether the directory monitoring system prevents connection to a directory if the directory fails to respond during 10 polling intervals.

Default—false

Editing Level—Basic

`snmp-agent`—(Optional) Specifies whether the SDX SNMP agent exports MIBs for this directory connection.

Default—false

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

slot *number* acp initial directory-eventing

Syntax

```
slot number acp initial directory-eventing {
    eventing;
    signature-dn signature-dn;
    polling-interval polling-interval;
    event-base-dn event-base-dn;
    dispatcher-pool-size dispatcher-pool-size;
}
```

Hierarchy Level

```
[edit slot number acp initial directory-eventing]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Change configuration for directory eventing properties. In most cases, you can use the default configuration for these properties.

Options

`eventing`—(Optional) Enable an SRC component to poll the directory for changes.

Default—true

Editing Level—Normal

`signature-dn signature-dn`—(Optional) DN of the directory entry that specifies the `usedDirectory` attribute for the SRC CLI. The `usedDirectory` attribute identifies the vendor of the directory server.

Value— DN

Default—o = umc

Editing Level—Expert

`polling-interval polling-interval`—(Optional) Interval at which an SRC component polls the directory to check for directory changes.

Value—Integer in the range 15–2147483647 s

Default—30

Editing Level—Normal

`event-base-dn` *event-base-dn*—(Optional)

DN of an entry superior to the data associated with an SRC component in the directory.

If you are storing non-SRC data in the directory, and that data changes frequently whereas the SRC data does not, you may need to adjust the default value to improve performance. For optimal performance, set the value to the DN of an entry superior to both the SRC data and the changing non-SRC data.

Value— DN

Default—o = UMC

Editing Level—Expert

`dispatcher-pool-size` *dispatcher-pool-size*—(Optional) Number of directory change notifications that can be sent simultaneously to the SRC component.

Value—Integer in the range 0–2147483647

Default—1

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

request acp reorganize-backup-database

Syntax

```
request acp reorganize-backup-database <slot slot>
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Reorganize the files that contain SRC-ACP data about subscribers, services, and congestion points. This action reduces the sizes of these files.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

Required Privilege Level

maintenance

show acp backbone congestion-point congestion-point-expression

Syntax

```
show acp backbone congestion-point congestion-point-expression <slot slot>
<virtual-router-name virtual-router-name> <service-name service-name>
<interface-name interface-name> <interface-description interface-description>
<interface-alias interface-alias> <nas-port-id nas-port-id> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display congestion point by service congestion point expression.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`virtual-router-name virtual-router-name`—(Optional) Name of virtual router from which to list congestion points.

Value— Virtual router name

Default— No value

`service-name service-name`—(Optional) Name of service used by backbone service to generate congestion points.

Value— Service name

Default— No value

`interface-name interface-name`—(Optional) Name of interface related to congestion points.

Value— Interface name

Default— No value

`interface-description` *interface-description*—(Optional) Description of interface used by backbone service to generate congestion points.

Value— Interface description

Default— No value

`interface-alias` *interface-alias*—(Optional) Interface alias used by backbone service to generate congestion points.

Value— Interface alias

Default— No value

`nas-port-id` *nas-port-id*—(Optional) Interface NAS port ID used by backbone service to generate congestion points.

Value— NAS port ID

Default— No value

(Optional) Output style.

Value

- `brief`— Display congestion point attributes.

Default—`detail`

Required Privilege Level

view

show acp backbone congestion-point dn

Syntax

```
show acp backbone congestion-point dn <slot slot> <congestion-point-dn
congestion-point-dn> <virtual-router-name virtual-router-name> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display congestion point by DN.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`congestion-point-dn congestion-point-dn`—(Optional) DN of congestion point for which you want to list all matching congestion points.

Value— All or part of the congestion point DN.

Default— No value

`virtual-router-name virtual-router-name`—(Optional) Name of virtual router from which to list congestion points.

Value— Virtual router name

Default— No value

(Optional) Output style.

Value

- `brief`— Display congestion point DN.

Default—detail

Required Privilege Level

view

show acp backbone service

Syntax

```
show acp backbone service <slot slot> <virtual-router-name virtual-router-name> <service-name service-name> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display information about services that SRC-ACP manages in the backbone network.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`virtual-router-name virtual-router-name`—(Optional) Name of virtual router from which to list backbone services.

Value— Virtual router name

Default— No value

`service-name service-name`—(Optional) Name of service used by backbone service to generate congestion points.

Value— Service name

Default— No value

(Optional) Output style.

Value

- `brief`— Display backbone service attributes.

Default—detail

Required Privilege Level

view

show acp edge congestion-point dn

Syntax

```
show acp edge congestion-point dn <slot slot> <congestion-point-dn congestion-
point-dn> <instance-id instance-id> <virtual-router-name virtual-router-name>
< (brief) > <maximum-results maximum-results>
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display congestion point by DN.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`congestion-point-dn congestion-point-dn`—(Optional) DN of congestion point for which you want to list all matching congestion points.

Value— All or part of the congestion point DN.

Default— No value

`instance-id instance-id`—(Optional) Name of an instance generated for a congestion point that is automatically created.

Value— All or part of the congestion point instance ID.

Default— No value

`virtual-router-name virtual-router-name`—(Optional) Name of virtual router from which to list congestion points.

Value— Virtual router name

Default— No value

(Optional) Output style.

Value

- `brief`— Display congestion point DN.

Default—`detail`

`maximum-results` *maximum-results*—(Optional) Number of results to be displayed.

Value—Integer in the range 1-2147483647

Default— 25

Required Privilege Level

view

show acp edge congestion-point subscriber-session-id

Syntax

```
show acp edge congestion-point subscriber-session-id <slot slot> <session-id
session-id> <virtual-router-name virtual-router-name> < (brief) > <maximum-
results maximum-results>
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display congestion point by subscriber session ID.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`session-id session-id`—(Optional) Subscriber session ID for which you want to list all matching congestion points.

Value— All or part of the subscriber session ID.

Default— No value

`virtual-router-name virtual-router-name`—(Optional) Name of virtual router from which to list congestion points.

Value— Virtual router name

Default— No value

(Optional) Output style.

Value

- `brief`— Display congestion point attributes.

Default—detail

`maximum-results` *maximum-results*—(Optional) Number of results to be displayed.

Value—Integer in the range 1-2147483647

Default— 25

Required Privilege Level

view

show acp edge subscriber

Syntax

```
show acp edge subscriber <slot slot> <virtual-router-name virtual-router-name>
<session-id session-id> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display subscriber sessions in the edge network.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`virtual-router-name virtual-router-name`—(Optional) Name of virtual router from which to list subscriber sessions.

Value— Virtual router name

Default— No value

`session-id session-id`—(Optional) Subscriber session ID for which you want to list all matching subscriber sessions.

Value— All or part of the subscriber session ID.

Default— No value

(Optional) Output style.

Value

- `brief`— Display subscriber session attributes.

Default—detail

Required Privilege Level

view

show acp remote-update congestion-point dn

Syntax

```
show acp remote-update congestion-point dn <slot slot> <congestion-point-dn
congestion-point-dn> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display congestion point by DN.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`congestion-point-dn congestion-point-dn`—(Optional) DN of congestion point for which you want to list all matching congestion points.

Value— All or part of the congestion point DN.

Default— No value

(Optional) Output style.

Value

- `brief`— Display congestion point DN.

Default—detail

Required Privilege Level

view

show acp remote-update congestion-point name

Syntax

```
show acp remote-update congestion-point name <slot slot> <device-name device-name> <interface-name interface-name> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display congestion point by interface name.

Options

slot slot—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

device-name device-name—(Optional) Device name of the congestion point.

Value— Device name

Default— No value

interface-name interface-name—(Optional) Interface name of the congestion point.

Value— Interface name

Default— No value

(Optional) Output style.

Value

- **brief**— Display congestion point DN.

Default—detail

Required Privilege Level

view

show acp remote-update subscriber

Syntax

```
show acp remote-update subscriber <slot slot> <device-name device-name> <nas-  
port-id nas-port-id> <nas-ip nas-ip> <subscriber-ip subscriber-ip> <phone  
phone> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display information about subscribers added through an external application.

Options

`slot slot`—(Optional) Number of the slot for which you want to configure values.

Value— Currently, the chassis has only one slot. The valid value is 0.

Default—0

`device-name device-name`—(Optional) Device name connected to subscriber.

Value— Device name

Default— No value

`nas-port-id nas-port-id`—(Optional) NAS port ID of interface connected to subscriber.

Value— NAS port ID

Default— No value

`nas-ip nas-ip`—(Optional) NAS IP address of device connected to subscriber.

Value— IP address

Default— No value

`subscriber-ip subscriber-ip`—(Optional) Subscriber IP address.

Value— IP address

Default— No value

phone *phone*—(Optional) Subscriber phone number.

Value— Phone number

Default— No value

(Optional) Output style.

Value

- *brief*— Display congestion point DN.

Default—detail

Required Privilege Level

view

show acp statistics device

Syntax

```
show acp statistics device <filter filter> < (brief) >
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display SNMP information for each device.

Options

filter filter—(Optional) Name of the device.

Value— All or part of the device name.

Default— No value

(Optional) Output style.

Value

- *brief*— Display only device names.

Default—detail

Required Privilege Level

view

show acp statistics directory

Syntax

```
show acp statistics directory
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display directory SNMP information.

Required Privilege Level

view

show acp statistics general

Syntax

```
show acp statistics general
```

Release Information

Command introduced in SRC Release 1.0.0

Description

Display SRC-ACP SNMP information.

Required Privilege Level

view

Dynamic Service Activator

The following table summarizes the SRC command-line interface (SRC CLI) for providing Dynamic Service Activator. Configuration statements and operational commands are listed in alphabetical order.

Dynamic Service Activator
Configuration Statements
shared_dsa_configuration
shared_dsa_configuration_client
shared_dsa_configuration_client_name_permissions
shared_dsa_configuration_client_name_permissions_method
shared_dsa_configuration_client_name_permissions_method_name_constraints
shared_dsa_configuration_client_name_permissions_script
shared_dsa_configuration_client_name_permissions_script_name_constraints
shared_dsa_configuration_logger
shared_dsa_configuration_logger_name_file
shared_dsa_configuration_logger_name_syslog
shared_dsa_configuration_method_commit-resources_constraints
shared_dsa_configuration_method_invoke-gateway-extension_constraints
shared_dsa_configuration_method_invoke-script_constraints
shared_dsa_configuration_method_query-available-services_constraints
shared_dsa_configuration_method_query-contexts_constraints
shared_dsa_configuration_method_release-resources_constraints
shared_dsa_configuration_method_subscriber-activate-service_constraints
shared_dsa_configuration_method_subscriber-deactivate-service_constraints
shared_dsa_configuration_method_subscriber-login_constraints
shared_dsa_configuration_method_subscriber-logout_constraints

shared_dsa_configuration_method_subscriber-modify-service_constraints
shared_dsa_configuration_method_subscriber-read-subscription_constraints
shared_dsa_configuration_nic-proxy-configuration
shared_dsa_configuration_nic-proxy-configuration_name_cache
shared_dsa_configuration_nic-proxy-configuration_name_nic-host-selection
shared_dsa_configuration_nic-proxy-configuration_name_nic-host-selection_blacklisting
shared_dsa_configuration_nic-proxy-configuration_name_resolution
shared_dsa_configuration_nic-proxy-configuration_name_test-nic-bindings
shared_dsa_configuration_nic-proxy-configuration_name_test-nic-bindings_key-values
shared_dsa_configuration_script
shared_dsa_configuration_script_name_constraints
shared_dsa_configuration_subscriber-types
shared_dsa_group
slot_number_dsa
slot_number_dsa_deploy
slot_number_dsa_initial
slot_number_dsa_initial_directory-connection
slot_number_dsa_initial_directory-eventing
Operational Commands
monitor_dsa_nic-proxy
monitor_dsa_soap-operation
show_dsa_statistics_general
show_dsa_statistics_nic-proxy
show_dsa_statistics_soap-operation
test_dsa_dsa-service_environment_clear
test_dsa_dsa-service_environment_clear_client-id

<u>test_dsa_dsa-service_environment_clear_client-password</u>
<u>test_dsa_dsa-service_environment_clear_dn</u>
<u>test_dsa_dsa-service_environment_clear_interface-index</u>
<u>test_dsa_dsa-service_environment_clear_interface-name</u>
<u>test_dsa_dsa-service_environment_clear_login-name</u>
<u>test_dsa_dsa-service_environment_clear_primary-user-name</u>
<u>test_dsa_dsa-service_environment_clear_subscriber-address</u>
<u>test_dsa_dsa-service_environment_clear_subscriber-constraints</u>
<u>test_dsa_dsa-service_environment_clear_subscriber-id</u>
<u>test_dsa_dsa-service_environment_clear_subscriber-password</u>
<u>test_dsa_dsa-service_environment_clear_subscriber-type</u>
<u>test_dsa_dsa-service_environment_clear_virtual-router</u>
<u>test_dsa_dsa-service_environment_set</u>
<u>test_dsa_dsa-service_environment_show</u>
<u>test_dsa_dsa-service_environment_show_client-id</u>
<u>test_dsa_dsa-service_environment_show_client-password</u>
<u>test_dsa_dsa-service_environment_show_dn</u>
<u>test_dsa_dsa-service_environment_show_interface-index</u>
<u>test_dsa_dsa-service_environment_show_interface-name</u>
<u>test_dsa_dsa-service_environment_show_login-name</u>
<u>test_dsa_dsa-service_environment_show_primary-user-name</u>
<u>test_dsa_dsa-service_environment_show_subscriber-address</u>
<u>test_dsa_dsa-service_environment_show_subscriber-constraints</u>
<u>test_dsa_dsa-service_environment_show_subscriber-id</u>
<u>test_dsa_dsa-service_environment_show_subscriber-password</u>
<u>test_dsa_dsa-service_environment_show_subscriber-type</u>

<u>test_dsa_dsa-service_environment_show_virtual-router</u>
<u>test_dsa_dsa-service_invoke-gateway-extension</u>
<u>test_dsa_dsa-service_invoke-script</u>
<u>test_dsa_dsa-service_subscriber-activate-service</u>
<u>test_dsa_dsa-service_subscriber-deactivate-service</u>
<u>test_dsa_dsa-service_subscriber-login</u>
<u>test_dsa_dsa-service_subscriber-logout</u>
<u>test_dsa_dsa-service_subscriber-modify-service</u>
<u>test_dsa_dsa-service_subscriber-read-subscription</u>
<u>test_dsa_pcmm-service_commit-resources</u>
<u>test_dsa_pcmm-service_environment_clear</u>
<u>test_dsa_pcmm-service_environment_clear_client-id</u>
<u>test_dsa_pcmm-service_environment_clear_client-password</u>
<u>test_dsa_pcmm-service_environment_clear_subscriber-address</u>
<u>test_dsa_pcmm-service_environment_clear_subscriber-uri</u>
<u>test_dsa_pcmm-service_environment_set</u>
<u>test_dsa_pcmm-service_environment_show</u>
<u>test_dsa_pcmm-service_environment_show_client-id</u>
<u>test_dsa_pcmm-service_environment_show_client-password</u>
<u>test_dsa_pcmm-service_environment_show_subscriber-address</u>
<u>test_dsa_pcmm-service_environment_show_subscriber-uri</u>
<u>test_dsa_pcmm-service_query-available-services</u>
<u>test_dsa_pcmm-service_query-contexts</u>
<u>test_dsa_pcmm-service_release-resources</u>

shared dsa configuration

Syntax

```
shared dsa configuration {  
    disable-access-control-mechanism;  
}
```

Hierarchy Level

```
[edit shared dsa configuration]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the general properties that determine the behavior of the application.

Options

`disable-access-control-mechanism`—(Optional) Specify whether the access control mechanism is disabled.

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration client

Syntax

```
shared dsa configuration client name ...
```

Hierarchy Level

```
[edit shared dsa configuration client]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the client.

Options

name *name*— Name of Dynamic Service Activator client. You must use a name that is configured on the Web application server for the user account.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration client *name* permissions

Syntax

```
shared dsa configuration client name permissions {
    pcmm-service [pcmm-service...];
}
```

Hierarchy Level

```
[edit shared dsa configuration client name permissions]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the services available to the client.

Options

`pcmm-service [pcmm-service...]`—(Optional) PCMM services available to the client.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration client *name* permissions method

Syntax

```
shared dsa configuration client name permissions method name ...
```

Hierarchy Level

```
[edit shared dsa configuration client name permissions method]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure client access to methods.

Options

`name name`— Name of the method.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration client *name* permissions method *name* constraints

Syntax

```
shared dsa configuration client name permissions method name constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration client name permissions method name constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the access constraints for this gateway client.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1–2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration client *name* permissions script

Syntax

```
shared dsa configuration client name permissions script name ...
```

Hierarchy Level

```
[edit shared dsa configuration client name permissions script]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure client access to scripts.

Options

`name name`— Name of the script.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration client *name* permissions script *name* constraints

Syntax

```
shared dsa configuration client name permissions script name constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration client name permissions script name constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the access constraints for this gateway client.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration logger

Syntax

```
shared dsa configuration logger name ...
```

Hierarchy Level

```
[edit shared dsa configuration logger]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Create a logging configuration for Dynamic Service Activator.

Options

`name name`— Name of the logging configuration.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration logger *name* file

Syntax

```
shared dsa configuration logger name file {
    filter filter;
    filename filename;
    rollover-filename rollover-filename;
    maximum-file-size maximum-file-size;
}
```

Hierarchy Level

```
[edit shared dsa configuration logger name file]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure logging of messages to a file.

Options

`filter filter`—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default— The default value is different for each type of component.

Editing Level—Basic

`filename filename`— Absolute path of the filename that contains the current logs.

Note: Make sure that the user under which the J2EE application server or Web application server runs has write access to this folder. If this user does not have write access to the default folder, configure the component or application to write logs in folders to which the user has write access.

Value— Filename

Default— No value

Editing Level—Basic

`rollover-filename rollover-filename`—(Optional) Absolute path of the filename that contains the log history. When the log file reaches the maximum size, the software closes the log file and renames it with the name you specify for the rollover file. If a previous rollover file exists, the software overwrites it. The software then reopens the log file and continues to save event messages in it.

Value— Path of filename

Example—`/opt/UMC/sae/var/log/sae.alt`

Default— The default value is different for each type of component.

Editing Level—Normal

`maximum-file-size maximum-file-size`—(Optional) Maximum size of the log file and the rollover file.

Do not set the maximum file size to a value greater than the available disk space.

Value—Integer in the range 0–2147483647 kbytes

Default— 1000000

Editing Level—Normal

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration logger *name* syslog

Syntax

```
shared dsa configuration logger name syslog {
    filter filter;
    host host;
    facility facility;
    format format;
}
```

Hierarchy Level

```
[edit shared dsa configuration logger name syslog]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure logging of messages to system logging.

Options

`filter filter`—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default—/error-

Editing Level—Basic

`host host`— IP address or name of a host that collects event messages by means of a standard system logging daemon.

Value— IP address or hostname

Default—loghost

Editing Level—Basic

`facility facility`—(Optional) Type of system log in accordance with the system logging protocol.

Value—Integer in the range 0–23

Default— 3

Editing Level—Advanced

`format` *format*—(Optional) MessageFormat string that specifies how the information in an event message is printed. (The strings {#} are replaced with the log information [...]).

Value— MessageFormat string as specified in <http://java.sun.com/j2se/1.4.2/docs/api/java/text/MessageFormat.html>.

The fields available for events are:

- 0—Time and date of the event
- 1—Name of the thread generating the event
- 2—Text message of the event
- 3—Category of the event
- 4—Priority of the event

Default— None

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method commit-resources constraints

Syntax

```
shared dsa configuration method commit-resources constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method commit-resources constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method invoke-gateway-extension constraints

Syntax

```
shared dsa configuration method invoke-gateway-extension constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method invoke-gateway-extension constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method invoke-script constraints

Syntax

```
shared dsa configuration method invoke-script constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method invoke-script constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method query-available-services constraints

Syntax

```
shared dsa configuration method query-available-services constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method query-available-services constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method query-contexts constraints

Syntax

```
shared dsa configuration method query-contexts constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method query-contexts constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method release-resources constraints

Syntax

```
shared dsa configuration method release-resources constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method release-resources constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method subscriber-activate-service constraints

Syntax

```
shared dsa configuration method subscriber-activate-
service constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method subscriber-activate-service constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1–2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method subscriber-deactivate-service constraints

Syntax

```
shared dsa configuration method subscriber-deactivate-
service constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method subscriber-deactivate-
service constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1–2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method subscriber-login constraints

Syntax

```
shared dsa configuration method subscriber-login constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method subscriber-login constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method subscriber-logout constraints

Syntax

```
shared dsa configuration method subscriber-logout constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method subscriber-logout constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method subscriber-modify-service constraints

Syntax

```
shared dsa configuration method subscriber-modify-service constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method subscriber-modify-service constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration method subscriber-read-subscription constraints

Syntax

```
shared dsa configuration method subscriber-read-
subscription constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration method subscriber-read-subscription constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the method for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1-2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration nic-proxy-configuration

Syntax

```
shared dsa configuration nic-proxy-configuration name {  
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the NIC proxy.

Options

`name name`— Name of the NIC proxy configuration.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration nic-proxy-configuration *name* cache

Syntax

```
shared dsa configuration nic-proxy-configuration name cache {
    cache-size cache-size;
    cache-cleanup-interval cache-cleanup-interval;
    cache-entry-age cache-entry-age;
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration name cache]
```

Description

Configure the NIC Proxy cache properties. You can modify cache properties for the NIC proxy to optimize the resolution performance for your network configuration and system resources. Typically, you can use the default settings for the cache properties.

Options

`cache-size cache-size`—(Optional) Maximum size of the cache in which the NIC proxy retains data. If you decrease the cache size or disable the cache while the NIC proxy is running, the NIC proxy removes entries in order of descending age until the cache size meets the new limit.

Value— Integer in the range 0–2147483647

Default— 10000

Editing Level—Advanced

`cache-cleanup-interval cache-cleanup-interval`— Time interval at which the NIC proxy removes expired entries from its cache.

Value— Number of seconds in the range 5–2147483

Default— 15

Editing Level—Advanced

`cache-entry-age cache-entry-age`—(Optional) Maximum time that the NIC proxy can cache an entry. The NIC proxy compares this property with the life expectancy of each entry and uses the lower value to determine when to remove the entry.

Value— Number of seconds in the range 0–4294967295

- 0 or unspecified—Life expectancy of the data, which determines expiration of data
- Other values—Actual time that the NIC proxy caches entries

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Advanced

shared dsa configuration nic-proxy-configuration *name* nic-host-selection

Syntax

```
shared dsa configuration nic-proxy-configuration name nic-host-selection {
    groups [groups...];
    selection-criteria (roundRobin | randomPick | priorityList);
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration name nic-host-selection]
```

Description

Configure the mechanism that a NIC proxy uses to select NIC system if multiple systems are available. You use NIC host selection when you use NIC replication.

Options

groups [*groups...*]—(Optional) List of groups of NIC hosts that the NIC proxy can contact for resolution requests.

Value— Names of groups.

Default— No value

Editing Level—Advanced

selection-criteria (roundRobin | randomPick | priorityList)—
Selection criteria that the NIC proxy uses to determine which NIC host to contact. Configure selection criteria if you configure more than one group.

Value— One of the following criteria:

- roundRobin—NIC proxy selects NIC hosts in a fixed, cyclic order. The NIC proxy always selects the next host in the list.
- randomPick—NIC proxy selects NIC hosts randomly from the list.
- priorityList—NIC proxy selects NIC hosts according to their assigned priorities in the list. If the host with the highest priority in the list is not available, the NIC proxy tries the host with the next-highest priority, and so on.

Use round-robin or random pick to distribute resolution requests among

NIC hosts. Use priority list if you prefer to use a particular NIC host; for example, you may reduce operating cost by using a local NIC host.

Default—round-

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Advanced

shared dsa configuration nic-proxy-configuration *name* nic-host-selection blacklisting

Syntax

```
shared dsa configuration nic-proxy-configuration name nic-host-
selection blacklisting {
    try-next-system-on-error;
    number-of-retries-before-blacklisting number-of-retries-before-
blacklisting;
    blacklist-retry-interval blacklist-retry-interval;
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration name nic-host-
selection blacklisting]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure how to handle nonresponsive NIC hosts. When a NIC host does not respond, it is blacklisted which means that other NIC hosts are contacted until the blacklisted host becomes available again.

Options

try-next-system-on-error—(Optional) Specifies whether or not the NIC proxy should contact the next specified NIC host if a NIC host is determined to be unavailable. Configure this property only if you configure more than one group.

Default—true

Editing Level—Advanced

number-of-retries-before-blacklisting *number-of-retries-before-blacklisting*— Number of times the NIC proxy tries to communicate with a NIC host before the NIC proxy stops communicating with the NIC host for a period of time.

Value—Integer in the range 0–2147483647

Default—3

Editing Level—Advanced

`blacklist-retry-interval` *blacklist-retry-interval*—Interval at which the NIC proxy attempts to connect to an unavailable NIC host.

Value—Integer in the range 15–2147483647 s

Default—15

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration nic-proxy-configuration *name* resolution

Syntax

```
shared dsa configuration nic-proxy-configuration name resolution {
    resolver-name resolver-name;
    key-type key-type;
    value-type value-type;
    expect-multiple-values;
    constraints constraints;
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration name resolution]
```

Description

Configure properties for a NIC proxy (NIC locator), the NIC component that requests information on behalf of an application.

Options

`resolver-name resolver-name`— NIC resolver that the NIC proxy uses. This resolver must be the same as one that is configured on the NIC host.

Value— Path to the NIC resolver.

Example—`/realms/ip/A1,/realms/dn/A1`.

Default— No value

Editing Level—Basic

`key-type key-type`— Type of data used that the key provides for the NIC resolution. You can provide a qualifier to a data type to distinguish between different instances of a data type in a resolution scenario, or to provide information about a data type to clarify the use of that data type in a resolution.

Value— One of the following types:

- `Ip` —Subscriber's IP address

- Vr—Virtual router
- Interface—Name of router's interface
- InterfaceId—Identifier of an interface on the router
- Dn—LDAP distinguished name for subscriber
- LoginName—Subscriber login ID
- AnyString—Other information

To qualify data types, enter a qualifier within parentheses.

Example—LoginName(username).

Default— No value

Editing Level—Basic

value-type value-type— Type of value to be returned in the resolution. The value type varies according to the application that uses the NIC proxy.

Value— One of the following types:

- SaeId—SAE server ID
- LoginName—Subscriber login ID
- AnyString—Other information

To qualify data types, enter a qualifier within parentheses.

Example—LoginName(username).

Default— No value

Editing Level—Basic

expect-multiple-values—(Optional) Specifies whether or not the key can have multiple corresponding values.

Editing Level—Basic

constraints constraints—(Optional) Data type that a resolver uses during the resolution process. A constraint represents a condition that must or may be satisfied before the next stage of the resolution process can proceed.

Configure a constraint only if the constraint will be provided by the application in the resolution request. Typically, you do not need to configure constraints.

Value— Data types of constraints specified for the NIC resolution.

Separate data types with commas.

Default— No value

Editing Level—Advanced

Required Privilege Level

system

Required Editing Level

Normal

shared dsa configuration nic-proxy-configuration *name* test-nic-bindings

Syntax

```
shared dsa configuration nic-proxy-configuration name test-nic-bindings {
    use-test-bindings;
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration name test-nic-bindings]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure key-value mappings to be used to test a NIC resolution.

Options

`use-test-bindings`—(Optional) Test the NIC resolutions without having to configure or run a NIC host. The values returned are those configured in the key-values property.

Default—false

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration nic-proxy-configuration *name* test-nic-bindings key-values

Syntax

```
shared dsa configuration nic-proxy-configuration name test-nic-bindings key-
values name {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration nic-proxy-configuration name test-nic-
bindings key-values]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Configure keys and associated values to use for testing. Define all of values to be returned for specified keys.

Options

name *name*—

Value—Text

value—

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Advanced

shared dsa configuration script

Syntax

```
shared dsa configuration script name {
    sae-locator-index sae-locator-index;
}
```

Hierarchy Level

```
[edit shared dsa configuration script]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure a script for Dynamic Service Activator.

Options

name *name*— Name of Dynamic Service Activator script.

Value—Text

sae-locator-index *sae-locator-index*— The zero-based index of the script argument to be used to locate the SAE server on which to invoke the script.

Value—Integer in the range -2147483648–2147483647

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration script *name* constraints

Syntax

```
shared dsa configuration script name constraints argument-index {
    value;
}
```

Hierarchy Level

```
[edit shared dsa configuration script name constraints]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure access constraints for the script for all clients.

Options

argument-index *argument-index*— Zero-based index of the argument.

Value—Integer in the range 1–2147483647

value— Regular expression that the argument must match.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa configuration subscriber-types

Syntax

```
shared dsa configuration subscriber-types name {
    subscriber-id-type (address | dn | login-name | interface-name |
interface-index | address-interface-name | primary-user-name);
    nic-proxy nic-proxy;
}
```

Hierarchy Level

```
[edit shared dsa configuration subscriber-types]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the subscriber types.

Options

name *name*— Name of the subscriber type used to construct the subscriber URI.

Value—Text

subscriber-id-type (address | dn | login-name | interface-name | interface-index | address-interface-name | primary-user-name)— The subscriber ID type used to pass correct argument to the subscriber URI.

Value— One of the following types:

- address—Subscriber's IP address
- dn—Distinguished name of subscriber profile
- login-name—Subscriber's login name
- interface-name—Name of the interface and name of the virtual router to which the subscriber connects
- interface-index—SNMP index of the interface and name of the virtual router to which the subscriber connects
- address-interface-name—Subscriber's IP address, name of the managed interface, and name of the virtual router to which the subscriber connects

- `primary-user-name`—Primary username

Editing Level—Basic

`nic-proxy` *nic-proxy*— The configuration that contains the NIC proxy configuration properties for the subscriber type.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared dsa group

Syntax

```
shared dsa group name ...
```

Hierarchy Level

```
[edit shared dsa group]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure group of Dynamic Service Activator configuration properties.

Options

`name name`— Name of an SRC-DSA configuration.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

slot *number* dsa

Syntax

```
slot number dsa {
    shared shared;
}
```

Hierarchy Level

```
[edit slot number dsa]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure local properties for Dynamic Service Activator.

Options

`shared shared`— The configuration namespace that contains the Dynamic Service Activator's configuration data. You cannot specify root (*/*).

Value—Text

Default—/sample

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

slot *number* dsa deploy

Syntax

```
slot number dsa deploy {
    virtual-host virtual-host;
}
```

Hierarchy Level

```
[edit slot number dsa deploy]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the virtual host on which to deploy the application.

Options

`virtual-host virtual-host`—(Optional) The host to which the application is deployed.

Value—Text

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

slot *number* dsa initial

Syntax

```
slot number dsa initial {
    base-dn base-dn;
    static-dn static-dn;
    dynamic-dn dynamic-dn;
}
```

Hierarchy Level

```
[edit slot number dsa initial]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure initial properties for SRC components.

Options

base-dn *base-dn*— DN of the root of the SDX data in the directory.

If you are storing non-SDX data in the directory, and that data changes frequently whereas the SDX data does not, you may need to adjust the default value to improve performance. For optimal performance, set the value to the DN of an entry superior to both the SDX data and the changing non-SDX data.

Value— DN

Default—o = UMC

Editing Level—Advanced

static-dn *static-dn*—(Optional) Location of administrator-defined configuration data in the directory.

Value—Text

Default—l = DynamicServiceActivation,l = WebApplication,
ou = staticConfiguration,ou = Configuration,o = Management, < base >

Editing Level—Expert

`dynamic-dn` *dynamic-dn*—(Optional) Location of programmatically-defined configuration data in the directory.

Value—Text

Default—ou = dynamicConfiguration, ou = Configuration,
o = Management, < base >

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

slot *number* dsa initial directory-connection

Syntax

```
slot number dsa initial directory-connection {
    url url;
    backup-urls [backup-urls...];
    principal principal;
    credentials credentials;
    protocol (ldaps);
    timeout timeout;
    check-interval check-interval;
    blacklist;
    snmp-agent;
}
```

Hierarchy Level

```
[edit slot number dsa initial directory-connection]
```

Description

Configure properties for the directory connection.

Options

`url url`—(Optional) URL that identifies the location of the primary directory server.

Value— URL

Default—`ldap://127.0.0.1:389`

Editing Level—Basic

`backup-urls [backup-urls...]`—(Optional) URLs that identify the locations of backup directory servers. Backup servers are used if the primary directory server is not accessible.

Value— List of URLs

Editing Level—Basic

`principal principal`— DN that the SRC component uses for authentication to access the directory.

Value— DN.

When you specify the DN, you can use `< base >` to indicate the base DN.

Editing Level—Basic

`credentials credentials`—Password with which the SRC component accesses the directory.

Value— Password

Editing Level—Basic

`protocol (ldaps)`—(Optional) Security protocol used to connect to the directory. If you do not configure a security protocol, plain socket is used.

Value

- `ldaps`— LDAPS which uses SSL.

Editing Level—Expert

`timeout timeout`—(Optional) Maximum amount of time during which the directory must respond to a connection request.

Value—Integer in the range 1–2147483647 s

Default— 10

Editing Level—Expert

`check-interval check-interval`—(Optional) Time interval at which the directory monitoring system verifies its connection to the directory. If the directory connection fails after this interval, the directory monitoring system initiates a connection to another directory.

Value—Integer in the range 15–2147483647 s

Default—60

Editing Level—Expert

`blacklist`—(Optional) Specifies whether the directory monitoring system prevents connection to a directory if the directory fails to respond during 10 polling intervals.

Default—false

Editing Level—Basic

`snmp-agent`—(Optional) Specifies whether the SDX SNMP agent exports MIBs for this directory connection.

Default—false

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

slot *number* dsa initial directory-eventing

Syntax

```
slot number dsa initial directory-eventing {
    eventing;
    signature-dn signature-dn;
    polling-interval polling-interval;
    event-base-dn event-base-dn;
    dispatcher-pool-size dispatcher-pool-size;
}
```

Hierarchy Level

```
[edit slot number dsa initial directory-eventing]
```

Release Information

Statement introduced in SRC Release 1.0.0

Description

Change configuration for directory eventing properties. In most cases, you can use the default configuration for these properties.

Options

`eventing`—(Optional) Enable an SRC component to poll the directory for changes.

Default—true

Editing Level—Normal

`signature-dn signature-dn`—(Optional) DN of the directory entry that specifies the `usedDirectory` attribute for the SRC CLI. The `usedDirectory` attribute identifies the vendor of the directory server.

Value— DN

Default—o = umc

Editing Level—Expert

`polling-interval polling-interval`—(Optional) Interval at which an SRC component polls the directory to check for directory changes.

Value—Integer in the range 15–2147483647 s

Default—30

Editing Level—Normal

`event-base-dn` *event-base-dn*—(Optional)

DN of an entry superior to the data associated with an SRC component in the directory.

If you are storing non-SRC data in the directory, and that data changes frequently whereas the SRC data does not, you may need to adjust the default value to improve performance. For optimal performance, set the value to the DN of an entry superior to both the SRC data and the changing non-SRC data.

Value— DN

Default—o = UMC

Editing Level—Expert

`dispatcher-pool-size` *dispatcher-pool-size*—(Optional) Number of directory change notifications that can be sent simultaneously to the SRC component.

Value—Integer in the range 0–2147483647

Default—1

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

monitor dsa nic-proxy

Syntax

```
monitor dsa nic-proxy proxy-name proxy-name <interval interval>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Monitor NIC proxy statistics for Dynamic Service Activator.

Options

proxy-name proxy-name— Name of the NIC proxy.

Value—Text

interval interval—(Optional) The frequency for refreshing the monitor.

Value—Integer in the range -2147483648–2147483647 s

Default—5

Required Privilege Level

view

monitor dsa soap-operation

Syntax

```
monitor dsa soap-operation operation-name operation-name <interval interval>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Monitor DSA SOAP operation statistics.

Options

operation-name operation-name— Name of the SOAP operation.

Value—Text

interval interval—(Optional) The frequency for refreshing the monitor.

Value—Integer in the range -2147483648–2147483647 s

Default—5

Required Privilege Level

view

show dsa statistics general

Syntax

```
show dsa statistics general
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display general information for Dynamic Service Activator.

Required Privilege Level

view

show dsa statistics nic-proxy

Syntax

```
show dsa statistics nic-proxy proxy-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display information about the NIC proxies for Dynamic Service Activator.

Options

proxy-name— Name of the NIC proxy.

Value— NIC proxy name.

Default— No value

Required Privilege Level

view

show dsa statistics soap-operation

Syntax

```
show dsa statistics soap-operation operation-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display information about the SOAP operations for Dynamic Service Activator.

Options

operation-name— Name of the SOAP operation.

Value—Text

Required Privilege Level

view

test dsa dsa-service environment clear

Syntax

```
test dsa dsa-service environment clear
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete Dynamic Service Activator service test settings for the current subscriber session.

Required Privilege Level

maintenance

test dsa dsa-service environment clear client-id

Syntax

```
test dsa dsa-service environment clear client-id
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the client ID.

Required Privilege Level

maintenance

test dsa dsa-service environment clear client-password

Syntax

```
test dsa dsa-service environment clear client-password
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the client password.

Required Privilege Level

maintenance

test dsa dsa-service environment clear dn

Syntax

```
test dsa dsa-service environment clear dn
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the DN of the subscriber profile.

Required Privilege Level

maintenance

test dsa dsa-service environment clear interface-index

Syntax

```
test dsa dsa-service environment clear interface-index
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the SNMP index of the interface.

Required Privilege Level

maintenance

test dsa dsa-service environment clear interface-name

Syntax

```
test dsa dsa-service environment clear interface-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the interface name.

Required Privilege Level

maintenance

test dsa dsa-service environment clear login-name

Syntax

```
test dsa dsa-service environment clear login-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the login name.

Required Privilege Level

maintenance

test dsa dsa-service environment clear primary-user-name

Syntax

```
test dsa dsa-service environment clear primary-user-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the primary username.

Required Privilege Level

maintenance

test dsa dsa-service environment clear subscriber-address

Syntax

```
test dsa dsa-service environment clear subscriber-address
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the subscriber address.

Required Privilege Level

maintenance

test dsa dsa-service environment clear subscriber-constraints

Syntax

```
test dsa dsa-service environment clear subscriber-constraints
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the subscriber constraints.

Required Privilege Level

maintenance

test dsa dsa-service environment clear subscriber-id

Syntax

```
test dsa dsa-service environment clear subscriber-id
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the subscriber ID.

Required Privilege Level

maintenance

test dsa dsa-service environment clear subscriber-password

Syntax

```
test dsa dsa-service environment clear subscriber-password
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the subscriber password.

Required Privilege Level

maintenance

test dsa dsa-service environment clear subscriber-type

Syntax

```
test dsa dsa-service environment clear subscriber-type
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the subscriber type.

Required Privilege Level

maintenance

test dsa dsa-service environment clear virtual-router

Syntax

```
test dsa dsa-service environment clear virtual-router
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for the virtual router name.

Required Privilege Level

maintenance

test dsa dsa-service environment set

Syntax

```
test dsa dsa-service environment set <client-id client-id> <client-password
client-password> <subscriber-id subscriber-id> <subscriber-password subscriber-
password> <subscriber-type subscriber-type> <subscriber-address subscriber-
address> <login-name login-name> <dn dn> <virtual-router virtual-router>
<interface-name interface-name> <interface-index interface-index> <primary-
user-name primary-user-name> <subscriber-constraints subscriber-constraints>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Create Dynamic Service Activator service test settings for the current subscriber session.

Options

client-id client-id—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password client-password—(Optional) Password for Dynamic Service Activator client.

Value—Text

subscriber-id subscriber-id—(Optional) Username for SAE subscriber.

Value—Text

subscriber-password subscriber-password—(Optional) Password for SAE subscriber.

Value—Text

subscriber-type subscriber-type—(Optional) Subscriber type defined in current

shared dsa group configuration.

Value—Text

subscriber-address *subscriber-address*—(Optional) IP address of the subscriber.

Value—Text

login-name *login-name*—(Optional) Login name of the subscriber.

Value—Text

dn *dn*—(Optional) DN of the subscriber profile.

Value—Text

virtual-router *virtual-router*—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service environment show

Syntax

```
test dsa dsa-service environment show
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display Dynamic Service Activator service test settings for the current subscriber session.

Required Privilege Level

maintenance

test dsa dsa-service environment show client-id

Syntax

```
test dsa dsa-service environment show client-id
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for client username.

Required Privilege Level

maintenance

test dsa dsa-service environment show client-password

Syntax

```
test dsa dsa-service environment show client-password
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for client password.

Required Privilege Level

maintenance

test dsa dsa-service environment show dn

Syntax

```
test dsa dsa-service environment show dn
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for DN of the subscriber profile.

Required Privilege Level

maintenance

test dsa dsa-service environment show interface-index

Syntax

```
test dsa dsa-service environment show interface-index
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for the SNMP index of the interface.

Required Privilege Level

maintenance

test dsa dsa-service environment show interface-name

Syntax

```
test dsa dsa-service environment show interface-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for interface name.

Required Privilege Level

maintenance

test dsa dsa-service environment show login-name

Syntax

```
test dsa dsa-service environment show login-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for login name.

Required Privilege Level

maintenance

test dsa dsa-service environment show primary-user-name

Syntax

```
test dsa dsa-service environment show primary-user-name
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for primary username.

Required Privilege Level

maintenance

test dsa dsa-service environment show subscriber-address

Syntax

```
test dsa dsa-service environment show subscriber-address
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for subscriber IP address.

Required Privilege Level

maintenance

test dsa dsa-service environment show subscriber-constraints

Syntax

```
test dsa dsa-service environment show subscriber-constraints
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for subscriber constraints.

Required Privilege Level

maintenance

test dsa dsa-service environment show subscriber-id

Syntax

```
test dsa dsa-service environment show subscriber-id
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for username that the SAE uses to authenticate the subscriber.

Required Privilege Level

maintenance

test dsa dsa-service environment show subscriber-password

Syntax

```
test dsa dsa-service environment show subscriber-password
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for the password that the SAE uses to authenticate the subscriber.

Required Privilege Level

maintenance

test dsa dsa-service environment show subscriber-type

Syntax

```
test dsa dsa-service environment show subscriber-type
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for subscriber type.

Required Privilege Level

maintenance

test dsa dsa-service environment show virtual-router

Syntax

```
test dsa dsa-service environment show virtual-router
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display test setting for virtual router.

Required Privilege Level

maintenance

test dsa dsa-service invoke-gateway-extension

Syntax

```
test dsa dsa-service invoke-gateway-extension gateway-extension-name gateway-extension-name gateway-extension-arguments gateway-extension-arguments <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test gateway extension invocation.

Options

`gateway-extension-name` *gateway-extension-name*— Name of the servlet that the gateway client invokes.

Value—Text

`gateway-extension-arguments` *gateway-extension-arguments*— Arguments that the gateway client passes to the servlet.

Value—Text

`client-id` *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

`client-password` *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service invoke-script

Syntax

```
test dsa dsa-service invoke-script sae-script-name sae-script-name sae-script-arguments sae-script-arguments <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test script invocation.

Options

sae-script-name sae-script-name— Name of the script that Dynamic Service Activator starts.

Value—Text

sae-script-arguments sae-script-arguments— Arguments that the script requires.

Value—Text

client-id client-id—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password client-password—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service subscriber-activate-service

Syntax

```
test dsa dsa-service subscriber-activate-service <subscriber-type subscriber-
type> <subscriber-address subscriber-address> <login-name login-name> <dn dn>
<virtual-router virtual-router> <interface-name interface-name> <interface-
index interface-index> <primary-user-name primary-user-name> <subscriber-
constraints subscriber-constraints> service-name service-name <service-session
service-session> <accounting-tag accounting-tag> <downstream-bandwidth
downstream-bandwidth> <upstream-bandwidth upstream-bandwidth> <session-timeout
session-timeout> <subscription-user subscription-user> <subscription-password
subscription-password> <substitutions substitutions> <client-id client-id>
<client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test subscriber service activation.

Options

subscriber-type *subscriber-type*—(Optional) Subscriber type defined in current shared dsa group configuration.

Value—Text

subscriber-address *subscriber-address*—(Optional) IP address of the subscriber.

Value—Text

login-name *login-name*—(Optional) Login name of the subscriber.

Value—Text

dn *dn*—(Optional) DN of the subscriber profile.

Value—Text

virtual-router *virtual-router*—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

service-name *service-name*— Name of the subscription.

Value—Text

service-session *service-session*—(Optional) Name of the service session.

Value—Text

accounting-tag *accounting-tag*—(Optional) Tag used to track a session for accounting purposes.

Value—Text

downstream-bandwidth *downstream-bandwidth*—(Optional) Traffic rate between

the subscriber and the network.

Value—Text

upstream-bandwidth *upstream-bandwidth*—(Optional) Traffic rate between the network and the subscriber.

Value—Text

session-timeout *session-timeout*—(Optional) Timeout for the service.

Value—Text

subscription-user *subscription-user*—(Optional) Name of the subscriber to the service.

Value—Text

subscription-password *subscription-password*—(Optional) Password of the subscriber to the service.

Value—Text

substitutions *substitutions*—(Optional) Attributes and values that the method should substitute for existing settings.

Value—Text

client-id *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service subscriber-deactivate-service

Syntax

```
test dsa dsa-service subscriber-deactivate-service <subscriber-type subscriber-type> <subscriber-address subscriber-address> <login-name login-name> <dn dn> <virtual-router virtual-router> <interface-name interface-name> <interface-index interface-index> <primary-user-name primary-user-name> <subscriber-constraints subscriber-constraints> service-name service-name <service-session service-session> <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test subscriber service deactivation.

Options

subscriber-type subscriber-type—(Optional) Subscriber type defined in current shared dsa group configuration.

Value—Text

subscriber-address subscriber-address—(Optional) IP address of the subscriber.

Value—Text

login-name login-name—(Optional) Login name of the subscriber.

Value—Text

dn dn—(Optional) DN of the subscriber profile.

Value—Text

virtual-router virtual-router—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

service-name *service-name*— Name of the subscription.

Value—Text

service-session *service-session*—(Optional) Name of the service session.

Value—Text

client-id *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service subscriber-login

Syntax

```
test dsa dsa-service subscriber-login <subscriber-type subscriber-type>
<subscriber-address subscriber-address> <login-name login-name> <dn dn>
<virtual-router virtual-router> <interface-name interface-name> <interface-
index interface-index> <primary-user-name primary-user-name> <subscriber-
constraints subscriber-constraints> <subscriber-id subscriber-id> <subscriber-
password subscriber-password> <client-id client-id> <client-password client-
password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test subscriber login.

Options

subscriber-type subscriber-type—(Optional) Subscriber type defined in current shared dsa group configuration.

Value—Text

subscriber-address subscriber-address—(Optional) IP address of the subscriber.

Value—Text

login-name login-name—(Optional) Login name of the subscriber.

Value—Text

dn dn—(Optional) DN of the subscriber profile.

Value—Text

virtual-router *virtual-router*—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

subscriber-id *subscriber-id*—(Optional) Username for the SAE subscriber.

Value—Text

subscriber-password *subscriber-password*—(Optional) Password for the SAE subscriber.

Value—Text

client-id *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service subscriber-logout

Syntax

```
test dsa dsa-service subscriber-logout <subscriber-type subscriber-type>
<subscriber-address subscriber-address> <login-name login-name> <dn dn>
<virtual-router virtual-router> <interface-name interface-name> <interface-
index interface-index> <primary-user-name primary-user-name> <subscriber-
constraints subscriber-constraints> <client-id client-id> <client-password
client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test subscriber logout.

Options

subscriber-type subscriber-type—(Optional) Subscriber type defined in current shared dsa group configuration.

Value—Text

subscriber-address subscriber-address—(Optional) IP address of the subscriber.

Value—Text

login-name login-name—(Optional) Login name of the subscriber.

Value—Text

dn dn—(Optional) DN of the subscriber profile.

Value—Text

virtual-router virtual-router—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

client-id *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text**Required Privilege Level**

maintenance

test dsa dsa-service subscriber-modify-service

Syntax

```
test dsa dsa-service subscriber-modify-service <subscriber-type subscriber-type> <subscriber-address subscriber-address> <login-name login-name> <dn dn> <virtual-router virtual-router> <interface-name interface-name> <interface-index interface-index> <primary-user-name primary-user-name> <subscriber-constraints subscriber-constraints> service-name service-name <service-session service-session> <accounting-tag accounting-tag> <downstream-bandwidth downstream-bandwidth> <upstream-bandwidth upstream-bandwidth> <session-timeout session-timeout> <subscription-user subscription-user> <subscription-password subscription-password> <substitutions substitutions> <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test subscriber service modifications.

Options

subscriber-type subscriber-type—(Optional) Subscriber type defined in current shared dsa group configuration.

Value—Text

subscriber-address subscriber-address—(Optional) IP address of the subscriber.

Value—Text

login-name login-name—(Optional) Login name of the subscriber.

Value—Text

dn dn—(Optional) DN of the subscriber profile.

Value—Text

virtual-router *virtual-router*—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

service-name *service-name*— Name of the subscription.

Value—Text

service-session *service-session*—(Optional) Name of the service session.

Value—Text

accounting-tag *accounting-tag*—(Optional) Tag used to track a session for accounting purposes.

Value—Text

downstream-bandwidth *downstream-bandwidth*—(Optional) Traffic rate between

the subscriber and the network.

Value—Text

upstream-bandwidth *upstream-bandwidth*—(Optional) Traffic rate between the network and the subscriber.

Value—Text

session-timeout *session-timeout*—(Optional) Timeout for the service.

Value—Text

subscription-user *subscription-user*—(Optional) Name of the subscriber to the service.

Value—Text

subscription-password *subscription-password*—(Optional) Password of the subscriber to the service.

Value—Text

substitutions *substitutions*—(Optional) Attributes and values that the method should substitute for existing settings.

Value—Text

client-id *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa dsa-service subscriber-read-subscription

Syntax

```
test dsa dsa-service subscriber-read-subscription <subscriber-type subscriber-type> <subscriber-address subscriber-address> <login-name login-name> <dn dn> <virtual-router virtual-router> <interface-name interface-name> <interface-index interface-index> <primary-user-name primary-user-name> <subscriber-constraints subscriber-constraints> <attributes attributes> <filter filter> <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Test subscriber's access to subscriptions.

Options

subscriber-type subscriber-type—(Optional) Subscriber type defined in current shared dsa group configuration.

Value—Text

subscriber-address subscriber-address—(Optional) IP address of the subscriber.

Value—Text

login-name login-name—(Optional) Login name of the subscriber.

Value—Text

dn dn—(Optional) DN of the subscriber profile.

Value—Text

virtual-router virtual-router—(Optional) Name of the virtual router.

Value—Text

interface-name *interface-name*—(Optional) Name of the interface.

Value—Text

interface-index *interface-index*—(Optional) SNMP index of the interface.

Value—Text

primary-user-name *primary-user-name*—(Optional) Primary username.

Value—Text

subscriber-constraints *subscriber-constraints*—(Optional) The constraint for the NIC key, in the format "< constraint name > = < constraint value >".

Value—Text

attributes *attributes*—(Optional) Attribute field in a select argument that indicates subscription attributes.

Value—Text

Default—serviceName

filter *filter*—(Optional) Filter field in a select argument that indicates subscriptions.

Value—Text

Default—*

client-id *client-id*—(Optional) Username for Dynamic Service Activator client.

Value—Text

client-password *client-password*—(Optional) Password for Dynamic Service Activator client.

Value—Text

Required Privilege Level

maintenance

test dsa pcmm-service commit-resources

Syntax

```
test dsa pcmm-service commit-resources <subscriber-address subscriber-address>
<subscriber-uri subscriber-uri> service-name service-name <context-id context-id>
<time-usage-limit time-usage-limit> <classifier classifier> <traffic-profile traffic-profile>
<flow-spec flow-spec> <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Specifies the resources that are being requested in the CommitResource message.

Options

`subscriber-address subscriber-address`—(Optional) IP address for PCMM service client.

Value—Text

`subscriber-uri subscriber-uri`—(Optional) Subscriber URI for PCMM service.

Value—Text

`service-name service-name`— Name of the SRC service.

Value—Text

`context-id context-id`—(Optional) Context ID; globally unique identifier that the application manager uses as the SRC session name.

Value—Text

`time-usage-limit time-usage-limit`—(Optional) Limit on the lifetime of a context.

Value—Text

`classifier classifier`—(Optional) Object that identifies the traffic flow for which the application server is requesting services. In the format: < parameter name > = < parameter value > .

Value—Text

`traffic-profile traffic-profile`—(Optional) The bandwidth and QoS characteristics desired for a request. In the format: < parameter name > = < parameter value > .

Value—Text

`flow-spec flow-spec`—(Optional) FlowSpec action to specify the traffic profile. In the format: < parameter name > = < parameter value > .

Value—Text

`client-id client-id`—(Optional) ID for PCMM service client.

Value—Text

`client-password client-password`—(Optional) Password for PCMM service client.

Value—Text**Required Privilege Level**

maintenance

test dsa pcmm-service environment clear

Syntax

```
test dsa pcmm-service environment clear
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete PCMM service test settings for the current subscriber session.

Required Privilege Level

maintenance

test dsa pcmm-service environment clear client-id

Syntax

```
test dsa pcmm-service environment clear client-id
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for PCMM service client ID.

Required Privilege Level

maintenance

test dsa pcmm-service environment clear client-password

Syntax

```
test dsa pcmm-service environment clear client-password
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for PCMM service client password.

Required Privilege Level

maintenance

test dsa pcmm-service environment clear subscriber-address

Syntax

```
test dsa pcmm-service environment clear subscriber-address
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for PCMM service subscriber IP address.

Required Privilege Level

maintenance

test dsa pcmm-service environment clear subscriber-uri

Syntax

```
test dsa pcmm-service environment clear subscriber-uri
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Delete test setting for PCMM service subscriber URI.

Required Privilege Level

maintenance

test dsa pcmm-service environment set

Syntax

```
test dsa pcmm-service environment set <client-id client-id> <client-password
client-password> <subscriber-address subscriber-address> <subscriber-uri
subscriber-uri>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Create PCMM service test settings for the current subscriber session.

Options

client-id client-id—(Optional) ID for PCMM service client.

Value—Text

client-password client-password—(Optional) Password for PCMM service client.

Value—Text

subscriber-address subscriber-address—(Optional) IP for PCMM service client.

Value—Text

subscriber-uri subscriber-uri—(Optional) Subscriber URI for PCMM service. In the following format: < subscriber-type > : < subscriber-comp > [& < subscriber-comp >]* [' < ' < constraint > [& < constraint >]*' > ']

Value—Text

Required Privilege Level

maintenance

test dsa pcmm-service environment show

Syntax

```
test dsa pcmm-service environment show
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display PCMM service test settings for the current subscriber session.

Required Privilege Level

maintenance

test dsa pcmm-service environment show client-id

Syntax

```
test dsa pcmm-service environment show client-id
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display PCMM service test setting for the client username.

Required Privilege Level

maintenance

test dsa pcmm-service environment show client-password

Syntax

```
test dsa pcmm-service environment show client-password
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display PCMM service test setting for the client password.

Required Privilege Level

maintenance

test dsa pcmm-service environment show subscriber-address

Syntax

```
test dsa pcmm-service environment show subscriber-address
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display PCMM service test setting for the IP address of the subscriber.

Required Privilege Level

maintenance

test dsa pcmm-service environment show subscriber-uri

Syntax

```
test dsa pcmm-service environment show subscriber-uri
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display PCMM service test setting for the subscriber URI.

Required Privilege Level

maintenance

test dsa pcmm-service query-available-services

Syntax

```
test dsa pcmm-service query-available-services <client-id client-id> <client-  
password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Searches for the services that are available for a specified subscriber.

Options

`client-id client-id`—(Optional) ID for PCMM service client.

Value—Text

`client-password client-password`—(Optional) Password for PCMM service client.

Value—Text

Required Privilege Level

maintenance

test dsa pcmm-service query-contexts

Syntax

```
test dsa pcmm-service query-contexts <subscriber-address subscriber-address>
<subscriber-uri subscriber-uri> <service-name service-name> <context-id
context-id> <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Searches for the context ID and context status for a subscriber.

Options

`subscriber-address subscriber-address`—(Optional) IP address for PCMM service client.

Value—Text

`subscriber-uri subscriber-uri`—(Optional) Subscriber URI for PCMM service.

Value—Text

`service-name service-name`—(Optional) Name of the SRC service.

Value—Text

`context-id context-id`—(Optional) Context ID; globally unique identifier that the application manager uses as the SRC session name.

Value—Text

`client-id client-id`—(Optional) ID for PCMM service client.

Value—Text

`client-password` *client-password*—(Optional) Password for PCMM service client.

Value—Text

Required Privilege Level

maintenance

test dsa pcmm-service release-resources

Syntax

```
test dsa pcmm-service release-resources <subscriber-address subscriber-address> <subscriber-uri subscriber-uri> service-name service-name <context-id context-id> <client-id client-id> <client-password client-password>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Specifies the resources that are being requested to be released in the ReleaseResources message.

Options

`subscriber-address subscriber-address`—(Optional) IP address for PCMM service client.

Value—Text

`subscriber-uri subscriber-uri`—(Optional) Subscriber URI for PCMM service.

Value—Text

`service-name service-name`— Name of the SRC service.

Value—Text

`context-id context-id`—(Optional) Context ID; globally unique identifier that the application manager uses as the SRC session name.

Value—Text

`client-id client-id`—(Optional) ID for PCMM service client.

Value—Text

`client-password` *client-password*—(Optional) Password for PCMM service client.

Value—Text

Required Privilege Level

maintenance

DIAMETER Application

The following table summarizes the SRC command-line interface (SRC CLI) for supporting the DIAMETER application. Configuration statements and operational commands are listed in alphabetical order.

DIAMETER
Configuration Statements
shared network nas-group
shared network nas-group name interface-classifier rule
shared network nas-group name interface-classifier rule name condition
shared network nas-group name peer
shared network nas-group name routes
shared network nas-group name routes name term
system diameter
system diameter client
system diameter logger
system diameter logger name file
system diameter server
Operational Commands
show diameter statistics
show diameter statistics message-handler
show diameter statistics message-handler message-flow
show diameter statistics process
show diameter statistics requests
show diameter status
show diameter status clients
show diameter status peers

shared network nas-group

Syntax

```
shared network nas-group name {
    hosted-by [hosted-by...];
    function (aaa);
    scope [scope...];
    default-peer default-peer;
    update-grace-period update-grace-period;
    initial-ppr-delay initial-ppr-delay;
}
```

Hierarchy Level

```
[edit shared network nas-group]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure group of equivalent peers.

Options

`name name`— Name of the NAS group.

Value—Text

`hosted-by [hosted-by...]`— Hosts that instantiate this peer group.

The DIAMETER server is running on every SRC-PE host. If the peer group is of type `aaa`, then the SAEs on the listed hosts will create device drivers for this peer group.

Value—Text

Editing Level—Basic

`function (aaa)`— Functional interface of the peer group.

Value

- `aaa`—AAA interface

Default—`aaa`

Editing Level—Basic

`scope [scope . . .]`—(Optional) Service scopes associated with the NAS group. The scopes are available for subscribers connected to this NAS group for selecting customized versions of services.

Value—Text

Default—No value

Editing Level—Basic

`default-peer default-peer`—(Optional) Default peer.

Value—Text

Editing Level—Basic

`update-grace-period update-grace-period`—(Optional) Grace period for interim updates.

Value—Integer in the range 0–2147483647 s

Editing Level—Basic

`initial-ppr-delay initial-ppr-delay`—(Optional) Delay for sending initial policy-install PPRs.

Value—Integer in the range 0–9223372036854775807 ms

Default—0

Editing Level—Expert

Required Privilege Level

system

Required Editing Level

Basic

shared network nas-group *name* interface-classifier rule

Syntax

```
shared network nas-group name interface-classifier rule name {
    target target;
    script script;
}
```

Hierarchy Level

```
[edit shared network nas-group name interface-classifier rule]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure an interface classification rule.

Options

name name— Name of the rule in the interface classification script.

Value— Text

target target—(Optional) Result of the classification script that gets returned to the SAE.

Value— Path to a policy group. For example, /sample/junose/DHCP.

Default— No value

Editing Level—Basic

script script—(Optional) Script target. A script that can contain definitions of custom functions that can be called during the matching process. The complete content of the script is interpreted when the classifier is initially loaded. Because you can insert code into a script target, you can use the classification script to perform various tasks.

Value— Script enclosed in quotation marks.

Default— No value

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared network nas-group *name* interface-classifier rule *name* condition

Syntax

```
shared network nas-group name interface-classifier rule name condition name ...
```

Hierarchy Level

```
[edit shared network nas-group name interface-classifier rule name condition]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure match conditions used to find a target. You can configure multiple conditions for each classifier rule.

Options

name name— Match conditions used to find a target. For more information about configuring match conditions, see *Classifying Interfaces and Subscribers with the SRC CLI* in *SRC-PE Subscribers and Subscriptions Guide*.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

shared network nas-group *name* peer

Syntax

```
shared network nas-group name peer name {
    protocol [(tcp | sctp)...];
    address [address...];
    local-address local-address;
    connect-timeout connect-timeout;
    watchdog-timeout watchdog-timeout;
    state-machine-timeout state-machine-timeout;
    reconnect-timeout reconnect-timeout;
    port port;
    origin-host origin-host;
    incoming-queue-limit incoming-queue-limit;
    active-peer;
}
```

Hierarchy Level

```
[edit shared network nas-group name peer]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the peer in the NAS group.

Options

name *name*— Name of the peer. The peer name must be unique in the NAS group.

Value—Text

protocol [(tcp | sctp)...]— Supported transport protocol.

Value

- tcp—TCP
- sctp—SCTP

Editing Level—Basic

`address` [*address . . .*]—Addresses to which the peer can be connected.

Value—IP address

Editing Level—Basic

`local-address` *local-address*—(Optional) Local IP address.

Value—IP address

Editing Level—Expert

`connect-timeout` *connect-timeout*—(Optional) Connect timeout.

Value—Integer in the range 0–2147483 s

Default—10

Editing Level—Basic

`watchdog-timeout` *watchdog-timeout*—(Optional) Watchdog timeout used for the connection to the remote peer.

Value—Integer in the range 0–2147483 s

Default—30

Editing Level—Expert

`state-machine-timeout` *state-machine-timeout*—(Optional) Diameter state machine timeout as specified in RFC 3588.

Value—Integer in the range 0–2147483 s

Default—30

Editing Level—Expert

`reconnect-timeout` *reconnect-timeout*—(Optional) Time interval between connection attempts when the peer is in the disconnected state.

Value—Integer in the range 0–2147483 s

Default—10

Editing Level—Expert

`port` *port*—(Optional) Client port.

Value—Integer in the range 1–65565

Default—3868

Editing Level—Basic

`origin-host` *origin-host*—(Optional) The expected origin-host that the peer presents during connection establishment.

Value—Text

Editing Level—Basic

`incoming-queue-limit` *incoming-queue-limit*—(Optional) Number of messages of the incoming message queue for a peer. Whenever the number of messages in the queue exceeds any multiple of this limit, the peer connection stops reading incoming requests. Similarly, when the limit is no longer exceeded, the peer connection resumes reading from the operating system transports.

Value—Integer in the range 1–2147483647

Editing Level—Expert

`active-peer`—(Optional) Specify whether the peer connection is in active mode.

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared network nas-group *name* routes

Syntax

```
shared network nas-group name routes name {
    precedence precedence;
}
```

Hierarchy Level

```
[edit shared network nas-group name routes]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure Diameter routing configuration.

Options

name name— Name of the route configuration.

Value—Text

precedence precedence—(Optional) The order by which the route is selected. The route which meets all the matching criteria and has the lowest precedence is selected first. Routes without the precedence defined are considered after those that have the precedence defined. Route with precedence of -1 is the default route. The default route is considered after all the other routes and only one default route can be defined.

Value—Integer in the range -1–2147483647

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

shared network nas-group *name* routes *name* term

Syntax

```
shared network nas-group name routes name term name {
    transaction-variable (request-packet | user-name | realm);
    dictionary-attribute (user-name | user-password | chap-password | nas-ip-
address | nas-port | service-type | framed-protocol | framed-ip-address |
framed-ip-netmask | framed-mtu | framed-compression | login-ip-host | callback-
number | state | vendor-specific | called-station-id | calling-station-id |
nas-identifier | login-lat-service | login-lat-node | login-lat-group | chap-
challenge | nas-port-type | port-limit | login-lat-port);
    operator (equals | not_equal | present | not_present | prefix | suffix |
range);
    value value;
    low low;
    high high;
}
```

Hierarchy Level

```
[edit shared network nas-group name routes name term]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the criteria for route selection.

Options

name name— Name of the matching criteria configuration.

Value—Text

transaction-variable (request-packet | user-name | realm)— Name of the transaction variable used as the matching criterion.

Value

- request-packet—RequestPacket transaction variable
- user-name—User-Name transaction variable

- realm—Realm transaction variable

Editing Level—Basic

dictionary-attribute (user-name | user-password | chap-password | nas-ip-address | nas-port | service-type | framed-protocol | framed-ip-address | framed-ip-netmask | framed-mtu | framed-compression | login-ip-host | callback-number | state | vendor-specific | called-station-id | calling-station-id | nas-identifier | login-lat-service | login-lat-node | login-lat-group | chap-challenge | nas-port-type | port-limit | login-lat-port)—
(Optional) Name of the dictionary attribute contained in the attribute store. Only applicable if the transaction variable is 'request-packet'.

Value

- user-name—The name of the user to be authenticated
- user-password—The password of the user to be authenticated
- chap-password—The response value provided by a PPP CHAP user
- nas-ip-address—The identifying IP address of the NAS
- nas-port—The physical port number of the NAS
- service-type—The type of service the user has requested
- framed-protocol—The framing to be used for framed access
- framed-ip-address—The address to be configured for the user
- framed-ip-netmask—The IP netmask to be configured for the user
- framed-mtu—The Maximum Transmission Unit to be configured for user
- framed-compression—A compression protocol to be used for the link
- login-ip-host—The system with which to connect the user
- callback-number—A dialing string to be used for callback
- state—A state attribute provided by the RADIUS server
- vendor-specific—A vendor-specific extended attribute
- called-station-id—The phone number that the user called
- calling-station-id—The phone number that the call came from
- nas-identifier—A string identifying the NAS originating the request
- login-lat-service—The system with which to connect the user by LAT
- login-lat-node—The node with which to automatically connect user by LAT
- login-lat-group—The LAT group codes which the user is

- authorized to use
- `chap-challenge`—The challenge sent by the NAS to a PPP CHAP user
- `nas-port-type`—The type of the physical port of the NAS
- `port-limit`—The maximum number of ports to be provided to the user
- `login-lat-port`—The port with which to connect the user by LAT

Editing Level—Basic

`operator (equals | not_equal | present | not_present | prefix | suffix | range)`—Operator for criterion matching.

Value

- `equals`—Target value equals
- `not_equal`—Target value does not equal
- `present`—Target exists
- `not_present`—Target does not exist
- `prefix`—Target value starts with
- `suffix`—Target value ends with
- `range`—Target value in the range of

Editing Level—Basic

`value value`—(Optional) Value to be matched by the target.

Value—Text

Editing Level—Basic

`low low`—(Optional) Low end of the range criterion.

Value—Integer in the range -2147483648–2147483647

Editing Level—Basic

`high high`—(Optional) High end of the range criterion.

Value—Integer in the range -2147483648–2147483647

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Basic

system diameter

Syntax

```
system diameter {
    java-heap-size java-heap-size;
    java-new-size java-new-size;
    java-garbage-collection-options java-garbage-collection-options;
    protocol [(tcp | sctp)...];
    local-address [local-address...];
    port port;
    origin-host origin-host;
    origin-realm origin-realm;
    active-peers;
    debug-mode;
    load-balancing-mode (failover | round-robin);
    transaction-processing-log (log-no-messages | log-severe-messages | log-
normal-messages | log-debug-messages);
    packet-trace-log (log-no-messages | log-severe-messages | log-normal-
messages | log-debug-messages);
    peer-state-machine-log (log-no-messages | log-severe-messages | log-
normal-messages | log-debug-messages);
    configuration-log (log-no-messages | log-severe-messages | log-normal-
messages | log-debug-messages);
}
```

Hierarchy Level

```
[edit system diameter]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure DIAMETER application.

Options

java-heap-size java-heap-size— Maximum Java heap (memory) size available to the JRE.

Value— Number of megabytes followed by m. For example, 896m. Change this value if you experience problems caused by lack of memory. Set the value lower than the available physical memory to

avoid low performance caused by disk swapping. See the documentation for the JRE for valid values.

Default— The value is calculated dynamically to 70 % of the available real memory.

Editing Level—Advanced

`java-new-size` *java-new-size*— Maximum Java new generation heap (memory) size available to the JRE when the Diameter server starts.

Value— Integer in the range 0– < Java heap size > . Specify the value in bytes or add m for megabytes, k for kilobytes, or g for gigabytes. For example, 200m. See the documentation for the JRE for valid values.

Default— 200m

Editing Level—Advanced

`java-garbage-collection-options` *java-garbage-collection-options*— Garbage collection functionality of the Java Virtual Machine.

Value—

Editing Level—Advanced

`protocol` [(tcp | sctp) . . .]— Supported transport protocol.

Value

- tcp—TCP
- sctp—SCTP

Editing Level—Basic

`local-address` [*local-address* . . .]—(Optional) Local IP addresses that the remote peers can use to reach this server.

Value—IP address

Editing Level—Basic

`port` *port*—(Optional) Server port.

Value—Integer in the range 1–65565

Default—3868

Editing Level—Basic

`origin-host` *origin-host*—(Optional) Fully qualified domain name used to identify this host to its DIAMETER peers.

Value—Text

Default— The host name as reported by `java.net.InetAddress.getLocalHost().getCanonicalHostName()`

Editing Level—Basic

`origin-realm` *origin-realm*—(Optional) The DNS name of the machine used to identify this host to its DIAMETER peers.

Value—Text

Default— The DNS name part of the local hostname as reported by `java.net.InetAddress.getLocalHost().getCanonicalHostName()`

Editing Level—Basic

`active-peers`—(Optional) Specify whether the peer connection is in active mode.

Default—true

Editing Level—Basic

`debug-mode`—(Optional) Specify whether the peer connection is in debug mode.

Default—false

Editing Level—Basic

`load-balancing-mode` (`failover` | `round-robin`)—(Optional) Strategy used to select a peer to forward a request message.

Value

- `failover`
- `round-robin`

Default—failover

Editing Level—Expert

`transaction-processing-log` (`log-no-messages` | `log-severe-messages` | `log-normal-messages` | `log-debug-messages`)—(Optional) Log level for transaction processing log.

Value

- log-no-messages
- log-severe-messages
- log-normal-messages
- log-debug-messages

Editing Level—Expert

packet-trace-log (log-no-messages | log-severe-messages | log-normal-messages | log-debug-messages) —(Optional) Log level for packet trace log.

Value

- log-no-messages
- log-severe-messages
- log-normal-messages
- log-debug-messages

Editing Level—Expert

peer-state-machine-log (log-no-messages | log-severe-messages | log-normal-messages | log-debug-messages) —(Optional) Log level for peer state machine log.

Value

- log-no-messages
- log-severe-messages
- log-normal-messages
- log-debug-messages

Editing Level—Expert

configuration-log (log-no-messages | log-severe-messages | log-normal-messages | log-debug-messages) —(Optional) Log level for configuration log.

Value

- log-no-messages

- log-severe-messages
- log-normal-messages
- log-debug-messages

Editing Level—Expert**Required Privilege Level**

system

Required Editing Level

Basic

system diameter client

Syntax

```
system diameter client {
    threads threads;
    keep-alive-time keep-alive-time;
}
```

Hierarchy Level

```
[edit system diameter client]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure properties for the client.

Options

`threads threads`—(Optional) Minimum number of threads to use.

Value—Integer in the range -2147483648–2147483647

Default—50

Editing Level—Basic

`keep-alive-time keep-alive-time`—(Optional) Interval to keep threads alive waiting for new commands.

Value—Integer in the range -9223372036854775808–9223372036854775807 ms

Default—60000

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Advanced

system diameter logger

Syntax

```
system diameter logger name ...
```

Hierarchy Level

```
[edit system diameter logger]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure the logging destination.

Options

`name name`— Name used to group parameters for the logging destination.

Value—Text

Required Privilege Level

system

Required Editing Level

Basic

system diameter logger *name* file

Syntax

```
system diameter logger name file {
    filter filter;
    filename filename;
    rollover-filename rollover-filename;
    maximum-file-size maximum-file-size;
}
```

Hierarchy Level

```
[edit system diameter logger name file]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure logging of messages to a file.

Options

filter filter—(Optional) Filter to define which event messages the software logs or ignores. Filters can specify the logging level, such as debug, or can specify expressions. For information about expressions, see the documentation that describes how to configure logging.

Value— Log filter

Default— The default value is different for each type of component.

Editing Level—Basic

filename filename— Absolute path of the filename that contains the current logs.

Note: Make sure that the user under which the J2EE application server or Web application server runs has write access to this folder. If this user does not have write access to the default folder, configure the component or application to write logs in folders to which the user has write access.

Value— Filename

Default— By default, SRC components and applications write log files in the folder in which the component or application is started.

Editing Level—Basic

`rollover-filename` *rollover-filename*—(Optional) Absolute path of the filename that contains the log history. When the log file reaches the maximum size, the software closes the log file and renames it with the name you specify for the rollover file. If a previous rollover file exists, the software overwrites it. The software then reopens the log file and continues to save event messages in it.

Value— Path of filename

Example—`/opt/UMC/sae/var/log/sae.alt`

Default— The default value is different for each type of component.

Editing Level—Normal

`maximum-file-size` *maximum-file-size*—(Optional) Maximum size of the log file and the rollover file.

Do not set the maximum file size to a value greater than the available disk space.

Value—Integer in the range 0–2147483647 kbytes

Default— 1000000

Editing Level—Normal

Required Privilege Level

system

Required Editing Level

Basic

system diameter server

Syntax

```
system diameter server {
    threads threads;
    keep-alive-time keep-alive-time;
}
```

Hierarchy Level

```
[edit system diameter server]
```

Release Information

Statement introduced in SRC Release 3.0.0

Description

Configure properties for the server.

Options

`threads threads`—(Optional) Minimum number of threads to use.

Value—Integer in the range -2147483648–2147483647

Default—50

Editing Level—Basic

`keep-alive-time keep-alive-time`—(Optional) Interval to keep threads alive waiting for new commands.

Value—Integer in the range -9223372036854775808–

9223372036854775807 ms

Default—60000

Editing Level—Basic

Required Privilege Level

system

Required Editing Level

Advanced

show diameter statistics

Syntax

```
show diameter statistics
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display Diameter statistics, including information about the server process and the current state of the Diameter server.

Required Privilege Level

No specific privilege required.

show diameter statistics message-handler

Syntax

```
show diameter statistics message-handler
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display statistics for the Diameter message handler.

Required Privilege Level

No specific privilege required.

show diameter statistics message-handler message-flow

Syntax

```
show diameter statistics message-handler message-flow <id id>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display statistics for Diameter message flows.

Options

`id id`—(Optional) Message flow ID filter.

Value— Substring of the message flow ID. If the message flow ID filter is not specified, all message flows are selected.

Default— No value

Required Privilege Level

No specific privilege required.

show diameter statistics process

Syntax

```
show diameter statistics process
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display information about the Diameter server process.

Required Privilege Level

No specific privilege required.

show diameter statistics requests

Syntax

```
show diameter statistics requests
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display information about the Diameter server requests.

Required Privilege Level

No specific privilege required.

show diameter status

Syntax

```
show diameter status < (brief) >
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display Diameter status.

Options

(Optional) Output style.

Value

- **brief**— Display only peer and client names.

Default— Detail

Required Privilege Level

No specific privilege required.

show diameter status clients

Syntax

```
show diameter status clients <client-name client-name>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display information for a client instance.

Options

`client-name client-name`—(Optional) Name of a client.

Value— All or part of the client name.

Default— No value

Required Privilege Level

No specific privilege required.

show diameter status peers

Syntax

```
show diameter status peers <peer-name peer-name>
```

Release Information

Command introduced in SRC Release 3.0.0

Description

Display information for a peer instance.

Options

peer-name peer-name—(Optional) Name of a peer.

Value— All or part of the peer name.

Default— No value

Required Privilege Level

No specific privilege required.