



Junos[®] OS for EX Series Ethernet Switches

Virtual Chassis Feature Guide for EX2200, EX3300,
EX4200, EX4500 and EX4550 Switches



Modified: 2019-03-21

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Junos® OS for EX Series Ethernet Switches Virtual Chassis Feature Guide for EX2200, EX3300, EX4200, EX4500 and EX4550 Switches
Copyright © 2019 Juniper Networks, Inc. All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <https://support.juniper.net/support/eula/>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

	About the Documentation	xv
	Documentation and Release Notes	xv
	Using the Examples in This Manual	xv
	Merging a Full Example	xvi
	Merging a Snippet	xvi
	Documentation Conventions	xvii
	Documentation Feedback	xix
	Requesting Technical Support	xix
	Self-Help Online Tools and Resources	xx
	Creating a Service Request with JTAC	xx
Part 1	Overview	
Chapter 1	Virtual Chassis Overview	3
	Virtual Chassis Overview for Switches	3
	Benefits of Virtual Chassis on Switches	4
	Virtual Chassis Basics on Switches	5
	Connecting Member Switches with Virtual Chassis Ports	5
	Virtual Chassis Configuration	6
	Configuring Interfaces for a Virtual Chassis	6
	Mixed and Non-mixed EX Series and QFX Series Virtual Chassis	6
	Virtual Chassis Member Switch Roles	7
	Global Management of Member Switches in a Virtual Chassis	7
	High Availability Using Redundancy	8
	Adaptability as an Access Switch or Distribution Switch	8
	Understanding EX Series Virtual Chassis	8
	Virtual Chassis Support on EX Series Switches	9
	Basic Configuration of EX Series Virtual Chassis	11
	EX2200 Switches in a Virtual Chassis	12
	EX2300 Switches in a Virtual Chassis	12
	EX3300 Switches in a Virtual Chassis	13
	EX3400 Switches in a Virtual Chassis	13
	EX4200, EX4500, and EX4550 Switches in a Virtual Chassis	14
	EX4300 Switches in a Virtual Chassis	14
	EX4600 Switches in a Virtual Chassis	15

Understanding Virtual Chassis Components	16
Maximum Switch Support	17
Maximum Number of Switches in an EX Series Virtual Chassis	17
Maximum Switch Support in a QFX Series Virtual Chassis (Including Mixed Virtual Chassis with EX Series Switches)	19
Virtual Chassis Ports (VCPs)	20
Virtual Chassis Port Options	20
Automatic Virtual Chassis Port (VCP) Conversion	22
Virtual Chassis Port Link Aggregation Groups	23
Master Routing Engine Role	23
Backup Routing Engine Role	24
Linecard Role	25
Member Switch and Member ID	26
Mastership Priority	27
Virtual Chassis Identifier (VCID)	27
Nonvolatile Storage in a Virtual Chassis	27
Understanding Mixed EX Series and QFX Series Virtual Chassis	29
Mixed and Non-mixed EX Series and QFX Series Virtual Chassis Summary	30
Understanding the Routing Engine Role in a Virtual Chassis With Different Types of Switches	32
Understanding QFX5100 and QFX5110 Switches in a Virtual Chassis	33
Understanding EX4300, QFX3500, QFX3600, and QFX5100 Switches in a Mixed Virtual Chassis	33
Understanding Mixed EX4300 and EX4600 Virtual Chassis	34
Understanding EX4300 Multigigabit and Other EX4300 Model Switches in a Mixed EX4300 Virtual Chassis	34
Understanding EX4200, EX4500, and EX4550 Switches in a Mixed Virtual Chassis	35
Understanding How the Master in a Virtual Chassis Is Elected	36
Understanding Software Upgrades in a Virtual Chassis	37
Automatic Software Updates	38
Nonstop Software Upgrade	38
Understanding Global Management of a Virtual Chassis	38
Understanding the High-Speed Interconnection of the Dedicated Virtual Chassis Ports Connecting EX4200, EX4500, and EX4550 Member Switches	41
Understanding Virtual Chassis Port Link Aggregation	41
Virtual Chassis Network Interface LAG Among Virtual Chassis Members	41
Virtual Chassis Port LAG Between Two Virtual Chassis Members	42
Understanding Fast Failover in an EX Series Virtual Chassis	43
Supported Topologies for Fast Failover	44
How Fast Failover Works	44
Fast Failover in a Ring Topology Using Dedicated VCPs	44
Fast Failover in a Ring Topology Using Uplink Module VCPs	46
Fast Failover in a Virtual Chassis Configuration Using Multiple Ring Topologies	48
Effects of Topology Changes on a Fast Failover Configuration	49

Understanding Split and Merge in a Virtual Chassis	50
What Happens When a Virtual Chassis Configuration Splits	50
Merging Virtual Chassis Configurations	51
Understanding Automatic Software Update on Virtual Chassis Member	
Switches	53
Automatic Software Update Basics	53
Automatic Software Update Restrictions	53
Understanding Nonstop Software Upgrade on EX Series Switches	54
Requirements for Performing an NSSU	55
How an NSSU Works	57
EX3300, EX3400, EX4200, EX4300, EX4500, EX4600, and Mixed	
Virtual Chassis	57
EX6200 and EX8200 Switches	58
EX8200 Virtual Chassis	59
NSSU Limitations	60
NSSU and Junos OS Release Support	60
Overview of NSSU Configuration and Operation	61
Understanding Virtual Chassis Device Reachability Testing	62
Understanding MAC Address Assignment on a Virtual Chassis	62
Understanding High Availability on an EX Series Virtual Chassis	63

Part 2

Chapter 2

Configuration

Configuration Examples	67
Example: Configuring an EX2200 Virtual Chassis with Four Member	
Switches	68
Example: Configuring an EX3300 Virtual Chassis with a Master and Backup	72
Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in	
a Single Wiring Closet	76
Example: Configuring an EX4500 Virtual Chassis with a Master and Backup in	
a Single Wiring Closet	82
Example: Expanding an EX3300 Virtual Chassis	87
Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet	92
Example: Adding EX4500 Switches to a Preprovisioned Virtual Chassis	98
Example: Adding an EX4500 Switch to a Nonprovisioned Virtual Chassis	102
Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch	
with a Default Configuration	107
Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple	
Wiring Closets	113
Example: Connecting EX4500 Member Switches in a Virtual Chassis Across	
Wiring Closets	121
Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned	
Configuration File	127
Example: Configuring a Preprovisioned Mixed EX4200 and EX4500 Virtual	
Chassis	139
Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an	
EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis	
Distribution Switch	144

	Example: Configuring Aggregated Ethernet High-Speed Uplinks with LACP Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch	151
	Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails	156
	Example: Assigning the Virtual Chassis ID to Determine Precedence During an EX4200 Virtual Chassis Merge	159
	Example: Configuring Link Aggregation Groups Using EX4200 Uplink Virtual Chassis Ports	161
	Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches	170
Chapter 3	Configuration Tasks	175
	Configuring an EX2200 Virtual Chassis (CLI Procedure)	176
	Configuring an EX2200 Virtual Chassis with a Preprovisioned Configuration File	177
	Configuring an EX2200 Virtual Chassis with a Nonprovisioned Configuration File	179
	Configuring an EX3300 Virtual Chassis (CLI Procedure)	181
	Configuring an EX3300 Virtual Chassis with a Preprovisioned Configuration File	181
	Configuring an EX3300 Virtual Chassis with a Nonprovisioned Configuration File	183
	Configuring an EX4200, EX4500, or EX4550 Virtual Chassis (CLI Procedure)	184
	Configuring an EX4200, EX4500, or EX4550 Virtual Chassis with a Preprovisioned Configuration File	185
	Configuring an EX4200, an EX4500, or EX4550 Virtual Chassis with a Nonprovisioned Configuration File	187
	Configuring a Virtual Chassis on an EX Series Switch (J-Web Procedure)	189
	Configuring an EX2200, EX2200-C, EX3300, EX4200, EX4300, EX4500, EX4550, or EX4600 Virtual Chassis (J-Web Procedure)	189
	Enabling Virtual Chassis Mode on an EX8200 Switch (J-Web Procedure)	191
	Configuring an EX8200 Virtual Chassis (J-Web Procedure)	191
	Preprovision the Virtual Chassis	192
	Configure Virtual Chassis Members	192
	Configure Virtual Chassis Ports	193
	Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches (CLI Procedure)	195
	Installing Software on a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Switches (CLI Procedure)	198
	Adding a New Switch to an Existing EX3300 Virtual Chassis (CLI Procedure)	200
	Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis (CLI Procedure)	201
	Adding a New Switch to an Existing Virtual Chassis Within the Same Wiring Closet	202
	Adding a New Switch from a Different Wiring Closet to an Existing Virtual Chassis	203

Adding a New Switch to an Existing Preprovisioned Virtual Chassis Using Autoprovisioning and Automatic VCP Conversion	205
Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis (CLI Procedure)	207
Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis (CLI Procedure)	209
Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis (CLI Procedure)	211
Removing or Replacing a Member Switch of a Virtual Chassis Configuration	213
Remove a Member Switch and Make Its Member ID Available for Reassignment to a Different Switch	214
Remove, Repair, and Reinstall the Same Switch	215
Remove a Member Switch, Replace It with a Different Switch, and Reapply the Old Configuration	216
Removing an EX4200, EX4500, or EX4550 Switch From a Mixed Virtual Chassis (CLI Procedure)	219
Configuring Mastership of a Virtual Chassis	220
Configuring Mastership Using a Preprovisioned Configuration File	221
Configuring Mastership Using a Configuration File That Is Not Preprovisioned	221
Setting a Port on an EX2200 Switch as a Virtual Chassis Port (CLI Procedure)	222
Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port	223
Setting an Uplink VCP Between the Member Switches in a Virtual Chassis	226
Setting an Uplink VCP on a Standalone Switch	227
Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch (CLI Procedure)	229
Setting an Uplink Port as a Virtual Chassis Port Using the LCD Panel	230
Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis (CLI Procedure)	231
Configuring the Timer for the Backup Member to Start Using Its Own MAC Address, as Master of a Virtual Chassis	232
Configuring Fast Failover in an EX Series Virtual Chassis	233
Disabling Fast Failover in an EX Series Virtual Chassis	234
Disabling Split and Merge in a Virtual Chassis	235
Configuring Automatic Software Update on Virtual Chassis Member Switches	235
Upgrading Software Using Nonstop Software Upgrade on EX Series Virtual Chassis and Mixed Virtual Chassis (CLI Procedure)	237
Preparing the Switch for Software Installation	238
Upgrading the Software Using NSSU	239
Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge	241
Configuring Graceful Routing Engine Switchover in a Virtual Chassis	242
Resetting the EX4500 Switch to Run as a Standalone Switch (CLI Procedure)	243

	Enabling VLAN Pruning for Broadcast, Multicast, and Unknown Unicast Traffic in an EX Series Virtual Chassis (CLI Procedure)	244
Chapter 4	Configuration Statements	245
	auto-conversion	246
	auto-sw-update	248
	fast-failover	251
	graceful-restart (Enabling Globally)	252
	graceful-switchover	253
	id	254
	lag-hash	255
	location (Virtual Chassis)	256
	mac-persistence-timer	257
	mastership-priority	258
	member	259
	no-management-vlan	260
	no-split-detection	261
	package-name	262
	preprovisioned	263
	redundancy (Graceful Switchover)	264
	role	265
	serial-number	268
	traceoptions (Virtual Chassis)	269
	vc-port	272
	vcp-snmp-statistics	273
	virtual-chassis	274
Part 3	Administration	
Chapter 5	Routine Monitoring	279
	Command Forwarding Usage with EX Series and QFX Series Virtual Chassis	279
	Verifying the Member ID, Role, and Neighbor Member Connections of a Virtual Chassis Member	284
	Verifying That Virtual Chassis Ports Are Operational	285
	Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis	287
	Verifying That Graceful Routing Engine Switchover Is Working in the Virtual Chassis	289
	Verifying the Setting for the PIC Mode on an EX4500 Switch in a Virtual Chassis	290
	Verifying the Setting for the Virtual Chassis Mode on EX4200, EX4500, and EX4550 Switches	291
	Verifying Connectivity Between Virtual Chassis Member Devices	291
Chapter 6	Operational Commands	293
	clear virtual-chassis vc-port statistics	294
	request chassis pic-mode	296
	request session member	298
	request system software nonstop-upgrade	299
	request virtual-chassis device-reachability	309

request virtual-chassis mode	312
request virtual-chassis recycle	316
request virtual-chassis renumber	317
request virtual-chassis vc-port (Dedicated VCP)	318
request virtual-chassis vc-port	320
show chassis nonstop-upgrade	322
show chassis pic-mode	324
show system uptime	326
show virtual-chassis active-topology	332
show virtual-chassis device-topology	337
show virtual-chassis protocol adjacency	344
show virtual-chassis protocol database	348
show virtual-chassis protocol interface	352
show virtual-chassis protocol route	355
show virtual-chassis protocol statistics	358
show virtual-chassis fast-failover	362
show virtual-chassis login	363
show virtual-chassis mode	364
show virtual-chassis	367
show virtual-chassis vc-path	373
show virtual-chassis vc-port	377
show virtual-chassis vc-port statistics	382

Part 4

Chapter 7

Troubleshooting

Troubleshooting Procedures	391
Troubleshooting an EX Series Virtual Chassis	391
A Disconnected Member Switch's ID Is Not Available for Reassignment	391
Load Factory Default Does Not Commit on a Multimember Virtual Chassis	391
The Member ID Persists When a Member Switch Is Disconnected From a Virtual Chassis	392
A Member Switch Is Not Participating in a Mixed Virtual Chassis	392
Unknown Traffic Looping Occurs After Configuring an Uplink Port as a Redundant VCP with a Dedicated VCP	394

List of Figures

Part 1	Overview	
Chapter 1	Virtual Chassis Overview	3
	Figure 1: Console Session Redirection (EX4200 Virtual Chassis Pictured)	39
	Figure 2: Management Ethernet Port Redirection to the VME Interface	40
	Figure 3: Normal Traffic Flow in a Ring Topology Using Dedicated VCPs	45
	Figure 4: Traffic Redirected by Fast Failover After a Dedicated VCP Link Failure	46
	Figure 5: Normal Traffic Flow in a Ring Topology Using SFP Uplink VCPs	47
	Figure 6: Traffic Redirected by Fast Failover After SFP Uplink VCP Link Failure	48
	Figure 7: Traffic Redirected by Fast Failover After VCP Link Failures in a Topology with Multiple Rings	49
Part 2	Configuration	
Chapter 2	Configuration Examples	67
	Figure 8: Basic EX4200 Virtual Chassis with Master and Backup	78
	Figure 9: Basic EX4500 Virtual Chassis with Master and Backup	84
	Figure 10: Expanded EX4200 Virtual Chassis in a Single Wiring Closet	94
	Figure 11: Mixed EX4200 and EX4500 Virtual Chassis Topology (Preprovisioned Configuration)	100
	Figure 12: Mixed EX4200 and EX4500 Virtual Chassis Topology (Nonprovisioned Configuration)	104
	Figure 13: Default Configuration of a Multimember EX4200 Virtual Chassis in a Single Wiring Closet	109
	Figure 14: EX4200 Virtual Chassis Interconnected Across Wiring Closets	116
	Figure 15: Mixed EX4200 and EX4500 Virtual Chassis Interconnected Across Wiring Closets	123
	Figure 16: Maximum Size EX4200 Virtual Chassis Interconnected Across Wiring Closets	133
	Figure 17: Topology for LAGs Connecting an EX4200 Virtual Chassis Access Switch to an EX4200 Virtual Chassis Distribution Switch	146
	Figure 18: Traffic Redirected by Fast Failover After VCP Link Failures in a Topology with Multiple Rings	157
	Figure 19: EX4200 Virtual Chassis Interconnected Across Wiring Closets to Form LAGs	164

List of Tables

	About the Documentation	xv
	Table 1: Notice Icons	xvii
	Table 2: Text and Syntax Conventions	xviii
Part 1	Overview	
Chapter 1	Virtual Chassis Overview	3
	Table 3: Minimum Junos OS Release by Virtual Chassis Connection Type	10
	Table 4: Maximum Member Switch Support for Virtual Chassis by Junos OS Release	17
	Table 5: VCP Options by Switch Type	21
	Table 6: Virtual Chassis Summary	31
	Table 7: Platform and Release Support for NSSU	60
	Table 8: Effects of a Routing Engine Switchover	64
Part 2	Configuration	
Chapter 2	Configuration Examples	67
	Table 9: Components of the Basic Virtual Chassis Access Switch Topology	69
	Table 10: Components of the Basic Virtual Chassis Access Switch Topology	73
	Table 11: Components of the Basic Virtual Chassis Access Switch Topology	78
	Table 12: Components of the Basic Virtual Chassis Access Switch Topology	84
	Table 13: Components of the Expanded Virtual Chassis Access Switch	88
	Table 14: Components of the Expanded Virtual Chassis Access Switch	93
	Table 15: Components of the EX4200 Virtual Chassis Before the EX4500 Member Switches Are Added	99
	Table 16: Final Mixed EX4200 and EX4500 Virtual Chassis Components	99
	Table 17: Components of the EX4200 Virtual Chassis Before the EX4500 Member Switches Are Added	103
	Table 18: Final Mixed EX4200 and EX4500 Virtual Chassis Components	104
	Table 19: Components of a Virtual Chassis Interconnected Across Multiple Wiring Closets	115
	Table 20: Components of a Virtual Chassis Interconnected Across Wiring Closets	123
	Table 21: Components of a Preprovisioned EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets	131
	Table 22: Components of a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis	141
	Table 23: Components of the Topology for Connecting a Virtual Chassis Access Switch to a Virtual Chassis Distribution Switch	146
Chapter 3	Configuration Tasks	175

	Table 24: Virtual Chassis Configuration Fields	191
Part 3	Administration	
Chapter 5	Routine Monitoring	279
	Table 25: Commands That Can be Run on All or Specific Members of the Virtual Chassis Configuration	280
Chapter 6	Operational Commands	293
	Table 26: request virtual chassis device reachability Output Fields	310
	Table 27: show chassis nonstop-upgrade Output Fields	322
	Table 28: show system uptime Output Fields	329
	Table 29: show virtual-chassis active-topology Output Fields	332
	Table 30: show virtual-chassis device-topology Output Fields	337
	Table 31: show virtual-chassis protocol adjacency Output Fields	345
	Table 32: show virtual-chassis protocol database Output Fields	349
	Table 33: show virtual-chassis protocol interface Output Fields	353
	Table 34: show virtual-chassis protocol route Output Fields	355
	Table 35: show virtual-chassis protocol statistics Output Fields	358
	Table 36: show virtual-chassis fast-failover Output Fields	362
	Table 37: show virtual-chassis mode Output Fields	364
	Table 38: show virtual-chassis Output Fields	368
	Table 39: show virtual-chassis vc-path Output Fields	374
	Table 40: show virtual-chassis vc-port Output Fields	377
	Table 41: show virtual-chassis vc-port statistics Output Fields	383

About the Documentation

- Documentation and Release Notes on page xv
- Using the Examples in This Manual on page xv
- Documentation Conventions on page xvii
- Documentation Feedback on page xix
- Requesting Technical Support on page xix

Documentation and Release Notes

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <https://www.juniper.net/documentation/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <https://www.juniper.net/books>.

Using the Examples in This Manual

If you want to use the examples in this manual, you can use the **load merge** or the **load merge relative** command. These commands cause the software to merge the incoming configuration into the current candidate configuration. The example does not become active until you commit the candidate configuration.

If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the **load merge** command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the **load merge relative** command. These procedures are described in the following sections.

Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file **ex-script.conf**. Copy the **ex-script.conf** file to the **/var/tmp** directory on your routing platform.

```
system {
  scripts {
    commit {
      file ex-script.xml;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}
```

2. Merge the contents of the file into your routing platform configuration by issuing the **load merge** configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete
```

Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file **ex-script-snippet.conf**. Copy the **ex-script-snippet.conf** file to the **/var/tmp** directory on your routing platform.

```
commit {
  file ex-script-snippet.xml; }
```


2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]
```

3. Merge the contents of the file into your routing platform configuration by issuing the **load merge relative** configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete
```

For more information about the **load** command, see [CLI Explorer](#).

Documentation Conventions

Table 1 on page xvii defines notice icons used in this guide.

Table 1: Notice Icons







Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 2 on page xviii defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: user@host> configure
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> show chassis alarms No alarms currently active
<i>Italic text like this</i>	<ul style="list-style-type: none"> Introduces or emphasizes important new terms. Identifies guide names. Identifies RFC and Internet draft titles. 	<ul style="list-style-type: none"> A policy <i>term</i> is a named structure that defines match conditions and actions. <i>Junos OS CLI User Guide</i> RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i>
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> To configure a stub area, include the stub statement at the [edit protocols ospf area area-id] hierarchy level. The console port is labeled CONSOLE.
< > (angle brackets)	Encloses optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Encloses a variable for which you can substitute one or more values.	community name members [community-ids]
Indentation and braces ({ })	Identifies a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	}

GUI Conventions

Table 2: Text and Syntax Conventions (continued)

Convention	Description	Examples
Bold text like this	Represents graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> In the Logical Interfaces box, select All Interfaces. To cancel the configuration, click Cancel.
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select Protocols>Ospf .

Documentation Feedback

We encourage you to provide feedback so that we can improve our documentation. You can use either of the following methods:

- Online feedback system—Click TechLibrary Feedback, on the lower right of any page on the [Juniper Networks TechLibrary](#) site, and do one of the following:



- Click the thumbs-up icon if the information on the page was helpful to you.
- Click the thumbs-down icon if the information on the page was not helpful to you or if you have suggestions for improvement, and use the pop-up form to provide feedback.
- E-mail—Send your comments to techpubs-comments@juniper.net. Include the document or topic name, URL or page number, and software version (if applicable).

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active Juniper Care or Partner Support Services support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <https://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <https://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <https://www.juniper.net/customers/support/>
- Search for known bugs: <https://prsearch.juniper.net/>
- Find product documentation: <https://www.juniper.net/documentation/>
- Find solutions and answer questions using our Knowledge Base: <https://kb.juniper.net/>
- Download the latest versions of software and review release notes: <https://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://kb.juniper.net/InfoCenter/>
- Join and participate in the Juniper Networks Community Forum: <https://www.juniper.net/company/communities/>
- Create a service request online: <https://myjuniper.juniper.net>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://entitlementsearch.juniper.net/entitlementsearch/>

Creating a Service Request with JTAC

You can create a service request with JTAC on the Web or by telephone.

- Visit <https://myjuniper.juniper.net>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <https://support.juniper.net/support/requesting-support/>.

PART 1

Overview

- [Virtual Chassis Overview on page 3](#)

CHAPTER 1

Virtual Chassis Overview

- [Virtual Chassis Overview for Switches on page 3](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding Virtual Chassis Components on page 16](#)
- [Understanding Mixed EX Series and QFX Series Virtual Chassis on page 29](#)
- [Understanding How the Master in a Virtual Chassis Is Elected on page 36](#)
- [Understanding Software Upgrades in a Virtual Chassis on page 37](#)
- [Understanding Global Management of a Virtual Chassis on page 38](#)
- [Understanding the High-Speed Interconnection of the Dedicated Virtual Chassis Ports Connecting EX4200, EX4500, and EX4550 Member Switches on page 41](#)
- [Understanding Virtual Chassis Port Link Aggregation on page 41](#)
- [Understanding Fast Failover in an EX Series Virtual Chassis on page 43](#)
- [Understanding Split and Merge in a Virtual Chassis on page 50](#)
- [Understanding Automatic Software Update on Virtual Chassis Member Switches on page 53](#)
- [Understanding Nonstop Software Upgrade on EX Series Switches on page 54](#)
- [Understanding Virtual Chassis Device Reachability Testing on page 62](#)
- [Understanding MAC Address Assignment on a Virtual Chassis on page 62](#)
- [Understanding High Availability on an EX Series Virtual Chassis on page 63](#)

Virtual Chassis Overview for Switches

Many Juniper Networks EX Series and QFX Series switches support Virtual Chassis, a flexible and scalable technology with which you can connect individual switches together to form one unit, and configure and manage the unit as a single chassis. Virtual Chassis ports (VCPs) connect member switches together to form a Virtual Chassis, and are responsible for passing all data and control traffic between member switches.

The following feature guides describe Virtual Chassis on different EX Series or QFX Series switches:

- *Virtual Chassis Feature Guide for EX2200, EX3300, EX4200, EX4500 and EX4550 Switches* covers configuring and maintaining EX2200, EX3300, EX4200, EX4500, and EX4550 Virtual Chassis.
- *Virtual Chassis Feature Guide for EX8200 Switches* describes configuring and maintaining EX8200 Virtual Chassis.
- For deployments with EX9200 switches, you should plan or move to MC-LAG or Junos Fusion Enterprise architectures rather than using a Virtual Chassis. We do not recommend using EX9200 switches in a Virtual Chassis. If needed to aid in migration away from EX9200 Virtual Chassis, see *Virtual Chassis Feature Guide for EX9200 Switches*.
- *Virtual Chassis Feature Guide for Switches* describes configuring and maintaining *all other* EX Series and QFX Series Virtual Chassis.



NOTE: Virtual Chassis Fabric (VCF) is an evolution of Virtual Chassis technology. VCF configurations share some elements of Virtual Chassis technology, including configuration statements and administrative commands, but use a spine-and-leaf topology with supported QFX Series switches as spine devices and supported EX Series and QFX Series switches as leaf devices. For details on configuring and maintaining a VCF, see the *Virtual Chassis Fabric Feature Guide*.

- [Benefits of Virtual Chassis on Switches on page 4](#)
- [Virtual Chassis Basics on Switches on page 5](#)
- [Global Management of Member Switches in a Virtual Chassis on page 7](#)
- [High Availability Using Redundancy on page 8](#)
- [Adaptability as an Access Switch or Distribution Switch on page 8](#)

Benefits of Virtual Chassis on Switches

- Simplifies configuration and maintenance: Multiple devices can be managed as a single device with the same or similar capabilities as the standalone device.
- Increases fault tolerance and high availability (HA): A Virtual Chassis can remain active and network traffic can be redirected to other member switches when a single member switch fails.
- Flattens your network and reduces networking overhead by allowing network devices to synchronize to one resilient logical device rather than to multiple physical devices.
- Enables a simplified Layer 2 network topology that minimizes or eliminates the need for loop prevention protocols such as Spanning Tree Protocol (STP).
- Provides a flexible model for expanding your network: You can easily add Virtual Chassis member switches to increase the number of access ports on your network to support

more servers, computers, phones, or other devices with minimal complications to the existing network topology and switch configuration.

Virtual Chassis Basics on Switches

Virtual Chassis is a feature on Juniper Networks routing or switching devices that provides network resiliency in the form of redundant Routing Engines and network expansion flexibility with minimal impact to a configuration.

Virtual Chassis technology on switches enables you to interconnect supported combinations of EX Series and QFX Series switches into one logical device that you can configure and manage as a single unit. Switches interconnected into a Virtual Chassis are called Virtual Chassis member switches, identified by a member ID within the Virtual Chassis.

Virtual Chassis member switches are interconnected and communicate with each other using Virtual Chassis ports (VCPs).

- [Connecting Member Switches with Virtual Chassis Ports on page 5](#)
- [Virtual Chassis Configuration on page 6](#)
- [Configuring Interfaces for a Virtual Chassis on page 6](#)
- [Mixed and Non-mixed EX Series and QFX Series Virtual Chassis on page 6](#)
- [Virtual Chassis Member Switch Roles on page 7](#)

Connecting Member Switches with Virtual Chassis Ports

A switch is not recognized by the Virtual Chassis as a member switch until it is interconnected with the master or interconnected with an existing member of the Virtual Chassis using VCPs. EX Series and QFX Series switches that can be in a Virtual Chassis might support one or more of the following VCP options:

- Network or uplink ports that support the option to be configured as VCPs. Most switches support this VCP option.
- Ports that are configured as VCPs in the default factory settings. These ports can also be converted into and used as network ports instead of as VCPs, and converted back into VCPs again if needed.
- Dedicated VCPs, which are ports that can only function as VCPs. Only a few switches have dedicated VCPs.

Available VCP options vary among the different switch models. See “[Virtual Chassis Port Options](#)” on page 20 for a summary of the ports that are supported as VCPs on different switches.

When a port is set as a VCP, it cannot be used for any other purpose. If you want to use the port for another purpose, you must delete the VCP setting using the **request virtual-chassis vc-port** command. You can run this command directly on the member whose uplink VCP setting you want to delete or through the master member of the Virtual Chassis configuration.



CAUTION: Deleting a VCP in a Virtual Chassis configuration can cause the Virtual Chassis configuration to split. For more information, see [“Understanding Split and Merge in a Virtual Chassis” on page 50](#).

If redundant VCP links of the same speed are connected between the same two member switches of a Virtual Chassis, the ports automatically form a VCP Link Aggregation Group (LAG) or bundle that distributes the inter-member VCP traffic load among them. See [“Understanding Virtual Chassis Port Link Aggregation” on page 41](#) for details.

Virtual Chassis Configuration

You configure and manage nearly all aspects of an EX Series or QFX Series Virtual Chassis through the master switch of the Virtual Chassis. However, you can also configure Virtual Chassis parameters when a switch is a standalone switch not interconnected with other members yet, because any switch that supports being in a Virtual Chassis is by default a single-member Virtual Chassis with member ID 0. Upon connecting the switch with others in a Virtual Chassis, any Virtual Chassis configuration statements and uplink Virtual Chassis port (VCP) settings previously configured on the standalone switch remain part of its configuration.

You can set up an EX Series or QFX Series Virtual Chassis using a nonprovisioned or preprovisioned configuration. If you want to deterministically control the roles and member IDs assigned to the member switches when creating and managing a Virtual Chassis, use a preprovisioned configuration, which distinguishes member switches by associating their serial numbers with the member ID.

When adding new member switches to a preprovisioned Virtual Chassis, you might be able to simplify the procedure by using the autoprovisioning feature, which automatically converts the interconnecting links into VCPs when cabling the new switch into the Virtual Chassis under certain conditions and configuration settings. See [“Automatic Virtual Chassis Port \(VCP\) Conversion” on page 22](#) for details.

Configuring Interfaces for a Virtual Chassis

The member ID of an EX Series or QFX Series Virtual Chassis member switch functions as an FPC slot number. When you are configuring interfaces for a Virtual Chassis configuration, you specify the appropriate member ID as the *slot* element of the interface name.

The default factory settings for a Virtual Chassis configuration include FPC 0 as a member of the default VLAN because FPC 0 is configured as part of the **ethernet-switching** family. To include the FPC in the default VLAN, add the **ethernet-switching** family to the configurations for those interfaces.

Mixed and Non-mixed EX Series and QFX Series Virtual Chassis

A Virtual Chassis might consist of all the same type of switches or different types of switches in supported combinations.

Some combinations of switches in a Virtual Chassis comprise a *mixed Virtual Chassis*, which contains member switches that have operational differences requiring the Virtual

Chassis to be configured with a mixed mode setting that enables all of the member switches to inter-operate successfully.

Some combinations of different types or models of switches can inter-operate in a Virtual Chassis without requiring the Virtual Chassis to be configured in mixed mode, such as different switches that can run the same Junos OS software image.

See [“Understanding Mixed EX Series and QFX Series Virtual Chassis” on page 29](#) for details on the different combinations of switches supported in a Virtual Chassis.

Virtual Chassis Member Switch Roles

Member switches in an EX Series or QFX Series Virtual Chassis operate in either a *master* Routing Engine role, *backup* Routing Engine role, or *linecard* role. For some mixed Virtual Chassis, the member switches in the Routing Engine role are recommended (and in some cases required) to be particular types or models of switches. Any switch supported in a Virtual Chassis can operate in the linecard role.

A standalone switch that supports Virtual Chassis is by default a single-member Virtual Chassis that is assigned member ID 0 and operates in the master Routing Engine role as the master of itself. When connected and configured into a Virtual Chassis with other member switches, the switch will be assigned a unique member ID and might take on a different role.

A nonprovisioned Virtual Chassis uses a mastership election algorithm to select the member switches that assume the master and backup roles if an existing member switch in the Routing Engine role fails or when new member switches are added. In a preprovisioned Virtual Chassis, you assign the roles to each member switch when forming the Virtual Chassis and adding or replacing member switches.

See the following for details on EX Series and QFX Series Virtual Chassis member switch roles:

- [Understanding Virtual Chassis Components on page 16](#)
- [Understanding How the Master in a Virtual Chassis Is Elected on page 36](#)

Global Management of Member Switches in a Virtual Chassis

The interconnected member switches in a Virtual Chassis operate and can be configured as a single network entity.

The serial console port and dedicated out-of-band management port on individual switches have global virtual counterparts when the switches are interconnected in a Virtual Chassis configuration. You can connect to the master switch by connecting a terminal directly to the console port of any member switch. A *virtual management Ethernet (VME)* interface allows you to remotely manage the Virtual Chassis configuration by connecting to the out-of-band management port of any member switch through a single IP address. You can perform remote configuration and administration of all member switches of the Virtual Chassis configuration using the Junos CLI through the VME interface. See [“Understanding Global Management of a Virtual Chassis” on page 38](#) for details.

When setting up a Virtual Chassis on EX Series switches that support the EZSetup script, you can run EZSetup once to specify the identification parameters for the master, and these parameters implicitly apply to all member switches of the Virtual Chassis.

On switches that support the J-Web user interface, you can view the Virtual Chassis as a single device in J-Web and apply various device management functions to all member switches of the Virtual Chassis.

High Availability Using Redundancy

Interconnecting EX Series or QFX Series switches into a Virtual Chassis increases your network's high availability. A Virtual Chassis is more fault tolerant than a standalone switch because it can remain active, forward traffic and provide sub-second convergence in the case of a device or link failure.

Standalone switches that support only a single Routing Engine can operate with a master and a backup Routing Engine when configured into a Virtual Chassis, and therefore support some high availability features that would otherwise not be available on the switch, such as Graceful Routing Engine Switchover (GRES) for hitless failover.

You can also increase fault tolerance within a Virtual Chassis by configuring other supported high availability features. For example, configuring Link Aggregation Group (LAG) bundles that include member links on different switches in the same Virtual Chassis enables traffic traversing the LAG to be redirected from a Virtual Chassis member switch that fails to links on another active Virtual Chassis member switch.

Adaptability as an Access Switch or Distribution Switch

A Virtual Chassis configuration supports a variety of user environments because it can be composed of different types of switches. You can select different switch models to support various functions. For example, you might set up one Virtual Chassis access switch configuration composed of full Power over Ethernet (PoE) models to support users sitting in cubicles equipped with PCs and Voice over IP (VoIP) phones. You could set up another Virtual Chassis configuration with partial PoE models to support the company's internal servers, and another to support the company's external servers. You can alternatively use a Virtual Chassis in a topology as a distribution switch.

Related Documentation

- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding QFX Series Virtual Chassis](#)
- [Understanding Virtual Chassis Components on page 16](#)
- [Understanding Global Management of a Virtual Chassis on page 38](#)
- [Understanding How the Master in a Virtual Chassis Is Elected on page 36](#)
- [Understanding High Availability on an EX Series Virtual Chassis on page 63](#)

Understanding EX Series Virtual Chassis

This topic introduces EX Series Virtual Chassis. An EX Series Virtual Chassis is a supported combination of interconnected EX2200, EX2300, EX3300, EX3400, EX4200, EX4500,

EX4550, EX4300, or EX4600 switches operating as one logical device and managed as a single chassis. Switches in a Virtual Chassis are called *member switches*.

For information on EX8200 Virtual Chassis, see *Virtual Chassis Feature Guide for EX8200 Switches*.

- [Virtual Chassis Support on EX Series Switches on page 9](#)
- [Basic Configuration of EX Series Virtual Chassis on page 11](#)
- [EX2200 Switches in a Virtual Chassis on page 12](#)
- [EX2300 Switches in a Virtual Chassis on page 12](#)
- [EX3300 Switches in a Virtual Chassis on page 13](#)
- [EX3400 Switches in a Virtual Chassis on page 13](#)
- [EX4200, EX4500, and EX4550 Switches in a Virtual Chassis on page 14](#)
- [EX4300 Switches in a Virtual Chassis on page 14](#)
- [EX4600 Switches in a Virtual Chassis on page 15](#)

Virtual Chassis Support on EX Series Switches

In an EX Series Virtual Chassis, you can interconnect standalone switches in the following combinations into one logical device, and manage the logical device as a single chassis:

- EX2200 Virtual Chassis, composed of up to four EX2200 switches.
- EX2300 Virtual Chassis, composed of up to four EX2300 switches or up to four EX2300 multigigabit model switches (EX2300-24MP, EX2300-48MP). Starting in Junos OS Release 18.4R1, EX2300 multigigabit model switches can also be combined with other EX2300 switches in the same Virtual Chassis, which operates as a non-mixed Virtual Chassis.
- EX3300 Virtual Chassis, composed of up to ten EX3300 switches.
- EX3400 Virtual Chassis, composed of up to ten EX3400 switches.
- EX4200 Virtual Chassis, composed of up to ten EX4200 switches.
- EX4300 Virtual Chassis, composed of up to ten EX4300 switches, including multigigabit models (EX4300-48MP). An EX4300 Virtual Chassis operates as a non-mixed Virtual Chassis if it is composed of only EX4300 multigigabit model switches, or composed of any combination of any other EX4300 switches excluding the multigigabit models. An EX4300 Virtual Chassis operates as a mixed EX4300 Virtual Chassis if it is composed of EX4300 multigigabit model (EX4300-48MP) switches mixed with any other EX4300 model switches.
- EX4500 Virtual Chassis, composed of up to ten EX4500 switches
- EX4550 Virtual Chassis, composed of up to ten EX4550 switches
- EX4600 Virtual Chassis, composed of up to ten EX4600 switches.
- Mixed EX4200 and EX4500 Virtual Chassis, composed of up to ten total EX4200 and EX4500 switches

- Mixed EX4200 and EX4550 Virtual Chassis, composed of up to ten total EX4200 and EX4550 switches
- Mixed EX4200, EX4500, and EX4550 Virtual Chassis, composed of up to ten total EX4200, EX4500, and EX4550 switches
- Mixed EX4300 and EX4600 Virtual Chassis, composed of up to ten total EX4300 (excluding multigigabit models) and EX4600 switches. The member switches in the master and backup Routing Engine roles must be EX4600 switches.
- Mixed EX4500 and EX4550 Virtual Chassis, composed of up to ten total EX4500 and EX4550 switches

Table 3 on page 10 lists the initial Junos OS release that supports each EX Series Virtual Chassis combination. “N/A” indicates the combination is *not supported*. Switches must be running the same version of Junos OS software to join a Virtual Chassis, although the images might be different on different types of switches when mixed hardware models are supported together in a Virtual Chassis.

Table 3: Minimum Junos OS Release by Virtual Chassis Connection Type

Switch	EX2200 Switch	EX2300 Switch	EX3300 Switch	EX3400 Switch	EX4200 Switch	EX4300 Switch	EX4500 Switch	EX4550 Switch	EX4600 Switch
EX2200	12.2R1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
EX2300	N/A	15.1X53-D50, 18.1R2 (MP models), 18.4R1 (MP and other models)	N/A	N/A	N/A	N/A	N/A	N/A	N/A
EX3300	N/A	N/A	11.3R1	N/A	N/A	N/A	N/A	N/A	N/A
EX3400	N/A	N/A	N/A	15.1X53-D50	N/A	N/A	N/A	N/A	N/A
EX4200	N/A	N/A	N/A	N/A	9.0R1	N/A	11.1R1	12.2R1	N/A
EX4300	N/A	N/A	N/A	N/A	N/A	13.2X50-D10, or 18.2R1 for MP models	N/A	N/A	13.2X51-D25, excludes EX4300 MP models
EX4500	N/A	N/A	N/A	N/A	11.1R1	N/A	11.1R1	12.2R1	N/A
EX4550	N/A	N/A	N/A	N/A	12.2R1	N/A	12.2R1	12.2R1	N/A

Table 3: Minimum Junos OS Release by Virtual Chassis Connection Type (continued)

Switch	EX2200 Switch	EX2300 Switch	EX3300 Switch	EX3400 Switch	EX4200 Switch	EX4300 Switch	EX4500 Switch	EX4550 Switch	EX4600 Switch
EX4600	N/A	N/A	N/A	N/A	N/A	13.2X51-D25, excludes EX4300 MP models	N/A	N/A	13.2X51-D25

Basic Configuration of EX Series Virtual Chassis

Some EX Series switches can only form a Virtual Chassis with the same type of switches, while some can be interconnected with other types of switches into a mixed-mode Virtual Chassis. See [“Understanding Mixed EX Series and QFX Series Virtual Chassis” on page 29](#) for details on the different types of switches that can be mixed in a Virtual Chassis.

You set up an EX Series Virtual Chassis by configuring Virtual Chassis ports (VCPs) on the member switches, and interconnecting the switches using the VCPs. VCPs are responsible for passing all data and control traffic between member switches in the Virtual Chassis. EX Series switches have one or more the following VCP options:

- Network or uplink ports that can be configured into VCPs.
- Default-configured VCPs, which are configured as VCPs in the default factory configuration, but can alternatively be converted into network or uplink ports if desired and reconverted back into VCPs if needed.
- Dedicated VCPs, which can only be used as VCPs.

See [“Virtual Chassis Port Options” on page 20](#) for details on which ports on different EX Series switches can be VCPs.

You can increase the VCP bandwidth between any two member switches by connecting multiple VCP links between the switches. When multiple VCP links interconnect the same two member switches, a Link Aggregation Group (LAG) bundle is formed if the links have the same speeds. For example, if you have four 40-Gbps links configured as VCPs between two member switches, a LAG with four member links at 160 Gbps of bandwidth is formed. Similarly, connecting two 10-Gbps links configured as VCPs between two member switches forms a LAG with 2 member links at 20 Gbps total bandwidth. However, 10-Gbps and 40-Gbps links configured as VCPs between two Virtual Chassis member switches cannot be member links of the same VCP LAG.

Within a single wiring closet, you can add a new member switch to a Virtual Chassis by cabling the member switch into the Virtual Chassis using supported VCP links. You can also easily expand a Virtual Chassis configuration beyond a single wiring closet or over a longer distance by connecting member switches together using uplink ports that are supported as VCPs.

You can set up a Virtual Chassis using either a nonprovisioned or a preprovisioned configuration. If you want to deterministically control the role and member ID assigned

to each member switch, use a preprovisioned configuration. Virtual Chassis member switches can be configured into and operate in one of three roles: master Routing Engine, backup Routing Engine, or linecard role. In some combinations of switches in a Virtual Chassis, certain switches are recommended or required to be in the Routing Engine roles. See [“Understanding Virtual Chassis Components” on page 16](#) for more information about Virtual Chassis roles.

You can simplify adding switches to a preprovisioned configuration by using the automatic VCP conversion feature (see [“Automatic Virtual Chassis Port \(VCP\) Conversion” on page 22](#)), which automatically converts uplink ports into VCPs on the member switches on both sides of the new VCP links as they are cabled. This Virtual Chassis expansion method is also referred to as *autoprovisioning*.

EX2200 Switches in a Virtual Chassis

Up to four EX2200 and EX2200-C switches can be interconnected into an EX2200 Virtual Chassis, and cannot be mixed with any other type of switches in a Virtual Chassis.

You can configure and use any EX2200 1-Gbps optical interfaces as VCPs. All RJ-45 interfaces, including built-in network ports with 10/100/1000BASE-T Gigabit Ethernet connectors and 1000BASE-T RJ-45 transceivers, can also be configured into VCPs. You can configure up to eight 1-Gbps interfaces configured as VCPs into a single Link Aggregation Group (LAG) bundle, so in an EX2200 Virtual Chassis, you can have a VCP LAG with a bandwidth of up to 8 Gbps.

EX2200 Virtual Chassis do not support other high availability features such as Graceful Routing Engine switchover (GRES), Nonstop bridging (NSB), Nonstop active routing (NSR), fast failover, and Nonstop software upgrade (NSSU).

An EX2200 Virtual Chassis is configured and managed similarly to other EX Series Virtual Chassis. See the following for details on configuring a Virtual Chassis with EX2200 switches:

- [Configuring an EX2200 Virtual Chassis \(CLI Procedure\) on page 176](#)

EX2300 Switches in a Virtual Chassis

You can connect up to four EX2300 switches into a Virtual Chassis. EX2300 switches cannot be combined into a mixed Virtual Chassis with other EX Series or QFX Series switches, but can be interconnected into a non-mixed Virtual Chassis as follows:

- Any combination of up to four EX2300 and EX2300-C switches.
- Any combination of up to four EX2300 multigigabit model (EX2300-24MP and EX2300-48MP) switches.
- (Starting in Junos OS Release 18.4R1) Any combination of up to four EX2300 multigigabit model switches and other EX2300 or EX2300-C model switches. You do not need to set mixed mode.



NOTE: In Junos OS releases prior to 18.4R1, you cannot mix EX2300 multigigabit model switches with other EX2300 or EX2300-C model switches in an EX2300 Virtual Chassis.

EX2300 switches do not have default or dedicated VCP ports, but you can configure the 10-Gbps Ethernet uplink ports as VCPs, and use those to interconnect the switches into a Virtual Chassis.

Interconnect EX2300 switches or EX2300 multigigabit switches into an EX2300 Virtual Chassis by configuring uplink ports as VCPs and using SFP+ transceivers. The uplink ports on EX2300 switches also support SFP transceivers, but you cannot use SFP transceivers on uplink ports to form an EX2300 Virtual Chassis.

In all EX2300 Virtual Chassis, any EX2300 switch model can be configured into any member switch role (master Routing Engine, backup Routing Engine, or linecard).

An EX2300 Virtual Chassis is configured and managed similarly to other EX Series and QFX Series Virtual Chassis. See the following for details on configuring or expanding an EX2300 Virtual Chassis:

- *Configuring an EX2300, EX3400, or EX4300 Virtual Chassis*
- *Adding a New Switch to an Existing EX2300, EX3400, or EX4300 Virtual Chassis*

EX3300 Switches in a Virtual Chassis

Up to ten EX3300 switches can be interconnected into a Virtual Chassis and cannot be mixed with any other type of switches.

Uplink ports 2 and 3 on EX3300 switches are configured as VCPs by default and can be used to interconnect member switches. You can change this default configuration or configure any of the other uplink ports as VCPs.

An EX3300 Virtual Chassis is configured and managed similarly to other EX Series Virtual Chassis. See the following for details on configuring or expanding a Virtual Chassis with EX3300 switches:

- [Configuring an EX3300 Virtual Chassis \(CLI Procedure\) on page 181](#)
- [Adding a New Switch to an Existing EX3300 Virtual Chassis \(CLI Procedure\) on page 200](#)

EX3400 Switches in a Virtual Chassis

You can connect up to ten of any models of EX3400 switches into a Virtual Chassis. EX3400 switches cannot be interconnected into a Virtual Chassis with any other EX Series or QFX Series switches.

By default, the QFSP+ uplink ports on EX3400 switches are configured as VCPs, or you can configure any SFP+ uplink module ports on EX3400 switches as VCPs. Uplink ports with SFP transceivers cannot be used as VCPs to interconnect EX3400 switches into a Virtual Chassis.

An EX3400 Virtual Chassis is configured and managed similarly to other EX Series and QFX Series Virtual Chassis. See the following for details on configuring or expanding an EX3400 Virtual Chassis:

- [*Configuring an EX2300, EX3400, or EX4300 Virtual Chassis*](#)
- [*Adding a New Switch to an Existing EX2300, EX3400, or EX4300 Virtual Chassis*](#)

EX4200, EX4500, and EX4550 Switches in a Virtual Chassis

Up to ten EX4200, EX4500, and EX4550 switches can be interconnected into a Virtual Chassis. You must set the Virtual Chassis to mixed mode if it is composed of EX4200 switches with EX4500 or EX4550 switches, but a Virtual Chassis with only one type of these switches or with only EX4500 and EX4550 switches operates as a non-mixed Virtual Chassis.

EX4200 switches have two built-in dedicated VCPs. EX4500 or EX4550 switches have dedicated VCPs on the Virtual Chassis module, and the EX4500 or EX4550 switch must have the PIC mode set to Virtual Chassis mode to interconnect them into a Virtual Chassis. Any SFP, SFP+, and XFP uplink ports on all of these switches can also be configured into VCPs. You can use the dedicated VCPs when the switches are close together, such as in the same wiring closet. Use uplink ports configured as VCPs for switches that located farther away, such as in different wiring closets.

An EX4200, EX4500, or EX4550 Virtual Chassis is configured and managed similarly to other EX Series Virtual Chassis. See the following for details on configuring a Virtual Chassis with these switches:

- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)

For procedures on adding a new switch to a Virtual Chassis composed of any of these switcheds in a wiring closet, see:

- [Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\) on page 201](#)
- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)
- [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)

EX4300 Switches in a Virtual Chassis

Up to ten EX4300 switches can be connected together to form an EX4300 Virtual Chassis. EX4300 switches can form a Virtual Chassis composed entirely of EX4300 switches

(not multigigabit models) or entirely of EX4300 multigigabit model (EX4300-48MP) switches as a non-mixed Virtual Chassis.

EX4300 multigigabit model switches and other EX4300 model switches can also be connected together into an EX4300 Virtual Chassis if the member switches are configured into mixed mode. In this case, the EX4300 member switches that are not multigigabit models must also be configured with a special option (**ieee-clause-82**) when setting mixed mode. The member switches in the Routing Engine role must be multigigabit model switches, and EX4300 switches that are not multigigabit models can only be configured into linecard role. Multigigabit model EX4300 switches cannot interoperate in a mixed Virtual Chassis with any other types of switches.

EX4300 switches that are not multigigabit models can be included in the linecard role in a mixed Virtual Chassis with EX4600 switches or QFX5100 switches. For more details on EX4300 member switches in a mixed Virtual Chassis, see [“Understanding Mixed EX Series and QFX Series Virtual Chassis” on page 29](#).

EX4300 switches (excluding multigigabit models) can also be included as leaf nodes in a Virtual Chassis Fabric (VCF). For information on EX4300 switches in a VCF, see *Virtual Chassis Fabric Overview*.

On EX4300 switches excluding the multigigabit models, all 40-Gbps QSFP+ optical ports are configured as VCPs by default, and any 10-Gbps uplink module ports can also be configured into VCPs as needed. As a result, an EX4300 Virtual Chassis can have either 40-Gbps or 10-Gbps VCP links, or a combination of both. You can easily add new switches to a Virtual Chassis whether the switch is installed in the same building or at a different site because the ports available to be used as VCPs are long-distance optical ports.

On EX4300 multigigabit models, the four 40-Gbps QSFP+ ports on the rear panel are dedicated VCPs. These are the only ports on EX4300 multigigabit model switches that can be used as VCPs, so any EX4300 Virtual Chassis that contains EX4300 multigigabit model switches can have only have VCP links that are 40 Gbps.

An EX4300 Virtual Chassis is configured and managed similarly to other EX Series and QFX Series Virtual Chassis. See the following for details on configuring and expanding an EX4300 Virtual Chassis:

- *Configuring an EX2300, EX3400, or EX4300 Virtual Chassis*
- *Adding a New Switch to an Existing EX2300, EX3400, or EX4300 Virtual Chassis*

EX4600 Switches in a Virtual Chassis

EX4600 switches can act as member switches in a non-mixed Virtual Chassis—a Virtual Chassis composed entirely of EX4600 switches—and also operate in a mixed Virtual Chassis with EX4300 switches. Any EX4300 switches except multigigabit models (EX4300-48MP) can be interconnected with EX4600 switches as a mixed EX4600 Virtual Chassis.

You can interconnect up to ten EX4600 switches or a combination of up to ten EX4600 and EX4300 switches into an EX4600 Virtual Chassis. However, in a mixed Virtual Chassis with EX4600 and EX4300 switches, EX4600 switches must be in the master and backup

Routing Engine roles; EX4300 member switches cannot be configured into the Routing Engine role. As a result, at least two of the member switches in a mixed EX4600 Virtual Chassis must be EX4600 switches in the master and backup Routing Engine roles. See [“Understanding Virtual Chassis Components” on page 16](#) for more information about Virtual Chassis member roles.

EX4600 switches do not have any ports that are configured into VCPs by default, but all 40-Gbps QSFP+ and 10-Gbps SFP+ optical ports on an EX4600 switch can be configured into VCPs. Because EX4300 switches support similar VCP options, both non-mixed and mixed EX4600 Virtual Chassis can have 40-Gbps VCP links, 10-Gbps VCP links, or a combination of both.

An EX4600 Virtual Chassis is configured, monitored, and maintained similarly to other EX and QFX Series Virtual Chassis. See the following for more details on configuring and expanding an EX4600 Virtual Chassis, including a mixed EX4600 Virtual Chassis with EX4300 switches:

- *Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis*
- *Adding an EX4600 Switch to a Mixed or Non-mixed Virtual Chassis*

Release History Table

Release	Description
18.4R1	Starting in Junos OS Release 18.4R1, EX2300 multigigabit model switches can also be combined with other EX2300 switches in the same Virtual Chassis, which operates as a non-mixed Virtual Chassis.

Related Documentation

- [Virtual Chassis Overview for Switches on page 3](#)
- [Understanding Virtual Chassis Components on page 16](#)
- [Understanding Virtual Chassis Port Link Aggregation on page 41](#)

Understanding Virtual Chassis Components

This topic describes the components of an EX series or a QFX Series Virtual Chassis.

- An EX Series Virtual Chassis is a supported combination of standalone EX Series switches interconnected and managed as a single chassis. This topic applies to all EX Series Virtual Chassis except EX8200 Virtual Chassis.

See *Understanding EX8200 Virtual Chassis Components* for information about EX8200 Virtual Chassis.



NOTE: We do not recommend using EX9200 switches in a Virtual Chassis, and support for that architecture was phased out as of Junos OS Release 17.1R1. For deployments with EX9200 switches, we recommend planning or moving to MC-LAG or Junos Fusion Enterprise architectures instead of using a Virtual Chassis.

- A QFX Series Virtual Chassis is a supported combination of standalone QFX3500, QFX3600, QFX5100, QFX5110, or QFX5200 switches interconnected and managed as a single chassis. EX4300 switches (excluding multigigabit models (EX4300-48MP)) can also be interconnected into a mixed Virtual Chassis with QFX3500, QFX3600, and QFX5100 switches.

This topic does not discuss Virtual Chassis Fabric components. For information on Virtual Chassis Fabric components, see *Understanding Virtual Chassis Fabric Components*.

- [Maximum Switch Support on page 17](#)
- [Virtual Chassis Ports \(VCPs\) on page 20](#)
- [Master Routing Engine Role on page 23](#)
- [Backup Routing Engine Role on page 24](#)
- [Linecard Role on page 25](#)
- [Member Switch and Member ID on page 26](#)
- [Mastership Priority on page 27](#)
- [Virtual Chassis Identifier \(VCID\) on page 27](#)
- [Nonvolatile Storage in a Virtual Chassis on page 27](#)

Maximum Switch Support

The maximum number of switches that a Virtual Chassis supports varies by Virtual Chassis and might also depend on the Junos OS release running on the Virtual Chassis.

- [Maximum Number of Switches in an EX Series Virtual Chassis on page 17](#)
- [Maximum Switch Support in a QFX Series Virtual Chassis \(Including Mixed Virtual Chassis with EX Series Switches\) on page 19](#)

Maximum Number of Switches in an EX Series Virtual Chassis

[Table 4 on page 17](#) lists the maximum member switch support by EX Series Virtual Chassis and Junos OS release.

Table 4: Maximum Member Switch Support for Virtual Chassis by Junos OS Release

Maximum Member Switch Support	Initial Junos OS Release
EX2200 Virtual Chassis	12.2R1—Initial release. Support for up to four EX2200 member switches.

Table 4: Maximum Member Switch Support for Virtual Chassis by Junos OS Release (continued)

Maximum Member Switch Support	Initial Junos OS Release
EX2300 Virtual Chassis	<p>15.1X53-D50—Initial release. Support for up to four EX2300 member switches.</p> <p>18.1R2—Support for up to four multigigabit EX2300 (EX2300-24MP and EX2300-48MP) member switches.</p> <p>18.4R1—Starting in Junos OS Release 18.4R1, up to four of any model EX2300 member switches (including multigigabit models and any other EX2300 switches) can be combined in the same Virtual Chassis.</p>
EX3300 Virtual Chassis	<p>11.3R1—Initial release. Support for up to six EX3300 member switches</p> <p>12.2R1—Starting in Junos OS Release 12.2R1, an EX3300 Virtual Chassis can support up to ten EX3300 member switches.</p>
EX3400 Virtual Chassis	15.1X53-D50—Initial release. Support for up to ten EX3400 member switches
EX4200 Virtual Chassis	9.0R1—Initial release. Support for up to ten EX4200 member switches
EX4300 Virtual Chassis	<p>13.2X50-D10—Initial release. Support for up to ten EX4300 member switches</p> <p>13.2X50-D20—Starting in Junos OS Release 13.2X50-D20, EX4300 switch support was added in a mixed QFX Series Virtual Chassis or in a VCF.</p> <p>18.2R1—Starting in Junos OS Release 18.2R1 with the introduction of EX4300 multigigabit model switches (EX4300-48MP), an EX4300 Virtual Chassis can contain up to ten EX4300 multigigabit model switches as a non-mixed Virtual Chassis or a combination of EX4300 multigigabit model switches with other EX4300 switches as a mixed EX4300 Virtual Chassis.</p>
EX4500 Virtual Chassis	<p>11.1R1—Initial release. Support for up to two EX4500 switches</p> <p>11.4R1—Support for up to ten EX4500 member switches</p>
EX4550 Virtual Chassis	12.2R1—Initial release. Support for up to ten EX4550 switches

Table 4: Maximum Member Switch Support for Virtual Chassis by Junos OS Release (continued)

Maximum Member Switch Support	Initial Junos OS Release
EX4600 Virtual Chassis	13.2X51-D25—Initial release. Support for up to ten EX4600 switches
Mixed EX4200 and EX4500 Virtual Chassis	11.1R1—Initial release. Support for up to two EX4500 switches and up to eight EX4200 switches 11.2R1—Support for up to nine EX4200 switches 11.4R1—Support for up to nine EX4500 switches
Mixed EX4200 and EX4550 Virtual Chassis	12.2R1—Initial release. Support for up to ten total EX4200 and EX4550 switches
Mixed EX4200, EX4500, and EX4550 Virtual Chassis	12.2R1—Initial release. Support for up to ten total EX4200, EX4500, and EX4550 switches
Mixed EX4300 and EX4600 Virtual Chassis	13.2X51-D25—Initial release. Support for up to ten total EX4300 and EX4600 switches. EX4600 switches must assume Routing Engine role. NOTE: EX4300 multigigabit model (EX4300-48MP) switches are not supported in a mixed Virtual Chassis with EX4600 switches.
Mixed EX4500 and EX4550 Virtual Chassis	12.2R1—Initial release. Support for up to ten total EX4500 and EX4550 switches
EX9200 Virtual Chassis	13.2R2—Initial release. Support for up to two EX9200 switches. NOTE: Support for EX9200 switches in a Virtual Chassis was phased out as of Junos OS Release 17.1R1. For deployments with EX9200 switches, we recommend planning or moving to MC-LAG or Junos Fusion Enterprise architectures instead of using a Virtual Chassis.

Maximum Switch Support in a QFX Series Virtual Chassis (Including Mixed Virtual Chassis with EX Series Switches)

In a QFX5200 Virtual Chassis, you can interconnect up to a maximum of 3 standalone QFX5200 switches as a non-mixed Virtual Chassis. (QFX5200 switches cannot be mixed with other types of switches in a Virtual Chassis.)

For all other QFX Series Virtual Chassis, you can interconnect up to 10 standalone switches in the following supported combinations:

- QFX5110 switches or a combination of QFX5110 switches and QFX5100 switches (a non-mixed Virtual Chassis)
- QFX5100 switches (a non-mixed Virtual Chassis)
- QFX5100 switches with any combination of QFX3500 and QFX3600 switches, and EX4300 switches excluding the multigigabit models (a mixed mode Virtual Chassis)
- QFX3500 switches, or QFX3600 switches, or any combination of QFX3500 switches and QFX3600 switches (a non-mixed Virtual Chassis)
- Any combination of QFX3500 and QFX3600 switches with EX4300 switches excluding the multigigabit models (a mixed mode Virtual Chassis)



NOTE: In Junos OS release 13.2X51-D20, you can interconnect only up to four QFX5100-96S switches in a non-mixed QFX5100 Virtual Chassis. Starting in Junos OS release 13.2X51-D25, you can configure up to ten QFX5100-96S switches into a mixed or non-mixed QFX5100 Virtual Chassis.

Virtual Chassis Ports (VCPs)

You set up a Virtual Chassis by configuring Virtual Chassis ports (VCPs) on the member switches, and interconnecting the switches using the VCPs. VCPs are responsible for passing all data and control traffic between member switches in the Virtual Chassis.

- [Virtual Chassis Port Options on page 20](#)
- [Automatic Virtual Chassis Port \(VCP\) Conversion on page 22](#)
- [Virtual Chassis Port Link Aggregation Groups on page 23](#)

Virtual Chassis Port Options

Some switches have dedicated VCPs; these ports can only be used as VCPs and cannot be reconfigured as network ports. Dedicated VCPs allow you to interconnect switches without requiring any additional interface configuration.

Some switches have ports that are configured as VCPs by default. You do not need to explicitly configure those as VCPs to use them to interconnect those switches into a Virtual Chassis.

Most switches have optical or uplink ports that can also be configured as VCPs.

To interconnect switches that do not have dedicated or default-configured VCPs, or to interconnect switches across greater distances than allowed by a dedicated VCP connection, you must configure the VCPs. Also, when adding switches to an existing Virtual Chassis, or adding new redundant links between existing members, if the automatic VCP conversion feature is enabled, under the right conditions the ports on both sides of the connection will convert into VCPs automatically (see [“Automatic Virtual Chassis Port \(VCP\) Conversion” on page 22](#)).

[Table 5 on page 21](#) summarizes the available VCP options on switches in an EX Series or QFX Series Virtual Chassis. For complete details on where dedicated VCPs,

default-configured VCPs, or ports that can be configured as VCPs are located on a switch, and what transceivers and cables are supported to use for VCP connections on the switch, see the hardware documentation for that type of switch.

Table 5: VCP Options by Switch Type

Switch	Dedicated VCPs	Default VCPs	Ports that can be configured and are supported as VCPs
EX2200	None	None	Any uplink ports All RJ-45 interfaces, including built-in network ports with 10/100/1000BASE-T Gigabit Ethernet connectors and 1000BASE-T RJ-45 transceivers
EX2300 (including multigigabit EX2300 models)	None	None	Uplink ports with SFP+ transceivers NOTE: You cannot use ports with SFP transceivers as VCPs on EX2300 switches to form a Virtual Chassis.
EX3300	None	Uplink ports 2 and 3	Any of the 4 uplink ports (0 through 3)
EX3400	None	All QSFP+ uplink ports	Any SFP+ uplink ports NOTE: You cannot use ports with SFP transceivers as VCPs on EX3400 switches to form a Virtual Chassis.
EX4200	2 ports on rear panel	None	Any uplink module ports (SFP, SFP+, or XFP) or through an SFP+ port on the EX4200-24F switch NOTE: You cannot set a 1000BASE-T copper SFP transceiver (EX-SFP-1GE-T) connection as a VCP on EX4200 switches.
EX4300	None	All QSFP+ ports	Any uplink ports installed with SFP+ or QSPF+ transceivers
EX4300 Multigigabit Models (EX4300-48MP)	4 40-Gbps QSFP+ ports on rear panel	None	None
EX4500 and EX4550	Two ports on the Virtual Chassis module	None	Any SFP+ port NOTE: You cannot use SFP+ uplink ports installed with 1000BASE-T copper SFP transceivers (EX-SFP-1GE-T) as VCP connections on EX4500 and EX4550 switches.
EX4600	None	None	Any SFP+ and QSFP+ ports
QFX3500 and QFX3600	None	None	Any non-channelized 40-Gbps QSFP+ interfaces
QFX5100	None	None	Any non-channelized 40-Gbps QSFP+ interfaces

Table 5: VCP Options by Switch Type (continued)

Switch	Dedicated VCPs	Default VCPs	Ports that can be configured and are supported as VCPs
QFX5110	None	None	Any 100-Gbps or 40-Gbps QSFP28 ports Any non-channelized 40-Gbps QSFP+ interfaces Any non-channelized 10-Gbps SFP+ interfaces (on QFX5110 switch models that support these ports)
QFX5200	None	None	Any 40-Gbps QSFP+ ports In Junos OS Release 17.3R2-S4, 100-Gbps QSFP28 ports are also supported as VCPs on QFX5200 switches.

All supported SFP, SFP+, and XFP uplink connections between EX4200, EX4500, and EX4550 switches can be configured as VCPs.

QSFP+ interfaces that have been channelized into SFP+ interfaces using a breakout cable cannot be configured into VCPs.

Automatic Virtual Chassis Port (VCP) Conversion

When the automatic VCP conversion feature is enabled and you cable a new link from a new switch being added into an existing Virtual Chassis, or add a redundant link between two members of a Virtual Chassis, ports that can be VCPs are automatically converted into VCPs under the following conditions:

- Link Layer Discovery Protocol (LLDP) or LLDP-Media Endpoint Discovery (LLDP-MED) is enabled on the interfaces for the members on both ends of the new link. The two sides exchange LLDP packets to accomplish the port conversion.
- The Virtual Chassis must be preprovisioned with the switches on both sides of the link already configured in the members list of the Virtual Chassis using the **set virtual-chassis member** command.
- The interfaces for the ports on both ends of the link are not already configured as VCPs. Both sides of the link must be in the same state to handshake and establish the VCP link.

Using automatic VCP conversion when adding a switch to a preprovisioned Virtual Chassis is also referred to as *autoprovisioning* the new member.

Ports that are configured as VCPs by default on a switch or that were previously configured into VCPs must be converted back into network ports using the **request virtual-chassis vc-port delete** command for the port to be eligible for automatic VCP conversion. A port that has been automatically converted into a VCP is not automatically converted back into a network port when you remove a switch from a Virtual Chassis and disconnect the link.

Automatic VCP conversion is enabled by default on all Virtual Chassis, except in the following cases:

- Starting in Junos OS Releases 15.1R7 and 14.1X53-D47, in EX2200, EX3300, EX4200, EX4500, and EX4550 Virtual Chassis, automatic VCP conversion is disabled by default. If desired, you can enable the feature by configuring the [auto-conversion](#) statement at the `[edit virtual-chassis]` hierarchy level on the Virtual Chassis.



CAUTION: When automatic VCP conversion is enabled in a Virtual Chassis with switches that have dedicated VCPs (EX4200, EX4500, or EX4550 Virtual Chassis), if network or uplink ports are automatically converted into VCPs to create a redundant link with a dedicated VCP connection between the same two Virtual Chassis members, you must reboot the Virtual Chassis to avoid creating a traffic loop within the Virtual Chassis. (The same issue can occur even if the ports are manually converted into VCPs to create the redundant VCP link with a dedicated VCP link, so the reboot is required to avoid traffic looping in that case as well.)

- Starting in Junos OS Releases 14.1X53-D47, 17.4R2, 18.1R3, 18.2R2, and 18.3R1 for EX4300, EX4600, and QFX Series Virtual Chassis (which have the automatic VCP conversion feature enabled by default), you can choose to disable the feature by configuring the **no-auto-conversion** statement at the `[edit virtual-chassis]` hierarchy level on the Virtual Chassis. To return to the default behavior to re-enable automatic VCP conversion, delete the **no-auto-conversion** statement from the configuration.

Virtual Chassis Port Link Aggregation Groups

You can increase VCP bandwidth between member switches by configuring multiple interfaces between the same two switches into VCPs. When multiple VCPs interconnect the same two member switches, a Link Aggregation Group (LAG) or bundle is automatically formed when the VCPs are on interfaces supporting identical speeds. For example, if you have two 40-Gbps QSFP+ interfaces configured as VCPs between member switches, a LAG with two member links with 80-Gbps of total bandwidth is formed. However, 10-Gigabit SFP+ and 40-Gbps QSFP+ interfaces configured as VCPs will not become members of the same LAG.

Within a Virtual Chassis, you can also configure network interfaces located on different Virtual Chassis member switches to form a LAG, which provides load-balancing and redundancy for network traffic forwarded by the Virtual Chassis. See [“Understanding Virtual Chassis Port Link Aggregation” on page 41](#) for details on the difference between VCP LAGs and network interface LAGs within a Virtual Chassis.

Master Routing Engine Role

In a Virtual Chassis, each member switch is assigned one of two roles: Routing Engine role or linecard role, and for Routing Engine role, receives a further designation as the master or backup Routing Engine.

The member that functions as the master in the Routing Engine role in the Virtual Chassis:

- Manages the member switches.
- Runs Junos OS for the switches as a master Routing Engine.

- Runs the chassis management processes and control protocols.
- Represents all the member switches interconnected within the Virtual Chassis configuration. (The hostname and other properties that you assign to this switch during setup apply to all members of the Virtual Chassis configuration.)

In a preprovisioned configuration, one of the two members assigned as **routing-engine** functions as the master member. The selection of which member assigned as **routing-engine** functions as master and which as backup is determined by the software based on the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#).

In a configuration that is not preprovisioned, the selection of the master and backup is determined by the mastership priority value and secondary factors in the master election algorithm.

All switches that are not assigned the master or backup Routing Engine role function in the linecard role.

Use the following guidelines for assigning Routing Engine roles to the switches in a mixed Virtual Chassis:

- In any mixed Virtual Chassis configuration that includes EX4200 switches, EX4500 switches, or EX4550 switches, any switch can be configured in any role in any configuration.
- In a mixed EX4300 Virtual Chassis composed of EX4300 multigigabit model (EX4300-48MP) and other EX4300 model switches, the switches in the Routing Engine role should always be EX4300 multigigabit model switches.
- In a mixed EX4600 Virtual Chassis with EX4300 switches, an EX4600 switch must assume the master role.
- In a mixed QFX Series Virtual Chassis made up of QFX5100 switches with QFX3500, QFX3600, or EX4300 switches, we recommend configuring QFX5100 switches into the Routing Engine role. If the mixed Virtual Chassis does not contain QFX5100 switches, we recommend configuring QFX3500 or QFX3600 switches into the Routing Engine role.
- In a QFX5110 Virtual Chassis with QFX5110 and QFX5100 switches, we recommend configuring only QFX5110 switches into the Routing Engine role.

Backup Routing Engine Role

The member that functions in the backup Routing Engine role in a Virtual Chassis:

- Maintains a state of readiness to take over the master Routing Engine role if the master fails.
- Runs Junos OS for the switches as a backup Routing Engine.
- Synchronizes with the master in terms of protocol states, forwarding tables, and other information, so that it is prepared to preserve routing information and maintain network connectivity without disruption in case the master is unavailable.

You must have at least two member switches in the Virtual Chassis configuration in order to have a backup Routing Engine member.

In a preprovisioned configuration, one of the two members assigned as **routing-engine** functions in the backup role. The selection of which member assigned as **routing-engine** functions as master and which as backup is determined by the software based on the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#).

In a configuration that is not preprovisioned, the selection of the master and backup is determined by the mastership priority value and secondary factors in the master election algorithm.

Use the following guidelines for assigning Routing Engine roles to the switches in a mixed Virtual Chassis:

- In any mixed Virtual Chassis configuration that includes EX4200 switches, EX4500 switches, or EX4550 switches, any switch can be configured in any role in any configuration.
- In a mixed EX4300 Virtual Chassis composed of EX4300 multigigabit model (EX4300-48MP) and other EX4300 model switches, the switches in the master and backup Routing Engine roles should always be EX4300 multigigabit model switches.
- In a mixed EX4600 Virtual Chassis with EX4300 switches, we strongly recommend configuring an EX4600 switch into the backup role. A mixed EX4600 and EX4300 Virtual Chassis must use an EX4600 member switch in the master role, and configuring an EX4600 switch into the backup role ensures that the Virtual Chassis remains up after a switchover event.
- In a mixed QFX Series Virtual Chassis made up of QFX5100 switches with QFX3500, QFX3600, or EX4300 switches, we recommend configuring the QFX5100 switches into the Routing Engine role. If the mixed Virtual Chassis does not contain QFX5100 switches, we recommend configuring QFX3500 or QFX3600 switches into the Routing Engine role.
- In a QFX5110 Virtual Chassis with QFX5110 and QFX5100 switches, we recommend configuring only QFX5110 switches into the Routing Engine role.

Linecard Role

A member that functions in the linecard role in a Virtual Chassis:

- Runs only a subset of Junos OS.
- Does not run the chassis control protocols.
- Can detect certain error conditions (such as an unplugged cable) on any interfaces that have been configured on it through the master.

The Virtual Chassis configuration must have at least three members in order to include a linecard member.

In a preprovisioned configuration, you can explicitly configure a member with the linecard role, which makes it ineligible for functioning as a master or backup Routing Engine.

In a configuration that is not preprovisioned, the members that are not selected as master or backup function as linecard members of the Virtual Chassis configuration. The selection of the master and backup is determined by the mastership priority value and secondary factors in the master election algorithm. A switch with a mastership priority of 0 is always in the linecard role.

Any switch can function in the linecard role in a mixed or non-mixed Virtual Chassis.

Use the following guidelines for assigning Routing Engine and linecard roles to the switches in a QFX Series Virtual Chassis:

- In a mixed QFX Series Virtual Chassis made up of QFX5100 switches with QFX3500, QFX3600, or EX4300 switches, we recommend configuring the QFX5100 switches into the Routing Engine role. If the mixed Virtual Chassis does not contain QFX5100 switches, we recommend configuring QFX3500 or QFX3600 switches into the Routing Engine role.
- In a QFX5110 Virtual Chassis made up of QFX5110 and QFX5100 switches, we recommend configuring only QFX5110 switches into the Routing Engine role.

Member Switch and Member ID

Each standalone switch that supports Virtual Chassis is a potential member of a Virtual Chassis configuration. When one of those switches is powered on, it receives a member ID that can be seen by viewing the front-panel LCD or by entering the **show virtual-chassis** command. If the switch is powered on as a standalone switch, that member's member ID is always 0. When the switch is interconnected with other switches in a Virtual Chassis configuration, its member ID is assigned by the master based on various factors, such as the order in which the switch was added to the Virtual Chassis configuration or the member ID assigned by a preprovisioned configuration. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#).

If the Virtual Chassis configuration previously included a member switch and that member was physically disconnected or removed from the Virtual Chassis configuration, its member ID is not available for assignment as part of the standard sequential assignment by the master. For example, you might have a Virtual Chassis configuration composed of member 0, member 2, and member 3, because member 1 was removed. When you add another member switch and power it on, the master assigns it as member 4.

The member ID distinguishes the member switches from one another. You use the member ID:

- To assign a mastership priority value to a member switch
- To configure interfaces for a member switch (The function is similar to that of a slot number on Juniper Networks routers.)
- To apply some operational commands to a member switch
- To display status or characteristics of a member switch

Mastership Priority

In a configuration that is not preprovisioned, you can designate the role (master or backup Routing Engine role, or linecard role) that a member switch assumes by configuring its mastership priority (from 0 through 255). The mastership priority value is the factor in the master election algorithm with the highest precedence for selecting the master of the Virtual Chassis configuration. A switch with a mastership priority of 0 never assumes the backup or master Routing Engine role.

The default value for mastership priority is 128. When a standalone switch is powered on, it receives the default mastership priority value. Because it is the only member of the Virtual Chassis configuration, it is also the master. When you interconnect a standalone switch to an existing Virtual Chassis configuration (which implicitly includes its own master), we recommend that you explicitly configure the mastership priority of the members that you want to function as the master and backup.



NOTE: Configuring the same mastership priority value for both the master and backup helps to ensure a smooth transition from master to backup when the master becomes unavailable. It prevents the original master from preempting control from the backup when the backup has taken control of the Virtual Chassis configuration because the original master became unavailable.

In a preprovisioned configuration, you assign the role of each member switch.

Virtual Chassis Identifier (VCID)

All members of a Virtual Chassis configuration share one Virtual Chassis identifier (VCID). This identifier is derived from internal parameters. When you are monitoring a Virtual Chassis configuration, the VCID is displayed in certain interface views and is also part of the **show virtual-chassis** output.

Nonvolatile Storage in a Virtual Chassis

EX Series and QFX Series switches store Junos OS system files in internal flash memory. In Virtual Chassis configurations, both the master and the backup switch store the configuration information for all the member switches.

Junos OS optimizes the way a Virtual Chassis stores its configuration if a member switch or the Virtual Chassis configuration is shut down improperly, as follows:

- If the master is not available, the backup switch takes on the role of the master and its internal flash memory takes over as the alternate location for maintaining nonvolatile configuration memory.
- If a member switch is taken offline for repair, the master stores the configuration of the member switch.



NOTE: File storage management differs in an EX8200 Virtual Chassis; see *Understanding File Storage in an EX8200 Virtual Chassis* for details.

Release History Table

Release	Description
18.4R1	Starting in Junos OS Release 18.4R1, up to four of any model EX2300 member switches (including multigigabit models and any other EX2300 switches) can be combined in the same Virtual Chassis.
18.2R1	Starting in Junos OS Release 18.2R1 with the introduction of EX4300 multigigabit model switches (EX4300-48MP), an EX4300 Virtual Chassis can contain up to ten EX4300 multigigabit model switches as a non-mixed Virtual Chassis or a combination of EX4300 multigigabit model switches with other EX4300 switches as a mixed EX4300 Virtual Chassis.
17.3R2-S4	In Junos OS Release 17.3R2-S4, 100-Gbps QSFP28 ports are also supported as VCPs on QFX5200 switches.
15.1R7	Starting in Junos OS Releases 15.1R7 and 14.1X53-D47, in EX2200, EX3300, EX4200, EX4500, and EX4550 Virtual Chassis, automatic VCP conversion is disabled by default.
14.1X53-D47	Starting in Junos OS Releases 14.1X53-D47, 17.4R2, 18.1R3, 18.2R2, and 18.3R1 for EX4300, EX4600, and QFX Series Virtual Chassis (which have the automatic VCP conversion feature enabled by default), you can choose to disable the feature by configuring the no-auto-conversion statement at the [edit virtual-chassis] hierarchy level on the Virtual Chassis.
13.2X53-D25	Starting in Junos OS release 13.2X51-D25, you can configure up to ten QFX5100-96S switches into a mixed or non-mixed QFX5100 Virtual Chassis.
13.2X51-D20	In Junos OS release 13.2X51-D20, you can interconnect only up to four QFX5100-96S switches in a non-mixed QFX5100 Virtual Chassis.
13.2X50-D20	Starting in Junos OS Release 13.2X50-D20, EX4300 switch support was added in a mixed QFX Series Virtual Chassis or in a VCF.
12.2R1	Starting in Junos OS Release 12.2R1, an EX3300 Virtual Chassis can support up to ten EX3300 member switches.

Related Documentation

- [Virtual Chassis Overview for Switches on page 3](#)
- [Understanding EX8200 Virtual Chassis Components](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding QFX Series Virtual Chassis](#)
- [Understanding Mixed EX Series and QFX Series Virtual Chassis on page 29](#)
- [Configuring a QFX Series Virtual Chassis](#)

- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)
- [Command Forwarding Usage with EX Series and QFX Series Virtual Chassis on page 279](#)
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
- [Example: Configuring an EX4500 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 82](#)
- [Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File on page 127](#)

Understanding Mixed EX Series and QFX Series Virtual Chassis

This topic describes the requirements for a mixed Virtual Chassis.

A *mixed Virtual Chassis* includes two or more types of EX Series switches, two or more types of QFX Series switches, or a supported combination of EX and QFX Series switches, where architectural differences require the Virtual Chassis to be configured into mixed mode for the switches to interoperate.

A Virtual Chassis composed of all the same type of switch can usually operate as a *non-mixed Virtual Chassis*, which does not require you to set mixed mode. However, the following Virtual Chassis that include different models of the same product must operate in mixed mode due to architecture differences between the different models:

- An EX4300 Virtual Chassis composed of EX4300 multigigabit model (EX4300-48MP) switches mixed with any other EX4300 model switches



NOTE: An EX4300 Virtual Chassis operates as a non-mixed Virtual Chassis if it is composed of only EX4300 multigigabit model switches, or composed of any combination of any other EX4300 switches (excluding the multigigabit models).

The following combinations of different switch types can be interconnected into a non-mixed Virtual Chassis that does not require you to set mixed mode because the switches can run the same software image when in a Virtual Chassis:

- An EX Series Virtual Chassis composed of only EX4500 and EX4550 switches
- An EX2300 Virtual Chassis composed of any models of EX2300 and EX2300 multigigabit switches



NOTE: Junos OS releases prior to 18.4R1 support forming an EX2300 Virtual Chassis using only EX2300 multigigabit switches or only EX2300 switches that are not multigigabit model switches. Starting in Junos OS Release 18.4R1, EX2300, EX2300-C, and EX2300 multigigabit switches can all be combined in the same non-mixed Virtual Chassis.

- A QFX Series Virtual Chassis composed of only QFX3500 and QFX3600 switches
- A QFX5110 Virtual Chassis composed of QFX5110 and supported QFX5100 switches

QFX5200, EX3400, EX3300, EX2300, and EX2200 switches cannot be part of any mixed Virtual Chassis.

- [Mixed and Non-mixed EX Series and QFX Series Virtual Chassis Summary on page 30](#)
- [Understanding the Routing Engine Role in a Virtual Chassis With Different Types of Switches on page 32](#)
- [Understanding QFX5100 and QFX5110 Switches in a Virtual Chassis on page 33](#)
- [Understanding EX4300, QFX3500, QFX3600, and QFX5100 Switches in a Mixed Virtual Chassis on page 33](#)
- [Understanding Mixed EX4300 and EX4600 Virtual Chassis on page 34](#)
- [Understanding EX4300 Multigigabit and Other EX4300 Model Switches in a Mixed EX4300 Virtual Chassis on page 34](#)
- [Understanding EX4200, EX4500, and EX4550 Switches in a Mixed Virtual Chassis on page 35](#)

Mixed and Non-mixed EX Series and QFX Series Virtual Chassis Summary

[Table 6 on page 31](#) provides a high-level overview of the EX Series and QFX Series switches allowed in the Routing Engine and line-card roles of supported mixed and non-mixed Virtual Chassis configurations. Any supported mixed or non-mixed combination of switches can be configured as a nonprovisioned or preprovisioned Virtual Chassis.

Table 6: Virtual Chassis Summary

Category	Allowed Routing Engine Members	Allowed Line Card Members
Non-mixed	QFX5200	QFX5200
	QFX5110	QFX5110 QFX5100 (with a “-qfx-5e-” Junos OS image)
	QFX5100	QFX5100
	QFX3600 QFX3500	QFX3600 QFX3500
	EX4600	EX4600
	EX4300 multigigabit models (EX4300-48MP) only	EX4300 multigigabit models (EX4300-48MP) only
	EX4300 (any models except multigigabit models)	EX4300 (any models except multigigabit models)
	EX4200	EX4200
	EX4500	EX4500
	EX4550	EX4550
	EX3400	EX3400
	EX3300	EX3300
	(Prior to Junos OS Release 18.4R1) EX2300 multigigabit models (EX2300-24MP and EX2300-48MP) only, or EX2300 and EX2300-C (excluding multigigabit models) only	(Prior to Junos OS Release 18.4R1) EX2300 multigigabit models (EX2300-24MP and EX2300-48MP) only, or EX2300 and EX2300-C (excluding multigigabit models) only
	(Starting with Junos OS Release 18.4R1) EX2300, EX2300-C, and EX2300 multigigabit models (EX2300-24MP and EX2300-48MP) (any models in any combination)	(Starting with Junos OS Release 18.4R1) EX2300, EX2300-C, and EX2300 multigigabit models (EX2300-24MP and EX2300-48MP) (any models in any combination))
	EX2200	EX2200

Table 6: Virtual Chassis Summary (continued)

Category	Allowed Routing Engine Members	Allowed Line Card Members
Mixed	QFX5100	QFX5100 QFX3600 QFX3500 EX4300 (any models except multigigabit models)
	QFX3600 QFX3500	QFX3600 QFX3500 EX4300 (any models except multigigabit models)
	EX4600	EX4600 EX4300 (any models except multigigabit models)
	EX4300 multigigabit models (EX4300-48MP)	EX4300 (any models including multigigabit models)
	EX4200, EX4500, EX4550 (any of these switches in any mixed combination)	EX4200, EX4500, EX4550 (any of these switches in any mixed combination)

Understanding the Routing Engine Role in a Virtual Chassis With Different Types of Switches

When you have different types of switches in a Virtual Chassis, the combination of switches you are interconnecting determines which switches should be in the master Routing Engine role. We also recommend always configuring the same type of switch into the master and backup Routing Engine roles, to ensure that the switch operating as the master remains the same type of switch in the event of a switchover.

- In a Virtual Chassis with QFX5110 and QFX5100 switches, which is considered to be a non-mixed QFX5110 Virtual Chassis, we recommend using QFX5110 switches in the master or backup Routing Engine roles, and you can use QFX5110 or supported QFX5100 switches for the remaining members in line-card role.
- In a mixed Virtual Chassis with QFX5100 switches combined with QFX3600, QFX3500, or EX4300 switches, you should use QFX5100 switches in the master Routing Engine role, and you can use QFX5100, QFX3600, QFX3500, or EX4300 switches in the line-card role.
- In a mixed Virtual Chassis with QFX3600 or QFX3500 switches with EX4300 switches, you should use QFX3500 or QFX3600 switches in the Routing Engine role, and you can use QFX3600, QFX3500, or EX4300 switches in the line-card role.
- In a mixed EX4300 and EX4600 Virtual Chassis, EX4600 switches automatically assume the master and backup Routing Engine roles, and you can use EX4300 or EX4600 switches in the line-card role. (EX4600 switches can be in a mixed Virtual Chassis with any EX4300 model switches except multigigabit models.)
- In a mixed EX4300 Virtual Chassis with EX4300 multigigabit model (EX4300-48MP) switches and any other models of EX4300 switches, you must use EX4300 multigigabit

models in the Routing Engine role, and you can use any EX4300 switches in the line-card role.

- In a mixed Virtual Chassis that includes any combination of EX4200 switches, EX4500 switches, and EX4550 switches, any switch can be configured in any role.

In most mixed Virtual Chassis, you must configure your Virtual Chassis to ensure a switch that supports operating as a master Routing Engine assumes the master Routing Engine role. Without user configuration, any switch might assume the master or backup Routing Engine role, with the exception of EX4300 switches in an EX4600 or QFX Series Virtual Chassis, which can never assume the Routing Engine role.

Understanding QFX5100 and QFX5110 Switches in a Virtual Chassis

Up to ten QFX5100 and QFX5110 switches can be interconnected using Virtual Chassis ports (VCPs) to form a *QFX5110 Virtual Chassis*, which is considered to be a non-mixed Virtual Chassis because both types of switches can run the same software image, and you do not need to configure mixed mode. A QFX5110 Virtual Chassis can contain QFX5110 and supported QFX5100 switches in any combination, but we recommend that only QFX5110 switches be in the master and backup Routing Engine roles, and QFX5100 switches only be configured into line-card role.



NOTE: A QFX5110 Virtual Chassis with QFX5100 switches can only be set up using QFX5110 and QFX5100 switches running the same Junos OS image that includes “-qfx-5e-” in the Junos OS software package filename downloaded from the Software Center. QFX5100 switches running a Junos OS image filename that includes “-qfx-5-” must first be upgraded to the “-qfx-5e-” image to join a QFX5110 Virtual Chassis. (See *Upgrading a QFX5100 Switch with a USB Device to Join a QFX5110 Virtual Chassis or Virtual Chassis Fabric.*)

QFX5100 switches can also be interconnected into a mixed Virtual Chassis with QFX3500, QFX3600, and EX4300 switches. See the next section for more information on a mixed QFX5100 Virtual Chassis.

Understanding EX4300, QFX3500, QFX3600, and QFX5100 Switches in a Mixed Virtual Chassis

A combination of up to ten EX4300 (excluding multigigabit models), QFX3500, QFX3600, and QFX5100 switches can be interconnected using VCPs to form a mixed QFX Series Virtual Chassis.

In a mixed QFX Series Virtual Chassis that includes QFX5100 switches, only QFX5100 switches should be configured into the Routing Engine role, and the remaining members can be any combination of EX4300, QFX3500, QFX3600, or QFX5100 switches configured into line-card role.

QFX3500 and QFX3600 switches can be interconnected using VCPs to form a Virtual Chassis that is non-mixed; you do not need to configure mixed mode for a Virtual Chassis composed of only QFX3500 and QFX3600 switches. QFX3500 and QFX3600 switches can also be in a mixed QFX Series Virtual Chassis with EX4300 switches. In this combination, only QFX3500 or QFX3600 switches should be configured into the Routing

Engine role, and the remaining members can be QFX3500, QFX3600, or EX4300 switches configured into line-card role.

EX4300 switches (excluding multigigabit models) can also be interconnected into a mixed Virtual Chassis with EX4600 switches. See the next section for information on mixed EX4300 and EX4600 Virtual Chassis.

Understanding Mixed EX4300 and EX4600 Virtual Chassis

Any EX4300 switches (except for multigigabit models) and EX4600 switches can be interconnected into a Virtual Chassis.

In a mixed EX4300 and EX4600 Virtual Chassis:

- You can interconnect up to ten member switches.
- An EX4600 switch automatically assumes the master Routing Engine role.
- EX4300 switches cannot assume the Routing Engine role.

EX4600 switches cannot be in a mixed Virtual Chassis with any other type of switch besides EX4300 switches that are not multigigabit model switches.

Understanding EX4300 Multigigabit and Other EX4300 Model Switches in a Mixed EX4300 Virtual Chassis

You can combine EX4300 multigigabit model (EX4300-48MP) switches with other EX4300 switches into a mixed EX4300 Virtual Chassis.



NOTE: If an EX4300 Virtual Chassis has only EX4300 multigigabit model switches, or only a combination of other models of EX4300 switches, the Virtual Chassis is a non-mixed Virtual Chassis and should not be configured into mixed mode.

In a mixed EX4300 Virtual Chassis:

- You can interconnect up to ten member switches.
- EX4300 switches in the Virtual Chassis that are not multigigabit model switches must be configured with the **ieee-clause-82** option when setting mixed mode. See *Configuring an EX2300, EX3400, or EX4300 Virtual Chassis* for details.
- Only EX4300 multigigabit model switches can be in the Routing Engine role.
- EX4300 switches that are not multigigabit model switches must be configured into line-card role.

EX4300 multigigabit switches cannot be in a mixed Virtual Chassis with any other type of switch besides other EX4300 switches.

Understanding EX4200, EX4500, and EX4550 Switches in a Mixed Virtual Chassis

EX4200 switches, EX4500 switches, and EX4550 switches can be interconnected into a Virtual Chassis to form a mixed EX4200 and EX4500 Virtual Chassis, mixed EX4200 and EX4550 Virtual Chassis, mixed EX4500 and EX4550 Virtual Chassis, or mixed EX4200, EX4500, and EX4550 Virtual Chassis. The mixed Virtual Chassis supports up to 10 member switches regardless of whether the switches are EX4200 switches, EX4500 switches, or EX4550 switches. Any model of EX4200, EX4500, or EX4550 switch can be interconnected into the same mixed Virtual Chassis. The master election process that decides member switch roles in a mixed Virtual Chassis is identical to the master election process in a non-mixed Virtual Chassis, so any member switch in a mixed Virtual Chassis can assume the master, backup, or line-card role.

EX4200 switches, EX4500 switches, and EX4550 switches cannot be interconnected into a Virtual Chassis with any other switches.

Related Documentation

- [Virtual Chassis Overview for Switches on page 3](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [*Understanding QFX Series Virtual Chassis*](#)
- [Understanding Virtual Chassis Components on page 16](#)

Understanding How the Master in a Virtual Chassis Is Elected



NOTE: This topic does not apply to EX8200 Virtual Chassis.

All switches that are interconnected in a Virtual Chassis configuration are member switches of that Virtual Chassis. Each Virtual Chassis configuration has one member that functions as the *master* in a Routing Engine role and controls the Virtual Chassis configuration.

When a Virtual Chassis configuration boots, the Juniper Networks Junos operating system (Junos OS) on the switches automatically runs a master election algorithm to determine which member switch assumes the role of master.

The algorithm proceeds from the top condition downward until the stated condition is satisfied:

1. Choose the member with the highest user-configured mastership priority (255 is the highest possible value). A switch with a mastership priority of 0 will always stay in the linecard role.
2. Choose the member that was master the last time the Virtual Chassis configuration booted.
3. Choose the member that has been included in the Virtual Chassis configuration for the longest period of time. (For this to be a deciding factor, there has to be a minimum time lapse of 1 minute between the power-ons of the individual interconnected member switches.)
4. Choose the member with the lowest MAC address.

The variations among switches and switch models do not impact the master election algorithm.

To ensure that a specific member is elected as the master:

1. Power on only the switch that you want to configure as master of the Virtual Chassis configuration.
2. Configure the mastership priority of that member to have the highest possible value (255).
3. Continue to configure other members through the master member.
4. Power on the other members.

You can also specify the switch roles by preprovisioning your Virtual Chassis. Preprovisioning a Virtual Chassis allows you to manually assign the member ID and role for each switch in the Virtual Chassis. See [“Configuring an EX3300 Virtual Chassis \(CLI Procedure\)” on page 181](#), [“Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\)” on page 184](#), [Configuring an EX2300, EX3400, or EX4300 Virtual Chassis](#), or [Configuring a QFX Series Virtual Chassis](#).

- Related Documentation**
- [Virtual Chassis Overview for Switches on page 3](#)
 - [Understanding EX Series Virtual Chassis on page 8](#)
 - [Understanding QFX Series Virtual Chassis](#)
 - [Understanding Virtual Chassis Components on page 16](#)

Understanding Software Upgrades in a Virtual Chassis

This topic discusses software upgrades on EX Series and QFX Series Virtual Chassis, except EX8200 Virtual Chassis. For information on software upgrades on an EX8200 Virtual Chassis, see [Understanding Software Upgrades in an EX8200 Virtual Chassis](#). For information on software upgrades on a Virtual Chassis Fabric (VCF), see [Understanding Software Upgrades in a Virtual Chassis Fabric](#).

In a Virtual Chassis, each member switch must be running the same version of Juniper Networks Junos operating system (Junos OS) that supports Virtual Chassis. You can install a new Junos OS release on the entire Virtual Chassis or on a particular member in the Virtual Chassis by using the same CLI command that you use to install Junos OS on standalone switches—the **request system software add** command.

In a mixed Virtual Chassis, the member switches must also be running the same version of Junos OS. You might need to specify multiple Junos OS images when manually or automatically upgrading a mixed Virtual Chassis. For example, an EX4200 switch runs a different Junos OS image than an EX4500 or EX4550 switch, or an EX4300 switch runs a different Junos OS image than a QFX5100 switch in a QFX5100 Virtual Chassis. You can upgrade all member switches simultaneously by specifying a path to multiple Junos OS images in the same **request system software add** command.



NOTE: Some switch platforms can run the same Junos OS image. For example, you do not need to use multiple Junos OS images when updating a Virtual Chassis with a combination of EX4500 and EX4550 switches, or a Virtual Chassis with a combination of QFX3500 and QFX3600 switches.

You can also use the following features to upgrade software on members of a Virtual Chassis:

- [Automatic Software Updates on page 38](#)
- [Nonstop Software Upgrade on page 38](#)

Automatic Software Updates

You can use the automatic software update feature on a non-mixed or mixed Virtual Chassis to automatically update the Junos OS version on member switches as you add them to a Virtual Chassis. See [“Understanding Automatic Software Update on Virtual Chassis Member Switches” on page 53](#) for more information.

If you are not configuring the automatic software update feature, we recommend that you update the new member switch to the version of Junos OS running on the Virtual Chassis before adding the member switch to the Virtual Chassis.

Nonstop Software Upgrade

You can also use nonstop software upgrade (NSSU) to upgrade Junos OS on all members of a Virtual Chassis for EX Series and QFX Series Virtual Chassis that support NSSU. NSSU provides an orderly upgrade of each member of the Virtual Chassis and takes advantage of graceful Routing Engine switchover, nonstop active routing, and link aggregation to minimize traffic disruption during the upgrade.

For more information about NSSU and the Virtual Chassis that support this feature, see:

- [Understanding Nonstop Software Upgrade on a Virtual Chassis and Mixed Virtual Chassis](#)
- [Upgrading Software on a Virtual Chassis and Mixed Virtual Chassis Using Nonstop Software Upgrade](#)
- (For legacy EX Series switches in a Virtual Chassis) [“Upgrading Software Using Nonstop Software Upgrade on EX Series Virtual Chassis and Mixed Virtual Chassis \(CLI Procedure\)” on page 237](#)

Related Documentation

- [Understanding Virtual Chassis Components on page 16](#)
- [Configuring Automatic Software Update on Virtual Chassis Member Switches on page 235](#)
- [Installing Software on an EX Series Switch with a Single Routing Engine \(CLI Procedure\)](#)
- [Installing Software on a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Switches \(CLI Procedure\) on page 198](#)

Understanding Global Management of a Virtual Chassis




NOTE: This topic does not apply to EX8200 Virtual Chassis. See [Understanding Global Management of an EX8200 Virtual Chassis](#).

A Virtual Chassis is composed of multiple switches, and it, therefore, has multiple console ports and multiple out-of-band management Ethernet ports located on the switches.

You can connect a PC or laptop directly to a console port of any member switch to set up and configure the Virtual Chassis. When you connect to the console port of any member

switch, the console session is redirected to the master switch, as shown in [Figure 1 on page 39](#).

Figure 1: Console Session Redirection (EX4200 Virtual Chassis Pictured)




If the master becomes unavailable, the console session is disconnected from the old master and a new session is established with the newly elected master.

An out-of-band management Ethernet port is often referred to simply as a management Ethernet port. It uses a dedicated management channel for device maintenance and allows a system administrator to monitor and manage the switch by remote control.

The Virtual Chassis configuration can be managed remotely through SSH or Telnet using a global management interface called the virtual management Ethernet (VME) interface. The VME interface is a logical interface representing all of the out-of-band management ports on the member switches. When you connect to the Virtual Chassis configuration using the VME interface's IP address, the connection is redirected to the master member as shown in [Figure 2 on page 40](#).

Figure 2: Management Ethernet Port Redirection to the VME Interface



If the master management Ethernet link is unavailable, the session is redirected through the backup management Ethernet link. If there is no active management Ethernet link on the backup, the VME interface chooses a management Ethernet link on one of the linecard members, selecting the linecard member with the lowest member ID as its first choice.

You can configure an IP address for the VME global management interface at any time.

You can perform remote configuration and administration of all members of the Virtual Chassis configuration through the VME interface.

Related Documentation

- [Understanding Virtual Chassis Components on page 16](#)
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)

- [Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis \(CLI Procedure\) on page 231](#)

Understanding the High-Speed Interconnection of the Dedicated Virtual Chassis Ports Connecting EX4200, EX4500, and EX4550 Member Switches

Two high-speed, dedicated Virtual Chassis ports (VCPs) on the EX4200 switches and on the Virtual Chassis modules on the EX4500 and EX4550 switches enable the member switches to be interconnected and operate as a single, powerful device. When dedicated VCP interfaces are used to form a ring topology, each segment provides 64 Gbps bidirectional bandwidth on an EX4200 switch and 128 Gbps bidirectional bandwidth on an EX4500 or EX4550 switch. Because the VCP links act as point-to-point links, multiple segments of the ring can be used simultaneously. This allows the Virtual Chassis configuration bandwidth to scale as you interconnect more members within the ring topology.

Related Documentation

- [Understanding Virtual Chassis Components on page 16](#)
- [Virtual Chassis Cabling Configuration Examples for EX4200 Switches](#)

Understanding Virtual Chassis Port Link Aggregation



NOTE: This topic applies to all EX Series and QFX Series Virtual Chassis, except for EX8200 Virtual Chassis. See *Understanding Virtual Chassis Port Link Aggregation in an EX8200 Virtual Chassis* for information about EX8200 Virtual Chassis link aggregation.

Within a Virtual Chassis, you can combine physical Ethernet ports to form a logical point-to-point link known as a *link aggregation group (LAG)* or *bundle*. The interfaces that are included in a LAG are sometimes referred to as member interfaces. Do not confuse this term with member switches, which refers to switches that are interconnected into a Virtual Chassis. A LAG in a Virtual Chassis can be composed of member interfaces located in different member switches in the Virtual Chassis, or composed of multiple redundant Virtual Chassis Port (VCP) links between two member switches in the Virtual Chassis, as described in the following sections.

- [Virtual Chassis Network Interface LAG Among Virtual Chassis Members on page 41](#)
- [Virtual Chassis Port LAG Between Two Virtual Chassis Members on page 42](#)

Virtual Chassis Network Interface LAG Among Virtual Chassis Members

When setting up interfaces in a Virtual Chassis, you can configure a combination of physical Ethernet ports belonging to different member switches to form a LAG. A LAG provides more bandwidth than a single Ethernet link can provide. Additionally, link aggregation provides network redundancy by load-balancing traffic across all available

links. If one of the links fails, the system automatically load-balances traffic across all remaining links.

Similarly, if a Virtual Chassis member switch that has LAG member interfaces on multiple member switches fails for any reason, the traffic traversing the LAG can be redirected through the active member switch. This setup has benefits for failover purposes and can be especially beneficial in cases when a member switch needs to be inactive for some time, such as during a software upgrade using NSSU.

Virtual Chassis Port LAG Between Two Virtual Chassis Members

You can configure optical uplink ports into Virtual Chassis ports (VCPs) that connect EX Series or QFX series switches together to form a Virtual Chassis. When you configure multiple uplink port VCPs connecting the same two member switches, those ports *automatically* form a LAG if the ports are configured to operate at the same link speeds. Each LAG is assigned a positive-integer identifier called a *trunk ID*. Up to 8 redundant VCP links can form a VCP LAG connecting two members in a Virtual Chassis, depending on the number of available ports that can be VCPs.



NOTE: On EX2200 and EX2200-C switches, you can also configure the RJ-45 interfaces, including built-in network ports with 10/100/1000BASE-T Gigabit Ethernet connectors and 1000BASE-T RJ-45 transceivers, into VCPs. Any interfaces on these switches that are configured as VCPs interconnecting two members will automatically form a LAG, regardless of whether the interfaces are optical transceiver interfaces, RJ-45 transceiver interfaces, or built-in network ports with 10/100/1000BASE-T Gigabit Ethernet connectors.

A VCP LAG automatically forms when any two member switches are interconnected with two or more VCP links of the same link speed in any of these configurations:

- If the VCP ports on both switches are ports you configured into VCPs or default-configured VCPs (for switches that have default VCPs).
- If the VCP ports on both switches are dedicated VCPs (for switches that have dedicated VCPs).
- In a mixed Virtual Chassis when the VCP links interconnect two different switch models.

A LAG over uplink VCPs provides higher overall bandwidth for forwarding traffic between the member switches connected by the optical VCPs, faster management communications, and greater redundancy of operations among the members than would be available without the LAG.

See [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#) or [Configuring a QFX Series Virtual Chassis](#) for information about configuring uplink ports into VCPs.

Related Documentation

- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding Aggregated Ethernet Interfaces and LACP for Switches](#)

- [Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch on page 144](#)
- [Example: Configuring Aggregated Ethernet High-Speed Uplinks with LACP Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch on page 151](#)
- [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
- [Example: Configuring Link Aggregation Groups Using EX4200 Uplink Virtual Chassis Ports on page 161](#)
- *Understanding QFX Series Virtual Chassis*
- *Configuring a QFX Series Virtual Chassis*

Understanding Fast Failover in an EX Series Virtual Chassis

The Virtual Chassis fast failover feature is a hardware-assisted failover mechanism that automatically reroutes traffic and reduces traffic loss in the event of a link failure or switch failure in a Virtual Chassis. If a link between two members fails, traffic flow between those members must be rerouted quickly so that there is minimal traffic loss.

Fast failover is effective only for Virtual Chassis members configured in ring topologies using identical port types.

Fast failover is supported for the following Virtual Chassis:

- EX3300 Virtual Chassis
- EX4200 Virtual Chassis
- Mixed EX4200 and EX4500 Virtual Chassis
- Mixed EX4200 and EX4550 Virtual Chassis
- Mixed EX4200, EX4500, and EX4550 Virtual Chassis
- EX4500 Virtual Chassis
- Mixed EX4500 and EX4550 Virtual Chassis
- EX4550 Virtual Chassis

In any mixed Virtual Chassis, fast failover is supported for all Virtual Chassis ports (VCPs), including VCPs that provide interconnections between different types of member switches.

This topic describes the following:

- [Supported Topologies for Fast Failover on page 44](#)
- [How Fast Failover Works on page 44](#)
- [Effects of Topology Changes on a Fast Failover Configuration on page 49](#)

Supported Topologies for Fast Failover

For fast failover to be effective, the Virtual Chassis members must be configured in a ring topology. The ring topology can be formed by using either dedicated VCPs or user-configured uplink VCPs. Fast failover is supported only in a ring topology that uses identical port types, for example, either a topology that uses all dedicated VCPs or one that uses all uplink VCPs. Fast failover is not supported in a ring topology that includes both dedicated VCPs and uplink VCPs. Fast failover is supported, however, in a Virtual Chassis configuration that consists of multiple rings.

How Fast Failover Works

When fast failover is activated, each VCP is automatically configured with a backup port of the same type (dedicated VCP, SFP uplink VCP, or XFP uplink VCP). If a VCP fails, its backup port is used to send traffic. These backup ports act as standby ports and are not meant for load-balancing traffic or any other purposes.

Fast Failover in a Ring Topology Using Dedicated VCPs

When fast failover is activated in a ring topology that uses dedicated VCPs, each VCP is automatically configured with a backup port of the same type. If a VCP fails, its backup port is used to send traffic. [Figure 3 on page 45](#) shows normal traffic flow in a ring topology using dedicated VCPs.

Figure 3: Normal Traffic Flow in a Ring Topology Using Dedicated VCPs





Figure 4 on page 46 shows traffic redirected by fast failover.

Figure 4: Traffic Redirected by Fast Failover After a Dedicated VCP Link Failure



When the failed link is restored, the Virtual Chassis reconfigures the topology to the topology's original state.

Fast Failover in a Ring Topology Using Uplink Module VCPs

In a ring topology that uses uplink VCPs, each uplink VCP is automatically configured with a backup uplink VCP. If an uplink VCP fails, its backup port is used to send traffic. [Figure 5 on page 47](#) shows normal traffic flow in a ring topology using SFP uplink VCPs. Normal traffic flow in a ring topology using XFP uplink VCPs is the same.



NOTE: To use SFP or XFP uplink ports as VCPs, you must configure them to be VCPs using the `request virtual-chassis vc-port` command. Once configured, they are converted into VCPs. For example, `xe-0/1/0` becomes `vc-p-255/1/0` after you configure it to be a VCP.



Figure 5: Normal Traffic Flow in a Ring Topology Using SFP Uplink VCPs

Figure 6 on page 48 shows traffic redirected by fast failover.

Figure 6: Traffic Redirected by Fast Failover After SFP Uplink VCP Link Failure




In a ring topology that uses SFP uplink VCPs, there are four ports per module. Consecutive pairs of ports are automatically configured as backup ports for each other. For example, if a Virtual Chassis member has an SFP uplink module installed, uplink module VCPs **ge-0/1/0** and **ge-0/1/1** are automatically configured as backup ports for each other. Similarly, ports **ge-0/1/2** and **ge-0/1/3** are automatically configured as backup ports for each other.

In a ring topology that uses XFP uplink module VCPs, there are only two ports per uplink module. Similarly to a topology that uses SFP uplink module VCPs, each port is automatically configured to back up the other port in the uplink module (for example, **xe-0/1/0** is the backup for **xe-0/1/1**).

Fast Failover in a Virtual Chassis Configuration Using Multiple Ring Topologies

Fast failover is supported in a Virtual Chassis configuration with a multiple-ring topology, as shown in [Figure 7 on page 49](#).

Figure 7: Traffic Redirected by Fast Failover After VCP Link Failures in a Topology with Multiple Rings



In this scenario, the Virtual Chassis configuration has three rings: two rings that use dedicated VCPs and one ring that uses SFP uplink module VCPs. Fast failover works independently on each ring. Each dedicated VCP in a ring is backed up by another dedicated VCP. Similarly, each SFP uplink module VCP is backed up by another SFP uplink module VCP. Fast failover does not support a ring topology consisting of a mix of dedicated VCPs and uplink module VCPs.

Effects of Topology Changes on a Fast Failover Configuration

When the fast failover feature is activated, topology changes to the Virtual Chassis configuration do not affect the fast failover configuration. In the event of a link or switch failure, fast failover functions normally.

Related Documentation

- [Understanding EX Series Virtual Chassis on page 8](#)
- [Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails on page 156](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)

Understanding Split and Merge in a Virtual Chassis

In a Virtual Chassis, two or more switches are connected together to form a unit that is managed as a single chassis. If there is a disruption to the Virtual Chassis configuration due to member switches failing or being removed from the configuration, the Virtual Chassis configuration splits into two separate Virtual Chassis. This situation could cause disruptions in the network if the two separate configurations share common resources, such as global IP addresses. The split and merge feature provides a method to prevent the separate Virtual Chassis configurations from adversely affecting the network and also allows the two parts to merge back into a single Virtual Chassis configuration.



NOTE: If a Virtual Chassis configuration splits into separate parts, we recommend that you resolve the problem that caused the Virtual Chassis configuration to split as soon as possible.

You can also use this feature to merge two active but separate Virtual Chassis that have not previously been part of the same configuration into one Virtual Chassis configuration.



NOTE: The split and merge feature is enabled by default on EX Series and QFX Series Virtual Chassis. You can disable the split and merge feature by using the `set virtual-chassis no-split-detection` command.

- [What Happens When a Virtual Chassis Configuration Splits on page 50](#)
- [Merging Virtual Chassis Configurations on page 51](#)

What Happens When a Virtual Chassis Configuration Splits

When a Virtual Chassis configuration splits into two separate Virtual Chassis configurations, the individual member switches detect this topology change and run the master election algorithm to select a new master for each of the two Virtual Chassis configurations. The new masters then determine whether their Virtual Chassis configuration remains active. One of the configurations remains active based on the following:

- It contains both the stable master and the stable backup (that is, the master and backup from the original Virtual Chassis configuration before the split).
- It contains the stable master and the configuration is greater than half the Virtual Chassis size.
- It contains the stable backup and is at least half the Virtual Chassis size.

In accordance with the rules given in the second and third list items, if the Virtual Chassis configuration splits into two equal parts and the stable master and stable backup are in different parts, then the part that contains the stable backup becomes active.



NOTE: The number of members in the Virtual Chassis configuration includes all member switches connected to date minus the number whose Virtual Chassis member IDs have been recycled (that is, made available for reassignment). Therefore, the size of the Virtual Chassis configuration increases when a new member switch is detected and decreases when a member switch's ID is recycled.

These rules ensure that only one of the two separate Virtual Chassis configurations created by the split remains active. The member switches in the inactive Virtual Chassis configuration remain in a linecard role. For the inactive members to become active again, one of the following things must happen:

- The problem that caused the original Virtual Chassis configuration to split is resolved, allowing the two Virtual Chassis configurations to merge.
- You load the factory default configuration on the inactive members, which causes the inactive members to function as standalone switches or become part of a different Virtual Chassis configuration.



NOTE: When you remove a member switch from a Virtual Chassis configuration, we recommend that you recycle the member ID using the `request virtual-chassis recycle` command.

Merging Virtual Chassis Configurations

There are two scenarios in which separate Virtual Chassis merge:

- A Virtual Chassis configuration that had split into two is now merging back into a single configuration because the problem that had caused it to split has been resolved.
- You want to merge two Virtual Chassis that had not previously been configured together.

Every Virtual Chassis configuration has a unique ID (VCID) that is automatically assigned when the Virtual Chassis configuration is formed. You can also explicitly assign a VCID using the `set virtual-chassis id` command. A VCID that you assign takes precedence over automatically assigned VCIDs.

When you reconnect the separate Virtual Chassis configurations or connect them for the first time, the members determine whether or not the separate Virtual Chassis configurations can merge. The members use the following rules to determine whether a merge is possible:

- If the Virtual Chassis configurations have the same VCID, then the configurations can merge. If the two Virtual Chassis were formed as the result of a split, they have the same VCID.
- If the VCIDs are different, then the two configurations can merge only if both are active (inactive configurations cannot merge, ensuring that members removed from one Virtual Chassis configuration do not become members of another Virtual Chassis).

configuration). If the configurations to merge are both active and one of them has a user-configured VCID, this ID becomes the ID of the merged Virtual Chassis. If neither Virtual Chassis has a user-configured VCID, then the VCID of the configuration with the highest mastership priority becomes the ID of the merged Virtual Chassis. The resulting merged Virtual Chassis configuration is active.

When you connect two Virtual Chassis configurations, the following events occur:

1. Connecting the two split Virtual Chassis configurations triggers the shortest-path-first (SPF) algorithm. The SPF algorithm computes the network topology and then triggers the master election algorithm. The master election algorithm waits for the members to synchronize the topology information before running.
2. The master election algorithm merges the VCIDs of all the members.
3. Each member runs the master election algorithm to select a master and a backup from among all members with the same VCIDs. For more information, see [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#).
4. The master determines whether the Virtual Chassis configuration is active or inactive. (See [“What Happens When a Virtual Chassis Configuration Splits” on page 50](#).)
5. If the Virtual Chassis configuration is active, the master assigns roles to all members. If the Virtual Chassis configuration is inactive, the master assigns all members the role of linecard.
6. When the other members receive their role from the master, they change their role to backup or linecard. They also use the active or inactive state information sent by the master to set their own state to active or inactive and to construct the Virtual Chassis member list from the information sent by the master.
7. If the Virtual Chassis state is active, the master waits for messages from the members indicating that they have changed their roles to the assigned roles, and then the master changes its own role to master.



NOTE: When you merge two Virtual Chassis that had not previously been part of the same Virtual Chassis configuration, any configuration settings (such as the settings for Telnet and FTP services, graceful Routing Engine switchover (GRES), fast failover, VLANs, and so on) that exist on the new master become the configuration settings for all members of the new Virtual Chassis, overwriting any other configuration settings.

**Related
Documentation**

- [Disabling Split and Merge in a Virtual Chassis on page 235](#)

- [Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge on page 241](#)
- [Example: Assigning the Virtual Chassis ID to Determine Precedence During an EX4200 Virtual Chassis Merge on page 159](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding QFX Series Virtual Chassis](#)

Understanding Automatic Software Update on Virtual Chassis Member Switches

You can use the automatic software update feature to automatically update the Juniper Networks Junos operating system (Junos OS) version on prospective member switches as you add them to an EX Series or QFX Series Virtual Chassis.

- [Automatic Software Update Basics on page 53](#)
- [Automatic Software Update Restrictions on page 53](#)

Automatic Software Update Basics

When you have configured automatic software update on a Virtual Chassis, the Junos OS version is updated on the new member switch when you add it to the Virtual Chassis. The new member switch immediately joins the Virtual Chassis configuration and is put in the active state.

For a standalone switch to join an existing Virtual Chassis, it must be running the same version of Junos OS that is running on the Virtual Chassis master. When the master in a Virtual Chassis detects that a new switch has been added to the configuration, it checks the software version on the new switch. If the software version on the new switch is not the same as the version running on the master, the master keeps the new switch in the inactive state. If you have not enabled the automatic software update feature, you have to manually install the correct software version on each prospective member switch as it is added to the Virtual Chassis.

Automatic Software Update Restrictions

Refer to [Feature Explorer](#) to see the EX Series and QFX Series Virtual Chassis that support automatic software updates, and the Junos OS release versions where the feature was introduced on each platform. Where the automatic software update feature is supported, see the Junos OS Release Notes for the release version running on the master for any limitations in using automatic software updates between that release version and any prospective member switch release versions.



CAUTION: A QFX5100 switch running a Junos OS software image with “-qfx-5-” in the package filename *must* first be upgraded to a Junos OS software image with “-qfx-5e-” in the package filename before it can be added to a QFX5110 Virtual Chassis or VCF. The automatic software update process cannot update a switch from a “-qfx-5-” image to a “-qfx-5e-” image.

See [Upgrading a QFX5100 Switch with a USB Device to Join a QFX5110 Virtual Chassis or Virtual Chassis Fabric](#).

After a QFX5100 switch is installed with a “-qfx-5e-” Junos OS software image, the automatic software update process can successfully update the switch automatically with a different version of a “-qfx-5e-” Junos OS image to match the other members in the Virtual Chassis or VCF.

**Related
Documentation**

- [Understanding Software Upgrades in a Virtual Chassis on page 37](#)
- [Configuring Automatic Software Update on Virtual Chassis Member Switches on page 235](#)
- [Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches on page 170](#)

Understanding Nonstop Software Upgrade on EX Series Switches

Nonstop software upgrade (NSSU) enables you to upgrade the software running on Juniper Networks EX Series Ethernet Switches with redundant Routing Engines and all member switches in EX Series Virtual Chassis by using a single command. During the upgrade there might be minimal network traffic disruption during mastership switchover, and the extent of disruption could be dependent on the network topology, configuration, network traffic, and other environment factors .



NOTE: When an EX Series switch in a mixed Virtual Chassis is upgraded to Junos OS Release 15.1 or later from a release earlier than Release 15.1, there might be a drop in traffic for up to 60 seconds.

NSSU is supported on the following EX Series platforms:

- EX3300 Virtual Chassis
- EX3400 Virtual Chassis
- EX4200 Virtual Chassis
- EX4300 Virtual Chassis
- EX4500 Virtual Chassis
- EX4550 Virtual Chassis
- All mixed Virtual Chassis composed of EX4200, EX4500, and EX4550 switches
- EX4600 Virtual Chassis
- EX6200 switches

- EX8200 switches
- EX8200 Virtual Chassis

Performing an NSSU provides these benefits:

- No disruption to the control plane—An NSSU takes advantage of graceful Routing Engine switchover (GRES) and nonstop active routing (NSR) to ensure no disruption to the control plane. During the upgrade process, interface, kernel, and routing protocol information is preserved.
- Minimal disruption to network traffic—An NSSU minimizes network traffic disruption by:
 - Upgrading line cards one at a time in an EX6200 switch, EX8200 switch, or EX8200 Virtual Chassis, permitting traffic to continue to flow through the line cards that are not being upgraded.
 - Upgrading member switches one at a time in an EX3300, EX3400, EX4200, EX4300, EX4500, EX4600, or mixed Virtual Chassis, permitting traffic to continue to flow through the members that are not being upgraded.

To achieve minimal disruption to traffic, you must configure link aggregation groups (LAGs) such that the member links of each LAG reside on different line cards or Virtual Chassis members. When one member link of a LAG is down, the remaining links are up, and traffic continues to flow through the LAG.



NOTE: Because NSSU upgrades the software on each line card or on each Virtual Chassis member one at a time, an upgrade using NSSU can take longer than an upgrade using the request system software add command.

In releases prior to Junos OS Release 16.1, for EX6200 switches, EX8200 switches, and EX8200 Virtual Chassis, you can reduce the amount of time an upgrade takes by configuring line-card upgrade groups. The line cards in an upgrade group are upgraded simultaneously, reducing the amount of time it takes to complete an upgrade. See *Configuring Line-Card Upgrade Groups for Nonstop Software Upgrade*.

This topic covers:

- [Requirements for Performing an NSSU on page 55](#)
- [How an NSSU Works on page 57](#)
- [NSSU Limitations on page 60](#)
- [NSSU and Junos OS Release Support on page 60](#)
- [Overview of NSSU Configuration and Operation on page 61](#)

Requirements for Performing an NSSU

The following requirements apply to all switches and Virtual Chassis:

- All Virtual Chassis members and all Routing Engines must be running the same Junos OS release.
- Graceful Routing Engine switchover (GRES) must be enabled.
- Nonstop active routing (NSR) must be enabled.



NOTE: Although nonstop bridging (NSB) does not have to be enabled to perform an NSSU, we recommend enabling NSB before performing an NSSU. Enabling NSB ensures that all NSB-supported Layer 2 protocols operate seamlessly during the Routing Engine switchover that is part of the NSSU. In releases prior to Junos OS Release 16.1, see *Configuring Nonstop Bridging on Switches (CLI Procedure)*.

- For minimal traffic disruption, you must define link aggregation groups (LAGs) such that the member links reside on different Virtual Chassis members or on different line cards.

The following are requirements for EX3300, EX3400, EX4200, EX4300, EX4500, EX4600, and mixed Virtual Chassis:

- The Virtual Chassis members must be connected in a ring topology so that no member is isolated as a result of another member being rebooted. This topology prevents the Virtual Chassis from splitting during an NSSU.
- The Virtual Chassis master and backup must be adjacent to each other in the ring topology. Adjacency permits the master and backup to always be in sync, even when the switches in linecard roles are rebooting.
- The Virtual Chassis must be preprovisioned so that the linecard role has been explicitly assigned to member switches acting in a linecard role. During an NSSU, the Virtual Chassis members must maintain their roles—the master and backup must maintain their master and backup roles (although mastership will change), and the remaining switches must maintain their linecard roles.
- A two-member Virtual Chassis must have **no-split-detection** configured so that the Virtual Chassis does not split when an NSSU upgrades a member.



NOTE: For the EX4300 Virtual Chassis, you should enable the `vcp-no-hold-time` statement at the `[edit virtual-chassis]` hierarchy level before performing a software upgrade using NSSU. If you do not enable the `vcp-no-hold-time` statement, the Virtual Chassis might split during the upgrade. A split Virtual Chassis can cause disruptions to your network, and you might have to manually reconfigure your Virtual Chassis after the NSSU if the split and merge feature was disabled. For more information about a split Virtual Chassis, see [“Understanding Split and Merge in a Virtual Chassis” on page 50](#)

How an NSSU Works

This section describes what happens when you request an NSSU on these switches and Virtual Chassis:

- [EX3300, EX3400, EX4200, EX4300, EX4500, EX4600, and Mixed Virtual Chassis on page 57](#)
- [EX6200 and EX8200 Switches on page 58](#)
- [EX8200 Virtual Chassis on page 59](#)

[EX3300, EX3400, EX4200, EX4300, EX4500, EX4600, and Mixed Virtual Chassis](#)

When you request an NSSU on an EX3300, EX3400, EX4200, EX4300, EX4500, or mixed Virtual Chassis:

1. The Virtual Chassis master verifies that:
 - The backup is online and running the same software version.
 - Graceful Routing Engine switchover (GRES) and nonstop active routing (NSR) are enabled.
 - The Virtual Chassis has a preprovisioned configuration.
2. The master installs the new software image on the backup and reboots it.
3. The master resynchronizes the backup.
4. The master installs the new software image on member switches that are in the linecard role and reboots them, one at a time. The master waits for each member to become online and active before starting the software upgrade on the next member.
5. When all members that are in the linecard role have been upgraded, the master performs a graceful Routing Engine switchover, and the upgraded backup becomes the master.
6. The software on the original master is upgraded and the original master is automatically rebooted. After the original master has rejoined the Virtual Chassis, you can optionally return control to it by requesting a graceful Routing Engine switchover.

EX6200 and EX8200 Switches

When you request an NSSU on a standalone switch with redundant Routing Engines:

1. The switch verifies that:
 - Both Routing Engines are online and running the same software version.
 - Both Routing Engines have sufficient storage space for the new software image.
 - Graceful Routing Engine switchover and nonstop active routing are enabled.
2. The switch installs the new software image on the backup Routing Engine and reboots it.
3. The switch resynchronizes the backup Routing Engine to the master Routing Engine.
4. The line cards in the first upgrade group (or the line card in slot 0, if no upgrade groups are defined) download the new image and then restart. Traffic continues to flow through the line cards in the other upgrade groups during this process.
5. When line cards restarted in Step 4 are online again, the line cards in the next upgrade group download the new image and restart. This process continues until all online line cards have restarted with the new software.



NOTE: If you have taken a line card offline with the CLI before you start the NSSU, the line card is not restarted and remains offline.

6. The switch performs a graceful Routing Engine switchover, so that the upgraded backup Routing Engine becomes the master.
7. The switch installs the new software on the original master Routing Engine.

To complete the upgrade process, the original master Routing Engine must be rebooted. You can do so manually or have the switch perform an automatic reboot by including the **reboot** option when you request the NSSU. After the original master has been rebooted, you can optionally return control to it by requesting a graceful Routing Engine switchover.
8. (EX6200 switch only) The original master Routing Engine reboots to complete the software upgrade.



NOTE: To complete the upgrade process on an EX8200 switch, you must intervene to reboot the original master Routing Engine. You can reboot the original master Routing Engine manually or have the switch perform an automatic reboot by including the `reboot` option when you request the NSSU.

9. (Optional) After the original master has been rebooted, you can return control to it by requesting a graceful Routing Engine switchover.

The switch can maintain normal operations with either Routing Engine acting as the master Routing Engine after the software upgrade, so you only have to perform this switchover if you want to return Routing Engine control to the original master Routing Engine.

EX8200 Virtual Chassis

When you request an NSSU on an EX8200 Virtual Chassis:

1. The master external Routing Engine verifies that:
 - It has a backup external Routing Engine that is online.
 - All Virtual Chassis members have redundant Routing Engines and the Routing Engines are online.
 - All Routing Engines are running the same software version.
 - All Routing Engines have sufficient storage space for the new software image.
 - Graceful Routing Engine switchover and nonstop active routing (NSR) are enabled.
2. The master external Routing Engine installs the new software image on the backup external Routing Engine and reboots it.
3. The backup external Routing Engine resynchronizes with the master external Routing Engine.
4. The master external Routing Engine installs the new software on the backup Routing Engines in the member switches and reboots the backup Routing Engines.
5. When the reboot of the backup Routing Engines complete, the line cards in the first upgrade group download the new image and then restart. (If no upgrade groups are defined, the line card in slot 0 of member 0 downloads the new image and restarts.) Traffic continues to flow through the line cards in the other upgrade groups during this process.
6. When line cards restarted in Step 5 are online again, the line cards in the next upgrade group (or the next sequential line card) download the new image and restart. This process continues until all online line cards have restarted with the new software.



NOTE: If you have taken a line card offline with the CLI before you start the NSSU, the line card is not restarted and remains offline.

7. The new software image is installed on the master Routing Engines, both external and internal.
8. The member switches perform a graceful Routing Engine switchover, so that the upgraded backup Routing Engines become masters.
9. The master external Routing Engine performs a graceful Routing Engine switchover so that the backup external Routing Engine is now the master.

To complete the upgrade process, the original master Routing Engines, both external and internal, must be rebooted. You can do so manually by establishing a console connection to each Routing Engine or have the reboot performed automatically by including the **reboot** option when you request the NSSU. After the original master external Routing Engine has been rebooted, you can optionally return control to it by requesting a graceful Routing Engine switchover.

NSSU Limitations

You cannot use an NSSU to downgrade the software—that is, to install an earlier version of the software than is currently running on the switch. To install an earlier software version, use the **request system software add** command.

You cannot roll back to the previous software version after you perform an upgrade using NSSU. If you need to roll back to the previous software version, you can do so by rebooting from the alternate root partition if you have not already copied the new software version into the alternate root partition.

NSSU and Junos OS Release Support

A Virtual Chassis must be running a Junos OS release that supports NSSU before you can perform an NSSU. If a Virtual Chassis is running a software version that does not support NSSU, use the **request system software add** command.

[Table 7 on page 60](#) lists the EX Series switches and Virtual Chassis that support NSSU and the Junos OS release at which they began supporting it.

Table 7: Platform and Release Support for NSSU

Platform	Junos OS Release
EX3300 Virtual Chassis	12.2 or later
EX3400 Virtual Chassis	15.1X53-D55
EX4200 Virtual Chassis	12.1 or later

Table 7: Platform and Release Support for NSSU (continued)

Platform	Junos OS Release
EX4300 Virtual Chassis	13.2X51-D20 or later
EX4500 Virtual Chassis	12.1 or later
EX4550 Virtual Chassis	12.2 or later
Mixed EX4200 and EX4500 Virtual Chassis	12.1 or later
Mixed EX4200 and EX4550 Virtual Chassis	12.2 or later
Mixed EX4200, EX4500, and EX4550 Virtual Chassis	12.2 or later
Mixed EX4500 and EX4550 Virtual Chassis	12.2 or later
EX6200 switch	12.2 or later
EX8200 switch	10.4 or later
EX8200 Virtual Chassis	11.1 or later

Overview of NSSU Configuration and Operation

You must ensure that the configuration of the switch or Virtual Chassis meets the requirements described in [“Requirements for Performing an NSSU” on page 55](#). NSSU requires no additional configuration.

In releases prior to Junos OS Release 16.1, for EX6200 switches, EX8200 switches, and EX8200 Virtual Chassis, you can optionally configure line-card upgrade groups using the CLI. See *Example: Configuring Line-Card Upgrade Groups for Nonstop Software Upgrade on EX Series Switches*.

You perform an NSSU by executing the `request system software nonstop-upgrade` command. For detailed instructions on how to perform an NSSU, see the topics in Related Documentation.

Release History Table

Release	Description
16.1	In releases prior to Junos OS Release 16.1, for EX6200 switches, EX8200 switches, and EX8200 Virtual Chassis, you can reduce the amount of time an upgrade takes by configuring line-card upgrade groups.

Related Documentation

- [Upgrading Software Using Nonstop Software Upgrade on EX Series Virtual Chassis and Mixed Virtual Chassis \(CLI Procedure\) on page 237](#)
- [Upgrading Software on an EX6200 or EX8200 Standalone Switch Using Nonstop Software Upgrade \(CLI Procedure\)](#)

- [Upgrading Software on an EX8200 Virtual Chassis Using Nonstop Software Upgrade \(CLI Procedure\)](#)
- [Configuring Nonstop Active Routing on Switches](#)
- [Configuring Graceful Routing Engine Switchover in a Virtual Chassis on page 242](#)
- [Example: Configuring Line-Card Upgrade Groups for Nonstop Software Upgrade on EX Series Switches](#)

Understanding Virtual Chassis Device Reachability Testing

You can use a Virtual Chassis device reachability test to verify that the connections that connect the Virtual Chassis member devices together are functioning properly. You typically use a device reachability test to verify host reachability and connectivity within a Virtual Chassis.

A Virtual Chassis device reachability test sends ping packets from one member of a Virtual Chassis to another member of a Virtual Chassis directly through the Virtual Chassis connections. The receiving Virtual Chassis member sends reply packets to confirm receipt of the ping packets from the sending device. The results of the test provide information that is helpful in verifying connectivity between Virtual Chassis member devices.

Related Documentation

- [Verifying Connectivity Between Virtual Chassis Member Devices on page 291](#)

Understanding MAC Address Assignment on a Virtual Chassis

In a Virtual Chassis, multiple switches—each with its own set of interfaces with unique MAC addresses—are connected together to form one chassis that can be managed as a single switch. The MAC address assigned to each network-facing interface on the switch changes when the switch joins a Virtual Chassis. Because all Layer 2 traffic decisions are based on an interface's MAC address, understanding MAC address assignment is important to understanding how network traffic is forwarded and received by the Virtual Chassis. For additional information about how a network uses MAC addresses to forward and receive traffic, see *Understanding Bridging and VLANs on Switches*.

When a Virtual Chassis is formed, the MAC address of the switch in the master role becomes the system MAC base address. The Virtual Chassis assigns the system MAC base address as the MAC address for all Layer 3 interfaces within the Virtual Chassis. The Virtual Chassis also assigns the system MAC base address to the virtual management Ethernet (VME) interface and to all of the virtual LANs (VLANs) in the Virtual Chassis.

The system MAC base address does not change in the event of a switchover if the switch that was originally configured in the master role remains a member of the Virtual Chassis. If the switch that was originally configured in the master role is removed from the Virtual Chassis, the MAC address of the current member switch in the master role is assigned as the system MAC base address after the MAC persistence timer interval has expired. You can configure the MAC persistence timer interval.

For Layer 2 and aggregated Ethernet interfaces, the Virtual Chassis assigns a unique MAC address that is derived from the member switch MAC address to each interface. The assignment of a unique MAC address to each network interface helps ensure that functions that require MAC address differentiation—such as redundant trunk groups (RTGs), Link Aggregation Control Protocol (LACP), and general monitoring functions—can function properly.



NOTE: Unique MAC address assignment for Layer 2 and aggregated Ethernet interfaces in a Virtual Chassis was introduced in Junos OS Release 11.3. The same MAC address could be assigned to interfaces on different member switches in the same Virtual Chassis prior to this release.

If you reconfigure a Layer 2 interface into a Layer 3 interface, or the reverse, within a Virtual Chassis, the MAC address of that interface changes accordingly.

MAC addresses are assigned to interfaces in a Virtual Chassis automatically—no user configuration is possible or required. You can view the MAC addresses that are assigned to the interfaces by using the **show interfaces** command.

Related Documentation

- [Understanding MAC Address Assignment on an EX Series Switch](#)
- [Configuring the Timer for the Backup Member to Start Using Its Own MAC Address, as Master of a Virtual Chassis on page 232](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [EX8200 Virtual Chassis Overview](#)
- [Understanding QFX Series Virtual Chassis](#)

Understanding High Availability on an EX Series Virtual Chassis

You increase your network's high availability (HA) when you interconnect a Juniper Networks EX Series Ethernet switch into a Virtual Chassis. A Virtual Chassis is more fault tolerant than a standalone EX series switch because it remains up when a single member switch fails, and provides sub-second convergence in the case of a device or link failure.

You can further improve HA by configuring the HA features available for your EX Series Virtual Chassis. You can, for instance, configure Link Aggregation Groups (LAG) bundles to include member links on multiple member switches in the same Virtual Chassis. This configuration increases fault tolerance because traffic traversing the LAG can be redirected to an active member switch when a single member switch fails.

A Virtual Chassis has dual Routing Engines—the switch in the master role and the switch in the backup role—and therefore supports many HA features not supported on standalone EX Series switches, such as Graceful Routing Engine Switchover (GRES) for hitless failover. For information on which of the High Availability features listed in [Table 8 on page 64](#) are supported in your EX Series Virtual Chassis, see [Feature Explorer](#).

Many HA features for the EX Series Virtual Chassis are designed to improve network resiliency after a Routing Engine switchover. [Table 8 on page 64](#) describes the effects of a Routing Engine switchover when no high availability features are enabled and when some High Availability features are enabled.

Table 8: Effects of a Routing Engine Switchover

High Availability Feature	Effect of Routing Engine Switchover
No HA features enabled	Kernel and forwarding state information is not preserved to the backup Routing Engine. A convergence process that requires all interfaces on the Virtual Chassis to be taken offline has to be performed before the Virtual Chassis returns online. The switchover can take several minutes and the Virtual Chassis does not send or receive traffic until the switchover is complete.
Graceful Routing Engine switchover (GRES) enabled	Kernel and forwarding state information is preserved on both Routing Engines, so the convergence process does not occur and the switchover happens quickly with minimal traffic loss.
Nonstop active routing (NSR), Nonstop bridging (NSB), or both enabled	<p>Layer 2 protocols that are supported by NSB are not disrupted by a Routing Engine switchover when NSB is enabled. Layer 2 protocol information for all active Layer 2 protocols is stored on both Routing Engines when NSB is enabled.</p> <p>Layer 3 protocols that are supported by NSR are not disrupted by a Routing Engine switchover when NSR is enabled. Layer 3 protocol information for all active Layer 3 protocols is stored on both Routing Engines when NSR is enabled.</p>
Graceful Protocol Restart enabled	Traffic is not interrupted during the switchover. Interface and kernel information is preserved. Graceful restart protocol extensions quickly collect and restore routing information for supported protocols from the neighboring devices.

Related Documentation

- [Understanding EX Series Virtual Chassis on page 8](#)

PART 2

Configuration

- [Configuration Examples on page 67](#)
- [Configuration Tasks on page 175](#)
- [Configuration Statements on page 245](#)

CHAPTER 2

Configuration Examples

- [Example: Configuring an EX2200 Virtual Chassis with Four Member Switches on page 68](#)
- [Example: Configuring an EX3300 Virtual Chassis with a Master and Backup on page 72](#)
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
- [Example: Configuring an EX4500 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 82](#)
- [Example: Expanding an EX3300 Virtual Chassis on page 87](#)
- [Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet on page 92](#)
- [Example: Adding EX4500 Switches to a Preprovisioned Virtual Chassis on page 98](#)
- [Example: Adding an EX4500 Switch to a Nonprovisioned Virtual Chassis on page 102](#)
- [Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration on page 107](#)
- [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
- [Example: Connecting EX4500 Member Switches in a Virtual Chassis Across Wiring Closets on page 121](#)
- [Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File on page 127](#)
- [Example: Configuring a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis on page 139](#)
- [Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch on page 144](#)
- [Example: Configuring Aggregated Ethernet High-Speed Uplinks with LACP Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch on page 151](#)
- [Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails on page 156](#)
- [Example: Assigning the Virtual Chassis ID to Determine Precedence During an EX4200 Virtual Chassis Merge on page 159](#)

- [Example: Configuring Link Aggregation Groups Using EX4200 Uplink Virtual Chassis Ports on page 161](#)
- [Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches on page 170](#)

Example: Configuring an EX2200 Virtual Chassis with Four Member Switches

A Virtual Chassis configuration is a scalable switch. You can provide secure, redundant network accessibility with an EX2200 Virtual Chassis. You can expand the Virtual Chassis configuration to include up to four EX2200 member switches to provide additional access interfaces as your office grows.

This example describes how to configure a four-member EX2200 Virtual Chassis. You can use this configuration with the same hardware and software configurations if the member switches are installed in the same or different wiring closets.

- [Requirements on page 68](#)
- [Overview and Topology on page 68](#)
- [Configuration on page 69](#)
- [Verification on page 70](#)
- [Troubleshooting the Virtual Chassis on page 71](#)

Requirements

This example uses the following hardware and software components:

- Four EX2200 switches
- Four Virtual Chassis port (VCP)-configurable optical modules.

To confirm which optical modules are supported for EX2200 switches and are VCP-configurable, see *Pluggable Transceivers Supported on EX2200 Switches*.

- Junos OS Release 12.2 or later for EX Series switches

Before you begin, be sure you have:

1. Rack-mounted the switches. See *Mounting an EX2200 Switch*.
2. Cabled the switches. See *Installing and Connecting an EX2200 Switch*.

Overview and Topology

This example shows a Virtual Chassis configuration composed of four EX2200 switches. You would typically use a four-member EX2200 Virtual Chassis to add ports at the access layer in a manner that minimized network complexity, or to combine two EX2200 access layer switches at different sites into a single switch. A Virtual Chassis reduces network complexity by allowing a single configuration to be applied to all member switches and by minimizing the need for a loop prevention protocol like Spanning Tree Protocol (STP).

You interconnect EX2200 switches into a Virtual Chassis by configuring uplink ports connecting EX2200 member switches as Virtual Chassis ports (VCPs). You must use the uplink ports configured as VCPs regardless of whether the member switches are installed in the same or different wiring closets.

After you interconnect the switches with the uplink ports and configure them as VCPs, the VCPs are operational. The mastership priorities and member IDs are assigned by the user using the Junos OS software in this example. The software elects a master based on several criteria, including how long a member switch has belonged to the Virtual Chassis configuration. For additional details on how the master switch is elected, see [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#).



NOTE: This example uses a nonprovisioned configuration. You can explicitly assign a role for each member switch by preprovisioning the Virtual Chassis. See [“Configuring an EX2200 Virtual Chassis \(CLI Procedure\)” on page 176](#).



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis.

The topology for this example consists of four EX2200 switches.

[Table 9 on page 69](#) shows the default configuration settings for the Virtual Chassis.

Table 9: Components of the Basic Virtual Chassis Access Switch Topology

Member Switch	Hardware	Member ID	Role and Priority
switch-0	EX2200 switch	0	Master: mastership priority 255
switch-1	EX2200 switch	1	Backup: mastership priority 255
switch-2	EX2200 switch	2	Line card; mastership priority 128
switch-3	EX2200 switch	3	Line card; mastership priority 128

Configuration

Step-by-Step Procedure

To configure a Virtual Chassis with four member switches in a single wiring closet:

1. Make sure the optical ports on the member switches are properly cabled. See *Installing a Transceiver*.
2. Power on switch-0 (the member switch that you want to function as the master).

3. When the CLI prompt becomes available, run the EZSetup program on switch-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* or *Connecting and Configuring an EX Series Switch (J-Web Procedure)* for details.

4. Configure switch-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired.

```
[edit]
user@switch-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

5. Configure the mastership priority of the switches that you want to act in the master and backup roles:

```
[edit virtual-chassis]
user@switch-0# set member 0 mastership-priority 255
user@switch-0# set member 1 mastership-priority 255
```

6. Power on switch-1. The default mastership priority selection algorithm uses the amount of time powered on to assign the backup role to a switch, so powering on switch-1 before switch-2 and switch-3 helps ensure the correct roles are assigned to each member switch.

7. Power on switch-2 and switch-3. You do not need to configure the mastership priority values for these switches since they will use the default priority values of 128.

8. Configure the optical ports on each switch as VCPs.

```
user@switch-0> request virtual-chassis vc-port set pic-slot 1 port 0
user@switch-0> request virtual-chassis vc-port set pic-slot 1 port 1
```

```
user@switch-1> request virtual-chassis vc-port set pic-slot 1 port 0
user@switch-1> request virtual-chassis vc-port set pic-slot 1 port 1
```

```
user@switch-2> request virtual-chassis vc-port set pic-slot 1 port 0
user@switch-2> request virtual-chassis vc-port set pic-slot 1 port 1
```

```
user@switch-3> request virtual-chassis vc-port set pic-slot 1 port 0
user@switch-3> request virtual-chassis vc-port set pic-slot 1 port 1
```

Verification

To confirm that the Virtual Chassis is operational, perform these tasks:

- [Verifying That the Member Switches are Present and the Roles are Properly Assigned on page 71](#)

Verifying That the Member Switches are Present and the Roles are Properly Assigned

Purpose Verify that the member switches are present in the Virtual Chassis and that the master switch, which has been selected by default, is the member switch that you want to function in that role.

Action List the member switches of the Virtual Chassis configuration:

```
user@switch-0> show virtual-chassis
```

```
Virtual Chassis ID: 5dfe.e61f.2abc
Virtual Chassis Mode: Enabled
```

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Neighbor ID	List Interface
0 (FPC 0)	Prsnt	GR0211195292	ex2200-24t-4g	255	Master*	NA	1	vcp-255/1/0
1 (FPC 1)	Prsnt	GP0211420824	ex2200-24t-4g	255	Backup	NA	3	vcp-255/1/1
2 (FPC 2)	Prsnt	GP0211464311	ex2200-24t-4g	128	Linecard	NA	0	vcp-255/1/0
3 (FPC 3)	Prsnt	CW0210108833	ex2200-24t-4g	128	Linecard	NA	2	vcp-255/1/1
							0	vcp-255/1/1

```
Member ID for next new member: None
```

Meaning The `show virtual-chassis` command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the status of each member switch, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected. The output shows that all switches are in the desired **Prsnt** state and that switch-0 and switch-1 are in the master and backup roles.

Troubleshooting the Virtual Chassis

To troubleshoot the configuration of an EX2200 Virtual Chassis, perform these tasks:

- [Troubleshooting the Assignment of Roles on page 71](#)
- [Troubleshooting the VCPs on page 72](#)

Troubleshooting the Assignment of Roles

Problem The master and backup roles are not assigned to the member switches that you want to function in these roles.

Solution Modify the mastership priority values.

To quickly modify the mastership priority of any switch in the Virtual Chassis (in this case, member ID 1), enter the following command:

```
[edit virtual-chassis]
user@switch-0# set member 1 mastership-priority 255
```

Troubleshooting the VCPs

Problem The VCPs are down.

- Solution**
1. Check to make sure that you have cabled the appropriate ports.
 2. Check to make sure that the cables are seated properly.
 3. Check the output of the **show virtual-chassis vc-port** command to ensure you properly configured the VCPs. Enter the **request virtual-chassis vc-port** command to reconfigure the VCPs, if needed.

Related Documentation

- [Configuring an EX2200 Virtual Chassis \(CLI Procedure\) on page 176](#)

Example: Configuring an EX3300 Virtual Chassis with a Master and Backup

A Virtual Chassis configuration is a scalable switch. You can provide secure, redundant network accessibility with a basic two-member EX3300 Virtual Chassis and later expand the Virtual Chassis configuration to provide additional access ports as your office grows.

This example describes how to configure an EX3300 Virtual Chassis with a master and backup in a single wiring closet. You could use the same software configuration, however, if the EX3300 switches were connected across wiring closets.

- [Requirements on page 72](#)
- [Overview and Topology on page 73](#)
- [Configuration on page 73](#)
- [Verification on page 74](#)
- [Troubleshooting the Virtual Chassis on page 76](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.3 or later for EX Series switches
- Two EX3300 switches

Before you begin, be sure you have:

1. Rack-mounted the switches. See *Mounting an EX3300 Switch*.
2. Cabled the switches. See *Virtual Chassis Cabling Configuration Examples for EX3300 Switches*.

Overview and Topology

A Virtual Chassis configuration allows you to accommodate the networking needs of a growing office. The default configuration of a two-member Virtual Chassis includes a master and a backup switch. In addition to providing more access ports than a single switch can provide, a Virtual Chassis configuration provides high availability through redundancy.

This example shows a Virtual Chassis configuration composed of two EX3300 switches. By default, EX3300 switches have two uplink ports configured as Virtual Chassis ports (VCPs). The EX3300 Virtual Chassis is connected using these VCPs.

After you interconnect the switches with the VCPs and power on the switches, the VCPs are operational. The mastership priorities and member IDs are assigned by the software. The software elects a master based on several criteria, including how long a member switch has belonged to the Virtual Chassis configuration. For additional details, see [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). Therefore, we recommend that you start by powering on only one member switch, the one that you want to function as the master.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis.

The topology for this example consists of two EX3300 switches.

[Table 10 on page 73](#) shows the default configuration settings for the two-member Virtual Chassis.

Table 10: Components of the Basic Virtual Chassis Access Switch Topology

Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX3300 switch	0	Master: mastership priority 128
SWA-1	EX3300 switch	1	Backup: mastership priority 128

Configuration

Configure a Virtual Chassis with a default master and backup in a single wiring closet:

Step-by-Step Procedure

To configure a Virtual Chassis with master and backup:

1. Make sure the VCPs on the rear panel of the member switches are properly cabled. See *Virtual Chassis Cabling Configuration Examples for EX3300 Switches*.
2. Power on SWA-0 (the member switch that you want to function as the master).
3. Check the front-panel LCD to confirm that the switch has powered on correctly.
4. Run the EZSetup program on SWA-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* or *Connecting and Configuring an EX Series Switch (J-Web Procedure)* for details.

5. Configure SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired.

```
[edit]
```

```
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

6. (Optional, but recommended) Disable the split and merge feature:

```
[edit virtual-chassis]
```

```
user@SWA-0# set no-split-detection
```

7. Power on SWA-1.

Verification

To confirm that the Virtual Chassis configuration is operational, perform these tasks:

- [Verifying That the Mastership Priority Is Assigned Appropriately on page 74](#)
- [Verifying That the VCPs Are Operational on page 75](#)

Verifying That the Mastership Priority Is Assigned Appropriately

Purpose Verify that the master, which has been selected by default, is the member switch that you want to function in that role.

- Action**
1. Check the front-panel LCD to confirm that the switch has powered on correctly and that a member ID has been assigned.
 2. List the member switches of the Virtual Chassis configuration.

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0019.e250.47a0
```

```
Mastership
```

```
Neighbor List
```

Member ID	Status	Serial No	Model	priority	Role	ID	Interface
0 (FPC 0)	Prsnt	AK0207360276	ex3300-24t	128	Master*	1	vcp-255/1/2
						1	vcp-255/1/3
1 (FPC 1)	Prsnt	AK0207360281	ex3300-24t	128	Backup	0	vcp-255/1/2
						0	vcp-255/1/3

Member ID for next new member: 2 (FPC 2)

Meaning The `show virtual-chassis` command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected. The output shows that SWA-0, member 0, has been assigned default mastership priority 128. Because SWA-0 is the first member to be powered on, it has the most seniority and is therefore assigned the role of master. SWA-1 is powered on after member 0, so it is assigned the role of backup. The member IDs are displayed on the front panel of the switches. Check and confirm whether the default assignment is satisfactory.

Verifying That the VCPs Are Operational

Purpose Verify that the VCPs interconnecting the switches are operational.

Action Display the VCPs of all the members:

```
user@SWA-0> show virtual-chassis vc-port all-members
fpc0:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Interface
1/2	Configured	Up	10000	1	vcp-255/1/2
1/3	Configured	Up	10000	1	vcp-255/1/3

```
fpc1:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Interface
1/2	Configured	Up	10000	0	vcp-255/1/2
1/3	Configured	Up	10000	0	vcp-255/1/3

Meaning The `show virtual-chassis vc-port` command lists the interfaces that are enabled for the member switches of the Virtual Chassis configuration and shows the status of the

interfaces. The output in this example shows that two of the VCPs are operational and two VCPs are not. A single cable has been used to interconnect vcp-0 of member ID 0 and vcp-0 of member ID 1. That interconnection is sufficient for the switch to be operational. However, we recommend that you connect the second set of VCPs for redundancy.

Troubleshooting the Virtual Chassis

To troubleshoot the configuration of a Virtual Chassis, perform these tasks:

- [Troubleshooting the Assignment of Roles on page 76](#)
- [Troubleshooting the VCPs on page 76](#)

Troubleshooting the Assignment of Roles

Problem The master and backup roles are not assigned to the member switches that you want to function in these roles.

Solution Modify the mastership priority values.

To quickly modify the mastership priority of SWA-1 (member ID 1), copy the following command and paste it into the switch terminal window:

```
[edit virtual-chassis]
user@SWA-1# set member 1 mastership-priority 255
```

Troubleshooting the VCPs

Problem The VCPs are down.

- Solution**
1. Check to make sure that you have cabled the appropriate ports.
 2. Check to make sure that the cables are seated properly.

You should generally cable and interconnect both of the VCPs on the member switches, for redundancy and high availability.

Related Documentation

- [Configuring an EX3300 Virtual Chassis \(CLI Procedure\) on page 181](#)

Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet

A Virtual Chassis configuration is a scalable switch. You can provide secure, redundant network accessibility with a basic two-member EX4200 Virtual Chassis and later expand the Virtual Chassis configuration to provide additional access ports as your office grows.

This example describes how to configure an EX4200 Virtual Chassis with a master and backup in a single wiring closet:

- [Requirements on page 77](#)
- [Overview and Topology on page 77](#)
- [Configuration on page 79](#)
- [Verification on page 79](#)
- [Troubleshooting the Virtual Chassis on page 81](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.0 or later for EX Series switches
- One EX4200-48P switch
- One EX4200-24T switch
- One XFP uplink module

Before you begin, be sure you have:

1. Rack-mounted the switches.
2. Installed the uplink module. See *Installing an Uplink Module in an EX4200 Switch*.
3. Cabled the switches. See *Connecting a Virtual Chassis Cable to an EX4200 Switch*.

Overview and Topology

A Virtual Chassis configuration allows you to accommodate the networking needs of a growing office. The default configuration of a two-member Virtual Chassis includes a master and a backup switch. In addition to providing more access ports than a single switch can provide, a Virtual Chassis configuration provides high availability through redundancy.

This example shows a Virtual Chassis configuration composed of two EX4200 switches. One of the switches has an uplink module with ports that can be configured to connect to a distribution switch or customer edge (CE) router or that can be configured as Virtual Chassis ports (VCPs) to interconnect with a member switch that is located too far for the dedicated VCP cabling. (The network interfaces on EX4200-24F switches can also be configured as VCPs.) For information on configuring the uplink ports as trunk ports to a distribution switch, see *Configuring Gigabit Ethernet Interfaces (CLI Procedure)*. For an example of configuring uplink ports as VCPs, see [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#).

By default, after you interconnect the switches with the dedicated VCPs and power on the switches, the VCPs are operational. The mastership priorities and member IDs are assigned by the software. The software elects a master based on several criteria, including how long a member switch has belonged to the Virtual Chassis configuration. For

additional details, see [“Understanding How the Master in a Virtual Chassis Is Elected”](#) on [page 36](#). Therefore, we recommend that you start by powering on only one member switch, the one that you want to function as the master.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis.

The Virtual Chassis configuration provides networking access for 50 onsite workers, who are sitting within range of a single wiring closet. The workers all use personal computers and VoIP phones. As the office grows, you can add more EX4200 switches to meet increased needs for access ports.

The topology for this example consists of two switches, one of which contains an uplink module:

- One EX4200-48P switch (SWA-0) with 48 access ports, all of which support PoE
- One EX4200-24T switch (SWA-1) with 24 access ports, including eight ports that support PoE
- One XFP uplink module, with two 10-Gigabit Ethernet ports, is installed in the EX4200-48P switch


[Table 11 on page 78](#) shows the default configuration settings for the two-member Virtual Chassis.

Table 11: Components of the Basic Virtual Chassis Access Switch Topology

Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX4200-48P switch	0	Master: mastership priority 128
SWA-1	EX4200-24T switch	1	Backup: mastership priority 128

[Figure 8 on page 78](#) shows that SWA-0 and SWA-1 are interconnected with their dedicated VCPs on the rear panel. The LCD on the front displays the member ID and role. SWA-0 also includes an uplink module. Its uplink ports can be used to connect to a distribution switch.

Figure 8: Basic EX4200 Virtual Chassis with Master and Backup



Configuration

Configure a Virtual Chassis with a default master and backup in a single wiring closet:

Step-by-Step Procedure

To configure a Virtual Chassis with master and backup:

1. Make sure the VCPs on the rear panel of the member switches are properly cabled. See *Virtual Chassis Cabling Configuration Examples for EX4200 Switches*.
2. Power on SWA-0 (the member switch that you want to function as the master).
3. Check the front-panel LCD to confirm that the switch has powered on correctly.
4. Run the EZSetup program on SWA-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* or *Connecting and Configuring an EX Series Switch (J-Web Procedure)* for details.
5. Configure SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired.

```
[edit]
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

6. (Optional, but recommended) Disable the split and merge feature:

```
[edit virtual-chassis]
user@SWA-0# set no-split-detection
```

7. Power on SWA-1.

Verification

To confirm that the Virtual Chassis configuration is operational, perform these tasks:

- [Verifying That the Mastership Priority Is Assigned Appropriately on page 79](#)
- [Verifying That the VCPs Are Operational on page 80](#)

Verifying That the Mastership Priority Is Assigned Appropriately

Purpose Verify that the master, which has been selected by default, is the member switch that you want to function in that role.

- Action**
1. Check the front-panel LCD to confirm that the switch has powered on correctly and that a member ID has been assigned.

2. List the member switches of the Virtual Chassis configuration.

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0019.e250.47a0
```

Member ID	Status	Serial No	Model	Mastership priority	Role	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	AK0207360276	ex4200-48p	128	Master*	1	vcp-0
						1	vcp-1
1 (FPC 1)	Prsnt	AK0207360281	ex4200-24t	128	Backup	0	vcp-0
						0	vcp-1

```
Member ID for next new member: 2 (FPC 2)
```

Meaning The `show virtual-chassis` command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected. The output shows that SWA-0, member 0, has been assigned default mastership priority 128. Because SWA-0 is the first member to be powered on, it has the most seniority and is therefore assigned the role of master. SWA-1 is powered on after member 0, so it is assigned the role of backup. The member IDs are displayed on the front panel of the switches. Check and confirm whether the default assignment is satisfactory.

Verifying That the VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting the switches are operational.

Action Display the VCPs of all the members:

```
user@SWA-0> show virtual-chassis vc-port all-members
fpc0:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	Up	32000	1	vcp-1
vcp-1	Dedicated	Up	32000	1	vcp-0

```
fpc1:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	Up	32000	1	vcp-1
vcp-1	Dedicated	Up	32000	1	vcp-0

Meaning The `show virtual-chassis vc-port` command lists the interfaces that are enabled for the member switches of the Virtual Chassis configuration and shows the status of the interfaces. The output in this example shows that two of the VCPs are operational and two VCPs are not. A single cable has been used to interconnect vcp-0 of member ID 0 and vcp-0 of member ID 1. That interconnection is sufficient for the switch to be operational. However, we recommend that you connect the second set of VCPs for redundancy.

Troubleshooting the Virtual Chassis

To troubleshoot the configuration of a Virtual Chassis, perform these tasks:

- [Troubleshooting the Assignment of Roles on page 81](#)
- [Troubleshooting the VCPs on page 82](#)

Troubleshooting the Assignment of Roles

Problem The master and backup roles are not assigned to the member switches that you want to function in these roles.

Solution Modify the mastership priority values.

To quickly modify the mastership priority of SWA-1 (member ID 1), copy the following command and paste it into the switch terminal window:

```
[edit virtual-chassis]
user@SWA-1# set member 1 mastership-priority 255
```

Troubleshooting the VCPs

Problem The VCPs are down.

Solution

1. Check to make sure that you have cabled the appropriate ports.
2. Check to make sure that the cables are seated properly.

You should generally cable and interconnect both of the VCPs on the member switches, for redundancy and high availability.

Related Documentation

- [Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet on page 92](#)
- [Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration on page 107](#)
- [Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File on page 127](#)
- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)

Example: Configuring an EX4500 Virtual Chassis with a Master and Backup in a Single Wiring Closet

A Virtual Chassis configuration is a scalable switch. You can provide secure, redundant network accessibility with a basic two-member EX4500 Virtual Chassis configuration and later expand the Virtual Chassis configuration to provide additional access ports as your office grows.

This example describes how to configure an EX4500 Virtual Chassis with a master and backup in a single wiring closet:

- [Requirements on page 82](#)
- [Overview and Topology on page 83](#)
- [Configuration on page 84](#)
- [Verification on page 85](#)
- [Troubleshooting the Virtual Chassis on page 86](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.1 or later for EX Series switches



NOTE: You must use Junos OS Release 11.4 or later if you are including three or more EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

- Two EX4500 switches with Virtual Chassis modules

Before you begin, be sure you have:

1. Rack-mounted the switches. See *Mounting an EX4500 Switch*.
2. Cabled the switches but not the Virtual Chassis ports (VCPs).
3. Installed the same version of Junos OS Release 11.1 or later on both the switches

Overview and Topology

A Virtual Chassis configuration allows you to accommodate the networking needs of a growing office. The default configuration of a two-member Virtual Chassis includes a master and a backup switch. In addition to providing more access ports than a single switch can provide, a Virtual Chassis configuration provides high availability through redundancy.

After you interconnect the switches using the dedicated VCPs and power on the switches, the VCPs are operational. The mastership priorities and member IDs are assigned by the software. The software elects a master based on several criteria, including how long a member switch has belonged to the Virtual Chassis configuration. For additional details, see [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). Therefore, we recommend that you start by powering on only one member switch, the one that you want to function as the master.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a Virtual Chassis.

The Virtual Chassis configuration provides networking access for onsite workers who are sitting within the range of a single wiring closet. The workers all use personal computers and VoIP phones. As the office grows, you can add EX4200 switches to meet increased needs for access ports.


The topology for this example consists of two EX4500 switches.

[Table 12 on page 84](#) shows the default configuration settings for the two-member Virtual Chassis.

Table 12: Components of the Basic Virtual Chassis Access Switch Topology

Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX4500 switch	0	Master: mastership priority 128
SWA-1	EX4500 switch	1	Backup: mastership priority 128

Figure 9 on page 84 shows that switches SWA-0 and SWA-1 are interconnected with their dedicated VCPs on the rear panel. The LCD on the front displays the member ID and role.

Figure 9: Basic EX4500 Virtual Chassis with Master and Backup

Configuration

Configure a Virtual Chassis with a default master and backup in a single wiring closet:

Step-by-Step Procedure

To configure a Virtual Chassis with master and backup:

1. Power on SWA-0 (the member switch that you want to function as the master).
2. Power on SWA-1 (the member switch that you want to function as the backup).
3. Set the PIC mode to Virtual Chassis mode on both switches:


```
user@swi tch> request chassis pic-mode virtual-chassis
```
4. Run the EZSetup program on SWA-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.
5. Cable the Virtual Chassis member switches together.
6. (Optional) Configure SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired:

```
[edit]
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

7. (Optional, but recommended) Disable the split and merge feature:


```
[edit virtual-chassis]
user@switch# set no-split-detection
```

Verification

To confirm that the Virtual Chassis configuration is operational, perform these tasks:

- [Verifying That the Mastership Priority Is Assigned Appropriately on page 85](#)
- [Verifying That the VCPs Are Operational on page 85](#)

Verifying That the Mastership Priority Is Assigned Appropriately

Purpose Verify that the master, which has been selected by default, is the member switch that you want to function in that role.

- Action**
1. Check the front-panel LCD to confirm that the switch has powered on correctly and that a member ID has been assigned.
 2. List the member switches of the Virtual Chassis configuration.

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0019.e250.47a0
```

Member ID	Status	Serial No	Model	Mastership priority	Role	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	AK0207360276	ex4500-40f	128	Master*	1	vcp-0
						1	vcp-1
1 (FPC 1)	Prsnt	AK0207360281	ex4500-40f	128	Backup	0	vcp-0
						0	vcp-1

Member ID for next new member: 2 (FPC 2)

Meaning The `show virtual-chassis` command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected. The output shows that SWA-0, member 0, has been assigned default mastership priority 128. Because SWA-0 is the first member to be powered on, it has the most seniority and is therefore assigned the role of master. SWA-1 is powered on after member 0, so it is assigned the role of backup. The member IDs are displayed on the front panel of the switches. Check and confirm whether the default assignment is satisfactory.

Verifying That the VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting the switches are operational.

Action Display the VCPs of all the members:

```
user@SWA-0> show virtual-chassis vc-port all-members
fpc0:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Neighbor Interface
vcp-0	Dedicated	Up	32000	1	vcp-1
vcp-1	Dedicated	Up	32000	1	vcp-0

```
fpc1:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Neighbor Interface
vcp-0	Dedicated	Up	32000	1	vcp-1
vcp-1	Dedicated	Up	32000	1	vcp-0

Meaning The `show virtual-chassis` command lists the interfaces that are enabled for the member switches of the Virtual Chassis configuration and shows the status of the interfaces. The output in this example shows that two of the VCPs are operational. A single cable has been used to interconnect vcp-0 of member ID 0 and vcp-0 of member ID 1. That interconnection is sufficient for the switch to be operational. However, we recommend that you connect the second set of VCPs for redundancy.

Troubleshooting the Virtual Chassis

To troubleshoot the configuration of a Virtual Chassis, perform these tasks:

- [Troubleshooting the Assignment of Roles on page 86](#)
- [Troubleshooting the VCPs on page 86](#)

Troubleshooting the Assignment of Roles

Problem The master and backup roles are not assigned to the member switches that you want to function in these roles.

Solution Modify the mastership priority values.

To quickly modify the mastership priority of SWA-1 (member ID 1), copy the following command and paste it into the switch terminal window:

```
[edit virtual-chassis]
user@SWA-1# set member 1 mastership-priority 255
```

Troubleshooting the VCPs

Problem The VCPs are down.

- Solution**
1. Check to make sure that you have cabled the appropriate ports.
 2. Check to make sure that the cables are seated properly.

We recommend that you interconnect both of the VCPs on the member switches, for redundancy and high availability.

- Related Documentation**
- [Example: Connecting EX4500 Member Switches in a Virtual Chassis Across Wiring Closets on page 121](#)
 - [Example: Configuring a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis on page 139](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)

Example: Expanding an EX3300 Virtual Chassis

An EX3300 Virtual Chassis is a scalable switch composed of multiple interconnected EX3300 switches.

This example describes how to configure an expanding EX3300 Virtual Chassis within a single wiring closet. The process, however, would be identical if you were connecting EX3300 member switches in different wiring closets:

- [Requirements on page 87](#)
- [Overview and Topology on page 87](#)
- [Configuration on page 88](#)
- [Verification on page 90](#)
- [Troubleshooting on page 91](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.3 or later for EX Series switches
- Three EX3300 switches

Before you begin, be sure you have confirmed that the existing EX3300 Virtual Chassis configuration is operating correctly. See [“Verifying That Virtual Chassis Ports Are Operational” on page 285](#).

Overview and Topology

A Virtual Chassis configuration can be expanded without disrupting the site's network connectivity. This example describes adding a member switch to an existing Virtual Chassis configuration to provide additional access ports for connecting more PCs and voice over IP (VoIP) phones at this location. You can continue to expand the Virtual

Chassis configuration with additional members in the same wiring closet, using the same procedure.

If you want to retain the roles of the existing master and backup switches, explicitly configure the mastership priority of these switches, specifying the highest possible value (255) for both the master and the backup.

During expansion, the existing Virtual Chassis configuration can remain powered on and connected to the network. Before powering up the new switch, interconnect it to the other switches using the default VCP uplink ports on the front panel. Do not run the EZSetup program on the added member switch.

This example shows an existing Virtual Chassis configuration composed of two EX3300 switches. The Virtual Chassis configuration is being expanded to include an additional EX3300 switch.

The topology for this example consists of three EX3300 switches.

Table 13 on page 88 shows the configuration settings for the expanded Virtual Chassis.

Table 13: Components of the Expanded Virtual Chassis Access Switch

Member Switch	Hardware	Member ID	Role in Virtual Chassis
SWA-0	EX3300 switch	0	master; mastership priority 255
SWA-1	EX3300 switch	1	backup; mastership priority 255
SWA-2	EX3300 switch	2	linecard; mastership priority 128

Configuration

To expand a Virtual Chassis configuration to include additional member switches within a single wiring closet, perform these tasks:



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis configuration.

CLI Quick Configuration

To maintain the master and backup roles of the existing members and ensure that the new member switch functions in a linecard role, copy the following commands and paste them into the terminal window:

```
[edit]
user@SWA-0# set virtual-chassis member 0 mastership-priority 255
user@SWA-1# set virtual-chassis member 1 mastership-priority 255
```

Step-by-Step Procedure To ensure that the existing member switches retain their current roles and to add another member switch in a linecard role:

1. Configure the mastership priority of SWA-0 (member 0) to be the highest possible value, thereby ensuring that it functions as the master of the expanded Virtual Chassis configuration.

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 255
```

2. Configure the mastership priority of SWA-1 (member 1) to be the highest possible value. This setting is recommended for high availability and smooth transition of mastership in case the original master becomes unavailable.

```
[edit virtual-chassis]
user@SWA-1# set member 1 mastership-priority 255
```

3. Interconnect the unpowered SWA-2 with SWA-0 using the default VCPs on the front panel. See *Virtual Chassis Cabling Configuration Examples for EX3300 Switches* for additional information.

4. Power on SWA-2.

You do not need to run EZSetup on SWA-2. The identification parameters that were set up for the master apply implicitly to all members of the Virtual Chassis configuration. SWA-2 functions in a linecard role, because SWA-0 and SWA-1 have been configured to the highest mastership priority values.

5. Confirm SWA-2 is now included in the Virtual Chassis configuration by checking the front-panel LCD for the member ID of this switch.

6. Cable the other VCP on SWA-2 to the Virtual Chassis.



NOTE: If you immediately cable both VCPs on SWA-2 into the existing Virtual Chassis, SWA-0 or SWA-1 might become nonoperational for several seconds. Network traffic to one of the switches is dropped during the downtime.

The switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Verification

To verify that the new switch has been added in the linecard role and that its VCPs are operational, perform these tasks:

- [Verifying That the New Switch Has Been Added in a Linecard Role on page 90](#)
- [Verifying That the VCPs Are Operational on page 90](#)

Verifying That the New Switch Has Been Added in a Linecard Role

Purpose Verify that SWA-2 has been added in a linecard role to the Virtual Chassis configuration.

Action Use the `show virtual-chassis` command to list the member switches with their member IDs, mastership priority values, and assigned roles.

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0000.e255.00e0
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex3300-24t	255	Master*	1 vcp-255/1/2 2 vcp-255/1/3
1 (FPC 1)	Prsnt	def456	ex3300-24t	255	Backup	2 vcp-255/1/2 0 vcp-255/1/3
2 (FPC 2)	Prsnt	abd231	ex3300-24t	128	Linecard	0 vcp-255/1/2 1 vcp-255/1/3

Meaning The `show virtual-chassis` command lists the member switches of the Virtual Chassis configuration with the member IDs and mastership priority values. It also displays the neighbor members with which each member is interconnected. This output shows that SWA-2 has been assigned member ID 2 and has the default mastership priority value 128. Because the mastership priority is lower than the mastership priority of the other members, SWA-2 functions in the linecard role. You can continue to add more member switches, following the same procedure. It is possible to have multiple members in linecard roles with the same mastership priority value.

Verifying That the VCPs Are Operational

Purpose Verify that the VCPs interconnecting the member switches are operational.

Action List the VCP interfaces on the Virtual Chassis configuration.

```
user@SWA-0>show virtual-chassis vc-port all-members
```

fpc0:		

Interface or PIC / Port	Type	Status
1/2	Configured	Up
1/3	Configured	Up
fpc1:		

Interface or PIC / Port	Type	Status
1/2	Configured	Up
1/3	Configured	Up
fpc2:		

Interface or PIC / Port	Type	Status
1/2	Configured	Up
1/3	Configured	Up

Meaning The `show virtual-chassis vc-port all-members` command lists all the interfaces for the Virtual Chassis configuration. In this case, no VCPs have been configured. However, the VCPs are automatically configured and enabled when you interconnect member switches using the default VCP uplink ports. We recommend that you interconnect the member switches using both VCPs for redundancy. The VCP interfaces are identified simply as **vcp-0** and **vcp-1**. The **fpc** number is the same as the member ID.

Troubleshooting

To troubleshoot the configuration of an expanded Virtual Chassis, perform these tasks:

- [Troubleshooting Mastership Priority on page 91](#)
- [Troubleshooting Nonoperational VCPs on page 92](#)

Troubleshooting Mastership Priority

Problem You want to designate a different member as the master.

Solution Change the mastership priority value or values of the switches, designating the highest mastership priority value for the switch that you want to be master.

1. Lower the mastership priority of the existing master (member 0).

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 1
```

2. Set the mastership priority of the member that you want to be the master to the highest possible value (255):

```
[edit virtual-chassis]
user@SWA-2# set member 2 mastership-priority 255
```

Troubleshooting Nonoperational VCPs

Problem The VCP interface shows a status of **down**.

Solution Check the cable to make sure that it is properly and securely connected to the VCPs.

Related Documentation

- [Configuring an EX3300 Virtual Chassis \(CLI Procedure\) on page 181](#)

Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet

A Virtual Chassis is a scalable switch composed of multiple interconnected EX4200 and EX4500 switches.

This example describes how to configure an expanding EX4200 Virtual Chassis within a single wiring closet:

- [Requirements on page 92](#)
- [Overview and Topology on page 93](#)
- [Configuration on page 94](#)
- [Verification on page 96](#)
- [Troubleshooting on page 97](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.0 or later for EX Series switches
- One EX4200-48P switch
- One EX4200-24T switch
- One EX4200-24P switch
- One XFP uplink module

Before you begin, be sure you have confirmed that the existing EX4200 Virtual Chassis configuration is operating correctly. See [“Verifying That Virtual Chassis Ports Are Operational” on page 285](#).

Overview and Topology

A Virtual Chassis configuration can be expanded without disrupting the site's network connectivity. This example describes adding a member switch to an existing Virtual Chassis configuration to provide additional access ports for connecting more PCs and Voice over IP (VoIP) phones at this location. You can continue to expand the Virtual Chassis configuration with additional members in the same wiring closet, using the same procedure. If you want to expand the Virtual Chassis configuration to include member switches in another wiring closet, see [“Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets”](#) on page 113.

If you want to retain the roles of the existing master and backup switches, explicitly configure the mastership priority of these switches, specifying the highest possible value (255) for both the master and the backup.

During expansion, the existing Virtual Chassis configuration can remain powered on and connected to the network. Before powering up the new switch, interconnect it to the other switches using the dedicated VCPs on the rear panel. Do not run the EZSetup program on the added member switch.

This example shows an existing Virtual Chassis configuration composed of two EX4200 switches. The Virtual Chassis configuration is being expanded to include an EX4200-24P switch.

The topology for this example consists of:

- One EX4200-48P switch (SWA-0) with 48 access ports, all of which support Power over Ethernet (PoE)
- One EX4200-24T switch (SWA-1) with 24 access ports, including eight ports that support PoE
- One EX4200-24P switch (SWA-2) with 24 access ports, all of which support PoE
- One uplink module with two 10-gigabit ports is installed in the EX4200-48P switch. These ports can be configured as trunk ports to connect to a distribution switch or customer edge (CE) router or as Virtual Chassis ports (VCPs) to interconnect with a member switch that is located too far for dedicated VCP cabling. (The uplink module ports on the SFP and SFP+ uplink modules and the SFP network interfaces on the EX4200-24F switches can also be used for these purposes.) For information on configuring the uplink ports as trunk ports to a distribution switch, see [Configuring Gigabit Ethernet Interfaces \(CLI Procedure\)](#). For information on configuring uplink ports as VCPs, see [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port”](#) on page 223.

Table 14 on page 93 shows the configuration settings for the expanded Virtual Chassis.

Table 14: Components of the Expanded Virtual Chassis Access Switch


Member Switch	Hardware	Member ID	Role in Virtual Chassis
SWA-0	EX4200-48P switch	0	master; mastership priority 255

Table 14: Components of the Expanded Virtual Chassis Access Switch (continued)

Member Switch	Hardware	Member ID	Role in Virtual Chassis
SWA-1	EX4200-24T switch	1	backup; mastership priority 255
SWA-2	EX4200-24P switch	2	linecard; mastership priority 128

Figure 10 on page 94 shows that the three member switches (SWA-0, SWA-1 and SWA-2) are interconnected with their dedicated VCPs on the rear panel. The LCD on the front displays the member ID and role. SWA-0 also includes an uplink module. Its uplink ports can be used to connect to a distribution switch.

Figure 10: Expanded EX4200 Virtual Chassis in a Single Wiring Closet



Configuration

To expand a Virtual Chassis configuration to include additional member switches within a single wiring closet, perform these tasks:



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis configuration.

CLI Quick Configuration

To maintain the master and backup roles of the existing members and ensure that the new member switch functions in a linecard role, copy the following commands and paste them into the terminal window:

```
[edit]
user@SWA-0# set virtual-chassis member 0 mastership-priority 255
user@SWA-1# set virtual-chassis member 1 mastership-priority 255
```

Step-by-Step Procedure To ensure that the existing member switches retain their current roles and to add another member switch in a linecard role:

1. Configure the mastership priority of SWA-0 (member 0) to be the highest possible value, thereby ensuring that it functions as the master of the expanded Virtual Chassis configuration.

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 255
```

2. Configure the mastership priority of SWA-1 (member 1) to be the highest possible value. This setting is recommended for high availability and smooth transition of mastership in case the original master becomes unavailable.

```
[edit virtual-chassis]
user@SWA-1# set member 1 mastership-priority 255
```

3. Interconnect the unpowered SWA-2 with SWA-0 using the dedicated VCPs on the rear panel. See *Virtual Chassis Cabling Configuration Examples for EX4200 Switches* for additional information.

4. Power on SWA-2.

You do not need to run EZSetup on SWA-2. The identification parameters that were set up for the master apply implicitly to all members of the Virtual Chassis configuration. SWA-2 functions in a linecard role, because SWA-0 and SWA-1 have been configured to the highest mastership priority values.

5. Confirm SWA-2 is now included in the Virtual Chassis configuration by checking the front-panel LCD for the member ID of this switch.

6. Cable the other VCP on SWA-2 to the Virtual Chassis.



NOTE: If you immediately cable both VCPs on SWA-2 into the existing Virtual Chassis, SWA-0 or SWA-1 might become nonoperational for several seconds. Network traffic to one of the switches is dropped during the downtime.

The switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Verification

To verify that the new switch has been added in the linecard role and that its VCPs are operational, perform these tasks:

- [Verifying That the New Switch Has Been Added in a Linecard Role on page 96](#)
- [Verifying That the VCPs Are Operational on page 96](#)

Verifying That the New Switch Has Been Added in a Linecard Role

Purpose Verify that SWA-2 has been added in a linecard role to the Virtual Chassis configuration.

Action Use the [show virtual-chassis](#) command to list the member switches with their member IDs, mastership priority values, and assigned roles.

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0000.e255.00e0
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4200-48p	255	Master*	1 vcp-0 2 vcp-1
1 (FPC 1)	Prsnt	def456	ex4200-24t	255	Backup	2 vcp-0 0 vcp-1
2 (FPC 2)	Prsnt	abd231	ex4200-24p	128	Linecard	0 vcp-0 1 vcp-1

Meaning The [show virtual-chassis](#) command lists the member switches of the Virtual Chassis configuration with the member IDs and mastership priority values. It also displays the neighbor members with which each member is interconnected. This output shows that SWA-2 has been assigned member ID 2 and has the default mastership priority value 128. Because the mastership priority is lower than the mastership priority of the other members, SWA-2 functions in the linecard role. You can continue to add more member switches, following the same procedure. It is possible to have multiple members in linecard roles with the same mastership priority value.

Verifying That the VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting the member switches are operational.

Action List the VCP interfaces on the Virtual Chassis configuration.

```
user@SWA-0>show virtual-chassis vc-port all-members
```

fpc0:		

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up
fpc1:		

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up
fpc2:		

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

Meaning The `show virtual-chassis vc-port all-members` command lists all the interfaces for the Virtual Chassis configuration. In this case, no VCP uplinks have been configured. However, the VCP interfaces are automatically configured and enabled when you interconnect member switches using the dedicated VCPs. We recommend that you interconnect the member switches using both VCPs for redundancy. The VCP interfaces are identified simply as **vcp-0** and **vcp-1**. The **fpc** number is the same as the member ID.

Troubleshooting

To troubleshoot the configuration of an expanded Virtual Chassis, perform these tasks:

- [Troubleshooting Mastership Priority on page 97](#)
- [Troubleshooting Nonoperational VCPs on page 98](#)

Troubleshooting Mastership Priority

Problem You want to designate a different member as the master.

Solution Change the mastership priority value or values of the switches, designating the highest mastership priority value for the switch that you want to be master.

1. Lower the mastership priority of the existing master (member 0).

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 1
```

2. Set the mastership priority of the member that you want to be the master to the highest possible value (255):

```
[edit virtual-chassis]
user@SWA-2# set member 2 mastership-priority 255
```

Troubleshooting Nonoperational VCPs

Problem The VCP interface shows a status of **down**.

Solution Check the cable to make sure that it is properly and securely connected to the VCPs.

- Related Documentation**
- [Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration on page 107](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
 - [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)

Example: Adding EX4500 Switches to a Preprovisioned Virtual Chassis

A Virtual Chassis is multiple switches operating as a single network entity. You might want to expand your existing Virtual Chassis by adding EX4500 switches to your Virtual Chassis configuration. You can include up to ten EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

This example describes how to add two EX4500 switches to an existing EX4200 Virtual Chassis that was preprovisioned. A preprovisioned configuration is a Virtual Chassis configuration in which the roles are statically assigned to each member switch:

- [Requirements on page 98](#)
- [Overview and Topology on page 99](#)
- [Configuration on page 100](#)
- [Verification on page 101](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.1 or later for EX Series switches
- Two EX4200 switches interconnected into a Virtual Chassis
- Two standalone EX4500 switches with Virtual Chassis modules

Before you begin, be sure you have:

1. An operational EX4200 Virtual Chassis with two member EX4200 switches that was configured using a preprovisioned configuration.

2. Installed the same version of Junos OS Release 11.1 or later on all members of the Virtual Chassis and on the EX4500 switches.



NOTE: You must use Junos OS Release 11.4 or later if you are including three or more EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

Overview and Topology

You can create an EX4200 Virtual Chassis by cabling two operational EX4200 switches together using the dedicated Virtual Chassis ports (VCPs) on each EX4200 switch. When you preprovision a Virtual Chassis, you configure the roles for each member switch.

Table 15 on page 99 shows the configuration of the two-member EX4200 Virtual Chassis before the EX4500 member switches were added.

Table 15: Components of the EX4200 Virtual Chassis Before the EX4500 Member Switches Are Added

Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX4200 switch	0	Master
SWA-1	EX4200 switch	1	Backup


Table 16 on page 99 shows the configuration of the mixed EX4200 and EX4500 Virtual Chassis after the EX4500 member switches are added to the Virtual Chassis and the roles are assigned.

Table 16: Final Mixed EX4200 and EX4500 Virtual Chassis Components

Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX4200 switch	0	Linecard
SWA-1	EX4200 switch	1	Linecard
SWA-2	EX4500 switch	2	Master
SWA-3	EX4500 switch	3	Backup

Figure 11 on page 100 shows the hardware topology of the mixed EX4200 and EX4500 Virtual Chassis.

Figure 11: Mixed EX4200 and EX4500 Virtual Chassis Topology (Preprovisioned Configuration)



Configuration

Step-by-Step Procedure

To add two EX4500 switches to an existing EX4200 Virtual Chassis that was preprovisioned:

1. Log in to the EX4200 Virtual Chassis.
2. Set all member switches into mixed mode:


```
user@switch> request virtual-chassis mode mixed all-members
```
3. Reboot all member switches in the Virtual Chassis:


```
user@switch> request system reboot
```
4. Power on SWA-2 and SWA-3, the EX4500 switches.
5. Set the PIC mode to the Virtual Chassis mode on both SWA-2 and SWA-3:


```
user@switch> request chassis pic-mode virtual-chassis
```
6. On each of the switches SWA-2 and SWA-3, configure the switch as a member of the mixed EX4200 and EX4500 Virtual Chassis:


```
user@switch> request virtual-chassis mode mixed
```
7. Reboot the EX4500 switches.
8. Log in to the EX4200 Virtual Chassis and change the roles of the EX4200 member switches to **line-card**:


```
[edit virtual-chassis]
user@SWA-0# set member 0 role line-card
user@SWA-0# set member 1 role line-card
```


9. Add the EX4500 switches to the Virtual Chassis configuration:

```
[edit virtual-chassis]
user@SWA-0# set member 2 serial-number ghi789 role routing-engine
user@SWA-0# set member 3 serial-number jkl012 role routing-engine
```

10. Cable SWA-2 and SWA-3 into the Virtual Chassis using the dedicated VCPs.



NOTE: We recommend cabling one VCP into the Virtual Chassis, waiting for the new switch to be recognized by the Virtual Chassis, then cabling the other VCP on the new switch into the Virtual Chassis.

If you immediately cable both VCPs into the existing Virtual Chassis, one of the Virtual Chassis member switches might become nonoperational for several seconds. Network traffic to that member switch is dropped during the downtime.

The switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Verification

To confirm that the Virtual Chassis configuration is operational, perform these tasks:

- [Verifying Virtual Chassis Availability and Roles on page 101](#)

Verifying Virtual Chassis Availability and Roles

Purpose Verify that the Virtual Chassis is up and that the member switches are in the correct roles.

Action List the member switches and roles.

```
user@SWA-2> show virtual-chassis
```

```
Virtual Chassis ID: 0019.e250.47a0
```

Member ID	Status	Serial No	Model	Mastership priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	AK02073602764	ex4200-48p	0	Linecard	1 vcp-0
1 (FPC 1)	Prsnt	AK02073602814	ex4200-48p	0	Linecard	3 vcp-1 0 vcp-0
2 (FPC 2)	Prsnt	AK02073602844	ex4500-40f	129	Master*	2 vcp-1 1 vcp-0
3 (FPC 3)	Prsnt	AK02073602088	ex4500-40f	129	Backup	3 vcp-1 2 vcp-0

```
0 vcp-1
```

Meaning The [show virtual-chassis](#) command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected. The output shows that the switches have the correct mastership priorities and roles.

- Related Documentation**
- [Example: Connecting EX4500 Member Switches in a Virtual Chassis Across Wiring Closets on page 121](#)
 - [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)

Example: Adding an EX4500 Switch to a Nonprovisioned Virtual Chassis

A Virtual Chassis is multiple switches operating as a single network entity. You might want to expand an existing Virtual Chassis by adding EX4500 switches to it. You can include up to ten EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

This example describes how to add two EX4500 switches to an existing EX4200 Virtual Chassis that was nonprovisioned. A nonprovisioned configuration is a Virtual Chassis whose roles were assigned automatically rather than configured statically (preprovisioned).

- [Requirements on page 102](#)
- [Overview and Topology on page 103](#)
- [Configuration on page 104](#)
- [Verification on page 106](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.1 or later for EX Series switches
- Two EX4200 switches interconnected into a nonprovisioned Virtual Chassis
- Two standalone EX4500 switches with Virtual Chassis modules

Before you begin, be sure you have:

1. An operational EX4200 Virtual Chassis with two member EX4200 switches that was configured using a nonprovisioned configuration.
2. Installed the same version of Junos OS Release 11.1 or later for all members of the Virtual Chassis and on the EX4500 switches.



NOTE: You must use Junos OS Release 11.4 or later if you are including three or more EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

Overview and Topology

You can create an EX4200 Virtual Chassis by cabling two operational EX4200 switches together using the dedicated Virtual Chassis ports (VCPs) on each EX4200 switch. When you cable a Virtual Chassis using the dedicated VCPs, the switches run a master election algorithm that determines the Virtual Chassis roles for each member switch. The master election algorithm first checks the mastership priority ID. The mastership priority ID is any number between 0 and 255. The switch with the higher mastership priority ID is elected into the master role and the other switch, unless it has been configured with a mastership priority value of 0, is elected into the backup role.

The default mastership priority ID for an EX4200 or EX4500 switch is 128. Both EX4200 switches are using this default mastership priority ID in the operational EX4200 Virtual Chassis in this example.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a Virtual Chassis.

Table 17 on page 103 shows the default configuration settings for the two-member Virtual Chassis before the EX4500 member switches are added to the Virtual Chassis.

Table 17: Components of the EX4200 Virtual Chassis Before the EX4500 Member Switches Are Added


Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX4200 switch	0	Master: mastership priority 128
SWA-1	EX4200 switch	1	Backup: mastership priority 128

Table 18 on page 104 shows the configuration of the mixed EX4200 and EX4500 Virtual Chassis after the EX4500 member switches are added to the Virtual Chassis and the EX4500 switches have been configured in the master and backup roles.

Table 18: Final Mixed EX4200 and EX4500 Virtual Chassis Components

Member Switch	Hardware	Member ID	Role and Priority
SWA-0	EX4200 switch	0	Linecard: mastership priority 0
SWA-1	EX4200 switch	1	Linecard: mastership priority 0
SWA-2	EX4500 switch	2	Master: mastership priority 255
SWA-3	EX4500 switch	3	Backup: mastership priority 255

Figure 12 on page 104 shows the hardware topology of the mixed EX4200 and EX4500 Virtual Chassis.

Figure 12: Mixed EX4200 and EX4500 Virtual Chassis Topology (Nonprovisioned Configuration)

Configuration

Step-by-Step Procedure

To add two EX4500 switches to an existing EX4200 Virtual Chassis:

1. Log in to the EX4200 Virtual Chassis.
2. Set all member switches into mixed mode:


```
user@switch> request virtual-chassis mode mixed all-members
```
3. Reboot all member switches in the Virtual Chassis:


```
user@switch> request system reboot
```
4. Power on SWA-2, the EX4500 switch that you want to function in the master role.

5. Power on SWA-3, the EX4500 switch that you want to function in the backup role.
6. Set the PIC mode to the Virtual Chassis mode on both SWA-2 and SWA-3:

`user@switch> request chassis pic-mode virtual-chassis`
7. Configure SWA-2 and SWA-3 as a member of the mixed EX4200 and EX4500 Virtual Chassis:

`user@switch> request virtual-chassis mode mixed`
8. Reboot the EX4500 switches.
9. Cable SWA-2 into the Virtual Chassis using the dedicated VCP on the back of the EX4200 member switch and the dedicated VCP on the Virtual Chassis module in the EX4500 switch.



NOTE: We recommend cabling one VCP into the Virtual Chassis, waiting for the new switch to be recognized by the Virtual Chassis, then cabling the other VCP on the new switch into the Virtual Chassis.

If you immediately cable both VCPs into the existing Virtual Chassis, one of the Virtual Chassis member switches might become nonoperational for several seconds. Network traffic to that member switch is dropped during the downtime.

The switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

10. Cable SWA-3 into the Virtual Chassis using the dedicated VCP on the back of the EX4200 member switch and the dedicated VCP on the Virtual Chassis module in the EX4500 switch.



NOTE: We recommend cabling one VCP into the Virtual Chassis, waiting for the new switch to be recognized by the Virtual Chassis, then cabling the other VCP on the new switch into the Virtual Chassis.

If you immediately cable both VCPs into the existing Virtual Chassis, one of the Virtual Chassis member switches might become nonoperational for several seconds. Network traffic to that member switch is dropped during the downtime.

The switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

-
11. Log in to the Virtual Chassis and set the mastership priority for the EX4200 switches to 0 and the EX4500 switches to 255:

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 0
user@SWA-0# set member 1 mastership-priority 0
user@SWA-0# set member 2 mastership-priority 255
user@SWA-0# set member 3 mastership-priority 255
```



NOTE: A switch with a mastership priority ID of 0 never assumes the master or backup role within a Virtual Chassis. This configuration ensures that the EX4200 member switches remain in the linecard roles even during Virtual Chassis topology changes.

If you want the EX4200 switches to assume the master or backup roles, assign the switches a mastership priority between 1 and 255.

Verification

To confirm that the Virtual Chassis configuration is operational, perform these tasks:

- [Verifying Virtual Chassis Availability and Roles on page 106](#)

Verifying Virtual Chassis Availability and Roles

Purpose Verify that the Virtual Chassis is up and that the member switches are in the correct roles.

Action List the member switches and roles.

```
user@SWA-2> show virtual-chassis
```

```

Virtual Chassis ID: 0019.e250.47a0
Member ID  Status  Serial No  Model  Mastership  Role  Neighbor List
0 (FPC 0)  Prsnt    AK02073602764  ex4200-48p  0  Linecard  1 vcp-0
1 (FPC 1)  Prsnt    AK02073602814  ex4200-48p  0  Linecard  3 vcp-1
2 (FPC 2)  Prsnt    AK02073602844  ex4500-40f  255 Master*  1 vcp-0
3 (FPC 3)  Prsnt    AK02073602088  ex4500-40f  255 Backup  2 vcp-0
0 vcp-1
Member ID for next new member: 4 (FPC 4)

```

Meaning The `show virtual-chassis` command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected. The output shows that the switches have the correct mastership priorities and roles.

- Related Documentation**
- [Example: Connecting EX4500 Member Switches in a Virtual Chassis Across Wiring Closets on page 121](#)
 - [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)

Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration

You can configure a multimember EX4200 Virtual Chassis access switch in a single wiring closet without setting any parameters—by simply cabling the switches together, using the dedicated Virtual Chassis ports (VCPs). You do not need to modify the default configuration to enable these ports. They are operational by default. The Virtual Chassis configuration automatically assigns the master, backup, and linecard roles, based on the sequence in which the switches are powered on and other factors in the master election algorithm.



TIP: We recommend that you explicitly configure the mastership priority of the switches to ensure that the switches continue to perform the desired roles when additional switches are added or other changes occur. However, it is possible to use the default configuration described in this example.

This example describes how to configure a multimember Virtual Chassis in a single wiring closet, using the default role assignments:

- [Requirements on page 108](#)
- [Overview and Topology on page 108](#)
- [Configuration on page 109](#)
- [Verification on page 110](#)
- [Troubleshooting on page 112](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.0 or later for EX Series switches
- Two EX4200-48P switches
- Four EX4200-24P switches

Overview and Topology

A Virtual Chassis configuration is easily expandable. This example shows a Virtual Chassis configuration composed of six EX4200 switches. It provides networking access for 180 onsite workers, who are sitting within range of a single wiring closet. The six combined switches are identified by a single host name and managed through a global management IP address.


To set up a multimember Virtual Chassis configuration within a single wiring closet, you need to run the EZSetup program only once. Connect to the master and run EZSetup to specify its identification, time zone, and network properties. When additional switches are connected through the Virtual Chassis ports (VCPs), they automatically receive the same properties that were specified for the master.

The topology for this example (see [Figure 13 on page 109](#)) consists of six switches:

- Two EX4200-48P switches (SWA-0 and SWA-1) with 48 access ports, all of which support Power over Ethernet (PoE)
- Four EX4200-24P switches (SWA-2, SWA-3, SWA-4, and SWA-5) with 24 access ports, all of which support PoE

[Figure 13 on page 109](#) shows that all the member switches are interconnected with the dedicated VCPs on the rear panel. The LCD on the front displays the member ID and role.

Figure 13: Default Configuration of a Multimember EX4200 Virtual Chassis in a Single Wiring Closet



Configuration

To configure a multimember Virtual Chassis access switch in a single wiring closet using the factory defaults, perform this task:

Step-by-Step Procedure

To configure a multimember Virtual Chassis with default role assignments:

1. Make sure the dedicated VCPs on the rear panel are properly cabled. See *Virtual Chassis Cabling Configuration Examples for EX4200 Switches* for additional information.
2. Power on the switch that you want to function as the master (SWA-0). This example uses one of the larger switches (EX4200-48P) as the master.
3. Check the front panel LCD to confirm that the switch has powered on correctly and that a member ID has been assigned.
4. Run the EZSetup program on SWA-0, the master, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.
5. Configure SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired.

[edit]

```
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

6. After a lapse of at least one minute, power on SWA-1. This example uses the second EX4200-48P switch as the backup.

7. Check the front panel LCD to confirm that the switch has powered on correctly and that a member ID has been assigned.
8. Power on SWA-2, and check the front panels to make sure that the switch is operating correctly.
9. Continue to power on the member switches one by one, checking the front panels as you proceed.

Verification

To confirm that the configuration is working properly, perform these tasks:

- [Verifying the Member IDs and Roles of the Member Switches on page 110](#)
- [Verifying That the VCPs Are Operational on page 111](#)

Verifying the Member IDs and Roles of the Member Switches

Purpose Verify that all the interconnected member switches are included within the Virtual Chassis configuration and that their roles are assigned appropriately.

Action Display the members of the Virtual Chassis configuration:

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0000.e255.00e0
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4200-48p	128	Master*	1 vcp-0 5 vcp-1
1 (FPC 1)	Prsnt	def123	ex4200-48p	128	Backup	2 vcp-0 0 vcp-1
2 (FPC 2)	Prsnt	abd231	ex4200-24p	128	Linecard	3 vcp-0 1 vcp-1
3 (FPC 3)	Prsnt	cab123	ex4200-24p	128	Linecard	4 vcp-0 2 vcp-1
4 (FPC 4)	Prsnt	fed456	ex4200-24p	128	Linecard	5 vcp-0 3 vcp-1
5 (FPC 5)	Prsnt	jk1231	ex4200-24p	128	Linecard	0 vcp-0 4 vcp-1

Meaning The `show virtual-chassis` command lists the member switches of the Virtual Chassis configuration with the member IDs and mastership priority values. It also displays the

neighbor members with which each member is interconnected. The **fpc** number is the same as the member ID.

Verifying That the VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting the member switches are operational.

Action Display the VCP interfaces.

```
user@SWA-0> show virtual-chassis vc-port all-members
```

```
fpc0:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

```
fpc1:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

```
fpc2:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

```
fpc3:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

```
fpc4:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

```
fpc5:
```

Interface or PIC / Port	Type	Status
vcp-0	Dedicated	Up
vcp-1	Dedicated	Up

Meaning The `show virtual-chassis vc-port all-members` command lists the VCP interfaces that are enabled for the member switches of the Virtual Chassis configuration and shows the status of the interfaces. In this case, no VCP uplinks have been configured. However, the VCP interfaces are automatically configured and enabled when you interconnect member switches using the dedicated VCPs. The dedicated VCP interfaces are identified simply as `vcp-0` and `vcp-1`. They do not use the standard interface address (in which the member ID is represented by the first digit). The output in this example shows that all interfaces are operational. The **fpc** number is the same as the member ID.

Troubleshooting

To troubleshoot the configuration of a multimember Virtual Chassis in a single wiring closet, perform these tasks:

- [Troubleshooting Mastership Priority on page 112](#)
- [Troubleshooting Nonoperational VCPs on page 112](#)

Troubleshooting Mastership Priority

Problem You want to explicitly designate one member as the master and another as backup.

Solution Change the mastership priority value of the member that you want to function as master, assigning the highest mastership priority value to that member.



NOTE: These configuration changes are made through the current master, SWA-0.

-
1. Configure mastership priority of member 0 to be the highest possible value.

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 255
```

2. Set the mastership priority of another member that you want to function as the backup member as the same value:

```
[edit virtual-chassis]
user@SWA-0# set member 2 mastership-priority 255
```

Troubleshooting Nonoperational VCPs

Problem The VCP interface shows a status of **down**.

Solution Check the cable to make sure that it is properly and securely connected to the VCPs.

- Related Documentation**
- [Understanding How the Master in a Virtual Chassis Is Elected on page 36](#)
 - [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
 - [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
 - [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)

Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets

An EX4200 Virtual Chassis can be composed of multiple EX4200 switches in different locations. You can install member switches in different wiring closets, interconnecting the member switches by cabling and configuring uplink module ports or SFP network ports on EX4200-24F switches as Virtual Chassis ports (VCPs).

This example shows how to use uplink VCPs to connect Virtual Chassis members that are located too far apart to be connected using the dedicated VCPs. Uplink VCPs can also be used to connect Virtual Chassis members to form link aggregation groups (LAGs). For the latter usage, see [“Example: Configuring Link Aggregation Groups Using EX4200 Uplink Virtual Chassis Ports” on page 161](#).



NOTE: You can also configure the SFP network ports on EX4200-24F switches as VCPs to connect Virtual Chassis member switches across wiring closets and to form LAGs.

This example describes how to configure a Virtual Chassis access switch interconnected across wiring closets:

- [Requirements on page 113](#)
- [Overview and Topology on page 114](#)
- [Configuration on page 116](#)
- [Verification on page 118](#)
- [Troubleshooting on page 120](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.0 or later for EX Series switches
- Four EX4200 switches
- Four XFP uplink modules

Before you interconnect the members of the Virtual Chassis configuration across wiring closets, be sure you have:

1. Installed an uplink module in each member switch. See *Installing an Uplink Module in an EX4200 Switch*.
2. Powered on and connected the switch in the master role, SWA-0, and run the EZSetup program (see [Table 19 on page 115](#) for switch names used in this example). See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.
3. Configured SWA-0 with the virtual management Ethernet (VME) interface for remote, out-of-band management of the Virtual Chassis configuration, if desired. See [“Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis \(CLI Procedure\)” on page 231](#).
4. Interconnected SWA-0 and SWA-1 using the dedicated VCPs on the rear panel. SWA-1 must not be powered on at this time.
5. Interconnected SWA-2 and SWA-3 using the dedicated VCPs on the rear panel. SWA-2 and SWA-3 must not be powered on at this time.

Overview and Topology

In this example, four EX4200 switches will be interconnected in a Virtual Chassis configuration. Two of these switches (SWA-0 and SWA-1) are located in wiring closet A, and the two other switches (SWA-2 and SWA-3) are located in wiring closet B.

For ease of monitoring and manageability, we want to interconnect all four switches as members of a Virtual Chassis configuration. Prior to configuring the Virtual Chassis, we installed uplink modules in each of the member switches. In this example, uplink modules are installed in all four members so that there are redundant VCP connections across the wiring closets. If you want to expand this configuration to include more members within these wiring closets, you do not need to add any more uplink modules. Simply use the dedicated VCPs on the rear panel. The redundancy of uplink VCPs provided in this example is sufficient.

We have interconnected the switches in wiring closet A and also interconnected the ones in wiring closet B using the dedicated VCPs. The interfaces for the dedicated VCPs are operational by default. They do not need to be configured.

However, the Virtual Chassis cables that interconnect the dedicated VCPs of member switches within a single wiring closet are not long enough to connect member switches across wiring closets. Instead, we will use the fiber-optic cable connections in the uplink modules to interconnect the member switches in wiring closet A to the member switches in wiring closet B. You only need to interconnect one member switch in wiring closet A to one in wiring closet B to form the Virtual Chassis configuration. However, for redundancy, this example connects uplink module ports from the two member switches in wiring closet A to the two member switches in wiring closet B.

We will specify the highest mastership priority value (255) for SWA-0 to make it the master before we power on SWA-1. Because SWA-0 and SWA-1 are interconnected with the dedicated VCPs, the master detects that SWA-1 is a member of its Virtual Chassis configuration and assigns it a member ID.

We configure SWA-2 in wiring closet B without running EZSetup by directly connecting to the console port. If you wish, you can run EZSetup and specify identification parameters. Later, when you interconnect SWA-2 with SWA-0, the master of the Virtual Chassis configuration, the master overwrites any conflicting parameters.

We will use SWA-2 as the backup of the Virtual Chassis configuration. If a problem occurs in wiring closet A, SWA-2 would take control of the Virtual Chassis configuration and maintain the network connections. We will configure the same mastership priority value for SWA-2 (255) that we configured for the master. Because we power on SWA-0 before we power on SWA-2, SWA-0 has additional prioritization properties that allow it to retain mastership of the Virtual Chassis configuration. We recommend setting identical mastership priority values for the master and backup members for high availability and smooth transition of mastership in case the original master becomes unavailable. (Setting identical mastership priority values for the master and backup members prevents the previous master from pre-empting the master role from the new master when the previous master comes back online.)

After we have configured SWA-2 and set one of its uplink module ports as an uplink VCP, we will interconnect its uplink VCP with an uplink VCP on SWA-0.

Finally, we will power on SWA-3. Because SWA-3 is interconnected with SWA-2 using the dedicated VCPs on the rear panel, the master will detect that SWA-3 is part of the expanded Virtual Chassis configuration and assign it member ID 3. For redundancy, we will configure an uplink VCP on SWA-3 through the master and interconnect that uplink VCP with an uplink VCP on SWA-1.

[Table 19 on page 115](#) shows the Virtual Chassis configuration settings for a Virtual Chassis composed of member switches in different wiring closets.


Table 19: Components of a Virtual Chassis Interconnected Across Multiple Wiring Closets

Switch	Member ID	Role and Priority	Location
SWA-0	0	master; mastership priority 255	Wiring closet A
SWA-1	1	linecard; mastership priority 128	Wiring closet A
SWA-2	2	backup; mastership priority 255	Wiring closet B
SWA-3	3	linecard; mastership priority 128	Wiring closet B

[Figure 14 on page 116](#) shows the different types of interconnections used for this Virtual Chassis configuration. The rear view shows the member switches within each wiring

closet interconnected to each other using the dedicated VCPs. The front view shows the uplink VCPs interconnected across the wiring closets.

Figure 14: EX4200 Virtual Chassis Interconnected Across Wiring Closets



Configuration

To configure the Virtual Chassis across multiple wiring closets, perform this task:

Step-by-Step Procedure

To configure a Virtual Chassis across multiple wiring closets:

1. Configure the mastership priority of SWA-0 (member 0) to be the highest possible value (255), thereby ensuring that it functions as the master of the expanded Virtual Chassis configuration:

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 255
```

2. Prepare the members in wiring closet A for interconnecting with the member switches in wiring closet B by setting uplink VCPs for member 0 and member 1:

```
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 0
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 0 member 1
```



NOTE:

- For redundancy, this example configures an uplink VCP in both SWA-0 and SWA-1.
- This example omits the specification of the member *member-id* option in configuring an uplink VCP for SWA-0 (and, later, for SWA-2). The command applies by default to the switch where it is executed.

3. Prepare SWA-2 in wiring closet B for interconnecting with the Virtual Chassis configuration by configuring its mastership priority to be the highest possible value

(255). Its member ID is currently 0, because it is not yet interconnected with the other members of the Virtual Chassis configuration. It is operating as a standalone switch. Its member ID will change when it is interconnected.

```
[edit virtual-chassis]
user@SWA-2# set member 0 mastership-priority 255
```



NOTE: SWA-2 is configured with the same mastership priority value that we configured for SWA-0. However, the longer uptime of SWA-0 ensures that, once the interconnection is made, SWA-0 functions as the master and SWA-2 functions as the backup.

4. Specify one uplink module port in SWA-2 as an uplink VCP. Its member ID is 0, because it is not yet interconnected with the other members of the Virtual Chassis configuration.



NOTE: The setting of the uplink VCP remains intact when SWA-2 reboots and joins the Virtual Chassis configuration as member 2.

```
user@SWA-2> request virtual-chassis vc-port set pic-slot 1 port 0
```

5. Physically interconnect SWA-0 and SWA-2 across wiring closets using their uplink VCPs. Although SWA-0 and SWA-2 have the same mastership priority value (255), SWA-0 was powered on first and thus has longer uptime. This results in SWA-0 retaining mastership while SWA-2 reboots and joins the now expanded Virtual Chassis configuration as the backup, with member ID 2.
6. Power on SWA-3. It joins the expanded Virtual Chassis configuration as member 3.



NOTE: Member ID 3 is assigned to SWA-3 because SWA-3 was powered on after members 0, 1, and 2.

7. Because SWA-3 is now interconnected as a member of the Virtual Chassis configuration, you can specify a redundant uplink VCP on SWA-3 through the master of the Virtual Chassis configuration:

```
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 0 member 3
```

8. Physically interconnect SWA-3 and SWA-1 across wiring closets using their uplink VCPs. Both SWA-1 and SWA-3 have the default mastership priority value (128) and function in a linecard role.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis.

Results Display the results of the configuration on SWA-0:

```
[edit]
user@SWA-0# show virtual-chassis
  member 0 {
    mastership-priority 255;
  }
  member 1 {
    mastership-priority 128;
  }
  member 2 {
    mastership-priority 255;
  }
  member 3 {
    mastership-priority 128;
  }
}
```

Verification

To confirm that the configuration is working properly, perform these tasks:

- [Verifying the Member IDs and Roles of the Member Switches on page 118](#)
- [Verifying that the Dedicated VCPs and Uplink VCPs Are Operational on page 119](#)

Verifying the Member IDs and Roles of the Member Switches

Purpose Verify that all the interconnected member switches are included within the Virtual Chassis configuration and that their roles are assigned appropriately.

Action Display the members of the Virtual Chassis configuration:

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 000.e255.00e0
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4200-48p	255	Master*	1 vcp-0 1 vcp-1 2 vcp-255/1/0

1 (FPC 1)	Prsnt	def456	ex4200-24t	128	Linecard	0 vcp-0 0 vcp-1 3 vcp-255/1/0
2 (FPC 2)	Prsnt	ghi789	ex4200-48p	255	Backup	3 vcp-0 3 vcp-1 0 vcp-255/1/0
3 (FPC 3)	Prsnt	jkl012	ex4200-24t	128	Linecard	2 vcp-0 2 vcp-1 1 vcp-255/1/0

Meaning The `show virtual-chassis` command lists the member switches interconnected as a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected.

Verifying that the Dedicated VCPs and Uplink VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting member switches in wiring closet A and the uplink VCPs interconnecting the member switches between wiring closets are operational.

Action Display the VCP interfaces:

```
user@SWA-0> show virtual-chassis vc-port all-members
```

fpc0:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	1	vcp-0
vcp-1	Dedicated	2	Up	32000	1	vcp-1
1/0	Configured	-1	Up	1000	2	vcp-255/1/0

fpc1:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	0	vcp-0
vcp-1	Dedicated	2	Up	32000	0	vcp-1
1/0	Configured	-1	Up	1000	3	vcp-255/1/0

fpc2:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
-------------------------------	------	-------------	--------	-----------------	----------------	-----------

vcp-0	Dedicated	1	Up	32000	3	vcp-0
vcp-1	Dedicated	2	Up	32000	3	vcp-1
1/0	Configured	-1	Up	1000	0	vcp-255/1/0

fpc3:						

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	2	vcp-0
vcp-1	Dedicated	2	Up	32000	2	vcp-1
1/0	Configured	-1	Up	1000	1	vcp-255/1/0

Meaning The dedicated VCPs are displayed as **vcp-0** and **vcp-1**. The interface on the switch that has been set as an uplink VCP is displayed as **1/0**. The member interface names of uplink VCPs are of the form **vcp-255/pic/port**—for example, **vcp-255/1/0**. In that name, **vcp-255** indicates that the interface is an uplink VCP, **1** is the uplink PIC number, and **0** is the uplink port number. The **fpc** number is the same as the member ID. The **Trunk ID** is a positive number ID assigned to the LAG formed by the Virtual Chassis. If no LAG is formed, the value is **-1**.

Troubleshooting

To troubleshoot a Virtual Chassis configuration that is interconnected across wiring closets, perform these tasks:

- [Troubleshooting Nonoperational VCPs on page 120](#)

Troubleshooting Nonoperational VCPs

Problem An uplink VCP shows a status of **down**.

Solution

- Check the cable to make sure that it is properly and securely connected to the ports.
- If the VCP is an uplink module port, make sure that it has been explicitly set as an uplink VCP.
- If the VCP is an uplink module port, make sure that you have specified the options (**pic-slot**, **port**, and **member**) correctly.

Related Documentation

- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
- [Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet on page 92](#)
- [Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration on page 107](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)

Example: Connecting EX4500 Member Switches in a Virtual Chassis Across Wiring Closets

An EX4500 switch can be a member of an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis. An EX4500 Virtual Chassis can be composed of two to ten EX4500 switches in different wiring closets or locations. A mixed EX4200 and EX4500 Virtual Chassis can be composed of EX4200 and EX4500 switches in different locations or wiring closets provided that at least one EX4200 switch is connected to one EX4500 switch using the dedicated Virtual Chassis port (VCP) connections available on both switches.

You connect EX4500 member switches in a Virtual Chassis that are in different wiring closets by cabling them together using a 10-Gigabit Ethernet SFP+ connection. You then must configure the 10-Gigabit Ethernet SFP+ connection as a Virtual Chassis port (VCP).

This example shows how to use the 10-Gigabit Ethernet SFP+ ports on EX4500 switches to connect two EX4500 member switches that are located too far apart to be connected using the dedicated VCPs in a mixed EX4200 and EX4500 Virtual Chassis. The procedure to connect two EX4500 switches in an EX4500 Virtual Chassis is identical to the procedure shown in this example.



NOTE: Any 10-Gigabit Ethernet SFP+ connection on an EX4500 switch can be configured as a VCP. An EX4500 switch has network and uplink ports that support 10-Gigabit Ethernet SFP+ transceivers.

This example describes how to connect two EX4500 member switches across wiring closets:

- [Requirements on page 121](#)
- [Overview and Topology on page 122](#)
- [Configuration on page 123](#)
- [Verification on page 126](#)
- [Troubleshooting on page 127](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.1 or later for EX Series switches



NOTE: You must use Junos OS Release 11.4 or later if you are including three or more EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

- Two EX4500 member switches

- Four EX4200 member switches

Before you interconnect the members of the Virtual Chassis configuration across wiring closets, be sure you have:

1. Preprovisioned the Virtual Chassis. See [“Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\)”](#) on page 195 for details.
2. (Optional) Configured SWA-0 with the virtual management Ethernet (VME) interface if you want remote, out-of-band management of the Virtual Chassis configuration. See [“Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis \(CLI Procedure\)”](#) on page 231.
3. Interconnected SWA-0, SWA-1, and SWA-2 using the dedicated VCPs.
4. Interconnected SWA-3, SWA-4, and SWA-5 using the dedicated VCPs.

Overview and Topology

In this example, two EX4500 switches and four EX4200 switches are interconnected in a mixed EX4200 and EX4500 Virtual Chassis configuration. One EX4500 switch (SWA-0) and two EX4200 switches (SWA-1 and SWA-2) are located in wiring closet A, and the other EX4500 switch (SWA-3) and the other two EX4200 switches (SWA-4 and SWA-5) are located in wiring closet B.

For ease of monitoring and manageability, we want to interconnect all six switches as members of a Virtual Chassis configuration.

We have interconnected the switches in wiring closet A and also interconnected the ones in wiring closet B using the dedicated VCPs. The interfaces for the dedicated VCPs are operational by default. They do not need to be configured.

However, the Virtual Chassis cables that interconnect the dedicated VCPs of member switches within a single wiring closet are not long enough to connect member switches across wiring closets. Instead, we will use a 10-Gigabit Ethernet SFP+ connection to interconnect the member switches in wiring closet A to the member switches in wiring closet B. You only need to interconnect one member switch in wiring closet A to one in wiring closet B to form the Virtual Chassis configuration. In this example, this connection will be made by connecting the EX4500 switches in each wiring closet together by configuring a 10-Gigabit Ethernet SFP+ connection as a VCP.

We will preprovision the entire Virtual Chassis to set the roles for all member switches.

We will first power on SWA-0 and preprovision the Virtual Chassis. We will then cable the Virtual Chassis before powering on the other member switches.


[Table 20 on page 123](#) shows the Virtual Chassis configuration settings for a Virtual Chassis composed of member switches in different wiring closets.

Table 20: Components of a Virtual Chassis Interconnected Across Wiring Closets

Switch	Model	Member ID	Role	Location
SWA-0	EX4500 switch	0	Master	Wiring closet A
SWA-1	EX4200 switch	1	Linecard	Wiring closet A
SWA-2	EX4200 switch	2	Linecard	Wiring closet A
SWA-3	EX4500 switch	3	Backup	Wiring closet B
SWA-4	EX4200 switch	4	Linecard	Wiring closet B
SWA-5	EX4200 switch	5	Linecard	Wiring closet B

Figure 15 on page 123 shows the different types of interconnections used for this Virtual Chassis configuration. The rear view shows the member switches within each wiring closet interconnected to each other using the dedicated VCPs. The front view shows the uplink VCPs interconnected across the wiring closets.

Figure 15: Mixed EX4200 and EX4500 Virtual Chassis Interconnected Across Wiring Closets



Configuration

To configure the Virtual Chassis across wiring closets, perform this task:

**Step-by-Step
Procedure**

To configure a Virtual Chassis across wiring closets:

1. Power on SWA-0 (the EX4500 switch acting as member 0).
2. Power on SWA-3 (the EX4500 switch acting as member 3).
3. Set the PIC mode to the Virtual Chassis mode on both SWA-0 and SWA-3:

user@switch> **request chassis pic-mode virtual-chassis**
4. Power on the remaining switches.
5. Configure all switches individually as members of the mixed EX4200 and EX4500 Virtual Chassis:

user@switch> **request virtual-chassis mode mixed**
6. Reboot all switches:

user@switch> **request system reboot**
7. Log back into SWA-0 after the reboot has completed.
8. Run EZSetup on SWA-0 to set the parameters for the entire Virtual Chassis. See *Connecting and Configuring an EX Series Switch (CLI Procedure)*.
9. Preprovision the Virtual Chassis from SWA-0. Specify all members for the Virtual Chassis configuration, listing each switch's serial number with the desired member ID and the desired role.

[edit virtual-chassis]
user@SWA-0# **set preprovisioned**
user@SWA-0# **set member 0 serial-number abc123 role routing-engine**
user@SWA-0# **set member 1 serial-number def456 role line-card**
user@SWA-0# **set member 2 serial-number ghi789 role line-card**
user@SWA-0# **set member 3 serial-number jkl012 role routing-engine**
user@SWA-0# **set member 4 serial-number mno345 role line-card**
user@SWA-0# **set member 5 serial-number pqr678 role line-card**
10. Commit the configuration:

user@SWA-0> **commit synchronize**
11. Prepare the members in wiring closet A for interconnecting with the member switches in wiring closet B by setting the 10-Gigabit Ethernet SFP+ interfaces on SWA-0 as VCPs:

user@SWA-0> **request virtual-chassis vc-port set pic-slot 0 port 0**
user@SWA-0> **request virtual-chassis vc-port set pic-slot 0 port 1**
user@SWA-0> **request virtual-chassis vc-port set pic-slot 0 port 2**
user@SWA-0> **request virtual-chassis vc-port set pic-slot 0 port 3**
user@SWA-0> **request virtual-chassis vc-port set pic-slot 0 port 4**


```

user@SWA-0> request virtual-chassis vc-port set pic-slot 0 port 5
user@SWA-0> request virtual-chassis vc-port set pic-slot 0 port 6
user@SWA-0> request virtual-chassis vc-port set pic-slot 0 port 7

```

12. Prepare the members in wiring closet B for interconnecting with the member switches in wiring closet A by setting the 10-Gigabit Ethernet SFP+ interfaces on SWA-3 as VCPs:

```

user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 0
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 1
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 2
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 3
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 4
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 5
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 6
user@SWA-3> request virtual-chassis vc-port set pic-slot 0 port 7

```

13. Physically interconnect SWA-0 with SWA-1, then interconnect all switches in wiring closet A.
14. Physically interconnect SWA-0 with SWA-3 across wiring closets using the 10-Gigabit Ethernet SFP+ connections.
15. Physically interconnect all switches in wiring closet B.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a Virtual Chassis.

Results Display the results of the configuration on SWA-0:

```

[edit virtual-chassis]
user@SWA-0# show
  member 0 {
    role routing-engine;
    serial-number abc123;
  }
  member 1 {
    role line-card;
    serial-number def456;
  }
  member 2 {
    role line-card;
    serial-number ghi789;
  }
  member 3 {
    role routing-engine;
    serial-number jkl012;
  }
  member 4 {

```

```

    role line-card;
    serial-number mno345;
  }
  member 5 {
    role line-card;
    serial-number pqr678;
  }
}

```

Verification

To confirm that the configuration is working properly, perform these tasks:

- [Verifying the Member IDs and Roles of the Member Switches on page 126](#)

Verifying the Member IDs and Roles of the Member Switches

Purpose Verify that all the interconnected member switches are included within the Virtual Chassis configuration and that their roles are assigned appropriately.

Action Display the members of the Virtual Chassis configuration:

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 000.e255.00e0
```

```
Virtual Chassis Mode: Mixed
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4500-40f	255	Master*	1 vcp-0 2 vcp-1 3 vcp-255/0/0 3 vcp-255/0/1 3 vcp-255/0/2 3 vcp-255/0/3 3 vcp-255/0/4 3 vcp-255/0/5 3 vcp-255/0/6 3 vcp-255/0/7
1 (FPC 1)	Prsnt	def456	ex4200-48p	128	Linecard	0 vcp-0 2 vcp-1
2 (FPC 2)	Prsnt	ghi789	ex4200-48p	128	Linecard	1 vcp-0 0 vcp-1
3 (FPC 3)	Prsnt	jk1012	ex4500-40f	255	Backup	4 vcp-0 5 vcp-1 0 vcp-255/0/0 0 vcp-255/0/1 0 vcp-255/0/2 0 vcp-255/0/3 0 vcp-255/0/4 0 vcp-255/0/5

							0 vcp-255/0/6
							0 vcp-255/0/7
4 (FPC 4)	Prsnt	mno345	ex4200-48p	128	Linecard	3 vcp-0	5 vcp-1
5 (FPC 5)	Prsnt	pqr678	ex4200-48p	128	Linecard	4 vcp-0	3 vcp-1

Meaning The `show virtual-chassis` command lists the member switches interconnected as a Virtual Chassis configuration with the member IDs that have been assigned by the master and the roles. It also displays the neighbor members with which each member is interconnected.

Troubleshooting

To troubleshoot a Virtual Chassis configuration that is interconnected across wiring closets, perform these tasks:

- [Troubleshooting Nonoperational VCPs on page 127](#)

Troubleshooting Nonoperational VCPs

Problem A user-configured VCP shows a status of **down**.

- Solution**
- Check the cable to make sure that it is properly and securely connected to the ports.
 - Make sure the VCP that it has been explicitly set as an uplink VCP.
 - Make sure that you have specified the options (*pic-slot*, *port*, and *member*) correctly.

- Related Documentation**
- [Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\) on page 229](#)

Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File

You can deterministically control both the role and the member ID assigned to each member switch in an EX4200 Virtual Chassis configuration by creating a preprovisioned configuration file.

A preprovisioned configuration file links the serial number of each EX4200 switch in the configuration to a specified member ID and role. The serial number must be specified in the configuration file for the member to be recognized as part of the Virtual Chassis configuration.



NOTE: When you use a preprovisioned configuration, you cannot modify the mastership priority or member ID of member switches through the user interfaces.



NOTE: After you have created a preprovisioned Virtual Chassis configuration, you can use the autoprovisioning feature to add member switches to that configuration. See [“Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\)” on page 201](#).

This example describes how to configure a Virtual Chassis across multiple wiring closets using a preprovisioned configuration file:

- [Requirements on page 128](#)
- [Overview and Topology on page 129](#)
- [Configuration on page 133](#)
- [Verification on page 136](#)
- [Troubleshooting on page 139](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.0 or later for EX Series switches
- Five EX4200-48P switches
- Five EX4200-24T switches
- Four XFP uplink modules

Before you create the preprovisioned configuration of the Virtual Chassis and interconnect the members across the wiring closets, be sure you have:

1. Made a list of the serial numbers of all the switches to be connected as a Virtual Chassis configuration.
2. Noted the desired role (**routing-engine** or **line-card**) of each switch. If you configure the member with a **routing-engine** role, it is eligible to function as a master or backup. If you configure the member with a **line-card** role, it is not eligible to become a master or backup.
3. Installed an uplink module in each of the member switches that will be interconnected across wiring closets. See *Installing an Uplink Module in an EX4200 Switch*.
4. Interconnected the member switches within each wiring closet using the dedicated VCPs on the rear panel of switches. See *Connecting a Virtual Chassis Cable to an EX4200 Switch*.
5. Powered on the switch that you plan to use as the master switch (SWA-0).
6. Run the EZSetup program on SWA-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.

SWA-0 is going to be configured in the example to function as the master of the Virtual Chassis configuration. Thus, the properties that you specify for SWA-0 will apply to the entire Virtual Chassis configuration, including all the member switches that you specify in the preprovisioned configuration file.

7. Configured SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired.

[edit]

```
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

Overview and Topology

You must select two members that you want to make eligible for election as master of the Virtual Chassis configuration. When you list these two members in the preprovisioned configuration file, you designate both members as **routing-engine**. One will function as the master of the Virtual Chassis configuration and the other will function as the backup.

You designate additional members, which are not eligible for election as master, as having the **line-card** role in the preprovisioned configuration file.

In this example, five EX4200 switches (SWA-0 through SWA-4) are interconnected with their dedicated VCPs in wiring closet A and five EX4200 switches (SWA-5 through SWA-9) are interconnected with their dedicated VCPs in wiring closet B.

SWA-0 (in wiring closet A) is going to be the master of the Virtual Chassis configuration. This example shows how to create a preprovisioned configuration file on SWA-0 for all member switches that will be interconnected in the Virtual Chassis configuration. The preprovisioned configuration file includes member IDs for the members in wiring closet A and for the members in wiring closet B.

SWA-5 (in wiring closet B) is going to be the backup of the Virtual Chassis configuration. Both SWA-0 and SWA-5 are specified in the preprovisioned configuration file with the role of **routing-engine**. All other members are specified with the role of **line-card**.

If all member switches could be interconnected with their dedicated VCPs, you could simply power on the switches after saving and committing the preprovisioned configuration file. The master detects the connection of the members through the dedicated VCPs and applies the parameters specified in the preprovisioned configuration file.

However, the Virtual Chassis cables that interconnect the VCPs of member switches within a single wiring closet are not long enough to connect member switches across wiring closets. Instead, you can configure the uplink module ports or the SFP network ports on EX4200-24F switches as VCPs to interconnect the member switches in wiring closet A to the member switch in wiring closet B. For redundancy, this example connects uplink VCPs from two member switches in wiring closet A (SWA-0 and SWA-2) to two member switches (SWA-5 and SWA-7) in wiring closet B.



NOTE: You can use interfaces on SFP, SFP+, and XFP uplink modules and the SFP network ports on EX4200-24F switches as VCPs. When an uplink module port or SFP network port is set as a VCP, it cannot be used for any other purpose. The SFP uplink module has four 1-Gbps ports; the SFP+ uplink module has four 1-Gbps or two 10-Gbps ports; the XFP uplink module has two 10-Gbps ports. The uplink module ports that are not set as VCPs can be configured as trunk ports to connect to a distribution switch.

Because this particular preprovisioned configuration is for a Virtual Chassis that is interconnected across wiring closets, we will bring up the Virtual Chassis configuration in stages. First, we power on SWA-0 (without powering on any other switches) and create the preprovisioned configuration file. Then we power on the remaining switches in wiring closet A. If we check the status of the Virtual Chassis configuration at this point by using the **show virtual-chassis** command, it will display only **member 0** through **member 4**. The members that have not yet been interconnected will not be listed.

Next power on SWA-5 without powering on the remaining switches (SWA-6 through SWA-9) in wiring closet B. Bring up SWA-5 as a standalone switch and set one of its uplinks as a VCP prior to interconnecting it with the Virtual Chassis configuration in wiring closet A. Without this setting, SWA-5 cannot be detected as a member switch by the master of the Virtual Chassis configuration.

You can set the uplink VCP of SWA-5 without running the EZSetup program by directly connecting to the console port. If you wish, you can run the EZSetup program and specify

identification parameters. When you interconnect SWA-5 with the master of the Virtual Chassis configuration, the master overwrites any conflicting parameters.

After setting the VCP in SWA-5, connect this VCP with the VCP of SWA-0 in wiring closet A. SWA-5 (serial number pqr678) is specified as a **routing-engine** in the preprovisioned configuration file.

This example uses SWA-5 as the backup of the Virtual Chassis configuration. If a problem occurred in wiring closet A, SWA-5 would take control of the Virtual Chassis configuration and maintain the network connections. Specify both SWA-0 and SWA-5 as **routing-engine**. Because SWA-0 is powered on prior to SWA-5, it has additional prioritization properties that cause it to be elected as master of the Virtual Chassis configuration.

After being physically interconnected with SWA-0, SWA-5 reboots and comes up as **member 5** and as the backup of the Virtual Chassis configuration.

Power on the remaining switches (SWA-6 through SWA-9) in wiring closet B. The master can now detect that all members are present. Finally, for redundancy, configure an additional VCP on SWA-7 through the master.

The topology for this example consists of:

- Three EX4200-48P switches (SWA-0, SWA-2, and SWA-4) in wiring closet A.
- Two EX4200-48P switches (SWA-5 and SWA-9) in wiring closet B.
- Two EX4200-24T switches (SWA-1 and SWA-3) in wiring closet A.
- Three EX4200-24T switches (SWA-6, SWA-7, and SWA-8) in wiring closet B.
- Four XFP uplink modules. Two are installed in wiring closet A and two are installed in wiring closet B.

[Table 21 on page 131](#) shows the Virtual Chassis configuration settings for a preprovisioned Virtual Chassis composed of member switches in different wiring closets.

Table 21: Components of a Preprovisioned EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets

Switch	Serial number	Member ID	Role	Uplink Module Ports	Hardware	Location
SWA-0	abc123	0	routing-engine	xe-0/1/0	EX4200-48P and XFP uplink module	Wiring closet A
SWA-1	def456	1	linecard		EX4200-24T	Wiring closet A
SWA-2	ghi789	2	linecard	xe-2/1/0	EX4200-48P and XFP uplink module	Wiring closet A
SWA-3	jkl012	3	linecard		EX4200-24T	Wiring closet A
SWA-4	mno345	4	linecard		EX4200-48P	Wiring closet A

Table 21: Components of a Preprovisioned EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets (continued)


Switch	Serial number	Member ID	Role	Uplink Module Ports	Hardware	Location
SWA-5	pqr678	5	routing-engine	xe-0/1/0 <small>NOTE: The member ID of SWA-5 is 0 at the time that its uplink module port is configured as a VCP.</small>	EX4200-48P and XFP uplink module	Wiring closet B
SWA-6	stu901	6	linecard		EX4200-24T	Wiring closet B
SWA-7	vwxyz234	7	linecard	xe-7/1/0	EX4200-24T and XFP uplink module	Wiring closet B
SWA-8	yza567	8	linecard		EX4200-24T	Wiring closet B
SWA-9	bcd890	9	linecard		EX4200-48P	Wiring closet B

Figure 16 on page 133 shows the different types of interconnections used for this Virtual Chassis configuration. The rear view shows that the member switches within each wiring closet are interconnected to each other using the dedicated VCPs. The front view shows that the uplink module ports that have been set as VCPs and interconnected across the wiring closets. The uplink module ports that are not set as VCPs can be configured as trunk ports to connect to a distribution switch.



NOTE: The interconnections shown in Figure 16 on page 133 are the same as they would be for a configuration that was not preprovisioned across wiring closets.

Figure 16: Maximum Size EX4200 Virtual Chassis Interconnected Across Wiring Closets



Configuration

To configure the Virtual Chassis across multiple wiring closets using a preprovisioned configuration, perform this task:



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis configuration.

Step-by-Step Procedure

To create a preprovisioned configuration for the Virtual Chassis:

1. Specify the preprovisioned configuration mode:

```
[edit virtual-chassis]
user@SWA-0# set preprovisioned
```

2. Specify all the members that will be included in the Virtual Chassis configuration, listing each switch's serial number with the desired member ID and the desired role:

```
[edit virtual-chassis]
user@SWA-0# set member 0 serial-number abc123 role routing-engine
user@SWA-0# set member 1 serial-number def456 role line-card
user@SWA-0# set member 2 serial-number ghi789 role line-card
user@SWA-0# set member 3 serial-number jkl012 role line-card
user@SWA-0# set member 4 serial-number mno345 role line-card
user@SWA-0# set member 5 serial-number pqr678 role routing-engine
user@SWA-0# set member 6 serial-number stu901 role line-card
user@SWA-0# set member 7 serial-number vwx234 role line-card
user@SWA-0# set member 8 serial-number yza567 role line-card
user@SWA-0# set member 9 serial-number bcd890 role line-card
```

3. Power on the member switches in wiring closet A.
4. Prepare the members in wiring closet A for interconnecting with the member switches in wiring closet B by setting uplink VCPs for member 0 and member 2:

```
user@SWA-0> request virtual-chassis vc-port (Dedicated VCP) set pic-slot 1 port 0
user@SWA-2> request virtual-chassis vc-port set pic-slot 1 port 0 member 2
```

**NOTE:**

- For redundancy, this example sets an uplink VCP in both SWA-0 and SWA-2.
 - This example omits the specification of the member 0 in setting the uplink for SWA-0. The command applies by default to the switch where it is executed.
-

5. Power on SWA-5 and connect to it. This switch comes up as member ID 0 and functions as master of itself. Although SWA-5 is listed in the preprovisioned configuration file, it is not a present member of the Virtual Chassis configuration that has been powered on thus far. In order for the master to detect SWA-5 as a connected member, you must first set an uplink VCP on SWA-5 and interconnect that VCP with the uplink VCP of SWA-0.
6. Set the first uplink of SWA-5 to function as a VCP. Because SWA-5 has been powered on as a separate switch and is still operating independently at this point, its member ID is 0.

```
user@SWA-5> request virtual-chassis vc-port set pic-slot 1 port 0
```



NOTE: This example omits the specification of the member 0 in configuring the uplink for SWA-5 (at this point the member ID of SWA-5 is still 0). The command applies by default to the switch where it is executed.

7. Power off SWA-5 and connect the fiber cable from SWA-5 uplink VCP **xe-0/1/0** to the uplink VCP **xe-0/1/0** on SWA-0.
8. Power on SWA-5.
9. Now that SWA-5 has been brought up as **member 5** of the Virtual Chassis configuration, power on the remaining switches (SWA-6 through SWA-9) in wiring closet B. They are interconnected with SWA-5 using the dedicated VCPs on the rear panel and are therefore detected by the master as interconnected members. If you check the status of the Virtual Chassis configuration at this point, all the members that were specified in the preprovisioned configuration file should be displayed as present. Additional configuration for member switches can now be done through the master switch.
10. Set one uplink module port of SWA-7 to function as a VCP:

```
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 0
member 7
```

Results Display the results of the configuration on SWA-0:

```
[edit]
user@SWA-0# show
virtual-chassis {
  member 0 {
    role routing-engine;
    serial-number abc123;
  }
  member 1 {
    role line-card;
    serial-number def456;
  }
  member 2 {
    role line-card;
    serial-number ghi789;
  }
  member 3 {
    role line-card;
    serial-number jkl012;
  }
  member 4 {
```

```

    role line-card;
    serial-number mno345;
  }
  member 5 {
    role routing-engine;
    serial-number pqr678;
  }
  member 6 {
    role line-card;
    serial-number stu901;
  }
  member 7 {
    role line-card;
    serial-number vwx234;
  }
  member 8 {
    role line-card;
    serial-number yza567;
  }
  member 9 {
    role line-card;
    serial-number bcd890;
  }
  preprovisioned;
}

```

Verification

To confirm that the configuration is working properly, perform these tasks:

- [Verifying the Member IDs and Roles of the Member Switches on page 136](#)
- [Verifying That the Dedicated VCPs and Uplink VCPs Are Operational on page 137](#)

Verifying the Member IDs and Roles of the Member Switches

Purpose Verify that the member IDs and roles are all set as expected.

Action Display the members of the Virtual Chassis configuration:

```
user@SWA-0> show virtual-chassis
```

```
Preprovisioned Virtual Chassis
Virtual Chassis ID: 0000.e255.0000
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4200-48p	129	Master*	1 vcp-0 4 vcp-1 5 1/0
1 (FPC 1)	Prsnt	def456	ex4200-24t	0	Linecard	2 vcp-0 0 vcp-1

2 (FPC 2)	Prsnt	ghi789	ex4200-48p	0	Linecard	3 vcp-0 1 vcp-1 7 1/0
3 (FPC 3)	Prsnt	jk1012	ex4200-24t	0	Linecard	4 vcp-0 2 vcp-1
4 (FPC 4)	Prsnt	mno345	ex4200-48p	0	Linecard	0 vcp-0 3 vcp-1
5 (FPC 5)	Prsnt	pqr678	ex4200-48p	129	Backup	6 vcp-0 9 vcp-1 0 1/0
6 (FPC 6)	Prsnt	stu901	ex4200-24t	0	Linecard	7 vcp-0 5 vcp-1
7 (FPC 7)	Prsnt	vwxyz234	ex4200-24t	0	Linecard	8 vcp-0 6 vcp-1 2 1/0
8 (FPC 8)	Prsnt	yza567	ex4200-24t	0	Linecard	9 vcp-0 7 vcp-1
9 (FPC 9)	Prsnt	bc7890	ex4200-48p	0	Linecard	5 vcp-0 8 vcp-1

Meaning The output shows that all members listed in the preprovisioned configuration file are connected to the Virtual Chassis configuration. It confirms that SWA-0 (member 0) is functioning as the master of the Virtual Chassis configuration. The other switch configured with the **routing-engine** role (SWA-5) is functioning as the backup. The **Neighbor List** displays the interconnections of the member VCPs.

Verifying That the Dedicated VCPs and Uplink VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting the member switches within each wiring closet and the uplink module VCPs interconnecting the member switches across wiring closets are operational.

Action Display the VCP interfaces:

```
user@SWA-0> show virtual-chassis vc-port all-members
```

```
fpc0:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Neighbor Interface
vcp-0	Dedicated	Up			
vcp-1	Dedicated	Up			
1/0	Configured	Up			

```
fpc1:
```

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
fpc2:				
Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
1/0	Configured	Up		
fpc3:				
Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
fpc4:				
Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
fpc5:				
Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
1/0	Configured	Up		
fpc6:				
Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
fpc7:				
Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID Interface
vcp-0	Dedicated	Up		
vcp-1	Dedicated	Up		
1/0	Configured	Up		
fpc8:				
Interface	Type	Status	Speed	Neighbor

or PIC / Port			(mbps)	ID	Interface
vcp-0	Dedicated	Up			
vcp-1	Dedicated	Up			

fpc9:					

Interface or PIC / Port	Type	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	Up			
vcp-1	Dedicated	Up			

Meaning The dedicated VCPs interconnecting the member switches within wiring closets are displayed as **vcp-0** and **vcp-1**. The uplink module VCPs interconnecting member switches (members 0, 2, 5, and 7) across wiring closets are displayed as 1/0 and 1/1 and identified as **Configured**.

Troubleshooting

To troubleshoot a preprovisioned Virtual Chassis configuration that is interconnected across wiring closets, perform these tasks:

- [Troubleshooting Nonoperational VCPs on page 139](#)

Troubleshooting Nonoperational VCPs

Problem A VCP shows a status of **down**.

Solution Check the cable to make sure that it is properly and securely connected to the ports.

- Related Documentation**
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
 - [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
 - [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)

Example: Configuring a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis

You can deterministically control both the role and the member ID assigned to each member switch in a mixed EX4200 and EX4500 Virtual Chassis configuration by creating a preprovisioned configuration.



NOTE: When you use a preprovisioned configuration, you cannot modify the mastership priority or member ID of member switches through the user interfaces.

This example describes how to configure a mixed EX4200 and EX4500 Virtual Chassis using a preprovisioned configuration file:

- [Requirements on page 140](#)
- [Overview and Topology on page 140](#)
- [Configuration on page 142](#)
- [Verification on page 143](#)
- [Troubleshooting on page 144](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 11.1 or later for EX Series switches



NOTE: You must use Junos OS Release 11.4 or later if you are including three or more EX4500 switches in an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis.

- Two EX4500 switches, each with a Virtual Chassis module
- Two EX4200 switches

Before you create the preprovisioned configuration of the Virtual Chassis and interconnect the members across the wiring closets, be sure you have:

1. Made a list of the serial numbers of all the switches to be connected as a Virtual Chassis configuration.
2. Noted the desired role (**routing-engine** or **line-card**) for each switch.
3. Ensured that the same version of Junos OS is running on all current or prospective member switches.

Overview and Topology

A preprovisioned configuration file links the serial number of each switch in the Virtual Chassis configuration to a specified member ID and role. The serial number must be specified in the configuration file for the member to be recognized as part of the Virtual Chassis configuration.

You designate additional members, which are not eligible for election as master, as having the **line-card** role in the preprovisioned configuration file.

In this example, two EX4500 switches (SWA-0 and SWA-1) are in the routing-engine role and interconnected to two EX4200 switches (SWA-2 and SWA-3) in the linecard role using dedicated Virtual Chassis ports (VCPs).

SWA-0 will be the master of the Virtual Chassis configuration. This example shows how to create a preprovisioned configuration file on SWA-0 for all member switches that will be interconnected in the Virtual Chassis configuration. The preprovisioned configuration file includes member IDs for all member switches.

SWA-1 will be the backup of the Virtual Chassis configuration. Both SWA-0 and SWA-1 are specified in the preprovisioned configuration file with the role of **routing-engine**. All other members are specified with the role of **line-card**.

After all member switches are interconnected with their dedicated VCPs, you can simply power on the switches after saving and committing the preprovisioned configuration file. The master detects the connection of the members through the dedicated VCPs and applies the parameters specified in the preprovisioned configuration file.



NOTE: You can use interfaces on SFP, SFP+, and XFP uplink modules as VCPs. When an uplink module port or SFP network port is set as a VCP, it cannot be used for any other purpose.

We will bring up the Virtual Chassis configuration in stages. First, we power on SWA-0 (without powering on any other switches) and create the preprovisioned configuration file. Then we power on the remaining switches.

The topology for this example consists of:

- Two EX4500 switches (SWA-0 and SWA-1)
- Two EX4200 switches (SWA-2 and SWA-3)

Table 22 on page 141 shows the Virtual Chassis configuration settings for a preprovisioned Virtual Chassis.

Table 22: Components of a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis

Switch	Serial number	Member ID	Role	Hardware
SWA-0	abc123	0	routing-engine	EX4500 switch with a Virtual Chassis module
SWA-1	def456	1	routing-engine	EX4500 switch with a Virtual Chassis module
SWA-2	ghi789	2	line-card	EX4200 switch
SWA-3	jkl012	3	line-card	EX4200 switch

Configuration

To configure the Virtual Chassis across multiple wiring closets using a preprovisioned configuration, perform this task:



NOTE: We recommend that you use the **commit synchronize** command to save any configuration changes that you make to a multimember Virtual Chassis configuration.

Step-by-Step Procedure

To create a preprovisioned configuration for the Virtual Chassis:

1. Power on the EX4500 switch (SWA-0) in the master role..
2. Set the PIC mode to Virtual Chassis mode on SWA-0:

```
user@switch> request chassis pic-mode virtual-chassis
```
3. Set the Virtual Chassis mode to mixed:

```
user@switch> request virtual-chassis mode mixed
```
4. Reboot the switch.
5. After the switch reboots, specify the preprovisioned configuration mode:

```
[edit virtual-chassis]  
user@SWA-0# set preprovisioned
```
6. Specify all members to be included in the Virtual Chassis configuration, listing each switch's serial number with the desired member ID and the desired role:

```
[edit virtual-chassis]  
user@SWA-0# set member 0 serial-number abc123 role routing-engine  
user@SWA-0# set member 1 serial-number def456 role line-card  
user@SWA-0# set member 2 serial-number ghi789 role line-card  
user@SWA-0# set member 3 serial-number jkl012 role line-card
```
7. Power on the remaining switches.
8. Set the Virtual Chassis mode to mixed on the remaining switches:

```
user@switch> request virtual-chassis mode mixed
```
9. Reboot the switches.
10. When the reboot completes, physically cable the switches together using the dedicated VCPs.

Results Display the results of the configuration on SWA-0:

```
[edit]
user@SWA-0# show
virtual-chassis {
  member 0 {
    role routing-engine;
    serial-number abc123;
  }
  member 1 {
    role line-card;
    serial-number def456;
  }
  member 2 {
    role line-card;
    serial-number ghi789;
  }
  member 3 {
    role line-card;
    serial-number jkl012;
  }
  preprovisioned;
}
```

Verification

To confirm that the configuration is working properly, perform these tasks:

- [Verifying the Member IDs and Roles of the Member Switches on page 143](#)

Verifying the Member IDs and Roles of the Member Switches

Purpose Verify that the member IDs and roles are all set as expected.

Action Display the members of the Virtual Chassis configuration:

```
user@SWA-0> show virtual-chassis
```

```
Preprovisioned Virtual Chassis
Virtual Chassis ID: 0000.e255.0000
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4500-40f	129	Master*	1 vcp-1 3 vcp-0
1 (FPC 1)	Prsnt	def456	ex4500-40f	0	Backup	0 vcp-0 2 vcp-1
2 (FPC 2)	Prsnt	ghi789	ex4200-48p	0	Linecard	1 vcp-0 3 vcp-1

3 (FPC 3)	Prsnt	jk1012	ex4200-24t	0	Linecard	2 vcp-0
						0 vcp-1

Meaning The output shows that all members listed in the preprovisioned configuration file are connected to the Virtual Chassis configuration. It confirms that SWA-0 (member 0) is functioning as the master of the Virtual Chassis configuration. The other switch configured with the **routing-engine** role (SWA-1) is functioning as the backup. The **Neighbor List** displays the interconnections of the member VCPs.

Troubleshooting

To troubleshoot a preprovisioned Virtual Chassis configuration that is interconnected across wiring closets, perform these tasks:

- [Troubleshooting Nonoperational VCPs on page 144](#)

Troubleshooting Nonoperational VCPs

Problem A VCP shows a status of **down**.

Solution Check the cable to make sure that it is properly and securely connected to the ports.

Related Documentation

- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)

Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch

EX Series switches allow you to combine multiple Ethernet links into one logical interface for higher bandwidth and redundancy. The ports that are combined in this manner are referred to as a link aggregation group (LAG) or bundle. The number of Ethernet links you can combine into a LAG depends on your EX Series switch model.

This example describes how to configure uplink LAGs to connect a Virtual Chassis access switch to a Virtual Chassis distribution switch:

- [Requirements on page 145](#)
- [Overview and Topology on page 145](#)
- [Configuration on page 147](#)
- [Verification on page 149](#)
- [Troubleshooting on page 150](#)

Requirements

This example uses the following software and hardware components:

- Junos OS Release 9.0 or later for EX Series switches
- Two EX4200-48P switches
- Two EX4200-24F switches
- Four XFP uplink modules

Before you configure the LAGs, be sure you have:

- Configured the Virtual Chassis switches. See [“Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\)”](#) on page 184.
- Configured the uplink ports on the switches as trunk ports. See *Configuring Gigabit Ethernet Interfaces (CLI Procedure)*.

Overview and Topology

For maximum speed and resiliency, you can combine uplinks between an access switch and a distribution switch into LAGs. Using LAGs can be particularly effective when connecting a multimember Virtual Chassis access switch to a multimember Virtual Chassis distribution switch.

The Virtual Chassis access switch in this example is composed of two member switches. Each member switch has an uplink module with two 10-Gigabit Ethernet ports. These ports are configured as trunk ports, connecting the access switch with the distribution switch.

Configuring the uplinks as LAGs has the following advantages:

- Link Aggregation Control Protocol (LACP) can optionally be configured for link negotiation.
- It doubles the speed of each uplink from 10 Gbps to 20 Gbps.
- If one physical port is lost for any reason (a cable is unplugged or a switch port fails, or one member switch is unavailable), the logical port transparently continues to function over the remaining physical port.

The topology used in this example consists of one Virtual Chassis access switch and one Virtual Chassis distribution switch. The access switch is composed of two EX4200-48P switches (SWA-0 and SWA-1), interconnected to each other with their Virtual Chassis ports (VCPs) as member switches of Host-A. The distribution switch is composed of two EX4200-24F switches (SWD-0 and SWD-1), interconnected with their VCPs as member switches of Host-D.

Each member of the access switch has an uplink module installed. Each uplink module has two ports. The uplinks are configured to act as trunk ports, connecting the access switch with the distribution switch. One uplink port from SWA-0 and one uplink port from SWA-1 are combined as LAG ae0 to SWD-0. This link is used for one VLAN. The remaining

uplink ports from SWA-0 and from SWA-1 are combined as a second LAG connection (**ae1**) to SWD-1. LAG **ae1** is used for another VLAN.



NOTE: If the remote end of the LAG link is a security device, LACP might not be supported because security devices require a deterministic configuration. In this case, do not configure LACP. All links in the LAG are permanently operational unless the switch detects a link failure within the Ethernet physical layer or data link layers.

Figure 17: Topology for LAGs Connecting an EX4200 Virtual Chassis Access Switch to an EX4200 Virtual Chassis Distribution Switch




Table 23 on page 146 details the topology used in this configuration example.

Table 23: Components of the Topology for Connecting a Virtual Chassis Access Switch to a Virtual Chassis Distribution Switch

Switch	Hostname and VCID	Base Hardware	Uplink Module	Member ID	Trunk Port
SWA-0	Host-A Access switch	EX4200-48P switch	One XFP uplink module	0	xe-0/1/0 to SWD-0 xe-0/1/1 to SWD-1
	VCID 1				

Table 23: Components of the Topology for Connecting a Virtual Chassis Access Switch to a Virtual Chassis Distribution Switch (continued)

Switch	Hostname and VCID	Base Hardware	Uplink Module	Member ID	Trunk Port
SWA-1	Host-A Access switch VCID 1	EX4200-48P switch	One XFP uplink module	1	xe-1/1/0 to SWD-0 xe-1/1/1 to SWD-1
SWD-0	Host-D Distribution switch VCID 4	EX4200 L-24F switch	One XFP uplink module	0	xe-0/1/0 to SWA-0 xe-0/1/1 to SWA-1
SWD-1	Host-D Distribution switch VCID 4	EX4200 L-24F switch	One XFP uplink module	1	xe-1/1/0 to SWA-0 xe-1/1/1 to SWA-1

Configuration

To configure two uplink LAGs from the Virtual Chassis access switch to the Virtual Chassis distribution switch:

CLI Quick Configuration

To quickly configure aggregated Ethernet high-speed uplinks between a Virtual Chassis access switch and a Virtual Chassis distribution switch, copy the following commands and paste them into the switch terminal window:

```
[edit]
set chassis aggregated-devices ethernet device-count 2
set interfaces ae0 aggregated-ether-options minimum-links 1
set interfaces ae0 aggregated-ether-options link-speed 10g
set interfaces ae1 aggregated-ether-options minimum-links 1
set interfaces ae1 aggregated-ether-options link-speed 10g
set interfaces ae0 unit 0 family inet address 192.0.2.0/25
set interfaces ae1 unit 0 family inet address 192.0.2.128/25
set interfaces xe-0/1/0 ether-options 802.3ad ae0
set interfaces xe-1/1/0 ether-options 802.3ad ae0
set interfaces xe-0/1/1 ether-options 802.3ad ae1
set interfaces xe-1/1/1 ether-options 802.3ad ae1
```

Step-by-Step Procedure

To configure aggregated Ethernet high-speed uplinks between a Virtual Chassis access switch and a Virtual Chassis distribution switch:

1. Specify the number of LAGs to be created on the chassis:

```
[edit chassis]
user@Host-A# set aggregated-devices ethernet device-count 2
```

2. Specify the number of links that need to be present for the ae0 LAG interface to be up:

```
[edit interfaces]
```

```
user@Host-A# set ae0 aggregated-ether-options minimum-links 1
```

3. Specify the number of links that need to be present for the **ae1** LAG interface to be up:

```
[edit interfaces]
user@Host-A# set ae1 aggregated-ether-options minimum-links 1
```

4. Specify the media speed of the **ae0** link:

```
[edit interfaces]
user@Host-A# set ae0 aggregated-ether-options link-speed 10g
```

5. Specify the media speed of the **ae1** link:

```
[edit interfaces]
user@Host-A# set ae1 aggregated-ether-options link-speed 10g
```

6. Specify the interface ID of the uplinks to be included in LAG **ae0**:

```
[edit interfaces]
user@Host-A# set xe-0/1/0 ether-options 802.3ad ae0
user@Host-A# set xe-1/1/0 ether-options 802.3ad ae0
```

7. Specify the interface ID of the uplinks to be included in LAG **ae1**:

```
[edit interfaces]
user@Host-A# set xe-0/1/1 ether-options 802.3ad ae1
user@Host-A# set xe-1/1/1 ether-options 802.3ad ae1
```

8. Specify that LAG **ae0** belongs to the subnet for the employee broadcast domain:

```
[edit interfaces]
user@Host-A# set ae0 unit 0 family inet address 192.0.2.0/25
```

9. Specify that LAG **ae1** belongs to the subnet for the guest broadcast domain:

```
[edit interfaces]
user@Host-A# set ae1 unit 0 family inet address 192.0.2.128/25
```

Results

Display the results of the configuration:

```
[edit]
chassis {
  aggregated-devices {
    ethernet {
      device-count 2;
    }
  }
}
interfaces {
```



```

ae0 {
  aggregated-ether-options {
    link-speed 10g;
    minimum-links 1;
  }
  unit 0 {
    family inet {
      address 192.0.2.0/25;
    }
  }
}
ae1 {
  aggregated-ether-options {
    link-speed 10g;
    minimum-links 1;
  }
  unit 0 {
    family inet {
      address 192.0.2.128/25;
    }
  }
}
xe-0/1/0 {
  ether-options {
    802.3ad ae0;
  }
}
xe-1/1/0 {
  ether-options {
    802.3ad ae0;
  }
}
xe-0/1/1 {
  ether-options {
    802.3ad ae1;
  }
}
xe-1/1/1 {
  ether-options {
    802.3ad ae1;
  }
}
}

```

Verification

To verify that switching is operational and two LAGs have been created, perform these tasks:

- [Verifying That LAG ae0 Has Been Created on page 150](#)
- [Verifying That LAG ae1 Has Been Created on page 150](#)

Verifying That LAG ae0 Has Been Created

Purpose Verify that LAG **ae0** has been created on the switch.

Action `show interfaces ae0 terse`

Interface	Admin	Link	Proto	Local	Remote
ae0	up	up			
ae0.0	up	up	inet	192.0.2.0/25	

Meaning The output confirms that the **ae0** link is up and shows the **family** and IP address assigned to this link.

Verifying That LAG ae1 Has Been Created

Purpose Verify that LAG **ae1** has been created on the switch

Action `show interfaces ae1 terse`

Interface	Admin	Link	Proto	Local	Remote
ae1	up	down			
ae1.0	up	down	inet	192.0.2.128/25	

Meaning The output shows that the **ae1** link is down.

Troubleshooting

Troubleshooting a LAG That Is Down

Problem The `show interfaces terse` command shows that the LAG is **down**.

Solution Check the following:

- Verify that there is no configuration mismatch.
- Verify that all member ports are up.
- Verify that a LAG is part of family ethernet switching (Layer 2 LAG) or family inet (Layer 3 LAG).
- Verify that the LAG member is connected to the correct LAG at the other end.
- Verify that the LAG members belong to the same switch (or the same Virtual Chassis).

- Related Documentation**
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
 - *Example: Connecting an EX Series Access Switch to a Distribution Switch.*
 - *Virtual Chassis Cabling Configuration Examples for EX4200 Switches*
 - *Installing an Uplink Module in an EX4200 Switch*

Example: Configuring Aggregated Ethernet High-Speed Uplinks with LACP Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch

EX Series switches allow you to combine multiple Ethernet links into one logical interface for higher bandwidth and redundancy. The ports that are combined in this manner are referred to as a link aggregation group (LAG) or bundle. EX Series switches allow you to further enhance these links by configuring Link Aggregation Control Protocol (LACP).

This example describes how to overlay LACP on the LAG configurations that were created in “[Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch](#)” on [page 144](#):

- [Requirements on page 151](#)
- [Overview and Topology on page 152](#)
- [Configuring LACP for the LAGs on the Virtual Chassis Access Switch on page 152](#)
- [Configuring LACP for the LAGs on the Virtual Chassis Distribution Switch on page 153](#)
- [Verification on page 154](#)
- [Troubleshooting on page 155](#)

Requirements

This example uses the following software and hardware components:

- Junos OS Release 9.0 or later for EX Series switches
- Two EX4200-48P switches
- Two EX4200-24F switches
- Four EX Series XFP uplink modules

Before you configure LACP, be sure you have:

- Set up the Virtual Chassis switches. See “[Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\)](#)” on [page 184](#).
- Configured the uplink ports on the switches as trunk ports. See *Configuring Gigabit Ethernet Interfaces (CLI Procedure)*.

- Configured the LAGs. See [“Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch” on page 144.](#)

Overview and Topology

This example assumes that you are familiar with [“Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch” on page 144.](#) The topology in this example is exactly the same as the topology in that other example. This example shows how to use LACP to enhance the LAG functionality.

LACP exchanges are made between *actors* (the transmitting link) and *partners* (the receiving link). The LACP mode can be either active or passive.



NOTE: If the actor and partner are both in passive mode, they do not exchange LACP packets, which results in the aggregated Ethernet links not coming up. By default, LACP is in passive mode. To initiate transmission of LACP packets and responses to LACP packets, you must enable LACP in active mode.

By default, the actor and partner send LACP packets every second.

The interval can be fast (every second) or slow (every 30 seconds).

Configuring LACP for the LAGs on the Virtual Chassis Access Switch

To configure LACP for the access switch LAGs, perform these tasks:

CLI Quick Configuration

To quickly configure LACP for the access switch LAGs, copy the following commands and paste them into the switch terminal window:

```
[edit]
set interfaces ae0 aggregated-ether-options lacp active periodic fast
set interfaces ae1 aggregated-ether-options lacp active periodic fast
```

Step-by-Step Procedure

To configure LACP for Host-A LAGs ae0 and ae1:

1. Specify the aggregated Ethernet options for both bundles:

```
[edit interfaces]
user@Host-A#set ae0 aggregated-ether-options lacp active periodic fast
user@Host-A#set ae1 aggregated-ether-options lacp active periodic fast
```

Results Display the results of the configuration:

```
[edit interfaces]
user@Host-A# show
ae0 {
  aggregated-ether-options {
```

```

    lacp {
        active;
        periodic fast;
    }
}
ae1 {
    aggregated-ether-options {
        lacp {
            active;
            periodic fast;
        }
    }
}

```

Configuring LACP for the LAGs on the Virtual Chassis Distribution Switch

To configure LACP for the two uplink LAGs from the Virtual Chassis access switch to the Virtual Chassis distribution switch, perform these tasks:

CLI Quick Configuration To quickly configure LACP for the distribution switch LAGs, copy the following commands and paste them into the switch terminal window:

```

[edit interfaces]
set ae0 aggregated-ether-options lacp passive periodic fast
set ae1 aggregated-ether-options lacp passive periodic fast

```

Step-by-Step Procedure To configure LACP for Host D LAGs ae0 and ae1:

1. Specify the aggregated Ethernet options for both bundles:

```

[edit interfaces]
user@Host-D#set ae0 aggregated-ether-options lacp passive periodic fast
user@Host-D#set ae1 aggregated-ether-options lacp passive periodic fast

```

Results Display the results of the configuration:

```

[edit interfaces]
user@Host-D# show
ae0 {
    aggregated-ether-options {
        lacp {
            passive;
            periodic fast;
        }
    }
}
ae1 {
    aggregated-ether-options {
        lacp {
            passive

```

```

        periodic fast;
    }
}
}

```

Verification

To verify that LACP packets are being exchanged, perform these tasks:

- [Verifying the LACP Settings on page 154](#)
- [Verifying That the LACP Packets Are Being Exchanged on page 154](#)

Verifying the LACP Settings

Purpose Verify that LACP has been set up correctly.

Action Use the `show lacp interfaces interface-name` command to check that LACP has been enabled as active on one end.

```
user@Host-A> show lacp interfaces xe-0/1/0
```

Aggregated interface: ae0

LACP state:	Role	Exp	Def	Dist	Col	Syn	Aggr	Timeout	Activity
xe-0/1/0	Actor	No	Yes	No	No	No	Yes	Fast	Active
xe-0/1/0	Partner	No	Yes	No	No	No	Yes	Fast	Passive
LACP protocol:	Receive State		Transmit State				Mux State		
xe-0/1/0	Defaulted		Fast periodic				Detached		

Meaning The output indicates that LACP has been set up correctly and is active at one end.

Verifying That the LACP Packets Are Being Exchanged

Purpose Verify that LACP packets are being exchanged.

Action Use the `show interfaces aex statistics` command to display LACP information.

```
user@Host-A> show interfaces ae0 statistics
```

```

Physical interface: ae0, Enabled, Physical link is Down
Interface index: 153, SNMP ifIndex: 30
Link-level type: Ethernet, MTU: 1514, Speed: Unspecified, Loopback: Disabled,
Source filtering: Disabled, Flow control: Disabled, Minimum links needed: 1,

```

```

Minimum bandwidth needed: 0
Device flags : Present Running
Interface flags: Hardware-Down SNMP-Traps Internal: 0x0
Current address: 02:19:e2:50:45:e0, Hardware address: 02:19:e2:50:45:e0
Last flapped : Never
Statistics last cleared: Never
  Input packets : 0
  Output packets: 0
Input errors: 0, Output errors: 0

Logical interface ae0.0 (Index 71) (SNMP ifIndex 34)
Flags: Hardware-Down Device-Down SNMP-Traps Encapsulation: ENET2
Statistics      Packets      pps      Bytes      bps
Bundle:
  Input :          0          0          0          0
  Output:          0          0          0          0
Protocol inet
Flags: None
Addresses, Flags: Dest-route-down Is-Preferred Is-Primary
  Destination: 10.10.10/24, Local: 10.10.10.1, Broadcast: 10.10.10.255

```

Meaning The output here shows that the link is down and that no protocol data units (PDUs) are being exchanged.

Troubleshooting

To troubleshoot a nonworking LACP link, perform these tasks:

- [Troubleshooting a Nonworking LACP Link on page 155](#)

[Troubleshooting a Nonworking LACP Link](#)

Problem The LACP link is not working.

Solution Check the following:

- Remove the LACP configuration and verify whether the static LAG is up.
- Verify that LACP is configured at both ends.
- Verify that LACP is not passive at both ends.
- Verify whether LACP protocol data units (PDUs) are being exchanged by running the **monitor traffic-interface lag-member detail** command.

Related Documentation

- *Example: Connecting an EX Series Access Switch to a Distribution Switch*
- *Virtual Chassis Cabling Configuration Examples for EX4200 Switches*
- *Installing an Uplink Module in an EX4200 Switch*

Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails

The Virtual Chassis fast failover feature is a hardware-assisted failover mechanism that automatically reroutes traffic and reduces traffic loss in the event of a link or switch failure. If a link between two members fails, traffic flow between those members must be rerouted quickly so that there is minimal traffic loss.

Fast failover is enabled by default on all dedicated EX4200 Virtual Chassis ports (VCPs).

This example describes how to configure fast failover on uplink module VCPs in an EX4200 Virtual Chassis configuration:

- [Requirements on page 156](#)
- [Overview and Topology on page 156](#)
- [Configuration on page 157](#)
- [Verification on page 158](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.3 or later for EX Series switches
- Six EX4200-24T switches
- Four SFP uplink modules

Before you begin configuring fast failover, be sure you have:

1. Mounted the switches. See *Mounting an EX4200 Switch*.
2. Cabled the switches in a multiple-ring topology to create the Virtual Chassis configuration. See *Connecting a Virtual Chassis Cable to an EX4200 Switch*.

Overview and Topology


In a Virtual Chassis configuration, fast failover automatically reroutes traffic and reduces traffic loss in the event of a link failure or a member switch failure. By default, fast failover is enabled on all dedicated VCPs. If you configure uplink module ports as VCPs, you must manually configure fast failover on these ports.

For fast failover to be effective, the Virtual Chassis members must be configured in a ring topology. The ring topology can be formed by using either dedicated VCPs or user-configured uplink module VCPs. Fast failover is supported only in a ring topology that uses identical port types, for example, either a topology that uses all dedicated VCPs or one that uses all uplink module VCPs. Fast failover is not supported in a ring topology that includes both dedicated VCPs and uplink module VCPs. Fast failover is supported, however, in a Virtual Chassis configuration that consists of multiple rings.

This example shows how to enable fast failover on uplink module VCPs.

Figure 18 on page 157 shows an example of a multiple-ring topology.

Figure 18: Traffic Redirected by Fast Failover After VCP Link Failures in a Topology with Multiple Rings



The topology for this example consists of six switches:

- Six EX4200-24T switches, four of which have an SFP uplink module installed (switches 1, 3, 4, and 6)

Configuration

To configure the fast failover feature on uplink module VCPs:

CLI Quick Configuration

To configure fast failover on all SFP uplink module VCPs, copy the following command and paste it into the terminal window on switch 1:

```
[edit]
set virtual-chassis fast-failover ge
```

Step-by-Step Procedure

To configure fast failover on SFP uplink module VCPs:

1. Enable fast failover on all SFP uplink module VCPs in the Virtual Chassis configuration:

```
[edit]
user@switch1# set virtual-chassis fast-failover ge
```



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis.

Results Check the results of the configuration:

```
[edit virtual-chassis]
user@switch1# show
fast-failover {
  ge;
}
```

Verification

To confirm that fast failover is enabled on SFP uplink module VCPs in the Virtual Chassis configuration, perform this task:

- [Verifying That Fast Failover Is Enabled on page 158](#)

Verifying That Fast Failover Is Enabled

Purpose Verify that fast failover has been enabled in a Virtual Chassis configuration.

Action Issue the `show virtual-chassis fast-failover` command.

```
user@switch1> show virtual-chassis fast-failover
```

```
Fast failover on dedicated VCP ports: Enabled
Fast failover on XE uplink VCP ports: Disabled
Fast failover on GE uplink VCP ports: Enabled
```

Meaning Fast failover is enabled on all dedicated VCPs and SFP uplink module VCPs in the Virtual Chassis configuration.

- Related Documentation**
- [Configuring Fast Failover in an EX Series Virtual Chassis on page 233](#)
 - [Disabling Fast Failover in an EX Series Virtual Chassis on page 234](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
 - [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)

Example: Assigning the Virtual Chassis ID to Determine Precedence During an EX4200 Virtual Chassis Merge

There are two scenarios in which separate Virtual Chassis merge:

- A Virtual Chassis configuration that had split into two is now merging back into a single configuration because the problem that had caused it to split has been resolved.
- You merge two Virtual Chassis that had not previously been configured together.

You can explicitly assign a Virtual Chassis ID (VCID) so that, when two EX4200 Virtual Chassis configurations merge, the ID that you assigned takes precedence over the automatically assigned VCIDs and becomes the ID of the newly merged Virtual Chassis configuration.

This example shows how to assign the VCID on an EX4200 Virtual Chassis. This process is identical on an EX4500 Virtual Chassis and on a mixed EX4200 and EX4500 Virtual Chassis.

This example describes how to assign the VCID in an EX4200 Virtual Chassis configuration:

- [Requirements on page 159](#)
- [Overview and Topology on page 160](#)
- [Configuration on page 160](#)
- [Verification on page 160](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.3 or later for EX Series switches
- Two EX4200-48P switches
- Two EX4200-24T switches

Before you begin, be sure you have:

1. Installed the switches. See *Mounting an EX4200 Switch*.
2. Cabled the switches to create the Virtual Chassis configuration. See *Connecting a Virtual Chassis Cable to an EX4200 Switch*.

Overview and Topology

Every Virtual Chassis configuration has a unique ID that is automatically assigned when the Virtual Chassis configuration is formed. You can also configure a Virtual Chassis ID using the **set virtual-chassis id** command. When two Virtual Chassis merge, the Virtual Chassis ID that you assigned takes precedence over the automatically assigned Virtual Chassis IDs and becomes the ID for the newly merged Virtual Chassis configuration.

The topology for this example consists of four switches:

- Two EX4200-24T switches
- Two EX4200-48P switches

The switches are connected as a four-member Virtual Chassis configuration and are identified as switch-A, switch-B, switch-C, and switch-D. The master is switch-A.

Configuration

To assign the Virtual Chassis ID in a Virtual Chassis configuration:

CLI Quick Configuration

To assign a Virtual Chassis ID so that when two Virtual Chassis configurations merge, the ID that you assigned takes precedence over the automatically assigned Virtual Chassis IDs and becomes the ID of the newly merged Virtual Chassis configuration, copy the following command and paste it into the terminal window:

```
[edit]  
set virtual-chassis id 9622.6ac8.5345
```

Step-by-Step Procedure

To assign the Virtual Chassis ID in a Virtual Chassis configuration:

1. Assign the Virtual Chassis ID:

```
[edit]  
user@switch-A# set virtual-chassis id 9622.6ac8.5345
```



NOTE: We recommend that you use the **commit synchronize** command to save any configuration changes that you make to a multimember Virtual Chassis configuration.

Verification

To verify that the Virtual Chassis ID has been assigned as you intended, perform these tasks:

- [Verifying That the Virtual Chassis ID Is Assigned on page 161](#)

Verifying That the Virtual Chassis ID Is Assigned

Purpose Verify that the Virtual Chassis ID has been assigned in a Virtual Chassis configuration.

Action Issue the **show configuration virtual-chassis id** command.

```
user@switch-A> show configuration virtual-chassis id
id 9622.6ac8.5345;
```

Meaning The Virtual Chassis ID has been assigned as 9622.6ac8.5345.

- Related Documentation**
- [Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge on page 241](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
 - [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)

Example: Configuring Link Aggregation Groups Using EX4200 Uplink Virtual Chassis Ports

You can form link aggregation groups (LAGs) between EX4200 Virtual Chassis member switches in different wiring closets using uplink Virtual Chassis ports (VCPs) and, on EX4200-24F switches, network VCPs. LAGs balance traffic across the member links, increase the uplink bandwidth, and provide increased availability. To form LAGs using uplink or network VCPs, you configure the uplink module interfaces or network interfaces on the member switches as VCPs and connect the VCPs using fiber-optic cables. For the LAGs to form, the uplink or network VCPs on each member switch that will form a LAG must operate at the same link speed and you must interconnect at least two uplink or network VCPs on each of those members. You can connect uplink or network VCPs operating at different link speeds, but they will not form a LAG.



NOTE: The LAGs formed by VCPs are different from LAGs formed by Virtual Chassis network interfaces. For more information on LAGs formed by network interfaces, see [“Understanding Virtual Chassis Port Link Aggregation” on page 41](#).

This example shows how to configure uplink module interfaces and network interfaces as VCPs on multiple member switches of a Virtual Chassis configuration and then connect them to form LAGs:

- [Requirements on page 162](#)
- [Overview and Topology on page 162](#)
- [Configuration on page 164](#)

- [Verification on page 167](#)
- [Troubleshooting on page 170](#)

Requirements

This example uses the following hardware and software components:

- Junos OS Release 9.6 or later for EX Series switches
- Five EX4200 switches, one of which is an EX4200-24F model
- Two SFP uplink modules
- Two XFP uplink modules

Before you configure the uplink module interfaces and network interfaces on Virtual Chassis member switches as VCPs and interconnect the members to form a LAG, be sure you have:

1. Installed the SFP uplink modules in the SWA-0 and SWA-2 switches and installed the XFP uplink modules in the SWA-1 and SWA-3 switches. See *Installing an Uplink Module in an EX4200 Switch*.
2. Powered on SWA-0, connected it to the network, and run the EZSetup program. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.
3. Configured SWA-0 with the virtual management Ethernet (VME) interface for remote, out-of-band management of the Virtual Chassis configuration, if desired. See [“Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis \(CLI Procedure\)” on page 231](#).
4. Ensured that SWA-1 is not powered on and then interconnected SWA-0 and SWA-1 using the dedicated VCPs on the rear panel.



NOTE: The interfaces for the dedicated VCPs are operational by default. They do not need to be configured.

5. Ensured that SWA-2, SWA-3, and SWA-4 are not powered on. They are not connected in any way, so when they are initially powered on they will be standalone switches.

Overview and Topology

In this example, five EX4200 switches will be interconnected to form LAGs for ease of monitoring and manageability. Two of these switches (SWA-0 and SWA-1) are located in wiring closet A and the three others (SWA-2, SWA-3, and SWA-4) are located in wiring closet B. SWA-0 will form one LAG with SWA-2 and another LAG with SWA-4, and SWA-1 will form a LAG with SWA-3.

We will use fiber-optic cables connected to the uplink and network VCPs to interconnect the member switches in wiring closet A to the member switches in wiring closet B.

We will specify the highest mastership priority value (255) for SWA-0 to make it the master before we power on SWA-1. Because SWA-0 and SWA-1 are interconnected with the dedicated VCPs, the master detects that SWA-1 is a member of its Virtual Chassis configuration and assigns it a member ID.

We will use SWA-2 as the backup of the Virtual Chassis configuration. We will configure the same mastership priority value for SWA-2 (255) that we configured for the master. Because we power on SWA-0 before we power on SWA-2, SWA-0 retains mastership of the Virtual Chassis configuration.




NOTE: We recommend setting identical mastership priority values for the master and backup members for high availability and smooth transition of mastership in case the original master becomes unavailable.

We will configure the uplink module interfaces on three of the switches as uplink VCPs. On the EX4200-24F switch we will configure two of the network interfaces as VCPs. We will interconnect two of the SFP uplink VCPs on SWA-0 with two of the SFP uplink VCPs on SWA-2. Similarly, we will interconnect the two XFP uplink VCPs on SWA-1 with the two XFP uplink VCPs on SWA-3. Finally, we will connect the two remaining SFP uplink VCPs on SWA-0 with two network VCPs on SWA-4. As a result, three LAGs will be automatically formed.

[Figure 19 on page 164](#) shows the interconnections used to form LAGs using uplink VCPs and the network VCPs after the procedure below has been completed.

Figure 19: EX4200 Virtual Chassis Interconnected Across Wiring Closets to Form LAGs



Configuration

To configure the Virtual Chassis uplink module interfaces and network interfaces as uplink VCPs and interconnect them between two wiring closets to form LAGs, perform this task:

Step-by-Step Procedure

To configure a Virtual Chassis across multiple wiring closets and interconnect them to form LAGs:

1. Configure the mastership priority of SWA-0 (member 0) to be the highest possible value (255), thereby ensuring that it functions as the master of the expanded Virtual Chassis configuration:
2. Power on SWA-1.
3. Prepare the members in wiring closet A for interconnecting with the member switches in wiring closet B by setting all of the SFP uplink module interfaces on SWA-0 and two of the uplink module interfaces on SWA-1 as uplink VCPs:

```
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 0
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 1
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 2
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 3
```



```
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 0 member 1
user@SWA-0> request virtual-chassis vc-port set pic-slot 1 port 1 member 1
```



NOTE: This example omits the specification of the member *member-id* option in configuring the uplink VCPs for SWA-0 (and, later, for SWA-2). The command applies by default to the switch where it is executed.

4. Power on SWA-2.
5. If SWA-2 was previously configured, revert it to the factory default configuration. See *Reverting to the Default Factory Configuration for the EX Series Switch*.
6. Prepare SWA-2 in wiring closet B by configuring its mastership priority to be the highest possible value (255). Its member ID is currently 0, because it is not yet interconnected with the other members of the Virtual Chassis configuration. It is operating as a standalone switch. Its member ID will change when it is interconnected.

```
[edit virtual-chassis]
user@SWA-2# set member 0 mastership-priority 255
```



NOTE: SWA-2 is configured with the same mastership priority value that we configured for SWA-0. However, the longer uptime of SWA-0 ensures that, once the interconnection is made, SWA-0 functions as the master and SWA-2 functions as the backup.

7. Specify two of the SFP uplink module interfaces in SWA-2 as uplink VCPs. The member IDs are 0, because they are not yet interconnected with the other members of the Virtual Chassis configuration:



NOTE: The settings of the uplink VCPs remain intact when SWA-2 reboots and joins the Virtual Chassis configuration as member 2.

```
user@SWA-2> request virtual-chassis vc-port set pic-slot 1 port 0
user@SWA-2> request virtual-chassis vc-port set pic-slot 1 port 1
```

8. Power off SWA-2.
9. Physically interconnect SWA-0 and SWA-2 across wiring closets using two of the uplink VCPs on each switch.

10. Power on SWA-2. SWA-2 joins the Virtual Chassis configuration and a LAG is automatically formed between SWA-0 and SWA-2. In addition, although SWA-0 and SWA-2 have the same mastership priority value (255), SWA-0 was powered on first and thus has longer uptime. This results in SWA-0 retaining mastership while SWA-2 reboots and joins the now expanded Virtual Chassis configuration as the backup, with member ID 2.
11. Power on SWA-3.
12. If SWA-3 was previously configured, revert it to the factory default configuration.
13. Specify both XFP uplink module interfaces in SWA-3 as uplink VCPs:

```
user@SWA-3> request virtual-chassis vc-port set pic-slot 1 port 0
user@SWA-3> request virtual-chassis vc-port set pic-slot 1 port 1
```
14. Power off SWA-3.
15. Physically interconnect SWA-3 with SWA-2 using their dedicated VCPs.
16. Physically interconnect SWA-1 and SWA-3 across wiring closets using their uplink VCPs.
17. Power on SWA-3. It joins the Virtual Chassis configuration as member 3.



NOTE: Member ID 3 is assigned to SWA-3 because SWA-3 was powered on after members 0, 1, and 2.

A LAG is automatically formed between SWA-1 and SWA-3. In addition, both SWA-1 and SWA-3 have the default mastership priority value (128) and function in a linecard role.

18. Power on SWA-4.
19. If SWA-4 was previously configured, revert it to the factory default configuration.
20. Configure two of the network interfaces on SWA-4 as uplink VCPs:

```
user@SWA-4> request virtual-chassis vc-port set pic-slot 0 port 20
user@SWA-4> request virtual-chassis vc-port set pic-slot 0 port 21
```
21. Power off SWA-4.

22. Physically interconnect SWA-4 and SWA-0 across wiring closets using the network VCPs on SWA-4 and the two remaining SFP uplink VCPs on SWA-0.
23. Power on SWA-4. A LAG is automatically formed between SWA-4 and SWA-0. In addition, SWA-4 joins the Virtual Chassis configuration in the linecard role.

Results Display the results of the configuration on SWA-0:

```
user@SWA-0> show configuration virtual-chassis
member 0 {
  mastership-priority 255;
}
member 1 {
  mastership-priority 128;
}
member 2 {
  mastership-priority 255;
}
member 3 {
  mastership-priority 128;
}
member 4 {
  mastership-priority 128;
}
}
```

Verification

To confirm that the configuration is working properly, perform these tasks:

- [Verifying the Member IDs and Roles of the Member Switches on page 167](#)
- [Verifying That the VCPs Are Operational on page 168](#)

Verifying the Member IDs and Roles of the Member Switches

Purpose Verify that all the interconnected member switches are included within the Virtual Chassis configuration and that their roles are assigned appropriately.

Action Display the members of the Virtual Chassis configuration:

```
user@SWA-0> show virtual-chassis
```

```
Virtual Chassis ID: 0000.e255.00e0
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID Interface
0 (FPC 0)	Prsnt	abc123	ex4200-48p	255	Master*	1 vcp-0 1 vcp-1 2 vcp-255/1/0

							2 vcp-255/1/1 4 vcp-255/0/20 4 vcp-255/0/21
1 (FPC 1)	Prsnt	def456	ex4200-24t	128	Linecard	0 vcp-0 0 vcp-1 3 vcp-255/1/0 3 vcp-255/1/1	
2 (FPC 2)	Prsnt	ghi789	ex4200-48p	255	Backup	3 vcp-0 3 vcp-1 0 vcp-255/1/0 0 vcp-255/1/1	
3 (FPC 3)	Prsnt	jk1012	ex4200-24t	128	Linecard	2 vcp-0 2 vcp-1 1 vcp-255/1/0 1 vcp-255/1/1	
4 (FPC 4)	Prsnt	mno345	ex4200-24f	128	Linecard	0 vcp-255/1/2 0 vcp-255/1/3	

Meaning The `show virtual-chassis` command lists the member switches interconnected in a Virtual Chassis configuration with the member IDs that have been assigned by the master, the mastership priority values, and the roles. It also displays the neighbor members with which each member is interconnected by the dedicated VCPs, by uplink VCPs, and by network VCPs.

Verifying That the VCPs Are Operational

Purpose Verify that the dedicated VCPs interconnecting member switches in wiring closets A and B and the uplink and network VCPs interconnecting the member switches between wiring closets are operational.

Action Display the Virtual Chassis interfaces:

```
user@SWA-0> show virtual-chassis vc-port all-members
```

fpc0:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	1	vcp-0
vcp-1	Dedicated	2	Up	32000	1	vcp-1
1/0	Configured	3	Up	1000	2	vcp-255/1/0
1/1	Configured	3	Up	1000	2	vcp-255/1/1
1/2	Configured	4	Up	1000	4	vcp-255/0/20
1/3	Configured	4	Up	1000	4	vcp-255/0/21

fpc1:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	0	vcp-0
vcp-1	Dedicated	2	Up	32000	0	vcp-1
1/0	Configured	3	Up	10000	3	vcp-255/1/0
1/1	Configured	3	Up	10000	3	vcp-255/1/1
fpc2:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	3	vcp-0
vcp-1	Dedicated	2	Up	32000	3	vcp-1
1/0	Configured	3	Up	1000	0	vcp-255/1/0
1/1	Configured	3	Up	1000	0	vcp-255/1/1
1/2		-1	Down	1000		
1/3		-1	Down	1000		
fpc3:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	2	vcp-0
vcp-1	Dedicated	2	Up	32000	2	vcp-1
1/0	Configured	3	Up	10000	1	vcp-255/1/0
1/1	Configured	3	Up	10000	1	vcp-255/1/1
fpc4:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Down	32000		
vcp-1	Dedicated	2	Down	32000		
0/20	Configured	3	Up	1000	0	vcp-255/1/2
0/21	Configured	3	Up	1000	0	vcp-255/1/3

Meaning The dedicated VCPs are displayed as **vcp-0** and **vcp-1**. The uplink module interfaces that have been set as uplink VCPs are displayed as **1/0**, **1/1**, **1/2**, and **1/3**. The network interfaces that have been set as VCPs are displayed as **0/20** and **0/21**. The neighbor interface names of uplink and network VCPs are of the form **vcp-255/pic/port**—for example, **vcp-255/1/0**. In that name, **vcp-255** indicates that the interface is a VCP, **1** is the uplink PIC number, and **0** is the port number. The **fpc** number is the same as the member ID. The trunk ID is a positive number ID assigned to the LAG formed by the Virtual Chassis. If no LAG is formed, the value is **-1**.



NOTE: Each switch assigns the trunk IDs to its local interfaces. As a result, the pair of interfaces that form one end of a LAG on one switch will have the same trunk ID, and the pair of interfaces that form the other end of the LAG will have the same trunk ID, but the trunk IDs on either end of the LAG might be different. For example, in [Figure 19 on page 164](#), the uplink VCPs 1/2 and 1/3 on SWA-0 form a LAG with the network VCPs 0/20 and 0/21 on SWA-4. Uplink VCPs 1/2 and 1/3 on SWA-0 both have trunk ID 4, while network VCPs 0/20 and 0/21 on SWA-4 both have trunk ID 3. The trunk IDs are different between the switches because SWA-0 assigns the trunk IDs for its local uplink VCPs and SWA-4 assigns the trunk IDs for its local VCPs.

Troubleshooting

To troubleshoot a Virtual Chassis configuration that is interconnected across wiring closets, perform this task:

- [Troubleshooting Nonoperational VCPs on page 170](#)

Troubleshooting Nonoperational VCPs

Problem	An uplink VCP shows a status of down .
Solution	<ul style="list-style-type: none">• Check the cable to make sure that it is properly and securely connected to the interfaces.• If the VCP is an uplink module interface, make sure that it has been explicitly set as an uplink VCP.• If the VCP is an uplink module interface, make sure that you have specified the options (<i>pic-slot</i>, <i>port</i>, and <i>member</i>) correctly.
Related Documentation	<ul style="list-style-type: none">• Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76• Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet on page 92• Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration on page 107• Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223

Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches

The automatic software update feature automatically updates the Junos OS version on prospective member switches as they are added to a Virtual Chassis configuration of EX4200 switches so the new member switch immediately joins the EX4200 Virtual

Chassis configuration and is put in the active state. If the software version on the new switch is not the same as the version running on the master, the master keeps the new switch in the inactive state. If you have not enabled the automatic software update feature, you will have to manually install the correct software version on each prospective member switch as it is added to the Virtual Chassis configuration.

This example describes how to configure the Virtual Chassis automatic software update feature:

- [Requirements on page 171](#)
- [Overview and Topology on page 171](#)
- [Configuration on page 172](#)
- [Verification on page 172](#)

Requirements

This example uses the following hardware and software components:

- Three EX4200 switches
- Junos OS Release 10.0 or later for EX Series switches

Before you begin, be sure you have:

1. Ensured that two member switches are running the same version of Junos OS for EX Series switches so that they can form the initial Virtual Chassis configuration.
2. Cabled and powered on those two switches to create the Virtual Chassis configuration. See *Connecting a Virtual Chassis Cable to an EX4200 Switch*.
3. Ensured that you know the name or the URL of the software package to be used by the automatic software update feature.
4. If you are going to perform an automatic software update, ensure that the version of Junos OS running on the Virtual Chassis is compatible with the version of Junos OS running on the prospective member switch for automatic software update. See [“Understanding Automatic Software Update on Virtual Chassis Member Switches” on page 53](#).

Overview and Topology

For a standalone EX4200 switch to join an existing Virtual Chassis configuration, it must be running the same version of Junos OS that is running on the Virtual Chassis master. If the software version on the new switch is not the same as the version running on the master, the master keeps the new switch in the inactive state.

The topology for this example consists of three EX Series switches. Two of the switches are connected in a Virtual Chassis configuration and are therefore running the same version of Junos OS for EX Series switches. The third switch is a standalone switch that

is running a different software version than the Virtual Chassis member switches. In this example, we will enable the automatic software update feature on the Virtual Chassis configuration and then add the third switch to the configuration. The master will detect the presence of the new switch, check the software version running on the new switch, and, because it is not the same version currently running on the master, will update the software version on the new switch and reboot the switch so that it can join the Virtual Chassis configuration and immediately be put in the active state.

Configuration

To configure automatic software update, perform this task:

Step-by-Step Procedure

To configure automatic software update:

1. Enable automatic software update and configure the path to the software package:


```
[edit]
user@switch# set virtual-chassis auto-sw-update package-name
/var/tmp/jinstall-ex-4200-10.0R1.1-domestic-signed.tgz
```
2. Connect the new switch to the existing Virtual Chassis configuration, and power on the switch.

Results Check the results of the configuration:

```
[edit virtual-chassis]
user@switch# show
auto-sw-update {
  package-name /var/tmp/jinstall-ex-4200-10.0R1.1-domestic-signed.tgz;
}
```

Verification

To verify that the software version on the new switch has been updated and that the switch has joined the Virtual Chassis configuration, perform this task:

- [Verifying That the Software Version Is Updated on page 172](#)

Verifying That the Software Version Is Updated

Purpose Verify that the new switch has joined the Virtual Chassis configuration.



NOTE: If the software version on the new switch had not been updated successfully, the master would not allow the switch to join the Virtual Chassis configuration.

Action Issue the **show virtual-chassis** command.

```
user@switch> show virtual-chassis
Virtual Chassis ID: 0019.e250.47a0
```

Member ID	Status	Serial No	Model	Mastership priority	Role	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	AK0207360276	ex4200-24t	255	Master*	1	vcp-1
						2	vcp-0
1 (FPC 1)	Prsnt	AK0207360281	ex4200-24t	255	Backup	2	vcp-1
						0	vcp-0
2 (FPC 2)	Prsnt	AJ0207391130	ex4200-48p	128	Linecard	0	vcp-1
						1	vcp-0

Meaning Because in the initial two-member Virtual Chassis configuration member 0 was the master and member 1 was the backup, the output shows that the new switch has been assigned member ID 2 and has been given the **Linecard** role. The **Status** field shows that member 2 is **Prsnt**, which means that it is in the active state.

- Related Documentation**
- [Configuring Automatic Software Update on Virtual Chassis Member Switches on page 235](#)
 - [Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\) on page 201](#)

CHAPTER 3

Configuration Tasks

- [Configuring an EX2200 Virtual Chassis \(CLI Procedure\) on page 176](#)
- [Configuring an EX3300 Virtual Chassis \(CLI Procedure\) on page 181](#)
- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
- [Installing Software on a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Switches \(CLI Procedure\) on page 198](#)
- [Adding a New Switch to an Existing EX3300 Virtual Chassis \(CLI Procedure\) on page 200](#)
- [Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\) on page 201](#)
- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)
- [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)
- [Removing or Replacing a Member Switch of a Virtual Chassis Configuration on page 213](#)
- [Removing an EX4200, EX4500, or EX4550 Switch From a Mixed Virtual Chassis \(CLI Procedure\) on page 219](#)
- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Setting a Port on an EX2200 Switch as a Virtual Chassis Port \(CLI Procedure\) on page 222](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)
- [Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\) on page 229](#)
- [Setting an Uplink Port as a Virtual Chassis Port Using the LCD Panel on page 230](#)
- [Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis \(CLI Procedure\) on page 231](#)
- [Configuring the Timer for the Backup Member to Start Using Its Own MAC Address, as Master of a Virtual Chassis on page 232](#)

- [Configuring Fast Failover in an EX Series Virtual Chassis on page 233](#)
- [Disabling Fast Failover in an EX Series Virtual Chassis on page 234](#)
- [Disabling Split and Merge in a Virtual Chassis on page 235](#)
- [Configuring Automatic Software Update on Virtual Chassis Member Switches on page 235](#)
- [Upgrading Software Using Nonstop Software Upgrade on EX Series Virtual Chassis and Mixed Virtual Chassis \(CLI Procedure\) on page 237](#)
- [Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge on page 241](#)
- [Configuring Graceful Routing Engine Switchover in a Virtual Chassis on page 242](#)
- [Resetting the EX4500 Switch to Run as a Standalone Switch \(CLI Procedure\) on page 243](#)
- [Enabling VLAN Pruning for Broadcast, Multicast, and Unknown Unicast Traffic in an EX Series Virtual Chassis \(CLI Procedure\) on page 244](#)

Configuring an EX2200 Virtual Chassis (CLI Procedure)

You configure an EX2200 Virtual Chassis by configuring interfaces connecting EX2200 switches into Virtual Chassis ports (VCPs). Optical interfaces on EX2200 and EX2200-C switches can be configured into VCPs and can be used to connect EX2200 switches into a Virtual Chassis over short and long distances (up to 49.7 miles). All RJ-45 interfaces, including built-in network ports with 10/100/1000BASE-T Gigabit Ethernet connectors and 1000BASE-T RJ-45 transceivers, on EX2200 and EX2200-C switches can also be configured into VCPs.

An EX2200 Virtual Chassis can be configured with either:

- A preprovisioned configuration—You can deterministically control the member ID and role assigned to a member switch by tying it to its serial number.
- A nonprovisioned configuration—The master sequentially assigns a member ID to other member switches. The role is determined by the mastership priority value and other factors in the master election algorithm.



NOTE: A Virtual Chassis configuration has two Routing Engines—the master switch and the backup switch. Therefore, we recommend that you always use `commit synchronize` rather than simply `commit` to save configuration changes made for a Virtual Chassis. This ensures that the configuration changes are saved in both Routing Engines.



NOTE: You do not have to purchase a license to configure an EX2200 Virtual Chassis starting in Junos OS release 12.3R2.

Prior to Junos OS release 12.3R2, two enhanced feature licenses (EFLs)—one for the switch in the master role and another for the switch in the backup role—must be purchased to create an EX2200 Virtual Chassis. See *Understanding Software Licenses for EX Series Switches*.

This topic includes:

- [Configuring an EX2200 Virtual Chassis with a Preprovisioned Configuration File on page 177](#)
- [Configuring an EX2200 Virtual Chassis with a Nonprovisioned Configuration File on page 179](#)

Configuring an EX2200 Virtual Chassis with a Preprovisioned Configuration File

Preprovisioning a Virtual Chassis configuration allows you to assign the member ID and role for each switch in the Virtual Chassis.

To configure a Virtual Chassis using a preprovisioned configuration:



NOTE: We recommend that you physically cable the ports as the final step of this procedure.

You can, however, configure an EX2200 Virtual Chassis while the cables are physically connected.

1. Make a list of the serial numbers of all the switches to be connected in a Virtual Chassis configuration.
2. Note the desired role (**routing-engine** or **line-card**) of each switch. If you configure the member with a **routing-engine** role, it is eligible to function in the master or backup role. If you configure the member with a **line-card** role, it is not eligible to function in the master or backup role.
3. Power on only the switch that you plan to use as the master switch.
4. Run the EZSetup program on the master switch, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.



NOTE: The properties that you specify for the master switch apply to the entire Virtual Chassis configuration.

5. (Optional) Configure the master switch with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis:

```
[edit]
user@switch# set interfaces vme unit 0 family inet address /ip-address/mask/
```

6. Specify the preprovisioned configuration mode:

```
[edit virtual-chassis]
user@switch# set preprovisioned
```

7. Specify all the members that you want included in the Virtual Chassis, listing each switch's serial number with the desired member ID and role:

```
[edit virtual-chassis]
user@switch# set member 0 serial-number abc123 role routing-engine
user@switch# set member 1 serial-number def456 role routing-engine
user@switch# set member 2 serial-number ghi789 role line-card
user@switch# set member 3 serial-number jkl012 role line-card
```

8. (Optional. Recommended for a two-member Virtual Chassis) Disable the split and merge feature:

```
[edit virtual-chassis]
user@switch# set no-split-detection
```

9. Power on the other member switches. The member IDs and roles have been determined by the configuration, so you can power on the member switches in any order.
10. On each individual member switch, configure the ports that will be used to interconnect the EX2200 member switches into VCPs.

You can configure a port on an EX2200 switch as a VCP using the following command:

```
user@switch> request virtual-chassis vc-port set pic-slot pic-slot-number port port-number
```

where *pic-slot-number* is the PIC slot number. The PIC slot number is *0* when you are configuring a built-in port as a VCP and *1* when you are configuring an uplink port as a VCP.

For instance, if you wanted to set built-in port 20 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 0 port 20
```

If you wanted to set uplink port 2 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 2
```

The VCPs automatically bundle into a Link Aggregation Group when two or more interfaces are configured into VCPs between the same two member switches. See [“Understanding Virtual Chassis Port Link Aggregation” on page 41](#).



NOTE: You cannot modify the mastership priority when you are using a preprovisioned configuration. The mastership priority values are generated automatically and controlled by the role that is assigned to the member switch in the configuration file. The two Routing Engines are assigned the same mastership priority value. However, the member that was powered on first has higher prioritization according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected”](#) on page 36.

Configuring an EX2200 Virtual Chassis with a Nonprovisioned Configuration File

You can use nonprovisioned configuration to configure an EX2200 Virtual Chassis.

To configure the Virtual Chassis using a nonprovisioned configuration:



NOTE: We recommend that you physically cable the ports as the final step of this procedure.

You can, however, configure an EX2200 Virtual Chassis while the cables are physically connected.

1. Power on only the switch that you plan to use as the master switch.
2. Run the EZSetup program on the master switch, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.



NOTE: The properties that you specify for the master switch apply to the entire Virtual Chassis configuration.

3. (Optional) Configure the master switch with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis:

```
[edit]
user@switch# set interfaces vme unit 0 family inet address /ip-address/mask/
```

4. (Optional) Configure mastership priority for the other member switches:

```
[edit virtual-chassis]
user@switch# set member 0 mastership-priority 255
user@switch# set member 1 mastership-priority 255
```

5. (Optional. Recommended for a two-member Virtual Chassis) On the master switch, disable the split and merge feature:

```
[edit virtual-chassis]
user@switch# set no-split-detection
```

6. Power on the other member switches.
7. On each individual member switch, configure the ports that will be used to interconnect the EX2200 member switches into VCPs.

You can configure a port on an EX2200 switch as a VCP using the following command:

```
user@switch> request virtual-chassis vc-port set pic-slot pic-slot-number port port-number
```

where *pic-slot-number* is the PIC slot number. The PIC slot number is 0 when you are configuring a built-in port as a VCP and 1 when you are configuring an uplink port as a VCP.

For instance, if you wanted to set built-in port 20 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 0 port 20
```

If you wanted to set uplink port 2 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 2
```

The VCPs automatically bundle into a Link Aggregation Group when two or more interfaces are configured into VCPs between the same two member switches. See [“Understanding Virtual Chassis Port Link Aggregation” on page 41](#).



NOTE: If you do not edit the Virtual Chassis configuration file, a nonprovisioned configuration is generated by default. The mastership priority value for each member switch is 128. The master role is selected by default. You can change the role that is performed by the members by modifying the mastership priority. See [“Configuring Mastership of a Virtual Chassis” on page 220](#). We recommend that you specify the same mastership priority value for the desired master and backup members. In this example, the highest possible mastership priority has been assigned to two members. However, the member that was powered on first has higher prioritization according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). The other members use the default mastership priority in this example, which configures them to function in the role of linecard.



NOTE: If you want to change the member ID that the master has assigned to a member switch, use the `request virtual-chassis renumber` command.

Related Documentation

- [Virtual Chassis Overview for Switches on page 3](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding EX2200 Virtual Chassis Hardware Configuration](#)

- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Configuring an EX3300 Virtual Chassis (CLI Procedure)

You must interconnect EX3300 switches using uplink ports configured as Virtual Chassis ports (VCPs). Uplink ports 2 and 3 on an EX3300 switch are configured as VCPs by default. You do not have to configure these interfaces to connect EX3300 switches together in a Virtual Chassis.

The uplink ports configured as VCPs are used to connect EX3300 switches into a Virtual Chassis in the same or different wiring closets over short and long distances (up to 6.2 miles).



NOTE: A multimember Virtual Chassis configuration has two Routing Engines, one in the master and the other in the backup. Therefore, we recommend that you always use `commit synchronize` rather than simply `commit` to save configuration changes made for a Virtual Chassis. This ensures that the configuration changes are saved in both Routing Engines.

An EX3300 Virtual Chassis can be configured with either:

- A preprovisioned configuration—Allows you to deterministically control the member ID and role assigned to a member switch by tying it to its serial number.
- A nonprovisioned configuration—The master sequentially assigns a member ID to other member switches. The role is determined by the mastership priority value and other factors in the master election algorithm.

This topic includes:

- [Configuring an EX3300 Virtual Chassis with a Preprovisioned Configuration File on page 181](#)
- [Configuring an EX3300 Virtual Chassis with a Nonprovisioned Configuration File on page 183](#)

Configuring an EX3300 Virtual Chassis with a Preprovisioned Configuration File

Preprovisioning a Virtual Chassis configuration allows you to assign the member ID and role for each switch in the Virtual Chassis. Preprovisioning is supported for an EX3300 Virtual Chassis.

To configure a Virtual Chassis using a preprovisioned configuration:

1. Make a list of the serial numbers of all the switches to be connected in a Virtual Chassis configuration.
2. Note the desired role (**routing-engine** or **line-card**) of each switch. If you configure the member with a **routing-engine** role, it is eligible to function in the master or backup role. If you configure the member with a **line-card** role, it is not eligible to function in the master or backup role.
3. Interconnect the member switches using uplink ports 2 and 3 of your EX3300 switches. See *Virtual Chassis Cabling Configuration Examples for EX3300 Switches*.



NOTE: For management purposes, we recommend arranging the switches in member ID sequence, either from top to bottom or from bottom to top (0–5).

4. Power on only the switch that you plan to use as the master switch. Do not power on the other switches at this time.
5. Run the EZSetup program on the master switch, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.



NOTE: The properties that you specify for the master switch apply to the entire Virtual Chassis configuration, including all the members listed in the preprovisioned configuration file.

6. (Optional) Configure the master switch with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis:

```
[edit]
user@switch# set interfaces vme unit 0 family inet address /ip-address/mask/
```

7. Specify the preprovisioned configuration mode:

```
[edit virtual-chassis]
user@switch# set preprovisioned
```

8. Specify all the members that you want to included in the Virtual Chassis configuration, listing each switch's serial number with the desired member ID and the desired role:

```
[edit virtual-chassis]
user@switch# set member 0 serial-number abc123 role routing-engine
user@switch# set member 1 serial-number def456 role line-card
user@switch# set member 2 serial-number ghi789 role line-card
user@switch# set member 3 serial-number jkl012 role line-card
user@switch# set member 4 serial-number mno345 role line-card
```

```
user@switch# set member 5 serial-number pqr678 role routing-engine
```

9. (Optional. Recommended for a two-member Virtual Chassis) Disable the split and merge feature:

```
[edit virtual-chassis]
user@switch# set no-split-detection
```

10. Power on the member switches.



NOTE: You cannot modify the mastership priority when you are using a preprovisioned configuration. The mastership priority values are generated automatically and controlled by the role that is assigned to the member switch in the configuration file. The two Routing Engines are assigned the same mastership priority value. However, the member that was powered on first has higher prioritization according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#).

Configuring an EX3300 Virtual Chassis with a Nonprovisioned Configuration File

Nonprovisioned configuration can be used to configure an EX3300 Virtual Chassis.

To configure the Virtual Chassis using a nonprovisioned configuration:

1. Interconnect the member switches using uplink ports 2 and 3 on your EX3300 switches. See *Virtual Chassis Cabling Configuration Examples for EX3300 Switches*.



NOTE: For management purposes, we recommend arranging the switches in member ID sequence, either from top to bottom or from bottom to top.

2. Power on only the switch that you plan to use as the master switch (SWA-0). Do not power on the other switches at this time.
3. Run the EZSetup program on SWA-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.



NOTE: The properties that you specify for SWA-0 apply to the entire Virtual Chassis configuration, including all the members interconnected through VCPs.

4. (Optional) Configure SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis:

```
[edit]
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

5. (Optional) Configure mastership priority for the master, backup, and other members:

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 255
user@SWA-0# set member 3 mastership-priority 255
```

6. (Optional. Recommended for a two-member Virtual Chassis) Disable the split and merge feature:

```
[edit virtual-chassis]
user@SWA-0# set no-split-detection
```

7. Power on the member switches in sequential order, one by one.



NOTE: If you do not edit the Virtual Chassis configuration file, a nonprovisioned configuration is generated by default. The mastership priority value for each member switch is 128. The master role is selected by default. You can change the role that is performed by the members by modifying the mastership priority. See [“Configuring Mastership of a Virtual Chassis” on page 220](#). We recommend that you specify the same mastership priority value for the desired master and backup members. In this example, the highest possible mastership priority has been assigned to two members. However, the member that was powered on first has higher prioritization according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). The other members use the default mastership priority in this example, which configures them to function in the role of linecard.



NOTE: If you want to change the member ID that the master has assigned to a member switch, use the [request virtual-chassis renumber](#) command.

Related Documentation

- [Example: Configuring an EX3300 Virtual Chassis with a Master and Backup on page 72](#)
- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Configuring an EX4200, EX4500, or EX4550 Virtual Chassis (CLI Procedure)

This topic does not apply to a mixed Virtual Chassis configuration. For information on configuring a mixed Virtual Chassis, see [“Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\)” on page 195](#).

You can interconnect EX4200, EX4500, and EX4550 switches using the dedicated Virtual Chassis ports (VCPs) on the rear panel of EX4200 switches and on the Virtual Chassis

module in EX4500 and EX4550 switches. You do not have to configure the interfaces for the dedicated VCPs.

If you want to interconnect member switches that are located in different racks or wiring closets, you interconnect them using optical ports configured as VCPs. See [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#) or [“Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\)” on page 229](#).



NOTE: A Virtual Chassis configuration has two Routing Engines, one in the master and the other in the backup. Therefore, we recommend that you always use **commit synchronize** rather than simply **commit** to save configuration changes made for a Virtual Chassis. This ensures that the configuration changes are saved in both Routing Engines.

An EX4200, EX4500, or EX4550 Virtual Chassis can be configured with either:

- A preprovisioned configuration—Allows you to deterministically control the member ID and role assigned to a member switch by tying it to its serial number.
- A nonprovisioned configuration—The master sequentially assigns a member ID to other member switches. The role is determined by the mastership priority value and other factors in the master election algorithm.

This topic includes:

- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis with a Preprovisioned Configuration File on page 185](#)
- [Configuring an EX4200, an EX4500, or EX4550 Virtual Chassis with a Nonprovisioned Configuration File on page 187](#)

Configuring an EX4200, EX4500, or EX4550 Virtual Chassis with a Preprovisioned Configuration File

Preprovisioning a Virtual Chassis configuration allows you to assign the member ID and role for each switch in the Virtual Chassis.

To configure a Virtual Chassis using a preprovisioned configuration:

1. Make a list of the serial numbers of all the switches to be connected in the Virtual Chassis configuration.
2. Note the desired role (**routing-engine** or **line-card**) you want for each switch. If you configure the member with a **routing-engine** role, it is eligible to function as a master or backup. If you configure the member with a **line-card** role, it is not eligible to become a master or backup.

- Interconnect the member switches using the dedicated VCPs. See *Connecting a Virtual Chassis Cable to an EX4200 Switch* or *Connecting a Virtual Chassis Cable to an EX4500 Switch*.



NOTE: For management purposes, we recommend arranging the switches in member ID sequence, either from top to bottom or from bottom to top (0–9).

- Power on only the switch that you plan to use as the master switch. Do not power on the other switches at this time.
- Run the EZSetup program on the master switch, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.



NOTE: The properties that you specify for the master switch apply to the entire Virtual Chassis configuration, including all the members listed in the preprovisioned configuration file.

- (Optional) Configure the master switch with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration:

```
[edit]
user@switch# set interfaces vme unit 0 family inet address /ip-address/mask/
```

- Specify the preprovisioned configuration mode:

```
[edit virtual-chassis]
user@switch# set preprovisioned
```

- From the master switch, specify all the members that you want to include in the Virtual Chassis configuration, listing each switch's serial number with the desired member ID and the desired role:

```
[edit virtual-chassis]
user@switch# set member 0 serial-number abc123 role routing-engine
user@switch# set member 1 serial-number def456 role line-card
user@switch# set member 2 serial-number ghi789 role line-card
user@switch# set member 3 serial-number jkl012 role line-card
user@switch# set member 4 serial-number mno345 role line-card
user@switch# set member 5 serial-number pqr678 role routing-engine
user@switch# set member 6 serial-number stu901 role line-card
user@switch# set member 7 serial-number vwx234 role line-card
user@switch# set member 8 serial-number yza567 role line-card
user@switch# set member 9 serial-number bcd890 role line-card
```

- (Optional. Recommended for a two-member Virtual Chassis) Disable the split and merge feature:

```
[edit virtual-chassis]
user@switch# set no-split-detection
```

10. Power on the member switches.

11. (EX4500 switches only) Verify the PIC mode setting:

```
user@switch> show chassis pic-mode
```

If the PIC mode setting is not set to **virtual-chassis**, set the PIC mode to **virtual-chassis**:

```
user@switch> request chassis pic-mode virtual-chassis
```



NOTE: This step is required if you are using the dedicated VCPs on the Virtual Chassis module to connect the Virtual Chassis.

The PIC mode setting has no impact on uplink ports that are configured as VCPs.



NOTE: You cannot modify the mastership priority when you are using a preprovisioned configuration. The mastership priority values are generated automatically and controlled by the role that is assigned to the member switch in the configuration file. The two Routing Engines are assigned the same mastership priority value. However, the member that was powered on first has higher prioritization according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected”](#) on page 36.

Configuring an EX4200, an EX4500, or EX4550 Virtual Chassis with a Nonprovisioned Configuration File

To configure the Virtual Chassis using a nonprovisioned configuration:

1. Interconnect the member switches using the dedicated VCPs. See *Connecting a Virtual Chassis Cable to an EX4200 Switch* or *Connecting a Virtual Chassis Cable to an EX4500 Switch*.



NOTE: For management purposes, we recommend arranging the switches in member ID sequence, either from top to bottom or from bottom to top (0–9).

2. Power on only the switch that you plan to use as the master switch (SWA-0). Do not power on the other switches at this time.

3. Run the EZSetup program on SWA-0, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for details.



NOTE: The properties that you specify for SWA-0 apply to the entire Virtual Chassis configuration, including all the members interconnected through VCPs.

4. (Optional) Configure SWA-0 with the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis configuration, if desired:

```
[edit]
user@SWA-0# set interfaces vme unit 0 family inet address /ip-address/mask/
```

5. Configure mastership priority for the master, backup, and other members, if desired:

```
[edit virtual-chassis]
user@SWA-0# set member 0 mastership-priority 255
user@SWA-0# set member 5 mastership-priority 255
```

6. (Optional. Recommended for a two-member Virtual Chassis) Disable the split and merge feature:

```
[edit virtual-chassis]
user@SWA-0# set no-split-detection
```

7. Power on the member switches in sequential order, one by one.

8. (EX4500 switches only) Enter the **show chassis pic-mode** operational mode command to verify the current PIC mode setting. If the PIC mode is currently set to **intraconnect**, enter the **request chassis pic-mode virtual-chassis** operational mode command to set the PIC mode to **virtual-chassis**. Reboot the switch to complete the procedure.



NOTE: This step is only required if you are using the dedicated VCP ports on the Virtual Chassis module.



NOTE: If you do not edit the Virtual Chassis configuration file, a nonprovisioned configuration is generated by default. The mastership priority value for each member switch is 128. The master role is selected by default. You can change the role that is performed by the members by modifying the mastership priority. See [“Configuring Mastership of a Virtual Chassis” on page 220](#). We recommend that you specify the same mastership priority value for the desired master and backup members. In this example, the highest possible mastership priority has been assigned to two members. However, the member that was powered on first has higher prioritization according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). The other members use the default mastership priority in this example, which configures them to function in the role of linecard.



NOTE: If you want to change the member ID that the master has assigned to a member switch, use the [request virtual-chassis renumber](#) command.

Related Documentation

- [Example: Configuring a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis on page 139](#)
- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Configuring a Virtual Chassis on an EX Series Switch (J-Web Procedure)

- [Configuring an EX2200, EX2200-C, EX3300, EX4200, EX4300, EX4500, EX4550, or EX4600 Virtual Chassis \(J-Web Procedure\) on page 189](#)
- [Enabling Virtual Chassis Mode on an EX8200 Switch \(J-Web Procedure\) on page 191](#)
- [Configuring an EX8200 Virtual Chassis \(J-Web Procedure\) on page 191](#)

Configuring an EX2200, EX2200-C, EX3300, EX4200, EX4300, EX4500, EX4550, or EX4600 Virtual Chassis (J-Web Procedure)



NOTE: This topic applies only to the J-Web Application package.

To take advantage of the scalability features of EX2200, EX2200-C, EX3300, EX4200, EX4300, EX4500, EX4550, and EX4600 switches, you can configure a Virtual Chassis. EX2200 and EX2200-C Virtual Chassis can include up to four member switches. EX3300 Virtual Chassis include up to six member switches. For Junos OS Release 14.1X53-D10 and later, EX3300 Virtual Chassis include up to 10 member switches. EX4200, EX4300, EX4500, EX4550, and EX4600 Virtual Chassis can include up to 10 member switches. You can interconnect the member switches by using dedicated Virtual Chassis ports

(VCPs). You do not have to configure the interface for the dedicated VCPs. If you want to interconnect member switches that are located in different racks or wiring closets, interconnect them using 10-gigabit ports (SFP+ uplink module ports or SFP+ network ports for EX4500) configured as VCPs. EX4300, EX4550, and EX4600 switches support 10-gigabit (SFP+ expansion module ports) and 40-gigabit (QSFP+ uplink module ports or fixed ports) Ethernet interface. See [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#).



NOTE: You can form a Virtual Chassis using EX4600 and EX4300 switches. When in a mixed Virtual Chassis consisting of EX4600 switches and EX4300 switches, the EX4600 switches can be the master, backup, or in the linecard role, while the EX4300 switches must be in the linecard role.

To configure a Virtual Chassis by using the J-Web interface:

1. Select **Configure > Virtual Chassis**.



NOTE: After you make changes to the configuration on this page, you must commit the changes for them to take effect. To commit all changes to the active configuration, select **Commit Options > Commit**. See [Using the Commit Options to Commit Configuration Changes](#) for details about all commit options.

2. The properties that you can configure are displayed.

The first section of the Virtual Chassis Configuration page displays the Virtual Chassis member configuration. The display includes a list of member switches, their member IDs, and the mastership priority.

The second section displays the operational status of the Virtual Chassis configuration, member details, and the dedicated and the configured VCPs.

3. Enter information into the page as described in [Table 24 on page 191](#).
4. Click one of the following options:
 - **Add**—To add a member's configuration to the Virtual Chassis configuration, click **Add**.
 - **Edit**—To modify an existing member's configuration, click **Edit**.
 - **Delete**—To delete the configuration of a member, click **Delete**.
5. To configure uplink ports on EX2200, EX2200-C, and EX3300 switches and uplink module ports on EX4200, EX4300, EX4500, and EX4600 switches as VCPs, select the member in the Virtual Chassis members list and select **Action > Set Uplink Port as VCP**. Select the port from the list.

On EX4550 switches, to configure a VCP, select the member in the Virtual Chassis members list and select **Action > Set Port as VCP**. Select the port from the list.

- To remove the VCP configuration from the uplink ports on EX2200, EX2200-C, and EX3300 switches and uplink module ports on EX4200, EX4300, EX4500, and EX4600 switches, select the member in the Virtual Chassis members list and select **Action > Delete Uplink Port as VCP**.

On EX4550 switches, to remove the VCP configuration from the port of a member, select the member in the Virtual Chassis members list and select **Action > Delete Port as VCP**.

Table 24: Virtual Chassis Configuration Fields

Field	Function	Your Action
Member Details		
Member ID	Specifies the identifier for the member switch.	Select an identifier (from 0 through 9) from the list. NOTE: For EX2200 Virtual Chassis, you can select the member ID (from 0 through 3) from the list.
Priority	Specifies the mastership priority to be assigned to the member.	Select a number from 1 through 255 , (255 being the highest priority and 128 , the default).
Disable Management VLAN	If you want to reserve an individual member's management Ethernet port, you can remove that port from being part of the virtual management Ethernet (VME) interface.	Click to disable the management VLAN on the port.
Refresh	Refreshes the operational status of Virtual Chassis members.	Click to refresh the operational status.

Enabling Virtual Chassis Mode on an EX8200 Switch (J-Web Procedure)

Using the J-Web interface, you can enable Virtual Chassis mode on an EX8200 switch. To enable Virtual Chassis mode:

- Select **Configure > Virtual Chassis**. The Virtual Chassis page displays the serial number of the member switch. You need the serial number while preprovisioning the Virtual Chassis.
- Click **Enable Virtual Chassis**.

Configuring an EX8200 Virtual Chassis (J-Web Procedure)

Using the J-Web interface, you can configure an EX8200 Virtual Chassis to include up to four EX8200 switches and one or two XRE200 External Routing Engines. You interconnect the member switches by connecting the management ports to the external Routing Engines, whose ports automatically function as Virtual Chassis ports (VCPs). A

VCP is any port whose function is to send and receive Virtual Chassis Control Protocol (VCCP) traffic to create, monitor, and maintain the Virtual Chassis. VCPs also carry data traffic through the Virtual Chassis.

The EX8200 Virtual Chassis wizard helps to preprovision Virtual Chassis members and to configure Virtual Chassis ports.

To configure an EX8200 Virtual Chassis, select **Configure > Virtual Chassis**. The Virtual Chassis wizard is displayed. You can:

- [Preprovision the Virtual Chassis on page 192](#)
- [Configure Virtual Chassis Members on page 192](#)
- [Configure Virtual Chassis Ports on page 193](#)

Preprovision the Virtual Chassis

If the Virtual Chassis has not been preprovisioned:

1. Select **Preprovision Virtual Chassis**. The prerequisites page is displayed.
2. Ensure that the following prerequisites are met:
 - The same version of Junos OS is running on all XRE200 Routing Engines and switches.
 - Virtual Chassis mode has been enabled on each EX8200 switch.
 - The XRE200 Routing Engines and switches have been cabled and connected.

Click **Next**. The Configure Virtual Chassis Members screen is displayed.

Configure Virtual Chassis Members

When you click **Configure Virtual Chassis Members** in the wizard, you can add a Virtual Chassis member, modify an existing Virtual Chassis member configuration, or delete the Virtual Chassis configuration for an existing member.

To add a Virtual Chassis member, click **Add**. For each member, specify:

- **Member ID**—The identifier for the member switch or the XRE200 External Routing Engine.
- **Serial Number**—The serial number of the member switch or the XRE200 External Routing Engine.
- **Management VLAN**—Click to enable or disable the management VLAN on the port.
- **Location**—A description of the location of the EX8200 member switch or external Routing Engine.
- **Role**—The role to be performed by each EX8200 member switch or each XRE200 External Routing Engine. EX8200 switches must be in the linecard role and XRE200 External Routing Engines must be in the Routing Engine role.

To edit an existing member configuration, click **Edit**.



NOTE: If you are editing an existing member configuration, you can modify only the Management VLAN option and the location of the Virtual Chassis member.

Click **Remove** to delete the Virtual Chassis configuration for an existing member.

Configure Virtual Chassis Ports

To configure Virtual Chassis ports that are needed between the switches for data traffic, select the **Configure Virtual Chassis Ports** option in the wizard.



NOTE: All XRE200 ports, the vcp-0/0 port, and any port on a Virtual Chassis Control Interface (VCCI) module are automatically VCPs. You need not configure these ports as VCPs.

1. Select the member from the list. The switch model, serial number, available ports, and configured ports are displayed. Select **All** to view details of available ports and configured ports of all the members.



NOTE: Only members with active EX8200-8XS line cards are listed. The J-Web interface does not support EX8200-2X4F40TE/PE line cards.

2. To convert network ports to Virtual Chassis ports or to convert Virtual Chassis ports to network ports, click the appropriate arrow.
3. Click **Next**. The Summary page displays the configuration changes. You can edit the configuration.

Release History Table

Release	Description
14.1X53-D10	For Junos OS Release 14.1X53-D10 and later, EX3300 Virtual Chassis include up to 10 member switches.

Related Documentation

- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\) on page 229](#)
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)

- [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
- *Virtual Chassis Cabling Configuration Examples for EX4200 Switches*
- [Understanding EX Series Virtual Chassis on page 8](#)
- *Configuring an EX8200 Virtual Chassis (CLI Procedure)*
- *Example: Setting Up a Full Mesh EX8200 Virtual Chassis with Two EX8200 Switches and Redundant XRE200 External Routing Engines*
- *Adding or Replacing a Member Switch or an External Routing Engine in an EX8200 Virtual Chassis (CLI Procedure)*
- *Verifying the Member ID, Role, and Neighbor Member Connections of an EX8200 Virtual Chassis Member*

Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches (CLI Procedure)

This topic explains how to configure a mixed Virtual Chassis composed of any combination of EX4200, EX4500, and EX4550 switches. For information on configuring an EX4200 Virtual Chassis, EX4500 Virtual Chassis, or EX4550 Virtual Chassis, see [“Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\)”](#) on page 184.

You can configure the following mixed Virtual Chassis:

- Mixed EX4200 and EX4500 Virtual Chassis
- Mixed EX4200 and EX4550 Virtual Chassis
- Mixed EX4200, EX4500, and EX4550 Virtual Chassis
- Mixed EX4500 and EX4550 Virtual Chassis

You can configure up to ten member switches in all mixed Virtual Chassis composed of EX4200, EX4500, and EX4550 switches. You can interconnect and mix any model of EX4200, EX4500, or EX4550 switch into the same mixed Virtual Chassis, and any EX4200, EX4500, or EX4550 switch can assume the master, backup, or linecard role. You can interconnect the member switches using the dedicated Virtual Chassis ports (VCPs) or by configuring optical ports as VCPs.

This procedure uses a preprovisioned Virtual Chassis configuration. A preprovisioned configuration allows you to deterministically control the member ID and role assigned to a member switch by tying it to its serial number.

Nonprovisioned configuration is also supported for a mixed Virtual Chassis configuration. In a nonprovisioned configuration, the master sequentially assigns a member ID to other member switches and the other member switches roles are determined by the mastership priority value and other factors in the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected”](#) on page 36.

Ensure that all switches are running the same version of Junos OS. See *Installing Software on an EX Series Switch with a Single Routing Engine (CLI Procedure)*.

To configure a mixed Virtual Chassis:

1. Make a list of the serial numbers of all the switches to be connected in the Virtual Chassis. You can get the serial numbers in the **show chassis hardware** output or by following the instructions in *Locating the Serial Number on an EX4200 Switch or Component*, *Locating the Serial Number on an EX4500 Switch or Component*, or *Locating the Serial Number on an EX4550 Switch or Component*.
2. Decide which switches you want to act in the master and backup roles. See [“Understanding Virtual Chassis Components”](#) on page 16.

3. Power and log in to the switch that you want to function in the master role. If the switch has not previously been configured, configure it. See *Connecting and Configuring an EX Series Switch (CLI Procedure)*.
4. Power and log in to the switch that you want to function in the backup role. If the switch has not previously been configured, configure it. See *Connecting and Configuring an EX Series Switch (CLI Procedure)*.
5. Power on all other member switches.

6. (EX4500 switches only) Verify the PIC mode setting:

```
user@switch> show chassis pic-mode
```

7. (EX4500 switches only) If the PIC mode was not set to Virtual Chassis mode, set the PIC mode to Virtual Chassis mode:

```
user@switch> request chassis pic-mode virtual-chassis
```



NOTE: This step is required if you are using the dedicated VCPs on the Virtual Chassis module to connect the Virtual Chassis.

The PIC mode setting has no impact on optical ports that are configured as VCPs.

8. (Mixed Virtual Chassis with EX4200 switches only) Set the Virtual Chassis mode to mixed on all member switches if your mixed Virtual Chassis includes EX4200 switches:

```
user@switch> request virtual-chassis mode mixed
```

9. If the PIC mode or the mixed mode was changed in step 7 or step 8, reboot each member switch:

```
user@switch> request system reboot
```

You can skip this step and proceed to step 11 if you did not change the PIC mode or the mixed mode.

10. After you have rebooted the switches, log into the switch that you powered on first. This switch is the master switch.
11. Run the EZSetup program on the master switch, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)*.



NOTE: The properties that you specify for the master switch apply to the entire Virtual Chassis.

12. (Optional) On the master switch, configure the virtual management Ethernet (VME) interface for out-of-band management of the Virtual Chassis, if desired:

```
[edit]
user@switch# set interfaces vme unit 0 family inet address /ip-address/mask/
```

13. On the master switch, specify the preprovisioned configuration mode:

```
[edit virtual-chassis]
user@switch# set preprovisioned
```

14. On the master switch, specify all members for the Virtual Chassis configuration, listing each switch's serial number with the desired member ID and the desired role.



NOTE: The routing-engine role can be assigned to any member switch, unless otherwise noted.

The routing-engine role can be assigned to any member switch in a mixed Virtual Chassis starting in Junos OS Release 11.4.

Ensure that you assign the routing-engine role to two members that are the same type of switch if you are running Junos OS Release 11.2 or 11.3..

Ensure that you assign only the routing-engine role to EX4500 member switches if you are running Junos OS Release 11.1.

```
[edit virtual-chassis]
user@switch# set member 0 serial-number serial-number role routing-engine
user@switch# set member 1 serial-number serial-number role routing-engine
user@switch# set member 2 serial-number serial-number role line-card
user@switch# set member 3 serial-number serial-number role line-card
user@switch# set member 4 serial-number serial-number role line-card
user@switch# set member 5 serial-number serial-number role line-card
user@switch# set member 6 serial-number serial-number role line-card
user@switch# set member 7 serial-number serial-number role line-card
user@switch# set member 8 serial-number serial-number role line-card
user@switch# set member 9 serial-number serial-number role line-card
```

15. Interconnect the member switches by using either the dedicated VCPs on the member switches (see *Connecting a Virtual Chassis Cable to an EX4200 Switch* or *Connecting a Virtual Chassis Cable to an EX4500 Switch*) or by connecting them through the optical ports that you have configured as VCPs (see [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#) or [“Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\)” on page 229](#)).



NOTE: You cannot modify the mastership priority when you are using a preprovisioned configuration. The mastership priority values are generated automatically and controlled by the role that is assigned to the member switch in the configuration file.

For information on adding a switch to an existing Virtual Chassis or configuring a Virtual Chassis port (VCP) to connect member switches over long distances, see [Related Documentation](#).

Related Documentation

- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\) on page 201](#)
- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)
- [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)
- [Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\) on page 229](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Installing Software on a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Switches (CLI Procedure)

You can use this procedure to upgrade or downgrade Junos OS for all member switches in an any operational mixed Virtual Chassis composed of any combination of EX4200, EX4500, or EX4550 switches.

To upgrade Junos OS for an operational mixed Virtual Chassis:

1. Download the same version of Junos OS software for each switch in the mixed Virtual Chassis.



NOTE: You must download Junos OS Release 11.4 or later if you have three or more EX4500 switches in your mixed Virtual Chassis.



NOTE: EX4500 and EX4550 switches run the same Junos OS. You only need to download one Junos OS image if you are running a mixed EX4500 and EX4550 Virtual Chassis.

2. (Optional) Back up the current software configuration to a second storage option. See the [Junos OS Installation and Upgrade Guide](#) for instructions on performing this task.

3. (Optional) Copy the software packages to the member switch acting in the master role. We recommend that you use FTP to copy the file to the `/var/tmp` directory.

This step is optional because Junos OS can also be upgraded when the software image is stored at a remote location. These instructions describe the software upgrade process for both scenarios.

4. Install the new packages on the Virtual Chassis:

```
user@switch> request system software add set [package (package)]
```



NOTE: You enter the `request system software add set [package package]` command once on the Virtual Chassis to download the software package onto all member switches in the mixed Virtual Chassis. If your mixed Virtual Chassis includes at least one EX4200 members switch, ensure that the `package` path points to one EX4200 Junos OS image and, one EX4500 Junos OS image.

You only need to download one EX4500 switch Junos OS image to upgrade a mixed Virtual Chassis because a Junos OS image for an EX4500 switch can be used to upgrade EX4500 and EX4550 switches.

Replace `package` with one of the following paths:

- For a software package in a local directory on the switch—`/var/tmp/package.tgz`.
- For a software package on a remote server:
 - `ftp://hostname/pathname/package.tgz`
 - `http://hostname/pathname/package.tgz`

where `package.tgz` is, for example, `jinstall-ex-4200-11.1R1.8-domestic-signed.tgz`.



NOTE: To abort the installation, do not reboot your Virtual Chassis; instead, finish the installation and then issue the `request system software delete package.tgz` command, where `package.tgz` is, for example, `jinstall-ex-4500-11.1R1.8-domestic-signed.tgz`. This is your last chance to stop the installation.

5. Reboot the Virtual Chassis to start the new software:

```
user@switch> request system reboot
```

6. After the reboot has completed, log in and verify that the new version of the software is properly installed for all member switches in the Virtual Chassis:

```
user@switch> show version
```

- Related Documentation**
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
 - [Understanding Virtual Chassis Components on page 16](#)

Adding a New Switch to an Existing EX3300 Virtual Chassis (CLI Procedure)

You can use this procedure to add an EX3300 switch to an EX3300 Virtual Chassis.

Before you begin, be sure you have:

- Mounted the new switch in a rack.
- Confirmed that the new switch is powered off.
- If you are expanding a preprovisioned configuration, made a note of the serial number (the number is on the back of the switch). You will need to edit the Virtual Chassis configuration to include the serial number of the new member switch.
- If you are expanding a preprovisioned configuration, edited the existing Virtual Chassis configuration to include the serial number of the new member switch. The parameters specified in the master Virtual Chassis configuration file are applied to the new switch after it has been interconnected to an existing member switch.



NOTE: If you are expanding a preprovisioned Virtual Chassis configuration, you can use the autoprovisioning feature to add member switches to that configuration.

- (Optional) Configured Ethernet interfaces on different member switches into the same LAG. See [“Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch” on page 144](#)

An active member switch might temporarily go down before coming back up as part of this procedure. Having traffic load-balanced across member switches using a LAG helps alleviate traffic loss during this procedure.

To add a new member switch to an existing Virtual Chassis configuration::

1. If the new member switch has been previously configured, revert that switch's configuration to the factory defaults. See *Reverting to the Default Factory Configuration for the EX Series Switch*.
2. Interconnect the unpowered new switch to one member of the existing Virtual Chassis configuration using either uplink port 2 or 3. Uplink ports 2 and 3 are configured as VCPs by default. See *Virtual Chassis Cabling Configuration Examples for EX3300 Switches*.

Connect only one VCP on the unpowered new switch to a VCP on a member switch in the existing Virtual Chassis at this point of the procedure.



NOTE: Because EX3300 switches use uplink ports configured as VCPs to form a Virtual Chassis, this step is identical for short and long distance (up to 6.2 miles) VCP connections.

3. Power on the new switch.
4. Confirm that the new member switch is now included within the Virtual Chassis configuration by checking the front-panel LCD for the member ID. It should display a member ID that is greater than 0 (1 through 5), because there is already at least one member of the Virtual Chassis configuration.



NOTE: If you are using a preprovisioned configuration, the member ID is automatically assigned to the member's serial number in the configuration file.

5. Cable the other default VCP - either uplink port 2 or 3 - on the new member switch to the Virtual Chassis.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Related Documentation

- [Example: Expanding an EX3300 Virtual Chassis on page 87](#)

Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis (CLI Procedure)

This topic explains how to add an EX4200 switch to an existing EX4200 Virtual Chassis. For information about adding an EX4200 switch to an EX4500 Virtual Chassis or a mixed Virtual Chassis, see [“Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\)” on page 207](#).

To add an EX4200 switch to an existing EX4200 Virtual Chassis, use the procedure that matches what you need to accomplish:

- [Adding a New Switch to an Existing Virtual Chassis Within the Same Wiring Closet on page 202](#)
- [Adding a New Switch from a Different Wiring Closet to an Existing Virtual Chassis on page 203](#)
- [Adding a New Switch to an Existing Preprovisioned Virtual Chassis Using Autoprovisioning and Automatic VCP Conversion on page 205](#)

Adding a New Switch to an Existing Virtual Chassis Within the Same Wiring Closet

This procedure can be used to add an EX4200 switch to an EX4200 Virtual Chassis.

Before you begin, be sure you have:

- Mounted the new switch in a rack.
- Confirmed that the new switch is powered off.
- If you are expanding a preprovisioned configuration, made a note of the serial number (the number is on the back of the switch). You will need to edit the Virtual Chassis configuration to include the serial number of the new member switch.
- If you are expanding a preprovisioned configuration, edited the existing Virtual Chassis configuration to include the serial number of the new member switch. The parameters specified in the master Virtual Chassis configuration file are applied to the new switch after it has been interconnected to an existing member switch.



.....

NOTE: After you have created a preprovisioned Virtual Chassis configuration, you can use the autoprovisioning feature to add member switches to that configuration.

.....

- (Optional) Configured Ethernet interfaces on different member switches into the same LAG.. See [“Example: Configuring Aggregated Ethernet High-Speed Uplinks Between an EX4200 Virtual Chassis Access Switch and an EX4200 Virtual Chassis Distribution Switch” on page 144](#)

An active member switch might temporarily go down before coming back up as part of this procedure. Having traffic load-balanced across member switches using a LAG helps alleviate traffic loss during this procedure.

To add a new member switch to an existing Virtual Chassis configuration within the same wiring closet:

1. If the new member switch has been previously configured, revert that switch's configuration to the factory defaults. See *Reverting to the Default Factory Configuration for the EX Series Switch*.
2. Interconnect the unpowered new switch to one member of the existing Virtual Chassis configuration using the dedicated Virtual Chassis ports (VCPs). Connect only one VCP

on the unpowered new switch to a VCP on a member switch in the existing Virtual Chassis at this point of the procedure.

3. Power on the new switch.
4. Confirm that the new member switch is now included within the Virtual Chassis configuration by checking the front-panel LCD for the member ID. It should display a member ID that is greater than 0 (1 through 9), because there is already at least one member of the Virtual Chassis configuration.



NOTE: If you are using a preprovisioned configuration, the member ID is automatically assigned to the member's serial number in the configuration file.

5. Cable the other dedicated VCP on the new member switch to the Virtual Chassis.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Adding a New Switch from a Different Wiring Closet to an Existing Virtual Chassis

This procedure can be used to add an EX4200 switch to an EX4200 Virtual Chassis from a different wiring closet to an existing Virtual Chassis.

To add a new switch from a different wiring closet to an existing Virtual Chassis configuration, you must use a long cable to connect the members switches across wiring closets. You can use any SFP, SFP+, or XFP port and a fiber-optic cable for this purpose.

Before you begin, be sure you have:

- Installed the uplink modules needed for the Virtual Chassis configuration. See *Installing an Uplink Module in an EX4200 Switch*.
- Mounted the new switch in a rack.
- If the new member switch has been previously configured, reverted its configuration to the factory defaults. See *Reverting to the Default Factory Configuration for the EX Series Switch*.

- If you are expanding a preprovisioned configuration, made a note of the serial number (the number is on the back of the switch). You will need to edit the Virtual Chassis configuration to include the serial number of the new member switch.
- If you are expanding a preprovisioned configuration, edited the existing Virtual Chassis configuration to include the serial number of the new member switch. You can specify the role of the new member switch when you add its serial number in the Virtual Chassis configuration file. The parameters specified in the master Virtual Chassis configuration file are applied to the new switch after it has been interconnected with its uplink VCP to an existing member switch.



NOTE: After you have created a preprovisioned Virtual Chassis configuration, you can use the autoprovisioning feature to add member switches to that configuration.

To add a new member switch that is going to be interconnected with the existing Virtual Chassis configuration across wiring closets:

1. Power on the new switch.
2. Connect a laptop or terminal to the console port of the switch, or use EZSetup on the LCD Panel of the standalone switch to specify temporary identification parameters. (When you interconnect the new member switch with the existing Virtual Chassis configuration, the master will overwrite and disable any specified parameters that conflict with the Virtual Chassis parameters or assigned member configuration.)
3. Use the CLI or the J-Web interface to set one uplink module port as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 0
```



NOTE: If you are using a nonprovisioned configuration, you might configure the new member switch with a mastership priority value that is less than that of the existing member switches. Doing so ensures that the new member switch will function in a linecard role when it is included within the Virtual Chassis configuration.

4. Power off the new switch.
5. Interconnect the new member switch to one existing member switch in the Virtual Chassis configuration using one of the uplink module ports that you has configured as a VCP. Connect only one VCP on the unpowered new switch to a VCP on a member switch in the existing Virtual Chassis at this point of the procedure.
6. Power on the new member switch.

7. Confirm that the new member switch is now included within the Virtual Chassis configuration by checking the front-panel LCD for the member ID. It should display a member ID that is greater than 0 (1 through 9), because there is already at least one member of the Virtual Chassis configuration.



NOTE: If you are using a preprovisioned configuration, the member ID is automatically assigned to the member's serial number in the configuration file.

8. Cable another user-configured VCP on the new member switch to the Virtual Chassis, if desired.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Adding a New Switch to an Existing Preprovisioned Virtual Chassis Using Autoprovisioning and Automatic VCP Conversion

This procedure can be used to add an EX4200 switch to an existing EX4200 Virtual Chassis using autoprovisioning, where after the new switch is provisioned and cabled into the Virtual Chassis, the interconnecting links automatically convert into VCP links.

Before you begin, be sure you have:

- Installed the uplink modules needed for the Virtual Chassis configuration.
- Mounted the new switch in a rack.
- Ensured that the preprovisioned Virtual Chassis configuration has an active master. For more information, see [“Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File”](#) on page 127.
- On the master, configured the Link Level Discovery Protocol (LLDP) on the uplink module ports that will be used as VCPs. LLDP is configured by default but might have been disabled. Both sides of the new links exchange LLDP messages to accomplish automatic VCP conversion. To configure LLDP, see *Configuring LLDP (CLI Procedure)*.
- Ensured that the new member switch has the factory-default configuration. If the new member switch has been previously configured, revert its configuration to the factory defaults. See *Reverting to the Default Factory Configuration for the EX Series Switch*.

- Made a note of the serial number (the number is on the back of the switch). You will need to edit the Virtual Chassis configuration to include the serial number of the new member switch.
- Edited the existing Virtual Chassis preprovisioned configuration to include the serial number of the new member switch. The parameters specified in the master Virtual Chassis configuration file are applied to the new member switch after it has been interconnected through its uplink VCP to an existing member switch.
- Prepared an existing member switch to interconnect with the new switch through an uplink module port by ensuring that port is not set as a VCP. One of the conditions for automatic VCP conversion to be invoked is that the ports on both sides of the new link must not already be configured as VCPs.



CAUTION: When automatic VCP conversion is enabled in a Virtual Chassis with switches that have dedicated VCPs (EX4200, EX4500, or EX4550 Virtual Chassis), if network or uplink ports are automatically converted into VCPs to create a redundant link with a dedicated VCP connection between the same two Virtual Chassis members, you must reboot the Virtual Chassis to avoid creating a traffic loop within the Virtual Chassis. (The same issue can occur even if the ports are manually converted into VCPs to create the redundant VCP link with a dedicated VCP link, so the reboot is required to avoid traffic looping in that case as well.)

- Ensured that the operational modes of the uplink modules on the existing member switch and the new member switch match.
- Confirmed that the new member switch is powered off.

If the preceding conditions are not met, autoprovisioning will not work and you will need to manually configure uplink module ports on the switch to be added to the configuration to be VCPs. For more information, see [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#).

To add a switch to an existing preprovisioned Virtual Chassis configuration using the autoprovisioning feature:

1. Interconnect the unpowered new switch to one member of the existing Virtual Chassis configuration. Only connect one VCP on the unpowered new switch to a VCP on a member switch in the existing Virtual Chassis at this point of the procedure.
2. Power on the new member switch.
3. Confirm that the new member switch is now included in the Virtual Chassis configuration by checking the front-panel LCD for the member ID. It should display a member ID in the range from 0 through 9. The member ID is automatically assigned to the new member switch's serial number in the configuration file.
4. Cable the other VCP on the new member switch to the Virtual Chassis.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Related Documentation

- [Example: Expanding an EX4200 Virtual Chassis in a Single Wiring Closet on page 92](#)
- [Example: Setting Up a Multimember EX4200 Virtual Chassis Access Switch with a Default Configuration on page 107](#)
- [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
- [Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File on page 127](#)
- [Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches on page 170](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis (CLI Procedure)

This topic explains how to add an EX4200 switch to an already configured and operational EX4500 Virtual Chassis or to a mixed EX4200 and EX4500 Virtual Chassis that was configured using a preprovisioned configuration.

To add an EX4200 switch to an EX4500 Virtual Chassis or a mixed EX4200 and EX4500 Virtual Chassis that was configured using a preprovisioned configuration:

1. Power on the EX4200 switch that will be added to the Virtual Chassis.
2. Set the Virtual Chassis mode to mixed:

```
user@switch> request virtual-chassis mode mixed
```

3. Reboot the EX4200 switch.

```
user@switch> request system reboot
```

4. Log in to the EX4500 Virtual Chassis or the mixed EX4200 and EX4500 Virtual Chassis.

5. (EX4500 Virtual Chassis only) Set the Virtual Chassis mode to mixed for all Virtual Chassis member switches:

```
user@switch> request virtual-chassis mode mixed all-members
```



NOTE: Each member switch will already have been configured in mixed mode in a mixed EX4200 and EX4500 Virtual Chassis.

6. (EX4500 Virtual Chassis only) Reboot all member switches in the EX4500 Virtual Chassis:

```
user@switch> request system reboot all-members
```

7. Add the EX4200 switch to the preprovisioned configuration:

```
[edit virtual-chassis]
user@SWA-0# set member 5 serial-number serial-number role role
```

8. If you are replacing an EX4500 switch in the **routing-engine** role with an EX4200 switch, change the role of the EX4500 switch to **line-card**:

```
[edit virtual-chassis]
user@switch# replace member 0 serial-number serial-number role routing-engine with member
0 serial-number serial-number role line-card
user@switch# replace member 1 serial-number serial-number role routing-engine with member
1 serial-number serial-number role line-card
```

9. Commit the configuration:

```
user@switch# commit synchronize
```

10. Cable one dedicated or user-configured Virtual Chassis port (VCP) on the new member switch to the existing Virtual Chassis. See *Connecting a Virtual Chassis Cable to an EX4200 Switch* or [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#).

11. Wait for the new switch to become operational in the Virtual Chassis. Monitor the **show virtual-chassis** command output to confirm the new switch is recognized by the Virtual Chassis and is in the **Prsnt** state.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

12. Cable the other dedicated or user-configured VCP on the new member switch to the Virtual Chassis.

Related Documentation

- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)
- [Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\) on page 229](#)

Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis (CLI Procedure)

An EX4500 switch can be added to an EX4200 Virtual Chassis to create a mixed EX4200 and EX4500 Virtual Chassis. This topic explains how to add an EX4500 switch to an already configured and operational EX4200 Virtual Chassis.

To add an EX4500 switch to an EX4200 Virtual Chassis that was configured using a preprovisioned configuration:

1. Power on the EX4500 switch with the installed Virtual Chassis module.
2. Verify the PIC mode setting:

```
user@switch> show chassis pic-mode
```

- 3.



NOTE: Step 3 is required only if you are using the dedicated VCPs on the Virtual Chassis module of the EX4500 switch to connect the Virtual Chassis.

If the PIC mode was not set to Virtual Chassis mode, set the PIC mode to Virtual Chassis mode:

```
user@switch> request chassis pic-mode virtual-chassis
```

4. Set the Virtual Chassis mode to mixed:

```
user@switch> request virtual-chassis mode mixed
```

5. Reboot the EX4500 switch.

```
user@switch> request system reboot
```

6. Log in to the EX4200 Virtual Chassis.

7. Set the Virtual Chassis mode to mixed for all member switches:

```
user@switch> request virtual-chassis mode mixed all-members
```

8. Reboot the Virtual Chassis.

```
user@switch> request system reboot all-members
```

9. Log in to the EX4200 Virtual Chassis after the reboot is complete.

10. On the master switch, add the EX4500 switch to the preprovisioned configuration:

```
[edit virtual-chassis]
user@switch# set member member-id serial-number serial-number role role
```

11. If you are using the EX4500 switch in the master role in place of an EX4200 switch, change the EX4200 switch in the **routing-engine** role to the **line-card** role:

```
[edit virtual-chassis]
user@switch# replace member 0 serial-number serial-number role routing-engine with member
0 serial-number serial-number role line-card
user@switch# replace member 1 serial-number serial-number role routing-engine with member
1 serial-number serial-number role line-card
```

12. Commit the configuration:

```
user@switch# commit synchronize
```

13. Interconnect the EX4500 switch to one member of the existing Virtual Chassis configuration. See *Connecting a Virtual Chassis Cable to an EX4200 Switch* and *Connecting a Virtual Chassis Cable to an EX4500 Switch*.

Connect only one VCP on the EX4500 switch to a VCP on a member switch in the existing Virtual Chassis at this point of the procedure.

14. Confirm that the new member switch is now included in the Virtual Chassis configuration by checking the front-panel LCD for the member ID. It should display a member ID in the range from 0 through 9. The member ID is automatically assigned to the new member switch's serial number in the configuration file.

15. Cable the other VCP on the Virtual Chassis of the EX4500 switch to the Virtual Chassis.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

Related Documentation

- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)
- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)

Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis (CLI Procedure)

An EX4500 switch can be added to an EX4200 Virtual Chassis to create a mixed EX4200 and EX4500 Virtual Chassis.

This topic explains how to add an EX4500 switch to an already configured and operational EX4200 Virtual Chassis that was configured using a nonprovisioned configuration.

Before you begin adding EX4500 switches to the Virtual Chassis:

- Ensure that a Virtual Chassis module is installed in the EX4500 switch.

To add an EX4500 switch to an EX4200 Virtual Chassis that was configured using a nonprovisioned configuration:

1. Power on the EX4500 switch.
2. Verify the PIC mode setting:

```
user@switch> show chassis pic-mode
```



NOTE: This step is required only if you are using the dedicated VCPs on the Virtual Chassis module of the EX4500 switch to connect the Virtual Chassis.

3. If the PIC mode was not set to Virtual Chassis mode, set the PIC mode to Virtual Chassis mode:

```
user@switch> request chassis pic-mode virtual-chassis
```

4. Set the Virtual Chassis mode to mixed:

```
user@switch> request virtual-chassis mode mixed
```

5. Reboot the EX4500 switch.

```
user@switch> request system reboot
```

6. Log in to the EX4200 Virtual Chassis.

7. Set the Virtual Chassis mode to mixed for all member switches:

```
user@switch> request virtual-chassis mode mixed all-members
```

8. Reboot all member switches in the Virtual Chassis.

```
user@switch> request system reboot all-members
```

9. After all members have rebooted, interconnect one dedicated VCP on the EX4500 switch with one dedicated VCP of a member EX4200 switch in the EX4200 Virtual Chassis. . See *Connecting a Virtual Chassis Cable to an EX4200 Switch* and *Connecting a Virtual Chassis Cable to an EX4500 Switch*.



NOTE: You can also connect an EX4500 switch into the Virtual Chassis by configuring an uplink port as a VCP. See [“Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch \(CLI Procedure\)” on page 229](#).

10. Log in to the Virtual Chassis.

11. Wait for the new switch to become operational in the Virtual Chassis. Monitor the **show virtual-chassis** command output to confirm the new switch is recognized by the Virtual Chassis and is in the **Prsnt** state.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

12. Cable the other dedicated or user-configured VCP on the new member switch to the Virtual Chassis.

13. (Optional) Set the mastership priority of the EX4500 switch. The switches with the highest mastership priorities assume the master role and backup roles.

```
[edit virtual-chassis]
user@switch# set member member-id mastership-priority mastership-priority
```

14. (Optional) From the master switch, set the mastership priority of the other member switches:

```
[edit virtual-chassis]
user@switch# replace member member-id mastership-priority mastership-priority with member
member-id mastership-priority mastership-priority
```

Related Documentation

- [Example: Adding an EX4500 Switch to a Nonprovisioned Virtual Chassis on page 102](#)
- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)

Removing or Replacing a Member Switch of a Virtual Chassis Configuration



NOTE: This topic does not apply to Virtual Chassis Fabric (VCF). See *Removing a Device From a Virtual Chassis Fabric* for VCF information. This topic also does not apply to EX8200 Virtual Chassis.

You can remove or replace a member switch in a Virtual Chassis without disrupting network service on the other member switches. You can retain the existing configuration of the member switch and apply it to a new member switch, or you can free up the member ID and make it available for assignment to a new member switch.



NOTE: When you add or delete member switches in a Virtual Chassis configuration, internal routing changes might cause temporary traffic loss for a few seconds. Also, if removing a member switch changes a mixed Virtual Chassis into a non-mixed Virtual Chassis, you must remove the mixed mode setting on all member switches of the Virtual Chassis and reboot the Virtual Chassis; network services are disrupted until the Virtual Chassis is up again.

If you want to remove or replace a member switch of a mixed Virtual Chassis that contains EX4200, EX4500, or EX4550 switches, see [“Removing an EX4200, EX4500, or EX4550 Switch From a Mixed Virtual Chassis \(CLI Procedure\)” on page 219](#).

If you want to replace a member switch with a different type of switch that changes the Virtual Chassis from a non-mixed to a mixed Virtual Chassis:

1. Remove the member switch as described in [“Remove a Member Switch and Make Its Member ID Available for Reassignment to a Different Switch”](#) on page 214.
2. Use the configuration procedure for adding a new switch to an existing Virtual Chassis based on the type of switch you are adding. (See Related Topics at the end of this topic.)

See [“Understanding Mixed EX Series and QFX Series Virtual Chassis”](#) on page 29 for the combinations of switches that comprise a mixed Virtual Chassis.

Otherwise, to remove or replace a member switch of an EX Series or QFX Series Virtual Chassis, use one of the following procedures that matches what you want to do.

- [Remove a Member Switch and Make Its Member ID Available for Reassignment to a Different Switch](#) on page 214
- [Remove, Repair, and Reinstall the Same Switch](#) on page 215
- [Remove a Member Switch, Replace It with a Different Switch, and Reapply the Old Configuration](#) on page 216

Remove a Member Switch and Make Its Member ID Available for Reassignment to a Different Switch

To remove a switch from a Virtual Chassis without replacing it:

1. Power off and disconnect the member switch you want to remove from the Virtual Chassis.
2. If the Virtual Chassis configuration is preprovisioned, on the Virtual Chassis master, remove the removed switch's member setting from the preprovisioned configuration.

```
[edit virtual-chassis]
user@vc-master# delete member removed-member-id
```

If the Virtual Chassis configuration is nonprovisioned, change the **mastership-priority** values of each member switch as needed to reconfigure the Virtual Chassis roles. See [“Configuring Mastership of a Virtual Chassis”](#) on page 220.

3. (Optional) If removing a member switch leaves only two remaining member switches in the Virtual Chassis, we recommend you disable split detection in a two-member Virtual Chassis. See [“Disabling Split and Merge in a Virtual Chassis”](#) on page 235 for details.
4. Commit any configuration changes made in previous steps.
5. (For a mixed Virtual Chassis only) If removing this member switch changes the Virtual Chassis from a mixed to a non-mixed Virtual Chassis, you must also remove the mixed-mode setting from the Virtual Chassis. See [“Understanding Mixed EX Series and QFX Series Virtual Chassis”](#) on page 29 for details on the combinations of switches that comprise a mixed Virtual Chassis. You must reboot the Virtual Chassis for the mode change to take effect. To do this, you can include the **reboot** option with the

request virtual-chassis mode mixed disable command that turns off mixed mode, or reboot all member switches of the Virtual Chassis separately when ready to do so, as shown below.

```
user@vc-master> request virtual-chassis mode mixed disable all-members
user@vc-master> request system reboot all-members
```

6. When you remove a member switch from a Virtual Chassis configuration, the master keeps that member switch's member ID in reserve. Use the following command on the Virtual Chassis master to make that member ID available for reassignment:

```
user@vc-master> request virtual-chassis recycle member-id member-id
```

7. If you want to use the removed switch as a standalone switch, you must remove any Virtual Chassis configuration items and settings on that switch. For a smooth transition to a new role as a standalone switch, we recommend to revert the switch to its default factory configuration using the **request system zeroize** command, and then apply the configuration items you want on the switch.

If you do not want to revert to default factory settings, use commands such as the following to remove Virtual Chassis settings for the mode and VCPs from the removed switch:

- a. If the switch was removed from a mixed-mode Virtual Chassis, disable the mixed-mode setting.

```
user@switch> request virtual-chassis mode mixed disable
```

- b. Delete the VCP settings for any ports that were used as VCPs:

```
user@switch> request virtual-chassis vc-port delete pic-slot pic-slot port port-number
```

- c. Reboot the standalone switch for settings such as mode changes to take effect.

Remove, Repair, and Reinstall the Same Switch

If you need to repair a member switch, you can remove it from the Virtual Chassis configuration without disrupting network service for the other member switches. The master stores the configuration for the member ID so that it can be reapplied when the member switch (with the same base MAC address) is reconnected.

To remove, repair, and reinstall the member switch:

1. Power off and disconnect the member switch to be repaired.
2. Repair, as necessary.
3. Reconnect the switch and power it on.

Remove a Member Switch, Replace It with a Different Switch, and Reapply the Old Configuration

If you are unable to repair a member switch, you can replace it with a different member switch of the same type while retaining the previous configuration. The master stores the configuration of the member switch that was removed. When you connect a different member switch, the master assigns a new member ID, but the old configuration is still stored under the previous member ID of the previous member switch.

To remove and replace a switch and reapply the old configuration:

1. Power off and disconnect the member switch to be replaced.
2. If the replacement member switch has been previously configured, revert that switch's configuration to the factory defaults. See the **request system zeroize** command.

The replacement member switch should be powered on and running with the factory default configuration at the end of this step.

3. (Required when automatic software update is not enabled on the Virtual Chassis and the new member switch is running a version of Junos OS that is different than the version of Junos OS running on the Virtual Chassis) Ensure that the correct version of Junos OS is or will be installed on the new member switch by performing *either* of the following tasks:
 - Enable automatic software update on the Virtual Chassis. See [“Configuring Automatic Software Update on Virtual Chassis Member Switches” on page 235](#). The Virtual Chassis will automatically update the software on the replacement switch in a later step when it is interconnected and recognized as part of the Virtual Chassis. The replacement switch does not require any action in this case for this step.
 - Install the version of Junos OS running on the Virtual Chassis onto the new member switch before interconnecting it into the Virtual Chassis. For EX series switches, see *Installing Software on an EX Series Switch with a Single Routing Engine (CLI Procedure)*, or for QFX Series switches, see *Software Installation and Upgrade Overview* and *Installing Software Packages on QFX Series Devices*. In this case, at the end of this step, the replacement switch will be running with the new version of the software and should have the factory default configuration.



CAUTION: A QFX5110 Virtual Chassis can only be set up using QFX5110 and QFX5100 switches that are running the same Junos OS image, which must be an image that includes “-qfx-5e-” in the software package filename when the Junos OS image is downloaded from the Software Center. If your replacement switch in a QFX5110 Virtual Chassis is a QFX5100 switch that was previously installed with and is running a Junos OS image from a software package filename that includes “-qfx-5-”, you *must* upgrade the replacement switch to a “-qfx-5e-” image instead before inserting it into the QFX5110 Virtual Chassis. See *Upgrading a QFX5100 Switch with a USB Device to Join a QFX5110 Virtual*

Chassis or Virtual Chassis Fabric. The automatic software update feature cannot update a “-qfx-5-” image to a “-qfx-5e-” image.

4. Connect one link from the replacement member switch to the Virtual Chassis as follows, depending on which type of ports you are using:

- If you are interconnecting a switch using dedicated Virtual Chassis Ports (VCPs), connect one dedicated VCP on the replacement member switch to a dedicated VCP on another member switch in the Virtual Chassis.

- If you are interconnecting a switch using optical ports configured as VCPs:

On the replacement switch, configure the optical ports that you are using to connect to the Virtual Chassis as VCPs. (The optical ports on the existing member switches in the Virtual Chassis where the replacement member switch will be connected should be configured as VCPs as well, if they are not already configured.) To configure an optical port as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port port-number
```

Connect one configured optical port VCP on the replacement switch to a configured optical port VCP on another member switch in the Virtual Chassis.



NOTE: You can set optical port VCPs on a standalone switch before interconnecting one link into an existing Virtual Chassis, or set optical port VCPs for the switch after interconnecting a link into the existing Virtual Chassis. In either case, you must set the ports as VCPs that are used to interconnect the switch into the Virtual Chassis for the master to detect and complete the process of adding the switch as a member. For more information on setting up VCPs on EX Series switches, see [“Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223](#). For details on which ports can be configured as VCPs in a QFX Series Virtual Chassis, see [“Understanding Virtual Chassis Components” on page 16](#).

5. Confirm that the new member switch is now included in the Virtual Chassis configuration on switches with a front-panel LCD by checking the display for the member ID. It should show a member ID in the range from 0 through 9.

If you are using a switch that does not have an LCD interface, confirm the switch is part of the Virtual Chassis configuration by entering the **show virtual-chassis** command and viewing the output.

6. Cable the other VCP on the replacement member switch into the Virtual Chassis based on how you planned to interconnect the switch in Step 4.



CAUTION: If you immediately cable both VCPs on the new switch into the existing Virtual Chassis at the same time, a member switch that was

already part of the Virtual Chassis might become nonoperational for several seconds. Network traffic to this switch is dropped during the downtime.

The member switch will return to the normal operational state with no user intervention, and normal operation of the Virtual Chassis will resume after this downtime.

7. To update the new member switch's current member ID to the member ID of the member switch that was removed from the Virtual Chassis configuration:
- In a nonprovisioned Virtual Chassis, issue the [request virtual-chassis renumber](#) command on the master member switch.
 - In a preprovisioned Virtual Chassis, on the master member switch, reconfigure the member information for the new member switch using the `[edit virtual-chassis] member` configuration statement.

To use the same member ID as the member that was replaced, associate the new switch's serial number (on the back of the switch) with the replaced member ID, as follows:

```
[edit virtual-chassis]
user@switch# set member replaced-member-ID serial-number new-member-serial-number
```



NOTE: You can alternatively use the `replace` configuration editing command to substitute the serial number of the replacement member switch for the replaced member's serial number in the existing configuration item for the replaced member.

To configure the new member switch with a different member ID, associate the new switch's serial number with the desired member ID and then delete the configuration item for the replaced member switch, as follows:

```
[edit virtual-chassis]
user@switch# set member new-member-ID serial-number new-member-serial-number
user@switch# delete member replaced-member-ID
```

Related Documentation

- [Adding a New Switch to an Existing EX2300, EX3400, or EX4300 Virtual Chassis](#)
- [Adding an EX4600 Switch to a Mixed or Non-mixed Virtual Chassis](#)
- [Adding a New Switch to an Existing QFX Series Virtual Chassis](#)
- [Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\) on page 201](#)
- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)

- [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)
- [Adding or Replacing a Member Switch or an External Routing Engine in an EX8200 Virtual Chassis \(CLI Procedure\)](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)

Removing an EX4200, EX4500, or EX4550 Switch From a Mixed Virtual Chassis (CLI Procedure)

This topic explains how to remove a switch from a mixed Virtual Chassis. It also explains how to reconfigure the Virtual Chassis in cases in which you are removing the switches to convert a mixed Virtual Chassis into an EX4200 Virtual Chassis, an EX4500 Virtual Chassis, or an EX4550 Virtual Chassis.

If you want to replace a member switch of a Virtual Chassis that only contains the same type of member switches, see [“Removing or Replacing a Member Switch of a Virtual Chassis Configuration” on page 213](#).

To remove a switch from a mixed Virtual Chassis:

1. Power off and disconnect the member switch that is being removed from the Virtual Chassis.
2. If the Virtual Chassis configuration was preprovisioned, remove the switch from the preprovisioned configuration. See [“Removing or Replacing a Member Switch of a Virtual Chassis Configuration” on page 213](#). If the Virtual Chassis was nonprovisioned, change the mastership-priority values of each member switch as needed to reconfigure the Virtual Chassis roles. See [“Configuring Mastership of a Virtual Chassis” on page 220](#).

3.



NOTE: You only have to set mixed mode when configuring an EX4200 switch into a Virtual Chassis that has EX4500 or EX4550 switches. You, therefore, do not have to have this setting unless an EX4200 switch is in your Virtual Chassis.

If you are removing the last EX4200 switch from a mixed Virtual Chassis, disable mixed Virtual Chassis mode for all of the switches in the Virtual Chassis:

```
user@switch> request virtual-chassis mode mixed disable all-members
```

Reboot all member switching the Virtual Chassis to complete this step:

```
user@switch> request system reboot all-members
```

4. If you want to place the removed switch back onto the network as a standalone switch, disable mixed Virtual Chassis mode on the switch:

```
user@switch> request virtual-chassis mode mixed disable
```

5. (EX4500 switch only) Set the PIC mode on the removed switch to **intraconnect**:

```
user@switch> request chassis pic-mode intraconnect
```

You only need to perform this step if you want to put the EX4500 switch back onto the network as a standalone switch.

6. Reboot the standalone switch so the new settings can take effect.

Configuring Mastership of a Virtual Chassis



NOTE: This topic applies to all QFX Virtual Chassis, and all EX Series Virtual Chassis except EX8200 Virtual Chassis.

A Virtual Chassis configuration has two Routing Engines—one is the switch in the master Routing Engine role and the other is the switch in the backup Routing Engine role. The remaining members operate in the linecard role. You can designate the role (master, backup, or linecard) that a member switch performs within any Virtual Chassis, whether or not you are using a preprovisioned configuration. For details on which switches in a mixed Virtual Chassis we recommend or are required to be configured into the master or backup Routing Engine role, see [“Understanding Mixed EX Series and QFX Series Virtual Chassis” on page 29](#).



NOTE: We recommend that you always use **commit synchronize** rather than **commit** to save configuration changes made for a Virtual Chassis, to ensure that the configuration changes are saved in both Routing Engines.

- [Configuring Mastership Using a Preprovisioned Configuration File on page 221](#)
- [Configuring Mastership Using a Configuration File That Is Not Preprovisioned on page 221](#)

Configuring Mastership Using a Preprovisioned Configuration File

To configure mastership using a preprovisioned configuration:

1. Note the serial numbers of the switches that you want to function as the master and backup Routing Engines.



NOTE: Serial number values are case-sensitive.

2. Power on only the switch that you want to function as the master Routing Engine.
3. Edit the configuration to specify the preprovisioned configuration mode:

```
[edit virtual-chassis]
user@switch# set preprovisioned
```

4. Specify the serial numbers of the member switches that you want to function as master and backup, specifying their role as **routing-engine**:

```
[edit]
user@switch# set virtual-chassis member 0 serial-number abc123 role routing-engine
user@switch# set virtual-chassis member 1 serial-number def456 role routing-engine
```



NOTE: You cannot directly modify the mastership priority value when you are using a preprovisioned configuration. The mastership priority values are generated automatically and controlled by the role that is assigned to the member switch in the configuration file. The two members assigned the **routing-engine** role are assigned the same mastership priority value (128). However, the member that was powered on first has higher priority for the master election according to the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). Only two members can be configured with the **routing-engine** role.

5. Specify the serial numbers of any other member switches that you are including in the Virtual Chassis configuration. You can also explicitly configure their role as **line-card**.

Configuring Mastership Using a Configuration File That Is Not Preprovisioned

To configure mastership of the Virtual Chassis through a configuration that is not preprovisioned:

1. Power on only the switch that you want to function as the master Routing Engine.
2. Configure the highest possible mastership priority value (**255**) for the member that you want to function as the master Routing Engine:

```
[edit virtual-chassis]
user@switch# set member 0 mastership-priority 255
```

3. Configure the same mastership priority value (continue to edit the Virtual Chassis configuration on the master) for the member that you want to be the backup Routing Engine:

```
[edit virtual-chassis]
user@switch# set member 1 mastership-priority 255
```



NOTE: We recommend that the master and backup have the same mastership priority value to prevent the master and backup status from switching back and forth between master and backup members in failover conditions.

4. Use the default mastership priority value (128) for the remaining member switches or configure the mastership priority to a value that is lower than the value specified for members functioning in the master and backup Routing Engine roles.

Related Documentation

- [Understanding Mixed EX Series and QFX Series Virtual Chassis on page 29](#)
- [Configuring a QFX Series Virtual Chassis](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
- [Adding a New EX4200 Switch to an Existing EX4200 Virtual Chassis \(CLI Procedure\) on page 201](#)
- [Adding an EX4200 Switch to a Preprovisioned EX4500 Virtual Chassis or a Preprovisioned Mixed EX4200 and EX4500 Virtual Chassis \(CLI Procedure\) on page 207](#)
- [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)

Setting a Port on an EX2200 Switch as a Virtual Chassis Port (CLI Procedure)

You configure an EX2200 Virtual Chassis by configuring interfaces connecting EX2200 switches into Virtual Chassis ports (VCPs). Optical interfaces on EX2200 and EX2200-C switches can be configured into VCPs. All RJ-45 interfaces, including built-in network ports with 10/100/1000BASE-T Gigabit Ethernet connectors and 1000BASE-T RJ-45 transceivers, on EX2200 and EX2200-C switches can also be configured into VCPs.

To set a port on an EX2200 or EX2200-C switch as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot pic-slot-number port port-number
```

where *pic-slot-number* is the PIC slot number. The PIC slot number is 0 when you are configuring a built-in port as a VCP and 1 when you are configuring an uplink port as a VCP.

For instance, if you wanted to set built-in port 20 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 0 port 20
```

If you wanted to set uplink port 2 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 2
```

You can configure an interface of a different member switch as a VCP when both switches are part of the same operational Virtual Chassis. You can perform this task by entering the same command with the *member* option:

```
user@switch> request virtual-chassis vc-port set pic-slot pic-slot-number port port-number  
member member-id
```

For instance, if you wanted to set built-in port 20 on member switch 3 as a VCP:

```
user@switch> request virtual-chassis vc-port set pic-slot 0 port 20 member 3
```



NOTE: The VCPs automatically bundle into a Link Aggregation Group when two or more interfaces are configured into VCPs between the same two member switches. See “Understanding Virtual Chassis Port Link Aggregation” on page 41.

Related Documentation

- [Configuring an EX2200 Virtual Chassis \(CLI Procedure\) on page 176](#)

Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port

The procedure described in this topic can be used to set up Virtual Chassis ports (VCPs) to connect two switches together within the same EX Series or QFX Series Virtual Chassis. Switches that can be members of a Virtual Chassis might have:

- Uplink ports that can be configured into VCPs and converted back into uplink ports as needed.
- Default-configured VCPs—Ports that are already configured into VCPs with the default factory configuration).
- Dedicated VCPs—Ports that can only be used as VCPs.

Under certain conditions, uplink ports that are supported as VCPs can automatically be converted into VCPs when interconnecting a member into an existing Virtual Chassis

(see [“Automatic Virtual Chassis Port \(VCP\) Conversion” on page 22](#)). Otherwise, you must manually convert uplink ports into VCPs using this procedure. See [“Virtual Chassis Port Options” on page 20](#) for a list of VCP options on each type of switch. For complete details about where a switch has dedicated VCPs, default-configured VCPs, or ports that can be configured as VCPs, and what transceivers and cables are supported to use for VCP connections on that switch, see the hardware documentation for the switch.

You typically configure an uplink port as a Virtual Chassis Port (VCP) for one of the following reasons:

- You want to interconnect two switches into a Virtual Chassis that have dedicated VCPs but are located in different wiring closets or sites, and the switches are farther apart than the maximum length of a dedicated VCP cable.
- You are configuring a Virtual Chassis composed of switches that support Virtual Chassis but do not have default-configured VCPs or dedicated VCPs.
- You are using default-configured VCPs or dedicated VCPs to interconnect members in a Virtual Chassis, and want to add redundant VCP links between members using additional ports that can be configured into VCPs.



CAUTION: If you configure an uplink port as a VCP to create a redundant link with a dedicated VCP connection on EX4200, EX4500, or EX4550 switches, to avoid traffic looping within the Virtual Chassis, you must reboot the Virtual Chassis after configuring the port conversion and cabling the VCP link. See [“Troubleshooting an EX Series Virtual Chassis” on page 391](#) for more information.

The following is a summary of VCP options or recommendations for switches that support Virtual Chassis:

- EX2200 switches—You explicitly configure VCPs to connect EX2200 switches together to form an EX2200 Virtual Chassis. See [“Setting a Port on an EX2200 Switch as a Virtual Chassis Port \(CLI Procedure\)” on page 222](#).
- EX2300 switches—You explicitly configure 10-Gigabit uplink ports with SFP+ transceivers as VCPs to connect EX2300 switches or multigigabit EX2300 switches together to form an EX2300 Virtual Chassis. (You cannot use ports with SFP transceivers as VCPs on EX2300 switches.)
- EX3300 switches—Explicitly configuring VCPs is usually not needed when configuring an EX3300 Virtual Chassis. Uplink ports 2 and 3 on an EX3300 switch are configured as VCPs by default and, therefore, do not require user configuration to be set as VCPs. We recommend that you use this procedure to configure an uplink port on an EX3300 switch as a VCP only if you configured ports 2 and 3 as network uplink ports and the ports need to be reconfigured as VCPs, or when ports 2 and 3 cannot be used as VCPs for some reason. You can use this procedure to configure any uplink port on an EX3300 switch as a VCP.
- EX3400 switches—Explicitly configuring VCPs is usually not needed when configuring an EX3400 Virtual Chassis. The QSFP+ ports on EX3400 switches, which correspond

to PIC (**pic-slot**) 1 ports 0 and 1, are configured as VCPs by default. Use this procedure only if you want to configure an SFP+ port on an EX3400 switch as a VCP, or if you want to reconfigure a QSFP+ port that had been configured into a network port back into a VCP. (You cannot use ports with SFP transceivers as VCPs on EX3400 switches.)

- EX4300 switches—Explicitly configuring VCPs is usually not needed when configuring an EX4300 Virtual Chassis. QSFP+ ports on EX4300 switches are configured as VCPs by default. Use this procedure only if you want to configure an SFP+ port on an EX4300 switch as a VCP, or if you want to reconfigure a QSFP+ port that had been configured into a network port back into a VCP.
- EX4200, EX4500, and EX4550 switches—EX4200, EX4500, and EX4550 switches have dedicated VCPs that are usually used to interconnect these switches into a Virtual Chassis. You can also interconnect EX4200, EX4500, and EX4550 switches that are beyond the reach of the dedicated Virtual Chassis cables as members of a Virtual Chassis by using the uplink ports—including the ports on the SFP uplink module, SFP+ uplink module, or XFP uplink module—and connecting the uplink ports. To use the uplink ports or SFP network ports for interconnecting member switches, you must explicitly set the uplink ports as VCPs.
- QFX Series switches—Explicitly setting up VCPs is required on any QFX Series switches to form a Virtual Chassis. QFX Series switches that support Virtual Chassis do not have any dedicated or default-configured VCPs, but you can configure any non-channelized QSFP+ ports (or QSFP28 ports, where supported) into VCPs.

When an uplink port is set as a VCP, it cannot be used for any other purpose. You can set one port as a VCP and configure other uplink ports in trunk mode as an uplink to another switch. You cannot use channelized ports as VCPs.

Before you set an uplink port as a VCP:

1. Verify that the port can be used as a VCP in your particular configuration. See [“Virtual Chassis Port Options” on page 20](#) for a summary of the VCP options on switches that support Virtual Chassis, and the hardware documentation for each type of switch for complete details about the ports and installed transceivers that can be used as VCPs.
2. If you are configuring an uplink module port as a VCP, if needed, install the uplink module in the member switches that you want to interconnect.
3. Power on and connect to the switch that you plan to designate as the master of the Virtual Chassis.



NOTE: Do not power on the other switches at this point.

4. Run EZSetup on the switch that you are configuring to be the master. Follow the prompts to specify the hostname and other identification, time zone, and network properties. See *Connecting and Configuring an EX Series Switch (CLI Procedure)* for

details. The properties that you specify for the master apply to the entire Virtual Chassis, including all the member switches that you later interconnect with the master.

5. If you want to configure and manage the Virtual Chassis remotely, specify the VME global management interface. You can configure the VME global management interface when you are setting up the master or you can do it after completing the other configuration steps for the Virtual Chassis. See [“Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis \(CLI Procedure\)” on page 231](#).
6. Configure mastership of the Virtual Chassis by using either the nonprovisioned or preprovisioned configuration. See [“Configuring Mastership of a Virtual Chassis” on page 220](#) for details.



NOTE: A Virtual Chassis has two Routing Engines, one in the master role and the other in the backup role. Therefore, we recommend that you always use `commit synchronize` rather than simply `commit` to save configuration changes made for a Virtual Chassis. This ensures that the configuration changes are saved in both Routing Engines.

Before you begin to interconnect a Virtual Chassis across long distances, such as between wiring closets:

- Prepare the existing Virtual Chassis for interconnecting with a potential member switch that is beyond the reach of a dedicated Virtual Chassis cable by setting at least one uplink VCP on an existing member of the Virtual Chassis.
- Prepare the potential member switch for interconnecting with the existing Virtual Chassis by setting at least one uplink VCP on the standalone switch.

You can set uplink VCPs on a standalone switch before interconnecting one link into an existing Virtual Chassis, or set uplink VCPs for a switch after interconnecting one link into an existing Virtual Chassis. In either case, you must set the ports as VCPs that are used to interconnect the switch into the Virtual Chassis for the master to detect the switch and complete the process of adding it as a member.



NOTE: We recommend that you set up two uplink VCP connections within each wiring closet for redundancy.

1. [Setting an Uplink VCP Between the Member Switches in a Virtual Chassis on page 226](#)
2. [Setting an Uplink VCP on a Standalone Switch on page 227](#)

Setting an Uplink VCP Between the Member Switches in a Virtual Chassis

From the Virtual Chassis, you can set an uplink port on the local member or on a specified member as a VCP.



NOTE: If you use the SFP+ uplink module, you must configure all member switches to support either 1-gigabit SFP transceivers or 10-gigabit SFP+ transceivers on EX4200 switches. See *Setting the Mode on an SFP+ or SFP+ MACSec Uplink Module*.

To set the uplink ports for the local member switch (for example, member 0) and for a different member switch (for example, member 1) to function as VCPs:

1. Set one uplink port of member 0 as a VCP. You do not need to specify the **member member-id** option, because the command applies by default on the member where it is executed.

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 0
```

2. Set one uplink port of member 1 as a VCP.

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 0 member 1
```

This step includes the member *member-id* option, because it is executed on a different member switch than the local member switch.



NOTE: You can also connect to a member switch individually using the **request session member** command, and set a VCP locally on that member. (As in Step 1, you do not specify the member option in that case.)

Setting an Uplink VCP on a Standalone Switch

You can set an uplink VCP on a standalone switch before interconnecting the link into an existing Virtual Chassis. You must set the port as a VCP for the Virtual Chassis master to detect the switch and complete the process of adding it as a member.

To set one uplink VCP on the potential member, which is currently operating as a standalone switch:

1. Power on the standalone switch.
2. Set one uplink port as a VCP. You do not need to specify the **member member-id** option, because the command applies by default on the member where it is executed.

```
user@switch> request virtual-chassis vc-port set pic-slot 1 port 0
```



NOTE: If you do specify the member *member-id* option, use member ID 0. Because the switch is not yet interconnected with the other members of the Virtual Chassis, its current member ID is 0. Its member ID will change when it is interconnected with the Virtual Chassis. It does not impact the functioning of the uplink VCP that its VCP is set with 0 as the member ID. The VCP has significance only on the local switch.

3. After you have set the uplink VCP on the standalone switch, physically interconnect its uplink port with the VCP uplink ports of the members in the existing Virtual Chassis.

The new member switch reboots and joins the now expanded Virtual Chassis with a different member ID.



NOTE: The setting for the new member switch's uplink VCP remains intact and is not affected by the change of member ID.

4. If you have additional members in the second wiring closet, set a redundant VCP uplink on another member switch by issuing the **request virtual-chassis vc-port** command.

Related Documentation

- [Configuring an EX3300 Virtual Chassis \(CLI Procedure\) on page 181](#)
- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)
- [Example: Configuring an EX4200 Virtual Chassis Interconnected Across Multiple Wiring Closets on page 113](#)
- [Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File on page 127](#)
- [Removing or Replacing a Member Switch of a Virtual Chassis Configuration on page 213](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Setting an Uplink Port as a Virtual Chassis Port on an EX4500 or EX4550 Switch (CLI Procedure)

You can set any optical port on an EX4500 switch as a Virtual Chassis port (VCP). Setting an optical port as a VCP is especially useful in cases in which you have to connect Virtual Chassis members together across a distance that is greater than the longest VCP cable can breach.

You can use the optical ports to connect EX4200 switches, EX4500 switches, and EX4550 switches together into a Virtual Chassis. All supported optical connections between EX4200, EX4500, and EX4550 switches can be configured as VCPs.



NOTE: The Virtual Chassis module for EX4500 switches is a field-replaceable unit (FRU) that is not shipped with all EX4500 switch models but can be purchased separately. See *Virtual Chassis Module in EX4500 Switches* and *EX4500 Switch Models*.



CAUTION: If you configure an uplink port as a VCP to create a redundant link with a dedicated VCP connection on EX4200, EX4500, or EX4550 switches, to avoid traffic looping within the Virtual Chassis, you must reboot the Virtual Chassis after configuring the port conversion and cabling the VCP link. See [“Troubleshooting an EX Series Virtual Chassis” on page 391](#) for more information.

Before you set an uplink port as a VCP on an EX4500 or EX4550 switch:

- Cable the uplink port connections.

To set the optical connection as a VCP:

1. Set the 10-Gigabit Ethernet SFP+ port as a VCP interface:

```
user@switch> request virtual-chassis vc-port set pic-slot pic-slot-number port port-number
```

where:

- *pic-slot-number*—The PIC slot number, which is 0 when specifying a native port, 1 when specifying a port on the uplink module in PIC slot number 1, and 2 when specifying a port on an uplink module in PIC slot number 2.
 - *port-number*—The port number on the switch or uplink module.
2. Log onto the other EX4500 switch, and set the other end of the connection as a VCP interface:

```
user@switch> request virtual-chassis vc-port set pic-slot pic-slot-number port port-number
```

- Related Documentation**
- [Example: Connecting EX4500 Member Switches in a Virtual Chassis Across Wiring Closets on page 121](#)

Setting an Uplink Port as a Virtual Chassis Port Using the LCD Panel

This topic describes how to set or delete the uplink ports as VCPs using the LCD panel.

The following procedure shows how to configure uplink module port **ge-0/1/2** as a VCP.

To set an uplink port as a VCP using the LCD panel:

1. Press **Menu** until you see **MAINTENANCE MENU**.
2. Press **Menu** until you see **REQUEST VC PORT**.
3. Press **Enter**. You will see **SET VC PORT?**.
4. Press **Enter**. You will see **SET FPC 0?**.
5. Press **Enter**. You will see **SET PIC 0?**.
6. Press **Menu** until you see **SET PIC 1?**.
7. Press **Enter**. You will see **SET PORT 0?**.
8. Press **Menu** until you see **SET PORT 2?**.
9. Press **Enter**. You will see **CONFIGURING**
10. Once the configuration has been accepted, press **Enter** to return to the **MAINTENANCE** menu.

You can also use the LCD panel to delete a VCP, thus resetting the port to an uplink port.

To reset **vcp-0/1/2** to an uplink port using the LCD panel:

1. Press **Menu** until you see **MAINTENANCE MENU**.
2. Press **Menu** until you see **REQUEST VC PORT**.
3. Press **Enter**. You will see **SET VC PORT?**.
4. Press **Menu**. You will see **DELETE VC PORT?**.

5. Press **Enter**. You will see **DELETE FPC 0?**.
6. Press **Enter**. You will see **DELETE PIC 0?**.
7. Press **Menu** until you see **DELETE PIC 1?**.
8. Press **Enter**. You will see **DELETE PORT 0?**.
9. Press **Menu** until you see **DELETE PORT 2?**.
10. Press **Enter**. You will see **CONFIGURING**
11. Once the configuration has been accepted, press **Enter** to return to the **MAINTENANCE** menu.

**Related
Documentation**

- *LCD Panel in EX3300 Switches*
- *LCD Panel in EX4200 Switches*
- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223](#)
- *Understanding Interface Naming Conventions*

Configuring the Virtual Management Ethernet Interface for Global Management of an EX Series Virtual Chassis (CLI Procedure)



NOTE: This topic does not apply to EX8200 Virtual Chassis.

If you want to configure and manage the Virtual Chassis remotely through SSH or Telnet, configure the virtual management Ethernet (VME) interface on the master of the Virtual Chassis. You can configure and manage all members of the Virtual Chassis through this single global interface by following these steps:

1. Power on the switch that you want to function as the master.
2. Check the front-panel LCD to confirm that the switch has powered on correctly.
3. Run the EZSetup program on the switch, specifying the identification parameters. See *Connecting and Configuring an EX Series Switch (CLI Procedure)*.

To configure the VME interface:

```
[edit]
user@switch# set interfaces vme unit 0 family inet address /ip-address/mask/
```

**Related
Documentation**

- [Example: Configuring an EX3300 Virtual Chassis with a Master and Backup on page 72](#)
- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
- [Understanding Global Management of a Virtual Chassis on page 38](#)

Configuring the Timer for the Backup Member to Start Using Its Own MAC Address, as Master of a Virtual Chassis

When a backup member takes control of a Virtual Chassis because of a reset or other temporary failure, the backup member uses the MAC address of the old master switch as the system MAC base address. This process helps ensure a smooth transition of mastership with no disruption to network connectivity.

The MAC persistence timer is used in situations in which the master switch is no longer a member of the Virtual Chassis because it has been physically disconnected or removed. If the old master switch does not rejoin the Virtual Chassis before the timer elapses, the new master switch starts using its own MAC address as the system's MAC base address. For information regarding how the system MAC base address is used to assign MAC addresses to ports in a Virtual Chassis, see [“Understanding MAC Address Assignment on a Virtual Chassis” on page 62](#).

The default timer value is 10 minutes. The maximum timer value is 60 minutes.

You can disable the MAC persistence timer starting in Junos OS Release 12.1R3. When the MAC persistence timer is disabled, the MAC address of the old master switch is used as the system MAC base address; no MAC address changes occur within the Virtual Chassis even when the old master switch is no longer a member of the Virtual Chassis because it has been physically disconnected or removed.

To configure or modify the MAC persistence timer:

```
[edit virtual-chassis]
user@switch# set mac-persistence-timer minutes
```

To disable the MAC persistence timer:

```
[edit virtual-chassis]
user@switch# set mac-persistence-timer disable
```

**Related
Documentation**

- [Configuring a QFX Series Virtual Chassis](#)
- [Understanding Virtual Chassis Components on page 16](#)

Configuring Fast Failover in an EX Series Virtual Chassis



NOTE: This topic does not apply to EX2200 Virtual Chassis and EX8200 Virtual Chassis.

The Virtual Chassis fast failover feature is a hardware-assisted failover mechanism that automatically reroutes traffic and reduces traffic loss in the event of a link or switch failure. If a link between two members fails, traffic flow between those members must be rerouted quickly so that there is minimal traffic loss.

Fast failover is enabled by default on dedicated Virtual Chassis ports (VCPs). You must manually enable fast failover on uplink ports that have been configured as VCPs or on EX3300 uplink ports that are configured as VCPs by default.

Before you begin configuring fast failover, ensure that the dedicated VCPs or uplink VCPs are connected in a ring topology.

- To reenabling the fast failover feature on all dedicated VCPs in a ring:

```
[edit]
user@switch# delete virtual-chassis fast-failover vcp disable
```

- To configure the fast failover feature on all XFP uplink VCPs in a ring:

```
[edit]
user@switch# set virtual-chassis fast-failover xe
```

- To configure the fast failover feature on all SFP uplink VCPs in a ring:

```
[edit]
user@switch# set virtual-chassis fast-failover ge
```

Related Documentation

- [Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails on page 156](#)
- [Disabling Fast Failover in an EX Series Virtual Chassis on page 234](#)
- [Understanding Fast Failover in an EX Series Virtual Chassis on page 43](#)

Disabling Fast Failover in an EX Series Virtual Chassis



NOTE: This topic does not apply to EX2200 Virtual Chassis and EX8200 Virtual Chassis.

Fast failover is enabled by default on dedicated Virtual Chassis ports (VCPs). You must use this procedure to manually disable fast failover on dedicated VCPs or to disable fast failover on uplink ports that you previously configured as VCPs.

- To disable the fast failover feature on all dedicated VCPs in a ring:

```
[edit]
user@switch# set virtual-chassis fast-failover vcp disable
```

- To disable the fast failover feature on all XFP uplink VCPs in a ring:

```
[edit]
user@switch# delete virtual-chassis fast-failover xe
```

- To disable the fast failover feature on all SFP uplink VCPs in a ring:

```
[edit]
user@switch# delete virtual-chassis fast-failover ge
```

Related Documentation

- [Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails on page 156](#)
- [Configuring Fast Failover in an EX Series Virtual Chassis on page 233](#)
- [Understanding Fast Failover in an EX Series Virtual Chassis on page 43](#)

Disabling Split and Merge in a Virtual Chassis

The split and merge feature is enabled by default on all EX Series switches and QFX Series devices in a Virtual Chassis. You can disable the split and merge feature. If you disable the split and merge feature and the Virtual Chassis splits, both parts of the split Virtual Chassis configuration remain active.

In a preprovisioned Virtual Chassis, if both of the Routing Engines end up in the same Virtual Chassis configuration after a split, the other part of the split Virtual Chassis configuration remains inactive. If the Routing Engines end up in different parts of the split Virtual Chassis configuration and the rest of the member switches are configured as having linecard roles, then a backup Routing Engine might not be selected for either part.

We recommend disabling split and merge on a Virtual Chassis with two member switches. A two-member switch Virtual Chassis that has disabled split and merge can reform more quickly and with less complications as a result of the feature being disabled.

To disable the split and merge feature in a Virtual Chassis:

```
[edit]
user@switch# set virtual-chassis no-split-detection
```

To remove this configuration item to enable the split and merge feature again (recommended when a two-member Virtual Chassis is expanded to have more members):

```
[edit]
user@switch# delete virtual-chassis no-split-detection
```

Related Documentation

- [Understanding Split and Merge in a Virtual Chassis on page 50](#)

Configuring Automatic Software Update on Virtual Chassis Member Switches

The automatic software update feature allows you to automatically update the software version on prospective member switches as they are added so that they can join the Virtual Chassis.



NOTE: The version of Junos OS running on the Virtual Chassis must be compatible with the software running on the prospective member switch for an automatic software update to occur. For information on Junos OS compatibility and other automatic software update restrictions, see [“Understanding Automatic Software Update on Virtual Chassis Member Switches” on page 53](#).

Before you begin, ensure that you know the name or the URL of the software package to be used by the automatic software update feature.

To configure the automatic software update feature for an EX Series or QFX Series Virtual Chassis that is not a mixed-mode Virtual Chassis:

[edit]

```
user@switch# set virtual-chassis auto-sw-update package-name package-name
```



NOTE: An EX4300 Virtual Chassis with a combination of EX4300 multigigabit model switches (EX4300-48MP) and other EX4300 switches must be configured in mixed mode, and the automatic software update feature is not supported in this case.



NOTE: A QFX5110 Virtual Chassis is considered to be a non-mixed Virtual Chassis. Because both QFX5110 and QFX5100 switches in a QFX5110 Virtual Chassis run the same software image, you can use the `auto-sw-update` command with one software package name for all members.



CAUTION: A QFX5100 switch running a Junos OS software image with “-qfx-5-” in the package filename *must* first be upgraded to a Junos OS software image with “-qfx-5e-” in the package filename before it can be added to a QFX5110 Virtual Chassis or VCF. The automatic software update process cannot update a switch from a “-qfx-5-” image to a “-qfx-5e-” image. See *Upgrading a QFX5100 Switch with a USB Device to Join a QFX5110 Virtual Chassis or Virtual Chassis Fabric*.

After a QFX5100 switch is installed with a “-qfx-5e-” Junos OS software image, the automatic software update process can successfully update the switch automatically with a different version of a “-qfx-5e-” Junos OS image to match the other members in the Virtual Chassis or VCF.

To configure the automatic software update feature on a mixed Virtual Chassis containing at least one EX4200 switch and at least one EX4500 or EX4550 switch, use the **ex-4200** option when you are specifying a path to a package for the EX4200 switches and the **ex-4500** option when you are specifying a path to a package for the EX4500 or EX4550 switches, as follows:

[edit]

```
user@switch# set virtual-chassis auto-sw-update ex-4200 package-name package-name
user@switch# set virtual-chassis auto-sw-update ex-4500 package-name package-name
```

You do not need to specify the **ex4500** option when configuring automatic software update for a Virtual Chassis with only a combination of EX4500 and EX4550 switches, which does not need to run in mixed mode. Specifying only a Junos OS package name for an EX4500 switch updates the software for both EX4500 and EX4550 switches.

To configure the automatic software update feature on a mixed QFX5100 Virtual Chassis composed of QFX5100 switches and at least one other supported type of device

(QFX3500, QFX3600, or EX4300 switches), you must specify a software package name for each type or family of device in the mixed Virtual Chassis:

- Specify the **qfx-5** option with the path to the Junos OS package for QFX5100 switches
- Specify the **qfx-3** option with the path to the Junos OS package for QFX3600 and QFX3500 switches
- Specify the **ex4300** option with the path to the Junos OS package for EX4300 switches

as follows:

```
[edit]
user@device# set virtual-chassis auto-sw-update qfx-5 package-name package-name
user@device# set virtual-chassis auto-sw-update qfx-3 package-name package-name
user@device# set virtual-chassis auto-sw-update ex-4300 package-name package-name
```

You can similarly specify different package names using the **ex-4600** and **ex-4300** options with the **auto-sw-update** statement to configure the automatic software update feature for a mixed EX4600 Virtual Chassis that contains EX4600 and EX4300 member switches.

If the software package is located on a local directory on the switch, use the following format for **package-name**:

/pathname/package-name

If the software package is to be downloaded and installed from a remote location, use one of the following formats:

ftp://hostname/pathname/package-name

ftp://username:prompt@ftp.hostname.net/package-name

http://hostname/pathname/package-name

- | | |
|------------------------------|--|
| Related Documentation | <ul style="list-style-type: none"> • Understanding Automatic Software Update on Virtual Chassis Member Switches on page 53 • Understanding Mixed EX Series and QFX Series Virtual Chassis on page 29 |
|------------------------------|--|

Upgrading Software Using Nonstop Software Upgrade on EX Series Virtual Chassis and Mixed Virtual Chassis (CLI Procedure)

You can use nonstop software upgrade (NSSU) to upgrade the software running on all member switches in most EX Series Virtual Chassis with minimal traffic disruption during the upgrade.

NSSU is supported on the following EX Series Virtual Chassis platforms:

- EX3300 Virtual Chassis
- EX3400 Virtual Chassis
- EX4200 Virtual Chassis

- EX4300 Virtual Chassis
- EX4500 Virtual Chassis
- EX4550 Virtual Chassis
- All mixed Virtual Chassis composed of EX4200, EX4500, and EX4550 switches
- EX8200 Virtual Chassis

This topic covers:

- [Preparing the Switch for Software Installation on page 238](#)
- [Upgrading the Software Using NSSU on page 239](#)

Preparing the Switch for Software Installation

Before you begin software installation using NSSU:

- Ensure that the Virtual Chassis is configured correctly to support NSSU. Verify that:
 - The Virtual Chassis members are connected in a ring topology. A ring topology prevents the Virtual Chassis from splitting during an NSSU.
 - The Virtual Chassis master and backup are adjacent to each other in the ring topology. Adjacency permits the master and backup to always be in sync, even when the switches in linecard roles are rebooting.
 - The Virtual Chassis is preprovisioned so that the linecard role has been explicitly assigned to member switches acting in the linecard role. During an NSSU, the Virtual Chassis members must maintain their roles—the master and backup must maintain their master and backup roles (although mastership will change), and the other member switches must maintain their linecard roles.

For information on configuring a preprovisioned Virtual Chassis, see [“Configuring an EX3300 Virtual Chassis \(CLI Procedure\)” on page 181](#), [“Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\)” on page 184](#), [Configuring an EX2300, EX3400, or EX4300 Virtual Chassis](#), and [Configuring an EX8200 Virtual Chassis \(CLI Procedure\)](#).

- A two-member Virtual Chassis has **no-split-detection** configured so that the Virtual Chassis does not split when an NSSU upgrades a member.
- Verify that the members are running the same version of the software:

```
user@switch> show version
```

If the Virtual Chassis members are not running the same version of the software, use the **request system software add** command to upgrade the software on the inconsistent members.

- Ensure that nonstop active routing (NSR) and graceful Routing Engine switchover (GRES) are enabled. To verify that they are enabled, you need to check only the state of nonstop active routing—if nonstop active routing is enabled, then graceful Routing Engine switchover is enabled.

To verify that nonstop active routing is enabled:

```
user@switch> show task replication
Stateful Replication: Enabled
RE mode: Master

Protocol           Synchronization Status
OSPF                Complete
BGP                 Complete
PIM                 Complete
```

If nonstop active routing is not enabled (**Stateful Replication is Disabled**), see *Configuring Nonstop Active Routing on Switches* for information on how to enable it.

- For the EX4300 Virtual Chassis, you should enable the **vcp-no-hold-time** statement at the **[edit virtual-chassis]** hierarchy level before performing a software upgrade using NSSU. If you do not enable the **vcp-no-hold-time** statement, the Virtual Chassis may split during the upgrade. A split Virtual Chassis can cause disruptions to your network, and you may have to manually reconfigure your Virtual Chassis after the NSSU if the split and merge feature was disabled. For more information about a split Virtual Chassis, see [“Understanding Split and Merge in a Virtual Chassis” on page 50](#).
- (Optional) Enable nonstop bridging (NSB). Enabling NSB ensures that all NSB-supported Layer 2 protocols operate seamlessly during the Routing Engine switchover that is part of the NSSU.
- (Optional) Back up the system software—Junos OS, the active configuration, and log files—on each member to an external storage device with the **request system snapshot** command.

Upgrading the Software Using NSSU

This procedure describes how to upgrade the software running on all Virtual Chassis members using NSSU. When the upgrade completes, all members are running the new version of the software. Because a graceful Routing Engine switchover occurs during the upgrade, the original Virtual Chassis backup is the new master.

To upgrade all members using NSSU:

1. Download the software package. If you are upgrading the software running on a mixed Virtual Chassis, download the software packages for both switch types.
2. Copy the software package or packages to the Virtual Chassis. We recommend that you copy the file to the **/var/tmp** directory on the master.
3. Log in to the Virtual Chassis using the console connection or the virtual management Ethernet (VME) interface. Using a console connection allows you to monitor the progress of the master switch reboot.
4. Start the NSSU:
 - On an EX3300 Virtual Chassis, EX3400 Virtual Chassis, EX4200 Virtual Chassis, EX4300 Virtual Chassis, EX4500 Virtual Chassis, or EX4550 Virtual Chassis, enter:

```
user@switch> request system software nonstop-upgrade
/var/tmp/package-name.tgz
```

where *package-name.tgz* is, for example, *jinstall-ex4200-12.1R2.5-domestic-signed.tgz*.

- On a mixed Virtual Chassis, enter:

```
user@switch> request system software nonstop-upgrade set
[/var/tmp/package-name.tgz /var/tmp/package-name.tgz]
```

where *[/var/tmp/package-name.tgz /var/tmp/package-name.tgz]* specifies the EX4200 and EX4500 software packages.

The switch displays status messages similar to the following messages as the upgrade executes:

```
Chassis ISSU Check Done
ISSU: Validating Image
ISSU: Preparing Backup RE
Installing image on other FPC's along with the backup

Checking pending install on fpc1
Pushing bundle to fpc1
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc1

Checking pending install on fpc2
Pushing bundle to fpc2
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc2

Rebooting fpc1
ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot
GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking In-Service-Upgrade status
  Item          Status          Reason
  FPC 0         Online
  FPC 1         Online
  FPC 2         Online (ISSU)
Going to install image on master
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
relinquish mastership
ISSU: IDLE

*** FINAL System shutdown message from user@switch ***
```

```
System going down IMMEDIATELY
```

```
Shutdown NOW!  
[pid 9336]
```

5. Log in after the reboot of the original master switch completes. To verify that the software on all Routing Engines in the Virtual Chassis members has been upgraded, enter the following command:

```
user@switch> show version
```

6. To ensure that the resilient dual-root partitions feature operates correctly, copy the new Junos OS image into the alternate root partitions of all members:

```
user@switch> request system snapshot slice alternate all-members
```

Resilient dual-root partitions allow the switch to boot transparently from the alternate root partition if the system fails to boot from the primary root partition.

Related Documentation

- [Understanding Nonstop Software Upgrade on EX Series Switches on page 54](#)
- [Configuring Dual-Root Partitions](#)
- [Understanding Software Installation on EX Series Switches](#)
- [Troubleshooting Software Installation](#)
- [Understanding Nonstop Software Upgrade on EX Series Switches on page 54](#)

Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge

Every Virtual Chassis has a unique ID that is automatically assigned when the Virtual Chassis configuration is formed. You can also explicitly assign a Virtual Chassis ID using the **set virtual-chassis id** command. When two Virtual Chassis configurations attempt to merge, the Virtual Chassis ID that you assigned takes precedence over the automatically assigned Virtual Chassis IDs and becomes the ID for the newly merged Virtual Chassis configuration.

To configure the Virtual Chassis ID:

```
[edit]  
user@switch# set virtual-chassis id id
```

Related Documentation

- [Understanding Split and Merge in a Virtual Chassis on page 50](#)

Configuring Graceful Routing Engine Switchover in a Virtual Chassis

In a Virtual Chassis, one member switch is assigned the master role and has the master Routing Engine. Another member switch is assigned the backup role and has the backup Routing Engine. Graceful Routing Engine switchover (GRES) enables the master and backup Routing Engines in a Virtual Chassis configuration to switch from the master to backup without interruption to packet forwarding as a hitless failover solution. When you configure graceful Routing Engine switchover, the backup Routing Engine automatically synchronizes with the master Routing Engine to preserve kernel state information and the forwarding state.

To set up the Virtual Chassis configuration to use graceful Routing Engine switchover (GRES):

1. Set up a minimum of two switches in a Virtual Chassis configuration with mastership priority of 255:

```
[edit]
user@switch# set virtual-chassis member 0 mastership-priority 255
[edit]
user@switch# set virtual-chassis member 1 mastership-priority 255
```

2. Set up graceful Routing Engine switchover:

```
[edit]
user@switch# set chassis redundancy graceful-switchover
```

Commit the configuration.



NOTE: We recommend that you use the `commit synchronize` command to save any configuration changes that you make to a multimember Virtual Chassis.

Related Documentation

- [Example: Configuring an EX4200 Virtual Chassis with a Master and Backup in a Single Wiring Closet on page 76](#)
- [High Availability Features for EX Series Switches Overview](#)
- [Understanding EX Series Virtual Chassis on page 8](#)
- [Understanding QFX Series Virtual Chassis](#)

Resetting the EX4500 Switch to Run as a Standalone Switch (CLI Procedure)

If you want to use an EX4500 switch as a standalone switch, we recommend that you set the PIC mode as **intraconnect**. The PIC mode setting determines whether the module that is plugged into the EX4500 switch operates as an intraconnect module or a Virtual Chassis module.



NOTE: Operating an EX4500 switch without the intraconnect module or the Virtual Chassis module is not supported.



NOTE: If you use the EX4500 switch as a standalone switch without changing the PIC mode setting to intraconnect, you will not be able to achieve 960 Gbps data rate throughput. Some of the bandwidth is reserved for the dedicated Virtual Chassis ports (VCPs).

The PIC mode is set to **virtual-chassis** in the factory default configuration. You cannot change the PIC mode setting in the factory default configuration; you must commit some other configuration change and then change the PIC mode setting.

To reset the PIC mode so that you can use the switch as a standalone switch:

1. Make any change to the default configuration file. For example, you could change the hostname:

```
[edit]
user@switch# set system host-name solo-4500
```

2. Commit the updated configuration file, so that it is no longer the factory default configuration:

```
[edit]
user@switch# commit
```

3. Change the setting of the PIC mode:

```
user@switch> request chassis pic-mode intraconnect
```

4. Reboot the switch to apply this changed PIC mode setting:

```
user@switch> request system reboot
```

5. Verify that the PIC mode setting has been changed to **intraconnect**:

```
user@switch> show chassis pic-mode
```

```
fpc0:
```

```
-----
Pic Mode: Intraconnect
```

- Related Documentation**
- [Verifying the Setting for the PIC Mode on an EX4500 Switch in a Virtual Chassis on page 290](#)
 - *EX4500 Default Configuration*

Enabling VLAN Pruning for Broadcast, Multicast, and Unknown Unicast Traffic in an EX Series Virtual Chassis (CLI Procedure)

You can enable VLAN pruning for VLANs assigned to interfaces in an EX Series Virtual Chassis. When you enable VLAN pruning for a VLAN in a Virtual Chassis, all broadcast, multicast, and unknown unicast traffic entering that VLAN uses the shortest possible path through the Virtual Chassis to the egress VLAN interface. Enabling VLAN pruning allows you to conserve bandwidth within the Virtual Chassis, since all broadcast, multicast, and unknown unicast traffic in a VLAN is broadcast to all Virtual Chassis member switches when VLAN pruning is disabled.



BEST PRACTICE: We recommend enabling VLAN pruning when configuring a VLAN on an EX Series Virtual Chassis.

To enable VLAN pruning when configuring a VLAN:

```
[edit]  
user@switch# set vlans vlan-name vlan-prune
```

- Related Documentation**
- *Configuring VLANs for EX Series Switches*

CHAPTER 4

Configuration Statements

- [auto-conversion](#) on page 246
- [auto-sw-update](#) on page 248
- [fast-failover](#) on page 251
- [graceful-restart \(Enabling Globally\)](#) on page 252
- [graceful-switchover](#) on page 253
- [id](#) on page 254
- [lag-hash](#) on page 255
- [location \(Virtual Chassis\)](#) on page 256
- [mac-persistence-timer](#) on page 257
- [mastership-priority](#) on page 258
- [member](#) on page 259
- [no-management-vlan](#) on page 260
- [no-split-detection](#) on page 261
- [package-name](#) on page 262
- [preprovisioned](#) on page 263
- [redundancy \(Graceful Switchover\)](#) on page 264
- [role](#) on page 265
- [serial-number](#) on page 268
- [traceoptions \(Virtual Chassis\)](#) on page 269
- [vc-port](#) on page 272
- [vcp-snmp-statistics](#) on page 273
- [virtual-chassis](#) on page 274

auto-conversion

Syntax	auto-conversion;
Hierarchy Level	[edit virtual-chassis]
Release Information	Statement introduced in Junos OS Releases 14.1X53-D47 and 15.1R7 for EX2200, EX3300, EX4200, EX4500, and EX4550 switches.
Description	Enable automatic Virtual Chassis port (VCP) conversion (also called VCP autoprovisioning) in a Virtual Chassis.



NOTE: This statement is available only for EX Series switches in a Virtual Chassis that have automatic VCP conversion *disabled* by default—EX2200, EX3300, EX4200, EX4500, and EX4550 switches. On these EX Series switches, the automatic VCP conversion feature was *enabled* by default in Junos OS Releases prior to 14.1X53-D47 and 15.1R7. This feature is disabled by default and this statement added as of those releases to allow you to selectively enable the feature. See [“Automatic Virtual Chassis Port \(VCP\) Conversion” on page 22](#) for details.

Configuring this statement enables the feature for the entire Virtual Chassis, and subsequently removing this statement returns the Virtual Chassis to the default behavior, in which automatic VCP conversion is disabled.

VCP links connect members in a Virtual Chassis using supported VCP ports on the member switches. Ports that are supported as VCPs and are not dedicated VCPs or configured as VCPs by default must be converted into VCPs to use them to interconnect Virtual Chassis members. You can manually convert a supported port into a VCP port using the [request virtual-chassis vc-port](#) command, or when automatic VCP conversion is enabled, a port will be automatically converted into a VCP under the following conditions:

- LLDP is enabled on the interfaces for the members on both sides of the link. The two interfaces exchange LLDP packets to accomplish the port conversion.
- The Virtual Chassis must be preprovisioned with the switches on both sides of the link already configured in the members list of the Virtual Chassis using the [set virtual-chassis member](#) command.
- The ports on both ends of the link are supported as VCPs and are *not* already configured as VCPs.

You might want to invoke automatic VCP conversion when adding a new switch to an existing Virtual Chassis or adding a redundant VCP link between two existing members of a Virtual Chassis.




NOTE: When automatic VCP conversion is enabled in a Virtual Chassis with switches that have dedicated VCPs (EX4200, EX4500, or EX4550 Virtual Chassis), if network or uplink ports are automatically converted into VCPs to create a redundant link with a dedicated VCP connection, you must reboot the Virtual Chassis to avoid creating a traffic loop within the Virtual Chassis. See [“Troubleshooting an EX Series Virtual Chassis” on page 391](#) for more information on this potential issue.

Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
---------------------------------	---

Related Documentation	<ul style="list-style-type: none">• Virtual Chassis Overview for Switches on page 3• Understanding Virtual Chassis Components on page 16• Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port on page 223
------------------------------	---

auto-sw-update

Syntax	<pre> auto-sw-update { (ex-4200 ex-4300 ex-4500 ex-4600 qfx-3 qfx-5) package-name package-name; } </pre>
Hierarchy Level	[edit virtual-chassis]
Release Information	<p>Statement introduced in Junos OS Release 10.0 for EX Series switches.</p> <p>The ex-4200 and ex-4500 options introduced in Junos OS Release 12.2 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>The ex-4300, qfx-3, and qfx-5 options introduced in Junos OS Release 13.2X51-D20.</p> <p>The ex-4600 option introduced in Junos OS Release 13.2X51-D25.</p>
Description	<p>Enable the automatic software update feature for Virtual Chassis or Virtual Chassis Fabric (VCF) configurations.</p> <p>You should only use the keywords that specify a device or device family—ex-4300, ex-4600, qfx-3, and qfx-5—when configuring automatic software update on a mixed mode Virtual Chassis or Virtual Chassis Fabric (VCF). You can simply specify the <i>package-name</i> without specifying the device keywords in non-mixed Virtual Chassis or VCF topologies.</p>
	<p> NOTE: The automatic software update feature is not supported for a mixed mode EX4300 Virtual Chassis with a combination of EX4300 multigigabit model (EX4300-48MP) switches and other EX4300 switches.</p>
	<p>You must enter the auto-sw-update statement multiple times—once for each device family in your mixed Virtual Chassis or VCF—in most scenarios when enabling the automatic software update for a mixed Virtual Chassis or VCF.</p> <p>The Junos OS package for an EX4500 switch updates the software for EX4500 and EX4550 switches. You do not, therefore, need to specify the ex-4500 keyword when configuring automatic software update for a mixed Virtual Chassis that include EX4500 and EX4550 switches only. You also only have to enter the ex-4500 keyword once to configure automatic software update for all EX4500 and EX4550 member switches in the same mixed Virtual Chassis.</p> <p>The Junos OS package for a QFX3500 device updates the software for QFX3500 and QFX3600 devices. You do not, therefore, need to specify the qfx-3 keyword when configuring automatic software update for a Virtual Chassis composed entirely of QFX3500 and QFX3600 devices. You also have to enter the qfx-3 keyword only once to</p>

configure automatic software update for all QFX3500 and QFX3600 member devices in the same mixed Virtual Chassis.

The Junos OS package for a QFX5110 device updates the software for both QFX5110 and QFX5100 devices in a QFX5110 Virtual Chassis or VCF, so you do not need to specify the **qfx-5** keyword when configuring automatic software update for a QFX5110 Virtual Chassis or VCF composed of both types of devices.



CAUTION: A QFX5100 switch running a Junos OS software image with “-qfx-5-” in the package filename *must* first be upgraded to a Junos OS software image with “-qfx-5e-” in the package filename before it can be added to a mixed QFX5110 Virtual Chassis or VCF. The automatic software update process cannot update a switch from a “-qfx-5-” image to a “-qfx-5e-” image. See *Upgrading a QFX5100 Switch with a USB Device to Join a QFX5110 Virtual Chassis or Virtual Chassis Fabric*.

After a QFX5100 switch is installed with a “-qfx-5e-” Junos OS software image, the automatic software update process can successfully update the switch automatically with a different version of a “-qfx-5e-” Junos OS image to match the other members in the Virtual Chassis or VCF.

The remaining statement is explained separately. See [CLI Explorer](#).

Default The automatic software update feature is disabled.

Options `package-name` *package-name*—Specify a path to a Junos OS software image.

ex-4200—Specify a path to a Junos OS image for an EX4200 switch when enabling automatic software update for a mixed EX4200 and EX4500 Virtual Chassis, mixed EX4200 and EX4550 Virtual Chassis, or mixed EX4200, EX4500, or EX4550 Virtual Chassis.

ex-4300—Specify a path to a Junos OS image for an EX4300 switch when enabling automatic software update for a mixed Virtual Chassis or VCF. Automatic software update is not supported for mixed mode EX4300 Virtual Chassis with a combination of EX4300 multigigabit model (EX4300-48MP) switches and other EX4300 switches, and this option is not applicable in that case.

ex-4500—Specify a path to a Junos OS image for an EX4500 switch, an EX4550 switch, or both types of switches when enabling automatic software update for a mixed EX4200 and EX4500 Virtual Chassis, mixed EX4200 and EX4550 Virtual Chassis, or mixed EX4200, EX4500, or EX4550 Virtual Chassis.

The Junos OS package for an EX4500 switch updates the software for EX4500 and EX4550 switches. Therefore, you only enter this command once to upgrade the EX4500 and EX4550 member switches in the same mixed Virtual Chassis.

The **ex-4500** keyword also does not need to be specified when configuring automatic software update for a mixed EX4500 and EX4550 Virtual Chassis.

ex-4600—Specify a path to a Junos OS image for an EX4600 switch when enabling automatic software update for a mixed Virtual Chassis.

qfx-3—Specify a path to a Junos OS image for a QFX3500, QFX3600, or both types of devices when enabling automatic software update for a mixed Virtual Chassis or VCF.

qfx-5—Specify a path to a Junos OS image for a QFX5100 device when enabling automatic software update for a mixed QFX5100 Virtual Chassis or VCF. You do not need to use this option for a QFX5110 Virtual Chassis or VCF that contains both QFX5110 and QFX5100 switches because the same software image runs on either type of switch.

Required Privilege Level	
system	To view this statement in the configuration.
system-control	To add this statement to the configuration.


Related Documentation

- [Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches on page 170](#)
- [Configuring Automatic Software Update on Virtual Chassis Member Switches on page 235](#)
- [Understanding Software Upgrades in a Virtual Chassis on page 37](#)
- *[Understanding Software Upgrades in a Virtual Chassis Fabric](#)*

fast-failover

Syntax	<code>fast-failover (ge vcp disable xe);</code>
Hierarchy Level	<code>[edit virtual-chassis]</code>
Release Information	Statement introduced in Junos OS Release 9.3 for EX Series switches.
Description	<p>Enable the fast failover feature on an uplink Virtual Chassis port (VCP).</p> <p>Fast failover is not supported on an EX2200 Virtual Chassis or EX8200 Virtual Chassis.</p>
Default	<p>Fast failover is enabled, by default, on dedicated VCPs.</p> <p>Fast failover is not enabled on uplink VCPs, including the uplink ports that are, by default, configured as VCPs on an EX3300 switch.</p>
Options	<ul style="list-style-type: none"> • ge—Enable fast failover on all Gigabit Ethernet uplink VCPs in the ring topology. • vcp disable—Disable fast failover on all dedicated VCPs in the ring topology. • xe—Enable fast failover on all 10-Gigabit Ethernet uplink VCPs in the ring topology.
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails on page 156 • Configuring Fast Failover in an EX Series Virtual Chassis on page 233 • Disabling Fast Failover in an EX Series Virtual Chassis on page 234

graceful-restart (Enabling Globally)

Syntax	<pre> graceful-restart { disable; helper-disable; maximum-helper-recovery-time <i>seconds</i>; maximum-helper-restart-time <i>seconds</i>; notify-duration <i>seconds</i>; recovery-time <i>seconds</i>; restart-duration <i>seconds</i>; stale-routes-time <i>seconds</i>; } </pre>
Hierarchy Level	<pre> [edit logical-systems <i>logical-system-name</i> routing-options], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> routing-options], [edit routing-options], [edit routing-instances <i>routing-instance-name</i> routing-options] </pre>
Release Information	<p>Statement introduced before Junos OS Release 7.4.</p> <p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 12.1 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 14.1X53-D20 for the OCX Series.</p>
Description	<p>You configure the graceful restart routing option globally to enable the feature, but not to enable graceful restart for all routing protocols in a routing instance. To enable graceful restart globally, include the graceful-restart statement under the [edit routing options] hierarchy level. This enables graceful restart globally for all routing protocols. You can, optionally, modify the global settings at the individual protocol level.</p>
	<p> NOTE:</p> <ul style="list-style-type: none"> For VPNs, the graceful-restart statement allows a router whose VPN control plane is undergoing a restart to continue to forward traffic while recovering its state from neighboring routers. For BGP, if you configure graceful restart after a BGP session has been established, the BGP session restarts and the peers negotiate graceful restart capabilities. LDP sessions flap when graceful-restart configurations change.
Default	Graceful restart is disabled by default.
Options	The remaining statements are explained separately. See CLI Explorer .

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Documentation

- *Enabling Graceful Restart*
- *Configuring Routing Protocols Graceful Restart*
- *Configuring Graceful Restart for MPLS-Related Protocols*
- *Configuring VPN Graceful Restart*
- *Configuring Logical System Graceful Restart*
- *Configuring Graceful Restart for QFabric Systems*

graceful-switchover

Syntax graceful-switchover;

Hierarchy Level [edit chassis (EX Series) [redundancy](#)]

Release Information Statement introduced in Junos OS Release 9.2 for EX Series switches.
Statement introduced in Junos OS Release 13.2 for the QFX Series.

Description For switches with more than one Routing Engine, including those in a Virtual Chassis or a Virtual Chassis Fabric, configure the master Routing Engine to switch over gracefully to a backup Routing Engine without interruption to packet forwarding.

Default Graceful Routing Engine switchover (GRES) is disabled.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.


Related Documentation

- *Example: Configuring Nonstop Active Routing on Switches*
- *Configuring Graceful Routing Engine Switchover*
- [Configuring Graceful Routing Engine Switchover in a Virtual Chassis on page 242](#)
- *Configuring Nonstop Active Routing on Switches*
- *Installing Software on an EX Series Switch with Redundant Routing Engines (CLI Procedure)*

id

Syntax	<code>id id;</code>
Hierarchy Level	<code>[edit virtual-chassis]</code>
Release Information	Statement introduced in Junos OS Release 9.3 for EX Series switches. Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series. Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).
Description	Configure the alphanumeric string that identifies a Virtual Chassis or Virtual Chassis Fabric (VCF) configuration.
Options	<i>id</i> —Virtual Chassis ID (VCID), which uses the ISO family address format—for example, 9622.6ac8.5345 .
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> • Example: Assigning the Virtual Chassis ID to Determine Precedence During an EX4200 Virtual Chassis Merge on page 159 • Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge on page 241 • <i>Configuring a QFX Series Virtual Chassis</i> • <i>Autoprovisioning a Virtual Chassis Fabric</i> • <i>Preprovisioning a Virtual Chassis Fabric</i> • <i>Configuring an EX8200 Virtual Chassis (CLI Procedure)</i> • <i>Understanding Virtual Chassis Member ID Numbering in an EX8200 Virtual Chassis</i>

lag-hash

Syntax	lag-hash (packet-based source-port-based);
Hierarchy Level	[edit virtual-chassis vc-port]
Release Information	Statement introduced in Junos OS Release 12.1 for EX Series switches.
Description	Enable hashing of link aggregation group (LAG) network traffic over a dedicated trunk port within a Virtual Chassis, and select how the traffic within the dedicated trunk port is hashed.
	<div>  <p>BEST PRACTICE: Do not configure this statement unless you have a compelling reason to configure it. Configuration of this statement is optional and is only useful in a few types of network setups.</p> </div>
Default	source-port-based
Options	<p>packet-based—Hashes all incoming LAG network traffic on the dedicated trunk port based on the packet.</p> <p>source-port-based—Hashes all incoming LAG network traffic on the dedicated trunk port based on the source.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>

location (Virtual Chassis)

Syntax	<code>location location;</code>
Hierarchy Level	[edit <code>virtual-chassis member member-id</code>]
Release Information	<p>Statement introduced in Junos OS Release 11.1 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>Set a description of the location of the Virtual Chassis or VCF member switch or external Routing Engine.</p> <p>The Location field is visible to users who enter the show virtual-chassis status detail command.</p> <p>Setting this description has no effect on the operation of the member device.</p>
Options	location —Location of the current member switch or external Routing Engine. The location can be any single word.
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none">• <i>Autoprovisioning a Virtual Chassis Fabric</i>• <i>Preprovisioning a Virtual Chassis Fabric</i>• <i>Configuring a QFX Series Virtual Chassis</i>• <i>Configuring an EX2300, EX3400, or EX4300 Virtual Chassis</i>• <i>Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis</i>

mac-persistence-timer

Syntax	<code>mac-persistence-timer (<i>minutes</i> disable);</code>
Hierarchy Level	[edit virtual-chassis]
Release Information	<p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Option disable introduced in Junos OS Release 12.2 for EX Series switches.</p> <p>The maximum timer limit changed from no maximum timer limit to 60 minutes in Junos OS Release 12.2 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>Specify how long the Virtual Chassis or VCF continues to use the MAC address of the switch that was originally configured in the master role as the system MAC base address after the original master switch is removed from the Virtual Chassis or VCF. The system MAC base address does not change in the event of a switchover provided the switch originally configured in the master role remains a member of the Virtual Chassis or VCF.</p> <p>The maximum timer limit is 60 minutes starting in Junos OS Release 12.2. There are no minimum or maximum timer limits in prior Junos OS releases.</p>
Default	The MAC persistence timer is set to 10 minutes by default.
Options	<p>minutes—Time in minutes that the member switch in the backup role continues to use the system MAC base address of the old master before using its own system MAC base address after the switch in the master role is physically disconnected or removed from the Virtual Chassis or VCF.</p> <p>disable—Disable the MAC persistence timer. The system MAC base address never changes when the MAC persistence timer is disabled, even when the switch in the master role is physically disconnected or removed from the Virtual Chassis or VCF.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Configuring the Timer for the Backup Member to Start Using Its Own MAC Address, as Master of a Virtual Chassis on page 232 • Autoprovisioning a Virtual Chassis Fabric • Preprovisioning a Virtual Chassis Fabric

mastership-priority

Syntax	<code>mastership-priority <i>number</i>;</code>
Hierarchy Level	<code>[edit virtual-chassis member <i>member-id</i>]</code>
Release Information	<p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Mastership priority option 0 introduced in Junos OS Release 11.1 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>The mastership priority value is the most important factor in determining the role of the member switch within a nonprovisioned Virtual Chassis or VCF configuration. Other factors (see “Understanding How the Master in a Virtual Chassis Is Elected” on page 36) also affect the election of the master.</p> <p>The mastership priority value takes the highest precedence in the master election algorithm. The member switch with highest mastership priority assumes the master Routing Engine role of the Virtual Chassis or VCF. Toggling back and forth between master and backup status in failover conditions is undesirable, so we recommend that you assign the same mastership priority value to both the master and the backup. Secondary factors in the master election algorithm determine which of these two members (that is, the two members that are assigned the highest mastership priority value) functions as the master of the Virtual Chassis or VCF.</p> <p>This statement is not used for the EX8200 Virtual Chassis, which determines mastership by external Routing Engine uptime.</p> <p>A switch with a mastership priority of 0 never takes the master or backup role.</p>
Default	128
Options	<p><i>number</i>—Mastership priority value.</p> <p>Range: 0 through 255</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • <i>Autoprovisioning a Virtual Chassis Fabric</i> • <i>Preprovisioning a Virtual Chassis Fabric</i> • <i>Configuring a QFX Series Virtual Chassis</i> • <i>Configuring an EX2300, EX3400, or EX4300 Virtual Chassis</i> • <i>Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis</i>

member

Syntax	<pre> member <i>member-id</i> { fabric-tree-root; location <i>location</i>; mastership-priority <i>number</i>; no-management-vlan; serial-number <i>serial-number</i>; role <i>role</i>; } </pre>
Hierarchy Level	[edit virtual-chassis]
Release Information	<p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Configure a switch or an XRE200 External Routing Engine as a member of a Virtual Chassis or a Virtual Chassis Fabric (VCF) with characteristics specified by the available options.
Default	<p>When an EX Series switch or a QFX Series devices configured in standalone mode is powered on but not interconnected through its Virtual Chassis ports (VCPs) with other member switches, its default member ID is 0.</p> <p>There is no default member ID in an EX8200 or EX9200 Virtual Chassis. An EX8200 or EX9200 Virtual Chassis must be preprovisioned, and that process configures the member IDs.</p>
Options	<p><i>member-id</i>—Identifies a specific member switch of a Virtual Chassis or VCF configuration.</p> <p>The exact range for a specific Virtual Chassis or VCF depends on the number of switches allowed in the Virtual Chassis or VCF.</p> <p>In an EX8200 Virtual Chassis, member IDs 0 through 7 are reserved for EX8200 member switches and member IDs 8 and 9 are reserved for the master and backup external Routing Engines.</p> <p>The remaining statement options set characteristics of the Virtual Chassis or VCF member, and are explained separately.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> <i>Autoprovisioning a Virtual Chassis Fabric</i> <i>Preprovisioning a Virtual Chassis Fabric</i>

- *Adding a Device to a Virtual Chassis Fabric*
- *Configuring a QFX Series Virtual Chassis*
- *Configuring an EX2300, EX3400, or EX4300 Virtual Chassis*
- *Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis*
- *Configuring an EX9200 Virtual Chassis*
- *Configuring a QFX Series Virtual Chassis*

no-management-vlan

Syntax	no-management-vlan;
Hierarchy Level	[edit virtual-chassis member member-id]
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series. Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).
Description	<p>Remove the specified member's out-of-band management port from the virtual management Ethernet (VME) global management VLAN of the Virtual Chassis or VCF configuration.</p> <p>For a member that is functioning in a linecard role, you can use this configuration to reserve the member's management Ethernet port for local troubleshooting:</p> <pre>virtual-chassis { member 2 { no-management-vlan; } }</pre> <p>You cannot configure the IP address for a local management Ethernet port using the CLI or the J-Web interface. To do this, you need to use the shell ifconfig command.</p>
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> • Understanding Global Management of a Virtual Chassis on page 38 • <i>Understanding Virtual Chassis Fabric Configuration</i>

no-split-detection

Syntax	no-split-detection;
Hierarchy Level	[edit virtual-chassis]
Release Information	<p>Statement introduced in Junos OS Release 9.3 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>Disable the split and merge feature in a Virtual Chassis or VCF configuration.</p> <p>We recommend using this statement to disable the split and merge feature when configuring a two-member Virtual Chassis. Enabling this statement on a two-member Virtual Chassis ensures that both switches remain in the correct Virtual Chassis roles in the event of a Virtual Chassis split.</p> <p>The split and merge feature is enabled by default when a Virtual Chassis is initially set up. If you set this option in a two-member Virtual Chassis and then expand the Virtual Chassis to add more members, we recommend deleting this configuration item to re-enable the split and merge feature again.</p>
Default	The split and merge feature is enabled.
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Example: Assigning the Virtual Chassis ID to Determine Precedence During an EX4200 Virtual Chassis Merge on page 159 • Disabling Split and Merge in a Virtual Chassis on page 235 • Assigning the Virtual Chassis ID to Determine Precedence During a Virtual Chassis Merge on page 241 • Disabling Split Detection in a Virtual Chassis Configuration • Understanding Split and Merge in a Virtual Chassis on page 50

package-name

Syntax	<code>package-name <i>package-name</i>;</code>
Hierarchy Level	<code>[edit virtual-chassis auto-sw-update]</code>
Release Information	Statement introduced in Junos OS Release 10.0 for EX Series switches. Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series. Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).
Description	Specify the software package name or location of the software package to be used by the automatic software update feature for Virtual Chassis or VCF.
Default	No package name is specified.
Options	<p><i>package-name</i>—Name of the software package or the URL to the software package to be used.</p> <ul style="list-style-type: none"> If the software package is located on a local directory on the switch, use the following format for <i>package-name</i>: <i>/pathname/package-name</i> If the software package is to be downloaded and installed from a remote location, use one of the following formats: <i>ftp://hostname/pathname/package-name</i> <i>ftp://username:prompt@ftp.hostname.net/package-name</i> <i>http://hostname/pathname/package-name</i>
Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
Related Documentation	<ul style="list-style-type: none"> Example: Configuring Automatic Software Update on EX4200 Virtual Chassis Member Switches on page 170 Configuring Automatic Software Update on Virtual Chassis Member Switches on page 235 Understanding Software Upgrades in a Virtual Chassis Fabric

preprovisioned

Syntax	preprovisioned;
Hierarchy Level	[edit virtual-chassis]
Release Information	<p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>Enable the preprovisioned configuration mode for a Virtual Chassis or Virtual Chassis Fabric (VCF) configuration.</p> <p>When the preprovisioned configuration mode is enabled, you cannot use the CLI or the J-Web interface to change the mastership priority or member ID of member switches.</p> <p>You must use this statement to configure an EX8200 Virtual Chassis. Nonprovisioned configuration of an EX8200 Virtual Chassis is not supported.</p>
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Preprovisioning a Virtual Chassis Fabric • Example: Configuring an EX4200 Virtual Chassis Using a Preprovisioned Configuration File on page 127 • Example: Setting Up a Full Mesh EX8200 Virtual Chassis with Two EX8200 Switches and Redundant XRE200 External Routing Engines • Configuring an EX4200, EX4500, or EX4550 Virtual Chassis (CLI Procedure) on page 184 • Configuring an EX8200 Virtual Chassis (CLI Procedure) • Configuring an EX9200 Virtual Chassis • Configuring a QFX Series Virtual Chassis • Removing or Replacing a Member Switch of a Virtual Chassis Configuration on page 213

redundancy (Graceful Switchover)

Syntax	<pre> redundancy { failover { on-disk-failure; on-loss-of-keepalives; } graceful-switchover; } </pre>
Hierarchy Level	[edit chassis (EX Series)]
Release Information	<p>Statement introduced in Junos OS Release 9.2 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 11.1 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 14.1X53-D20 for the OCX Series.</p>
Description	<p>Enable redundant Routing Engines on a Virtual Chassis with two or more member switches or on a Virtual Chassis Fabric, on a standalone EX6200 or EX8200 switch with more than one Routing Engine.</p> <p>The remaining statements are explained separately. See CLI Explorer.</p>
Default	Redundancy is enabled for the Routing Engines.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • graceful-switchover on page 253 • Configuring Graceful Routing Engine Switchover in a Virtual Chassis on page 242 • <i>Configuring Graceful Routing Engine Switchover</i> • <i>Installing Software on an EX Series Switch with Redundant Routing Engines (CLI Procedure)</i> • <i>High Availability Features for EX Series Switches Overview</i>

role

Syntax	<code>role (line-card routing-engine);</code>
Hierarchy Level	<code>[edit virtual-chassis member <i>member-id</i>]</code>
Release Information	Statement introduced in Junos OS Release 9.0 for EX Series switches. Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series. Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).

Description Specify the roles of the members of the Virtual Chassis or a Virtual Chassis Fabric (VCF) in a preprovisioned Virtual Chassis. For a mixed Virtual Chassis or VCF, see “[Understanding Mixed EX Series and QFX Series Virtual Chassis](#)” on page 29 or *Understanding Mixed Virtual Chassis Fabric* for any recommendations or requirements for assigning the Routing Engine role based on the types of switches comprising the Virtual Chassis or VCF.

Virtual Chassis Fabric

Specify the role to be performed by each switch. In a VCF, two spine devices are configured into the Routing Engine role and the remaining spine devices and all leaf devices are configured into the **line-card** role. The role must also be associated with the member's serial number (see [serial-number](#)).

EX Series (except EX8200 Virtual Chassis) and QFX Series Virtual Chassis

Specify the role to be performed by each member switch. Associate the role with the member's serial number (see [serial-number](#)).

When you use a preprovisioned configuration, you cannot modify the mastership priority or member ID of member switches through the user interfaces. The mastership priority value is generated by the software, based on the assigned role:

- A member configured as **routing-engine** is assigned the mastership priority 129.
- A member configured as **line-card** is assigned the mastership priority 0.
- A member listed in the preprovisioned configuration without an explicitly specified role is assigned the **line-card** role and mastership priority 0 by default.

The configured role specifications are permanent. If both **routing-engine** members fail, a **line-card** member cannot take over as master of the Virtual Chassis configuration. You must delete the preprovisioned configuration to change the specified roles in a Virtual Chassis.

Explicitly configure two members as **routing-engine** and configure additional switches as members of the preprovisioned Virtual Chassis by specifying only their serial numbers. If you do not explicitly configure the role of the additional members, they function in a **line-card** role by default. In that case, a member that is functioning in a **line-card** role can

take over mastership if the members functioning as master and backup (**routing-engine** role) both fail.

EX8200 Virtual Chassis

Specify the role to be performed by each XRE200 External Routing Engine and each EX8200 member switch. Associate the role with the member's serial number (see [serial-number](#)). An EX8200 Virtual Chassis cannot function when both external Routing Engines, which must be configured in the **routing-engine** role, have failed.

- Options**
- **line-card**—Enables the member to be eligible to function only in the linecard role. Any member of the Virtual Chassis or VCF configuration other than the master or backup functions in the linecard role and runs only a subset of Junos OS for EX Series switches. A member functioning in the linecard role does not run the control protocols or the chassis management processes.

A Virtual Chassis must have at least three members for one member to function in the linecard role.

In an EX8200 Virtual Chassis configuration, all member switches must be in the linecard role.

- **routing-engine**—Enables the member to function as a master or backup Routing Engine of the Virtual Chassis or VCF configuration. The master manages all members and runs the chassis management processes and control protocols. The backup synchronizes with the master in terms of protocol states, forwarding tables, and so forth, so that it is prepared to preserve routing information and maintain network connectivity without disruption in case the master is unavailable.

In a Virtual Chassis composed of EX Series switches (except EX8200 switches) or QFX Series switches, specify two and only two members in the **routing-engine** role. The software determines which of the two members assigned the **routing-engine** role functions as master, based on the master election algorithm. See [“Understanding How the Master in a Virtual Chassis Is Elected” on page 36](#). In these Virtual Chassis, the **routing-engine** role is associated with a switch. For a mixed Virtual Chassis or VCF, see [“Understanding Mixed EX Series and QFX Series Virtual Chassis” on page 29](#) or [Understanding Mixed Virtual Chassis Fabric](#) for specific recommendations or requirements for assigning the Routing Engine role based on the types of switches comprising the Virtual Chassis or VCF. The remaining switches are configured into the linecard role.

In an EX8200 Virtual Chassis, all XRE200 External Routing Engines must be in the **routing-engine** role.

Required Privilege Level	system—To view this statement in the configuration.
	system-control—To add this statement to the configuration.

**Related
Documentation**

- *Autoprovisioning a Virtual Chassis Fabric*
- *Preprovisioning a Virtual Chassis Fabric*
- *Configuring an EX2300, EX3400, or EX4300 Virtual Chassis*
- *Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis*
- *Configuring an EX9200 Virtual Chassis*
- *Configuring a QFX Series Virtual Chassis*
- [Removing or Replacing a Member Switch of a Virtual Chassis Configuration on page 213](#)

serial-number

Syntax	<code>serial-number serial-number;</code>
Hierarchy Level	[edit virtual-chassis member member-id]
Release Information	<p>Statement introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>In a preprovisioned Virtual Chassis or Virtual Chassis Fabric (VCF), specify the serial number of each member switch to be included in the configuration. If you do not include the serial number within the configuration, the switch cannot be recognized as a member of a preprovisioned configuration. Serial number values are case-sensitive.</p> <p>In an EX8200 Virtual Chassis configuration, specify the serial number of each XRE200 External Routing Engine and each EX8200 member switch to be included in the Virtual Chassis configuration. If you do not include the serial number within the Virtual Chassis configuration, the external Routing Engine or switch cannot be recognized as a member of the configuration.</p>
Options	serial-number —Permanent serial number for the external Routing Engine or for the member switch.
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • <i>Autoprovisioning a Virtual Chassis Fabric</i> • <i>Preprovisioning a Virtual Chassis Fabric</i> • <i>Configuring an EX2300, EX3400, or EX4300 Virtual Chassis</i> • <i>Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis</i> • <i>Configuring an EX9200 Virtual Chassis</i> • <i>Configuring a QFX Series Virtual Chassis</i>

traceoptions (Virtual Chassis)

Syntax

```
traceoptions {
  file filename <files number> <no-stamp> <replace> <size size> <world-readable |
    no-world-readable>;
  flag flag <detail> <disable> <receive> <send>;
}
```

Hierarchy Level [edit [virtual-chassis](#)]

Release Information Statement introduced in Junos OS Release 9.0 for EX Series switches.
 Option **detail** added in Junos OS Release 9.2 for EX Series switches.
 Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.
 Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).

Description Define tracing operations for the Virtual Chassis or VCF.

Each Virtual Chassis or VCF member is updated with configured tracing options, and the log file is stored locally on each device.



NOTE: In a large-scale VCF, use system logging and tracing with discretion, and only for troubleshooting. These operations place an extra load on the master Routing Engine device, which can impact VCF convergence time and stability. All tracing options should be disabled during normal VCF operation. To troubleshoot particular problems, selectively enable tracing options, and disable them again after collecting the desired information.

Default Tracing operations are disabled.

Options **detail**—(Optional) Generate detailed trace information for a flag.



NOTE: Enable tracing at the detail level only while troubleshooting a particular issue, and disable it again for normal system operation.

disable—(Optional) Disable a flag.

file *filename*—Name of the file to receive the output of the tracing operation. Enclose the name within quotation marks. All files are placed in the directory **/var/log**.

files *number*—(Optional) Maximum number of trace files. When a trace file named ***trace-file*** reaches its maximum size, it is renamed ***trace-file.0***, then ***trace-file.1***, and so on, until the maximum number of trace files is reached. Then the oldest trace file

is overwritten. If you specify a maximum number of files, you also must specify a maximum file size with the **size** option.

Range: 2 through 1000

Default: 3 files

flag flag—Tracing operation to perform. To specify more than one tracing operation, include multiple flag statements. You can include the following flags:

- **all**—All tracing operations.



TIP: The **all** flag displays a subset of logs that are generally useful in debugging issues, and for more detailed information, you can use options **all detail**. However, to avoid significantly impacting VCF stability, use this high level of tracing only for troubleshooting for a short period of time, and not during normal VCF operation.

- **auto-configuration**—Trace Virtual Chassis ports (VCPs) that have been automatically configured.
- **csn**—Trace Virtual Chassis complete sequence number (CSN) packets.
- **error**—Trace Virtual Chassis errored packets.
- **hello**—Trace Virtual Chassis hello packets.
- **krt**—Trace Virtual Chassis KRT events.
- **lsp**—Trace Virtual Chassis link-state packets.
- **lsp-generation**—Trace Virtual Chassis link-state packet generation.
- **me**—Trace Virtual Chassis ME events.
- **normal**—Trace normal events.
- **packets**—Trace Virtual Chassis packets.
- **parse**—Trace reading of the configuration.
- **psn**—Trace partial sequence number (PSN) packets.
- **route**—Trace Virtual Chassis routing information.
- **spf**—Trace Virtual Chassis SPF events.
- **state**—Trace Virtual Chassis state transitions.
- **task**—Trace Virtual Chassis task operations.

no-stamp—(Optional) Do not place a timestamp on any trace file.

no-world-readable—(Optional) Restrict file access to the user who created the file.

receive—(Optional) Trace received packets.

replace—(Optional) Replace a trace file rather than appending information to it.

send—(Optional) Trace transmitted packets.

size *size*—(Optional) Maximum size of each trace file, in kilobytes (KB), megabytes (MB), or gigabytes (GB). When a trace file named **trace-file** reaches its maximum size, it is renamed **trace-file.0**, then **trace-file.1**, and so on, until the maximum number of trace files is reached. Then the oldest trace file is overwritten. If you specify a maximum number of files, you also must specify a maximum file size with the **files** option.

Syntax: **xk** to specify KB, **xm** to specify MB, or **xg** to specify GB

Range: 10 KB through 1 GB

Default: 128 KB

world-readable—(Optional) Enable unrestricted file access.

Required Privilege Level	system—To view this statement in the configuration. system-control—To add this statement to the configuration.
---------------------------------	---

Related Documentation	<ul style="list-style-type: none"> • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287 • Verifying the Member ID, Role, and Neighbor Member Connections of a Virtual Chassis Member on page 284 • Verifying That Virtual Chassis Ports Are Operational on page 285 • Troubleshooting an EX Series Virtual Chassis on page 391 • Troubleshooting Virtual Chassis Fabric
------------------------------	---

vc-port

Syntax `vc-port {
 lag-hash (packet-based | source-port-based);
 }`

Hierarchy Level [edit [virtual-chassis](#)]

Release Information Statement introduced in Junos OS Release 12.1 for EX Series switches.

Description Enable hashing of link aggregation group (LAG) network traffic over a dedicated trunk port within a Virtual Chassis.

You select how to direct all LAG traffic through the dedicated trunk port by using the **lag-hash** statement.



BEST PRACTICE: Do not configure this statement unless you have a compelling reason to configure it. Configuration of this statement is optional and is only useful in a few types of network setups.

The remaining statement is explained separately. See [CLI Explorer](#).

Default source-port-based

Required Privilege Level system—To view this statement in the configuration.
 system-control—To add this statement to the configuration.

vcp-snmp-statistics

Syntax	<code>vcp-snmp-statistics;</code>
Hierarchy Level	[edit virtual-chassis]
Release Information	Statement introduced in Junos OS Release 14.1X53-D40 and 15.1R5 only on EX2200, EX3300, EX4200, EX4500, EX4550, and EX8200 switches. Statement deprecated in Junos OS Releases after 14.1X53 and 15.1.
Description	<p>Enable SNMP monitoring of the Virtual Chassis ports (VCPs) for all VCPs in the Virtual Chassis or Virtual Chassis Fabric (VCF).</p> <p>When this statement is enabled, SNMP gathers statistics on the Junos VCP MIBs. You can retrieve the statistics gathered by SNMP for these MIBs by using the <i>show snmp mib</i> command with the walk and ascii options and specifying jnxVirtualChassisPortInPkts.</p>
Default	SNMP is disabled by default on devices running Junos OS.
Required Privilege Level	<p>system—To view this statement in the configuration.</p> <p>system-control—To add this statement to the configuration.</p>
Related Documentation	<ul style="list-style-type: none"> • Understanding EX Series Virtual Chassis on page 8 • <i>Understanding QFX Series Virtual Chassis</i> • Understanding Virtual Chassis Components on page 16

virtual-chassis

```
Syntax virtual-chassis {
    aliases {
        serial-number serial-number {
            alias-name alias-name;
        }
    }
    auto-conversion;
    auto-provisioned;
    auto-sw-update {
        (ex-4200 | ex-4300 | ex-4500 | ex-4600 | qfx-3 | qfx-5)
        package-name package-name;
    }
    fast-failover (ge | vcp disable | xe);
    graceful-restart {
        disable;
    }
    id id;
    mac-persistence-timer (minutes | disable);
    member member-id {
        fabric-tree-root;
        location location;
        mastership-priority number;
        no-management-vlan;
        serial-number;
        role;
    }
    no-auto-conversion;
    no-split-detection;
    preprovisioned;
    traceoptions (Virtual Chassis) {
        file filename <files number> <size size> <world-readable | no-world-readable> <match
            regex>;
        flag flag ;
    }
    vc-port {
        lag-hash (packet-based | source-port-based);
    }
    vcp-no-hold-time;
    vcp-snmp-statistics;
}
```

Hierarchy Level [\[edit\]](#)

Release Information Statement introduced in Junos OS Release 9.0 for EX Series switches.
Statement introduced in Junos OS Release 13.2X50-D15 for the QFX Series.
Statement introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).

Description Configure a Virtual Chassis or a Virtual Chassis Fabric (VCF).

The remaining statements are explained separately. See [CLI Explorer](#).

Default A standalone EX Series switch is a Virtual Chassis by default. It has a default member ID of 0, a default mastership priority of 128, and a default role as master.

A QFX Series device configured in standalone mode is a Virtual Chassis by default. It has a default member ID of 0, a default mastership priority of 128, and a default role as master.

A standalone XRE200 External Routing Engine or EX8200 switch is not part of an EX8200 Virtual Chassis until a Virtual Chassis configuration is set up.

Required Privilege Level system—To view this statement in the configuration.
system-control—To add this statement to the configuration.

Related Documentation

- *Autoprovisioning a Virtual Chassis Fabric*
- *Preprovisioning a Virtual Chassis Fabric*
- *Adding a Device to a Virtual Chassis Fabric*
- *Configuring a QFX Series Virtual Chassis*
- *Configuring an EX2300, EX3400, or EX4300 Virtual Chassis*
- *Configuring EX4600 Switches in a Mixed or Non-Mixed Virtual Chassis*
- *Configuring an EX9200 Virtual Chassis*

PART 3

Administration

- [Routine Monitoring on page 279](#)
- [Operational Commands on page 293](#)

CHAPTER 5

Routine Monitoring

- [Command Forwarding Usage with EX Series and QFX Series Virtual Chassis on page 279](#)
- [Verifying the Member ID, Role, and Neighbor Member Connections of a Virtual Chassis Member on page 284](#)
- [Verifying That Virtual Chassis Ports Are Operational on page 285](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
- [Verifying That Graceful Routing Engine Switchover Is Working in the Virtual Chassis on page 289](#)
- [Verifying the Setting for the PIC Mode on an EX4500 Switch in a Virtual Chassis on page 290](#)
- [Verifying the Setting for the Virtual Chassis Mode on EX4200, EX4500, and EX4550 Switches on page 291](#)
- [Verifying Connectivity Between Virtual Chassis Member Devices on page 291](#)

Command Forwarding Usage with EX Series and QFX Series Virtual Chassis

Some CLI commands can be run either on all members or on a specific member of a Virtual Chassis configuration. This functionality is referred to as command forwarding.

You can always specify that these commands be applied to all member switches in the Virtual Chassis by using the **all-members** option, or to a specific member switch by using the **member-member-id** option. If neither option is specified, the default command forwarding behavior, which varies by command, is used. See the **Default** row in [Table 25 on page 280](#) to learn the command forwarding behavior for a specific command.

For example, to collect information about a particular member switch prior to contacting Juniper Networks Technical Assistance Center (JTAC), use the **request support information member member-id** command to gather data for the specified member switch. If you want to gather this data for all member switches in the Virtual Chassis, you can enter the **request support information** command, which by default uses the **all-members** option, or the **request support information all-members** command.

[Table 25 on page 280](#) provides a list of commands that can be run either on all members of the Virtual Chassis configuration or on a specific member switch.

Table 25: Commands That Can be Run on All or Specific Members of the Virtual Chassis Configuration

Command	Purpose	all-members	member-member-id	Default
request support information	<p>Use this command when you contact JTAC about your component problem. This command is the equivalent of using the following CLI commands:</p> <ul style="list-style-type: none"> • show version • show chassis firmware • show chassis hardware • show chassis environment • show interfaces extensive (for each configured interface) • show configuration (excluding any SECRET-DATA) • show system virtual-memory 	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
request system partition hard-disk	<p>Set up the hard disk for partitioning. After this command is issued, the hard disk is partitioned the next time the system is rebooted. When the hard disk is partitioned, the contents of /altroot and /altconfig are saved and restored. All other data on the hard disk is at risk of being lost.</p>	Partitions the hard disk on all members of the Virtual Chassis configuration.	Partitions the hard disk on the specified member switch.	all-members
request system reboot	<p>Reboot Junos OS for EX Series or QFX Series switches after a software upgrade and occasionally to recover from an error condition.</p>	Reboots all members of the Virtual Chassis configuration.	Reboots the specified member switch.	all-members

Table 25: Commands That Can be Run on All or Specific Members of the Virtual Chassis Configuration (continued)

Command	Purpose	all-members	member-member-id	Default
request system snapshot	Back up the currently running and active file system.	Backs up the file systems on all members of the Virtual Chassis configuration.	Backs up the file system on the specified member switch.	all-members
request system storage cleanup	Free storage space on the switch by rotating log files and proposing a list of files for deletion. User input is required for file deletion.	Runs cleanup on all members of the Virtual Chassis configuration.	Runs cleanup on the specified member switch.	all-members
show log user	Display users who are viewing the system log.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	master switch only
show system alarms	Display active system alarms.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system audit	Display the state and checksum values for file systems.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system boot-messages	Display initial messages generated by the system kernel upon startup. These messages are the contents of <code>/var/run/dmesg.boot</code> .	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members

Table 25: Commands That Can be Run on All or Specific Members of the Virtual Chassis Configuration (continued)

Command	Purpose	all-members	member-member-id	Default
show system buffers	Display information about the buffer pool that the Routing Engine uses for local traffic. Local traffic is the routing and management traffic that is exchanged between the Routing Engine and the Packet Forwarding Engine within the switch, as well as the routing and management traffic from IP (that is, from OSPF, BGP, SNMP, ping operations, and so on).	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system connections	Display information about the active IP sockets on the Routing Engine. Use this command to verify which servers are active on a system and which connections are currently in progress.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system core-dumps	Display a core file generated by an internal Junos OS process.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system directory-usage	Display directory usage information.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	master switch only
show system processes	Display information about software processes that are running on the switch and that have controlling terminals.	Displays information for all members of the Virtual Chassis configuration.		all-members

Table 25: Commands That Can be Run on All or Specific Members of the Virtual Chassis Configuration (continued)

Command	Purpose	all-members	member-member-id	Default
show system reboot	Display pending system reboots or halts.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system snapshot	Display information about the backup software that is located in the /altroot and /altconfig file systems. To back up software, use the request system snapshot command.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system software	Display the Junos OS extensions loaded on your switch.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system statistics	Display systemwide protocol-related statistics.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system storage	Display statistics about the amount of free disk space in the switch's file systems.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system uptime	Display the current time and information about how long the switch, the switch software, and any existing protocols have been running	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members
show system users	Show all users who are currently logged in.	Shows all users who are currently logged in to any members of the Virtual Chassis configuration.	Shows all users who are currently logged in to the specified member switch.	all-members

Table 25: Commands That Can be Run on All or Specific Members of the Virtual Chassis Configuration (continued)

Command	Purpose	all-members	member-member-id	Default
show system virtual-memory	Display the usage of Junos OS kernel memory, listed first by size of allocation and then by type of usage. Use show system virtual-memory for troubleshooting with JTAC.	Displays information for all members of the Virtual Chassis configuration.	Displays information for the specified member switch.	all-members

- Related Documentation**
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
 - [Virtual Chassis Overview for Switches on page 3](#)
 - [Understanding Virtual Chassis Components on page 16](#)

Verifying the Member ID, Role, and Neighbor Member Connections of a Virtual Chassis Member

Purpose You can designate the role that a member performs within a Virtual Chassis or you can allow the role to be assigned by default. You can designate the member ID that is assigned to a specific switch by creating a permanent association between the switch's serial number and a member ID, using a preprovisioned configuration. Or you can let the member ID be assigned by the master, based on the sequence in which the member switch is powered on and on which member IDs are currently available.

The role and member ID of the member switch are displayed on the front-panel LCD (for switches that have an LCD) or in the output from the **show virtual-chassis** CLI command.

Each member switch can be cabled to one or two other member switches, using either the dedicated Virtual Chassis ports (VCPs) on the rear panel, an uplink port that has been configured as a VCP, or an optical port that has been configured as a VCP. The members that are cabled together are considered neighbor members.

Action To display the role and member ID assignments using the CLI:

```
user@switch> show virtual-chassis
```

```
Virtual Chassis ID: 0000.e255.00e0
```

Member ID	Status	Serial No	Model	Mastership Priority	Role	Neighbor List ID, Interface
0 (FPC 0)	Prsnt	abc123	ex4200-48p	255	Master*	1 vcp-0 2 vcp-1

1 (FPC 1)	Prsnt	def456	ex4200-24t	255	Backup	2 vcp-0 0 vcp-1
2 (FPC 2)	Prsnt	abd231	ex4200-24p	128	Linecard	0 vcp-0 1 vcp-1

Meaning This output verifies that three EX4200 switches have been interconnected as a Virtual Chassis configuration through their dedicated VCPs to create an EX4200 Virtual Chassis. The display shows which of the VCPs is connected to which neighbor. The first port (**vcp-0**) of member **0** is connected to member **1** and the second port of member **0** (**vcp-1**) is connected to member **2**. The FPC slots for the switches are the same as the member IDs.

The **Mastership Priority** values indicate that the master and backup members have been explicitly configured, because they are not using the default value (128).



NOTE: This example uses output from an EX4200 Virtual Chassis. The output, with the exception of the Model column, would be identical on all other Virtual Chassis.

Related Documentation

- [Configuring Mastership of a Virtual Chassis on page 220](#)
- [Configuring a QFX Series Virtual Chassis](#)
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)

Verifying That Virtual Chassis Ports Are Operational

Purpose Display the status of Virtual Chassis ports (VCPs) in a Virtual Chassis or Virtual Chassis Fabric (VCF).



NOTE: VCPs are not displayed when you issue the `show interfaces` command.

Action Display the VCPs:

```
user@switch> show virtual-chassis vc-port all-members
```

```
fpc0:
```

Interface or	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
--------------	------	----------	--------	--------------	-------------	-----------

PIC / Port						
vcp-0	Dedicated	1	Up	32000	1	vcp-0
vcp-1	Dedicated	2	Up	32000	1	vcp-1
1/0	Configured	3	Up	1000	2	vcp-255/1/0
1/1	Configured	3	Up	1000	2	vcp-255/1/1
1/2	Configured	4	Up	1000	4	vcp-255/0/20
1/3	Configured	4	Up	1000	4	vcp-255/0/21

fpc1:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	0	vcp-0
vcp-1	Dedicated	2	Up	32000	0	vcp-1
1/0	Configured	3	Up	10000	3	vcp-255/1/0
1/1	Configured	3	Up	10000	3	vcp-255/1/1

fpc2:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	3	vcp-0
vcp-1	Dedicated	2	Up	32000	3	vcp-1
1/0	Configured	3	Up	1000	0	vcp-255/1/0
1/1	Configured	3	Up	1000	0	vcp-255/1/1
1/2		-1	Down	1000		
1/3		-1	Down	1000		

fpc3:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	2	vcp-0
vcp-1	Dedicated	2	Up	32000	2	vcp-1
1/0	Configured	3	Up	10000	1	vcp-255/1/0
1/1	Configured	3	Up	10000	1	vcp-255/1/1

fpc4:						
Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Down	32000		
vcp-1	Dedicated	2	Down	32000		
0/20	Configured	3	Up	1000	0	vcp-255/1/2
0/21	Configured	3	Up	1000	0	vcp-255/1/3

Meaning The dedicated VCPs are displayed as **vcp-0** and **vcp-1**. The uplink interfaces that have been set as uplink VCPs are displayed as **1/0**, **1/1**, **1/2**, and **1/3**. The network interfaces that have been set as VCPs are displayed as **0/20** and **0/21**. The neighbor interface names of uplink and network VCPs are of the form **vcp-255/pic/port**—for example, **vcp-255/1/0**. In that name, **vcp-255** indicates that the interface is a VCP, **1** is the uplink PIC number, and **0** is the port number. The **fpc** number is the same as the member ID. The trunk ID is

a positive number ID assigned to the link aggregation group (LAG) formed by the Virtual Chassis. If no LAG is formed, the value is -1.



NOTE: This example uses output from an EX4200 Virtual Chassis. The output is similar on all other types of Virtual Chassis or for a VCF.

Related Documentation

- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
- [Configuring an EX3300 Virtual Chassis \(CLI Procedure\) on page 181](#)
- [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
- [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)

Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis

Purpose



NOTE: This topic applies only to the J-Web Application package.

You can use the J-Web monitoring functionality to view information about the switches that are members of a Virtual Chassis and their ports. J-Web monitoring is supported on EX2200, EX3300, EX4200, EX4300, EX4500, EX4550, and EX8200 switches in a Virtual Chassis. Starting with Junos OS Releases 14.1X53-D10 and 16.1R1, J-Web monitoring is supported on EX4600 switches and EX4600 switches in a Virtual Chassis.

Use the monitoring functionality to view the following information about the switches and the ports on EX2200, EX3300, EX4200, EX4300, EX4500, EX4550, and EX8200 switches that are members of a Virtual Chassis:

- Member details and how members are connected with each other
- Traffic statistics for Virtual Chassis ports (VCPs) of the selected members
- Details of the VCP packet counters

Action

To view Virtual Chassis monitoring details in the J-Web interface for a Virtual Chassis, select **Monitor > Virtual Chassis**.

To view member details for all members in the CLI, enter the following command:

```
user@switch> show virtual-chassis
```

To view VCP traffic statistics for a specific member in the CLI, enter the following command:

```
user@switch> show virtual-chassis vc-port statistics member member-id
```

To view the path a packet takes when going from a source interface to a destination interface in a Virtual Chassis configuration using the CLI, enter the following command:

```
user@switch> show virtual-chassis vc-path
```

Meaning In the J-Web interface, the top half of the screen displays details of the Virtual Chassis configuration, such as:

- Member
- Role
- Status
- Interface
- Type
- Speed
- Neighboring Member ID
- Link Status
- Error count



NOTE: If the member switch in the Virtual Chassis is not provisioned, the member ID will be displayed as -.

Click the **Stop** button to stop fetching values from the switch, and click the **Start** button to start plotting data again from the point where it was stopped.

To view a graph of the statistics for the selected VCP of the member, click **Show Graph**.

Refresh Interval (sec)—Displays the time interval you have set for page refresh.

Click **Clear Statistics** to clear the monitoring statistics for the selected member switch. You can specify the interval at which the member details and statistics must be refreshed.

The bottom half of the screen displays a chart of the Virtual Chassis statistics and the port packet counters.

For details about the output from CLI commands, see the [show virtual-chassis](#) and [show virtual-chassis vc-port statistics](#) command summaries.

Release History Table

Release	Description
14.1X53-D10	Starting with Junos OS Releases 14.1X53-D10 and 16.1R1, J-Web monitoring is supported on EX4600 switches and EX4600 switches in a Virtual Chassis.

Related Documentation

- [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)
- [Verifying the Member ID, Role, and Neighbor Member Connections of a Virtual Chassis Member on page 284](#)

Verifying That Graceful Routing Engine Switchover Is Working in the Virtual Chassis

Purpose Verify that a Graceful Routing Engine switchover (GRES) between two member switches acting as the master and backup routing engines in a Virtual Chassis has occurred.

Action On the master switch, verify the member ID of the backup Routing Engine:

```
{master:0}
user@switch> show virtual-chassis

Virtual Chassis ID: 5efa.4b7a.aae6
```

Member ID	Status	Serial No	Model	Mastership priority	Role	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	BM0208105281	ex4200-24t	255	Master*	1	vcp-0
1 (FPC 1)	Prsnt	BP0208192350	ex4200-48t	255	Backup	0	vcp-0

```
Member ID for next new member: 2 (FPC 2)
```

1. Connect to the backup Routing Engine:

```
{master:0}
user@switch> request session member 1
```

```
{backup:1}
user@switch>
```

2. Verify that the backup Routing Engine is ready for switchover on member ID 1:

```
{backup:1}
user@switch> show system switchover
```

```
Graceful switchover: On
Configuration database: Ready
Kernel database: Ready
Peer state: Steady State
```

3. Switch the current backup Routing Engine to master Routing Engine:



NOTE: You must wait a minimum of two minutes between Routing Engine failovers for the Routing Engines to synchronize.

```
{backup:1}
user@switch> request chassis routing-engine master acquire
```

4. Verify that the master and backup Routing Engines have switched roles:



NOTE: Member ID1 is now the master and member ID 0 is now the backup.

```
{master:1}
user@switch> show virtual-chassis
```

```
Virtual Chassis ID: 5efa.4b7a.aae6
Mastership
Neighbor List
```

Member ID	Status	Serial No	Model	priority	Role	ID	Interface
0 (FPC 0)	Prsnt	BM0208105281	ex4200-24t	255	Backup	1	vcp-0
1 (FPC 1)	Prsnt	BP0208192350	ex4200-48t	255	Master*	0	vcp-0

```
Member ID for next new member: 2 (FPC 2)
```

Meaning With graceful Routing Engine switchover enabled, when you initiated a switchover from the backup Routing Engine, the backup Routing Engine became the master and the master Routing Engine became the backup.

Related Documentation

- [Configuring Graceful Routing Engine Switchover in a Virtual Chassis on page 242](#)

Verifying the Setting for the PIC Mode on an EX4500 Switch in a Virtual Chassis

Purpose Verify the PIC mode setting for an EX4500 or EX4550 switch in a Virtual Chassis.

Action To verify the current PIC mode setting:

```
user@switch> show chassis pic-mode
```

```
fpc0:
```

```
-----
Pic Mode: Intraconnect
```

Meaning The output shows that the PIC mode is currently set to Intraconnect. The Intraconnect mode sets the EX4500 as a standalone switch.

You must set the PIC mode to **virtual-chassis** if you want to connect the switch into a Virtual Chassis using the dedicated Virtual Chassis ports (VCPs) on the Virtual Chassis module. The default PIC mode setting is **virtual chassis**.

- Related Documentation**
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
 - [Resetting the EX4500 Switch to Run as a Standalone Switch \(CLI Procedure\) on page 243](#)

Verifying the Setting for the Virtual Chassis Mode on EX4200, EX4500, and EX4550 Switches

Purpose You must configure EX4200, EX4500, and EX4550 switches into mixed Virtual Chassis mode if you want those switches to act as member switches in a mixed EX4200 and EX4500 Virtual Chassis, mixed EX4200 and EX4550 Virtual Chassis, or mixed EX4200, EX4500, and EX4550 Virtual Chassis. You must also configure a switch out of mixed Virtual Chassis mode if you remove the switch from a mixed Virtual Chassis. You must change the Virtual Chassis mode for all member switches in a Virtual Chassis if the Virtual Chassis is changed to a non-mixed Virtual Chassis..

Action To display the Virtual Chassis mode of any EX4200, EX4500, or EX4550 switch:

```
user@switch> show virtual-chassis mode
```

```
fpc0:
```

```
-----  
Mixed Mode: Disabled
```

Meaning The output indicates that the switch is currently not in mixed Virtual Chassis mode.

- Related Documentation**
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)

Verifying Connectivity Between Virtual Chassis Member Devices

Purpose Verify that a member device is reachable through the Virtual Chassis.

Action 1. Run a Virtual Chassis device reachability test:

```
user@switch> request virtual-chassis device-reachability test-name name source-fpc  
source-fpc-id destination-fpc destination-fpc-id
```

2. View the test results that appear on the screen:

```
Device Reachability Statistics:  
Test Name                : member0-to-member2  
  
Performing Test: 1  
  
56 bytes from 0: session-id 0 seq-id 0  
56 bytes from 0: session-id 0 seq-id 1  
56 bytes from 0: session-id 0 seq-id 2  
56 bytes from 0: session-id 0 seq-id 3  
56 bytes from 0: session-id 0 seq-id 4  
--- ping statistics ---  
Session ID                : 0  
Packets Count/Sent/Received/Sendfail : 5/5/5/0  
Unknown/Timedout/Duplicate packets received : 0/0/0  
Round-trip Min/Avg/Max    : 181/807/3010 usec
```

Meaning The test results confirm that the connection between the member devices within the Virtual Chassis is operating properly. The **Packets Count/Sent/Received/Sendfail** output shows that five ping packets were sent and five ping packets were returned. The **Unknown/Timedout/Duplicate packets received** field output shows that zero ping packets errors occurred during the test. The **Round-trip Min/Avg/Max** output shows that all of the test packets took between 181 and 3010 microseconds to traverse the path.

Related Documentation

- [Understanding Virtual Chassis Device Reachability Testing on page 62](#)

CHAPTER 6

Operational Commands

- clear virtual-chassis vc-port statistics
- request chassis pic-mode
- request session member
- request system software nonstop-upgrade
- request virtual-chassis device-reachability
- request virtual-chassis mode
- request virtual-chassis recycle
- request virtual-chassis renumber
- request virtual-chassis vc-port (Dedicated VCP)
- request virtual-chassis vc-port
- show chassis nonstop-upgrade
- show chassis pic-mode
- show system uptime
- show virtual-chassis active-topology
- show virtual-chassis device-topology
- show virtual-chassis protocol adjacency
- show virtual-chassis protocol database
- show virtual-chassis protocol interface
- show virtual-chassis protocol route
- show virtual-chassis protocol statistics
- show virtual-chassis fast-failover
- show virtual-chassis login
- show virtual-chassis mode
- show virtual-chassis
- show virtual-chassis vc-path
- show virtual-chassis vc-port
- show virtual-chassis vc-port statistics

clear virtual-chassis vc-port statistics

Syntax	<pre>clear virtual-chassis vc-port statistics <all-members> <interface-name> <local> <member member-id></pre>
Release Information	<p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>The options all-members and local were added in Junos OS Release 9.3 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric.</p>
Description	Clear—reset to zero (0)—the traffic statistics counters on Virtual Chassis ports (VCPs).
Options	<p>none—Clear traffic statistics for VCPs of all members of a Virtual Chassis or VCF.</p> <p>all-members—(Optional) Clear traffic statistics for VCPs of all members of a Virtual Chassis or VCF.</p> <p>interface-name—(Optional) Clear traffic statistics for the specified VCP.</p> <p>local—(Optional) Clear traffic statistics for VCPs from the switch or external Routing Engine on which this command is entered.</p> <p>member member-id—(Optional) Clear traffic statistics for VCPs from the specified member of a Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • show virtual-chassis vc-port statistics on page 382 • show virtual-chassis vc-port on page 377 • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287
List of Sample Output	<p>clear virtual-chassis vc-port statistics (EX4200 Virtual Chassis) on page 294</p> <p>clear virtual-chassis vc-port statistics (EX8200 Virtual Chassis) on page 295</p> <p>clear virtual-chassis vc-port statistics member 3 on page 295</p>

Sample Output

clear virtual-chassis vc-port statistics (EX4200 Virtual Chassis)

```
user@switch> clear virtual-chassis vc-port statistics
```

```
fpc0:
-----
Statistics cleared
```

clear virtual-chassis vc-port statistics (EX8200 Virtual Chassis)

```
user@external-routing-engine> clear virtual-chassis vc-port statistics
```

```
member0:
-----
Statistics cleared
```

```
member1:
-----
Statistics cleared
```

```
member8:
-----
Statistics cleared
```

```
member9:
-----
Statistics cleared
```

clear virtual-chassis vc-port statistics member 3

```
user@switch> clear virtual-chassis vc-port statistics member 3
```

```
Cleared statistics on member 3
```

request chassis pic-mode

Syntax `request chassis pic-mode (intraconnect | virtual-chassis)
<all-members>
<local>
<member member-id>`

Release Information Command introduced in Junos OS Release 11.1 for EX Series switches.

Description Set the PIC mode on an EX4500 switch. The PIC mode command determines whether the module that is plugged into the EX4500 switch operates as an intraconnect module or a Virtual Chassis module.



NOTE: Operating an EX4500 switch without the intraconnect module or the Virtual Chassis module is not supported.



NOTE: If you use the EX4500 switch as a standalone switch without changing the PIC mode setting to `intraconnect`, you will not be able to achieve 960 Gbps data rate throughput. Some of the bandwidth is reserved for the dedicated Virtual Chassis ports (VCPs).

The PIC mode must be set to **virtual-chassis** if the EX4500 switch is cabled into a Virtual Chassis using the dedicated VCPs on the Virtual Chassis module. This is the setting in the default factory configuration. The **intraconnect** PIC mode is not supported by the default factory configuration.

If you want to use the EX4500 switch as a standalone switch, you must take several steps to reset the PIC mode as **intraconnect**. You cannot reset the PIC mode **intraconnect** simply by issuing the `request chassis pic-mode intraconnect` command. See [“Resetting the EX4500 Switch to Run as a Standalone Switch \(CLI Procedure\)”](#) on page 243.

Use the `show chassis pic-mode` command to verify the current PIC mode setting.

The PIC mode setting is maintained through reboots even though it is set in operational mode.

You do not need to enter this command to use the Virtual Chassis module on an EX4550 switch.

Options **intraconnect**—Set the PIC mode to intraconnect.

virtual-chassis—Set the PIC mode to Virtual Chassis.

all-members—(Optional) Set the PIC mode for all members of the Virtual Chassis configuration. This is the default option.

local—(Optional) Set the PIC mode on the member switch where the command is issued.

member *member-id*—(Optional) Set the PIC mode on the specified member of the Virtual Chassis configuration.

Required Privilege Level

view

Related Documentation

- [Verifying the Setting for the PIC Mode on an EX4500 Switch in a Virtual Chassis on page 290](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
- [Adding an EX4500 Switch to a Preprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 209](#)
- [Adding an EX4500 Switch to a Nonprovisioned EX4200 Virtual Chassis \(CLI Procedure\) on page 211](#)

List of Sample Output [request chassis pic-mode virtual-chassis on page 297](#)
[request chassis pic-mode intraconnect on page 297](#)

Sample Output

[request chassis pic-mode virtual-chassis](#)

```
user@switch> request chassis pic-mode virtual-chassis
```

[request chassis pic-mode intraconnect](#)

```
user@switch> request chassis pic-mode intraconnect
```

```
fpc0:
```

```
-----
virtual-chassis (mode unchanged; intraconnect mode not supported on factory-default config)
```

request session member

Syntax	<code>request session member <i>member-id</i></code>
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series. Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).
Description	Start a session with the specified member of a Virtual Chassis or a VCF.
Options	<i>member-id</i> —Member ID for the specific member of the Virtual Chassis or VCF.
Required Privilege Level	maintenance
Related Documentation	<ul style="list-style-type: none">• member on page 259• Understanding Virtual Chassis Components on page 16

request system software nonstop-upgrade

Syntax `request system software nonstop-upgrade (package-name | set [package-name package-name])`
`<force-host>`
`<no-copy>`
`<no-old-master-upgrade>`
`<reboot >`
`<unlink>`

Release Information Command introduced in Junos OS Release 10.4 for EX Series switches.
Option **set [*package-name package-name*]** added in Junos OS Release 12.1 for EX Series switches.
Command introduced in Junos OS Release 13.2X50-D20 for the QFX Series.
Command introduced in Junos OS Release 15.1X53-D55 for EX3400 switches.

Description Perform a nonstop software upgrade (NSSU) on a switch with redundant Routing Engines or on a Virtual Chassis or Virtual Chassis Fabric (VCF). The behavior of this command depends on the type of switch, Virtual Chassis, or VCF on which it is executed, as follows:

- When you execute this command on any of the following Virtual Chassis or VCF configurations, all members are upgraded:
 - EX3300, EX3400, EX4200, EX4300, EX4500, EX4550, or EX4600 Virtual Chassis
 - Mixed Virtual Chassis composed of any combination of EX4200, EX4500, and EX4550 switches, or EX4300 and EX4600 switches
 - QFX3500 and QFX3600 Virtual Chassis
 - Fixed configuration of switches in a VCF (QFX3500/QFX3600 and QFX5100 switches)
 - Mixed VCF composed of any combination of QFX3500/QFX3600, QFX5100, and EX4300 switches

The original Virtual Chassis or VCF backup becomes the master. The original master is automatically upgraded and rebooted and rejoins the Virtual Chassis or VCF as the backup after the upgrade completes.

- When you execute this command on an EX6200 or EX8200 switch, both the backup and master Routing Engines are upgraded, with the original backup Routing Engine becoming the new master at the end of the upgrade.
 - On an EX6200 switch, the original master Routing Engine is automatically rebooted.
 - On an EX8200 switch, the original master Routing Engine is not automatically rebooted unless you specify the **reboot** option.
- When you execute this command on an EX8200 Virtual Chassis, all master and backup Routing Engines are upgraded in the Virtual Chassis, including the external Routing Engines. The original backup Routing Engines become the new master Routing Engines.

The original master Routing Engines are not automatically rebooted, unless you specify the **reboot** option.

This command has the following requirements:

- All Virtual Chassis members, VCF members, and all Routing Engines must be running the same Junos OS release.
- Graceful Routing Engine switchover (GRES) must be enabled.
- Nonstop active routing (NSR) must be enabled.



NOTE: Although nonstop bridging (NSB) does not have to be enabled for you to use this command, we recommend that you enable NSB. Enabling NSB ensures that all NSB-supported Layer 2 protocols operate seamlessly during the Routing Engine switchover that is part of the NSSU. See *Configuring Nonstop Bridging on EX Series Switches (CLI Procedure)*.

- The command must be executed from the master Routing Engine on a standalone switch or from the master on a Virtual Chassis.
- For minimal traffic disruption, you must define link aggregation groups (LAGs) such that the member links reside on different Virtual Chassis members (for EX3300, EX3400, EX4200, EX4300, EX4500, EX4550, EX4600, QFX3500 and QFX3600 Virtual Chassis, and mixed Virtual Chassis, and VCF) or on different line cards (for EX6200 and EX8200 switches, and for EX8200 Virtual Chassis).
- For EX3300, EX3400, EX4200, EX4300, EX4500, EX4550, EX4600, QFX3500 and QFX3600 Virtual Chassis, and mixed Virtual Chassis:
 - The Virtual Chassis members must be connected in a ring topology. A ring topology prevents the Virtual Chassis from splitting during an NSSU.
 - The Virtual Chassis master and backup must be adjacent to each other in the ring topology. Adjacency permits the master and backup to always be in sync, even when the switches in line-card roles are rebooting.
 - The Virtual Chassis must be pre-configured so that the line-card role has been explicitly assigned to member switches acting in a line-card role. During an NSSU, the Virtual Chassis members must maintain their roles—the master and backup must maintain their Routing Engine roles (although mastership will change), and the remaining switches must maintain their line-card roles.
 - A two-member Virtual Chassis must have **no-split-detection** configured so that the Virtual Chassis does not split when an NSSU upgrades a member.
- For Virtual Chassis Fabric:

- Only two pre-provisioned members in the Routing Engine role are supported. If more than two Routing Engines are configured, a warning is issued and the NSSU process stops.
- The VCF members are connected in a spine and leaf topology. A spine and leaf topology prevents the VCF from splitting during an NSSU. Each leaf device must be connected to both spine devices.
- The VCF must be pre-configured so that the line-card role has been explicitly assigned to member switches acting in a line-card role, and that the Routing Engine role has been explicitly assigned to member switches acting in a Routing Engine role. During an NSSU, the VCF members must maintain their roles—the master and backup must maintain their master and backup roles (although mastership will change), the member switches must remain their Routing Engine roles, and the remaining switches must maintain their line-card roles.
- A two-member VCF must have **no-split-detection** configured so that the VCF does not split when an NSSU upgrades a member.

Options *package-name*—Location from which the software package or bundle is to be installed.
For example:

- */var/tmp/package-name*—For a software package or bundle that is being installed from a local directory on the switch.
- *protocol://hostname/pathname/package-name*—For a software package or bundle that is to be downloaded and installed from a remote location. Replace **protocol** with one of the following:
 - **ftp**—File Transfer Protocol.
Use *ftp://hostname/pathname/package-name*. To specify authentication credentials, use *ftp://<username>:<password>@hostname/pathname/package-name*. To have the system prompt you for the password, specify **prompt** in place of the password. If a password is required, and you do not specify the password or **prompt**, an error message is displayed.
 - **http**—Hypertext Transfer Protocol.
Use *http://hostname/pathname/package-name*. To specify authentication credentials, use *http://<username>:<password>@hostname/pathname/package-name*. If a password is required and you omit it, you are prompted for it.
 - **scp**—Secure copy (available only for Canada and U.S. version).
Use *scp://hostname/pathname/package-name*. To specify authentication credentials, use *scp://<username>:<password>@hostname/pathname/package-name*.



NOTE: The *pathname* in the protocol is the relative path to the user home directory on the remote system and not the root directory.

set [*package-name package-name*]—(Mixed Virtual Chassis only) Locations of the EX4200 and the EX4500 installation packages. These packages must be for the same Junos OS release. See the description of the *package-name* option for information about how to specify the location of the installation packages.

force-host—(Optional) Force the addition of host software package or bundle (ignore warnings) on a QFX5100 device.

no-copy—(Optional) Install a software package or bundle, but do not save copies of package or bundle files.

no-old-master-upgrade—(Optional) (EX8200 switches only) Upgrade the backup Routing Engine only. After the upgrade completes, the original master Routing Engine becomes the backup Routing Engine and continues running the previous software version.

reboot—(Optional) (EX8200 switches and EX8200 Virtual Chassis only) When the **reboot** option is included, the original master (new backup) Routing Engines are automatically rebooted after being upgraded to the new software. When the **reboot** option is not included, you must manually reboot the original master (new backup) Routing Engines using the **request system reboot** command.



NOTE: If you do not use the **reboot** option on an EX8200 Virtual Chassis, you must establish a connection to the console port on the Switch Fabric and Routing Engine (SRE) module or Routing Engine (RE) module to perform the manual reboot of the backup Routing Engines.

unlink—(Optional) Remove the software package after a successful upgrade is completed.

Required Privilege Level maintenance

Related Documentation

- [show chassis nonstop-upgrade on page 322](#)
- *Upgrading Software on an EX6200 or EX8200 Standalone Switch Using Nonstop Software Upgrade (CLI Procedure)*
- *Upgrading Software on an EX8200 Virtual Chassis Using Nonstop Software Upgrade (CLI Procedure)*
- *Upgrading Software on a Virtual Chassis and Mixed Virtual Chassis Using Nonstop Software Upgrade*
- *Upgrading Software on a Virtual Chassis Fabric Using Nonstop Software Upgrade*

List of Sample Output

[request system software nonstop-upgrade \(EX4200 Virtual Chassis\) on page 303](#)
[request system software nonstop-upgrade \(EX6200 Switch\) on page 304](#)
[request system software nonstop-upgrade reboot \(EX8200 Switch\) on page 305](#)

[request system software nonstop-upgrade no-old-master-upgrade \(EX8200 Switch\) on page 306](#)

[request system software nonstop-upgrade reboot \(EX8200 Virtual Chassis\) on page 307](#)

Output Fields When you enter this command, you are provided feedback on the status of your request.

Sample Output

[request system software nonstop-upgrade \(EX4200 Virtual Chassis\)](#)

```
user@switch> request system software nonstop-upgrade
/var/tmp/jinstall-ex-4200-12.1R5.5-domestic-signed.tgz
Chassis ISSU Check Done
ISSU: Validating Image
ISSU: Preparing Backup RE
Installing image on other FPC's along with the backup

Checking pending install on fpc1
Pushing bundle to fpc1
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc1

Checking pending install on fpc2
Pushing bundle to fpc2
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc2

Checking pending install on fpc3
Pushing bundle to fpc3
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc3

Checking pending install on fpc4
Pushing bundle to fpc4
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc4

Checking pending install on fpc5
Pushing bundle to fpc5
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc5

Checking pending install on fpc6
Pushing bundle to fpc6
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc6

Checking pending install on fpc7
Pushing bundle to fpc7
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Completed install on fpc7
```

```

Backup upgrade done
Rebooting Backup RE

Rebooting fpc1
ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot
GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking In-Service-Upgrade status
  Item          Status          Reason
  FPC 0         Online
  FPC 1         Online
  FPC 2         Online (ISSU)
  FPC 3         Online (ISSU)
  FPC 4         Online (ISSU)
  FPC 5         Online (ISSU)
  FPC 6         Online (ISSU)
  FPC 7         Online (ISSU)
Going to install image on master
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
relinquish mastership
ISSU: IDLE

*** FINAL System shutdown message from root@switch ***

System going down IMMEDIATELY

Shutdown NOW!
[pid 9336]

```

request system software nonstop-upgrade (EX6200 Switch)

```

{master}
user@switch> request system software nonstop-upgrade
/var/tmp/jinstall-ex-6200-12.2R5.5-domestic-signed.tgz
Chassis ISSU Check Done
ISSU: Validating Image
ISSU: Preparing Backup RE
Pushing bundle to re0
NOTICE: Validating configuration against
jinstall-ex-6200-12.2R5.5-domestic-signed.tgz.
NOTICE: Use the 'no-validate' option to skip this if desired.
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Backup upgrade done
Rebooting Backup RE

Rebooting re0
ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot

```

```

GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking In-Service-Upgrade status
  Item           Status           Reason
  FPC 0          Online (ISSU)
  FPC 1          Online (ISSU)
  FPC 2          Online (ISSU)
  FPC 3          Online (ISSU)
  FPC 4          Online
  FPC 5          Online
  FPC 6          Online (ISSU)
  FPC 7          Online (ISSU)
  FPC 8          Online (ISSU)
  FPC 9          Online (ISSU)
Going to install image on master
NOTICE: Validating configuration against
jinstall-ex-6200-12.2R5.5-domestic-signed.tgz.
NOTICE: Use the 'no-validate' option to skip this if desired.
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
relinquish mastership
ISSU: IDLE
Trying to relinquish mastership before rebooting...
Resolving mastership...
Complete. The other routing engine becomes the master.

*** FINAL System shutdown message from user@switch ***

System going down IMMEDIATELY

```

request system software nonstop-upgrade reboot (EX8200 Switch)

```

{master}
user@switch> request system software nonstop-upgrade reboot
/var/tmp/jinstall-ex-8200-10.4R1.5-domestic-signed.tgz
Chassis ISSU Check Done
ISSU: Validating Image
ISSU: Preparing Backup RE
Pushing bundle to re1
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Backup upgrade done
Rebooting Backup RE

Rebooting re1
ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot
GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs

```

```

ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking In-Service-Upgrade status
  Item          Status          Reason
  FPC 0         Online (ISSU)
  FPC 2         Offline          Offlined by CLI command
  FPC 3         Online (ISSU)
Resolving mastership...
Complete. The other routing engine becomes the master.
ISSU: RE switchover Done
ISSU: Upgrading Old Master RE
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
ISSU: Old Master Upgrade Done
ISSU: IDLE
Shutdown NOW!
[pid 2635]

*** FINAL System shutdown message from user@switch ***
System going down IMMEDIATELY

```

request system software nonstop-upgrade no-old-master-upgrade (EX8200 Switch)

```

{master}
user@switch> request system software nonstop-upgrade no-old-master-upgrade
/var/tmp/jinstall-ex-8200-10.4R1.5-domestic-signed.tgz
Chassis ISSU Check Done
ISSU: Validating Image
ISSU: Preparing Backup RE
Pushing bundle to re1
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Backup upgrade done
Rebooting Backup RE

Rebooting re1
ISSU: Backup RE Prepare Done
Waiting for Backup RE reboot
GRES operational
Initiating Chassis In-Service-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking In-Service-Upgrade status
  Item          Status          Reason
  FPC 0         Online (ISSU)
  FPC 1         Online (ISSU)
  FPC 2         Online (ISSU)
  FPC 3         Offline          Offlined by CLI command
  FPC 4         Online (ISSU)
  FPC 5         Online (ISSU)
  FPC 6         Online (ISSU)
  FPC 7         Online (ISSU)
Resolving mastership...
Complete. The other routing engine becomes the master.

```

```
ISSU: RE switchover Done
Skipping Old Master Upgrade
ISSU: IDLE
```

request system software nonstop-upgrade reboot (EX8200 Virtual Chassis)

```
{master:9}
user@external-routing-engine> request system software nonstop-upgrade reboot
/var/tmp/jinstall-ex-xre200-11.1-20101130.0-domestic-signed.tgz
Chassis ISSU Check Done
ISSU: Validating Image
ISSU: Preparing LCC Backup REs
ISSU: Preparing Backup RE
Pushing bundle /var/tmp/jinstall-ex-xre200-11.1-20101130.0-domestic-signed.tgz
to member8
-----
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
VC Backup upgrade done
Rebooting VC Backup RE

Rebooting member8
ISSU: Backup RE Prepare Done
Waiting for VC Backup RE reboot
Pushing bundle to member0-backup
Pushing bundle to member1-backup
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately

Rebooting member0-backup
Rebooting LCC [member0-backup]

Rebooting member1-backup
Rebooting LCC [member1-backup]
ISSU: LCC Backup REs Prepare Done
GRES operational
Initiating Chassis Nonstop-Software-Upgrade
Chassis ISSU Started
ISSU: Preparing Daemons
ISSU: Daemons Ready for ISSU
ISSU: Starting Upgrade for FRUs
ISSU: Preparing for Switchover
ISSU: Ready for Switchover
Checking Nonstop-Upgrade status
member0:
-----


| Item  | Status        | Reason |
|-------|---------------|--------|
| FPC 0 | Online (ISSU) |        |
| FPC 1 | Online (ISSU) |        |
| FPC 2 | Online (ISSU) |        |
| FPC 5 | Online (ISSU) |        |


member1:
-----


| Item  | Status        | Reason                 |
|-------|---------------|------------------------|
| FPC 0 | Online (ISSU) |                        |
| FPC 1 | Offline       | Offlined due to config |


```

```

FPC 2      Online (ISSU)
FPC 3      Online (ISSU)
FPC 4      Online (ISSU)
FPC 5      Online (ISSU)
FPC 7      Online (ISSU)

member0:
-----
Item        Status          Reason
FPC 0      Online (ISSU)
FPC 1      Online (ISSU)
FPC 2      Online (ISSU)
FPC 5      Online (ISSU)

member1:
-----
Item        Status          Reason
FPC 0      Online (ISSU)
FPC 1      Offline          Offlined due to config
FPC 2      Online (ISSU)
FPC 3      Online (ISSU)
FPC 4      Online (ISSU)
FPC 5      Online (ISSU)
FPC 7      Online (ISSU)
ISSU: Upgrading Old Master RE
Pushing bundle /var/tmp/incoming-package-8200.tgz to member0-master
Pushing bundle /var/tmp/incoming-package-8200.tgz to member1-master

ISSU: RE switchover Done
WARNING: A reboot is required to install the software
WARNING: Use the 'request system reboot' command immediately
Rebooting ...
shutdown: [pid 2188]
Shutdown NOW!
ISSU: Old Master Upgrade Done
ISSU: IDLE
Shutdown NOW!

*** FINAL System shutdown message from root@ ***
System going down IMMEDIATELY

```


request virtual-chassis device-reachability

Syntax `request virtual-chassis device-reachability test-name name (source-fpc source-fpc-id | source-ip-address source-ip-address) (destination-device device-id | destination-fpc destination-fpc-id | destination-ip-address destination-ip-address)`
`<probe-count count>`
`<probe-interval interval>`
`<probe-pattern pattern>`
`<test-count count>`
`<test-interval interval>`

Release Information Command introduced in Junos OS Release 11.2 for EX Series switches.

Description Run a Virtual Chassis device reachability test. A Virtual Chassis device reachability test sends ping packets from one member of a Virtual Chassis to another member of a Virtual Chassis directly through the Virtual Chassis connections. The receiving Virtual Chassis member sends reply packets to confirm receipt of the ping packets from the sending device. The results of the test immediately provide information that is helpful in verifying connectivity between Virtual Chassis member devices.

Options **test-name *name***—Specify the name of the test. The name can be any single-word character string. Spaces are not allowed.

source-fpc *source-fpc-id*—Specify the FPC that sends the first ping message.

source-ip-address *source-ip-address*—Specify the source IP address that receives the ping message.

destination-device *device-id*—Specify the device in the Virtual Chassis that receives the ping message.

destination-fpc *destination-fpc-id*—Specify the FPC that receives the first ping message.

destination-ip-address *destination-ip-address*—Specify the destination IP address that receives the ping message.

probe-count *count*—(Optional) Specify the number of ping messages to send for the test. The count can be any number from 1 through 10. The default count is 5.

probe-interval *interval*—(Optional) Specify the time in seconds between the ping messages that are sent during the test. The interval can be any number from 1 through 3. The default interval is 1 second.

probe-pattern *pattern*—(Optional) Specify a payload pattern in the ping message. Enter the pattern in hexadecimal format.

test-count *count*—(Optional) Specify the number of times to run the test. The count can be any number from 1 through 3. The default count is 1.

test-interval *interval*—(Optional) Specify the time in seconds between tests when multiple tests are specified. The interval can be any number from 1 through 3. The default interval is 1.

Required Privilege Level system-control

Related Documentation

- [Verifying Connectivity Between Virtual Chassis Member Devices on page 291](#)

Output Fields Table 26 on page 310 lists the output fields for the **request virtual chassis device reachability** command. Output fields are listed in the approximate order in which they appear.

Table 26: request virtual chassis device reachability Output Fields

Field Name	Field Description
Test Name	The name of the test.
Performing Test	The test number.
Session ID	The session ID. This output is always 0 and not useful for Virtual Chassis device reachability tests.
Packets Count/Sent/Received/Sendfail	The number of total ping packets sent, including the total number of ping packets counted (Count), sent (Sent), received (Received), and packets that could not be sent (Sendfail).
Unknown/Timedout/Duplicate packets received	The failed pings, including the number of ping packets that failed for an unknown reason (Unknown), timed out (Timed Out), and the number of duplicate received ping packets (Duplicate packets received).
Round-trip Min/Avg/Max	The average round-trip ping time, including the shortest ping time (Min), the average ping time (Avg), and the maximum ping time (Max).

Sample Output

request virtual-chassis device-reachability test-name member0-to-member2 source-fpc 0 destination-fpc 2

```
user@switch> request virtual-chassis device-reachability test-name member0-to-member2
source-fpc 0 destination-fpc 2
```

Device Reachability Statistics:

Test Name : member0-to-member2

Performing Test: 1

56 bytes from 0: session-id 0 seq-id 0

56 bytes from 0: session-id 0 seq-id 1

56 bytes from 0: session-id 0 seq-id 2

56 bytes from 0: session-id 0 seq-id 3

```
56 bytes from 0: session-id 0 seq-id 4
--- ping statistics ---
Session ID                               : 0
Packets Count/Sent/Received/Sendfail     : 5/5/5/0
Unknown/Timedout/Duplicate packets received : 0/0/0
Round-trip Min/Avg/Max                   : 181/807/3010 usec
```

request virtual-chassis mode

Syntax

```
request virtual-chassis mode
  fabric
  mixed <ieee-clause-82>
  <disable>
  <reboot>
  <all-members>
  <local>
  <member member-id>
```

Release Information Command introduced in Junos OS Release 11.1 for EX Series switches.
 Command introduced in Junos OS Release 13.2X51-D20 for QFX Series devices.
fabric keyword introduced in Junos OS Release 13.2X51-D20 for EX Series switches and QFX Series devices in a Virtual Chassis Fabric (VCF).
 Command introduced in Junos OS Release 13.2X51-D20 for VCF.
ieee-clause-82 mixed-mode option introduced for EX4300 switches mixed with EX4300 multigigabit switches in a Virtual Chassis in Junos OS Release 18.2R1.

Description Configure the mode for a device or multiple devices in a Virtual Chassis or a VCF. The Virtual Chassis mode setting is maintained through reboots even though it is set in operational mode.

Fabric Mode

A device is configured in fabric mode to participate as a member device in a VCF.

Mixed Mode

A device must be configured in mixed mode when it is participating in a Virtual Chassis or a VCF with devices that have differences in how they interoperate. See [“Understanding Mixed EX Series and QFX Series Virtual Chassis” on page 29](#) or *Understanding Mixed Virtual Chassis Fabric* for details on which devices can be interconnected to form a mixed Virtual Chassis or VCF.



NOTE: You do not need to configure mixed mode if the only devices in your Virtual Chassis are the following combinations of switches, which form a non-mixed Virtual Chassis or VCF because the devices can run the same software images:

- Only EX4500 and EX4550 switches in an EX Series Virtual Chassis.
- Only QFX3500 and QFX3600 switches in a QFX Series Virtual Chassis.
- QFX5110 and QFX5100 switches in a QFX5110 Virtual Chassis or QFX5110 VCF.

You must include the **ieee-clause-82** option when setting **mixed** mode on EX4300 switches that are not multigigabit models for those switches to participate in an EX4300 Virtual Chassis with EX4300 multigigabit model switches (EX4300-48MP). Due to platform differences, this mode is required for other EX4300 switches to properly communicate with EX4300 multigigabit switches.

Do not enable the **request virtual-chassis mode mixed** command for a standalone device or for a member switch that is intended to remain in a non-mixed Virtual Chassis or VCF. Enabling this command reduces the maximum scaling numbers for some features on the switch, Virtual Chassis, or VCF.



BEST PRACTICE: For a mixed Virtual Chassis, to avoid potential traffic disruptions and configuration issues, we recommend configuring mixed mode on your device before cabling it into your Virtual Chassis, and rebooting the device to complete this configuration procedure before interconnecting it into the Virtual Chassis. Similarly, for a VCF, to avoid potential traffic disruptions and configuration issues, we recommend configuring the fabric and, if applicable, the mixed mode settings on your device and rebooting it before cabling it into the VCF. You can change the fabric and mixed mode settings manually after a device has been added to a Virtual Chassis or VCF.

If you set only some of the devices in a mixed Virtual Chassis or VCF to mixed mode using this command, the mixed Virtual Chassis or VCF might not form. If you experience this issue, enter the **request virtual-chassis mode mixed all-members** command to set the Virtual Chassis mode to mixed for all devices in the Virtual Chassis or VCF. You then need to reboot the devices that have been set into mixed mode to complete the procedure. The Virtual Chassis or VCF forms after the devices have rebooted.



NOTE: When you do not use this command to set any of the switches in a mixed EX4200 and EX4500 Virtual Chassis to mixed mode, a mixed EX4200 and EX4500 Virtual Chassis forms with one of the switches assuming the master role if the switches are running Junos OS Release 11.4 or later. All other switches in the mixed EX4200 and EX4500 Virtual Chassis are placed into the linecard role. If you experience this behavior, enter the **request virtual-chassis mode mixed all-members** command to set the Virtual Chassis mode to mixed for all switches in the Virtual Chassis. You will then need to reboot the switches to complete the procedure. The Virtual Chassis will form after all of the switches have rebooted.

Options **No options (default)**—Set the Virtual Chassis mode for all members of the Virtual Chassis or VCF.

all-members—(Optional) Set the Virtual Chassis mode for all members of the Virtual Chassis or VCF.

disable—Disable the Virtual Chassis fabric or mixed mode setting if it was previously enabled.

fabric—Set the device into fabric mode so that the device can participate in a VCF.

local—(Optional) Set the Virtual Chassis mode only on the member device where the command is issued.

member *member-id*—(Optional) Set the Virtual Chassis mode on the specified member of the Virtual Chassis or VCF.

mixed <ieee-clause-82> —Set the device into mixed mode so that the device can participate in a mixed Virtual Chassis or mixed VCF. The **ieee-clause-82** mixed-mode option is required when mixing EX4300 switches that are not multigigabit models with EX4300 multigigabit (EX4300-48MP) model switches in an EX4300 Virtual Chassis.

reboot—After applying the mode change specified by the other options, reboot the device automatically.

Required Privilege Level system-control

Related Documentation

- [Understanding Mixed EX Series and QFX Series Virtual Chassis on page 29](#)
- [Understanding Mixed Virtual Chassis Fabric](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
- [Verifying the Virtual Chassis Fabric Mode Settings](#)
- [Verifying the Member ID, Role, and Neighbor Member Connections of a Virtual Chassis Member on page 284](#)

List of Sample Output

[request virtual-chassis mode mixed on page 314](#)
[request virtual-chassis mode fabric mixed reboot on page 314](#)
[request virtual-chassis mode mixed \(with IEEE Clause 82 mode for EX4300 switches mixed with EX4300 multigigabit switches in a Virtual Chassis\) on page 315](#)

Sample Output

`request virtual-chassis mode mixed`

```
user@switch> request virtual-chassis mode mixed
```

Sample Output

`request virtual-chassis mode fabric mixed reboot`


```
user@switch> request virtual-chassis mode fabric mixed reboot
```

Sample Output

request virtual-chassis mode mixed (with IEEE Clause 82 mode for EX4300 switches mixed with EX4300 multigigabit switches in a Virtual Chassis)

```
user@switch> request virtual-chassis mode ieee-clause-82 mixed
```

request virtual-chassis recycle

Syntax	<code>request virtual-chassis recycle member-id <i>member-id</i></code>
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches. Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.
Description	<p>Make a previously used member ID available for reassignment.</p> <p>When you remove a member switch from the Virtual Chassis configuration, the master reserves that member ID. To make the member ID available for reassignment, you must use this command.</p>
	<div> NOTE: You must run this command from the Virtual Chassis member in the master role.</div>
Options	<code>member-id <i>member-id</i></code> —Specify the member ID that you want to make available for reassignment to a different member.
Required Privilege Level	system-control
Related Documentation	<ul style="list-style-type: none">• request virtual-chassis renumber on page 317• Removing or Replacing a Member Switch of a Virtual Chassis Configuration on page 213
List of Sample Output	request virtual-chassis recycle member-id 3 on page 316 request virtual-chassis recycle member-id 1 on page 316

Sample Output

request virtual-chassis recycle member-id 3

```
user@switch> request virtual-chassis recycle member-id 3
```

Sample Output

request virtual-chassis recycle member-id 1

```
user@external-routing-engine> request virtual-chassis recycle member-id 1
```


request virtual-chassis renumber

Syntax `request virtual-chassis renumber member-id old-member-id new-member-id new-member-id`

Release Information Command introduced in Junos OS Release 9.0 for EX Series switches.
Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.

Description Renumber a member of a Virtual Chassis configuration.



NOTE: You must run this command from the Virtual Chassis member in the master role.

Options `member-id old-member-id`—Specify the ID of the member that you wish to renumber.
`new-member-id new-member-id`—Specify an unassigned member ID.

Required Privilege Level system-control

Related Documentation

- [request virtual-chassis recycle on page 316](#)
- [Removing or Replacing a Member Switch of a Virtual Chassis Configuration on page 213](#)

List of Sample Output [request virtual-chassis renumber member-id 5 new-member-id 4 on page 317](#)
[request virtual-chassis renumber member-id 1 new-member-id 0 on page 317](#)

Sample Output

`request virtual-chassis renumber member-id 5 new-member-id 4`

```
user@switch> request virtual-chassis renumber member-id 5 new-member-id 4
```

`request virtual-chassis renumber member-id 1 new-member-id 0`

```
user@external-routing-engine> request virtual-chassis renumber member-id 1 new-member-id 0
```

request virtual-chassis vc-port (Dedicated VCP)

Syntax	request virtual-chassis vc-port set interface <i>vcp-interface-name</i> <member <i>member-id</i>> <disable>
Release Information	Command introduced in Junos OS Release 9.0 for EX Series switches.
Description	<p>Disable or enable a Virtual Chassis port (VCP) on a dedicated VCP.</p> <p>Configure a Gigabit Ethernet link on an EX8200 switch as a VCP in an EX8200 Virtual Chassis. You can use this command only to configure a link between two EX8200 member switches as a VCP link; all other links in an EX8200 Virtual Chassis are automatically VCP links.</p>
Options	<p>interface <i>vcp-interface-name</i>—Name of the interface to enable or disable.</p> <p>If you omit member <i>member-id</i> in an EX4200 Virtual Chassis, EX4500 Virtual Chassis, EX4550 Virtual Chassis, mixed Virtual Chassis, this command defaults to disabling or enabling the dedicated VCP on the switch where the command is issued. The dedicated VCPs are enabled in the factory default configuration.</p> <p>member <i>member-id</i>—(Optional on EX4200, EX4500, and EX4550 switches; required on EX8200 switches) Enable or disable the specified VCP on the specified member of the Virtual Chassis configuration.</p> <p>This option must be specified when using this command to configure a VCP link between two EX8200 switches.</p> <p>disable—(Optional) Disable the specified VCP. If you omit this keyword, the command enables the dedicated VCP.</p>
Required Privilege Level	system-control
Related Documentation	<ul style="list-style-type: none"> • request virtual-chassis vc-port on page 320 (Uplink VCP) • show virtual-chassis vc-port on page 377 • show virtual-chassis vc-port statistics on page 382 • clear virtual-chassis vc-port statistics on page 294 • Understanding Virtual Chassis Components on page 16
List of Sample Output	<p>request virtual-chassis vc-port set interface vcp-0 disable (EX4200 Virtual Chassis) on page 319</p> <p>request virtual-chassis vc-port set fpc-slot 4 pic-slot 0 port 2 member 1 (EX8200 Virtual Chassis) on page 319</p>

[request virtual-chassis vc-port set interface vcp-0 member 3 disable \(EX8200 Virtual Chassis\) on page 319](#)

Sample Output

[request virtual-chassis vc-port set interface vcp-0 disable \(EX4200 Virtual Chassis\)](#)

```
user@switch> request virtual-chassis vc-port set interface vcp-0 disable
```

To check the results of this command, use the [show virtual-chassis vc-port](#) command.

[request virtual-chassis vc-port set fpc-slot 4 pic-slot 0 port 2 member 1 \(EX8200 Virtual Chassis\)](#)

```
user@external-routing-engine>
```

```
request virtual-chassis vc-port set fpc-slot 4 pic-slot 0 port 2 member 1
```

To check the results of this command, use the [show virtual-chassis vc-port](#) command.

[request virtual-chassis vc-port set interface vcp-0 member 3 disable \(EX8200 Virtual Chassis\)](#)

```
user@external-routing-engine> request virtual-chassis vc-port set interface vcp-0 member  
3 disable
```

To check the results of this command, use the [show virtual-chassis vc-port](#) command.

request virtual-chassis vc-port

Syntax request virtual-chassis vc-port [set | delete]
 <fpc-slot *fpc-slot*>
 pic-slot *pic-slot*
 port *port-number*
 <member *member-id*>

Release Information Command introduced in Junos OS Release 9.0 for EX Series switches.
 Option **fpc-slot** introduced in Junos OS Release 10.4 for EX Series switches.
 Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.
 Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).

Description Enable or disable an optical port as a Virtual Chassis port (VCP).

If you omit **member *member-id***, this command defaults to enabling or disabling the uplink VCP or SFP network port configured as a VCP on the switch where the command is issued.

You might experience a temporary traffic disruption immediately after creating or deleting a user-configured VCP in an EX8200 Virtual Chassis.



NOTE: Some EX Series switches have ports that are configured as VCPs by default. You do not need to explicitly configure those ports as VCPs to use them to interconnect the switch into a Virtual Chassis. See [“Understanding Virtual Chassis Components” on page 16](#) for details.

Options **set**—Set a network port as a VCP to convert a network port into a VCP.

delete—Delete the VCP setting on a port to convert a VCP into a network port.

pic-slot *pic-slot*—Number of the PIC slot for the port on the switch.

port *port-number*—Number of the port that is to be enabled or disabled as a VCP.

member *member-id*—(Optional) Enable or disable the specified VCP on the specified member of the Virtual Chassis or VCF.

Required Privilege Level system-control

Related Documentation

- [request virtual-chassis vc-port \(Dedicated VCP\) on page 318](#)
- [show virtual-chassis vc-port on page 377](#)
- [show virtual-chassis vc-port statistics on page 382](#)

- [clear virtual-chassis vc-port statistics on page 294](#)
- *Virtual Chassis Port (VCP) Interface Names in an EX8200 Virtual Chassis*
- [Understanding Virtual Chassis Components on page 16](#)

List of Sample Output [request virtual-chassis vc-port set pic-slot 1 port 0 on page 321](#)
[request virtual-chassis vc-port set pic-slot 1 port 1 member 3 on page 321](#)
[request virtual-chassis vc-port delete pic-slot 1 port 1 member 3 on page 321](#)

Sample Output

[request virtual-chassis vc-port set pic-slot 1 port 0](#)

user@switch> [request virtual-chassis vc-port set pic-slot 1 port 0](#)

To check the results of this command, use the [show virtual-chassis vc-port](#) command.

[request virtual-chassis vc-port set pic-slot 1 port 1 member 3](#)

user@switch> [request virtual-chassis vc-port set pic-slot 1 port 1 member 3](#)

To check the results of this command, use the [show virtual-chassis vc-port](#) command.

[request virtual-chassis vc-port delete pic-slot 1 port 1 member 3](#)

user@switch> [request virtual-chassis vc-port delete pic-slot 1 port 1 member 3](#)

To check the results of this command, use the [show virtual-chassis vc-port](#) command.

show chassis nonstop-upgrade

Syntax	show chassis nonstop-upgrade
Release Information	Command introduced in Junos OS Release 10.4 for EX Series switches. Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.
Description	(EX6200 switches, EX8200 switches, EX8200 Virtual Chassis, QFX3500 and QFX3600 Virtual Chassis, and Virtual Chassis Fabric only) Display the status of the line cards or Virtual Chassis members in the linecard role after the most recent nonstop software upgrade (NSSU). This command must be issued on the master Routing Engine.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • request system software nonstop-upgrade on page 299 • <i>Upgrading Software on an EX6200 or EX8200 Standalone Switch Using Nonstop Software Upgrade (CLI Procedure)</i> • <i>Upgrading Software on a Virtual Chassis and Mixed Virtual Chassis Using Nonstop Software Upgrade</i> • <i>Upgrading Software on a Virtual Chassis Fabric Using Nonstop Software Upgrade</i> • <i>Upgrading Software on an EX8200 Virtual Chassis Using Nonstop Software Upgrade (CLI Procedure)</i>
List of Sample Output	show chassis nonstop-upgrade (EX8200 Switch) on page 323 show chassis nonstop-upgrade (EX8200 Virtual Chassis) on page 323 show chassis nonstop-upgrade (Virtual Chassis Fabric) on page 323
Output Fields	Table 27 on page 322 lists the output fields for the show chassis nonstop-upgrade command. Output fields are listed in the approximate order in which they appear.

Table 27: show chassis nonstop-upgrade Output Fields

Field Name	Field Description
Item	Line card slot number.
Status	State of line card: <ul style="list-style-type: none"> • Error—Line card is in an error state. • Offline—Line card is powered down. • Online—Line card is online and running.
Reason	Reason for the state (if the line card is offline).

Sample Output

show chassis nonstop-upgrade (EX8200 Switch)

```
user@switch> show chassis nonstop-upgrade
```

Item	Status	Reason
FPC 0	Online	
FPC 1	Online	
FPC 2	Online	
FPC 3	Offline	Offlined by CLI command
FPC 4	Online	
FPC 5	Online	
FPC 6	Online	
FPC 7	Online	

show chassis nonstop-upgrade (EX8200 Virtual Chassis)

```
user@external-routing-engine> show chassis nonstop-upgrade
member0:
```

Item	Status	Reason
FPC 0	Online	
FPC 1	Online	
FPC 2	Online	
FPC 5	Online	

```
member1:
```

Item	Status	Reason
FPC 0	Online	
FPC 1	Offline	Offlined due to config
FPC 2	Online	
FPC 3	Online	
FPC 4	Online	
FPC 5	Online	
FPC 7	Online	

show chassis nonstop-upgrade (Virtual Chassis Fabric)

Item	Status	Reason
FPC 0	Online	
FPC 1	Online	
FPC 2	Online	
FPC 3	Online	
FPC 4	Online	
FPC 5	Online	

show chassis pic-mode

Syntax `show chassis pic-mode`
`<all-members>`
`<local>`
`<member member-id>`

Release Information Command introduced in Junos OS Release 11.1 for EX Series switches.

Description Display the PIC mode on an EX4500 switch.

The PIC mode must be set to **virtual-chassis** if the EX4500 switch is cabled into a Virtual Chassis using the dedicated Virtual Chassis ports (VCPs) on the Virtual Chassis module.



NOTE: This PIC mode setting is not used on an EX4550 switch.

The default PIC mode setting is **virtual-chassis**.

Use the **request chassis pic-mode** command to configure the PIC mode setting.

Options **none**—Display the PIC mode on the member switch where the command is issued.

all-members—(Optional) Display the PIC mode for all members of the Virtual Chassis configuration.

local—(Optional) Display the PIC mode on the member switch where the command is issued.

member *member-id*—(Optional) Display the PIC mode of the specified member of the Virtual Chassis configuration.

Required Privilege Level view

Related Documentation

- [request chassis pic-mode on page 296](#)
- [Resetting the EX4500 Switch to Run as a Standalone Switch \(CLI Procedure\) on page 243](#)
- [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)

List of Sample Output [show chassis pic-mode on page 325](#)

Sample Output

show chassis pic-mode

```
user@switch> show chassis pic-mode
```

```
fpc0:
```

```
-----  
Pic Mode: Intraconnect
```

show system uptime

- List of Syntax**
- Syntax on page 326
 - Syntax (EX Series Switches) on page 326
 - Syntax (QFX Series) on page 326
 - Syntax (TX Matrix Router) on page 326
 - Syntax (TX Matrix Plus Router) on page 326
 - Syntax (MX Series Router) on page 326
 - Syntax (Junos OS Evolved) on page 326

Syntax show system uptime

Syntax (EX Series Switches)

```
show system uptime
<all-members>
<local>
<member member-id>
```

Syntax (QFX Series)

```
show system uptime
<director-group name>
<infrastructure name>
<interconnect-device name>
<node-group name>
```

Syntax (TX Matrix Router)

```
show system uptime
<all-chassis | all-lcc | lcc number | scc>
```

Syntax (TX Matrix Plus Router)

```
show system uptime
<detail>
<all-chassis | all-lcc | lcc number | sfc number>
```

Syntax (MX Series Router)

```
show system uptime
<all-members>
<invoke-on>
<local>
<member member-id>
```

Syntax (Junos OS Evolved)

```
show system uptime
<node node-name>
```

Release Information

Command introduced before Junos OS Release 7.4.

Command introduced in Junos OS Release 9.0 for EX Series switches.

sfc option introduced for the TX Matrix Plus router in JUNOS Release 9.6.

Command introduced in Junos OS Release 11.1 for the QFX Series.

Command introduced in Junos OS Release 14.1X53-D20 for the OCX Series.
node option introduced in Junos OS Evolved Release 18.3R1.

Description Display the current time and information about how long the router or switch, router or switch software, and routing protocols have been running.



NOTE: Time values computed from differences in timestamps can vary due to the insertion or deletion of leap-seconds between them.

Options **none**—Show time since the system rebooted and processes started.

all-chassis—(TX Matrix routers and TX Matrix Plus routers only) (Optional) Show time since the system rebooted and processes started on all the routers in the chassis.

all-lcc—(TX Matrix routers and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show time since the system rebooted and processes started for all T640 routers (or line-card chassis) connected to the TX Matrix router. On a TX Matrix Plus router, show time since the system rebooted and processes started for all connected T1600 or T4000 LCCs.

all-members—(EX4200 switches and MX Series routers only) (Optional) Show time since the system rebooted and processes started on all members of the Virtual Chassis configuration.

director-group *name*—(QFabric systems only) (Optional) Show time since the system rebooted and processes started on the Director group.

infrastructure *name*—(QFabric systems only) (Optional) Show time since the system rebooted and processes started on the fabric control Routing Engine and fabric manager Routing Engine.

interconnect-device *name*—(QFabric systems only) (Optional) Show time since the system rebooted and processes started on the Interconnect device.

invoke-on—(MX Series routers only) (Optional) Display the time since the system rebooted and processes started on the master Routing Engine, backup Routing Engine, or both, on a router with two Routing Engines.

lcc *number*—(TX Matrix routers and TX Matrix Plus routers only) (Optional) On a TX Matrix router, show time since the system rebooted and processes started for a specific T640 router that is connected to the TX Matrix router. On a TX Matrix Plus router, show time since the system rebooted and processes started for a specific router that is connected to the TX Matrix Plus router.

Replace *number* with the following values depending on the LCC configuration:

- 0 through 3, when T640 routers are connected to a TX Matrix router in a routing matrix.
- 0 through 3, when T1600 routers are connected to a TX Matrix Plus router in a routing matrix.
- 0 through 7, when T1600 routers are connected to a TX Matrix Plus router with 3D SIBs in a routing matrix.
- 0, 2, 4, or 6, when T4000 routers are connected to a TX Matrix Plus router with 3D SIBs in a routing matrix.

local—(EX4200 switches and MX Series routers only) (Optional) Show time since the system rebooted and processes started on the local Virtual Chassis member.

member *member-id*—(EX4200 switches and MX Series routers only) (Optional) Show time since the system rebooted and processes started on the specified member of the Virtual Chassis configuration. For EX4200 switches, replace *member-id* with a value from 0 through 9. For an MX Series Virtual Chassis, replace *member-id* with a value of 0 or 1.

node *node-name*—(Junos OS Evolved only) (Optional) Display uptime information for the specified node. When **node** option is not used, display uptime information for entire system. From the system's point of view, the system booted time is the time when the system was assembled and is available in `/var/run/system_boot_time`.

node-group *name*—(QFabric systems only) (Optional) Show time since the system rebooted and processes started on the Node group.

scc—(TX Matrix routers only) (Optional) Show time since the system rebooted and processes started for the TX Matrix router (or switch-card chassis).

sfc *number*—(TX Matrix Plus routers only) (Optional) Show time since the system rebooted and processes started for the TX Matrix Plus router. Replace *number* with 0.

Additional Information By default, when you issue the **show system uptime** command on the master Routing Engine of a TX Matrix router or a TX Matrix Plus router, the command is broadcast to all the master Routing Engines of the LCCs connected to it in the routing matrix. Likewise, if you issue the same command on the backup Routing Engine of a TX Matrix or a TX Matrix Plus router, the command is broadcast to all backup Routing Engines of the LCCs that are connected to it in the routing matrix.

Required Privilege Level view

Related Documentation

- *10-Gigabit Ethernet LAN/WAN PIC with XFP (T640 Router)*

- [Routing Matrix with a TX Matrix Plus Router Solutions Page](#)

List of Sample Output [show system uptime on page 329](#)
[show system uptime \(for Junos OS Evolved without node option\) on page 330](#)
[show system uptime node \(for Junos OS Evolved\) on page 330](#)
[show system uptime all-lcc \(TX Matrix Router\) on page 330](#)
[show system uptime all-lcc \(TX Matrix Plus Router\) on page 330](#)
[show system uptime \(EX Series\) on page 331](#)
[show system uptime \(QFX Series\) on page 331](#)

Output Fields [Table 28 on page 329](#) describes the output fields for the **show system uptime** command. Output fields are listed in the approximate order in which they appear.

Table 28: show system uptime Output Fields

Field Name	Field Description
System booted	(Only for Junos OS Evolved when node option is not used) Time system was last booted. From the system's point of view, the system booted time is the time when the system was assembled and is available in <code>/var/run/system_boot_time</code> .
System-wide users	(Only for Junos OS Evolved when node option is not used) Number of system-wide users.
Current time	Current system time in UTC.
Time Source	Reference time source that the system is locked to.
System booted	Date and time when the Routing Engine on the router or switch was last booted and how long it has been running.
Protocols started	Date and time when the routing protocols were last started and how long they have been running.
Last configured	Date and time when a configuration was last committed. Also shows the name of the user who issued the last commit command.
time and up	Current time, in the local time zone, and how long the router or switch has been operational.
users	Number of users logged in to the router or switch.
load averages	Load averages for the last 1 minute, 5 minutes, and 15 minutes.

Sample Output

show system uptime

```
user@host> show system uptime
Current time:      1998-10-13 19:45:47 UTC
Time Source:      NTP CLOCK
System booted:    1998-10-12 20:51:41 UTC (22:54:06 ago)
Protocols started: 1998-10-13 19:33:45 UTC (00:12:02 ago)
```

```
Last configured: 1998-10-13 19:33:45 UTC (00:12:02 ago) by abc
12:45PM up 22:54, 2 users, load averages: 0.07, 0.02, 0.01
```

show system uptime (for Junos OS Evolved without node option)

```
user@host> show system uptime

root@evovptxq_RE0-re0> show system uptime
System booted: 2017-05-10 15:45:57 PDT (6d 00:22 ago)
System-wide users: 1
```

show system uptime node (for Junos OS Evolved)

```
user@host> show system uptime node re0

Current time: 2017-05-16 16:13:18 PDT
Node booted: 2017-05-10 15:45:29 PDT (6d 00:27 ago)
Last configured: 2017-05-10 15:31:46 PDT (6d 00:41 ago) by root
16:13:18 up 6 days, 27 min, 1 user, load averages: 2.69, 2.58, 2.57
```

show system uptime all-lcc (TX Matrix Router)

```
user@host> show system uptime all-lcc

lcc0-re0:
-----
Current time: 2004-09-13 09:55:35 PDT
Time Source: LOCAL CLOCK
System booted: 2004-09-13 03:13:55 PDT (06:41:40 ago)
Last configured: 2004-09-13 03:17:48 PDT (06:37:47 ago) by root
9:55AM PDT up 6:42, 1 user, load averages: 0.02, 0.03, 0.00
lcc2-re0:
-----
Current time: 2004-09-13 09:55:35 PDT
Time Source: LOCAL CLOCK
System booted: 2004-09-12 03:23:43 PDT (1d 06:31 ago)
Last configured: 2004-09-13 03:05:36 PDT (06:49:59 ago) by root
9:55AM PDT up 1 day, 6:32, 1 user, load averages: 0.02, 0.01, 0.00
```

show system uptime all-lcc (TX Matrix Plus Router)

```
user@host> show system uptime all-lcc

sfc0-re0:
-----
Current time: 2009-05-25 00:24:30 PDT
Time Source: NTP CLOCK
System booted: 2009-05-24 06:39:33 PDT (17:44:57 ago)
Protocols started: 2009-05-24 06:40:30 PDT (17:44:00 ago)
Last configured: 2009-05-24 06:33:27 PDT (17:51:03 ago) by user1
12:24AM up 17:45, 2 users, load averages: 0.07, 0.05, 0.01

lcc0-re0:
-----
Current time: 2009-05-25 00:24:30 PDT
Time Source: NTP CLOCK
System booted: 2009-05-24 06:39:46 PDT (17:44:44 ago)
error: the routing subsystem is not running
```

```
Last configured: 2009-05-24 06:40:47 PDT (17:43:43 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

```
lcc1-re0:
```

```
-----
Current time: 2009-05-25 00:24:30 PDT
Time Source: NTP CLOCK
System booted: 2009-05-24 06:39:38 PDT (17:44:52 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:18 PDT (17:44:12 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

```
lcc2-re0:
```

```
-----
Current time: 2009-05-25 00:24:30 PDT
Time Source: NTP CLOCK
System booted: 2009-05-24 06:39:48 PDT (17:44:42 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:44 PDT (17:43:46 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

```
lcc3-re0:
```

```
-----
Current time: 2009-05-25 00:24:30 PDT
Time Source: NTP CLOCK
System booted: 2009-05-24 06:39:44 PDT (17:44:46 ago)
error: the routing subsystem is not running
Last configured: 2009-05-24 06:40:08 PDT (17:44:22 ago) by root
12:24AM up 17:45, 0 users, load averages: 0.00, 0.00, 0.00
```

show system uptime (EX Series)

```
user@switch> show system uptime
```

```
Current time: 2014-03-12 16:39:56 UTC
Time Source: NTP CLOCK
System booted: 2014-03-12 14:58:05 UTC (01:41:51 ago)
Protocols started: 2014-03-12 14:59:48 UTC (01:40:08 ago)
Last configured: 2014-03-12 14:58:58 UTC (01:40:58 ago) by root
4:39PM up 1:42, 4 users, load averages: 0.02, 0.02, 0.00
```

show system uptime (QFX Series)

```
user@switch> show system uptime
```

```
Current time: 2010-08-27 03:12:30 PDT
Time Source: NTP CLOCK
System booted: 2010-08-13 17:11:54 PDT (1w6d 10:00 ago)
Protocols started: 2010-08-13 17:13:56 PDT (1w6d 09:58 ago)
Last configured: 2010-08-26 05:54:00 PDT (21:18:30 ago) by user
3:12AM up 13 days, 10:01, 3 users, load averages: 0.00, 0.00, 0.00
```

show virtual-chassis active-topology

Syntax	<pre>show virtual-chassis active-topology <all-members> <local> <member <i>member-id</i>></pre>
Release Information	<p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the active topology of the Virtual Chassis or VCF with next-hop reachability information.
Options	<p>none—Display the active topology of the member switch where the command is issued.</p> <p>all-members—(Optional) Display the active topology of all members of the Virtual Chassis or VCF.</p> <p>local—(Optional) Display the active topology of the switch or external Routing Engine on which this command is entered.</p> <p>member <i>member-id</i>—(Optional) Display the active topology of the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287
List of Sample Output	<p>show virtual-chassis active-topology (EX4200 Virtual Chassis) on page 333</p> <p>show virtual-chassis active-topology (EX8200 Virtual Chassis) on page 333</p> <p>show virtual-chassis active-topology (Virtual Chassis Fabric) on page 334</p>
Output Fields	Table 29 on page 332 lists the output fields for the show virtual-chassis active-topology command. Output fields are listed in the approximate order in which they appear.

Table 29: show virtual-chassis active-topology Output Fields

Field Name	Field Description
Destination ID	Specifies the member ID of the destination.
Next-hop	<p>Specifies the member ID and Virtual Chassis port (VCP) of the next hop to which packets for the destination ID are forwarded.</p> <p>The next hop can be more than one device in a VCF.</p>

Sample Output

show virtual-chassis active-topology (EX4200 Virtual Chassis)

```
user@switch> show virtual-chassis active-topology
```

```

1                1(vcp-1)

2                1(vcp-1)

3                1(vcp-1)

4                1(vcp-1)

5                8(vcp-0) 1(vcp-1)

6                8(vcp-0)

7                8(vcp-0)

8                8(vcp-0)
```

show virtual-chassis active-topology (EX8200 Virtual Chassis)

```
user@external-routing-engine> show virtual-chassis active-topology
```

```
member0:
```

Destination ID	Next-hop
1	1(vcp-4/0/4.32768)
8	8(vcp-0/0.32768)
9	8(vcp-0/0.32768)

```
member1:
```

Destination ID	Next-hop
0	0(vcp-3/0/4.32768)
8	8(vcp-0/0.32768)

9	8(vcp-0/0.32768)
member8:	
Destination ID	Next-hop
0	0(vcp-1/1.32768)
1	1(vcp-1/2.32768)
9	9(vcp-2/1.32768)
member9:	
Destination ID	Next-hop
0	8(vcp-1/2.32768)
1	8(vcp-1/2.32768)
8	8(vcp-1/2.32768)

show virtual-chassis active-topology (Virtual Chassis Fabric)

user@device> show virtual-chassis active-topology

fpc0:	
Destination ID	Next-hop
1 6(vcp-255/0/1.32768)	4(vcp-255/0/2.32768) 5(vcp-255/0/3.32768)
2 6(vcp-255/0/1.32768)	4(vcp-255/0/2.32768) 5(vcp-255/0/3.32768)
3 6(vcp-255/0/1.32768)	4(vcp-255/0/2.32768) 5(vcp-255/0/3.32768)
4	4(vcp-255/0/2.32768)
5	5(vcp-255/0/3.32768)
6	6(vcp-255/0/1.32768)
fpc1:	
Destination ID	Next-hop
0 6(vcp-255/0/1.32768)	4(vcp-255/0/2.32768) 5(vcp-255/0/3.32768)
2 6(vcp-255/0/1.32768)	4(vcp-255/0/2.32768) 5(vcp-255/0/3.32768)
3 6(vcp-255/0/1.32768)	4(vcp-255/0/2.32768) 5(vcp-255/0/3.32768)
4	4(vcp-255/0/2.32768)

```

5                               5(vcp-255/0/3.32768)
6                               6(vcp-255/0/1.32768)
fpc2:
-----
Destination ID      Next-hop
0                   4(vcp-255/0/2.32768)  5(vcp-255/0/3.32768)
6(vcp-255/0/1.32768)
1                   4(vcp-255/0/2.32768)  5(vcp-255/0/3.32768)
6(vcp-255/0/1.32768)
3                   4(vcp-255/0/2.32768)  5(vcp-255/0/3.32768)
6(vcp-255/0/1.32768)
4                   4(vcp-255/0/2.32768)
5                   5(vcp-255/0/3.32768)
6                   6(vcp-255/0/1.32768)
fpc3:
-----
Destination ID      Next-hop
0                   4(vcp-255/0/2.32768)  5(vcp-255/0/3.32768)
6(vcp-255/0/1.32768)
1                   4(vcp-255/0/2.32768)  5(vcp-255/0/3.32768)
6(vcp-255/0/1.32768)
2                   4(vcp-255/0/2.32768)  5(vcp-255/0/3.32768)
6(vcp-255/0/1.32768)
4                   4(vcp-255/0/2.32768)
5                   5(vcp-255/0/3.32768)
6                   6(vcp-255/0/1.32768)
fpc4:
-----
Destination ID      Next-hop
0                   0(vcp-255/0/48.32768)
1                   1(vcp-255/0/49.32768)
2                   2(vcp-255/0/50.32768)
3                   3(vcp-255/0/51.32768)
5                   3(vcp-255/0/51.32768)  2(vcp-255/0/50.32768)
0(vcp-255/0/48.32768) 1(vcp-255/0/49.32768)
6                   3(vcp-255/0/51.32768)  2(vcp-255/0/50.32768)
0(vcp-255/0/48.32768) 1(vcp-255/0/49.32768)

```

fpc5:

Destination ID	Next-hop	
0	0(vcp-255/0/48.32768)	
1	1(vcp-255/0/49.32768)	
2	2(vcp-255/0/50.32768)	
3	3(vcp-255/0/51.32768)	
4	3(vcp-255/0/51.32768)	2(vcp-255/0/50.32768)
0(vcp-255/0/48.32768)	1(vcp-255/0/49.32768)	
6	3(vcp-255/0/51.32768)	2(vcp-255/0/50.32768)
0(vcp-255/0/48.32768)	1(vcp-255/0/49.32768)	

fpc6:

Destination ID	Next-hop	
0	0(vcp-255/0/0.32768)	
1	1(vcp-255/0/1.32768)	
2	2(vcp-255/0/2.32768)	
3	3(vcp-255/0/3.32768)	
4	3(vcp-255/0/3.32768)	2(vcp-255/0/2.32768)
0(vcp-255/0/0.32768)	1(vcp-255/0/1.32768)	
5	3(vcp-255/0/3.32768)	2(vcp-255/0/2.32768)
0(vcp-255/0/0.32768)	1(vcp-255/0/1.32768)	

show virtual-chassis device-topology

Syntax	<pre>show virtual-chassis device-topology <all-members> <local> <member <i>member-id</i>></pre>
Release Information	<p>Command introduced in Junos OS Release 10.4 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the device topology—the member and system IDs, the VCP numbers, and device status—for all hardware devices in the Virtual Chassis or VCF.
Options	<p>none—Display the device topology for all members of the Virtual Chassis or VCF.</p> <p>all-members—(Optional) Display the device topology for all members of the Virtual Chassis or VCF.</p> <p>local—(Optional) Display the device topology for the switch or external Routing Engine on which this command is entered.</p> <p>member <i>member-id</i>—(Optional) Display the device topology for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Understanding Virtual Chassis Port Link Aggregation on page 41 • Understanding EX8200 Virtual Chassis Topologies
Output Fields	Table 30 on page 337 lists the output fields for the show virtual-chassis device-topology command. Output fields are listed in the approximate order in which they appear.

Table 30: show virtual-chassis device-topology Output Fields

Field Name	Field Description
Member	Assigned member ID.
Device	<p>Assigned device ID.</p> <p>For an EX8200 Virtual Chassis, the member ID and the device ID are always identical.</p>

Table 30: show virtual-chassis device-topology Output Fields (continued)

Field Name	Field Description
Status	The status of the device within the Virtual Chassis or VCF. Outputs include: <ul style="list-style-type: none"> Prsnt—Device is currently connected to and participating in the Virtual Chassis or VCF. NotPrsnt—Device is assigned but is not currently connected.
System ID	System ID of the device. The system ID of the device is the device's MAC address.
Member (Neighbor List)	Assigned member ID of the neighbor device.
Device (Neighbor List)	Assigned device ID of the neighbor device. For an EX8200 Virtual Chassis, the member ID and the device ID are always identical.
Interface (Neighbor List)	The interface connecting the device to the neighbor.

Sample Output

show virtual-chassis device-topology

```
user@switch> show virtual-chassis device-topology
```

```
member0:
```

```
-----
                        Neighbor List
Member  Device  Status  System ID      Member  Device  Interface
  0      0      Prsnt   0021.59f7.d000    8        8      vcp-0/0
                        1        1      vcp-4/0/1
  1      1      Prsnt   0026.888d.6800    8        8      vcp-0/0
                        9        9      vcp-0/1
                        0        0      vcp-3/0/4
  8      8      Prsnt   0000.4a75.9b7c    9        9      vcp-1/0
                        0        0      vcp-1/1
                        1        1      vcp-1/2
  9      9      Prsnt   0000.73e9.9a57    8        8      vcp-1/0
                        1        1      vcp-1/1
```

```
member1:
```

```
-----
                        Neighbor List
Member  Device  Status  System ID      Member  Device  Interface
  0      0      Prsnt   0021.59f7.d000    8        8      vcp-0/0
                        1        1      vcp-4/0/1
  1      1      Prsnt   0026.888d.6800    8        8      vcp-0/0
                        9        9      vcp-0/1
                        0        0      vcp-3/0/4
  8      8      Prsnt   0000.4a75.9b7c    9        9      vcp-1/0
                        0        0      vcp-1/1
```

9	9	Prsnt	0000.73e9.9a57	1	1	vcp-1/2
				8	8	vcp-1/0
				1	1	vcp-1/1
member8:						

Neighbor List						
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	0021.59f7.d000	8	8	vcp-0/0
				1	1	vcp-4/0/1
1	1	Prsnt	0026.888d.6800	8	8	vcp-0/0
				9	9	vcp-0/1
				0	0	vcp-3/0/4
8	8	Prsnt	0000.4a75.9b7c	9	9	vcp-1/0
				0	0	vcp-1/1
				1	1	vcp-1/2
9	9	Prsnt	0000.73e9.9a57	8	8	vcp-1/0
				1	1	vcp-1/1
member9:						

Neighbor List						
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	0021.59f7.d000	8	8	vcp-0/0
				1	1	vcp-4/0/1
1	1	Prsnt	0026.888d.6800	8	8	vcp-0/0
				9	9	vcp-0/1
				0	0	vcp-3/0/4
8	8	Prsnt	0000.4a75.9b7c	9	9	vcp-1/0
				0	0	vcp-1/1
				1	1	vcp-1/2
9	9	Prsnt	0000.73e9.9a57	8	8	vcp-1/0
				1	1	vcp-1/1

show virtual-chassis device-topology (Virtual Chassis Fabric)

user@device> show virtual-chassis device-topology

fpc0:						

Neighbor List						
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50

6	6	Prsnt	100e.7eb6.3b00	1	1	vcp-255/0/49
				0	0	vcp-255/0/48
				3	3	vcp-255/0/3
				2	2	vcp-255/0/2
				0	0	vcp-255/0/0
				1	1	vcp-255/0/1
fpc1:						

				Neighbor List		
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				1	1	vcp-255/0/49
				0	0	vcp-255/0/48
6	6	Prsnt	100e.7eb6.3b00	3	3	vcp-255/0/3
				2	2	vcp-255/0/2
				0	0	vcp-255/0/0
				1	1	vcp-255/0/1
fpc2:						

				Neighbor List		
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				1	1	vcp-255/0/49
				0	0	vcp-255/0/48

6	6	Prsnt	100e.7eb6.3b00	3	3	vcp-255/0/3
				2	2	vcp-255/0/2
				0	0	vcp-255/0/0
				1	1	vcp-255/0/1

fpc3:

				Neighbor List		
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				1	1	vcp-255/0/49
				0	0	vcp-255/0/48
6	6	Prsnt	100e.7eb6.3b00	3	3	vcp-255/0/3
				2	2	vcp-255/0/2
				0	0	vcp-255/0/0
				1	1	vcp-255/0/1

fpc4:

				Neighbor List		
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				1	1	vcp-255/0/49
				0	0	vcp-255/0/48
6	6	Prsnt	100e.7eb6.3b00	3	3	vcp-255/0/3
				2	2	vcp-255/0/2

```

0      0      vcp-255/0/0
1      1      vcp-255/0/1

```

fpc5:

				Neighbor List		
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				1	1	vcp-255/0/49
				0	0	vcp-255/0/48
6	6	Prsnt	100e.7eb6.3b00	3	3	vcp-255/0/3
				2	2	vcp-255/0/2
				0	0	vcp-255/0/0
				1	1	vcp-255/0/1

fpc6:

				Neighbor List		
Member	Device	Status	System ID	Member	Device	Interface
0	0	Prsnt	100e.7eb6.a900	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
1	1	Prsnt	100e.7eb8.3a40	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
2	2	Prsnt	100e.7eb5.d700	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
3	3	Prsnt	100e.7eb5.c440	4	4	vcp-255/0/2
				5	5	vcp-255/0/3
				6	6	vcp-255/0/1
4	4	Prsnt	100e.7eb5.7e40	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				0	0	vcp-255/0/48
				1	1	vcp-255/0/49
5	5	Prsnt	100e.7eb5.80c0	3	3	vcp-255/0/51
				2	2	vcp-255/0/50
				1	1	vcp-255/0/49
				0	0	vcp-255/0/48
6	6	Prsnt	100e.7eb6.3b00	3	3	vcp-255/0/3
				2	2	vcp-255/0/2
				0	0	vcp-255/0/0
				1	1	vcp-255/0/1

show virtual-chassis protocol adjacency

Syntax	<pre>show virtual-chassis protocol adjacency <brief detail extensive> <all-members> <local> <member <i>member-id</i>> <system-id></pre>
Release Information	<p>Command introduced in Junos OS Release 10.4 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the Virtual Chassis Control Protocol (VCCP) adjacency statistics in the Virtual Chassis or VCF for all hardware devices.
Options	<p>none—Display VCCP adjacency statistics in brief form for all members of the Virtual Chassis or VCF.</p> <p>brief detail extensive—(Optional) Display the specified level of output. Using the brief option is equivalent to entering the command with no options (the default). The detail and extensive options provide identical displays.</p> <p>all-members—(Optional) Display VCCP adjacency statistics in brief form for all members of the Virtual Chassis or VCF.</p> <p>local—(Optional) Display VCCP adjacency statistics for the switch or external Routing Engine on which this command is entered.</p> <p>member <i>member-id</i>—(Optional) Display VCCP adjacency statistics for the specified member of the Virtual Chassis or VCF.</p> <p>system-id—(Optional) Display VCCP adjacency statistics for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Understanding Virtual Chassis Port Link Aggregation on page 41 • Understanding the Virtual Chassis Control Protocol in an EX8200 Virtual Chassis
List of Sample Output	<p>show virtual-chassis protocol adjacency on page 345</p> <p>show virtual-chassis protocol adjacency detail on page 346</p>
Output Fields	Table 31 on page 345 lists the output fields for the show virtual-chassis protocol adjacency command. Output fields are listed in the approximate order in which they appear.

Table 31: show virtual-chassis protocol adjacency Output Fields

Field Name	Field Description	Level of Output
Interface	Name of the Virtual Chassis port (VCP) interface.	All levels
System	The MAC address of the device on the receiving side of the VCP link.	All levels
State	State of the link. Outputs include: <ul style="list-style-type: none"> • Up—The link is up. • Down—The link is down. • New—The link is new. • One-way—The link is transmitting traffic in one direction. • Initializing—The link is initializing. • Rejected—The link is rejected. 	All levels
Hold, Expires in	Remaining holdtime of the adjacency.	All levels
Priority	Priority to become the designated intermediary system.	detail
Up/Down Transitions	Count of adjacency status transition changes from up to down or down to up.	detail
Last transition	Time of the last up/down transition.	detail

Sample Output

show virtual-chassis protocol adjacency

```
user@switch> show virtual-chassis protocol adjacency
```

```
member0:
```

```
-----
Interface      System      State      Hold (secs)
vcp-0/0.32768  0000.4a75.9b7c Up          57
vcp-0/1.32768  0000.4a75.9b7c Up          59
vcp-4/0/1.32768 0026.888d.6800 Up          57
```

```
member1:
```

```
-----
Interface      System      State      Hold (secs)
vcp-0/0.32768  0000.4a75.9b7c Up          58
vcp-0/1.32768  0000.73e9.9a57 Up          59
vcp-3/0/4.32768 0021.59f7.d000 Up          58
```

```
member8:
```

```
-----
Interface      System      State      Hold (secs)
vcp-1/0.32768  0000.73e9.9a57 Up          58
vcp-1/1.32768  0021.59f7.d000 Up          58
vcp-1/2.32768  0026.888d.6800 Up          59
vcp-2/0.32768  0021.59f7.d000 Up          59
```

```
member9:
```

Interface	System	State	Hold (secs)
vcp-1/0.32768	0000.4a75.9b7c	Up	58
vcp-1/1.32768	0026.888d.6800	Up	59

show virtual-chassis protocol adjacency detail

```
user@switch> show virtual-chassis protocol adjacency detail
```

```
member0:
```

```
-----
0000.4a75.9b7c
  interface-name: vcp-0/0.32768, State: Up, Expires in 57 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:37 ago

0000.4a75.9b7c
  interface-name: vcp-0/1.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:37 ago

0026.888d.6800
  interface-name: vcp-4/0/1.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 22:06:39 ago
```

```
member1:
```

```
-----
0000.4a75.9b7c
  interface-name: vcp-0/0.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:38 ago

0000.73e9.9a57
  interface-name: vcp-0/1.32768, State: Up, Expires in 58 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 22:17:36 ago

0021.59f7.d000
  interface-name: vcp-3/0/4.32768, State: Up, Expires in 58 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 22:06:39 ago
```

```
member8:
```

```
-----
0000.73e9.9a57
  interface-name: vcp-1/0.32768, State: Up, Expires in 58 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:38 ago

0021.59f7.d000
  interface-name: vcp-1/1.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:38 ago

0026.888d.6800
  interface-name: vcp-1/2.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:38 ago

0021.59f7.d000
  interface-name: vcp-2/0.32768, State: Up, Expires in 57 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:38 ago
```

```
member9:
```

```
0000.4a75.9b7c
  interface-name: vcp-1/0.32768, State: Up, Expires in 59 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 19:26:38 ago

0026.888d.6800
  interface-name: vcp-1/1.32768, State: Up, Expires in 58 secs
  Priority: 0, Up/Down transitions: 1, Last transition: 22:17:36 ago
```

show virtual-chassis protocol database

Syntax	<pre>show virtual-chassis protocol database <brief detail extensive> <all-members> <local> <member <i>member-id</i>></pre>
Release Information	<p>Command introduced in Junos OS Release 10.4 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the Virtual Chassis Control Protocol (VCCP) database statistics for all hardware devices within the Virtual Chassis or VCF.
Options	<p>none—Display VCCP database statistics in brief form for all members of the Virtual Chassis or VCF.</p> <p>brief detail extensive—(Optional) Display the specified level of output. Using the brief option is equivalent to entering the command with no options (the default). The detail option provides more output than the brief option. The extensive option provides all output and is most useful for customer support personnel.</p> <p>all-members—(Optional) Display VCCP database statistics in brief form for all members of the Virtual Chassis or VCF.</p> <p>local—(Optional) Display VCCP database statistics for the switch or external Routing Engine on which this command is entered.</p> <p>member <i>member-id</i>—(Optional) Display VCCP database statistics for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Understanding the Virtual Chassis Control Protocol in an EX8200 Virtual Chassis • Understanding Virtual Chassis Components on page 16
List of Sample Output	<p>show virtual-chassis protocol database on page 349</p> <p>show virtual-chassis protocol database detail on page 350</p>
Output Fields	Table 32 on page 349 lists the output fields for the show virtual-chassis protocol database command. Output fields are listed in the approximate order in which they appear.

Table 32: show virtual-chassis protocol database Output Fields

Field Name	Field Description	Level of Output
LSP ID	Link-state protocol (LSP) data unit identifier.	All levels
Sequence	Sequence number of the LSP.	All levels
Checksum	Checksum value of the LSP.	All levels
Lifetime	Remaining lifetime of the LSP, in seconds.	All levels
Neighbor	MAC address of the neighbor on the advertising system.	detail
Interface	Virtual Chassis port (VCP) interface name.	detail
Metric	Metric of the prefix or neighbor.	detail

The **extensive** output was omitted from this list. The **extensive** output is useful for customer support personnel only.

Sample Output

show virtual-chassis protocol database

```
user@switch> show virtual-chassis protocol database
```

```
member0:
```

```
-----
LSP ID          Sequence Checksum Lifetime
0000.4a75.9b7c.00-00  0x1dd80  0xc2e3   116
0000.73e9.9a57.00-00  0xf361   0x27e8   113
0021.59f7.d000.00-00  0x16882  0x3993   118
0026.888d.6800.00-00  0x1691f  0x82b7   116
  4 LSPs
```

```
member1:
```

```
-----
LSP ID          Sequence Checksum Lifetime
0000.4a75.9b7c.00-00  0x1dd80  0xc2e3   116
0000.73e9.9a57.00-00  0xf361   0x27e8   114
0021.59f7.d000.00-00  0x16883  0x289    116
0026.888d.6800.00-00  0x1691f  0x82b7   118
  4 LSPs
```

```
member8:
```

```
-----
LSP ID          Sequence Checksum Lifetime
0000.4a75.9b7c.00-00  0x1dd80  0xc2e3   118
0000.73e9.9a57.00-00  0xf361   0x27e8   114
0021.59f7.d000.00-00  0x16883  0x289    116
0026.888d.6800.00-00  0x16920  0xa335   116
  4 LSPs
```

```
member9:
```

LSP ID	Sequence	Checksum	Lifetime
0000.4a75.9b7c.00-00	0x1dd80	0xc2e3	116
0000.73e9.9a57.00-00	0xf361	0x27e8	116
0021.59f7.d000.00-00	0x16883	0x289	114
0026.888d.6800.00-00	0x16920	0xa335	116
4 LSPs			

show virtual-chassis protocol database detail

user@switch> show virtual-chassis protocol database detail

member0:

```
-----
0000.4a75.9b7c.00-00 Sequence: 0x1ddbc, Checksum: 0x3111, Lifetime: 115 secs
Neighbor: 0000.73e9.9a57.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-1/1.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/2.32768 Metric: 150

0000.73e9.9a57.00-00 Sequence: 0xf381, Checksum: 0xe065, Lifetime: 114 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/1.32768 Metric: 150

0021.59f7.d000.00-00 Sequence: 0x168af, Checksum: 0x8b0b, Lifetime: 118 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-4/0/1.32768 Metric: 15

0026.888d.6800.00-00 Sequence: 0x1694e, Checksum: 0xca97, Lifetime: 115 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0000.73e9.9a57.00 Interface: vcp-0/1.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-3/0/4.32768 Metric: 15
```

member1:

```
-----
0000.4a75.9b7c.00-00 Sequence: 0x1ddbc, Checksum: 0x3111, Lifetime: 115 secs
Neighbor: 0000.73e9.9a57.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-1/1.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/2.32768 Metric: 150

0000.73e9.9a57.00-00 Sequence: 0xf381, Checksum: 0xe065, Lifetime: 116 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/1.32768 Metric: 150

0021.59f7.d000.00-00 Sequence: 0x168af, Checksum: 0x8b0b, Lifetime: 116 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-4/0/1.32768 Metric: 15

0026.888d.6800.00-00 Sequence: 0x1694e, Checksum: 0xca97, Lifetime: 117 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0000.73e9.9a57.00 Interface: vcp-0/1.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-3/0/4.32768 Metric: 15
```

member8:

```
-----
0000.4a75.9b7c.00-00 Sequence: 0x1ddbd, Checksum: 0xfd83, Lifetime: 118 secs
Neighbor: 0000.73e9.9a57.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-1/1.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/2.32768 Metric: 150
```

```

0000.73e9.9a57.00-00 Sequence: 0xf381, Checksum: 0xe065, Lifetime: 115 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/1.32768 Metric: 150

0021.59f7.d000.00-00 Sequence: 0x168af, Checksum: 0x8b0b, Lifetime: 116 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-4/0/1.32768 Metric: 15

0026.888d.6800.00-00 Sequence: 0x1694e, Checksum: 0xca97, Lifetime: 115 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0000.73e9.9a57.00 Interface: vcp-0/1.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-3/0/4.32768 Metric: 15

```

member9:

```

-----

0000.4a75.9b7c.00-00 Sequence: 0x1ddbd, Checksum: 0xfd83, Lifetime: 116 secs
Neighbor: 0000.73e9.9a57.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-1/1.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/2.32768 Metric: 150

0000.73e9.9a57.00-00 Sequence: 0xf381, Checksum: 0xe065, Lifetime: 117 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-1/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-1/1.32768 Metric: 150

0021.59f7.d000.00-00 Sequence: 0x168af, Checksum: 0x8b0b, Lifetime: 113 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0026.888d.6800.00 Interface: vcp-4/0/1.32768 Metric: 15

0026.888d.6800.00-00 Sequence: 0x1694f, Checksum: 0xa61a, Lifetime: 116 secs
Neighbor: 0000.4a75.9b7c.00 Interface: vcp-0/0.32768 Metric: 150
Neighbor: 0000.73e9.9a57.00 Interface: vcp-0/1.32768 Metric: 150
Neighbor: 0021.59f7.d000.00 Interface: vcp-3/0/4.32768 Metric: 15

```

show virtual-chassis protocol interface

Syntax	<pre>show virtual-chassis protocol interface <brief detail> <all-members> <interface-name> <local> <member member-id></pre>
Release Information	<p>Command introduced in Junos OS Release 10.4 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display information about Virtual Chassis Control Protocol (VCCP) statistics for VCCP-enabled interfaces within the Virtual Chassis or VCF.
Options	<p>none—Display the VCCP interface statistics in brief form for all members of the Virtual Chassis or VCF.</p> <p>brief detail —(Optional) Display the specified level of output. Using the brief option is equivalent to entering the command with no options (the default). The detail option provides more output than the brief option.</p> <p>all-members—(Optional) Display VCCP interface statistics for all members of the Virtual Chassis or VCF.</p> <p>interface-name—(Optional) Display VCCP interface statistics for the specified interface.</p> <p>local—(Optional) Display VCCP interface statistics for the switch or external Routing Engine on which this command is entered.</p> <p>member member-id—(Optional) Display VCCP interface statistics for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Understanding EX Series Virtual Chassis on page 8 • Understanding QFX Series Virtual Chassis • Understanding Virtual Chassis Ports in an EX8200 Virtual Chassis • Understanding the Virtual Chassis Control Protocol in an EX8200 Virtual Chassis
List of Sample Output	show virtual-chassis protocol interface on page 353
Output Fields	Table 33 on page 353 lists the output fields for the show virtual-chassis protocol interface command. Output fields are listed in the approximate order in which they appear.

Table 33: show virtual-chassis protocol interface Output Fields

Field Name	Field Description	Level of Output
Interface	Name of the VCP.	All levels
State	State of the link. Outputs include: <ul style="list-style-type: none"> • Up—The link is up. • Down—The link is down. 	All levels
Metric	Metric of the prefix or neighbor.	All levels

Sample Output

show virtual-chassis protocol interface

```
user@switch> show virtual-chassis protocol interface
```

```
member0:
```

```
-----
```

```
IS-IS interface database:
```

Interface	State	Metric
vcp-0/0.32768	Up	150
vcp-0/1.32768	Up	150
vcp-4/0/1.32768	Up	15
vcp-4/0/7.32768	Down	15

```
member1:
```

```
-----
```

```
IS-IS interface database:
```

Interface	State	Metric
vcp-0/0.32768	Up	150
vcp-0/1.32768	Up	150
vcp-3/0/4.32768	Up	15

```
member8:
```

```
-----
```

```
IS-IS interface database:
```

Interface	State	Metric
vcp-0/0.32768	Down	150
vcp-1/0.32768	Up	150
vcp-1/1.32768	Up	150
vcp-1/2.32768	Up	150
vcp-1/3.32768	Down	150
vcp-2/0.32768	Up	150
vcp-2/1.32768	Down	150
vcp-2/2.32768	Down	150
vcp-2/3.32768	Down	150

```
member9:
```

```
-----
```

```
IS-IS interface database:
```

Interface	State	Metric
vcp-0/0.32768	Down	150
vcp-1/0.32768	Up	150
vcp-1/1.32768	Up	150

vcp-1/2.32768	Down	150
vcp-1/3.32768	Down	150

show virtual-chassis protocol route

Syntax	<pre>show virtual-chassis protocol route <all-members> <destination-id> <local> <member member-id></pre>
Release Information	<p>Command introduced in Junos OS Release 10.4 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the unicast and multicast Virtual Chassis Control Protocol (VCCP) routing tables within the Virtual Chassis or VCF.
Options	<p>none—Display the unicast and multicast routing tables for all members of the Virtual Chassis.</p> <p>all-members—(Optional) Display the unicast and multicast routing tables for all members of the Virtual Chassis or VCF.</p> <p>destination-id—(Optional) Display the unicast and multicast routing tables to the specified destination member ID for each member of the Virtual Chassis or VCF.</p> <p>local—(Optional) Display the unicast and multicast routing tables on the device where this command is entered.</p> <p>member member-id—(Optional) Display the unicast and multicast routing tables for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Understanding EX Series Virtual Chassis on page 8 • Understanding QFX Series Virtual Chassis • Understanding the Virtual Chassis Control Protocol in an EX8200 Virtual Chassis
List of Sample Output	show virtual-chassis protocol route on page 356
Output Fields	Table 34 on page 355 lists the output fields for the show virtual-chassis protocol route command. Output fields are listed in the approximate order in which they appear.

Table 34: show virtual-chassis protocol route Output Fields

Field Name	Field Description
Dev	MAC address of the member storing the VCCP routing table.

Table 34: show virtual-chassis protocol route Output Fields (continued)

Field Name	Field Description
Version	Version of the shortest-path-first algorithm that generated the routing table.
System ID	MAC address of the device.
Version	Version of the shortest-path-first (SPF) algorithm that generated the route.
Metric	The metric number to get to that device.
Interface	Name of the Virtual Chassis port (VCP) interface connecting the devices.
Via	MAC address of the next-hop device, if applicable.

Sample Output

show virtual-chassis protocol route

```

user@switch> show virtual-chassis protocol route
member0:
-----
Dev 0021.59f7.d000 ucast routing table          Current version: 21
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c    21      150 vcp-0/1.32768 0000.4a75.9b7c
0000.73e9.9a57    21      165 vcp-4/0/1.32768 0026.888d.6800
0021.59f7.d000    21         0
0026.888d.6800    21      15 vcp-4/0/1.32768 0026.888d.6800

Dev 0021.59f7.d000 mcast routing table          Current version: 21
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c    21
0000.73e9.9a57    21
0021.59f7.d000    21      vcp-4/0/1.32768
                                vcp-0/1.32768
0026.888d.6800    21

member1:
-----
Dev 0026.888d.6800 ucast routing table          Current version: 25
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c    25      150 vcp-0/0.32768 0000.4a75.9b7c
0000.73e9.9a57    25      150 vcp-0/1.32768 0000.73e9.9a57
0021.59f7.d000    25      15 vcp-3/0/4.32768 0021.59f7.d000
0026.888d.6800    25         0

Dev 0026.888d.6800 mcast routing table          Current version: 25
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c    25

```



```

0000.73e9.9a57      25      vcp-3/0/4.32768
0021.59f7.d000      25      vcp-0/1.32768
0026.888d.6800      25      vcp-3/0/4.32768
                        vcp-0/0.32768
                        vcp-0/1.32768

```

```
member8:
```

```
-----
Dev 0000.4a75.9b7c ucast routing table          Current version: 39

```

```
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c      39      0
0000.73e9.9a57      39      150 vcp-1/0.32768 0000.73e9.9a57
0021.59f7.d000      39      150 vcp-2/0.32768 0021.59f7.d000
0026.888d.6800      39      150 vcp-1/2.32768 0026.888d.6800

```

```
Dev 0000.4a75.9b7c mcast routing table          Current version: 39

```

```
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c      39      vcp-1/0.32768
                        vcp-2/0.32768
                        vcp-1/2.32768
0000.73e9.9a57      39
0021.59f7.d000      39
0026.888d.6800      39

```

```
member9:
```

```
-----
Dev 0000.73e9.9a57 ucast routing table          Current version: 31

```

```
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c      31      150 vcp-1/0.32768 0000.4a75.9b7c
0000.73e9.9a57      31      0
0021.59f7.d000      31      165 vcp-1/1.32768 0026.888d.6800
0026.888d.6800      31      150 vcp-1/1.32768 0026.888d.6800

```

```
Dev 0000.73e9.9a57 mcast routing table          Current version: 31

```

```
-----
System ID      Version  Metric Interface  Via
0000.4a75.9b7c      31
0000.73e9.9a57      31      vcp-1/0.32768
                        vcp-1/1.32768
0021.59f7.d000      31
0026.888d.6800      31

```

show virtual-chassis protocol statistics

Syntax	<pre>show virtual-chassis protocol statistics <all-members> <interface-name> <local> <member member-id></pre>
Release Information	<p>Command introduced in Junos OS Release 10.4 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the Virtual Chassis Control Protocol (VCCP) statistics for all hardware devices within the Virtual Chassis or VCF.
Options	<p>none—Display VCCP statistics for all members of the Virtual Chassis or VCF.</p> <p>all-members—(Optional) Display VCCP statistics for all members of the Virtual Chassis or VCF.</p> <p>interface-name—(Optional) Display VCCP statistics for the specified interface.</p> <p>local—(Optional) Display VCCP statistics for the switch or external Routing Engine on which this command is entered.</p> <p>member member-id—(Optional) Display VCCP statistics for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	clear
Related Documentation	<ul style="list-style-type: none"> • Understanding EX Series Virtual Chassis on page 8 • Understanding QFX Series Virtual Chassis • Understanding the Virtual Chassis Control Protocol in an EX8200 Virtual Chassis
List of Sample Output	show virtual-chassis protocol statistics on page 359
Output Fields	Table 35 on page 358 lists the output fields for the show virtual-chassis protocol interface command. Output fields are listed in the approximate order in which they appear.

Table 35: show virtual-chassis protocol statistics Output Fields

Field Name	Field Description
PDU type	Protocol data unit type.
Received	Number of PDUs received since VCCP started or since the statistics were set to zero.

Table 35: show virtual-chassis protocol statistics Output Fields (continued)

Field Name	Field Description
Processed	Number of PDUs received minus the number of PDUs dropped.
Drops	Number of PDUs dropped.
Sent	Number of PDUs transmitted since VCCP started or since the statistics were set to zero.
Rexmit	Number of PDUs retransmitted since VCCP started or since the statistics were set to zero.
Total Packets Received	Number of PDUs received since VCCP started or since the statistics were set to zero.
Total Packets Sent	Number of PDUs sent since VCCP started or since the statistics were set to zero.
LSP queue length	Number of link-state PDUs waiting in the queue for processing. This value is almost always 0.
SPF runs	Number of shortest-path-first (SPF) calculations that have been performed.
Fragments Rebuilt	Number of link-state PDU fragments that the local system has computed.
LSP Regenerations	Number of link-state PDUs that have been regenerated. A link-state PDU is regenerated when it is nearing the end of its lifetime and it has not changed.
Purges initiated	Number of purges that the system initiated. A purge is initiated if the software determines that a link-state PDU must be removed from the network.

Sample Output

show virtual-chassis protocol statistics

```
user@switch> show virtual-chassis protocol statistics
```

```
member0:
```

```
-----
IS-IS statistics for 0021.59f7.d000:
```

PDU type	Received	Processed	Drops	Sent	Rexmit
LSP	8166	8166	0	4551	0
HELLO	1659	1659	0	1693	0
CSNP	2	2	0	3	0
PSNP	1909	1909	0	2293	0
Unknown	0	0	0	0	0
Totals	11736	11736	0	8540	0

```
Total packets received: 11736 Sent: 8540
```

```
LSP queue length: 0 Drops: 0
SPF runs: 9
Fragments rebuilt: 1640
LSP regenerations: 1
Purges initiated: 0
```

member1:

IS-IS statistics for 0026.888d.6800:

PDU type	Received	Processed	Drops	Sent	Rexmit
LSP	10909	10909	0	12088	0
HELLO	1877	1877	0	2251	0
CSNP	3	3	0	3	0
PSNP	3846	3846	0	3732	0
Unknown	0	0	0	0	0
Totals	16635	16635	0	18074	0

Total packets received: 16635 Sent: 18074

LSP queue length: 0 Drops: 0

SPF runs: 13

Fragments rebuilt: 1871

LSP regenerations: 2

Purges initiated: 0

member8:

IS-IS statistics for 0000.4a75.9b7c:

PDU type	Received	Processed	Drops	Sent	Rexmit
LSP	7935	7935	0	14865	0
HELLO	2695	2695	0	7124	0
CSNP	4	4	0	4	0
PSNP	4398	4398	0	3666	0
Unknown	0	0	0	0	0
Totals	15032	15032	0	25659	0

Total packets received: 15032 Sent: 25659

LSP queue length: 0 Drops: 0

SPF runs: 26

Fragments rebuilt: 2666

LSP regenerations: 4

Purges initiated: 0

member9:

IS-IS statistics for 0000.73e9.9a57:

PDU type	Received	Processed	Drops	Sent	Rexmit
LSP	10800	10800	0	6327	0
HELLO	1492	1492	0	2356	0
CSNP	2	2	0	2	0
PSNP	2683	2683	0	3149	0
Unknown	0	0	0	0	0
Totals	14977	14977	0	11834	0

Total packets received: 14977 Sent: 11834

LSP queue length: 0 Drops: 0

SPF runs: 19

Fragments rebuilt: 1510

LSP regenerations: 6

Purges initiated: 0

show virtual-chassis fast-failover

Syntax	show virtual-chassis fast-failover
Release Information	Command introduced in Junos OS Release 9.3 for EX Series switches.
Description	Display information about the fast failover feature in a Virtual Chassis configuration.
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • Example: Configuring Fast Failover on Uplink Module VCPs to Reroute Traffic When an EX4200 Virtual Chassis Switch or Intermember Link Fails on page 156 • Configuring Fast Failover in an EX Series Virtual Chassis on page 233 • Disabling Fast Failover in an EX Series Virtual Chassis on page 234
List of Sample Output	show virtual-chassis fast-failover on page 362
Output Fields	Table 36 on page 362 lists the output fields for the show virtual-chassis fast-failover command. Output fields are listed in the approximate order in which they appear.

Table 36: show virtual-chassis fast-failover Output Fields

Field Name	Field Description
Fast failover on dedicated VCP ports	Indicates fast failover status on dedicated VCPs.
Fast failover on XE uplink VCP ports	Indicates fast failover status on XFP uplink VCPs.
Fast failover on GE uplink VCP ports	Indicates fast failover status on SFP uplink VCPs.

Sample Output

show virtual-chassis fast-failover

```
user@switch1> show virtual-chassis fast-failover
Fast failover on dedicated VCP ports: Enabled
Fast failover on XE uplink VCP ports: Disabled
Fast failover on GE uplink VCP ports: Enabled
```

show virtual-chassis login

Syntax	<code>show virtual-chassis login</code>
Release Information	<p>Command introduced in Junos OS Release 9.3 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	<p>Supply the address of the host that logged into the Virtual Chassis or VCF, or identify the location of the member switch that redirected the current session to a different member switch.</p> <p>You might need this information for tracing or troubleshooting purposes.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • request session member on page 298 • Understanding Global Management of a Virtual Chassis on page 38
List of Sample Output	<p>show virtual-chassis login (Direct Login to the Master Console Port) on page 363</p> <p>show virtual-chassis login (Backup Console Session Redirected to the Master Console Port) on page 363</p>

Sample Output

show virtual-chassis login (Direct Login to the Master Console Port)

```
user@switch> show virtual-chassis login
Current login session initiated from host 192.0.2.3
```

show virtual-chassis login (Backup Console Session Redirected to the Master Console Port)

```
user@switch> show virtual-chassis login
Current login session initiated from host backup
```

show virtual-chassis mode

Syntax	<pre>show virtual-chassis mode <all-members> <local> <member <i>member-id</i>></pre>
Release Information	<p>Command introduced in Junos OS Release 11.1 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for QFX Series devices.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p> <p>Current mode and Future mode after reboot fields introduced in Junos OS Release 13.2X51-D20.</p>
Description	Display the Virtual Chassis or Virtual Chassis Fabric (VCF) mixed mode status.
Options	<p>none—Display the Virtual Chassis or VCF mixed mode status for the device on which the command is entered.</p> <p>all-members—(Optional) Display the Virtual Chassis or VCF mixed mode status for all member devices in the Virtual Chassis or VCF.</p> <p>local—(Optional) Display the Virtual Chassis or VCF mixed mode status for the device on which the command is entered.</p> <p>member <i>member-id</i>—(Optional) Display the Virtual Chassis or VCF mixed mode status for the specified member device..</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • request virtual-chassis mode on page 312 • Verifying the Virtual Chassis Fabric Mode Settings • Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches (CLI Procedure) on page 195
List of Sample Output	<p>show virtual-chassis mode (EX4200) on page 365</p> <p>show virtual-chassis mode (QFX5100) on page 365</p>
Output Fields	Table 37 on page 364 lists the output fields for the show virtual-chassis mode command.

Table 37: show virtual-chassis mode Output Fields

Field Name	Field Description
Mixed Mode	Specifies the mixed mode status of the member switch. Mixed mode is either Enabled or Disabled .

Table 37: show virtual-chassis mode Output Fields (continued)

Field Name	Field Description
Current mode	<p>Specifies the current mixed and fabric mode settings running on the member device or devices.</p> <p>A device reboot is required to change the fabric or mixed mode. The Current mode and Future mode after reboot are different when the mode has been changed but the device has not been rebooted.</p> <p>Outputs include:</p> <ul style="list-style-type: none"> • Fabric with mixed devices—Fabric mode and mixed mode are enabled. • Fabric with similar devices—Fabric mode is enabled and mixed mode is disabled. • Virtual Chassis with mixed devices—Fabric mode is disabled and mixed mode is enabled. • Virtual Chassis with similar devices—Fabric mode is disabled and mixed mode is disabled.
Future mode after reboot	<p>Specifies the mixed and fabric mode settings running on the member device or devices.</p> <p>A device reboot is required to change the fabric or mixed mode. The Current mode and Future mode after reboot are different when the mode has been changed but the device has not been rebooted.</p> <p>Outputs include:</p> <ul style="list-style-type: none"> • Fabric with mixed devices—Fabric mode and mixed mode are enabled. • Fabric with similar devices—Fabric mode is enabled and mixed mode is disabled. • Virtual Chassis with mixed devices—Fabric mode is disabled and mixed mode is enabled. • Virtual Chassis with similar devices—Fabric mode is disabled and mixed mode is disabled.

Sample Output

show virtual-chassis mode (EX4200)

```
user@switch>show virtual-chassis mode
```

```
fpc0:
```

```
-----
Mixed Mode: Disabled
```

Sample Output

show virtual-chassis mode (QFX5100)

```
user@switch>show virtual-chassis mode
```

```
fpc0:
```

```
-----
Current mode : Fabric with similar devices
Future mode after reboot : Fabric with similar devices
```

```
fpc1:
```

```
-----
Current mode : Fabric with similar devices
Future mode after reboot : Fabric with similar devices
```

```
fpc2:
```

```
-----
Current mode : Fabric with similar devices
```

Future mode after reboot : Fabric with similar devices

fpc3:

Current mode : Fabric with similar devices

Future mode after reboot : Fabric with similar devices

fpc4:

Current mode : Fabric with similar devices

Future mode after reboot : Fabric with similar devices

show virtual-chassis

Syntax	show virtual-chassis <status>
Release Information	<p>Command introduced in Junos OS Release 9.2 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF). Fabric ID, Fabric Mode, and Route Mode output fields introduced in Junos OS Release 13.2X51-D20.</p> <p>Alias-Name output field introduced in Junos OS Release 14.1X53-D10.</p>
Description	Display information about all members of the Virtual Chassis or VCF.
Options	<p>none—Display information about all Virtual Chassis or VCF member devices.</p> <p>status—Same output as for show virtual-chassis without any options.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show virtual-chassis active-topology on page 332 • show virtual-chassis protocol adjacency on page 344 • show virtual-chassis vc-path on page 373 • Understanding Mixed EX Series and QFX Series Virtual Chassis on page 29 • Understanding Mixed Virtual Chassis Fabric • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287
List of Sample Output	<p>show virtual-chassis (EX2300 multigigabit model—EX2300-24MP and EX2300-48MP—Virtual Chassis) on page 369</p> <p>show virtual-chassis (EX2300 and EX2300 multigigabit model (EX2300-24MP, EX2300-48MP) Virtual Chassis) on page 370</p> <p>show virtual-chassis (EX4200 Virtual Chassis) on page 370</p> <p>show virtual-chassis (Mixed EX4300 multigigabit model—EX4300-48MP—Virtual Chassis) on page 370</p> <p>show virtual-chassis (EX8200 Virtual Chassis) on page 371</p> <p>show virtual-chassis (QFX5110 Virtual Chassis) on page 371</p> <p>show virtual-chassis (QFX5200 Virtual Chassis) on page 372</p> <p>show virtual-chassis (QFX5100 Virtual Chassis Fabric) on page 372</p>
Output Fields	Table 38 on page 368 lists the output fields for the show virtual-chassis command. Output fields are listed in the approximate order in which they appear.

Table 38: show virtual-chassis Output Fields

Field Name	Field Description
Fabric ID	(VCF only) Assigned ID used to identify the VCF.
Fabric Mode	(VCF only) Mode of the VCF: Enabled, Disabled, or Mixed.
Preprovisioned Virtual Chassis or Preprovisioned Virtual Chassis Fabric	Virtual Chassis or VCF is configured using preprovisioning.
Virtual Chassis ID	Assigned ID that applies to the entire Virtual Chassis or VCF.
Virtual Chassis Mode	<p>Mode of the Virtual Chassis or VCF. This field indicates support for the Virtual Chassis feature and, if a Virtual Chassis is configured, if it is a mixed or homogenous Virtual Chassis. Values can be:</p> <ul style="list-style-type: none"> • Enabled—The platform supports the Virtual Chassis feature. If a Virtual Chassis is currently configured, this is a homogenous Virtual Chassis (all members are the same type of switch). • Disabled—The switch does not support the Virtual Chassis feature. <p>NOTE: Switches that support the Virtual Chassis feature do not display this value. Even if a Virtual Chassis is not currently configured, those switches display Enabled in this field.</p> <ul style="list-style-type: none"> • Mixed—The platform supports the Virtual Chassis feature, and is configured as a mixed mode Virtual Chassis (members consist of more than one type of switch).
Member ID	<p>Assigned member ID and FPC:</p> <ul style="list-style-type: none"> • On all EX Series Virtual Chassis except EX8200 Virtual Chassis, and on a VCF, the FPC number refers to the member ID assigned to the switch. • On EX8200 Virtual Chassis, member IDs are numbered 0 through 9. The FPC number indicates the slot number of the line card within the Virtual Chassis. The FPC number on member 0 is always 0 through 15. The FPC number on member 1 is always 16 through 31. The FPC number on member 2 is always 32 through 47; and so on for the members.
Status	<p>For a nonprovisioned configuration:</p> <ul style="list-style-type: none"> • Prsnt for a member that is currently connected to the Virtual Chassis or VCF configuration. • NotPrsnt for a member ID that has been assigned but is not currently connected. <p>For a preprovisioned configuration:</p> <ul style="list-style-type: none"> • Prsnt for a member that is specified in the preprovisioned configuration file and is currently connected to the Virtual Chassis or VCF. • Unprvsnd for a member that is interconnected with the Virtual Chassis or VCF configuration but is not specified in the preprovisioned configuration file.
Serial No	Serial number of the member device.

Table 38: show virtual-chassis Output Fields (continued)

Field Name	Field Description
Alias-Name	<p>The user-configured alias of the member device.</p> <p>The Alias-Name field appears only if an alias has been configured for at least one device in the Virtual Chassis or VCF. Aliases are configured using the alias-name statement in the <code>[edit virtual-chassis aliases serial-number serial-number]</code> hierarchy.</p>
Model	Model number of the member device.
Mastership Priority or Mstr prio	Mastership priority value of the member device.
Role	<p>Role of the member device: master, backup, or linecard.</p> <p>An asterisk (*) following the Role denotes the member device on which the show virtual-chassis <status> command was issued.</p>
Mixed Mode	<p>Mixed mode configuration status:</p> <ul style="list-style-type: none"> • Y for a member device configured in mixed mode. • N for a member device not configured in mixed mode. • NA for a member device that cannot be configured in mixed mode.
Route Mode	The route mode of the member device: fabric (F) or Virtual Chassis (V).
Location	<p>Location of the member device.</p> <p>If this field is empty, the location field was not set for the device.</p>
Neighbor List ID and Interface	Member ID of the neighbor member to which this member's Virtual Chassis port (VCP) is connected, and the VCP interface name.

Sample Output

show virtual-chassis (EX2300 multigigabit model—EX2300-24MP and EX2300-48MP—Virtual Chassis)

```
user@switch> show virtual-chassis
```

```
Virtual Chassis ID: cdef.789a.bc12
Virtual Chassis Mode: Enabled
```

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Route Mode	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	XY1222340011	ex2300-24mp	128	Backup	N	VC	3	vcp-255/1/0
								1	vcp-255/1/2
1 (FPC 1)	Prsnt	XY1222340021	ex2300-48mp	128	Master*	N	VC	2	vcp-255/1/4
								0	vcp-255/1/1
2 (FPC 2)	Prsnt	XY1222340031	ex2300-24mp	128	Linecard	N	VC	3	vcp-255/1/0
								1	vcp-255/1/1
3 (FPC 3)	Prsnt	XY1222340041	ex2300-48mp	128	Linecard	N	VC	0	vcp-255/1/4
								2	vcp-255/1/5

show virtual-chassis (EX2300 and EX2300 multigigabit model (EX2300-24MP, EX2300-48MP) Virtual Chassis)

```
user@switch> show virtual-chassis status
```

Preprovisioned Virtual Chassis

Virtual Chassis ID: 9876.5432.abcd

Virtual Chassis Mode: Enabled

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Route Mode	Neighbor ID	List Interface
0 (FPC 0)	Prsnt	XP0123450001	ex2300-24mp	129	Backup	N	VC	1	vcp-255/1/3
								3	vcp-255/1/0
1 (FPC 1)	Prsnt	JJ0123450001	ex2300-24p	129	Master*	N	VC	2	vcp-255/1/0
								0	vcp-255/1/1
2 (FPC 2)	Prsnt	JJ0123450002	ex2300-24p	0	Linecard	N	VC	3	vcp-255/1/2
								1	vcp-255/1/3
3 (FPC 3)	Prsnt	XP0123450002	ex2300-48mp	0	Linecard	N	VC	2	vcp-255/1/5
								0	vcp-255/1/0

show virtual-chassis (EX4200 Virtual Chassis)

```
user@switch> show virtual-chassis
```

Virtual Chassis ID: 00ab.cdef.1234

Virtual Chassis Mode: Enabled

Member ID	Status	Serial No	Model	Mastership priority	Role	Mixed Mode	Neighbor ID	List Interface
0 (FPC 0)	Prsnt	AK0207360276	ex4200-24t	249	Master*	N	8	vcp-0
							1	vcp-1
1 (FPC 1)	Prsnt	AK0207360281	ex4200-24t	248	Backup	N	0	vcp-0
							2	vcp-1
2 (FPC 2)	Prsnt	AJ0207391130	ex4200-48p	247	Linecard	N	1	vcp-0
							3	vcp-1
3 (FPC 3)	Prsnt	AK0207360280	ex4200-24t	246	Linecard	N	2	vcp-0
							4	vcp-1
4 (FPC 4)	Prsnt	AJ0207391113	ex4200-48p	245	Linecard	N	3	vcp-0
							5	vcp-1
5 (FPC 5)	Prsnt	BP0207452204	ex4200-48t	244	Linecard	N	4	vcp-0
							6	vcp-1
6 (FPC 6)	Prsnt	BP0207452222	ex4200-48t	243	Linecard	N	5	vcp-0
							7	vcp-1
7 (FPC 7)	Prsnt	BR0207432028	ex4200-24f	242	Linecard	N	6	vcp-0
							8	vcp-1
8 (FPC 8)	Prsnt	BR0207431996	ex4200-24f	241	Linecard	N	7	vcp-0
							0	vcp-1

Member ID for next new member: 9 (FPC 9)

show virtual-chassis (Mixed EX4300 multigigabit model—EX4300-48MP—Virtual Chassis)

```
user@switch> show virtual-chassis
```

Preprovisioned Virtual Chassis

Virtual Chassis ID: abcd.ef00.1234

Virtual Chassis Mode: Mixed

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Route Mode	Neighbor ID	List Interface
0 (FPC 0)	Prsnt	XR3617480028	ex4300-48mp	129	Master*	Y	VC	1	vcp-255/1/0

1 (FPC 1)	Prsnt	XR3617480029	ex4300-48mp	129	Backup	Y	VC	3 vcp-255/1/3
								0 vcp-255/1/1
2 (FPC 2)	Prsnt	XR3617480001	ex4300-48mp	0	Linecard	Y	VC	2 vcp-255/1/3
								3 vcp-255/1/1
3 (FPC 3)	Prsnt	PE3715471074	ex4300-48t	0	Linecard	Y	VC	1 vcp-255/1/3
								0 vcp-255/1/0
								2 vcp-255/1/2

show virtual-chassis (EX8200 Virtual Chassis)

user@external-routing-engine> show virtual-chassis

Virtual Chassis ID: cdc1.1212.efef

Virtual Chassis Mode: Enabled

Member ID	Status	Serial No	Model	Mastership priority	Role	Neighbor List ID Interface
0 (FPC 0-15)	Prsnt	BA0908380001	ex8216	0	Linecard	8 vcp-0/0 8 vcp-0/1 1 vcp-4/0/4
1 (FPC 16-31)	Prsnt	BT0909411634	ex8208	0	Linecard	8 vcp-0/0 0 vcp-3/0/4
8 (FPC 128-143)	Prsnt	062009000021	ex-xre	128	Master	9 vcp-1/0 1 vcp-1/2 9 vcp-1/3 0 vcp-2/0 9 vcp-2/1 0 vcp-1/1
9 (FPC 144-159)	Prsnt	062009000022	ex-xre	128	Backup*	8 vcp-1/0 8 vcp-1/2 8 vcp-1/3 8 vcp-1/3

show virtual-chassis (QFX5110 Virtual Chassis)

user@switch> show virtual-chassis

Preprovisioned Virtual Chassis

Virtual Chassis ID: abab.1212.cdc1

Virtual Chassis Mode: Enabled

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Route Mode	Neighbor List ID Interface
0 (FPC 0)	Prsnt	WT3116360038	qfx5110-32q	129	Backup	Y	VC	9 vcp-255/0/12 1 vcp-255/0/16
1 (FPC 1)	Prsnt	WT3116360041	qfx5110-32q	129	Master*	Y	VC	2 vcp-255/0/16 0 vcp-255/0/17
2 (FPC 2)	Prsnt	WT3116360051	qfx5110-32q	0	Linecard	Y	VC	3 vcp-255/0/11 1 vcp-255/0/14
3 (FPC 3)	Prsnt	WT3116360055	qfx5110-32q	0	Linecard	Y	VC	4 vcp-255/0/14 2 vcp-255/0/31
4 (FPC 4)	Prsnt	WT3116360056	qfx5110-32q	0	Linecard	Y	VC	5 vcp-255/0/10 3 vcp-255/0/5
5 (FPC 5)	Prsnt	TB3716340058	qfx5100e-24q-2p	0	Linecard	Y	VC	6 vcp-255/0/12 4 vcp-255/0/20
6 (FPC 6)	Prsnt	WS3715500018	qfx5110-48s-4c	0	Linecard	Y	VC	7 vcp-255/0/10 5 vcp-255/0/49
7 (FPC 7)	Prsnt	TA3714110007	qfx5100e-48s-6q	0	Linecard	Y	VC	6 vcp-255/0/18

8 (FPC 8)	Prsnt	WS3715500022	qfx5110-48s-4c	0	Linecard	Y	VC	8	vcp-255/0/31
								7	vcp-255/0/21
								9	vcp-255/0/49
9 (FPC 9)	Prsnt	WT3116360061	qfx5110-32q	0	Linecard	Y	VC	8	vcp-255/0/13
								0	vcp-255/0/17

show virtual-chassis (QFX5200 Virtual Chassis)

```
user@switch> show virtual-chassis
```

Virtual Chassis ID: abab.1212.cdcd
Virtual Chassis Mode: Enabled

Member ID	Status	Serial No	Model	prio	Role	Mixed Mode	Route Mode	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	XY0123456789	qfx5200-32c-r	128	Master*	N	VC	1	vcp-255/0/19
								2	vcp-255/0/26
1 (FPC 1)	Prsnt	XY0123456780	qfx5200-32c-r	128	Linecard	N	VC	0	vcp-255/0/20
								2	vcp-255/0/16
2 (FPC 2)	Prsnt	YZ0123456789	qfx5200-32c-32q	128	Backup	N	VC	0	vcp-255/0/15
								1	vcp-255/0/18

show virtual-chassis (QFX5100 Virtual Chassis Fabric)

```
user@switch> show virtual-chassis
```

Preprovisioned Virtual Chassis Fabric
Fabric ID: 0123.abcd.4567
Fabric Mode: Enabled

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Route Mode	Neighbor List ID	Interface
0 (FPC 0)	Prsnt	AB3112430001	qfx5100-48s	129	Master*	N	F	3	vcp-255/1/0
								2	vcp-255/1/1
								4	vcp-255/1/2
								4	vcp-255/1/3
1 (FPC 1)	Prsnt	AB3112230001	qfx5100-48s	129	Backup	N	F	3	vcp-255/1/0
								2	vcp-255/1/1
								4	vcp-255/1/2
								4	vcp-255/1/3
2 (FPC 2)	Prsnt	AB3112460011	qfx5100-48s	0	Linecard	N	F	1	vcp-255/1/0
								0	vcp-255/1/1
3 (FPC 3)	Prsnt	AB3112460011	qfx5100-48s	0	Linecard	N	F	1	vcp-255/1/0
								0	vcp-255/1/1
4 (FPC 4)	Prsnt	AB3112430011	qfx5100-48s	0	Linecard	N	F	1	vcp-255/1/0
								0	vcp-255/1/1

show virtual-chassis vc-path

Syntax	show virtual-chassis vc-path source-interface <i>interface-name</i> destination-interface <i>interface-name</i>
Release Information	Command introduced in Junos OS Release 9.6 for EX Series switches. Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.
Description	<p>Show the forwarding path a packet takes when going from a source interface to a destination interface in a Virtual Chassis or VCF configuration.</p> <p>Starting in Junos OS Releases 14.1X53-D40, 15.1R5, and 16.1R3, when used in VCF configurations, this command displays additional information about next hops, including when the forwarding path has multiple possible next hops within the VCF.</p>
Options	<p>source-interface <i>interface-name</i>—Name of the interface from which the packet originates in the Virtual Chassis or VCF</p> <p>destination-interface <i>interface-name</i>—Name of the interface to which the packet is being delivered in the Virtual Chassis or VCF</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287 • Understanding EX Series Virtual Chassis on page 8 • Understanding QFX Series Virtual Chassis • EX8200 Virtual Chassis Overview
List of Sample Output	<p>show virtual-chassis vc-path source-interface destination-interface (Virtual Chassis) on page 374</p> <p>show virtual-chassis vc-path source-interface destination-interface (Virtual Chassis Fabric) on page 375</p>
Output Fields	<p>Table 39 on page 374 lists the output fields for the show virtual-chassis vc-path command. Output fields are listed in the approximate order in which they appear.</p> <p>Some output field names and display order differ between the output for a Virtual Chassis and for a VCF. When this command is used to display forwarding paths in a VCF, additional fields are included in the output to show details of multiple possible next hops. The differences are described in Table 39 on page 374 and shown in sample output for each mode.</p>

Table 39: show virtual-chassis vc-path Output Fields

Field Name	Field Description
Hop	<p>The hop number along the path between the source and destination interfaces. The first hop entry (Hop 0) is the packet's source, intermediate hop information represents transitions through the members within the Virtual Chassis or VCF, and the last hop entry represents arrival at the packet's destination.</p> <p>For VCF output, each Hop entry also shows information about multiple possible next hops towards the destination. See Next-hop PFE, Interface, and Bandwidth output field descriptions for details.</p>
Member (Virtual Chassis) Member-ID (VCF)	The Virtual Chassis or VCF member ID of the switch that contains the Packet Forwarding Engine for each hop through which the packet passes.
PFE-Device (Virtual Chassis) PFE (VCF)	<p>The number of the Packet Forwarding Engine in each Virtual Chassis or VCF member through which a packet passes.</p> <p>For Virtual Chassis output, the Packet Forwarding Engine in each row is the next hop of the preceding Packet Forwarding Engine, including intermediate transitions through members within the Virtual Chassis.</p> <p>VCF output is expanded on multiple rows to show more information about multiple possible next hops—each hop entry is followed by one or more Next-hop PFE output fields with interface name and bandwidth information for each possible next hop.</p>
Next-hop PFE (VCF only)	One or more possible next-hop Packet Forwarding Engine numbers for VCF member Member-ID . Each Next-hop entry includes the next-hops's interface name and bandwidth.
Interface	<p>The name of the interface through which the Packet Forwarding Engines are connected. The interface for the first hop (Hop 0) is always the source interface.</p> <p>VCF output provides more information about multiple possible next hops for each hop entry, listing the Interface and the interface Bandwidth for each possible Next-hop PFE.</p>
Bandwidth (VCF only)	The bandwidth (in Gbps) of the next-hop interface for the associated Next-hop PFE entry.

Sample Output

show virtual-chassis vc-path source-interface destination-interface (Virtual Chassis)

```
user@switch> show virtual-chassis vc-path source-interface ge-0/0/0 destination-interface ge-1/0/1
```

```
vc-path from ge-0/0/0 to ge-1/0/1
Hop      Member  PFE-Device  Interface
0         0         1         ge-0/0/0
1         0         0        internal-1/24
2         1         3         vcp-0
```

```
3      1      4      ge-1/0/1
```

show virtual-chassis vc-path source-interface destination-interface (Virtual Chassis Fabric)

This example shows **vc-path** command output for two source-to-destination paths in the following Virtual Chassis Fabric displayed by the **show virtual-chassis** command:

```
user@switch> show virtual-chassis
```

```
Preprovisioned Virtual Chassis Fabric
Fabric ID: ec56.0915.8595
Fabric Mode: Enabled
```

Member ID	Status	Serial No	Model	Mstr prio	Role	Mixed Mode	Route Mode	Neighbor List ID	Interface
1 (FPC 1)	Prsnt	VX1234560001	qfx5100-24q-aa	129	Backup	N	F	7	vcp-255/0/7
								8	vcp-255/0/8
								12	vcp-255/0/12
								3	vcp-255/0/3
								4	vcp-255/0/4
								5	vcp-255/0/5
								6	vcp-255/0/6
								10	vcp-255/0/10
								11	vcp-255/0/11
2 (FPC 2)	Prsnt	VX1234560002	qfx5100-24q-aa	129	Master*	N	F	9	vcp-255/0/9
								7	vcp-255/0/7
								8	vcp-255/0/8
								12	vcp-255/0/12
								3	vcp-255/0/3
								4	vcp-255/0/4
								5	vcp-255/0/5
								6	vcp-255/0/6
								10	vcp-255/0/10
								11	vcp-255/0/11
3 (FPC 3)	Prsnt	VX1234560003	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
4 (FPC 4)	Prsnt	VX1234560004	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
5 (FPC 5)	Prsnt	VX1234560005	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
6 (FPC 6)	Prsnt	VX1234560006	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
7 (FPC 7)	Prsnt	VX1234560007	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
8 (FPC 8)	Prsnt	VX1234560008	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
9 (FPC 9)	Prsnt	VX1234560009	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
10 (FPC 10)	Prsnt	VX1234560010	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
11 (FPC 11)	Prsnt	VX1234560011	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2
12 (FPC 12)	Prsnt	VX1234560012	qfx5100-24q-aa	0	Linecard	N	F	1	vcp-255/0/1
								2	vcp-255/0/2

```
user@switch> show virtual-chassis vc-path source-interface xe-12/0/25 destination-interface xe-5/0/25
```

Fabric forwarding path from xe-12/0/25 (PFE 12) to xe-5/0/25 (PFE 5)

```
Hop  0  Member-ID 12  PFE   12
  Next-hop PFE   1
    Interface vcp-255/0/1.32768  Bandwidth  40
  Next-hop PFE   2
    Interface vcp-255/0/2.32768  Bandwidth  40
Hop  1  Member-ID   1  PFE    1
  Next-hop PFE   5
    Interface vcp-255/0/5.32768  Bandwidth  40
Hop  1  Member-ID   2  PFE    2
  Next-hop PFE   5
    Interface vcp-255/0/5.32768  Bandwidth  40
Hop  2  Member-ID   5  PFE    5
```

user@switch> show virtual-chassis vc-path source-interface xe-12/0/25 destination-interface xe-1/0/25

Fabric forwarding path from xe-12/0/25 (PFE 12) to xe-1/0/25 (PFE 1)

```
Hop  0  Member-ID 12  PFE   12
  Next-hop PFE   1
    Interface vcp-255/0/1.32768  Bandwidth  40
Hop  1  Member-ID   1  PFE    1
```

show virtual-chassis vc-port

Syntax	<pre>show virtual-chassis vc-port <all-members> <local> <member <i>member-id</i>></pre>
Release Information	<p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the status of the Virtual Chassis ports (VCPs), including both dedicated VCPs and uplink ports configured as VCPs, if present.
Options	<p>none—Display the operational status of all VCPs of the member switch where the command is issued.</p> <p>all-members—(Optional) Display the operational status of all VCPs on all members of the Virtual Chassis or VCF.</p> <p>local—(Optional) Display the operational status of the switch or external Routing Engine on which this command is entered.</p> <p>member <i>member-id</i>—(Optional) Display the operational status of all VCPs for the specified member of the Virtual Chassis or VCF.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • show virtual-chassis vc-port statistics on page 382 • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287
List of Sample Output	<p>show virtual-chassis vc-port (EX4200 Virtual Chassis) on page 379</p> <p>show virtual-chassis vc-port (EX8200 Virtual Chassis) on page 379</p> <p>show virtual-chassis vc-port all-members on page 380</p>
Output Fields	<p>Table 40 on page 377 lists the output fields for the show virtual-chassis vc-port command. Output fields are listed in the approximate order in which they appear.</p>

Table 40: show virtual-chassis vc-port Output Fields

Field Name	Field Description
<i>fpcnumber</i>	The FPC number is the same as the member ID.

Table 40: show virtual-chassis vc-port Output Fields (continued)

Field Name	Field Description
Interface or PIC/Port	<p>VCP name.</p> <ul style="list-style-type: none"> The dedicated VCPs in an EX4200 or EX4500 Virtual Chassis are vcp-0 and vcp-1. The dedicated VCPs in an EX4550 Virtual Chassis are VCP-1/0, VCP-1/1, VCP-2/0, and VCP-2/1. Optical ports set as VCPs are named 1/0 and 1/1, representing the PIC number and the port number. The native VCP (port 0) on an XRE200 External Routing Engine in an EX8200 Virtual Chassis is named vcp-0. The VCPs on each Virtual Chassis Control Interface (VCCI) module in an XRE200 External Routing Engine are named using the vcp-slot-number/port-number convention; for instance, vcp-1/0. The VCPs on EX8200 member switches are named using the vcp-slot-number/pic-number/interface-number convention; for instance, vcp-3/0/2. A 255 as the first number in your port number indicates that your VCP is part of a Link Aggregation group (LAG) bundle. For instance, a display of vcp-255/1/0 indicates that the dedicated VCP named vcp-1/0 is part of a LAG bundle. A display of vcp-255/1/0 indicates that an uplink port that was previously named xe-0/1/0 is now part of a VCP LAG bundle.
Type	<p>Type of VCP:</p> <ul style="list-style-type: none"> Dedicated—The rear panel VCP on an EX4200, EX4500, or EX4550 switch, or any VCP link connected to an XRE200 External Routing Engine in an EX8200 Virtual Chassis. Configured—Optical port configured as a VCP. Auto-Configured—Optical port autoconfigured as a VCP. <p>See “Setting an Uplink Port on an EX Series or QFX Series Switch as a Virtual Chassis Port” on page 223 or Configuring a QFX Series Virtual Chassis for information about configuring VCPs.</p>
Trunk ID	<p>A positive-number ID assigned to a link aggregation group (LAG) formed by the Virtual Chassis. The trunk ID value is –1 if no trunk is formed. A LAG between uplink VCPs requires that the link speed be the same on connected interfaces and that at least two VCPs on one member be connected to at least two VCPs on the other member in an EX4200 or EX4500 Virtual Chassis.</p> <p>Dedicated VCP LAGs are assigned trunk IDs 1 and 2. Trunk IDs for LAGs formed with uplink VCPs therefore have values of 3 or greater.</p> <p>The trunk ID value changes if the link-adjacency state between LAG members changes; trunk membership is then allocated or deallocated.</p>
Status	<p>Interface status:</p> <ul style="list-style-type: none"> absent—Interface is not a VCP link. down—VCP link is down. up—VCP link is up.
Speed (mbps)	Speed of the interface in megabits per second.
Neighbor ID/Interface	The Virtual Chassis member ID and interface of a VCP on a member that is connected to the interface or PIC/Port field in the same row as this interface.

Sample Output

show virtual-chassis vc-port (EX4200 Virtual Chassis)

```
user@switch> show virtual-chassis vc-port
```

```
fpc0:
```

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	1	vcp-1
vcp-1	Dedicated	2	Up	32000	0	vcp-0
1/0	Auto-Configured	3	Up	1000	2	vcp-255/1/0
1/0	Auto-Configured	3	Up	1000	2	vcp-255/1/1

show virtual-chassis vc-port (EX8200 Virtual Chassis)

```
user@external-routing-engine> show virtual-chassis vc-port
```

```
member0:
```

Interface or Slot/PIC/Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0/0	Dedicated	-1	Up	1000	8	vcp-1/1
vcp-0/1	Dedicated	-1	Up	1000	8	vcp-2/0
4/0/4	Configured	-1	Up	10000	1	vcp-3/0/4
4/0/7	Configured	-1	Down	10000		
4/0/3	Configured		Absent			
4/0/2	Configured		Absent			
4/0/5	Configured		Absent			
4/0/6	Configured		Absent			
4/0/1	Configured		Absent			
4/0/0	Configured		Absent			

```
member1:
```

Interface or Slot/PIC/Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0/0	Dedicated	-1	Up	1000	8	vcp-1/2
3/0/0	Configured	-1	Down	10000		
3/0/1	Configured	-1	Down	10000		
3/0/4	Configured	-1	Up	10000	0	vcp-4/0/4
3/0/5	Configured		Absent			
4/0/5	Configured		Absent			
4/0/4	Configured		Absent			

```
member8:
```

Interface or Slot/PIC/Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0/0	Dedicated	-1	Down	1000		
vcp-1/0	Dedicated	-1	Up	1000	9	vcp-1/0
vcp-1/1	Dedicated	-1	Up	1000	0	vcp-0/0
vcp-1/2	Dedicated	-1	Up	1000	1	vcp-0/0
vcp-1/3	Dedicated	-1	Up	1000	9	vcp-1/3

vcp-2/0	Dedicated	-1	Up	1000	0	vcp-0/1
vcp-2/1	Dedicated	-1	Up	1000	9	vcp-1/2
vcp-2/2	Dedicated	-1	Down	1000		
vcp-2/3	Dedicated	-1	Down	1000		

member9:

Interface or Slot/PIC/Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0/0	Dedicated	-1	Disabled	1000		
vcp-1/0	Dedicated	-1	Up	1000	8	vcp-1/0
vcp-1/1	Dedicated	-1	Down	1000		
vcp-1/2	Dedicated	-1	Up	1000	8	vcp-2/1
vcp-1/3	Dedicated	-1	Up	1000	8	vcp-1/3

show virtual-chassis vc-port all-members

```
user@switch> show virtual-chassis vc-port all-members
```

fpc0:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	1	vcp-1
vcp-1	Dedicated	2	Up	32000	0	vcp-0
1/0	Auto-Configured	3	Up	1000	2	vcp-255/1/0
1/1	Auto-Configured	3	Up	1000	2	vcp-255/1/1

fpc1:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	0	vcp-1
vcp-1	Dedicated	2	Up	32000	0	vcp-0
1/0	Auto-Configured	-1	Up	1000	3	vcp-255/1/0

fpc2:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	3	vcp-1
vcp-1	Dedicated	2	Up	32000	3	vcp-0
1/0	Auto-Configured	3	Up	1000	0	vcp-255/1/0
1/1	Auto-Configured	3	Up	1000	0	vcp-255/1/1

fpc3:

Interface or PIC / Port	Type	Trunk ID	Status	Speed (mbps)	Neighbor ID	Interface
vcp-0	Dedicated	1	Up	32000	2	vcp-0
vcp-1	Dedicated	2	Up	32000	2	vcp-1
1/0	Auto-Configured	-1	Up	1000	1	vcp-255/1/0

show virtual-chassis vc-port statistics

Syntax	<pre>show virtual-chassis vc-port statistics <all-members> <brief detail extensive > <interface-name> <local> <member member-id></pre>
Release Information	<p>Command introduced in Junos OS Release 9.0 for EX Series switches.</p> <p>The options all-members, brief, detail, extensive, and local were added in Junos OS Release 9.3 for EX Series switches.</p> <p>Command introduced in Junos OS Release 13.2X50-D15 for the QFX Series.</p> <p>Command introduced in Junos OS Release 13.2X51-D20 for Virtual Chassis Fabric (VCF).</p>
Description	Display the traffic statistics collected on Virtual Chassis ports (VCPs).
Options	<p>none—Display traffic statistics for VCPs of all members of a Virtual Chassis or VCF.</p> <p>brief detail extensive—(Optional) Display the specified level of output. Using the brief option is equivalent to entering the command with no options (the default). The detail and extensive options provide identical displays.</p> <p>all-members—(Optional) Display traffic statistics for VCPs of all members of a Virtual Chassis or VCF.</p> <p>interface-name—(Optional) Display traffic statistics for the specified VCP.</p> <p>local—(Optional) Display traffic statistics for VCPs on the switch or external Routing Engine on which this command is entered.</p> <p>member member-id—(Optional) Display traffic statistics for VCPs on the specified member of a Virtual Chassis or VCF.</p>
Required Privilege Level	view
Related Documentation	<ul style="list-style-type: none"> • clear virtual-chassis vc-port statistics on page 294 • show virtual-chassis vc-port on page 377 • Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287 • Verifying Virtual Chassis Ports in an EX8200 Virtual Chassis
List of Sample Output	<p>show virtual-chassis vc-port statistics on page 385</p> <p>show virtual-chassis vc-port statistics (EX8200 Virtual Chassis) on page 386</p> <p>show virtual-chassis vc-port statistics brief on page 386</p>

[show virtual-chassis vc-port statistics extensive on page 386](#)
[show virtual-chassis vc-port statistics member 0 on page 388](#)

Output Fields [Table 41 on page 383](#) lists the output fields for the **show virtual-chassis vc-port statistics** command. Output fields are listed in the approximate order in which they appear.

Table 41: show virtual-chassis vc-port statistics Output Fields

Field Name	Field Description	Level of Output
fpcnumber	(All Virtual Chassis except EX8200 Virtual Chassis. VCF) ID of the Virtual Chassis member. The FPC number is the same as the member ID.	All levels
member number	(EX8200 Virtual Chassis only) Member ID of the Virtual Chassis member.	All levels
Interface	VCP name.	brief
Input Octets/Packets	Number of octets and packets received on the VCP.	brief, member, none
Output Octets/Packets	Number of octets and packets transmitted on the VCP.	brief, member, none
master: number	Member ID of the master Routing Engine.	All levels
Port	VCP for which RX (Receive) statistics, TX (Transmit) statistics, or both are reported by the VCP subsystem during a sampling interval—since the statistics counter was last cleared.	detail, extensive
Total octets	Total number of octets received and transmitted on the VCP.	detail, extensive
Total packets	Total number of packets received and transmitted on the VCP.	detail, extensive
Unicast packets	Number of unicast packets received and transmitted on the VCP.	detail, extensive
Broadcast packets	Number of broadcast packets received and transmitted on the VCP.	detail, extensive
Multicast packets	Number of multicast packets received and transmitted on the VCP.	detail, extensive
MAC control frames	Number of media access control (MAC) control frames received and transmitted on the VCP.	detail, extensive

Table 41: show virtual-chassis vc-port statistics Output Fields (continued)

Field Name	Field Description	Level of Output
CRC alignment errors	<p>Number of packets received on the VCP that had a length—excluding framing bits, but including frame check sequence (FCS) octets—of between 64 and 1518 octets, inclusive, and had one of the following errors:</p> <ul style="list-style-type: none"> Invalid FCS with an integral number of octets (FCS error) Invalid FCS with a nonintegral number of octets (alignment error) 	detail, extensive
Oversize packets	Number of packets received on the VCP that were longer than 1518 octets (excluding framing bits, but including FCS octets) but were otherwise well formed.	detail, extensive
Undersize packets	Number of packets received on the VCP that were shorter than 64 octets (excluding framing bits but including FCS octets) and were otherwise well formed..	detail, extensive
Jabber packets	<p>Number of packets received on the VCP that were longer than 1518 octets—excluding framing bits, but including FCS octets—and that had either an FCS error or an alignment error.</p> <p>NOTE: This definition of <i>jabber</i> is different from the definition in IEEE-802.3 section 8.2.1.5 (10Base5) and section 10.3.1.4 (10Base2). These documents define <i>jabber</i> as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.</p>	detail, extensive
Fragments received	<p>Number of packets received on the VCP that were shorter than 64 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error.</p> <p>Fragment frames normally increment because both runs (which are normal occurrences caused by collisions) and noise hits are counted.</p>	detail, extensive
Ifout errors	Number of outbound packets received on the VCP that could not be transmitted because of errors.	detail, extensive
Packet drop events	Number of outbound packets received on the VCP that were dropped, rather than being encapsulated and sent out of the switch as fragments. The packet drop counter is incremented if a temporary shortage of packet memory causes packet fragmentation to fail.	detail, extensive
64 octets frames	Number of packets received on the VCP (including invalid packets) that were 64 octets in length (excluding framing bits, but including FCS octets).	detail, extensive

Table 41: show virtual-chassis vc-port statistics Output Fields (continued)

Field Name	Field Description	Level of Output
65–127 octets frames	Number of packets received on the VCP (including invalid packets) that were between 65 and 127 octets in length, inclusive (excluding framing bits, but including FCS octets).	detail, extensive
128–255 octets frames	Number of packets received on the VCP (including invalid packets) that were between 128 and 255 octets in length, inclusive (excluding framing bits, but including FCS octets).	detail, extensive
256–511 octets frames	Number of packets received on the VCP (including invalid packets) that were between 256 and 511 octets in length, inclusive (excluding framing bits, but including FCS octets).	detail, extensive
512–1023 octets frames	Number of packets received on the VCP (including invalid packets) that were between 512 and 1023 octets in length, inclusive (excluding framing bits, but including FCS octets).	detail, extensive
1024–1518 octets frames	Number of packets received on the VCP (including invalid packets) that were between 1024 and 1518 octets in length, inclusive (excluding framing bits, but including FCS octets).	detail, extensive
Rate packets per second	Number of packets per second received and transmitted on the VCP.	detail, extensive
Rate bytes per second	Number of bytes per second received and transmitted on the VCP.	detail, extensive

Sample Output

show virtual-chassis vc-port statistics

```
user@switch> show virtual-chassis vc-port statistics
```

```
fpc0:
```

```
-----
Interface      Input  Octets/Packets      Output  Octets/Packets
internal-0/24   0          / 0                0          / 0
internal-0/25   0          / 0                0          / 0
internal-1/26   0          / 0                0          / 0
internal-1/27   0          / 0                0          / 0
vcp-0           0          / 0                0          / 0
vcp-1           0          / 0                0          / 0
internal-0/26   0          / 0                0          / 0
internal-0/27   0          / 0                0          / 0
internal-1/24   0          / 0                0          / 0
internal-1/25   0          / 0                0          / 0
```

```
{master:0}
```

show virtual-chassis vc-port statistics (EX8200 Virtual Chassis)

```

user@external-routing-engine> show virtual-chassis vc-port statistics

member0:
-----
Interface          Input Octets/Packets      Output Octets/Packets
vcp-4/0/4           43171238 / 48152          47687133 / 51891
vcp-4/0/7           0 / 0                     0 / 0

member1:
-----
Interface          Input Octets/Packets      Output Octets/Packets
vcp-3/0/0           0 / 0                     0 / 0
vcp-3/0/1           0 / 0                     0 / 0
vcp-3/0/4           47695376 / 51899          43180556 / 48160

member8:
-----

member9:
-----

```

show virtual-chassis vc-port statistics brief

```

user@switch> show virtual-chassis vc-port statistics brief

fpc0:
-----
Interface          Input Octets/Packets      Output Octets/Packets
internal-0/24       0 / 0                     0 / 0
internal-0/25       0 / 0                     0 / 0
internal-1/26       0 / 0                     0 / 0
internal-1/27       0 / 0                     0 / 0
vcp-0               0 / 0                     0 / 0
vcp-1               0 / 0                     0 / 0
internal-0/26       0 / 0                     0 / 0
internal-0/27       0 / 0                     0 / 0
internal-1/24       0 / 0                     0 / 0
internal-1/25       0 / 0                     0 / 0

{master:0}

```

show virtual-chassis vc-port statistics extensive

```

user@switch> show virtual-chassis vc-port statistics extensive

fpc0:
-----

```

	RX	TX
Port: internal-0/24		
Total octets:	0	0
Total packets:	0	0
Unicast packets:	0	0
Broadcast packets:	0	0
Multicast packets:	0	0
MAC control frames:	0	0
CRC alignment errors:	0	

```

Oversize packets:      0
Undersize packets:    0
Jabber packets:       0
Fragments received:   0
Ifout errors:         0
Packet drop events:   0
  64      octets frames: 0
  65-127  octets frames: 0
  128-255 octets frames: 0
  256-511 octets frames: 0
  512-1023 octets frames: 0
  1024-1518 octets frames: 0
Rate packets per second: 0      0
Rate bytes per second: 0      0

...

Port: vcp-0
Total octets:      0      0
Total packets:     0      0
Unicast packets:   0      0
Broadcast packets: 0      0
Multicast packets: 0      0
MAC control frames: 0      0
CRC alignment errors: 0
Oversize packets: 0
Undersize packets: 0
Jabber packets:    0
Fragments received: 0
Ifout errors:      0
Packet drop events: 0
  64      octets frames: 0
  65-127  octets frames: 0
  128-255 octets frames: 0
  256-511 octets frames: 0
  512-1023 octets frames: 0
  1024-1518 octets frames: 0
Rate packets per second: 0      0
Rate bytes per second: 0      0

Port: vcp-1
Total octets:      0      0
Total packets:     0      0
Unicast packets:   0      0
Broadcast packets: 0      0
Multicast packets: 0      0
MAC control frames: 0      0
CRC alignment errors: 0
Oversize packets: 0
Undersize packets: 0
Jabber packets:    0
Fragments received: 0
Ifout errors:      0
Packet drop events: 0
  64      octets frames: 0
  65-127  octets frames: 0
  128-255 octets frames: 0
  256-511 octets frames: 0
  512-1023 octets frames: 0
  1024-1518 octets frames: 0

```

```

Rate packets per second: 0          0
Rate bytes per second:  0          0

...

{master:0}

```

show virtual-chassis vc-port statistics member 0

```
user@switch>show virtual-chassis vc-port statistics member 0
```

```
fpc0:
```

Interface	Input	Octets/Packets	Output	Octets/Packets
internal-0/24	0	/ 0	0	/ 0
internal-0/25	0	/ 0	0	/ 0
internal-1/26	0	/ 0	0	/ 0
internal-1/27	0	/ 0	0	/ 0
vcp-0	0	/ 0	0	/ 0
vcp-1	0	/ 0	0	/ 0
internal-0/26	0	/ 0	0	/ 0
internal-0/27	0	/ 0	0	/ 0
internal-1/24	0	/ 0	0	/ 0
internal-1/25	0	/ 0	0	/ 0

```
{master:0}
```


PART 4

Troubleshooting

- [Troubleshooting Procedures on page 391](#)

CHAPTER 7

Troubleshooting Procedures

- [Troubleshooting an EX Series Virtual Chassis on page 391](#)

Troubleshooting an EX Series Virtual Chassis

This topic describes the following troubleshooting issues for a Virtual Chassis:

- [A Disconnected Member Switch's ID Is Not Available for Reassignment on page 391](#)
- [Load Factory Default Does Not Commit on a Multimember Virtual Chassis on page 391](#)
- [The Member ID Persists When a Member Switch Is Disconnected From a Virtual Chassis on page 392](#)
- [A Member Switch Is Not Participating in a Mixed Virtual Chassis on page 392](#)
- [Unknown Traffic Looping Occurs After Configuring an Uplink Port as a Redundant VCP with a Dedicated VCP on page 394](#)

A Disconnected Member Switch's ID Is Not Available for Reassignment

Problem **Description:** You disconnected a switch from the Virtual Chassis, but the disconnected switch's member ID is still displayed in the status output. You cannot reassign that member ID to another switch.

Solution When you disconnect a member of a Virtual Chassis configuration, the master retains the member ID and member configuration in its configuration database. Output from the [show virtual-chassis](#) command continues to display the member ID of the disconnected member with a status of **NotPrsnt**.

If want to permanently disconnect the member switch, you can free up the member ID by using the [request virtual-chassis recycle](#) command. This will also clear the status of that member.

Load Factory Default Does Not Commit on a Multimember Virtual Chassis

Problem **Description:** The [load factory-default](#) command fails on a multimember Virtual Chassis.

Solution The **load factory-default** command is not supported on a multimember Virtual Chassis configuration. For information on how to revert the switches in the Virtual Chassis to factory default settings, see *Reverting to the Default Factory Configuration for the EX Series Switch*.

The Member ID Persists When a Member Switch Is Disconnected From a Virtual Chassis

Problem **Description:** Gigabit Ethernet interfaces retain their previous slot numbers when a member switch is disconnected from the Virtual Chassis.

Solution If a switch had been previously connected as a member of a Virtual Chassis configuration, it retains the member ID that it was assigned as a member of that configuration even after it is disconnected and operating as a standalone switch. The interfaces that were configured while the switch was a member of the Virtual Chassis configuration retain the old member ID as the first digit of the interface name.

For example, if the switch was previously member 1, its interfaces are named **ge-1/0/0** and so on.

To change the switch's member ID, so that its member ID is 0, and to rename the switch's interfaces accordingly:

1. To change the member ID to 0:

```
user@switch> request virtual-chassis renumber member-id 1 new-member-id 0
```

2. To rename the interfaces to match the new member ID:

```
[edit virtual-chassis]  
user@switch# replace pattern ge-1/ with ge-0/
```

A Member Switch Is Not Participating in a Mixed Virtual Chassis

Problem **Description:** A member switch in a mixed Virtual Chassis is not participating in the Virtual Chassis. The **show virtual-chassis** output indicates the member switch status is **Inactive** or **NotPrsnt**.

This issue is most likely to occur immediately after you have cabled a mixed Virtual Chassis.

Solution The Virtual Chassis mode on the switch might not be set to **mixed** mode. If the member switch is an EX4500 switch and is cabled into the Virtual Chassis through the dedicated Virtual Chassis port (VCP), the PIC mode might also be set to **Intraconnect** instead of **virtual-chassis**.

To verify the Virtual Chassis mode:

```
user@switch> show virtual-chassis mode
```

```
fpc0:
-----
Mixed Mode: Enabled
fpc1:
-----
Mixed Mode: Enabled
fpc2:
-----
Mixed Mode: Enabled
fpc3:
-----
Mixed Mode: Enabled
fpc4:
-----
Mixed Mode: Disabled
fpc5:
-----
Mixed Mode: Enabled
```

To change the Virtual Chassis mode on a member switch (in this case, member ID 4) to **mixed** mode:

```
user@switch> request virtual-chassis mode mixed member 4
```

(EX4500 switch only) To verify the PIC mode:

```
user@switch> show chassis pic-mode
```

```
fpc0:
-----
Pic Mode: Not-Applicable
fpc1:
-----
Pic Mode: Not-Applicable
fpc2:
-----
Pic Mode: Not-Applicable
fpc3:
-----
Pic Mode: Not-Applicable
fpc4:
-----
Pic Mode: PIC 3: Intraconnect
fpc5:
-----
Pic Mode: PIC 3: virtual-chassis
```

To change the PIC mode on an EX4500 switch to **virtual-chassis** mode (in this case, member ID 4):

```
user@switch> request chassis pic-mode virtual-chassis member 4
```

The member switch must be rebooted for the Virtual Chassis mode or PIC mode setting change to take effect. To reboot the member switch (in this case, member ID 4):

```
user@switch> request system reboot member 4
```

Unknown Traffic Looping Occurs After Configuring an Uplink Port as a Redundant VCP with a Dedicated VCP

Problem **Description:** In a Virtual Chassis comprised of EX4200, EX4500, or EX4550 switches, you observe unrecoverable looping of unknown unicast or multicast traffic following the addition of a redundant VCP link between two member switches, when the two members are connected by a dedicated VCP link and the redundant link was created by converting uplink ports to VCPs.

This behavior can occur whether the redundant VCP link is created by setting the ports manually as VCPs or if the automatic VCP conversion feature is invoked and converts the ports into VCPs automatically.

Solution Reboot the Virtual Chassis to properly detect the converted VCP as a redundant link with the dedicated VCP link.

After the conversion from a network port to a VCP, the egress filter table is not updated and the redundant VCP remains enabled for forwarding, which causes the looping behavior. The reboot process detects the converted port as a VCP and brings it up as disabled for forwarding.

As a result, we do not recommend connecting redundant converted uplink VCP ports between members already connected by dedicated VCPs on an active Virtual Chassis; instead, plan to add redundant uplink VCP connections during a maintenance window that can include a Virtual Chassis reboot cycle. This recommendation also applies when adding a new member to an existing active Virtual Chassis where you are adding redundant VCP links between the new member and one of its neighbors that mix dedicated VCPs and converted uplink VCPs.

- Related Documentation**
- [Monitoring the Virtual Chassis Status and Statistics on EX Series Virtual Chassis on page 287](#)
 - [Configuring an EX4200, EX4500, or EX4550 Virtual Chassis \(CLI Procedure\) on page 184](#)
 - [Configuring a Mixed Virtual Chassis with EX4200, EX4500, and EX4550 Member Switches \(CLI Procedure\) on page 195](#)
 - [Configuring a Virtual Chassis on an EX Series Switch \(J-Web Procedure\) on page 189](#)