



JunosE™ Software for E Series™ Broadband Services Routers

System Event Logging Reference Guide

Release

14.2.x



Published: 2013-03-21

Juniper Networks, Inc.
1194 North Mathilda Avenue
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

JunosE™ Software for E Series™ Broadband Services Routers System Event Logging Reference Guide
Release 14.2.x
Copyright © 2013, Juniper Networks, Inc.
All rights reserved.

Revision History
April 2013—FRS JunosE 14.2.x

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Abbreviated Table of Contents

	About the Documentation	xvii
Part 1	Chapters	
Chapter 1	System Logging Overview	3
Chapter 2	Event Categories	21
Part 2	Event Categories	
Chapter 3	A Commands	25
Chapter 4	B Commands	35
Chapter 5	C Commands	51
Chapter 6	D Commands	57
Chapter 7	E Commands	79
Chapter 8	F Commands	81
Chapter 9	G and H Commands	87
Chapter 10	I Commands	91
Chapter 11	L Commands	129
Chapter 12	M Commands	145
Chapter 13	N Commands	165
Chapter 14	O Commands	169
Chapter 15	P Commands	193
Chapter 16	Q Commands	213
Chapter 17	R Commands	215
Chapter 18	S Commands	229
Chapter 19	T Commands	247
Chapter 20	U Commands	255
Chapter 21	V Commands	257
Part 3	Index	
	Index	263

Table of Contents

	About the Documentation	xvii
	E Series and JunosE Documentation and Release Notes	xvii
	Audience	xvii
	E Series and JunosE Text and Syntax Conventions	xvii
	Obtaining Documentation	xix
	Documentation Feedback	xix
	Requesting Technical Support	xix
	Self-Help Online Tools and Resources	xx
	Opening a Case with JTAC	xx
Part 1	Chapters	
Chapter 1	System Logging Overview	3
	Overview of System Logging	3
	Log Severity	3
	Log Verbosity	4
	Persistent Logs	4
	Logging Platform Considerations	5
	Configuring Event Logging	5
	Configuring Log Severity for Individual and Systemwide Logs	10
	Configuring Log Verbosity for Individual Logs or All Logs	13
	Setting the Timestamp for Log Messages	14
	Configuring Log Filters	15
	Turning Off Log Filters	16
	Monitoring Logging System Events	16
Chapter 2	Event Categories	21
Part 2	Event Categories	
Chapter 3	A Commands	25
	aaaAtm1483Cfg	25
	aaaEngineGeneral	26
	aaaQosCfg	26
	aaaServerGeneral	27
	aaaUserAccess	28
	addressServerGeneral	28
	ar1AaaServerGeneral	29
	atm	29
	atm1483	30
	atm1483VcClass	31
	atmAal5	31

	atmVcClass	32
	auditIpsec	32
Chapter 4	B Commands	35
	bfdAdaptivity	35
	bfdEvents	36
	bfdGeneral	36
	bfdSession	37
	bgpConnections	37
	bgpDampening	38
	bgpEvents	39
	bgpGeneral	40
	bgpGracefulRestart	40
	bgpIpv6Issu	41
	bgpIpv6NextHops	42
	bgpKeepAlives	42
	bgpMessages	43
	bgpNeighborChanges	44
	bgpNextHops	45
	bgpRoutes	45
	bridge	48
	bridgeEngine	49
	bridgingMgr	49
	bulkStats	50
Chapter 5	C Commands	51
	cacGeneral	51
	cacIntf	52
	cliCommand	52
	cliGeneral	53
	connectionManager	53
	cops	54
	copsPr	54
	coreDump	55
	ctreeLog	55
Chapter 6	D Commands	57
	dcm	58
	dcmEngineGeneral	58
	debounceEvents	59
	debounceGeneral	59
	dhcpCapture	60
	dhcpExternal	60
	dhcpExternalEngine	61
	dhcpGeneral	61
	dhcpIssuLog	62
	dhcpLocalClients	62
	dhcpLocalGeneral	63
	dhcpLocalHighAvailability	63
	dhcpLocalPool	64

	dhcpLocalProtocol	64
	dhcpOfferLog	65
	dhcpPbeGeneral	66
	dhcpProxyGeneral	66
	dhcpRelayGeneral	67
	dhcpRelayNvWriterGeneral	67
	dhcpv6Client	68
	dhcpv6DemuxGeneral	68
	dhcpv6LocalSubInterfaceTable	69
	dhcpv6LsGeneral	69
	dismanEventManager	70
	dnsGeneralLog	71
	dosProtection	71
	ds1	72
	ds3	72
	dvmrpGeneral	73
	dvmrpGracefulRestart	74
	dvmrpMcastTable	74
	dvmrpProbeRcv	75
	dvmrpProbeSent	75
	dvmrpRtTable	76
Chapter 7	E Commands	79
	ethernet	79
	ethernetStateSession	79
Chapter 8	F Commands	81
	fileSystem	81
	flowInspection	82
	flowInspectionEngine	82
	flowServicesFirewallAlert	83
	flowServicesFirewallAudit	83
	frameRelay	84
	fsAgent	84
	ft1	85
	ftpClient	85
	ftpServer	86
Chapter 9	G and H Commands	87
	gplaan	87
	ha	87
	hdlc	88
	hotfixGeneral	89
	httpServer	89
Chapter 10	I Commands	91
	icImageFixServer	92
	icmpTraffic	93
	icmpv6Traffic	94
	icrPartitionManager	94

igmpGeneral	95
igmpGracefulRestart	96
igmpGroupState	97
ikeCertificateMgr	97
ikeEnrollment	98
ikepki	98
interModuleCommunication	99
ipAccessList	100
ipEngine	100
ipEngineering	101
ipflowstats	101
ipflowstatsEngine	102
ipGeneral	102
ipIfCreator	104
ipInterface	104
ipNhopTrackerGeneral	105
ipProfileMgr	105
ipRoutePolicy	106
ipRouteTable	106
ipseclDb	107
ipsecPIThrottler	107
ipsecXcfgSM	108
ipSubscriberMgr	108
ipTraffic	109
ipTunnel	109
ipv6AccessList	110
ipv6Engineering	111
ipv6General	111
ipv6Interface	112
ipv6ProfileMgr	113
ipv6RouteTable	113
ipv6Traffic	114
ipv6Types	115
isisAdjChange	115
isisAdjPackets	116
isisBfdEvents	117
isisChecksumErr	117
isisGeneral	118
isisHelloGeneral	118
isisHelloPackets	119
isisIpv6Log	119
isisLdpEvents	120
isisLocalUpdate	120
isisMplsTeAdvertisements	121
isisMplsTeEvents	122
isisNsfEvents	122
isisProtocolErr	123
isisSnppackets	123
isisSpfEvents	124

	isisSpfStatistics	124
	isisSpfTriggers	125
	isisUpdatePackets	125
	isVoice	126
	itm	126
Chapter 11	L Commands	129
	l2cGeneral	130
	l2cKeepAlive	130
	l2cPacket	131
	l2tp	131
	l2tpDialoutGenerator	132
	l2tpDisconnectCause	132
	l2tpIpLowerBinding	133
	l2tpStateMachine	133
	lasv6General	134
	ldpConnect	134
	ldpGeneral	135
	ldpGracefulRestart	135
	ldpHelloMessages	136
	ldpHelloMgr	136
	ldpInterface	137
	ldpMessages	138
	ldpPeer	138
	ldpShimInterface	139
	ldpSocket	140
	ldpTimer	140
	ldpVpls	141
	ldpWorker	141
	localAddressServerGeneral	142
	localAuthServer	142
	localEnableAuthServer	143
	localLinePassword	143
Chapter 12	M Commands	145
	macroData	146
	macroScheduler	146
	mgtmGeneral	147
	mgtmGracefulRestart	148
	mgtmv6General	148
	mgtmv6GracefulRestart	149
	mldGeneral	150
	mldGracefulRestart	151
	mldGroupState	151
	mmcd	152
	mobileIpv4HaBinding	152
	mobileIpv4HaEng	153
	mobileIpv4HaEvent	153
	mobileIpv4HaLog	154
	mplsFwdTable	154

	mplsGeneral	155
	mplsHighAvailability	155
	mplsMajorInterface	156
	mplsMinorInterface	157
	mplsRouter	158
	mplsShimInterface	158
	mplsTraffic	159
	mrInfoLog	159
	mrInfoRcvdLog	160
	mrInfoSentLog	160
	mtraceLog	161
	mtraceRcvdLog	161
	mtraceSentLog	162
	multicastTraffic	162
Chapter 13	N Commands	165
	nameResolverLog	165
	nfsClient	165
	noneAaaAddrServer	166
	noneAaaServer	166
	ntpGeneral	167
Chapter 14	O Commands	169
	oam3ahAssociations	170
	oam3ahEvents	170
	oam3ahPdus	171
	os	171
	ospfElectDr	172
	ospfGeneral	173
	ospfHelloPktsRcvd	174
	ospfHelloPktsSent	175
	ospfInterface	176
	ospfLdpEvents	176
	ospfLsa	177
	ospfNeighbor	177
	ospfPktsRcvd	178
	ospfPktsSent	178
	ospfRestart	179
	ospfRoute	180
	ospfSpfExt	180
	ospfSpfInter	181
	ospfSpfIntra	181
	ospfTeDatabase	182
	ospfTeSpf	182
	ospfv3ElectDr	183
	ospfv3General	184
	ospfv3HelloPktsRcvd	185
	ospfv3HelloPktsSent	185
	ospfv3Interface	186
	ospfv3Lsa	187

	ospfv3Neighbor	187
	ospfv3PktsRcvd	188
	ospfv3PktsSent	189
	ospfv3Route	189
	ospfv3SpfExt	190
	ospfv3SpfInter	190
	ospfv3SpfIntra	191
Chapter 15	P Commands	193
	pimAutoRPRcvdLog	194
	pimAutoRPSentLog	195
	pimBsrRcvdLog	195
	pimBsrSentLog	196
	pimGracefulRestartLog	197
	pimHelloRcvdLog	197
	pimHelloSentLog	198
	pimIpv6AutoRPRcvdLog	198
	pimIpv6AutoRPSentLog	199
	pimIpv6BsrRcvdLog	200
	pimIpv6BsrSentLog	201
	pimIpv6GracefulRestartLog	201
	pimIpv6HelloRcvdLog	202
	pimIpv6HelloSentLog	203
	pimIpv6PktsRcvdLog	203
	pimIpv6PktsSentLog	204
	pimPktsRcvdLog	205
	pimPktsSentLog	205
	pimsmGeneral	206
	pimsmMvpn	206
	policyMgrAttachment	207
	policyMgrGeneral	207
	policyMgrPacketLog	208
	ppp	208
	pppoe	209
	pppoeControlPacket	210
	pppPacket	210
	pppStateMachine	211
	profileMgr	212
Chapter 16	Q Commands	213
	qm	213
	qos	213
	qosAttachment	214
Chapter 17	R Commands	215
	radiusAttributes	215
	radiusClient	216
	radiusCoAAttributes	216
	radiusDisconnectGeneral	217
	radiusRelayGeneral	217

	radiusSendAttributes	218
	remOps	219
	resourceThresholdTrap	219
	ripBfd	220
	ripGeneral	220
	ripRoute	221
	ripRtTable	222
	routeDownloader	222
	routerLog	223
	rsvpAsyncMgr	224
	rsvpBfd	224
	rsvpGeneral	225
	rsvpGracefulRestart	225
	rsvpInterface	226
	rsvpTunnel	226
Chapter 18	S Commands	229
	security	230
	serviceability	230
	serviceMgr	231
	serviceMgrClientSession	231
	serviceMgrDcm	232
	serviceMgrMacroManager	232
	serviceMgrPerformance	233
	serviceMgrServiceDef	233
	serviceMgrServiceInstance	234
	serviceMgrServiceSession	234
	serviceMgrSubscriberSession	235
	sftpClient	235
	slep	236
	snmp	236
	snmpIfMib	237
	snmpPduAudit	237
	snmpSetPduAudit	238
	snmpTrap	238
	sonet	239
	sonetPath	239
	sonetVT	240
	ssccDetailPm	240
	ssccDetailSsc	241
	ssccGeneral	241
	ssccLacGeneral	242
	ssh	242
	stTunnel	243
	stTunnelEngine	244
	system	244
Chapter 19	T Commands	247
	tacacsPlusServer	247
	tcpGeneral	248

	tcpTraffic	248
	tcpv6Traffic	249
	telnet	250
	telnetClient	250
	tftpClient	251
	trackerEvents	251
	trackerGeneral	252
	tsm	252
Chapter 20	U Commands	255
	udpTraffic	255
	udpv6Traffic	256
Chapter 21	V Commands	257
	vrrp	257
	vrrpTracking	258
	vsm	258
	vsmEngine	259
Part 3	Index	
	Index	263

List of Tables

	About the Documentation	xvii
	Table 1: Notice Icons	xviii
	Table 2: Text and Syntax Conventions	xviii
Part 1	Chapters	
Chapter 1	System Logging Overview	3
	Table 3: Log Severity Descriptions	4

About the Documentation

- E Series and JunosE Documentation and Release Notes on page xvii
- Audience on page xvii
- E Series and JunosE Text and Syntax Conventions on page xvii
- Obtaining Documentation on page xix
- Documentation Feedback on page xix
- Requesting Technical Support on page xix

E Series and JunosE Documentation and Release Notes

For a list of related JunosE documentation, see
<http://www.juniper.net/techpubs/software/index.html>.

If the information in the latest release notes differs from the information in the documentation, follow the *JunosE Release Notes*.

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at
<http://www.juniper.net/techpubs/>.

Audience

This guide is intended for experienced system and network specialists working with Juniper Networks E Series Broadband Services Routers in an Internet access environment.

E Series and JunosE Text and Syntax Conventions

Table 1 on page xviii defines notice icons used in this documentation.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2 on page xviii defines text and syntax conventions that we use throughout the E Series and JunosE documentation.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents commands and keywords in text.	<ul style="list-style-type: none"> Issue the clock source command. Specify the keyword exp-msg.
Bold text like this	Represents text that the user must type.	host1(config)#traffic class low-loss1
Fixed-width text like this	Represents information as displayed on your terminal's screen.	host1#show ip ospf 2 Routing Process OSPF 2 with Router ID 5.5.0.250 Router is an Area Border Router (ABR)
<i>Italic text like this</i>	<ul style="list-style-type: none"> Emphasizes words. Identifies variables. Identifies chapter, appendix, and book names. 	<ul style="list-style-type: none"> There are two levels of access: <i>user</i> and <i>privileged</i>. <i>clusterId</i>, <i>ipAddress</i>. <i>Appendix A, System Specifications</i>
Plus sign (+) linking key names	Indicates that you must press two or more keys simultaneously.	Press Ctrl + b.
Syntax Conventions in the Command Reference Guide		
Plain text like this	Represents keywords.	terminal length
<i>Italic text like this</i>	Represents variables.	<i>mask</i> , <i>accessListName</i>

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
(pipe symbol)	Represents a choice to select one keyword or variable to the left or to the right of this symbol. (The keyword or variable can be either optional or required.)	diagnostic line
[] (brackets)	Represent optional keywords or variables.	[internal external]
[]* (brackets and asterisk)	Represent optional keywords or variables that can be entered more than once.	[level1 level2 l1]*
{ } (braces)	Represent required keywords or variables.	{ permit deny } { in out } { clusterId ipAddress }

Obtaining Documentation

To obtain the most current version of all Juniper Networks technical documentation, see the Technical Documentation page on the Juniper Networks Web site at <http://www.juniper.net/>.

To download complete sets of technical documentation to create your own documentation CD-ROMs or DVD-ROMs, see the Portable Libraries page at

<http://www.juniper.net/techpubs/resources/index.html>

Copies of the Management Information Bases (MIBs) for a particular software release are available for download in the software image bundle from the Juniper Networks Web site at <http://www.juniper.net/>.

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation to better meet your needs. Send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract,

or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf> .
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/> .
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum: <http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

PART 1

Chapters

- [System Logging Overview on page 3](#)
- [Event Categories on page 21](#)

CHAPTER 1

System Logging Overview

E Series Broadband Services Routers enable you to log system events to discover and isolate problems with your system. This chapter explains how to use the command-line interface (CLI) to monitor your system's log configuration and stay informed about all system events that you want to track.

This chapter contains the following sections:

- [Overview of System Logging on page 3](#)
- [Logging Platform Considerations on page 5](#)
- [Configuring Event Logging on page 5](#)
- [Configuring Log Severity for Individual and Systemwide Logs on page 10](#)
- [Configuring Log Verbosity for Individual Logs or All Logs on page 13](#)
- [Setting the Timestamp for Log Messages on page 14](#)
- [Configuring Log Filters on page 15](#)
- [Turning Off Log Filters on page 16](#)
- [Monitoring Logging System Events on page 16](#)

Overview of System Logging

System events are classified into event categories. Using the CLI, you can determine which event categories to log. To fully utilize the logging facility, you need to understand *log severity* and *log verbosity*.

Log Severity

Log severity is a level that is assigned to an event or log message. Log severity levels apply to event categories, such as `bulkStats`, `bgpRoutes`, or `atm1483`.

The minimum severity of a log message for an individual category is described either by a severity number in the range 0–7 or a descriptive priority term, such as *emergency* or *debug*. The lower the severity number is, the higher the priority. See [Table 3 on page 4](#).



NOTE: Not every event category supports every severity level. For a list of event categories and the severity levels that each category supports, see “Event Categories” on page 21.

Table 3: Log Severity Descriptions

Severity Number	Severity Name	System Response
0	Emergency	System unusable; shelf reset
1	Alert	Immediate action needed; card reset
2	Critical	Critical conditions exist; interface is down
3	Error	Error conditions; nonrecoverable software error
4	Warning	Warning conditions; recoverable software error
5	Notice	Normal but significant conditions; nonerror, low-verbosity information
6	Info	Informational messages; nonerror, medium-verbosity information
7	Debug	Debug messages; nonerror, high-verbosity information

Log Verbosity

The verbosity level determines the amount of information that appears in each message. You can assign the verbosity level for the log category. Verbosity levels can be any of the following:

- Low—Terse
- Medium—Moderate
- High—Verbose



NOTE: Many event categories provide only low-verbosity detail regardless of the verbosity setting.

Persistent Logs

Log messages can survive a system reboot. After a reboot, the system rebuilds the list of log messages. However, if the system detects any problems or has gone through a power cycle, the buffer is reset, and the log messages from the previous session are lost.

Log messages are not synchronized between primary and redundant SRP modules. During a switchover from a primary to a redundant SRP module, existing log messages are not transferred to the redundant SRP module.

Logging Platform Considerations

System logs are supported on all E Series routers.

For information about the modules supported on E Series routers:

- See the *ERX Module Guide* for modules supported on ERX7xx models, ERX14xx models, and the Juniper Networks ERX310 Broadband Services Router.
- See the *E120 and E320 Module Guide* for modules supported on the Juniper Networks E120 and E320 Broadband Services Routers.

Configuring Event Logging

By default, event logging is enabled and has default settings. This section explains how to change settings to customize event logging to fit your needs.

- Set a baseline for when the system begins logging messages.

```
host1#baseline log 11:12:55 April 30 2002
```

- Set the log severity.

```
host1(config)#log severity warning
```

- Remove the limit on the number of buffers available for an event category.

```
host1(config)#log unlimit qos
```

- Set the log verbosity.

```
host1(config)#log verbosity low
```

- Log messages to a specified destination.

```
host1(config)#log destination syslog 10.10.9.5 include ospfGeneral
mplsGeneral os
```

- Select fields to be added to logs.

```
host1(config)#log fields timestamp instance no-calling-task
```

- Enable logs destined for a console to be displayed at the current console device.

```
host1#log here
```

The next sections explain how to configure individual and systemwide logs, how to format timestamps for log messages, and how to configure log filters.

- baseline log**
- Use to set a baseline for logging events. Only log messages timestamped after the baseline appear when you enter the **show log data delta** command.
 - To use the current system time, do not enter any options.
 - To set a specific time, use the following syntax:

Hour:Minute[:Second]—Current time in 24-hour format. Seconds are optional.

- **utc**—Enter this keyword to indicate that the time entered is in universal coordinated time (UTC), rather than local time.

- To set a specific date, use the following syntax:

Month Day Year—You must spell out the name of the month.

- **last-reset**—Causes the system to display log messages generated since the last time the system was reset

- Examples

```
host1#baseline log 11:12:55 April 30 2002
host1#baseline log last-reset
```

- There is no **no** version.
- See baseline log.

- log destination**
- Use to log messages to the specified destination, including system log, console, and nv-file (nonvolatile storage).



NOTE: You can display traffic logs—such as ipTraffic, icmpTraffic, tcpTraffic, and udpTraffic—only through the **show log data** command or from the SRP module console. You cannot redirect traffic logs elsewhere, such as to a system log or nonvolatile storage file, or to a Telnet session.

- Use the **severity** keyword to limit the messages logged based on priority level.
- The following information applies to logging messages to system log servers.
 - You can have multiple system log servers, but must configure logging to each one separately.
 - A particular message within a specified event category is logged to a particular system log server only if the priority of the message is greater than or equal to both the priority of the event category and the priority of that system log server.
 - If you log messages to a system log server, you can also specify:
 - **facility**—Specifies a facility ID on the system log destination host. The range is 0–7, representing the logging facilities local0–local7.
 - **include**—Logs only the listed categories to system log; no other categories are logged unless specifically included by issuing this command again.
 - **exclude**—Logs all categories to system log except the listed categories; all other categories are logged unless specifically excluded by issuing this command again.
 - Issuing an **include** command after an **exclude** command (or vice versa) overrides the earlier command. Therefore, you cannot enter a command including certain categories and then follow it with a command excluding others. Similarly, you cannot

enter a command excluding certain categories and then follow it with a command including others.

- You can issue successive **include** commands or successive **exclude** commands; in this case, the successive commands expand the list of included or excluded categories.
- Example 1—The first command causes only the ospfGeneral, mplsGeneral, and os event categories to be logged to system log at 10.10.9.5. The second command reverses this inclusion and restores the logging of all event categories.

```
host1(config)#log destination syslog 10.10.9.5 include ospfGeneral
mplsGeneral os
host1(config)#no log destination syslog 10.10.9.5
```

- Example 2—The first command again causes only the ospfGeneral, mplsGeneral, and os event categories to be logged to system log at 10.10.9.5. The second command reverses the inclusion of ospfGeneral and os. The mplsGeneral category is still included and is thus the only category logged.

```
host1(config)#log destination syslog 10.10.9.5 include ospfGeneral mplsGeneral os
host1(config)#no log destination syslog 10.10.9.5 include ospfGeneral os
```

- Example 3—The first command causes the isisGeneral, ipRoutePolicy, and ipTraffic event categories to be excluded from logging to system log at 10.1.2.3. The second command reverses this exclusion and restores the logging of all event categories.

```
host1(config)#log destination syslog 10.1.2.3 exclude isisGeneral ipRoutePolicy ipTraffic
host1(config)#no log destination syslog 10.1.2.3 exclude
```

- Example 4—The first command again causes the isisGeneral, ipRoutePolicy, and ipTraffic event categories to be excluded from logging to system log at 10.1.2.3. The second command reverses the exclusion of ipRoutePolicy and ipTraffic. The isisGeneral category is still excluded; all other events are logged.

```
host1(config)#log destination syslog 10.1.2.3 exclude isisGeneral
ipRoutePolicy ipTraffic
host1(config)#no log destination syslog 10.1.2.3 exclude isisGeneral
```

- Example 5—The first command causes the isisGeneral event category to be excluded from logging to system log at 10.1.2.3. The second command causes ospfGeneral to also be excluded from logging.

```
host1(config)#log destination syslog 10.1.2.3 exclude isisGeneral
host1(config)#log destination syslog 10.1.2.3 exclude ospfGeneral
```

- Example 6—The first command causes the isisGeneral event category to be excluded from logging to system log at 10.1.2.3; all other events are logged. The second command overrides the first and causes the exclusion of all events except ospfGeneral.

```
host1(config)#log destination syslog 10.1.2.3 exclude isisGeneral
host1(config)#log destination syslog 10.1.2.3 include ospfGeneral
```

- Use the **no** version to reverse the effects of previous commands or restore the default, which is to log all event categories.
- See log destination.

- log destination syslog source**
- Use to specify a source interface type and location for events logged to system log at the specified IP address.
 - Overrides the actual source interface type and location. The IP address associated with the specified source interface is used as the source address for subsequent system log messages.
 - Example
`host1(config)#log destination syslog 10.1.2.3 source atm 0/1`
 - Use the **no** version to restore the actual source interface type and location.
 - See log destination syslog source.
- log engineering**
- Use to enable engineering logs.
 - Provides troubleshooting information to assist you when contacting Juniper Networks Technical Assistance Center (JTAC).
 - Example
`host1(config)#log engineering`
 - Use the **no** form of this command to disable engineering logs.
 - See log engineering.
- log fields**
- Use to select fields to be added to all logs. These fields include a timestamp for the message, an instance identifier, and the name of the internal software application that created the message.
 - Example
`host1(config)#log fields timestamp instance no-calling-task`
 - Use the **no** version to restore the default log field settings.
 - See log fields.
- log here**
- Use to enable logs destined for a console to be displayed at the current console.
 - By default, the local console automatically receives all log messages if console is a destination. The exception is the cliCommand log, whose log events do not appear on the console.
 - By default, Telnet consoles do not receive log messages.
 - Example
`host1#log here`
 - Use the **no** version to disable logs destined for a console from being displayed on this console.
 - See log here.

- log severity**
- Use to set the severity level for systemwide logs (that is, when you do not specify an individual event category) or for a specific event category. For a list of severity values, see [Table 3 on page 4](#).



NOTE: Assigning a log severity to an individual event category changes its state to Assigned. You cannot change the severity of that event category using systemwide level commands until you return the event category to its default, unassigned state with the **no log severity** command.

- If you do not specify a category, the severity value changes for all categories except individual categories for which you previously set a specific severity level. See [“Configuring Log Severity for Individual and Systemwide Logs” on page 10](#) for details.
- Each event category has its own default severity value. For most categories, the default is Error.
- To disable all *default* level log messages, use the **off** keyword without specifying an event category.
- To disable individual level log messages, use the **off** keyword and specify the event category that you want to disable.
- Example


```
host1(config)#log severity warning
```
- Use the **no** version to return the systemwide (when assigned) or default severity values to event categories.
- Use the **no** version with an* (asterisk) to return all event categories (modified either systemwide or individually) to their default severity setting. For example:


```
host1(config)#no log severity *
```
- See log severity.

- log unlimited**
- Use to remove the limit on the number of outstanding buffers for an event category, such as when the system is dropping logs of a particular category.
 - Example


```
host1(config)#log unlimited qos
```
 - Use the **no** version to return to the default value.
 - See log unlimited.

- log verbosity**
- Use to set the verbosity level for a selected category or for all categories.
 - If you do not specify a category, then the verbosity level is set for all categories.
 - The default verbosity setting for all logs is low.
 - Example


```
host1(config)#log verbosity low
```

- Use the **no** version to return to the default verbosity (low) for the selected category.
- See log verbosity.

Configuring Log Severity for Individual and Systemwide Logs

You can change the severity setting for *individual* logs and the *systemwide* value.

When working with log severities, keep the following in mind:

- All log event categories have a default. However, the default values can vary for each category. For example, most event categories have a default severity of Error. However, some event categories may have a default severity of Notice, Warning, Info, and so on.
- Log event categories have two states—unassigned (default) and assigned. How a log event category reacts to the **log severity** command depends on its current state.
- You can change log severities for event categories at a systemwide level or an individual level. Systemwide changes are those that modify a large number of unassigned event categories at one time; for example, the command **log severity debug off**. Individual changes are those that indicate an explicit event category that you want to change; for example, the command **log severity notice clicommand**.
- Changes to log event categories at an individual level take precedence over those made at the systemwide level.
- Changes to log event categories at the systemwide level take precedence over the default.
- Assigning a log severity to an individual event category changes its state to Assigned. This means that you cannot change the severity of that event category using systemwide level commands until you return the event category to its default, unassigned state by using the **no log severity eventCategory** command.
- To return all logs, systemwide and individual, to their default, unassigned severity level, use the **no log severity *** command.
- To see whether individual or systemwide severity and verbosity settings are in effect, use the **show log configuration** command.

Example The following example demonstrates the effects of event category state in regard to using systemwide commands:

1. In Configuration mode and having made no changes to the severity settings of any event categories, view the log configuration:

```
host1(config)#run show log config
log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here
```

```
Warning: Logging to this terminal is disabled
no log severity
```

category	severity	verbosity	filters	notes
-----	-----	-----	-----	-----
aaaAtm1483Cfg	ERROR	low		
aaaEngineGeneral	ERROR	low		
aaaServerGeneral	ERROR	low		
aaaUserAccess	ERROR	low		
addressServerGeneral	ERROR	low		
ar1AaaServerGeneral	ERROR	low		
atm	ERROR	low		
atm1483	ERROR	low		
atmAa15	ERROR	low		

Notice that the atm event category has a default severity of Error.

2. Change all event categories to Warning, systemwide, and view the log configuration:

```
host1(config)#log severity warning
host1(config)#run show log config
log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here

Warning: Logging to this terminal is disabled
log severity WARNING
```

category	severity	verbosity	filters	notes
-----	-----	-----	-----	-----
aaaAtm1483Cfg	WARNING	low		1
aaaEngineGeneral	WARNING	low		1
aaaServerGeneral	WARNING	low		1
aaaUserAccess	WARNING	low		1
addressServerGeneral	WARNING	low		1
ar1AaaServerGeneral	WARNING	low		1
atm	WARNING	low		1
atm1483	WARNING	low		1
atmAa15	WARNING	low		1

3. Change the atm category to have a log severity of Emergency and view the log configuration:

```
host1(config)#log severity emergency atm
host1(config)#run show log config
log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here

Warning: Logging to this terminal is disabled
log severity WARNING
```

category	severity	verbosity	filters	notes
-----	-----	-----	-----	-----
aaaAtm1483Cfg	WARNING	low		1
aaaEngineGeneral	WARNING	low		1
aaaServerGeneral	WARNING	low		1
aaaUserAccess	WARNING	low		1
addressServerGeneral	WARNING	low		1
ar1AaaServerGeneral	WARNING	low		1
atm	EMERGENCY	low		2

```

atm1483          WARNING    low          1
atmAa15          WARNING    low          1

```

4. Change all event categories to Alert, systemwide, and view the log configuration:

```

host1(config)#log severity alert
host1(config)#run show log config
log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here

```

```

Warning: Logging to this terminal is disabled
log severity ALERT

```

category	severity	verbosity	filters	notes
aaaAtm1483Cfg	ALERT	low		1
aaaEngineGeneral	ALERT	low		1
aaaServerGeneral	ALERT	low		1
aaaUserAccess	ALERT	low		1
addressServerGeneral	ALERT	low		1
ar1AaaServerGeneral	ALERT	low		1
atm	EMERGENCY	low		2
atm1483	ALERT	low		1
atmAa15	ALERT	low		1

Notice that the atm event category that you individually assigned in Step 3 does not change.

5. Turn off log notification, systemwide, and view the log configuration:

```

host1(config)#log severity off
host1(config)#run show log config
log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here

```

```

Warning: Logging to this terminal is disabled
log severity OFF

```

category	severity	verbosity	filters	notes
aaaAtm1483Cfg	OFF	low		1
aaaEngineGeneral	OFF	low		1
aaaServerGeneral	OFF	low		1
aaaUserAccess	OFF	low		1
addressServerGeneral	OFF	low		1
ar1AaaServerGeneral	OFF	low		1
atm	EMERGENCY	low		2
atm1483	OFF	low		1
atmAa15	OFF	low		1

Notice that the atm event category does not change.

6. Remove the assigned status of the atm event category and view the log configuration:

```

host1(config)#no log severity atm
host1(config)#run show log config

```

```

log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here

```

Warning: Logging to this terminal is disabled
log severity OFF

category	severity	verbosity	filters	notes
-----	-----	-----	-----	-----
aaaAtm1483Cfg	OFF	low		1
aaaEngineGeneral	OFF	low		1
aaaServerGeneral	OFF	low		1
aaaUserAccess	OFF	low		1
addressServerGeneral	OFF	low		1
ar1AaaServerGeneral	OFF	low		1
atm	OFF	low		1
atm1483	OFF	low		1
atmAa15	OFF	low		1

Notice that the atm event category follows the systemwide severity level of OFF. The systemwide setting takes precedence over the atm event category default of Error.

7. Change all event categories, systemwide, to their default/unassigned levels, and view the log configuration:

```

host1(config)#no log severity *
Please wait...
host1(config)#run show log config
log destination console severity WARNING
log destination nv-file severity CRITICAL
log destination syslog 10.10.4.240 facility 7 severity DEBUG
no log engineering
log fields timestamp instance no-calling-task
no log here

```

Warning: Logging to this terminal is disabled
no log severity

category	severity	verbosity	filters	notes
-----	-----	-----	-----	-----
aaaAtm1483Cfg	ERROR	low		
aaaEngineGeneral	ERROR	low		
aaaServerGeneral	ERROR	low		
aaaUserAccess	ERROR	low		
addressServerGeneral	ERROR	low		
ar1AaaServerGeneral	ERROR	low		
atm	ERROR	low		
atm1483	ERROR	low		
atmAa15	ERROR	low		

Configuring Log Verbosity for Individual Logs or All Logs

The default verbosity setting for all logs is low. To change the logging verbosity of an individual log, specify a category when you enter the **log verbosity** command. To change the log verbosity of every log, do not specify an event category when you enter the **log verbosity** command. However, after you enter the **log verbosity** command without

specifying a particular event category, all logs are set to the new verbosity. No log verbosity overrides are saved.

Example The following example sets all log categories to verbosity medium, and then it sets the verbosity level for ds3 events to high.

```
host1(config)#log verbosity medium
host1(config)#log verbosity high ds3
```

Setting the Timestamp for Log Messages

You can use the **service timestamps** command to format timestamps for log messages. By default, log messages display universal coordinated time (UTC) without the time zone.

The following examples illustrate how you can change the timestamp on log messages.

- Set the time zone to eastern daylight time (EDT), 5 hours behind UTC, and display the local time on the log messages.

```
host1(config)#clock timezone EDT -5
```

- Display UTC, but no time zone, on the log messages.

```
host1(config)#service timestamps log datetime
host1#exit
host1#show log data category cliCommand severity info
*****
NOTICE 05/14/2001 18:24:49 cliCommand: "configure terminal", console
NOTICE 05/14/2001 18:24:45 cliCommand: "service timestamps log datetime", console
*****
```

- Display UTC and the time zone on the log messages.

```
host1#configure terminal
host1(config)#service timestamps log datetime show-timezone
host1(config)#exit
host1#show log data category cliCommand severity info
*****
NOTICE 05/14/2001 18:28:45 UTC EDT cliCommand: "configure terminal", console
NOTICE 05/14/2001 18:28:42 UTC EDT cliCommand: "service timestamps log datetime
show-timezone", console
*****
```

- Display no timestamp on the log messages.

```
host1#configure terminal
host1(config)#no service timestamps
host1#exit
host1#show log data category cliCommand severity info
*****
NOTICE 134 cliCommand: "configure terminal", console
NOTICE 133 cliCommand: "no service timestamps", console
*****
```

- service timestamps**
- Use to format timestamps for log messages.
 - For information about setting local times and time zones, see *JunosE System Basics Configuration Guide*.

- The **show log data** command displays the log data with the current timestamp format.
- The **show log data nv-file** command displays the log data with the timestamp format in effect at the time the log record was written.
- Use the **no** version to remove timestamps from log messages.
- See service timestamps.

Configuring Log Filters

Many event categories contain filters so you can further refine the type of information that the system logs. For example, when logging BGP connections, you can limit the information logged to a specific access class, peer, route map, or virtual router.

You define filters when you set the log severity for an event category. The online Help shows the options you can set for each filter.



NOTE: You can use the packet flow monitoring feature to create user-defined classification parameters that specify the packet data that is logged. See [Packet Tagging Overview](#).

The following example creates a filter that logs BGP connection information at the debug severity level on traffic that matches access list ListOne, and is incoming traffic to virtual router default.

```
host1(config)# log severity debug bgpevents ?
  access-class  Select an access list for the filter
  in            Select import/in direction for the filter
  out          Select export/out direction for the filter
  peer         Select a peer IP address for the filter
  route-map    Select a route map for the filter
  router       Identify an instance of a virtual router
  <cr>
host1(config)# log severity debug bgpevents access-class ?
  WORD  The access list
host1(config)# log severity debug bgpevents access-class ListOne ?
  filtering-router  Identify virtual router where access-class/route-map are defined
  in               Select import/in direction for the filter
  out              Select export/out direction for the filter
  route-map       Select a route map for the filter
  <cr>
host1(config)# log severity debug bgpevents access-class ListOne route-map ?
  WORD  The route map
host1(config)# log severity debug bgpevents access-class ListOne route-map default ?
  filtering-router  Identify virtual router where access-class/route-map are defined
  in               Select import/in direction for the filter
  out              Select export/out direction for the filter
  <cr>
host1(config)# log severity debug bgpevents access-class ListOne route-map default in
```

The next example limits the logging of PPP debug events to traffic to or from the POS interface in slot 2/0.

```
host1(config)#log severity debug ppp ?
  atm          Specify an ATM PPP interface
  fastEthernet Specify a fastEthernet interface
  gigabitEthernet Specify a gigabitEthernet interface
  mlppp        Specify an MLPPP network interface
  pos          Specify a POS PPP interface
  serial       Specify a serial PPP interface
  <cr>
```

```
host1(config)#log severity debug ppp pos 2/0
```

To obtain a list of the filters available in each event category, see [“Event Categories” on page 21](#).

Turning Off Log Filters

You can turn off filters in three ways:

- Turn off all filters
- Turn off all filters for an event category
- Turn off a specific filter

To turn off all filters:

```
host1(config)#no log filters
```

To turn off all filters for an event category, use the **no** version of the **log severity** command along with the category name. For example:

```
host1(config)#no log severity bgpEvents filters
```

To turn off a specific filter, use the **no** version of the **log severity** command that you used to add the filter. For example:

```
host1(config)#no log severity bgpEvents peer 10.0.0.2 10.0.0.1
```

no log filters

- Use to turn off log filters.
- To turn off all filters for an event category, specify the category name.
- Example

```
host1(config)#no log filters
```

- To turn off a specific filter, use the **no** version of the **log severity** command that you used to add the filter.
- See no log filters.

Monitoring Logging System Events

Use the **show log configuration** command to display your log configuration. Use the **show log data** command to display system events on your screen.

You can use the output filtering feature of the **show** command to include or exclude lines of output based on a text string you specify. See *show Commands in JunosE System Basics Configuration Guide* for details.

show log configuration • Use to show the logging configuration on your system.

- Example 1—Factory defaults are set

```
host1#show log configuration
log destination console severity WARNING
log destination nv-file severity CRITICAL
no log engineering
log fields timestamp instance no-calling-task
no log severity
```

category	severity	verbosity	filters
NameResolverLog	ERROR	low	
aaaAtm1483Cfg	ERROR	low	
aaaEngineGeneral	ERROR	low	
aaaServerGeneral	ERROR	low	
addressServerGeneral	ERROR	low	
atm	ERROR	low	
atm1483	ERROR	low	
atmAa15	ERROR	low	
bgpConnections	ERROR	low	
...			
cliCommand	NOTICE	low	
controlNetworkSlave	ERROR	low	
cops	ERROR	low	
...			
udpTraffic	ERROR	low	

- Example 2—Individual log **udpTraffic** is set to warning

```
host1#(config)#log severity warning udpTraffic
host1##show log configuration
log destination console severity WARNING
log destination nv-file severity CRITICAL
no log engineering
log fields timestamp instance no-calling-task
no log severity
```

category	severity	verbosity	filters
NameResolverLog	ERROR	low	
aaaAtm1483Cfg	ERROR	low	
aaaEngineGeneral	ERROR	low	
aaaServerGeneral	ERROR	low	
addressServerGeneral	ERROR	low	
atm	ERROR	low	
atm1483	ERROR	low	
atmAa15	ERROR	low	
bgpConnections	ERROR	low	
...			
cliCommand	NOTICE	low	
controlNetworkSlave	ERROR	low	
cops	ERROR	low	
...			
udpTraffic	WARNING*	low	

* Default severity setting is overridden by the individual log severity setting.

- Example 3—Log severity is set to alert

```
host1#(config)#log severity alert
host1#show log configuration
log destination console severity WARNING
log destination nv-file severity CRITICAL
no log engineering
log fields timestamp instance no-calling-task
log severity ALERT
```

category	severity	verbosity	filters
-----	-----	-----	-----
NameResolverLog	ALERT#	low	
aaaAtm1483Cfg	ALERT#	low	
aaaEngineGeneral	ALERT#	low	
aaaServerGeneral	ALERT#	low	
addressServerGeneral	ALERT#	low	
atm	ALERT#	low	
atm1483	ALERT#	low	
atmAa15	ALERT#	low	
bgpConnections	ALERT#	low	
...			
cliCommand	ALERT#	low	
controlNetworkSlave	ALERT#	low	
cops	ALERT#	low	
...			
udpTraffic	ALERT#	low	

* Default severity setting is overridden by the system-wide severity setting.

- Example 4—Individual log atm is set to severity warning

```
host1#(config)#log severity warning atm
host1#show log configuration
log destination console severity WARNING
log destination nv-file severity CRITICAL
no log engineering
log fields timestamp instance no-calling-task
log severity ALERT
```

category	severity	verbosity	filters
-----	-----	-----	-----
NameResolverLog	ALERT#	low	
aaaAtm1483Cfg	ALERT#	low	
aaaEngineGeneral	ALERT#	low	
aaaServerGeneral	ALERT#	low	
addressServerGeneral	ALERT#	low	
atm	WARNING*	low	
atm1483	ALERT#	low	
atmAa15	ALERT#	low	
bgpConnections	ALERT#	low	
...			
cliCommand	ALERT#	low	
controlNetworkSlave	ALERT#	low	
cops	ALERT#	low	
...			
udpTraffic	ALERT#	low	

* Default severity setting is overridden by the system-wide severity setting.

* Default severity setting is overridden by the individual log severity setting.

- See show log configuration.

show log data • Use to display system events.

- Use keywords to select which events are displayed:

- **category**—Limits the display to a single log event category. See the CLI online Help for available categories.

- Example

```
host1#show log data category os
```

- **delta**—Limits the display to events that occurred after the time set with the log baseline command.

- **nv-file**—Displays the information that is currently logged to nonvolatile storage.

- Example

```
host1# show log data nv-file
logFile.temp: The system cannot find the file specified.
ALERT 09/12/2000 21:29:17 os: ASSERTION FAILED: file mplsNvs2.cc, line 789
ALERT 09/20/2000 02:18:06 os: ASSERTION FAILED: file osPool.cc, line 819
ALERT 09/20/2000 02:26:35 os: ASSERTION FAILED: file osPool.cc, line 819
ALERT 09/20/2000 02:44:33 os: ASSERTION FAILED: file osPool.cc, line 819
ALERT 09/20/2000 04:56:35 os: ASSERTION FAILED: file osPool.cc, line 819
ALERT 09/27/2000 03:10:25 os: ASSERTION FAILED: file
/sw0/sc/nvs/include/./nvMapBackend.h, line 235
ALERT 10/02/2000 04:05:42 os: ASSERTION FAILED: file osHeap.cc, line 439
ALERT 10/02/2000 04:08:04 os: ASSERTION FAILED: file osMessageQueue.cc,
line
42, rip1
ALERT 10/12/2000 03:43:38 os: PANIC: file osSemaphore.cc, line 54
ALERT 11/01/2000 02:03:49 os: ASSERTION FAILED: file cliCommand.cc, line
195
```

- **severity**—Displays events that have a specific severity level.

- Example

```
host1# show log data severity notice
NOTICE 01/10/2001 00:59:50 os: config -- using running
NOTICE 01/10/2001 00:59:52 os: srp application, build date: 0x3a437424 (FRI
DEC 22 2000 15:32:52 UTC)
NOTICE 01/10/2001 00:59:52 os: last reset: user reboot, reason: not specified
NOTICE 01/10/2001 00:59:52 os: OsIsrRegistrar: 0xb
NOTICE 01/10/2001 00:59:52 os: OsIsrRegistrar: 0xa
NOTICE 01/10/2001 00:59:52 os: OsIsrRegistrar: 0x2
```

- By combining keywords, you can further limit the information displayed. See the CLI online Help for information about the keywords available at each level.

```
host1#show log data nv-file severity alert
```

- See show log data.

CHAPTER 2

Event Categories

This chapter lists each event category in the system software. To help you determine the severity level to set when troubleshooting, the log strategy for each event category is included. The log strategy shows the type of information logged for each severity level. In addition, this chapter includes the filters available in each event category.

PART 2

Event Categories

- [A Commands on page 25](#)
- [B Commands on page 35](#)
- [C Commands on page 51](#)
- [D Commands on page 57](#)
- [E Commands on page 79](#)
- [F Commands on page 81](#)
- [G and H Commands on page 87](#)
- [I Commands on page 91](#)
- [L Commands on page 129](#)
- [M Commands on page 145](#)
- [N Commands on page 165](#)
- [O Commands on page 169](#)
- [P Commands on page 193](#)
- [Q Commands on page 213](#)
- [R Commands on page 215](#)
- [S Commands on page 229](#)
- [T Commands on page 247](#)
- [U Commands on page 255](#)
- [V Commands on page 257](#)

CHAPTER 3

A Commands

- [aaaAtm1483Cfg on page 25](#)
- [aaaEngineGeneral on page 26](#)
- [aaaQosCfg on page 26](#)
- [aaaServerGeneral on page 27](#)
- [aaaUserAccess on page 28](#)
- [addressServerGeneral on page 28](#)
- [ar1AaaServerGeneral on page 29](#)
- [atm on page 29](#)
- [atm1483 on page 30](#)
- [atm1483VcClass on page 31](#)
- [atmAal5 on page 31](#)
- [atmVcClass on page 32](#)
- [auditIpsec on page 32](#)

aaaAtm1483Cfg

Description	AAA ATM 1483 subinterface configuration
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Illegal service category traffic parameter received from AAA; unable to modify circuit traffic parameters using those received from AAA
Notice Log	None
Info	None

Debug Notification from AAA indicating that an ATM 1483 subinterface configuration is available; ATM 1483 processing configuration received from AAA; unable to get ATM 1483 subinterface information; number of ATM 1483 configuration entries is out of range

Filter None

aaaEngineGeneral

Description AAA engine general

Emergency None

Alert None

Critical None

Error None

Warning Log None

Notice Log Control flow and key events, less verbose than debug

Info None

Debug Control flow and key events

Filter None

aaaQosCfg

Description AAA QoS configuration logs

Emergency None

Alert None

Critical None

Error None

Warning Log None

Notice Log None

Info None

Debug AAA QoS configuration tracking

Filter None

aaaServerGeneral

Description AAA server general

Emergency None

Alert None

Critical None

Error Subscriber count exceeds license plus grace; internal attachment errors; unable to delete username trigger from NVS; unable to insert encrypted username trigger in NVS

Warning Log Subscriber count exceeds license; cannot grow internal memory pools; accounting message failures; the Framed-IPv6-Prefix RADIUS attribute is used for both IPv6 Neighbor Discovery router advertisements and DHCPv6 Prefix Delegation; Notify duplicate event ignored for profileHandle: *profileHandle* issu in progress; Notify duplicate event ignored for profileHandle: *profileHandle* unable to allocate memory; unable to delete trigger from aaaUsernameToTriggerDataMap

Notice Log Authentication failures resulting from memory allocation failures

Info None

Debug Authentication failures resulting from reasons other than memory allocation failures; status of authentication; accounting and address assignment requests sent to local (internal) servers; duplicate accounting message failures; EAP challenge received; memory allocation failure for tunnel definition table and profile; failed to insert tunnel attribute and tunnel tag table; container size exceeded: creating new; found unexpected tunnel table; dsl-forum attribute type parse error: limited data or overflow; Duplicate prefix event received for profileHandle: *profileHandle*; failed to configure *radiusPerProfileMap* entry due to unavailability of the resources; failed to configure *aaaPerProfileNameMap* entry due to insertion failure; deletion of the AAA per-profile results in an internal error due to failure of the AAA per-profile name mapping table; displays the value of NAS-Port and NAS-Port-Type; detected duplicate prefix; unable to detect duplicate prefix; failed to allocate IPv6 prefix; failure of IPCP negotiations with LCP configuration requests and LCP terminate requests; authentication request and authentication termination failure from the AAA server; denial of authentication owing to failure of Access-Request and Access-Accept messages; release and acquisition of IPv4 addresses during interim accounting; transmission of RADIUS messages with ipv4-release-control RADIUS VSA attribute [26-164] included; successful release and negotiation of IPv4 addresses; Service Manager accounting activation when the IPv4 interface moves to the up state; Service Manager accounting deactivation when the IPv4 interface moves to the down state; No

IPv4-related attributes received : Inhibit IPv4CP for profileHandle; No IPv6-related attributes received : Inhibit IPv6CP for profileHandle; failed to send interim accounting messages to the primary accounting server; interim accounting is disabled on the broadcast virtual router; user accounting is disabled on the broadcast virtual router

Filter None

aaaUserAccess

Description	AAA user access
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	User is granted or denied access
Debug	No IPv4 and IPv6 information received from the RADIUS server
Filter	None

addressServerGeneral

Description	Address server general
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Address server request failure (for example, configured address server is not available)
Notice Log	None

Info	None
Debug	None
Filter	None

ar1AaaServerGeneral

Description	Platform-dependent AAA server
Emergency	None
Alert	None
Critical	None
Error	Internal (NVS) errors for limit configuration per interface
Warning Log	None
Notice Log	None
Info	None
Debug	Interface information insufficient to identify the user's interface location
Filter	None

atm

Description	ATM interface
Emergency	None
Alert	None
Critical	None
Error	Unable to reenable ILMI administrative state after UNI version change
Warning Log	Error getting location of underlying physical interface; error binding or unbinding to physical interface; error allocating memory for new interface; error setting system identifier; error adding or configuring an interface; error getting capabilities of interface; error getting maximum VPI/VCI for interface; error getting maximum virtual circuit descriptor for interface; unable to store or allocate memory for F4 OAM circuit data; unable to configure F4 OAM circuit for interface

Notice Log	Interface pool expanded by an incremental number of entries; report retry delay in seconds when waiting for the underlying physical interface to be created; unable to allocate a message to send an interface up or down notification; unable to add or configure interface
Info	Dropping interface up, down, or not present notification due to removal of interface; discarding F4 OAM circuits when interface does not support F4 OAM
Debug	None
Filter	None

atm1483

Description	ATM 1483 data service
Emergency	None
Alert	None
Critical	None
Error	Error applying static map entry for a newly created circuit of an NBMA interface; unable to configure interfaces on ATM interface; unable to determine interface location for ATM AAL5 interface; unable to determine maximum interface configuration count for interface; unable to configure interface on ATM interface
Warning Log	Error getting location of underlying AAL5 or ATM interface; error binding to AAL5 interface; error opening a circuit for an NBMA interface; attempting to associate a static map to an underlying ATM interface that does not exist; error restoring circuits from NVS; error removing static map entry; NVS entry not found for static map entry; error storing static map entry in NVS; error expanding interface pool, interface binding pool, or subscriber pool
Notice Log	Interface pool, interface binding pool, or subscriber pool expanded by an incremental number of entries; unable to allocate a message to send a subinterface up or down notification
Info	Dropping subinterface up or down notification due to removal of subinterface; configure interfaces on ATM interface; elapsed time for downloading interfaces; elapsed time for ATM AAL5 present notification; maximum interface count per call
Debug	None
Filter	None

atm1483VcClass

Description	Application of attributes configured in a virtual circuit (VC) class to PVCs
Emergency	None
Alert	None
Critical	None
Error	In routers with high availability enabled, failure to mirror the VC modification or failure to associate the VC modification with the standby SRP module
Warning Log	Failure to find the PVCs associated with this VC class; failure to apply the VC class attributes to the appropriate PVCs; the log message displays a brief description of the failure
Notice Log	None
Info	None
Debug	None
Filter	None

atmAal5

Description	ATM Adaptation Layer 5
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Error getting location of underlying ATM interface; error binding to ATM interface; unable to expand interface pool; error creating interface; unable to set administrative status of interface
Notice Log	Interface pool expanded by an incremental number of entries; report retry delay in seconds when waiting for the underlying ATM interface to be created; unable to allocate a message to send an interface up or down notification

Info	Dropping interface up or down notification due to removal of interface
Debug	None
Filter	None

atmVcClass

Description	Information on VC class operational errors
Emergency	None
Alert	None
Critical	None
Error	Resource failure errors, such as error allocating memory for adding a VC class; internal software errors; error processing a VC class association; when using SNMP, unable to set a VC class state from not in service to in service, or vice-versa; unable to find an existing VC class in the internal data structure; unable to complete processing after a high availability switchover
Warning Log	None
Notice Log	None
Info	None
Debug	Unable to update mirrored storage for a high availability switchover
Filter	None

auditIpsec

Description	IKE SA negotiations
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None

Notice Log Information about IKE SA negotiation payloads

Info None

Debug None

Filter None

CHAPTER 4

B Commands

- [bfdAdaptivity](#) on page 35
- [bfdEvents](#) on page 36
- [bfdGeneral](#) on page 36
- [bfdSession](#) on page 37
- [bgpConnections](#) on page 37
- [bgpDampening](#) on page 38
- [bgpEvents](#) on page 39
- [bgpGeneral](#) on page 40
- [bgpGracefulRestart](#) on page 40
- [bgpIpv6Issu](#) on page 41
- [bgpIpv6NextHops](#) on page 42
- [bgpKeepAlives](#) on page 42
- [bgpMessages](#) on page 43
- [bgpNeighborChanges](#) on page 44
- [bgpNextHops](#) on page 45
- [bgpRoutes](#) on page 45
- [bridge](#) on page 48
- [bridgeEngine](#) on page 49
- [bridgingMgr](#) on page 49
- [bulkStats](#) on page 50

bfdAdaptivity

Description	BFD adaptivity events
--------------------	-----------------------

Emergency	None
------------------	------

Alert	None
--------------	------

Critical	None
-----------------	------

Error	None
Warning Log	None
Notice Log	None
Info	BFD session adaptivity events
Debug	BFD session adaptivity events
Filter	None

bfdEvents

Description	BFD Events
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	BFD session state changes
Debug	None
Filter	None

bfdGeneral

Description	BFD general events
Emergency	None
Alert	None
Critical	None
Error	None

Warning Log	None
Notice Log	BFD enabled/disabled on an interface from a client
Info	None
Debug	None
Filter	None

bfdSession

Description	BFD session events
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Unknown BFD session
Notice Log	Session state changes
Info	Session parameter changes
Debug	None
Filter	None

bgpConnections

Description	BGP TCP/IP connection activity
Emergency	None
Alert	None
Critical	None
Error	Error setting password for specified peer; error binding to update-source address for specified peer

Warning Log	TCP error occurred while receiving data
Notice Log	Outbound TCP connection initiated, completed, or failed; inbound TCP connection accepted, refused, or failed; TCP connection closed by peer
Info	None
Debug	TCP connection is ready to send; data received on TCP connection; notification message sent; could not send notification message due to flow control—will retry later; error while sending notification message; keepalive message sent; could not send keepalive message due to flow control—will retry later; error while sending keepalive message; message other than notification or keepalive sent; could not send other message than notification or keepalive due to flow control—will retry later; error while sending other message than notification or keepalive
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—See description of the bgpRoutes peer filter for information about this filter
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter
Filter 5	in—This filter is not currently supported
Filter 6	out—This filter is not currently supported

bgpDampening

Description	BGP dampening
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Route is suppressed by route-flap dampening; route is no longer suppressed by route-flap dampening
Info	None

Debug	None
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—See description of the bgpRoutes peer filter for information about this filter
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter
Filter 5	in—This filter is not currently supported
Filter 6	out—This filter is not currently supported

bgpEvents

Description	BGP finite state machine (FSM) events and transitions
Emergency	None
Alert	None
Critical	None
Error	Event occurred that was not expected for current state
Warning Log	None
Notice Log	One of the following events occurred: start, stop, inbound-connection-arrived, outbound-connection-complete, connection-error, connection-closed, start-timer-expired, connect-timer-expired, hold-timer-expired, keep-alive-timer-expired, open-received, update-received, keep-alive-received, notification-received, route-refresh, route-refresh-cisco
Info	None
Debug	None
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—See description of the bgpRoutes peer filter for information about this filter
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter

Filter 5 in—This filter is not currently supported

Filter 6 out—This filter is not currently supported

bgpGeneral

Description	BGP general information
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	BGP IPv4 route-target-signaling address family enabled or disabled; making local route to multihomed site less preferred (local-preference < >) because down bit is set
Info	None
Debug	Setting local preference to < > for redistributed route of layer2 site
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—See description of the bgpRoutes peer filter for information about this filter
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter
Filter 5	in—This filter is not currently supported
Filter 6	out—This filter is not currently supported

bgpGracefulRestart

Description	BGP Graceful Restart Feature log
Emergency	None
Alert	None

Critical	None
Error	None
Warning Log	None
Notice Log	Log BGP performed or did not perform a graceful restart; router supports or does not support non-stop forwarding; router is capable of switching gracefully, deferring, or resuming best path selection decision process; BGP routes allowed or prevented from being downloaded to line cards; graceful-restart timer expiration; marking or removing stale routes; waiting to receive end-of-rib marker from peer; received end-of-rib marker from all peers
Info	None
Debug	Standby SRP will wait for BGP convergence on next restart
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—This filter is not currently supported
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter
Filter 5	in—This filter is not currently supported
Filter 6	out—This filter is not currently supported

bgplpv6Issu

Description	BGP IPv6-specific information
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Notification disallowing any configuration
Notice Log	Notify the status of the unified ISSU signal

Info	None
Debug	Bind or unbind of the unified ISSU signal, keepalive, and graceful restart information
Filter	None

bgpIpv6NextHops

Description	BGP indirect next-hops for IPv6 NLRI
Emergency	None
Alert	None
Critical	None
Error	Errors in BGP IPv6 next hop events and state transitions
Warning Log	None
Notice Log	State transitions of BGP IPv6 next hops
Info	None
Debug	BGP IPv6 indirect next-hop events
Filter 1	router—See description of the bgpRoutes router filter for information about this filter
Filter 2	remote-ipv6-address—Matches on the IPv6 address of the BGP indirect next-hop

bgpKeepAlives

Description	BGP keepalive messages
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Keepalive message received with unexpected additional data after header
Notice Log	Keepalive message received; keepalive message sent

Info	None
Debug	None
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—See description of the bgpRoutes peer filter for information about this filter
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter
Filter 5	in—Matches on traffic coming into the router
Filter 6	out—Matches on traffic going out of the router



NOTE: Send messages are logged to the bgpKeepAlives log when a message is added to the send queue. A debug message is logged in to the bgpConnections log when the message is actually passed to TCP.

bgpMessages

Description	BGP protocol messages
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Unknown message type received; invalid field in received message; notification message received or sent; invalid capability length in received ORF capability; invalid capability value in received ORF capability; invalid ORF in received ORF capability; ORF entries exceeded maximum limit in received prefix list
Notice Log	Open message received or sent; update message received or sent; route-refresh message received or sent; route-refresh-cisco message received or sent; received ORF capability; received route refresh message with ORF entries
Info	None

Debug Keepalive message received or sent (Full decode of message logged if verbosity is high)



NOTE: Send messages are logged to the `bgpMessages` log when a message is added to the send queue. A debug message is logged to the `bgpConnections` log when the message is actually passed to TCP.

Filter 1 access-class—This filter is not currently supported

Filter 2 peer—See description of the `bgpRoutes` peer filter for information about this filter

Filter 3 route-map—This filter is not currently supported

Filter 4 router—See description of the `bgpRoutes` router filter for information about this filter

Filter 5 in—Matches on traffic coming into the router

Filter 6 out—Matches on traffic going out of the router

bgpNeighborChanges

Description BGP neighbor change

Emergency None

Alert None

Critical None

Error None

Warning Log None

Notice Log A peer has entered into or left the established state; reason for a session going idle

Info None

Debug None

Filter 1 access-class—This filter is not currently supported

Filter 2 peer—See description of the `bgpRoutes` peer filter for information about this filter

Filter 3 route-map—This filter is not currently supported

Filter 4 router—See description of the bgpRoutes router filter for information about this filter

Filter 5 in—This filter is not currently supported

Filter 6 out—This filter is not currently supported

bgpNextHops

Description	VPN and non-VPN BGP indirect next hops
Emergency	None
Alert	None
Critical	None
Error	Errors in BGP next hop events and state transitions
Warning Log	None
Notice Log	State transitions of BGP next hops
Info	None
Debug	BGP indirect next-hop events
Filter 1	access-class—This filter is not currently supported
Filter 2	peer—See description of the bgpRoutes peer filter for information about this filter
Filter 3	route-map—This filter is not currently supported
Filter 4	router—See description of the bgpRoutes router filter for information about this filter
Filter 5	in—Matches on traffic coming into the router
Filter 6	out—Matches on traffic going out of the router

bgpRoutes

Description	BGP routing table updates
Emergency	None
Alert	None

Critical	None
Error	None
Warning Log	Failure to add, remove, or modify BGP route in IP forwarding table
Notice Log	BGP route added to, removed from, or modified in the IP forwarding table; aggregate route added to, removed from, or modified in Loc-RIB; network route added to, removed from, or modified in Loc-RIB; best route for internal peers for a given prefix became available; best route for internal peers for a given prefix is no longer available, has changed, or has become available; best route for external peers for a given prefix is no longer available, has changed, or has become available; MPLS base tunnel used to reach an indirect next-hop came up or went down; MPLS stacked tunnel for label came up; indirect next-hop became reachable or unreachable; direct next-hop for an indirect next-hop changed; MPLS tunnel for Inter-AS label came up or went down; route added to L2VPN instance; route deleted from L2VPN instance; route modified for L2VPN instance; -VE device for multihomed local layer 2 site 1 changed from <i>peer</i> to <i>peer2</i>
Info	None
Debug	Redistributed route added to, removed from, or modified in Loc-RIB; advertisement for a given prefix received; withdraw for a given prefix received; local route-target-filtering route added to or removed from <i>prefix</i> in <i>addressFamily</i>
Filter 1	<p>access-class <i>accessClassName</i> [route-map <i>routeMapName</i> <i>routeMapOptions</i> filtering-router <i>filteringRouterName</i> <i>filteringRouterOptions</i> in out]</p> <ul style="list-style-type: none">• access-class—Logs events for traffic that matches a specific access class• <i>accessClassName</i> —Name of the access class for which you want to log events• route-map—Logs events for traffic that matches a specific route map• <i>routeMapName</i>—Name of route map for which you want to log events• <i>routeMapOptions</i>—In the following format—filtering-router <i>filteringRouterName</i> <i>filteringRouterOptions</i> in out• filtering-router—Logs events only if the access class or route map are defined on a specific virtual router• <i>filteringRouterName</i>—Virtual router where the access class or route map or both are defined• <i>filteringRouterOptions</i>—in out• in—Matches on traffic coming into the access class, route map, or virtual router• out—Matches on traffic sent out of the access class, route map, or virtual router
Filter 2	<p>peer <i>peerIpAddress</i> <i>peerIpv6Address</i> [access-class <i>accessClassName</i> <i>accessClassOptions</i>]</p>

```
route-map routeMapName routeMapOptions |
filtering-router filteringRouterName filteringRouterOptions | in | out ]
```

- *peer*—Logs events for traffic that matches a specific peer
- *peerIpAddress*—IP address of the peer for which you want to log events
- *peerIpv6Address*—IPv6 address of the peer for which you want to log events
- *access-class*—Logs events for traffic that matches a specific access class
- *accessClassName*—Name of the access class for which you want to log events
- *accessClassOptions*—In the following format—filtering-router *filteringRouterName* *filteringRouterOptions* | in | out
- *route-map*—Logs events for traffic that matches a specific route map
- *routeMapName*—Name of route map for which you want to log events
- *routeMapOptions*—In the following format—filtering-router *filteringRouterName* *filteringRouterOptions* | in | out
- *filtering-router*—Logs events only if the peer, access class or route map are defined on a specific virtual router
- *filteringRouterName*—Virtual router where the peer, access class or route map or both are defined
- *filteringRouterOptions*—in | out
- *in*—Matches on traffic coming into the peer, access class, route map, or virtual router
- *out*—Matches on traffic sent out of the peer, access class, route map, or virtual router

Filter 3 `route-map routeMapName`
`[filtering-router filteringRouterName filteringRouterOptions | in | out]`

- *route-map*—Logs events for traffic that matches a specific route map
- *routeMapName*—Name of route map for which you want to log events
- *filtering-router*—Logs events only if the route map is defined on a specific virtual router
- *filteringRouterName*—Virtual router where the route map is defined
- *filteringRouterOptions*—in | out
- *in*—Matches on traffic coming into the route map or virtual router
- *out*—Matches on traffic sent out of the route map or virtual router

Filter 4 `router virtualRouterName [access-class accessClassName accessClassOptions |`
`route-map routeMapName routeMapOptions |`
`filtering-router filteringRouterName filteringRouterOptions |`
`peer peerIpAddress peerOptions | in | out]`

- *router*—Logs events for traffic on a specific virtual router
- *virtualRouterName*—Name of virtual router

- **access-class**—Logs events for traffic that matches a specific access class on the specified router
- **accessClassName**—Name of the access class for which you want to log events
- **accessClassOptions**—In the following format—route-map *routeMapName routeMapOptions* | virtual-router *virtualRouterName virtualRouterOptions* | in | out
- **route-map**—Logs events for traffic that matches a specific route map
- **routeMapName**—Name of route map for which you want to log events
- **routeMapOptions**—In the following format—virtual-router *virtualRouterName virtualRouterOptions* | in | out
- **filtering-router**—Logs events only if the access class or route map is defined on a specific virtual router
- **filteringRouterName**—Virtual router where the access class or route map is defined
- **filteringRouterOptions**—In the following format—in | out
- **peer**—Logs events for traffic that matches a specific peer
- **peerIpAddress**—Address of the peer for which you want to log events
- **peerOptions**—In the following format—access-class *accessClassName accessClassOptions* | filtering-router *filteringRouterName filteringRouterOptions* | route-map *routeMapName routeMapOptions* | in | out
- **in**—Matches on traffic coming into the virtual router, access class, or route map
- **out**—Matches on traffic sent out of the virtual router, access class, or route map

Filter 5 in—Matches on traffic coming into the router

Filter 6 out—Matches on traffic going out of the router

bridge

Description	Bridge group configuration
Emergency	None
Alert	None
Critical	None
Error	Bridge interface, learning, aging, and static MAC address errors
Warning Log	Bridge resources (maximum interfaces, memory exhaustion)
Notice Log	Bridge group interface location availability, operation status, and MTU changes

Info	Bridge group state changes (start, shutdown); bridge interface, learning, aging, and static MAC address modifications
Debug	Verbose bridge interface, learning, aging, and static MAC address configuration and status
Filter	None

bridgeEngine

Description	Bridge engine configuration
Emergency	None
Alert	None
Critical	None
Error	Bridge engine, bridge agent, and bridge interface errors
Warning Log	Bridge engine resources (maximum interfaces, memory exhaustion)
Notice Log	Slot status; bridge interface location availability
Info	Bridge engine and bridge agent state changes (create, start, stop delete); bridge engine, bridge agent, and bridge interface modifications
Debug	Verbose bridge engine, bridge agent, and bridge interface configuration and status
Filter	None

bridgingMgr

Description	Bridging manager configuration
Emergency	None
Alert	None
Critical	None
Error	Bridge mode, bridge group, and subscriber policy errors
Warning Log	Bridging manager resources (maximum bridge groups, maximum subscriber policies, memory exhaustion)

Notice Log	None
Info	Bridging manager operation state changes (init, start, shutdown); bridge mode, bridge group, and subscriber policy modifications
Debug	Verbose bridge mode, bridge group, and subscriber policy configuration and status
Filter	None

bulkStats

Description	Bulk statistics collector
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Operational failures, such as failed transfer—reverting to secondary receiver, file full, file creation failure, file deletion failure
Notice Log	File full or file nearly full conditions, preparing to send an SNMP trap
Info	Status of user configuration commands
Debug	Tracks performance progress of bulkstats application
Filter	None

CHAPTER 5

C Commands

- [cacGeneral](#) on page 51
- [cacIntf](#) on page 52
- [cliCommand](#) on page 52
- [cliGeneral](#) on page 53
- [connectionManager](#) on page 53
- [cops](#) on page 54
- [copsPr](#) on page 54
- [coreDump](#) on page 55
- [ctreeLog](#) on page 55

[cacGeneral](#)

Description	CAC general purpose
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Unusual conditions in IGP/CAC interaction
Notice Log	None
Info	None
Debug	General debugging info
Filter	None

cacIntf

Description CAC interface events

Emergency None

Alert None

Critical None

Error None

Warning Log Unusual or failure situations in interface processing

Notice Log None

Info None

Debug Interface level debugging info

Filter interface *interfaceType* *interfaceSpecifier*

- interface—Logs events for a specific interface
- *interfaceType*—Type of interface on which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

cliCommand

Description CLI commands

Emergency None

Alert None

Critical None

Error None

Warning Log None

Notice Log	All successful CLI configuration commands
Info	All unsuccessful CLI configuration commands; all nonconfiguration commands
Debug	None
Filter	None

cliGeneral

Description	CLI general log
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	CLI command mode from prior release no longer exists; the overridden privilege level command will be discarded
Notice Log	None
Info	None
Debug	None
Filter	None

connectionManager

Description	Logging various conditions in the component that manages the chassis fabric.
Emergency	None
Alert	None
Critical	10G and 5G SRP modules only—Detection that the FPGAs have not been loaded (results in an SRP [and chassis] reset)
Error	10G and 5G SRP modules only—That there is not enough bandwidth for a particular board in the system, that connections could not be added in the fabric due to resource limitations (such as memory), that a board was just removed and the resource will not

be needed when this condition is detected momentarily, or that a connection cannot be closed or a multicast destination cannot be dropped.

Warning Log	Cannot connect to a particular source or destination address (board may have just been removed)
Notice Log	A connection that previously could not be closed has now closed; a multicast destination that previously could not be dropped has now been dropped
Info	Various logs to indicate events and transitions for low level diagnosis
Debug	Various logs to indicate events and transitions for low level diagnosis
Filter	None

cops

Description	Common Open Policy Service (COPS) protocol
Emergency	None
Alert	None
Critical	None
Error	COPS message with bad header, version, length, or client
Warning Log	Unexpected socket event
Notice Log	COPS layer enabled or disabled; socket remotely closed
Info	None
Debug	COPS session instantiation or removal; COPS connection or socket creation or deletion; keepalive value
Filter	None

copsPr

Description	COPS-PR general log
Emergency	None
Alert	None

Critical	None
Error	Error decoding COPS-PR messages received from the SDX program
Warning Log	Outstanding COPS-PR pool allocations while attempting to shut down SSC client; temporary resource allocations while sending COPS-PR messages to SDX program
Notice Log	None
Info	None
Debug	None
Filter	None

coreDump

Description	Core dump events
Emergency	None
Alert	None
Critical	None
Error	Connection errors; file open errors; write failures; core dump failures; transfer errors
Warning Log	Core dump configuration changes due to core dump monitor; core dump monitor memory allocation errors
Notice Log	Successful line card core dump; core dump attempts; core dump progression; core dump monitor checks; core dump monitor transfer completions; core dump monitor dump file deletion
Info	None
Debug	lcLoader creation; dump request receipt; core dump monitor start; core dump monitor stop
Filter	None

ctreeLog

Description	For internal maintenance of IP routes
Emergency	None

Alert	None
Critical	None
Error	Failure in insertion, deletion, and update of IP routes in internal data structure used to maintain the routes
Warning Log	None
Notice Log	None
Info	None
Debug	Creation or deletion of an internal data structure
Filter	None

CHAPTER 6

D Commands

- [dcm on page 58](#)
- [dcmEngineGeneral on page 58](#)
- [debounceEvents on page 59](#)
- [debounceGeneral on page 59](#)
- [dhcpCapture on page 60](#)
- [dhcpExternal on page 60](#)
- [dhcpExternalEngine on page 61](#)
- [dhcpGeneral on page 61](#)
- [dhcplssuLog on page 62](#)
- [dhcpLocalClients on page 62](#)
- [dhcpLocalGeneral on page 63](#)
- [dhcpLocalHighAvailability on page 63](#)
- [dhcpLocalPool on page 64](#)
- [dhcpLocalProtocol on page 64](#)
- [dhcpOfferLog on page 65](#)
- [dhcpPbeGeneral on page 66](#)
- [dhcpProxyGeneral on page 66](#)
- [dhcpRelayGeneral on page 67](#)
- [dhcpRelayNvWriterGeneral on page 67](#)
- [dhcipv6Client on page 68](#)
- [dhcipv6DemuxGeneral on page 68](#)
- [dhcipv6LocalSubInterfaceTable on page 69](#)
- [dhcipv6LsGeneral on page 69](#)
- [dismanEventManager on page 70](#)
- [dnsGeneralLog on page 71](#)
- [dosProtection on page 71](#)
- [ds1 on page 72](#)
- [ds3 on page 72](#)

- [dvmrpGeneral](#) on page 73
- [dvmrpGracefulRestart](#) on page 74
- [dvmrpMcastTable](#) on page 74
- [dvmrpProbeRcv](#) on page 75
- [dvmrpProbeSent](#) on page 75
- [dvmrpRtTable](#) on page 76

dcm

Description	Dynamic Configuration Manager
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Schedule engine event; status of dynamic interface creation; receipt of teardown signal for a dynamic interface; no interface adapter to propagate teardown; creation of dynamic PPP interface failed; creation of dynamic PPPoE interface failed
Filter	None

dcmEngineGeneral

Description	DCM engine general
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None

Notice Log	None
Info	None
Debug	Giving notify credits to line module; receipt of request buffer from line module; starting line module communication session; Ack/Nack dynamic interface creation request
Filter	None

debounceEvents

Description	Events causing changes to the upper-layer link status based on Ethernet debounce configuration
Emergency	None
Alert	Debounce preempted; link stabilized to operational up or down status
Critical	None
Error	None
Warning Log	None
Notice Log	Events causing finite state machine transitions
Info	Events not causing finite state machine transitions
Debug	None
Filter	None

debounceGeneral

Description	Ethernet debounce configuration status log
Emergency	None
Alert	None
Critical	None
Error	Error in enabling or disabling the debounce timer on the Ethernet interface
Warning Log	None

Notice Log Debounce timer enabled or disabled on the Ethernet interface

Info None

Debug None

Filter None

dhcpCapture

Description DHCP packet capture

Emergency None

Alert None

Critical None

Error Configuration errors

Warning Log Processing errors (resource exhaustion)

Notice Log None

Info Logged DHCP packets, configured by the **ip dhcp-capture** command (specify high verbosity for detail)

Debug Configuration change details; DHCP discover, offer, request, decline, and ACK/NAK packets on a per-interface basis

Filter None

dhcpExternal

Description DHCP external

Emergency None

Alert None

Critical None

Error Configuration errors; client processing errors (invalid data)

Warning Log Client processing errors (resource exhaustion)

Notice Log	Configuration changes
Info	None
Debug	Configuration change details; client events
Filter	None

dhcpExternalEngine

Description	DHCP external engine
Emergency	None
Alert	None
Critical	None
Error	Configuration errors; client processing errors (invalid data)
Warning Log	None
Notice Log	None
Info	System events (line cards online/offline)
Debug	Configuration change details; client events
Filter	None

dhcpGeneral

Description	DHCP general
Emergency	None
Alert	Rvn8
Critical	None
Error	None
Warning Log	None
Notice Log	None

Info	None
Debug	DHCP message received
Filter	None

dhcpIssuLog

Description	DHCP ISSU information
Emergency	None
Alert	None
Critical	None
Error	Error recreating DHCP ISSU IC shadow and its data structures, followed by an ISSU halt
Warning Log	Buffering capacity exceeded between DHCP engine and the driver/ISSU shadow driver
Notice Log	None
Info	None
Debug	Normal operation: packet processing events, creation and deletion of DHCP common objects during ISSU
Filter	None

dhcpLocalClients

Description	DHCP local server clients
Emergency	None
Alert	None
Critical	None
Error	Cannot find the client's interface; cannot find the client to expire the lease or remove it from the database; trying to expire client's lease or remove it from database with bad IP address; requested MAC address does not match the available address; cannot allocate SDX subscriber information
Warning Log	Cannot find the DHCP instance for the client with an expired lease; cannot find the DHCP instance to release the client IP address; secondary DNS without primary DNS configured,

using DHCP values; secondary NetBIOS Name Server (NBNS) without primary NBNS configured, using DHCP values

Notice Log	None
Info	None
Debug	Removing stale offers to clients and stale clients; adding and removing clients; expiring client's lease; client's transactions with DHCP local server
Filter	None

dhcpLocalGeneral

Description	General DHCP local server
Emergency	None
Alert	None
Critical	None
Error	Memory allocation failure; cannot find interface location for the UID
Warning Log	No DHCP instance to process the received packet; hard limits reached; packet discarded due to no resources
Notice Log	DHCP local server not configured; client's session failed to start
Info	Client per-interface limit exceeded; client per-interface exceeded condition abated
Debug	Any log message that indicates the status of the general operation of the DHCP local server; NVS actions; grace period lease state; configuration changes
Filter	None



NOTE: This category replaces the dhcpLocalServerGeneral category.

dhcpLocalHighAvailability

Description	DHCP local high availability
Emergency	None

Alert	None
Critical	None
Error	Out of resources errors; nonrecoverable software errors during client restoration or mirroring, pool creation/modification; recoverable software errors during modification of existing client
Warning Log	Recoverable software errors during client, server or pool configuration; out of resources on new client, server, or pool configuration; timer configuration problems
Notice Log	Normal recovery following SRP switch
Info	None
Debug	Normal client, server, pool processing
Filter	None

dhcpLocalPool

Description	DHCP local address pool, including normal, linked, and shared pools
Emergency	None
Alert	Local pool IP address is exhausted (address limit violation)
Critical	Higher limit of address pool utilization reached
Error	None
Warning Log	Lower limit of address pool utilization reached; invalid DHCP local address pool attributes
Notice Log	None
Info	None
Debug	DHCP local address pool resolution; address allocation; minimum or maximum threshold values are modified for the base pool in a linked pool
Filter	None

dhcpLocalProtocol

Description	DHCP local server protocol
--------------------	----------------------------

Emergency	None
Alert	None
Critical	None
Error	Cannot find interface; remote client bind add failed; client failed to decline IP address; client failed to decline a null offered IP address; delete remote client entry failed
Warning Log	AAA not responding; SDX program not responding; rediscovering with no IP address allocated; a renewal is received on the line module for an unknown client; secondary DNS without primary DNS configured, using DHCP values; secondary NetBIOS Name Server (NBNS) without primary NBNS configured, using DHCP values; duplicate MAC address detected
Notice Log	None
Info	None
Debug	Received packet; transmit packet; authentication status; DHCP local server state transitions
Filter	<p>interface <i>interfaceType</i> <i>interfaceSpecifier</i></p> <ul style="list-style-type: none"> • <i>interface</i>—Logs events for a specific interface • <i>interfaceType</i>—Type of interface for which you want to log events • <i>interfaceSpecifier</i>—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

dhcpOfferLog

Description	DHCP offer selection process log
Emergency	None
Alert	None
Critical	None
Error	None

Warning Log	None
Notice Log	None
Info	None
Debug	Status of the offer selection process
Filter	None

dhcpPbeGeneral

Description	DHCP Proxy Backend Log
Emergency	None
Alert	None
Critical	None
Error	Heap exhaustion
Warning Log	Failure to send a DHCP message to a client
Notice Log	Failure to restore client after reboot or interface change; failure to allocate memory from task-controlled pools
Info	None
Debug	Status of task and DHCP operations
Filter	None

dhcpProxyGeneral

Description	DHCP Proxy general
Emergency	None
Alert	None
Critical	None
Error	None

Warning Log	None
Notice Log	Cold and warm restart of DHCP proxy client; DHCP proxy client starts and ends the restoration of client bindings from the mirrored storage for a virtual router
Info	None
Debug	Control flow and key events; DHCP proxy client ends the process of restoring client bindings on a virtual router; DHCP proxy client restores each client binding from mirrored storage with the client IP address and state of the binding
Filter	None

dhcpRelayGeneral

Description	DHCP Relay general
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Warm start recovery problems (high availability and unified ISSU)
Info	None
Debug	Control flow and key events, packets that are transmitted using the layer 2 unicast feature, status and changes to DHCP relay agent information option and suboptions
Filter	None

dhcpRelayNvWriterGeneral

Description	DHCP host route preservation
Emergency	None
Alert	None
Critical	None

Error	Out of memory conditions
Warning Log	Unexpected unified ISSU signal, removing all NVS and routing table entries at startup, removing routing table entries at startup due to inconsistencies
Notice Log	Removing or adding entries on start up due to inconsistencies
Info	None
Debug	Receiving unified ISSU signal, construction of the writer, saving to NVS, removing router, removing routes, adding routes
Filter	None

dhcpv6Client

Description	DHCPv6 internal test client events
Emergency	None
Alert	None
Critical	None
Error	Problems communicating with IPv6; invalid message types received; out-of-memory conditions; serious DHCPv6 protocol state errors; internal errors
Warning Log	Minor DHCPv6 protocol errors
Notice Log	None
Info	None
Debug	None
Filter	None

dhcpv6DemuxGeneral

Description	DHCPv6 packet demultiplexer events
Emergency	None
Alert	None

Critical	None
Error	UDP transmit errors, out-of-memory conditions, internal errors
Warning Log	Invalid DHCPv6 packet type received
Notice Log	None
Info	None
Debug	None
Filter	None

dhcpv6LocalSubInterfaceTable

Description	DHCPv6 local server subinterface table log
Emergency	None
Alert	None
Critical	None
Error	Failure to insert an entry in the DHCPv6 subinterface table
Warning Log	None
Notice Log	None
Info	None
Debug	Status of DHCPv6 subinterface table–related operations
Filter	None
Related Documentation	<ul style="list-style-type: none"> Limiting the Maximum Number of IPv6 Prefixes Delegated Per Interface by the DHCPv6 Local Server Overview

dhcpv6LsGeneral

Description	DHCPv6 local server events
Emergency	None

Alert	None
Critical	None
Error	Failure to create server (bad router or out of memory); errors encountered while processing ISSU signals or while mirroring; initialization error during the configuration of the DUID type
Warning Log	Attempt to remove a nonexistent server; any failure during the configuration of the DUID type
Notice Log	Failure to create server (IPv6 not licensed); cold/warm restart of DHCPv6 local server; before/after restoring client bindings; warm SRP switchover problems during the configuration of the DUID type
Info	None
Debug	Server bind, creation, deletion, unbind, and restoration of bindings post warm SRP switchover; Prefix Allocation Notification: designated prefix is already in use by another client; if ISSU is running on a DHCPv6 local server, ISSU and HA debug messages are logged; authentication of subscribers with the AAA username
Filter	None

dismanEventMgr

Description	Distributed management event manager
Emergency	None
Alert	None
Critical	None
Error	Configuration errors; Sampling, testing and setting errors
Warning Log	Limit maximums reached
Notice Log	Trigger values reached
Info	Application started; traps activated; sampling information provided
Debug	None
Filter	None

dnsGeneralLog

Description	DNS general
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Failure to post a message to DNS about the query response from DNS server
Notice Log	None
Info	None
Debug	Dump DNS response packet; trace DNS query submission; trace DNS response parsing and processing; trace dropped queries if router is shutting down or DNS disabled in virtual router; trace DNS cache cleanup
Filter	None

dosProtection

Description	DoS general
Emergency	None
Alert	None
Critical	Suspicious control flows exceed threshold for specific line module; possible distributed DoS attack
Error	Control flow changed to suspicious.
Warning Log	Flow table overflow, protocol (or priority) has transitioned to suspicious
Notice Log	Suspicious control flow returned to nonsuspicious protocol (or priority) has transitioned from suspicious
Info	Suspicious control flow deleted
Debug	None

Filter None

ds1

Description DS1 layer

Emergency None

Alert None

Critical None

Error None

Warning Log Interface creation or binding failure

Notice Log Failure to bring line module application online; dropped interface state change notification due to lack of resources; discarded stale line module notification

Info Dropped interface state change notification for unknown or removed interface

Debug None

Filter None

ds3

Description DS3 layer

Emergency None

Alert None

Critical None

Error None

Warning Log Failure to create or bind interface


Notice Log Failure to bring line module application online; dropped interface state change notification due to lack of resources; discarded stale line module notification

Info Dropped interface state change notification for unknown or removed interface

Debug None

Filter None

dvmrpGeneral

Description	DVMRP general
Emergency	None
Alert	None
Critical	None
Error	Memory allocation errors; bad parameters (internal errors); designated forwarder errors (two for same interface, DoNotForward by no designated forwarder); processing prune errors; graft errors; internal errors; catastrophic RT table errors; management interaction errors; NVS errors
Warning Log	Unable to add local route; routeHogCheck; routeLimit
Notice Log	Route expiration; pruneProcessing (send or receive); graftAck processing; source group (SG) state information; deletion of an output interface; nbrQuickDelete; nbrReset; nbrTimeOut; error adding neighbor on Route Report Reception
Info	Designated forwarder election information; sending graft; timer expired for MulticastEntry; attempting to log duplicate accept filter; external route deleted or added
Debug	Local address creation or deletion; information about accept filters; dvmrpInterface creation or deletion; sgTimeout information; noMoreOifs info; sg creation information; multicastForwarding enabled or disabled; DvmrpInit; dvmrpEnable/Disable; rpfCallback
Filter 1	<p>interface <i>interfaceType interfaceSpecifier</i></p> <ul style="list-style-type: none"> • interface—Logs events for a specific interface • <i>interfaceType</i>—Type of interface for which you want to log events • <i>interfaceSpecifier</i>—Location of interface in the appropriate format
<div style="display: flex; align-items: center;">  <p>NOTE: For information about interface types and specifiers, see <i>Interface Types and Specifiers</i> in <i>JunosE Command Reference Guide</i>.</p> </div>	
Filter 2	<p>router <i>virtualRouterName</i> [interface <i>interfaceType interfaceSpecifier</i>]</p> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

- **interface**—Logs events on a specific interface on the virtual router
- **interfaceType**—Type of interface for which you want to log events
- **interfaceSpecifier**—Location of interface in the appropriate format



.....

NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

.....

dvmrpGracefulRestart

Description	DVMRP graceful restart
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	DVMRP graceful restart complete
Info	None
Debug	None
Filter	None

dvmrpMcastTable

Description	DVMRP multicast table messages
Emergency	None
Alert	None
Critical	None
Error	Error removing MulticastEntry; adding duplicate MulticastEntry; adding nonexistent MulticastEntry; attempting to send prune to nonexistent neighbor; error deleting MulticastEntry; error adding outgoing interfaces

Warning Log	Deleting MulticastEntry with no SG state found; attempting to create MulticastEntry, but unable to do so
Notice Log	Creating MulticastEntry
Info	rePruning; delOif; add outgoing interface; not adding outgoing interface for some reason; creating sgoiflist; pruneDelayCallback; prune; deleting MulticastEntry
Debug	None
Filter 1	interface—See description of the dvmrpGeneral interface filter for information about this filter
Filter 2	router—See description of the dvmrpGeneral router filter for information about this filter

dvmrpProbeRcv

Description	DVMRP probe received
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	procProbe new neighbor
Info	None
Debug	Processing probe (verified has our address in packet); display probe
Filter 1	interface—See description of the dvmrpGeneral interface filter for information about this filter
Filter 2	router—See description of the dvmrpGeneral router filter for information about this filter

dvmrpProbeSent

Description	DVMRP probe sent
Emergency	None

Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Send probe
Filter 1	interface—See description of the dvmrpGeneral interface filter for information about this filter
Filter 2	router—See description of the dvmrpGeneral router filter for information about this filter

dvmrpRtTable

Description	DVMRP Routing Table
Emergency	None
Alert	None
Critical	None
Error	Route error; router report error; error replacing route after applying accept filter; internal errors
Warning Log	Unable to create new route; deleting routing table
Notice Log	Error in report packet; adding or replacing local route; ignoring poison on upstream user interface (USIF); deleting all dependent neighbors
Info	Processing report; added route from report; declaring ourselves as designated forwarder; route update
Debug	Delete route; insert route
Filter 1	interface—See description of the dvmrpGeneral interface filter for information about this filter

Filter 2 router—See description of the `dvmpGeneral` router filter for information about this filter

CHAPTER 7

E Commands

- [ethernet on page 79](#)
- [ethernetStateSession on page 79](#)

ethernet

Description	Ethernet layer
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Cannot configure Ethernet interface successfully; memory pool depleted
Notice Log	No pool space; can bring interface up
Info	Hardware present or not present notification
Debug	Interface created or deleted
Filter	None

ethernetStateSession

Description	Configuration of the Fast Ethernet management port on the SRP IOA on the E320 router or the E120 router
Emergency	None
Alert	None
Critical	None

Error	Configuration errors for duplex mode and speed settings on the Fast Ethernet management port
Warning Log	Configuration did not occur for duplex mode and speed on the Fast Ethernet management port
Notice Log	None
Info	None
Debug	None
Filter	None

CHAPTER 8

F Commands

- [fileSystem](#) on page 81
- [flowInspection](#) on page 82
- [flowInspectionEngine](#) on page 82
- [flowServicesFirewallAlert](#) on page 83
- [flowServicesFirewallAudit](#) on page 83
- [frameRelay](#) on page 84
- [fsAgent](#) on page 84
- [ftl](#) on page 85
- [ftpClient](#) on page 85
- [ftpServer](#) on page 86

fileSystem

Description	File system
Emergency	None
Alert	None
Critical	Configuration consistency check failed; HA/sync may be disabled
Error	Error enabling or disabling
Warning Log	Missing of invalid armed files
Notice Log	Configuration checker enabled or disabled
Info	None
Debug	Timestamp of last synchronization
Filter	None

flowInspection

Description	Flow inspection
Emergency	None
Alert	None
Critical	None
Error	Configuration error for bulk static translations; failure to increase size of translation database; pool range overlap; more DNS queries than can be processed
Warning Log	Translation timeout change not applied to existing translations; failure to install translations
Notice Log	None
Info	Allocation and deallocation of NAT address or NAPT address/port
Debug	Increase size of translation database; add or remove address pool ranges
Filter	None

flowInspectionEngine

Description	Flow inspection engine
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Virtual router not found during deletion request
Notice Log	None
Info	None
Debug	Engine creation, timer state information, setCoreLocation notification
Filter	None

flowServicesFirewallAlert

Description	Firewall
Emergency	None
Alert	None
Critical	None
Error	No resources; number of connections has exceeded the specified limit; destination host is blocked or cleared; NAT disallows a connection; no controlling list; bad packet received
Warning Log	None
Notice Log	Oldest entry deleted; rate of connections has decreased to the specified limit; number of connections has decreased to below the specified limit
Info	None
Debug	None
Filter	None

flowServicesFirewallAudit

Description	Firewall
Emergency	None
Alert	None
Critical	None
Error	New connection disallowed
Warning Log	None
Notice Log	Transition from half-open to fully complete connection; transition to half-open connection
Info	None
Debug	None
Filter	None

frameRelay

Description	Frame Relay layer
Emergency	None
Alert	None
Critical	Failure to bring up the application due to lack of memory resources
Error	Summary information about automatic removal of interface or circuit from nonvolatile storage on startup; internal resource pool is too small
Warning Log	None
Notice Log	Lack of pool space for SNMP traps (it is permissible for SNMP traps to be unreliable); failure to obtain line module configuration on line module insertion
Info	Line module insertion and removal information
Debug	Creation of interfaces or circuits from nonvolatile storage on startup; detailed information about automatic removal of interfaces or circuit from nonvolatile storage on startup; reporting on SNMP traps for interfaces or circuits; engine debug messages
Filter	None

fsAgent

Description	File System Agent
Emergency	None
Alert	None
Critical	Previous file system sync failed—booting protected images
Error	File system unavailable
Warning Log	File transfer initialization failure; unexpected software error
Notice Log	None
Info	File transfer notification; platform or release mismatch; file transfer error; release file is corrupt; image path not found; insufficient resources to copy release

Debug Status of copy running-config; file transfer status; backup boot-setting configuration notification; subsystem release configuration notification

Filter None

ftl

Description FTI layer

Emergency None

Alert None

Critical None

Error None

Warning Log Interface creation or binding failure

Notice Log Failure to bring line module application online; dropped interface state change notification due to lack of resources; discarded stale line module notification

Info Dropped interface state change notification for unknown or removed interface

Debug None

Filter None

ftpClient

Description FTP client

Emergency None

Alert None

Critical None

Error Unexpected results during a transfer

Warning Log None

Notice Log Completion status of a network connection command (example: " Succeeded creating data socket")

Info	Completion status of a user command (example: "IS command succeeded")
Debug	None
Filter	None

ftpServer

Description	FTP server
Emergency	None
Alert	None
Critical	None
Error	Error listening for new client connection; error creating daemon task
Warning Log	Error creating new server task; socket write error; error adjusting socket window size
Notice Log	Daemon task created; waiting for new client connection; accept client from host a.b.c.d; maximum client sessions exceeded; FTP daemon shutdown complete
Info	Starting FTP daemon shutdown
Debug	Read FTP command
Filter	None

CHAPTER 9

G and H Commands

- [gplan on page 87](#)
- [ha on page 87](#)
- [hdlc on page 88](#)
- [hotfixGeneral on page 89](#)
- [httpServer on page 89](#)

[gplan](#)

Description	General purpose locally allocated address notifier
Emergency	None
Alert	None
Critical	None
Error	Out of resources
Warning Log	None
Notice Log	Task creation or deletion
Info	None
Debug	Adding or deleting IP addresses; adding or deleting user sessions
Filter	None

[ha](#)

Description	High availability messages
Emergency	None

Alert	None
Critical	None
Error	Accessing redundancy mode not supported on the standby SRP; changing redundancy mode not supported on the standby SRP; high availability disabled due to state error; error encountered during the transition from one high availability state to another when stateful line module switchover is performed
Warning Log	High availability for SRP and line modules disabled due to incompatible release on standby; high availability for SRP and line modules disabled due to user initiated disable
Notice Log	High availability for SRP and line modules disabled due to standby down; high availability is now active
Info	None
Debug	None
Filter	None

hdlc

Description	HDLC layer
Emergency	None
Alert	None
Critical	None
Error	Interface creation failures (interface is not created); interface configuration errors; interface pool failures
Warning Log	Interface creation failures during initialization; interface deletion failures (interface is still deleted); interface pool failures (might not cause problems)
Notice Log	Interface pool changes
Info	Layer initialization messages; interface creation; interface modification; interface deletion
Debug	Detailed layer initialization; interface creation details; interface deletion details
Filter	None

hotfixGeneral

Description	Hotfix general
Emergency	None
Alert	None
Critical	None
Error	Error conditions causing startup hotfix activation to fail
Warning Log	Failed to deactivate or disarm a hotfix; attempts to activate incompatible hotfixes
Notice Log	Activation or arming of a hotfix
Info	None
Debug	None
Filter	None

httpServer

Description	Embedded HTTP server
Emergency	None
Alert	None
Critical	None
Error	Failure to enable HTTP daemons (httpd); failure to remove httpd; failure to grow pool of httpds or pool of HTTP connections (https); failure to listen on httpd socket; failure to set TCP socket options; failure to remove TCP socket; failure to queue HTTP event (socket accept, socket approve, socket send, socket receive); failure to queue HTTP event for maximum connection aging; invalid HTTP event
Warning Log	Refused HTTP connection due to too many simultaneous connections from same host; refused HTTP connection due to access list deny; failure to perform TCP socket approval; failure to send data on TCP socket
Notice Log	None

- Info** Start or stop HTTP process; create or remove httpd; growing a pool of httpds; enable or disable httpd; growing a pool of HTTP connections (https); failure to perform TCP socket accept; growing a pool of HTTP events; updated HTTP scalars; handed out (global/token) address to dhcp-ls client; authentication passed from dhcp-ls for a given client; renewing token address for dhcp-ls client; removed session with dhcp-ls; removed global address through gplaanDelete; dhcp-ls user login/logout/shortcut login; create or remove HTTP interface redirect URL
- Debug** Server self-bind (for example, started HTTP without instantiating any httpd); attempt to remove nonexistent httpd; attempt to reread from NVS; updated httpd; create or remove session with dhcp-ls; bind or unbind with policy table; invalid or valid TCP socket approve or accept; received data from stale socket; create or remove HTTP connection; receive data from httpc; queued HTTP event; aging group of https; added new address at dhcp-ls session; phase 1 of 2 for authentication passed from dhcp-ls for a given client; revoking token address for a given dhcp-ls client
- Filter** None

CHAPTER 10

I Commands

- [iclImageFixServer](#) on page 92
- [icmpTraffic](#) on page 93
- [icmpv6Traffic](#) on page 94
- [icrPartitionManager](#) on page 94
- [igmpGeneral](#) on page 95
- [igmpGracefulRestart](#) on page 96
- [igmpGroupState](#) on page 97
- [ikeCertificateMgr](#) on page 97
- [ikeEnrollment](#) on page 98
- [ikepki](#) on page 98
- [interModuleCommunication](#) on page 99
- [ipAccessList](#) on page 100
- [ipEngine](#) on page 100
- [ipEngineering](#) on page 101
- [ipflowstats](#) on page 101
- [ipflowstatsEngine](#) on page 102
- [ipGeneral](#) on page 102
- [ipIfCreator](#) on page 104
- [ipInterface](#) on page 104
- [ipNhopTrackerGeneral](#) on page 105
- [ipProfileMgr](#) on page 105
- [ipRoutePolicy](#) on page 106
- [ipRouteTable](#) on page 106
- [ipseclDb](#) on page 107
- [ipsecP1Throttler](#) on page 107
- [ipsecXcfgSM](#) on page 108
- [ipSubscriberMgr](#) on page 108
- [ipTraffic](#) on page 109

- [ipTunnel](#) on page 109
- [ipv6AccessList](#) on page 110
- [ipv6Engineering](#) on page 111
- [ipv6General](#) on page 111
- [ipv6Interface](#) on page 112
- [ipv6ProfileMgr](#) on page 113
- [ipv6RouteTable](#) on page 113
- [ipv6Traffic](#) on page 114
- [ipv6Types](#) on page 115
- [isisAdjChange](#) on page 115
- [isisAdjPackets](#) on page 116
- [isisBfdEvents](#) on page 117
- [isisChecksumErr](#) on page 117
- [isisGeneral](#) on page 118
- [isisHelloGeneral](#) on page 118
- [isisHelloPackets](#) on page 119
- [isisIpv6Log](#) on page 119
- [isisLdpEvents](#) on page 120
- [isisLocalUpdate](#) on page 120
- [isisMplsTeAdvertisements](#) on page 121
- [isisMplsTeEvents](#) on page 122
- [isisNsfEvents](#) on page 122
- [isisProtocolErr](#) on page 123
- [isisSnPackets](#) on page 123
- [isisSpfEvents](#) on page 124
- [isisSpfStatistics](#) on page 124
- [isisSpfTriggers](#) on page 125
- [isisUpdatePackets](#) on page 125
- [isVoice](#) on page 126
- [itm](#) on page 126

icImageFixServer

Description	IC image fix server
Emergency	None
Alert	None
Critical	None

Error	Memory allocation failure; ImageFix load failure; manual ImageFix activation failure; ImageFix file errors
Warning Log	Buffer allocation failure; unexpected status received in state X
Notice Log	Application image up, startup ImageFixes activated; reversion from FC ImageFix to release FC image requires reload of line module; FC ImageFix found for line module
Info	State machine change; unexpected internal communication error; loading complete announcement; IC up-to-date following SRP switch; sending ImageFix descriptor to line module
Debug	Controller state change announcement; board state change announcement; manual ImageFix [de]activation attempt; subsystem announced
Filter	None

icmpTraffic

Description	ICMP frame transmit or receive
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	All ICMP transmit or receive events
Filter 1	remote-ip-address <i>ipAddress</i> [<i>ipAddressMask</i>] <ul style="list-style-type: none"> remote-ip-address—Logs events for a remote address <i>ipAddress</i>—Address of remote system for which you want to log messages <i>ipAddressMask</i>—Mask for the remote address
Filter 2	router <i>virtualRouterName</i> [remote-ip-address <i>ipAddress</i> [<i>ipAddressMask</i>]]

- **router**—Logs events on a specific virtual router
- **virtualRouterName**—Name of virtual router for which you want to log events
- **remote-ip-address**—Logs events for a remote address
- **ipAddress**—Address of remote system for which you want to log messages
- **ipAddressMask**—Mask for the remote address

icmpv6Traffic

Description	ICMPv6 frame transmit or receive
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Packets of unknown types, invalid headers, with header errors
Notice Log	None
Info	Failures due to checksum errors, unsupported
Debug	All ICMPv6 transmit or receive events
Filter 1	[remote-ipv6-address <i>ipv6Address</i>] <ul style="list-style-type: none">• remote-ipv6-address—Logs events for packets arriving from or going to a specified IPv6 address• ipv6Address—IPv6 address of remote system for which you want to log messages
Filter 2	router <i>virtualRouterName</i> [address <i>ipv6Address</i>] <ul style="list-style-type: none">• router—Logs events on a specific virtual router• virtualRouterName—Name of virtual router for which you want to log events• address—Logs events on a specific IPv6 address• ipv6Address—Address of remote system for which you want to log messages

icrPartitionManager

Description	Interchassis Redundancy Partition Manager
--------------------	---

Emergency	None
Alert	None
Critical	None
Error	Errors allocating memory for any ICR activity; Error adding, configuring, removing ICR partitions and other errors during ICR transition.
Warning Log	None
Notice Log	Delay in changing the state of the ICR partition; Unable to change the state of the ICR partition because of RADIUS access issues.
Info	None
Debug	Successful ICR configuration such as creation and removal of ICR partition ; Addition and removal of ICR group members within partition, PPP, AAA, and Ethernet acknowledgement messages during ICR transitions, and other messages.
Filter	None

igmpGeneral

Description	IGMP general
Emergency	None
Alert	None
Critical	None
Error	Nonrecoverable errors
Warning Log	NVS errors
Notice Log	Errors while configuring or learning groups
Info	None
Debug	IGMP interface or group state change; errors in packet transmit or receive
Filter 1	interface <i>interfaceType</i> <i>interfaceSpecifier</i> <ul style="list-style-type: none"> interface—Logs events for a specific interface

- *interfaceType*—Type of interface for which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

Filter 2 `router virtualRouterName [interface interfaceType interfaceSpecifier]`

- *router*—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events
- *interface*—Logs events on a specific interface on the virtual router
- *interfaceType*—Type of interface for which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

igmpGracefulRestart

Description	IGMP graceful restart
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	IGMP/MLD graceful restart complete
Info	None
Debug	None
Filter	None

igmpGroupState

Description	IGMP group state change events
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	igmp v2 first host join, last host leave events (Release 5.0 and earlier); igmp v3 state change and source-list change events aggregated across all hosts on the interface (Release 5.1.0 and later)
Debug	None
Filter	router <i>virtualRouterName</i> [interface <i>interfaceType</i> <i>interfaceSpecifier</i>] <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of the virtual router for which you want to log events • interface—Logs events on a specific interface on the virtual router • <i>interfaceType</i>—Type of the interface for which you want to log events. For example, atm or fastEthernet. • <i>interfaceSpecifier</i>—Location of the interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

ikeCertificateMgr

Description	Displays events relating to ERX key generation, certificate status, and certificate processing
Emergency	None
Alert	None

Critical	None
Error	Initialization problems
Warning Log	Missing ERX private key; public key does not match private key; certificate expired; memory allocation problems; CRL too large; attempt to generate new key pair before deleting old one; key generation problems; problem reading private key
Notice Log	Problem decoding certificates; IKE authentication problems related to certificates
Info	None
Debug	Certificate database notifications
Filter	None

ikeEnrollment

Description	Displays events relating to certificate enrollment
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Identity no set; missing ERX private key; missing CA certificate; enrollment failures
Notice Log	None
Info	Received CA certificate; received CA and RA certificate chain; received ERX certificate; retry scep poll message
Debug	Found CA certificate; found ERX certificates; enrollment failure details
Filter	None

ikepki

Description	IKE SA negotiation
Emergency	None

Alert	None
Critical	None
Error	Event occurred that is unexpected for the current state
Warning Log	Memory pool growth problems; recoverable state problems; receiving IKE packets for unconfigured peer
Notice Log	IKE configuration problems—no preshared keys for peer; recoverable status conditions
Info	Number of successful SAs negotiation, both phase 1 and phase 2; unsuccessful phase 1 negotiation information; unsuccessful phase 2 negotiation information
Debug	Detailed SA negotiation debug information
Filter	None

interModuleCommunication

Description	Intermodule communication monitoring
Emergency	None
Alert	None
Critical	Line module resetting after recovery attempts fail; standby SRP module resetting after monitoring thresholds exceeded; primary SRP module resetting after all line modules fail because of issue with primary SRP module
Error	None
Warning Log	Line module recovery attempts after monitoring thresholds exceeded
Notice Log	Ping monitoring threshold exceeded; ICC session monitoring threshold exceeded; ICC connection monitoring threshold exceeded
Info	Intermodule communication monitoring condition, state change, and corresponding action
Debug	None
Filter	<i>slot slotNumber</i> <ul style="list-style-type: none"> slot—Logs events for a specific slot

- *slotNumber*—Number of slot for which you want to log events

ipAccessList

Description	IP access list matching
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Access list rule has been matched
Debug	None
Filter 1	<div>accessList<ul style="list-style-type: none">• accessList—Logs a match on any access-list entry for all access lists</div>
Filter 2	<div>accessList router <i>virtualRouterName</i> access-list <i>accessListName</i> access-element-id <i>idNumber</i><ul style="list-style-type: none">• accessList—Logs a match on any access-list entry• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events• access-list—Logs events for a specific access list• <i>accessListName</i>—Name of access list for which you want to log events• access-element-id—Logs events for a specific element ID• <i>idNumber</i>—Element ID number for which you want to log events; the element ID is automatically assigned for access-list rules that you explicitly create and is shown by issuing the show access-list detail command</div>

ipEngine

Description	IP chassis manager
Emergency	None

Alert	None
Critical	None
Error	Failure in operations such as adding, removing, or deleting interfaces or distributing routing tables to line modules
Warning Log	Errors such as attempting to configure something that is not supported on a module, or routing table memory is approaching 80 percent full
Notice Log	Something unexpected happened; for example, an interface was deleted twice or, internal to the software, connections between IC and SRP were deleted twice
Info	Completion status of a user command (for example: "IS command succeeded")
Debug	An engine or agent that corresponds to a virtual router is added or deleted; an interface is added or deleted
Filter	None

ipEngineering

Description	IP Engineering
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Notifying AAA about duplicate prefix: <i>profileHandle</i> (authId: <i>authId</i> , rtr uid: <i>router</i>)
Debug	None
Filter	None

ipflowstats

Description	J-Flow statistics
--------------------	-------------------

Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Application starting
Info	Interfaces become available or unavailable
Debug	Main and History cache tables are cleared
Filter	None

ipflowstatsEngine

Description	J-Flow statistics engine
Emergency	None
Alert	None
Critical	None
Error	Agents stopping or deleting; memory allocation errors; line module errors
Warning Log	Problems bring modules or slots up or down
Notice Log	None
Info	Agent or master creation; slot or operation state information
Debug	Creation or removal of engine; initialization problems
Filter	None

ipGeneral

Description	IP general
Emergency	None

Alert	None
Critical	(IP) Interface stacking management errors
Error	(ARP) Allocation of Ethernet next hop failed (IP) Not able to create interface or create address on null 0 interface; undefined IP status code; interface stacking management errors; send and forward failures because of not finding corresponding egress or ingress nodes; conflict in adding hidden routes
Warning Log	(IP) NVS load errors; failure to add address on an interface because of low memory
Notice Log	None
Info	None
Debug	(ARP) NextHopPool is out of memory and trying to expire old entries; ARP data events (IP) Interface stacking management errors

Filter 1 `interface interfaceType interfaceSpecifier`

- `interface`—Logs events for a specific interface
- `interfaceType`—Type of interface for which you want to log events
- `interfaceSpecifier`—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

Filter 2 `router virtualRouterName [interface interfaceType interfaceSpecifier]`

- `router`—Logs events for a specific virtual router
- `virtualRouterName`—Name of virtual router for which you want to log events
- `interface`—Logs events on a specific interface on the virtual router
- `interfaceType`—Type of interface for which you want to log events. For example, atm or fastEthernet.
- `interfaceSpecifier`—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

ipIfCreator

Description	IP interface creator events
Emergency	None
Alert	None
Critical	None
Error	Out of resources failures in midoperation; client application and DCM interaction errors (out-of-range sessionId or enum; unrecognized message type); failure during client callback for interface creation
Warning Log	Client session already unbound; unable to process new configuration requests (out of resources)
Notice Log	Interface deletion failure in DCM (no client acknowledgement required)
Info	None
Debug	Client interaction during bind or unbind, session creation or shutdown, and interface creation or deletion; DCM interaction during interface creation or deletion
Filter	None

ipInterface

Description	IP interface
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Error status is returned by lower layer configuration; best route is pointing to an unnumbered interface with an invalid source IP address; unnumbered interface is pointing to invalid loopback interface problems; packets received with invalid source IP address on interfaces
Notice Log	None

Info	None
Debug	Interface state transitions and deletions; interface state machine events
Filter 1	interface—See description of the ipGeneral interface filter for information about this filter
Filter 2	router—See description of the ipGeneral router filter for information about this filter

ipNhopTrackerGeneral

Description	Next-hop tracker for IP shared interfaces
Emergency	None
Alert	None
Critical	None
Error	Errors in tracking of routes that resolve indirect next hops
Warning Log	None
Notice Log	None
Info	None
Debug	None
Filter	None

ipProfileMgr

Description	IP Profile Manager
Emergency	None
Alert	None
Critical	None
Error	Failure to create or delete dynamic IP interfaces
Warning Log	None
Notice Log	None

Info	None
Debug	Events related to dynamic IP interface creation or deletion; assignment or unassignment of profiles to interfaces
Filter	None

ipRoutePolicy

Description	IP route policy
Emergency	None
Alert	None
Critical	None
Error	Failure to clean up NVS while a routing policy was being deleted; failure to store the routing policy to NVS while a new routing policy was being created; failure to find an expected routing policy created previously
Warning Log	Failure to create a new routing policy due to memory limitation; misuse of a routing policy
Notice Log	None
Info	Result of routing policy check; specifies which routing policy is used
Debug	Successful addition or deletion of routing policies
Filter	<i>router virtualRouterName</i> <ul style="list-style-type: none">• <i>router</i>—Logs IP route policy events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ipRouteTable

Description	IP routing table
Emergency	None
Alert	None
Critical	None

Error	Next-hop resolution-related problems; exceeding maximum route limit or warning threshold
Warning Log	Failure to add route
Notice Log	None
Info	In process of finding best route information
Debug	Normal routing table updates; next-hop resolution for static routes
Filter 1	interface—See description of the ipGeneral interface filter for information about this filter
Filter 2	router—See description of the ipGeneral router filter for information about this filter

ipseclDb

Description	Phase 1 identity database information. Used for deciding which phase 1 identity to use for incoming IKE negotiations.
Emergency	None
Alert	None
Critical	None
Error	Internal dBase issue with hashes
Warning Log	Problems adding or deleting entries
Notice Log	None
Info	Adding entries to database
Debug	Detailed database information and transactions
Filter	None

ipsecP1Throttler

Description	Ongoing phase 1 negotiations
Emergency	None
Alert	None

Critical	None
Error	None
Warning Log	Throttling instances based on suspicious flows (for example, the same peer failing repeated fast negotiations)
Notice Log	None
Info	None
Debug	None
Filter	None

ipsecXcfgSM

Description	Xauth application state machine information.
Emergency	None
Alert	None
Critical	None
Error	Internal state machine errors
Warning Log	State machine unexpected events; problems with xauth negotiations
Notice Log	Significant state changes
Info	None
Debug	None
Filter	None

ipSubscriberMgr

Description	IP Subscriber Manager
Emergency	None
Alert	None

Critical	None
Error	Primary interface not found
Warning Log	None
Notice Log	None
Info	None
Debug	Dump parameters for methods; dump results for lookups; dump points during thread execution; log in of multiple subscribers with the same IP address on different DHCP Local Servers across virtual routers
Filter	None

ipTraffic

Description	IP frame transmit and receive
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Data errors detected in frames
Notice Log	Dropped frames—No error
Info	None
Debug	Normal data events
Filter 1	interface—See description of the ipGeneral interface filter for information about this filter
Filter 2	router—See description of the ipGeneral router filter for information about this filter

ipTunnel

Description	IP tunnel
Emergency	None

Alert	None
Critical	None
Error	None
Warning Log	Unexpected but recoverable events
Notice Log	No more pool space for interface up notification
Info	None
Debug	Function trace
Filter	None

ipv6AccessList

Description	IPv6 access list matching
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Access list rule has been matched
Debug	None
Filter 1	accessList <ul style="list-style-type: none">accessList—Logs a match on any access-list entry for all IPv6 access lists
Filter 2	accessList router <i>virtualRouterName</i> access-list <i>accessListName</i> access-element-id <i>idNumber</i> <ul style="list-style-type: none">accessList—Logs a match on any access-list entryrouter—Logs events for a specific virtual router

- *virtualRouterName*—Name of virtual router for which you want to log events
- *access-list*—Logs events for a specific access list
- *accessListName* —Name of access list for which you want to log events
- *access-element-id*—Logs events for a specific element ID
- *idNumber*—Element ID number for which you want to log events; the element ID is automatically assigned for access-list rules that you explicitly create and is shown by issuing the **show ipv6 access-list detail** command

ipv6Engineering

Description	IPv6 Engineering
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Downloaded route is replaced by another route
Info	None
Debug	Download-related API methods are called
Filter	None

ipv6General

Description	IPv6 general
Emergency	None
Alert	None
Critical	None
Error	License-related errors (for example, attempting to configure IPv6 without configuring the license first); error in sending interface up or down events to IPv6
Warning Log	Primary IPv6 address on an interface is not found

Notice Log None

Info None

Debug None

Filter 1 `interface interfaceType interfaceSpecifier`

- `interface`—Logs events for a specific interface
- `interfaceType`—Type of interface for which you want to log events
- `interfaceSpecifier`—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

Filter 2 `router virtualRouterName [interface interfaceType interfaceSpecifier]`

- `router`—Logs events for a specific virtual router
- `virtualRouterName`—Name of virtual router for which you want to log events
- `interface`—Logs events on a specific interface on the virtual router
- `interfaceType`—Type of interface for which you want to log events (for example, atm or fastEthernet)
- `interfaceSpecifier`—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

ipv6Interface

Description IPv6 interface

Emergency None

Alert None

Critical None

Error None

Warning Log	Interface configuration errors; errors in pointing interface to another interface; interface LocalAddress-related errors
Notice Log	None
Info	None
Debug	Interface state transitions
Filter 1	interface—See description of the ipv6General interface filter for information about this filter
Filter 2	router—See description of the ipv6General router filter for information about this filter

ipv6ProfileMgr

Description	IPv6 Profile Manager
Emergency	None
Alert	None
Critical	None
Error	Failure to create or delete dynamic IPv6 interfaces
Warning Log	None
Notice Log	None
Info	None
Debug	Events related to dynamic IPv6 interface creation or deletion; assignment or unassignment of profiles to interfaces
Filter	None

ipv6RouteTable

Description	IPv6 routing table
Emergency	None
Alert	None

Critical	None
Error	Next-hop resolution-related problems; exceeding maximum route limit or warning threshold; route add and delete errors
Warning Log	Route limit-related warnings
Notice Log	Route limit-related messages
Info	None
Debug	Normal routing table updates; next-hop resolution for static routes; redistribution events; overload list processing; routing table session creation; route change notification events; route add/delete information; route cleanup events
Filter 1	interface—See description of the ipv6General interface filter for information about this filter
Filter 2	router—See description of the ipv6General router filter for information about this filter

ipv6Traffic

Description	IPv6 frame transmit and receive
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Normal data events
Filter 1	[router <i>virtualRouterName</i>] <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

Filter 2 [address *ipv6Address*]

- address—Logs events for packets arriving from or going to a specified IPv6 address
- *ipv6Address*—IPv6 address of remote system for which you want to log messages

ipv6Types

Description	IPv6 general
Emergency	None
Alert	None
Critical	System out of memory error for allocating IPv6 addresses; IPv6 shutdown started in all virtual routers
Error	System low on memory; IPv6 address allocation may fail
Warning Log	None
Notice Log	None
Info	None
Debug	None
Filter	None

isisAdjChange

Description	IS-IS adjacency up or down
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Adjacency state change
Info	None

Debug None

Filter 1 `interface interfaceType interfaceSpecifier`

- `interface`—Logs events for a specific interface
- `interfaceType`—Type of interface for which you want to log events
- `interfaceSpecifier`—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

Filter 2 `router virtualRouterName [interface interfaceType interfaceSpecifier]`

- `router`—Logs events for a specific virtual router
- `virtualRouterName`—Name of virtual router for which you want to log events
- `interface`—Logs events on a specific interface on the virtual router
- `interfaceType`—Type of interface for which you want to log events
- `interfaceSpecifier`—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

isisAdjPackets

Description IS-IS adjacency hello packets

Emergency None

Alert None

Critical None

Error None

Warning Log Error in sent IIH or received IIH

Notice Log Sent or received IIH, DR election

Info Authentication failed

Debug	Detailed information about IIH
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisBfdEvents

Description	IS-IS and BFD interaction and IS-IS session log
Emergency	None
Alert	None
Critical	None
Error	BFD to IS-IS interaction failure errors; out of memory errors
Warning Log	None
Notice Log	None
Info	BFD session state changes
Debug	None
Filter	Router and interface

isisChecksumErr

Description	IS-IS checksum errors
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	LSP checksum error
Notice Log	None

Info	None
Debug	None
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisGeneral

Description	IS-IS system notifications
Emergency	None
Alert	None
Critical	None
Error	Error in restoring NVS
Warning Log	Exceeding maximum IP addresses on interface or maximum sequence number
Notice Log	Error in redistributing routes; LAN circuit coming up; BGP converged; BGP not converged and IS-IS times out; transient black hole avoidance suppressed because graceful restart has been configured and is in progress
Info	None
Debug	Redistributed routes
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisHelloGeneral

Description	IS-IS system notifications
Emergency	None
Alert	None
Critical	None

Error	Memory failure and other fatal errors
Warning Log	Communication failure between IS-IS and IS-IS hello
Notice Log	None
Info	None
Debug	Timer expiration and other normal events
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisHelloPackets

Description	IS-IS hello packets
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Hello packets sent and received
Debug	Dumping hello packet in detail
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisIpv6Log

Description	IS-IS IPv6 events
Emergency	None

Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	IS-IS IPv6 events
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisLdpEvents

Description	Displays information about the interactions between LDP and IS-IS in the course of LDP-IGP synchronization.
Emergency	None
Alert	None
Critical	None
Error	Failure to communicate with LDP and out of memory conditions
Warning Log	None
Notice Log	None
Info	None
Debug	LDP interactions
Filter	None

isisLocalUpdate

Description	IS-IS local LSP packets
--------------------	-------------------------

Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Sent local LSP
Info	None
Debug	None
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisMplsTeAdvertisements

Description	IS-IS MPLS traffic engineering advertisements
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Resource information changes
Filter	None

isisMplsTeEvents

Description	IS-IS MPLS traffic engineering
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Start or stop MPLS function; tunnel in use by IS-IS; explicit route computation
Debug	Detailed debugging information for MPLS function
Filter	None

isisNsfEvents

Description	Log events related to IS-IS non-stop forwarding procedure during system warm start
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Logs IS-IS NSF timer related events (for example, expiration and cancellation of timers [T1, T2, T3])
Debug	Restart-request transmit; restart-ack receive; SNP receive processing; LSP synchronization; LSP purging

Filter 1 interface—See description of the `isisAdjChange` interface filter for information about this filter

Filter 2 router—See description of the `isisAdjChange` router filter for information about this filter

isisProtocolErr

Description	IS-IS protocol errors
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	LSP protocol error
Notice Log	None
Info	None
Debug	None
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> router—Logs events for a specific virtual router <i>virtualRouterName</i>—Name of virtual router for which you want to log events

isisSnppackets

Description	IS-IS complete sequence numbers PDU (CSNP) and partial sequence numbers PDU (PSNP) packets
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Error in received CSNP or PSNP

Notice Log	Sent PSNP; received CSNP or PSNP packets; PSNP authentication failed
Info	Sent CSNP packets; CSNP authentication failed
Debug	LSP entries
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isisSpfEvents

Description	IS-IS Shortest Path First (SPF)
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Start or suspend SPF; updating routing table
Info	Add tent or path; process LSP; attach bit is ignored for <i>sysid</i> ; no automatic default routes
Debug	Add route
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

isisSpfStatistics

Description	IS-IS SPF timing and statistic data
Emergency	None
Alert	None
Critical	None

Error	None
Warning Log	None
Notice Log	SPF compute time
Info	None
Debug	None
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

isisSpfTriggers

Description	IS-IS SPF triggering
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	SPF trigger event
Info	None
Debug	None
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

isisUpdatePackets

Description	IS-IS LSP packets sent or received
Emergency	None

Alert	None
Critical	None
Error	None
Warning Log	Error in received LSP
Notice Log	Sent or received LSP
Info	Authentication failed; processed received LSP
Debug	Set or cleared SRM flags; building LSP
Filter 1	interface—See description of the isisAdjChange interface filter for information about this filter
Filter 2	router—See description of the isisAdjChange router filter for information about this filter

isVoice

Description	IS Voice application
Emergency	None
Alert	None
Critical	None
Error	NVS error; out of resources error; unexpected error
Warning Log	IP request failed
Notice Log	LSP used by IP circuit changes state (up, down, or modified); IP circuit requested, updated, or removed
Info	Voice gateway session established, terminated, or replaced
Debug	Management get, set, create, and remove
Filter	None

itm

Description	IPsec transport mode
--------------------	----------------------

Emergency	None
Alert	None
Critical	None
Error	IPsec transport protocol interaction failures; interface engine interaction failures; IPsec transport profile configuration errors; interface configuration errors
Warning Log	Recoverable IPsec transport interface–related configuration and operational error
Notice Log	IPsec transport interface state change
Info	IPsec transport interface interaction with IKE protocol; interface pool usage
Debug	Details about the interaction between the IPsec transport interface and the IKE protocol; configuration and operational changes of the IPsec transport interface events; interface engine interaction
Filter	None

CHAPTER 11

L Commands

- [l2cGeneral on page 130](#)
- [l2cKeepAlive on page 130](#)
- [l2cPacket on page 131](#)
- [l2tp on page 131](#)
- [l2tpDialoutGenerator on page 132](#)
- [l2tpDisconnectCause on page 132](#)
- [l2tpIpLowerBinding on page 133](#)
- [l2tpStateMachine on page 133](#)
- [lasv6General on page 134](#)
- [ldpConnect on page 134](#)
- [ldpGeneral on page 135](#)
- [ldpGracefulRestart on page 135](#)
- [ldpHelloMessages on page 136](#)
- [ldpHelloMgr on page 136](#)
- [ldpInterface on page 137](#)
- [ldpMessages on page 138](#)
- [ldpPeer on page 138](#)
- [ldpShimInterface on page 139](#)
- [ldpSocket on page 140](#)
- [ldpTimer on page 140](#)
- [ldpVpls on page 141](#)
- [ldpWorker on page 141](#)
- [localAddressServerGeneral on page 142](#)
- [localAuthServer on page 142](#)
- [localEnableAuthServer on page 143](#)
- [localLinePassword on page 143](#)

l2cGeneral

Description	Layer 2 Control application general
Emergency	None
Alert	None
Critical	None
Error	Signal protocol failures, out of resources errors
Warning Log	Signal unexpected but recoverable socket conditions
Notice Log	None
Info	None
Debug	Neighbor, socket events
Filter	None

l2cKeepAlive

Description	Layer 2 Control adjacency packets
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Adjacency protocol packet processing
Filter	None

l2cPacket

Description	Layer 2 Control protocol packets
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Signal recoverable, unexpected packet processing failures
Notice Log	None
Info	None
Debug	Protocol packet exchange
Filter	None

l2tp

Description	Layer 2 Tunneling Protocol
Emergency	None
Alert	None
Critical	Nonrecoverable error
Error	Configuration error
Warning Log	Protocol error; insufficient resources; notify the reason for not sending the RX Connect-Speed AVP value to LNS
Notice Log	Status change; protocol warnings; in LNS, notify the session Rx Connect-Speed AVP value which is received in LNS in the Incoming-Call-Connected message
Info	Protocol operational information
Debug	Detailed debugging information; in LAC, notify the session Rx Connect-Speed AVP value which is to be sent to LNS

Filter None

l2tpDialoutGenerator

Description	L2TP dial-out
Emergency	None
Alert	None
Critical	None
Error	Internal software consistency errors; dial-out service denial because of insufficient resources; dial-out session failure
Warning Log	Dial-out NVS consistency errors; restrictions on maximum simultaneous dial-out components
Notice Log	None
Info	Dial-out resource pool expansion
Debug	None
Filter	None

l2tpDisconnectCause

Description	L2TP disconnect cause
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Disconnect error code information generated at LAC
Debug	None

Filter None

l2tpIpLowerBinding

Description Lower binding for L2TP and IP

Emergency None

Alert None

Critical None

Error Virtual router does not have a configured router ID; virtual router has a null router ID

Warning Log None

Notice Log None

Info None

Debug None

Filter None

l2tpStateMachine

Description Layer 2 Tunnel Protocol state machine trace

Emergency None

Alert None

Critical None

Error None

Warning Log None

Notice Log None

Info None

Debug State machine trace

Filter None

lasv6General

Description	IPv6 local address pool details
Emergency	None
Alert	None
Critical	None
Error	Error in configuration of the command for IPv6 local address pool or runtime errors, if any, that occur; IPv6 Neighbor Discovery router advertisements Prefix Allocation Failure; IPv6 Neighbor Discovery router advertisements Prefix pool name – Invalid length received; IPv6 Neighbor Discovery router advertisements Prefix pool not found; Authentication denied due to RADIUS Access-Request and Access-Accept failure; Reception of RADIUS message with Ipv6 Neighbor Discovery router advertisements prefix pool name VSA attribute included
Warning Log	None
Notice Log	LASv6 warm restart complete
Info	None
Debug	Detailed debugging information to assist in troubleshooting and analyzing problems
Filter	None

ldpConnect

Description	LDP connection information
Emergency	None
Alert	None
Critical	None
Error	Memory allocation failure.
Warning Log	None
Notice Log	LDP connection creation and deletion information
Info	None

Debug None

Filter *router virtualRouterName*

- *router*—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events

ldpGeneral

Description Label Distribution Protocol general events

Emergency None

Alert None

Critical None

Error Memory allocation failures; protocol interaction failures

Warning Log Message processing errors

Notice Log Interface transition; adjacency transition

Info Minor timer processing error

Debug LDP finite state machine transactions; RouteTable interaction transaction; message processing transaction

Filter *router virtualRouterName*

- *router*—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events

ldpGracefulRestart

Description LDP graceful restart events

Emergency None

Alert None

Critical None

Error None

Warning Log	None
Notice Log	LDP Neighbor Graceful Restart state changes
Info	LDP Graceful Restart timer operation
Debug	LDP Graceful Restart debug message
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ldpHelloMessages

Description	Label Distribution Protocol hello message event
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	LDP hello message processing errors
Notice Log	LDP hello message reception and transmission
Info	LDP hello message processing and transmission transaction
Debug	LDP hello message processing and transmission transaction details
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ldpHelloMgr

Description	Displays details about the task dedicated for sending LDP hellos, the LDP hello manager
Emergency	None
Alert	None

Critical	None
Error	Memory allocation failure
Warning Log	None
Notice Log	Hello transmission failure due to interface down
Info	None
Debug	Hello transmission debug information
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ldpInterface

Description	LDP interface
Emergency	None
Alert	None
Critical	None
Error	Failure to enable LDP on the interface
Warning Log	None
Notice Log	Interface up and interface down events
Info	None
Debug	Event with detailed interface parameters for normal operation
Filter	router <i>virtualRouterName</i> [interface <i>interfaceType</i> <i>interfaceSpecifier</i>] <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events • interface—Logs events on a specific interface on the virtual router • <i>interfaceType</i>—Type of interface for which you want to log events • <i>interfaceSpecifier</i>—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

ldpMessages

Description	Label Distribution Protocol session message events
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Minor TCP transmission error
Info	LDP session message processing and transmission transaction
Debug	None
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ldpPeer

Description	LDP peer events
Emergency	None
Alert	None
Critical	None
Error	LDP neighbor authentication setting failure
Warning Log	None

Notice Log	LDP neighbor authentication transaction
Info	None
Debug	LDP peer maintenance transaction
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ldpShimInterface

Description	LDP shim interface
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	None
Filter	router <i>virtualRouterName</i> [interface <i>interfaceType</i> <i>interfaceSpecifier</i>] <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events • interface—Logs events on a specific interface on the virtual router • <i>interfaceType</i>—Type of interface for which you want to log events • <i>interfaceSpecifier</i>—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

ldpSocket

Description	Displays details about the socket that is used to exchange LDP session messages and keepalives
Emergency	None
Alert	None
Critical	None
Error	Memory allocation failure
Warning Log	Socket creation failure
Notice Log	Socket creation and deletion information
Info	None
Debug	Socket send and receive information
Filter	<i>router virtualRouterName</i> <ul style="list-style-type: none">• <i>router</i>—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

ldpTimer

Description	Displays details about LDP timer events; when a timer expires or is scheduled
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Timer event information

Filter *router virtualRouterName*

- *router*—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events

ldpVpls

Description Displays details about LDP signaling for VPLS configurations

Emergency None

Alert None

Critical None

Error None

Warning Log VPLS failure

Notice Log VPLS up and down state information

Info None

Debug VPLS debug information

Filter *router virtualRouterName*

- *router*—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events

ldpWorker

Description Displays details about the background LDP jobs (LDP worker events)

Emergency None

Alert None

Critical None

Error Memory allocation failure

Warning Log Invalid PDU

Notice Log Worker creation and deletion information

Info	TCP socket reset by peer
Debug	Worker running information
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events

localAddressServerGeneral

Description	LAS general
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Attempts to set a local pool group name; attempts to restore an overlapping address range from a previous version of the software
Notice Log	Attempts to allocate an address from the backup local address pool group name because all the addresses in the primary local address pool group have been already allocated.
Info	None
Debug	Control flow and key events
Filter	None

localAuthServer

Description	Local authentication server
Emergency	None
Alert	None
Critical	None
Error	Cannot bind to local authentication server; memory cannot be allocated for local authentication server; cannot send configuration request; cannot send information

request; invalid virtual router; error with specified user database; cannot create local user database at startup

Warning Log Internal AAA user profile missing; cannot create users at startup; user associated with invalid virtual router; users reassigned to default user database; invalid user database; cannot associate users with virtual router

Notice Log None

Info None

Debug Server started; server bind occurred; no user name provided; no CHAP challenge provided; no authenticate request message allocated

Filter None

localEnableAuthServer

Description Authentication server using locally stored enable secret

Emergency None

Alert None

Critical None

Error None

Warning Log Connection granted: no secrets are configured

Notice Log None

Info None

Debug Authentication attempted; no memory for protocol message; connection granted: correct password; connection denied: incorrect password

Filter None

localLinePassword

Description Local line password authentication server

Emergency None

Alert None

Critical	None
Error	Unknown algorithm for local password
Warning Log	Connection granted or denied due to possible misconfiguration
Notice Log	None
Info	None
Debug	Connection granted or denied due to incorrect password
Filter	None

CHAPTER 12

M Commands

- [macroData](#) on page 146
- [macroScheduler](#) on page 146
- [mgmtGeneral](#) on page 147
- [mgmtGracefulRestart](#) on page 148
- [mgmtmv6General](#) on page 148
- [mgmtmv6GracefulRestart](#) on page 149
- [mldGeneral](#) on page 150
- [mldGracefulRestart](#) on page 151
- [mldGroupState](#) on page 151
- [mmcd](#) on page 152
- [mobileIpv4HaBinding](#) on page 152
- [mobileIpv4HaEng](#) on page 153
- [mobileIpv4HaEvent](#) on page 153
- [mobileIpv4HaLog](#) on page 154
- [mplsFwdTable](#) on page 154
- [mplsGeneral](#) on page 155
- [mplsHighAvailability](#) on page 155
- [mplsMajorInterface](#) on page 156
- [mplsMinorInterface](#) on page 157
- [mplsRouter](#) on page 158
- [mplsShimInterface](#) on page 158
- [mplsTraffic](#) on page 159
- [mrInfoLog](#) on page 159
- [mrInfoRcvdLog](#) on page 160
- [mrInfoSentLog](#) on page 160
- [mtraceLog](#) on page 161
- [mtraceRcvdLog](#) on page 161

- [mtraceSentLog](#) on page 162
- [multicastTraffic](#) on page 162

macroData

Description	Macro information
Emergency	None
Alert	None
Critical	None
Error	Error while running the macro
Warning Log	None
Notice Log	Data from env.setResults
Info	None
Debug	None
Filter	None

macroScheduler

Description	Macro information
Emergency	None
Alert	None
Critical	None
Error	Scheduled macro cannot be run
Warning Log	None
Notice Log	Start and completion of scheduled macro, Values set using env.setResult
Info	None
Debug	None
Filter	None

mgtmGeneral

Description	IP multicast group table manager general information
Emergency	None
Alert	None
Critical	None
Error	Major errors in MGMTM API calls resulting in failure
Warning Log	IP Multicast fastpath forwarding not supported on interface
Notice Log	Errors in MGMTM API calls; CAC limit exceeded on join/outgoing interface/port resulting in blocking of the join interface
Info	State change events; invalid parameters in API calls
Debug	(Source, Group) entries not found

Filter 1 interface *interfaceType interfaceSpecifier*

- interface—Logs events for a specific interface
- *interfaceType*—Type of interface for which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

Filter 2 router *virtualRouterName* [interface *interfaceType interfaceSpecifier*]

- router—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events
- interface—Logs events on a specific interface on the virtual router
- *interfaceType*—Type of interface for which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

mgtmGracefulRestart

Description	MGTm graceful restart
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Multicast graceful restart complete
Info	None
Debug	IGMP, PIM, IP route table multicast graceful restart complete
Filter	None

mgtmv6General

Description	IPv6 multicast group table manager general information
Emergency	None
Alert	None
Critical	None
Error	Major errors in MGTM API calls resulting in failure
Warning Log	IPv6 Multicast fastpath forwarding not supported on interface
Notice Log	Errors in MGTM API calls
Info	State change events; invalid parameters in API calls
Debug	(Source, Group) entries not found
Filter 1	interface <i>interfaceType interfaceSpecifier</i> <ul style="list-style-type: none">• interface—Logs events for a specific interface

- *interfaceType*—Type of interface for which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

Filter 2 `router virtualRouterName [interface interfaceType interfaceSpecifier]`

- *router*—Logs events for a specific virtual router
- *virtualRouterName*—Name of virtual router for which you want to log events
- *interface*—Logs events on a specific interface on the virtual router
- *interfaceType*—Type of interface for which you want to log events
- *interfaceSpecifier*—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

mgtmv6GracefulRestart

Description	MGTM V6 graceful restart
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	Multicast graceful restart complete
Info	None
Debug	IGMP, PIM, IP route table multicast graceful restart complete
Filter	None

mldGeneral

Description	Multicast Listener Discovery (MLD) general
Emergency	None
Alert	None
Critical	None
Error	Nonrecoverable errors
Warning Log	NVS errors
Notice Log	Errors while configuring or learning groups
Info	None
Debug	MLD interface or group state change
Filter 1	<p>interface <i>interfaceType interfaceSpecifier</i></p> <ul style="list-style-type: none">• interface—Logs events for a specific interface• <i>interfaceType</i>—Type of interface for which you want to log events• <i>interfaceSpecifier</i>—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

Filter 2	<p>router <i>virtualRouterName</i> [interface <i>interfaceType interfaceSpecifier</i>]</p> <ul style="list-style-type: none">• router—Logs events for a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events• interface—Logs events on a specific interface on the virtual router• <i>interfaceType</i>—Type of interface for which you want to log events• <i>interfaceSpecifier</i>—Location of interface in the appropriate format
-----------------	--



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

mldGracefulRestart

Description	MLD graceful restart
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	IGMP/MLD graceful restart complete
Info	None
Debug	None
Filter	None

mldGroupState

Description	Multicast Listener Discovery (MLD) group state change events
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	MLDv1 first host join, last host done events; MLDv2 state change and source-list change events aggregated across all hosts on the interface
Debug	None
Filter	router <i>virtualRouterName</i> [interface <i>interfaceType</i> <i>interfaceSpecifier</i>]

- **router**—Logs events for a specific virtual router
- **virtualRouterName**—Name of the virtual router for which you want to log events
- **interface**—Logs events on a specific interface on the virtual router
- **interfaceType**—The type of the interface for which you want to log events. For example, atm or fastEthernet.
- **interfaceSpecifier**—The location of the interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

mmcd

Description	MMC switch fabric driver
Emergency	None
Alert	None
Critical	None
Error	Errors in hardware configuration; resource limitation in fabric reached; errors in hardware
Warning Log	None
Notice Log	None
Info	None
Debug	Initialization details; configuration details; connection status details
Filter	None

mobileIpv4HaBinding

Description	Mobile IPv4 home agent binding
Emergency	None
Alert	None
Critical	None

Error	Registration request (RRQ) from foreign agent is prohibited by host access control list (ACL)
Warning Log	None
Notice Log	None
Info	None
Debug	Mobile IP timer started for n seconds, where n is the number of seconds
Filter	None

mobileipv4HaEng

Description	Mobile IPv4 home agent engineering
Emergency	None
Alert	None
Critical	None
Error	Home agent does not exist in the virtual router
Warning Log	None
Notice Log	Mobile IP warm restart initiated
Info	None
Debug	Verifying replay attack
Filter	None

mobileipv4HaEvent

Description	Mobile IPv4 home agent events
Emergency	None
Alert	None
Critical	None

Error	Authentication check failed
Warning Log	None
Notice Log	None
Info	None
Debug	Authentication check succeeded
Filter	None

mobileIpv4HaLog

Description	Mobile IPv4 home agent log
Emergency	None
Alert	None
Critical	None
Error	Registration request sanity check failed
Warning Log	None
Notice Log	Home agent deactivated in virtual router
Info	Home agent activated in virtual router
Debug	Authentication, authorization, and accounting (AAA) granted
Filter	None

mplsFwdTable

Description	MPLS forwarding table events
Emergency	None
Alert	None
Critical	None
Error	Nonfatal internal errors

Warning Log	Minor nonfatal internal errors
Notice Log	None
Info	None
Debug	Addition, deletion, and modification of table entries
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

mplsGeneral

Description	MPLS general purpose
Emergency	None
Alert	None
Critical	None
Error	Nonfatal internal errors; configuration errors
Warning Log	Major interface deletion; minor internal errors
Notice Log	None
Info	NVS operations
Debug	NVS operations; timer operations; minor interface label stacking; function flows; L2VPN instance created, destroyed
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of virtual router for which you want to log events

mplsHighAvailability

Description	MPLS high availability events
Emergency	None

Alert	None
Critical	None
Error	Nonfatal internal errors
Warning Log	Minor nonfatal internal errors
Notice Log	None
Info	Recovery of state information from NVS and mirrored storage; high-availability interactions with MPLS signaling protocols and line cards (major events)
Debug	High-availability interactions with MPLS signaling protocols and line modules (minor events)
Filter	None

mplsMajorInterface

Description	MPLS major interface
Emergency	None
Alert	None
Critical	None
Error	Signaling protocol interaction failures; major interface engine interaction failures; major interface finite state machine bad state transitions; major interface configuration errors; LSM interface label space interaction failures
Warning Log	None
Notice Log	None
Info	None
Debug	Major interface finite state machine transitions; signaling protocol interaction; major interface to engine transactions; major interface configuration transactions; LSM interface label space transactions
Filter	router <i>virtualRouterName</i> [interface <i>interfaceType</i> <i>interfaceSpecifier</i>]

- **router**—Logs events for a specific virtual router
- **virtualRouterName**—Name of virtual router for which you want to log events
- **interface**—Logs events on a specific interface on the virtual router
- **interfaceType**—Type of interface for which you want to log events
- **interfaceSpecifier**—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

mplsMinorInterface

Description	MPLS minor interface
Emergency	None
Alert	None
Critical	None
Error	Tunnel/LSP setup or teardown signaling protocol interaction failures; minor interface engine interaction failures; minor interface finite state machine bad state transitions; minor interface configuration errors; minor interface to IP interaction failures
Warning Log	None
Notice Log	None
Info	None
Debug	Minor interface to engine transactions; minor interface to IP transactions; minor interface configuration transactions; signaling protocol LSP setup or teardown transactions; minor interface finite state machine transitions
Filter 1	interface <i>interfaceType interfaceSpecifier</i> <ul style="list-style-type: none"> • interface—Logs events for a specific interface • interfaceType—Type of interface for which you want to log events • interfaceSpecifier—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	IP multicast packet transmit or receive information
Filter 1	<p>remote-ip-address <i>ipAddress</i> [<i>ipAddressMask</i>]</p> <ul style="list-style-type: none">• remote-ip-address—Logs events for a remote address• <i>ipAddress</i>—Address of remote system for which you want to log messages• <i>ipAddressMask</i>—Mask for the remote address
Filter 2	<p>router <i>virtualRouterName</i> [remote-ip-address <i>ipAddress</i> [<i>ipAddressMask</i>]]</p> <ul style="list-style-type: none">• router—Logs events on a specific virtual router• <i>virtualRouterName</i>—Name of virtual router for which you want to log events• remote-ip-address—Logs events for a remote address• <i>ipAddress</i>—Address of remote system for which you want to log messages• <i>ipAddressMask</i>—Mask for the remote address

- *interfaceType*—Type of the interface for which you want to log events (for example, atm or fastEthernet)
- *interfaceSpecifier*—Location of the interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

ospfHelloPktsSent

Description	Sending of hello messages on OSPF-enabled interfaces
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Information about hello messages sent on OSPF-enabled interfaces (ip source/destination, length)
Filter	router <i>virtualRouterName</i> [interface <i>interfaceType</i> <i>interfaceSpecifier</i>] <ul style="list-style-type: none"> • router—Logs events for a specific virtual router • <i>virtualRouterName</i>—Name of the virtual router for which you want to log events • interface—Logs events on a specific OSPF-enabled interface on the virtual router • <i>interfaceType</i>—Type of the interface for which you want to log events (for example, atm or fastEthernet) • <i>interfaceSpecifier</i>—Location of the interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

pimIpv6BsrSentLog

Description	Transmission of PIM-SM IPv6 BSR messages (BSM and C-RP-Advs)
Emergency	None
Alert	None
Critical	None
Error	System errors
Warning Log	None
Notice Log	None
Info	Description of transmitted messages (specify high verbosity for detail)
Debug	None
Filter 1	interface-ip-address—See description of the pimAutoRPRcvdLog interface-ip-address filter for information about this filter
Filter 2	router—See description of the pimAutoRPRcvdLog router filter for information about this filter

pimIpv6GracefulRestartLog

Description	PIM IPv6 graceful restart
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	PIM graceful restart complete
Info	None
Debug	None

Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Short description of the PIM messages received
Debug	Complete description of the PIM messages received
Filter 1	interface-ipv6-address—See description of the pimIpv6HelloRcvdLog interface-ipv6-address filter for information about this filter
Filter 2	router—See description of the pimIpv6HelloRcvdLog router filter for information about this filter

pimIpv6PktsSentLog

Description	Protocol Independent Multicast (PIM) nonhello (Register/RegisterStop/JoinPrune/Assert/Graft/GraftAck) messages sent
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Short description of the PIM messages sent
Debug	Complete description of the PIM messages sent
Filter 1	interface-ipv6-address—See description of the pimIpv6HelloRcvdLog interface-ipv6-address filter for information about this filter

Info	Short description of the PIM messages sent
Debug	Complete description of the PIM messages sent
Filter 1	interface-ip-address—See description of the pimAutoRPRcvdLog interface-ip-address filter for information about this filter
Filter 2	router—See description of the pimAutoRPRcvdLog router filter for information about this filter

pimsmGeneral

Description	General PIM sparse mode events
Emergency	None
Alert	None
Critical	Failure to initialize PIM sparse mode; memory allocation failures
Error	Error enabling or disabling PIM sparse mode; error adding or removing state
Warning Log	None
Notice Log	None
Info	Successful addition or removal of peer
Debug	None
Filter	None

pimsmMvpn

Description	Multicast VPN events, including default and data MDT creation and deletion
Emergency	None
Alert	None
Critical	None
Error	Failure to create MDT
Warning Log	None

Notice Log	Successful creation or deletion of default MDT; switch from data MDT to default MDT or from default MDT to data MDT
Info	Successful creation or deletion of data MDT
Debug	None
Filter	None

policyMgrAttachment

Description	Policy Manager policy attachment activity
Emergency	None
Alert	None
Critical	None
Error	Error attaching policies to static and dynamic interfaces
Warning Log	None
Notice Log	None
Info	Successful attachment of policies to dynamic interfaces
Debug	CAM resource allocation on a line module is exceeded; the particular policy fails to be attached to the interface
Filter	None

policyMgrGeneral

Description	Policy Manager general information
Emergency	None
Alert	None
Critical	None
Error	Error storing or restoring policy manager data to and from NVS; resource exhaustion errors

Warning Log	None
Notice Log	None
Info	None
Debug	144-bit, 288-bit, or 576-bit CAM entry allocated for a classifier entry in a particular policy
Filter	None

policyMgrPacketLog

Description	Policy Manager packets
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	Packet trace
Debug	None
Filter	None

ppp

Description	Point-to-Point Protocol layer
Emergency	None
Alert	None
Critical	Nonrecoverable error
Error	Recoverable error
Warning Log	Resource or configuration problem



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

pppoeControlPacket

Description	PPPoE control packet trace
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Control packets logged; control packet log enabled
Filter	interface <i>interfaceType</i> <i>interfaceSpecifier</i> <ul style="list-style-type: none">• <i>interface</i>—Logs PPP events for a specific interface• <i>interfaceType</i>—Type of interface for which you want to log PPP events• <i>interfaceSpecifier</i>—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see Interface Types and Specifiers in *JunosE Command Reference Guide*.

pppPacket

Description	PPP packet capture
Emergency	None
Alert	None

Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Packet trace
Filter	interface <i>interfaceType</i> <i>interfaceSpecifier</i> <ul style="list-style-type: none"> • interface—Logs PPP events for a specific interface • <i>interfaceType</i>—Type of interface for which you want to log PPP events • <i>interfaceSpecifier</i>—Location of interface in the appropriate format



NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

pppStateMachine

Description	PPP state machine trace
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	State machine trace
Filter	interface <i>interfaceType</i> <i>interfaceSpecifier</i>

- **interface**—Logs PPP events for a specific interface
- **interfaceType**—Type of interface for which you want to log PPP events. For example, atm or fastEthernet
- **interfaceSpecifier**—Location of interface in the appropriate format



.....

NOTE: For information about interface types and specifiers, see *Interface Types and Specifiers* in *JunosE Command Reference Guide*.

.....

profileMgr

Description	Profile manager
Emergency	None
Alert	None
Critical	None
Error	Profile manager process creation failed
Warning Log	Profile being removed was not found
Notice Log	None
Info	None
Debug	Initialize profiles from NVS at startup; dump list of profiles after startup initialization; read or save profile numbering seed to and from NVS; profile manager process creation succeeded; NVS updated; profile lookup succeeded; validating or executing removal of profile
Filter	None

CHAPTER 16

Q Commands

- [qm on page 213](#)
- [qos on page 213](#)
- [qosAttachment on page 214](#)

qm

Description	Queue manager
Emergency	None
Alert	None
Critical	None
Error	Queue memory errors; line module queue errors; queue database synchronization errors
Warning Log	None
Notice Log	None
Info	None
Debug	None
Filter	None

qos

Description	QoS events
Emergency	None
Alert	None

Critical	None
Error	QoS object creation and modification failures due to resource limitations or configuration limitations; QoS profile to interface attachment failures; QoS failover messages reported by line module
Warning Log	None
Notice Log	None
Info	Modification, creation, and destruction of QoS objects; attachment of modification of QoS objects; attachment of QoS profiles to interfaces; detachment of QoS profiles from interfaces; modification of QoS profiles; QoS interface location availability operations
Debug	Dynamic attachment of QoS profile to interfaces
Filter	None

qosAttachment

Description	QoS profile attachment to interface configuration
Emergency	None
Alert	None
Critical	None
Error	QoS attachment failures
Warning Log	None
Notice Log	None
Info	Attachment of QoS profiles; modification of QoS profile attachments
Debug	Dynamic attachment of QoS profiles; QoS profile attach/detach tracing
Filter	None

CHAPTER 17

R Commands

- [radiusAttributes](#) on page 215
- [radiusClient](#) on page 216
- [radiusCoAAttributes](#) on page 216
- [radiusDisconnectGeneral](#) on page 217
- [radiusRelayGeneral](#) on page 217
- [radiusSendAttributes](#) on page 218
- [remOps](#) on page 219
- [resourceThresholdTrap](#) on page 219
- [ripBfd](#) on page 220
- [ripGeneral](#) on page 220
- [ripRoute](#) on page 221
- [ripRtTable](#) on page 222
- [routeDownloader](#) on page 222
- [routerLog](#) on page 223
- [rsvpAsyncMgr](#) on page 224
- [rsvpBfd](#) on page 224
- [rsvpGeneral](#) on page 225
- [rsvpGracefulRestart](#) on page 225
- [rsvpInterface](#) on page 226
- [rsvpTunnel](#) on page 226

radiusAttributes

Description RADIUS user attributes

Emergency None

Alert None

Critical None

rsvpAsyncMgr

Description	RSVP asynchronous manager events
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	None
Notice Log	None
Info	None
Debug	Events processed by the asynchronous manager (for example, qos-profile/policy creation/deletion/attachment)
Filter	None

rsvpBfd

Description	RSVP-TE and BFD interaction
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	RSVP-TE client session create failed
Notice Log	None
Info	BFD session create failed for IP address
Debug	Delete BFD; RSVP-TE established session with BFD manager; Creating BFD session for interface; deleting BFD session for interface
Filter	Router and interface

Error	Operational errors; resource allocation failures
Warning Log	Operational failures; fast-reroute triggering
Notice Log	Less serious operational failures; network changes
Info	Minor internal errors; timer operations
Debug	Function flows, parameter passing
Filter	router <i>virtualRouterName</i> <ul style="list-style-type: none">• router—Logs events for traffic on a specific virtual router• <i>virtualRouterName</i>—Name of virtual router

serviceMgr

Description	Service manager
Emergency	None
Alert	None
Critical	None
Error	Information about detected abnormalities during execution
Warning Log	Information about exceeded thresholds
Notice Log	None
Info	None
Debug	Information about the code path executed along with values of parameters
Filter	None

serviceMgrClientSession

Description	Service manager client session
Emergency	None
Alert	None
Critical	None
Error	Information about detected abnormalities during execution
Warning Log	Information about exceeded thresholds
Notice Log	None
Info	None
Debug	Information about the code path executed along with values of parameters
Filter	None

serviceMgrDcm

Description	Service manager DCM
Emergency	None
Alert	None
Critical	None
Error	Information about detected abnormalities during execution
Warning Log	Information about exceeded thresholds
Notice Log	None
Info	None
Debug	Information about the code path executed along with values of parameters
Filter	None

serviceMgrMacroManager

Description	Service manager macro manager
Emergency	None
Alert	None
Critical	None
Error	Information about detected abnormalities during execution
Warning Log	Information about exceeded thresholds
Notice Log	None
Info	None
Debug	Information about the code path executed along with values of parameters
Filter	None

out of synchronization notification; NVS subsystem redundancy size mismatch; line module ID block misconfigured

Notice Log Subsystem failure condition abatement (heap/CPU utilization, NVS, power, fan, network timing, temperature); new module announcement; module revision mismatch; module upgraded or downgraded (ECC/non-ECC); module online or offline

Info Synchronization start, complete; line module set timing failed (not necessarily an error); NVS volume flush

Debug Module state change; module memory announcement; redundancy role changes; server role changes; module enable, disable, or clear notification; file system synchronization (normal operation); line module timing source set failure (not necessarily an error); image protection notification

Filter slot *slotNumber*

- slot—Logs events for a specific slot
- *slotNumber*—Number of slot for which you want to log events

CHAPTER 19

T Commands

- [tacacsPlusServer](#) on page 247
- [tcpGeneral](#) on page 248
- [tcpTraffic](#) on page 248
- [tcpv6Traffic](#) on page 249
- [telnet](#) on page 250
- [telnetClient](#) on page 250
- [tftpClient](#) on page 251
- [trackerEvents](#) on page 251
- [trackerGeneral](#) on page 252
- [tsm](#) on page 252

tacacsPlusServer

Description	TACACS+ server
Emergency	None
Alert	None
Critical	None
Error	Unable to start TACACS+; failed to create tacacsPlusProcess instance while in startup
Warning Log	Failed to create a host while reading parameters from NVS; primary host not found in NVS; more than one primary host found in NVS; number of primary hosts in NVS is not one, and attempts to correct this condition failed; unable to bind socket to source address configured to TACACS+ server
Notice Log	Received unexpected data from the TACACS+ host, which will result in authentication failure; either there is no host in NVS, or all attempts to configure a host failed
Info	None

Warning Log	None
Notice Log	Unexpected socket condition; unable to connect to remote host; successful connection; ENV send failure; resource allocation failure
Info	Connection attempt; detailed connection information (per connection); escape character announcement; connection closed
Debug	None
Filter	None

tftpClient

Description	TFTP client log
Emergency	None
Alert	None
Critical	None
Error	Memory allocation failures
Warning Log	None
Notice Log	TFTP error message received from remote host
Info	Initiating communication with remote host; discarded messages
Debug	TFTP responses received from incorrect source port on remote host
Filter	None

trackerEvents

Description	Tracker event propagation
Emergency	None
Alert	None
Critical	None
Error	None

Warning Log	None
Notice Log	None
Info	Indicates if there is a memory shortage for event propagation
Debug	Provides debug information for event propagation from the tracker component
Filter	None

trackerGeneral

Description	Tracker component
Emergency	None
Alert	None
Critical	None
Error	None
Warning Log	Indicates if there is a memory shortage for tracker operations
Notice Log	None
Info	Indicates if there is a memory shortage for accommodating new clients
Debug	Provides debug information for the tracker component
Filter	None

tsm

Description	Tunnel server manager
Emergency	None
Alert	None
Critical	Number of interfaces in use is critically close to maximum
Error	Memory exhaustion errors

Warning Log	Nonvolatile storage integrity problems; memory exhaustion-based denial of service; number of interfaces in use reaching high levels
Notice Log	Nonvolatile storage allocation problems; memory pool expansion
Info	Resource-restriction based denial of service; line module up or down transitions
Debug	Program debugging information including function call tracing
Filter	None

PART 3

Index

- [Index on page 263](#)

