

# C Series Controllers

## C3000 and C5000 Hardware Guide



---

Published: 2013-07-02

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, California 94089  
USA  
408-745-2000  
[www.juniper.net](http://www.juniper.net)

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

*C3000 and C5000 Controller Hardware Guide*  
Copyright © 2013, Juniper Networks, Inc.  
All rights reserved.

#### Revision History

March 2013—Updated the procedure for connecting AC power.  
June 2011—Updated fan module serial number location information.  
May 2011—Updated the number of subscribers.  
March 2011—Updated DC power range.  
October 2010—Initial release.

The information in this document is current as of the date on the title page.

#### YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

#### END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

# Table of Contents

	<b>About the Documentation . . . . .</b>	<b>xi</b>
	SRC Documentation and Release Notes . . . . .	xi
	Audience . . . . .	xi
	Documentation Conventions . . . . .	xi
	Documentation Feedback . . . . .	xiii
	Requesting Technical Support . . . . .	xiii
	Self-Help Online Tools and Resources . . . . .	xiv
	Opening a Case with JTAC . . . . .	xiv
<b>Part 1</b>	<b>Overview of the C Series Controller</b>	
<b>Chapter 1</b>	<b>Overview of the C Series Controller . . . . .</b>	<b>3</b>
	C Series System Description . . . . .	3
	C Series Network Management Tools . . . . .	4
	CLI Management . . . . .	5
	SNMP MIB Management . . . . .	5
<b>Chapter 2</b>	<b>C3000 and C5000 Controller Hardware Components . . . . .</b>	<b>7</b>
	C Series Model Components . . . . .	7
	C3000 and C5000 Front Panel Description . . . . .	8
	LEDs on the Front Panel . . . . .	8
	Ports on the Front Panel . . . . .	9
	C3000 and C5000 Power Overview . . . . .	10
	C3000 and C5000 Power Supply Description . . . . .	10
	AC Power Supply Description . . . . .	10
	DC Power Supply Description . . . . .	10
	C3000 and C5000 Power Supply LED . . . . .	11
	C3000 and C5000 Fan Module Description . . . . .	12
	C3000 and C5000 Hard Disk Overview . . . . .	13
	C3000 and C5000 Hard Disk Description . . . . .	13
	C3000 and C5000 Controller Data Storage . . . . .	14
	C3000 and C5000 Hard Disk LEDs . . . . .	14
<b>Part 2</b>	<b>Setting Up the C3000 and C5000 Controllers</b>	
<b>Chapter 3</b>	<b>Preparing the Site for C3000 and C5000 Controller Installation . . . . .</b>	<b>19</b>
	C3000 and C5000 Site Preparation Checklist . . . . .	19
	C3000 and C5000 Controller Rack Requirements . . . . .	20
	C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance . . . . .	22

<b>Chapter 4</b>	<b>Overview of C3000 and C5000 Controller Installation . . . . .</b>	<b>23</b>
	C3000 and C5000 Installation Summary . . . . .	23
<b>Chapter 5</b>	<b>Unpacking the C Series Controller . . . . .</b>	<b>25</b>
	Unpacking the C Series Controller . . . . .	25
	Verifying the C Series Controller Parts Received . . . . .	26
<b>Chapter 6</b>	<b>Installing the C3000 and C5000 Controller . . . . .</b>	<b>29</b>
	Installing the C Series Controller in a Four-Post Rack . . . . .	29
	Installing the C Series Controller in a Two-Post Rack . . . . .	30
<b>Chapter 7</b>	<b>Connecting the C3000 and C5000 Controller . . . . .</b>	<b>33</b>
	Connecting Power to an AC-Powered C3000 or C5000 Controller . . . . .	33
	Connecting Power to a DC-Powered C3000 or C5000 Controller . . . . .	34
	Connecting the C Series Controllers to External Devices . . . . .	36
	Connecting the C Series Controller to a Network for Out-of-Band Management . . . . .	36
	Connecting the C Series Controller to a Management Console . . . . .	37
	Powering On the C Series C3000 or C5000 Controller . . . . .	38
<b>Chapter 8</b>	<b>Initially Configuring the C Series Controller . . . . .</b>	<b>39</b>
	C Series Configuration Overview . . . . .	39
	Performing the Initial Software Configuration for the C Series Controller . . . . .	39
	Setting Up Management Access and Logging In . . . . .	40
	Configuring the Juniper Networks Database . . . . .	41
	Configuring Hostname and Domain Parameters . . . . .	41
	Configuring the System for Remote Access . . . . .	42
	Configuring the System to Accept SSH and Telnet Connections . . . . .	43
	Adding an Admin User Account . . . . .	43
<b>Part 3</b>	<b>Hardware Maintenance and Replacement Procedures</b>	
<b>Chapter 9</b>	<b>Maintaining C3000 and C5000 Controller Hardware Components . . . . .</b>	<b>47</b>
	Storing C Series Modules and Components . . . . .	47
	Cleaning C Series Components Overview . . . . .	47
	Maintaining the C Series Hard Disks . . . . .	48
<b>Chapter 10</b>	<b>Replacing C3000 and C5000 Controller Hardware Components . . . . .</b>	<b>51</b>
	Tools and Parts Required to Replace C Series Components . . . . .	51
	Replacing a C3000 or C5000 Fan Module . . . . .	51
	Removing a C3000 or C5000 Fan Module . . . . .	52
	Installing a C3000 or C5000 Fan Module . . . . .	52
	Replacing a C3000 or C5000 Hard Disk . . . . .	53
	Removing a C3000 or C5000 Hard Disk . . . . .	53
	Installing a C3000 or C5000 Hard Disk . . . . .	54
	Replacing a C3000 or C5000 Power Supply . . . . .	55
	Removing a C3000 or C5000 Power Supply . . . . .	55
	Installing a C3000 or C5000 Power Supply . . . . .	57
	Replacing a C3000 or C5000 AC Power Cord . . . . .	58
	Disconnecting a C3000 or C5000 AC Power Cord . . . . .	58
	Connecting a C3000 or C5000 AC Power Cord . . . . .	58

	Replacing a C3000 or C5000 DC Power Cable . . . . .	59
	Disconnecting a C3000 or C5000 DC Power Cable . . . . .	59
	Connecting a C3000 or C5000 DC Power Cable . . . . .	60
<b>Part 4</b>	<b>Appendixes</b>	
<b>Appendix A</b>	<b>Safety and Regulatory Compliance Information for the C3000 and C5000 Controllers . . . . .</b>	<b>65</b>
	C3000 and C5000 Safety Notices . . . . .	65
	Lithium Battery . . . . .	65
	Power Disconnection . . . . .	66
	Power Cable Warning . . . . .	66
	Power Cable Warning (Japanese) . . . . .	66
	Working with Lasers . . . . .	67
	VCCI Compliance . . . . .	67
	C3000 and C5000 General Safety Guidelines . . . . .	67
	C3000 and C5000 Safety and Emissions Certifications . . . . .	69
	Declaration of Conformity for the C3000 and C5000 Controllers . . . . .	69
	C3000 and C5000 Cabling Recommendations . . . . .	70
<b>Appendix B</b>	<b>C3000 and C5000 Controller Physical Specifications . . . . .</b>	<b>73</b>
	C3000 and C5000 Controller Physical Specifications . . . . .	73
<b>Appendix C</b>	<b>C3000 and C5000 Controller Environmental Specifications . . . . .</b>	<b>75</b>
	C3000 and C5000 Controller Environmental Specifications . . . . .	75
<b>Appendix D</b>	<b>Power Guidelines, Requirements, and Specifications for the C3000 and C5000 Controller . . . . .</b>	<b>77</b>
	C3000 and C5000 AC Power Specifications and Requirements . . . . .	77
	AC Power Electrical Specifications for the C Series Controller . . . . .	77
	C3000 and C5000 AC Power Cord Specifications . . . . .	78
	C3000 and C5000 DC Power Specifications and Requirements . . . . .	79
	DC Power Electrical Specifications for the C Series Controller . . . . .	79
	DC Power Cable Specifications for C Series Controllers . . . . .	79
	DC Power Cable Lug Specifications . . . . .	79
	DC Power Cable Specifications . . . . .	80
<b>Appendix E</b>	<b>C3000 and C5000 Controller Cable Connector Pinouts . . . . .</b>	<b>81</b>
	C3000 and C5000 RJ-45 Console Connector Pinouts . . . . .	81
<b>Appendix F</b>	<b>Contacting Customer Support and Returning C3000 and C5000 Hardware . . . . .</b>	<b>83</b>
	Locating C Series Component Serial Numbers . . . . .	83
	Displaying C Series Component Serial Numbers . . . . .	83
	C Series Chassis Serial Number Label . . . . .	83
	C Series Fan Module Serial Number Label . . . . .	84
	C Series Hard Disk Serial Number Label . . . . .	85

C Series Power Supply Serial Number Label .....	85
Contacting Customer Support .....	86
Returning a Hardware Component to Juniper Networks, Inc. ....	87
Packing the C Series Controller for Shipment .....	88
Guidelines for Packing C Series Components for Shipment .....	89

## Part 5

### Index

Index .....	93
-------------	----

# List of Figures

<b>Part 1</b>	<b>Overview of the C Series Controller</b>	
<b>Chapter 1</b>	<b>Overview of the C Series Controller . . . . .</b>	<b>3</b>
	Figure 1: Front View of the C3000 Model . . . . .	4
	Figure 2: Front View of the C5000 Model . . . . .	4
	Figure 3: Rear View of the C3000 and C5000 Models . . . . .	4
<b>Chapter 2</b>	<b>C3000 and C5000 Controller Hardware Components . . . . .</b>	<b>7</b>
	Figure 4: C3000 and C5000 Front Panel LEDs . . . . .	9
	Figure 5: C3000 and C5000 AC Power Supply . . . . .	10
	Figure 6: C3000 and C5000 DC Power Supply . . . . .	11
	Figure 7: Airflow Through the C3000 and C5000 Controllers . . . . .	13
	Figure 8: C3000 and C5000 Cooling Fan Modules . . . . .	13
<b>Part 2</b>	<b>Setting Up the C3000 and C5000 Controllers</b>	
<b>Chapter 3</b>	<b>Preparing the Site for C3000 and C5000 Controller Installation . . . . .</b>	<b>19</b>
	Figure 9: Typical Open-Frame Rack . . . . .	21
	Figure 10: C Series Chassis Dimensions and Clearance Requirements . . . . .	22
<b>Chapter 6</b>	<b>Installing the C3000 and C5000 Controller . . . . .</b>	<b>29</b>
	Figure 11: Installing the C Series Controller in a Four-Post Rack . . . . .	30
	Figure 12: Installing the C Series Controller in a Two-Post Rack . . . . .	31
<b>Chapter 7</b>	<b>Connecting the C3000 and C5000 Controller . . . . .</b>	<b>33</b>
	Figure 13: Connecting Power on an AC-Powered C3000 or C5000 Controller . . . . .	33
	Figure 14: Connecting DC Power Cables to the Controller . . . . .	36
	Figure 15: Ethernet Cable Connector . . . . .	36
	Figure 16: Network Ports Location . . . . .	37
	Figure 17: Console Cable Connector . . . . .	37
	Figure 18: Console Port Location . . . . .	37
<b>Part 3</b>	<b>Hardware Maintenance and Replacement Procedures</b>	
<b>Chapter 10</b>	<b>Replacing C3000 and C5000 Controller Hardware Components . . . . .</b>	<b>51</b>
	Figure 19: Removing a C3000 or C5000 Fan Module . . . . .	52
	Figure 20: Installing a C3000 or C5000 Fan Module . . . . .	53
	Figure 21: Removing a C3000 or C5000 Hard Disk . . . . .	54
	Figure 22: Installing a C3000 or C5000 Hard Disk . . . . .	55
	Figure 23: Removing a C3000 or C5000 AC Power Supply . . . . .	56
	Figure 24: Removing a C3000 or C5000 DC Power Supply . . . . .	56
	Figure 25: Installing a C3000 or C5000 AC Power Supply . . . . .	57
	Figure 26: Installing a C3000 or C5000 DC Power Supply . . . . .	58

	Figure 27: Disconnecting a C3000 or C5000 DC Power Cable . . . . .	60
	Figure 28: Connecting a C3000 or C5000 DC Power Cable . . . . .	61
<b>Part 4</b>	<b>Appendixes</b>	
<b>Appendix A</b>	<b>Safety and Regulatory Compliance Information for the C3000 and C5000 Controllers . . . . .</b>	<b>65</b>
	Figure 29: C3000 and C5000 Controllers Declaration of Conformity . . . . .	70
<b>Appendix D</b>	<b>Power Guidelines, Requirements, and Specifications for the C3000 and C5000 Controller . . . . .</b>	<b>77</b>
	Figure 30: DC Power Cable Lug . . . . .	79
<b>Appendix F</b>	<b>Contacting Customer Support and Returning C3000 and C5000 Hardware . . . . .</b>	<b>83</b>
	Figure 31: C Series Chassis Serial Number Label . . . . .	84
	Figure 32: C Series Fan Module Serial Number Label . . . . .	84
	Figure 33: C Series Hard Disk Serial Number Label . . . . .	85
	Figure 34: C Series Power Supply Serial Number Label . . . . .	86



# List of Tables

	<b>About the Documentation</b> . . . . .	<b>xi</b>
	Table 1: Notice Icons . . . . .	xii
	Table 2: Text Conventions . . . . .	xii
<b>Part 1</b>	<b>Overview of the C Series Controller</b>	
<b>Chapter 1</b>	<b>Overview of the C Series Controller</b> . . . . .	<b>3</b>
	Table 3: C Series Model Differences . . . . .	3
<b>Chapter 2</b>	<b>C3000 and C5000 Controller Hardware Components</b> . . . . .	<b>7</b>
	Table 4: Front Panel LEDs . . . . .	9
	Table 5: Front Panel Ports . . . . .	9
	Table 6: C3000 and C5000 Power Supply LEDs . . . . .	11
	Table 7: C3000 and C5000 Hard Disk LEDs . . . . .	15
<b>Part 2</b>	<b>Setting Up the C3000 and C5000 Controllers</b>	
<b>Chapter 3</b>	<b>Preparing the Site for C3000 and C5000 Controller Installation</b> . . . . .	<b>19</b>
	Table 8: C Series Site Preparation Checklist . . . . .	19
	Table 9: C Series Rack Requirements and Specifications . . . . .	20
<b>Chapter 5</b>	<b>Unpacking the C Series Controller</b> . . . . .	<b>25</b>
	Table 10: Parts List for a Fully Configured C Series Controller . . . . .	26
	Table 11: Accessory Box Parts List for a C Series Controller . . . . .	26
<b>Part 4</b>	<b>Appendixes</b>	
<b>Appendix B</b>	<b>C3000 and C5000 Controller Physical Specifications</b> . . . . .	<b>73</b>
	Table 12: C3000 and C5000 Controller Physical Specifications . . . . .	73
<b>Appendix C</b>	<b>C3000 and C5000 Controller Environmental Specifications</b> . . . . .	<b>75</b>
	Table 13: C3000 and C5000 Controller Environmental Specifications . . . . .	75
<b>Appendix D</b>	<b>Power Guidelines, Requirements, and Specifications for the C3000 and C5000 Controller</b> . . . . .	<b>77</b>
	Table 14: AC Power Electrical Specifications . . . . .	77
	Table 15: AC Power Cord Specifications . . . . .	78
	Table 16: DC Power Electrical Specifications . . . . .	79
<b>Appendix E</b>	<b>C3000 and C5000 Controller Cable Connector Pinouts</b> . . . . .	<b>81</b>
	Table 17: RJ-45 Console Connector Pinouts . . . . .	81



# About the Documentation

- SRC Documentation and Release Notes on page xi
- Audience on page xi
- Documentation Conventions on page xi
- Documentation Feedback on page xiii
- Requesting Technical Support on page xiii

## SRC Documentation and Release Notes

---

For a list of related SRC documentation, see  
<http://www.juniper.net/techpubs/software/junos/>.

If the information in the latest *SRC Release Notes* differs from the information in the SRC guides, follow the *SRC Release Notes*.

## Audience

---

This documentation is intended for experienced system and network specialists working with routers running Junos OS and JunosE software in an Internet access environment. We assume that readers know how to use the routers, directories, and RADIUS servers that they will deploy in their SRC networks. If you are using the SRC software in a cable network environment, we assume that you are familiar with the PacketCable Multimedia Specification (PCMM) as defined by Cable Television Laboratories, Inc. (CableLabs) and with the Data-over-Cable Service Interface Specifications (DOCSIS) 1.1 protocol. We also assume that you are familiar with operating a multiple service operator (MSO) multimedia-managed IP network.

## Documentation Conventions

---

[Table 1 on page xii](#) defines the notice icons used in this guide. [Table 2 on page xii](#) defines text conventions used throughout this documentation.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.

Table 2: Text Conventions

Convention	Description	Examples
<b>Bold text like this</b>	<ul style="list-style-type: none"> <li>Represents keywords, scripts, and tools in text.</li> <li>Represents a GUI element that the user selects, clicks, checks, or clears.</li> </ul>	<ul style="list-style-type: none"> <li>Specify the keyword <b>exp-msg</b>.</li> <li>Run the <b>install.sh</b> script.</li> <li>Use the <b>pkgadd</b> tool.</li> <li>To cancel the configuration, click <b>Cancel</b>.</li> </ul>
<b>Bold text like this</b>	Represents text that the user must type.	<b>user@host# set cache-entry-age cache-entry-age</b>
Fixed-width text like this	Represents information as displayed on your terminal's screen, such as CLI commands in output displays.	<pre> nic-locators {   login {     resolution {       resolver-name /realms/         login/A1;       key-type  LoginName;       value-type SaeId;     }   } } </pre>
Regular sans serif typeface	<ul style="list-style-type: none"> <li>Represents configuration statements.</li> <li>Indicates SRC CLI commands and options in text.</li> <li>Represents examples in procedures.</li> <li>Represents URLs.</li> </ul>	<ul style="list-style-type: none"> <li><b>system ldap server{ stand-alone;</b></li> <li>Use the <b>request sae modify device failover</b> command with the <b>force</b> option</li> <li><b>user@host# ...</b></li> <li><b>http://www.juniper.net/techpubs/software/management/src/api-index.html</b></li> </ul>
<i>Italic sans serif typeface</i>	Represents variables in SRC CLI commands.	<b>user@host# set local-address local-address</b>
Angle brackets	In text descriptions, indicate optional keywords or variables.	Another runtime variable is <gfwif>.
Key name	Indicates the name of a key on the keyboard.	Press Enter.

Table 2: Text Conventions (*continued*)

Key names linked with a plus sign (+)	Indicates that you must press two or more keys simultaneously.	Press Ctrl + b.
<i>Italic typeface</i>	<ul style="list-style-type: none"> <li>Emphasizes words.</li> <li>Identifies book names.</li> <li>Identifies distinguished names.</li> <li>Identifies files, directories, and paths in text but not in command examples.</li> </ul>	<ul style="list-style-type: none"> <li>There are two levels of access: <i>user</i> and <i>privileged</i>.</li> <li><i>SRC PE Getting Started Guide</i></li> <li><i>o=Users, o=UMC</i></li> <li>The <i>/etc/default.properties</i> file.</li> </ul>
Backslash	At the end of a line, indicates that the text wraps to the next line.	Plugin.radiusAcct-1.class=\net.juniper.smgmt.sae.plugin\RADIUSTrackingPluginEvent
Words separated by the   symbol	Represent a choice to select one keyword or variable to the left or right of this symbol. (The keyword or variable may be either optional or required.)	diagnostic   line

## Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net), or fill out the documentation feedback form at <https://www.juniper.net/cgi-bin/docbugreport/>. If you are using e-mail, be sure to include the following information with your comments:

- Document or topic name
- URL or page number
- Software release version (if applicable)

## Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or JNASC support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

## Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://www.juniper.net/alerts/>
- Join and participate in the Juniper Networks Community Forum: <http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

## Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

## PART 1

# Overview of the C Series Controller

- [Overview of the C Series Controller on page 3](#)
- [C3000 and C5000 Controller Hardware Components on page 7](#)





## CHAPTER 1

# Overview of the C Series Controller

- [C Series System Description on page 3](#)
- [C Series Network Management Tools on page 4](#)

### C Series System Description

---

The C Series Controller enables you to easily install, configure, and support Juniper Networks Session and Resource Control (SRC) software. It provides easy access to troubleshooting information, such as reporting events, logs, and system dumps while providing session resource controller functionality.

There are two C Series Controller models: the C3000 model and the C5000 model. Each model is composed of four hard drives, three fan modules, redundant power supplies, one USB port, a console management port, and four Ethernet ports.

Both models use the same software. However, the specific model determines the number of service session licenses and concurrent subscribers allowed on each unit. (See [Table 3 on page 3](#).)

**Table 3: C Series Model Differences**

Model	Concurrent Subscribers
C3000	300,000
C5000	900,000



**NOTE:** The models illustrated in this book might look different from your model because of configuration variations.

Figure 1: Front View of the C3000 Model




Figure 2: Front View of the C5000 Model





Figure 3: Rear View of the C3000 and C5000 Models



- Related Documentation**
- [C Series Network Management Tools on page 4](#)
  - [C Series Model Components on page 7](#)

## C Series Network Management Tools

You can use different management tools to configure the system to meet the specific networking requirements.

- [CLI Management on page 5](#)
- [SNMP MIB Management on page 5](#)

## CLI Management

The command-line interface (CLI) provides fully developed and automated configuration and status functionality through a local RS-232 port, Telnet, or SSH over any reachable network. For a full discussion of the CLI, see the *SRC PE CLI User Guide*.

## SNMP MIB Management

The system offers a complete SNMP interface for configuration, status, and alarm reporting. For more information, see the *SRC PE Monitoring and Troubleshooting Guide*.

### Related Documentation

- [C Series System Description on page 3](#)
- [C Series Model Components on page 7](#)
- [C Series Configuration Overview on page 39](#)



## CHAPTER 2

# C3000 and C5000 Controller Hardware Components

- [C Series Model Components on page 7](#)
- [C3000 and C5000 Front Panel Description on page 8](#)
- [C3000 and C5000 Power Overview on page 10](#)
- [C3000 and C5000 Fan Module Description on page 12](#)
- [C3000 and C5000 Hard Disk Overview on page 13](#)

### C Series Model Components

---

The C3000 model and C5000 model contain the following components:

- Internal memory
- CPU
- Hard drive—Each model has four hot-swappable, redundant drives in a redundant array of independent disks (RAID) 1+0 (mirror) configuration. The hard drives are located in the front of the C Series chassis.
- Fans—Three hot-swappable fan modules located in the rear of the chassis provide front to back cooling.
- Power supply—Each model has two hot-swappable, redundant AC or DC power supplies located in the rear.
- Console management port—Each model has one RS-232 port that accepts a DB-9 (female) connector for direct CLI access from a console terminal.
- USB port—Each model has one port that can be used for memory storage devices.
- IPMI 2.0 management interface.
- Ethernet interfaces—Each model has four 10/100/1000Base-T Ethernet ports (**ETH0** through **ETH3**) that accept an RJ-45 (male) connector, providing an out-of-band connection for LAN access through a Telnet session, SSH, or SNMP. The **ETH0** port provides access from a network that is behind a firewall. The **ETH0** port provides remote access to the IPMI module for remote hardware status monitoring, power management, and serial over LAN (SOL) access. The **ETH1** port provides access for applications on an external network, such as the Internet.

- Status LEDs—Each model has LEDs that provide status information about hard drives, power supplies, and interfaces.
- USB storage device—Contains the latest system software, including the operating system for the C Series Controller. The device can be read-only or read/write and should be used to recover from a major software failure. See the *SRC Getting Started Guide* for more information about recovering from a software failure.



**NOTE:** From SRC software release 4.5, the USB storage device supplied with the C Series Controller can be a read/write USB or a read-only USB and prior to the release 4.5, the C-Series was shipped only with a read-only USB. You can only recover the system software and cannot create an installation medium or back up the system configuration by using a read-only USB storage device.

For identifying a read-only USB or a read/write USB, contact Juniper Networks Technical Assistance Center (JTAC).

- 
- Rack-mount and rail kit.

**Related  
Documentation**

- [C Series System Description on page 3](#)
- [C3000 and C5000 Front Panel Description on page 8](#)
- [C3000 and C5000 Power Supply Description on page 10](#)
- [C3000 and C5000 Fan Module Description on page 12](#)
- [C3000 and C5000 Hard Disk Description on page 13](#)

---

## C3000 and C5000 Front Panel Description

The front panel is located on the left side of C3000 and C5000 Controllers.

The front panel LEDs and ports are described in:

- [LEDs on the Front Panel on page 8](#)
- [Ports on the Front Panel on page 9](#)

### LEDs on the Front Panel

[Table 4 on page 9](#) contains the LEDs located on the front panel of the C3000 and C5000 Controllers (see [Figure 4 on page 9](#)).

Figure 4: C3000 and C5000 Front Panel LEDs




Table 4: Front Panel LEDs

LED	Color	State	Description
Chassis	Green	On steadily	Indicates that the chassis is powered on
	–	Off	Indicates that the chassis is powered off
Alarm/Fail	Red	On steadily	Indicates that a fan module, power supply, or temperature alarm has occurred
		Flashing	Indicates a hardware failure
LAN status	Green	Flashing	Indicates that the link is active
Speed status	–	Off	Indicates a 10-Mbps link speed
	Green	Flashing	Indicates a 100-Mbps link speed
	Yellow	Flashing	Indicates a 1-Gbps link speed

Ports on the Front Panel

Table 5 on page 9 displays the ports that are located on the front panel of C3000 and C5000 Controllers.

Table 5: Front Panel Ports

Port	Description
Console	One RJ-45 console port
Network	Four RJ-45 Ethernet 10/100/1000
USB	One USB maintenance port

Related Documentation

- [C3000 and C5000 RJ-45 Console Connector Pinouts on page 81](#)

## C3000 and C5000 Power Overview

---

- [C3000 and C5000 Power Supply Description on page 10](#)
- [C3000 and C5000 Power Supply LED on page 11](#)

### C3000 and C5000 Power Supply Description

C3000 and C5000 Controllers ship with dual power supplies. In addition to providing power to the controller, the power supplies provide a fan that helps cool the system. The power supply slots are located on the far-right side of the rear panel of the controller. Power supplies are field-replaceable and hot-swappable.

The power supplies are controlled by a momentary switch. Pressing the switch reboots the chassis. Holding the switch down forces a hard shutdown.

A single power supply provides power to all components. One power supply is required. A second power supply provides redundancy. If a power supply in a redundant configuration fails, the operational power supply takes over without interruption and assumes responsibility for the entire power load.

- [AC Power Supply Description on page 10](#)
- [DC Power Supply Description on page 10](#)


#### AC Power Supply Description

---

Each AC power supply contains an AC power input, status LED, eject lever, and handle, as shown in [Figure 5 on page 10](#).

Each inlet requires a dedicated AC power feed and a dedicated customer site circuit breaker. For existing power supplies, we recommend that you use a minimum 5 A (110 VAC) customer site circuit breaker, or as required by local code.

**Figure 5: C3000 and C5000 AC Power Supply**



#### DC Power Supply Description


---

Each DC power supply contains a single DC power input, status LED, eject lever, and handle, as shown in [Figure 5 on page 10](#).



The DC power input (–48 VDC and return) requires a dedicated customer site circuit breaker. We recommend that you use a dedicated customer site circuit breaker rated for 10 A (–48 VDC) minimum, or as required by local code.

**Figure 6: C3000 and C5000 DC Power Supply**



**Related Documentation**

- [C3000 and C5000 Power Supply LED on page 11](#)
- [Connecting Power to an AC-Powered C3000 or C5000 Controller on page 33](#)
- [Connecting Power to a DC-Powered C3000 or C5000 Controller on page 34](#)
- [AC Power Electrical Specifications for the C Series Controller on page 77](#)
- [DC Power Electrical Specifications for the C Series Controller on page 79](#)

## C3000 and C5000 Power Supply LED

Each power supply has a single bicolor LED to indicate status, as shown in [Table 6 on page 11](#).

**Table 6: C3000 and C5000 Power Supply LEDs**

Color	State	Description
Green	On steadily	Indicates that the power supply is functioning normally

Table 6: C3000 and C5000 Power Supply LEDs (*continued*)

Color	State	Description
Yellow	On steadily	Indicates that the power supply is in Standby Mode, which means the power supply is powered but is not powering the system
–	Off	Indicates one of the following: <ul style="list-style-type: none"> <li>• Power supply is disconnected from AC power feed.</li> <li>• AC power input voltage is not within normal operating range.</li> <li>• There is no AC power input.</li> </ul>

**Related  
Documentation**


- [C3000 and C5000 Power Supply Description on page 10](#)
- [Connecting Power to an AC-Powered C3000 or C5000 Controller on page 33](#)
- [Connecting Power to a DC-Powered C3000 or C5000 Controller on page 34](#)
- [AC Power Electrical Specifications for the C Series Controller on page 77](#)
- [DC Power Electrical Specifications for the C Series Controller on page 79](#)

## C3000 and C5000 Fan Module Description

The C3000 and C5000 Controllers have three individual cooling fan modules that work together to keep all components within the acceptable temperature range. The fan modules install in the rear of the controller and are hot-swappable.


The air intake is located on the front sides of the chassis. Air is pulled through the chassis and is exhausted out the rear by the fans. The power supplies are self-cooling and are located in the rear of the controller to the right of the fans. The exhaust for the power supplies is located on the right side of the rear of the chassis.

Figure 7: Airflow Through the C3000 and C5000 Controllers



The chassis monitors the temperature of the components. When the controller is operating normally, the fan modules function at lower than full speed. If a fan module fails or the ambient temperature rises above a threshold, the speed of the remaining fan modules is automatically adjusted to keep the temperature within the acceptable range. If the ambient maximum temperature specification is exceeded and the system cannot be adequately cooled, the system shuts down by disabling output power from each power supply.

Figure 8: C3000 and C5000 Cooling Fan Modules



#### Related Documentation

- [Replacing a C3000 or C5000 Fan Module on page 51](#)

## C3000 and C5000 Hard Disk Overview

- [C3000 and C5000 Hard Disk Description on page 13](#)
- [C3000 and C5000 Controller Data Storage on page 14](#)
- [C3000 and C5000 Hard Disk LEDs on page 14](#)

## C3000 and C5000 Hard Disk Description

The C3000 and C5000 Controllers ship with four 146-GB hard disks. The hard disks provide a fully redundant storage system on the controllers; all directories and files saved

on one hard disk are also saved on the other hard disk. The hard disks can be installed in the hard disk slots and provide the following functions:

- Mirroring—Copy data to more than one disk
- Striping—Split data across more than one disk
- Error correction—Provide redundant data storage to detect and resolve problems

The controllers use a redundant array of independent disk (RAID) 1+0 configuration to store and replicate data among multiple hard disk drives. In a RAID 1+0 configuration, drives are striped for performance and duplicated for fault tolerance.

**Related  
Documentation**

- [C3000 and C5000 Hard Disk LEDs on page 14](#)
- [Maintaining the C Series Hard Disks on page 48](#)

## C3000 and C5000 Controller Data Storage

A C Series Controller provides data redundancy by supplying four hard drives (or disks) in a redundant array of independent disks (RAID). Disks are configured as a RAID level-1 Enhanced (RAID 1E) array, which combines mirroring and striping for high performance and redundancy. If one disk becomes inoperable, the RAID controller switches read and write requests to the remaining functional drives in the array, which allows the C Series Controller to continue to function.

When you replace a faulty disk, or disable and then enable a disk, the RAID controller copies the data from the other disks in the array to the new or enabled disk and establishes mirroring and striping for the disk array.

The disks mount from the front of the chassis on both the C3000 and C5000 systems.

When you access the disks in the disk mount:

- Disk 0 is on the top left.
- Disk 1 is on the bottom left.
- Disk 2 is on the top right.
- Disk 3 is on the bottom right.

**Related  
Documentation**

- [C3000 and C5000 Hard Disk Description on page 13](#)
- [C3000 and C5000 Hard Disk LEDs on page 14](#)
- [Maintaining the C Series Hard Disks on page 48](#)

## C3000 and C5000 Hard Disk LEDs

Each hard disk has two LEDs to indicate status, as shown in [Table 7 on page 15](#).

Table 7: C3000 and C5000 Hard Disk LEDs

Color	Location	State	Description
Green	Top	On steadily	Indicates hard disk activity
Red	Bottom	On steadily	Indicates a hard disk failure

- Related Documentation**
- [C3000 and C5000 Hard Disk Description on page 13](#)
  - [Maintaining the C Series Hard Disks on page 48](#)



## PART 2

# Setting Up the C3000 and C5000 Controllers

- [Preparing the Site for C3000 and C5000 Controller Installation on page 19](#)
- [Overview of C3000 and C5000 Controller Installation on page 23](#)
- [Unpacking the C Series Controller on page 25](#)
- [Installing the C3000 and C5000 Controller on page 29](#)
- [Connecting the C3000 and C5000 Controller on page 33](#)
- [Initially Configuring the C Series Controller on page 39](#)





## CHAPTER 3

# Preparing the Site for C3000 and C5000 Controller Installation

- C3000 and C5000 Site Preparation Checklist on page 19
- C3000 and C5000 Controller Rack Requirements on page 20
- C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance on page 22

### C3000 and C5000 Site Preparation Checklist

The checklist in [Table 8 on page 19](#) summarizes the tasks you must perform when preparing a site for controller installation.

**Table 8: C Series Site Preparation Checklist**

Item or Task	For More Information	Performed By	Date
Verify that environmental factors such as temperature and humidity do not exceed controller tolerances.	"C3000 and C5000 Controller Environmental Specifications" on page 75		
Select the type of rack.	"C3000 and C5000 Controller Rack Requirements" on page 20		
Plan rack or cabinet location, including required space clearances.	<ul style="list-style-type: none"><li>• C3000 and C5000 Controller Rack Requirements on page 20</li><li>• C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance on page 22</li></ul>		
If a rack is used, secure it to the floor and building structure.	"C3000 and C5000 Controller Rack Requirements" on page 20		
Acquire cables and connectors.			
Measure the distance between external power sources and the controller installation site.			

- Related Documentation**
- [C3000 and C5000 Installation Summary on page 23](#)
  - [Unpacking the C Series Controller on page 25](#)
  - [C Series Configuration Overview on page 39](#)

## C3000 and C5000 Controller Rack Requirements

The controller can be installed in a rack. Many types of racks are acceptable, including four-post (telco) racks and open-frame racks. An example of an open-frame rack appears in [Figure 9 on page 21](#). [Table 9 on page 20](#) summarizes rack requirements and specifications for the C Series Controllers.


**Table 9: C Series Rack Requirements and Specifications**

Rack Requirement	Guidelines
Rack type and mounting bracket hole spacing	<p>Use a four-post rack or a two-post rack. You can mount the controller on any four-post or two-post rack that provides bracket holes or hole patterns spaced at 1 U (1.75-in. or 4.44-cm) increments and that meets the size and strength requirements specified in this table.</p> <p>A U is the standard rack unit defined in <i>Cabinets, Racks, Panels, and Associated Equipment</i> (document number EIA-310-D) published by the Electronics Industry Association (<a href="http://www.eia.org">http://www.eia.org</a>).</p>
Rack size and strength	<ul style="list-style-type: none"> <li>• Ensure that the rack is a 19-in. rack as defined in <i>Cabinets, Racks, Panels, and Associated Equipment</i> (document number EIA-310-D) published by the Electronics Industry Association (<a href="http://www.eia.org">http://www.eia.org</a>).</li> <li>• Ensure that the rack is one of the following standard lengths: <ul style="list-style-type: none"> <li>• 23.62 in. (600 mm)</li> <li>• 30.0 in. (762 mm)</li> <li>• 31.5 in. (800 mm)</li> </ul> </li> <li>• The rack rails must be spaced widely enough to accommodate the controller chassis's external dimensions: 3.5 in. (8.8 cm) high, 23.5 in. (59.7 cm) deep, and 17.26 in. (43.7 cm) wide. The outer edges of the mounting brackets extend the width to 19.2 in. (48.7 cm). The spacing of rails and adjacent racks must also allow for the clearances around the controller and rack, which are specified in "<a href="#">C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance</a>" on page 22.</li> <li>• The C Series Controller ships with the mounting brackets installed in the front-mount position. You can also move the brackets to the center-mount position to install the controller in a two-post rack. For instructions about center mounting the controller, see "<a href="#">Installing the C Series Controller in a Two-Post Rack</a>" on page 30.</li> <li>• The chassis height of 3.5 in. (8.8 cm) is approximately 2 U. You can stack several controllers in a cabinet that has sufficient usable vertical space. Each controller requires 2 U.</li> <li>• The rack must be strong enough to support the weight of the fully configured controller, up to 43.31 lb (19.65 kg).</li> <li>• Ensure that the spacing of rails and adjacent racks allows for the proper clearance around the controller and rack as specified in "<a href="#">C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance</a>" on page 22.</li> <li>• Install heavier systems on the bottom of the rack. Mount lighter systems higher in the rack.</li> <li>• Install and electrically ground racks according to manufacturer instructions.</li> </ul>

Table 9: C Series Rack Requirements and Specifications (*continued*)

Rack Requirement	Guidelines
Rack connection to the building structure	<ul style="list-style-type: none"> <li>Secure the rack to the building structure.</li> <li>If earthquakes are a possibility in your geographical area, secure the rack to the floor.</li> <li>Secure the rack to the ceiling brackets, as well as to floor brackets for maximum stability.</li> </ul>

Figure 9: Typical Open-Frame Rack



**Related Documentation**


- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance on page 22](#)
- [C3000 and C5000 Installation Summary on page 23](#)

## C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance

When planning the installation site, allow sufficient clearance around the rack (see [Figure 10 on page 22](#)):

- For the cooling system to function properly, the airflow around the chassis must be unrestricted. Allow at least 6 in. (15.2 cm) of clearance between side-cooled controllers. Allow 2.8 in. (7 cm) between the side of the chassis and any non-heat-producing surface such as a wall.
- For service personnel to remove and install hardware components, there must be adequate space at the front and back of the controller. Allow at least 24 in. (61 cm) both in front of and behind the controller.

**Figure 10: C Series Chassis Dimensions and Clearance Requirements**



**Height:** 3.5" (8.8 cm)

### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Controller Rack Requirements on page 20](#)
- [C3000 and C5000 Installation Summary on page 23](#)

## CHAPTER 4

# Overview of C3000 and C5000 Controller Installation

- [C3000 and C5000 Installation Summary on page 23](#)

## C3000 and C5000 Installation Summary

---

To install the C Series Controller:

1. Prepare your installation site.
  - See [“C3000 and C5000 Site Preparation Checklist” on page 19](#).
2. Review the safety guidelines and warnings.
  - [C3000 and C5000 Safety Notices on page 65](#)
  - [C3000 and C5000 General Safety Guidelines on page 67](#)
3. Unpack the controller and verify the parts.
  - a. [Unpacking the C Series Controller on page 25](#)
  - b. [Verifying the C Series Controller Parts Received on page 26](#)
4. Install the mounting hardware if needed, and install the controller in a rack.
  - [Installing the C Series Controller in a Two-Post Rack on page 30](#)
  - [Installing the C Series Controller in a Four-Post Rack on page 29](#)
5. Connect cables to the network and external devices:
  - See [“Connecting the C Series Controllers to External Devices” on page 36](#).
6. Connect the AC power cord or DC power cables.
  - [Connecting Power to an AC-Powered C3000 or C5000 Controller on page 33](#)
  - [Connecting Power to a DC-Powered C3000 or C5000 Controller on page 34](#)
7. Power on the controller.
  - See [“Powering On the C Series C3000 or C5000 Controller” on page 38](#).
8. Perform the initial system configuration.

See ["Performing the Initial Software Configuration for the C Series Controller"](#) on [page 39](#).

## CHAPTER 5

# Unpacking the C Series Controller

- [Unpacking the C Series Controller on page 25](#)
- [Verifying the C Series Controller Parts Received on page 26](#)

## Unpacking the C Series Controller

---

Before you begin unpacking the item, be sure you have the following tools:

- No. 2 Phillips screwdriver
- Utility knife
- Mechanical lift, or at least one person to assist in lifting

The system is shipped in a cardboard carton and secured with foam packing material. The carton also contains an accessory box and quick start instructions.



**NOTE:** The controller is maximally protected inside the shipping carton. Do not unpack it until you are ready to begin installation.



**WARNING:** Three people are required to install the system in a rack: two to lift it into position and one to screw it to the rack.

To unpack the controller:

1. Move the shipping carton to a staging area as close to the installation site as possible, but where you have enough room to remove the controller.
2. Position the carton so that the arrows are pointing up.
3. Open the top flaps on the shipping carton.
4. Remove the accessory box, and verify the contents against the parts inventory on the label attached to the carton.
5. Pull out the packing material holding the controller in place.

6. Verify the contents of the carton against the packing list included with the controller.
7. Save the shipping carton and packing materials in case you later need to move or ship the controller.

**Related Documentation**

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)
- [Verifying the C Series Controller Parts Received on page 26](#)

## Verifying the C Series Controller Parts Received

A packing list is included in each shipment. Check the parts in the shipment against the items on the packing list. The packing list specifies the part numbers and descriptions of each part in your order.

If any part is missing, contact a Juniper Networks customer service representative.

A fully configured controller contains the controller chassis with installed components, listed in [Table 10 on page 26](#), and an accessory box, which contains the parts listed in [Table 11 on page 26](#). The parts shipped with your controller can vary depending on the configuration you ordered.

**Table 10: Parts List for a Fully Configured C Series Controller**

Component	Quantity
Chassis	1
Power supplies	2
Fan modules	3
Hard disks	4
Quick start installation instructions	1
Blank panels for slots without components installed	One blank panel for each slot not occupied by a component

**Table 11: Accessory Box Parts List for a C Series Controller**

Component	Quantity
Shipping label 4" x 6"	1
ESD bag	1
Cable, DB9 to RJ45 Adapter, 7 ft., straight through	1
Cable, Ethernet, OSC-ETH-7-BL, 7 ft. Blue	1



Table 11: Accessory Box Parts List for a C Series Controller *(continued)*

Component	Quantity
Power cord (for your region)	2

**Related  
Documentation**

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)
- [Unpacking the C Series Controller on page 25](#)



## CHAPTER 6

# Installing the C3000 and C5000 Controller

- [Installing the C Series Controller in a Four-Post Rack on page 29](#)
- [Installing the C Series Controller in a Two-Post Rack on page 30](#)

### Installing the C Series Controller in a Four-Post Rack


---

The C3000 and C5000 Controllers require additional support when mounted on the rack-mount system. This option is the default configuration.

To install the mounting hardware for a four-post rack:

1. Insert four rack-mount screws on each side of the system to secure the front of the chassis to the equipment rack.
2. Slide the rear-mount rail brackets into the backs of the front rails on either side of the chassis, and align the brackets with your rear equipment rack posts. Secure the rear-mount rail brackets to your equipment rack with two rack mount screws each.
3. Insert locking screws on the sides of the rear-mount brackets to secure the front and rear mounting brackets in place. See [Figure 11 on page 30](#).
4. Verify that the mounting screws on one side of the rack are aligned with the mounting screws on the opposite side and that the appliance is level.

Figure 11: Installing the C Series Controller in a Four-Post Rack



#### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Controller Rack Requirements on page 20](#)
- [C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance on page 22](#)
- [C3000 and C5000 Installation Summary on page 23](#)


### Installing the C Series Controller in a Two-Post Rack

To install the C Series Controller in a two-post rack, you must attach the mounting hardware for center mounting. Center mounting allows the controller to be midmounted so that there is even clearance on the front and rear of the rack.

To mount the controller using the center-mount option:

1. Remove the two front-mount rails from either side of the chassis.
2. Insert one midmount bracket to the center on either side of the chassis.
3. Attach the chassis to the equipment rack, and insert the other two midmount brackets on either side of the system to secure the chassis to the backs of the post (see [Figure 12 on page 31](#)).
4. Verify that the mounting screws on one side of the rack are aligned with the mounting screws on the opposite side and that the appliance is level.

Figure 12: Installing the C Series Controller in a Two-Post Rack



g005107

**Related Documentation**

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Controller Rack Requirements on page 20](#)
- [C3000 and C5000 Clearance Requirements for Airflow and Hardware Maintenance on page 22](#)
- [C3000 and C5000 Installation Summary on page 23](#)



## CHAPTER 7

# Connecting the C3000 and C5000 Controller

- [Connecting Power to an AC-Powered C3000 or C5000 Controller on page 33](#)
- [Connecting Power to a DC-Powered C3000 or C5000 Controller on page 34](#)
- [Connecting the C Series Controllers to External Devices on page 36](#)
- [Powering On the C Series C3000 or C5000 Controller on page 38](#)

## Connecting Power to an AC-Powered C3000 or C5000 Controller




**NOTE:** C3000 and C5000 Controllers now ship with a retainer clip for the power cord. The retainer clip prevents accidental disconnection of the power cord by securing the cord to the chassis. Steps 1 and 3 apply only to appliances equipped with retainer clips.

To connect AC power to a C3000 or C5000 Controller (see: [Figure 13 on page 33](#))

1. Squeeze the two sides of the power cord retainer clip and insert the L-shaped ends of the wire clip into the holes in the bracket on each side of the AC appliance inlet.

**Figure 13: Connecting Power on an AC-Powered C3000 or C5000 Controller**



2. Insert the coupler end of the power cord into the AC appliance inlet.

If your controller contains two power supplies, plug each power cord into a separate power circuit to ensure that the device continues to receive power if one of the power circuits fails.


3. Push the power cord into the slot in the adjustment nut of the power cord retainer clip. Turn the nut until it is snug against the base of the coupler and the slot in the nut is turned 90° from the top of the switch.



**NOTE:** We suggest that you use an uninterruptible power supply (UPS) with your C Series Controller.



**NOTE:** To provide redundancy, do not terminate Power A and Power B leads at the same power source.



#### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)
- [AC Power Electrical Specifications for the C Series Controller on page 77](#)
- [C3000 and C5000 AC Power Cord Specifications on page 78](#)

## Connecting Power to a DC-Powered C3000 or C5000 Controller

On a DC-powered controller, the DC power cables from the external DC power sources connect to the field-wiring terminals on each power supply.

Connect DC power to the controller by inserting power cables into the field-wiring terminals on the faceplate of each power supply. DC power cables and lugs are not supplied with the device. For more information about the required cable type, see [“DC Power Cable Specifications for C Series Controllers” on page 79](#).



**CAUTION:** There is no standard color coding for DC power cables. The color coding used by the external DC power source at your site determines the color coding for the leads on the DC power cables that attach to the terminal studs on the power supply faceplate. You must ensure that power connections maintain the proper polarity. The power source cables might be labeled (+) and (–) to indicate their polarity.



To connect DC power to a C3000 or C5000 Controller (see [Figure 14 on page 36](#)):

1. Verify that there is no power flowing from either external power source, so that the voltage across the leads of the DC power cables is 0 V. Ensure that there is no chance that the cable leads might become active during the procedure.
2. Remove the clear plastic shield covering the field-wiring terminals on the power supply.
3. Remove the screws on the field-wiring and ground terminal.
4. Verify that a licensed electrician has attached a listed DC power cable lug to each power source cable and ground cable.



**NOTE:** You must bend the cable lug that attaches to the DC power source cable at a 90° angle in order to properly install the clear plastic shield covering.


5. Insert the DC power and ground cable lugs into the appropriate terminals. Using a number 1 Phillips screwdriver, turn the screw on each terminal clockwise to secure the cable. Apply 8.68 lb-in. (.98 Nm) of torque to each screw.
  - a. Insert the positive (+) source cable into the return terminal, which is labeled **RTN**.
  - b. Insert the negative (–) source cable into the input terminal, which is labeled **–48V**.
  - c. Align the ground cable with the ground terminal.



**CAUTION:** Ensure that each cable lug seats flush against the surface of the terminal block as you tighten the screws.

6. Verify that the DC source power and grounding cables are correct, that they are not touching or blocking access to controller components, and that they do not drape where people could trip on them.
7. Replace the clear plastic shield over the field-wiring terminals.
8. Turn on the current from the power source so that voltage flows to the controller.

Figure 14: Connecting DC Power Cables to the Controller



#### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)
- [DC Power Electrical Specifications for the C Series Controller on page 79](#)

## Connecting the C Series Controllers to External Devices

- [Connecting the C Series Controller to a Network for Out-of-Band Management on page 36](#)
- [Connecting the C Series Controller to a Management Console on page 37](#)

### Connecting the C Series Controller to a Network for Out-of-Band Management

To connect the C Series Controller to a network for out-of-band management, connect an Ethernet cable with RJ-45 connectors to one of the Ethernet ports on the front panel. One Ethernet cable is provided with the controller.

To connect to the Ethernet port on the front panel to a network:

1. Turn off the power to the management device.
2. Plug one end of the Ethernet cable ([Figure 15 on page 36](#) shows the connector) into one of the Ethernet ports on the front panel. [Figure 16 on page 37](#) shows the port. Plug the other end of the cable into the network device.

Figure 15: Ethernet Cable Connector





Figure 16: Network Ports Location



### Connecting the C Series Controller to a Management Console

Before powering on the system, you must set up a management console. The console enables you to communicate with your system during the power-on process and to manage your system using the command-line interface (CLI).

When connecting a console directly to the system, use a cable appropriate to your terminal connector. The cable must have a female DB-9 connector to attach to the RS-232 port on the system.

To connect the C3000 or C5000 Controller to a management console:

1. Turn off the power to the console.
2. Plug the RJ-45 end of the serial cable (Figure 17 on page 37 shows the connector) into the port labeled **CONSOLE** on the front panel. Figure 18 on page 37 shows the location of the port on the front panel.
3. Plug the female DB-9 end into the device's serial port.

Figure 17: Console Cable Connector





Figure 18: Console Port Location



## Powering On the C Series C3000 or C5000 Controller

---



**CAUTION:** Evaluate the overall loading of the branch circuit before you install any equipment into a rack.

To power on the system:

1. Verify that the power source is operational and turned on.
2. Inspect all power connections to the system.
3. Confirm that all connections are secure.
4. Push the momentary power switch on the rear panel.

The green status LED on the power supply turns on.

5. Monitor the LEDs to verify that the system is booting properly.

When the prompt appears on the system console, you can log in and configure the system.

### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)
- [AC Power Electrical Specifications for the C Series Controller on page 77](#)
- [DC Power Electrical Specifications for the C Series Controller on page 79](#)

## CHAPTER 8

# Initially Configuring the C Series Controller

- [C Series Configuration Overview on page 39](#)
- [Performing the Initial Software Configuration for the C Series Controller on page 39](#)

## C Series Configuration Overview

---

After powering on the system, perform the following tasks required to get the controller ready to work with:

1. Connect a management console to the system, configure it, and log in.  
[See “Setting Up Management Access and Logging In” on page 40.](#)
2. Configure the Juniper Networks Database.  
[See “Configuring the Juniper Networks Database” on page 41.](#)
3. Configure hostname and domain information.  
[See “Configuring Hostname and Domain Parameters” on page 41.](#)
4. Configure the system for remote access.  
[See “Configuring the System for Remote Access” on page 42.](#)
5. Configure the system to accept SSH and Telnet connections.  
[See “Configuring the System to Accept SSH and Telnet Connections” on page 43.](#)
6. Add an Admin user account.  
[See “Adding an Admin User Account” on page 43.](#)

### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)

## Performing the Initial Software Configuration for the C Series Controller

---

- [Setting Up Management Access and Logging In on page 40](#)
- [Configuring the Juniper Networks Database on page 41](#)
- [Configuring Hostname and Domain Parameters on page 41](#)

- [Configuring the System for Remote Access on page 42](#)
- [Configuring the System to Accept SSH and Telnet Connections on page 43](#)
- [Adding an Admin User Account on page 43](#)

## Setting Up Management Access and Logging In

Before you power on the system, you must set up a management console. (See [“Connecting the C Series Controllers to External Devices” on page 36.](#))

You can monitor and manage the system through either of these methods:

- Console terminal—Connect a console (PC, Macintosh, or UNIX workstation) directly to the system's RS-232 serial port.
- Remote console—Connect a 10/100Base-T port (**ETH0**) to an Ethernet network, and run SSH or Telnet from a remote console.

For initial access to the system, you need to physically connect your console directly to the system's RS-232 port. Through this connection you use the SRC command-line interface (CLI) to set the hostname and domain information. You can then access the system remotely (for example, by means of SSH).

To communicate with the system, you must have a terminal emulation program running on your PC or Macintosh. You can use any terminal emulation program, such as HyperTerminal. A UNIX workstation can use the emulator TIP.

To log in to the system:

1. Start your terminal emulation program using the following settings:

- Bits per second: 9600
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: none

2. Enter the username.

```
SRC Release 4.0 [V.4.0.0.R-1]
localhost login:root
```

3. Enter the password.

```
Password:password
```

You are now logged in as root user.

4. To access the CLI, enter the **cli** command.

```
[root@localhost ~]# cli
```

```
--- SRC CLI 4.0 build CLI.R.4.0.0.001
(c) 2005-2009 Juniper Networks Inc.
root@localhost>
```

## Configuring the Juniper Networks Database

Each C Series Controller contains a Juniper Networks database. The database stores SRC data, sample data, configuration information, and user profiles. You must enable the Juniper Networks database the first time you power on the system. It can operate as a standalone database or as a member of a community of Juniper Networks databases.



**NOTE:** The Juniper Networks database must be running before you start configuring the SRC software.

Typically, you run the database in standalone mode only in testing environments. In standalone mode, the database does not communicate with other Juniper Networks databases; there is no data distribution and no redundancy. In community mode, databases distribute data changes among specified databases. When you have two or more C Series Controllers, enable the Juniper Networks database to run in community mode, and assign a role to each database:

- Primary role—A database that provides read and write access to client applications. It replicates its data and distributes changes to any Juniper Networks databases configured as neighbors.
- Secondary role—A database that provides read access to client applications. If client applications try to write data to this database, the database refers the client to a primary database.

In the following example, a standalone database is enabled.

To enable a Juniper Networks database to run in standalone mode:

1. From configuration mode, access the configuration statement that configures the Juniper Networks database.

```
root@host# edit system ldap server
```

2. Enable standalone mode.

```
[edit system ldap server]
root@host# set stand-alone
```

## Configuring Hostname and Domain Parameters

To set hostname and domain parameters:

1. Enter configuration mode.

```
root@host> edit
```

2. Configure the hostname.

```
[edit]
root@host# set system host-name host-name
```

For example:

```
[edit]
root@host# set system host-name my-hostname
```

3. Configure either a list of domain names to search, or create the domain name. We recommend configuring a list of domain names to search.

To configure a list of domain names to search:

```
[edit]
root@host# set system domain-search [domain-name1, domain-name2, ...]
```

For example:

```
[edit]
root@host# set system domain-search [my-domain.juniper.net domain.juniper2.net]
```

To configure the domain name:

```
[edit]
root@host# set system domain-name domain-name
```

For example:

```
[edit]
root@host# set system domain-name my-domain.juniper.net
```

## Configuring the System for Remote Access

To allow remote access to the system, you must configure the generic interfaces. You can specify an IP address with mask or a broadcast address with mask for an interface. For more information, see *C Series Controller Remote Access*.

To configure the generic interfaces:

1. From configuration mode, access the configuration statement that configures the interface.

```
root@host# edit interfaces eth0
```

2. Specify the unit, family, and IP address for the interface.

```
[edit interfaces eth0]
root@host# set unit number family inet address address
```

For example, to configure an interface with only an IP address:

```
[edit interfaces eth0]
root@host# set unit 0 family inet address 192.2.0.10/24
```

3. (Optional) Specify the broadcast address for the interface.

```
[edit interfaces eth0]
root@host# set unit number family inet broadcast broadcast
```

For example, to configure an interface with only a broadcast address:

```
[edit interfaces eth0]
root@host# set unit 0 family inet broadcast 192.2.0.255
```

4. Verify the interface configuration.

```
[edit interfaces eth0]
```



```

root@host# show
unit 0 {
family {
inet {
broadcast 192.2.0.255;
}
}
}

```

## Configuring the System to Accept SSH and Telnet Connections

You can enable SSH and Telnet to let users who have the appropriate privileges connect to the system. For security reasons, we recommend that you do not allow remote users to access the CLI as **root**. The system does not allow **root** access over a Telnet connection. For more information, see *Configuring a C Series Controller to Accept SSH Connections (SRC CLI)*.

To configure the system to accept SSH connections:

1. From configuration mode, access the **[edit system services ssh]** hierarchy level.
2. (Optional) Specify whether or not to allow root login through SSH.

```

[edit system services ssh]
root@host> set root-login (allow | deny | deny-password)

```

where:

- **allow**— Allow users to log in to the C Series Controller as **root** through SSH.
- **deny**— Disable users from logging in to the system as **root** through SSH.
- **deny-password**— Allow users to log in to the system as root through SSH when the authentication method (for example, RSA authentication) does not require a password. (Default)

To configure the system to accept Telnet connections:

- In edit mode, type the following command.

```

[edit]
root@host# set system services telnet

```

## Adding an Admin User Account

Although you use **root** access for initial configuration of the system, you use user accounts to enter commands and statements at the CLI. Therefore, you must set up an admin account to allow further configuration. You can use a built-in class, such as super-user.

To configure an account for an administrative user:

1. Create an account for an administrative user.

```

[edit]
root@host# edit system login user user

```

For example:

```
[edit]
root@host# edit system login user myadmin
```

2. Set the class for the administrative user to the login class that you created.

```
[edit system login user myadmin]
root@host# set class class
```

For example:

```
[edit system login user myadmin]
root@host# set class super-user
```

3. Specify the name of the administrative user.

```
[edit system login user myadmin]
root@host# set full-name "John Doe"
```

4. Set the CLI editing level to expert.

```
[edit system login user myadmin]
root@host# set level expert
```

5. (Optional) Specify that a space be used for command completion.

```
[edit system login user myadmin]
root@host# set complete-on-space on
```

6. Verify that the configuration for the administrative user is correct.

```
[edit system login user myadmin]
root@host# show
class super-user;
full-name "John Doe";
uid 506;
gid 100;
level expert;
complete-on-space on;
```

7. Set the password of the user.

```
[edit]
root@host# edit system login user myadmin authentication
[edit system login user myadmin authentication]
root@host# set plain-text-password
```

**Related  
Documentation**

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Installation Summary on page 23](#)
- [C Series Configuration Overview on page 39](#)

## PART 3

# Hardware Maintenance and Replacement Procedures

- [Maintaining C3000 and C5000 Controller Hardware Components on page 47](#)
- [Replacing C3000 and C5000 Controller Hardware Components on page 51](#)



## CHAPTER 9

# Maintaining C3000 and C5000 Controller Hardware Components

- [Storing C Series Modules and Components on page 47](#)
- [Cleaning C Series Components Overview on page 47](#)
- [Maintaining the C Series Hard Disks on page 48](#)

### Storing C Series Modules and Components

---

Retain the packaging in which a component was shipped, and use this packaging to store the item.



**CAUTION:** Failure to store electronic components correctly can lead to damage of these items.

Follow these guidelines for storing components:

- Store each component in a separate antistatic bag.
- Store components in an antistatic plastic container. Some of these containers can accommodate several components in separate compartments.
- Do not store multiple components in an antistatic bag or container where they can touch other items.
- (Optional) Store the item in its antistatic bag or container within the protective packaging or padded box that the item was shipped in.

#### Related Documentation

- [Cleaning C Series Components Overview on page 47](#)
- [Maintaining the C Series Hard Disks on page 48](#)

### Cleaning C Series Components Overview

---

Clean the system with a dry cloth every few weeks to prevent excessive dust accumulation. This cleaning helps to maintain the efficiency of the cooling system and to prevent damage to electronic components.



**WARNING:** Do not insert any metal object, such as a screwdriver, or place your hand into an open slot when the system is on. Remove jewelry (including rings, necklaces, and watches) before working on equipment that is connected to power lines. These actions prevent electric shock and serious burns.



**CAUTION:** When cleaning the system, wear an antistatic device. This action helps to protect components from damage by electrostatic discharge.

- Related Documentation**
- [Storing C Series Modules and Components on page 47](#)
  - [Maintaining the C Series Hard Disks on page 48](#)

## Maintaining the C Series Hard Disks

**Purpose** For optimum controller performance, verify the condition of the hard disks.

**Action** On a regular basis:

- Check the hard disk status LEDs to view information about the status of the hard disk.
- To check the status of the hard disk, issue the **show disk status** command. The output is similar to the following:

```
user@host> show disk status
```

### Controller information

```
Controller type           : SAS1068E
BIOS version              : 6.26.00.00
Firmware version          : 1.27.00.00
Channel description       : 1 Serial Attached SCSI
Initiator ID              : 112
Maximum physical devices  : 62
Concurrent commands supported : 277
Slot                      : 57
Bus                       : 5
Device                   : 0
Function                  : 0
RAID Support              : Yes
```

### IR Volume information

```
IR volume 1
Volume ID                 : 16
Status of volume          : Okay (OKY)
RAID level                 : 1E
Size (in MB)              : 278472
Physical hard disks (Target ID) : 20 17 18 19
```

### Physical device information

```
Initiator at ID #112
Target on ID #17
```

```

Device is a Hard disk
Enclosure #           : 1
Slot #               : 1
Connector ID         : 1
Target ID            : 17
State                 : Online (ONL)
Size (in MB)/(in sectors) : 140014/286749488
Manufacturer         : SEAGATE
Model Number         : ST9146852SS
Firmware Revision    : 0005
Serial No            : 6TB0094A00009037Q6C1
Drive Type           : SAS
Protocol             : SAS

Target on ID #18
Device is a Hard disk
Enclosure #           : 1
Slot #               : 2
Connector ID         : 2
Target ID            : 18
State                 : Online (ONL)
Size (in MB)/(in sectors) : 140014/286749488
Manufacturer         : SEAGATE
Model Number         : ST9146852SS
Firmware Revision    : 0005
Serial No            : 6TB007E000009038UBWS
Drive Type           : SAS
Protocol             : SAS

Target on ID #19
Device is a Hard disk
Enclosure #           : 1
Slot #               : 3
Connector ID         : 3
Target ID            : 19
State                 : Online (ONL)
Size (in MB)/(in sectors) : 140014/286749488
Manufacturer         : SEAGATE
Model Number         : ST9146852SS
Firmware Revision    : 0005
Serial No            : 6TB0093R00009038UAV8
Drive Type           : SAS
Protocol             : SAS

Target on ID #20
Device is a Hard disk
Enclosure #           : 1
Slot #               : 0
Connector ID         : 0
Target ID            : 20
State                 : Online (ONL)
Size (in MB)/(in sectors) : 140014/286749488
Manufacturer         : SEAGATE
Model Number         : ST9146852SS
Firmware Revision    : 0005
Serial No            : 6TB008W200009038UAVT
Drive Type           : SAS
Protocol             : SAS

-----
Enclosure information
-----
Enclosure#           : 1
Logical ID           : 000368d4:500e0810
Numslots             : 8

```

StartSlot	: 0
Start TargetID	: 0
Start Bus	: 0

---

IR Volume 1	
Volume ID	: 16
Current operation	: None
Volume status	: Enabled
Volume state	: Optimal
Physical disk I/Os	: Not quiesced

- Related Documentation**
- [Storing C Series Modules and Components on page 47](#)
  - [Cleaning C Series Components Overview on page 47](#)



## CHAPTER 10

# Replacing C3000 and C5000 Controller Hardware Components

- [Tools and Parts Required to Replace C Series Components on page 51](#)
- [Replacing a C3000 or C5000 Fan Module on page 51](#)
- [Replacing a C3000 or C5000 Hard Disk on page 53](#)
- [Replacing a C3000 or C5000 Power Supply on page 55](#)
- [Replacing a C3000 or C5000 AC Power Cord on page 58](#)
- [Replacing a C3000 or C5000 DC Power Cable on page 59](#)

## Tools and Parts Required to Replace C Series Components

---

You need the following tools and parts to replace components:

- Flathead and Phillips screwdrivers
- Insulated adjustable wrench
- Antistatic wrist strap
- Antistatic bags (or other protective packaging to hold components)
- Plastic boots or other protective covers for fiber-optic connectors

### Related Documentation

- [Replacing a C3000 or C5000 Fan Module on page 51](#)
- [Replacing a C3000 or C5000 Hard Disk on page 53](#)
- [Replacing a C3000 or C5000 Power Supply on page 55](#)

## Replacing a C3000 or C5000 Fan Module

---

- [Removing a C3000 or C5000 Fan Module on page 52](#)
- [Installing a C3000 or C5000 Fan Module on page 52](#)

## Removing a C3000 or C5000 Fan Module

C3000 and C5000 Controllers have three fan modules located on the rear of the chassis. The fan module is a hot-removable and hot-insertable field replaceable unit (FRU): You can remove and replace it without powering off the controller or disrupting controller functions.


Ensure that you have the following parts and tools available:

- A Phillips (+) screwdriver, number 2

To remove a fan module from a C3000 or C5000 Controller (see [Figure 19 on page 52](#)):

1. Loosen the captive screws on either side of the fan module.
2. Grasp the captive screws and slide the fan module out of the chassis.

**Figure 19: Removing a C3000 or C5000 Fan Module**



## Installing a C3000 or C5000 Fan Module

C3000 and C5000 Controllers have three fan modules located on the rear of the chassis. The fan module is a hot-removable and hot-insertable field replaceable unit (FRU): You can remove and replace it without powering off the controller or disrupting controller functions.


Ensure that you have the following parts and tools available:

- A Phillips (+) screwdriver, number 2

To install the fan module in a C3000 or C5000 Controller (see [Figure 20 on page 53](#)):

1. Remove the fan module from its bag.
2. Using both hands, align the fan module with the guides on the fan module slot on the rear panel of the chassis.
3. Slide the fan module into the fan module slot until it is firmly seated.
4. Tighten both captive screws to secure the fan.

Figure 20: Installing a C3000 or C5000 Fan Module



#### Related Documentation

- [C3000 and C5000 Fan Module Description on page 12](#)
- [C Series Fan Module Serial Number Label on page 84](#)

## Replacing a C3000 or C5000 Hard Disk

- [Removing a C3000 or C5000 Hard Disk on page 53](#)
- [Installing a C3000 or C5000 Hard Disk on page 54](#)

### Removing a C3000 or C5000 Hard Disk

C3000 and C5000 Controllers have four hard disk arrays located in two slots on the front of the chassis. The hard disk is a hot-removable and hot-insertable field replaceable unit (FRU): You can remove and replace it without powering off the controller or disrupting controller functions.

Ensure that you have the following parts and tools available:

- Phillips (+) screwdriver, number 2
- An antistatic bag or an antistatic mat

To remove a hard disk on a C3000 or C5000 Controller (see [Figure 21 on page 54](#)):

1. Place the antistatic bag or the antistatic mat on a flat, stable surface.
2. From the CLI, disable the disk. The hard disks are numbered 0 through 3.

```
user@host> request disk disable device device-number
```




**NOTE:** Do not power off the C Series Controller when you are swapping a disk, because doing so might result in initialization errors.

3. Using a flat screwdriver, turn the screw to the unlocked position so that the notch in the screw is oriented horizontally.

4. Push the screw knob in so that the ejector handle is released.
5. Gently pull the ejector handle toward you, and slide the hard disk out of the hard disk slot. Keep one hand underneath the hard disk to support it while removing it from the chassis.

**Figure 21: Removing a C3000 or C5000 Hard Disk**



## Installing a C3000 or C5000 Hard Disk

C3000 and C5000 Controllers have four hard disk arrays located in two bays on the front of the chassis. The hard disk is a hot-removable and hot-insertable field replaceable unit (FRU): You can remove and replace it without powering off the controller or disrupting controller functions.

To replace a hard disk on a C3000 or C5000 Controller (see [Figure 22 on page 55](#)):


1. Slide the hard disk into the bay.
2. Push the ejector lever so that the latch closes and the hard disk secures firmly in place.
3. Using a flat screwdriver, turn the screw to the locked position so that the notch in the screw is oriented vertically.
4. From the CLI, enable the disk. The hard disks are numbered 0 through 3.

```
user@host> request disk enable device device-number
```

5. Verify that the disk is initialized.

```
user@host> show disk status
```

Figure 22: Installing a C3000 or C5000 Hard Disk



#### Related Documentation

- [C3000 and C5000 Hard Disk Description on page 13](#)
- [Maintaining the C Series Hard Disks on page 48](#)
- [C Series Hard Disk Serial Number Label on page 85](#)

## Replacing a C3000 or C5000 Power Supply

- [Removing a C3000 or C5000 Power Supply on page 55](#)
- [Installing a C3000 or C5000 Power Supply on page 57](#)

### Removing a C3000 or C5000 Power Supply

The power supply in a C3000 or C5000 Controller is a hot-removable and hot-insertable field-replaceable unit (FRU) located on the far right side of the rear panel. Two power supplies can be installed in a C3000 or C5000 Controller. You can remove and replace a single power supply without powering off the controller or disrupting external controller functions.

Ensure that you have the following parts and tools available to remove a power supply from a C3000 or C5000 Controller.


- Replacement power supply or blank cover for the power supply slot

To remove a power supply on a C3000 or C5000 Controller (see [Figure 23 on page 56](#) and [Figure 24 on page 56](#)):


1. Remove the power cord or power cable as described in "[Disconnecting a C3000 or C5000 AC Power Cord](#)" on page 58 or "[Disconnecting a C3000 or C5000 DC Power Cable](#)" on page 59.

2. Push the power supply faceplate latch to the right while pulling the power supply away from the controller to release the latch. Stop pulling the power supply after the latch has been released.
3. Taking care not to touch power supply components, pins, leads, or solder connections, place one hand under the power supply to support it. Grasp the power supply handle with your other hand and, pull the power supply completely out of the chassis.

**Figure 23: Removing a C3000 or C5000 AC Power Supply**



**Figure 24: Removing a C3000 or C5000 DC Power Supply**



## Installing a C3000 or C5000 Power Supply

The AC power supply in a C3000 or C5000 Controller is a hot-removable and hot-insertable field-replaceable unit (FRU) located on the far right side of the rear panel. Two AC power supplies can be installed in a C3000 or C5000 Controller. You can remove and replace a single AC power supply without powering off the controller or disrupting external controller functions.

To install a power supply on a C3000 or C5000 Controller (see [Figure 25 on page 57](#) and [Figure 26 on page 58](#)):

1. Taking care not to touch power supply components, pins, leads, or solder connections, remove the power supply from its bag.
2. Using one hand on the faceplate handle and the other hand on the bottom of the power supply to support its weight, slide the power supply straight into the power supply slot until the power supply is approximately halfway to the back of the controller.
3. Remove the hand supporting the bottom of the power supply.
4. Gently slide the power supply straight into the chassis until the power supply is almost fully seated in the slot. The power supply will reach a point where backpressure will prevent the power supply from pushing forward; do not force the power supply fully into the slot at this point of the procedure.
5. Use your thumb to move the latch at the top of the power supply faceplate to the right, and push the power supply flush into the back of the chassis. Release the latch.
6. Using a flat screwdriver, turn the screw to the locked position so that the notch in the screw is oriented vertically.

**Figure 25: Installing a C3000 or C5000 AC Power Supply**





Figure 26: Installing a C3000 or C5000 DC Power Supply



#### Related Documentation

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Replacing a C3000 or C5000 AC Power Cord on page 58](#)
- [Replacing a C3000 or C5000 DC Power Cable on page 59](#)
- [C Series Power Supply Serial Number Label on page 85](#)

## Replacing a C3000 or C5000 AC Power Cord

- [Disconnecting a C3000 or C5000 AC Power Cord on page 58](#)
- [Connecting a C3000 or C5000 AC Power Cord on page 58](#)

### Disconnecting a C3000 or C5000 AC Power Cord

To disconnect the AC power cord:

1. Unplug the power cord from the power source receptacle.
2. Unplug the power cord from the appliance inlet on the power supply.

### Connecting a C3000 or C5000 AC Power Cord

To connect the AC power cord:

1. Locate a replacement power cord with the type of plug appropriate to your geographical location (see [“C3000 and C5000 AC Power Cord Specifications” on page 78](#)).
2. Plug the replacement power cord into the corresponding appliance inlet located in the chassis directly above the power supply.
3. Insert the power cord plug into an external AC power source receptacle.





**NOTE:** Each power supply must be connected to a dedicated AC power feed and a dedicated customer site circuit breaker. We recommend that you use a 5 A (110 VAC) minimum, or as required by local code.

4. Dress the power cord appropriately. Verify that the power cord does not block the air exhaust and access to router components, or drape where people could trip on it.
5. Observe the status LEDs on the power supply faceplate. If the power supply is correctly installed and functioning normally, the status LED lights green steadily.

**Related Documentation**

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Replacing a C3000 or C5000 Power Supply on page 55](#)
- [C Series Power Supply Serial Number Label on page 85](#)

---

## Replacing a C3000 or C5000 DC Power Cable


- [Disconnecting a C3000 or C5000 DC Power Cable on page 59](#)
- [Connecting a C3000 or C5000 DC Power Cable on page 60](#)

### Disconnecting a C3000 or C5000 DC Power Cable

To disconnect a power cable for a DC power supply (see [Figure 27 on page 60](#)):

1. Switch off the dedicated customer site circuit breaker for the power supply being removed.
2. Make sure that the voltage across the DC power source cable leads is 0 V and that there is no chance that the cables might become active during the removal process.
3. Verify that the status LED on the power supply is not lit.
4. Remove the power cable from the external DC power source.
5. Remove the clear plastic shield covering the field-wiring terminals on the power supply.
6. Remove the screws on the field-wiring and ground terminal.
7. Carefully move the power cables out of the way.

Figure 27: Disconnecting a C3000 or C5000 DC Power Cable



### Connecting a C3000 or C5000 DC Power Cable



**WARNING:** Before performing DC power procedures, ensure that power is removed from the DC circuit. To ensure that all power is off, locate the circuit breaker on the panel board that services the DC circuit, switch the circuit breaker to the off position, and tape the switch handle of the circuit breaker in the off position.

To connect a power cable for a DC power supply:

1. Locate a replacement power cable.
2. Verify that a licensed electrician has attached a cable lug to the replacement power cable.



**NOTE:** You must bend the cable lug that attaches to the DC power source cable at a 90° angle in order to properly install the clear plastic shield covering.


3. Verify that the status LED is off.
4. Insert the DC power and ground cable lugs into the appropriate terminals. Using a number 1 Phillips screwdriver, turn the screw on each terminal clockwise to secure the cable. Apply 8.68 lb-in. (.98 Nm) of torque to each screw.
  - a. Insert the positive (+) source cable into the return terminal, which is labeled **RTN**.
  - b. Insert the negative (–) source cable into the input terminal, which is labeled **–48V**.
  - c. Align the ground cable with the ground terminal.



**CAUTION:** Ensure that each cable lug seats flush against the surface of the terminal block as you tighten the screws.

5. Verify that the DC source power and grounding cables are correct, that they are not touching or blocking access to controller components, and that they do not drape where people could trip on them.
6. Replace the clear plastic shield over the field-wiring terminals.
7. Attach the power cable to the DC power source.
8. Turn on the dedicated customer site circuit breaker to the power supply.
9. Verify that the status LED on the power supply is lit steadily. If the power supply is correctly installed and functioning normally, the status LED lights green steadily.

**Figure 28: Connecting a C3000 or C5000 DC Power Cable**



**Related Documentation**

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Replacing a C3000 or C5000 Power Supply on page 55](#)
- [C Series Power Supply Serial Number Label on page 85](#)



## PART 4

# Appendixes

- [Safety and Regulatory Compliance Information for the C3000 and C5000 Controllers on page 65](#)
- [C3000 and C5000 Controller Physical Specifications on page 73](#)
- [C3000 and C5000 Controller Environmental Specifications on page 75](#)
- [Power Guidelines, Requirements, and Specifications for the C3000 and C5000 Controller on page 77](#)
- [C3000 and C5000 Controller Cable Connector Pinouts on page 81](#)
- [Contacting Customer Support and Returning C3000 and C5000 Hardware on page 83](#)



## APPENDIX A

# Safety and Regulatory Compliance Information for the C3000 and C5000 Controllers

- C3000 and C5000 Safety Notices on page 65
- C3000 and C5000 General Safety Guidelines on page 67
- C3000 and C5000 Safety and Emissions Certifications on page 69
- Declaration of Conformity for the C3000 and C5000 Controllers on page 69
- C3000 and C5000 Cabling Recommendations on page 70

## C3000 and C5000 Safety Notices

---

- Lithium Battery on page 65
- Power Disconnection on page 66
- Power Cable Warning on page 66
- Power Cable Warning (Japanese) on page 66
- Working with Lasers on page 67
- VCCI Compliance on page 67

### Lithium Battery



.....

**WARNING:** There is a danger of explosion if the battery is incorrectly replaced. Return the device to the manufacturer for battery replacement. Moreover, never open the chassis under any circumstances. Doing so will also void the warranty.

.....



.....

**WARNING:** La batterie présente un risque d'explosion si elle n'est pas remplacée comme il se doit. Retournez l'appareil au fabricant pour faire remplacer la batterie. Le châssis ne doit par ailleurs en aucun cas être ouvert. Cela annulerait la garantie.

.....

## Power Disconnection



**WARNING:** Before working on a device that has an On/Off switch, turn the power off and disconnect the power cord to all power supplies.

For DC power supplies, locate the circuit breaker on the panel board that services the DC circuit, switch the circuit breaker to the off position, and tape the switch handle of the circuit breaker in the off position.



**WARNING:** Avant de commencer à travailler sur un appareil muni d'un interrupteur On. Off (Marche/Arrêt), Coupez l'alimentation et débranchez le cordon d'alimentation de toute source d'alimentation.

Dans le cas d'une alimentation à courant continu, repérez le disjoncteur sur le tableau de contrôle qui alimente le circuit c.c., placez-le en position d'off (arrêt) et maintenez le bouton du disjoncteur en position d'arrêt à l'aide de ruban adhésif.

## Power Cable Warning



**WARNING:** This unit has two power cables. To avoid electric shock, disconnect both power cables before servicing the unit.



**WARNING:** Cette unité possède deux cordons d'alimentation. Pour supprimer tout risque électrique, débranchez les deux cordons d'alimentation de l'unité.

## Power Cable Warning (Japanese)



**WARNING:** The attached power cable is only for this product. Do not use the cable for another product.

### 注意

附属の電源コードセットはこの製品専用です。  
他の電気機器には使用しないでください。

g017253



## Working with Lasers

Some Juniper Networks devices are equipped with fiber-optic ports, which emit radiation that may be harmful to the human eye. Fiber-optic ports are considered Class 1 laser or Class 1 LED ports.



**WARNING:** Class 1 Laser product.



**WARNING:** Class 1 LED product.



**WARNING:** Do not stare into the laser beam or view it directly with optical instruments.

To avoid exposure to radiation, do not stare into the aperture of a fiber-optic port. Invisible radiation might be emitted from the aperture of the port when no fiber cable is connected.

These products have been tested and found to comply with Class 1 limits of IEC 60825-1, IEC 60825-2, EN 60825-1, EN 60825-2, and 21CFR1040.

## VCCI Compliance



**WARNING:** This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures. (VCCI-A)

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

### Related Documentation

- [C3000 and C5000 General Safety Guidelines on page 67](#)

## C3000 and C5000 General Safety Guidelines

For your safety, before installing the system, review all safety warnings in this topic.



**WARNING:** The recommended maximum ambient temperature is 104°F (40°C). For safe operation take into consideration the internal temperature within the rack.



**WARNING:** Install equipment in the rack from the bottom upward. Doing this helps maintain the stability of the rack and reduces the chance of the rack tipping over.



**WARNING:** Do not insert any metal object, such as a screwdriver, into the system. Doing so can cause electric shock and serious burns.



**WARNING:** Three people are required to install the system in a rack: two to lift the system into position and one to screw it to the rack.



**WARNING:** Connect the system or rack to ground (earth), and ensure that a reliable grounding path is maintained in the rack.



**WARNING:** Do not work on the system or connect or disconnect cables during lightning activity.



**WARNING:** Be sure that circuit breakers for the power source are in the OFF position before attaching power cables.



**WARNING:** Before servicing the system, turn off the power.



**WARNING:** Remove jewelry (including rings, necklaces, and watches) before working on equipment that is connected to power lines. Metal objects heat up when connected to power and ground and can cause serious burns or become welded to the terminals.



**CAUTION:** Evaluate the overall loading of the branch circuit before you install any equipment into a rack.

Related Documentation • [C3000 and C5000 Safety Notices on page 65](#)

## C3000 and C5000 Safety and Emissions Certifications

---

The C3000 and C5000 Controllers have the following safety certifications:

- CAN/CSA-C22.2 No 60950-1:2003
- UL60950
- EN60950-1:2001+A11
- IEC 60950-1:2001

The C3000 and C5000 Controllers have the following emissions certifications:

- FCC Class A
- EN 55022 Class A
- EN 55024 Immunity
- EN 61000-3-2
- VCCI Class A

**Related  
Documentation**

- [C3000 and C5000 Safety Notices on page 65](#)
- [C3000 and C5000 General Safety Guidelines on page 67](#)

## Declaration of Conformity for the C3000 and C5000 Controllers

---

[Figure 29 on page 70](#) shows the Declaration of Conformity for the controller.

Figure 29: C3000 and C5000 Controllers Declaration of Conformity

**JUNIPER**  
NETWORKS

**Declaration of Conformity**  
**R&TTE Directive 1999/5/EC**  
according to EN 45014

**CE**

**Juniper Networks, Inc.**  
1194 N. Mathilda Ave  
Sunnyvale, CA 94089 USA

declares under our sole responsibility that the product(s):

**JA-C3000-A-BSE and JA-C5000-A-BSE**

are in conformity with the provisions of R&TTE Directive 1999/5/EC. The conformity has been assessed according to the procedure detailed in Annex II of the Directive.

The following harmonized standards were applied:

<b>EMC</b>	<b>EN 300 386 v1.4.1: 2008</b>
	<b>EN 55022 + A1 Class A: 2006</b>
	<b>EN 55024 +A1+A2: 1998</b>
<b>Safety</b>	<b>EN 60950-1: 2006 (2nd Edition)</b>

This product carries the CE Mark, which was first affixed in 2010.

Place	Signature	Date
Sunnyvale, CA		16-Sep-10

**Michael J. Azar**  
**Homologation Manager**  
1194 N. Mathilda Ave  
Sunnyvale, CA 94089 USA

DoC: 10- 0005

## C3000 and C5000 Cabling Recommendations

Comply with the following recommendations:

- Use only shielded cables.
- Ensure that cable distance and rate limits meet IEEE-recommended maximum distances and speeds for signaling purposes. For information about attenuation and power loss in optical fiber cables see:

- ANSI T1.646a-1997 Telecommunications – Broadband ISDN - Physical Layer Specification for User-Network Interfaces Including DS1/ATM (1997)
- ANSI T1.646-1995 Telecommunications – Broadband ISDN - Physical Layer Specification for User-Network Interfaces Including DS1/ATM (1995)
- Ensure that power cables deliver sufficient power to the system.
- Attach laser fiber connectors only to Class 1 laser devices in accordance with IEC 60825-1, Safety of Laser Products - Part 1.
- Route cables so that they do not restrict ventilation or airflow.
- Route cables so that modules and field-replaceable units are easily accessible.
- Route cables in a logical direction to prevent loss of connectivity to other equipment in the rack, to associated equipment in adjacent racks, or to the backbone network.

For additional cable recommendations, consult the document GR-63–CORE: Network Equipment Building System (NEBS) Requirements: Physical Protection, Issue 2, April 2002.

**Related  
Documentation**

- [C3000 and C5000 Site Preparation Checklist on page 19](#)



APPENDIX B

# C3000 and C5000 Controller Physical Specifications

- [C3000 and C5000 Controller Physical Specifications on page 73](#)

## C3000 and C5000 Controller Physical Specifications

Table 12 on page 73 summarizes the physical specifications for the chassis.

Table 12: C3000 and C5000 Controller Physical Specifications

Description	Weight	Width	Depth	Height
Chassis dimension	43.31 lb (19.65 kg)	17.26 in. (43.7 cm)	23.5 in. (59.7 cm)	3.5 in. (8.8 cm)
Hard Disk	0.6 lb (265 g)	2.9 in. (7.4 cm)	4.9 in. (12.5 cm)	0.6 in. (1.5 cm)
Fan module	0.6 lb (300 g)	4.3 in. (11 cm)	1.63 in. (4.13 cm)	3.25 in. (8.25 cm)
DC power supply	2.6 lb (1.2 kg)	3 in. (7.62 cm)	12 in. (30.48 cm)	1.56 in. (3.96 cm)
AC power supply	2.6 lb (1.2 kg)	3 in. (7.62 cm)	12 in. (30.48 cm)	1.56 in. (3.96 cm)

**Related Documentation**

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [C3000 and C5000 Controller Environmental Specifications on page 75](#)





## APPENDIX C

# C3000 and C5000 Controller Environmental Specifications

- [C3000 and C5000 Controller Environmental Specifications on page 75](#)

## C3000 and C5000 Controller Environmental Specifications

[Table 13 on page 75](#) indicates the environmental specifications required for normal controller operation. In addition, the site should be as dust-free as possible.

**Table 13: C3000 and C5000 Controller Environmental Specifications**

Description	Value
Altitude	No performance degradation to 10,000 ft (3048 m)
Relative humidity	Normal operation ensured in relative humidity range of 5% to 95%, noncondensing
Temperature	Normal operation ensured in temperature range of 41°F (5°C) to 104°F (40°C)  Nonoperating storage temperature in shipping container: –40°F (–40°C) to 158°F (70°C)  1909 BTU/hour (560 W)



**NOTE:** Install the controller only in restricted areas, such as dedicated equipment rooms and equipment closets, in accordance with Articles 110-16, 110-17, and 110-18 of the National Electrical Code, ANSI/NFPA 70.

### Related Documentation

- [C3000 and C5000 Site Preparation Checklist on page 19](#)
- [Cleaning C Series Components Overview on page 47](#)
- [C3000 and C5000 Controller Physical Specifications on page 73](#)



## APPENDIX D

# Power Guidelines, Requirements, and Specifications for the C3000 and C5000 Controller

- [C3000 and C5000 AC Power Specifications and Requirements on page 77](#)
- [C3000 and C5000 DC Power Specifications and Requirements on page 79](#)

## C3000 and C5000 AC Power Specifications and Requirements

---

- [AC Power Electrical Specifications for the C Series Controller on page 77](#)
- [C3000 and C5000 AC Power Cord Specifications on page 78](#)

### AC Power Electrical Specifications for the C Series Controller

[Table 14 on page 77](#) lists the AC power supply electrical specifications.

**Table 14: AC Power Electrical Specifications**

Item	Specification
AC power supply output power	560 W
AC system input power	350 W
AC input voltage	Operating range: 100 to 240 VAC
AC input line frequency	50 to 60 Hz (nominal)
AC system current rating	5A @ 110 VAC
Efficiency	80% minimum at full load

#### Related Documentation

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Connecting Power to an AC-Powered C3000 or C5000 Controller on page 33](#)
- [C3000 and C5000 AC Power Cord Specifications on page 78](#)

## C3000 and C5000 AC Power Cord Specifications

Each AC power supply has a single AC appliance inlet located on the power supply that requires a dedicated AC power feed. Most sites distribute power through a main conduit that leads to frame-mounted power distribution panels, one of which can be located at the top of the rack that houses the controller. An AC power cord connects each power supply to the power distribution panel.

The controller ships with detachable AC power cords, each approximately 8 ft (2.5 m) long that supply AC power to the controller. The C13 appliance coupler at the female end of the cord inserts into the AC appliance inlet coupler, type C14 (right angle) as described by International Electrotechnical Commission (IEC) standard 60320. The plug at the male end of the power cord fits into the power source receptacle that is standard for your geographical location. [Table 15 on page 78](#) provides specifications for the AC power cord provided for each country or region.

**Table 15: AC Power Cord Specifications**

Country	Model Number	Electrical Specification	Plug Type
Australia	CBL-GP-JX-PWR-AU	250 VAC, 10 A, 50 Hz	AS/NZ 3112-1993
China	CBL-GP-JX-PWR-CH	250 VAC, 10 A, 50 Hz	GB2099.1 1996 and GB1002 1996 (CHI-10P)
Europe (except Italy and United Kingdom)	CBL-GP-JX-PWR-EU	250 VAC, 10 A, 50 Hz	CEE (7) VII
Italy	CBL-GP-JX-PWR-IT	250 VAC, 10 A, 50 Hz	IEC60884-1
Japan	CBL-GP-JX-PWR-JP	125 VAC, 12 A, 50 Hz or 60 Hz	JIS 8303 and 8306
Korea	CBL-GP-JX-PWR-KR	250 VAC, 10 A, 50 Hz	KSC8305 and EN 60320 C13
North America	CBL-GP-JX-PWR-US	125 VAC, 10 A, 60 Hz	NEWA 5-15P
Switzerland	CBL-GP-JX-PWR-SZ	250 VAC, 10 A, 50 Hz	SEV 1011,1991, and EN 60320 C13
United Kingdom	CBL-GP-JX-PWR-UK	250 VAC, 10 A, 50 Hz	BS1363



**WARNING:** The AC power cord for the controller is intended for use with the controller only and not for any other use.

### Related Documentation

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Connecting Power to an AC-Powered C3000 or C5000 Controller on page 33](#)
- [AC Power Electrical Specifications for the C Series Controller on page 77](#)

## C3000 and C5000 DC Power Specifications and Requirements

- [DC Power Electrical Specifications for the C Series Controller on page 79](#)
- [DC Power Cable Specifications for C Series Controllers on page 79](#)

### DC Power Electrical Specifications for the C Series Controller

Table 16 on page 79 lists the DC power electrical specifications.

**Table 16: DC Power Electrical Specifications**

Item	Specification
Maximum power supply output power	560 W
DC system input power	350 W
DC input voltage	–38 VDC to –72 VDC
DC input current rating	10 A @ –48 VDC
Efficiency	80% minimum at full load

#### Related Documentation

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Connecting a C3000 or C5000 DC Power Cable on page 60](#)
- [DC Power Cable Specifications for C Series Controllers on page 79](#)


### DC Power Cable Specifications for C Series Controllers

- [DC Power Cable Lug Specifications on page 79](#)
- [DC Power Cable Specifications on page 80](#)

#### DC Power Cable Lug Specifications

To connect the DC power cables to the controller, you must use cable lugs that have the specifications shown in [Figure 30 on page 79](#).

**Figure 30: DC Power Cable Lug**





.....

**CAUTION:** Before you install a C Series Controller, a licensed electrician must attach a cable lug to the power cables. A cable with an incorrectly attached lug can damage the controller.

.....

### DC Power Cable Specifications

---

You must use DC power cables that meet the following specifications: 14–12 AWG (1.9 mm<sup>2</sup> minimum) wire, or as required by the local code.

#### Related Documentation

- [C3000 and C5000 Power Supply Description on page 10](#)
- [Connecting a C3000 or C5000 DC Power Cable on page 60](#)
- [DC Power Electrical Specifications for the C Series Controller on page 79](#)

APPENDIX E

# C3000 and C5000 Controller Cable Connector Pinouts

- [C3000 and C5000 RJ-45 Console Connector Pinouts on page 81](#)

## C3000 and C5000 RJ-45 Console Connector Pinouts

[Table 17 on page 81](#) shows the pinouts for the RJ-45 console connector pinouts.

**Table 17: RJ-45 Console Connector Pinouts**

Pin	Signal	Description
1	RTS output	Request to send
2	DTR output	Data terminal ready
3	TxD output	Transmit data
4	GND	Chassis ground
5	GND	Chassis ground
6	RxD input	Receive data
7	DSR Input	Data set ready
8	CTS Input	Clear to send

**Related Documentation**

- [Connecting the C Series Controllers to External Devices on page 36](#)





## APPENDIX F

# Contacting Customer Support and Returning C3000 and C5000 Hardware

- [Locating C Series Component Serial Numbers on page 83](#)
- [Contacting Customer Support on page 86](#)
- [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
- [Packing the C Series Controller for Shipment on page 88](#)
- [Guidelines for Packing C Series Components for Shipment on page 89](#)

## Locating C Series Component Serial Numbers

---

- [Displaying C Series Component Serial Numbers on page 83](#)
- [C Series Chassis Serial Number Label on page 83](#)
- [C Series Fan Module Serial Number Label on page 84](#)
- [C Series Hard Disk Serial Number Label on page 85](#)
- [C Series Power Supply Serial Number Label on page 85](#)

## Displaying C Series Component Serial Numbers

Before contacting Juniper Networks to request a Return Materials Authorization (RMA), you must find the serial number on the chassis or component. To list all the chassis components and their serial numbers, enter the following command:


```
user@host> show system information
```

You can also find the serial numbers on the components.

## C Series Chassis Serial Number Label

The chassis serial number is located on the rear of the chassis (see [Figure 31 on page 84](#)).

Figure 31: C Series Chassis Serial Number Label




#### Related Documentation

- [Contacting Customer Support on page 86](#)
- [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
- [Packing the C Series Controller for Shipment on page 88](#)
- [Guidelines for Packing C Series Components for Shipment on page 89](#)

### C Series Fan Module Serial Number Label

For replacement fan modules only, the serial number is located on the top of the fan module (see [Figure 32 on page 84](#)).

Figure 32: C Series Fan Module Serial Number Label




- Related Documentation**
- [Contacting Customer Support on page 86](#)
  - [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
  - [Packing the C Series Controller for Shipment on page 88](#)
  - [Guidelines for Packing C Series Components for Shipment on page 89](#)

### C Series Hard Disk Serial Number Label

The hard disk serial number is located on the top of the hard disk (see [Figure 33 on page 85](#)).

**Figure 33: C Series Hard Disk Serial Number Label**




- Related Documentation**
- [Contacting Customer Support on page 86](#)
  - [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
  - [Packing the C Series Controller for Shipment on page 88](#)
  - [Guidelines for Packing C Series Components for Shipment on page 89](#)

### C Series Power Supply Serial Number Label

The power supply serial number is located on the side of the power supply (see [Figure 34 on page 86](#)).

Figure 34: C Series Power Supply Serial Number Label

**Related Documentation**

- [Contacting Customer Support on page 86](#)
- [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
- [Packing the C Series Controller for Shipment on page 88](#)
- [Guidelines for Packing C Series Components for Shipment on page 89](#)

## Contacting Customer Support

You can contact Juniper Networks Technical Assistance Center (JTAC) 24 hours a day, 7 days a week in one of the following ways:

- On the Web, using the Case Manager link at:

<http://www.juniper.net/support/>

- By telephone:

From the US and Canada: 1-888-314-JTAC

From all other locations: 1-408-745-9500

If contacting JTAC by phone, enter your 11-digit case number followed by the # key if this is an existing case, or press the \* key to be routed to the next available support engineer.

When requesting support from JTAC by telephone, be prepared to provide the following information:

- Your existing case number, if you have one
- Details of the failure or problem
- Type of activity being performed on the controller when the problem occurred
- Configuration data using one or more of the **show** commands

- Related Documentation**
- [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
  - [Packing the C Series Controller for Shipment on page 88](#)
  - [Guidelines for Packing C Series Components for Shipment on page 89](#)

## Returning a Hardware Component to Juniper Networks, Inc.

---

If a problem cannot be resolved by the JTAC technician, a Return Materials Authorization (RMA) is issued. This number is used to track the returned material at the factory and to return repaired or new components to the customer as needed.



**NOTE:** Do not return any component to Juniper Networks, Inc. unless you have first obtained an RMA number. Juniper Networks, Inc. reserves the right to refuse shipments that do not have an RMA. Refused shipments will be returned to the customer via collect freight.

For more information about return and repair policies, see the customer support Web page at <http://www.juniper.net/support/guidelines.html>.

For product problems or technical support issues, contact the Juniper Networks Technical Assistance Center (JTAC) using the Case Manager link at <http://www.juniper.net/support/> or at 1-888-314-JTAC (within the United States) or 1-408-745-9500 (from outside the United States).

To return a hardware component:

1. Determine the part number and serial number of the component.
2. Obtain an RMA number from the Juniper Networks Technical Assistance Center (JTAC). You can send e-mail or telephone as described above.
3. Provide the following information in your e-mail message or during the telephone call:
  - Part number and serial number of component
  - Your name, organization name, telephone number, and fax number
  - Description of the failure
4. The support representative validates your request and issues an RMA number for return of the component.
5. Pack the chassis or component for shipment.

- Related Documentation**
- [Contacting Customer Support on page 86](#)
  - [Packing the C Series Controller for Shipment on page 88](#)
  - [Guidelines for Packing C Series Components for Shipment on page 89](#)

## Packing the C Series Controller for Shipment

---

To pack the chassis for shipment:

1. Ground yourself by using an antistatic wrist strap or other device.
2. Retrieve the shipping box and packing materials in which the controller was originally shipped. If you do not have these materials, contact your Juniper Networks representative about approved packaging materials.
3. On the console or other management device connected to the controller, enter CLI operational mode and issue the **request system halt** command to halt your system.  

```
user@host> request system halt
```

Wait until a message appears on the console confirming that the operating system has halted.

For more information about the command, see the *SRC PE CLI Command Reference*.

4. Shut down power to the controller by holding down the power input switch.
5. Disconnect power from the controller.
6. Remove the cables that connect to all external devices.
7. Remove all field-replaceable units (FRUs) from the controller.
8. Remove the controller from the rack. One person should grasp the controller while a second person unscrews and removes the mounting screws from the rack. One lifter can then move the controller to the shipping container.
9. Place the controller in the shipping container.
10. Cover the controller with an ESD bag, and place the packing foam on top of and around the controller.
11. Replace the accessory box on top of the packing foam.
12. Securely tape the box closed.
13. Write the RMA number on the exterior of the box to ensure proper tracking.

### Related Documentation

- [Contacting Customer Support on page 86](#)
- [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
- [Guidelines for Packing C Series Components for Shipment on page 89](#)

## Guidelines for Packing C Series Components for Shipment

---

To pack and ship individual components:

- When you return components, make sure they are adequately protected with packing materials and packed so that the pieces are prevented from moving around inside the carton.
- Use the original shipping materials if they are available.
- Place individual components in electrostatic bags.
- Write the RMA number on the exterior of the box to ensure proper tracking.



CAUTION: Do not stack any of the controller components.

### Related Documentation

- [Contacting Customer Support on page 86](#)
- [Returning a Hardware Component to Juniper Networks, Inc. on page 87](#)
- [Packing the C Series Controller for Shipment on page 88](#)





## PART 5

# Index

- [Index on page 93](#)



# Index

## A

AC power	
connecting for the first time.....	33
electrical specifications.....	77
AC power cord	
connecting.....	58
disconnecting.....	58
electrical specifications.....	78
replacing.....	58
AC power supply	
description.....	10
power cord, connecting.....	58
power cord, disconnecting.....	58
power cord, replacing.....	58
access, management.....	4, 39
accessory box	
removing.....	25
verifying parts received.....	26
admin account	
configuring.....	43
airflow.....	12
required clearance around chassis for.....	22
altitude, acceptable range.....	75
antistatic bags and containers.....	47

## C

C Series Controller	
cabling recommendations.....	70
component overview.....	7
connecting AC power.....	33
connecting DC power.....	34
connecting external devices.....	36
declaration of conformity.....	69
emissions certifications.....	69
initially configuring.....	39
installing in a four-post rack.....	29
installing in a two-post rack.....	30
packing for shipment.....	88
powering on.....	38
safety certifications.....	69
safety guidelines.....	67

serial number location.....	83
unpacking.....	25
cables	
AC power See AC power cord	
configuring.....	70
DC power See DC power cable	
recommendations.....	70
case number, for JTAC.....	86
chassis	
serial number location.....	83
checklist for site preparation.....	19
cleaning the system.....	47
clearance, around rack.....	22
CLI (command-line interface).....	5
CLI command	
to display serial number.....	83
command-line interface.....	5
commands	
request system halt.....	88
show disk status.....	48
show system information.....	83
component	
returning.....	87
components	
cleaning.....	47
overview.....	7
packing for shipment.....	89
packing guidelines.....	89
returning.....	47
storing.....	47
configuration overview.....	39
console connector, pinouts.....	81
console management port.....	7
console port	
location of.....	9
conventions	
notice icons.....	xi
text.....	xi
cords	
AC power See AC power cord	
DC power See DC power cable	
customer support.....	xiii
contacting JTAC.....	xiii, 86

## D

data storage.....	14
DC power	
connecting for the first time.....	34
electrical specifications.....	79

DC power cable		
connecting.....	60	
disconnecting.....	59	
replacing.....	59	
specifications.....	79	
DC power cable lug		
specifications.....	79	
DC power supply		
description.....	10	
power cable, connecting.....	60	
power cable, disconnecting.....	59	
power cable, replacing.....	59	
declaration of conformity.....	69	
documentation		
comments on.....	xiii	
domain parameters		
configuring.....	41	
<b>E</b>		
earthquakes		
tested toleration for seismic.....	75	
emissions certifications.....	69	
environmental specifications.....	75	
Ethernet interfaces.....	7	
external devices		
connecting.....	36	
<b>F</b>		
fan module		
description.....	12	
installing.....	52	
removing.....	52	
replacing.....	51	
serial number location.....	84	
front panel		
description.....	8	
LEDs.....	8	
ports.....	9	
<b>G</b>		
guidelines See specifications		
<b>H</b>		
hard disk		
data storage.....	14	
description.....	13	
installing.....	54	
LEDs.....	14	
maintaining.....	48	
removing.....	53	
replacing.....	53	
serial number location.....	85	
hardware		
cable configuration.....	70	
cleaning.....	47	
packing guidelines.....	89	
returning.....	87	
hostname		
configuring.....	41	
humidity (relative), acceptable.....	75	
<b>I</b>		
installation summary.....	23	
instructions		
site preparation.....	19	
<b>J</b>		
Juniper Networks database		
configuring.....	41	
enabling.....	41	
<b>L</b>		
laser warnings.....	67	
lithium battery warning.....	65	
<b>M</b>		
maintenance guidelines		
overview.....	47	
management access.....	4	
configuring.....	40	
SNMP.....	5	
management console		
connecting.....	37	
Management Information Bases.....	5	
manuals		
comments on.....	xiii	
MIBs (Management Information Bases).....	5	
modules		
storing.....	47	
<b>N</b>		
network management		
configuring.....	39	
tools.....	4	
network port		
location of.....	9	
notice icons.....	xi	

- notices
  - class A warning.....67
  - declaration of conformity.....69
  - safety.....65
  - VCCI compliance.....67
- O**
- open-frame rack *See* rack
- out-of-band management
  - connecting.....36
- P**
- physical specifications.....73
- pinouts
  - console connector.....81
- power cable warning
  - English.....66
  - French.....66
  - Japanese.....66
- power disconnection warning.....66
- power supply
  - AC power cord, *See* AC power cord
  - DC power cable, *See* DC power cable
  - description.....10
  - installing.....57
  - LEDs.....11
  - removing.....55
  - replacing.....55
  - serial number location.....85
- power system specifications.....77
- R**
- rack
  - clearance around, required.....22
  - requirements.....20
- relative humidity, acceptable.....75
- remote access
  - configuring.....42
- request system halt command.....88
- requirements *See* specifications
- return procedure, hardware.....87
- S**
- safety certifications.....69
- safety guidelines.....67
- safety notices.....65
- seismic (earthquake).....75
- serial number
  - chassis.....83
  - fan module.....84
  - hard disk.....85
  - in output from show chassis hardware
    - command.....83
    - power supply.....85
- SFPs (small form-factor pluggable transceivers)
  - storing.....47
- show chassis hardware command.....83
- show disk status command.....48
- show system information command.....83
- site
  - environmental specifications.....75
  - preparation checklist.....19
- SNMP for management access.....5
- specifications
  - AC power cord.....78
  - clearance around rack.....22
  - DC power cable.....79
  - DC power cable lugs.....79
  - electrical
    - AC.....77
    - DC.....79
  - environmental.....75
  - physical.....73
  - power system.....77
  - thermal output.....75
- SRC data, configuring.....41
- SSH
  - configuring.....43
- static electricity, protecting against.....47
- storing, modules and components.....47
- support, technical *See* technical support
- system
  - description.....3
- T**
- technical support
  - contacting JTAC.....xiii
- telco rack *See* rack
- telnet
  - configuring.....43
- temperature, acceptable range.....75
- text conventions defined.....xi
- thermal output.....75
- tolerances.....75
- tools required
  - replacing components.....51

troubleshooting	
safety guidelines.....	67

## U

unpacking the C Series Controller.....	25
USB port.....	7
location of.....	9
USB storage device.....	8

## V

VCCI compliance.....	67
----------------------	----

## W

warning	
lithium battery.....	65
power cable.....	66
power disconnection.....	66
working with lasers.....	67