



CTP150 Platform Hardware Documentation



Modified: 2015-11-22

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Copyright © 2015, Juniper Networks, Inc. All rights reserved.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

CTP150 Platform Hardware Documentation

Copyright © 2015, Juniper Networks, Inc.
All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

	About the Documentation	xi
	Documentation and Release Notes	xi
	Documentation Conventions	xi
	Documentation Feedback	xiii
	Requesting Technical Support	xiv
	Self-Help Online Tools and Resources	xiv
	Opening a Case with JTAC	xiv
Part 1	Overview	
Chapter 1	CTP150 Platform Overview	3
	Introducing CTP Platforms	3
	CTP150 Platform Overview	3
Chapter 2	CTP150 Interface Modules	7
	CTP150 Serial Interface Module	7
	CTP150 Multiservice Interface Module	8
	CTP150 T1/E1 Interface Module	9
	CTP150 Clock Module	10
Part 2	Planning	
Chapter 3	System Specifications and Certifications	13
	CTP150 Platform Specifications	13
	CTP150 Platform Certifications	15
Chapter 4	Planning and Preparing the Site	17
	Before You Install a CTP Platform	17
	CTP150 Environmental Requirements	17
Chapter 5	Equipment Rack Requirements	19
	CTP150 Rack Requirements	19
	CTP150 Mechanical Requirements	19
	CTP150 Space Requirements	20
	CTP150 Rack Installation	20
	CTP Cabling Recommendations	20
Chapter 6	Cable and Pinout Specifications	23
	CTP150 Interface Module HD-26 Connector Cable Pinouts	23
	EIA-530 Connector Interface Signal Pinouts (DB-25 Female DCE)	23
	EIA-530 Connector Interface Signal Pinouts (DB-25 Male DTE)	25
	X.21 Connector Interface Signal Pinouts (DB-15 Female DCE)	26
	X.21 Connector Interface Signal Pinouts (DB-15 Male DTE)	27

	V.24 Connector Interface Signal Pinouts (RJ-45 Male)	28
	CTP150 Console Cable Pinouts	30
	CTP Fast Ethernet and Power Cables	31
	Fast Ethernet Cables	31
	DC Power Cables	31
Part 3	Safety	
Chapter 7	General Safety Guidelines and Warnings	35
	CTP Safety Guidelines and Warnings	35
Chapter 8	Module Installation Safety Guidelines and Warnings	37
	Safety Guidelines and Warnings for Installing CTP Modules	37
Chapter 9	Hardware Compliance	39
	Declaration of Conformity for the CTP150 Platform	39
	Federal Communications Commission (FCC) Statement	40
	FCC Requirements for Consumer Products	41
	Food and Drug Administration, Center for Devices and Radiological Health	41
	Compliance with Canadian Regulations	42
	Industry Canada Notice	42
	Industry Canada Notice CS-03	42
	Avis CS-03 d'Industrie Canada	42
	Canadian Department of Communications Explanatory Notes	43
	DOC Explanatory Notes: Equipment Attachment Limitations	43
	Notes explicatives du ministère des Communications: limites visant les accessoires	44
Part 4	Installation	
Chapter 10	Unpacking and Inspecting	47
	Before You Unpack the CTP Platform	47
	Unpacking the CTP Device	47
	Inspecting Platform Components and Accessories	48
	If You Detect or Suspect Damage	48
	Contacting Juniper Networks	49
Chapter 11	Installing the Chassis	51
	Before You Install the CTP150 Platform	51
	Installing the CTP150 Platform in Freestanding Mode	51
	Installing the CTP150 Platform in a Rack	52
Chapter 12	Installing Modules	53
	CTP150 Modules Slot and Port Numbering	53
	Protecting CTP Modules and Slots	53
	Required Tools and Safety Items for Installing CTP Modules	54
	Installing a CTP Interface Module, Processor Module, or Clock Module	55
	Removing a CTP Interface Module, Processor Module, or Clock Module	55
	Installing or Removing a CTP150 CompactFlash Card	56

Chapter 13	Cabling	57
	Cabling the CTP150 Platform Overview	57
	Required Tools, Wires, and Cables for the CTP150 Platform	57
	Cabling a CTP150 Interface Module	58
	CTP150 Fast Ethernet Cables	59
Chapter 14	Accessing the CTP150 Platform	61
	Setting Up Management Access to the CTP150 Platform	61
	Connecting Directly to the CTP150 Platform	61
	Using HyperTerminal to Access the CTP150 Device	62
	Using SSH to Access the CTP Platform	62
Chapter 15	Powering On and Initially Configuring the CTP150 Platform	65
	Before You Power On the CTP150 Device	65
	Powering On the CTP150 Device	66
	Configuring the First Boot Script for the CTP150 Device	66
	Powering Off the CTP Platform	68
Part 5	Maintenance	
Chapter 16	Maintaining Components	71
	Required Tools for Maintaining the CTP Platform	71
	Storing CTP Modules and Other Components	71
	Cleaning the CTP Platform	72
	Replacing an AC Power Supply	72
Chapter 17	Product Reclamation and Recycling	75
	Product Reclamation and Recycling Program	75
Chapter 18	Packing and Returning Hardware	77
	Return Procedure	77
	Returning CTP Products for Repair or Replacement	77
Part 6	Troubleshooting	
Chapter 19	Troubleshooting Power Failures	81
	CTP Platform Does Not Power On	81
	CTP Platform Shuts Down	81
Chapter 20	Contacting Customer Support	83
	Contacting Customer Support	83
	Locating CTP Component Serial Numbers	83
	Information You Might Need to Supply to JTAC	84
Part 7	Index	
	Index	87

List of Figures

Part 1	Overview	
Chapter 1	CTP150 Platform Overview	3
	Figure 1: CTP150 Chassis (Front View)	4
	Figure 2: CTP150 Chassis (Rear View)	5
Chapter 2	CTP150 Interface Modules	7
	Figure 3: CTP150 Serial Interface Module	7
	Figure 4: CTP150 Serial Multiservice Interface Module	8
	Figure 5: CTP150 TI/EI Interface Module	9
Part 2	Planning	
Chapter 6	Cable and Pinout Specifications	23
	Figure 6: CTP150 Console Cable Pin Configurations	30
Part 3	Safety	
Chapter 9	Hardware Compliance	39
	Figure 7: CTP150 Platform Declaration of Conformity	40
Part 5	Maintenance	
Chapter 16	Maintaining Components	71
	Figure 8: Replacing an AC Power Supply	73

List of Tables

	About the Documentation	xi
	Table 1: Notice Icons	xii
	Table 2: Text and Syntax Conventions	xii
Part 2	Planning	
Chapter 3	System Specifications and Certifications	13
	Table 3: CTP150 Platform Specifications	13
	Table 4: CTP150 Platform Certifications	15
Chapter 6	Cable and Pinout Specifications	23
	Table 5: EIA-530 Connector Interface Signals for HD-26 to Female DB-25	23
	Table 6: EIA-530 Connector Interface Signals to Male DB-25	25
	Table 7: X.21 Connector Interface Signals for HD-26 to Female DB-15	26
	Table 8: X.21 Connector Interface Signals for HD-26 to Male DB-15	27
	Table 9: V.24 Connector Interface Signals for HD-26 to RJ-45	28
	Table 10: CTP150 Series Console Cable Pinouts	30
Part 4	Installation	
Chapter 13	Cabling	57
	Table 11: Required Cables	58

About the Documentation

- Documentation and Release Notes on page xi
- Documentation Conventions on page xi
- Documentation Feedback on page xiii
- Requesting Technical Support on page xiv

Documentation and Release Notes

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

Documentation Conventions

Table 1 on page xii defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 2 on page xii defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: user@host> configure
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> show chassis alarms No alarms currently active
<i>Italic text like this</i>	<ul style="list-style-type: none"> Introduces or emphasizes important new terms. Identifies guide names. Identifies RFC and Internet draft titles. 	<ul style="list-style-type: none"> A policy <i>term</i> is a named structure that defines match conditions and actions. <i>Junos OS CLI User Guide</i> RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i>

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none">To configure a stub area, include the stub statement at the [edit protocols ospf area area-id] hierarchy level.The console port is labeled CONSOLE.
< > (angle brackets)	Encloses optional keywords or variables.	stub <default-metric <i>metric</i>>;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Encloses a variable for which you can substitute one or more values.	community name members [<i>community-ids</i>]
Indentation and braces ({ })	Identifies a level in the configuration hierarchy.	<pre>[edit] routing-options { static { route default { nexthop <i>address</i>; retain; } } }</pre>
;(semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
GUI Conventions		
Bold text like this	Represents graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none">In the Logical Interfaces box, select All Interfaces.To cancel the configuration, click Cancel.
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select Protocols>Ospf .

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can provide feedback by using either of the following methods:

- Online feedback rating system—On any page at the Juniper Networks Technical Documentation site at <http://www.juniper.net/techpubs/index.html>, simply click the stars to rate the content, and use the pop-up form to provide us with information about your experience. Alternately, you can use the online feedback form at <http://www.juniper.net/techpubs/feedback/>.

- E-mail—Send your comments to techpubs-comments@juniper.net. Include the document or topic name, URL or page number, and software version (if applicable).

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or Partner Support Service support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <http://kb.juniper.net/InfoCenter/>
- Join and participate in the Juniper Networks Community Forum: <http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.

PART 1

Overview

- [CTPI50 Platform Overview on page 3](#)
- [CTPI50 Interface Modules on page 7](#)

CHAPTER 1

CTP150 Platform Overview

- [Introducing CTP Platforms on page 3](#)
- [CTP150 Platform Overview on page 3](#)

Introducing CTP Platforms

Juniper Networks CTP Series Circuit to Packet platforms provide advanced technology and features required to reliably transport legacy time-division multiplexing (TDM) and other circuit-based applications across next-generation IP networks. CTP platforms create an IP packet flow from a serial data or analog voice connection at one end and provide the necessary processing to re-create the serial bit stream or analog signal from the received packet flow at the other end.

CTP platforms provide compact and lightweight chassis, high port density, and multiple Ethernet interfaces. Each CTP platform runs the CTP operating system (CTPOS) and can be managed by the Juniper Networks CTPView Network Management System, a secure, Web-based management tool for provisioning, managing, running diagnostics, monitoring, and reporting on all CTP devices and circuits in the network.

CTP150 Platform Overview

The Juniper Networks CTP150 Circuit to Packet platform is a 1-U high, full-rack wide chassis designed for tabletop or shelf installation. It can also be installed in a rack with the supplied rack-mounting kit. The CTP150 platform has two removable modules for serial interfaces, T1/E1 interfaces, or both, and a removable Type II CompactFlash card, but no hard drive. It is available in a removable AC-powered version only.



CAUTION: Do not remove CompactFlash cards from a running device. If you remove the card while data is being written to or copied from the CompactFlash card, data can be lost or corrupted. Therefore, we strongly recommend that you shut down the device before removing or inserting a CompactFlash card.


The front panel comprises the following components (see [Figure 1 on page 4](#)):

- Power LED—Green when power is connected.
- CompactFlash LED—Solid amber when the CompactFlash drive is in use.
- Hardware LED—Quickly blinking red for a fan failure, slowly blinking red for the removable AC power supply in use, and solid red when overheating.
- Serial console port—Provides access, by means of an RJ-45 connector, to the command-line interface (CLI).
- Two traffic interface ports—Connect the appliance to your network, receiving and forwarding traffic, over copper Ethernet 10/100/1000 interfaces.
- USB port.
- Slots for two removable interface modules in three versions:
 - 4-port serial interface
 - 4-port serial interface with multiservice daughter board
 - 4-port T1/E interface



NOTE: The module slots are numbered 0 and 1 from left to right. If only one module is used, it must be inserted in slot 0. Also, any single clock module must be connected to the CLK connector in the left-most module slot 0.

Figure 1: CTP150 Chassis (Front View)




The rear panel comprises the following components (see [Figure 2 on page 5](#)):

- Removable CompactFlash drive—The device must be powered off when you insert or remove the CompactFlash card. The CTP150 platform does not provide a hard drive, nor is it required.
- Removable AC power supply—Power input using a standard IEC power cord.
- Fans—When the device is cool, the appliance fans spin at a slower speed to reduce noise and save energy. As the device heats up, the fans run at a faster speed. In the event of fan failure, the hardware LED blinks quickly and the remaining fan or fans run at full speed until the failed fan is replaced. The fans for this model are not field replaceable units (FRUs).

[Figure 2 on page 5](#) shows the CompactFlash drive with the cover plate removed.

Figure 2: CTP150 Chassis (Rear View)



Related Documentation

- [Introducing CTP Platforms on page 3](#)

CHAPTER 2

CTP150 Interface Modules


- CTP150 Serial Interface Module on page 7
- CTP150 Multiservice Interface Module on page 8
- CTP150 T1/E1 Interface Module on page 9
- CTP150 Clock Module on page 10

CTP150 Serial Interface Module

The Juniper Networks CTP150 Circuit to Packet platform optionally includes a replaceable CTP150–IM–SER serial interface module that can be paired with another module of the same type or a T1/E1 interface module. The serial interface module also has the option of supporting two multiservice daughter cards for 4-KHz or high quality analog audio, or interranger instrumentation group (IRIG) signals. See “[CTP150 Multiservice Interface Module](#)” on page 8 for details.

The four-port serial interface module supports individual cabling for each port. The CTP150 ports have small serial ports for HD-26 26-pin connectors (see [Figure 3 on page 7](#)). The lowest-numbered port (marked 0) is at the bottom left, and the highest-numbered port (marked 3) is at the top right.

Figure 3: CTP150 Serial Interface Module



The software-selectable interfaces for the module are RS-232/V.24, EIA530/X.21, EIA530A, V.35, and IRIG. Software-selectable rates range from 50 bps to 12.228 Mbps.

The module also includes an external clock reference port for an HD-26 connector. Note that only one external clock reference is required even if there are two interface modules, serial or T1/E1.



NOTE: The external clock reference port must be the one in module slot 0, the left-most slot in the front of the CTP150 chassis.

Related Documentation

- [CTP150 Multiservice Interface Module on page 8](#)
- [CTP150 T1/E1 Interface Module on page 9](#)

CTP150 Multiservice Interface Module

The Juniper Networks CTP150 Circuit to Packet platform optionally includes a Serial Multiservice Interface module CTP150-IM-SER-MS. The module provides 4-KHz or high quality analog audio, or interranging instrumentation group (IRIG) signals.


The multiservice card enables an IRIG time code (IRIG-B) signal to be transported through an IP network. The IRIG-B standard consists of a family of rate-scaled serial time codes with formats containing up to three coded expressions or words. The IRIG-B pulse code contains one frame of 100 elements per second for the time of the year and GPS receiver status. IRIG-B encodes day of year, hour, minute, and second data on a 1-KHz carrier frequency, with an update rate of once per second.



NOTE: Only ports 0 and 2 (the bottom two ports) on the front of the serial module can be used for the multiservice features. You can configure direction, output high and low levels, and data range for this module.

The four-port serial interface module supports individual cabling for each port. The CTP150 ports have small serial ports for HD-26 26-pin connectors (see [Figure 4 on page 8](#)). The lowest-numbered port (marked 0) is at the bottom left, and the highest-numbered port (marked 3) is at the top right.

Figure 4: CTP150 Serial Multiservice Interface Module



The software-selectable interfaces for the module on all ports are RS-232/V.24, EIA530/X.21, EIA530A, V.35, and IRIG. Software-selectable rates range from 50 bps to 12.228 Mbps. On ports 0 and 2 there are also options for 4KHz (4WTO) analog, or high quality analog.

The module also includes an external clock reference port for an HD-26 connector. Note that only one external clock reference is required even if there are two interface modules, serial or T1/E1.



NOTE: The external clock reference port must be the one in module slot 0, the left-most slot in the front of the CTP150 chassis.

Related Documentation


- [CTP150 Serial Interface Module on page 7](#)
- [Serial Multiservice Interface Module Overview](#)

CTP150 T1/E1 Interface Module

The Juniper Networks CTP150 Circuit to Packet platform optionally includes a replaceable CTP150-IM-4P-T1E1 interface module that can be paired with another module of the same type or a serial interface module.

The four-port T1/E1 interface module supports individual cabling for each port. The CTP150 ports have T1/E1 ports for RJ-48 connectors (see [Figure 5 on page 9](#)). The highest-numbered port (labeled **3**) is on the left, and the lowest-numbered port (labeled **0**) is at the right, with the **CLK** port still farther to the right.

Figure 5: CTP150 T1/E1 Interface Module



The software-selectable T1/E1 interfaces for the module are T1, E1, fractional T1, and fractional E1. CSU options, encoding, and encapsulation are also software-selectable.

The module also includes an external clock reference port for an RJ-48 connector. Note that only one external clock reference is required even if there are two interface modules, serial or T1/E1.

If you want to use an external clock as node reference, then the clock must be connected to module slot **0**. Slot 0 is the left module slot.



NOTE: The external clock reference port must be the one in module slot 0, the left-most module slot in the front of the CTP150 chassis.

Related Documentation

- [CTP150 Serial Interface Module on page 7](#)
- [CTP150 Multiservice Interface Module on page 8](#)
- [CTP150 Interface Module HD-26 Connector Cable Pinouts on page 23](#)
- [CTP150 Console Cable Pinouts on page 30](#)

CTP150 Clock Module

Clock interface modules provide clock distribution between modules when the backplane is in use by voice applications. For the CTP150 model, the serial and T1/E1 interfaces each have a clock port, although only one port needs to be used for both interfaces. One port is of the HD-26 connector type, and the other is of the RJ-45 connector type.



NOTE: The external clock reference port must be connected to any module that is in slot 0, the left-most module slot on the chassis.

Related Documentation

- [CTP150 Serial Interface Module on page 7](#)
- [CTP150 Multiservice Interface Module on page 8](#)
- [CTP150 T1/E1 Interface Module on page 9](#)

PART 2

Planning

- [System Specifications and Certifications on page 13](#)
- [Planning and Preparing the Site on page 17](#)
- [Equipment Rack Requirements on page 19](#)
- [Cable and Pinout Specifications on page 23](#)

CHAPTER 3

System Specifications and Certifications

- [CTPI50 Platform Specifications on page 13](#)
- [CTPI50 Platform Certifications on page 15](#)

CTPI50 Platform Specifications

Table 3: CTPI50 Platform Specifications

Category	Specification
Weight	
Chassis only	14.5 lb (6.6 kg)
Dimensions	
Chassis only	1.73 in. (4.4 cm) high
	17.24 in. (43.8 cm) wide
	14.5 in. (36.8 cm) deep
Environmental Requirements	
Ambient operating temperature	32 to 104° F (0 to 40° C)
Ambient operating humidity	5% to 90% (noncondensing)
DC Input	
Voltage	–40 to –60 VDC
Current	20A @ –60V
Power	560 W
Redundancy (input power)	Single DC line input feed
AC Input	
Power required	100–240 VAC
AC line frequency	50–60 Hz

Table 3: CTP150 Platform Specifications (*continued*)

Category	Specification
Nominal current (115V amps)	<1.0
Power	100 W
Space Requirements	3 ft. (90 cm) behind device or rack. Do not block air vents on the front or back of the device.
Airflow	Fan
Safety Agency Certification	<ul style="list-style-type: none"> • AS/NZS 60950.1-2003 Safety of Information Technology Equipment • CAN/CSA-C22.2 No. 60950-1 (2007) Information Technology Equipment - Safety • EN 60950-1 (2005) Information Technology Equipment - Safety • IEC 60950-1 (2005) Information Technology Equipment - Safety (All country deviations) • Low Voltage Directive (2006/95/EC) • UL 60950-1 (1st Ed.) Information Technology Equipment - Safety
Electromagnetic Emissions Agency Certification	<ul style="list-style-type: none"> • AS/NZS CISPR 22:2004 • BSMI CNS 13438 and NCC C6357 Taiwan Radiated Emissions • EMC Directive (89/336/EEC) • EN 300 386 V1.3.3 (2005) Telecom Network Equipment - EMC requirements • EN 55022 Class A (2006) European Radiated Emissions • EN 55024 +A1+A2 (1998) Information Technology Equipment Immunity Characteristics • EN-61000-3-2 (2006) Power Line Harmonics (2006) Power Line Harmonics • EN-61000-3-3 +A1 +A2 +A3 (1995) Power Line Voltage Fluctuations • EN-61000-4-2 +A1 +A2 (1995) Electrostatic Discharge • EN-61000-4-3 +A1+A2 (2002) Radiated Immunity • EN-61000-4-4 (2004) Electrical Fast Transients • EN-61000-4-5 (2006) Surge • EN-61000-4-6 (2007) Immunity to Conducted Disturbances • ETSI 300-386, Telecommunication Network Equipment; ElectroMagnetic Compatibility (EMC) requirements • FCC Part 15 Class A (2007) USA Radiated Emissions • IECS-03 Issue 3 Class A • VCCI Class A (2007) Japanese Radiated Emissions

CTPI50 Platform Certifications

Table 4: CTPI50 Platform Certifications

Category	Specification
Safety Agency Certification	<ul style="list-style-type: none"> • AS/NZS 60950.1-2003 Safety of Information Technology Equipment • CAN/CSA-C22.2 No. 60950-1 (2007) Information Technology Equipment - Safety • EN 60950-1 (2005) Information Technology Equipment - Safety • IEC 60950-1 (2005) Information Technology Equipment - Safety (All country deviations) • Low Voltage Directive (2006/95/EC) • UL 60950-1 (1st Ed.) Information Technology Equipment - Safety
Electromagnetic Emissions Agency Certification	<ul style="list-style-type: none"> • AS/NZS CISPR 22:2004 • BSMI CNS 13438 and NCC C6357 Taiwan Radiated Emissions • EMC Directive (89/336/EEC) • EN 300 386 V1.3.3 (2005) Telecom Network Equipment - EMC requirements • EN 55022 Class A (2006) European Radiated Emissions • EN 55024 +A1+A2 (1998) Information Technology Equipment Immunity Characteristics • EN-61000-3-2 (2006) Power Line Harmonics (2006) Power Line Harmonics • EN-61000-3-3 +A1 +A2 +A3 (1995) Power Line Voltage Fluctuations • EN-61000-4-2 +A1 +A2 (1995) Electrostatic Discharge • EN-61000-4-3 +A1+A2 (2002) Radiated Immunity • EN-61000-4-4 (2004) Electrical Fast Transients • EN-61000-4-5 (2006) Surge • EN-61000-4-6 (2007) Immunity to Conducted Disturbances • EN-61000-4-11 (2004) Voltage Dips and Sags • ETSI 300-386, Telecommunication Network Equipment; ElectroMagnetic Compatibility (EMC) requirements • FCC Part 15 Class A (2007) USA Radiated Emissions • IECS-03 Issue 3 Class A • VCCI Class A (2007) Japanese Radiated Emissions

CHAPTER 4

Planning and Preparing the Site

- [Before You Install a CTP Platform on page 17](#)
- [CTP150 Environmental Requirements on page 17](#)

Before You Install a CTP Platform

Before you install a Juniper Networks CTP Circuit to Packet platform:

- Verify that the electrical supply meets all power requirements. See the system specifications for the applicable CTP model.
- Verify that the site meets all environment specifications. Refer to the environmental requirements and the system specifications for the applicable CTP model.
- Verify that the cables you plan to use meet the specifications, and review the cabling recommendations.
- Verify the operation of all telephone circuits, digital services, and T1 facilities required for installation.
- Ensure that all IP requirements are met, such as IP addresses, subnet masks, and any specific routing protocol information.

CTP150 Environmental Requirements

See the “[CTP150 Platform Specifications](#)” on [page 13](#) for complete environmental specifications.

Choose a location for the device that is dry, relatively dust free, well ventilated, and air conditioned. If you install equipment in a rack, be sure that the floor is capable of supporting the combined weight of the rack and the installed equipment. Place the device in a location with sufficient access to power and network cables.

Like other network devices, the device generates a significant amount of heat. You must provide a balanced environment so that the device performs properly and safely. See the individual system specifications for acceptable ranges of temperature and humidity.

Be sure to allow enough space around the device for adequate ventilation. Inadequate ventilation can cause the device to overheat.



.....

CAUTION: Do not block the air vents on the device. Otherwise, the device might overheat.

.....

**Related
Documentation**

- [Before You Install a CTP Platform on page 17](#)

CHAPTER 5

Equipment Rack Requirements

- [CTP150 Rack Requirements on page 19](#)
- [CTP150 Mechanical Requirements on page 19](#)
- [CTP150 Space Requirements on page 20](#)
- [CTP150 Rack Installation on page 20](#)
- [CTP Cabling Recommendations on page 20](#)

CTP150 Rack Requirements

When allocating equipment rack space, consider the following:

- Type of equipment racks recommended for the system
- Number of equipment racks required to hold your current system configuration
- Future expansion

Make sure that your distribution rack meets basic mechanical and space requirements and complies with conventional standards. In the United States, use *EIA-310-D Cabinets, Racks, Panels, and Associated Equipment, September 1992*.

Related Documentation

- [CTP150 Mechanical Requirements on page 19](#)
- [CTP150 Space Requirements on page 20](#)
- [CTP150 Rack Installation on page 20](#)

CTP150 Mechanical Requirements

Follow these mechanical requirements for your rack:

- Select from the following rack options:
 - Two-post rack—a freestanding enclosed cabinet with two mounting posts in the front
 - Telco-type rack—two adjacent mounting posts that you must secure to the floor or an overhead structure

- Four-post rack—a freestanding open rack, either open or closed
- The rack must have at least two mounting posts.
- The distance between the mounting holes in the two posts must be 18.31 in. +/- .063 in., as specified in the EIA-310-D document.
- An optional mounting kit is available for midchassis mounting. Contact your Juniper Networks sales representative for more information.

Related Documentation

- [CTP150 Rack Requirements on page 19](#)
- [CTP150 Space Requirements on page 20](#)
- [CTP150 Rack Installation on page 20](#)

CTP150 Space Requirements

If you use an enclosed rack for the device, ensure that there is a minimum of 3 in. of clearance between the inner side wall and the system. This clearance space ensures adequate air flow.

Related Documentation

- [CTP150 Rack Requirements on page 19](#)
- [CTP150 Mechanical Requirements on page 19](#)
- [CTP150 Rack Installation on page 20](#)

CTP150 Rack Installation

To confirm proper equipment rack installation, verify the following:

- Racks are installed and electrically grounded according to manufacturer instructions.
- Equipment racks are anchored to the floor and, when possible, anchored to the ceiling as well.
- Equipment rack installations comply with applicable local, state, and national codes.

Related Documentation

- [CTP150 Rack Requirements on page 19](#)
- [CTP150 Mechanical Requirements on page 19](#)
- [CTP150 Space Requirements on page 20](#)

CTP Cabling Recommendations

We suggest that you comply with the following recommendations:

- Ensure that cable distance and rate limits meet IEEE-recommended maximum speeds and distances for signaling purposes. For information about attenuation and power loss in optical fiber cables see:

- ANSI T1.646a-1997 Telecommunications – Broadband ISDN - Physical Layer Specification for User-Network Interfaces Including DS1/ATM (1997)
- ANSI T1.646-1995 Telecommunications – Broadband ISDN - Physical Layer Specification for User-Network Interfaces Including DS1/ATM (1995)
- Ensure that power cables deliver sufficient power to the device.
- Attach laser fiber connectors only to Class 1 laser devices in accordance with IEC 60825-1, Safety of Laser Products - Part 1.
- Route cables so that they do not restrict ventilation or airflow.
- Route cables so that modules and field-replaceable units are easily accessible.
- Route cables in a logical direction to prevent loss of connectivity to other equipment in the rack, associated equipment in adjacent racks, or to the backbone network.
- Consider using cable-management brackets to keep network cables untangled and orderly and to prevent cables from hindering access to other slots.

For additional cable recommendations, consult the document *GR-63-CORE: Network Equipment Building System (NEBS) Requirements: Physical Protection, Issue 2, April 2002*.

Cable and Pinout Specifications

- [CTPI50 Interface Module HD-26 Connector Cable Pinouts on page 23](#)
- [CTPI50 Console Cable Pinouts on page 30](#)
- [CTP Fast Ethernet and Power Cables on page 31](#)

CTPI50 Interface Module HD-26 Connector Cable Pinouts

The CTP150 device has five separate EIA-530 cabling options for the serial interface module, with a male HD-26 connector on the module end and the following connectors on the DCE or DTE end:

- Female DB-25 connector on the DCE end for EIA-530/RS-422/V.11, RS-232/V.24, V.35
- Male DB-25 connector on the DTE end for EIA-530/RS-422/V.11, RS-232/V.24, V.35
- Female DB-15 connector on the DCE end for X.21
- Male DB-15 connector on the DTE end for X.21
- RJ-45 connector for Radio V.24 Sync interface

The pinouts for these connections have different configurations for EIA-530, RS-232, voice, and T1 interface signals.

- [EIA-530 Connector Interface Signal Pinouts \(DB-25 Female DCE\) on page 23](#)
- [EIA-530 Connector Interface Signal Pinouts \(DB-25 Male DTE\) on page 25](#)
- [X.21 Connector Interface Signal Pinouts \(DB-15 Female DCE\) on page 26](#)
- [X.21 Connector Interface Signal Pinouts \(DB-15 Male DTE\) on page 27](#)
- [V.24 Connector Interface Signal Pinouts \(RJ-45 Male\) on page 28](#)

EIA-530 Connector Interface Signal Pinouts (DB-25 Female DCE)

[Table 5 on page 23](#) lists the EIA-530 interface signal pinouts for the HD-26 connector to the female DB-25 connector for the CTP150 platform.

Table 5: EIA-530 Connector Interface Signals for HD-26 to Female DB-25

HD-26 Pin	DB-25 Pin	Description	Circuit
1	3	Receive data (RD)—A	BB

Table 5: EIA-530 Connector Interface Signals for HD-26 to Female DB-25 (*continued*)

HD-26 Pin	DB-25 Pin	Description	Circuit
2	17	Receive timing (RT)—A	DD
3	15	Send timing (ST)—A (DCE)	DB
4	24	Transmit timing (TT)—A (DTE)	DA
5	2	Send data (SD)—A	BA
6	8	Data carrier detect (DCD)—A	CF
7	6	Data set ready (DSR)—A	CC
8	5	Clear to send (CTS)—A	CB
9	13	Clear to send (CTS)—B	CB
10	19	Request to send (RTS)—B	CA
11	4	Request to send (RTS)—A	CA
12	20	Data terminal ready (DTR)—A	CD
13	18	Local loopback (LL)	LL
14	16	Receive data (RD)—B	BB
15	9	Receive timing (RT)—B	DD
16	12	Send timing (ST)—B (DCE)	DB
17	11	Transmit timing (TT)—B (DTE)	DA
18	14	Clear to send (CTS)—B	BA
19	10	Data carrier detect (DCD)—B	CF
20	22	Data set ready (DSR)—B	CC
21	21	Remote loopback (RL)	RL
22	25	Test mode (TM)	TM
23	—	—	—
24, 26	7	Signal ground (GND)	Ground
25	23	Data terminal ready (DTR)—B	CD

EIA-530 Connector Interface Signal Pinouts (DB-25 Male DTE)

Table 6 on page 25 lists the EIA-530 interface signal pinouts for the HD-26 connector to the male DB-25 connector for the CTP150 platform.

Table 6: EIA-530 Connector Interface Signals to Male DB-25

HD-26 Pin	DB-25 Pin	Description
1	2	Transmit data—A
2	24	Transmit timing—A (DTE)
3	15	Send timing—A (DCE)
4	17	Receive timing—A
5	3	Receive data—A
6	8	Data carrier detect—A
7	20	Data terminal ready—A
8	4	Request to send—A
9	19	Request to send—B
10	13	Clear to send—B
11	5	Clear to send—A
12	6	Data set ready—A
13	18	Local loopback
14	14	Transmit data—B
15	11	Transmit timing—B (DTE)
16	12	Send timing—B (DCE)
17	9	Receive timing—B
18	16	Receive data—B
19	10	Data carrier detect—B
20	23	Data terminal ready—B
21	25	Test mode

Table 6: EIA-530 Connector Interface Signals to Male DB-25 (*continued*)

HD-26 Pin	DB-25 Pin	Description
22	21	Remote loop
23	—	—
24, 26	7	Ground
25	22	Data set ready—B

X.21 Connector Interface Signal Pinouts (DB-15 Female DCE)

Table 7 on page 26 lists the X.21 interface signal pinouts for the HD-26 connector to the female DB-15 connector for the CTP150 platform.

Table 7: X.21 Connector Interface Signals for HD-26 to Female DB-15

HD-26 Pin	DB-15 Pin	Description
1	4	Receive—A
2	6	Signal timing—A
3	—	—
4	7	Byte timing—A
5	2	Transmit—A
6	—	—
7	—	—
8	5	Indication—A
9	12	Indication—B
10	10	Control—B
11	3	Control—A
12	—	—
13	—	—
14	11	Receive—B
15	13	Signal timing—B

Table 7: X.21 Connector Interface Signals for HD-26 to Female DB-15 (*continued*)

HD-26 Pin	DB-15 Pin	Description
16	—	—
17	14	Byte timing—B
18	9	Transmit—B
19	—	—
20	—	—
21	—	—
22	—	—
23	—	—
24, 26	8	Ground
25	—	—

X.21 Connector Interface Signal Pinouts (DB-15 Male DTE)

Table 8 on page 27 lists the X.21 interface signal pinouts for the HD-26 connector to the male DB-15 connector for the CTP150 platform.

Table 8: X.21 Connector Interface Signals for HD-26 to Male DB-15

HD-26 Pin	DB-15 Pin	Description
1	2	Transmit—A
2	7	Byte timing—A
3	—	—
4	6	Signal timing—A
5	4	Receive—A
6	—	—
7	—	—
8	3	Control—A
9	10	Control—B

Table 8: X.21 Connector Interface Signals for HD-26 to Male DB-15 (*continued*)

HD-26 Pin	DB-15 Pin	Description
10	12	Indication—B
11	5	Indication—A
12	—	—
13	—	—
14	9	Transmit—B
15	14	Byte timing—B
16	—	—
17	13	Signal timing—B
18	11	Receive—B
19	—	—
20	—	—
21	—	—
22	—	—
23	—	—
24, 26	8	Ground
25	—	—

V.24 Connector Interface Signal Pinouts (RJ-45 Male)

Table 9 on page 28 lists the V.24 interface signal pinouts for the HD-26 connector to the male RJ-45 connector for the CTP150 platform.

Table 9: V.24 Connector Interface Signals for HD-26 to RJ-45

HD-26 Pin	RJ-45 Pin	Description
1	5	TX
2	1	RCLK
3	3	TCLK

Table 9: V.24 Connector Interface Signals for HD-26 to RJ-45 (*continued*)

HD-26 Pin	RJ-45 Pin	Description
5	6	RX
6	2	CD
8	7	CTS
11	8	RTS
24, 26	4	GND

- Related Documentation**
- [CTP150 Console Cable Pinouts on page 30](#)
 - [CTP Fast Ethernet and Power Cables on page 31](#)


CTP150 Console Cable Pinouts

The console connector to the CTP150 platform is a standard RJ-45 to DB-9 adapter cable. [Figure 6 on page 30](#) displays the console cable pin configurations for CTP150 device. On the left is the RJ-45 connector, and on the right is the DB-9 connector with the pin numbering indicated.

The console connections are configured to the following parameters:

- Speed: 9600 bps
- Data bits: 8
- Stop bits: 1
- Flow control: Xon/Xoff
- Parity: none

Figure 6: CTP150 Console Cable Pin Configurations



[Table 10 on page 30](#) lists console cable pinouts for the CTP150 device based on the pin configurations.

Table 10: CTP150 Series Console Cable Pinouts

CTP RJ-45 Pin	Console DB-9 Pin
1 RTS	8 CTS
2 DTR	6 DSR
3 TXD	2 RXD
4 GND	5 GND
5 GND	5 GND
6 RXD	3 TXD
7 DSR	4 DTR
8 CTS	7 RTS

Related • [CTP Fast Ethernet and Power Cables on page 31](#)

Documentation

CTP Fast Ethernet and Power Cables ---

- [Fast Ethernet Cables on page 31](#)
- [DC Power Cables on page 31](#)

Fast Ethernet Cables

The Ethernet connection is a standard RJ-45 connector. Typically, a straight-through cable is used to connect to a switch, and a crossover cable is used to connect to a router.

DC Power Cables

For CTP chassis with DC power options, we recommend 18-AWG power cables.

PART 3

Safety

- [General Safety Guidelines and Warnings on page 35](#)
- [Module Installation Safety Guidelines and Warnings on page 37](#)
- [Hardware Compliance on page 39](#)

CHAPTER 7

General Safety Guidelines and Warnings

- CTP Safety Guidelines and Warnings on page 35

CTP Safety Guidelines and Warnings

For your safety, before installing the device, review all safety warnings in this section.



WARNING: The recommended maximum ambient temperature is 40°C (104°F). For safe operation take into consideration the internal temperature within the rack.



WARNING: Install equipment in the rack from the bottom upward. Doing this helps maintain the stability of the rack and reduces the chance of the rack tipping over.



WARNING: Do not insert any metal object, such as a screwdriver, into an open slot or the backplane. Doing so can cause electric shock and serious burns.



WARNING: For the larger CTP series devices, three people are required to install the device in a rack: two to lift the device into position and one to screw it to the rack.



WARNING: Connect the device or rack to ground (earth), and ensure that a reliable grounding path is maintained in the rack.



WARNING: Do not work on the device or connect or disconnect cables during lightning activity.



WARNING: Be sure that circuit breakers for the power source are in the OFF position before attaching power cables.



WARNING: Before servicing the device, turn off the power.



WARNING: Remove jewelry (including rings, necklaces, and watches) before working on equipment that is connected to power lines. Metal objects heat up when connected to power and ground and can cause serious burns or become welded to the terminals.



CAUTION: Evaluate the overall loading of the branch circuit before you install any equipment into a rack.

**Related
Documentation**

- [Federal Communications Commission \(FCC\) Statement on page 40](#)
- [FCC Requirements for Consumer Products on page 41](#)
- [Food and Drug Administration, Center for Devices and Radiological Health on page 41](#)
- [Compliance with Canadian Regulations on page 42](#)
- [Before You Install a CTP Platform on page 17](#)

CHAPTER 8

Module Installation Safety Guidelines and Warnings

- [Safety Guidelines and Warnings for Installing CTP Modules on page 37](#)

Safety Guidelines and Warnings for Installing CTP Modules

Before and during the installation process, observe the following warnings:



WARNING: Do not work on the device or connect or disconnect cables during lightning activity.



WARNING: Be sure circuit breakers for the power source are in the OFF position before attaching power cables.



WARNING: Remove jewelry (including rings, necklaces, and watches) before working on equipment that is connected to power lines. Metal objects heat up when connected to power and ground and can cause serious burns or become welded to the terminals.



WARNING: Do not insert any metal object, such as a screwdriver, into an open slot or the midplane. Doing so can cause electric shock and serious burns.



WARNING: Never attempt to repair parts of modules yourself. Only trained customer service personnel are authorized to service parts. Call Juniper Networks Customer Service to make arrangements to return defective modules for repair.

**Related
Documentation**

- [Required Tools and Safety Items for Installing CTP Modules on page 54](#)
- [Federal Communications Commission \(FCC\) Statement on page 40](#)
- [FCC Requirements for Consumer Products on page 41](#)
- [Food and Drug Administration, Center for Devices and Radiological Health on page 41](#)
- [Compliance with Canadian Regulations on page 42](#)

CHAPTER 9

Hardware Compliance

- Declaration of Conformity for the CTP150 Platform on page 39
- Federal Communications Commission (FCC) Statement on page 40
- FCC Requirements for Consumer Products on page 41
- Food and Drug Administration, Center for Devices and Radiological Health on page 41
- Compliance with Canadian Regulations on page 42

Declaration of Conformity for the CTP150 Platform

Figure 7 on page 40 shows the Declaration of Conformity for the CTP150 platform.

Figure 7: CTP150 Platform Declaration of Conformity



Declaration of Conformity
R&TTE Directive 1999/5/EC
Low Voltage Directive 2006/95/EC
EMC Directive 2004/108/EC
 according to EN 45014



Juniper Networks, Inc.
 1194 N. Mathilda Ave
 Sunnyvale, CA 94089 USA

declares under our sole responsibility that the product:

CTP150

is in conformity with the provisions of the Low Voltage Directive 2006/95/EC, EMC Directive 2004/108/EC and R&TTE Directive 1999/5/EC. The conformity has been assessed according to the procedure detailed in Annex II of the R&TTE Directive.

The following harmonized standards were applied:

EMC	EN 300 386 v1.3.3: 2005
	EN 55022 Class A: 2006
	EN 55024 +A1+A2: 1998
Safety	EN 60950-1: 2001 1st Edition

This product carries the CE Mark, which was first affixed in 2010.

Place
 Sunnyvale, CA

Signature

Kevin Kimma
Compliance Manager
 1194 N. Mathilda Ave
 Sunnyvale, CA 94089 USA

Date
 3/5/2010

DoC No: CTP150_1

Related Documentation • [CTP150 Platform Specifications on page 13](#)

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in

a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

This equipment is designed for use with properly shielded and terminated cables. Refer to the installation sections of this manual before operation.

Reference: CFR 47, Part 15J, Sect 15.105 April 18, 1989

Caution: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- Related Documentation**
- [FCC Requirements for Consumer Products on page 41](#)
 - [Food and Drug Administration, Center for Devices and Radiological Health on page 41](#)
 - [Compliance with Canadian Regulations on page 42](#)

FCC Requirements for Consumer Products

This equipment complies with FCC rules, Part 68. On the back side of this equipment is a label that contains, among other information, the FCC Registration Number and Ringer Equivalence Number (REN) for this equipment. If requested, provide this information to your telephone company.

If this equipment causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice is not practical, you will be notified as soon as possible. You will be advised of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper operation of your equipment. If they do, you will be given advance notice to give you an opportunity to maintain uninterrupted service.

If you experience trouble with this equipment, please contact the manufacturer for warranty/repair information. The telephone company may ask that you disconnect this equipment from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

- Related Documentation**
- [Federal Communications Commission \(FCC\) Statement on page 40](#)
 - [Food and Drug Administration, Center for Devices and Radiological Health on page 41](#)
 - [Compliance with Canadian Regulations on page 42](#)

Food and Drug Administration, Center for Devices and Radiological Health

This equipment complies with 21 CFR 1040.10 and 1040.11 for the safe use of lasers.

- Related Documentation**
- [Federal Communications Commission \(FCC\) Statement on page 40](#)
 - [FCC Requirements for Consumer Products on page 41](#)
 - [Compliance with Canadian Regulations on page 42](#)

Compliance with Canadian Regulations

- [Industry Canada Notice on page 42](#)
- [Canadian Department of Communications Explanatory Notes on page 43](#)

Industry Canada Notice

- [Industry Canada Notice CS-03 on page 42](#)
- [Avis CS-03 d'Industrie Canada on page 42](#)

Industry Canada Notice CS-03

The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operation and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee that the equipment will operate to the user's satisfaction. Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Notice: The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

Avis CS-03 d'Industrie Canada

L'étiquette du ministère des Communications du Canada indique que l'appareillage est certifié, c'est-à-dire qu'il respecte certaines exigences de sécurité et de fonctionnement visant les réseaux de télécommunications. Le ministère ne garantit pas que l'appareillage

fonctionnera à la satisfaction de l'utilisateur. Avant d'installer l'appareillage, s'assurer qu'il peut être branché aux installations du service de télécommunications local. L'appareillage doit aussi être raccordé selon des méthodes acceptées. Le client doit toutefois prendre note qu'une telle installation n'assure pas un service parfait en tout temps.

Les réparations de l'appareillage certifié devraient être confiées à un service d'entretien canadien désigné par le fournisseur. En cas de réparation ou de modification effectuées par l'utilisateur ou de mauvais fonctionnement de l'appareillage, le service de télécommunications peut demander le débranchement de l'appareillage.

Pour leur propre sécurité, les utilisateurs devraient s'assurer que les mises à la terre des lignes de distribution d'électricité, des lignes téléphoniques et de la tuyauterie métallique interne sont raccordées ensemble. Cette mesure de sécurité est particulièrement importante en milieu rural.

Attention: Les utilisateurs ne doivent pas procéder à ces raccordements eux-mêmes mais doivent plutôt faire appel aux pouvoirs de réglementation en cause ou à un électricien, selon le cas.

Avis: Veuillez prendre note que pour tout appareillage supportant des lignes de type "loopstart," l'indice d'équivalence de la sonnerie (IES) assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface. La terminaison d'une interface téléphonique peut consister en une combinaison de quelques dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5. Le REN figure sur l'étiquette "FCC Rules Part 68" située sur le support du module ou à l'arrière de l'unité.

Canadian Department of Communications Explanatory Notes

- [DOC Explanatory Notes: Equipment Attachment Limitations on page 43](#)
- [Notes explicatives du ministère des Communications: limites visant les accessoires on page 44](#)

DOC Explanatory Notes: Equipment Attachment Limitations

The Canadian Department of Communications label identifies certified equipment. This certification meets certain telecommunication network protective, operational and safety requirements. The department does not guarantee that the equipment will operate to the users satisfaction.

Before installing the equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above condition may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this

equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

Notes explicatives du ministère des Communications: limites visant les accessoires

L'étiquette du ministère des Communications du Canada indique que l'appareillage est certifié, c'est-à-dire qu'il respecte certaines exigences de sécurité et de fonctionnement visant les réseaux de télécommunications. Le ministère ne garantit pas que l'appareillage fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer l'appareillage, s'assurer qu'il peut être branché aux installations du service de télécommunications local. L'appareillage doit aussi être raccordé selon des méthodes acceptées. Dans certains cas, le câblage interne du service de télécommunications utilisé pour une ligne individuelle peut être allongé au moyen d'un connecteur certifié (prolongateur téléphonique). Le client doit toutefois prendre note qu'une telle installation n'assure pas un service parfait en tout temps.

Les réparations de l'appareillage certifié devraient être confiées à un service d'entretien canadien désigné par le fournisseur. En cas de réparation ou de modification effectuées par l'utilisateur ou de mauvais fonctionnement de l'appareillage, le service de télécommunications peut demander le débranchement de l'appareillage.

Pour leur propre sécurité, les utilisateurs devraient s'assurer que les mises à la terre des lignes de distribution d'électricité, des lignes téléphoniques et de la tuyauterie métallique interne sont raccordées ensemble. Cette mesure de sécurité est particulièrement importante en milieu rural.

Attention: Les utilisateurs ne doivent pas procéder à ces raccordements eux-mêmes mais doivent plutôt faire appel aux pouvoirs de réglementation en cause ou à un électricien, selon le cas.

Related Documentation

- [Federal Communications Commission \(FCC\) Statement on page 40](#)
- [FCC Requirements for Consumer Products on page 41](#)
- [Food and Drug Administration, Center for Devices and Radiological Health on page 41](#)

PART 4

Installation

- [Unpacking and Inspecting on page 47](#)
- [Installing the Chassis on page 51](#)
- [Installing Modules on page 53](#)
- [Cabling on page 57](#)
- [Accessing the CTP150 Platform on page 61](#)
- [Powering On and Initially Configuring the CTP150 Platform on page 65](#)

CHAPTER 10

Unpacking and Inspecting

- [Before You Unpack the CTP Platform on page 47](#)
- [Unpacking the CTP Device on page 47](#)
- [Inspecting Platform Components and Accessories on page 48](#)
- [If You Detect or Suspect Damage on page 48](#)
- [Contacting Juniper Networks on page 49](#)

Before You Unpack the CTP Platform

Before you begin unpacking the device, be sure you have the following tools:

- No. 2 Phillips screwdriver
- Utility knife
- Mechanical lift, or at least two people to assist in lifting

Related Documentation

- [Unpacking the CTP Device on page 47](#)
- [Inspecting Platform Components and Accessories on page 48](#)
- [If You Detect or Suspect Damage on page 48](#)
- [Contacting Juniper Networks on page 49](#)

Unpacking the CTP Device

Depending on the device, it may be delivered boxed, bolted, and strapped to a skid. For your convenience, we recommend that you unpack the device in the location where you want to install it.



WARNING: For the larger CTP series devices, three people are required to install the device in a rack: two to lift the device into position and one to screw it to the rack.

To unpack the device:

1. Cut the two straps that secure the carton to the skid, open the carton from the top, and remove the box of accessories that sits on top of the device.
2. Unlock the four plastic clips that hold the box to the skid by squeezing them in their center and pulling out, and then lift the carton off the device.
3. Remove the three screws that attach each of the two L-brackets to the device.
4. To avoid scratching the device when removing it from the skid, detach one of the L-brackets from the skid by removing the three screws.

**Related
Documentation**

- [Before You Unpack the CTP Platform on page 47](#)
- [Inspecting Platform Components and Accessories on page 48](#)
- [If You Detect or Suspect Damage on page 48](#)
- [Contacting Juniper Networks on page 49](#)

Inspecting Platform Components and Accessories

After you remove the equipment from the shipping containers:

- Confirm the contents of each container.
- Inspect all external surfaces and external connectors for visible signs of damage.
- Inspect all accessories shipped with each unit.
- Document any damage noted during your inspection.
- Confirm that the platform has the correct number and type of modules for your ordered configuration.

**Related
Documentation**

- [Before You Unpack the CTP Platform on page 47](#)
- [Unpacking the CTP Device on page 47](#)
- [If You Detect or Suspect Damage on page 48](#)
- [Contacting Juniper Networks on page 49](#)

If You Detect or Suspect Damage

If you detect or suspect damage to any equipment:

- Contact the shipper responsible for delivery, and formally report the damage.
- Contact your Juniper Networks sales representative or reseller.

**Related
Documentation**

- [Before You Unpack the CTP Platform on page 47](#)
- [Unpacking the CTP Device on page 47](#)

- [Inspecting Platform Components and Accessories on page 48](#)
- [Contacting Juniper Networks on page 49](#)

[Contacting Juniper Networks](#)

Please contact Juniper Networks at 1-888-314-JTAC (from the United States, Canada, or Mexico) or 1-408-745-9500 (from elsewhere), or contact your sales representative if you have any questions or concerns. See [“Contacting Customer Support” on page 83](#) for complete contact information.

Related Documentation

- [Before You Unpack the CTP Platform on page 47](#)
- [Unpacking the CTP Device on page 47](#)
- [Inspecting Platform Components and Accessories on page 48](#)
- [If You Detect or Suspect Damage on page 48](#)

CHAPTER 11

Installing the Chassis

- [Before You Install the CTP150 Platform on page 51](#)
- [Installing the CTP150 Platform in Freestanding Mode on page 51](#)
- [Installing the CTP150 Platform in a Rack on page 52](#)

Before You Install the CTP150 Platform

Before installing the platform:

- Refer to the platform specifications for the particular CTP model or series.
- Have a plan for installing the device that takes into consideration future expansion.
- Have the tools and accessories needed to complete the installation.
- Read and understand the clearance requirements for the front and back of the chassis for cable routing and other unit access. See "[CTP150 Environmental Requirements](#)" on [page 17](#) for more information.
- Read and understand the clearance requirements for the top and bottom of the chassis to ensure adequate ventilation.
- Prepare the equipment racks by measuring and marking space for each device and plenum you plan to install.

Related Documentation

- [Installing the CTP150 Platform in a Rack on page 52](#)
- [Installing the CTP150 Platform in Freestanding Mode on page 51](#)

Installing the CTP150 Platform in Freestanding Mode

When installing the device on a table top or in any other freestanding mode, be sure to leave enough space around the device for adequate ventilation. Position the chassis with easy access to the connections that it needs for power, local communications, and remote communications.



WARNING: At least two people are required to lift the device. Three people are required for the heavier CTP platforms.



CAUTION: To prevent electrostatic damage to the device and its components, make sure that persons handling the device wear an antistatic device.

**Related
Documentation**

- [Before You Install the CTP150 Platform on page 51](#)
- [Installing the CTP150 Platform in a Rack on page 52](#)
- [Cabling the CTP150 Platform Overview on page 57](#)

Installing the CTP150 Platform in a Rack

To install the CTP platform in a rack, you need:

- Phillips screwdriver
- Four 10-32 x 3/8 Phillips screws for each device to be installed

Follow these guidelines:

1. Following your installation plan, use a tape measure and marking pen to measure and mark space on each equipment rack for each platform component. For horizontal spacing, follow Network Equipment Building System (NEBS) requirements.
2. With one person standing on the left side of the device and another standing on the right side, lift the device into the rack.
3. Position the device in its designated location in the equipment rack. Make sure the holes of the mounting brackets align evenly with the holes of the equipment rack on both sides.
4. Starting at the bottom of the device, secure the device in the equipment rack by using the 10-32 x 3/8 Phillips screws. Have a third person do this for the larger and heavier CTP chassis.
5. Connect the necessary cables. (See [“Cabling the CTP150 Platform Overview” on page 57](#) for instructions about installing the cables.)

**Related
Documentation**

- [Before You Install the CTP150 Platform on page 51](#)
- [Installing the CTP150 Platform in Freestanding Mode on page 51](#)
- [Cabling the CTP150 Platform Overview on page 57](#)

CHAPTER 12

Installing Modules

- [CTP150 Modules Slot and Port Numbering on page 53](#)
- [Protecting CTP Modules and Slots on page 53](#)
- [Required Tools and Safety Items for Installing CTP Modules on page 54](#)
- [Installing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)
- [Removing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)
- [Installing or Removing a CTP150 CompactFlash Card on page 56](#)

CTP150 Modules Slot and Port Numbering

The CTP150 device has removable interface modules from the front, but no removable fan trays.

In CTP150 devices, slot numbering is from left to right, 0 to 1. Any single module must be installed in slot 0, and any single clock connection must come from the port in slot 0.

CTP150 port numbering on the front panel for the serial interface module is bottom left 0, top left 1, bottom right 2, and top right 3.

Port numbering for the T1/E1 interface module is 0, 1, 2, and 3, from right to left with a clock port at the far right.

Related Documentation

- [Protecting CTP Modules and Slots on page 53](#)
- [Installing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)

Protecting CTP Modules and Slots

To prevent damage from electrostatic discharge, wear an antistatic wrist strap, and ensure proper grounding when handling components.

To protect the modules, components, and slots when installing components, observe the following guidelines:



CAUTION: When handling components, use an antistatic wrist strap connected to a proper grounding device. This action helps to protect the module from damage by electrostatic discharge.



CAUTION: Always handle a module by its edges. Do not touch the components, pins, leads, or solder connections.



CAUTION: If you meet strong resistance when attempting to seat a module using the ejectors, remove it from the chassis and confirm that the slot is designed to hold the module. Also, be sure that you have aligned the left and right edges in the correct matching module guides.



CAUTION: Be sure to cover every empty slot with a blank filler panel to protect the device from dust or other foreign substances and to ensure proper device cooling.



CAUTION: Do not discard the antistatic bag. When a module is not in use, store it in an antistatic bag.

**Related
Documentation**

- [Safety Guidelines and Warnings for Installing CTP Modules on page 37](#)
- [Required Tools and Safety Items for Installing CTP Modules on page 54](#)

Required Tools and Safety Items for Installing CTP Modules

You need the following tools to install a CTP module:

- Phillips screwdriver
- Flathead screwdriver
- ESD wrist strap or other grounding device

**Related
Documentation**

- [Safety Guidelines and Warnings for Installing CTP Modules on page 37](#)
- [Installing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)

Installing a CTP Interface Module, Processor Module, or Clock Module

To install a CTP module:

1. Ground yourself by using an antistatic wrist strap or other device, and connect it to one of the ESD grounding jacks, if available, or another grounding device.
2. Choose the slot where you want to insert the module.
3. With a Phillips screwdriver, loosen the screws that secure the blank filler panel covering the empty chassis slot, if present, and remove the filler panel.
4. Remove the module from its antistatic bag, being careful not to touch module components, pins, leads, or solder connections.
5. Verify that the ejectors are in the open position (facing outward).
6. Guide the module into the chassis by placing it between the guides of the selected slot and pushing the module until it stops.

The module stops sliding when the ejectors make contact with the chassis.



CAUTION: If you meet strong resistance when attempting to seat the module using the ejectors, remove it from the chassis, and confirm that the slot is designed to hold the component. Also, be sure that you have aligned the left and right edges in the correct matching tracks.

7. Insert the module into the midplane by simultaneously pressing both ejectors inward and exerting forward pressure on the module. The small red release buttons should click into place.
8. Tighten the module's captive screws using a Phillips screwdriver.



NOTE: Tighten the captive screws completely before installing an adjacent module so that proper electromagnetic interference (EMI) gasket compression occurs. Failure to do this can make it difficult to install adjacent modules.

9. Go to *Cabling a CTP Interface Module*.

Related Documentation

- [Removing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)

Removing a CTP Interface Module, Processor Module, or Clock Module



NOTE: We recommend that you issue the `slot disable` command from the CLI before removing a line module.



CAUTION: If you do not use the `halt` command before powering down the CTP device, the CompactFlash card might become corrupted.

To remove a CTP module:

1. Issue the **halt** command.
2. Ground yourself by using an antistatic wrist strap or other device, and connect it to an ESD grounding jack, if available, or another grounding device.
3. Use a Philips screwdriver to loosen the captive screws located at the top and bottom of the module panel.
4. If the module has ejector handles, press the red release buttons, and pull the ejector handles outward to the open position.
5. Carefully slide the module out of the chassis.
6. Place the module in its antistatic bag, being careful not to touch module components, pins, leads or solder connections.
7. Cover the empty chassis slot with a blank filler panel, and tighten the filler panel's captive screws using a Phillips screwdriver. Turn both screws several times before tightening them completely.

**Related
Documentation**

- [Installing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)

Installing or Removing a CTP150 CompactFlash Card

The CompactFlash card is installed in the rear panel of the CTP150. To remove or install the CompactFlash card:

1. Power off the unit.
2. Remove the CompactFlash face plate in the center of the rear panel by unscrewing the two retaining screws.
3. Remove or install the CompactFlash card in the flash socket.
4. Replace the face plate with the two retaining screws.

**Related
Documentation**

- [Installing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)

CHAPTER 13

Cabling

- [Cabling the CTP150 Platform Overview on page 57](#)
- [Required Tools, Wires, and Cables for the CTP150 Platform on page 57](#)
- [Cabling a CTP150 Interface Module on page 58](#)
- [CTP150 Fast Ethernet Cables on page 59](#)

Cabling the CTP150 Platform Overview

Cabling the CTP platform requires the following main tasks:

1. Familiarize yourself with the module ports, and ensure that you have the cables and wires needed to complete each cabling procedure.
2. Read and understand all safety warnings. (See [“CTP Safety Guidelines and Warnings” on page 35.](#))
3. Connect timing ports.
4. Connect grounding wires to the chassis.
5. Connect the power cables from the power source to the power supply.
6. Connect the interface modules to their appropriate network interface.

Related Documentation

- [CTP Cabling Recommendations on page 20](#)
- [Required Tools, Wires, and Cables for the CTP150 Platform on page 57](#)
- [Setting Up Management Access to the CTP150 Platform on page 61](#)
- [CTP150 Console Port Setup](#)
- [Cabling a CTP150 Interface Module on page 58](#)

Required Tools, Wires, and Cables for the CTP150 Platform

Cabling your device takes only a few minutes. You need the following items and the cables listed in [Table 11 on page 58](#) for proper installation:

- 1/8-inch flathead screwdriver
- 3/8-inch wrench or 3/8-inch nut-driver

- No. 2 Phillips screwdriver
- Ground wires—We recommend a minimum of 18-AWG ground wire for AC and DC-powered versions, if applicable.
- Two #10 keps (supplied) to connect the ground (earth) wire to the ground terminal.
- Power module wiring—We recommend a minimum of 18-AWG wire for the device with a dual stud terminal lug with 5/8-inch spacing.

Consider the distance from the connection point and the configuration of the device when determining the size of wire used.

Table 11: Required Cables

Connection	Port and Cable Used
Management connection between the processor module and the LAN	One 10/100Base-T Ethernet management port with an RJ-45 connector.
Management connection between the processor module and a management console	One RS-232 port with a DB-9 connector for VT100 management access.
Direct connections to interface modules	Cables vary depending on module.

Related Documentation

- [Cabling the CTP150 Platform Overview on page 57](#)
- [Cabling a CTP150 Interface Module on page 58](#)

Cabling a CTP150 Interface Module

To install a cable in an interface module:

1. Ground yourself by using an antistatic wrist strap or other device, and connect it to an ESD grounding jack, if available, or another grounding device.
2. Remove the dust cover that protects the cable connectors.
3. Slide the cable as far as you can into the module until it clicks into place.
4. Gently pull the cable to confirm that it is inserted correctly.
5. Go on to [“Before You Power On the CTP150 Device” on page 65](#).

Related Documentation

- [Required Tools, Wires, and Cables for the CTP150 Platform on page 57](#)
- [Setting Up Management Access to the CTP150 Platform on page 61](#)
- [CTP150 Console Port Setup](#)
- [Using SSH to Access the CTP Platform on page 62](#)

CTP150 Fast Ethernet Cables

The Ethernet connection is a standard RJ-45 connector. Typically, a straight-through cable is used to connect to a switch, and a crossover cable is used to connect to a router.

**Related
Documentation**

- [Cabling the CTP150 Platform Overview on page 57](#)
- [Required Tools, Wires, and Cables for the CTP150 Platform on page 57](#)
- [Cabling a CTP150 Interface Module on page 58](#)

Accessing the CTP150 Platform

- [Setting Up Management Access to the CTP150 Platform on page 61](#)
- [Connecting Directly to the CTP150 Platform on page 61](#)
- [Using HyperTerminal to Access the CTP150 Device on page 62](#)
- [Using SSH to Access the CTP Platform on page 62](#)

Setting Up Management Access to the CTP150 Platform

Before you power on the device for the first time, you need to physically connect a console (PC, Macintosh, or UNIX workstation) to the device's **CONSOLE** port. Through this connection, you communicate with the CTP150 device during the power-on process to set an IP address and initially configure the device.

After you configure an IP address on the CTP150 device, you can access the device remotely through the Ethernet port by running SSH from a remote console.

Related Documentation

- [Connecting Directly to the CTP150 Platform on page 61](#)
- [Using HyperTerminal to Access the CTP150 Device on page 62](#)
- [Using SSH to Access the CTP Platform on page 62](#)

Connecting Directly to the CTP150 Platform

You can connect a console terminal (PC, Macintosh, or UNIX workstation) directly to the **CONSOLE** port on the CTP150 device. Initial configuration of the CTP device requires a direct connection. Once you configure an IP address for the device, you can connect to the device remotely.

To communicate with the device through the console, you must have a terminal emulation program running on your console terminal. You can use any terminal emulation program, such as HyperTerminal. A UNIX workstation can use the emulator TIP.

To connect a console directly to the CTP150 device:

1. Connect the RJ-45 connector to the **CONSOLE** port.
2. Connect the crossover adapter connector to your console's serial port.

3. You can now power on the device. See *Powering On and Initially Configuring the CTP150 Device*.

- Related Documentation**
- [Setting Up Management Access to the CTP150 Platform on page 61](#)
 - [Using HyperTerminal to Access the CTP150 Device on page 62](#)

Using HyperTerminal to Access the CTP150 Device

If your console uses a version of Microsoft Windows (such as Windows XP or Windows NT 4.0) that supports the HyperTerminal application, you can access the device through HyperTerminal.

1. Click the **Start** button and select **Programs, Accessories, Communications, and HyperTerminal**.
2. In the HyperTerminal window, select **HyperTerminal**.
3. In the Connection Description dialog box, enter a name for your device in the Name field.
4. Select any icon to represent your terminal emulation, and click **OK**.
5. In the Connect To dialog box, in the Connect using field, select the appropriate COM port to use (for example, **COM1**), and click **OK**.
6. In the COM1 Properties dialog box, select the following settings:
 - Bits per second: 9600
 - Data bits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: Xon/Xoff
7. Click **OK**.

- Related Documentation**
- [Setting Up Management Access to the CTP150 Platform on page 61](#)
 - [Connecting Directly to the CTP150 Platform on page 61](#)

Using SSH to Access the CTP Platform

When you have configured an IP address for the CTP150 device, you can run SSH from a remote host to access the device through its Ethernet port. To connect the Ethernet port to the network:

1. Connect an Ethernet RJ-45 cable to one of the two Ethernet ports on the front panel of the CTP150 chassis.
2. Connect the other end of the cable to the appropriate Ethernet network for an out-of-band connection.



.....

CAUTION: Do not change the IP address for the Ethernet interface that you are using to communicate with the device. If you change the address, you will lose the SSH session.

.....

**Related
Documentation**

- [Setting Up Management Access to the CTP150 Platform on page 61](#)

CHAPTER 15

Powering On and Initially Configuring the CTP150 Platform

- [Before You Power On the CTP150 Device on page 65](#)
- [Powering On the CTP150 Device on page 66](#)
- [Configuring the First Boot Script for the CTP150 Device on page 66](#)
- [Powering Off the CTP Platform on page 68](#)

Before You Power On the CTP150 Device

Before powering on the device, make sure you complete the following tasks. See the appropriate sections for information about these tasks.



WARNING: Be sure the power source is turned off and the device is turned off before you perform the installation tasks.

- [Installing a CTP Interface Module, Processor Module, or Clock Module on page 55](#)
- [Setting Up Management Access to the CTP150 Platform on page 61](#)

Related Documentation

- [Powering On the CTP150 Device on page 66](#)
- [Powering Off the CTP Platform on page 68](#)

Powering On the CTP150 Device

In this procedure we assume that the device is already connected to a power source.

For specifications on the electrical requirements for the device, see [“CTP150 Platform Specifications” on page 13](#).



CAUTION: Evaluate the overall loading of the branch circuit before you install any equipment into a rack.

To power on the device:

1. Verify that the power source is operational.
2. Inspect all grounding and power connections to the device chassis.
3. Confirm that all cable connections are secure.
4. Switch any available power switches to ON.
5. Monitor LEDs to verify that the device is booting properly.

The device goes through a boot process. When a prompt appears on the console, the device is ready to be configured. If the device is new, it boots to a first boot script. If the device is already operational, it boots to a login prompt.

During initial power-on, the components of the platform run boot code, go through a series of self-diagnostic tests, and synchronize with each other.

When the tests are complete, use the LEDs on each module to determine the status of the device. Observe the module LEDs on the front or rear components.

- Related Documentation**
- [Before You Power On the CTP150 Device on page 65](#)
 - [Powering Off the CTP Platform on page 68](#)

Configuring the First Boot Script for the CTP150 Device

For the first-time boot process, there is a series of login prompts that require the following settings:

1. Default username (**ctp**) and password (**ctp**). (We recommend that you change the root password after entering the default.)
2. Supported protocol or protocols—(0) IPv4 only, (1) IPv6 only, or (2) IPv4 and IPv6. Enter the appropriate number value.
3. Default interface—From the list of available devices, such as eth0 and eth1 (or more), enter the one to be the default.
4. Hostname of the device.

5. IP address of the interface—Enter the IP address of the selected interface, or accept the loopback address (127.0.0.1) by default.
6. Netmask of the IP address—Enter the netmask (such as 255.255.255.128), or accept 255.255.255.0 as the default.
7. Gateway IP address—Enter the IP address of the gateway, or accept the local address (127.0.0.1) as the default
8. Maximum transmission unit (MTU)—Enter the MTU in bytes, or accept 1500 bytes as the default.
9. Static routes added to the default interface, if any.
10. Date and time GMT (more precisely, UTC)—Enter these separately in digits for the month, day, hour, and minutes in Coordinated Universal Time (UTC), or accept the internal settings.

The device goes into startup mode.

For example:

```

**** First boot of this flash. Setting up basic system configuration. ****
***** Setting up the root password *****
Changing root's password!
Changing password for user root.
New password:
Retype new password:
BAD PASSWORD: it is too short
passwd: all authentication tokens updated successfully.
Backing up /etc to nonvolatile storage..
***** Setting up the network *****
Configure supported protocols:
0) IPv4 Only
1) IPv6 Only
2) IPv4 & IPv6

```

Please select your option (rtn for 0):

There are 2 ethernet devices available for use. The default device is the device through which the default gateway can be accessed. Ctp circuits can run over any ethernet device, default or not. A default device must be configured, other devices may be configured and enabled, or disabled. Here is a list to the available devices and their descriptions:

```

eth0: 10/100/1000 Copper (right)
eth1: 10/100/1000 Copper (left)

```

What device would you like to make the IPV4 default device? (rtn for eth0):
 OK, eth0 (10/100/1000 Copper (right)) will be configured as IPV4 default device.

Please input the hostname (return for (none)): ctp150bot

```

===== Configuration for eth0 (default device):
Please input the ip (return for 127.0.0.1): 10.3.206.10
Please input the netmask (return for 255.255.255.0): 255.255.0.0
Please input the gateway (return for 127.0.0.1): 10.3.0.1
Please input the mtu in bytes (return for 1500):

```

Add route to interface eth0 [n]

```
=====
=== OS Security level set to LOW ===
=====
```

```
Backing up /etc to nonvolatile storage..
Backing up /usr/local to nonvolatile storage..
***** Setting up date/time *****
Setting the date (GMT). Please input the year [2008-2020] (return for 2010):

Setting the date (GMT). Please input the month [1-12] (return for 11):

Setting the date (GMT). Please input the day [1-31] (return for 14):

Setting the date (GMT). Please input the hour [0-23] (return for 16):

Setting the date (GMT). Please input the minute [0-59] (return for 41):

INIT: Entering runlevel: 3
Entering non-interactive startup
```

Related Documentation • [Powering On the CTP150 Device on page 66](#)

Powering Off the CTP Platform

Use one of the following methods to power off the device:

- Using the **halt** Command at the CTP Command Line
- Using the CTP Menu

To power off the CTP platform from the CTP command line:

Before you power off the device, enter the **halt** command to temporarily suspend the device's operation.



CAUTION: If you do not use the **halt** command before removing or powering down the device, the device's CompactFlash card might become corrupted.

To power off the device from the CTP Menu:

1. From the Main Menu, select **5) Node Operations**.
2. From the Node Operations Menu, select **10) Powerdown Node**.

PART 5

Maintenance

- [Maintaining Components on page 71](#)
- [Product Reclamation and Recycling on page 75](#)
- [Packing and Returning Hardware on page 77](#)

CHAPTER 16

Maintaining Components

- [Required Tools for Maintaining the CTP Platform on page 71](#)
- [Storing CTP Modules and Other Components on page 71](#)
- [Cleaning the CTP Platform on page 72](#)
- [Replacing an AC Power Supply on page 72](#)

Required Tools for Maintaining the CTP Platform

You need the following tools and other items to replace platform components:

- Flathead and Phillips screwdrivers
- Insulated adjustable wrench
- Antistatic wrist strap
- Antistatic bags (or other protective packaging to hold components)
- Plastic boots or other protective covers for fiber-optic connectors

Related Documentation

- [Storing CTP Modules and Other Components on page 71](#)
- [Cleaning the CTP Platform on page 72](#)

Storing CTP Modules and Other Components

Retain the packaging in which a module or other component was shipped, and use this packaging to store the item. Modules are shipped in antistatic bags and protective packaging. Components, such as transceivers and CompactFlash cards, are shipped in antistatic plastic containers within an antistatic padded box.



CAUTION: Failure to store electronic modules and components correctly can lead to damage of these items.

Follow these guidelines for storing modules and other components:

- Store each module in a separate antistatic bag.
- Store other components in an antistatic plastic container. Some of these containers can accommodate several components in separate compartments.
- Do not store multiple modules or other components in an antistatic bag or container where they can touch other items.
- (Optional) Store the item in its antistatic bag or container within the protective packaging or padded box that the item was shipped in.

**Related
Documentation**

- [Required Tools for Maintaining the CTP Platform on page 71](#)
- [Cleaning the CTP Platform on page 72](#)

Cleaning the CTP Platform

Dust is attracted to the area where the air intake vents are located. Clean the area with a dry cloth every few weeks to prevent excessive accumulation of dust. This cleaning helps to maintain the efficiency of the cooling system and to prevent damage to electronic components.



WARNING: Do not insert any metal object, such as a screwdriver, or place your hand into an open slot or the backplane when the device is on. Remove jewelry (including rings, necklaces, and watches) before working on equipment that is connected to power lines. These actions prevent electric shock and serious burns.



CAUTION: When cleaning the device, wear an antistatic wrist strap connected to an ESD grounding jack. This action helps to protect modules from damage by electrostatic discharge.

**Related
Documentation**

- [Required Tools for Maintaining the CTP Platform on page 71](#)
- [Storing CTP Modules and Other Components on page 71](#)

Replacing an AC Power Supply


Before you remove a power supply, be aware of the following:

- The minimum number of power supplies must be present in the router at all times.
- To maintain proper cooling and prevent thermal shutdown of the operating power supply unit, each power supply slot must contain either a power supply or a blank panel. If you remove a power supply, you must install a replacement power supply or a blank panel shortly after the removal.
- After powering off a power supply, wait at least 60 seconds before turning it back on.

To remove an AC power supply (see [Figure 8 on page 73](#) for a representative AC power supply at the rear of the chassis):

1. Switch off the dedicated customer site circuit breaker for the power supply, and remove the power cord from the AC power source. Follow the instructions for your site.
2. Attach an electrostatic discharge (ESD) grounding strap to your bare wrist, and connect the strap to one of the ESD points on the chassis.
3. If the chassis has a power switch, move it to the off (O) position.
4. Unplug the power cord from the power source receptacle.
5. Unplug the power cord from the appliance inlet in the chassis above the power supply.
6. The AC power supply has a pull handle and a locking tab. Press the locking tab to the right while you pull the unit out using the handle.

Figure 8: Replacing an AC Power Supply



To install an AC power supply (see [Figure 8 on page 73](#)):

1. Move the AC input switch next to the appliance inlet on the power supply to the off (O) position.
2. Using both hands, slide the power supply straight into the chassis until the power supply is fully seated in the chassis slot. The power supply faceplate should be flush with any adjacent power supply faceplate or blank installed in the power supply slot.
3. Tighten both captive screws at the bottom of the power supply.
4. Attach the power cord to the power supply.
5. Attach the power cord to the AC power source, and switch on the dedicated customer site circuit breaker. Follow the instructions for your site.
6. If the chassis has a power switch, move it to the on (I) position.
7. Observe the status LEDs on the power supply faceplate. If the power supply is correctly installed and functioning normally, the **AC OK** and **DC OK** LEDs light steadily, and the **PS FAIL** LED is not lit.

Related Documentation

- [Required Tools for Maintaining the CTP Platform on page 71](#)
- [Storing CTP Modules and Other Components on page 71](#)
- [Cleaning the CTP Platform on page 72](#)

CHAPTER 17

Product Reclamation and Recycling

- Product Reclamation and Recycling Program on page 75

Product Reclamation and Recycling Program

Juniper Networks is committed to environmentally responsible behavior. As part of this commitment, we continually work to comply with environmental standards such as the European Union's *Waste Electrical and Electronic Equipment* (WEEE) Directive and *Restriction of Hazardous Substances* (RoHS) Directive.

These directives and other similar regulations from countries outside the European Union regulate electronic waste management and the reduction or elimination of specific hazardous materials in electronic products. The WEEE Directive requires electrical and electronics manufacturers to provide mechanisms for the recycling and reuse of their products. The RoHS Directive restricts the use of certain substances that are commonly found in electronic products today. Restricted substances include heavy metals, including lead, and polybrominated materials. The RoHS Directive, with some exemptions, applies to all electrical and electronic equipment.

In accordance with Article 11(2) of Directive 2002/96/EC (WEEE), products put on the market after 13 August 2005 are marked with the following symbol or include it in their documentation: a crossed-out wheeled waste bin with a bar beneath.



Juniper Networks provides recycling support for our equipment worldwide to comply with the WEEE Directive. For recycling information, go to <http://www.juniper.net/environmental>, and indicate the type of Juniper Networks equipment that you wish to dispose of and the country where it is currently located, or contact your Juniper Networks account representative.

Products returned through our reclamation process are recycled, recovered, or disposed of in a responsible manner. Our packaging is designed to be recycled and should be handled in accordance with your local recycling policies.

- Related Documentation**
- [Return Procedure on page 77](#)
 - [Returning CTP Products for Repair or Replacement on page 77](#)

CHAPTER 18

Packing and Returning Hardware

- [Return Procedure on page 77](#)
- [Returning CTP Products for Repair or Replacement on page 77](#)

Return Procedure

When you need to return a component:

1. Determine the part number and serial number of the component. For instructions, see [“Locating CTP Component Serial Numbers” on page 83](#).
2. Obtain a Return Materials Authorization (RMA) number from the Juniper Networks Technical Assistance Center (JTAC). See [“Information You Might Need to Supply to JTAC” on page 84](#).

Provide the following information in your e-mail message or during the telephone call:

- Part number and serial number of component
- Your name, organization name, telephone number, and fax number
- The shipping address for the replacement component, including contact name and phone number
- Description of the failure

The support representative validates your request and issues an RMA number for return of the component.

3. Pack the device or component for shipment, performing the procedure described in [“Returning CTP Products for Repair or Replacement” on page 77](#).

Related Documentation

- [Returning CTP Products for Repair or Replacement on page 77](#)
- [Contacting Customer Support on page 83](#)

Returning CTP Products for Repair or Replacement

In the event of a hardware failure, please contact Juniper Networks to obtain a Return Material Authorization (RMA) number. This number is necessary to ensure proper tracking and handling of returned material at the factory. Do not return any hardware until you

have received an RMA. Juniper Networks reserves the right to refuse shipments that do not have an RMA. Refused shipments are returned to the shipper through collect freight.

If possible, use the original shipping crate, pallet, and packing materials in which the chassis was originally shipped. If these materials are unavailable, use comparable shipping material, or contact your Juniper Networks representative for information about approved packaging material.

See the customer support Web page for complete repair and return policies and procedures.

To pack the chassis for shipment:

1. Ground yourself by using an antistatic wrist strap or other device.
2. Issue the proper shutdown commands to halt your system.
3. Switch all power switches to the OFF position.
4. Remove all cables from the chassis.
5. Remove all major components from the chassis, including interface modules, processor modules, RTMs, and fan trays.
6. Remove the chassis from the rack and bolt it to the shipping pallet.
7. Cover the chassis with an ESD bag and place packing foam on top of and around the chassis.
8. Place the crate cover over the chassis and fasten the cover to the pallet.

**Related
Documentation**

- [Contacting Customer Support on page 83](#)
- [Return Procedure on page 77](#)
- [Locating CTP Component Serial Numbers on page 83](#)
- [Information You Might Need to Supply to JTAC on page 84](#)

PART 6

Troubleshooting

- [Troubleshooting Power Failures on page 81](#)
- [Contacting Customer Support on page 83](#)

CHAPTER 19

Troubleshooting Power Failures

- [CTP Platform Does Not Power On on page 81](#)
- [CTP Platform Shuts Down on page 81](#)

CTP Platform Does Not Power On

Problem **Description:**

Symptoms:

- Device is not receiving power.
- Module's power supply has malfunctioned.
- Power source cannot handle system load.

Solution

1. Verify that all power connections are correct.
2. Verify that the power supply is delivering the correct voltage, current, and wattage to the device. See the system specifications for your particular CTP platform.
3. If the platform still does not operate, contact the Juniper Networks Technical Assistance Center (JTAC).

Related Documentation • [CTP Platform Shuts Down on page 81](#)

CTP Platform Shuts Down

Problem **Description:**

Symptoms:

- Temperature is too high.
- Power is lost.

Solution

1. Verify that power connections are properly attached.
2. Verify that device is receiving power.

3. Look to see whether or not the LEDs are lit.
4. Run diagnostics using the CLI.
5. If the device does not reset, contact JTAC.

**Related
Documentation**

- [CTP Platform Does Not Power On on page 81](#)

CHAPTER 20

Contacting Customer Support

- [Contacting Customer Support on page 83](#)
- [Locating CTP Component Serial Numbers on page 83](#)
- [Information You Might Need to Supply to JTAC on page 84](#)

Contacting Customer Support

See the Juniper Networks Web site for complete customer service information:

- <http://www.juniper.net/support/guidelines.html>

For your convenience, we provide multiple options for requesting and receiving technical support from the Juniper Networks Technical Assistance Center (JTAC):

- By the Web using Juniper Networks, Inc. Case Manager:

<https://www.juniper.net/cm/index.jsp>

- By telephone:

From the US, Canada, and Mexico at 1-888-314-JTAC

From all other locations at 408-745-9500

Related Documentation

- [Return Procedure on page 77](#)
- [Locating CTP Component Serial Numbers on page 83](#)
- [Information You Might Need to Supply to JTAC on page 84](#)
- [Returning CTP Products for Repair or Replacement on page 77](#)

Locating CTP Component Serial Numbers

Before contacting Juniper Networks to request a Return Materials Authorization (RMA), you must find the serial number on the chassis or component.

Serial numbers are located on the modules. ID labels are usually applied near the ejector.

Related Documentation

- [Contacting Customer Support on page 83](#)

- [Return Procedure on page 77](#)
- [Information You Might Need to Supply to JTAC on page 84](#)
- [Returning CTP Products for Repair or Replacement on page 77](#)

Information You Might Need to Supply to JTAC

When requesting technical support from JTAC by phone, be prepared to provide the following information:

- Priority level
- Indication of what activity was being performed on the device when the problem occurred
- Problem detail and configuration data

When a new request for technical support is submitted, the JTAC engineer:

1. Opens a case and assigns a number.
2. Begins troubleshooting, diagnostics, and problem replication (if appropriate).
3. Provides you with periodic updates on problem status and escalates the problem as appropriate according to escalation management guidelines.
4. Closes the case when you agree that the problem has been resolved.

Related Documentation

- [Contacting Customer Support on page 83](#)
- [Return Procedure on page 77](#)
- [Locating CTP Component Serial Numbers on page 83](#)
- [Returning CTP Products for Repair or Replacement on page 77](#)

PART 7

Index

- [Index on page 87](#)

Index

Symbols

#, comments in configuration statements.....	xiii
(), in syntax descriptions.....	xiii
< >, in syntax descriptions.....	xiii
[], in configuration statements.....	xiii
{ }, in configuration statements.....	xiii
(pipe), in syntax descriptions.....	xiii

A

AC power supply, replacing.....	72
accessing	
connecting directly.....	61
HyperTerminal.....	62
management console.....	61
SSH setup.....	62

B

braces, in configuration statements.....	xiii
brackets	
angle, in syntax descriptions.....	xiii
square, in configuration statements.....	xiii

C

cabling	
fast Ethernet.....	31, 59
interface module.....	58
overview.....	57
power.....	31
recommendations.....	20
required tools.....	57
Case Manager, Juniper.....	83
cleaning platform.....	72
clock module.....	10
comments, in configuration statements.....	xiii
compact flash card, installing and removing.....	56
compliance, regulatory	
Canadian.....	42
FCC.....	40, 41
FDA.....	41
console See management console	

conventions

text and syntax.....	xii
CTP overview.....	3
CTP150 multiservice interface module.....	4, 8
CTP150 platform.....	3
specifications.....	13, 15
CTP150 serial interface module.....	4, 7
CTP150 T1/E1 interface module.....	4, 9
CTPOS.....	3
CTPView.....	3
curly braces, in configuration statements.....	xiii
customer support.....	xiv, 83
contacting JTAC.....	xiv
contacting Juniper.....	49
information needed.....	84
locating serial numbers.....	83
return procedure.....	77

D

damaged components, returning.....	48
DB-9	
connector.....	58
crossover cable.....	30
declaration of conformity, EC	
CTP150.....	39
documentation	
comments on.....	xiii

E

EIA-530 data interface.....	23
EIA-530/X.21 data interface.....	7
EIA530(A) data interface.....	7
environmental requirements.....	17

F

font conventions.....	xii
-----------------------	-----

H

HD-26 connector.....	7, 8
pinouts.....	23
HyperTerminal access.....	62

I

inspecting before installation.....	48
installing	
AC power supply.....	72
before.....	51
compact flash card.....	56
freestanding.....	51

modules.....	55
responsibilities.....	17
safety guidelines.....	37
tools required.....	54
interface modules	
cabling.....	58
pinouts See pinouts	
IRIG data interface.....	7

J

JTAC, contacting.....	83, 84
-----------------------	--------

M

maintaining	
cleaning.....	72
storing modules.....	71
tools required.....	71
management console	
accessing.....	61
direct connection.....	61
pinouts.....	30
manuals	
comments on.....	xiii
modules and components	
cleaning.....	72
installing.....	55
port numbering.....	53
protecting.....	53
removing.....	55
replacing.....	71
slot numbering.....	53
storing.....	71

P

parentheses, in syntax descriptions.....	xiii
pinouts	
HD-26 connector.....	23
port numbering, modules.....	53
power	
cables, DC.....	31
failures.....	81
shutdowns.....	81
powering off.....	68
powering on.....	65
preinstallation responsibilities.....	17

R

rack	
installation guidelines.....	20
installing in.....	52
mechanical requirements.....	19
requirements.....	19
space requirements.....	20
reclamation and recycling.....	75
removing modules.....	55
replacing components.....	71
return procedure.....	77
RJ-45 connector.....	4, 30, 31, 58, 59, 61, 62
RJ-48 connector.....	9
RS-232 port.....	58, 61
RS-232/V.24 port.....	7

S

safety guidelines.....	35
installation.....	37
serial number, locating.....	83
slot numbering, modules.....	53
SSH connection.....	62
storing components.....	71
support, technical See technical support	
syntax conventions.....	xii

T

technical support.....	83
contacting JTAC.....	xiv
troubleshooting power failures.....	81

U

uninstalling modules.....	55
unpacking and inspecting.....	47

V

V.35 data interface.....	7
--------------------------	---

X

X.21 data interface.....	26
--------------------------	----