



CTPView Network Management System Administration Guide

Release
7.0, CTPView Release 7.0



Modified: 2015-09-29
Revision 1

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Copyright © 2015, Juniper Networks, Inc. All rights reserved.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

CTPView Network Management System Administration

Copyright © 2015, Juniper Networks, Inc.
All rights reserved.

Revision History
September 2014—Revision 1

The information in this document is current as of the date on the title page.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement (“EULA”) posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

Part 1	Overview	
Chapter 1	Circuit to Packet System Overview	3
	Circuit to Packet Network Overview	3
	Serial Stream Processing	4
	Transmit Packet Processing	4
	Receive Packet Processing	5
	Serial Stream Creation	5
	Clock Options	5
	Circuit to Packet Network Software Overview	6
Part 2	Installation	
Chapter 2	Installation Tasks Overview	9
	Updating the CTPView Server Operating System and CTPView Network Management System Software	10
Chapter 3	Installation and Upgrade Tasks for the CTPView Server OS and CTPView Software	13
	Installing or Upgrading the CTPView Server OS	14
	Saving the CTPView Configuration Settings and Data (CTPView Server Menu)	16
	Creating More Disk Space on the CTPView Server (CTPView)	17
	Creating More Disk Space on the CTPView Server (CTPView Server Menu)	18
	Installing the CTPView Server OS (CTPView Server CLI)	18
	Restoring CTPView Software Configuration Settings and Data (CTPView)	19
	Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)	20
	Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)	20
	Reviewing the Installation Log for Errors (CTPView Server CLI)	21
	Verifying the CTPView Server OS Installation (CTPView)	21
	Validating the CTPView Server Configuration (CTPView)	22
Chapter 4	Upgrade Tasks for Only the CTPView Software	23
	Upgrading Only the CTPView Software	23
	Upgrading the CTPView Software with a Complete Archive File	25
	Upgrading the CTPView Software with a Web Archive File	26
Chapter 5	Configuration Tasks for CTPView Administrative Settings	27
	Configuring the CTPView Administrative Settings	27
	Preparing a New Server	29

	Changing the BIOS Menu Password (CTPView Server CLI)	29
	Changing the Server's Default User Account Password (CTPView Server CLI)	30
	Changing the Server's Root Account Password (CTPView Server CLI)	31
	Changing the GRUB Boot Loader Password (CTPView Server Menu)	31
	Changing the MySQL Apache Account Password (CTPView Server Menu)	32
	Changing the MySQL Root Account Password (CTPView Server Menu)	33
	Configuring the Network Access (CTPView Server Menu)	33
	Creating a Self-Signed Web Certificate (CTPView Server Menu)	34
	Updating the CTPView Software	36
	Logging In with a Browser (CTPView)	36
	Changing the CTPView GUI Default User Account Password (CTPView)	37
	Creating a New Global_Admin Account (CTPView)	37
Chapter 6	Upgrade Tasks for CTPOS	39
	Using the CTPView Server Software to Update CTPOS (CTPView)	39
	Burning an Image of CTPOS to a CompactFlash Card (CTPView Server Menu)	40
	Burning CTPOS Images to a CompactFlash Card (CTPView Server CLI)	40
Chapter 7	Default Accounts and Passwords	43
	Default CTPOS and CTPView Accounts and Passwords	43
	Changing the User Password (CTP Menu)	44
	CTPOS and CTPView Software Password Requirements	46
Chapter 8	Understanding CTPView Upgrade Files	47
	Understanding CTPView Software Upgrade Files	47
Part 3	Administration	
Chapter 9	Managing and Displaying Users (CTPView)	51
	Managing CTPView Users with the CTPView Admin Center	51
	Accessing the CTPView Admin Center (CTPView)	52
	Monitoring CTPView Users (CTPView)	53
	Adding New CTPView Users (CTPView)	53
	Modifying CTPView User Properties (CTPView)	54
	Monitoring CTPView Groups (CTPView)	54
	Modifying CTPView User Group Affiliation (CTPView)	54
	Adding a New CTPView User Group (CTPView)	55
	Modifying CTPView User Group Default Properties (CTPView)	55
	Prohibiting and Reinstating CTPView Access by Users (CTPView)	56
	Displaying Prohibited CTPView Users (CTPView)	56
	Prohibiting User Access to CTPView (CTPView)	56
	Reinstating Prohibited CTPView Users (CTPView)	57
	Deleting Users and Groups (CTPView)	57
	Deleting Active CTPView Users (CTPView)	57
	Deleting Inactive CTPView Users (CTPView)	57
	Deleting Prohibited CTPView Users (CTPView)	58
	Deleting CTPView Groups (CTPView)	58

	Managing User Passwords (CTPView)	58
	Limiting Password Reuse (CTPView)	58
	Excluding Passwords from Use (CTPView)	58
	Reinstating Excluded Passwords (CTPView)	59
	Changing Requirements for New Passwords (CTPView)	59
	Configuring User Login Properties (CTPView)	59
	Logging Out a CTPView User (CTPView)	60
	Configuring Automatic Logout for a CTPView User (CTPView)	60
	Configuring the Number of Login Attempts Allowed Before Lockout (CTPView)	60
	Configuring a Lockout Period for CTPView Users (CTPView)	60
	Clearing CTPView User Counters (CTPView)	61
	Reinstating Locked-Out IP Addresses (CTPView)	61
	Creating an Access Filter to Allow or Deny IP Addresses (CTPView)	61
	Removing an IP Access Filter (CTPView)	61
	Understanding CTPView GUI User Levels	62
	CTPOS and CTPView Software Password Requirements	62
Chapter 10	Managing the CTPView Server (CTPView)	65
	Adding and Removing CTP Platforms Managed by CTPView Software (CTPView)	65
	Adding and Removing Host Groups (CTPView)	66
	Adding and Removing SNMP Communities (CTPView)	67
	Managing CTP Platforms in the Network (CTPView)	68
	Configuring Email Notifications (CTPView)	69
	Setting the CTPView Server Start-Up Banner (CTPView)	70
	Setting the CTP Platforms Login Banner (CTPView)	70
	Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView)	71
	Setting the CTPView Server Clock (CTPView)	72
	Setting the CTPOS Clock (CTP Menu)	73
	Managing NTP Servers for the CTPView Network (CTPView)	74
	Accessing the NTP Server Settings Window (CTPView)	76
	Stopping the NTP Daemon (CTPView)	76
	Adding an NTP Peer (CTPView)	76
	Removing an NTP Peer (CTPView)	76
	Synchronizing the CTPView Server to an NTP Peer (CTPView)	76
	Adding NTP Network Clients (CTPView)	77
	Removing an NTP Network Client (CTPView)	77
	Modifying the Netmask of an NTP Network Client (CTPView)	77
	Configuring Automatic Monitoring of CTP Platforms (CTPView)	77
	Accessing the CTPView Automatic Functions Window (CTPView)	78
	Adding an Automatic Monitoring Operation (CTPView)	79
	Removing an Automatic Monitoring Operation (CTPView)	79
	Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms (CTPView)	79
	Restoring CTPView Software Configuration Settings and Data (CTPView)	80
	Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)	81

	Synchronizing Multiple CTPView Servers (CTPView)	81
	Configuring a CTPView Server Synchronization Network (CTPView)	82
	Synchronizing the CTPView Server Network Automatically (CTPView)	83
	Synchronizing the CTPView Server Network Manually (CTPView)	84
Chapter 11	Monitoring CTP Platforms (CTPView)	85
	Monitoring the Network with the CTPView Software (CTPView)	85
	Changing the Display Settings for CTPView Network Monitoring (CTPView)	87
	Checking the CTPView Server Connection to CTP Platforms in the Network (CTPView)	87
	Checking Connections from the Network Monitoring Pane (CTPView)	88
	Checking Connections from the Node Maintenance Pane (CTPView)	88
	Displaying Previously Logged Connection Status (CTPView)	88
	Checking Connections in the Remote Host Options Window (CTPView)	89
	Displaying Runtime Query Results for a CTP Platform (CTPView)	89
	Overriding CTP Platform Network Status and Adding Comments (CTPView)	90
	Saving CTP Platform Configurations (CTPView)	91
	Setting an Audible Alert for CTP Platform Status (CTPView)	93
	Displaying CTPView Network Reports (CTPView)	93
	Field Descriptions in CTPView Network Reports (CTPView)	95
	Displaying Network Statistics (CTPView)	96
Chapter 12	Changing CTPView GUI Settings	99
	Configuring CTPView Software for Tabbed or Nontabbed Browsers (CTPView)	99
	Changing the CTPView Display Settings (CTPView)	100
	Displaying Help for CTPView GUI Settings (CTPView)	100
Chapter 13	Managing and Displaying Users (CTPView Server Menu)	103
	Accessing the CTPView Server Configuration Menu (CTPView Server Menu)	103
	Managing CTPView Users (CTPView Server Menu)	104
	Monitoring CTPView Users (CTPView Server Menu)	104
	Listing Admin Shell Accounts (CTPView Server Menu)	104
	Adding Admin Shell Accounts (CTPView Server Menu)	105
	Deleting Admin Shell Accounts (CTPView Server Menu)	105
	Unlocking a User Account (CTP Menu)	105
	Adding a VLAN Interface to a Node (CTP Menu)	106
	Adding a VLAN ID to the System	107
	Configuring VLAN Interface by Using the VLAN ID	108
	Accessing the Security Profile Configuration Menu (CTP Menu)	110
	Classification of CTPView Shell Account Users	111
	Managing User Passwords (CTPView Server Menu)	111
	Listing User Accounts (CTPView Server Menu)	111
	Displaying Password Expiration Settings (CTPView Server Menu)	112
	Changing Password Expiration Settings (CTPView Server Menu)	112
	Displaying Password Requirements (CTPView Server Menu)	113
	Changing Password Requirements (CTPView Server Menu)	113
	Configuring CTPView User Authentication with Steel-Belted RADIUS	113
	Configuring RADIUS Settings on the CTPView Server	114
	Configuring the SBR Server's Dictionary Files	116

	Configuring the SBR Server's Active Authentication Method	117
	Adding the CTPView Server as a RADIUS Client on an SBR Server	117
	Adding CTPView Users to an SBR Server	117
	Assigning SecurID Tokens to CTPView Users	118
	Configuring CTPOS and CTPView User Authentication with TACACS+	118
	Configuring TACACS+ Settings from the CTPView Server	119
	Configuring TACACS+ Settings from the CTPView Web Interface	120
Chapter 14	Managing the CTPView Server (CTPView Server Menu)	123
	Managing CTPView Server Secure Logs (CTPView Server Menu)	123
	Viewing Secure Logs (CTPView Server Menu)	124
	Copying Secure Logs to a Remote Host (CTPView Server Menu)	124
	Configuring Remote Logging Options (CTPView Server Menu)	124
	Displaying the Remote Logging Configuration (CTPView Server Menu)	124
	Setting the CTPView Server Start-Up Banner (CTPView Server Menu)	125
	Managing Access Security for the CTPView Server (CTPView Server Menu)	125
	Viewing the Access Security Level for the CTPView Server (CTPView Server Menu)	126
	Setting Access Security for the CTPView Server (CTPView Server Menu)	126
	Establishing an SSH Connection (CTP Menu)	127
	Configuring an SSH Connection to a CTP Platform That Persists Through the Session (CTPView Server Menu)	127
	Viewing the Current State of Port Forwarding (CTPView Server Menu)	128
	Setting Port Forwarding Permissions (CTPView Server Menu)	128
	Closing Port Forwarding Sockets (CTPView Server Menu)	128
	Clearing Open Sockets by Restarting the Apache Daemon (CTPView Server Menu)	128
	Saving the CTPView Configuration Settings and Data (CTPView Server Menu)	129
	Creating More Disk Space on the CTPView Server (CTPView Server Menu)	130
	Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)	131
	Restarting the MySQL Server (CTPView Server Menu)	131
	Setting the Logging Level (CTPView Server Menu)	132
Chapter 15	Restoring Default Values on the CTPView Server	133
	Resetting the Default System Administrator Account (CTPView Server Menu)	133
	Resetting the Data File Permissions (CTPView Server Menu)	133
	Resetting the CTPView System Files to the Default Values (CTPView Server Menu)	134
	Burning an Image of CTPOS to a CompactFlash Card (CTPView Server Menu)	136
	Resetting the Default Firewall Settings (CTPView Server Menu)	137
Chapter 16	Changing Administrative Passwords to Improve Access Security	139
	Changing Passwords to Improve Access Security	139
	Changing the BIOS Menu Password (CTPView Server CLI)	140
	Changing the Server's Root Account Password (CTPView Server CLI)	141

	Changing the GRUB Boot Loader Password (CTPView Server Menu)	141
	Changing the MySQL Apache Account Password (CTPView Server Menu)	142
	Changing the MySQL Root Account Password (CTPView Server Menu)	143
Chapter 17	Using Third-Party Software on CTPView Servers	145
	Third-Party Software on CTPView Servers	145
Part 4	Troubleshooting	
Chapter 18	Validating the CTPView Server System Configuration	149
	Validating the CTPView Server Configuration (CTPView)	149
Chapter 19	Restoring CLI Access to the CTPView Server	151
	Restoring Access to a CTPView Server	151
	Accessing a Shell on the CTPView Server (CTPView Server CLI)	152
	Setting a New Password for a Nonroot User Account (CTPView Server CLI) . . .	153
	Setting a New Password for a Root User Account (CTPView Server CLI)	154
	Creating a Nonroot User Account and Password (CTPView Server CLI)	154
Chapter 20	Restoring Browser Access to a CTPView Server	157
	Restoring Browser Access to a CTPView Server (CTPView Server Menu)	157
Chapter 21	Changing a CTPOS User Password	159
	Changing a User Password for a CTP Platform	159
Chapter 22	Booting the CTPView Server from the CD-ROM Drive	161
	Booting the CTPView Server from the CD Drive	161
Chapter 23	Restarting the Apache Daemon In the Event of Browser Issues	163
	Restarting the Apache Daemon (CTPView Server Menu)	163
Part 5	Index	
	Index	167

List of Figures

Part 1	Overview	
Chapter 1	Circuit to Packet System Overview	3
	Figure 1: Sample Application Using CTP Products	3
	Figure 2: Circuit-to-Packet Conversion Processes	4
Part 2	Installation	
Chapter 2	Installation Tasks Overview	9
	Figure 3: Decision Tree for Updating CTPView Server Software	12

List of Tables

Part 2	Installation	
Chapter 7	Default Accounts and Passwords	43
	Table 1: CTPView Server Default Accounts and Passwords	43
	Table 2: CTPOS Default Account and Password	44
	Table 3: Requirements for New Password	45
Chapter 8	Understanding CTPView Upgrade Files	47
	Table 4: CTPView Software Upgrade Files	47
Part 3	Administration	
Chapter 10	Managing the CTPView Server (CTPView)	65
	Table 5: CTP Platform Events for Email Notifications	69
	Table 6: Summary Information for NTP Server Peers	74
	Table 7: Prefixes Designating Peer Clock Selection Status	75
	Table 8: Current CTPView Automatic Settings	77
Chapter 11	Monitoring CTP Platforms (CTPView)	85
	Table 9: Platform Group and Bundle Status	86
	Table 10: CTPView Network Reports Fields	95
Chapter 13	Managing and Displaying Users (CTPView Server Menu)	103
	Table 11: Configuring a VLAN Interface	108
	Table 12: IP Parameters for Configuring a VLAN	109
	Table 13: CTPView User Password Expiration Settings	112
	Table 14: RADIUS Menu Options	115
	Table 15: TACACS+ Settings for CTPView Server	120
	Table 16: TACACS+ Settings for the CTPView Web Interface	121
Chapter 14	Managing the CTPView Server (CTPView Server Menu)	123
	Table 17: Access Security Levels for SSH Connections	126
	Table 18: Access Security Levels for CTPView GUI	127

PART 1

Overview

- [Circuit to Packet System Overview on page 3](#)

CHAPTER 1

Circuit to Packet System Overview


- [Circuit to Packet Network Overview on page 3](#)
- [Circuit to Packet Network Software Overview on page 6](#)

Circuit to Packet Network Overview

The CTP products are designed to create an IP packet flow from a serial data stream or analog voice connection, providing the necessary processing to re-create the serial bit stream or analog signal from an IP packet flow.


CTP products are designed to accommodate the delay, delay jitter, and packet reordering characteristics of an IP network. [Figure 1 on page 3](#) shows examples of applications that use CTP products.

Figure 1: Sample Application Using CTP Products



Numerous processes must occur to adapt serial data to and from IP packets. These processes are summarized in [Figure 2 on page 4](#). You configure the characteristics of the processes by using the CTP menu interface or the CTPView graphical user interface.

Figure 2: Circuit-to-Packet Conversion Processes



Using the menu interface, you can configure the CTP products to accept a serial data stream and create an IP flow that will be transferred across an IP network. The connection provided by the CTP platform is a physical layer circuit between the end user equipment.

Serial Stream Processing

Rate selection and clock configuration allow the serial interface rate to be configured through the software. Rates supported range from less than 300 bps to 12.288 Mbps (in subhertz increments).

You can configure the CTP systems by using the menu interface to provide multiple prioritized node clock references. An external reference input and any of the serial interfaces may be used for the node reference clock. Reference frequencies must be 32 KHz, $n \times 64$ KHz, or 1,544 KHz up to a maximum of 4096 KHz (2048 KHz maximum on the CTP1002).

The electrical characteristics and encoding of the CTP ports are software configurable. The available options are EIA530, EIA530A, RS-232, V.35, analog 4WTO, conditioned diphas, isochronous, T1, and E1.

An analog voice signal terminated on the 4WTO interface is converted into a 64-Kbps pulse-code modulation (PCM) digital bit stream before adaptation to and from an IP flow. The analog interface allows transmit and receive levels to be adjusted.

Transmit Packet Processing

The CTP platform is configured with the remote IP address of the device where the packets created from the local serial port are to be routed.

The CTP remote port is specified by the IP address and physical port number of the remote unit and port.

The packet size created by the CTP platform may be set from 32 to 1456 bytes. Larger packet sizes are more bandwidth-efficient but introduce more serialization delay when the packet is created. The menu interface verifies that the combination of packet size and data rate does not result in a packet rate exceeding 1200 packets per second.

Time to live (TTL) may be set from 0 to 255. The TTL is the maximum number of hops in the IP network that the packet may travel before it is discarded by the network. You can configure the service type byte, which some IP networks use to determine the quality of service provided to the IP flow.

Receive Packet Processing

A receive buffer is required to smooth the timing jitter of received packets because of the delay variance that is inevitably encountered in the IP network. The configuration allows you to configure both the size of the buffer (in 1-ms increments) and the maximum amount of buffering delay allowed before the buffer will recenter. The size of the buffer configured should depend on the performance and characteristics of the IP network.

The CTP platform automatically resequences packets when they arrive out of order. If a packet is not received, the CTP platform inserts all data in lieu of the packet information so that bit count integrity is maintained.

You can prompt the menu interface to display detailed information about the port status, such as packet counts, late packets, missing packets, and buffer fill.

Serial Stream Creation

The packet receive process allows the serial data rate to be configured through the software. Rates supported range from less than 300 bps to 12.288 Mbps in subhertz increments. Conditioned diphase and isochronous interfaces operate at rates up to 1.024 Mbps.

Clock Options

The CTP platform provides numerous options for physical layer clocking:

- Interface clocking options—The CTP platform allows complete configuration flexibility of interface clocking. This flexibility includes your ability to specify how clocks are generated (that is, from the node clock, which can be phase locked to an external clock input) and what clocks are used to process the data from the attached device. The CTP platform can synthesize over 1.5 billion rates between 1 bps and 12.288 Mbps.
- Asymmetric clocking—You can configure CTP circuits to synthesize asymmetric rates.
- Reference clock input—The CTP platform can phase lock its node clock to an interface clock or external reference input. Up to five prioritized references can be configured. The node provides a reference holdover if all references are lost.
- Plesiochronous operation—Calibrated Clock is a patented CTP feature that allows the one-time calibration of the CTP oscillator to a known reference. Depending on environmental factors, two units calibrated to the same clock will have a clock

difference as small as 100 parts per billion. This calibration enables CTP circuits to operate for long periods of time before a buffer recenter occurs.

- Adaptive clocking—Although IP router networks do not transfer physical layer clocking, the CTP adaptive clocking feature, using patented Advanced Time Domain Processing (ATDP), allows the CTP platform to recover clocking information from the remote CTP port and adjust the local clock accordingly. ATDP provides rapid convergence to the correct clock, and does not vary due to changes in the average jitter buffer fill. As a result, a CTP circuit will continuously operate without a buffer recenter, even when clock references are not used.

**Related
Documentation**

- [*Adding a Bundle \(CTPView\)*](#)
- [*Adding a Bundle \(CTP Menu\)*](#)
- [*Selecting the Type of Clocking on Serial Ports for CTP Bundles \(CTPView\)*](#)
- [*Configuring Custom Clocking for CTP Bundles \(CTPView\)*](#)
- [*Configuring Adaptive Clocking for CTP Bundles \(CTPView\)*](#)
- [*Configuring IP Parameters for CTP Bundles \(CTP Menu\)*](#)

Circuit to Packet Network Software Overview

This topic provides an overview of the software components of the CTPView Network Management System and the CTP platforms.

A typical Circuit to Packet network consists of one or more CTP platforms and a CTPView server. The CTPView server runs the CTPView Network Management System software to manage the CTP platforms and construct the circuit-to-packet traffic bundles.

The software components consist of the following:

- CTPOS—Operating system that runs on the CTP platforms.
- Fedora Core (FC) OS—Operating system that runs on the CTPView server.
- CTPView Network Management System—Software that you use to build circuits and manage the CTP platforms. You can access this software through a browser application or through a text-based menu set.

In this document, we use the term *CTPView GUI* to refer to the browser application, and the term *CTPView server menu* to refer to the text-based menus. *CTPView software* typically refers to the CTPView Network Management System without regard to the method used to access the server.

**Related
Documentation**

- [*Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10*](#)

PART 2

Installation

- [Installation Tasks Overview on page 9](#)
- [Installation and Upgrade Tasks for the CTPView Server OS and CTPView Software on page 13](#)
- [Upgrade Tasks for Only the CTPView Software on page 23](#)
- [Configuration Tasks for CTPView Administrative Settings on page 27](#)
- [Upgrade Tasks for CTPOS on page 39](#)
- [Default Accounts and Passwords on page 43](#)
- [Understanding CTPView Upgrade Files on page 47](#)

CHAPTER 2

Installation Tasks Overview

- [Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10](#)

Updating the CTPView Server Operating System and CTPView Network Management System Software

This topic provides an overview of installing and upgrading the software on the CTPView server. You can install or upgrade the server operating system (OS), and you can upgrade the CTPView software that you use to manage the CTP Series devices. CTPView servers are provided with an OS and the CTPView software already installed. You can upgrade any CTPView server to a higher-numbered software release.

Your choice of upgrade procedure depends on the version of the operating system (OS) running on the CTPView server to be upgraded. To upgrade to the current release, your CTPView server must be running either Fedora Core 4 (FC4) OS or Fedora Core 9 (FC9) OS. CTPView servers are shipped with the latest supported version. CTPView servers have been shipped with the following OS versions:

- FC9 on servers shipped after August 2008.
- FC4 on servers shipped from November, 2006 through August 2008.
- FC1 on servers shipped before November 2006.

You can determine your server OS version in any of the following ways:

- In CTPView, navigate to **Server > Diagnostics**. The OS version is displayed in the Distro Name field in the System Vital block section of the page.
- Log in to the server shell and enter **uname -r** on the command line. The kernel version that is displayed includes the OS version: **fc1**, **fc4**, **fc9**.
- Log in to the server shell and enter **menu** and then the root password on the command line. The heading of the configuration menu that is displayed includes the OS release and kernel versions.



NOTE: If your server is running FC1, we recommend that you upgrade to a more recent model server.

Depending on your goals and your current software versions, upgrading your system software includes one or more of the following tasks:

- Install or upgrade to the latest server OS version, and upgrade to the latest CTPView software versions.

You can choose this task for any CTP server. *Installing* the OS reformats the server hard drives and deletes all existing data and settings. These actions put your server into a stable known state with all security features enabled. *Upgrading* to the latest OS version does not format the server hard drives; your existing data and settings are preserved. In either case, you also upgrade to the latest CTPView software version.

See [“Installing or Upgrading the CTPView Server OS” on page 14](#).

- Upgrade to the latest CTPView software version.

When you do not need or want to change the OS version, you can simply upgrade to the latest CTPView version.

See [“Upgrading Only the CTPView Software” on page 23](#).

- Configure administrative settings to complete the upgrade.

When you receive a new CTP server from Juniper Networks that is running CTPView 3.2R1 or higher, you need only configure the administrative settings. To enable all of the security updates, an administrator must configure certain server settings during the upgrade process.


You must also perform this task to validate the administrative settings in either of the following cases:

- You upgraded the CTPView software on a server running FC4 and CTPView 2.2R1 or lower.
- You installed or upgraded the server to the latest OS version.

See *Configuring the CTPView Administrative Settings*.

[Figure 3 on page 12](#) illustrates the decision process you use to determine which tasks to perform.

Figure 3: Decision Tree for Updating CTPView Server Software



g015391

Related Documentation

- [Accessing a Shell on the CTPView Server \(CTPView Server CLI\)](#) on page 152

CHAPTER 3

Installation and Upgrade Tasks for the CTPView Server OS and CTPView Software

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Saving the CTPView Configuration Settings and Data \(CTPView Server Menu\) on page 16](#)
- [Creating More Disk Space on the CTPView Server \(CTPView\) on page 17](#)
- [Creating More Disk Space on the CTPView Server \(CTPView Server Menu\) on page 18](#)
- [Installing the CTPView Server OS \(CTPView Server CLI\) on page 18](#)
- [Restoring CTPView Software Configuration Settings and Data \(CTPView\) on page 19](#)
- [Restoring CTPView Software Configuration Settings and Data with the Restore Utility \(CTPView Server Menu\) on page 20](#)
- [Restoring CTPView Software Data by Manually Synchronizing the CTPView Server \(CTPView\) on page 20](#)
- [Reviewing the Installation Log for Errors \(CTPView Server CLI\) on page 21](#)
- [Verifying the CTPView Server OS Installation \(CTPView\) on page 21](#)
- [Validating the CTPView Server Configuration \(CTPView\) on page 22](#)

Installing or Upgrading the CTPView Server OS

This topic provides an overview of installing and upgrading the operating system (OS) for the CTPView server.

Before you begin, do all of the following:

- Verify that this is the procedure you wish to use to update the software on the CTPView server. See [“Updating the CTPView Server Operating System and CTPView Network Management System Software” on page 10](#).
- Ensure that you have a monitor and keyboard connected to the CTPView server. You must also have an external storage device connected to the server in order to save the current data and settings for CTPView.
- Ensure that the server is connected to the network.
- If your server is currently running FC1, you must be running CTPView 2.1R2 or 2.1R3 in order to back up your existing data and configuration settings before upgrading the OS version. See [“Upgrading Only the CTPView Software” on page 23](#) for information on upgrading the CTPView software before you perform the tasks in this topic.



NOTE: If your server is running FC1, we recommend that you upgrade to a more recent model server.

Perform the following tasks

1. Save the current configuration settings and data to an external storage device.
See [“Saving the CTPView Configuration Settings and Data \(CTPView Server Menu\)” on page 16](#).
2. Install or upgrade the CTPView server OS.
See [“Installing the CTPView Server OS \(CTPView Server CLI\)” on page 18](#).
3. Restore the configuration settings and data.
See [“Restoring CTPView Software Configuration Settings and Data \(CTPView\)” on page 19](#).
4. Review the installation log for errors.
See [“Reviewing the Installation Log for Errors \(CTPView Server CLI\)” on page 21](#).
5. Configure CTPView administrative settings to complete server setup and ensure that security settings are correct.
See [“Configuring the CTPView Administrative Settings” on page 27](#).
6. Verify that the server OS was successfully installed or upgraded.
See [“Verifying the CTPView Server OS Installation \(CTPView\)” on page 21](#).
7. Validate the server configuration.

See [“Validating the CTPView Server Configuration \(CTPView\)”](#) on page 22.

Related Documentation

- [Default CTPOS and CTPView Accounts and Passwords](#) on page 43

Saving the CTPView Configuration Settings and Data (CTPView Server Menu)

This topic describes how to save the current configuration settings and data for the CTPView software. Although you can perform this task at any time, it is typically performed before you upgrade the CTPView server OS and the CTPView software.

You can use the backup utility in the CTPView server menu to save the information into an archive (.tgz) file and, if desired, move the archive to an external storage device. If you do not use the utility to move the archive, you can later copy or move it manually from outside the CTPView server menu.



NOTE: If you do not move the archive file to an external storage device, you are not protected from loss of the backed-up data. If you are upgrading the software, you must move the file to an appropriate location.

Alternatively, when you have more than one CTPView server, you can use the CTPView software GUI to synchronize the server with another server to save the settings and data. See [“Synchronizing Multiple CTPView Servers \(CTPView\)” on page 81](#) for the synchronization procedure.



NOTE: We recommend that you use the CTPView server backup utility to save your current information.

Before you use the CTPView server backup utility:

- Confirm that the external storage device is running a UNIX-like operating system and is enabled for SSH connections.



NOTE: Although the external storage device can use any operating system, the CTPView backup utility can automatically transfer the backup file only to a device that is running a UNIX-like operating system. If the device is running a different kind of OS, you must transfer the backup file with a copy utility that is compatible with that OS.

- Confirm that a network path exists between the CTPView server and the external storage device used for storing the backup file.
- Confirm that the hard drive on the CTPView server that you are backing up has at least 25 percent free space. If you attempt to run the backup utility when less than 25 percent free space is available, the utility prompts you to delete more old data files before you continue. See [“Creating More Disk Space on the CTPView Server \(CTPView\)” on page 17](#).
- Log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To back up your current information with the CTPView server backup utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions Menu is displayed.

2. Select **1) Save Current Settings and Data**.

If an archive file already exists in the `/var/www/html/acorn/data` directory on the server, the utility prompts you to delete or move the archive.

3. (Optional) From outside the menu (for example, in another terminal window), manually move the old archive to an external storage device if you want to save the information.
4. Enter **y** to delete the old archive.

The utility deletes the old archive file and creates the new archive file.

5. Enter **y** to move the new archive to an external location.
6. Follow the prompts to enter the IP address, username, and absolute path to the external device.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Creating More Disk Space on the CTPView Server \(CTPView\) on page 17](#)
- [Creating More Disk Space on the CTPView Server \(CTPView Server Menu\) on page 18](#)

Creating More Disk Space on the CTPView Server (CTPView)

This topic describes how to determine the amount of free disk space on the CTPView server and how to ensure that sufficient free space is always available on the server.

To determine the amount of free disk space that is available on the CTPView server:

1. In the side pane, select **Server > Diagnostics**.
The System Information pane is displayed.
2. Find the value for Totals in the Mounted Filesystems section. The value should be **75%** or less.

To automatically delete old files to create more free disk space:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Automatic Functions**.
3. Under the Action heading in the Add New Automatic Entry section, select old data files to delete. You can choose to remove outdated files that are over 6 months old, over 9 months old, or over 12 months old.
4. Click **Add New Entry**. From this point forward, files are deleted from the server when they exceed the selected age.

If you subsequently no longer want old files to be automatically removed, select that Action under Current CTPView Automatic Settings and click **Remove Selected Lines**.

- Related Documentation**
- [Saving the CTPView Configuration Settings and Data \(CTPView Server Menu\) on page 16](#)
 - [Installing or Upgrading the CTPView Server OS on page 14](#)

Creating More Disk Space on the CTPView Server (CTPView Server Menu)

This topic describes how to create free space by removing redundant data files from the server.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “[Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)](#)” on page 103.

To delete old files to create more free disk space:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.
The Backup Functions menu is displayed.
2. Select **3) Remove Redundant Binary Data Files**.

- Related Documentation**
- [Saving the CTPView Configuration Settings and Data \(CTPView Server Menu\) on page 16](#)
 - [Installing or Upgrading the CTPView Server OS on page 14](#)

Installing the CTPView Server OS (CTPView Server CLI)

This topic describes how to install the latest CTPView server OS. The server OS must be installed from the CTPView Management System CDs. Contact Juniper Networks Customer Support to send you the CDs.



NOTE: The CTPView software is automatically installed when you install or upgrade the server OS with the CTPView Management System CDs.

To install or upgrade CTPView server OS:

1. Insert the first CD from the latest CTPView Management System CD set into the server.
2. From the CLI, select **System Configuration > Reboot System** to reboot the server.
The reboot process halts at the Juniper CTPView Management System window.
3. At the boot prompt, enter **ctpview-install** or **ctpview-upgrade**.



NOTE: We recommend that you choose **ctpview-install**. This action reformats the server hard drives, installs the latest version of the server OS, and creates a conforming instance of the OS. If you choose **ctpview-upgrade**, the latest version of the OS is installed, but the server hard drives are not reformatted.

4. Follow the prompts to remove and insert the remaining CDs to complete the installation or upgrade process.

On some early hardware systems a RAMDISK error may be reported at the beginning of the upgrade process. If this occurs, perform the following steps:

1. Leave the first CD in the server and use the server power switch to reboot the server.
2. When the boot prompt appears, enter **mediacheck**. The server displays the message “Could not find kernel image: mediacheck”.
3. At the boot prompt, enter **ctpview-install** or **ctpview-upgrade**.

The upgrade process should proceed normally.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)

Restoring CTPView Software Configuration Settings and Data (CTPView)

This topic lists two methods to restore the CTPView software configuration settings and data. Typically you restore this information only after one of the following events has occurred:

- An installation of the latest version of the CTPView server operating system, which reformats the server’s hard drives.
- In the unlikely event of a data loss.

Use one of the following methods to restore saved CTPView information:

- Use the CTPView restore utility in the CTPView server menu. You must use this method when you have only a single CTPView server.

See “[Restoring CTPView Software Configuration Settings and Data with the Restore Utility \(CTPView Server Menu\)](#)” on page 20.

- Synchronize the server. This method is available only when you have two or more CTPView servers in your network.

See “[Restoring CTPView Software Data by Manually Synchronizing the CTPView Server \(CTPView\)](#)” on page 20.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)

Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)

This topic describes how to use the CTPView restore utility to restore the CTPView software configuration settings and data from a previously saved archive file.

Before you begin:

- Copy the backup (archive) file from its externally saved location to the `/var/www/html/acorn/data` directory on the server. The filename is in the format `ctpview_data_server-name_date.tgz`.
- Log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To restore your saved information with the CTPView restore utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions menu is displayed.

2. Select **2) Restore Settings and Data**.

You are prompted to use the archive file. After the restore script runs, you are prompted to run it again.

Related Documentation

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Restoring CTPView Software Configuration Settings and Data \(CTPView\) on page 19](#)

Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)

This topic describes how to use CTPView server synchronization to restore the CTPView software configuration settings and data.

To restore your saved information by synchronizing the CTPView server with another server:

1. Log in to the CTPView GUI on the server for which you are restoring the data.
2. In the side pane, select **Server > Administration** to display the Administrative Functions pane.
3. Click **Server Synchronization**.
4. Verify that the server is either not listed or its Server Type is set to Not Selected.
5. Log in to the CTPView GUI on the server from which you are restoring the data.
6. In the side pane, select **Server > Administration** to display the Administrative Functions pane.

7. Click **Server Synchronization**.
8. Ensure that the Server Type is set to Primary Server for this server, Secondary Server for the server being updated, and Not Selected for all other CTPView servers listed.
9. Click **Manually Synchronize Network**.
The Synchronize Secondary Servers window opens.
10. Click **Select All Hosts**, and then click **Synchronize Servers**.
11. When the synchronization is completed, restore the Server Type for all CTPView servers to the values that you normally use for your network.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Restoring CTPView Software Configuration Settings and Data \(CTPView\) on page 19](#)

Reviewing the Installation Log for Errors (CTPView Server CLI)

This topic describes how to use the CTPView installation log to check for errors. This log file maintains a record of all CTPView installations and upgrades.

To check the installation log for errors:

1. Using an SSH application, log in to the CTPView server.



NOTE: If you do not successfully log in within 60 seconds, the session is closed.

2. Enter **su -** and then the root password.
3. Enter **more /var/log/ctpview_autoinstall.log** to view the log.

Press the Spacebar to scroll through the log. Verify that no unresolved errors are listed for the latest installation or upgrade.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)

Verifying the CTPView Server OS Installation (CTPView)

This topic describes how to determine whether the CTPView server OS installation or upgrade completed successfully.

To validate the system configuration:

1. Log in to the CTPView GUI.
2. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

3. In the System Vital section, verify that the following values match the information listed in the release notes or in [“Understanding CTPView Software Upgrade Files” on page 47](#) for the OS version that you installed.

- Kernel Version
- Distro Name (distribution name)



NOTE: The kernel version and distribution name are also displayed in the heading on the CTPView Configuration Menu.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)

Validating the CTPView Server Configuration (CTPView)

This topic describes how to validate the CTPView server system configuration. Examining the system configuration information is a useful first step in troubleshooting many issues. Validate the configuration after installing or upgrading the CTPView software or server OS to determine whether the operation completed successfully.

The validation utility reports on a long list of configuration details that are critical or desirable for proper operation of the CTPView software. Instructions are provided for correcting items that are out of compliance.

To validate the system configuration:

1. Log in to the CTPView GUI.
2. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

3. Click **Validate Server Configuration**.

The Server Configuration Validation pane is displayed.

4. Confirm that all fields are set to their default values.

The display indicates whether each item is valid or noncompliant. A highlighted field indicates a problem. Follow the displayed instructions to correct the problem.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)

CHAPTER 4

Upgrade Tasks for Only the CTPView Software

- [Upgrading Only the CTPView Software on page 23](#)
- [Upgrading the CTPView Software with a Complete Archive File on page 25](#)
- [Upgrading the CTPView Software with a Web Archive File on page 26](#)

Upgrading Only the CTPView Software

This topic provides an overview of upgrading the CTPView software.

Before you begin, do all of the following:

- Using an SSH application, log in to the CTPView server, and enter **uname -r** on the CLI to determine the version of the operating system (OS). The initial characters in the output correlate to an OS version as follows:
 - 2.6.25 indicates that the operating system is FC9.
 - 2.6.11, 2.6.16, or 2.6.17 indicates that the operating system is FC4.
 - 2.4 indicates that the OS version is FC1.
- Determine the version of the CTPView software. In the CTPView server shell, enter **menu**, and then enter the root password when prompted. The software version is displayed in the heading. Alternatively, you can log in to the CTPView GUI and look in the heading next to the server IP address to determine the version of the CTPView software.
- Determine which upgrade file is required for your combination of currently installed CTPView server OS and CTPView software. See [“Understanding CTPView Software Upgrade Files” on page 47](#) for guidance. The *CTPView Release Notes* for the version you are upgrading to also describes the required upgrade files.

The steps you must perform to upgrade the CTPView software depend on the currently installed versions of the server OS and the CTPView software. Two kinds of CTPView update archive files are available, *web* files and *complete* files:

- Web files are used for minor software updates. Their filenames are in the format **web_server-os-version_upgrade-version_date.tgz**. For example, the file

web_fcX_3.4R1_090715.tgz provides an upgrade to CTPView 3.4R1 for CTPView servers running either FC4 or FC9.

To upgrade the CTPView software with a web archive file, see [“Upgrading the CTPView Software with a Web Archive File” on page 26](#).

- Complete files are used for more significant upgrades, and include additional software modules compared to the web files. Their filenames are in the format **ctpview_server-os-version_complete_upgrade-version_date.tgz**. For example, the file **ctpview_fc4_complete_3.4R1_090715.tgz** provides an upgrade to CTPView 3.4R1 for CTPView servers running either FC4.

To upgrade the CTPView software with a complete archive file, see [“Upgrading the CTPView Software with a Complete Archive File” on page 25](#).



NOTE: The CTPView Release Notes for the version you are upgrading to describes the upgrade files required for various combinations of currently installed CTPView server OS and CTPView software. [“Understanding CTPView Software Upgrade Files” on page 47](#) also provides a more complete list of upgrade files and their associated software combinations.



NOTE: When the CTPView server OS version is FC1, you must first upgrade to a higher OS version. See [“Installing or Upgrading the CTPView Server OS” on page 14](#).



NOTE: When you upgrade a version of CTPView that is lower than 2.2, the existing server CLI passwords and server accounts are not modified other than that the user account *Juniper* is added. However, all the existing CTPView user accounts are removed. Browser access to CTPView 2.2R1 and higher is through a new login interface that requires an administrator to create new usernames and passwords.

When you upgrade a version of CTPView that is lower than 2.0.4R1, you may need to update the server Ethernet settings after the upgrade. If so, use the CLI menu on the CTPView server to make the changes: **2) System Configuration > 1) Display Current Configuration**. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

Related Documentation

- [Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10](#)
- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Default CTPOS and CTPView Accounts and Passwords on page 43](#)
- [Understanding CTPView Software Upgrade Files on page 47](#)

Upgrading the CTPView Software with a Complete Archive File

This topic describes how to upgrade the CTPView software with a complete archive file.

Before you begin, ensure that you have determined the correct archive file to use for your upgrade. See “[Upgrading Only the CTPView Software](#)” on page 23 for more information.

To upgrade the CTPView software with a complete archive file:

1. Access the CTPView software download page at the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>.
2. Locate the update archive file appropriate for your current CTPView server OS and your CTPOS version.
3. Use a Secure Copy Protocol (SCP) program to copy the complete archive file to the **/tmp** directory on the server.

The filename is in the format

ctpview_server-os-version_complete_upgrade-version_date.tgz.

4. Log in to the server and switch to the root account.
5. Change the directory to **/tmp**.
6. Extract the archive by entering **tar -xvzf filename**.



NOTE: This step is not required when the CTPView server is running CTPView 3.4R2–p1 or higher-numbered releases. In these releases, the complete archive is automatically extracted when you run the upgrade script in the next step.

7. Run the installation script by entering **upgrade**.
8. Configure CTPView administrative settings to complete server setup, and ensure that security settings are correct.
See [Configuring the CTPView Administrative Settings](#).
9. To validate the system configuration, see “[Validating the CTPView Server Configuration \(CTPView\)](#)” on page 22.

Related Documentation

- [Updating the CTPView Server Operating System and CTPView Network Management System Software](#) on page 10
- [Upgrading Only the CTPView Software](#) on page 23
- [Understanding CTPView Software Upgrade Files](#) on page 47

Upgrading the CTPView Software with a Web Archive File

This topic describes how to upgrade the CTPView software with a web archive file.

Before you begin, ensure that you have determined the correct archive file to use for your upgrade. See [“Upgrading Only the CTPView Software” on page 23](#) for more information.

To upgrade the CTPView software with a web archive file:

1. Access the CTPView software download page at the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>.
2. Locate the update archive file appropriate for your current CTPView server OS and your CTPOS version.
3. Use a Secure Copy Protocol (SCP) program to copy the web archive file to the **/tmp** directory on the CTPView server.

The filename is in the format **web_server-os-version_upgrade-version_date.tgz**.

4. Log in to the server and switch to the root account.
5. Change the directory to **/tmp**.
6. Run the installation script by entering **upgrade**.
7. Configure CTPView administrative settings to complete server setup, and ensure that security settings are correct.

See *Configuring the CTPView Administrative Settings*.

8. To validate the system configuration, see [“Validating the CTPView Server Configuration \(CTPView\)” on page 22](#).

Related Documentation

- [Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10](#)
- [Upgrading Only the CTPView Software on page 23](#)
- [Understanding CTPView Software Upgrade Files on page 47](#)

CHAPTER 5

Configuration Tasks for CTPView Administrative Settings

- [Configuring the CTPView Administrative Settings on page 27](#)
- [Preparing a New Server on page 29](#)
- [Changing the BIOS Menu Password \(CTPView Server CLI\) on page 29](#)
- [Changing the Server's Default User Account Password \(CTPView Server CLI\) on page 30](#)
- [Changing the Server's Root Account Password \(CTPView Server CLI\) on page 31](#)
- [Changing the GRUB Boot Loader Password \(CTPView Server Menu\) on page 31](#)
- [Changing the MySQL Apache Account Password \(CTPView Server Menu\) on page 32](#)
- [Changing the MySQL Root Account Password \(CTPView Server Menu\) on page 33](#)
- [Configuring the Network Access \(CTPView Server Menu\) on page 33](#)
- [Creating a Self-Signed Web Certificate \(CTPView Server Menu\) on page 34](#)
- [Updating the CTPView Software on page 36](#)
- [Logging In with a Browser \(CTPView\) on page 36](#)
- [Changing the CTPView GUI Default User Account Password \(CTPView\) on page 37](#)
- [Creating a New Global_Admin Account \(CTPView\) on page 37](#)

Configuring the CTPView Administrative Settings

This topic provides an overview of configuring CTPView administrative settings. You must configure these settings when you receive a new CTPView server and after you install or upgrade the CTPView server operating system (OS) or the CTPView software. Many of the settings provide better access security for your CTP network. Juniper Networks recommends that you perform some of the following tasks at least every year; details are in the task.

To configure the administrative settings:

- If the CTPView server is new, prepare the server for configuring the administrative settings.

See [“Preparing a New Server” on page 29](#).

- Change the default password used to access the BIOS menu.

See [“Changing the BIOS Menu Password \(CTPView Server CLI\)”](#) on page 29.

- Change the default password for the server’s default user account.

See [“Changing the Server's Default User Account Password \(CTPView Server CLI\)”](#) on page 30.

- Change the default password for the server’s root account.

See [“Changing the Server's Root Account Password \(CTPView Server CLI\)”](#) on page 31.

- Change the default password used to access the GRUB Boot Loader menu.

See [“Changing the GRUB Boot Loader Password \(CTPView Server Menu\)”](#) on page 31.

- Change the default password for the MySQL server Apache user account.

See [“Changing the MySQL Apache Account Password \(CTPView Server Menu\)”](#) on page 32.

- Change the default password for the MySQL server Root user account.

See [“Changing the MySQL Root Account Password \(CTPView Server Menu\)”](#) on page 33.

- Configure the server to operate on your network.

See [“Configuring the Network Access \(CTPView Server Menu\)”](#) on page 33.

- Create a self-signed Web certificate.

See [“Creating a Self-Signed Web Certificate \(CTPView Server Menu\)”](#) on page 34.

- Update the CTPView software to ensure that you have the latest features.

See [“Updating the CTPView Software”](#) on page 36.

- Verify that you can log in to the CTPView GUI from your Web browser.

See [“Logging In with a Browser \(CTPView\)”](#) on page 36.

- Change the default password for the CTPView GUI default user account.

See [“Changing the CTPView GUI Default User Account Password \(CTPView\)”](#) on page 37.

- Create at least one global administrative account to access the CTPView Admin Center in the CTPView GUI.

See [“Creating a New Global_Admin Account \(CTPView\)”](#) on page 37.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS](#) on page 14

Preparing a New Server

When you receive a new CTPView server, you must perform some physical tasks before proceeding.

To prepare a new server for use:

1. If you wish to install the server in an equipment rack, follow the instructions provided in the *Rack Installation Guide* that is included with the server.

2. Connect a monitor and keyboard to the server.

The server's serial COM1 port connection has the following configuration:

- Speed—9600 bps
- Data bits—8
- Parity—none
- Stop bits—1

3. Connect the server to the appropriate Ethernet network through the 10/100Base-T port labeled 1.

4. Verify that all ground and power connections to the server chassis are secure. Power on the server and monitor the front panel LEDs to verify that the server boots properly.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)

Changing the BIOS Menu Password (CTPView Server CLI)

For security purposes, change the default password for BIOS menu access. This account has no username associated with it. The BIOS menu password should conform to your local password requirements.



BEST PRACTICE: Change the BIOS menu password at least yearly and whenever administrators change.

To change the BIOS menu password:

1. Power on or reboot the server.
2. During the boot process, press F2 while the Dell logo is displayed on the monitor. The boot process continues and displays several messages in turn on the screen.
3. Enter the default password when the process pauses and displays "Enter Setup Password."

For the default BIOS menu password, see "[Default CTPOS and CTPView Accounts and Passwords](#)" on page 43.

4. At the BIOS menu, select **System Security** and press Enter.
 5. Highlight **Setup Password**—be sure that you have not selected **System Password**—and press Enter.
 6. Enter your new BIOS password, reenter it, and then Press Enter to continue.
 7. Press Esc.
 8. In the window that opens, select **Save Changes and Exit** and press Enter.
- The server restarts.

**Related
Documentation**

- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Changing the Server's Default User Account Password (CTPView Server CLI)

For security purposes, change the default password for the server's default user account. You can choose instead to delete the default user account when all other administrative configuration tasks have been completed.



CAUTION: Do not delete the default user account until after you have created another user account. Otherwise, you will not be able to log in to the server.

To change the password for the server's default user account:

1. Log in to the CTPView server as the default user, using either a directly connected keyboard and monitor or an SSH application over your network.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)” on page 33](#).

For the default account username and password, see [“Default CTPOS and CTPView Accounts and Passwords” on page 43](#). You cannot log in using the root account.

2. Enter **passwd**.
3. When prompted, enter the new password for the default user account.

**Related
Documentation**

- [Configuring the CTPView Administrative Settings on page 27](#)
- [CTPOS and CTPView Software Password Requirements on page 46](#)

Changing the Server's Root Account Password (CTPView Server CLI)

For security purposes, change the default password for the server's root user account. The root account password should conform to your local password requirements.



BEST PRACTICE: Change the root account password at least yearly and whenever administrators change.

To change the root account password:

1. Log in to the CTPView server as a non-root user, using either a directly connected keyboard and monitor or an SSH application over your network.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)” on page 33](#).

2. Enter **su -** to switch to the root account.
3. Enter the default root password.

For the default root password, see [“Default CTPOS and CTPView Accounts and Passwords” on page 43](#). You cannot log in using the root account.

4. Enter **passwd**.
5. Enter your new password.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Changing the GRUB Boot Loader Password (CTPView Server Menu)

For security purposes, change the default password for the GRUB Boot Loader menu.



BEST PRACTICE: Change the GRUB Boot Loader password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)” on page 33](#).

To change the GRUB Boot Loader password:

1. From the CTPView Configuration Menu, select **Option 8 (GRUB Functions)**.
2. Select **1) Change GRUB password**.
3. Follow the prompts to complete changing the password.

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Changing the MySQL Apache Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server Apache user account.



BEST PRACTICE: Change the MySQL Apache password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)” on page 33](#).

To change the MySQL Apache password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **2) Change MySQL Apache password**.
3. Follow the prompts to complete changing the password.

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)

- [Changing Passwords to Improve Access Security on page 139](#)

Changing the MySQL Root Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server root user account.



BEST PRACTICE: Change the MySQL Root Account password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)” on page 33](#).

To change the MySQL root account password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **1) Change MySQL root password**.
3. Follow the prompts to complete changing the password.

Related Documentation

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Configuring the Network Access (CTPView Server Menu)

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address.

To configure server access to your network:

1. From the CTPView Configuration Menu, select **2) System Configuration** and enter **y** to continue.
2. Select **1) Display Current Configuration** to review the current configuration.
3. Use options **2)** through **5)** to configure the server to operate on your network.
4. Exit the submenu to implement your changes.

**Related
Documentation**

- [Configuring the CTPView Administrative Settings on page 27](#)

Creating a Self-Signed Web Certificate (CTPView Server Menu)

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To create a self-signed Web certificate:

1. From the CTPView Configuration Menu, select **9) AAA Functions**.

The AAA functions for CTPView can be viewed and set in the AAA sub-menu of the CLI menu script. Only System Administrators have authorization to view or modify the AAA functions. Configuration of the CTPView AAA functions has three major components:

- Configuring the global configuration parameters, for example entering the IP addresses of the RADIUS servers you want to use for authentication.
- Configuring the global configuration parameters, for example entering the IP addresses of the TACACS+ servers you want to use for authentication.
- Then selecting the options which the various access methods will use. For example, enabling HTTPS – CAC/PKI with OCSP certificate validation.

2. Select **7) CAC/PKI Configuration**.

This selection enables you to perform CAC/PKI configuration (HTTPS). CTPView is built with a default server certificate installed which is sufficient for testing purposes only. Before deploying the server in a production environment you must obtain and install a server certificate issued by a Trusted Signing CA. If you attempt to access multiple CTPView servers running on CentOS which are still using their default self-signed certificates you may be denied access by your browser because it will detect that multiple servers are presenting certificates with the same serial number. Obtaining and installing a signed server certificate is a simple process. First, you must create a certificate signing request (CSR) for your server which you will present to the Trusted Signing CA you have selected to use. To start, go to the CAC/PKI Configuration menu. The path is menu > AAA Functions > CAC/PKI Configuration.

3. In the CAC/PKI Menu, select **2) Self-Sign CSR**.

While it is preferred that you have your server CSR signed by a Trusted Signing CA, where that is not possible you may generate a self-signed server certificate using the CTPView_CA issued by Juniper Networks. Note that if you use the CTPView_CA certificate, the self-signed certificate will generate an error in client browsers to the effect that the signing certificate authority is unknown and not trusted. However you will be able to successfully complete the connection. To use the CTPView_CA to sign your CSR select Self-Sign CSR from the CAC/PKI Menu.

Enter the CSR filename and the utility will create a signed server certificate which you can then import into the certificate database. No additional Chain of Trust certificates are required to use the CTPView_CA. As when creating a CSR, repeating the signing process has no effect on the configuration or operation of the server since a separate process is required to import the certificate. When the Trusted Signing CA sends you the signed server certificate you will need to import it into your server's certificate database. You will also need to import all of the certificates that make up the Chain of Trust for your new server certificate. These are available from your Trusted Signing CA. Copy all of the certificates into the /tmp directory of the server. They can have any filename and file extension.

4. Enter answers for each question that is subsequently displayed.

You are required to enter the Encryption Key Size, Common Name, Organization Name and Country. You may also include any combination of these optional fields: Organizational Unit (3 possible fields), State, and City/Town. The script will generate a random seed to use when creating the CSR by using the timing of keystrokes on your keyboard. The CSR will be a RSA certificate in ASCII format (i.e. plain text), using either 1024 or 2048 bit encryption depending on your choice when creating the CSR. The CSR name will be <Common Name>.csr and is created in the /tmp directory on the server. If you want to change any of the information you entered when creating the CSR simply create a new CSR. Creating a CSR has no effect on the configuration or operation of the server. Send the CSR which you created to your Trusted Signing CA. You may be asked to send the CSR as an email attachment or to paste the CSR into a web form. You can do that by opening the CSR file with a text editor, such as WordPad or VI, then use the copy and paste editing functions to transfer the new certificate request to the web form.



NOTE: For **Common Name**, enter the IP address of the server. Otherwise, your users' browsers will report a domain name mismatch when users connect to the server.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)

Updating the CTPView Software

or a new server, upgrade to the latest version of the CTPView software to ensure that you have the latest features available.

To update the CTPView software:

1. Use your Juniper Networks customer support username and password to log in to the CTP support site at <https://www.juniper.net/customers/csc/software/ctp/>.
2. If present, download an update for your version of the CTPView software and the associated Release Notes.

The CTPView version number is displayed in the heading of the CTPView Configuration Menu utility.

3. Upgrade the CTPView software according to the instructions presented in “[Upgrading Only the CTPView Software](#)” on page 23.



NOTE: Always refer to the Release Notes associated with the update. These Release Notes may contain information that supersedes the information in that topic.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)

Logging In with a Browser (CTPView)

Verify that you can log in to the CTPView software from a Web browser. You must be able to access the CTPView software to complete the administrative configuration.

To log in to the server with a browser:

1. In the address bar of a browser enter the address <https://your-server-ip-address>.
2. Accept the certificate when your browser warns that the security certificate presented by the website was not issued by a trusted certificate authority.
3. When the CTPView login page appears, log in as the default CTPView user for the Global_Admin account.

For the default password, see “[Default CTPOS and CTPView Accounts and Passwords](#)” on page 43.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)

Changing the CTPView GUI Default User Account Password (CTPView)

For security purposes, change the default password for the CTPView GUI default user account.

To change the CTPView default user account password:

1. Log in to the CTPView GUI with the default username and password.

For the default username and password, see [“Default CTPOS and CTPView Accounts and Passwords” on page 43](#). You cannot log in using the root account.

2. Click **Edit My Account**.
3. Type the current password and the new password, and reenter the new password.
Click **Password Help** to learn how to create an acceptable CTPView password.
4. Click **Update Password**.

Related Documentation

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)

Creating a New Global_Admin Account (CTPView)

A global administrative (Global_Admin) account is required to access the CTPView Admin Center. Do not use the default user account for routine access. Create a separate account for each user that requires administrative access. Beginning with CTPView 2.2R2, the security-enhanced interface allows only one active session per username. When a second user attempts to log in with the same username in an active session, both IP addresses for the clients and the username are locked from access for a preset lockout period.

To create a Global_Admin account:

1. Log in to the CTPView GUI with the default username and password.
For the default username and password, see [“Default CTPOS and CTPView Accounts and Passwords” on page 43](#).
2. Click **Admin Center**.
3. Select **Users > All Users**.
4. Type the desired username, group name, and password, and click **Add User**.
5. Select **Users > Modify User Properties**.
6. Select the **Global_Admin** user level.
7. Log out of CTPView and use the new account to log back in.

Related Documentation

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)

CHAPTER 6

Upgrade Tasks for CTPOS

- Using the CTPView Server Software to Update CTPOS (CTPView) on page 39
- Burning an Image of CTPOS to a CompactFlash Card (CTPView Server Menu) on page 40
- Burning CTPOS Images to a CompactFlash Card (CTPView Server CLI) on page 40

Using the CTPView Server Software to Update CTPOS (CTPView)

You can use the CTPView software to distribute and install CTPOS update archive files on the CTP platforms in your network.

To update CTPOS:

1. Access the CTP platform software download page at the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>.
2. Use a Secure Copy Protocol (SCP) program to copy the web archive file to the **ctp** directory on the CTPView server.

You must be a member of the **server** group to access this directory. The CTPView server automatically checks and modifies the copied file's ownership and permissions as necessary.

3. Log in to the CTPView GUI.
4. In the side pane, select **Node > Maintenance**.
5. Click **Upgrade CTP Software**.

The Upgrade CTP Software window is displayed.

6. Select the desired archive file from the list.
7. Click the name of the platform you want to update.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

8. Click **Upgrade CTP(s)**.

The selected CTP platforms are upgraded sequentially. A progress window shows the status of the upgrade.

- Related Documentation**
- [Default CTPOS and CTPView Accounts and Passwords on page 43](#)

Burning an Image of CTPOS to a CompactFlash Card (CTPView Server Menu)

You can burn CTPOS images to a CompactFlash Card either from the CTPView Server Menu or from the CTPView Server CLI. This section describes how to burn an image of CTPOS from the CTPView Server Menu.

Before using CTPView to burn CTP software images onto CompactFlash cards, you must copy the appropriate CTP image files to the proper directory on the CTPView server. Released versions of CTP operating system software images are available for download from the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>. You need your customer support username and password to access this site.

Place the CTP flash image file on the CTPView server in the `/var/www/html/flash/` directory. To copy software into this directory, you must be a root user or a member of the UNIX group `server`, such as the default user `juniper`. You do not need to modify the file's ownership and permissions after you copy it into the `/flash` directory.

Before you begin, log in to the CTPView server and access the CTPView Server Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To burn an image of the CTPOS:

1. From the CTPView Server Configuration Menu, select **4) Advanced Functions**.
2. Select **8) Burn CTPOS Flash Image**.

- Related Documentation**
- [Burning CTPOS Images to a CompactFlash Card \(CTPView Server CLI\) on page 40](#)

Burning CTPOS Images to a CompactFlash Card (CTPView Server CLI)

Before using CTPView to burn CTP software images onto CompactFlash cards, you must copy the appropriate CTP image files to the proper directory on the CTPView server. Released versions of CTP operating system software images are available for download from the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>. You need your customer support username and password to access this site.

Place the CTP flash image file on the CTPView server in the `/var/www/html/flash/` directory. To copy software into this directory, you must be a root user or a member of the UNIX group `server`, such as the default user `juniper`. You do not need to modify the file's ownership and permissions after you copy it into the `/flash` directory.

You must have physical access to the CTPView server to perform this procedure.

To burn a CTPOS image to a CompactFlash card:

1. Place the new CompactFlash card into a USB CompactFlash card adapter, and insert the adapter into one of the USB ports on the CTPView server.

The CTPView server automatically mounts the adapter.

2. Log in to the CTPView server and switch to the root account.

Use a directly connected monitor and keyboard or use SSH from a remote computer to log in to the server.

3. Change directories to **/var/www/html/flash**.

4. Enter **./burn flash_version**.

The image filename is **flash_version**. If you fail to include the version when you enter the command, the CTPView server displays usage instructions and a list of available flash images.

5. Answer the screen prompts to complete the process.

6. Log out of the server and remove the USB CompactFlash card adapter.

**Related
Documentation**

- [Burning an Image of CTPOS to a CompactFlash Card \(CTPView Server Menu\) on page 40](#)

CHAPTER 7

Default Accounts and Passwords

- [Default CTPOS and CTPView Accounts and Passwords on page 43](#)
- [Changing the User Password \(CTP Menu\) on page 44](#)
- [CTPOS and CTPView Software Password Requirements on page 46](#)

Default CTPOS and CTPView Accounts and Passwords

This topic lists the default accounts and passwords for the CTP Series platforms and the CTPView server.

[Table 1 on page 43](#) lists the default accounts and passwords to access the CTPView server.

Table 1: CTPView Server Default Accounts and Passwords

Application	Account	Default Username	Default Password
Server (CLI)	BIOS menu	Not applicable	CTPView-2-2
Server (CLI)	GRUB boot loader	Not applicable	CTPView-2-2
Server (CLI)	user account	juniper_sa (lowercase j)	CTPView-2-2
Server (CLI)	root account	root	CTPView-2-2
CTPView (browser)	Global_Admin account	Juniper (uppercase J)	CTPView-2-2
MySQL (CLI)	root account	root	CTPView-2-2
MySQL (CLI)	Apache account	ctpview_mysql	CTPView-2-2



NOTE: Upgrading from a CTPView software version lower than 2.2 to the current software does not change the existing server passwords or accounts except to add the *juniper* user account. However, all the user accounts that existed in the lower version of the CTPView software are removed. In the higher versions, browser access to the CTPView server is through a login interface, which requires that an administrator create new usernames and passwords.

Table 2 on page 44 lists the default accounts and passwords to access CTPOS on the CTP Series platforms.

Table 2: CTPOS Default Account and Password

Application	Account	Default Username	Default Password
CTP platform	CLI menu	ctp	ctp
CTP platform	System administrator—Member of the system administrator class. Certain tasks require a user in this class when the CTPOS security level is set to high.	ctp_sa	ctp_sa
CTP platform	System auditor—Enables the user to view logs for the platform when the CTPOS security level is set to high.	ctp_aud	ctp_aud

Related Documentation

- [Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10](#)
- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Upgrading Only the CTPView Software on page 23](#)
- [Setting a New Password for a Nonroot User Account \(CTPView Server CLI\) on page 153](#)
- [Setting a New Password for a Root User Account \(CTPView Server CLI\) on page 154](#)
- [CTPOS and CTPView Software Password Requirements on page 46](#)

Changing the User Password (CTP Menu)

You can change your password by logging in to the CTP system. The new password must meet the requirements that are specified in the Configuration Security Profile menu.

To change your password by using the CTP Menu:

1. From the Main Menu, select **5) Node Operations**.
2. Select **13) Set your password**.

The CTP system displays the password requirements based on your security profile. [Table 3 on page 45](#) lists the security profiles and their password requirements.

The minimum password length is 5.

Passwords are required to have a minimum of:

0 lowercase letter(s),

0 uppercase letter(s),

0 numeral(s) and

0 other character(s).

The number of allowed retries is 3.

Changing password for user ctp.

Changing password for ctp.

(current) UNIX password:

Follow the onscreen instructions to set the new password.

The following message is displayed if you do not have the permissions required to change password:

This user does not have privileges to do this.

Table 3: Requirements for New Password

Password Attributes	Units	Security Profiles and Their Attribute Range in CTPView		Security Profiles and Their Attribute Range in CTPOS	
		High	Low	High	Low/Very Low
Minimum length	char	15–64	5–64	15–256	15–256
Maximum length	char	15–64	5–64	256	256
Minimum lowercase characters	char	1–10	0–10	1–15	0–15
Minimum uppercase characters	char	1–10	0–10	1–15	0–15
Minimum digits	char	1–10	0–10	1–15	0–15
Minimum other characters	char	1–10	0–10	1–15	0–15
Contains username	–	no	no	no	no
Checked with cracklib library	–	yes	no	yes	yes
Min required new characters	number	5	0	5	5
Allowed authentication retries	–	1–3	1–3	1–3	1–3
Lockout after login failure	seconds	60-indefinite	60-indefinite	900	900

- Related Documentation**
- [CTPOS and CTPView Software Password Requirements on page 46](#)
 - [Default CTPOS and CTPView Accounts and Passwords on page 43](#)
 - [Managing User Passwords \(CTPView Server Menu\) on page 111](#)

CTPOS and CTPView Software Password Requirements

Certain requirements apply to passwords for the following:

- CTPOS
- CTPView server shell access accounts
- CTPView GUI access accounts
- MySQL accounts
- GRUB Boot loader

New passwords must include the following:

- From 15 to 56 characters in total
- At least one lowercase letter
- At least one uppercase letter
- At least one numeral
- At least one of the following nonalphanumeric characters: ~ ! @ # % & - _ = { } [] ,

New passwords must not include either of the following:

- The username as part of the password.
- More than two adjacent repeated characters.

- Related Documentation**
- *CTPView Network Management System Administration*
 - [Managing CTPView Users with the CTPView Admin Center on page 51](#)
 - [Adding New CTPView Users \(CTPView\) on page 53](#)
 - [Changing the MySQL Apache Account Password \(CTPView Server Menu\) on page 32](#)
 - [Changing the MySQL Root Account Password \(CTPView Server Menu\) on page 33](#)
 - [Changing the GRUB Boot Loader Password \(CTPView Server Menu\) on page 31](#)
 - [Changing the User Password \(CTP Menu\) on page 44](#)
 - [Setting a New Password for a Nonroot User Account \(CTPView Server CLI\) on page 153](#)
 - [Setting a New Password for a Root User Account \(CTPView Server CLI\) on page 154](#)
 - [Default CTPOS and CTPView Accounts and Passwords on page 43](#)

CHAPTER 8

Understanding CTPView Upgrade Files

- Understanding CTPView Software Upgrade Files on page 47

Understanding CTPView Software Upgrade Files

The CTPView software upgrade file that you download from the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw> depends on the CTPView server's operating system (OS), the version of CTPView software currently installed on the server, and the CTPView software release that you want to upgrade to. Table 4 on page 47 lists the combinations of OS and CTPView software and the associated upgrade file. The *CTPView Release Notes* for the version you are upgrading to also describes the upgrade files required for various combinations of currently installed CTPView server OS and CTPView software.

Table 4: CTPView Software Upgrade Files

CTPView Server OS	Installed CTPView Release	Upgrade to CTPView Release	Archive File for Upgrade	Server Reboots During Upgrade?
CentOS 5.3	4.2 or later	4.4R1	web_update_4.4R1_120731.tgz	No
	4.1 or earlier	4.4R1	ctpview_complete_centos_4.4R1_120731.tgz	Yes
FC9	3.4R2 or later	4.4R1	web_update_4.4R1_120731.tgz	No
	3.4R1 or earlier	4.4R1	ctpview_complete_fc9_4.4R1_120731.tgz	Yes
FC9	3.3Rx	3.4R1	ctpview_fc9_complete_3.4R1_090715.tgz	No
FC9	3.2Rx	3.4R1	ctpview_fc9_complete_3.4R1_090715.tgz	Yes
FC9	3.2R3 or higher	3.3R2	web_fcX_3.3R2_090616.tgz	No
FC9	3.2R3 or higher	3.2R4	web_fcX_3.2R4_090903.tgz	No
FC9	3.2R3 or higher	3.2R3	web_fcX_3.2R3_090402.tgz	No
FC9	3.2R1 or 3.2R2	3.3R2	ctpview_fc9_complete_3.3R2_090616.tgz	Yes

Table 4: CTPView Software Upgrade Files (*continued*)

CTPView Server OS	Installed CTPView Release	Upgrade to CTPView Release	Archive File for Upgrade	Server Reboots During Upgrade?
FC9	3.2R1 or 3.2R2	3.2R4	ctpview_fc9_complete_3.2R4_090903.tgz	Yes
FC9	3.2R1 or 3.2R2	3.2R3	ctpview_fc9_complete_3.2R3_090402.tgz	Yes
FC9	3.2R1	3.2R2	ctpview_fc9_complete_3.2R2_090112.tgz	Yes
FC4	2.2R2 or higher	3.4R1	web_fcX_3.4R1_090715.tgz	No
FC4	2.2R2 or higher	3.3R2	web_fcX_3.3R2_090616.tgz	No
FC4	2.2R2 or higher	3.2R4	web_fcX_3.2R4_090903.tgz	No
FC4	2.2R2 or higher	3.2R3	web_fcX_3.2R3_090402.tgz	No
FC4	2.2R2 or higher	3.2R2	web_fcX_3.2R2_090112.tgz	No
FC4	2.2R1 or lower	3.4R1	ctpview_fc4_complete_3.4R1_090715.tgz	Yes
FC4	2.2R1 or lower	3.3R2	ctpview_fc4_complete_3.3R2_090616.tgz	Yes
FC4	2.2R1 or lower	3.2R4	ctpview_fc4_complete_3.2R4_090903.tgz	Yes
FC4	2.2R1 or lower	3.2R3	ctpview_fc4_complete_3.2R3_090402.tgz	Yes
FC4	2.2R1 or lower	3.2R2	ctpview_fc4_complete_3.2R2_090112.tgz	No
FC4	2.5Rx	2.5R4	web_fc4_2.5R4_090105.tgz	No
FC4	2.4Rx or lower	2.5R4	ctpview_fc4_complete_2.5R4_090105.tgz	No
FC1		3.2R2	Refer to 3.2 manuals	
FC1		2.5R4	refer to 2.5 manuals	

Related Documentation • [Upgrading Only the CTPView Software on page 23](#)

PART 3

Administration

- [Managing and Displaying Users \(CTPView\) on page 51](#)
- [Managing the CTPView Server \(CTPView\) on page 65](#)
- [Monitoring CTP Platforms \(CTPView\) on page 85](#)
- [Changing CTPView GUI Settings on page 99](#)
- [Managing and Displaying Users \(CTPView Server Menu\) on page 103](#)
- [Managing the CTPView Server \(CTPView Server Menu\) on page 123](#)
- [Restoring Default Values on the CTPView Server on page 133](#)
- [Changing Administrative Passwords to Improve Access Security on page 139](#)
- [Using Third-Party Software on CTPView Servers on page 145](#)

CHAPTER 9

Managing and Displaying Users (CTPView)

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)
- [Accessing the CTPView Admin Center \(CTPView\) on page 52](#)
- [Monitoring CTPView Users \(CTPView\) on page 53](#)
- [Adding New CTPView Users \(CTPView\) on page 53](#)
- [Modifying CTPView User Properties \(CTPView\) on page 54](#)
- [Monitoring CTPView Groups \(CTPView\) on page 54](#)
- [Modifying CTPView User Group Affiliation \(CTPView\) on page 54](#)
- [Adding a New CTPView User Group \(CTPView\) on page 55](#)
- [Modifying CTPView User Group Default Properties \(CTPView\) on page 55](#)
- [Prohibiting and Reinstating CTPView Access by Users \(CTPView\) on page 56](#)
- [Deleting Users and Groups \(CTPView\) on page 57](#)
- [Managing User Passwords \(CTPView\) on page 58](#)
- [Configuring User Login Properties \(CTPView\) on page 59](#)
- [Understanding CTPView GUI User Levels on page 62](#)
- [CTPOS and CTPView Software Password Requirements on page 62](#)

Managing CTPView Users with the CTPView Admin Center

The CTPView Admin Center provides a central location for managing users, passwords, groups, and access for CTPView users. Only Global_Admin users can create, modify, and delete CTPView user accounts.

You can perform the following tasks in the Admin Center:

- [Accessing the CTPView Admin Center \(CTPView\) on page 52](#)
- [Monitoring CTPView Users \(CTPView\) on page 53](#)
- [Adding New CTPView Users \(CTPView\) on page 53](#)
- [Modifying CTPView User Properties \(CTPView\) on page 54](#)
- [Monitoring CTPView Groups \(CTPView\) on page 54](#)

- [Modifying CTPView User Group Affiliation \(CTPView\) on page 54](#)
- [Adding a New CTPView User Group \(CTPView\) on page 55](#)
- [Modifying CTPView User Group Default Properties \(CTPView\) on page 55](#)
- [Prohibiting and Reinstating CTPView Access by Users \(CTPView\) on page 56](#)
- [Deleting Users and Groups \(CTPView\) on page 57](#)
- [Managing User Passwords \(CTPView\) on page 58](#)
- [Configuring User Login Properties \(CTPView\) on page 59](#)
- [Unlocking a User Account \(CTP Menu\) on page 105](#)

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)

Accessing the CTPView Admin Center (CTPView)

The CTPView Admin Center provides a central location for managing users, passwords, groups, and access for CTPView users. Only Global_Admin users can create, modify, and delete CTPView user accounts.

To access the CTPView Admin Center:

- On the CTPView Login Page, click **Admin Center**. The CTPView Login Administration page is displayed. This documentation refers to this page as the CTPView Admin Center.

To display all configuration choices available in the CTPView Admin Center:

- From the Admin Center, click **Display All**.

Although all configuration choices are listed, clicking the button to make any configuration change returns you to the Admin Center display for only that configuration choice.

To block global access to the CTPView Admin Center:

1. From the Admin Center, click **Access To CTPView is ALLOWED**.
2. Confirm your decision when prompted.

To reinstate global access to the CTPView Admin Center:

1. From the Admin Center, click **ALL ACCESS To CTPView Is BLOCKED**.
2. Confirm your decision when prompted.

**Related
Documentation**

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Monitoring CTPView Users (CTPView)

To display all CTPView users that are currently logged in to the server through the CTPView GUI:

- From the Admin Center, select **Users > Active Users** to display all users that are currently logged in.

A view-only table lists the username, the user browser's IP address, the time the browser session began, the time of last activity, and the current period of inactivity. Users logged in through an SSH connection to the CTPView server are not displayed; see "[Managing CTPView Users \(CTPView Server Menu\)](#)" on page 104 for information about viewing these users.

To display all CTPView users regardless of login status:

- From the Admin Center, select **Users > All Users**.

This view-only table displays all users who are in the CTPView user database, as well as each user's group affiliation, user level, and the time of last login.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Adding New CTPView Users (CTPView)

To add a new CTPView user:

1. From the Admin Center, select **Users > Add New User**.
2. Type a username for the new user.

The username must be at least 6 characters and no more than 30 characters in length. The name can include alphanumeric characters and the following nonalphanumeric characters:

~ ! @ # % & - _ = { } [] ,

3. Select a group for the new user from the list.

The new user is assigned the properties associated with this group.

4. Type a password for the user in both fields.

Click **Password Help** to display the password requirements. The user is forced to change this password at the first login.

5. Click **Add User**.

The new user is immediately added to the **All Users** table.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)
- [CTPOS and CTPView Software Password Requirements on page 46](#)

Modifying CTPView User Properties (CTPView)

CTPView users are assigned to a group when created, and inherit the properties associated with that user group. You can override these properties for any or all members of a group.

To modify CTPView user properties:

1. From the Admin Center, select **Users > Modify User Properties**.
2. Select a username from the list to display the user's current properties.
3. (Optional) Select a new user level.
4. (Optional) Select the maximum number of days allowed between logins.
5. (Optional) Select the minimum number of days allowed between password changes.
6. (Optional) Select the number of days a new password is valid.
7. (Optional) Select the number of days before password expiration that a warning is first provided.
8. (Optional) Select the number of days the user can still log in after a password expires before access is blocked.
9. (Optional) Type a date on which access is blocked from that date forward.

This field overrides all other properties.

10. Click **Update User Properties**.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Monitoring CTPView Groups (CTPView)

To display all CTPView user groups:

1. From the Admin Center, select **Groups > All Groups**.

The view-only table displays all groups that are currently configured. The table also lists the default user properties configured for the group. You can configure individual user properties to override the group defaults.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Modifying CTPView User Group Affiliation (CTPView)

CTPView users are assigned to a group when created. Typically, groups are used to group users that share a common set of user properties. However, shared properties are not a requirement. If desired, user groups can simply label a set of users without regard to their individual user properties.



NOTE: Changing a user's group affiliation does not alter the user's current properties.

To modify CTPView user properties:

1. From the Admin Center, select **Users > Modify User's Group Affiliation**.
2. Select a username from the list to display the user's current group affiliation.
3. Select a new group from the list.
4. Click **Update Group**.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Adding a New CTPView User Group (CTPView)

To add a new CTPView user group:

1. From the Admin Center, select **Groups > Add New Group**.
2. Enter a group name.

The group name must be at least 6 characters and no more than 30 characters in length. The name can include alphanumeric characters and the following nonalphanumeric characters:

~ ! @ # % & - _ = { } [] ,

3. Select a default user level for members of the group.
4. Click **Add Group**.

Modifying CTPView User Group Default Properties (CTPView)

CTPView users are assigned to a user group when created and by default inherit the properties associated with the group. You can override these properties for any or all members of a group.

To modify CTPView user properties:

1. From the Admin Center, select **Groups > Modify Group Properties**.
2. Select a group name from the list to display the group's current properties.
3. (Optional) Select a default user level.
4. (Optional) Select the maximum number of days allowed between logins.
The default is 30 days.
5. (Optional) Select the minimum number of days allowed between password changes.
The default is 1 day.

6. (Optional) Select the number of days a new password is valid.

The default is 60 days.

7. (Optional) Select the number of days before password expiration that a warning is first provided.

The default is 7 days.

8. (Optional) Select the number of days the user can still log in after a password expires before access is blocked.

The default is 14 days.

9. (Optional) Type a date on which access is blocked from that date forward.

This field overrides all other properties.

10. (Optional) Select **Update current members** to apply these changes to all members of the group.

If you do not select this option, the group changes do not affect any current member of the group.

11. Click **Update Group Properties**.

**Related
Documentation**

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Prohibiting and Reinstating CTPView Access by Users (CTPView)

You can prevent individual users from accessing the CTPView software until you reinstate that access.

- [Displaying Prohibited CTPView Users \(CTPView\) on page 56](#)
- [Prohibiting User Access to CTPView \(CTPView\) on page 56](#)
- [Reinstating Prohibited CTPView Users \(CTPView\) on page 57](#)

Displaying Prohibited CTPView Users (CTPView)

To display currently prohibited CTPView users:

- From the Admin Center, select **Prohibit > Current Prohibited Users**.

The view-only table displays all prohibited users, the time each was prohibited, who prohibited the user, and the last time the user access the CTPView software.

Prohibiting User Access to CTPView (CTPView)

To prohibit a CTPView user:

1. From the Admin Center, select **Prohibit > Designate Prohibited User**.
2. Select the user from the list.
3. Click **Submit Prohibited User**.

Reinstating Prohibited CTPView Users (CTPView)

To reinstate a currently prohibited CTPView user:

1. From the Admin Center, select **Prohibit > Reinstate Prohibited User**.
2. Select the user from the list.
3. Click **Reinstate Prohibited User**.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Deleting Users and Groups (CTPView)

You can delete active and inactive CTPView users from the user database. Inactive users are those who have not logged in within a specified number of days; the default is 365 days. Active users have logged in more recently than the default. You can also delete user groups.

- [Deleting Active CTPView Users \(CTPView\) on page 57](#)
- [Deleting Inactive CTPView Users \(CTPView\) on page 57](#)
- [Deleting Prohibited CTPView Users \(CTPView\) on page 58](#)
- [Deleting CTPView Groups \(CTPView\) on page 58](#)

Deleting Active CTPView Users (CTPView)

To delete an active CTPView user:

1. From the Admin Center, select **Delete > Delete User**.
2. Select the user from the list.



NOTE: Prohibited and inactive users do not appear on the list and must be deleted separately.

3. Click **Delete User**.

Deleting Inactive CTPView Users (CTPView)

To delete an inactive CTPView user:

1. From the Admin Center, select **Delete > Inactive User**.
2. Select the number of days without a login to designate inactive users.
3. Click **Delete Inactive Users**.

Deleting Prohibited CTPView Users (CTPView)

To delete a currently prohibited CTPView user from the database:

1. From the Admin Center, select **Prohibit > Delete Prohibited User**.
2. Select the user from the list.
3. Click **Delete Prohibited User**.

Deleting CTPView Groups (CTPView)

To delete a CTPView user group and all its members:

1. From the Admin Center, select **Delete > Delete Group**.
2. Select the group from the list.
3. Click **Delete Group**.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Managing User Passwords (CTPView)

You can limit how frequently a user can reuse a password, exclude passwords, reinstate excluded passwords, and specify the rules for forming passwords.

- [Limiting Password Reuse \(CTPView\) on page 58](#)
- [Excluding Passwords from Use \(CTPView\) on page 58](#)
- [Reinstating Excluded Passwords \(CTPView\) on page 59](#)
- [Changing Requirements for New Passwords \(CTPView\) on page 59](#)

Limiting Password Reuse (CTPView)

To limit how frequently a password can be reused:

1. From the Admin Center, select **Passwords > Re-Use Password Limit**.
2. Select the number of new passwords a user must create before a given password can be re-used.
3. Click **Set Password Re-Use Limit**.

Excluding Passwords from Use (CTPView)

To exclude certain passwords from use:

1. From the Admin Center, select **Passwords > Excluded Passwords**.
2. Type a password to add to the list of excluded passwords.
3. Click **Add Password to List**.

Reinstating Excluded Passwords (CTPView)

To reinstate a previously excluded password for use:

1. From the Admin Center, select **Passwords > Excluded Passwords**.
2. Select the password from the list of excluded passwords.
3. Click **Reinstate Selected Passwords**.

Changing Requirements for New Passwords (CTPView)

To change the requirements for new passwords (current passwords are not affected):

1. From the Admin Center, select **Passwords > Modify Password Requirements**.
2. (Optional) Select the minimum password length, in the range 15 through 56.
3. (Optional) Select the maximum password length, in the range 15 through 56.
The default is 56 characters.
4. (Optional) Select the minimum number of lowercase letters, in the range 1 through 56.
5. (Optional) Select the minimum number of uppercase letters, in the range 1 through 56.
6. (Optional) Select the minimum number of numerals, in the range 1 through 56.
7. (Optional) Select the minimum number of nonalphanumeric characters, in the range 1 through 56.
8. Click **Update Password Properties**.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)
- [CTPOS and CTPView Software Password Requirements on page 46](#)

Configuring User Login Properties (CTPView)

You can configure a number of properties that affect how users log in to and log out of the CTPView software.

- [Logging Out a CTPView User \(CTPView\) on page 60](#)
- [Configuring Automatic Logout for a CTPView User \(CTPView\) on page 60](#)
- [Configuring the Number of Login Attempts Allowed Before Lockout \(CTPView\) on page 60](#)
- [Configuring a Lockout Period for CTPView Users \(CTPView\) on page 60](#)
- [Clearing CTPView User Counters \(CTPView\) on page 61](#)
- [Reinstating Locked-Out IP Addresses \(CTPView\) on page 61](#)

- [Creating an Access Filter to Allow or Deny IP Addresses \(CTPView\)](#) on page 61
- [Removing an IP Access Filter \(CTPView\)](#) on page 61

Logging Out a CTPView User (CTPView)

To log out a CTPView user:

1. From the Admin Center, select **Login/Logout > Logout Users**.
2. Select the user from the list.
3. Click **Logout Selected Users**.

Configuring Automatic Logout for a CTPView User (CTPView)

To specify that a CTPView user is automatically logged out after a certain period:

1. From the Admin Center, select **Login/Logout > Auto Logout**.
2. Select the inactivity period from the list.
3. Click **Set Auto Logout Period**.

Configuring the Number of Login Attempts Allowed Before Lockout (CTPView)

To specify how many times a CTPView user can attempt to log in before the login is considered to have failed and the user is locked out:

1. From the Admin Center, select **Login/Logout > Login Limit**.
2. Select the number of attempts allowed from the list.
3. Click **Set Failed Login Limit**.

Configuring a Lockout Period for CTPView Users (CTPView)

When a user exceeds the allowed number of failed login attempts or tries to open multiple CTPView sessions from unique IP addresses, the user is prevented from accessing CTPView for a lockout period.

To specify a CTPView user's lockout period:

1. From the Admin Center, select **Login/Logout > Lockout Period**.
2. Select the lockout period from the list.
3. Click **Set Lockout Period**.

Clearing CTPView User Counters (CTPView)

Two counters are associated with each CTPView user. One counter tracks the number of failed login attempts. This counter is automatically reset to zero after a successful login. The other counter tracks the number of reminders that a user receives to change the user password. This counter is automatically reset after the user has selected a new password. When either counter exceeds the allowed limit, the user is locked out of CTPView access.

To clear a user's counters:

1. From the Admin Center, select **Login/Logout > Clear Counters**.
2. Select the user from the list.
3. Click **Clear Counters**.

Reinstating Locked-Out IP Addresses (CTPView)

When a user attempts to access the CTPView software from a second IP address with a currently active username, the username and both IP addresses are locked.

To reinstate an IP address that has been locked from CTPView access:

1. From the Admin Center, select **Login/Logout > Unlock IP**.
2. Select the IP address from the list.
3. Click **Reinstate Locked IP**.

Creating an Access Filter to Allow or Deny IP Addresses (CTPView)

IP access filters enable you to specify whether users from an IP address or range of IP addresses are allowed or denied access to the CTPView software.

To create an IP access filter:

1. From the Admin Center, select **Login/Logout > IP Access Filter**.
2. Type an IP address or range of IP addresses.
3. Select whether to allow or deny that address or range access to the CTPView software.

In the case of conflict between multiple filters, a rule to deny an address or range overrides a rule that allows access.

4. Click **Add IP Range to List**.

Removing an IP Access Filter (CTPView)

To remove an IP filter:

1. From the Admin Center, select **Login/Logout > IP Access Filter**.
2. Select the IP address from the list.

3. Click **Remove IP Range From List**.

**Related
Documentation**

- [Managing CTPView Users with the CTPView Admin Center on page 51](#)

Understanding CTPView GUI User Levels

This topic describes the user security levels available in the CTPView GUI.

Three user levels are provided to enhance the security of CTPView GUI logins:

- **Net_View**—Users in this class are restricted to query-only access to CTP platforms. Early versions of the CTPView software referred to this class as query-only users. Net_View users can change their own passwords.
- **Net_Admin**—Users in this class can configure CTP platforms. They do not have permission to create or modify CTPView user accounts. Early versions of the CTPView software referred to this class as administrators. Net_Admin users can change their own passwords.
- **Global_Admin**—Users in this class have all the privileges of the Net_Admin class. They are also able to create and modify user accounts. Only members of the Global_Admin user class have access to the CTPView Admin Center, where CTPView user and password profiles are managed.

Each CTPView user has a profile that describes user properties, including user privileges and restrictions. All users are assigned to user groups. Each user group has a set of default user properties that are transferred to new users created in or assigned to that group. Global_Admin users can modify any of the user properties on a per-user basis.

CTPOS and CTPView Software Password Requirements

Certain requirements apply to passwords for the following:

- CTPOS
- CTPView server shell access accounts
- CTPView GUI access accounts
- MySQL accounts
- GRUB Boot loader

New passwords must include the following:

- From 15 to 56 characters in total
- At least one lowercase letter
- At least one uppercase letter
- At least one numeral
- At least one of the following nonalphanumeric characters: ~ ! @ # % & - _ = { } [] ,

New passwords must not include either of the following:

- The username as part of the password.
- More than two adjacent repeated characters.

**Related
Documentation**

- *CTPView Network Management System Administration*
- [Managing CTPView Users with the CTPView Admin Center on page 51](#)
- [Adding New CTPView Users \(CTPView\) on page 53](#)
- [Changing the MySQL Apache Account Password \(CTPView Server Menu\) on page 32](#)
- [Changing the MySQL Root Account Password \(CTPView Server Menu\) on page 33](#)
- [Changing the GRUB Boot Loader Password \(CTPView Server Menu\) on page 31](#)
- [Changing the User Password \(CTP Menu\) on page 44](#)
- [Setting a New Password for a Nonroot User Account \(CTPView Server CLI\) on page 153](#)
- [Setting a New Password for a Root User Account \(CTPView Server CLI\) on page 154](#)
- [Default CTPOS and CTPView Accounts and Passwords on page 43](#)

CHAPTER 10

Managing the CTPView Server (CTPView)

- Adding and Removing CTP Platforms Managed by CTPView Software (CTPView) on page 65
- Adding and Removing Host Groups (CTPView) on page 66
- Adding and Removing SNMP Communities (CTPView) on page 67
- Managing CTP Platforms in the Network (CTPView) on page 68
- Configuring Email Notifications (CTPView) on page 69
- Setting the CTPView Server Start-Up Banner (CTPView) on page 70
- Setting the CTP Platforms Login Banner (CTPView) on page 70
- Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView) on page 71
- Setting the CTPView Server Clock (CTPView) on page 72
- Setting the CTPOS Clock (CTP Menu) on page 73
- Managing NTP Servers for the CTPView Network (CTPView) on page 74
- Configuring Automatic Monitoring of CTP Platforms (CTPView) on page 77
- Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms (CTPView) on page 79
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 80
- Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView) on page 81
- Synchronizing Multiple CTPView Servers (CTPView) on page 81

Adding and Removing CTP Platforms Managed by CTPView Software (CTPView)

Before you can use CTPView to manage the CTP platforms in your network, you must configure the platform information in the CTPView software. In the context of the network, the CTP platforms are often referred to as remote hosts, nodes, and remote platforms.

To add a CTP platform to your network:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Enter a unique name for the remote host.

3. Enter a management IP address for the host.
This address is used for the CTPView management connection to the host.
4. If the host is running CTPOS 4.1 or lower, select the checkbox.
5. Enter a password to be used by the CTPView software when accessing the host.
6. Select a group to associate with the host; only the **default** group is available if no other groups have been configured.
7. Select the model number for the host.
8. Include or exclude the host from monitoring by the CTPView software by selecting **Yes** or **No**.
9. Select how the CTPView software accesses the host when the host has been including for network monitoring.
10. Select the SNMP community associated with the host.
11. Click **Add New Remote Host**.

To remove a CTP platform from your network:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click the **Remove Remote Host** field, select the group to which the host belongs, and then select the remote host.
3. Click **Remove Remote Host**.

Adding and Removing Host Groups (CTPView)

CTPView software enables you to create host groups. Subsequently you assign one or more CTP platforms to each host group. The host groups enable easier connection and monitoring of CTP platforms, especially as your network becomes large and complex. Host groups are displayed at the top of the CTPView side pane. There you can choose a group and then connect to a host that is a member of that group.

Host groups and names are often configured based on geography or application type. If you do not define a group, then the CTP platforms are placed in the default group.

To add a host group:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Enter a unique name for the host group.
Group names can include from 3 to 20 characters consisting of letters, numbers, hyphens, and underscores.
3. Click **Add New Group**.

To remove a host group:



NOTE: Removing a host group automatically deletes all host that are members of that group. If that is not your intention, move those hosts to another group before you perform the following steps.

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click the **Remove Host Group** field and select the group.
3. Click **Remove Group**.

**Related
Documentation**

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)

Adding and Removing SNMP Communities (CTPView)

You can configure SNMP communities for management of CTP platforms in your network.

To add an SNMP community:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Enter a unique name for the community.
3. Click **Add New Community**.

To remove an SNMP community:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Select the community.
3. Click **Remove Community**.

**Related
Documentation**

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)

Managing CTP Platforms in the Network (CTPView)

When CTP platforms have already been configured in the CTPView software, you can subsequently change many aspects of that configuration.

To manage a CTP platform (remote host) in your network:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

2. Click **Manage Network Hosts**.

The Manage Network pane is displayed.

3. Select a host group and click **Show Selected Groups**.

A table listing all CTP platforms in the network is displayed.

4. (Optional) Select a different **Group Name** to change the host's group affiliation.

5. (Optional) Make a selection in the **Monitor** column to change whether CTPView monitors the host.

6. (Optional) Make a selection in the **Connect Type** column to change how CTPView accesses a monitored host.

7. (Optional) Make a selection in the **SNMP Community** column to change the SNMP community associated with the host.

8. Click **Submit Changes**. If you do not want to submit your changes, then click **Reset**.

Alternatively, you can perform the following steps to access CTP platform management:

1. In the side pane, select **Network > Monitoring**.

The Administrative Functions pane is displayed.

2. Click **Manage Network Hosts**.

The Network Monitoring pane is displayed.

3. Click **Manage Network**.

The Manage Network pane is displayed.

4. Perform steps 3 through 8 as described above.

Related Documentation

- [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 87](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 87](#)
-

Configuring Email Notifications (CTPView)

You can configure the CTPView software to send email notifications to a distribution list when certain events take place on the CTP platform. [Table 5 on page 69](#) lists the events for which you can configure email notification.

Table 5: CTP Platform Events for Email Notifications

Event
CTP platform state is Unreachable.
CTP platform state is Check Host.
CTP port state is Active-Down.
CTP port state is Assessing.
CTP port state is Active-Up.
CTP port state is Disabled.

To configure email notifications for CTP platform events:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Email Notifications**.
The Email Notifications window is displayed.
3. Enter the name or IP address of a qualified mail server.
4. Click **Change Mail Server**.
5. Click **Send Test Email** to verify email connectivity.
6. Type an email address in the **Add Recipient to List** field.
7. (Optional) Check **Add Recipient to all Lists** if you want the recipient to receive notification for all events.
8. Click **Add Email Address** to add the recipient to the master list of email recipients.
9. For any event listed in [Table 5 on page 69](#), select a recipient for notification and click **Add Recipient**.
10. Click **Close Window** when finished.

To remove recipients from a notification list:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Email Notifications**.

The Email Notifications window is displayed.

3. Do either of the following:
 - Select a recipient from the master list, and click **Remove Email Address** to remove the recipient from all notifications.
 - Select a recipient from any of the event lists, and click **Remove Recipient** to remove the recipient from that list.
4. Click **Close Window** when finished.

Related Documentation • [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)

Setting the CTPView Server Start-Up Banner (CTPView)

When you log in to the CTPView server, a log-in or start-up banner presents a message. This banner is displayed whether you log in through the CTPView GUI or through an SSH connection. You can change the banner to display the desired message.

To set the start-up banner:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.
2. Click **Set Start-up Banner**.

The Modify Start-Up Banner Content window is displayed.
3. Type your message in the field.
4. Click **Submit Changes**. If you do not want to submit your changes, then click **Undo Changes**.

Related Documentation • [Setting the CTP Platforms Login Banner \(CTPView\) on page 70](#)

Setting the CTP Platforms Login Banner (CTPView)

When you log in to the CTP platforms through an SSH connection, a banner presents a message. You can change the banner to display the desired message. You can also configure different banners for different CTP platforms.

To set the platform login banner:

1. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.
2. Click **Update CTP Login Banner**.

The Upgrade CTP Banner window opens and displays the current CTPView software start-up banner and a list of platform groups and their members.

3. Skip to step 8 if you want to copy the current banner to the CTP platforms.
4. Click **Change Banner** to use a message different than the current banner.
The Modify Start-Up Banner Content window is displayed.
5. Type your message in the field.
6. Click **Submit Changes**. This action changes the start-up banner for CTPView itself. If you do not want to submit your changes, then click **Undo Changes**.
7. Click **Return to CTP Banner Upgrade**.
8. Click the name of a platform. You can select more than one platform by holding down the Ctrl key when you click the platform names.
9. Click **Upgrade Banner on CTP(s)**.

The banner is pushed to each selected CTP platform. The new login banner is displayed in your terminal window when you create an SSH connection to the platform. It is also displayed when you log in to the CTPView server through the CTPView GUI or through an SSH connection.

**Related
Documentation**

- [Setting the CTPView Server Start-Up Banner \(CTPView\) on page 70](#)

Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView)

This topic describes how to configure CTP platforms so that an SSH connection remains established for the entire session when the CTPView server connects to the platform.

SSH port forwarding creates an encrypted and protected connection between the CTPView software and a remote CTP platform, that remains up as long as the server connection to the platform is up. It must be enabled on both the CTP platform and the CTPView software; it is enabled on both by default. When this feature is not enabled, the CTPView server creates a separate SSH connection to the platform for each command and configuration change. This feature reduces overhead and increases performance of the CTPView software. You can choose to disable this feature or reenale it.

To disable SSH port forwarding on the connected CTP platform:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **CTP Port Forwarding Is Allowed** and confirm the action when prompted.
The button text changes to **CTP Port Forwarding Is Prohibited**.

To enable SSH port forwarding on the connected CTP platform:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **CTP Port Forwarding Is Prohibited** and confirm the action when prompted.

The button text changes to **CTP Port Forwarding Is Allowed**.

You can also change the state of this feature by selecting **System > Configuration** in the side pane and clicking **SysMon**. You can then select **Enabled** or **Disabled** for the feature.

When the SSH port forwarding connection is successfully made to a connected CTP platform, Port Forwarding is displayed at the top of the side pane immediately under the name of the connected CTP platform.

**Related
Documentation**

- [Configuring an SSH Connection to a CTP Platform That Persists Through the Session \(CTPView Server Menu\) on page 127](#)

Setting the CTPView Server Clock (CTPView)

The date and time configured on the CTPView server is displayed in the heading section of the CTPView GUI, regardless of which pane is currently displayed. You can change the time zone, date, and time for the server.



NOTE: We strongly recommend that you set the time zone to Coordinated Universal Time (UTC) on all CTPView servers and CTP platforms in your network. This practice is necessary to enable the statistics graphs of CTP network behavior to accurately represent when particular events occurred. CTP platform time is set when you first power up the device.

To set the date and time on the CTPView server clock:

1. In the heading section, click the globe icon to the right of the current time display.

The Clock CTPView window is displayed.

2. (Optional) Select a different time zone and click **Submit New Timezone**.



NOTE: Changing the time zone reboots the CTPView server.

3. If you want only to adjust the time and not change the time zone, click **Cancel**.

The Clock CTPView window now displays the current time and fields for the new time.

4. Select new values to adjust any or all of the day, month, year, hour, minute, or second, and click **Submit Changes**.

The current time displayed in the CTPView GUI does not update automatically. When you navigate to any other pane in the software, the time display updates.

**Related
Documentation**

- [Powering On the CTP Platform](#)
- [Managing NTP Servers for the CTPView Network \(CTPView\) on page 74](#)

Setting the CTPOS Clock (CTP Menu)

Starting with CTPOS 6.7, you can change the time zone on the basis of your location. It is recommended that you configure the same time zone for both CTPView server and CTPOS to enable the system to correctly display the statistics graphs. Conflicting time zones causes the plot values to be offset from their correct positions on the time axis.



NOTE: Only a system administrator can change the time zone of the system.

To change the time zone from CTP Menu:

1. From the Main Menu, select **5) Node Operations > 1) Change Node Date/Time/TimeZone > .**
2. Select **1) Set time-zone.**

```
=====
= (ctp_90 05/07/14 12:49:22 UTC) | Time Operations
=====
```

Please select a number from the following list:

```
-----
0) Back to Previous Menu
1) Set time-zone
2) Set date/time
----- Your choice [0]: 1
```

```
*****
It is recommended that the timezone of CTP systems
should be similar to the timezone of CTPView servers
for better visibility of the statistical graphs.
*****
```

```
=====
= (ctp_90 05/07/14 12:49:25 UTC) | Time Zone Operations
=====
```

Please select a number from the following list:

```
-----
0) Back to Previous Menu
1) UTC (recommended)
2) Africa
3) America
4) Antartica
5) Arctic
6) Asia
7) Atlantic
8) Europe
9) Pacific
----- Your choice [1]: 4
```

```
=====
= (ctp_90 05/07/14 17:13:00 UTC) | Countries/Cities in Antartica
=====
```

Please select a number from the following list:

```

-----
0) Back to Previous Menu
1) Casey
2) Davis
3) DumontDurville
4) Mawson
5) McMurdo
6) Palmer
7) Rothera
8) South_Pole
9) Syowa
10) Vostok
----- Your choice [0]: 1

***
*** You are about to modify a system parameter that will require
*** a system reboot when complete.
***
*** If you decide to continue, the system will automatically
*** reboot upon leaving these menus.
***
*** Note: If these parameters are changed incorrectly,
***       system may not be reachable via the network
***       after the system reboots.
***

Are you sure? y[n]:

```

The CTP system reboots after you confirm the choice.

Managing NTP Servers for the CTPView Network (CTPView)

NTP servers are used to synchronize system clocks over an IP network. You can manage your NTP peers and clients from the NTP Server Settings window. This window displays the results of a query of the configured NTP peers. [Table 6 on page 74](#) describes the information provided in the results. From this window you can stop the NTP daemon, add and remove NTP peers, and synchronize to a particular peer. For more information about the information displayed in the summary, consult a reference on NTP.

Table 6: Summary Information for NTP Server Peers

Field	Description
remote	Hostname or IP address of the reference clock source. LOCAL refers to the system time on the NTP server. Table 7 on page 75 describes the meaning of a prefix to the name or address.
refid	Reference ID that identifies the type of the reference clock. Typically this is the master clock to which that NTP server peer is synchronized. When the master clock is unknown, 0.0.0.0 is displayed.
st	Stratum number of the NTP server peer.
t	Remote peer type: broadcast, local, multicast, or unicast.
when	Time since the last packet was received, in seconds. When this value matches the poll value, the reference clock is queried, and when is reset to zero.
poll	Polling interval, in seconds.

Table 6: Summary Information for NTP Server Peers (*continued*)

reach	Reachability register, displayed in octal format. Indicates whether data was readable from the NTP server peer at the last poll, and whether the peer was synchronized to another time source.
delay	Current estimated round-trip time for queries to the remote peer.
offset	Difference between the reference time value and the CTPView server clock.
jitter	Magnitude of the jitter between several time queries.

A prefix to the peer name or IP address indicates the fate of the peer in the clock selection process. [Table 7 on page 75](#) describes the possible values.

Table 7: Prefixes Designating Peer Clock Selection Status

Prefix	Meaning
space	The peer is discarded as unreachable, synchronized to this server (I a synchronization loop), or having a very large synchronization distance.
x	Peer is discarded by the intersection algorithm as a false ticker.
-	Peer is discarded by the clustering algorithm as an outlier.
+	Peer is a survivor and a candidate for the combining algorithm.
#	Peer is a survivor, but is not one of the first six peers sorted by synchronization distance. If the association is ephemeral, it may be demobilized to conserve resources.
*	Peer has been declared the system peer and lends its variables to the system variables.
o	Peer has been declared the system peer and lends its variables to the system variables. However, the actual system synchronization is derived from a pulse-per-second (PPS) signal, either indirectly by means of the PPS reference clock drive or directly by means of the kernel interface.

A summary of NTP network client access lists the IP address and netmask for each network client. You can add and remove network clients and modify client netmasks.

- [Accessing the NTP Server Settings Window \(CTPView\) on page 76](#)
- [Stopping the NTP Daemon \(CTPView\) on page 76](#)
- [Adding an NTP Peer \(CTPView\) on page 76](#)
- [Removing an NTP Peer \(CTPView\) on page 76](#)
- [Synchronizing the CTPView Server to an NTP Peer \(CTPView\) on page 76](#)
- [Adding NTP Network Clients \(CTPView\) on page 77](#)
- [Removing an NTP Network Client \(CTPView\) on page 77](#)
- [Modifying the Netmask of an NTP Network Client \(CTPView\) on page 77](#)

Accessing the NTP Server Settings Window (CTPView)

To configure NTP servers:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

2. Click **NTP Server Configuration**.

The NTP Server Settings window is displayed.

Stopping the NTP Daemon (CTPView)

To stop the NTP sever daemon:

- In the NTP Server Settings window, click **Stop NTP Daemon**.

The connection to the listed NTP server peers is brought down, and the Summary of NTP Server Pairs table is cleared.

Adding an NTP Peer (CTPView)

To add an NTP peer to the summary table:

1. In the NTP Server Settings window, type an IP address or fully qualified domain name in the Manage NTP Peers section.
2. Click **Add New NTP Peer**.

The peer address or name and information appear in the summary table.

Removing an NTP Peer (CTPView)

To remove an NTP peer from the list of configured peers:

1. In the NTP Server Settings window, select a peer to remove in the Manage NTP Peers section.
2. Click **Remove Selected Peer**.

The peer is removed from the table, and the NTP daemon is restarted if it was running.

Synchronizing the CTPView Server to an NTP Peer (CTPView)

To manually synchronize the server to an NTP peer:

1. In the NTP Server Settings window, select a peer for synchronization in the Manage NTP Peers section.
2. Click **Sync to Selected Peer**.

Adding NTP Network Clients (CTPView)

To add a new network client:

1. In the NTP Server Settings window, type an IP address or fully qualified domain name in the Manage NTP Client Access section.
2. Click **Add New Network Client**.

The client address or name and netmask appear in the summary table.

Removing an NTP Network Client (CTPView)

To remove an NTP network client from the list of configured clients:

1. In the NTP Server Settings window, select a client to remove in the Manage NTP Client Access section.
2. Click **Remove Selected Network Client**.

The client is removed from the table, and the NTP daemon is restarted if it was running.

Modifying the Netmask of an NTP Network Client (CTPView)

To modify a client netmask:

1. In the NTP Server Settings window, select a client in the Manage NTP Client Access section.
2. Select a new netmask.
3. Click **Modify Client Netmask**.

Configuring Automatic Monitoring of CTP Platforms (CTPView)

You can configure certain monitoring operations to be automatically performed on the CTP platforms in the network. You manage these operations in the CTPView Automatic Functions window. This window displays a summary table of the currently configured automatic settings for the connected CTP platform. [Table 8 on page 77](#) describes the information provided in the table. From this window you can add and remove automatic operations for the CTP platform, and configure the monitoring details.

Table 8: Current CTPView Automatic Settings

Field	Description
-------	-------------

Table 8: Current CTPView Automatic Settings (*continued*)

Action	<p>One of the following monitoring operations:</p> <ul style="list-style-type: none"> • Backup Current MySQL Databases • Gather Remote Host Statistical Data—Retrieves the data used to create the plots of IP Buffer Usage, Delay Jitter, Round Trip Delay, and Missing Packets. • Update Network Interface Device Information—Collects network interface device information. Use this automatic function if you configure virtual IP addresses using the CLI or if you use multiple CTPView servers to configure CTP platforms and virtual IP addresses. • Remove Outdated Files—Removes older files (typically CTP platform statistical data) based on the age of the data. The age criterion can be set to 6, 9, or 12 months. We recommend that you configure this automatic function to ensure that the file system does not become filled. • Synchronize Secondary Servers—Copies information from the primary server to each secondary server. The information includes SSH keys, archived port configurations, email notifications, port forwarding settings, trigger point for hard drive usage warning level, and CTP platform identification information (IP address, hostname, group name). • Synchronize Secondary Servers and Remote Hosts—Copies information from the primary server to each secondary server and CTP platform. The information transferred to the secondary servers includes SSH keys, archived port configurations, email notifications, port forwarding settings, trigger point for hard drive warning usage level, CTP identification information (IP address, hostname, group name), and CTP statistical data. The function copied from the primary server to CTP platforms includes each secondary server's SSH key. • Save Current CTP Host System Configuration—Saves every CTP platform configuration at the specified time interval. CTPView will save the 10 most recent configurations.
Minute	Minute of the hour when the operation is scheduled to take place.
Hour	Hour of the day when the operation is scheduled to take place.
Day	Date when the operation is scheduled to take place.
Month	Month when the operation is scheduled to take place.
Day of Week	Day of the week when the operation is scheduled to take place.

- [Accessing the CTPView Automatic Functions Window \(CTPView\) on page 78](#)
- [Adding an Automatic Monitoring Operation \(CTPView\) on page 79](#)
- [Removing an Automatic Monitoring Operation \(CTPView\) on page 79](#)

Accessing the CTPView Automatic Functions Window (CTPView)

To configure automatic functions:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Automatic Functions**.
The CTPView Automatic Functions window is displayed.

Adding an Automatic Monitoring Operation (CTPView)

To add an automatic monitoring operation:

1. In the CTPView Automatic Functions window, select an action.
2. Select when you want the operation to take place.

The numbers you select represent a specific time, not an interval of time. For example, the default setting of [0,1,ANY,ANY,ANY] means that action occurs at the 0 minute (on the hour) of the first hour (1 AM) every day (any day of any month, landing on any day of the week). A setting of [30,16,8,ANY,ANY] causes the action to occur at 4:30 PM on the 8th of every month.

3. Click **Add New Entry**; the operation appears in the summary table.

If you decide not to add the entry, click **Reset**.

To have the same function performed at different times, add a new entry for that operation for each time.

Removing an Automatic Monitoring Operation (CTPView)

To remove an automatic monitoring operation:

1. In the summary table in the CTPView Automatic Functions window, click the **Remove** checkbox for each action you want to remove.
2. Click **Remove Selected Lines**; the operation disappears from the summary table.

Related Documentation

- [Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms \(CTPView\) on page 79](#)
- [Synchronizing Multiple CTPView Servers \(CTPView\) on page 81](#)

Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms (CTPView)

You can specify a limit on the bandwidth used for file transfers between the CTPView server and the CTP platforms in the network. By default, the *bandwidth throttling* value is set to 100,000 Kbps, the full bandwidth available on the server's Ethernet port. Throttling the bandwidth is typically not necessary and may be required only when the local LAN segment experiences significant load and bandwidth limitations.

The following functions are affected by bandwidth throttling:

- Gathering statistical data for plots
- Synchronizing secondary CTPView servers
- Saving CTP platform configurations
- Modifying CTP platform login banners
- Upgrading the CTP operating system software



NOTE: The bandwidth throttling configuration has no effect on data packet throttling.

To configure the bandwidth limit:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

2. Click **Automatic Functions**.

The CTPView Automatic Functions window is displayed, and shows the current value for bandwidth throttling for the CTPView server.

3. Select a new throttling value.
4. Click **Modify Throttle Value**.

**Related
Documentation**

- [Configuring Automatic Monitoring of CTP Platforms \(CTPView\) on page 77](#)

Restoring CTPView Software Configuration Settings and Data (CTPView)

This topic lists two methods to restore the CTPView software configuration settings and data. Typically you restore this information only after one of the following events has occurred:

- An installation of the latest version of the CTPView server operating system, which reformats the server's hard drives.
- In the unlikely event of a data loss.

Use one of the following methods to restore saved CTPView information:

- Use the CTPView restore utility in the CTPView server menu. You must use this method when you have only a single CTPView server.

See [“Restoring CTPView Software Configuration Settings and Data with the Restore Utility \(CTPView Server Menu\)” on page 20](#).

- Synchronize the server. This method is available only when you have two or more CTPView servers in your network.

See [“Restoring CTPView Software Data by Manually Synchronizing the CTPView Server \(CTPView\)” on page 20](#).

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)

Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)

This topic describes how to use CTPView server synchronization to restore the CTPView software configuration settings and data.

To restore your saved information by synchronizing the CTPView server with another server:

1. Log in to the CTPView GUI on the server for which you are restoring the data.
2. In the side pane, select **Server > Administration** to display the Administrative Functions pane.
3. Click **Server Synchronization**.
4. Verify that the server is either not listed or its Server Type is set to Not Selected.
5. Log in to the CTPView GUI on the server from which you are restoring the data.
6. In the side pane, select **Server > Administration** to display the Administrative Functions pane.
7. Click **Server Synchronization**.
8. Ensure that the Server Type is set to Primary Server for this server, Secondary Server for the server being updated, and Not Selected for all other CTPView servers listed.
9. Click **Manually Synchronize Network**.
The Synchronize Secondary Servers window opens.
10. Click **Select All Hosts**, and then click **Synchronize Servers**.
11. When the synchronization is completed, restore the Server Type for all CTPView servers to the values that you normally use for your network.

Related Documentation

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Restoring CTPView Software Configuration Settings and Data \(CTPView\) on page 19](#)

Synchronizing Multiple CTPView Servers (CTPView)

When you have more than one CTPView server in your network, you can synchronize some or all of the servers to the same configuration. You must designate one server as the primary server and the others as secondary servers. When you add a secondary server, the primary server sets up SSH authorization keys with the secondary server so it can communicate without requiring the login password again. The server configuration settings apply only to the server you are logged in to. These settings do not affect the other CTPView servers in the network.

The primary server has a 15-second period to establish contact with a remote CTP platform. If the period times out, the primary server skips to the next remote CTP platform and continues executing the program. This information is displayed in the screen output

and logs. When you add a new remote CTP platform to a primary server, the new platform's SSH RSA keys are also exchanged with each secondary server. You can disable this feature in the Administrative Functions pane when you add the new remote platform.

The following definitions are restricted in scope to the server that you are logged in to. Each server maintains its own file of server designations that it refers to when performing a server synchronization. You do not need to configure settings on a remote secondary server for that server to be updated by the primary server that is performing the synchronization.

- **Primary server**—You can designate any server running the correct CTPView software version as a primary server. The primary server runs the synchronization program and distributes data to the secondary servers. Regardless of how any other server is configured, the data on a primary server cannot be overwritten by any other server running the server synchronization program.
- **Secondary server**—On the primary server, you can designate any server running the correct CTPView software version as a secondary server. Synchronization updates the data files on the secondary server to match the files on the primary server.
- **Data files**—Synchronization applies to statistical history archived from the CTP platforms and the information needed to communicate with the platforms: IP addresses, hostnames, host menus, and SSH authorization keys.



NOTE: Server synchronization is supported only on CTPView 1.4.2 or higher releases.

- [Configuring a CTPView Server Synchronization Network \(CTPView\) on page 82](#)
- [Synchronizing the CTPView Server Network Automatically \(CTPView\) on page 83](#)
- [Synchronizing the CTPView Server Network Manually \(CTPView\) on page 84](#)

Configuring a CTPView Server Synchronization Network (CTPView)

You must identify a primary server and one or more secondary servers as members of a synchronization network.

To configure your synchronization network:

1. Log in to the CTPView server selected to be the primary server.
2. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
3. Click **Server Synchronization**.
The Server Synchronization pane is displayed.
4. In the Add Network Server section, type the information required for the primary server: IP address, name, admin login name, and login password, and click **Add New Server**.

The primary server information is displayed in the Current Server Synchronization Settings table. The server name is used for display purposes only and does not need to be the server's UNIX hostname.

5. Add the same information to the table for each of the additional CTPView servers in your network that you want to synchronize with the primary server.
6. In the Current Server Synchronization Settings table, select a server type for each server: **Primary Server** for the primary CTPView server, and **Secondary Server** for each of the secondary servers.

The primary server must be the server you are currently logged in to.

7. (Optional) Set the server type to **Not Selected** when you want to temporarily remove a server from the synchronization process.

To add this server back to the synchronization network, select **Secondary Server** for the server type.

8. (Optional) Click the **Remove** box to remove a server from the synchronization network.

The server is deleted from the table. If you later want this server to be part of the synchronization network, you must add it back to the table.

9. Click **Commit Changes** to save this configuration.

If you want to restore the original settings in the table, click **Reset** instead of **Commit Changes**.

Synchronizing the CTPView Server Network Automatically (CTPView)

To automatically synchronize your network:

1. In the Server Synchronization pane, click **Set Automatic Functions**.

The CTPView Automatic Functions pane is displayed.

2. Select **Synchronize Secondary Servers and Remote Hosts** or **Synchronize Secondary Servers**.

When the secondary servers and the CTP platforms are synchronized, the CTPView software copies the necessary SSH keys to each secondary server so that it can communicate with the CTP platforms without requiring the login password to be entered. When only the secondary servers are synchronized, only server-specific information is synchronized.

3. Select when you want the operation to take place.

The optimal configuration runs the synchronization shortly after the statistical data is obtained from the CTP platforms. The numbers you select represent a specific time, not an interval of time. For example, the default setting of [0,1,ANY,ANY,ANY] means that synchronization occurs at the 0 minute (on the hour) of the first hour (1 AM) every day (any day of any month, landing on any day of the week). A setting of [30,16,8,ANY,ANY] causes the synchronization to occur at 4:30 PM on the 8th of every month.

4. Click **Add New Entry**; the operation appears in the summary table.

If you decide not to add the entry, click **Reset**.

To have the same function performed at different times, add a new entry for that operation for each time.

Synchronizing the CTPView Server Network Manually (CTPView)

To manually synchronize your network:

1. In the Server Synchronization pane, click **Manually Synchronize Network**.

The Synchronize Secondary Servers window is displayed.

2. (Optional) Click the name of the CTP platform on which you want to check the SSH RSA keys during synchronization.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

3. Click **Synchronize Servers**.

CHAPTER 11

Monitoring CTP Platforms (CTPView)

- [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 87](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 87](#)
- [Displaying Runtime Query Results for a CTP Platform \(CTPView\) on page 89](#)
- [Overriding CTP Platform Network Status and Adding Comments \(CTPView\) on page 90](#)
- [Saving CTP Platform Configurations \(CTPView\) on page 91](#)
- [Setting an Audible Alert for CTP Platform Status \(CTPView\) on page 93](#)
- [Displaying CTPView Network Reports \(CTPView\) on page 93](#)
- [Field Descriptions in CTPView Network Reports \(CTPView\) on page 95](#)
- [Displaying Network Statistics \(CTPView\) on page 96](#)

Monitoring the Network with the CTPView Software (CTPView)

You can enable network monitoring so that the CTPView software can periodically check the status of CTP platforms in your network. You can modify the network monitoring settings from the CTPView web interface. Before you can use network monitoring, you need to add your CTP devices (hosts) to the CTPView configuration and enable the device for network monitoring. To do so, use one of the following topics:

- [Adding and Removing CTP Platforms Managed by CTPView Software \(CTPView\) on page 65](#)
- [Adding and Removing Host Groups \(CTPView\) on page 66](#)

To enable CTPView network monitoring:

1. In the side pane, select **Network > Monitoring**.

The Network Monitoring pane is displayed. A Network Monitoring box displays the status of monitoring, **Running** or **Stopped**.

2. Click the button for the group of CTP devices you want to monitor.
3. Click **Click to Start** to initiate monitoring of the selected group.

The operation or alarm status of each device in the group, and of each bundle on the device, is displayed. [Table 9 on page 86](#) lists the status options. A color key in the pane indicates the bundle state. The highest alarm level on a CTP device percolates up to the button for its group.

Table 9: Platform Group and Bundle Status

Status	Description
Active-Down	The bundle is configured as active, but the bundle state is Down, meaning that no circuit is established to the bundle.
Active-Up	The bundle is configured as active, and the bundle state is Up, meaning that a circuit is established to the bundle.
Assessing	The problem is being assessed, and a user has placed the CTP platform into the Assessing state.
Check Host	The CTP platform is reachable across the network, but the CTPView software is unable to communicate with the platform to obtain the status of the bundles.
Disabled	The circuit is configured as disabled. Ports not attached to bundles are marked Disabled.
No Data	No data can be obtained from the CTP platform. You must investigate further to determine the cause.
Unreachable	The CTPView server cannot reach the CTP host. This alarm can be due to an IP network problem, a site problem (such as a power outage), or a CTP equipment or configuration issue.

You can click on a CTP platform button or a bundle or port button to perform additional monitoring operations, such as checking the host connection, displaying the runtime query results, or overriding the network status.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 87](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 87](#)
- [Displaying Runtime Query Results for a CTP Platform \(CTPView\) on page 89](#)
- [Overriding CTP Platform Network Status and Adding Comments \(CTPView\) on page 90](#)
- [Configuring Email Notifications \(CTPView\) on page 69](#)

Changing the Display Settings for CTPView Network Monitoring (CTPView)

You can change several settings to customize the look of CTPView network monitoring.

To change the display settings:

1. In the side pane, select **Network > Monitoring**.

The Network Monitoring pane is displayed.

2. Click **Display Settings**.

The Display Options window opens.

You can change the following display options:

- Number of platform group buttons in a row.
 - Width of each group button, in pixels.
 - Text size of each group button, in pixels.
 - Text size of each bundle or port button, in pixels.
 - Level of debugging information.
 - Audible notification by the browser each time status is reported as UNREACHABLE, CHECKHOST, or ACTIVE-DOWN.
3. Select the setting values you want to change. Click **Submit Choices** to accept your changes, or click **Undo Changes** to restore the current value.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)
- [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 87](#)
- [Setting an Audible Alert for CTP Platform Status \(CTPView\) on page 93](#)

Checking the CTPView Server Connection to CTP Platforms in the Network (CTPView)

You can determine whether the CTPView server is currently able to reach one or more of the CTP platforms in your network. This is a one-time, immediate check rather than ongoing network monitoring. You can check the connection status from the Network Monitoring pane or from the Node Maintenance pane.

- [Checking Connections from the Network Monitoring Pane \(CTPView\) on page 88](#)
- [Checking Connections from the Node Maintenance Pane \(CTPView\) on page 88](#)
- [Displaying Previously Logged Connection Status \(CTPView\) on page 88](#)
- [Checking Connections in the Remote Host Options Window \(CTPView\) on page 89](#)

Checking Connections from the Network Monitoring Pane (CTPView)

To check the current reachability of CTP platforms:

1. In the side pane, select **Network > Monitoring**.

The Network Monitoring pane is displayed.

2. Click **Check Connections**.

The Check Connections to CTPs window opens and displays a list of platform groups and their members.

3. Click the name of the platform you want to check.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

4. Click **Check Connection to Selected CTPs**.

The CTPView software checks the connection to each selected CTP device in turn and displays the results.

Checking Connections from the Node Maintenance Pane (CTPView)

You can also check CTP platform connections from the Node Maintenance pane.

1. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.

2. Click **Check Connection to CTP(s)**.

The Check Connections to CTPs window opens and displays a list of platform groups and their members.

3. Click the name of the platform you want to check.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

4. Click **Check Connection to Selected CTPs**.

The CTPView software checks the connection to each selected CTP device in turn and displays the results.

Displaying Previously Logged Connection Status (CTPView)

To display logs of previous connection checks:

1. In the Check Connections to CTPs window, click **Show Active Log**.
2. (Optional) Click **Archive This Log** to archive the current results summary tables.
3. (Optional) Click **View All Summaries** to display previously archived results summary tables.

Checking Connections in the Remote Host Options Window (CTPView)

The CTPView software provides another way to check CTP platform connections starting from the Network Monitoring pane.

1. Perform the steps listed in [“Monitoring the Network with the CTPView Software \(CTPView\)” on page 85](#).

Monitoring is started for the selected bundle or platform.

2. Click the button for a platform or bundle being monitored.

The Remote Host Options window is displayed.

3. Click **Check Host Connection**.

A new window displays the SSH query and response and the SNMP query and response.



NOTE: To receive a response for an SNMP query, you need to configure and enable SNMP on the target CTP device.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)
- [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 87](#)

Displaying Runtime Query Results for a CTP Platform (CTPView)

You can quickly access the runtime query results for a CTP platform or bundle from the Network Monitoring pane.

To display the runtime query results:

1. Perform the steps listed in [“Monitoring the Network with the CTPView Software \(CTPView\)” on page 85](#).

The Network Monitoring pane is displayed.

2. Click the button for a platform or bundle being monitored.

The Remote Host Options window is displayed.

3. Click **Open Bundle Runtime Query Page** for all bundles or, if you selected an individual bundle, for that bundle.

The Bundle Runtime Information page appears.

4. Select a row and click **Display Selected Bundles**.

Runtime query results for the selected bundle are displayed.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)

- [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 87](#)
- [Displaying Running CTP Bundle Configuration, State, and Counters \(CTPView\)](#)

Overriding CTP Platform Network Status and Adding Comments (CTPView)

You can manually override the status of CTP platforms. You can also add comments that appear in the Remote Host Options window for a CTP platform that is currently being monitored.

To override the status of a platform:

1. Perform the steps listed in [“Monitoring the Network with the CTPView Software \(CTPView\)” on page 85](#).

The Network Monitoring pane is displayed.

2. Click the button for a platform being monitored.

The Remote Host Options window is displayed.

3. Click **Modify Host Status/Comments**.

The Modify Host Comments window is displayed.

4. Select **Yes** to set the status to Assessing.

If the status was previously overridden and set to Assessing, you can select **No** to remove the override.

5. Click **Submit Changes**.

A magnifying glass icon appears in the button for the platform, its group, and its network. The status color of only the platform button is set to orange for Assessing. The group and network buttons display only the most severe status reported for a platform that has not been manually overridden.

To add a comment:

1. Perform the steps listed in [“Monitoring the Network with the CTPView Software \(CTPView\)” on page 85](#).

The Network Monitoring pane is displayed.

2. Click the button for a platform being monitored.

The Remote Host Options window is displayed.

3. Click **Modify Host Status/Comments**.

The Modify Host Comments window is displayed.

4. Type a comment of up to 125 characters in the comment field.

5. Click **Submit Changes** to apply your text to the Remote Host Options window.

Alternatively, click **Delete Comments** to remove a current comment (and if applied, the Assessing status), or **Undo Changes** to cancel your comment change. A time stamp indicates when the comment was last modified.

- Related Documentation**
- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)
 - [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)

Saving CTP Platform Configurations (CTPView)

You can set an automatic function to save the CTPView configuration for the CTP platforms in your network automatically. The automatic function stores up to the 10 most recent configuration files. You can also save the configuration manually. Manually saved configurations are stored in addition to any automatically saved configurations. You can also save previously stored configurations for any CTP platform.

To configure automatic file saving:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Automatic Functions**.
The CTPView Automatic Functions window is displayed.
3. In the Action section in the second box, select **Save Current CTP Host System Configurations**.
4. Select when you want the operation to take place.
5. Click **Add New Entry**; the operation appears in the summary table. Or, if you do not want to add the entry, click **Reset**.

To have the configurations saved at additional times, add a new entry for that operation for each time.

To save the configurations manually:

1. In the side pane, select **Node > Maintenance**.
The Administrative Functions pane is displayed.
2. Click **Save/Restore CTP Configurations**.
The CTP System Configuration window is displayed.
3. Select the desired host.
4. Click **Save CTP Configuration**.
The name and IP address of the selected host is displayed.
5. (Optional) Type text for a label associated with the configuration.
6. Click **Click To Save Current CTP Configuration**.

The configuration is added to the list of saved configurations.

To restore a configuration:



NOTE: Restoring a saved configuration to a CTP platform reboots that device.

1. In the side pane, select **Node > Maintenance**.

The Administrative Functions pane is displayed.

2. Click **Save/Restore CTP Configurations**.

The CTP System Configuration window is displayed.

3. Select the desired host.

4. Click **Restore CTP Configuration**.

The name and IP address of the selected host is displayed.

5. Select a saved configuration from the list.

6. Click **Restore CTP Configuration**.

The CTP platform is rebooted as part of the restoration process.

To delete a saved configuration:

1. In the side pane, select **Node > Maintenance**.

The Administrative Functions pane is displayed.

2. Click **Save/Restore CTP Configurations**.

The CTP System Configuration window is displayed.

3. Select the desired host.

4. Click **Delete Saved CTP Configuration**.

The name and IP address of the selected host is displayed.

5. Select a saved configuration from the list.

6. Click **Delete CTP Configuration**.

Setting an Audible Alert for CTP Platform Status (CTPView)

You can set an alert that the CTPView browser plays every time it detects a CTP platform status as UNREACHABLE, CHECKHOST, or ACTIVE-DOWN. You can add additional alert sounds to the available choices.

To select an alert sound:

1. In the side pane, select **Network > Monitoring**.
The Network Monitoring pane is displayed.
2. Click **Display Settings**.
The Display Options window opens.
3. Select Enabled to set the browser to play an alert.
4. Select an alert sound from the list.
5. Click **Submit Choices** to accept your changes, or click **Undo Changes** to restore the current value.

To add additional alert sounds:

- Copy the sound files to the CTPView server directory `/var/www/html/acorn/sounds/`.



NOTE: Only files in .wav format are supported. The sound filename can include only alphanumeric characters and the underscore (_) character. The filename root is displayed as the label for the sound in the browser. The CTPView software automatically corrects illegal filenames and modifies file permissions as needed to enable the embedded media player to read the file.

The default browser installation for LINUX workstations may not include an embedded media player. An easy-to-install multimedia plug-in is available at <http://fredrik.hubbe.net/plugger.html>.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 68](#)
- [Monitoring the Network with the CTPView Software \(CTPView\) on page 85](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 87](#)

Displaying CTPView Network Reports (CTPView)

The CTPView software provides the following reports that detail how ports are provisioned on the CTP platforms in your network:

- Channelization Report—Information about all ports on selected CTP platforms.

- Configured Ports Report—Information about only the configured ports on selected CTP platforms.
- Non-configured Ports Report—Information about only ports that are incompletely configured on selected CTP platforms.

To display the desired report:

1. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.

2. Click **View Network Host Reports**.

The CTPView Network Reports pane is displayed.

3. Select one or more remote hosts (CTP platform), or click **Select All Hosts** to select all listed CTP platforms.

4. Click the button for the desired report.

The report is displayed in the bottom of the pane. Click **Clear/Reload Page** to remove the report from the pane.

5. (Optional) Click on a column header in the report to sort the data in ascending order for that column.
6. (Optional) Select a different font size for readability.
7. (Optional) Click **Printer Friendly Page** to display the report in a format suitable for printing.

You can select and copy the printer-friendly information and paste it in a spreadsheet.

The report database is updated whenever you use the CTPView software to provision a CTP platform. You can also save the CTP platform configuration data to the database automatically or manually.

To update the database automatically, see [“Configuring Automatic Monitoring of CTP Platforms \(CTPView\)” on page 77](#).

1. To update the database manually:

2. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.

3. Click **View Network Host Reports**.

The CTPView Network Reports pane is displayed.

4. Click **Update Database**.

Related Documentation

- [Field Descriptions in CTPView Network Reports \(CTPView\) on page 95](#)

Field Descriptions in CTPView Network Reports (CTPView)

Table 10 on page 95 describes the information provided by the CTPView software in the CTPView network reports.

Table 10: CTPView Network Reports Fields

Field	Description
Source IP Address	IP address of the source CTP platform.
Source Host Name	Name of the source CTP platform.
Source Port Number	Number identifying port on the source CTP platform.
Source CID	Source circuit ID.
Source Bundle Number	Number identifying bundle on the source CTP platform.
Destination IP Address	IP address of the destination CTP platform.
Destination Host Name	Name of the destination CTP platform.
Destination Port/CID Number	Destination port and circuit ID.
Source Interface Type	Type of interface on the source CTP platform: EIA530, EIA530A, RS-232, V.35, T1/E1, fractional T1/E1, or 4WTO analog voice.
Source Port Speed	Clock speed configured for the source CTP platform.
Source Service Type TOS/DSCP	Value of the Type of Service byte in packets sent from the source CTP platform to the IP network.
Source Port Descriptor	Descriptive term or name applied to the port.
Source Bundle Descriptor	Descriptive term or name applied to the bundle.
Source Code Version	CTPOS software version running on the source CTP platform.
Last Update	Date and time report was last updated to the database.

Related Documentation • [Displaying CTPView Network Reports \(CTPView\) on page 93](#)

Displaying Network Statistics (CTPView)

The CTPView software periodically retrieves IP performance information from each CTP platform in the network. The data is retrieved at 1-minute intervals and includes the following observation:

- Minimum, maximum, and average values for the buffer state
- Calculated IP packet delay variance (jitter)
- Missing packet counts
- Round-trip packet delay

The plots display information for the currently connected CTP platform. You can display plots for a single bundle or all configured bundles on the connected CTP platform. Each plot's Y axis is automatically scaled for convenient viewing. However, for the buffer, packet delay variance, and round-trip delay plots, you can specify different units, minimum values, and maximum values for the Y axis intervals. You can select the period of time for which you want to review the data, from the preceding hour up to the preceding week, or you can set a custom period to review.



NOTE: The Network Statistics pane requires you to select the circuit of interest based on bundle numbers. An expanding table in the pane displays a summary of the current bundle circuits and their attached ports on the connected platform.

To display a plot of IP statistics for the connected CTP platform:

1. In the side pane, select **Statistics > Plots**.

The Network Statistics pane is displayed.

2. Click on the time period button for which you want data to be plotted.

The plots are displayed, and the period plotted is indicated. Click any plot to open a larger version in a new window.

You can click a button for a single bundle or all configured bundles. To plot data for a single bundle, expand the table, follow the directions in the pane to display and select the bundle. Time period buttons are then displayed for that bundle.

To display a plot with different values for the Y axis:

1. In the Network Statistics pane, click **Custom Y-axis Options**.

The Network Statistics pane is displayed.

2. Select any combination of minimum value, maximum value, or different units for the Y axis.

You can select these values for the Buffer, IP packet delay variation, or IP one-way packet loss plots. You can click **Reset Custom Y-axis** to restore the default values for all plots.

To display a plot for a custom time period:

1. In the Network Statistics pane, click **Custom Y-axis Options**.

The Network Statistics pane is displayed.

2. Click **Custom Time Options**.
3. Select a starting and ending year, month, day, hour and minute.
4. Click **Custom Time** for the bundles you want to plot.

You can click **Reset Custom Time** to restore the default values for all plots.

The plots are displayed, and the period plotted is indicated. Click any plot to open a larger version in a new window.

Changing CTPView GUI Settings

- [Configuring CTPView Software for Tabbed or Nontabbed Browsers \(CTPView\) on page 99](#)
- [Changing the CTPView Display Settings \(CTPView\) on page 100](#)
- [Displaying Help for CTPView GUI Settings \(CTPView\) on page 100](#)

Configuring CTPView Software for Tabbed or Nontabbed Browsers (CTPView)

You can configure the CTPView software to be displayed properly in a tabbed browser or a nontabbed browser. By default, the software is set to classic, which supports a nontabbed browser. You must separately configure each browser that you use.

To set the browser preference for tabs:

1. In the side pane, select **Server > GUI Settings**.
The GUI Settings pane is displayed.
2. Select **Classic** for nontabbed browsers or **Tab** for tabbed browsers.
3. Click **Change CTPView Style**.

The viewing style is displayed in the side pane under **Server**.

To open a CTPView window in a new tab in your browser:

- In the side pane, select **Server > New Window**.

The current tabbed browsers do not support dynamically changing the tab's title after a page has been loaded onto the screen. The CTPView software uses frames to open new content in the viewing window without reloading the entire page, so the tab titles cannot describe the current content. The CTPView software adds a bracketed sequencing number to the tab title to differentiate the tabs for easier browser, and keeps track of the number of tabs that you have opened.

To reset the tab count:

1. In the side pane, select **Server > GUI Settings**.
The GUI Settings pane is displayed.
2. Click **Reset Browser Tab Index**.

The count resets to 1. The next tab you open will have the sequence number 1. The counter is automatically reset when you close all the browser windows.

Changing the CTPView Display Settings (CTPView)

You can modify the appearance of text, and the background color of tables and some buttons in the CTPView software. By default, text is displayed in 3-point Verdana.

To change the text appearance:

1. In the side pane, select **Server > GUI Settings**.

The GUI Settings pane is displayed.

2. Select a font style.
3. Select a base text size.
4. Click **Submit Changes**.

To change the background color of certain tables and buttons:

1. In the side pane, select **Server > GUI Settings**.

The GUI Settings pane is displayed.

2. Type the hexadecimal code for the new color in the field for the table, button, or message type that you want to change.
3. (Optional) Click **Go To Color Chart** to view a table of codes for browser-safe colors, and type the code.
4. Click **Submit Changes**.

Alternatively, you can restore the default colors by clicking **Use Default Colors**.

The current window refreshes immediately with the text or color changes. However, other windows (or tabs) that are open when you make the change are not automatically refreshed. The changes appear in any windows that you subsequently open.

Related Documentation

- [Displaying Help for CTPView GUI Settings \(CTPView\) on page 100](#)

Displaying Help for CTPView GUI Settings (CTPView)

You can display troubleshooting information and tips regarding CTPView GUI settings and browser display.

To display GUI help:

1. In the side pane, select **Server > GUI Settings**.

The GUI Settings pane is displayed.

2. Click **Troubleshooting and Tips**.

The Troubleshooting and Tips pane is displayed.

**Related
Documentation**

- [Changing the CTPView Display Settings \(CTPView\) on page 100](#)

CHAPTER 13

Managing and Displaying Users (CTPView Server Menu)

- [Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\) on page 103](#)
- [Managing CTPView Users \(CTPView Server Menu\) on page 104](#)
- [Unlocking a User Account \(CTP Menu\) on page 105](#)
- [Adding a VLAN Interface to a Node \(CTP Menu\) on page 106](#)
- [Accessing the Security Profile Configuration Menu \(CTP Menu\) on page 110](#)
- [Classification of CTPView Shell Account Users on page 111](#)
- [Managing User Passwords \(CTPView Server Menu\) on page 111](#)
- [Configuring CTPView User Authentication with Steel-Belted RADIUS on page 113](#)
- [Configuring CTPOS and CTPView User Authentication with TACACS+ on page 118](#)

Accessing the CTPView Server Configuration Menu (CTPView Server Menu)

To access the CTPView server CLI menu:

1. Using an SSH application, log in to the CTPView server.



NOTE: If you do not successfully log in within 60 seconds, the session is closed.

Alternatively, you can log in directly to the CTPView server if you connect a keyboard and monitor to the server. Using an SSH application requires that the CTP server already be configured in your network with an assigned IP address.

2. Enter **menu**.
3. Enter the root password.

The CTPView Configuration Menu is displayed.

Related Documentation

- [Default CTPOS and CTPView Accounts and Passwords on page 43](#)

Managing CTPView Users (CTPView Server Menu)

You can view currently active shell account users, and add or delete administrator shell accounts. Shell accounts provide access to the CTPView server by means of an SSH application.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To manage user passwords, you must first access the User Management Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
2. Select **1) User Management**.

The User Management Menu is displayed.



NOTE: The Security Profile Configuration Menu has an idle timeout period of 10 minutes. If no action is performed for 10 minutes, the user is logged out of the Security Profile Configuration Menu, and is brought back to the Node Operations Menu.

- [Monitoring CTPView Users \(CTPView Server Menu\) on page 104](#)
- [Listing Admin Shell Accounts \(CTPView Server Menu\) on page 104](#)
- [Adding Admin Shell Accounts \(CTPView Server Menu\) on page 105](#)
- [Deleting Admin Shell Accounts \(CTPView Server Menu\) on page 105](#)

Monitoring CTPView Users (CTPView Server Menu)

To display all CTPView users that are currently logged in to the server through SSH:

- From the User Management Menu, select **1) List users currently logged on**.

Only users logged in to the server through a secure shell (not through the CTPView GUI) are listed. The table lists the username, whether the user logged in remotely or locally, the time the session began, and the user's IP address. Local user connections are indicated by *tty*; remote SSH connections are indicated by *pts*.

Listing Admin Shell Accounts (CTPView Server Menu)

You use a shell account to access the CTPView server with an SSH application.

To list all administrator shell accounts:

- From the User Management Menu, select **2) List admin shell accounts**.

The usernames for the shell accounts are listed according to their classification, Administrator or User.

Adding Admin Shell Accounts (CTPView Server Menu)

To add an administrator shell account:

1. From the User Management Menu, select **3) Add admin shell accounts**.
2. Enter the username for the account.
Only alphanumeric characters, underscores, and periods are allowed in a username.
3. Enter the appropriate number to classify the user as an Administrator or User.
4. Enter a new password for the user.
The password requirements are displayed to assist you in choosing an appropriate password.

Deleting Admin Shell Accounts (CTPView Server Menu)

To delete an administrator shell account:

1. From the User Management Menu, select **4) Delete admin shell accounts**.
2. Enter the username for the account.

Related Documentation

- [Classification of CTPView Shell Account Users on page 111](#)

Unlocking a User Account (CTP Menu)

Every user created in the CTP system expires after a specified time limit. If there is no user activity for a specified number of days after the expiry of the password, the user is locked out of the system. Such users can access the system only after their account is unlocked by a system administrator.



NOTE: The menu option, **Unlock user account** is displayed only if you log in as a system administrator.

This topic describes how to unlock a user account that has been locked out because of prolonged inactivity.

To unlock a user from the CTP Menu:

1. From the Main Menu, select **5) Node Operations > 15) Unlock user account** and specify the user account to be unlocked.

```
=====
= (ctp_87 04/08/14 15:29:21 UTC) | Node Operations Menu
=====
```

Please select a number from the following list:

```
-----
0) Back to Previous Menu
```

- 1) Change Node Date/Time/TimeZone
- 2) Display network settings
- 3) Configure network settings
- 4) Initialize Database
- 5) Ping IP address
- 6) Traceroute IP address
- 7) ssh to another host
- 8) System descriptor field:
- 9) Reboot Node
- 10) Powerdown Node
- 11) Display ethernet media
- 12) Config ethernet media
- 13) Set your password
- 14) Config security profile
- 15) Unlock user account
- Your choice [0]: 15

Enter the user to be unlocked:

Usage: chage [-l] [-m min_days] [-M max_days] [-W warn]
[-I inactive] [-E expire] [-d last_day] user

chage—Sets the password expiry information for a user.

-l—Sets the expiry information for an account.

-m—Sets the minimum number of days that must pass before the password can be changed again. This is calculated from the date when the password was last changed.

-M—Sets the maximum number of days after which password must be changed. This is calculated from the date when the password was last changed.

-W—Sets the number of days before the expiry of the current password to issue password change warning. before

-I—Sets the number of days after password expiry when the account will be locked.

-E—Sets the password expiry date for a user. Specify date in the format MM/DD/YYYY or YYYY-MM-DD.

-d—Sets the last day for the user to change password.

user—User account

Adding a VLAN Interface to a Node (CTP Menu)

This topic describes how add a VLAN interface to a node. Adding VLAN interfaces to a node comprises two steps:

- [Adding a VLAN ID to the System on page 107](#)
- [Configuring VLAN Interface by Using the VLAN ID on page 108](#)

Adding a VLAN ID to the System

When you add a VLAN to a node, the network and CTP devices are restarted to update the network parameters. The node is not restarted.



NOTE: For VLAN switchover to function correctly, VLANs must be configured on the primary Ethernet interface (for example, eth1) that has IPv4 configured and Ethernet switchover enabled.

To add a VLAN ID to the system from the CTP Menu:

1. From the Main Menu, select **5) Node Operations > 3) Configure network settings > 8) VLAN Configuration**.

```
=====
= (ctp_90 05/08/14 23:03:48 WST) | Network Configuration Menu
=====
Please select a number from the following list:
-----
0) Back to Previous Menu
1) Supported Protocols: IPv4 only
2) IPv4 Configuration
3) IPv6 Configuration
4) Virtual IP addresses
5) OAM port (IPv4): 16
6) CTP Bndl Data pkt protocol: 47
7) CTP Bndl OAM port (IPv6): 32
8) VLAN Configuration
9) Current Configuration (active on reboot)
10) Port operations (PBS/bridge)
11) Config port operational mode (CE/PBS/bridge)
12) Config access ip filtering
13) SNMP Configuration
----- Your choice [0]: 8
***
*** You are about to modify a system parameter that will require
*** a network restart when complete.
***
*** If you decide to continue, the network will automatically
*** restart upon leaving the menu, existing menu session will be
*** terminated and active circuits will take traffic hits. For
*** further configuration re-initiate the menu session.
***
*** Note: If these parameters are changed incorrectly,
*** system may not be reachable via the network
*** after the network restarts.
***
Are you sure? y[n]: y
Existing VLAN interfaces :
No VLAN is configured yet
How do you want to change VLANs (add/delete/quit) ? (rtn for show): add
Which ethernet port the new VLAN will be added on? (0-3)[0] 1
What is the new VLAN id? (0-4095)[0] 111
Existing VLAN interfaces :
eth1.111: Vlan ID 111 on ethernet port 1
How do you want to change VLANs (add/delete/quit) ? (rtn for show): quit
```

- Follow the onscreen instructions and configure the options as described in [Table 11 on page 108](#).

Table 11: Configuring a VLAN Interface

Field	Function	Your Action
How do you want to change VLANs ?	Enter add to add a new VLAN, delete to remove a VLAN, and rtn to show existing VLANs.	Enter add to create a new VLAN.
Which ethernet port the new VLAN will be added on ?		Specify the ethernet port number. The default value is 0 (zero).
What is the new VLAN id ?		Assign the VLAN ID for the newly created VLAN in the range 0–4095. The default value is 0 (zero).

Configuring VLAN Interface by Using the VLAN ID

- From the Main Menu, select **5) Node Operations > 3) Configure network settings > 2) IPv4 Configuration** to assign an IP address for the VLAN.

```
=====
= (ctp_90 05/08/14 23:09:40 WST) | Network Configuration Menu
=====
Please select a number from the following list:
-----
0) Back to Previous Menu
1) Supported Protocols: IPv4 only
2) IPv4 Configuration
3) IPv6 Configuration
4) Virtual IP addresses
5) OAM port (IPv4): 16
6) CTP Bndl Data pkt protocol: 47
7) CTP Bndl OAM port (IPv6): 32
8) VLAN Configuration
9) Current Configuration (active on reboot)
10) Port operations (PBS/bridge)
11) Config port operational mode (CE/PBS/bridge)
12) Config access ip filtering
13) SNMP Configuration
----- Your choice [8]: 2
***
*** You are about to modify a system parameter that will require
*** a network restart when complete.
***
*** If you decide to continue, the network will automatically
*** restart upon leaving the menu, existing menu session will be
*** terminated and active circuits will take traffic hits. For
*** further configuration re-initiate the menu session.
***
*** Note: If these parameters are changed incorrectly,
*** system may not be reachable via the network
*** after the network restarts.
***
Are you sure? y[n]: y
There are 2 ethernet devices available for use. The default device
```



```

is the device through which the default gateway can be accessed.
Ctp circuits can run over any ethernet device, default or not.
A default device must be configured, other devices may be configured
and enabled, or disabled. Here is a list of the available devices
and their descriptions:
Copyright © 2014, Juniper Networks, Inc. 3
eth0: 10/100/1000 Copper (right back)
eth1: 10/100/1000 Copper (left back)
List of VLAN interface :
eth1.111: Vlan ID 111 on ethernet port 1
What device would you like to make the IPV4 default device? (rtn for eth1):
OK, eth1 (10/100/1000 Copper (left back)) will be configured as IPV4 default
device.
Please input the hostname (return for ctp_90):
===== Configuration for eth0:
Activate IPV4 interface eth0 on boot [n]
===== Configuration for eth1 (default device):
Please input the ip (return for 10.216.118.90):
Please input the netmask (return for 255.255.254.0):
Please input the gateway (return for 10.216.119.254):
Please input the mtu in bytes (return for 1500):
Add route to interface eth1 [n]
IPV4 configuration for VLAN interfaces :
===== Configuration for eth1.111:
Activate IPV4 interface eth1.111 on boot [n] y
Please input the ip (return for 10.0.0.1): 1.1.1.1
Please input the netmask (return for 255.255.255.0):
Please input the mtu in bytes (return for 1500):
Add route to interface eth1.111 [n]

```

2. Follow the onscreen instructions and configure the options as described in

[Table 12 on page 109.](#)

Table 12: IP Parameters for Configuring a VLAN

Field	Your Action
What device would you like to make the IPv4 default device ?	Select the default Ethernet device.
Please input the hostname.	Specify the host name. Press Enter to select the default hostname.
Activate the IPv4 interface eth0 on boot.	Enter n . Ethernet failover may not work correctly if multiple Ethernet interfaces are activated or the active Ethernet interface is configured as the secondary interface.
Configuration for eth1 (default device)	Enter the IP address, network mask, gateway, and MTU for eth1.
Activate the IPv4 interface eth1.111 on boot.	Enter y .
Configuration for eth1.111	Enter the IP address, network mask, and MTU for eth1.111.

Accessing the Security Profile Configuration Menu (CTP Menu)

You can monitor and manage CTPOS and CTPView users by accessing the Main Security Profile Configuration Menu in CTPOS or the CTPView Server Menu. This section describes how to access the Main Security Profile Configuration Menu from CTPOS. To access Security Profile Configuration Menu from the CTPView Server Menu and manage users, see [“Managing CTPView Users \(CTPView Server Menu\)” on page 104](#). The options in the Security Profile Configuration Menu are the same whether you access it from the CTPView Server Menu or from CTPOS.

To access the Main Security Profile Configuration Menu from CTPOS:

1. From the Main Menu, select **5) Node Operations > 14) Config security profile**.
2. When prompted, enter the root password.

In order to configure the security profile you will need the password for root. Would you like to continue? y[n]: y

Password:

```
*****
****      CTP Security Profile Menu V 2.0      ****
**** Host nova_70: Sat Jan  4 04:21:27 2014
**** User root logged in from 10.215.146.80 as root
**** **** All actions are logged **** ****
*****
```

Main Security Profile Configuration Menu

Please choose a menu item from the following list:

- 0) Exit Security Profile Menu
- 1) User Management
- 2) Password Management
- 3) Secure Log Management
- 4) Change login banner
- 5) Modify Security Level
- 6) Set Management Port Forwarding



NOTE: The Security Profile Configuration Menu has an idle timeout period of 10 minutes. If no action is performed for 10 minutes, the user is logged out of the Security Profile Configuration Menu and is brought back to the Node Operations Menu.

Related Documentation

- [Managing CTPView Users \(CTPView Server Menu\) on page 104](#)
- [Managing User Passwords \(CTPView Server Menu\) on page 111](#)
- [Managing CTPView Server Secure Logs \(CTPView Server Menu\) on page 123](#)
- [Setting the CTPView Server Start-Up Banner \(CTPView Server Menu\) on page 125](#)
- [Managing Access Security for the CTPView Server \(CTPView Server Menu\) on page 125](#)

- [Configuring an SSH Connection to a CTP Platform that Persists Through the Session \(CTPView\) on page 71](#)

Classification of CTPView Shell Account Users

Users that access the CTPView server running FC OS through a shell account are classified into one of the following classes:

- Administrator—Can configure the CTP platform, configure loops and BERTs, and query the status of ports and clocking.
- User—Can issue commands only to query the status of ports and clocking.

Managing User Passwords (CTPView Server Menu)

You can display user accounts and password settings, configure various aging criteria for user passwords, and specify the rules for forming passwords.

Before you begin, log in to the CTPView server, and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To manage user passwords, you must first access the Password Management Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
2. Select **2) Password Management**.

The Password Management Menu is displayed.

- [Listing User Accounts \(CTPView Server Menu\) on page 111](#)
- [Displaying Password Expiration Settings \(CTPView Server Menu\) on page 112](#)
- [Changing Password Expiration Settings \(CTPView Server Menu\) on page 112](#)
- [Displaying Password Requirements \(CTPView Server Menu\) on page 113](#)
- [Changing Password Requirements \(CTPView Server Menu\) on page 113](#)

Listing User Accounts (CTPView Server Menu)

The usernames for the accounts are listed according to their classification, Administrator or User..

To list the usernames for CTPView server accounts:

- From the Password Management Menu, select **1) List user & admin accounts**.

Displaying Password Expiration Settings (CTPView Server Menu)

To display the current password expiration settings for a user account:

- From the Password Management Menu, select **2) Display password expiration details**.

Table 13 on page 112 describes the information listed in the output.

Table 13: CTPView User Password Expiration Settings

Field	Description
Account is/is not locked	Status of the account. Locked accounts cannot access CTPView server.
Minimum	Minimum number of days that must elapse before the user can change this password, in the range 1 through 60.
Maximum	Maximum number of days that this password is valid.
Warning	Number of days before password expiration that the user is warned of the impending expiration.
Inactive	Number of days of inactivity after the password expires before the account is locked out (unable to access CTPView server)
Last Change	Date that this password was last changed.
Password Expires	Date that this password expires. Calculated by counting the Maximum value from the Last Change date.
Password Inactive	Date that this password becomes inactive. Calculated by counting the Inactive value from the Password Expires date.
Account Expires	Date that the account expires.

Changing Password Expiration Settings (CTPView Server Menu)

To change the password expiration settings for a user account:

1. From the Password Management Menu, select **3) Manage password requirements**.
2. Enter the password expiration values when prompted.

Each prompt provides a description and range for the value.

Displaying Password Requirements (CTPView Server Menu)

To display the current requirements for forming a password:

- From the Password Management Menu, select **4) Show password requirements**.

The output lists the minimum password length, the minimum number of lowercase letters, uppercase letters, numerals, and nonalphanumeric characters; and the number of times a user can attempt to enter the correct password before being blocked.

Changing Password Requirements (CTPView Server Menu)

User passwords have strict criteria. You must include a nonzero minimum of lowercase letters, uppercase letters, numerals, and certain nonalphanumeric characters. You must also set the number of times a user can enter the password incorrectly before being blocked from access.

To change the requirements for forming a password:

1. From the Password Management Menu, select **5) Manage password requirements**.
2. Enter values for the password requirements when prompted.

Each prompt provides a description and range for the value.

Related Documentation

- [Default CTPOS and CTPView Accounts and Passwords on page 43](#)
- [CTPOS and CTPView Software Password Requirements on page 46](#)

Configuring CTPView User Authentication with Steel-Belted RADIUS

Starting with CTPView Release 4.1, you can provide RADIUS authentication to both HTTPS and SSH users. Earlier releases of CTPView supported RADIUS authentication only for HTTPS users. Enabling RADIUS authentication for SSH users ensures that both HTTPS and SSH users have a common authentication method without requiring separate user-specific configuration.

Starting with CTPView Release 4.1, users do not require a local user account on the CTPView server. For CTPView 4.0 and earlier, a user must have an account on the CTPView server. You can add a user or verify whether a user account exists from the CTPView CLI menu. The username for the CTPView account must match the username that is configured on the RADIUS server.

You can enable or disable RADIUS authentication for both SSH and HTTPS users. You can block a specific user by disabling that user from the RADIUS server.

To provide RADIUS authentication, use an independent Steel-Belted RADIUS (SBR) server or an RSA SecurID appliance with your CTPView server running FC9 or Centos OS and CTPView 3.4R1 or later. The RSA SecurID appliance incorporates an SBR server, making the configuration very similar to that of an independent SBR server.

Users are authenticated in the following order:

1. By the SBR server.
2. By the local CTPView application.

You can configure the SBR server to use native user authentication or pass-through authentication with RSA SecurID.

- Native user authentication references user accounts stored on the SBR server. When trying the native user method, the SBR software searches its database for an entry whose User-Type is Native User and whose username matches the User-Name in the Access-Request.
- Pass-through authentication (two-factor authentication) enables the SBR server to pass authentication requests through to RSA Authentication Manager (RSA SecurID). RSA SecurID is then responsible for validating the username and password found in the Access-Request.

The order of authentication between these two categories of users is set on the SBR server. You can add the same user (that is, the same user ID) to both the SBR server and the local CTPView application.

1. [Configuring RADIUS Settings on the CTPView Server on page 114](#)
2. [Configuring the SBR Server's Dictionary Files on page 116](#)
3. [Configuring the SBR Server's Active Authentication Method on page 117](#)
4. [Adding the CTPView Server as a RADIUS Client on an SBR Server on page 117](#)
5. [Adding CTPView Users to an SBR Server on page 117](#)
6. [Assigning SecurID Tokens to CTPView Users on page 118](#)

Configuring RADIUS Settings on the CTPView Server

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To configure RADIUS settings on the CTPView server:

1. From the CTPView Configuration Menu, select **9) AAA Functions**.

The RADIUS Menu is displayed.

2. Select **8) RADIUS/RSA SecurID Configuration**. Configure the parameters described in [Table 14 on page 115](#).

Table 14: RADIUS Menu Options

Field	Function	Your Action
Servers	<p>Displays the RADIUS servers configured on CTPView.</p> <p>You can add up to 10 RADIUS servers.</p> <p>If you define multiple servers, the order in which they are tried differs on the basis of whether the user is trying to access CTPView via SSH or HTTPS. For access via SSH, the servers are tried in order. For HTTPS access, the servers are tried in a round-robin fashion. In both cases, the process continues until the system receives a response from a server or until the maximum number of retries is reached for all servers.</p>	<p>Specify a RADIUS server.</p> <p>Make sure you specify an IPv4 address if you are configuring RADIUS authentication for HTTPS. IPv6 addresses are supported for RADIUS authentication for SSH.</p>
Destination Port	Specifies the RADIUS destination port.	The default value is 1812.
Retry Attempts	Specifies the number of attempts that the CTPView server makes to contact the listed RADIUS server.	Specify a value in the range of 0 through 9.
Off-Line-Failover	Determines whether the login credentials are passed to the local account login function when no RADIUS server responds to the login request.	<p>Select one:</p> <ul style="list-style-type: none"> Allowed to Loc Acct—User credentials are passed to the local account login function. Not Allowed—User is denied access and the session is terminated.
Reject-Failover	<p>Determines whether the login credentials are passed to the local account login function.</p> <p>The user credentials are not passed if the login information is incorrect or if the user does not have an account for the RADIUS server.</p>	<p>Select one:</p> <ul style="list-style-type: none"> Allowed to Loc Acct—User credentials are passed to the local account login function. Not Allowed—User is denied access and the session is terminated.

3. Select **6) Initialize Web UI Template Accounts**.
4. Enter the MySQL root account password when prompted.
5. Select **1) Servers**.

The system displays the RADIUS servers that are configured currently.
6. Enter **y** to add, remove, or modify a server from the list.



NOTE: Whenever you make changes to the server list, you must reenter all RADIUS servers.

7. When prompted, enter the following information:
 - Shared secret
 - Timeout period
 - Number of retries



NOTE: For shared secret, only alphanumeric characters and special characters such as “at” sign (@), curly braces ({}), pound sign (#), percent sign (%), tilde (~), square brackets ([]), equal sign (=), comma (,), em dash (–), and underscore (_) are supported.

Configuring the SBR Server's Dictionary Files

To configure the SBR server's dictionary files:

1. Log in to the SBR server as an administrator.
2. Open the file **C:\Program Files\Juniper Networks\Steel-Belted RADIUS\Service\juniper.dct** and append the following new block of text to the bottom of the file:

```
#####
# CTP Specific Attributes
#####
ATTRIBUTE Juniper-CTP-Group Juniper-VSA(21, integer) r
VALUE Juniper-CTP-Group Read_Only 1
VALUE Juniper-CTP-Group Admin 2
VALUE Juniper-CTP-Group Privileged_Admin 3
VALUE Juniper-CTP-Group Auditor 4
ATTRIBUTE Juniper-CTPView-APP-Group Juniper-VSA(22,integer) r
VALUE Juniper-CTPView-APP-Group Net_View 1
VALUE Juniper-CTPView-APP-Group Net_Admin 2
VALUE Juniper-CTPView-APP-Group Global_Admin 3
VALUE Juniper-CTPView-APP-Group NET_DIAG 4
ATTRIBUTE Juniper-CTPView-OS-Group Juniper-VSA(23, integer) r
VALUE Juniper-CTPView-OS-Group Web_Manager 1
VALUE Juniper-CTPView-OS-Group System_Admin 2
VALUE Juniper-CTPView-OS-Group Auditor 3
#####
# CTP Specific Attributes
#####
```

3. Open the file **C:\Program Files\Juniper Networks\Steel-Belted RADIUS\Service\vendor.ini** and locate the block of text that begins:

```
vendor-product = Juniper M/T Series
```

4. Add the following text after that block.

```
vendor-product = Juniper CTP Series
dictionary = Juniper
ignore ports = no
port-number-usage = per-port-type
help-id = 2000
```




NOTE: SBR Enterprise Release 6.1.4 and SBR Carrier Release 7.2.4 supports the RADIUS attributes required for CTP Series. This step is required only if you are using an earlier version of SBR and the Juniper CTP Series attribute is not listed.

5. Restart the Steel-Belted RADIUS service on the server.

Configuring the SBR Server's Active Authentication Method

To configure the SBR server's active authentication method:

1. Launch the Steel-Belted RADIUS Administrator application from your web browser by entering the address `http://SBR-server-IP-address:1812`.
2. Click **Launch**.
3. Select **Steel-Belted RADIUS > Authentication Policies > Order of Methods**.

Ensure that your chosen method, Native User or SecurID User, is listed under the section Active Authentication Methods.

Adding the CTPView Server as a RADIUS Client on an SBR Server

To add the CTPView server as a RADIUS client on an SBR server:

1. Launch the Steel-Belted RADIUS Administrator application from your web browser by entering the address `http://SBR-server-IP-address:1812`.
2. Click **Launch**.
3. Select **Steel-Belted RADIUS > RADIUS Clients**.
4. Add your CTPView server as a client. In the Make or model field, select **Juniper CTP Series**.

Adding CTPView Users to an SBR Server

To add CTPView users to an SBR server:

1. Launch the Steel-Belted RADIUS Administrator application from your web browser by entering the address `http://SBR-server-IP-address:1812`.
2. Click **Launch**.
3. Select the user type.
 - For native users, select **Steel-Belted RADIUS > Users > Native**.
 - For RSA SecurID users, select **Steel-Belted RADIUS > Users > SecurID**.
4. Add a user with the Add Native User dialog box or the Add SecurID dialog box, depending on your choice in the previous step.

5. In the Attributes section, click the **Return List** tab and then click **Add**. The Add Return List Attribute dialog box opens.
6. In the Attributes section select **Juniper-CTPView_APP-Group**.
7. In the Value section select one of the following authorization levels for the user you are adding:
 - Global_Admin
 - Net_Admin
 - Net_View
 - Net_Diag

Assigning SecurID Tokens to CTPView Users

SecurID authentication requires that you issue a SecurID token to each user and assign it to them on the RSA SecurID appliance. The first time a new user logs in to the CTPView software, the *token code* displayed on the SecurID token is the password. The user is then prompted to create a PIN. On subsequent logins, the user's PIN followed immediately by the token code displayed on the SecurID token is the password.

To assign SecurID tokens:

1. On the RSA SecurID appliance, launch the RSA Authentication Manager Host Mode application.
2. Select **User > Add User**.
3. Complete at least the following required fields:
 - Last Name
 - Default Login
 - Required to Create a PIN
 - Assign Token

Configuring CTPOS and CTPView User Authentication with TACACS+

The TACACS+ protocol provides access control (authentication, authorization, and accounting services) for routers and network access servers through one or more centralized TACACS+ servers. Unlike RADIUS, TACACS+ provides separate handling of authentication, authorization, and accounting services. CTPOS and CTPView use only authentication and authorization services, and do not use the accounting service.

CTP devices act as TACACS+ clients, which send request for authentication and authorization from the centralized TACACS+ servers that have separate user databases for CTPOS CLI users, CTPView CLI users, and CTPView Web UI users.

TACACS+ is supported only on CTPOS Release 6.4 and later and CTPView Release 4.4 and later. In earlier releases, RADIUS is used for remote authentication and authorization.

Effective from CTPOS Release 6.4 and CTPView Release 4.4, both RADIUS and TACACS+ are supported.

CTP uses TACACS+ authentication to authenticate users based on the login credentials that are configured on the centralized TACACS+ servers and provides the privileges to the TACACS+ clients. The user is logged in to the device with the privileges that TACACS+ server returns after successful authentication and authorization.

- [Configuring TACACS+ Settings from the CTPView Server on page 119](#)
- [Configuring TACACS+ Settings from the CTPView Web Interface on page 120](#)

Configuring TACACS+ Settings from the CTPView Server

You can configure TACACS+ for CTPView CLI and CTPView HTTPS users only from CTPView menu. You cannot enable both RADIUS and TACACS+ at the same time. You can enable TACACS+ only after disabling RADIUS.

To configure TACACS+ settings on the CTPView server:

1. From the AAA Menu, select **2) SSH(2nd) - RADIUS/RSA > 2) TACACS+**.

The current status of TACACS+ is displayed.

Currently, SSH - TACACS+ is set to Disabled.

Please choose a menu item from the following list:

0) Return to previous menu

1) Enable

2) Disable

Enter your selection for SSH - TACACS+

Please input an integer between 0 and 2 [0]:

2. Select **1) Enable** to enable TACACS+.

Please choose a menu item from the following list:

0) Return to previous menu

1) RADIUS/RSA: Disabled

2) TACACS+: Enabled

Please input your choice [0]:

3. Return to the AAA Menu, and select **9) TACACS+ Configuration > 1) Servers** to configure the TACACS+ servers.
4. Follow the onscreen instructions and configure the parameters as described in [Table 15 on page 120](#).

Table 15: TACACS+ Settings for CTPView Server

Field	Function	Your Action
Servers	<p>You can configure up to 10 TACACS+ servers each for CTPOS and CTPView users for authentication and authorization.</p> <p>The CTP device tries to authenticate the user from the first server in the list. If the first server is unavailable or fails to authenticate, then it tries to authenticate from the second server in the list, and so on.</p> <p>Authorization is done on the server that successfully authenticates the user.</p>	<p>Enter the IP address of the server and specify the shared secret.</p> <p>Shared secret is the secret key used to encrypt and decrypt packets that are sent and received from the server. The same secret key is used to encrypt and decrypt packets that are sent to and received from the TACACS+ clients.</p>
Destination Port	<p>TACACS+ uses the TCP port for sending and receiving data.</p> <p>Port 49 is reserved for TACACS+ and is the default port.</p>	Enter the destination port number.
Timeout	<p>Time in seconds that the TACACS+ client should wait for a response from the TACACS+ server after sending the authentication and authorization request. Timeout value applies to all the TACACS+ servers that are configured.</p> <p>The default timeout value is 5 seconds.</p>	Specify a value in the range 1–60.
Off-Line-Failover	<p>You can use the local authentication credentials if the configured TACACS+ servers are unavailable or no response is received from the TACACS+ servers.</p> <p>The default option is Allowed to Loc Acct.</p>	<p>Select one.</p> <ul style="list-style-type: none"> • Not Allowed • Allowed to Loc Acct
Reject-Failover	<p>You can use the local authentication credentials if the TACACS+ server rejects the attempt to authenticate.</p> <p>The default option is Allowed to Loc Acct.</p>	<p>Select one.</p> <ul style="list-style-type: none"> • Not Allowed • Allowed to Loc Acct

5. From the TACACS+ Menu, select **6) Initialize Web UI Template Accounts**.

6. Enter the MySQL administrator account password when prompted.

The required template accounts are added to CTPView. These accounts are not configurable. This step is performed as part of the initial configuration of CTPView as a TACACS+ client. However, repeating this step has no detrimental effect on the TACACS+ configuration.

Configuring TACACS+ Settings from the CTPView Web Interface

You can configure TACACS+ for CTPOS users from the CTPView web interface.

To configure TACACS+ from the CTPView web interface:

1. In the side pane, select **System > Configuration**.
2. Click **Node Settings > TACACS+ Settings** tab.

The TACACS+ Settings page is displayed.

3. Configure the parameters described in [Table 16 on page 121](#) and click **Submit Settings**.
4. (Optional) Click **System > Query > Node Settings** to verify the TACACS+ configuration details.

Table 16: TACACS+ Settings for the CTPView Web Interface

Field	Function	Your Action
Status	Specifies whether TACACS+ is enabled or disabled. TACACS+ is disabled by default.	Select one. <ul style="list-style-type: none"> • Enabled • Disabled
Dest Port	TACACS+ uses the TCP port for sending and receiving data. Port 49 is reserved for TACACS+ and is the default port.	Enter the destination port number.
Timeout	Time in seconds that the TACACS+ client should wait for a response from the TACACS+ server after sending the authentication and authorization request. Timeout value applies to all the TACACS+ servers that are configured. The default timeout value is 5 seconds.	Specify a value.
Off-Line-Failover	You can use the local authentication credentials if the configured TACACS+ servers are unavailable or no response is received from the TACACS+ servers. The default option is Allowed to Loc Acct .	Select one. <ul style="list-style-type: none"> • Not Allowed • Allowed to Loc Acct
Reject-Failover	You can use the local authentication credentials if the TACACS+ server rejects the attempt to authenticate. The default option is Allowed to Loc Acct .	Select one. <ul style="list-style-type: none"> • Not Allowed • Allowed to Loc Acct
Servers	You can configure up to 10 TACACS+ servers each for CTPOS and CTPView users for authentication and authorization. CTP tries to authenticate the user from the first server in the list. If the first server is unavailable or fails to authenticate, then it tries to authenticate from the second server in the list, and so on. Authorization is done on the server that successfully authenticates the user.	Enter the IP address of the server, and specify a shared secret.
Shared Secret	Shared secret is the secret key that TACACS+ servers use to encrypt and decrypt packets that are sent and received from the server. TACACS+ clients use the same secret key to encrypt and decrypt packets.	Specify the shared secret.

Related Documentation • [Configuring the TACACS+ Server](#)

Managing the CTPView Server (CTPView Server Menu)

- [Managing CTPView Server Secure Logs \(CTPView Server Menu\) on page 123](#)
- [Setting the CTPView Server Start-Up Banner \(CTPView Server Menu\) on page 125](#)
- [Managing Access Security for the CTPView Server \(CTPView Server Menu\) on page 125](#)
- [Establishing an SSH Connection \(CTP Menu\) on page 127](#)
- [Configuring an SSH Connection to a CTP Platform That Persists Through the Session \(CTPView Server Menu\) on page 127](#)
- [Saving the CTPView Configuration Settings and Data \(CTPView Server Menu\) on page 129](#)
- [Creating More Disk Space on the CTPView Server \(CTPView Server Menu\) on page 130](#)
- [Restoring CTPView Software Configuration Settings and Data with the Restore Utility \(CTPView Server Menu\) on page 131](#)
- [Restarting the MySQL Server \(CTPView Server Menu\) on page 131](#)
- [Setting the Logging Level \(CTPView Server Menu\) on page 132](#)

Managing CTPView Server Secure Logs (CTPView Server Menu)

This topic describes management of the `/var/log/secure` and `/var/log/secure.ext` logs stored on the CTPView server. The secure log provides an audit trail of user and administrator activity on the CTPView server. All actions performed on the CTPView server through the menu are logged and viewable. These logs do not record actions taken through the CTPView GUI.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To manage event logs, you must first access the Secure Log Management Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
The Main Security Profile Configuration Menu is displayed.
2. Select **3) Secure Log Management**.

The Secure Log Management Menu is displayed.

- [Viewing Secure Logs \(CTPView Server Menu\) on page 124](#)
- [Copying Secure Logs to a Remote Host \(CTPView Server Menu\) on page 124](#)
- [Configuring Remote Logging Options \(CTPView Server Menu\) on page 124](#)
- [Displaying the Remote Logging Configuration \(CTPView Server Menu\) on page 124](#)

Viewing Secure Logs (CTPView Server Menu)

To display all secure logs:

1. From the Secure Log Management Menu, select **1) Scan/view log entries**.
2. Follow the displayed instructions to navigate through the logs.

Copying Secure Logs to a Remote Host (CTPView Server Menu)

Before you perform this operation, you must have the IP address, username, and path to the directory in the user's account where the files will be copied.

To copy the logs to a remote host using secure copy (scp):

1. From the Secure Log Management Menu, select **2) Copy logs to remote host**.
2. Enter the information for the remote host as prompted.

Configuring Remote Logging Options (CTPView Server Menu)

You can enable the secure logs to be automatically logged to one or more remote servers.

To configure remote logging options:

1. From the Secure Log Management Menu, select **3) Configure remote logging options**.
2. Enable or disable remote logging.
3. If you have enabled remote logging, enter the IP address as prompted for each remote log server.

When you enable or disable remote logging, the system logger is shut down and then restarted to either send or stop sending subsequent logs to the remote servers.

Displaying the Remote Logging Configuration (CTPView Server Menu)

To display the remote logging configuration:

- From the Secure Log Management Menu, select **4) Show remote logging configuration**.

The status of remote logging is displayed. When remote logging is enabled, the IP address of the remote logging servers is also displayed.

Setting the CTPView Server Start-Up Banner (CTPView Server Menu)

When you log in to the CTPView server, a log-in or start-up banner presents a message. You can change the banner to provide an appropriate message.

To set the start-up banner:

1. From the CTPView Configuration Menu, select **1) Security Profile**.

The Main Security Profile Configuration Menu is displayed.

2. Select **4) Change login banner**.

The current banner is displayed.

3. Enter **y** to continue.

4. Enter your message in the field, up to 80 characters per line.

Only alphanumeric characters, commas, and underscores are allowed in the text.

5. Enter a blank line to end the message.

The new message is displayed.

6. Enter **y** to accept the new message.



NOTE: The log in banner is pushed to all CTP platforms on the network. You see the banner when you log in to CTPView whether by the GUI or by secure shell to the server.

Related Documentation

- [Setting the CTP Platforms Login Banner \(CTPView\) on page 70](#)

Managing Access Security for the CTPView Server (CTPView Server Menu)

You can control access to the CTPView server by setting security levels for access to the CTPView server through the CTPView GUI or through an SSH connection. The security levels determine the severity of password restrictions, installation or removal of certain utilities, control of root log in, and so on.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To manage security access levels, you must first access the Security Level Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
2. Select **5) Modify Security Level**.

The Security Level Menu is displayed.

- [Viewing the Access Security Level for the CTPView Server \(CTPView Server Menu\) on page 126](#)
- [Setting Access Security for the CTPView Server \(CTPView Server Menu\) on page 126](#)

Viewing the Access Security Level for the CTPView Server (CTPView Server Menu)

To display the current settings for access to the CTPView server:

- From the Security Level Menu, select **1) View current security level**.

The security level for access through an SSH connection and to the CTPView GUI are displayed.

Setting Access Security for the CTPView Server (CTPView Server Menu)

To set the security level for access to the CTPView server:

1. From the Security Level Menu, select one of the following options to set the SSH access level: **3) Set OS level to 'very-low'**, **4) Set OS level to 'low'**, **5) Set OS level to 'high'**.

[Table 17 on page 126](#) describes these security levels.

2. Select one of the following options to set the CTPView GUI access level: **6) Set GUI level to 'low'** or **7) Set GUI level to 'high'**.

[Table 18 on page 127](#) describes these security levels.

The `sshd` process is stopped and restarted whenever you change the security level.

Table 17: Access Security Levels for SSH Connections

Access Security Level	Description
very-low	<ul style="list-style-type: none"> • Enables root login. • Disables session inactivity timeout. • Enables Fedora Core OS default username/password restrictions. • Enables single-user mode login for password recovery. • Installs <code>tcpdump</code> and <code>hdparm</code> utilities. These files must exist in the <code>/tmp</code> directory.
low	<ul style="list-style-type: none"> • Disables root login. • Disables session inactivity timeout. • Enables Fedora Core OS default username/password restrictions. • Enables single-user mode login for password recovery. • Installs <code>tcpdump</code> and <code>hdparm</code> utilities. These files must exist in the <code>/tmp</code> directory.
high	<ul style="list-style-type: none"> • Disables root login. • Enables session inactivity timeout. • Enables elevated username/password restrictions. • Disables single-user mode login. • Removes <code>tcpdump</code> and <code>hdparm</code> utilities.

Table 18: Access Security Levels for CTPView GUI

Access Security Level	Description
low	Enables permissive username/password restrictions.
high	Enables elevated username/password restrictions.

Establishing an SSH Connection (CTP Menu)

You can establish a secure connection to any CTP device to administer and maintain it remotely over the network. You can establish an SSH connection to a remote host from the CTPMenu by specifying the IP address of the remote host. You can also use the CTPView Node Maintenance window to establish an SSH session to a host. This topic describes how to establish a secure connection to a remote host from the CTPMenu.



NOTE: Only system administrators are allowed to establish SSH connections to other devices.

To establish an SSH connection to a remote host from the CTP Menu:

1. From the Main Menu, select **5) Node Operations**.
2. Select **7) ssh to another host**.
3. When prompted, enter the IP address of the host to connect to that host.

Configuring an SSH Connection to a CTP Platform That Persists Through the Session (CTPView Server Menu)

This topic describes how to configure the CTPView server so that an SSH connection remains established for the entire session when the CTPView server connects to a CTP platform.

SSH port forwarding creates an encrypted and protected connection between the CTPView software and a remote CTP platform, that remains up as long as the server connection to the platform is up. It must be enabled on both the CTP platform and the CTPView software; it is enabled on both by default. When this feature is not enabled, the CTPView server creates a separate SSH connection to the platform for each command and configuration change. This feature reduces overhead and increases performance of the CTPView software. You can choose to disable this feature or reenale it.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To configure the CTPView server for port forwarding, you must first access the Port Forwarding Menu:

- From the CTPView Configuration Menu, select **3) Port Forwarding**.

The Port Forwarding Menu is displayed.

- [Viewing the Current State of Port Forwarding \(CTPView Server Menu\) on page 128](#)
- [Setting Port Forwarding Permissions \(CTPView Server Menu\) on page 128](#)
- [Closing Port Forwarding Sockets \(CTPView Server Menu\) on page 128](#)
- [Clearing Open Sockets by Restarting the Apache Daemon \(CTPView Server Menu\) on page 128](#)

Viewing the Current State of Port Forwarding (CTPView Server Menu)

To display the current state of port forwarding on the CTPView server:

- From the Port Forwarding Menu, select **1) View Current State**.

The state is displayed, Allowed or Prohibited.

Setting Port Forwarding Permissions (CTPView Server Menu)

To set the permissions for port forwarding on the CTPView server:

1. From the Port Forwarding Menu, select **2) Set Port Forwarding Permissions**.
2. Select **1) Allow** or **2) Prohibit**.

The new state is displayed.

Closing Port Forwarding Sockets (CTPView Server Menu)

To close all open port forwarding sockets on the CTPView server:

- From the Port Forwarding Menu, select **3) Close Port Forwarding Sockets**.

Clearing Open Sockets by Restarting the Apache Daemon (CTPView Server Menu)

When you configure port forwarding, you may want to clear all the open sockets that were used for the previous port forwarding configuration. You can do so by restarting the Apache daemon.

To restart the Apache daemon on the CTPView server:

- From the Port Forwarding Menu, select **4) Restart Apache Daemon**.

You can also restart the Apache daemon elsewhere in the server menus. From the CTPView Configuration Menu, select **7) CTPView Access Functions > 2) Restart Apache Daemon**.

Related Documentation

- [Configuring an SSH Connection to a CTP Platform that Persists Through the Session \(CTPView\) on page 71](#)

Saving the CTPView Configuration Settings and Data (CTPView Server Menu)

This topic describes how to save the current configuration settings and data for the CTPView software. Although you can perform this task at any time, it is typically performed before you upgrade the CTPView server OS and the CTPView software.

You can use the backup utility in the CTPView server menu to save the information into an archive (.tgz) file and, if desired, move the archive to an external storage device. If you do not use the utility to move the archive, you can later copy or move it manually from outside the CTPView server menu.



NOTE: If you do not move the archive file to an external storage device, you are not protected from loss of the backed-up data. If you are upgrading the software, you must move the file to an appropriate location.

Alternatively, when you have more than one CTPView server, you can use the CTPView software GUI to synchronize the server with another server to save the settings and data. See [“Synchronizing Multiple CTPView Servers \(CTPView\)” on page 81](#) for the synchronization procedure.



NOTE: We recommend that you use the CTPView server backup utility to save your current information.

Before you use the CTPView server backup utility:

- Confirm that the external storage device is running a UNIX-like operating system and is enabled for SSH connections.



NOTE: Although the external storage device can use any operating system, the CTPView backup utility can automatically transfer the backup file only to a device that is running a UNIX-like operating system. If the device is running a different kind of OS, you must transfer the backup file with a copy utility that is compatible with that OS.

- Confirm that a network path exists between the CTPView server and the external storage device used for storing the backup file.
- Confirm that the hard drive on the CTPView server that you are backing up has at least 25 percent free space. If you attempt to run the backup utility when less than 25 percent free space is available, the utility prompts you to delete more old data files before you continue. See [“Creating More Disk Space on the CTPView Server \(CTPView\)” on page 17](#).
- Log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To back up your current information with the CTPView server backup utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions Menu is displayed.

2. Select **1) Save Current Settings and Data**.

If an archive file already exists in the `/var/www/html/acorn/data` directory on the server, the utility prompts you to delete or move the archive.

3. (Optional) From outside the menu (for example, in another terminal window), manually move the old archive to an external storage device if you want to save the information.
4. Enter **y** to delete the old archive.

The utility deletes the old archive file and creates the new archive file.

5. Enter **y** to move the new archive to an external location.
6. Follow the prompts to enter the IP address, username, and absolute path to the external device.

**Related
Documentation**

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Creating More Disk Space on the CTPView Server \(CTPView\) on page 17](#)
- [Creating More Disk Space on the CTPView Server \(CTPView Server Menu\) on page 18](#)

Creating More Disk Space on the CTPView Server (CTPView Server Menu)

This topic describes how to create free space by removing redundant data files from the server.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To delete old files to create more free disk space:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions menu is displayed.

2. Select **3) Remove Redundant Binary Data Files**.

**Related
Documentation**

- [Saving the CTPView Configuration Settings and Data \(CTPView Server Menu\) on page 16](#)
- [Installing or Upgrading the CTPView Server OS on page 14](#)

Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)

This topic describes how to use the CTPView restore utility to restore the CTPView software configuration settings and data from a previously saved archive file.

Before you begin:

- Copy the backup (archive) file from its externally saved location to the `/var/www/html/acorn/data` directory on the server. The filename is in the format `ctpview_data_server-name_date.tgz`.
- Log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To restore your saved information with the CTPView restore utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions menu is displayed.

2. Select **2) Restore Settings and Data**.

You are prompted to use the archive file. After the restore script runs, you are prompted to run it again.

Related Documentation

- [Installing or Upgrading the CTPView Server OS on page 14](#)
- [Restoring CTPView Software Configuration Settings and Data \(CTPView\) on page 19](#)

Restarting the MySQL Server (CTPView Server Menu)



NOTE: Restart the MySQL server only under the guidance of the Juniper Networks Technical Assistance Center (JTAC).

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To restart the MySQL server on the CTPView server:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **3) Restart MySQL Server**.

The MySQL server is stopped and then restarted.

Setting the Logging Level (CTPView Server Menu)

You can specify the logging level, which determines what events are logged. The log output is placed in the `/var/log/acornngui.log` file.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To set the logging level:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **7) Set Logging Level**.
3. Enter one of the following:
 - **1) Normal (Most commands, All errors)**
 - **2) Debug Level 1 (All commands, All errors)**
 - **3) Debug Level 2 (All commands, All output)**

CHAPTER 15

Restoring Default Values on the CTPView Server

- [Resetting the Default System Administrator Account \(CTPView Server Menu\) on page 133](#)
- [Resetting the Data File Permissions \(CTPView Server Menu\) on page 133](#)
- [Resetting the CTPView System Files to the Default Values \(CTPView Server Menu\) on page 134](#)
- [Burning an Image of CTPOS to a CompactFlash Card \(CTPView Server Menu\) on page 136](#)
- [Resetting the Default Firewall Settings \(CTPView Server Menu\) on page 137](#)

Resetting the Default System Administrator Account (CTPView Server Menu)

You can remove the configured values for the CTPView System Administrator account and restore the default values.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To reset the System Administrator account and password to the default values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **6) Reset account for default System Administrator**.

Resetting the Data File Permissions (CTPView Server Menu)

You can remove all configured permissions for the CTPView server data files.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To reset the data file permission values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.

2. Select **5) Reset Data File Permissions**.
3. Enter **1) Yes** when prompted to continue.

Resetting the CTPView System Files to the Default Values (CTPView Server Menu)

You can remove all configured values for the CTPView server system files and restore the default values.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To reset the CTPView system files to the default values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **3) Reset System Files to default CTPView values**.
3. Enter **1) Yes** when prompted to continue.

CTPView displays information about the actions taken, as shown in the following sample output.

```
*****
Modifying the system files on this server to Juniper CTPView default values .
. .

===== Refreshing log directory =====
===== setting log file permissions =====
===== Verifying default umask =====
===== Updated runtime level in /etc/inittab file =====
===== Serial console access already set in /etc/inittab file =====
===== Added ttyS0 to /etc/securetty file =====
===== Serial parameters already set in /boot/grub/grub.conf file =====
===== Timeout parameters already set in /boot/grub/grub.conf file =====
===== CTPView title already set in /boot/grub/grub.conf file =====
===== Disabling pool.ntp.org servers in /etc/ntp.conf file =====
===== Enabling 127.127.1.0 as local clock in /etc/ntp.conf file =====
Shutting down ntpd:                [ OK ]
Starting ntpd:                      [ OK ]
===== Setting status of system services =====
== set httpd on
Stopping httpd:                    [ OK ]
Closing CTPView sockets:           [ OK ]
Starting httpd:                    [ OK ]
== set ntpd on
Shutting down ntpd:                [ OK ]
Starting ntpd:                      [ OK ]
== set sendmail on
Shutting down sm-client:           [ OK ]
Shutting down sendmail:            [ OK ]
Starting sendmail:                 [ OK ]
Starting sm-client:                 [ OK ]
== set sshd on
Stopping sshd:                     [ OK ]
Starting sshd:                     [ OK ]
```

```

== set mysqld on
Stopping MySQL: [ OK ]
Starting MySQL: [ OK ]
== set network on
Shutting down interface eth0: [ OK ]
Shutting down loopback interface: [ OK ]
Bringing up loopback interface: [ OK ]
Bringing up interface eth0: [ OK ]
== set auditd on
Stopping auditd: [ OK ]
Error deleting rule (Operation not permitted)
Starting auditd: [ OK ]
Error deleting rule (Operation not permitted)
There was an error in line 7 of /etc/audit/audit.rules
== set anacron off
== set atd off
== set netfs off
== set nfslock off
== set NetworkManager off
===== File /etc/cron.daily/00-logwatch did not exist
===== Directory /mnt/usbhd already exists
===== Directory /mnt/flash already exists
===== Directory /mnt/cdrom already exists
===== Cleared /etc/resolv.conf file
===== Restarting network daemon =====
Shutting down interface eth0: [ OK ]
Shutting down loopback interface: [ OK ]
Bringing up loopback interface: [ OK ]
Bringing up interface eth0: [ OK ]
===== nullok option already disabled in /etc/pam.d/system-auth file =====
===== Setting credit options in /etc/pam.d/system-auth file =====
===== Setting remember options in /etc/pam.d/system-auth file =====
===== Setting configuration in /etc/ssh/sshd_config file =====
===== Setting configuration in /etc/ssh/ssh_config file =====
===== Setting single user login configuration =====
===== Setting login.def parameters =====
===== Setting man file permissions =====
===== Setting access.conf parameters =====
===== Disable <Ctrl><Alt><Del> =====
===== Setting root directory file permissions =====
===== Setting nosuid in fstab file =====
===== Setting allowable cron access =====
===== Setting cron permissions =====
===== Setting httpd permissions =====
===== Setting logwatch.pl permissions =====
===== Setting denied at access =====
===== Setting sysctl parameters =====
===== Setting traceroute permissions =====
===== Disable decode alias =====
===== Setting snmpd permissions =====
===== Setting rsyslog permissions =====
===== Setting encryption parameters =====
===== Setting security tools permissions =====
===== Rotating logs =====
===== Removing non-owned files =====
find: /proc/4297/task/4297/fd/4: No such file or directory
find: /proc/4297/task/4297/fd/4: No such file or directory
find: /proc/4297/task/4297/fdinfo/4: No such file or directory
find: /proc/4297/task/4297/fdinfo/4: No such file or directory
find: /proc/4297/fd/4: No such file or directory
find: /proc/4297/fd/4: No such file or directory

```

```
find: /proc/4297/fdinfo/4: No such file or directory
find: /proc/4297/fdinfo/4: No such file or directory
===== Restarting sshd =====
Stopping sshd: [ OK ]
Starting sshd: [ OK ]
===== Disabling welcome page =====
===== Disabling browser access to manual =====
===== Setting KeepAlive to On =====
===== Setting StartServers to 8 =====
===== Setting MaxSpareServers to 10 =====
===== Setting -ExecCGI Option =====
===== Setting -FollowSymLinks Option =====
===== Setting -IncludesNOEXEC Option =====
===== Setting -MultiViews Option =====
===== Setting -Indexes Option =====
===== Setting LimitRequestBody Option =====
===== Restarting httpd daemon =====
Stopping httpd: [ OK ]
Closing CTPView sockets: [ NONE ]
Starting httpd: [ OK ]
===== Setting cgi-bin permissions =====
===== Setting httpasswd permissions =====
===== Removing application/x-shell mime types =====

>>>>> JUNIPER SERVER MODIFICATIONS COMPLETE. <<<<<<
```

Burning an Image of CTPOS to a CompactFlash Card (CTPView Server Menu)

You can burn CTPOS images to a CompactFlash Card either from the CTPView Server Menu or from the CTPView Server CLI. This section describes how to burn an image of CTPOS from the CTPView Server Menu.

Before using CTPView to burn CTP software images onto CompactFlash cards, you must copy the appropriate CTP image files to the proper directory on the CTPView server. Released versions of CTP operating system software images are available for download from the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>. You need your customer support username and password to access this site.

Place the CTP flash image file on the CTPView server in the `/var/www/html/flash/` directory. To copy software into this directory, you must be a root user or a member of the UNIX group `server`, such as the default user `juniper`. You do not need to modify the file's ownership and permissions after you copy it into the `/flash` directory.

Before you begin, log in to the CTPView server and access the CTPView Server Configuration Menu. See “[Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)](#)” on page 103.

To burn an image of the CTPOS:

1. From the CTPView Server Configuration Menu, select **4) Advanced Functions**.
2. Select **8) Burn CTPOS Flash Image**.

Related Documentation • [Burning CTPOS Images to a CompactFlash Card \(CTPView Server CLI\) on page 40](#)

Resetting the Default Firewall Settings (CTPView Server Menu)

You can remove all configured values for the CTPView server firewall and restore the default values.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To reset the CTPView server firewall settings to the default values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **1) Reset Default Firewall Settings**.
3. Enter **1) Yes** when prompted to continue.

The default firewall values are restored in `/etc/sysconfig/iptables`. The NTP daemon is started, and the SSH daemon is stopped and then restarted.

CHAPTER 16

Changing Administrative Passwords to Improve Access Security

- [Changing Passwords to Improve Access Security on page 139](#)
- [Changing the BIOS Menu Password \(CTPView Server CLI\) on page 140](#)
- [Changing the Server's Root Account Password \(CTPView Server CLI\) on page 141](#)
- [Changing the GRUB Boot Loader Password \(CTPView Server Menu\) on page 141](#)
- [Changing the MySQL Apache Account Password \(CTPView Server Menu\) on page 142](#)
- [Changing the MySQL Root Account Password \(CTPView Server Menu\) on page 143](#)

Changing Passwords to Improve Access Security

A number of administrative passwords must be changed when you install a new CTPView server or upgrade the software. Juniper Networks also recommends that you change the following administrative passwords at least on an annual basis, and whenever CTP network administrators are changed.

To change administrative passwords:

- Change the BIOS menu password.
[See “Changing the BIOS Menu Password \(CTPView Server CLI\)” on page 29.](#)
- Change the CTPView server's root account password.
[See “Changing the Server's Root Account Password \(CTPView Server CLI\)” on page 31.](#)
- Change the GRUB Boot Loader password.
[See “Changing the GRUB Boot Loader Password \(CTPView Server Menu\)” on page 31.](#)
- Change the MySQL Apache account password.
[See “Changing the MySQL Apache Account Password \(CTPView Server Menu\)” on page 32.](#)
- Change the MySQL root account password.
[See “Changing the MySQL Root Account Password \(CTPView Server Menu\)” on page 33.](#)

Changing the BIOS Menu Password (CTPView Server CLI)

For security purposes, change the default password for BIOS menu access. This account has no username associated with it. The BIOS menu password should conform to your local password requirements.



BEST PRACTICE: Change the BIOS menu password at least yearly and whenever administrators change.

To change the BIOS menu password:

1. Power on or reboot the server.
2. During the boot process, press F2 while the Dell logo is displayed on the monitor. The boot process continues and displays several messages in turn on the screen.
3. Enter the default password when the process pauses and displays “Enter Setup Password.”

For the default BIOS menu password, see [“Default CTPOS and CTPView Accounts and Passwords” on page 43](#).

4. At the BIOS menu, select **System Security** and press Enter.
5. Highlight **Setup Password**—be sure that you have not selected **System Password**—and press Enter.
6. Enter your new BIOS password, reenter it, and then Press Enter to continue.
7. Press Esc.
8. In the window that opens, select **Save Changes and Exit** and press Enter.

The server restarts.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Changing the Server's Root Account Password (CTPView Server CLI)

For security purposes, change the default password for the server's root user account. The root account password should conform to your local password requirements.



BEST PRACTICE: Change the root account password at least yearly and whenever administrators change.

To change the root account password:

1. Log in to the CTPView server as a non-root user, using either a directly connected keyboard and monitor or an SSH application over your network.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “[Configuring the Network Access \(CTPView Server Menu\)](#)” on page 33.

2. Enter **su -** to switch to the root account.
3. Enter the default root password.

For the default root password, see “[Default CTPOS and CTPView Accounts and Passwords](#)” on page 43. You cannot log in using the root account.

4. Enter **passwd**.
5. Enter your new password.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Changing the GRUB Boot Loader Password (CTPView Server Menu)

For security purposes, change the default password for the GRUB Boot Loader menu.



BEST PRACTICE: Change the GRUB Boot Loader password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “[Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)](#)” on page 103.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)”](#) on page 33.

To change the GRUB Boot Loader password:

1. From the CTPView Configuration Menu, select **Option 8 (GRUB Functions)**.
2. Select **1) Change GRUB password**.
3. Follow the prompts to complete changing the password.

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Changing the MySQL Apache Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server Apache user account.



BEST PRACTICE: Change the MySQL Apache password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)”](#) on page 103.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)”](#) on page 33.

To change the MySQL Apache password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **2) Change MySQL Apache password**.
3. Follow the prompts to complete changing the password.

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)

- [Changing Passwords to Improve Access Security on page 139](#)

Changing the MySQL Root Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server root user account.



BEST PRACTICE: Change the MySQL Root Account password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See [“Configuring the Network Access \(CTPView Server Menu\)” on page 33](#).

To change the MySQL root account password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **1) Change MySQL root password**.
3. Follow the prompts to complete changing the password.

Related Documentation

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Configuring the CTPView Administrative Settings on page 27](#)
- [Changing Passwords to Improve Access Security on page 139](#)

Using Third-Party Software on CTPView Servers

- [Third-Party Software on CTPView Servers on page 145](#)

Third-Party Software on CTPView Servers

You may choose to use third-party software on your CTPView server.



NOTE: Third-party software installed on the CTPView server is not supported by Juniper Networks.

Typical third-party software is one of the following types:

- System file monitoring and management software

Tripwire third-party software is preloaded onto the CTPView server. Tripwire facilitates security, intrusion detection, damage evaluation, and recovery. You can use this software to generate a baseline of system files and directories after you have configured your server to a known secure state. Tripwire subsequently monitors the system files and directories and compares them with the baseline, enabling you to identify any changes that have been made.

Refer to the Tripwire documentation for more information. Complete documentation is located on the CTPView server in the

`/usr/share/doc/tripwire-<current-version-number>` directory.

- Antivirus software

McAfee VirusScan for UNIX, version 5.10.0, is the only antivirus application from a DOD-approved vendor that is compatible with CTPView server software.

The CTPView server includes a dedicated directory, `/var/av`, for installation of antivirus software. You must be a member of the **server** group to install the antivirus software directly into the `/var/av` directory. After the software archive is in the `/var/av` directory, follow the installation directions in the McAfee product guide. We recommend that you select the default choices offered when installing the antivirus software. Refer to the antivirus documentation for more information about this software.

PART 4

Troubleshooting

- [Validating the CTPView Server System Configuration on page 149](#)
- [Restoring CLI Access to the CTPView Server on page 151](#)
- [Restoring Browser Access to a CTPView Server on page 157](#)
- [Changing a CTPOS User Password on page 159](#)
- [Booting the CTPView Server from the CD-ROM Drive on page 161](#)
- [Restarting the Apache Daemon In the Event of Browser Issues on page 163](#)

Validating the CTPView Server System Configuration

- [Validating the CTPView Server Configuration \(CTPView\) on page 149](#)

Validating the CTPView Server Configuration (CTPView)

This topic describes how to validate the CTPView server system configuration. Examining the system configuration information is a useful first step in troubleshooting many issues. Validate the configuration after installing or upgrading the CTPView software or server OS to determine whether the operation completed successfully.

The validation utility reports on a long list of configuration details that are critical or desirable for proper operation of the CTPView software. Instructions are provided for correcting items that are out of compliance.

To validate the system configuration:

1. Log in to the CTPView GUI.
2. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

3. Click **Validate Server Configuration**.

The Server Configuration Validation pane is displayed.

4. Confirm that all fields are set to their default values.

The display indicates whether each item is valid or noncompliant. A highlighted field indicates a problem. Follow the displayed instructions to correct the problem.

Related Documentation

- [Installing or Upgrading the CTPView Server OS on page 14](#)

CHAPTER 19

Restoring CLI Access to the CTPView Server

- [Restoring Access to a CTPView Server on page 151](#)
- [Accessing a Shell on the CTPView Server \(CTPView Server CLI\) on page 152](#)
- [Setting a New Password for a Nonroot User Account \(CTPView Server CLI\) on page 153](#)
- [Setting a New Password for a Root User Account \(CTPView Server CLI\) on page 154](#)
- [Creating a Nonroot User Account and Password \(CTPView Server CLI\) on page 154](#)

Restoring Access to a CTPView Server

You must use a nonroot password to log in to the CTPView server. If you lose all the nonroot passwords, then you cannot access the CTPView server.

To perform tasks on the server as a root user, you must first log in using an existing nonroot account. You then switch to the root account with the command **su -** and enter the root password.

This topic describes how to restore access to the CTPView server in any of the following events:

- You lose the passwords to all nonroot user accounts.
- You lose the root password.
- You lose the all nonroot user passwords and the root password.

Before you begin, you must have the GRUB Boot Loader password and physical access to the server with a connected monitor and keyboard.

If you do not have the GRUB Boot Loader password, you must use the system motherboard jumpers to disable the password protection feature before proceeding. You can find details about how to perform this task on the Dell PowerEdge Documentation CD, which was included with the original packing material for the CTPView server.

To restore access to the CTPView server when you have lost all nonroot user passwords:

1. Access a shell.

See [“Accessing a Shell on the CTPView Server \(CTPView Server CLI\)” on page 152](#).

2. Set a new password for a nonroot user account.

See [“Setting a New Password for a Nonroot User Account \(CTPView Server CLI\)”](#) on page 153.

3. Create a temporary nonroot user account and password, access the root account, and create a new permanent nonroot user.

See [“Creating a Nonroot User Account and Password \(CTPView Server CLI\)”](#) on page 154.

To restore access to the CTPView server when you have lost the root password:

1. Access a shell.

See [“Accessing a Shell on the CTPView Server \(CTPView Server CLI\)”](#) on page 152.

2. Set a new password for a root user account.

See [“Setting a New Password for a Root User Account \(CTPView Server CLI\)”](#) on page 154.

To restore access to the CTPView server when you have lost all nonroot user passwords and the root password:

1. Access a shell.

See [“Accessing a Shell on the CTPView Server \(CTPView Server CLI\)”](#) on page 152.

2. Set a new password for a root user account.

See [“Setting a New Password for a Root User Account \(CTPView Server CLI\)”](#) on page 154.

3. Set a new password for a nonroot user account.

See [“Setting a New Password for a Nonroot User Account \(CTPView Server CLI\)”](#) on page 153.

4. Create a temporary nonroot user account and password, access the root account, and create a new permanent nonroot user account.

See [“Creating a Nonroot User Account and Password \(CTPView Server CLI\)”](#) on page 154.

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)

Accessing a Shell on the CTPView Server (CTPView Server CLI)

Before you begin, you must have physical access to the server with a connected monitor and keyboard.

To gain access to a shell:

1. Use the power switch on the server to turn off the power.
2. Turn on the server power.
3. When the blue GNU GRUB screen appears, enter the letter **p**. You have only a few seconds to do this.
4. Enter the GRUB Boot Loader password.
5. Enter the letter **e**.
6. Use the keyboard arrows to highlight the line that begins with the word **kernel**.
7. Enter the letter **e**.
8. Enter the following code at the end of the highlighted line:

```
init=/bin/bash
```

9. Enter the letter **b**.

The system boots and displays the **bash-3.00#** shell prompt.

10. Enter the following command:

```
/bin/mount /dev/md2 -o remount,rw
```

Related Documentation

- [Restoring Access to a CTPView Server on page 151](#)

Setting a New Password for a Nonroot User Account (CTPView Server CLI)

Before you begin, prepare the server by accessing the shell. See “[Accessing a Shell on the CTPView Server \(CTPView Server CLI\)](#)” on page 152.

To set a new password for a nonroot user account:

1. Enter the following command:
2. Enter the new password for the nonroot user when prompted.
3. Enter the following command:

```
/bin/mount /dev/md2 -o remount,ro
```

4. Enter the command **reboot**.

Wait for the server to reboot.

Related Documentation

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Restoring Access to a CTPView Server on page 151](#)

Setting a New Password for a Root User Account (CTPView Server CLI)

Ensure that the new root account password conforms to your local password requirements.

Before you begin, prepare the server by accessing the shell. See [“Accessing a Shell on the CTPView Server \(CTPView Server CLI\)”](#) on page 152.

To set a new password for a root user account:

1. Enter the following command:

```
/usr/bin/passwd
```

2. Enter the new password when prompted.

3. Enter the following command:

```
/bin/mount /dev/md2 -o remount,ro
```

4. Enter the command **reboot**.

Wait for the server to reboot.

Related Documentation

- [Restoring Access to a CTPView Server on page 151](#)

Creating a Nonroot User Account and Password (CTPView Server CLI)

Before you begin, prepare the server by accessing the shell. See [“Accessing a Shell on the CTPView Server \(CTPView Server CLI\)”](#) on page 152.

To create a new account and password for a nonroot user:

1. Enter the following command:

```
/usr/sbin/useradd username
```

2. Enter the following command:

```
/usr/bin/passwd username
```

3. Enter the new password for the nonroot user when prompted.

4. Enter the following command:

```
/bin/mount /dev/md2 -o remount,ro
```

5. Enter the command **reboot**.

Wait for the server to reboot.

6. Log in as the new temporary user.

7. Enter the command **su -** to switch to the root account and display the CTPView Configuration Menu utility.

8. Create a new permanent nonroot user account.

9. Exit the utility, the root account, and then the temporary user account.
10. Log in as the new permanent nonroot user.
11. Enter the command **su -** to switch to the root account.
12. Enter the following command to delete the temporary user account:

/usr/bin/userdel -r username

**Related
Documentation**

- [CTPOS and CTPView Software Password Requirements on page 46](#)
- [Restoring Access to a CTPView Server on page 151](#)

CHAPTER 20

Restoring Browser Access to a CTPView Server

- [Restoring Browser Access to a CTPView Server \(CTPView Server Menu\) on page 157](#)

Restoring Browser Access to a CTPView Server (CTPView Server Menu)

You cannot recover lost usernames and passwords. If you lose access to the CTPView GUI as a Global_Admin user, you can use the following procedure to restore the default Global_Admin user account *Juniper*, select a new password for user *Juniper*, and assign the user to the default user group *TempGroup*.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See [“Accessing the CTPView Server Configuration Menu \(CTPView Server Menu\)” on page 103](#).

To restore browser access to the CTPView server:

1. From the CTPView Configuration Menu, select **7) CTPView Access Functions**.
2. Select **1) Reset password for default user Juniper**.
3. Follow the prompts to assign user *Juniper* to user group *TempGroup*. The user is given default user properties.
4. Log in to the CTPView GUI with the restored user password, and review the default user values in CTPView Admin Center. Make any appropriate changes.

Changing a CTPOS User Password

- [Changing a User Password for a CTP Platform on page 159](#)

Changing a User Password for a CTP Platform

The CTPOS software is installed on a CompactFlash card that normally operates in a read-only state. You must make the card writable in order to change a user password. Only the root user is allowed to make the CompactFlash card writable.

To change a CTP platform user's password:

1. Log in to the CTP platform as a nonroot user.
2. Enter the command **su -** to switch to the root account.
3. Enter the following command to make the CompactFlash card writable:
mfw
4. Open a new SSH window and log in with the username whose password you want to change.
5. Follow the prompts to change the password.
6. Enter the command **su -** to switch to the root account.
7. Enter the following command to return the CompactFlash card to read-only:
mfr



NOTE: For users who employ the utility SecureCRT for SSH to access the CTP platform, you must change the Authentication method on SecureCRT from the default setting of Password to Keyboard Interactive. If you fail to do so, the password prompts originating at the CTP platform are prevented from reaching your display, and the password update procedure fails.

Related Documentation

- [CTPOS and CTPView Software Password Requirements on page 46](#)

Booting the CTPView Server from the CD-ROM Drive

- [Booting the CTPView Server from the CD Drive on page 161](#)

Booting the CTPView Server from the CD Drive

For security purposes, booting from the CD drive is disabled in the system BIOS settings. If you need to boot from a CD, you must reconfigure the BIOS. You must also have physical access to the server and have the BIOS Menu password.

If you have forgotten the BIOS Menu password, use the system motherboard jumpers to disable the password protection feature before proceeding. Details about how to perform this task are found on the Dell PowerEdge Documentation CD, which was included with the original CTPView server packing material.

To boot the CTPView server from the CD drive:

1. Connect a monitor, keyboard, and mouse to the server.
2. Power on the server and press F2 while the Dell logo is displayed.

The phrase **Entering Setup** appears in the top right corner of the screen, and then the BIOS setup screen loads. If you miss pressing F2 at the proper time, press Ctrl+Alt+Delete to reboot the system so you can repeat this step.

The bottom line on the screen contains help for navigating and modifying this menu.

3. Insert the CD boot disk into the CD drive.
4. Enter the BIOS Menu password, and press Enter to continue.
5. Highlight **Boot Sequence**, press Enter, and select **IDE CD-ROM device**. Press Enter to continue.
6. Press Esc. In the pop-up window highlight **Save Changes and Exit**, and press Enter.

The server restarts and boots from the CD.



NOTE: For security considerations, it is important that you subsequently disable booting from a CD.

To disable booting from the CD drive:

1. Repeat Steps 1 through 4 above.
2. Highlight **Boot Sequence**, press Enter, and clear **IDE CD-ROM device**. Press Enter to continue.
3. Press Esc. In the pop-up window highlight **Save Changes and Exit**, and press Enter.

The server restarts and boots from CompactFlash memory.

CHAPTER 23

Restarting the Apache Daemon In the Event of Browser Issues

- [Restarting the Apache Daemon \(CTPView Server Menu\) on page 163](#)

Restarting the Apache Daemon (CTPView Server Menu)

If you are having problems viewing or accessing the CTPView GUI in your browser, you might want to restart the Apache daemon on the CTPView server.

To restore browser access to the CTPView server:

1. From the CTPView Configuration Menu, select **7) CTPView Access Functions**.
2. Select **2) Restart Apache Daemon**.

PART 5

Index

- [Index on page 167](#)

Index

A

access security	
CTPView server, managing.....	125
accounts	
creating CTPView server nonroot.....	154
default CTPOS.....	43
default CTPView server.....	43
address filter, IP See IP access filter	
Admin Center	
accessing.....	52
groups	
adding.....	55
deleting.....	58
modifying affiliation.....	54
modifying properties.....	55
monitoring.....	54
passwords	
changing requirements.....	59
excluding from use.....	58
limiting use.....	58
managing user.....	58
reinstating excluded.....	59
users	
adding.....	53
automatic logout.....	60
counters.....	61
deleting active.....	57
deleting inactive.....	57
deleting prohibited.....	58
displaying prohibited.....	56
IP access filters, creating.....	61
IP access filters, removing.....	61
locked-out IP addresses.....	61
lockout period.....	60
logging out selected.....	60
login attempts.....	60
login properties.....	59
managing access.....	56
modifying properties.....	54
monitoring.....	53

prohibiting.....	56
reinstating prohibited.....	57
administrative passwords	
changing.....	139
administrative settings	
configuring.....	27
Apache daemon	
restarting.....	127, 163
archive file	
complete, upgrading CTPView software	
with.....	25
web, upgrading CTPView software with.....	26
authentication	
CTPView software users with Steel-Belted	
RADIUS.....	113

B

bandwidth throttling.....	79
banner	
CTPView start-up (log-in).....	70
setting	
CTPView server menu.....	125
BIOS menu	
changing the password.....	29, 140
booting CTPView server from CD.....	161
browser	
logging in.....	36
restarting Apache daemon on CTPView	
server.....	163
restoring access.....	157

C

Circuit to Packet network	
clock options.....	5
overview.....	3
receive packet processing.....	5
serial stream processing.....	4
software overview.....	6
transmit packet processing.....	4
clock options.....	5
CompactFlash card	
burning a CTPOS image to.....	40
changing read/write state.....	159
configuration settings	
restoring (CTPView server menu).....	20, 131
saving CTPView software.....	16, 129
configuration, server	
restoring overview (CTPView GUI).....	19, 80

CTP platforms	
adding and removing.....	65
adding comments to monitoring status.....	90
automatically collecting statistical data.....	77
changing display settings for network monitoring.....	87
checking connections to the CTPView server.....	87
displaying network statistics.....	96
displaying reports.....	93
displaying runtime query results.....	89
host groups, adding and removing.....	66
managing monitoring.....	68
manually overriding monitoring status.....	90
monitoring (CTPView GUI).....	85
passwords changing user.....	159
port forwarding clearing open sockets.....	127
configuring the platform.....	71
configuring the server.....	127
restoring configuration.....	91
saving configuration automatically.....	91
setting audible status alert.....	93
SNMP communities, adding and removing.....	67
SSH connections clearing open sockets.....	127
configuring the platform.....	71
configuring the server.....	127
understanding network reports.....	95
updating CTPOS.....	39
CTPOS	
burn CTPOS flash image.....	40, 136
burning image to a CompactFlash card.....	40
default accounts and passwords.....	43
updating.....	39
upgrade files.....	47
CTPView	
menu, accessing.....	103
TACACS+, configuring.....	120
TACACS+, query	120
TACACS+, settings.....	120
CTPView Admin Center See Admin Center	
CTPView GUI	
adding comments to platform monitoring status.....	90
Admin Center, accessing.....	52
automatically removing outdated files.....	77
automatically synchronizing servers.....	77
bandwidth throttling.....	79
browser settings.....	99
browser, logging in.....	36
changing default user password.....	37
checking network connections.....	87
configuring automatic functions.....	77
creating more server disk space.....	17
CTP platform reports.....	93
display settings.....	100
display settings help.....	100
displaying platform and port runtime query results.....	89
email notifications.....	69
Global_Admin account, creating.....	37
groups adding.....	55
deleting.....	58
modifying affiliation.....	54
modifying properties.....	55
monitoring.....	54
host groups, adding and removing.....	66
managing users and groups.....	51
manually overriding platform monitoring status.....	90
monitoring the CTP platform network.....	85
network monitoring display settings.....	87
network reports.....	93
field descriptions.....	95
network statistics.....	96
NTP servers, managing.....	74
passwords changing requirements.....	59
excluding from use.....	58
limiting user.....	58
managing user.....	58
reinstating excluded.....	59
platforms, adding and removing.....	65
port forwarding, managing.....	71
restoring configuration CTP platform.....	91
CTPView server, by synchronizing servers.....	20, 81
restoring server configuration overview.....	19, 80
saving configuration CTP platform.....	91
server clock, setting.....	72
setting audible platform status alert.....	93

SNMP communities, adding and removing.....	67	log-in banner, setting.....	125
start-up (log-in) banner.....	70	logging level, setting.....	132
support for tabbed or nontabbed browsers.....	99	logs, managing.....	123
synchronizing servers		MySQL server, restarting.....	131
automatically.....	83	network access, configuring.....	33
manually.....	84	password	
network configuration.....	82	creating nonroot.....	154
overview.....	81	setting new nonroot.....	153
user properties, modifying.....	54	setting new root.....	154
users		password requirements.....	46, 62
adding.....	53	port forwarding, configuring.....	127
automatic logout.....	60	preparing a new.....	29
counters.....	61	restoring browser access.....	157
deleting active.....	57	restoring configuration by synchronizing servers.....	20, 81
deleting inactive.....	57	restoring configuration overview	
deleting prohibited.....	58	CTPView GUI.....	19, 80
displaying prohibited.....	56	restoring configuration settings	
IP access filters, creating.....	61	CTPView server menu.....	20, 131
IP address access filters, removing.....	61	restoring shell access.....	151
locked-out IP addresses.....	61	software installation and upgrade	
lockout period.....	60	overview.....	10
logging out selected.....	60	start-up (log-in) banner.....	70
login attempts.....	60	synchronizing to restore configuration.....	20, 81
login properties.....	59	system administrator account, resetting.....	133
managing access.....	56	system file defaults, restoring.....	134
monitoring.....	53	TACACS+ settings.....	119
prohibiting.....	56	TACACS+, configuring.....	119
reinstating prohibited.....	57	third-party software on.....	145
validating server configuration.....	22, 149	upgrade files.....	47
verifying server OS installation.....	21	upgrading the software overview.....	10
CTPView server		user passwords, managing.....	111
access security, managing.....	118, 125	users, managing shell account.....	104
account		validating configuration.....	22, 149
creating nonroot.....	154	verifying OS installation.....	21
acquiring shell access.....	152	web certificate, creating.....	34
booting from CD.....	161	CTPView server CLI	
clock, setting.....	72	BIOS menu password.....	29, 140
creating disk space		burning CTPOS image to a CompactFlash card.....	40
CTPView GUI.....	17	changing default user password.....	30
data file permissions, resetting.....	133	changing root account password.....	31, 141
default accounts and passwords.....	43	installing server OS.....	18
determining free disk space.....	17	reviewing the installation log.....	21
disk space, creating		CTPView server menu	
CTPView server menu.....	18, 130	access security, managing.....	125
firewall defaults, restoring.....	137	accessing.....	103
installation log.....	21	creating more server disk space.....	18, 130
installing OS (CTPView server CLI).....	18	GRUB boot loader password.....	31, 141
installing the software overview.....	10		

log-in banner, setting.....	125	groups, user	
logging level, setting.....	132	adding.....	55
logs, managing.....	123	deleting.....	58
MySQL Apache account password.....	32, 142	managing.....	51
MySQL root account password.....	33, 143	modifying affiliation.....	54
MySQL server, restarting.....	131	modifying properties.....	55
network access, configuring.....	33	monitoring.....	54
port forwarding, managing.....	127	GRUB boot loader	
restoring server configuration settings.....	20, 131	changing the password.....	31, 141
saving CTPView configuration		H	
settings.....	16, 129	host groups	
TACACS+, configuring.....	118	adding and removing.....	66
user passwords, managing.....	111	I	
users, managing shell account.....	104	installation	
web certificate, creating.....	34	reviewing log for errors.....	21
CTPView server OS		software overview.....	10
software installation and upgrade		IP access filter.....	61
overview.....	10	IP address filter See IP access filter	
tasks.....	14	L	
verifying installation.....	21	limiting CTP network bandwidth.....	79
CTPView software		log-in banner	
configuring administrative settings.....	27	configuring.....	70
saving configuration settings.....	16, 129	setting	
updating CTPOS.....	39	CTPView server menu.....	125
upgrade files.....	47	logging level	
upgrading		CTPView server, setting.....	132
overview.....	23	login security	
with complete archive file.....	25	CTPView software.....	62
with web archive file.....	26	logs	
user security levels.....	62	managing CTPView server.....	123
D		M	
data file permissions		menu	
CTPView server, resetting.....	133	accessing CTPView server.....	103
E		MySQL database	
email notifications		automatically backing up.....	77
configuring.....	69	changing the Apache account	
F		password.....	32, 142
files		changing the root account password.....	33, 143
removing (CTPView GUI).....	17	MySQL server	
removing (CTPView server menu).....	18, 130	restarting.....	131
firewall		N	
CTPView server defaults, restoring.....	137	native authentication with Steel-Belted	
G		RADIUS.....	113
Global_Admin account			
creating CTPView GUI.....	37		

- network access
 - configuring server.....33
- network reports
 - displaying CTP platform.....93
 - understanding CTP platform.....95
- nonroot account
 - creating.....154
- nonroot passwords
 - creating.....154
 - setting new.....153
- NTP servers
 - managing.....74
- O**
 - OS, CTPView server
 - installing (CTPView server CLI).....18
 - software installation and upgrade
 - overview.....10
 - tasks.....14
 - verifying installation on server.....21
 - outdated files
 - automatically removing.....77
 - removing (CTPView GUI).....17
 - removing (CTPView server menu).....18, 130
 - overview
 - Circuit to Packet network.....3
 - CTP network software.....6
 - restoring configuration.....19, 80
 - restoring server configuration
 - CTPView GUI.....19, 80
 - software installation and upgrade
 - CTPView server.....10
 - synchronizing servers (CTPView)
 - CTPView GUI.....81
- P**
 - passwords
 - BIOS menu changing.....29, 140
 - changing administrative.....139
 - changing requirements.....59
 - CTP platform user
 - changing.....159
 - CTPOS
 - default.....43
 - CTPView GUI
 - changing default.....37
 - CTPView server
 - changing default.....30
 - changing root.....31, 141
 - creating nonroot.....154
 - default.....43
 - recovering lost.....151
 - requirements.....46, 62
 - setting new nonroot.....153
 - setting new root.....154
 - excluding from use.....58
 - expiration of user.....111
 - Global_Admin account.....37
 - GRUB boot loader changing.....31, 141
 - limiting use.....58
 - managing user.....58
 - MySQL database changing.....32, 33, 142, 143
 - reinstating excluded.....59
 - requirements of user.....111
 - port forwarding
 - configuring on CTP platforms.....71
 - configuring on the CTPView server.....127
- R**
 - receive packet processing.....5
 - redundant files
 - removing (CTPView GUI).....17
 - removing (CTPView server menu).....18, 130
 - remote host See CTP platforms
 - root passwords
 - setting new CTPView server.....154
 - RSA SecurID authentication with Steel-Belted
 - RADIUS.....113
- S**
 - security levels
 - user.....62
 - serial stream processing.....4
 - setting user password
 - resetting password.....44
 - shell access to CTPView server
 - acquiring.....152
 - restoring.....151
 - SNMP communities See adding and removing software
 - installation and upgrade
 - CTPView server OS tasks.....14
 - CTPView server overview.....10
 - network management only.....23
 - upgrade files.....47

SSH	
connections to CTP platforms	
configuring on the platform.....	71
persistent connections to CTP platforms	
configuring on the server.....	127
start-up banner	
configuring.....	70
setting	
CTPView server menu.....	125
Steel-Belted RADIUS	
authentication for CTPView software	
users.....	113
synchronization of CTPView servers	
automatic method.....	83
configuring the synchronization network.....	82
manual method.....	84
overview.....	81
to restore configuration.....	20, 81
system administrator account	
CTPView server, resetting.....	133
system file	
CTPView server defaults, restoring.....	134
T	
third-party software	
using on the CTPView server.....	145
transmit packet processing.....	4
troubleshooting	
installation issues.....	21
two factor authentication with Steel-Belted RADIUS.....	113
U	
upgrade	
CTPView Network Management Software.....	23
software overview.....	10
user groups See groups, user	
user passwords	
changing CTP platform.....	159
changing CTPView GUI default.....	37
changing server's default.....	30
changing server's root.....	31, 141
expiration.....	111
requirements.....	111
users	
adding.....	53
authentication with Steel-Belted RADIUS.....	113
automatic logout.....	60
counters.....	61
deleting active.....	57
deleting inactive.....	57
deleting prohibited.....	58
displaying prohibited.....	56
IP access filters	
creating.....	61
removing.....	61
locked-out IP addresses.....	61
lockout period.....	60
logging out selected.....	60
login attempts.....	60
login properties.....	59
managing.....	51
managing access.....	56
managing passwords.....	58
modifying properties.....	54
monitoring.....	53
password requirements.....	46, 62
prohibiting.....	56
reinstating prohibited.....	57
security levels.....	62
shell account, classification.....	111
shell account, managing.....	104
W	
web certificate	
creating.....	34