



**JUNOS™**  
**Internet Software**  
**for M-series and T-series Routing Platforms**

## **Network Operations Guide**

## **Hardware**

**Juniper Networks, Inc.**  
1194 North Mathilda Avenue  
Sunnyvale, CA 94089  
USA  
408-745-2000  
**[www.juniper.net](http://www.juniper.net)**

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986–1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by The Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, The Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirtan's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

Juniper Networks, the Juniper Networks logo, NetScreen, NetScreen Technologies, the NetScreen logo, NetScreen-Global Pro, ScreenOS, and GigaScreen are registered trademarks of Juniper Networks, Inc. in the United States and other countries.

The following are trademarks of Juniper Networks, Inc.: ERX, E-series, ESP, Instant Virtual Extranet, Internet Processor, J2300, J4300, J6300, J-Protect, J-series, J-Web, JUNOS, JUNOScope, JUNOScript, JUNOSe, M5, M7i, M10, M10i, M20, M40, M40e, M160, M320, M-series, MMD, NetScreen-5GT, NetScreen-5XP, NetScreen-5XT, NetScreen-25, NetScreen-50, NetScreen-204, NetScreen-208, NetScreen-500, NetScreen-5200, NetScreen-5400, NetScreen-IDP 10, NetScreen-IDP 100, NetScreen-IDP 500, NetScreen-Remote Security Client, NetScreen-Remote VPN Client, NetScreen-SA 1000 Series, NetScreen-SA 3000 Series, NetScreen-SA 5000 Series, NetScreen-SA Central Manager, NetScreen Secure Access, NetScreen-SM 3000, NetScreen-Security Manager, NMC-RX, SDX, Stateful Signature, T320, T640, T-series, and TX Matrix. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners. All specifications are subject to change without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

Copyright © 2005, Juniper Networks, Inc.  
All rights reserved. Printed in USA.

*JUNOS Internet Software for M-series and T-series Routing Platforms Network Operations Guide: Hardware*

Copyright © 2005, Juniper Networks, Inc.  
All rights reserved. Printed in USA.

Writer: Donice G. Mitchell  
Editor: Sonia Saruba  
Covers and template design: Edmonds Design

Thanks to Damien Holloway, Jim Boyle, John Hammond, John Jacobs, Majid Ansari, Nitin Serro, Richard Southerland, and Robert Kim for their help with the revision of this guide.

Revision History  
21 March 2005—Revision 1

The information in this document is current as of the date listed in the revision history.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

#### Year 2000 Notice

Juniper Networks hardware and software products are Year 2000 compliant. The JUNOS software has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

#### Software License

The terms and conditions for using this software are described in the software license contained in the acknowledgment to your purchase order or, to the extent applicable, to any reseller agreement or end-user purchase agreement executed between you and Juniper Networks. By using this software, you indicate that you understand and agree to be bound by those terms and conditions.

Generally speaking, the software license restricts the manner in which you are permitted to use the software and may contain prohibitions against certain uses. The software license may state conditions under which the license is automatically terminated. You should consult the license for further details.

For complete product documentation, please see the Juniper Networks Web site at [www.juniper.net/techpubs](http://www.juniper.net/techpubs).

#### End User License Agreement

**READ THIS END USER LICENSE AGREEMENT ("AGREEMENT") BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE.** BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

**1. The Parties.** The parties to this Agreement are Juniper Networks, Inc. and its subsidiaries (collectively "Juniper"), and the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software ("Customer") (collectively, the "Parties").

**2. The Software.** In this Agreement, "Software" means the program modules and features of the Juniper or Juniper-supplied software, and updates and releases of such software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller.

**3. License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

- a. Customer shall use the Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller, unless the applicable Juniper documentation expressly permits installation on non-Juniper equipment.
- b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees.
- c. Other Juniper documentation for the Software (such as product purchase documents, documents accompanying the product, the Software user manual(s), Juniper's website for the Software, or messages displayed by the Software) may specify limits to Customer's use of the Software. Such limits may restrict use to a maximum number of seats, concurrent users, sessions, subscribers, nodes, or transactions, or require the purchase of separate licenses to use particular features, functionalities, or capabilities, or provide temporal or geographical limits. Customer's use of the Software shall be subject to all such limitations and purchase of all applicable licenses.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

**4. Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any 'locked' or key-restricted feature, function, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use the Software on non-Juniper equipment where the Juniper documentation does not expressly permit installation on non-Juniper equipment; (j) use the Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; or (k) use the Software in any manner other than as expressly provided herein.

**5. Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

**6. Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software.

**7. Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

**8. Warranty, Limitation of Liability, Disclaimer of Warranty.** If the Software is distributed on physical media (such as CD), Juniper warrants for 90 days from delivery that the media on which the Software is delivered will be free of defects in material and workmanship under normal use. This limited warranty extends only to the Customer. Except as may be expressly provided in separate documentation from Juniper, no other warranties apply to the Software, and the Software is otherwise provided AS IS. Customer assumes all risks arising from use of the Software. Customer's sole remedy and Juniper's entire liability under this limited warranty is that Juniper, at its option, will repair or replace the media containing the Software, or provide a refund, provided that Customer makes a proper warranty claim to Juniper, in writing, within the warranty period. Nothing in this Agreement shall give rise to any obligation to support the Software. Any such support shall be governed by a separate, written agreement. To the maximum extent permitted by law, Juniper shall not be liable for any liability for lost profits, loss of data or costs or procurement of substitute goods or services, or for any special, indirect, or consequential damages arising out of this Agreement, the Software, or any Juniper or Juniper-supplied software. In no event shall Juniper be liable for damages arising from unauthorized or improper use of any Juniper or Juniper-supplied software.

EXCEPT AS EXPRESSLY PROVIDED HEREIN OR IN SEPARATE DOCUMENTATION PROVIDED FROM JUNIPER AND TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK.

**9. Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

**10. Taxes.** All license fees for the Software are exclusive of taxes, withholdings, duties, or levies (collectively "Taxes"). Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software.

**11. Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to you may contain encryption or other capabilities restricting your ability to export the Software without an export license.

**12. Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14(ALT III) as applicable.

**13. Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement.

If you have any questions about this agreement, contact Juniper Networks at the following address:

Juniper Networks, Inc.  
1194 North Mathilda Avenue  
Sunnyvale, CA 94089 USA  
Attn: Contracts Administrator



# Abbreviated Table of Contents

About This Manual

xxvii

<b>Part 1</b>	<b>Understanding M-series and T-series Internet Routers</b>	
Chapter 1	M5 and M10 Internet Router Overview	3
Chapter 2	M7i Internet Router Overview	7
Chapter 3	M10i Internet Router Overview	11
Chapter 4	M20 Internet Router Overview	15
Chapter 5	M40 Internet Router Overview	19
Chapter 6	M40e Internet Router Overview	23
Chapter 7	M160 Internet Router Overview	27
Chapter 8	M320 Internet Router Overview	31
Chapter 9	T320 Internet Router Overview	35
Chapter 10	T640 Internet Routing Node Overview	39
<b>Part 2</b>	<b>Understanding Methodology and Tools for Monitoring Router Components</b>	
Chapter 11	Understanding the Method and Tools for Monitoring Router Components	47
<b>Part 3</b>	<b>Monitoring Key and Common Router Components</b>	
Chapter 12	Monitoring Key Router Components	91
Chapter 13	Monitoring the Router Chassis	107
Chapter 14	Monitoring the Routing Engine	125
Chapter 15	Monitoring FPCs	163
Chapter 16	Monitoring PICs	183
Chapter 17	Monitoring the Craft Interface	197
Chapter 18	Monitoring Power Supplies	217
Chapter 19	Monitoring the Cooling System	251
Chapter 20	Maintaining the Cable Management System, Cables, and Connectors	275

<b>Part 4</b>	<b>Monitoring M320 and T320 Router and T640 Routing Node-Specific Components</b>	
Chapter 21	Monitoring the Host Subsystem	289
Chapter 22	Monitoring the Control Board	301
Chapter 23	Monitoring the SCGs	315
Chapter 24	Monitoring the SIBs	325
 <b>Part 5</b>	 <b>Monitoring M40e and M160 Internet Router-Specific Components</b>	
Chapter 25	Monitoring the Host Module	341
Chapter 26	Monitoring the SFMs	347
Chapter 27	Monitoring the MCS	359
Chapter 28	Monitoring the PCG	369
Chapter 29	Monitoring the CIP	381
 <b>Part 6</b>	 <b>Monitoring M40 Internet Router-Specific Components</b>	
Chapter 30	Monitoring the SCB	393
 <b>Part 7</b>	 <b>Monitoring M20 Internet Router-Specific Components</b>	
Chapter 31	Monitoring the SSB	405
 <b>Part 8</b>	 <b>Monitoring M7i and M10i Router-Specific Components</b>	
Chapter 32	Monitoring the CFEBs	417
Chapter 33	Monitoring the HCM	431
Chapter 34	Monitoring the FIC	443
 <b>Part 9</b>	 <b>Monitoring M5 and M10 Router-Specific Components</b>	
Chapter 35	Monitoring the FEB	453

<b>Part 10</b>	<b>Monitoring Redundant Router Components</b>	
Chapter 36	Host Redundancy Overview	463
Chapter 37	Monitoring Redundant Routing Engines	491
Chapter 38	Monitoring Redundant Power Supplies	507
Chapter 39	Monitoring Redundant Cooling System Components	523
Chapter 40	Monitoring Redundant SIBs	543
Chapter 41	Monitoring Redundant SCGs	551
Chapter 42	Monitoring Redundant Control Boards	559
Chapter 43	Monitoring Redundant MCSs	567
Chapter 44	Monitoring Redundant SFMs	577
Chapter 45	Monitoring Redundant PCGs	595
Chapter 46	Monitoring Redundant SSBs	605
Chapter 47	Monitoring Redundant CFEBs	617
Chapter 48	Monitoring Redundant HCMs	623
 <b>Part 11</b>	 <b>Appendices</b>	
Appendix A	Command-Line Interface Overview	633
 <b>Part 12</b>	 <b>Index</b>	
	Index	659



# Table of Contents

<b>About This Manual</b>	<b>xxvii</b>
Objectives .....	xxvii
Audience .....	xxvii
Document Organization .....	xxviii
Chapter Organization .....	xxviii
Documentation Conventions .....	xxix
Related Juniper Networks Documentation .....	xxx
Documentation Feedback .....	xxxii
Requesting Support .....	xxxiii

## Part 1

### Understanding M-series and T-series Internet Routers

<b>Chapter 1</b>	<b>M5 and M10 Internet Router Overview</b>	<b>3</b>
	M5 and M10 Router Components .....	4
	Monitoring M5 and M10 Router Components .....	5
<b>Chapter 2</b>	<b>M7i Internet Router Overview</b>	<b>7</b>
	M7i Router Components .....	8
	Monitoring M7i Router Components .....	9
<b>Chapter 3</b>	<b>M10i Internet Router Overview</b>	<b>11</b>
	M10i Router Components .....	12
	Monitoring M10i Router Components .....	13
<b>Chapter 4</b>	<b>M20 Internet Router Overview</b>	<b>15</b>
	M20 Router Components .....	16
	Monitoring M20 Router Components .....	17
<b>Chapter 5</b>	<b>M40 Internet Router Overview</b>	<b>19</b>
	M40 Router Components .....	20
	Monitoring M40 Router Components .....	21
<b>Chapter 6</b>	<b>M40e Internet Router Overview</b>	<b>23</b>
	M40e Router Major Hardware Components .....	24
	Monitoring M40e Router Components .....	25

<b>Chapter 7</b>	<b>M160 Internet Router Overview</b>	<b>27</b>
	M160 Router Major Hardware Components .....	28
	Monitoring M160 Router Components .....	29
<b>Chapter 8</b>	<b>M320 Internet Router Overview</b>	<b>31</b>
	M320 Router Major Hardware Components .....	32
	Monitoring M320 Router Components .....	33
<b>Chapter 9</b>	<b>T320 Internet Router Overview</b>	<b>35</b>
	T320 Router Major Hardware Components .....	36
	Monitoring T320 Router Components .....	37
<b>Chapter 10</b>	<b>T640 Internet Routing Node Overview</b>	<b>39</b>
	T640 Routing Node Major Hardware Components .....	41
	Monitoring T640 Routing Node Components .....	42

## Part 2      **Understanding Methodology and Tools for Monitoring Router Components**

<b>Chapter 11</b>	<b>Understanding the Method and Tools for Monitoring Router Components</b>	<b>47</b>
	Basic Router Component Monitoring Method .....	47
	Basic Router Component Monitoring Tools .....	49
	Common Operational Mode CLI Commands To Monitor Router Components .....	53
	Using the Basic Monitoring Method .....	55
	Check the Router Component Status .....	56
	Check the Router Craft Interface .....	56
	Check the Component LEDs .....	57
	Display Detailed Component Environmental Information .....	59
	Display Detailed Component Operational Information .....	60
	Gather Component Alarm Information .....	60
	Display the Current Router Alarms .....	61
	Display Error Messages in the Messages Log File .....	83
	Display Error Messages in the Chassis Daemon Log File .....	83
	Verify the Component Problem .....	84
	Fix the Problem .....	84
	Contact JTAC .....	84
	Return the Failed Component .....	86

**Part 3****Monitoring Key and Common Router Components**

<b>Chapter 12</b>	<b>Monitoring Key Router Components</b>	<b>91</b>
	Understanding Key Router Components .....	92
	Packet Forwarding Engine .....	92
	Data Flow Through the Router Packet Forwarding Engine .....	93
	Routing Engine .....	104
	Routing Engine Functions .....	105
<b>Chapter 13</b>	<b>Monitoring the Router Chassis</b>	<b>107</b>
	Understanding the Router Chassis .....	108
	Checking the Router Chassis Component Status .....	117
	Display the Hardware Components Installed in the Router Chassis .....	117
	Check the Component Environmental Status.....	118
	Check the Component Status from the Craft Interface.....	118
	Checking Router Alarms.....	119
	Display Current Component Alarms .....	120
	Display Component Error Messages in the System Log File.....	121
	Display Component Errors in the Chassis Daemon Log File.....	122
	Verifying Router Component Failure .....	122
	Replacing a Failed Component.....	122
<b>Chapter 14</b>	<b>Monitoring the Routing Engine</b>	<b>125</b>
	Understanding the Routing Engine.....	127
	Routing Engine Types and Characteristics .....	127
	M7i and M10i Router Routing Engine.....	128
	M5, M10, M20, M40, M40e, and M160 Router Routing Engines .....	129
	M320 Router Routing Engine .....	129
	T320 Router and T640 Routing Node Routing Engine .....	130
	Routing Engine Locations .....	130
	M5, M10, and M20 Router Routing Engines Location.....	131
	M7i and M10i Router Routing Engine Location .....	131
	M40 Router Routing Engine Location .....	132
	M40e and M160 Router Routing Engine Location .....	133
	M320 Router Routing Engine Location .....	134
	T320 Router and T640 Routing Node Routing Engine Location .....	134
	Routing Engine Redundancy.....	135
	Routing Engine Component Companionship .....	135
	Routing Engine Boot Devices .....	135
	Routing Engine Storage Media .....	136
	Monitoring the Routing Engine Status .....	136
	Check the Detailed Routing Engine Status .....	137
	Check the Routing Engine LEDs.....	138
	Check the M7i Routing Engine LEDs .....	139
	Check the M10i Router Routing Engine LEDs.....	139
	Check the M20 Router Routing Engine LEDs.....	140
	Check the M40 Router Routing Engine LEDs.....	142
	Check the M40e and M160 Router Routing Engine LEDs .....	143
	Check the M320 Router Routing Engine LEDs.....	144
	Check the T320 Router Routing Engine LEDs.....	144
	Check the T640 Routing Node Routing Engine LEDs.....	145

Check the Redundant Routing Engine Status from the Craft Interface	
CLI Output .....	146
Verifying Routing Engine Failure .....	149
Check Core Files If the Routing Engine Reboots .....	149
List the Core Files Generated After A Crash Occurs .....	149
Display the Messages Log File After A Crash Occurs .....	150
Example of When No Core File Is Generated .....	150
Example of Boot Messages If Routing Engine Fails to Boot .....	150
Check for Compact Flash Media and Hard Disk Failure .....	150
When the Compact Flash Is Removed from the Boot List .....	151
Determine Why Compact Flash Did Not Mount .....	151
When the Hard Disk Is Removed from the Boot List .....	152
Verify That the Hard Disk Did Not Mount .....	152
Verify That the Hard Disk Is Missing from The Boot List .....	153
View Alarms When Media Is Removed from the Boot List .....	153
Understand What Happens When Memory Failures Occur .....	154
Check the Router File System and Boot Disk .....	154
Display the Current Routing Engine Alarms .....	155
Display Error Messages in the System Log File .....	155
Document the Events Prior to the Failure .....	156
Getting Routing Engine Hardware Information .....	157
Display Routing Engine Hardware Information .....	157
Locate the Routing Engine Serial Number ID Label .....	158
M7i Router Routing Engine Serial Number ID Label Location .....	158
M10i Router Routing Engine Serial Number ID Label Location .....	158
Teknor Type 2 Routing Engine Serial Number ID Label Location ....	158
M40 Router Routing Engine Serial Number ID Label Location .....	159
M320 Router Serial Number ID Label Location .....	160
T320 Router and T640 Routing Node Serial Number ID Label	
Location .....	160
Removing a Routing Engine .....	161
<b>Chapter 15    Monitoring FPCs</b>	<b>163</b>
Understanding FPCs .....	164
Checking the FPC Status .....	166
Check FPC Status and Utilization .....	166
Check FPC Status and Uptime .....	167
Check FPC Status and Temperature .....	167
Check the FPC LED States .....	168
Checking for FPC Alarms .....	169
Display the Current FPC Alarms .....	169
Display FPC Error Messages in the System Log File .....	170
Display FPC Error Messages in the Chassis Daemon Log File .....	171
Verifying FPC Failure .....	173
Document Events Prior to the FPC Failure .....	173
Check the FPC Installation .....	173
Check the FPC Fuses .....	174
Take the FPC Offline .....	175
Perform an FPC Swap Test .....	176
Display the FPC Software Version Information .....	176
Display the FPC Hardware Information .....	177
Locate the FPC Serial Number ID Label .....	177
Replacing an FPC .....	181



<b>Chapter 16</b>	<b>Monitoring PICs</b>	<b>183</b>
	Understanding PICs .....	184
	Checking the PIC Status .....	186
	Display the PIC Media Type and FPC Status .....	186
	Display the PIC Interface Status Information .....	187
	Check the PIC LED States .....	188
	Checking PIC Alarms.....	189
	Check Current Chassis Alarms.....	189
	Display Error Messages in the System Log File .....	190
	Verifying PIC Failure .....	190
	Perform a PIC Swap Test .....	190
	Display PIC Hardware Information .....	191
	Locate the PIC Serial Number ID Label .....	192
	Replacing a PIC .....	195
<b>Chapter 17</b>	<b>Monitoring the Craft Interface</b>	<b>197</b>
	Understanding the Craft Interface .....	199
	Monitoring the Craft Interface Status .....	203
	View the Craft Interface Status .....	203
	Check the Craft Interface Environmental Status .....	203
	Viewing Craft Interface Information from the Command Line .....	204
	Verifying Craft Interface Failure .....	205
	Display Craft Interface Alarms.....	206
	Display Craft Interface Error Messages in the System Log File.....	207
	Display Craft Interface Messages in the Chassis Daemon Log File .....	208
	Display Craft Interface Hardware Information .....	208
	Replacing the Craft Interface.....	209
	Replace the M20 Router Craft Interface .....	209
	Replace the M40 Router Craft Interface .....	209
	Replace the M40e and M160 Router Craft Interface .....	210
	Replace the M320 Router Craft Interface.....	211
	Replace the T320 Router and T640 Routing Node Craft Interface.....	212
	Locating the Craft Interface Serial Number ID Label.....	213
	Locate the M20 Router Craft Interface Serial Number ID Label.....	213
	Locate the M40 Router Craft Interface Serial Number ID Label.....	214
	Locate the M40e and M160 Router Craft Interface Serial Number ID Label .....	214
	Locate the M320 Router Craft Interface Serial Number ID Label.....	215
	Locate the T320 Router and T640 Routing Node Craft Interface Serial Number ID Label.....	215
	Returning the Craft Interface.....	215

<b>Chapter 18</b>	<b>Monitoring Power Supplies</b>	<b>217</b>
	Understanding Power Supplies.....	218
	M5/M10 Router Power Supplies.....	219
	M7i Router Power Supplies.....	220
	M10i Router Power Supplies.....	221
	M20 Router Power Supplies.....	222
	M40 Router Power Supplies.....	223
	M40e Router Power Supplies.....	224
	M160 Router Power Supplies.....	226
	M320 Router Power Supplies.....	227
	T320 Router Power Supplies.....	228
	T640 Routing Node Power Supplies.....	229
	Checking the Power Supply Cables .....	229
	Checking the Power Supply Status .....	230
	Check the Power Supply Environmental Status .....	230
	Check the Power Supply LEDs .....	232
	Checking for Power Supply Alarms .....	235
	Display Current Power Supply Alarms .....	235
	Display Power Supply Error Messages in the System Log File.....	238
	Display Power Supply Error Messages in the Chassis Daemon Log File .....	238
	Verifying Power Supply Failure .....	239
	Check the Power Supply Power Switch.....	239
	Check the Circuit Breaker .....	239
	Perform a Power Supply Swap Test.....	240
	Check the Router Cooling System.....	240
	Test the Power Supply .....	241
	Getting Power Supply Hardware Information.....	241
	Display the Power Supply Hardware Information .....	242
	Locate the Power Supply Serial Number ID Label .....	242
	Replacing the Power Supplies .....	250
<b>Chapter 19</b>	<b>Monitoring the Cooling System</b>	<b>251</b>
	Understanding the Cooling System .....	252
	M5 and M10 Router Cooling Systems .....	253
	M7i Router Cooling System .....	253
	M10i Router Cooling System .....	254
	M20 Router Cooling System .....	255
	M40 Router Cooling System .....	256
	M40e and M160 Router Cooling Systems .....	259
	M320 Router Cooling System .....	261
	T320 Router and T640 Routing Node Cooling Systems.....	263
	Checking the Cooling System Status .....	267
	Checking the Cooling System Alarms .....	269
	Check the Alarm Indicators on the Craft Interface .....	270
	Display Current Cooling System Alarms .....	270
	Display Cooling System Error Messages in the System Log File .....	271
	Maintaining the Air Filter .....	272
	Verifying a Fan Failure.....	272
	Verifying an Impeller Failure.....	273
	Replacing a Cooling System Component .....	273

<b>Chapter 20</b>	<b>Maintaining the Cable Management System, Cables, and Connectors</b>	<b>275</b>
	Understanding the Cable Management System, Cables, and Connectors .....	276
	M5 and M10 Router Cable Management System .....	277
	M10i Router Cable Management System .....	277
	M20 Router Cable Management System .....	278
	M40 Router Cable Management System .....	279
	M40e and M160 Router Cable Management System .....	280
	M320 Router Cable Management System .....	280
	T320 Router and T640 Routing Node Cable Management System .....	281
	Maintaining the PIC Cables .....	281
	Maintaining the PIC Fiber-Optic Cable .....	282
	Cleaning the Transceivers .....	282
	Checking the PIC Port Status .....	283
	Check the PIC or FPC LED Status .....	283
	Display the PIC Media Type .....	284
	Maintaining the Power Cables .....	285
	Maintaining Routing Engine External Cables .....	285
	Replacing the Cable Management System .....	285

## Part 4

### Monitoring M320 and T320 Router and T640 Routing Node-Specific Components

<b>Chapter 21</b>	<b>Monitoring the Host Subsystem</b>	<b>289</b>
	Understanding the Host Subsystem .....	290
	M320 and T320 Router and T640 Routing Node Routing Engines .....	291
	M320 Router Routing Engine .....	291
	T320 Router and T640 Routing Node Routing Engine .....	291
	M320 and T320 Router and T640 Routing Node Control Boards .....	292
	M320 Router Control Board .....	292
	T320 Router Control Board .....	292
	T640 Routing Node Control Board .....	293
	Host Subsystem Location .....	294
	Checking the Host Subsystem Status .....	295
	Checking the Routing Engine Status .....	297
	Checking the Control Board Status .....	298
<b>Chapter 22</b>	<b>Monitoring the Control Board</b>	<b>301</b>
	Understanding the Control Board .....	303
	M320 Router Control Board .....	303
	T320 Router Control Board .....	304
	T640 Routing Node Control Board .....	304
	M320, T320 Router, and T640 Routing Node Control Board Location .....	305
	Monitoring the Control Board Status .....	306
	Check the Control Board Environmental Status .....	306
	Check the Control Board Status from the Craft Interface .....	307
	Checking the Control Board Alarms .....	308
	Display Control Board Alarms .....	308
	Check the Control Board LEDs .....	309
	Display Control Board Error Messages in the System Log File .....	309

Display Control Board Error Messages in the Chassis Daemon Log File .....	309
Verifying Control Board Failure .....	310
Check the Control Board Connection .....	310
Check the Control Board Fuses .....	311
Perform a Control Board Swap Test .....	312
Display the Control Board Hardware Information .....	313
Locate the Control Board Serial Number ID Label .....	314
Returning the Control Board .....	314
<b>Chapter 23   Monitoring the SCGs</b>	<b>315</b>
Understanding the SCG .....	316
Monitoring the SCG Status .....	317
Monitor the SCG Environmental Status .....	317
Display the SCG LED States at the Command Line .....	318
Look at the SCG LEDs on the Faceplate .....	319
Determining SCG Mastership .....	319
Display the SCG Master from the Craft Interface Output .....	319
Look at the SCG LEDs on the Faceplate .....	320
Displaying SCG Alarms .....	320
Display Current SCG Alarms .....	320
Display SCG Error Messages in the System Log File .....	321
Display SCG Error Messages in the Chassis Daemon Log File .....	321
Verifying SCG Failure .....	322
Check the SCG Connection .....	322
Perform an SCG Swap Test .....	322
Getting SCG Hardware Information .....	323
Display the SCG Hardware Information .....	323
Locate the SCG Serial Number ID Label .....	324
Returning the SCG .....	324
<b>Chapter 24   Monitoring the SIBs</b>	<b>325</b>
Understanding the SIBs .....	326
M320 Router SIBs .....	328
T320 Router SIBs .....	329
T640 Routing Node SIBs .....	329
Monitoring the SIB Status .....	329
Display the SIB Summary Status .....	330
Display the SIB LED Status at the Command Line .....	330
Check the SIB LED Status on the Faceplate .....	330
Display the SIB Environmental Status .....	331
Displaying SIB Alarms .....	332
Display Current SIB Alarms .....	332
Display SIB Error Messages in the System Log File .....	333
Display SIB Error Messages in the Chassis Daemon Log File .....	333
Verifying SIB Failure .....	334
Check the SIB Connection .....	334
Check the SIB Fuses .....	334
Perform an SIB Swap Test .....	336
Getting SIB Hardware Information .....	337
Display SIB Hardware Information .....	337
Locate the SIB Serial Number ID Label .....	338

Returning the SIB .....	338
-------------------------	-----

## Part 5

### Monitoring M40e and M160 Internet Router-Specific Components

<b>Chapter 25</b>	<b>Monitoring the Host Module</b>	<b>341</b>
	Understanding the Host Module .....	341
	Checking the Host Module Status .....	344
	Checking the Routing Engine Status .....	345
	Checking the MCS Status .....	346
<b>Chapter 26</b>	<b>Monitoring the SFMs</b>	<b>347</b>
	Understanding the SFMs .....	348
	Monitoring the SFM Status .....	349
	Display the SFM Summary Status .....	349
	Display the SFM LED Status at the Command Line .....	351
	Check the SFM LED Status on the Faceplate .....	351
	Display the SFM Environmental Status .....	351
	Displaying SFM Alarms .....	353
	Display Current SFM Alarms .....	353
	Display SFM Error Messages in the System Log File .....	353
	Display SFM Error Messages in the Chassis Daemon Log File .....	354
	Verifying SFM Failure .....	355
	Check the SFM Connection .....	355
	Check the SFM Fuses .....	355
	Perform an SFM Swap Test .....	356
	Getting SFM Hardware Information .....	357
	Display SFM Hardware Information .....	357
	Locate the SFM Serial Number ID Label .....	357
	Replacing the SFM .....	358
<b>Chapter 27</b>	<b>Monitoring the MCS</b>	<b>359</b>
	Understanding the MCS .....	360
	Checking the MCS Status .....	362
	Check the MCS Environmental Status .....	362
	Check the MCS Status from the Craft Interface .....	363
	Check the MCS LEDs .....	364
	Verifying MCS Failure .....	365
	Check the MCS Fuses .....	365
	Perform an MCS Swap Test .....	366
	Getting MCS Hardware Information .....	367
	Display the MCS Hardware Information .....	367
	Locate the MCS Serial Number ID Label .....	368
	Returning the MCS .....	368

<b>Chapter 28</b>	<b>Monitoring the PCG</b>	<b>369</b>
	Understanding the PCG .....	370
	Monitoring the PCG Status .....	371
	Monitor the PCG Environmental Status .....	371
	Display the PCG LED States at the Command Line .....	372
	Look at the PCG LEDs on the Faceplate .....	373
	Determining PCG Mastership .....	373
	Display the PCG Master in the Craft Interface Output .....	373
	Look at the PCG LEDs on the Faceplate .....	374
	Display the Packet Forwarding Engine Current Clock Source .....	374
	Displaying PCG Alarms .....	375
	Display Current PCG Alarms .....	375
	Display PCG Error Messages in the System Log File .....	375
	Display PCG Error Messages in the Chassis Daemon Log File .....	375
	Verifying PCG Failure .....	376
	Check the PCG Connection .....	376
	Check the PCG Fuses .....	377
	Perform a PCG Swap Test .....	378
	Getting PCG Hardware Information .....	378
	Display the PCG Hardware Information .....	379
	Locate the PCG Serial Number ID Label .....	379
	Replacing the PCG .....	379
<b>Chapter 29</b>	<b>Monitoring the CIP</b>	<b>381</b>
	Understanding the CIP .....	382
	Monitoring the CIP Status .....	384
	Checking for CIP Alarms .....	385
	Display Current CIP Alarms .....	385
	Display CIP Error Messages in the System Log File .....	385
	Display CIP Error Messages in the Chassis Daemon Log File .....	386
	Verifying CIP Failure .....	386
	Check the CIP Connection .....	386
	Check the Ethernet Port Functionality .....	386
	Performing a CIP Swap Test .....	387
	Getting CIP Hardware Information .....	388
	Display CIP Hardware Information .....	388
	Locating the CIP Serial Number ID Label .....	389
	Replacing the CIP .....	389

**Part 6****Monitoring M40 Internet Router-Specific Components**

---

<b>Chapter 30</b>	<b>Monitoring the SCB</b>	<b>393</b>
	Understanding the SCB .....	394
	Monitoring the SCB Status .....	395
	Display the SCB Environmental Status .....	396
	Display the SCB Detailed Status .....	396
	Check the SCB LED Status .....	397
	Checking for SCB Alarms .....	398
	Display SCB Error Messages in the System Log File .....	398
	Display SCB Error Messages in the Chassis Daemon Log File .....	399
	Verifying SCB Failure .....	400
	Check the SCB Connection .....	400
	Perform an SCB Swap Test .....	400
	Getting SCB Hardware Information .....	401
	Display the SCB Hardware Information .....	401
	Locate the SCB Serial Number ID Label .....	402
	Display the SCB Firmware Version .....	402
	Returning the SCB .....	402

**Part 7****Monitoring M20 Internet Router-Specific Components**

---

<b>Chapter 31</b>	<b>Monitoring the SSB</b>	<b>405</b>
	Understanding the SSB .....	406
	Monitoring the SSB Status .....	408
	Display the SSB Environmental Status .....	408
	Display the SSB Detailed Status .....	409
	Check the SSB LEDs .....	409
	Checking for SSB Alarms .....	410
	Display SSB Error Messages in the System Log File .....	410
	Display SSB Error Messages in the Chassis Daemon Log File .....	411
	Verifying SSB Failure .....	411
	Check the SSB Connection .....	411
	Perform a Swap Test on the SSB .....	412
	Getting SSB Hardware Information .....	413
	Display the SSB Hardware Information .....	413
	Locate the SSB Serial Number ID Label .....	413
	Display the SSB Firmware Version .....	414
	Replacing the SSB .....	414

**Part 8****Monitoring M7i and M10i Router-Specific Components**

<b>Chapter 32</b>	<b>Monitoring the CFEBs</b>	<b>417</b>
	Understanding the CFEB .....	419
	Monitoring the CFEB Status .....	421
	Display the CFEB Environmental Status .....	422
	Display the CFEB Detailed Status .....	422
	Check CFEB LEDs .....	423
	Checking for CFEB Alarms .....	423
	Display CFEB Alarms .....	423
	Check the CFEB LEDs .....	424
	Display CFEB Error Messages in the System Log File .....	424
	Display CFEB Error Messages in the Chassis Daemon Log File .....	425
	Verifying CFEB Failure .....	426
	Check the CFEB Uptime .....	426
	Check the System Uptime .....	427
	Check the CFEB Connection .....	427
	Perform a Swap Test on the CFEB .....	427
	Perform a Swap Test on the CFEB .....	428
	Getting CFEB Hardware Information .....	429
	Display the CFEB Hardware Information .....	429
	Display the CFEB Firmware Information .....	430
	Locate the CFEB Serial Number ID Label .....	430
	Returning the CFEB .....	430
<b>Chapter 33</b>	<b>Monitoring the HCM</b>	<b>431</b>
	Understanding the HCM .....	433
	Monitoring the HCM Status .....	434
	Check HCM LEDs .....	435
	Check HCM Environmental Status .....	435
	Check the Companion Routing Engine Status .....	435
	Displaying HCM Alarms .....	437
	Performing A Swap Test .....	438
	Remove An HCM .....	438
	Install an HCM .....	440
	Getting HCM Hardware Information .....	441
	Display the HCM Hardware Information .....	441
	Locate the HCM Serial Number ID Label .....	442
	Returning the HCM .....	442
<b>Chapter 34</b>	<b>Monitoring the FIC</b>	<b>443</b>
	Understanding the FIC .....	444
	Monitoring the FIC Status .....	445
	Understand FIC Slot Numbering .....	445
	Display FIC Status at the Command Line .....	445
	Check FIC LEDs .....	446
	Displaying FIC Alarms .....	446
	Display the FIC Status .....	446
	Display FIC Errors In the nmessages Log File .....	446
	Display FIC Errors In the chassisd Log File .....	447
	Verifying FIC Failure .....	447
	Displaying FIC Hardware Information .....	448



Display the FIC Hardware Information .....	448
Display the M7i Router Chassis Serial Number .....	448
Removing the FIC .....	449
Returning the FIC .....	449

## Part 9

## Monitoring M5 and M10 Router-Specific Components

<b>Chapter 35</b>	<b>Monitoring the FEB</b>	<b>453</b>
Understanding the FEB .....	454	
Monitoring the FEB Status .....	455	
Display the FEB Environmental Status .....	455	
Display the FEB Detailed Status .....	456	
Verifying FEB Failure .....	456	
Check the FEB Uptime .....	457	
Check the System Uptime .....	457	
Check the FEB Connection .....	457	
Perform a Swap Test on the FEB .....	458	
Getting FEB Hardware Information .....	459	
Display the FEB Hardware Information .....	459	
Display the FEB Firmware Information .....	459	
Locate the FEB Serial Number ID Label .....	460	
Returning the FEB .....	460	

## Part 10

## Monitoring Redundant Router Components

<b>Chapter 36</b>	<b>Host Redundancy Overview</b>	<b>463</b>
Understanding Redundancy for the Routing Engine, Host Module, and Host Subsystem .....	465	
M10i Router Redundant Routing Engines and HCMs .....	465	
M20 Router Redundant Routing Engines and SSBs .....	466	
M40e and M160 Router Redundant Host Modules .....	467	
M320 Router, T320 Router, and T640 Routing Node Redundant Host Subsystems .....	468	
Routing Engine, Host Module, and Host Subsystem Redundancy Connections .....	469	
Redundancy Connection for an M10i Router .....	470	
Redundancy Connection for an M20 Router .....	471	
Redundancy Connection for an M40e or M160 Router .....	472	
Redundancy Connection for an M320 Router .....	473	
Redundancy Connection for a T320 Router and T640 Routing Node .....	474	
Determining Which Routing Engine You Are Logged In To .....	475	
Display Routing Engine Status .....	476	
Display the Router Hardware .....	476	
Determining Routing Engine Mastership .....	477	
Determine the Routing Engine Mastership By Checking Status .....	477	
Determine Routing Engine Mastership By Checking the LEDs .....	478	
Log In To Backup Routing Engine If graceful-switchover is Configured .....	478	

Manually Configuring Master and Backup Routing Engines .....	478
Manually Switching Routing Engine Mastership .....	481
Determining Why Mastership Switched .....	482
Configuring the Backup Routing Engine to Assume Mastership on Failure of Keepalives .....	485
Avoiding Redundancy Problems .....	486
Operate the Same Type of Routing Engine and JUNOS Software .....	486
Use the Groups Configuration .....	486
Synchronize Configurations .....	488
Copy a Configuration File from One Routing Engine to Another .....	488
Use the Proper Shutdown Process on a Backup Routing Engine .....	489
<b>Chapter 37      Monitoring Redundant Routing Engines</b> .....	<b>491</b>
Understanding Redundant Routing Engines .....	493
Redundant Routing Engine Characteristics .....	493
M10i Router Routing Engine Redundancy .....	494
M20 Router Routing Engine Redundancy .....	495
M40e and M160 Router Routing Engine Redundancy .....	496
M320 Router Routing Engine Redundancy .....	497
T320 Router and T640 Routing Node Routing Engine Redundancy .....	498
Understanding the Redundant Routing Engine Configuration .....	500
Understanding Redundant Routing Engine Automatic Failover .....	501
Understanding the Default Routing Engine Redundancy Behavior .....	501
Displaying the Redundant Routing Engines Installed in the Router .....	502
Checking the Redundant Routing Engine Status .....	503
Displaying Redundant Routing Engine Mastership and Backup .....	503
Displaying Redundant Routing Engine Errors .....	504
Manually Switching from Master to Backup Routing Engine .....	504
Replacing a Redundant Routing Engine .....	506
<b>Chapter 38      Monitoring Redundant Power Supplies</b> .....	<b>507</b>
Understanding Redundant Power Supplies .....	508
M5/M10 Router Redundant Power Supplies .....	508
M7i Router Redundant Power Supplies .....	509
M10i Router Redundant Power Supplies .....	510
M20 Router Redundant Power Supplies .....	511
M40 Router Redundant Power Supplies .....	512
M40e Router Power Supplies nand Location .....	513
M160 Router Redundant Power Supplies .....	515
M320 Router Redundant Power Supplies .....	516
T320 Router Redundant Power Supplies .....	517
T640 Routing Node Redundant Power Supplies .....	518
Displaying Redundant Power Supplies Installed In The Router .....	519
Checking the Redundant Power Supply Status .....	521
Checking for Power Supply Alarms .....	521
Verifying Power Supply Failure .....	521
Getting Power Hardware Information .....	521
Replacing a Power Supply .....	521

<b>Chapter 39</b>	<b>Monitoring Redundant Cooling System Components</b>	<b>523</b>
	Understanding Redundant Cooling System Components .....	524
	M5 and M10 Router Redundant Cooling System Components.....	525
	M7i Router Redundant Cooling System Components .....	526
	M10i Router Redundant Cooling System Components .....	527
	M20 Router Redundant Cooling System Components .....	527
	M40 Router Redundant Cooling System Components .....	529
	M40e and M160 Router Redundant Cooling System Components.....	531
	M320 Router Redundant Cooling System Components .....	533
	T320 Router Redundant Cooling System Components .....	534
	T640 Routing Node Redundant Cooling System Components .....	537
	Displaying Redundant Cooling System Components.....	539
	Checking the Redundant Cooling System Status .....	541
	Checking the Redundant Cooling System Alarms.....	541
	Removing a Cooling System Component .....	541
	Returning Redundant Cooling System Components .....	541
<b>Chapter 40</b>	<b>Monitoring Redundant SIBs</b>	<b>543</b>
	Understanding Redundant SIBs.....	544
	SIB Location and Redundancy .....	545
	M320 Router SIBs .....	546
	T320 Router SIBs .....	546
	T640 Routing Node SIBs .....	546
	Displaying Redundant SIB Hardware Information.....	547
	Displaying SIB Redundancy Information.....	547
	Monitoring Redundant SIB Status.....	548
	Displaying SIB Alarms .....	548
	Performing a Swap Test on a SIB .....	549
	Returning the SIB .....	549
<b>Chapter 41</b>	<b>Monitoring Redundant SCGs</b>	<b>551</b>
	Understanding Redundant SCGs .....	552
	Displaying Redundant SCG Hardware Information.....	553
	Monitoring Redundant SCG Status .....	553
	Monitor the Redundant SCG Environmental Status.....	553
	Display the Redundant SCG LED States at the Command Line .....	555
	View the Redundant SCG LEDs.....	555
	Displaying Redundant SCG Mastership.....	555
	Display the SCG Master and Standby from the Craft Interface Output ...	556
	View the SCG LEDs .....	556
	Performing a Swap Test on a Redundant SCG .....	556
	Returning the SCG.....	557
<b>Chapter 42</b>	<b>Monitoring Redundant Control Boards</b>	<b>559</b>
	Understanding Redundant Control Boards .....	561
	Displaying Redundant Control Board Hardware Information .....	563
	Displaying Redundant Control Board Mastership .....	563
	Check the Redundant Control Board Environmental Status .....	564
	Check the Redundant Control Board Status from the Craft Interface .....	565
	Check the Redundant Control Board LED Status.....	565
	Switching Control Board Mastership .....	565
	Checking the Control Board Alarms .....	565

	Replacing a Control Board.....	566
	Returning the Control Board .....	566
<b>Chapter 43</b>	<b>Monitoring Redundant MCSs</b>	<b>567</b>
	Understanding Redundant MCSs.....	569
	Displaying Redundant MCS Hardware Information .....	570
	Monitoring Redundant MCS Status.....	570
	Check the Redundant MCS Environmental Status.....	571
	Check the Redundant MCS Status from the Craft Interface .....	572
	Check the Redundant MCS LED Status .....	573
	Displaying Redundant MCS Mastership.....	573
	Switching MCS Mastership .....	573
	Performing a Swap Test on a Redundant MCS .....	573
	Returning an MCS .....	575
<b>Chapter 44</b>	<b>Monitoring Redundant SFMs</b>	<b>577</b>
	Understanding Redundant SFMs.....	579
	Understanding M40e Router Redundant SFM Configuration .....	580
	Understanding M40e Router Redundant SFM Operation.....	580
	Understanding M160 Router Redundant SFM Operation.....	580
	Displaying Redundant SFM Hardware Information .....	581
	Monitoring Redundant SFM Status .....	581
	Display the SFM Summary Status .....	582
	Display the SFM LED Status at the Command Line.....	584
	Check the SFM LED Status on the Faceplate .....	584
	Display the SFM Environmental Status .....	585
	Displaying Redundant SFM Mastership .....	587
	Display SFM Mastership at the Command Line.....	587
	Display SFM Mastership Information from the Craft Interface .....	588
	Displaying Redundant SFM Alarms .....	588
	Display the Current Redundant SFM Alarms.....	588
	Display SFM Error Messages in the System Log File .....	589
	Display SFM Error Messages in the Chassis Daemon Log File .....	589
	Verifying SFM Failure.....	590
	Check the SFM Connection.....	590
	Restart the SFM .....	590
	Perform an SFM Swap Test.....	591
	Controlling Redundant SFMs.....	591
	Take an SFM Offline .....	592
	Bring an SFM Online.....	592
	Switch SFM Mastership .....	593
	Replacing an SFM .....	593
<b>Chapter 45</b>	<b>Monitoring Redundant PCGs</b>	<b>595</b>
	Understanding Redundant PCGs .....	596
	Displaying Redundant PCG Hardware Information .....	597
	Monitoring Redundant PCG Status .....	597
	Monitor the Redundant PCG Environmental Status.....	597
	Display the Redundant PCG Status from the Craft Interface .....	598
	Check the PCG LED Status on the Faceplate .....	599
	Determining Redundant PCG Mastership .....	599
	Display the PCG Master from the Craft Interface .....	599
	Check the PCG LEDs on the Faceplate .....	600

	Display the Packet Forwarding Engine Current Clock Source.....	600
	Displaying PCG Failure Alarms.....	600
	Replacing a PCG.....	601
	Bringing the Replaced PCG Online.....	602
	Verifying That the Replaced PCG Is Online.....	602
	Display the Replaced PCG Environmental Status.....	602
	Display PCG Messages in the System Log File.....	603
	Display PCG Error Messages in the Chassis Daemon Log File.....	603
<b>Chapter 46</b>	<b>Monitoring Redundant SSBs</b>	<b>605</b>
	Understanding Redundant SSBs.....	606
	Displaying Redundant SSB Configuration.....	608
	Displaying Redundant SSB Hardware Information.....	608
	Monitoring Redundant SSB Status.....	609
	Display the Redundant SSB Environmental Status.....	609
	Display the Redundant SSB Detailed Status.....	610
	Check the Redundant SSB LEDs.....	610
	Displaying Redundant SSB Mastership.....	611
	Display SSB Mastership from the Command Line.....	611
	Check the SSB Mastership from the LEDs.....	612
	Checking for SSB Alarms.....	612
	Display the Current SSB Alarms.....	612
	Display SSB Error Messages in the System Log File.....	612
	Display SSB Error Messages in the Chassis Daemon Log File.....	613
	Verifying SSB Failure.....	613
	Check the SSB Connection.....	614
	Perform a Swap Test on the SSB.....	614
	Switch SSB Mastership.....	615
	Replacing the SSB.....	616
<b>Chapter 47</b>	<b>Monitoring Redundant CFEBs</b>	<b>617</b>
	Understanding Redundant CFEBs.....	618
	Displaying Redundant CFEB Hardware Information.....	620
	Displaying CFEB Mastership.....	620
	Check CFEB LEDs.....	620
	Display the CFEB Status.....	621
	Display CFEB Alarms.....	621
	Verifying CFEB Failure.....	621
	Returning the CFEB.....	621
<b>Chapter 48</b>	<b>Monitoring Redundant HCMs</b>	<b>623</b>
	Understanding Redundant HCMs.....	624
	Displaying Redundant HCM Hardware Information.....	625
	Displaying HCM Status and Mastership.....	625
	Check the HCM LEDs.....	625
	Check the HCM Environmental Status.....	626
	Switching HCM Mastership.....	627
	Displaying HCM Alarms.....	628
	Verifying HCM Failure.....	628
	Performing a Swap Test on an HCM.....	629
	Returning an HCM.....	629

**Part 11****Appendices**

---

<b>Appendix A</b>	<b>Command-Line Interface Overview</b>	<b>633</b>
	CLI Operational Mode .....	633
	Using the CLI Operational Mode .....	635
	Entering the CLI Operational Mode .....	636
	Getting Help on Commands at a Hierarchy Level .....	636
	Getting Help About Commands.....	636
	Having the CLI Complete Commands.....	638
	Using CLI Command Completion .....	638
	Displaying CLI Command History .....	639
	CLI Configuration Mode .....	639
	Configuration Statements and Identifiers.....	641
	Configuration Statement Hierarchy .....	644
	Using the CLI Configuration Mode .....	645
	Entering Configuration Mode .....	646
	Exiting Configuration Mode.....	647
	Moving Among Levels of the Hierarchy.....	647
	Displaying the Current Configuration .....	647
	Modifying the Configuration.....	649
	Removing a Statement.....	649
	Running Operational Mode CLI Commands from Configuration Mode..	649
	Displaying Configuration Mode Command History .....	650
	Committing a Configuration .....	650
	Saving a Configuration to a File .....	651
	Returning to a Previously Committed Configuration .....	651
	Getting Help About Statements .....	653

**Part 12****Index**

---

<b>Index</b>	<b>659</b>
--------------	------------

---

# About This Manual

This chapter provides a high-level overview of the *JUNOS Internet Software for M-series and T-series Routing Platforms Hardware Network Operations Guide*:

- Objectives on page xxvii
- Audience on page xxvii
- Document Organization on page xxviii
- Chapter Organization on page xxviii
- Documentation Conventions on page xxix
- Related Juniper Networks Documentation on page xxx
- Documentation Feedback on page xxxii
- Requesting Support on page xxxiii

## Objectives

---

This manual provides operational information helpful in monitoring Juniper Networks M-series and T-series router components and isolating potential problems. This manual is not directly related to any particular release of the JUNOS Internet software.

To obtain the most current version of this manual, refer to the product documentation page on the Juniper Networks Web site, which is located at <http://www.juniper.net/>.

## Audience

---

This manual is designed for Network Operations Center (NOC) personnel who monitor a Juniper Networks router.

It assumes that you have a broad understanding of networks in general, the Internet in particular, networking principles, and network configuration. This manual assumes that you are familiar with one or more of the following Internet routing protocols: Border Gateway Protocol (BGP), Routing Information Protocol (RIP), Intermediate System-to-Intermediate System (IS-IS), Open Shortest Path First (OSPF), Internet Control Message Protocol (ICMP) router discovery, Internet Group Management Protocol (IGMP), Distance Vector Multicast Routing Protocol (DVMRP), Protocol-Independent Multicast (PIM), Multiprotocol Label Switching (MPLS), Resource Reservation Protocol (RSVP), and Simple Network Management Protocol (SNMP).

Personnel operating the equipment must be trained and competent; must not conduct themselves in a careless, willfully negligent, or hostile manner; and must abide by the instructions provided by the documentation.

## Document Organization

---

This manual is divided into several parts. Each part describes the most common tasks for monitoring a particular interface, and the individual chapters within a part describe one or more step-by-step procedures for each task.

This manual also contains a complete index.

## Chapter Organization

---

Most chapters in this manual consist of a checklist at the beginning of the chapter listing the tasks and commands for monitoring the component. The tasks and commands are then explained in step-by-step procedures.

Each step-by-step procedure consists of some or all of the following parts:

- Purpose—Describes what is affected if this task is not performed or what is accomplished with this task.
- What Is... —Describes a component (usually hardware).
- Step(s) To Take—Lists the steps in the task.
- Action—Describes an action to perform in order to complete the step.
- Sample Output—Presents sample output relevant to the procedure.
- What It Means—Describes or summarizes what is presented in the sample output.
- Symptom/Indications—Describes a problem with the software or hardware.
- See Also—Lists other topics related to this task.
- Alternative Actions—Describes other commands or ways of doing the task.



- Syntax—Describes the full syntax of the command or configuration statement. For an explanation of how to read the syntax statements, see “Documentation Conventions” on page xxix.

## Documentation Conventions

Table 1 defines notice icons used in this guide.

**Table 1: Notice Icons**



Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.

Table 2 defines the text and syntax conventions used in this guide.

**Table 2: Text and Syntax Conventions**

Convention	Element	Example
<b>Bold sans serif typeface</b>	Represents text that you type.	To enter configuration mode, type the configure command:  user@host> <b>configure</b>
Fixed-width typeface	Represents output on the terminal screen.	user@host> <b>show chassis alarms</b> No alarms currently active
<i>Italic typeface</i>	<ul style="list-style-type: none"> <li>■ Introduces important new terms.</li> <li>■ Identifies book names.</li> <li>■ Identifies RFC and Internet draft titles.</li> </ul>	<ul style="list-style-type: none"> <li>■ A policy <i>term</i> is a named structure that defines match conditions and actions.</li> <li>■ <i>JUNOS System Basics Configuration Guide</i></li> <li>■ RFC 1997, <i>BGP Communities Attribute</i></li> </ul>
<i>Italic sans serif typeface</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# <b>set system domain-name</b> domain-name
Sans serif typeface	Represents names of configuration statements, commands, files, and directories; IP addresses; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> <li>■ To configure a stub area, include the <b>stub</b> statement at the [edit protocols ospf area <i>area-id</i>] hierarchy level.</li> <li>■ The console port is labeled <b>CONSOLE</b>.</li> </ul>
< > (angle brackets)	Enclose optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast   multicast ( <i>string1</i>   <i>string2</i>   <i>string3</i> )
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp {           # Required for dynamic MPLS only
[ ] (square brackets)	Enclose a variable for which you can substitute one or more values.	community name members [ <i>community-ids</i> ]

Convention	Element	Example
Indentation and braces ( { } )	Identify a level in the configuration hierarchy.	<pre>[edit] routing-options {   static {     route default {       nexthop address;       retain;     }   } }</pre>
; (semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
J-Web GUI Conventions		
Bold typeface	Represents J-Web graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"><li>■ In the Logical Interfaces box, select <b>All Interfaces</b>.</li><li>■ To cancel the configuration, click <b>Cancel</b>.</li></ul>
> (bold right angle bracket)	Separates levels in a hierarchy of J-Web selections.	In the configuration editor hierarchy, select <b>Protocols &gt; Ospf</b> .

## Related Juniper Networks Documentation

Table 3 lists the software and hardware guides and release notes for Juniper Networks J-series, M-series, and T-series routing platforms and describes the contents of each document. Table 4 lists the books included in the *Network Operations Guide* series.

**Table 3: Juniper Networks Technical Documentation**

Document	Description
<b>JUNOS Internet Software for J-series, M-series, and T-series Routing Platforms Configuration Guides</b>	
<i>Feature Guide</i>	Provides a detailed explanation and configuration examples for several of the most complex features in the JUNOS software.
<i>JUNOS-FIPS Configuration Guide</i>	(M-series and T-series routing platforms only) Provides an overview of JUNOS-FIPS 140-2 concepts and describes how to install and configure the JUNOS-FIPS software. Describes FIPS-related commands and how to configure, authorize, and zeroize the AS II FIPS PIC.
<i>MPLS Applications</i>	Provides an overview of traffic engineering concepts and describes how to configure traffic engineering protocols.
<i>Multicast Protocols</i>	Provides an overview of multicast concepts and describes how to configure multicast routing protocols.
<i>Network Interfaces and Class of Service</i>	Provides an overview of the network interface and class-of-service functions of the JUNOS software and describes how to configure the network interfaces on the routing platform.
<i>Network Management</i>	Provides an overview of network management concepts and describes how to configure various network management features, such as SNMP and accounting options.
<i>Policy Framework</i>	Provides an overview of policy concepts and describes how to configure routing policy, firewall filters, forwarding options, and cflowd.
<i>Routing Protocols</i>	Provides an overview of routing concepts and describes how to configure routing, routing instances, and unicast routing protocols.
<i>Services Interfaces</i>	Provides an overview of the services interfaces functions of the JUNOS software and describes how to configure the services interfaces on the routing platform.

Document	Description
<i>System Basics</i>	Provides an overview of the JUNOS software and describes how to install and upgrade the software. This guide also describes how to configure system management functions and how to configure the chassis, including user accounts, passwords, and redundancy.
<i>VPNs</i>	Provides an overview and describes how to configure Layer 2 and Layer 3 virtual private networks (VPNs), virtual private LAN service (VPLS), and Layer 2 circuits. Provides configuration examples.
<b>JUNOS References</b>	
<i>Network and Services Interfaces Command Reference</i>	Describes the JUNOS software operational mode commands you use to monitor and troubleshoot network and services interfaces on Juniper Networks J-series, M-series, and T-series routing platforms.
<i>Protocols, Class of Service, and System Basics Command Reference</i>	Describes the JUNOS software operational mode commands you use to monitor and troubleshoot most aspects of Juniper Networks J-series, M-series, and T-series routing platforms.
<i>System Log Messages Reference</i>	Describes how to access and interpret system log messages generated by JUNOS software modules and provides a reference page for each message.
<b>JUNOScript API Documentation</b>	
<i>JUNOScript API Guide</i>	Describes how to use the JUNOScript application programming interface (API) to monitor and configure Juniper Networks routing platforms.
<i>JUNOScript API Configuration Reference</i>	Provides a reference page for the configuration tags in the JUNOScript API.
<i>JUNOScript API Operational Reference</i>	Provides a reference page for the operational tags in the JUNOScript API.
<b>JUNOS Comprehensive Index and Glossary</b>	
<i>Comprehensive Index and Glossary</i>	Provides a complete index of all JUNOS software books and the <i>JUNOScript API Guide</i> . Also provides a comprehensive glossary.
<b>JUNOScope Documentation</b>	
<i>JUNOScope Software User Guide</i>	Describes the JUNOScope software graphical user interface (GUI), how to install and administer the software, and how to use the software to manage routing platform configuration files and monitor routing platform operations.
<b>J-series Services Router Documentation</b>	
<i>J-series Services Router Getting Started Guide</i>	Provides an overview, basic instructions, and specifications for J-series Services Routers. The guide explains how to prepare your site for installation, unpack and install the router and its components, install licenses, and establish basic connectivity.
<i>J-series Services Router Configuration Guide</i>	Explains how to configure the interfaces on J-series Services Routers for basic IP routing with standard routing protocols. The guide also shows how to configure virtual private networks (VPNs), configure and manage multicast networks, and apply routing techniques such as policies, firewall filters, IP Security (IPSec) tunnels, and service classification for safer, more efficient routing.
<i>J-series Services Router Administration Guide</i>	Shows how to manage users and operations, monitor network performance, upgrade software, and diagnose common problems on J-series Services Routers.
<b>M-series and T-series Hardware Documentation</b>	
<i>Hardware Guide</i>	Describes how to install, maintain, and troubleshoot routing platforms and components. Each platform has its own hardware guide.
<i>PIC Guide</i>	Describes the routing platform Physical Interface Cards (PICs). Each platform has its own PIC guide.

Document	Description
<b>Release Notes</b>	
<i>JUNOS Release Notes</i>	Summarize new features and known problems for a particular software release, provide corrections and updates to published JUNOS and JUNOScript manuals, provide information that might have been omitted from the manuals, and describe upgrade and downgrade procedures.
<i>Hardware Release Notes</i>	Describe the available documentation for the routing platform and the supported PICs, and summarize known problems with the hardware and accompanying software. Each platform has its own release notes.
<i>JUNOScope Software Release Notes</i>	Contain corrections and updates to the published JUNOScope manual, provide information that might have been omitted from the manual, and describe upgrade and downgrade procedures.
<i>J-series Services Router Release Notes</i>	Briefly describe the J-series Services Router features, identify known hardware problems, and provide upgrade and downgrade instructions.

**Table 4: JUNOS Internet Software Network Operations Guides**

Book	Description
<b>JUNOS Internet Software for M-series and T-series Routing Platforms Network Operations Guides</b>	
<i>Baseline</i>	Describes the most basic tasks for running a network using Juniper Networks products. Tasks include upgrading and reinstalling JUNOS software, gathering basic system management information, verifying your network topology, and searching log messages.
<i>Interfaces</i>	Describes tasks for monitoring interfaces. Tasks include using loopback testing and locating alarms.
<i>MPLS</i>	Describes tasks for configuring, monitoring, and troubleshooting an example MPLS network. Tasks include verifying the correct configuration of the MPLS and RSVP protocols, displaying the status and statistics of MPLS running on all routers in the network, and using the layered MPLS troubleshooting model to investigate problems with an MPLS network.
<i>Hardware</i>	Describes tasks for monitoring M-series and T-series routing platforms.

## Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. Send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net), or fill out the documentation feedback form at <http://www.juniper.net/techpubs/docbug/docbugreport.html>. If you are using e-mail, be sure to include the following information with your comments:

- Document name
- Document part number
- Page number
- Software release version

## Requesting Support

---

For technical support, open a support case using the Case Manager link at <http://www.juniper.net/support/> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).



## Part 1

# Understanding M-series and T-series Internet Routers

- M5 and M10 Internet Router Overview on page 3
- M7i Internet Router Overview on page 7
- M10i Internet Router Overview on page 11
- M20 Internet Router Overview on page 15
- M40 Internet Router Overview on page 19
- M40e Internet Router Overview on page 23
- M160 Internet Router Overview on page 27
- M320 Internet Router Overview on page 31
- T320 Internet Router Overview on page 35
- T640 Internet Routing Node Overview on page 39





## Chapter 1

# M5 and M10 Internet Router Overview




**NOTE:** See the End-of-sale and End-of-service Announcement for the M5 and M10 routing platforms and products at <https://www.juniper.net/support/eol/>.


The M5 and M10 Internet routers provide edge and core applications for small IP networks where space and power are at a premium. The routers support the JUNOS software which provides router configuration and monitoring. (See Figure 1.)

**Figure 1: M5 and M10 Routers**


M5 router front



M10 router front



M5 and M10 router rear



1275

The M5 and M10 routers include the router-specific Forwarding Engine Board (FEB) component that provides route lookup, filtering, and sampling, as well as switching to the destination Physical Interface Card (PIC). The FEB performs the function of the Flexible PIC Concentrators (FPCs) on other M-series routers. The FEB contains the Internet Processor II application-specific integrated circuit (ASIC), two distributed Buffer Manager ASICs, and two I/O Manager ASICs, and is responsible for making forwarding decisions, distributing packets throughout memory, and forwarding notification of outgoing packets.

The M5 and M10 routers provide a wide range of high-performance interfaces from T1 and E1 through OC12c/STM4 (for the M5 router) or OC48c/STM16 (for the M10 router). PICs between the two routers are interchangeable. For more information about supported PICs and FPCs for each M-series router type, see the appropriate PIC installation guide.

The M5 and M10 router Internet processor II ASIC forwards packets at a throughput rate of up to 5 Gbps for the M5 router and up to 10 plus Gbps for the M10 router. The ASIC technology provides such packet processing as rate limiting, filtering, and sampling of IP services.

## M5 and M10 Router Components

Table 5 lists the major M5 and M10 router components and characteristics.

**Table 5: M5 and M10 Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Cooling system	1 fan tray (3 fans)	Cools router components	Yes	Hot-removable, hot-insertable	–
Craft interface	1	Displays the status and allows you to perform control functions	–	–	–
FEB	1	Connects PICs to other components and houses shared memory	–	Requires router shutdown	–
PIC	1–4 M5 routers 1–8 M10 routers	Provides interfaces to various network media	–	Hot-removable, hot-insertable	Yes
Power supply	2 AC or 2 DC	Distributes needed voltages to components	Yes	Hot-removable, hot-insertable	–
Routing Engine	1	Handles routing protocols and maintains routing tables	–	Requires router shutdown	–

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M5 and M10 Router Components

---

See the following chapters for information about monitoring the M5 and M10 router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the FEB” on page 453




## Chapter 2

# M7i Internet Router Overview


The M7i Internet router provides security and performance in small to medium Points of Presence (PoPs), as well as a carrier-class customer premise equipment (CPE) solution for managed services and campus border router applications. (See Figure 2.)

**Figure 2: M7i Router**

M7i router front



M7i router rear



g002225

The M7i router includes the Compact Forwarding Engine Board (CFEB) which provides route lookup, filtering, and switching on incoming data packets, then directs outbound packets to the appropriate interface for transmission to the network. It can process 16 million packets per second (Mpps). The CFEB communicates with the Routing Engine using a dedicated 100-Mbps link that transfers routing table data from the Routing Engine to the forwarding table. The link is also used to transfer routing link-state updates and other packets destined for the router from the CFEB to the Routing Engine.

A built-in tunnel interface encapsulates arbitrary packets inside a transport protocol, providing a private, secure path through an otherwise public network. The built-in tunnel interface on the CFEB is configured the same way as a PIC. For information about configuring the built-in tunnel interface, see the *JUNOS Services Interfaces Configuration Guide*.

The Adaptive Services PIC-Integrated (ASP-I) is an optional component on the CFEB which performs one or more services on traffic—Stateful firewall, Network Address Translation (NAT) or intrusion detection services (IDS)—before it reaches its destination.

In addition to accommodating up to four Physical Interface Cards (PICs), the M7i router includes a built-in Fixed Interface Card (FIC) that provides two Fast Ethernet ports or one Gigabit Ethernet port, depending on which FIC or which model was ordered. For more information about Fast Ethernet and Gigabit Ethernet interfaces, see the *M7i Internet Router PIC Guide*.

The M7i router supports various PICs, including ATM, channelized, Ethernet, IP services, and SONET/SDH interfaces. For more information about supported PICs, see the *M7i Internet Router PIC Guide*.

The M7i router provides a maximum aggregate throughput of 8.4 gigabits per second (Gbps). Control operations in the router are performed by the Routing Engine, which runs JUNOS software to handle routing protocols, traffic engineering, policy, policing, monitoring, and configuration management. Forwarding operations in the router are performed by the Packet Forwarding Engine.

## M7i Router Components

Table 4 lists the major M7i router components and characteristics.

**Table 4: M7i Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
CFEB	1	Provides route lookup, management of shared memory, transfer of outgoing data packets, and transfer of exception and control packets; includes built-in tunnel interface and optional Adaptive Services PIC	–	Hot-pluggable (routing functions are interrupted when removed)	Yes
Cooling system	1 fan tray (4 fans)	Cools router components	–	Hot-removable, hot-insertable	–
FIC	1	Receives incoming packets and transmits outgoing packets to the network, displays alarm status, and takes PICs online and offline (2 Fast Ethernet or 1 Gigabit Ethernet)	–	Built-in	PICs On/Off button
PIC	1–4	Provides interfaces to various network media and performs framing and line-speed signaling	–	Hot-removable, hot-insertable	Yes
Power supply	2 AC or 2 DC	Distributes needed voltages to components	Yes	Hot-removable, hot-insertable	Yes
Routing Engine	1	Maintains the routing tables, manages the routing protocols, controls the interfaces, controls some chassis components, and provides the interface for system management and user access	–	Hot-pluggable (routing functions are interrupted when removed)	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M7i Router Components

---

See the following chapters for information about monitoring the M7i router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring PICs” on page 183
- “Monitoring the FIC” on page 443
- “Monitoring the CFEs” on page 417
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251






## Chapter 3

# M10i Internet Router Overview


The M10i Internet router provides high-speed interfaces for medium and large networks and network applications, such as those supported by Internet service providers (ISPs). (See Figure 3.)

**Figure 3: M10i Router**

M10i router front



M10i router rear



The M10i router includes the router-specific Compact Forwarding Engine Board (CFEB) which performs route lookup, filtering, and switching on incoming data packets, then directs outbound packets to the appropriate Flexible PIC Concentrator (FPC) for transmission to the network. It can process 16 million packets per second (Mpps).

A High-Availability Chassis Manager (HCM) works with its companion Routing Engine to provide control and monitoring functions for router components. The HCM also displays alarm status and takes Physical Interface Cards (PICs) online and offline.

On the M10i router, built-in FPCs house the PICs that connect the router to network media. The router supports up to eight PICs, including ATM, Channelized, Gigabit Ethernet, IP Services, and SONET/SDH interfaces. For more information on PICs, see the *M10i Internet Router PIC Guide*.

Some PICs, such as Gigabit Ethernet PICs, accept small form-factor pluggable transceivers (SFPs), which are fiber-optic transceivers that can be removed from the PIC.

The M10i router provides a maximum aggregate throughput of 12.8 gigabits per second (Gbps). Control operations in the router are performed by the Routing Engine, which runs JUNOS software to handle routing protocols, traffic engineering, policy, policing, monitoring, and configuration management. Forwarding operations in the router are performed by the Packet Forwarding Engine.

## M10i Router Components

Table 5 lists the major M10i router components and characteristics.

**Table 5: M10i Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
CFEB	1 or 2	Provides route lookup, filtering, and switching on incoming data packets; directs outbound packets to the appropriate FPC for transmission to the network	Yes	Hot-pluggable	Yes
Cooling system	2 fan trays (8 fans)	Cools router components	Yes	Hot-removable, hot-insertable	–
FPC	2	House the PICs that connect the router to network media	–	Built-in	–
HCM	2	Works with a companion Routing Engine to provide control and monitoring functions for router components; displays alarm status; takes PICs online and offline		Hot-pluggable	–
PIC	1–8	Provides interfaces to various network media; receives incoming packets from the network and transmits outgoing packets to the network, performing framing and line-speed signaling for their media type; encapsulates outgoing packets received from the FPCs before transmitting them.	–	Hot-removable, hot-insertable	Yes (On the HCM)
Power supply	1–4 AC or DC	Distributes needed voltages to components	Yes	Hot-removable, hot-insertable	Yes
SFP		Fiber-optic transceivers that connect to PICs	–	Hot-removable, hot-insertable	–
Routing Engine	1 or 2	Runs the JUNOS software; maintains the routing tables, manages the routing protocols used on the router, controls the router's interfaces, controls some chassis components, and provides the interface for system management and user access to the router	Yes	Hot-pluggable	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M10i Router Components

---

See the following chapters for information about monitoring the M10i router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the FIC” on page 443
- “Monitoring the CFEs” on page 417
- “Monitoring the HCM” on page 431
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275




## Chapter 4

# M20 Internet Router Overview


The M20 Internet router provides dedicated access, public and private peering, and hosting sites for medium core IP networks. The M20 router supports the JUNOS software which provides router configuration and monitoring. (See Figure 4.)

**Figure 4: M20 Router**

Front



Rear



1271

The M20 router includes the router-specific System and Switch Board (SSB) that provides route lookup, filtering, and sampling to the destination Flexible PIC Concentrator (FPC). The SSB contains both the Internet Processor II application-specific integrated circuit (ASIC) and the Distributed Buffer Manager ASIC, and makes forwarding decisions, distributes data cells throughout memory, processes exception and control packets, monitors system components, and controls FPC resets. You can install up to two SSBs.

Physical Interface Cards (PICs) are available in supported media types, including Asynchronous Transfer Mode (ATM), Channelized, DS3, E1, E3, T1, Ethernet, SONET/SDH, and IP services. The M20 and M40 router FPCs and PICs are interchangeable, and most of the PICs can also be used in the M40e Internet router. For more information about supported PICs and FPCs for each M-series router type, see the appropriate PIC installation guide.

The M20 router Internet Processor II ASIC forwards packets at a throughput rate of up to 20Gigabits per second (Gbps). An optional redundant switching fabric and Routing Engine increase system availability and ensure automatic failover in case of component failure. The ASIC technology provides such packet processing as route lookups, filtering, sampling, rate limiting, load balancing, buffer management, switching, and encapsulation and de-encapsulation of IP services.

## M20 Router Components

Table 6 lists the major M20 router components and characteristics.

**Table 6: M20 Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Cooling system	3 fan trays and 1 rear Routing Engine fan	Cools router components	Yes	Hot-removable, hot-insertable	–
Craft interface	1	Displays the status and allows you to perform control functions	–	Hot-removable, hot-insertable	–
FPC	1–4	Connects PICs to other components and houses shared memory	–	Hot-removable, hot-insertable	Yes
PIC	1–4 per FPC	Provides interfaces to various network media	–	Hot-removable, hot-insertable	–
Power supply	2 AC or 2 DC	Distributes needed voltages to components	Yes	Hot-removable, hot-insertable	–
Routing Engine	1–2	Handles routing protocols and maintains routing tables	Yes	Hot-pluggable	Yes
SSB	1–2	Performs router lookups, manages shared memory, and transfers control packets	Yes	Hot-pluggable	–

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M20 Router Components

---

See the following chapters for information about monitoring the M20 router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the SSB” on page 405
- “Monitoring Redundant SSBs” on page 605





## Chapter 5

# M40 Internet Router Overview




**NOTE:** See the End-of-sale and End-of-service Announcement for the M40 routing platform and products at <https://www.juniper.net/support/eol/>.


The M40 Internet router provides high-speed forwarding performance, packet processing, and port density for high-growth core IP networks. The M40 router supports the JUNOS software which provides router configuration and monitoring. (See Figure 5.)

**Figure 5: M40 Router**

Front



Rear



1268

The M40 router includes the router-specific System Control Board (SCB). The SCB contains the Internet Processor II application-specific integrated circuit (ASIC) and performs sampling, filtering, and packet forwarding decisions. The SCB processes exception and control packets, monitors system components, and controls Flexible PIC Concentrator (FPC) resets.

Physical Interface Cards (PICs) are available in supported media types, including Asynchronous Transfer Mode (ATM), Channelized, DS3, E1, E3, T1, Ethernet, SONET/SDH, and IP services. The M40 router provides the bandwidth to grow networks to OC48c/STM16 speeds. The M20 and M40 FPCs and PICs are interchangeable, and most of the PICs can also be used in the M40e Internet router. For more information about supported PICs and FPCs for each M-series router type, see the appropriate PIC installation guide.

The M40 router Internet processor II ASIC forwards packets at a throughput rate of up to 40 Gigabits per second (Gbps). The ASIC technology provides such packet processing as route lookups, filtering, sampling, rate limiting, load balancing, buffer management, switching, and encapsulation and de-encapsulation of IP services. The M40 router delivers the bandwidth required to grow networks to OC48c/STM16 speeds in a cost-effective manner.

## M40 Router Components

Table 7 lists the major M40 router components and characteristics.

**Table 7: M40 Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Cooling system	2 impeller trays and 1 fan assembly (3 fans)	Cools router components	Yes	Hot-removable, hot-insertable	–
Craft interface	1	Displays the status and allows you to perform control functions	–	Hot-removable, hot-insertable	–
FPC	1–8	Connects PICs to other components and houses shared memory	–	Hot-removable, hot-insertable	Yes
PIC	1–4 per FPC	Provides interfaces to various network media	–	Hot-removable, hot-insertable	–
Power supply	2 AC or 2 DC	Distributes voltages to components	Yes	Hot-removable, hot-insertable	–
Routing Engine	1	Handles routing protocols and maintains routing tables	–	Hot-pluggable	–
SCB	1	Performs router lookups, monitors systems, and transfers control packets	–	Hot-pluggable	–

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.

- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M40 Router Components

---

See the following chapters for information about monitoring the M40 router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the SCB” on page 393




## Chapter 6

# M40e Internet Router Overview

The M40e Internet router provides a dense, highly redundant platform primarily for dedicated access aggregation at the edge as well as for mid-size core IP networks. The M40e router supports the JUNOS software which provides router configuration and monitoring. (See Figure 6.)

**Figure 6: M40e Router**



The M40e router shares the same chassis and many of the same components as the M160 Internet router. It accepts both AC and DC power supplies. The M40e router can have up to two Switching and Forwarding Modules (SFMs). The SFMs contain the Internet Processor II application-specific integrated circuit (ASIC) and two Distributed Buffer Manager ASICs, and make forwarding decisions, distribute packets throughout memory, and forward notification of outgoing packets.

The M40e router includes the host module that constructs routing tables, performs system management functions, and generates the SONET/SDH clock signal for SONET/SDH interfaces. The host module contains the Routing Engine and the Miscellaneous Control Subsystem (MCS). The Routing Engine manages routing protocols and maintains the routing tables. For a host module to function, both of these components must be installed and operational.

The M40e router houses three types of Flexible PIC Concentrators (FPCs): one to accommodate M20 and M40 Physical Interface Cards (PICs), and two to accommodate hot-swappable M160 router PICs. The Type 1 FPCs for the M40e and M160 routers are interchangeable.

PICs are available in supported media types, including Asynchronous Transfer Mode (ATM), Channelized DS3, E1, E3, T1, Ethernet, SONET/SDH, and IP services. For more information about supported PICs and FPCs for each M-series router type, see the appropriate PIC installation guide.

The M40e router Internet Processor II ASIC forwards packets at a throughput rate of up to 40 Gigabits (Gbps). The ASIC technology provides such packet processing as rate limiting, filtering, and IP services sampling.

## M40e Router Major Hardware Components

Table 8 lists the major M40e router components and characteristics.

**Table 8: M40e Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Connector Interface Panel (CIP)	1	Provides ports for external management and alarm relay devices	–	Requires router shutdown	–
Cooling system	3 impellers, 1 fan tray	Cools router components	Yes	Hot-removable, hot-insertable	–
Craft interface	1	Displays status information	–	Hot-removable, hot-insertable	–
FPC	1–8	Connects PICs to other components and houses shared memory	–	Hot-removable, hot-insertable	Yes
Host module	1–2	Handles routing protocols and maintains routing tables	Yes	Hot-pluggable	–
MCS	1–2	Provides system control and monitoring	Yes	Hot-pluggable	Yes
PFE Clock Generator (PCG)	2	Provides a 125-MHz system clock	Yes	Hot-pluggable	Yes
PIC	1–4 per FPC	Provides interfaces to various network media	–	Hot-removable, hot-insertable	Yes
Power supply (AC or DC)	2	Distributes power to components	Yes	Hot-removable, hot-insertable	–
Routing Engine	1–2	Manages routing protocols and maintains routing tables	Yes	Hot-pluggable	–
SFM	1–2	Provides packet switching, packet forwarding, and route lookup	Yes	Hot-pluggable	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M40e Router Components

---

See the following chapters for information about monitoring the M40e router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the Host Module” on page 341
- “Monitoring the SFMs” on page 347
- “Monitoring Redundant SFMs” on page 577
- “Monitoring the MCS” on page 359
- “Monitoring Redundant MCSs” on page 567
- “Monitoring the PCG” on page 369

- “Monitoring Redundant PCGs” on page 595
- “Monitoring the CIP” on page 381




## Chapter 7

# M160 Internet Router Overview

The M160 Internet router provides a dense, highly redundant platform primarily for large backbone core IP networks where switching fabric and Routing Engine redundancy are required. The M160 router supports the JUNOS software which provides router configuration and monitoring. (See Figure 7.)

**Figure 7: M160 Router**



The Type 1 Flexible PIC Concentrators (FPCs) for the M40e and M160 routers are interchangeable. The M160 router supports two types of FPCs: FPC1 supports Physical Interface Cards (PICs), including the single-port OC12 and Gigabit Ethernet; and FPC2 supports higher-speed PICs, including OC48 and Tunnel Services. The router can operate with any combination of FPC1s and FPC2s installed. For more information about supported PICs and FPCs for each M-series router type, see the appropriate PIC installation guide.

The M160 router accepts only DC power supplies.

1269

The M160 router can have up to four Switching and Forwarding Modules (SFMs). The SFMs contain the Internet Processor II application-specific integrated circuit (ASIC) and two Distributed Buffer Manager ASICs, and make forwarding decisions, distribute packets throughout memory, and forward notification of outgoing packets.

The M160 router includes the host module that constructs routing tables, performs system management functions, and generates the SONET/SDH clock signal for SONET/SDH interfaces. The host module contains the Routing Engine and the Miscellaneous Control Subsystem (MCS). The Routing Engine manages routing protocols and maintains the routing tables. For a host module to function, both of these components must be installed and operational.

PICs are available in supported media types, including Asynchronous Transfer Mode (ATM), Channelized DS3, E1, E3, T1, Ethernet, SONET/SDH, and IP services. The M160 router supports both M160 and M40e PICs. For more information about supported PICs for each M-series router type, see the appropriate PIC installation guide.

The M160 router Internet Processor II ASIC forwards packets at a throughput rate of up to 160 Gbps. The ASIC technology provides such packet processing as route lookups, filtering, sampling, rate limiting, load balancing, buffer management, switching, and encapsulation and de-encapsulation of IP services.

## M160 Router Major Hardware Components

Table 9 lists the major M160 router components and characteristics.

**Table 9: M160 Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-replaceable	Offline Button
CIP	1	Provides ports for external management, BITS interfaces, and alarm relay devices	–	Requires router shutdown	–
Cooling system	3 impellers and 1 fan tray (4 fans)	Cools router components	Yes	Hot-removable	–
Craft interface	1	Displays status and allows you to perform control functions	–	Hot-removable, hot-insertable	–
FPC	1–8	Connects PICs to other components and houses shared memory	–	Hot-removable, hot-insertable	Yes
Host module	1–2	Handles routing protocols and maintains routing tables	Yes	Hot-pluggable	–
MCS	1–2	Provides system control and monitoring	Yes	Hot-pluggable	Yes
PCG	2	Provides a 125-MHz system clock	Yes	Hot-pluggable	Yes
PICs	1–4 per FPC	Provides interfaces to various network media	–	Hot-removable, hot-insertable	Yes
Power supply (DC only)	2	Distributes needed voltages to components	Yes	Hot-removable, hot-insertable	–

Component	Quantity	Function	Redundant	Field-replaceable	Offline Button
Routing Engine	1–2	Manages routing protocols and maintains routing tables	Yes	Hot-pluggable	–
SFM	1–4	Provides packet switching, packet forwarding, and route lookup	Yes	Hot-removable, hot-insertable	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M160 Router Components

See the following chapters for information about monitoring and troubleshooting the M160 router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the Host Module” on page 341
- “Monitoring the SFMs” on page 347

- “Monitoring Redundant SFMs” on page 577
- “Monitoring the MCS” on page 359
- “Monitoring Redundant MCSs” on page 567
- “Monitoring the PCG” on page 369
- “Monitoring Redundant PCGs” on page 595
- “Monitoring the CIP” on page 381


## Chapter 8

# M320 Internet Router Overview


The M320 Internet router is a high-density edge aggregation, routing, and service creation platform that can be deployed in core, peering, and data center applications. Optimized for dense edge aggregation and service creation, the M320 router can provide a single point of edge aggregation for thousands of customers over any access type, including ATM, Frame Relay, Ethernet, and Time-Division Multiplexing (TDM), at any speed from DS0 up to OC192/STM64 and 10-Gigabit Ethernet. (See Figure 8.)

**Figure 8: M320 Router**

M320 router front



M320 router rear



The M320 router includes Switch Interface Boards (SIBs) that provide the switching function to the destination Flexible PIC Concentrator (FPC) at a total of 385 million packets per second (Mpps) of forwarding. The host subsystem, which consists of the Routing Engine and Control Board, provides the routing and system management functions of the router.

The router supports up to eight FPCs providing SONET/SDH OC-48/STM16, SONET/SDH OC192/STM64, and 160-Gigabit Ethernet media. The router supports three types of FPCs: FPC1 for hot-swappable M40e PICs, FPC2 for hot-swappable M160 PICs, and FPC3 for 10-Gbps T-series Physical Interface Cards (PICs). For more information about supported PICs, see the *M320 Internet Router PIC Guide*.

The M320 router provides a maximum aggregate throughput of 320 gigabits per second (GBps) full duplex. The JUNOS software runs on a control subsystem with dedicated hardware, ensuring that control functions are performed without affecting the forwarding subsystem. Forwarding and packet processing operations in the router are performed by dedicated programmable ASICs that enable the router to achieve data forwarding rates that match current fiber-optic capacity.

## M320 Router Major Hardware Components

Table 10 lists the T320 router major components and characteristics.

**Table 10: M320 Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Connector Interface Panel (CIP)	1	Provides ports for external management and alarm relay devices; includes an electrostatic discharge (ESD) point	—	Hot-pluggable	—
Control Board	1–2	Monitors and controls router components (requires a Routing Engine)	Yes	Hot-pluggable (if not redundant)	Yes
Cooling system	2 front fan trays, 1 rear fan tray	Cools router components	Yes	Hot-removable, Hot insertable	—
Craft interface	1	Displays status and provides an interface for controlling router functions	—	Hot-removable, hot-insertable	—
FPC	1–8	Connects PICs to other router components, contains Packet Forwarding Engines (supports FPC1, FPC2, and FPC3)	—	Hot-removable, hot-insertable	Yes
Host subsystem	1–2	Consists of a Routing Engine and Control Board and provides routing and system management functions	Yes	Hot-pluggable	—
PIC	1–4 per FPC	Provides an interface to various network media	—	Hot-removable, hot-insertable	Yes
Power supply (DC only)	2	Distributes needed voltages to router components	Yes	Hot-removable, hot-insertable	—
Routing Engine	1–2	Provides routing functions and routing tables (requires a Control Board)	Yes	Hot-pluggable (if not redundant)	Reset button
SIB	4	Provides switching function to the destination FPC	Yes	Hot-removable, hot-insertable	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring M320 Router Components

---

See the following chapters for information about monitoring the M320 router components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring the Host Subsystem” on page 289
- “Host Redundancy Overview” on page 463
- “Monitoring the Control Board” on page 301
- “Monitoring Redundant Control Boards” on page 559
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the SIBs” on page 325
- “Monitoring Redundant SIBs” on page 543

- “Monitoring the CIP” on page 381




## Chapter 9

# T320 Internet Router Overview

The T320 router provides 320-Gbps throughput and 385-Mpps forwarding rate and supports 16 10-Gbps (OC192c/STM64 and 10-Gigabit Ethernet) ports, as well as OC48c/STM16 for medium and large core networks, as well as for intermediate core aggregation of access routers, peering, and metro Ethernet network applications, such as those supported by Internet service providers (ISPs). It provides a cost-effective migration path to an MPLS infrastructure. The T320 router supports the JUNOS software, which provides router configuration and monitoring. (See Figure 9.)

**Figure 9: T320 Router**



The router supports three types of FPCs:

- FPC1—Supports PICs that are also used in the FPC1 of a Juniper Networks M-series router
- FPC2—Supports PICs that are also used in the FPC2 of a Juniper Networks M-series router and T640 Internet routing node

- FPC3—Supports higher-speed PICs that are also used in the FPC3 of a Juniper Networks T640 routing node

The router can operate with any combination of FPCs installed.

Forwarding operations in the router are performed by the Packet Forwarding Engines. Each FPC contains one Packet Forwarding Engine. The Packet Forwarding Engines receive incoming packets from the PICs installed on the FPC and forward them through the switch planes to the appropriate destination port. Each FPC contains data memory, which is managed by the Queuing and Memory Interface application-specific integrate circuits (ASICs).

PICs provide the physical connection to various network media types, receiving incoming packets from the network and transmitting outgoing packets to the network. PICs for the T320 router currently support the following network media types: ATM, ATM2, Fast Ethernet, Gigabit Ethernet, 10 Gigabit Ethernet, SONET/SDH OC3c/STM1, SONET/SDH OC12c/STM4, OC48c/STM16, OC192c/STM64, and Tunnel services. For more information on PICs used in the router, see the *T320 Internet Router PIC Guide*.

The T320 router supports two DC power supplies, which share the load evenly.

Three Switch Interface Boards (SIBs) provide the switching function to the destination FPC. The SIBs create the switch fabric for the router, providing up to a total of 320 million packets per second (Mpps) of forwarding.

Routing and system management functions of the router are performed by the host subsystem. The host subsystem consists of the Routing Engine and the Control Board.

The Routing Engine maintains the routing tables used by the router and controls the routing protocols that run on the router. Each Control Board works with an adjacent Routing Engine to provide control and monitoring functions for the router. These include determining Routing Engine mastership, controlling power, reset and SONET clocking for the other router components, monitoring and controlling fan speed, and monitoring system status using I<sup>2</sup>C controllers.

## T320 Router Major Hardware Components

Table 11 lists the T320 router major components and characteristics.

**Table 11: T320 Router Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Connector Interface Panel (CIP)	1	Provides ports for external management and alarm relay devices	—	Hot-pluggable	—
Control Board	1–2	Monitors and controls router components	Yes	Hot-pluggable	Yes
Cooling system	2 front fan trays, 1 rear fan tray	Cools router components	Yes	hot-removable, hot insertable	—

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Craft interface	1	Displays status and provides an interface for controlling router functions	—	Hot-removable, hot-insertable	—
FPC	1–8	Connect PICs to other router components, contains Packet Forwarding Engines	—	Hot-removable, hot-insertable	Yes
PIC	1–2 per FPC	Provides an interface to various network media	—	Hot-removable, hot-insertable	Yes
Power supply (DC only)	2	Distributes needed voltages to router components	Yes	Hot-removable, hot-insertable	—
Routing Engine	1–2	Provides routing functions and routing tables	Yes	Hot-removable, hot-insertable	Yes
SONET Clock Generator (SCG)	1–2	Provides Stratum 3 SONET/SDH clocking	Yes	Hot-pluggable	Yes
SIB	3	Provides switch fabric	2 active, 1 standby	Hot-removable, hot-insertable	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring T320 Router Components

See the following chapters for information about monitoring and troubleshooting the T320 router components:


- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507

- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the Host Subsystem” on page 289
- “Host Redundancy Overview” on page 463
- “Monitoring the Control Board” on page 301
- “Monitoring Redundant Control Boards” on page 559
- “Monitoring the SCGs” on page 315
- “Monitoring Redundant SCGs” on page 551
- “Monitoring the SIBs” on page 325
- “Monitoring Redundant SIBs” on page 543
- “Monitoring the CIP” on page 381

## Chapter 10

# **T640 Internet Routing Node Overview**

The T640 Internet routing node provides 40G capable platform, delivering 640 Gigabits per second (Gbps) of capacity and up to 770 million packets per second (Mpps) of throughput and supports 32 10-Gbps (OC192c/STM64 and 10-Gigabit Ethernet) ports, as well as OC48c/STM16, Gigabit Ethernet, SONET/SDH, and other high-speed interfaces for large core networks and network applications, such as those supported by Internet service providers (ISPs). It provides a cost-effective migration path to an Multiprotocol Label Switching (MPLS) infrastructure. The T640 routing node supports the JUNOS software which provides router configuration and monitoring. (See Figure 10.)

**Figure 10: T640 Routing Node**

In a standalone configuration, the T640 routing node's maximum aggregate throughput is 320 Gbps, full duplex.

The T640 routing node supports two types of Flexible PIC Concentrators (FPCs):

- FPC2—Rated at 10 Gbps full duplex; supports PICs that are also used in the M160 router.
- FPC3—Rated at 40 Gbps full duplex; supports higher-speed PICs.

The T640 routing node can operate with any combination of FPC2s and FPC3s installed. Each FPC contains one or two Packet Forwarding Engines. The Packet Forwarding Engine consists of Layer 2/Layer 3 Packet Processing application-specific integrated circuits (ASICs), Switch Interface ASICs, T-series Internet Processor ASICs, and a memory subsystem (MMB) which includes the Queuing and Memory Interface ASICs. The Packet Forwarding Engine receives incoming packets from the PICs installed on the FPC and forwards them through the switch planes to the appropriate destination port. Each FPC contains data memory, which is managed by the Queuing and Memory Interface ASICs. Each FPC3 has two Packet Forwarding Engines, and each FPC2 has one Packet Forwarding Engine.

Physical Interface Cards (PICs) provide the physical connection to various network media types, receiving incoming packets from the network and transmitting outgoing packets to the network. PICs for the T640 routing node currently support the following network media types: Gigabit Ethernet, SONET/SDH OC12c/STM4, OC48c/STM16, OC192c/STM64, and Tunnel Services. You can install up to four PICs into the slots in each FPC. For more information on PICs used in the routing node, see the *T640 Internet Routing Node PIC Guide*.

The Switch Interface Boards (SIBs) provide the switching function to the destination FPC. The SIBs create the switch fabric for the routing node, providing up to a total of 640 million Mpps of forwarding. Five SIBs are installed in the routing node.

The host subsystem provides the routing and system management functions of the routing node. The host subsystem consists of the Routing Engine and the Control Board. The Routing Engine maintains the routing tables used by the routing node and controls the routing protocols that run on the routing node.

Each Control Board works with an adjacent Routing Engine to provide control and monitoring functions for the routing node. These include determining Routing Engine mastership; controlling power, reset, and SONET clocking for the other routing node components; monitoring and controlling fan speed; and monitoring system status using I<sup>2</sup>C controllers.

ASICs are a definitive part of the router design; these ASICs enable the router to achieve data rates that match current fiber-optic capacity.

## T640 Routing Node Major Hardware Components

Table 12 lists the major T640 routing node components and characteristics.

**Table 12: T640 Routing Node Major Hardware Components**

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
Connector Interface Panel (CIP)	1	Provides ports for external management and alarm relay devices	—	Hot-pluggable	—
Control Board	1–2	Monitors and controls router components	Yes	Hot-pluggable	Yes
Cooling system	2 front fan trays, 1 rear fan tray	Cools router components	Yes	hot-removable, hot-insertable	—
Craft interface	1	Displays status and provides an interface for controlling router functions	—	Hot-removable, hot-insertable	—
FPC	1–8	Connect PICs to other router components, contains Packet Forwarding Engines	—	Hot-removable, hot-insertable	Yes
PIC	1–4 per FPC	Provides an interface to various network media	—	Hot-removable, hot-insertable	Yes
Power supply (DC only)	2	Distributes needed voltages to router components	Yes	Hot-removable, hot-insertable	—
Routing Engine	1–2	Provides routing functions and routing tables	Yes	Hot-removable, hot-insertable	Yes

Component	Quantity	Function	Redundant	Field-Replaceable	Offline Button
SONET Clock Generator (SCG)	1 - 2	Provides Stratum 3 SONET/SDH clockings	Yes	Hot-pluggable	Yes
SIB	5	Provides switch fabric	4 active, 1 standby	Hot-removable, hot-insertable	Yes

Field-replaceable units (FRUs) are router components that can be replaced at the customer site. Replacing FRUs requires minimal router downtime. There are three types of FRUs:

- Hot-removable and hot-insertable—You can remove and replace the component without powering down the router or interrupting the routing functions.
- Hot-pluggable—You can remove the component without powering down the router, but routing functions are interrupted until the replacement is installed.
- Requires router shutdown—You must power down the router before removing the component.

## Monitoring T640 Routing Node Components

See the following chapters for information about monitoring and troubleshooting the T640 routing node components:

- “Monitoring the Router Chassis” on page 107
- “Monitoring the Routing Engine” on page 125
- “Monitoring Redundant Routing Engines” on page 491
- “Monitoring FPCs” on page 163
- “Monitoring PICs” on page 183
- “Monitoring the Craft Interface” on page 197
- “Monitoring Power Supplies” on page 217
- “Monitoring Redundant Power Supplies” on page 507
- “Monitoring the Cooling System” on page 251
- “Monitoring Redundant Cooling System Components” on page 523
- “Maintaining the Cable Management System, Cables, and Connectors” on page 275
- “Monitoring the Host Subsystem” on page 289
- “Host Redundancy Overview” on page 463



- “Monitoring the Control Board” on page 301
- “Monitoring Redundant Control Boards” on page 559
- “Monitoring the SCGs” on page 315
- “Monitoring Redundant SCGs” on page 551
- “Monitoring the SIBs” on page 325
- “Monitoring Redundant SIBs” on page 543
- “Monitoring the CIP” on page 381



## Part 2

# **Understanding Methodology and Tools for Monitoring Router Components**

- Understanding the Method and Tools for Monitoring Router Components on page 47



## Chapter 11

# Understanding the Method and Tools for Monitoring Router Components


This chapter describes the method and tools you use to monitor and isolate problems on router hardware components. It includes the following information:

- Basic Router Component Monitoring Method on page 47
- Basic Router Component Monitoring Tools on page 49
- Using the Basic Monitoring Method on page 55

## Basic Router Component Monitoring Method

Figure 11 shows the basic method you use to monitor router hardware components.

**Figure 11: Basic Method for Monitoring Router Components**



You should routinely monitor the status of all Juniper Networks routers running on the network.

The Simple Network Management Protocol (SNMP) network manager software running on a network management system (NMS) in the network operations center (NOC) discovers, polls, and exchanges network management information with the JUNOS software SNMP agent running on Juniper Networks routers. The SNMP network manager software collects information about router connectivity, operation, and events.

The SNMP agent responds to requests for information and controls access to its Management Information Bases (MIBs). The MIBs define all objects that can be managed on the router via SNMP. The JUNOS software chassis MIB provides environmental monitoring information on the router and its components. MIB objects represent each component and the status of the components.

A trap is generated and reported to the SNMP manager software when a significant event occurs on the router, such as an error or failure. When a trap occurs, you can log in to that router to get specific operational status information about the problem; for more information, see “Check the Router Component Status” on page 29 and “Gather Component Alarm Information” on page 33. Verify the problem and fix it if possible; for more information, see “Verify the Component Problem” on page 34 and “Fix the Problem” on page 35. If you cannot verify or fix the problem, contact the Juniper Networks Technical Assistance Center (JTAC) for more advanced analysis and troubleshooting, and return the component once failure is verified; for more information, see “Contact JTAC” on page 35 and “Return the Failed Component” on page 36.

## Basic Router Component Monitoring Tools

Table 13 lists and describes the purposes of the basic tools you use to monitor router hardware.

**Table 13: Basic Tools for Monitoring Router Components**

Router Component Monitor Tool	Purpose
JUNOS SNMP Agent, MIBs, and traps	<ul style="list-style-type: none"> <li>■ The JUNOS SNMP agent runs on Juniper Networks routers, exchanging network management information with SNMP manager software running on an NMS or host. The SNMP manager collects information about network connectivity, activity, and events by polling the router. The agent responds to requests for information and actions from the manager.</li> <li>■ The SNMP agent also controls access to the agent's MIBs. The JUNOS software chassis MIB represents each component and the status of the components.</li> <li>■ The agent sends a trap to the SNMP manager software when an event occurs on the router. A trap reports significant events occurring on a network device; for example, most often errors or failures.</li> </ul>
JUNOS Software	<p>The primary means of accessing and controlling the JUNOS software is the command-line interface (CLI).</p> <p>For M5, M10, M20, and M40 routers, the router provides three ports on the craft interface for connecting external management devices to the Routing Engine and hence to the JUNOS software.</p> <p>For M40e, M160, M320, and T320 routers, and the T640 routing node, the management ports are located on the Connector Interface Panel (CIP).</p> <p>For M7i and M10i routers, the management ports are located on the Routing Engine.</p> <p>The management ports include the following:</p> <ul style="list-style-type: none"> <li>■ Ethernet—Used to connect the Routing Engine to a management LAN (or any other device that plugs into an Ethernet connection) for out-of-band management of the router. The Ethernet port can be 10 or 100 Mbps and uses an autosensing RJ-45 connector. The Ethernet management port has two LEDs, which indicate the type of connection in use. A yellow LED lights when a 10-Mbps connection is active, and a green LED lights when a 100-Mbps connection is active.</li> <li>■ Console—Used to connect a system console to the Routing Engine with an RS-232 serial cable.</li> <li>■ Auxiliary—Used to connect a laptop computer or modem to the Routing Engine with an RS-232 cable.</li> </ul>

Router Component Monitor Tool	Purpose
JUNOS software CLI commands	<p>The JUNOS software CLI has two modes: operational and configuration.</p> <p>Note: You only need to type <b>cli</b> if you log in to the router as root. Otherwise, the CLI should be already in operational mode.</p> <ul style="list-style-type: none"><li>■ In operational mode, you monitor and troubleshoot the software, network connectivity, and router by entering CLI commands. To enter operational mode, log in to the router and type <b>cli</b> at the command prompt.</li><li>■ In configuration mode, you configure the JUNOS software that controls the router. To enter configuration mode:<ul style="list-style-type: none"><li>a. Log in to the router.</li><li>b. Start the CLI by typing <b>cli</b> at the command prompt.</li><li>c. Type <b>edit</b> at the command prompt.</li></ul></li></ul> <p>For more information about JUNOS CLI commands, see “Monitoring the CIP” on page 381.</p>



Router Component Monitor Tool	Purpose
Router craft interface	<p>The craft interface provides status and troubleshooting information at a glance and lets you perform many system control functions. The craft interface provides the following information:</p> <ul style="list-style-type: none"> <li>■ M5 and M10 routers: Alarm LEDs and lamp test button, Routing Engine ports, link and activity status lights, and Physical Interface Card (PIC) online/offline buttons</li> <li>■ M7i router: Networking interface Link/Activity LEDs, PIC On/Off LEDs, and alarm LEDs are located on the FIC</li> <li>■ M10i routers: HCM status LEDs, PIC On/Off LEDs, and alarm LEDs are located on the HCM</li> <li>■ M20 router: Alarm relay contacts, LEDs, and cutoff button, Routing Engine interface ports and status indicators, Routing Engine LEDs and offline buttons, Flexible PIC Concentrator (FPC) LEDs and offline button</li> <li>■ M40 router: Alarm relay contacts, LEDs, cutoff button, FPC LEDs and offline button, LCD display and navigation buttons, and Routing Engine LEDs and interface ports</li> <li>■ M40e router: Alarm LEDs and alarm cutoff/lamp test button, LCD display and navigation buttons, host module LEDs, and FPC LEDs and offline button</li> <li>■ M160 router: Alarm LEDs and alarm cutoff/lamp test button, LCD display and navigation buttons, host module LEDs, and FPC LEDs and offline button</li> <li>■ M320 router: Routing Engine LEDs, Switch Interface Board (SIB) LEDs, power supply LEDs, LCD display and navigation buttons, alarm LEDs, and FPC LEDs</li> <li>■ T320 router and T640 routing node: Alarm LEDs and lamp test button, LCD display and navigation buttons, host subsystem LEDs, SIB LED, FPC LEDs, and FPC online/offline buttons</li> </ul> <p>The M40e, M160, and T320 routers and the T640 routing node have a CIP that contains the Alarm Relay contacts, management ports, and Link and Activity Status lights.</p> <p>To display craft interface information, use the following CLI command:</p> <pre>show chassis craft-interface</pre>

Router Component Monitor Tool	Purpose
Router component LEDs	<p>Router components have faceplates with LEDs that display the component status:</p> <ul style="list-style-type: none"> <li>■ M5 and M10 routers: PICs and power supplies</li> <li>■ M7i router: Compact Forwarding Engine Board (CFEB), PICs, Fixed Interface Cards (FICs) (Fast Ethernet and Gigabit Ethernet), and power supplies</li> <li>■ M10i router: CFEB, High-Availability Chassis Manager (HCM), and power supplies</li> <li>■ M20 router: System and Switch Boards (SSBs) and power supplies</li> <li>■ M40 router: System Control Boards (SCBs) and power supplies</li> <li>■ M40e router: Switching and Forwarding Modules (SFMs), Packet Forwarding Engine Clock Generators (PCGs), Miscellaneous Control Subsystem (MCS), and power supplies</li> <li>■ M160 router: SFMs, PCGs, MCS, and power supplies</li> <li>■ M320 router: SIBs, Control Boards, and power supplies</li> <li>■ T320 router and T640 routing node: SIBs, Control Boards, SONET Clock Generators (SCGs), and power supplies</li> </ul> <p>To display some router component LED status, use the following CLI command:</p> <pre>show chassis craft-interface</pre>
messages system log file	<p>The <b>messages</b> system log file records the messages generated by component operational events, including error messages generated by component failures. To view the <b>messages</b> log file, use the following CLI command:</p> <pre>show log messages</pre> <p>To monitor the <b>messages</b> log file in real time, use the following CLI command:</p> <pre>monitor start messages</pre> <p>To stop monitoring the <b>messages</b> log file, use the following CLI command:</p> <pre>monitor stop messages</pre>
chassisd system log file	<p>The chassis daemon (<b>chassisd</b>) log file keeps track of the state of each chassis component. To view the <b>chassisd</b> log file, use the following CLI command:</p> <pre>show log chassisd</pre> <p>To monitor the <b>chassisd</b> log file in real time, use the following CLI command:</p> <pre>monitor start chassisd</pre> <p>To stop monitoring the <b>chassisd</b> log file, use the following CLI command:</p> <pre>monitor stop chassisd</pre>

Router Component Monitor Tool	Purpose
Swap test	Remove the failed component. Replace it with one that you know works. Check the component status. If the replacement component works, it confirms that the original one failed.
JTAC	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States). JTAC can do more extensive testing to determine the root of the problem.

### Common Operational Mode CLI Commands To Monitor Router Components



**NOTE:** If the Forwarding Engine Board (FEB) on M5 and M10 routers, CFEB on M10i routers, SSB on M20 routers, SCB on M40 routers, SFM on M40e and M160 routers, or SIB on M320 routers, T320 routers and the T640 routing node is not running and if you log in to the backup Routing Engine, no information about chassis components is available through the CLI.

**Action** To use the CLI to monitor routers, follow these steps:

1. Log in to the router.
2. At the command prompt, type **cli** to start the JUNOS software and enter operational mode.



**NOTE:** You only need to type **cli** if you log in to the router as root. Otherwise, the CLI should already be in operational mode.

3. Use one of the operational mode CLI commands listed in Table 14.

**Table 14: Operational Mode CLI Commands for Router Monitoring**

Command	Description
show version	Displays the router hostname, model number, and version of JUNOS software running on the router.
show chassis firmware	Displays firmware and operating system version for router components.
show chassis hardware	Displays an inventory of the hardware components installed in the router, including the component name, version, part number, serial number, and a brief description.
show chassis environment	Displays environmental information about the router chassis, including the temperature and status.

Command	Description
<code>show chassis environment</code> <i>component-name</i>	<p>Displays more detailed operational status information about the following components:</p> <ul style="list-style-type: none"> <li>■ M5, M10, M7i, M10i, M20 routers: Routing Engine</li> <li>■ M40e and M160 routers: FPC, FPM, MCS, PCG, Power Entry Modules (PEM), Routing Engine, and SFM</li> <li>■ M320 router: Control Board, FPC, FPM, PEM, Routing Engine, and SIB</li> <li>■ T320 router and T640 routing node: Control Board, FPC, FPM, PEM, Routing Engine, SCG, and SIB</li> </ul>
<code>show chassis craft-interface</code>	Displays operational status information about the router, including the alarm status and LED status of major components.
<code>show chassis alarms</code>	Displays the current router component alarms that have been generated, including the date, time, severity level, and description.
<code>show chassis component-name</code>	<p>Displays more detailed operational status information about the following components:</p> <ul style="list-style-type: none"> <li>■ M7i router: CFEB, FPC, PIC, and Routing Engine</li> <li>■ M10i router: CFEB, Ethernet switch, FPC, PIC, and Routing Engine</li> <li>■ M20 router: FPC, PIC, Routing Engine, and SSB</li> <li>■ M40e/M160 router: Ethernet switch, FPCs, PICs, Routing Engine, and SFMs</li> <li>■ M320 router: Ethernet switch, FPCs, SIBs, PICs, and Routing Engine</li> <li>■ T320 router and T640 routing node: Ethernet switch, FPCs, PICs, Routing Engine, SIBs, and switch processor mezzanine board (SPMB)</li> </ul> <p>The command displays the total CPU DRAM and SRAM being used by the SFM processor. The command output displays the time that the SFM became active and how long the SFM has been up and running. A small uptime means that the component came online a short time ago and could indicate a possible FPC error condition.</p>
<code>show log messages</code>	<p>Displays the contents of the <b>messages</b> system log file that records messages generated by component operational events, including error messages generated by component failures.</p> <p>To monitor the <b>messages</b> file in real time, use the <b>monitor start messages</b> CLI command. This command displays the new entries in the file until you stop monitoring by using the <b>monitor stop messages</b> CLI command.</p>

Command	Description
show log chassisd	<p>Displays the contents of the chassis daemon (chassisd) log file that keeps track of the state of each chassis component</p> <p>To monitor the chassisd file in real time, use the <b>monitor start chassisd</b> CLI command. This command displays the new entries in the file until you stop monitoring by using the <b>monitor stop chassisd</b> CLI command.</p>
request support information	<p>Use this command when you contact JTAC about your component problem. This command is the equivalent of using the following CLI commands (see “Contact JTAC” on page 35):</p> <ul style="list-style-type: none"> <li>■ show system uptime</li> <li>■ show version detail</li> <li>■ show system core-dumps</li> <li>■ show chassis hardware</li> <li>■ show system processes extensive</li> <li>■ show pfe statistics error</li> <li>■ show chassis routing-engine</li> <li>■ show chassis environment</li> <li>■ show chassis firmware</li> <li>■ show chassis fpc detail</li> <li>■ show system boot-messages</li> <li>■ show system storage</li> <li>■ show system virtual-memory</li> <li>■ show system buffer</li> <li>■ show system queues</li> <li>■ show system statistics</li> <li>■ show configuration   except SECRET-DATA</li> <li>■ show interfaces extensive (for each configured interface)</li> <li>■ show chassis hardware extensive</li> </ul>

## Using the Basic Monitoring Method

**Steps To Take** To monitor router components, follow these steps:

1. Check the Router Component Status on page 56
2. Gather Component Alarm Information on page 60
3. Verify the Component Problem on page 84
4. Fix the Problem on page 84
5. Contact JTAC on page 84
6. Return the Failed Component on page 86

## Step 1: Check the Router Component Status

**Steps To Take** To check the router component status, follow these steps:

1. Check the Router Craft Interface on page 56
2. Check the Component LEDs on page 57
3. Display Detailed Component Environmental Information on page 59
4. Display Detailed Component Operational Information on page 60

### Check the Router Craft Interface

**Action** To check the craft interface information for router status, do one of the following:

- Use the following CLI command:

```
user@host> show chassis craft-interface
```

The command output displays the router alarm indicator status, the LCD display information (router name, router uptime, and status message that rotates at 2-second intervals), and the major component LED status. Table 15 describes the CLI command output for each router type. For more detailed information about the craft interface, see “Monitoring the Craft Interface” on page 197.

**Table 15: show chassis craft-interface CLI Command Output for Router Types**

Router	CLI Command Output
M5/M10	Red alarm, Yellow alarm, Routing Engine OK, Routing Engine Fail, FPCs, and LCD screen. <i>Note:</i> Even though there is no LCD screen on the M5/M10 routers, there is still output from this command for the LCD.
M7i/M10i	Red alarm, Yellow alarm, Routing Engine OK, Routing Engine Fail, FPCs, and LCD screen. <i>Note:</i> Even though there is no LCD screen on the M7i/M10i routers, there is still output from this command for the LCD.
M20	Red alarm, Yellow alarm, Routing Engine OK, Routing Engine Fail, FPCs, and LCD screen.
M40	Red alarm, Yellow alarm, Routing Engine OK, Routing Engine Fail, FPCs, and LCD screen.
M40e/M160	FPM Display contents, Front Panel System LEDs (Routing Engine OK, Fail, Master), Front Panel Alarm Indicators (Red LED, Yellow LED, Major relay, Minor relay), Front Panel FPC LEDs, MCS LEDs, PCG LEDs, and SFM LEDs.
M320	FPM Display contents, Front Panel System LEDs (Routing Engine OK, Fail, Master), Front Panel Alarm Indicators (Red LED, Yellow LED, Major relay, Minor relay), Front Panel FPC LEDs, Control Board LEDs, SIB LEDs, and power supply (PS) LEDs.
T320/T640	FPM Display contents, Front Panel System LEDs (Routing Engine OK, Fail, Master), Front Panel Alarm Indicators (Red LED, Yellow LED, Major relay, Minor relay), Front Panel FPC LEDs, Control Board LEDs, SCG LEDs, and SIB LEDs.

- Physically look at the router craft interface. Table 16 shows the component characteristics of each router craft interface.

**Table 16: Router Craft Interface Component Characteristics**

Component	M5/ M10	M7i/ M10i	M20	M40	M40e	M160	M320	T320	T640
Alarm LEDs	X	X	X	X	X	X	X	X	X
Alarm cutoff/Lamp Test button (AC)/LT)	X	X	X		X	X	X	X	X
Alarm relay contacts		X	X	X	X (in CIP)	X (in CIP)		X (in CIP)	X (in CIP)
Link and activity status lights	X	X	X		X (in CIP)	X (in CIP)		X (in CIP)	X (in CIP)
LCD display and navigation buttons				X	X	X	X	X	X
Routing Engine ports	X		X	X	X (in CIP)	X (in CIP)		X (in CIP)	X (in CIP)
Routing Engine LEDs			X	X			X		
Host module LEDs					X	X			
Host subsystem LEDs								X	X
PIC online and offline buttons	X	X							
FPC LEDs	No Craft Interface	No Craft Interface	X	X	X	X	X	X	X
FPC offline buttons			X	X	X	X	X	X	X
SIB LEDs							X	X	X
Power supply LEDs							X		

### Check the Component LEDs

**Action** To check the component LED status, do one of the following:

- Use the following CLI command:

```
user@host> show chassis craft-interface
```

The command output displays the LED status for the following components:

- M7i/M10i/M20 router: Routing Engine and FPC
- M40e/M160 router: Routing Engine, FPC, MCS, PCG, and SFM
- M320 router: Routing Engine, FPC, Control Board, SIB, and power supply (PS)
- T320 router and T640 routing node: Routing Engine, FPC, Control Board, SCG, and SIB

- Physically look at the craft interface. You see the following component LEDs:
  - M5/M10, M20, and M40 routers: Routing Engine
  - M40e/M160 routers: host module
  - T320 router and T640 routing node: host subsystem, FPCs, PICs, and SIBs
- Look at the LEDs on the component faceplate. Table 17 describes where the LEDs are located on the router.

**Table 17: Component LED Location on the Router**

Component	LED Location on the Router
Routing Engine	<p>(M5/M10, M40e, and M160 routers) Remove the component cover.</p> <p>(M7i/M10i routers) On the Routing Engine faceplate at the front of the router.</p> <p>(M20 router) On the rear Routing Engine panel.</p> <p>(M20, M40, M40e, M160, and M320 routers) On the craft interface.</p> <ul style="list-style-type: none"> <li>■ The M40e and M160 router Routing Engine is paired with an MCS and is monitored by the host module LEDs on the craft interface.</li> <li>■ The M320 router, T320 router, and the T640 routing node Routing Engine is paired with a Control Board and is monitored by the host subsystem LEDs on the craft interface</li> </ul> <p>Remove the cover for the Routing Engine on the M40e, M160, and T320 routers and the T640 routing node.</p> <p><i>Note:</i> You cannot see the Routing Engine LED on the M40 router.</p>
FPC	<p>(M20, M40, M40e, M160, and M320 routers) On the FPC faceplate at the front of the router.</p> <p>(M320 router) On the craft interface</p>
PIC	<p>(M5 and M10 routers) On the craft interface.</p> <p>(M7i router) On the PIC faceplate at the front of the router.</p> <p>(M10i router) On the FIC faceplate at the front of the router and on the PIC faceplate at front of the router.</p> <p>(All other routers) On the PIC faceplate at the front of the router.</p>
Power supply	<p>On the power supply faceplate at the bottom rear of the router.</p> <p>(M320 router) On the craft interface.</p>
Host module	<p>(M40e and M160 routers) On the craft interface. Remove the component cover.</p>
SFM	<p>(M40e and M160 routers) On the SFM faceplate at the rear of the router. Remove the component cover.</p>
MCS	<p>(M40e and M160 routers) On the MCS faceplate at the rear of the router. Remove the component cover.</p>
PCG	<p>(M40e and M160 routers) On the PCG faceplate at the rear of the router. Remove the component cover.</p>
SCB	<p>(M40 router) On the SCB faceplate at the front of the router, vertical in the middle of the FPC card cage.</p>
SSB	<p>(M20 router) On the SSB faceplate at the top front of the router.</p>
Control Board	<p>(T320 router and T640 routing node) On the Control Board faceplate at the upper rear of the chassis.</p>



Component	LED Location on the Router
SCG	(T320 router and T640 routing node) On the SCG faceplate at the upper rear of the chassis.
SIB	(M320, T320 router and T640 routing node) On the SIB faceplate at the center rear of the chassis. (M320 router) On the craft interface.
CFEB	(M7i/M10i routers) On the DFEB faceplate at the rear of the router.
FIC	(M7i router) On the FIC faceplate at front of the router.
HCM	(M10i router) On the HCM faceplate at front of the router.

### Display Detailed Component Environmental Information

(For M7i, M10i, M40e, M160, M320, and T320 routers and T640 routing node) You can display detailed environmental status information about certain router components.

**Action** To display detailed environmental status information about a component, use the following CLI command:

```
user@host> show chassis environment component-name
```

The command output displays the temperature of the air passing by the component, in degrees Centigrade and Fahrenheit. It also displays whether the fans and/or blowers are at normal or high speed.

Table 18 lists the operational mode CLI commands for each router component for which you can display more detailed information.

**Table 18: Component Detailed Environmental Status CLI Commands**

Component	Operational Mode CLI Command
FEb	show chassis environment feb
FPC	show chassis environment fpc
FPM or craft interface	show chassis environment fpm
MCS	show chassis environment mcs
PCG	show chassis environment pcg
PEM or power supply	show chassis environment pem
Routing Engine	show chassis environment routing-engine
SFM	show chassis environment sfm
Control Board	show chassis environment cb
SIB	show chassis environment sib
SCG	show chassis environment scg

## Display Detailed Component Operational Information

You can display detailed operational information about certain router components. This feature is available on all routing platforms except the M5/M10, M20, and M40 routing platforms.

**Action** To display detailed operational information about a component, use the following CLI command:

```
user@host> show chassis component-name
```

The command output displays the temperature of the air passing by the component, in degrees Centigrade and Fahrenheit. It displays the total percentage of CPU, interrupt, heap space, and buffer space being used by the component processor, including the total DRAM available to the component processor. The command output displays the time when the component started running and how long the component has been running. A short uptime can indicate a problem with the component.

Table 19 lists the components for which you can display more detailed operational status information.

**Table 19: Component Detailed Operational Status CLI Commands**

Component	Operational Mode CLI Command
CFEB	show chassis cfeb
Ethernet switch	show chassis ethernet-switch
FPC	show chassis fpc
Routing Engine	show chassis routing-engine
FEB	show chassis feb
SCB	show chassis scb
SFM	show chassis sfm
SSB	show chassis ssb
SPMB	show chassis spmb
SIB	show chassis spmb sibs
Control Board (Ethernet switch)	show chassis ethernet-switch

## Step 2: Gather Component Alarm Information

**Steps To Take** To gather component alarm information, follow these steps:

1. Display the Current Router Alarms on page 33
2. Display Error Messages in the Messages Log File on page 33
3. Display Error Messages in the Chassis Daemon Log File on page 34

## Display the Current Router Alarms

**Action** To display the current router component alarms, use the following CLI command:

```
user@host> show chassis alarms
```

The command output displays the number of alarms currently active, the time when the alarm began, the severity level, and an alarm description. Note the date and time of an alarm so that you can correlate it with error messages in the `messages` system log file.

Various conditions related to the chassis components trigger yellow and red alarms. You cannot configure these conditions. Table 20 through Table 27 list the alarms that the chassis components can generate.

Table 20 lists the alarms that the chassis components can generate on an M5 or M10 router.

**Table 20: M5 or M10 Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Alternative media	The router boots from alternate boot device: the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan trays	One fan tray was removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays were removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or is spinning below required speed.	Replace the failed fan tray.	Red
FEB	The Control Board failed. If this occurs, the board attempts to reboot.	Replace the failed FEB.	Red
FPC	An FPC failed. If this occurs, the FPC attempts to reboot. If the SCB sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Routing Engine	Error in reading or writing compact flash.	Reformat the compact flash and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	System booted from hard disk.	Install a bootable image on the compact flash. If this fails, replace failed Routing Engine.	Yellow
	Compact flash is missing in boot list.	Replace the failed Routing Engine.	Red
	Hard disk is missing in boot list.	Replace the failed Routing Engine.	Red
Power supplies	A power supply was removed from the chassis.	Install the missing power supply.	Yellow
	A power supply failed.	Replace the failed power supply.	Red
Temperature	The chassis temperature exceeded 55 degrees, the fans were turned on to full speed, and one or more fans failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and the fans turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan has failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 22 lists the alarms that the chassis components can generate on M7i and M10i routing platforms.

**Table 21: M7i or M10i Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Alternative media	The router has a optional flash disk and boots from an alternate boot device. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
CFEB	For an M7i router, the CFEB failed. If this occurs, the board attempts to reboot.	Replace the failed CFEB.	Red
	For an M10i router, both Control Boards were removed or have failed.	Replace the failed or missing CFEB.	Red
	Too many hard errors in CFEB memory.	Replace the failed CFEB.	Red
	Too many soft errors in CFEB memory.	Replace the failed CFEB.	Red
	A CFEB microcode download failed.	Replace the failed CFEB.	Red
Fan trays	A fan has failed.	Replace the failed fan tray.	Red
	For an M7i router, a fan tray was removed from the chassis.	Install the missing fan tray.	Red
	For an M10i router, both fan trays are absent from the chassis.	Install the missing fan tray.	Red
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's midplane from the front is broken.	-----	Red
Power supplies	A power supply was removed.	Insert missing power supply.	Yellow
	A power supply failed.	Replace the failed power supply.	Red
	For an M10i router, only one power supply is operating.	Insert or replace the secondary power supply.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Routing Engine	Error in reading or writing hard disk.	Reformat the hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat the compact flash and install bootable image. If this fails, replace the failed Routing Engine.	Yellow
	System booted from hard disk. This alarm only applies, if you have an optional flash drive.	Install a bootable image on the compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash is missing in boot list.	Replace the failed Routing Engine.	Red
	Hard disk is missing in boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
Temperature	The chassis temperature exceeded 55 degrees C, the fans turned on to full speed, and one or more fans failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and the fans turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 22 lists the alarms that the chassis components can generate on an M20 router.

**Table 22: M20 Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Alternative media	The router boots from alternate boot device: the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan trays	One fan tray was removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays were removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or is spinning below required speed.	Replace the fan tray.	Red
FPC	An FPC failed. If this occurs, the FPC attempts to reboot. If the SCB sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Routing Engine	Error in reading or writing hard disk.	Reformat the hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat the compact flash and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	System booted from the default backup Routing Engine. If you manually switched mastership, ignore this alarm condition.	Install a bootable image on the default master Routing Engine. If this fails, replace the failed Routing Engine.	Yellow
	System booted from the hard disk.	Install a bootable image on the compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash is missing in the boot list.	Replace the failed Routing Engine.	Red
	Hard disk is missing in the boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
Power supplies	A power supply was removed from the chassis.	Insert power supply into empty slot.	Yellow
	A power supply failed.	Replace the failed power supply.	Red
SSB	The Control Board failed. If this occurs, the board attempts to reboot.	Replace the failed Control Board.	Red



Chassis Component	Alarm Condition	Remedy	Alarm Severity
Temperature	The chassis temperature exceeded 55 degrees, the fans turned on to full speed, and one or more fans have failed	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and the fans turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 23 lists the alarms that the chassis components can generate on an M40 router.

**Table 23: M40 Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Air filter	Change the air filter.	Change the air filter.	-----
Alternative media	The router boots from an alternate boot device: the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan trays	One fan tray was removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays were removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or is spinning below the required speed.	Replace the fan tray.	Red
FPC	An FPC has an out-of-range or invalid temperature reading.	Replace the failed FPC.	Yellow
	An FPC microcode download has failed.	Replace the failed FPC.	Red
	An FPC failed. If this occurs, the FPC attempts to reboot. If the SCB sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
	Too many hard errors in FPC memory.	Replace the failed FPC.	Red
	Too many soft errors in FPC memory.	Replace the failed FPC.	Red
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Power supplies	A power supply was removed from the chassis.	Insert a power supply into an empty slot.	Yellow
	A power supply temperature sensor failed.	Replace the failed power supply or power entry module.	Yellow
	A power supply fan failed.	Replace the failed power supply fan.	Yellow
	A power supply has high temperature.	Replace the failed power supply or power entry module.	Red
	A 5V power supply has failed.	Replace the failed power supply or power entry module.	Red
	A 3.3V power supply failed.	Replace the failed power supply or power entry module.	Red
	A 2.5V power supply failed.	Replace the failed power supply or power entry module.	Red
	A power supply input failed.	Check the power supply input connection.	Red
Routing Engine	A power supply has failed.	Replace the failed power supply or power entry module.	Red
	Error in reading or writing hard disk.	Reformat the hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat the compact flash and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	System booted from default backup Routing Engine. If you manually switched mastership, ignore this alarm condition.	Install a bootable image on the default master Routing Engine. If this fails, replace the failed Routing Engine.	Yellow
	System booted from hard disk.	Install a bootable image on the compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash missing in boot list.	Replace the failed Routing Engine.	Red
	Hard disk missing in boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
SCB	The SCB failed. If this occurs, the board attempts to reboot.	Replace the failed SCB.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Temperature	The chassis temperature exceeded 55 degrees C, the fans turned on to full speed, and one or more fans failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees, and the fans turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 24 lists the alarms that the chassis components can generate on an M40e or M160 router.

**Table 24: M40e or M160 Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Air filter	Change the air filter.	Change the air filter.	----- -
Alternative media	The router boots from an alternate boot device: the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
CIP	A CIP is missing.	Insert a CIP into an empty slot.	Red
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan trays	One fan tray was removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays were removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or is spinning below the required speed.	Replace the fan tray.	Red
FPC	An FPC has an out-of-range or invalid temperature reading.	Replace the failed FPC.	Yellow
	An FPC microcode download failed.	Replace the failed FPC.	Red
	An FPC failed. If this occurs, the FPC attempts to reboot. If the MCS sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
	Too many hard errors in FPC memory.	Replace the failed FPC.	Red
	Too many soft errors in FPC memory.	Replace the failed FPC.	Red
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
MCS	An MCS has an out-of-range or invalid temperature reading.	Replace the failed MCS.	Yellow
	An MCS was removed.	Reinstall MCS0.	Yellow
	An MCS has failed.	Replace the failed MCS.	Red
PCG	A backup PCG is offline.	Set the backup PCG online.	Yellow
	A PCG has an out-of-range or invalid temperature reading.	Replace the failed PCG.	Yellow
	A PCG was removed.	Insert a PCG into empty slot.	Yellow
	A PCG failed to come online.	Replace the failed PCG.	Red
Routing Engine	Error in reading or writing hard disk.	Reformat the hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat the compact flash and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	System booted from the default backup Routing Engine. If you manually switched mastership, ignore this alarm condition.	Install a bootable image on the default master Routing Engine. If this fails, replace the failed Routing Engine.	Yellow
	System booted from hard disk.	Install a bootable image on the compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash is missing in the boot list.	Replace the failed Routing Engine.	Red
	Hard disk is missing in the boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
Power supplies	A power supply was removed from the chassis.	Insert a power supply into the empty slot.	Yellow
	A power supply failed.	Replace the failed power supply.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
SFM	An SFM has an out of range or invalid temperature reading on SPP.	Replace the failed SFM.	Yellow
	An SFM has an out of range or invalid temperature reading on SPR.	Replace the failed SFM.	Yellow
	An SFM is offline.	Set the SFM online.	Yellow
	An SFM has failed.	Replace the failed SFM.	Red
	An SFM has been removed from the chassis.	Insert the SFM into an empty slot.	Red
	All SFMs are offline or missing from the chassis.	Insert SFMs into an empty slots or set all SFMs online.	Red
Temperature	The chassis temperature exceeded 55 degrees, the fans turned on to full speed, and one or more fans failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and the fans turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 25 lists the alarms that the chassis components can generate on an M320 router.

**Table 25: M320 Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Air filters	Change the air filter.	Change the air filter.	-----
Alternative media	The router boots from an alternate boot device: the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
Control Board	A Control Board was removed.	Insert a Control Board into the empty slot.	Yellow
	A Control Board temperature sensor alarm failed.	Replace the failed Control Board.	Yellow
	A Control Board failed.	Replace the failed Control Board.	Red
CIP	A CIP is missing.	Insert a CIP into an empty slot.	Red
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan trays	One fan tray was removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays were removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or is spinning below the required speed.	Replace the fan tray.	Red
FPC	An FPC has an out of range or invalid temperature reading.	Replace the failed FPC.	Yellow
	An FPC microcode download has failed.	Replace the failed FPC.	Red
	An FPC failed. If this occurs, the FPC attempts to reboot. If the SCB sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
	Too many hard errors in FPC memory.	Replace the failed FPC.	Red
	Too many soft errors in FPC memory.	Replace the failed FPC.	Red



Chassis Component	Alarm Condition	Remedy	Alarm Severity
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red
Power supplies	A power supply was removed from the chassis.	Insert a power supply into the empty slot.	Yellow
	A power supply failed.	Replace the failed power supply.	Red
Routing Engine	Error in reading or writing hard disk.	Reformat the hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat compact flash and install bootable image. If this fails, replace failed Routing Engine.	Yellow
	System booted from the default backup Routing Engine. If you manually switched mastership, ignore this alarm condition.	Install a bootable image on default master Routing Engine. If this fails, replace the failed Routing Engine.	Yellow
	System booted from hard disk.	Install a bootable image on compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash is missing in boot list.	Replace the failed Routing Engine.	Red
	Hard disk is missing in boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
SIB	A spare SIB is missing.	Insert a spare SIB into an empty slot.	Yellow
	An SIB failed.	Replace the failed SIB.	Yellow
	A spare SIB failed.	Replace the failed SIB.	Yellow
	An SIB has an out of range or invalid temperature reading.	Replace the failed SIB.	Yellow
	An SIB is missing.	Insert a SIB into an empty slot.	Red
	An SIB has failed.	Replace the failed SIB.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Temperature	The chassis temperature has exceeded 55 degrees C, the fans have been turned on to full speed, and one or more fans have failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature has exceeded 65 degrees C and the fans have been turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan has failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	Chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor has failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 26 lists the alarms that the chassis components can generate on an T320 router.

**Table 26: T320 Router Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Air filters	Change the air filter.	Change the air filters.	-----
Alternative media	The router boots from alternate boot device: the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
Control Board	A Control Board was removed.	Insert a Control Board into an empty slot.	Yellow
	A Control Board temperature sensor alarm failed.	Replace the failed Control Board.	Yellow
	A Control Board failed.	Replace the failed Control Board.	Red
CIP	A CIP is missing.	Insert a CIP into an empty slot.	Red
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan Trays	One fan tray has been removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays have been removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or spinning below require speed.	Replace the fan tray.	Red
FPC	An FPC has an out-of-range or invalid temperature reading.	Replace the failed FPC.	Yellow
	An FPC microcode download has failed.	Replace the failed FPC.	Red
	An FPC has failed. If this occurs, the FPC attempts to reboot. If the SCB sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
	Too many hard errors in FPC memory.	Replace the failed FPC.	Red
	Too many soft errors in FPC memory.	Replace the failed FPC.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red
Power supplies	A power supply was removed from the chassis.	Insert a power supply into an empty slot.	Yellow
	A power supply failed.	Replace the failed power supply.	Red
Routing Engine	Error in reading or writing hard disk.	Reformat hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat the compact flash and install bootable image. If this fails, replace failed Routing Engine.	Yellow
	System booted from default backup Routing Engine. If you manually switched mastership, ignore this alarm condition.	Install a bootable image on default master Routing Engine. If this fails, replace the failed Routing Engine.	Yellow
	System booted from hard disk.	Install a bootable image on the compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash missing in boot list.	Replace the failed Routing Engine.	Red
	Hard disk missing in boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
SIB	A spare SIB is missing.	Insert the spare SIB into an empty slot.	Yellow
	An SIB has failed.	Replace the failed SIB.	Yellow
	A spare SIB has failed.	Replace the failed SIB.	Yellow
	A SIB has an out-of-range or invalid temperature reading.	Replace the failed SIB.	Yellow
	An SIB is missing.	Insert an SIB into an empty slot.	Red
	An SIB has failed.	Replace the failed SIB.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Temperature	The chassis temperature exceeded 55 degrees, the fans turned on to full speed, and one or more fans failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and the fans turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	Chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red

Table 27 lists the alarms that the chassis components can generate on a T640 routing node.

**Table 27: T640 Routing Node Chassis Component Alarm Conditions**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Air filter	Change the air filter.	Change the air filter.	-----
Alternative media	The router boots from alternate boot device, the hard disk. Typically, the router boots from the flash drive. If you configure your router to boot from the hard disk, ignore this alarm condition.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Yellow
Control Board	A Control Board was removed.	Insert a Control Board into an empty slot.	Yellow
	A Control Board temperature sensor alarm has failed.	Replace the failed Control Board.	Yellow
	A Control Board failed.	Replace the failed Control Board.	Red
CIP	A CIP is missing.	Insert a CIP into an empty slot.	Red
Craft interface	The craft interface failed.	Replace the failed craft interface.	Red
Fan trays	One fan tray was removed from the chassis.	Install the missing fan tray.	Yellow
	Two or more fan trays were removed from the chassis.	Install the missing fan trays.	Red
	One fan in the chassis is not spinning or is spinning below the required speed.	Replace the fan tray.	Red
FPC	An FPC has an out-of-range or invalid temperature reading.	Replace the failed FPC.	Yellow
	An FPC microcode download has failed.	Replace the failed FPC.	Red
	An FPC has failed. If this occurs, the FPC attempts to reboot. If the SCB sees that an FPC is rebooting too often, it shuts down the FPC.	Replace the failed FPC.	Red
	Too many hard errors in FPC memory.	Replace the failed FPC.	Red
	Too many soft errors in FPC memory.	Replace the failed FPC.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
Hot swapping	Too many hot-swap interrupts are occurring. This message generally indicates that a hardware component that plugs into the router's backplane from the front (generally, an FPC) is broken.	-----	Red
Routing Engine	Error in reading or writing hard disk.	Reformat the hard disk and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	Error in reading or writing compact flash.	Reformat the compact flash and install a bootable image. If this fails, replace the failed Routing Engine.	Yellow
	System booted from the default backup Routing Engine. If you manually switched mastership, ignore this alarm condition.	Install a bootable image on the default master Routing Engine. If this fails, replace the failed Routing Engine.	Yellow
	System booted from the hard disk.	Install a bootable image on the compact flash. If this fails, replace the failed Routing Engine.	Yellow
	Compact flash is missing in boot list.	Replace the failed Routing Engine.	Red
	Hard disk is missing in boot list.	Replace the failed Routing Engine.	Red
	Routing Engine failed to boot.	Replace the failed Routing Engine.	Red
Power supplies	A power supply was removed from the chassis.	Insert a power supply into an empty slot.	Yellow
	A power supply has failed.	Replace the failed power supply.	Red
SCG	A backup SCG is offline.	Set the backup SCG online.	Yellow
	An SCG has an out-of-range or invalid temperature reading.	Replace the failed SCG.	Yellow
	An SCG was removed.	Insert an SCG into an empty slot.	Yellow
	All SCGs are offline or missing.	Insert SCGs into empty slots or set all SCGs online.	Red
	An SCG failed.	Replace the failed SCG.	Red

Chassis Component	Alarm Condition	Remedy	Alarm Severity
SIB	A spare SIB is missing.	Insert a spare SIB into an empty slot.	Yellow
	An SIB failed.	Replace the failed SIB.	Yellow
	A spare SIB failed.	Replace the failed SIB.	Yellow
	A SIB has an out-of-range or invalid temperature reading.	Replace the failed SIB.	Yellow
	An SIB is missing.	Insert an SIB into empty slot.	Red
	An SIB failed.	Replace the failed SIB.	Red
SPMB	A local SPMB is offline.	Reset the Control Board. If this fails, replace the Control Board.	Red
Temperature	The chassis temperature exceeded 55 degrees, the fans turned on to full speed, and one or more fans have failed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and the fans have been turned on to full speed.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Yellow
	The chassis temperature exceeded 65 degrees C and a fan failed. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	Chassis temperature exceeded 75 degrees C. If this condition persists for more than 4 minutes, the router shuts down.	<ul style="list-style-type: none"> <li>■ Check the room temperature.</li> <li>■ Check the air filter and replace it.</li> <li>■ Check the air flow.</li> <li>■ Check the fan.</li> </ul>	Red
	The temperature sensor failed.	For technical support, open a support case using the Case Manager link at <a href="http://www.juniper.net/support/">http://www.juniper.net/support/</a> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).	Red



## Display Error Messages in the Messages Log File

**Action** To display router component error messages in the `messages` system log file, use the following CLI command:

```
user@host> show log messages
```

The `messages` system log file records the time the failure or event occurred, the severity level, a code, and a message description. Display the error messages in the `messages` system log file logged at least 5 minutes before and after the alarm event.

To search for specific information in the log file, use the `| match component-name` command; for example, use `show log messages | match fpc`. If there is a space in the component name, enclose the component name in quotation marks; for example, `| match "power supply"`.

To search for multiple items in the log file, use the `| match` command followed by the multiple items, separated by the `|` (pipe), and enclosed in quotation marks; for example, `| match "fpc | sfm | kernel | tnp"`.

To monitor the `messages` file in real time, use the `monitor start messages` CLI command. This command displays the new entries in the file until you stop monitoring by using the `monitor stop messages` CLI command.

For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Display Error Messages in the Chassis Daemon Log File

**Action** To display router component errors in the chassis daemon (`chassisd`) system log file, use the following CLI command:

```
user@host> show log chassisd
```

The chassis daemon (`chassisd`) log file keeps track of the state of each chassis component.

To search for specific information in the log file, use the `| match component-name` command; for example, `show log messages | match fpc`. If there is a space in the component name, enclose the component name in quotation marks; for example, `| match "power supply"`.

To search for multiple items in the log file, use the `| match` command followed by the multiple items, separated by the `|` (pipe), and enclosed in quotation marks; for example, `| match "fpc | sfm | kernel | tnp"`.

To monitor the `chassisd` file in real time, use the `monitor start chassisd` CLI command. This command displays the new entries in the file until you stop monitoring by using the `monitor stop chassisd` CLI command.

### Step 3: Verify the Component Problem

Test a component only if it is not associated with a previously reported router component failure case and if testing will not compromise the integrity of the router and other components.

**Action** To verify component failure, follow these steps:

1. Make sure that the component is well seated in its slot and connected to the router midplane.



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the component for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

---

2. Perform a swap test on the component that has failed or has a problem. Take the component offline if necessary, remove it, and replace it with one that you know works. If the replaced component works, there was a problem with the component you removed.

### Step 4: Fix the Problem

**Action** If the router alarm condition is your responsibility, take action and correct it. For example, replace a dirty air filter, clean a fiber-optic cable, connect the component securely to the midplane, or reset the component. Otherwise, escalate the alarm condition and contact JTAC.



**NOTE:** Do not straighten component pins. If a component's pins are bent, return the component with a Return Material Authorization (RMA). Straightening the pins may cause intermittent problems in the future.

---

### Step 5: Contact JTAC

JTAC performs more advanced troubleshooting. If you cannot determine the cause of a problem or need additional assistance, open a support case using the Case Manager link at <http://www.juniper.net/support/> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).

**Action** To provide JTAC with information about the system, use the following CLI command:

```
user@host> request support information
```

Include the command output in your support request.

Because the output of this command is generally quite long, you can redirect the output to a file by using the following CLI command:

```
user@host> request support information | save filename
```

The **request support information** command is a combination of the following CLI operational mode commands:

- **show version detail**—Display the current time and information about how long the router, router software, and routing protocols have been running.
- **show version detail**—Display version information for the JUNOS software packages and the software for each software process.
- **show system core-dumps**—This is a hidden command used specifically by JTAC for troubleshooting router problems.
- **show chassis hardware**—Display a list of all the components installed in the router chassis. The output includes the component name, version, part number, serial number, and a brief description.
- **show system processes extensive**—Display exhaustive system processes that are running on the router and have controlling terminal information. This option is equivalent to the UNIX **top -bSld1 infinity** command.
- **show pfe statistics error**—Display statistics about the Packet Forwarding Engine errors.
- **show chassis routing-engine**—Display information about the Routing Engine.
- **show chassis environment**—Display environmental information about the router chassis, including the temperature and information about the fans, power supplies, and Routing Engine.
- **show chassis firmware**—Display the version levels of the firmware running on the SCB, SFM, SSB, FEB, and FPCs.
- **show chassis fpc detail**—Display detailed status information for all FPCs or for a specified FPC.
- **show system boot messages**—Display initial messages generated by the system kernel upon boot. This is the contents of the **/var/run/dmesg.boot** file.
- **show system storage**—Display statistics about the amount of free disk space in the router's file systems. Values are displayed in 1024-byte (1-KB) blocks. This command is equivalent to the UNIX **df -k** command.
- **show system virtual-memory**—Display the usage of JUNOS kernel memory, listed first by size of allocation and then by type of usage.
- **show system buffer**—Display information about the buffer pool that the Routing Engine uses for local traffic, which is the routing and management traffic that is exchanged between the Routing Engine and the Packet Forwarding Engine within the router, as well as the routing and management traffic from IP (that is, from OSPF, BGP, SNMP, pings, and so on).
- **show system statistics**—Display system statistics for all protocols.

- **show configuration | except SECRET-DATA**—Display the configuration that currently is running on the router, which is the last committed configuration. If you have modified the configuration since you last committed it, the configuration information displayed by the **show configuration** command will be different from that displayed with the **show** command from the **[edit]** hierarchy level in JUNOS software CLI configuration mode.
- **show interfaces extensive**—Display static status information about router interfaces.
- **show chassis hardware extensive**—Display extensive information about hardware installed in the router chassis.

## Step 6: Return the Failed Component

**Action** To return a failed component, follow these steps:

1. Determine the part number and serial number of the component. To list the numbers for all components installed in the chassis, use the following CLI command:

```
user@host> show chassis hardware
```

If the component does not appear in the hardware inventory listing, check the failed component for the attached serial number ID label.



**NOTE:** The cooling system components (fans and impellers) do not have serial numbers. Therefore, you will not see a serial number listed in the hardware inventory or a serial number ID label on the component.

---

2. Obtain a Return Materials Authorization (RMA) number from JTAC. Open a support case using the Case Manager link at <http://www.juniper.net/support/> or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).

Provide the following information in your e-mail message or during the telephone call:

- Part number, description, and serial number of the component
- Your name, organization name, telephone number, fax number, and e-mail address
- Shipping address for the replacement component, including a contact name, phone number, and e-mail address
- Description of the failure, including log messages

The support representative will validate your request and issue an RMA number for the return of the component.

3. Pack the router or component for shipment, as described in the appropriate router hardware guide. Label the package with the corresponding RMA number.



## Part 3

# Monitoring Key and Common Router Components

- Monitoring Key Router Components on page 91
- Monitoring the Router Chassis on page 107
- Monitoring the Routing Engine on page 125
- Monitoring FPCs on page 163
- Monitoring PICs on page 183
- Monitoring the Craft Interface on page 197
- Monitoring Power Supplies on page 217
- Monitoring the Cooling System on page 251
- Maintaining the Cable Management System, Cables, and Connectors on page 275





## Chapter 12

# Monitoring Key Router Components

You monitor the key router components—the Routing Engine and the Packet Forwarding Engine—to ensure that the router is handling general routing operations and is forwarding packets properly. This chapter provides an overview of these components and includes the following information:

- Understanding Key Router Components on page 92
  - Packet Forwarding Engine on page 92
  - Routing Engine on page 104

For information about what components comprise the Packet Forwarding Engine on each routing platform, see Table 29 on page 93.

For information about monitoring the Routing Engine, see:

- Monitoring the Routing Engine on page 125
- Monitoring Redundant Routing Engines on page 491

## Understanding Key Router Components

**Purpose** Inspect the Routing Engine and the Packet Forwarding Engine to ensure that the router is handling general routing operations and is forwarding packets properly.


**What Are the Key Router Components**

The router consists of two major architectural components:

- Packet Forwarding Engine—This high-performance, application-specific integrated circuit (ASIC)-based component provides Layer 2 and Layer 3 packet switching, route lookups, and packet forwarding.
- Routing Engine—Provides Layer 3 routing services and network management.

The Packet Forwarding Engine and the Routing Engine perform their primary tasks independently, although they constantly communicate through a 100-Mbps internal link. This arrangement provides streamlined forwarding and routing control and the capability to run Internet-scale backbone networks at high speeds. Figure 12 illustrates the relationship between the Packet Forwarding Engine and the Routing Engine.

**Figure 12: Router Architecture**



### Packet Forwarding Engine

The Packet Forwarding Engine provides Layer 2 and Layer 3 packet switching, route lookups, packet forwarding, and route lookup functions. Table 28 lists the Packet Forwarding Engine forwarding rate and aggregate throughput for each routing platform.

**Table 28: Packet Forwarding Engine Forwarding Rate and Aggregate Throughput Characteristics Per Routing Platform**

Specifications	M5/ M10	M7i	M10i	M20	M40	M40e	M160	M320	T320	T640
Packet forwarding rate in million packets per second (Mpps)	40	16	16	40	40	40	160	385	385	770
Aggregate throughput in gigabits per second (Gbps)	6.4	8.4	12.8	25.6	40	51.2	160	320	320	640

For M-series routers, the Packet Forwarding Engine is implemented in ASICs that are located on the System Control Board (SCB): a Forwarding Engine Board (FEB) (M5/M10 router), System and Switch Board (SSB) (M20 router), SCB (M40 router), or Switching and Forwarding Module (SFM) (M40e and M160 routers). It uses a centralized route lookup engine and shared memory. For T-series routers, the Packet Forwarding Engine is implemented in ASICs that are physically located on the Flexible PIC Concentrator (FPCs) and Physical Interface Card (PICs).

Table 29 lists the Packet Forwarding Engine components for each routing platform.

**Table 29: Router Packet Forwarding Engine Components Per Routing Platform**

Component	M5/ M10	M7i	M10i	M20	M40	M40e	M160	M320	T320	T640
Midplane	X	X	X	X	X	X	X	X		
PIC	X	X	X	X	X	X	X	X	X	X
FPC	Built-in			X	X	X	X	X	X	X
FIC		X								
CFEB		X	X							
FEB	X									
SSB				X						
SCB					X					
SFM						X	X			
Layer 2/Layer 3 Packet Processing ASIC									X	X
Queuing and Memory Interface ASICs								X	X	X
T-series Internet Processor								X	X	X
Switch Interface ASICs								X	X	X
Media-specific ASICs on the PICs	X	X	X	X	X	X	X	X	X	X

### Data Flow Through the Router Packet Forwarding Engine

This section describes the sequence in which data flows through each router Packet Forwarding Engine.


- Data Flow Through the M5 and M10 Router Packet Forwarding Engine on page 94
- Data Flow Through the M7i Router Packet Forwarding Engine on page 95
- Data Flow Through the M10i Router Packet Forwarding Engine on page 96
- Data Flow Through the M20 Router Packet Forwarding Engine on page 97
- Data Flow Through the M40 Router Packet Forwarding Engine on page 98
- Data Flow Through the M40e Router Packet Forwarding Engine on page 99
- Data Flow Through the M160 Router Packet Forwarding Engine on page 100

- Data Flow Through the M320 Router and T640 Routing Node Packet Forwarding Engine on page 101
- Data Flow Through the T320 Router and T640 Routing Node Packet Forwarding Engine on page 103

### **Data Flow Through the M5 and M10 Router Packet Forwarding Engine**

Data flows through the M5 and M10 router Packet Forwarding Engine in the sequence shown in Figure 13:

**Figure 13: M5 and M10 Router Packet Forwarding Engine Components and Data Flow**




1335

1. Packets arrive at an incoming PIC interface.
2. The PIC passes the packets through the midplane to the FEB, where the I/O Manager ASIC breaks them into 64-byte cells.
3. The Distributed Buffer Manager ASIC on the FEB distributes the data cells throughout memory banks on the FEB.
4. The Internet Processor II ASIC on the FEB performs route lookups and makes forwarding decisions.
5. The Internet Processor II ASIC notifies a second Distributed Buffer Manager ASIC on the FEB, which forwards the notification to the outgoing interface.
6. The I/O Manager ASIC on the FEB reassembles data cells in shared memory into data packets as they are ready for transmission and passes them to the outgoing PIC through the midplane.
7. The outgoing PIC transmits the data packets.

### Data Flow Through the M7i Router Packet Forwarding Engine

Data flows through the M7i router Packet Forwarding Engine in the following sequence shown in Figure 14. Use of ASICs promotes efficient movement of data packets through the system.

**Figure 14: M7i Router Packet Forwarding Engine Components and Data Flow**




1. Packets arrive at an incoming networking interface.
2. The networking interface passes the packets to the CFEB, where the integrated ASIC processes the packet headers, divides the packets into 64-byte data cells, and distributes the data cells throughout the memory buffer.
3. The integrated ASIC on the CFEB performs a route lookup for each packet and decides how to forward it.
  - a. If services are configured for the packet, the integrated ASIC reassembles the packet and passes it to the services interface.
  - b. The services interface passes the packet to the CFEB, where the integrated ASIC processes the packet, divides the packet into 64-byte cells, and distributes the data cells throughout the memory buffer.
  - c. The integrated ASIC performs a second route lookup for each packet and decides how to forward it.
4. The integrated ASIC notifies the outbound networking interface.
5. The integrated ASIC reassembles data cells stored in shared memory into data packets as they are ready for transmission and passes them to the outbound networking interface.
6. The outbound networking interface transmits the data packets.

### Data Flow Through the M10i Router Packet Forwarding Engine

Data flows through the M10i routers Packet Forwarding Engine in the sequence shown in Figure 15. Use of ASICs promotes efficient movement of data packets through the system.

**Figure 15: M10i Router Packet Forwarding Engine Components and Data Flow**




1. Packets arrive at an incoming networking interface.
2. The networking interface passes the packets to the CFEB, where the integrated ASIC processes the packet headers, divides the packets into 64-byte data cells, and distributes the data cells throughout the memory buffer.
3. The integrated ASIC on the CFEB performs a route lookup for each packet and decides how to forward it.
  - a. If services are configured for the packet, the integrated ASIC reassembles the packet and passes it to the services interface.
  - b. The services interface passes the packet to the CFEB, where the integrated ASIC processes the packet, divides the packet into 64-byte cells, and distributes the data cells throughout the memory buffer.
  - c. The integrated ASIC performs a second route lookup for each packet and decides how to forward it.
4. The integrated ASIC notifies the outbound networking interface.
5. The integrated ASIC reassembles data cells stored in shared memory into data packets as they are ready for transmission and passes them to the outbound networking interface.
6. The outbound networking interface transmits the data packets.

### Data Flow Through the M20 Router Packet Forwarding Engine

Data flows through the M20 router Packet Forwarding Engine in the sequence shown in Figure 16.

**Figure 16: M20 Router Packet Forwarding Engine Components and Data Flow**




1243

1. Packets arrive at an incoming PIC interface.
2. The I/O Manager ASIC processes the packet headers, divides the packets into 64-byte data cells, and passes the cells through the midplane to the SSB.
3. A Distributed Buffer Manager ASIC on the SSB distributes the data cells throughout the memory buffers located on and shared by all the FPCs.
4. The Internet Processor II ASIC on the SSB performs a route lookup for each packet and decides how to forward it.
5. The Internet Processor II ASIC notifies a Distributed Buffer Manager ASIC on the SSB of the forwarding decision, and the Distributed Buffer Manager ASIC forwards the notification to the FPC that hosts the appropriate outbound interface.
6. The I/O Manager ASIC on the FPC reassembles data cells stored in shared memory into data packets as they are ready for transmission and passes them through the Packet Director ASIC to the outbound PIC.
7. The outbound PIC transmits the data packets.

**Data Flow Through the M40 Router Packet Forwarding Engine**

Data flows through the M40 router Packet Forwarding Engine in the sequence shown in Figure 17.

**Figure 17: M40 Router Packet Forwarding Engine Components and Data Flow**

1243a


1. Packets arrive at an incoming PIC interface.
2. The PIC passes the packets to the FPC, where the I/O Manager ASIC processes the packet headers, divides the packets into 64-byte data cells, and passes the cells to the backplane.
3. The Distributed Buffer Manager ASIC on the backplane distributes the data cells throughout the memory buffers located on and shared by all the FPCs.
4. The Internet Processor or Internet Processor II ASIC on the SCB performs route lookups and makes forwarding decisions.
5. The Internet Processor or Internet Processor II ASIC notifies a second Distributed Buffer Manager ASIC on the backplane of the routing decision.
6. The Distributed Buffer Manager ASIC forwards the notification to the FPC that hosts the outbound PIC.
7. The I/O Manager ASIC on the FPC reassembles data cells in shared memory into data packets as they are ready for transmission and passes them to the outbound PIC.
8. The outbound PIC transmits the data packets.



### Data Flow Through the M40e Router Packet Forwarding Engine

Data flows through the M40e router Packet Forwarding Engine in the sequence shown Figure 18.

**Figure 18: M40e Router Packet Forwarding Engine Components and Data Flow**




1. Packets arrive at an incoming PIC interface.
2. The PIC passes the packets to the FPC, where the Packet Director ASIC directs them to the active I/O Manager ASIC.
3. The I/O Manager ASIC processes the packet headers, divides the packets into 64-byte data cells, and passes the cells through the midplane to the SFM.
4. A Distributed Buffer Manager ASIC on the SFM distributes the data cells throughout the memory buffers located on and shared by all the FPCs.
5. The Internet Processor II ASIC on the SFM performs a route lookup for each packet and decides how to forward it.
6. The Internet Processor II ASIC notifies the second Distributed Buffer Manager ASIC (on the SFM) of the forwarding decision, and the Distributed Buffer Manager ASIC forwards the notification to the FPC that hosts the appropriate outbound interface.
7. The I/O Manager ASIC on the FPC reassembles data cells stored in shared memory into data packets as they are ready for transmission and passes them through the Packet Director ASIC to the outbound PIC.
8. The outbound PIC transmits the data packets.

1921

**Data Flow Through the M160 Router Packet Forwarding Engine**

Data flows through the M160 router Packet Forwarding Engine in the sequence shown in Figure 19.

**Figure 19: M160 Router Packet Forwarding Engine Components and Data Flow**




1. Packets arrive at an incoming PIC interface.
2. The PIC passes the packets to the FPC, where the Packet Director ASIC distributes them among the I/O Manager ASICs.
3. The I/O Manager ASICs process the packet headers, divide the packets into 64-byte data cells, and pass the cells through the midplane to the SFMs.
4. The Distributed Buffer Manager ASICs on the SFMs distribute the data cells throughout memory buffers located on and shared by all the FPCs.
5. For each packet, an Internet Processor II ASIC on an SFM performs a route lookup and decides how to forward the packet.
6. The Internet Processor II ASIC notifies a second Distributed Buffer Manager ASIC (on the SFM) of the forwarding decision, and the Distributed Buffer Manager ASIC forwards the notification to the FPC that hosts the appropriate outbound interface.
7. The I/O Manager ASIC on the FPC reassembles data cells in shared memory into data packets as they are ready for transmission and passes them through the Packet Director ASIC to the outbound PIC.
8. The outbound PIC transmits the data packets.

### Data Flow Through the M320 Router and T640 Routing Node Packet Forwarding Engine

Data flows through the M320 routing node Packet Forwarding Engine in the sequence shown Figure 20.

**Figure 20: M320 Router Packet Forwarding Engine Components and Data Flow**




1. Packets arrive at an incoming PIC interface.
2. The PIC passes the packets to the FPC, where the Layer 2/Layer 3 Packet Processing ASIC performs Layer 2 and Layer 3 parsing and divides the packets into 64-byte cells.
3. The Switch Interface ASIC extracts the route lookup key, places it in a notification and passes the notification to the Internet Processor ASIC. The Switch Interface ASIC also passes the data cells to the Queuing and Memory Interface ASICs for buffering.
4. The Queuing and Memory Interface ASICs pass the data cells to memory for buffering.
5. The Internet Processor ASIC performs the route lookup and forwards the notification to the Queuing and Memory Interface ASIC.

6. The Queuing and Memory Interface ASIC sends the notification to the Switch Interface ASIC facing the switch fabric, unless the destination is on the same Packet Forwarding Engine. In this case, the notification is sent back to the Switch Interface ASIC facing the outgoing ports, and the packets are sent to the outgoing port without passing through the switch fabric (see Step 13).
7. The Switch Interface ASIC sends bandwidth requests through the switch fabric to the destination port. The Switch Interface ASIC also issues read requests to the Queuing and Memory Interface ASIC to begin reading data cells out of memory.
8. The destination Switch Interface ASIC sends bandwidth grants through the switch fabric to the originating Switch Interface ASIC.
9. Upon receipt of each bandwidth grant, the originating Switch Interface ASIC sends a cell through the switch fabric to the destination Packet Forwarding Engine.
10. The destination Switch Interface ASIC receives cells from the switch fabric. It extracts the route lookup key from each cell, places it in a notification, and forwards the notification to the Internet Processor ASIC.
11. The Internet Processor ASIC performs the route lookup, and forwards the notification to the Queuing and Memory Interface ASIC.
12. The Queuing and Memory Interface ASIC forwards the notification, including next-hop information, to the Switch Interface ASIC.
13. The Switch Interface ASIC sends read requests to the Queuing and Memory Interface ASIC to read the data cells out of memory, and passes the cells to the Layer 2/Layer 3 Packet Processing ASIC.
14. The Layer 2/Layer 3 Packet Processing ASIC reassembles the data cells into packets, adds Layer 2 encapsulation, and sends the packets to the outgoing PIC interface.
15. The outgoing PIC sends the packets out into the network.

### Data Flow Through the T320 Router and T640 Routing Node Packet Forwarding Engine

Data flows through the T320 router and T640 routing node Packet Forwarding Engine in the following sequence shown in Figure 21.

**Figure 21: T320 Router and T640 Routing Node Packet Forwarding Engine Components and Data Flow**



1. Packets arrive at an incoming PIC interface.
2. The PIC passes the packets to the FPC, where the Layer 2/Layer 3 Packet Processing ASIC performs Layer 2 and Layer 3 parsing and divides the packets into 64-byte cells.
3. The Switch Interface ASIC extracts the route lookup key, places it in a notification, and passes the notification to the T-series Internet Processor. The Switch Interface ASIC also passes the data cells to the Queuing and Memory Interface ASICs for buffering.
4. The Queuing and Memory Interface ASICs pass the data cells to memory for buffering.
5. The T-series Internet Processor performs the route lookup and forwards the notification to the Queuing and Memory Interface ASIC.


6. The Queuing and Memory Interface ASIC sends the notification to the Switch Interface ASIC facing the switch fabric, unless the destination is on the same Packet Forwarding Engine. In this case, the notification is sent back to the Switch Interface ASIC facing the outgoing ports, and the packets are sent to the outgoing port without passing through the switch fabric (see Step 13).
7. The Switch Interface ASIC sends bandwidth requests through the switch fabric to the destination port. The Switch Interface ASIC also issues read requests to the Queuing and Memory Interface ASIC to begin reading data cells out of memory.
8. The destination Switch Interface ASIC sends bandwidth grants through the switch fabric to the originating Switch Interface ASIC.
9. Upon receipt of each bandwidth grant, the originating Switch Interface ASIC sends a cell through the switch fabric to the destination Packet Forwarding Engine.
10. The destination Switch Interface ASIC receives cells from the switch fabric. It extracts the route lookup key from each cell, places it in a notification, and forwards the notification to the T-series Internet Processor.
11. The T-series Internet Processor performs the route lookup, and forwards the notification to the Queuing and Memory Interface ASIC.
12. The Queuing and Memory Interface ASIC forwards the notification, including next-hop information, to the Switch Interface ASIC.
13. The Switch Interface ASIC sends read requests to the Queuing and Memory Interface ASIC to read the data cells out of memory, and passes the cells to the Layer 2/Layer 3 Packet Processing ASIC.
14. The Layer 2/Layer 3 Packet Processing ASIC reassembles the data cells into packets, adds Layer 2 encapsulation, and sends the packets to the outgoing PIC interface.
15. The outgoing PIC sends the packets out into the network.

## **Routing Engine**

The Routing Engine consists of JUNOS software running on an Intel-based Peripheral Component Interconnect (PCI) platform. The JUNOS kernel supports JUNOS system processes which handle system management processes, routing protocols, and control functions (see Figure 22 on page 105).

The Routing Engine handles all the routing protocol processes, as well as other software processes that control the router interfaces, the chassis components, system management, and user access to the router. These routing and software processes run on top of a kernel that interacts with the Packet Forwarding Engine.

The Routing Engine has a dedicated 100-Mbps internal connection to the Packet Forwarding Engine.

**Figure 22: Routing Engine Architecture**

1164

### Routing Engine Functions


The Routing Engine handles all the routing protocol processes, as well as other software processes that control the router interfaces, system management, and user access to the router. These routing and software processes run on top of a kernel that interacts with the T-series Internet Processor in the Packet Forwarding Engine.

The Routing Engine provides the following functions:

- Routing protocol packet processing—All routing protocol packets from the network are directed to the Routing Engine, and hence do not delay the Packet Forwarding Engine unnecessarily.
- Software modularity—By dividing the different software functions into separate processes, the failure of one process is isolated from others and has little or no effect on them.
- In-depth Internet functionality—Each routing protocol is implemented with a complete set of Internet features and provides full flexibility for advertising, filtering, and modifying routes. Routing policies are set according to route parameters (such as prefix, prefix lengths, and BGP attributes).
- Scalability—The JUNOS routing tables are designed to hold all the routes in current and imminent networks. Additionally, the JUNOS software efficiently supports large numbers of interfaces and virtual circuits.
- Management interface—Different levels of system management practices are provided, including a command-line interface (CLI) and SNMP.
- Storage and change management—Configuration files, system images, and microcode can be held and maintained in primary and secondary storage systems, permitting local or remote upgrades.
- Efficiency and flexibility monitoring—The router permits alarm handling and packet counting. For example, the router allows information to be gathered on every port, without adversely affecting packet forwarding performance.

The Routing Engine constructs and maintains one or more routing tables (see Figure 23). From the routing tables, the Routing Engine derives a table of active routes, called the *forwarding table*, which is copied into the Packet Forwarding Engines. The design of the T-series Internet Processor allows the forwarding table in the Packet Forwarding Engines to be updated without interrupting the router's forwarding.

**Figure 23: Control Packet Handling for Routing and Forwarding Table Update**



On the M320 and T320 routers and the T640 routing node, the host subsystem provides the routing and system management functions. The host subsystem consists of the Routing Engine and the Control Board. For more information about the host subsystem, see “Monitoring the Host Subsystem” on page 289. For more information about the Control Boards, see “Monitoring the Control Board” on page 301.

On the M40e and M160 routers, the host module provides the routing and system management functions. The host module consists of the Routing Engine and the Miscellaneous Control Subsystem (MCS). For more information about the host module, see “Monitoring the Host Module” on page 341. For more information about the MCS, see “Monitoring the MCS” on page 359.

On the M10i router, the Routing Engine works with its companion High-Availability Chassis Manager (HCM) to provide control and monitoring functions for router components. For more information about the HCM, see “Monitoring the HCM” on page 431.



## Chapter 13

# Monitoring the Router Chassis

You monitor the router to ensure that the installed components are operating normally and that packets are being received and forwarded to their destination. (See Table 30.)

**Table 30: Checklist for Monitoring the Router Chassis**

Monitor Chassis Tasks	Command or Action
<b>Understanding the Router Chassis on page 108</b>	
■ M5 and M10 Router Chassis and Components on page 109	
■ M7i Router Chassis and Components on page 109	
■ M10i Router Chassis and Components on page 110	
■ M20 Router Chassis and Components on page 110	
■ M40 Router Chassis and Components on page 111	
■ M40e Router Chassis and Components on page 112	
■ M160 Router Chassis and Components on page 113	
■ M320 Router Chassis and Components on page 114	
■ T320 Router Chassis and Components on page 115	
■ T640 Routing Node and Components on page 116	
<b>Checking the Router Chassis Component Status on page 117</b>	
1. Display the Hardware Components Installed in the Router Chassis on page 117	show chassis hardware
2. Check the Component Environmental Status on page 118	show chassis environment
3. Check the Component Status from the Craft Interface on page 118	show chassis craft-interface
<b>Checking Router Alarms on page 119</b>	
1. Display Current Component Alarms on page 120	show chassis alarms
	show chassis craft-interface
2. Display Component Error Messages in the System Log File on page 121	show log messages
3. Display Component Errors in the Chassis Daemon Log File on page 122	show log chassisd

Monitor Chassis Tasks	Command or Action
<b>Verifying Router Component Failure on page 122</b>	Replace the failed component with one that you know works and check its status.
<b>Replacing a Failed Component on page 122</b>	<ol style="list-style-type: none"><li>1. Locate the component serial number ID label.</li><li>2. Obtain a Return Material Authorization (RMA) from JTAC.</li><li>3. Pack the component and ship it.</li></ol> See “Return the Failed Component” on page 86, or follow the procedures in the appropriate router hardware guide.

## Understanding the Router Chassis

**Purpose** Monitor the router chassis to ensure that the installed components are operating normally and that packets are being forwarded to their destination.

**What Is a Chassis** The router chassis is a rigid sheet-metal structure that houses all of the router hardware components. For more information about the router chassis, see the appropriate router hardware guide.

Figure 24 shows the front and rear of the M5 and M10 Internet router chassis and the installed components.

**Figure 24: M5 and M10 Router Chassis and Components**




Figure 25 shows the front and rear of the M7i Internet router chassis and the installed components.

**Figure 25: M7i Router Chassis and Components**





Figure 26 shows the front and rear of the M10i Internet router chassis and the installed components.

**Figure 26: M10i Router Chassis and Components**

**M10i router front**



**M10i router rear**





Figure 27 shows the front and rear of the M20 Internet router chassis and the installed components.

**Figure 27: M20 Router Chassis and Components**

**Front**



**Rear**






Figure 28 shows the front and rear of the M40 Internet router chassis and the installed components.

**Figure 28: M40 Router Chassis and Components**

Front




Rear



1268

Figure 29 shows the front and rear of the M40e Internet router chassis and the installed components.


**Figure 29: M40e Router Chassis and Components**



1270

Figure 30 shows the front and rear of the M160 Internet router chassis and the installed components.

**Figure 30: M160 Router Chassis and Components**




1269

Figure 26 shows the front and rear of the M320 Internet router chassis and the installed components.

**Figure 31: M320 Router Chassis and Components**

**M320 router front**



**M320 router rear**






Figure 32 shows the front and rear of the T320 Internet router chassis and installed components.

**Figure 32: T320 Router Chassis and Components**





Figure 33 shows the front and rear of the T640 Internet routing node and the frinstalled components.

**Figure 33: T640 Routing Node and Components**



- See Also**
- M5 and M10 Internet Router Overview on page 3
  - M7i Internet Router Overview on page 7
  - M10i Internet Router Overview on page 11
  - M20 Internet Router Overview on page 15
  - M40 Internet Router Overview on page 19
  - M40e Internet Router Overview on page 23
  - M160 Internet Router Overview on page 27
  - M320 Internet Router Overview on page 31

“T320 Internet Router Overview” on page 35

“T640 Internet Routing Node Overview” on page 39

## Checking the Router Chassis Component Status

**Steps To Take** To check the status of the components installed in the router chassis, follow these steps:

1. Display the Hardware Components Installed in the Router Chassis on page 117
2. Check the Component Environmental Status on page 118
3. Check the Component Status from the Craft Interface on page 118

### Step 1: Display the Hardware Components Installed in the Router Chassis

**Action** To display a list of the hardware components installed in the router chassis, use the following JUNOS command-line interface (CLI) operational mode command:

```
user@host> show chassis hardware
```

Sample Output	m160@host> show chassis hardware				
	Item	Version	Part number	Serial number	Description
	Chassis			101	M160
	Midplane	REV 02	710-001245	S/N AB4107	
	FPM CMB	REV 01	710-001642	S/N AA2911	
	FPM Display	REV 01	710-001647	S/N AA2999	
	CIP	REV 02	710-001593	S/N AA9563	
	PEM 0	Rev 01	740-001243	S/N KJ35769	DC
	PEM 1	Rev 01	740-001243	S/N KJ35765	DC
	PCG 0	REV 01	710-001568	S/N AA9794	
	PCG 1	REV 01	710-001568	S/N AA9804	
	Host 1			da000004f8d57001	Present
	MCS 1	REV 03	710-001226	S/N AA9777	
	SFM 0 SPP	REV 04	710-001228	S/N AA2975	
	SFM 0 SPR	REV 02	710-001224	S/N AA9838	Internet Processor I
	SFM 1 SPP	REV 04	710-001228	S/N AA2860	
	SFM 1 SPR	REV 01	710-001224	S/N AB0139	Internet Processor I
	FPC 0	REV 03	710-001255	S/N AA9806	FPC Type 1
	CPU	REV 02	710-001217	S/N AA9590	
	PIC 1	REV 05	750-000616	S/N AA1527	1x OC-12 ATM, MM
	PIC 2	REV 05	750-000616	S/N AA1535	1x OC-12 ATM, MM
	PIC 3	REV 01	750-000616	S/N AA1519	1x OC-12 ATM, MM
	FPC 1	REV 02	710-001611	S/N AA9523	FPC Type 2
	CPU	REV 02	710-001217	S/N AA9571	
	PIC 0	REV 03	750-001900	S/N AA9626	1x STM-16 SDH, SMIR
	PIC 1	REV 01	710-002381	S/N AD3633	2x G/E, 1000 BASE-SX
	FPC 2				FPC Type OC192
	CPU	REV 03	710-001217	S/N AB3329	
	PIC 0	REV 01			1x OC-192 SM SR-2

**What It Means** The command output displays a list of the components installed in the M160 router chassis, including the name, revision level, part number, serial number, and a brief description of the component. From this output, you can determine which components to maintain and monitor to ensure optimum router operation. The command output is similar for other routers.

## Step 2: Check the Component Environmental Status

**Action** To check the environmental status of the router component, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
m20@host> show chassis environment
```

Class	Item	Status	Measurement
Power	Power Supply A	OK	
	Power Supply B	OK	
Temp	FPC Slot 1	OK	30 degrees C / 86 degrees F
	FPC Slot 2	OK	29 degrees C / 84 degrees F
	Power Supply A	OK	23 degrees C / 73 degrees F
	Power Supply B	OK	21 degrees C / 69 degrees F
	SSB Slot 0	OK	30 degrees C / 86 degrees F
	Backplane	OK	24 degrees C / 75 degrees F
Fans	Rear Fan	OK	Spinning at normal speed
	Upper Fan	OK	Spinning at normal speed
	Middle Fan	OK	Spinning at normal speed
	Bottom Fan	OK	Spinning at normal speed
Misc	Craft Interface	OK	

**What It Means** The command output lists the components installed in an M20 router chassis, including the category or class, component name, operational status, and temperature or speed measurement. Use this command to get a quick status of each component installed in the router chassis. You can also use the `show chassis component-name` CLI command to get more detailed status information on certain components for isolating problems. For an example, see “Display Detailed Component Environmental Information” on page 59.

## Step 3: Check the Component Status from the Craft Interface

**Action** To check the router operation status from the craft interface, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
m160@host> show chassis craft-interface
```

FPM Display contents:

```
+-----+
|myrouter|
|Up: 1+16:46|
|        |
|Fans OK  |
+-----+
```

Front Panel System LEDs:

```
Host    0    1
-----
OK       .    *
Fail     .    .
Master   .    *
```

Front Panel Alarm Indicators:

```
-----
Red LED   .
Yellow LED .
Major relay .
```

```

Minor relay  .

Front Panel FPC LEDs:
FPC    0    1    2    3    4    5    6    7
-----
Red     .     .     .     .     .     .     .     .
Green  *     *     .     .     .     .     .     .

MCS and SFM LEDs:
MCS     0    1      SFM    0    1    2    3
-----
Amber           .           .     .
Green           .           .     .
Blue            *           *     *
  
```

**What It Means** The command output displays the router system operation status for an M160 router, including the alarm indicators, the information displayed on the craft interface LCD display, and the component LEDs. An asterisk (\*) indicates that the component is operating normally. A dot is merely a placeholder, and indicates nothing. For example, the asterisks in the **Host Front Panel System LEDs** section indicate that the Routing Engine in slot 1 is operating normally and that it is the master. The dots in the **Front Panel Alarm Indicators** section indicate that there are no system alarms.

**Alternative Actions** Physically look at the router craft interface. The router name in the LCD display helps verify that you have located the correct router to monitor. For more information about the craft interface, see “Monitoring the Craft Interface” on page 197 or the appropriate router hardware guide.

### Checking Router Alarms

Chassis alarms indicate a problem with a chassis component, such as the Flexible PIC Concentrators (FPCs), cooling system, power supplies, and other components. For a listing of the chassis alarms for a particular router, see the appropriate router hardware guide.

For information about conditions that trigger router component alarms, see:

- “M5 or M10 Router Chassis Component Alarm Conditions” on page 61
- “M7i or M10i Router Chassis Component Alarm Conditions” on page 63
- “M20 Router Chassis Component Alarm Conditions” on page 65
- “M40 Router Chassis Component Alarm Conditions” on page 68
- “M40e or M160 Router Chassis Component Alarm Conditions” on page 71
- “M320 Router Chassis Component Alarm Conditions” on page 74
- “T320 Router Chassis Component Alarm Conditions” on page 77
- “T640 Routing Node Chassis Component Alarm Conditions” on page 80

**Steps To Take** To check router system alarms, follow these steps:

1. Display Current Component Alarms on page 120
2. Display Component Error Messages in the System Log File on page 121

## Step 1: Display Current Component Alarms

**Action** To display the active chassis alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output** user@host> **show chassis alarms**  
5 alarms are currently active

Alarm time	Class Description
2002-04-16 15:09:01 PDT	Major PIC 2/2 failed to initialize
2002-04-16 15:08:40 PDT	Major Power Supply A 2.5 volt output failed
2002-04-16 15:08:40 PDT	Major Power Supply A 5 volt output failed
2002-04-16 15:08:40 PDT	Major Power Supply A 3.3 volt output failed
2002-04-16 15:08:40 PDT	Major Power Supply A fan failed

**What It Means** The command output displays the number of alarms currently active, the time at which the alarm began, the severity level, and an alarm description. Note the date and time of an alarm so that you can correlate it with error messages in the **messages** system log file. This sample command output is for a router from which the lower fan tray and the power supply have been removed, and the management Ethernet interface disconnected. The craft interface display, in alarm mode, displays a short description of the alarm. The **show chassis alarms** command output displays a longer description of the alarm.

**Alternative Actions** To view active router alarms, you can physically look at the craft interface or use the **show chassis craft-interface** command.

The **show chassis craft-interface** command displays the most severe alarm first, the alarm indicator status, and the number of active alarms. You cannot scroll through the alarms (if there are more than two) at the command line.

```
user@host> show chassis craft-interface
Red alarm:      LED on, relay on
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host fail LED:  Off
```

```
FPCs      0  1  2  3
-----
Green     *  *  *  *
Red       .  .  .  .
```

**LCD screen:**

```
+-----+
|myrouter|
|5 Alarms active|
|R: PIC 2/2 FAILED|
|R: Supply A 2v FAIL|
+-----+
```

When a red or yellow alarm occurs, the craft interface goes into alarm mode. Alarm mode preempts idle mode, displaying a message to alert you of serious alarm conditions. In alarm mode, the screen displays the following information:

- First line—Name of the router.
- Second line—Number of alarms active on the router.
- Third and fourth lines—Individual alarms, with the most severe condition shown first. Each line indicates whether the alarm is red (R) or yellow (Y).

For more information about the craft interface, see “Monitoring the Craft Interface” on page 197 or the appropriate router hardware guide.

## Step 2: Display Component Error Messages in the System Log File

**Action** To display component error messages in the `messages` system log file, use the following JUNOS CLI operational mode command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
[...Output truncated...]
Apr 17 11:12:45 tyleno1 scb CM: ALARM SET: (Major) Power Supply B fan failed
Apr 17 11:12:46 tyleno1 scb CM: ALARM CLEAR: Power Supply B fan failed
Apr 17 11:12:46 tyleno1 alarmd[590]: Alarm cleared: Pwr supply color=RED,
class=CHASSIS, reason=Power Supply B fan failed
Apr 17 11:13:09 tyleno1 alarmd[590]: Alarm set: Pwr supply color=RED,
class=CHASSIS, reason=Power Supply B fan failed
Apr 17 11:13:09 tyleno1 scb CM: ALARM SET: (Major) Power Supply B fan failed
Apr 17 11:13:10 tyleno1 alarmd[590]: Alarm cleared: Pwr supply color=RED,
class=CHASSIS, reason=Power Supply B fan failed
Apr 17 11:13:10 tyleno1 scb CM: ALARM CLEAR: Power Supply B fan failed
[...Output truncated...]
```

**What It Means** The `messages` system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can use the date and time to browse the `messages` log file, or you can use the `show log messages | match component-name` command to view error messages that are specific to a particular component. For example, the command output shows the common power supply error messages logged from the router. In the filter expression, if there is a space in the component name, enclose the component name in quotation marks, for example `| match "power supply"`.

Use system log file information to isolate a component problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated at the time of the event. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

### Step 3: Display Component Errors in the Chassis Daemon Log File

**Action** To display component error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```
user@host> show log chassisd
Jun 11 20:45:08 *** inventory change ***
Jun 11 20:45:08 CIP set alarm 0x1
Jun 11 20:45:08 alarm op fru 34 op 1 reason 1
Jun 11 20:45:08 send: red alarm set, class 100 obj 112 reason 1
Jun 11 20:45:08 CIP removed
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is maintained when components are added or removed. The command output displays error messages that are generated when a Connector Interface Panel (CIP) fails or is removed.

## Verifying Router Component Failure



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the component for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To verify router component failure, perform a swap test on a component as follows:

1. Replace a failed component with one that you know works.
2. Verify the component status by using the appropriate `show chassis component-name` command. If the replaced component works, the original component is defective.
3. If the replaced component does not work, remove it and check the component midplane connector for bent pins. If the replaced component still does not work, contact JTAC, and see “Return the Failed Component” on page 86.

## Replacing a Failed Component

**Action** To return the router chassis, you need to know the chassis serial number. To display the midplane serial number, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
m160@host> show chassis hardware
```

Item	Version	Part number	Serial number	Description
Chassis			101	M160
Midplane	REV 02	710-001245	S/N AB4107	
FPM CMB	REV 01	710-001642	S/N AA2911	
FPM Display	REV 01	710-001647	S/N AA2999	

[...Output truncated...]



**What It Means** The chassis serial number is AB4107.

To return a chassis, see “Return the Failed Component” on page 86. See also the appropriate router hardware guide.



## Chapter 14

# Monitoring the Routing Engine

You monitor and maintain the Routing Engine, a key router component, to ensure that all system processes function normally, including routing protocols, packet forwarding tables, router interfaces, system management, JUNOS software and file system storage, and monitoring functions. (See Table 31.)

**Table 31: Checklist for Monitoring the Routing Engine**

Monitor Routing Engine Tasks	Command or Action
<b>Understanding the Routing Engine on page 127</b>	
<ul style="list-style-type: none"><li>■ Routing Engine Types and Characteristics on page 127</li><li>■ Routing Engine Locations on page 130</li><li>■ Routing Engine Redundancy on page 135</li><li>■ Routing Engine Component Companionship on page 135</li><li>■ Routing Engine Boot Devices on page 135</li><li>■ Routing Engine Storage Media on page 136</li></ul>	
<b>Monitoring the Routing Engine Status on page 136</b>	
1. Check the Detailed Routing Engine Status on page 137	<code>show chassis routing-engine</code> <code>show chassis environment routing-engine</code>
2. Check the Routing Engine LEDs on page 138	<ul style="list-style-type: none"><li>■ Check the M7i Routing Engine LEDs on page 139</li><li>■ Check the M20 Router Routing Engine LEDs on page 140</li><li>■ Check the M40 Router Routing Engine LEDs on page 142</li><li>■ Check the M40e and M160 Router Routing Engine LEDs on page 143</li><li>■ Check the M320 Router Routing Engine LEDs on page 144</li><li>■ Check the T320 Router Routing Engine LEDs on page 144</li><li>■ Check the T640 Routing Node Routing Engine LEDs on page 145</li></ul>
3. Check the Redundant Routing Engine Status from the Craft Interface CLI Output on page 146	<code>show chassis craft-interface</code>
<b>Verifying Routing Engine Failure on page 149</b>	
1. Check Core Files If the Routing Engine Reboots on page 149	<ul style="list-style-type: none"><li>■ List the Core Files Generated After A Crash Occurs on page 149</li><li>■ Display the Messages Log File After A Crash Occurs on page 150</li><li>■ Example of When No Core File Is Generated on page 150</li></ul>

Monitor Routing Engine Tasks	Command or Action
2. Example of Boot Messages If Routing Engine Fails to Boot on page 150	show system storage show system boot-messages show log messages
3. Check for Compact Flash Media and Hard Disk Failure on page 150	<ul style="list-style-type: none"> <li>■ When the Compact Flash Is Removed from the Boot List on page 151</li> <li>■ Determine Why Compact Flash Did Not Mount on page 151</li> <li>■ When the Hard Disk Is Removed from the Boot List on page 152</li> <li>■ Verify That the Hard Disk Did Not Mount on page 152</li> <li>■ Verify That the Hard Disk Is Missing from The Boot List on page 153</li> <li>■ View Alarms When Media Is Removed from the Boot List on page 153</li> </ul>
4. Understand What Happens When Memory Failures Occur on page 154	
5. Check the Router File System and Boot Disk on page 154	show system storage
6. Display the Current Routing Engine Alarms on page 155	show chassis alarms
7. Display Error Messages in the System Log File on page 155	show log messages
8. Document the Events Prior to the Failure on page 156	Write down failure events as they occur. Turn on logging on your system console.
<b>Getting Routing Engine Hardware Information on page 157</b>	
1. Display Routing Engine Hardware Information on page 157	show chassis hardware
2. Locate the Routing Engine Serial Number ID Label on page 158	Locate the Routing Engine serial number ID label. If you see two serial numbers, give both to JTAC.
<b>Removing a Routing Engine on page 161</b>	<p>The Routing Engine is hot-pluggable. Follow the procedures in the applicable router hardware guide.</p> <p><b>Note:</b> The M5/M10 routers have a cover over the Routing Engine. The M40e and M160 routers have a cover over all the rear chassis components. Remember to remove the screws (M5/M10, M20, M40e, and M160 routers) or captive screws (T320 router and T640 routing node) next to the ejector clips before you remove the Routing Engine.</p>

## Understanding the Routing Engine

---

**Purpose** Inspect the Routing Engine to ensure that key system processes are operating normally.

**What Is a Routing Engine** The Routing Engine is a key component in the router. It is primarily responsible for the protocol intelligence of the router. Thus, it is responsible for creating a routing table, which consists of all routes learned by all protocols running on the router. The Routing Engine interprets the routing table, generates a subset of routes to be used for all forwarding purposes, and places them in the forwarding table. The Routing Engine also holds the microcode for the Packet Forwarding Engine.

The Routing Engine is responsible for user interaction functions, such as the command-line interface (CLI), Simple Network Management Protocol (SNMP) management, and craft interface interaction.

The Routing Engine consists of the following components:

- Intel Pentium compact Peripheral Component Interconnect (PCI) platform
- Nonrotating compact flash drive (RAM disk)
- Standard rotating hard drive
- Removable media drive

The JUNOS software resides on the compact flash drive, with an alternate copy residing on the system hard drive.

This section also includes the following information:

- Routing Engine Types and Characteristics on page 127
- Routing Engine Locations on page 130
- Routing Engine Redundancy on page 135
- Routing Engine Component Companionship on page 135

### ***Routing Engine Types and Characteristics***

This section lists the Routing Engine characteristics that are supported in each routing platform. It also shows the Routing Engine component supported in each routing platform. This section covers the following routing platforms:

- M7i and M10i Router Routing Engine on page 128
- M5, M10, M20, M40, M40e, and M160 Router Routing Engines on page 129
- M320 Router Routing Engine on page 129
- T320 Router and T640 Routing Node Routing Engine on page 130

Table 32 lists the Routing Engine type characteristics for each routing platform.


**Table 32: Routing Engine Characteristics Per Routing Platform**

Routing Engine	CLI Name	Processor	Memory	Hard Drive	Routing Platforms
RE-M40 (RE-200)	RE1	Intel Pentium 200 MHz	256 MB	6.4 GB	M40
RE-333 – 768	RE2	Intel Pentium2 333 MHz	768 MB 256 MB (M5, M10)	10 – 20 GB	M5, M10, M20, M40 (requires new housing)
RE-600 – 2048	RE3	Intel Pentium3 600 HHz	2048 MB	30 GB	M5, M10, M20, M40, M40e, M160, T320, T640
RE-1600 – 2048	RE4	Intel Pentium4 1.6 GHz	2048 MB	30 GB	M320, T320, T640
RE-400 – 256 + 512 Upgrade	RE5	Intel Celeron 400 MHz	768 MB	20 GB	M7i, M10i

## M7i and M10i Router Routing Engine

Figure 34 shows the Routing Engine that is supported in the M7i and M10i routing platforms. For the current Routing Engines supported on these routing platforms, see Figure 32.


**Figure 34: M7i and M10i Router Routing Engine**



### M5, M10, M20, M40, M40e, and M160 Router Routing Engines

Figure 35 shows the Routing Engines that are supported in the M5, M10, M20, M40, M40e, and M160 routing platforms. For the current Routing Engines supported on these routing platforms, see Figure 32 on page 128.


**Figure 35: M5, M10, M20, M40, M40e, and M160 Router Routing Engines**



### M320 Router Routing Engine

Figure 36 shows the Routing Engine that is supported in the M320 routing platform. For the current Routing Engines supported on these routing platforms, see Figure 32 on page 128.

**Figure 36: M320 Router Routing Engine**



### T320 Router and T640 Routing Node Routing Engine

Figure 37 shows the Routing Engine that is supported in the M320 routing platform. For the current Routing Engines supported on these routing platforms, see Figure 32 on page 128.

**Figure 37: T320 Router and T640 Routing Node Routing Engine**




Figure 38 shows the Routing Engine location in the M5, M10, and M20 Internet routers.

### Routing Engine Locations

This section shows where the Routing Engines are installed in each Routing Platform. This section includes the following locations:


- M5, M10, and M20 Router Routing Engines Location on page 131
- M7i and M10i Router Routing Engine Location on page 131
- M40 Router Routing Engine Location on page 132
- M40e and M160 Router Routing Engine Location on page 133
- M320 Router Routing Engine Location on page 134
- T320 Router and T640 Routing Node Routing Engine Location on page 134



### M5, M10, and M20 Router Routing Engines Location

Figure 38 shows the Routing Engine location in the M5, M10, and M20 routing platforms.


**Figure 38: M5, M10, and M20 Router Routing Engine Location**



### M7i and M10i Router Routing Engine Location

Figure 39 shows the Routing Engine location in the M7i and M10i routers.


**Figure 39: M7i and M10i Router Routing Engine Location**



## M40 Router Routing Engine Location

Figure 40 shows the location of the Routing Engine on the M40 router.

**Figure 40: M40 Router Routing Engine Location**



On the M40 Internet router, the Routing Engine module resides in a metal housing at the back of the chassis, below the fans, in a compartment behind the card cage (see Figure 40).

The M40 router supports three Routing Engine models: RE-M40 (RE1), RE-333 (RE2), and RE-600 (RE3). See Table 32 on page 128.

All M40 routers shipped before mid-2001 had RE-M40 Routing Engines. All M40 routers shipped after mid-2001 have the RE-333 Routing Engine and housing. You could also upgrade to the RE-600 (RE3) Routing Engine.

The RE-333 and the RE-600 Routing Engines share the same housing, which is different from the RE-M40. Therefore, if you want to upgrade from an RE-M40 to an RE-333 or RE-600, you must also upgrade the Routing Engine housing.



**NOTE:** Effective July 15, 2001, the RE-M40 Routing Engine was replaced by the RE-333 Routing Engine, which was made available with JUNOS software, release 4.2. After July 15, 2004, the RE-M40 Routing Engine is no longer supported. See “Routing Engine Characteristics Per Routing Platform” on page 128.

See also the End-of-sale and End-of-service Announcement for the M40 routing platform and products at <https://www.juniper.net/support/eol/>.


If you upgrade the Routing Engine housing, the PCMCIA card slot is not accessible and you must use the LS-120 PC card. If you want to install a new version of the JUNOS software, you must use the LS-120 drive.

You can replace the entire Routing Engine housing or just the Routing Engine.

### M40e and M160 Router Routing Engine Location

Figure 41 shows the Routing Engine location on the M40e and M160 router.

**Figure 41: M40e and M160 Router Routing Engine Location**




1689

### M320 Router Routing Engine Location

Figure 42 show the Routing Engine location on the M320 Internet router.

**Figure 42: M320 Router Routing Engine Location**

M320 router rear




### T320 Router and T640 Routing Node Routing Engine Location


Figure 43 shows the Routing Engine location on the T320 router and T640 routing node.

**Figure 43: T320 Router and T640 Routing Node Routing Engine Location**

T320 router rear



T640 routing node rear



## Routing Engine Redundancy

Table 33 shows the routing platforms that can have redundant Routing Engines. See “Routing Engine Component Companionship” on page 135.

**Table 33: Redundant Routing Engines**

Characteristic	M5/ M10	M7i	M10i	M20	M40	M40e/M160	M320/T320/ T640
Redundant Routing Engines			X works with HCM	X		X (Host Module) works with MCS	X (Host Subsystem) works with Control Board

## Routing Engine Component Companionship

On the M10i router, the Routing Engine works with its companion High-Availability Chassis Manager (HCM) to provide control and monitoring functions for router components. For more information about the HCM, see “Monitoring the HCM” on page 431. For more information about monitoring Redundant HCMs, see “Monitoring Redundant HCMs” on page 623.

For information about monitoring redundant Routing Engines, see “Host Redundancy Overview” on page 463 and “Monitoring Redundant Routing Engines” on page 491.

On the M40e and M160 routers, the host module provides the routing and system management functions. The host module consists of the Routing Engine and the Miscellaneous Control Subsystem (MCS). For more information about the host module, see “Monitoring the Host Module” on page 341. For more information about the MCS, see “Monitoring the MCS” on page 359.

On the M320 router, T320 router, and T640 routing node, the host subsystem provides the routing and system management functions. The host subsystem consists of the Routing Engine and the Control Board. For more information about the host subsystem, see “Monitoring the Host Subsystem” on page 289. For information about the Control Boards, see “Monitoring the Control Board” on page 301.

For more detailed information about the Routing Engine, see the appropriate router hardware guide.

## Routing Engine Boot Devices

Generally the router boots on the primary boot device, which is the flash disk. This device contains the current router configuration and the last three committed configurations in the `juniper.conf`, `juniper.conf.1.gz`, `juniper.conf.2.gz`, and `juniper.conf.3.gz` files, respectively. These files are located in the `/config` directory.

If the flash disk fails, the router attempts to boot from the hard disk, which is the alternate boot device.

If a removable media is installed when the router boots, the router attempts to boot the image on it. If the booting fails, the router tries the flash drive and then the hard disk.

If the router boots from an alternate boot device, the JUNOS software displays a message indicating this when you log in to the router. For example, this message shows that the software booted from the hard disk (*/dev/ad2s1a*):

```
login: username
Password: password
Last login: date on terminal

— JUNOS 6.4 R1 built date
—
— NOTICE: System is running on alternate media device (/dev/ad1).
```

## Routing Engine Storage Media

The router has three forms of storage media:

- Flash drive, which is a nonrotating drive. When a new router is shipped from the factory, the JUNOS software is preinstalled on the flash drive.
- Hard disk, which is a rotating drive. When a new router is shipped from the factory, the JUNOS software is preinstalled on the hard disk. This drive is also used to store system log files and diagnostic dump files.
- Removable media, either a PC card or an LS-120 floppy disk. The removable media that ships with each router contains a copy of the JUNOS software.

Table 43 on page 154 shows the storage media device names (as of JUNOS release 5.x and above) by Routing Engine type.

- See Also**
- “Host Redundancy Overview” on page 463
  - “Monitoring Redundant Routing Engines” on page 491

## Monitoring the Routing Engine Status

---

For information about conditions that trigger Routing Engine alarms, see “Display the Current Router Alarms” on page 61.

**Steps To Take** To monitor the Routing Engine status, follow these steps:

1. Check the Detailed Routing Engine Status on page 137
2. Check the Routing Engine LEDs on page 138

## Step 1: Check the Detailed Routing Engine Status

**Action** To display a detailed status of the Routing Engine, use the following JUNOS CLI operational mode command:

```
user@host> show chassis routing-engine
```

**Sample Output**

```
user@host> show chassis routing-engine
Routing Engine status
Slot 0
  Current state: Master
  Election priority: Master
  Temperature          41 C / 105 degrees F
  DRAM                 765 Mbytes
  CPU utilization
    User               0 percent
    Background         0 percent
    Kernel             0 percent
    Interrupt          0 percent
    Idle               100 percent
  Serial ID            39000004f8bdec01
  Start time           2000-01-04 22:02:58 UTC
  Uptime               14 hours, 45 minutes, 40 seconds
  Load averages
    1 minute           0.05
    5 minute           0.04
    15 minute          0.01

Slot 1
  Current state      Backup
  Election priority  Backup (default)
  Temperature        41 C / 105 degrees F
  DRAM               765 Mbytes
  CPU utilization
    User             0 percent
    Background       0 percent
    Kernel           0 percent
    Interrupt        2 percent
    Idle             98 percent
  Serial ID          f2000004f903a801
  Start time         2000-01-04 01:28:02 UTC
  Uptime             20 hours, 38 minutes, 1 seconds
```

**What It Means** The command output displays the Routing Engine slot number, current state (**Master**, **Backup**, or **Disabled**), election priority (**Master** or **Backup**), and the airflow temperature. The command output also displays the total DRAM available to the Routing Engine processor, the CPU utilization percentage, and the Routing Engine serial number for the slot. The command output displays when the Routing Engine started running, how long the Routing Engine has been running, and the time, uptime, and load averages for the last 1, 5, and 15 minutes.

Check the **Uptime** to ensure that the Routing Engine has not rebooted since it started running.

**Alternative Actions** (For M7i, M10i, M40e, M160, M320, and T320 routers and the T640 routing node)  
To check the status and temperature of the Routing Engines, use the following CLI command:

```
user@host> show chassis environment routing-engine
```

```
user@host> show chassis environment routing-engine
Route engine 0 status:
  State:                Present Master
  Temperature:          0 degrees C / 32 degrees F
Route engine 1 status:
  State:                Present
```

The command output displays the Routing Engine slot number, operating state, temperature, and whether it is operating as the master or backup. The state can be **Present** or **Absent**.

To check the status and temperature of a particular Routing Engine, use the following CLI command:

```
user@host> show chassis environment routing-engine slot
```

## **Step 2: Check the Routing Engine LEDs**

**Steps To Take** To check the Routing Engine status LEDs, do one of the following:

1. Check the M7i Routing Engine LEDs on page 139
2. Check the M10i Router Routing Engine LEDs on page 139
3. Check the M20 Router Routing Engine LEDs on page 140
4. Check the M40 Router Routing Engine LEDs on page 142
5. Check the M40e and M160 Router Routing Engine LEDs on page 143
6. Check the M320 Router Routing Engine LEDs on page 144
7. Check the T320 Router Routing Engine LEDs on page 144
8. Check the T640 Routing Node Routing Engine LEDs on page 145



## Check the M7i Routing Engine LEDs

**Action** Check the four LEDs located on the Routing Engine faceplate. A green LED labeled HDD, a blue LED labeled MASTER, a red LED labeled FAIL, and a green LED labeled ONLINE indicate Routing Engine status. Table 34 describes the LED states.

**Table 34: M7i and M10i Router Routing Engine LED States**

Label	Color	State	Description
HDD	Green	Blinking	There is read/write activity on the PC card.
MASTER	Blue	On steadily	Routing Engine is functioning as master.
FAIL	Red	On steadily	Routing Engine is not operational.
ONLINE	Green	On steadily	Routing Engine is running normally.

## Check the M10i Router Routing Engine LEDs

The M10i router Routing Engine has four LEDs indicating Routing Engine status: a green LED labeled HDD, a blue LED labeled MASTER, a red LED labeled FAIL, and a green LED labeled ONLINE.

**Figure 44: M10i Routing Engine LEDs**




Table 35 describes the M10i router Routing Engine LEDs.

**Table 35: M10i Router Routing Engine LEDs and Buttons**

Label	Color	State	Description
HDD	Green	Blinking	There is read/write activity on the PC card.
MASTER	Blue	On steadily	Routing Engine is functioning as master.
FAIL	Red	On steadily	Routing Engine is not operational.
OFFLINE	Green	On steadily	Routing Engine is running normally.

You can see the Routing Engine LEDs on the Routing Engine panel located on the back of the router.

### Check the M20 Router Routing Engine LEDs

The M20 router Routing Engine LEDs and buttons are located near the middle of the craft interface above and below the Juniper Networks logo (see Figure 45).

**Figure 45: M20 Router Craft Interface Routing Engine LEDs and Buttons**








Table 36 describes the M20 router Routing Engine LEDs.

**Table 36: M20 Router Routing Engine LEDs and Buttons**

Label	Shape	Color	State	Description
MASTER		Blue	On steadily	Routing Engine is functioning as master.
ONLINE		Green	On steadily	Routing Engine has successfully booted and is running normally.
OFFLINE		Amber	On steadily	Routing Engine is not operational, or is in reset mode.
RE0, RE1		—	—	Press to take the Routing Engine offline.

You can see the Routing Engine LEDs on the craft interface or on the Routing Engine panel located on the back of the router (see Figure 46).

**Figure 46: M20 Router Routing Engine Panel**




Figure 37 describes the Routing Engine panel LEDs.

**Table 37: Routing Engine Panel LEDs**

Label	Color	State	Description
OFFLINE	Amber	On steadily	Routing Engine is not operational or is in reset mode.
ONLINE	Green	On steadily	Routing Engine is running normally.
MASTER	Blue	On steadily	Routing Engine is functioning as master.

Check the M40 Router Routing Engine LEDs

Check the Routing Engine LEDs on the bottom right of the craft interface. A red Fail LED and a green OK LED indicate the status of the Routing Engine. The green OK LED should light steadily. Figure 47 shows the Routing Engine LEDs.

Figure 47: M40 Router Craft Interface Routing Engine LEDs







Table 38 describes the Routing Engine LED states.

Table 38: M40 Router Routing Engine LEDs

Label	Shape	Color	State	Description
OK		Green	On steadily	Presence of the Routing Engine is detected by the System Control Board (SCB).
OK		Green	Blinking	Routing Engine is starting up.
FAIL		Red	On steadily	Presence of the Routing Engine is not detected by the SCB, or the Routing Engine is not operational.

### Check the M40e and M160 Router Routing Engine LEDs

Check the host module LEDs on the upper right of the craft interface. Three LEDs—one green **MASTER**, one green **ONLINE**, and one red **OFFLINE**—indicate the status of each host module. The LEDs marked **HOST0** show the status of the Routing Engine in slot **RE0** and the MCS in slot **MCS0**. The LEDs marked **HOST1** show the status of the Routing Engine in slot **RE1** and the MCS in slot **MCS1**.

Figure 48 shows the host module LEDs on the M40e and M160 router craft interface.

**Figure 48: M40e and M160 Router Redundant Host Module LEDs**




Table 39 describes the host module LEDs.


**Table 39: M40e and M160 Router Host Module LEDs**

Label	Shape	Color	State	Description
MASTER	○	Green	On steadily	Host module (Routing Engine and MCS) is functioning as master.
ONLINE	○	Green	On steadily	Host module is present and operational.
			Blinking	Host module is starting up.
OFFLINE	○	Red	On steadily	Host module is not present, or is present but not operational.

### Check the M320 Router Routing Engine LEDs

Figure 49 shows the host module LEDs on the M320 router craft interface.

**Figure 49: M320 Router Redundant Host Module LEDs**



Each host subsystem has three LEDs, located in the middle of the craft interface, that indicate status. The LEDs labeled RE0 show the status of the Routing Engine in slot RE0 and the Control Board in slot CB0. The LEDs labeled RE1 show the status of the Routing Engine in slot RE1 and the Control Board in slot CB1. Table 40 describes the functions of the host subsystem LEDs.


**Table 40: M320 Router Host Subsystem LEDs**

Label	Color	State	Description
FAIL	Red	On steadily	Host module is offline.
OK	Green	On steadily	Host module is online and functioning normally.
MASTER	Green	On steadily	Host module is functioning as master.

### Check the T320 Router Routing Engine LEDs

Figure 50 shows the host module LEDs on the T320 router craft interface.

**Figure 50: T320 Router Redundant Host Module LEDs**



Each host subsystem has three LEDs, located on the upper right of the craft interface, which indicate status. The LEDs labeled HOST0 show the status of the Routing Engine in slot RE0 and the Control Board in slot CB0. The LEDs labeled HOST1 show the status of the Routing Engine in slot RE1 and the Control Board in slot CB1.

Table 41 describes the functions of the host subsystem LEDs.


**Table 41: T320 Router Host Subsystem LEDs**

Label	Color	State	Description
OK	Green	On steadily	Host module is online and functioning normally.
FAIL	Red	On steadily	Host module is offline.
MASTER	Green	On steadily	Host module is functioning as master.

### Check the T640 Routing Node Routing Engine LEDs

Figure 51 shows the host module LEDs on the T640 routing node craft interface.

**Figure 51: T640 Routing Node Redundant Host Module LEDs**



Each host subsystem has three LEDs, located on the upper right of the craft interface, which indicate status. The LEDs labeled **HOST0** show the status of the Routing Engine in slot **RE0** and the Control Board in slot **CB0**. The LEDs labeled **HOST1** show the status of the Routing Engine in slot **RE1** and the Control Board in slot **CB1**. Table 42 describes the functions of the host subsystem LEDs.

**Table 42: T640 Routing Node Host Subsystem LEDs**

Label	Color	State	Description
OK	Green	On steadily	Host module is online and functioning normally.
FAIL	Red	On steadily	Host module is offline.
MASTER	Green	On steadily	Host module is functioning as master.

**Step 3: Check the Redundant Routing Engine Status from the Craft Interface CLI Output**

**Action** To view the Routing Engine status from the craft interface, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output** user@host> show chassis craft-interface

For M10i routers:

```
Red alarm:          LED off, relay off
Yellow alarm:       LED on, relay on
Routing Engine OK LED: On
Routing Engine fail LED: Off
```

```
FPCs      0  1
-----
```

```
Green     *  *
```

```
Red       .  .
```

LCD screen:

```
+-----+
|waddle  |
|1 Alarm active|
|Y: Backup RE Active|
|        |
+-----+
```

For M20 routers:

```
Red alarm:          LED off, relay off
Yellow alarm:       LED off, relay off
Routing Engine OK LED: On
Routing Engine fail LED: Off
```

```
FPCs      0  1  2  3
-----
```

```
Green     .  *  *  .
```

```
Red       .  .  .  .
```

LCD screen:

```
+-----+
|myrouter|
|Up: 5+00:16:57|
|        |
|0pps Load|
+-----+
```

For M40e/M160 routers:

FPM Display contents:

```
+-----+
|myrouter|
|1 Alarm active|
|Y: PEM 0 Absent|
|        |
+-----+
```



## Front Panel System LEDs:

Host	0	1
-----		
OK	*	*
Fail	.	.
Master	*	.

For M320 routers:

## FPM Display contents:

[...Output truncated...]

## Front Panel System LEDs:

Routing Engine	0	1
-----		
OK	*	.
Fail	.	.
Master	*	.

[...Output truncated...]

For T320 routers:

## FPM Display contents:

[...Output truncated...]

## Front Panel System LEDs:

Routing Engine	0	1
-----		
OK	*	.
Fail	.	.
Master	*	.

[...Output truncated...]

For T640 routing nodes:

## FPM Display contents:

```

+-----+
|bananas-re0|
|Up: 7+00:20|
|           |
|Fans OK    |
+-----+

```

## Front Panel System LEDs:

Routing Engine	0	1
-----		
OK	*	.
Fail	.	.
Master	*	.

## Front Panel Alarm Indicators:

-----

Red LED .

Yellow LED .

Major relay .

Minor relay .

```

Front Panel FPC LEDs:
FPC    0    1    2    3    4    5    6    7
-----
Red     .    *    .    .    .    .    .    .
Green  *    .    *    *    .    *    .    .

CB LEDs:
      CB    0    1
-----
Amber   .    .
Green  *    .
Blue   *    .

SCG LEDs:
      SCG    0    1
-----
Amber   .    .
Green  *    *
Blue   *    .

SIB LEDs:
      SIB    0    1    2    3    4
-----
Red     .    .    .    .    .
Green  *    *    *    *    *

```

**What It Means** The M10i router craft interface command output displays the LED status of the master Routing Engine, indicating whether the **OK** and **Fail** LEDs are **on** or **off**. It also displays that the backup Routing Engine is active.

The M20 router craft interface command output displays the LED status of the master Routing Engine, indicating whether the **OK** and **Fail** LEDs are **on** or **off**.

The M40e and M160 router craft interface command output also displays the LED status of both the master and backup host modules that include the master and backup Routing Engines. By default, the master host module (**Host 0**) has components installed in slots **RE0** and **MCS0**; the backup host module (**Host 1**) has components installed in slots **RE1** and **MCS1**.

The T640 routing node craft interface command output indicates that **RE0** is the master Routing Engine, and that it is active. The status under the backup Routing Engine (**RE1**) has no indicators.

## Verifying Routing Engine Failure



**NOTE:** Routing Engine failures can include compact flash failure and hard disk failure. If the Routing Engine has a compact flash failure and hard disk failure at the same time, you will not be able to boot up the Routing Engine.

The following sections describe how to check for the following failure conditions:



**NOTE:** The M7i and M10i routers by default come with no compact flash.

- Steps To Follow**
1. Check Core Files If the Routing Engine Reboots on page 149
  2. Example of Boot Messages If Routing Engine Fails to Boot on page 150
  3. Check for Compact Flash Media and Hard Disk Failure on page 150

### Step 1: Check Core Files If the Routing Engine Reboots

#### List the Core Files Generated After A Crash Occurs

A vmcore file is only generated if the Routing Engine has a kernel crash. Kernel crashes can be generated by such things as a bug in the kernel software or bad memory. If the router has a kernel crash, the vmcore.<n> file is generated while the Routing Engine comes back up.

**Action** A vmcore file is always saved in /var/crash/. To view the core file that is generated when a crash occurs, use the following CLI command:

```
user@host> file list /var/crash/ detail
```

**Sample Output**

```
user@host> file list /var/crash/ detail
/var/crash/:
total 892856
-rw-r--r--  1 root  wheel           2 May 14  2004 bounds
-rw-r--r--  1 root  wheel 11959693 Oct 13  2003 kernel.0
-rw-r--r--  1 root  wheel 10114127 May 14  2004 kernel.1
-rw-r--r--  1 root  wheel           5 Feb 26  1997 minfree
-rw-----  1 root  wheel 805240832 Oct 13  2003 vmcore.0
-rw-----  1 root  wheel 805240832 May 14  2004 vmcore.1
```

**What It Means** The command output lists the vmcore.<n> files that have been generated.

## Display the Messages Log File After A Crash Occurs

**Action** You might see the following in the `/var/log/messages` file after the router comes back up after a kernel crash occurred. To view the `messages` log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Mar  9 12:22:02 host savecore: Router crashed....
Mar  9 12:22:02 host savecore: reboot after panic: Loss of soft watchdog Mar  9
12:22:02 host savecore: system went down at Sun Mar  9 12:22:02 2003 Mar  9
12:22:02 host savecore: Selective dump will be saved now
```

**What It Means** A kernel crash occurred and a core file has been generated.

## Example of When No Core File Is Generated

When a power outage occurs, no kernel crash core file is generated. To view the `messages` log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Aug 15 15:35:58 host /kernel: checking for core dump...
Aug 15 15:35:59 host /kernel: savecore: Router rebooted. Cause unknown....
Aug 15 15:35:59 host savecore: Router rebooted. Cause unknown....
```

**What It Means** The kernel checks for a core dump file when the router reboots.

## Example of Boot Messages If Routing Engine Fails to Boot

The following example shows boot messages that occur when a Routing Engine remains in a constant boot loop. In this condition, contact JTAC for further analysis and assistance.

```
Trying to boot from PCMCIA Flash Card ...
Trying to boot from Compact Flash ...
Trying to boot from Ethernet ...
```

## Step 2: Check for Compact Flash Media and Hard Disk Failure

If the Routing Engine has a compact flash failure, the router boots from the hard disk. When you log in to the router, the JUNOS software CLI will indicate that the router has booted from alternate media.

If the Routing Engine has a hard drive failure, the router boots from the compact flash as usual. However, the router cannot write to the hard drive.

### When the Compact Flash Is Removed from the Boot List

You can have a compact flash error when conditions, such as a HARD READ error occurs. When the compact flash is removed from the boot list, the following message displays you log in to the router:

```

Login: user

--- JUNOS 6.0R1.6 built 2003-09-24 04:06:27 UTC
---
--- NOTICE: System is running on alternate media device    (/dev/ad1s1a).
---

user@host>

```

**Action** Check to see which file system is mounted by using the following CLI command:

```
user@host> show system storage
```

**Sample Output**

```

user@host> show system storage
Filesystem      512-blocks      Used      Avail Capacity Mounted on
/dev/ad1s1a      218690      56502      144694      28% /
devfs            32          32          0      100% /dev/
/dev/vn0         18316      18316          0      100% /packages/mnt/jbase
devfs            32          32          0      100% /dev/
/dev/vn1         45448      45448          0      100%
/packages/mnt/jkernel-6.0R1.6
/dev/vn2         20532      20532          0      100%
/packages/mnt/jpfe-M160-6.0R1.6
/dev/vn3          3580          3580          0      100%
/packages/mnt/jdocs-6.0R1.6
/dev/vn4         20728      20728          0      100%
/packages/mnt/jroute-6.0R1.6
/dev/vn5          9256          9256          0      100%
/packages/mnt/jcrypto-6.0R1.6
mfs:139          4064278          2      3739134          0% /tmp
/dev/ad1s1e       24234          4      22292          0% /config
procfs           8            8            0      100% /proc
/dev/ad1s1f      52492630     7988510     40304710      17% /var

```

**What It Means** The command output will not show ad0 (the compact-flash) mounted, but instead, ad1 (the hard disk) has the root file system mounted.

### Determine Why Compact Flash Did Not Mount

**Action** To determine why the compact-flash did not get mounted, use the following CLI command:

```

user@host> show system boot-messages | match "ad0|ad1"

user@host> show system boot-messages | match "ad0|ad1"
ad0: not attached, missing in Boot List
ad1: 28615MB <FUJITSU MHS2030AT> [58140/16/63] at ata0-slave using BIOSDMA
Mounting root from ufs:/dev/ad1s1a

```

**What It Means** The command output shows that the compact flash (ad0) was removed from the boot list.

### When the Hard Disk Is Removed from the Boot List

The following boot messages list on the console shows symptoms that signify a hard disk failure. These messages are not in the `boot-messages` log file.

**Sample Output**

```
/dev/ad1s1f: CAN'T CHECK FILE SYSTEM.
/dev/ad1s1f: UNEXPECTED INCONSISTENCY; RUN fsck MANUALLY.
Can't open /dev/ad1s1f: Device not configured
WARNING:
WARNING: /var mount failed, building emergency /var
WARNING:
dumpon: sysctl: kern.dumpdev: Device not configured
mgd: commit complete
dumpon: sysctl: kern.dumpdev: Device not configured
mgd: commit complete
```

**What it Means** The boot messages show that the hard disk (ad1) was removed from the boot list (using JUNOS, release 6.1R1.4).

### Verify That the Hard Disk Did Not Mount

**Action** To verify that the hard disk (ad1) did not get mounted, use the following CLI command:

```
user@host> show system storage
```

**Sample Output** The following sample output was taken from a RE-333 Routing Engine.

```
user@host> show system storage
```

Filesystem	512-blocks	Used	Avail	Capacity	Mounted on
/dev/ad0s1a	218690	60294	140902	30%	/
devfs	32	32	0	100%	/dev/
/dev/vn0	20044	20044	0	100%	/packages/mnt/jbase
devfs	32	32	0	100%	/dev/
/dev/vn1	51920	51920	0	100%	
/packages/mnt/jkernel-6.1R1.4					
/dev/vn2	22328	22328	0	100%	
/packages/mnt/jpfe-M160-6.1R1.4					
/dev/vn3	3844	3844	0	100%	
/packages/mnt/jdocs-6.1R1.4					
/dev/vn4	23328	23328	0	100%	
/packages/mnt/jroute-6.1R1.4					
/dev/vn5	8820	8820	0	100%	
/packages/mnt/jcrypto-6.1R1.4					
mfs:139	127006	16914	99932	14%	/tmp
/dev/ad0s1e	24234	28	22268	0%	/config
procfs	8	8	0	100%	/proc

**What It Means** The command shows that the hard disk (ad1) is not mounted. Instead, /var now exists only in the swap partition (mfs:139), so any contents saved to /var will not be saved at the next reboot.

```
user@host> start shell
user@host% ls -l /
total 47
-rw-r--r-- 1 root wheel 4735 Mar 31 2001 COPYRIGHT
dr-xr-xr-x 2 root wheel 512 Jan 20 2004 altconfig
dr-xr-xr-x 2 root wheel 512 Jan 20 2004 altroot
drwxr-xr-x 2 root wheel 512 Dec 29 12:00 bin
```

```

dr-xr-xr-x 3 root wheel 512 Feb 4 23:16 boot
drwxr-xr-x 3 root wheel 512 Feb 3 18:08 config
dr-xr-xr-x 4 root wheel 2084 Feb 4 23:18 dev dr-xr-xr-x 7 root wheel 1536
Feb 4 23:19 etc
lrwxr-xr-x 1 root wheel 17 Dec 29 12:02 kernel -> /packages/jkernel
dr-xr-xr-x 2 root wheel 512 Jan 20 2004 mnt
drwxr-xr-x 2 root wheel 512 Feb 3 21:16 modules
drwxr-xr-x 3 root wheel 1536 Feb 3 21:19 packages
dr-xr-xr-x 1 root wheel 512 Feb 4 23:29 proc
dr-xr-xr-x 2 root wheel 512 Feb 3 21:15 root
dr-xr-xr-x 3 root wheel 1536 Feb 3 21:15/sbin
drwxrwxrwt 3 root wheel 512 Feb 4 23:19 tmp
dr-xr-xr-x 8 root wheel 512 Dec 29 12:00 usr
lrwxr-xr-x 1 root wheel 8 Feb 4 23:18 var -> /tmp/var

```

**What It Means** The example shows that `var` has a symbolic link to the `/tmp/var` directory. It resides under the `/tmp/var` directory, and is mounted on the `mfs` partition.

### Verify That the Hard Disk Is Missing from The Boot List

**Action** To verify that the hard disk (`ad1`) is missing from the boot list, use the following CLI command:

```
user@host> show system boot-messages | match "ad0|ad1"
```

**Sample Output**

```

user@host> show system boot-messages | match "ad0|ad1"
ad0: 122MB <SanDisk SDCFB-128> [980/8/32] at ata0-master using PIO4
ad1: not attached, missing in Boot List
Mounting root from ufs:/dev/ad0s1a

```

**What It Means** The device is taken out of the boot list because of an error condition, such as a `HARD READ` error.

### View Alarms When Media Is Removed from the Boot List

**Action** To display an alarm that is generated when media (compact flash or hard disk) is removed from the boot list, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```

user@host> show chassis alarms
1 alarms currently active
Alarm time          Class  Description
2005-02-04 23:19:27 CET  Major  hard-disk missing in Boot List

```

**What It Means** When the router is operational and the hard disk is removed from the boot list, a minor yellow alarm is generated. When the router is rebooted and the hard disk is still removed from the boot list, a red major alarm is generated.

**What It Means** The command output displays a major alarm indicating what media is missing from the boot list and the time and date when the event occurred.

### Step 3: Understand What Happens When Memory Failures Occur

Most Juniper Networks Routing Engines support Error Checking and Correction (ECC) protected memory. There are two types of memory errors: single-bit and multiple-bit.

A single-bit error is when a single 0 or 1 bit is incorrect. The system detects and corrects single-bit errors, then logs the event in the `/var/log/eccd` file. If there are persistent single-bit errors, the Routing Engine controller reboots the Routing Engine. Persistent single-bit errors could be a symptom of bad RAM.

Multiple-bit errors are when multiple bits are incorrect. By default, if a multiple-bit error is detected, a nonmaskable interrupt (NMI) is generated to interrupt the Routing Engine and panic the kernel causing the router to subsequently reboot. The Routing Engine panics the kernel, and leaves a vmcore file. Multi-bit parity error detection was implemented in JUNOS software release 5.3 and above.

### Step 4: Check the Router File System and Boot Disk

**Action** Table 43 specifies the storage media by Routing Engine type. The device names are displayed when the router boots. To display the Routing Engine type on some routers, use the `show chassis hardware` CLI command.

**Table 43: Storage Media Device Names**

Storage Media	RE-M40 (RE1)	RE-400 (RE5)	RE-333 (RE2)/ RE-600 (RE3)	RE-1600 (RE4)
Flash drive	ad0	ad0	ad0	ad0
Hard disk	ad2	ad1	ad1	ad1
Removable media	afd0	ad3	ad3	ad3 and ad4

**Action** To check the router file system and on which disk the router booted, use the following CLI command:

```
user@host> show system storage
```

**Sample Output**

```
user@host> show system storage
Filesystem 1K-blocks    Used    Avail Capacity  Mounted on
/dev/ad0s1a 65687    26701    33732    44%      /
devfs        16        16         0    100%    /dev/
/dev/vn1     9310     9310         0    100%    /packages/mnt/jbase
/dev/vn2     8442     8442         0    100%
/packages/mnt/jkernel-5.0R5.1
/dev/vn3     11486    11486         0    100%    /packages/mnt/jpfe-5.0R5.1
/dev/vn4      5742     5742         0    100%    /packages/mnt/jroute-5.0R5.1
/dev/vn5      1488     1488         0    100%
/packages/mnt/jcrypto-5.0R5.1
/dev/vn6       792       792         0    100%    /packages/mnt/jdocs-5.0R5.1
mfs:181     762223        3    701243     0%      /tmp
/dev/ad0s1e  25263        7    23235     0%      /config
procfs        4         4         0    100%    /proc
/dev/ad1s1f 7156052  337194  6246374     5%      /var
```



**What It Means** The command output displays statistics about the amount of free disk space in the router's file systems, including the amount used, the amount available, and the percentage of system space being used. The values are displayed in 1024-byte (1 KB) blocks.

Filesystem is the name of the file system on which the Routing Engine booted. The command output also displays the directory to which the file system is mounted. During normal operation, the / and /config directories are from the compact flash drive and the /var directory is from the hard drive. If the router booted off the hard drive, the `show system storage` command will show all three directories on the hard drive. If the hard drive fails and the router booted off the compact flash drive, the `show system storage` command will show all three directories on the compact flash drive.

### Step 5: Display the Current Routing Engine Alarms

To display information about the conditions that trigger Routing Engine alarms for each router type, see "Display the Current Router Alarms" on page 61.



**NOTE:** An event may occasionally cause the Routing Engine not to boot and you will not be able to display the current alarms.

**Action** To display the current Routing Engine alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1 alarms currently active
Alarm time           Class  Description
2001-07-22 15:12:19 PDT Major  hard-disk missing in Boot List
2002-05-14 09:20:36 PDT Major  compact-flash missing in Boot List
2002-05-14 09:20:31 PDT Minor  Boot from alternate media
```

**What It Means** The command output displays the alarm time, severity level, and description.

### Step 6: Display Error Messages in the System Log File

**Action** To view Routing Engine error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output** For compact flash drive errors:

```
user@host> show log messages
Feb  3 07:58:17 host /kernel: ad0: HARD WRITE ERROR blk# 135783 status=51
error=10 Feb  3 07:58:17 host /kernel: ad0: HARD WRITE ERROR blk# 137633
status=51 error=10 Feb  3 07:58:47 host /kernel: ad0: HARD WRITE ERROR blk#
135731 status=51 error=10 Feb  3 07:58:47 host /kernel: ad0: HARD WRITE ERROR
blk# 135783 status=51 error=10 Feb  3 07:58:47 host /kernel: ad0: HARD WRITE
ERROR blk# 137633 status=51 error=10
```

For hard drive errors:

```
user@host> show log messages
Jun  3 12:00:28 router /kernel: ad1: WRITE command timeout - resetting
Jun  3 12:00:44 router /kernel: ata0: resetting devices ..
Jun  3 12:00:44 router /kernel: ata0: Succeeded in resetting devices.
Jun  3 12:00:28 router /kernel: ad1: WRITE command timeout - resetting
Jun  3 12:00:17 router /kernel: ata0: resetting devices ..
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. Use the **show log messages** CLI command to browse error messages that are generated at least 5 minutes before and after an event. You can also use the **show log messages | match "device-name"** command to view error messages that are specific to a device name. Use this information to diagnose a problem and to let JTAC know what error messages were generated and the router events prior to the event. For more information about system log messages, see the *JUNOS Software System Log Messages Reference*.

## Step 7: Document the Events Prior to the Failure

- Action** To document events that occurred prior to a Routing Engine failure, follow these steps:
1. Write down any events such as an abrupt router shutdown because of a power outage, a software upgrade, a configuration commit, or a system snapshot request.
  2. Write down any recovery procedures attempted. If the Routing Engine reported some errors on the hard drive but appeared to be working fine or a backup Routing Engine is available, it may not be necessary to recover.
  3. Turn on logging to your console to start capturing screen output. This is especially useful if a terminal server is connected to the Routing Engine console port.
  4. While you have screen capturing enabled, boot the Routing Engine and look at the router boot messages.

## Getting Routing Engine Hardware Information

**Steps To Take** To get hardware information for a failed Routing Engine, follow these steps:

1. Display Routing Engine Hardware Information on page 157
2. Locate the Routing Engine Serial Number ID Label on page 158

### Step 1: Display Routing Engine Hardware Information

**Action** To display the Routing Engine hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output** For an M20 router with two Routing Engines:

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis
Backplane        REV 03   710-001517   AA7915
Power Supply A   Rev 01   740-001465   000011         AC
Power Supply B   Rev 01   740-001465   000016         AC
Display          REV 04   710-001519   AE6019
Routing Engine 0                32000004f8ff1201 RE-2.0
Routing Engine 1 REV 01   740-003239   AARCH00        RE-2.0
[...Output truncated...]
```

For M40 router components:

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Backplane        REV 02   710-000073   S/N AA0053
Power supply A   Rev 2    740-000235   S/N 000042     DC
Maxicab          REV X1   710-000229   S/N AA0139
Minicab          REV X1   710-000482   S/N AA0201
[...Output truncated...]
```

**What It Means** The sample output for an M20 router displays the Routing Engine, slot number, and serial number, and indicates that it is present in the router. Give this information to JTAC if the Routing Engine fails.

The sample output for an M40 router shows that the maxicab is the (Motorola) Routing Engine, and the minicab is the Routing Engine and Packet Forwarding Engine interface.

On other routers, the Routing Engine serial number is located in the host hardware inventory line.

## Step 2: Locate the Routing Engine Serial Number ID Label

If the Routing Engine fails, you cannot see the Routing Engine hardware information when you use the `show chassis hardware` command. You must manually locate the serial number ID label on the component.

Some Routing Engines may have more than one serial number. Contact your Juniper Networks support representative if you need assistance in determining which serial number to provide.

**Action** Look on the Routing Engine for the serial number ID label.


### M7i Router Routing Engine Serial Number ID Label Location

The serial number ID label is located on the left side near the midplane connector.

### M10i Router Routing Engine Serial Number ID Label Location


The serial number ID label is located on the left side, near the back (see Figure 52).

**Figure 52: M10i Router Routing Engine Serial Number ID Label Location**




### Teknor Type 2 Routing Engine Serial Number ID Label Location

For all routers with a Type 2 (Teknor) Routing Engine, the serial number ID label is located on the top right side of the Routing Engine (see Figure 53 on page 159). If there are multiple labels on the Routing Engine, the label marked “Teknor Silicon Serial ID” is the correct serial number. The serial number ID label includes two serial numbers: a 16-digit number on the top and a 10-digit number on the bottom. Give both serial numbers to JTAC.

**Figure 53: Routing Engine Serial Number ID Label Location for All Routers****M40 Router Routing Engine Serial Number ID Label Location**


For M40 routers, the serial number that you use depends on whether you purchased the Routing Engine housing or just the Routing Engine. If you purchased the Routing Engine housing, the serial number is located on the maxicab, as shown in Figure 54. If you purchased the Routing Engine only, remove the Routing Engine and locate the serial number ID label, as shown in Figure 54. If there are multiple labels on the Routing Engine, the label marked “Teknor Silicon Serial ID” is the correct serial number.

**Figure 54: M40 Router Routing Engine Serial Number ID Label**

### M320 Router Serial Number ID Label Location

The serial number label is located on the right side of the top of the Routing Engine (see Figure 55).


**Figure 55: M320 Router Routing Engine Serial Number ID Label Location**



### T320 Router and T640 Routing Node Serial Number ID Label Location

For the T320 router and T640 routing node, the serial number ID label is located on the right side of the top of the Routing Engine (see Figure 56).

**Figure 56: T320 Router and T640 Routing Node Routing Engine Serial Number ID Label**



## Removing a Routing Engine

---

**Action** To replace the Routing Engine, see the appropriate router hardware guide. See also, “Replacing a Redundant Routing Engine” on page 506..



**NOTE:** The M5 and M10 routers have a cover over the Routing Engine. The M40e and M160 routers have a cover over all the rear chassis components.

---





## Chapter 15

# Monitoring FPCs

You monitor and maintain Flexible PIC Concentrators (FPCs) to connect Physical Interface Cards (PICs) to the rest of the router so that incoming packets are forwarded across the midplane to the appropriate destination ports. (See Table 44.)

**Table 44: Checklist for Monitoring FPCs**

Monitor FPC Tasks	Command or Action
<b>Understanding FPCs on page 164</b>	
■ FPC Numbering on page 165	
<b>Checking the FPC Status on page 166</b>	
1. Check FPC Status and Utilization on page 166	<code>show chassis fpc</code>
2. Check FPC Status and Uptime on page 167	<code>show chassis fpc detail fpc-slot</code>
3. (M40e, M160, M320, and T320 routers and T640 routing node only) Check FPC Status and Temperature on page 167	<code>show chassis environment fpc fpc-slot</code>
4. Check the FPC LED States on page 168	<code>show chassis craft-interface</code> Or, physically check the FPC LEDs on the Front Panel Module (FPM).
<b>Checking for FPC Alarms on page 169</b>	
1. Display the Current FPC Alarms on page 169	<code>show chassis alarms</code>
2. Display FPC Error Messages in the System Log File on page 170	<code>show log messages   match "fpc  kernel   tnp"</code>
3. Display FPC Error Messages in the Chassis Daemon Log File on page 171	<code>show log chassisd   match fpc</code>
<b>Verifying FPC Failure on page 173</b>	
1. Document Events Prior to the FPC Failure on page 173	Document a software upgrade, hardware upgrade, or reset.
2. Check the FPC Installation on page 173	Check that the FPC is seated in the slot. Try to bring the FPC online.
3. Check the FPC Fuses on page 174	The fuses for the and FPCs are located in the rear of the midplane behind the power supply in slot PEM0.
4. Take the FPC Offline on page 175	Press the offline button for approximately 3 seconds.
5. Perform an FPC Swap Test on page 176	Replace the FPC with one that you know works.
6. Display the FPC Software Version Information on page 176	<code>show version brief</code>
7. Display the FPC Hardware Information on page 177	<code>show chassis hardware</code>

Monitor FPC Tasks	Command or Action
8. Locate the FPC Serial Number ID Label on page 177	<ul style="list-style-type: none"> <li>■ M20 Internet router—With the FPC in horizontal position, look on the top back right of the FPC.</li> <li>■ M40 Internet router—With the FPC in vertical position, look on the back left side of the FPC.</li> <li>■ M40e and M160 routers—With the FPC in vertical position, look on the center right side of the FPC.</li> <li>■ For M320 routers—On an FPC3, the serial number ID label is located on the center of the right side. On an FPC2, the serial number label is located on the top PIC slot.</li> <li>■ For T320 routers—On an FPC3, the serial number ID label is located on the center of the right side. On an FPC1 and FPC2, the serial number ID label is located near the top PIC slot.</li> <li>■ For T640 routing nodes—On an FPC3, the serial number label is located on the center of the right side. On an FPC2, the serial number label is located near the top PIC slot.</li> </ul>
Replacing an FPC on page 181	See “Return the Failed Component” on page 86. Follow the procedure in the appropriate router hardware guide.

## Understanding FPCs

**Purpose** Inspect the FPCs to ensure that they connect PICs to the rest of the router so that incoming packets are forwarded across the midplane to the appropriate destination port.

**What Is an FPC** The FPC is a component of the Packet Forwarding Engine. FPCs house the various PICs used in the router.

The FPCs installed in the router depend on the platform and the PICs needed. Table 45 provides some FPC characteristics for each router type.


For a listing of available FPCs and supported PICs, see the appropriate router hardware guide and router PIC guide.

**Table 45: FPC Characteristics Per Routing Platform**

FPC Characteristic	M5/ M10	M7i	M10i	M20	M40	M40e	M160	M320	T320	T640
FPC types supported per router	FPC built into the FEB	FPC built into the router	FPC built into the router	FPC	FPC	M40e-FPC1, M40e-FPC2	FPC1, FPC2	FPC1, FPC2, FPC3	FPC1, FPC2, FPC3	FPC2, FPC3
FPC slots per router	1/2	1	2	4	8	8	8	8	8	8

Figure 57 shows the location and numbering of the FPCs in each router platform.

**Figure 57: FPC Numbering**



FPCs are hot-insertable and hot-removable. You can remove and replace them without powering down the router or disrupting the routing functions.

**See Also** “Monitoring PICs” on page 183

## Checking the FPC Status

**Steps To Take** To check the FPC status, follow these steps:

1. Check FPC Status and Utilization on page 166
2. Check FPC Status and Uptime on page 167
3. Check FPC Status and Temperature on page 167
4. Check the FPC LED States on page 168

### Step 1: Check FPC Status and Utilization

**Action** To display brief status and utilization information for all FPCs installed in the router, use the following JUNOS command-line interface (CLI) operational mode command:

```
user@host> show chassis fpc
```

**Sample Output** user@m160> show chassis fpc

Temp	CPU Utilization (%)	Memory	Utilization (%)				
Slot	State	(C)	Total	Interrupt	DRAM (MB)	Heap	Buffer
0	Online	43	3	0	32	1	39
1	Online	47	3	0	32	1	39
2	Online	42	3	0	32	1	40
3	Online	40	4	0	32	1	39
4	Online	41	4	0	32	1	39
5	Online	42	0	0	32	1	39
6	Empty	0	0	0	0	0	0
7	Empty	0	0	0	0	0	0

**What It Means** Use the `show chassis fpc` command to identify whether there is a problem with any of the FPCs installed in the router. The command output displays a brief status of all the FPCs installed in the router. The state can be **online**, **dead**, **diag**, **dormant**, **empty**, **online**, **probed**, or **probe-wait**. If the FPC state is **dead**, an alarm occurs. For more detailed information about the FPC states, see the *JUNOS Protocols, Class of Service, and System Basics Command Reference*.

The temperature is that of the air flowing past the FPC. If the temperature is too high, an alarm occurs.

The CPU and memory information is the total percentage of CPU being used by the FPC processor, the total CPU being used by the FPC processor, the percentage of CPU being used for interrupts, and the total DRAM available to the FPC processor. The percentage of heap space (dynamic memory) reflects the buffer space being used by the FPC processor. If the heap space exceeds 80 percent, there might be a software problem (memory leak).

The output also displays the percentage of buffer space being used by the FPC processor for buffering internal messages.

## Step 2: Check FPC Status and Uptime

**Action** To display the status and uptime for a particular FPC slot, use the following CLI command:

```
user@host> show chassis fpc detail fpc-slot
```

**Sample Output**

```
user@m160> show chassis fpc detail 3
Slot 3 information:
  State                               Online
  Temperature                         36 degrees C / 96 degrees F
  Total CPU DRAM                      32 Mbytes
  Total SRAM                          4 Mbytes
  Total SDRAM                         256 Mbytes
  I/O Manager ASIC information        Version 2.0, Foundry IBM, Part number 0
  I/O Manager ASIC information        Version 2.0, Foundry IBM, Part number 0
  I/O Manager ASIC information        Version 2.0, Foundry IBM, Part number 0
  Start time:                        2002-03-19 13:13:26 PST
  Uptime:                            6 days, 1 hour, 19 minutes, 36 seconds
```

**What It Means** The command output shows status information for the FPC in slot 3, including the operating state. The state can be online, dead, diag, dormant, empty, online, probed, or probe-wait. If the FPC state is dead, an alarm occurs. For more detailed information about the FPC states, see the *JUNOS Protocols, Class of Service, and System Basics Command Reference*. The command output also shows temperature, memory usage, I/O Manager application-specific integrated circuit (ASIC) version level, start time, and uptime. The uptime is important to determine how long the FPC has been operational. A small uptime means that the FPC came online a short time ago and could indicate a possible FPC error condition.

**Syntax** show chassis fpc <pic-status <fpc-slot>>  
show chassis fpc <detail <fpc-slot>>

## Step 3: Check FPC Status and Temperature

**Action** (M40e, M160, M320, and T320 routers and T640 routing node only) To display the FPC status and temperature for a particular FPC slot, use the following CLI command:

```
user@host> show chassis environment fpc fpc-slot
```

```
user@m160> show chassis environment fpc 0
FPC 0 status:
  State                               Online
  Temperature                         39 degrees C / 102 degrees F
  Power:
    1.5 V                             1496 mV
    2.5 V                             2485 mV
    3.3 V                             3306 mV
    5.0 V                             4991 mV
    5.0 V bias                        4993 mV
    8.0 V bias                        8251 mV
  CMB Revision                        12
```

**What It Means** The command output displays the status of the FPC in slot 0, including the state, temperature, voltage levels on the FPC, and the revision level of the chassis management bus slave. The state can be **Unknown**, **Empty**, **Present**, **Ready**, **Announce**, **online**, **Online**, **Offline**, or **Diagnostics**. An **Offline** state indicates an FPC error condition.

## Step 4: Check the FPC LED States

**Action** To check the FPC LED status, use the following CLI command:

```
user@host> show chassis craft-interface
```



**Sample Output**

```
user@host> show chassis craft-interface
[...Output truncated...]
Front Panel FPC LEDs:
FPC    0    1    2    3    4    5    6    7
-----
Red     .    .    .    .    .    .    .    .
Green  *    *    .    .    .    .    .    .
[...Output truncated...]
```

**What It Means** The Front Panel FPC LEDs section displays the status of each FPC. The FPCs have two operational states: **Green** (OK), and **Red** (Fail). Asterisks (\*) indicate the operating state. Dots indicate an off state for LEDs. If both red and green LEDs have dots, the FPC slot is empty. Asterisks in the **Green** state indicate that the FPCs in slots 0 and 1 are operating normally. No FPCs are installed in slots 2 through 7.

**Alternative Action** (For all routers except the M5, M7i, M10, and M10i) You can also check the FPC status by looking at the LEDs on the faceplate. Each FPC has two LEDs that report its status. Only one LED state can occur at a time. Table 46 describes the FPC LEDs.

**Table 46: FPC LEDs on the Faceplate**

Label	Shape	Color	State	Description
OK		Green	On steadily	FPC is functioning normally.
			Blinking	FPC is starting up.
FAIL		Red	On steadily	FPC has failed.

(For all routers except the M5, M7i, M10, and M10i, you can check the FPC status by looking at the FPC LEDs on the craft interface. Table 47 describes the functions of the FPC LEDs.

**Table 47: FPC LEDs on the Craft Interface**

Label	Color	State	Description
FAIL	Red	On steadily	FPC has failed.
OK	Green	On steadily	FPC is functioning normally.
		Blinking	FPC is starting up.

## Checking for FPC Alarms

---

**Steps To Take** To check for FPC alarms, follow these steps:

1. Display the Current FPC Alarms on page 169
2. Display FPC Error Messages in the System Log File on page 170
3. Display FPC Error Messages in the Chassis Daemon Log File on page 171

### Step 1: Display the Current FPC Alarms

**Action** You can display current FPC alarms at the command line or use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1 alarms currently active
Alarm time          Class  Description
2002-04-16 15:09:00 UTC Major  Too many unrecoverable errors
```

**What It Means** The command output displays the current FPC alarms, including the time the alarm occurred, the severity level, and the alarm description. At the command line, you see the following FPC error messages:

```
Too many unrecoverable errors
Too many recoverable errors
```

From the router craft interface LCD screen, you see the following:

```
Slot x: errors
```

**Alternative Actions** Check for FPC alarms on the router craft interface. You can physically look at the craft interface or use the **show chassis craft-interface** command. When a red or yellow alarm occurs, the craft interface goes into alarm mode. Alarm mode preempts idle mode, displaying a message to alert you of serious alarm conditions. In alarm mode, the screen displays the following information:

```
+-----+
|myrouter|
|1 Alarm active|
|R: Slot 2:errors|
|         |
+-----+
```

The craft interface output provides the following information:

- First line—Name of the router.
- Second line—Number of alarms active on the router.
- Third and fourth lines—Individual alarms, with the most severe condition shown first. Each line indicates whether the alarm is a red (R) or yellow (Y) alarm.

For more information about the craft interface, see “Monitoring the Craft Interface” on page 197 or the appropriate hardware guide.

For more information about craft interface alarms, see “Display the Current Router Alarms” on page 61.

## Step 2: Display FPC Error Messages in the System Log File

**Action** To check for FPC error messages in the system log `messages` file, use the following CLI command:

```
user@host> show log messages | match fpc
```

Check for error messages at least 5 minutes before and after an FPC alarm occurs.

**Sample Output** The following output displays when you browse through the `messages` log file using the time and date stamp to look for error messages that occur 5 minutes before and after the FPC event:

```
user@host> show log messages
Mar 10 09:20:31 cls-edge-02 ssb RDP: Keepalive timeout for
rdp.(scb:chassis).(fpc1:36865) (elapsed 5595)
Mar 10 09:20:33 cls-edge-02 ssb SSB(0): Slot 0, serial number S/N BD9709.
Mar 10 09:20:37 cls-edge-02 ssb BCHIP 1: SRAM test failed.
Mar 10 09:20:37 cls-edge-02 ssb CM(0): Slot 1: B-chip diagnostics failed
Mar 10 09:20:37 cls-edge-02 ssb CM(0): Slot 1: Unrecoverable error; probe failed
Mar 10 09:20:37 cls-edge-02 ssb CM(0): Slot 1: Too many unrecoverable errors,
going off-line
Mar 10 09:20:37 cls-edge-02 ssb CM(0): ALARM SET: (Major) Slot 1: Too many
unrecoverable errors
Mar 10 09:20:37 cls-edge-02 ssb CM(0): Slot 1: Off-line
Mar 10 09:20:38 cls-edge-02 ssb PFEMAN: FPC socket closure indicated
Mar 10 09:20:38 cls-edge-02 ssb PFEMAN: closing FPC 1 socket
Mar 10 09:20:42 cls-edge-02 ssb PFEMAN: FPC socket closure indicated
Mar 10 09:20:42 cls-edge-02 ssb PFEMAN: close on unlisted socket, 0xb0e200
```

The following output displays when you use the `| match` filter command to look for specific information in the `messages` log file:

```
user@host> show log messages | match fpc
Mar 31 05:07:58 bopper fpc6 D4-6/0 AMCC: Transmitter laser bias out of range.
Mar 31 05:08:37 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: fpc 2, power on
timeout, retry 1, restarting
Mar 31 05:08:44 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: fpc 5, power on
timeout, retry 1, restarting
Mar 31 05:10:19 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: fpc 2, power on
timeout, retry 2, restarting
Mar 31 05:10:26 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: fpc 5, power on
timeout, retry 2, restarting
Mar 31 05:12:00 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: fpc 2, power on
timeout, retry 3, restarting
Mar 31 05:12:07 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: fpc 5, power on
timeout, retry 3, restarting
Mar 31 05:13:41 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: FPC 2
unresponsive, setting offline!
Mar 31 05:13:48 bopper chassisd[630]: CHASSISD_FRU_UNRESPONSIVE: FPC 5
unresponsive, setting offline!
```



**What It Means** When an FPC fails, the System and Switch Board (SSB), System Control Board (SCB), and Switching and Forwarding Modules (SFMs) generate error messages. The `messages` system log file records the time the failure or event occurred, the severity level, a code, and a message description. Use the `show log messages | match fpc` command to view only FPC error messages. Use this information to diagnose an FPC problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events prior to the FPC problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

### Step 3: Display FPC Error Messages in the Chassis Daemon Log File

**Action** To display FPC error messages in the `chassisd` log file, use the following CLI command:

```
user@host> show log chassisd | match "fpc | kernel | tnp"
```

**Sample Output**

```
user@host> show log chassisd | match "fpc | kernel | tnp"
Nov 11 15:58:31 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=0, tnpaddr=2
Nov 11 15:58:42 m40-2 tnp.bootpd[2497]: BOOTPD_BOOTSTRING: Boot string: boot 1
fpc.jbf
Nov 11 15:58:42 m40-2 tnp.tftpd[2647]: TFTPD_CONNECT_INFO: tftp read from addr
16 port 1024 file fpc.jbf
Nov 11 15:58:42 m40-2 tnp.bootpd[2497]: BOOTPD_BOOTSTRING: Boot string: boot 1
fpc.jbf
Nov 11 15:58:43 m40-2 tnp.tftpd[2649]: TFTPD_CONNECT_INFO: tftp read from addr
17 port 1024 file fpc.jbf
Nov 11 15:58:44 m40-2 tnp.tftpd[2651]: TFTPD_CONNECT_INFO: tftp read from addr
18 port 1024 file fpc.jbf
Nov 11 15:58:45 m40-2 tnp.tftpd[2653]: TFTPD_CONNECT_INFO: tftp read from addr
19 port 1024 file fpc.jbf
Nov 11 15:58:46 m40-2 tnp.tftpd[2655]: TFTPD_CONNECT_INFO: tftp read from addr
20 port 1024 file fpc.jbf
Nov 11 15:58:47 m40-2 tnp.tftpd[2657]: TFTPD_CONNECT_INFO: tftp read from addr
21 port 1024 file fpc.jbf
Nov 11 15:58:47 m40-2 fpc6 TFTP Error - Timeout
Nov 11 15:58:47 m40-2 fpc7 TFTP Error - Timeout
Nov 11 15:58:48 m40-2 tnp.tftpd[2659]: TFTPD_CONNECT_INFO: tftp read from addr
22 port 1024 file fpc.jbf
Nov 11 15:58:49 m40-2 tnp.tftpd[2661]: TFTPD_CONNECT_INFO: tftp read from addr
23 port 1024 file fpc.jbf
Nov 11 15:58:50 m40-2 tnp.tftpd[2663]: TFTPD_CONNECT_INFO: tftp read from addr
22 port 1024 file fpc.jbf
Nov 11 15:58:50 m40-2 fpc6 TFTP read - saw block 1, expected 572
Nov 11 15:58:51 m40-2 tnp.tftpd[2665]: TFTPD_CONNECT_INFO: tftp read from addr
23 port 1024 file fpc.jbf
Nov 11 15:58:51 m40-2 fpc6 TFTP read - saw block 1, expected 731
Nov 11 15:58:51 m40-2 fpc7 TFTP read - saw block 1, expected 200
Nov 11 15:58:52 m40-2 fpc6 TFTP read - saw block 1, expected 775
Nov 11 15:58:52 m40-2 fpc7 TFTP read - saw block 1, expected 265
Nov 11 15:58:52 m40-2 tnp.tftpd[2647]: TFTPD_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:58:53 m40-2 fpc6 TFTP read - saw block 1, expected 782
Nov 11 15:58:53 m40-2 fpc7 TFTP read - saw block 1, expected 340
Nov 11 15:58:54 m40-2 fpc7 TFTP read - saw block 1, expected 428
Nov 11 15:58:54 m40-2 fpc6 TFTP read - saw block 1, expected 1016
Nov 11 15:58:55 m40-2 fpc7 TFTP read - saw block 1, expected 531
Nov 11 15:58:57 m40-2 tnp.tftpd[2649]: TFTPD_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
```

```

Nov 11 15:58:57 m40-2 tnp.tftpd[2651]: TFTP_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:58:58 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=1, tnpaddr=16
Nov 11 15:58:58 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 0 restart
Nov 11 15:59:00 m40-2 tnp.tftpd[2653]: TFTP_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:59:00 m40-2 tnp.tftpd[2659]: TFTP_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:59:01 m40-2 tnp.tftpd[2655]: TFTP_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:59:02 m40-2 tnp.tftpd[2661]: TFTP_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:59:02 m40-2 tnp.tftpd[2657]: TFTP_SENDCOMPLETE_INFO: Sent 2335 blocks
of 1024 and 1 block of 960 for file '/usr/share/pfe/fpc.jbf'
Nov 11 15:59:03 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=2, tnpaddr=17
Nov 11 15:59:03 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 1 restart
Nov 11 15:59:03 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=3, tnpaddr=18
Nov 11 15:59:03 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 2 restart
Nov 11 15:59:06 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=4, tnpaddr=19
Nov 11 15:59:06 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 3 restart
Nov 11 15:59:07 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=5, tnpaddr=22
Nov 11 15:59:07 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 6 restart
Nov 11 15:59:07 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=6, tnpaddr=20
Nov 11 15:59:08 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 4 restart
Nov 11 15:59:08 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=7, tnpaddr=23
Nov 11 15:59:08 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 7 restart
Nov 11 15:59:09 m40-2 /kernel: pfe_listener_connect: conn established: listener
idx=8, tnpaddr=21
Nov 11 15:59:09 m40-2 chassisd[2476]: CHASSISD_EVENT: fpc slot 5 restart

```

**What It Means** The chassisd log file is a database that provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. The sample command output shows the results of a multiple item search in the log file (“fpc | kernel | tnp”): error messages for the FPC, kernel, and Trivial Networking Protocol (TNP) that indicate communication issues between the Routing Engine and the Packet Forwarding Engine components.

## Verifying FPC Failure

---

**Action** To verify an FPC failure, follow these steps:

1. Document Events Prior to the FPC Failure on page 173
2. Check the FPC Installation on page 173
3. Check the FPC Fuses on page 174
4. Take the FPC Offline on page 175
5. Perform an FPC Swap Test on page 176
6. Display the FPC Software Version Information on page 176
7. Display the FPC Hardware Information on page 177
8. Locate the FPC Serial Number ID Label on page 177

### Step 1: Document Events Prior to the FPC Failure

**Action** To document an FPC failure, record any events that may have led to the FPC failure, such as a software upgrade, hardware upgrade, or a reset. Capture system log file error messages 5 minutes before and after a failure event by using the **show log messages** command and use the time and date stamp to browse the file. You can use the **show log messages | match** command to view certain common error messages and help identify why an FPC failure occurred.

### Step 2: Check the FPC Installation

**Action** To check the FPC installation and verify an FPC failure, follow these steps:

1. Make sure that the FPC is seated in its slot. Use a screwdriver to check that the screws at the top and bottom of the card carrier are tight.
2. Try to bring the FPC online. Press the online button on the craft interface or FPM for a few seconds. If the FPC does not come online, it has probably failed.
3. If the FPC comes online, check the FPC detailed status with the following CLI command:

```
user@host> show chassis fpc detail fpc-slot
```

**Alternative Action** For the M40e, M160, M320 and T320 routers and T640 routing node, to bring the FPC online, use the **request chassis fpc slot-number online** command.

### **Step 3: Check the FPC Fuses**

The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly. You must remove the lower impeller assembly to access the fuses, as described in the appropriate hardware guide.

The M320 router requires fuses for the FPCs. The fuses for the and FPCs are located in the rear of the midplane behind the power supply in slot **PEM0**.

When the fuse for an FPC blows, the FPC stops functioning even though it is installed correctly and the power supplies are providing power to the router.

For the M40e and M160 routers, when a fuse has blown but the power supplies are still delivering power to router, the amber LED adjacent to the fuse lights. For vertically oriented fuses (in the groups labeled **J241** through **J244**).


Another indication that a fuse has blown is when the colored indicator bulb inside it becomes visible through the clear cover on the fuse. For information about the indicator bulb color for each fuse type, see the appropriate router hardware guide.

A blown fuse can cause a component to fail even though it is correctly installed and the power supplies are functioning. Check for a blown fuse in the following circumstances:

- The LED that indicates normal operation for the component fails to light.
- The appropriate CLI **show chassis environment** command indicates that the component is installed but is not receiving power.

Figure 58 shows the location of the M320 fuses in the rear of the midplane for the FPC. (The labels shown in the figure do not appear on the actual fuses—the clear cover on every fuse reads BUSS GMT-X—and might not match the labels on the midplane. Ignore the labels on the midplane.)

**Figure 58: Component Fuses in the M320 Router Midplane**



#### Step 4: Take the FPC Offline

The FPCs are hot-insertable and hot-removable. When you remove an FPC, the router continues to function, although the PIC interfaces installed on the FPC no longer function.

**Action** To take an FPC offline, press the offline button for approximately 3 seconds, and follow the instructions in the appropriate router hardware guide.

## Step 5: Perform an FPC Swap Test



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the FPC for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an FPC, follow these steps:

1. Remove the FPC that you suspect has failed from the router chassis.
2. Inspect the router midplane for bent pins. Inspect the FPC connector for pins that are stuck. If you find a bent or stuck pin, see “Return the Failed Component” on page 86.
3. If there are no bent or stuck pins and there is a spare FPC slot in the router, insert the FPC that failed into a spare slot. If the FPC still fails, see “Return the Failed Component” on page 86. If there is no spare FPC slot, insert an FPC that you know works into the slot where the FPC failed. If the FPC works, the replaced FPC failed. If the FPC does not work, the FPC slot has failed.

## Step 6: Display the FPC Software Version Information

**Action** To display the version of kernel software running on the router, use the following CLI command:

```
user@host> show version brief
```

**Sample Output**

```
user@host> show version brief
Hostname: host
Model: m160
JUNOS Base OS boot [5.5R1.2]
JUNOS Base OS Software Suite [5.5R1.2]
JUNOS Kernel Software Suite [5.5R1.2]
JUNOS Packet Forwarding Engine Support [5.5R1.2]
JUNOS Routing Software Suite [5.5R1.2]
JUNOS Online Documentation [5.5R1.2]
JUNOS Crypto Software Suite [5.5R1.2]
```

**What It Means** The command output displays the router hostname, model number, and the version of software running on the router. The kernel software version is important when diagnosing FPC issues. You will need this information when you contact JTAC.

## Step 7: Display the FPC Hardware Information

**Action** To display the FPC hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
[...Output truncated...]
FPC 0         REV 01   710-001292   AE3843         1x OC-48 SONET, SMIR
  PIC 0       REV 04   750-000617   AE2495
FPC 1         REV 07   710-000175   AA3408         1x Tunnel
  PIC 0       REV 01   750-001323   AB1244
  PIC 1       REV 05   750-000613   AA3151         1x OC-12 SONET, SMIR
FPC 3         REV 01   710-000175   AA0048         1x OC-12 SONET, SMIR
  PIC 0       REV 04   750-000613   aa0343         1x OC-12 ATM, MM
  PIC 1       REV 05   750-000616   AA1394         1x OC-12 SONET, SMIR
  PIC 2       REV 04   750-000613   AA0377         1x Tunnel
  PIC 3       REV 04   750-000613   AA0378
FPC 5         REV 07   710-000175   AA3475         4x OC-3 SONET, MM
  PIC 0       REV 04   750-000611   AA3506         1x G/E, 1000 BASE-SX
  PIC 2       REV 06   750-001072   AA1785
FPC 7         REV 07   710-000175   AA3409         4x OC-3 SONET, SMIR
  PIC 1       REV X1   750-000603   AA0181
```


**What It Means** The command output displays each FPC installed in the router, including the version level, part number, serial number, and description. The output also displays a description of the PICs installed in each FPC. You will need this information when you contact JTAC.

## Step 8: Locate the FPC Serial Number ID Label

**Action** The serial number ID label is small, rectangular, and has the component serial number and bar code on it. To locate the FPC serial number ID label, do one of the following:


- M20 router—With the FPC in horizontal position, look on the top back right of the FPC (see Figure 59).

**Figure 59: M20 Router FPC Serial Number ID Label**




- M40 router—With the FPC in vertical position, look on the back left side of the FPC (see Figure 60).

**Figure 60: M40 Router FPC Serial Number ID Label**



- M40e and M160 routers—With the FPC in vertical position, look on the center right side of the FPC (see Figure 61).


**Figure 61: M40e and M160 Router FPC Serial Number ID Label**






- M320 routers—The serial number ID label is located on the center of the right side of the FPC3 (see Figure 62). On an FPC2, the serial number label is located on the top PIC slot.

**Figure 62: M320 FPC Serial Number ID Label**




- T320 routers—The serial number ID label is located on the center of the right side of the FPC3 (see Figure 63). On an FPC1 and FPC2, the serial number ID label is located near the top PIC slot.

**Figure 63: T320 Router FPC Serial Number ID Label**



- T640 routing nodes— The serial number label is located on the center of the right side of the FPC3 (see Figure 64). On an FPC2, the serial number label is located near the top PIC slot.

**Figure 64: T640 Routing Node Serial Number Label**



## Replacing an FPC

The FPC is hot-removable and hot-insertable. You can remove or replace it without powering down the router and disrupting routing functions. However, you must first take the FPC offline by pressing the FPC offline button on the router craft interface for all router platforms except the M5 and M10 routers.

**Action** To return a failed FPC, see “Return the Failed Component” on page 86. To replace an FPC, see the appropriate router hardware guide.



## Chapter 16

# Monitoring PICs

You monitor and maintain Physical Interface Cards (PICs) to ensure that they receive incoming packets from the network and transmit outgoing packets to the network. (See Table 48.)

**Table 48: Checklist for Monitoring PICs**

Monitor PIC Tasks	Command or Action
<b>Understanding PICs on page 184</b>	
■ PIC Location, Row, and Slot Numbering on page 185	
<b>Checking the PIC Status on page 186</b>	
1. Display the PIC Media Type and FPC Status on page 186	<code>show chassis fpc pic-status</code> <code>show chassis pic pic-slot # fpc-slot #</code>
2. Display the PIC Interface Status Information on page 187	<code>show interfaces terse</code>
3. Check the PIC LED States on page 188	Check the PIC port LEDs.
<b>Checking PIC Alarms on page 189</b>	
1. Check Current Chassis Alarms on page 189	<code>show chassis alarms</code> <code>show chassis craft-interface</code>
2. Display Error Messages in the System Log File on page 190	<code>show log messages   match PIC</code>
<b>Verifying PIC Failure on page 190</b>	
1. Perform a PIC Swap Test on page 190	Replace the PIC with one that you know works, then use the <code>show chassis fpc pic-status</code> command.
2. Display PIC Hardware Information on page 191	<code>show chassis hardware</code>
3. Locate the PIC Serial Number ID Label on page 192	Look on the right side of the top of the PIC if horizontally oriented. Look on the left side of the PIC if vertically oriented.
<b>Replacing a PIC on page 195</b>	See “Return the Failed Component” on page 86. Follow the procedure in the appropriate router hardware guide. See also the appropriate PIC guide.

## Understanding PICs

**Purpose** Inspect PICs to ensure that data packets are received from and transmitted to the network for supported media types.

**What Is a PIC** A PIC is an interface card through which network cables carry data transmissions to and from the network plug. A PIC installs into a Flexible PIC Concentrator (FPC).

PICs are hot-removable and hot-insertable. Removing or inserting a PIC causes a brief interruption of forwarding performance. Each PIC has an ejector lever at the bottom of its faceplate that allows for easy removal from the router.

Table 49 lists some PIC characteristics for each routing platform. A PIC performs framing and line-speed signaling for its media type.


**Table 49: PIC Characteristics Per Routing Platform**

PIC Characteristic	M5/ M10	M7i	M10i	M20	M40	M40e	M160	M320	T320	T640
Single-wide PICs per FPC	4/8	4	8	16	32	32	32	32	16 (2 PICs per FPC)	32
Accepts Quad-wide PIC	Yes, M10 Internet router only	Yes	Yes, FPC not required	Yes, FPC not required	No	Yes, FPC not required	N/A	2 PICs per FPC <sup>3</sup>	N/A	N/A

Before transmitting outgoing data packets, the PICs encapsulate packets received from the FPCs. Each PIC is equipped with an application-specific integrated circuit (ASIC) that performs control functions specific to the PIC's media type.

For a listing of PICs supported for each routing platform, see the appropriate router hardware guide and the router PIC guide.

Figure 65 on page 185 shows the PIC location in each router and the corresponding row and slot numbering.

**Figure 65: PIC Location, Row, and Slot Numbering**

**See Also** “Monitoring FPCs” on page 163

## Checking the PIC Status

---

**Steps To Take** To check the PIC status, follow these steps:

1. Display the PIC Media Type and FPC Status on page 186
2. Display the PIC Interface Status Information on page 187
3. Check the PIC LED States on page 188

### Step 1: Display the PIC Media Type and FPC Status

**Action** To display the PIC media type and FPC status, use the following JUNOS command-line interface (CLI) operational mode command:

```
user@host> show chassis fpc pic-status
```

**Sample Output** user@host> show chassis fpc pic-status

```
Slot 0 Online
  PIC 0    1x OC-12 SONET, MM
  PIC 1    4x OC-3 SONET, SMIR
  PIC 2    4x E1, BNC
  PIC 3    1x CSTM1, SMIR
Slot 1 Online
  PIC 0    4x CT3
Slot 2 Online
  PIC 0    1x Tunnel
Slot 4 Online
Slot 5 Offline
Slot 6 Online
  PIC 0    1x OC-192 12xMM VSR
```

**What It Means** The command output displays the status for all FPCs installed in the router and a description of the PICs installed in each FPC, including the number of ports, media type, mode, and reach. The FPCs in slots 0, 1, 2, 4, and 6 are online. The FPC in slot 5 is offline. The PICs installed in the router include SONET, E1, Channelized STM1, CT3, Tunnel, and OC192 media PICs.

In the example, PIC 0 is one-port, SONET, OC12, and multimode.

For more detailed information about PIC types, see the appropriate router PIC guide.

**Alternative Actions** To check PIC status including port information, use the `show chassis pic pic-slot # fpc-slot #` CLI command. The command output for an M10i router displays the PIC type, ASIC type, operating status, PIC version, and how long the PIC has been online. Additionally, the command output displays the PIC port number, type, small form-factor pluggable transceiver (SFP) vendor, and part number information.

```
user@host> show chassis pic pic-slot 0 fpc-slot 1
```



**Sample Output**

```

user@host> show chassis pic pic-slot 0 fpc-slot 1
PIC fpc slot 1 pic slot 0 information:
  Type                1x OC-48 SONET SFP
  ASIC type            D chip
  State                Online
  PIC version          1.1
  Uptime               7 days, 13 hours, 29 minutes, 51 seconds

PIC Port Information:
  Port      Cable      SFP      SFP Vendor
  Number    Type        Vendor Name  Part Number
  0         OC48 SHORT REACH SumitomoElectric SCP6828-J1-ANE
  1         UNKNOWN CABLE
  2         UNKNOWN CABLE
  3         UNKNOWN CABLE

```

To check the PIC media type and status for a particular FPC, use the `show chassis fpc pic-status fpc-slot` command.

To display PIC hardware information, including the media type description, use the `show chassis hardware` command.

**Syntax** `show chassis fpc <pic-status <fpc-slot>>`  
`show chassis hardware`

## Step 2: Display the PIC Interface Status Information

**Action** To display the status of each configured interface, use the following JUNOS CLI operational mode command:

```
user@host> show interfaces terse
```

**Sample Output**

```

user@host> show interfaces terse
Interface      Adman Link Port Local      Remote
so-0/0/0       up    up
so-0/0/0.0     up    up  inet  192.168.36.201  --> 192.168.36.200
so-0/1/0       up    down
so-0/1/1       up    down
e1-0/2/0       up    down
e1-0/2/1       up    down
t1-1/0/0:1     up    down
t1-1/0/0:2     up    down
gr-2/0/0       up    up
ip-2/0/0       up    up
[...Output truncated...]

```

**What It Means** The command output shows the names of all interfaces configured on the router. The interface name indicates the *media type-fpc/pic/port* (for example, `so-0/0/0.0`). It shows whether the interface is on (**up**) or off (**down**) and whether the link state is up or down. Additionally, the output shows the protocol configured on that interface and the local address of the interface, as well as the address of the remote side of a connection for point-to-point interfaces. Refer to the PIC for port numbering.

A line in the sample output shows the status of a SONET interface on FPC 0, PIC 0, port 0, and logical unit number 0. The status of the interface is **up**. The link status is **up**. The protocol configured on the interface is **inet**. The local interface IP address is **192.168.36.201** and the remote IP address is **192.168.36.200**.

The interface is configured with a /32 subnet. If you configure the interface with a different subnet, the output will be different.

For more detailed information about monitoring interfaces, see the *JUNOS Network Interfaces and Class of Service Configuration Guide*.

**Alternative Actions** To view more detailed information about a particular interface, use the **show interfaces *interface-name* brief** command. The command output shows the interface status, link-level type, loopback, device flags, interface flags, keepalive settings, keepalive input, active alarms, and defects.

To view interface status information, use the **show interface descriptions** command. This command displays the interface status and the description given when configured on the router.

**Syntax** **show interfaces terse** <*interface-name*>  
**show interfaces** <*interface-name*> **brief**

### Step 3: Check the PIC LED States

For PICs that have a physical port, the LEDs indicate the status of the physical link. If the LED is green, the physical link is up. If the LED is red or amber, the physical link is down. Usually, when the LED is red, the receive port is not receiving a signal. If the LED is amber, the receive port is getting a remote alarm from the device.

For PICs with no physical port, such as a tunnel or encryption PIC, the LED indicates the status of the PIC.

The Tunnel PIC, which has no ports, has a single LED. Each LED has four different states, described in Table 50.

**Table 50: Tunnel PIC LEDs**

Color	State	Description
Red	Fail	The FPC has detected a PIC failure.
Green	Normal	The port is functioning normally.
Amber	Problem detected; still functioning	To track the problem, use the CLI.
None	Not enabled	The port is not enabled or the PIC is offline.

For M7i and M10i routers, most PICs have an LED labeled **STATUS** on the PIC faceplate. Some PICs have additional LEDs, often one per port. The meaning of the LED states differs for various PICs. For more information, see the appropriate router PIC guide.

## Checking PIC Alarms

---

**Steps To Take** To check for PIC alarms, follow these steps:

1. Check Current Chassis Alarms on page 189
2. Display Error Messages in the System Log File on page 190

### Step 1: Check Current Chassis Alarms

**Action** To display current PIC alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1 alarms currently active
Alarm time          Class  Description
2002-04-08 10:01:20 PDT  Major  PIC 0/2 failed to initialize
```

**What It Means** The command output displays the alarm time, severity level, and description.

**Alternative Action** You can also display PIC alarms by using the following CLI command:

```
user@host> show chassis craft-interface
```

```
user@host> show chassis craft-interface
Red alarm:      LED on, relay on
Yellow alarm:   LED off, relay off
Host OK LED:    On
Host fail LED:  Off
```

```
FPCs      0  1  2  3  4  5  6  7
-----
Green     *  .  .  *  .  .  .  .
Red       .  .  .  .  .  .  .  .
```

LCD screen:

```
+-----+
|myrouter|
|1 Alarm active|
|R: PIC 0/2 FAILED|
|         |
+-----+
```

## Step 2: Display Error Messages in the System Log File

**Action** To display PIC error messages in the system log file, use the following CLI command:

```
user@host> show log messages | match PIC
```

**Sample Output**

```
user@host> show log messages | match PIC
Apr  8 10:01:20 aspirin scb CM: PIC 0/2, ID 0x0206, hardware error, offlined
Apr  8 10:01:20 aspirin alarmd[2671]: Alarm set: FPC color=RED, class=CHASSIS,
reason=PIC 0/2 failed to initialize
Apr  8 10:01:20 aspirin fpc0 PIC: PIC 2 discovery error (1)
Apr  8 10:01:20 aspirin fpc0 CMFPC: Hardware error discovering PIC 2, ID 0x0206
Apr  8 10:01:21 aspirin scb CM: ALARM SET: (Major) Slot 0: PIC 0/2 failed to
initialize
```

**What It Means** When a PIC fails, the `messages` system log file records the time the failure or event occurred, the severity level, a code, and a message description. Use the `show log messages` command to browse error messages that are generated at least 5 minutes before and after a PIC event. You can also use the `show log messages | match PIC` command to view specific PIC error messages with common information. Use this information to diagnose a PIC problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events prior to the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Verifying PIC Failure

---

**Steps To Take** To verify PIC failure, follow these steps:

1. Perform a PIC Swap Test on page 190
2. Display PIC Hardware Information on page 191
3. Locate the PIC Serial Number ID Label on page 192

### Step 1: Perform a PIC Swap Test

**Action** To perform a swap test on a PIC, follow these steps:

1. Ensure that the PIC is firmly seated in the FPC or the FPC slot.
2. If the PIC is firmly seated and still fails, remove it from the FPC. Follow the PIC removal procedure in the appropriate router PIC guide.

3. Check the PIC connector pins.
  - a. If a pin is bent, contact JTAC and generate a Return Material Authorization (RMA). For more information about returning a failed router part, see “Return the Failed Component” on page 86.
  - b. If no pins are bent, install a PIC that you know works into the FPC.
  - c. Check the PIC status by looking at the PIC LEDs and using the **show chassis fpc pic-status** command (see “Display the PIC Media Type and FPC Status” on page 186).
4. If the PIC works, then the PIC you removed is defective. Contact JTAC and generate an RMA. See “Return the Failed Component” on page 86.

## Step 2: Display PIC Hardware Information

**Action** To display PIC hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
[...Output truncated...]
FPC 0          REV 03    710-001255   S/N AA9806          FPC Type 1
CPU           REV 02    710-001217   S/N AA9590
PIC 1          REV 05    750-000616   S/N AA1527          1x OC-12 ATM, MM
PIC 2          REV 05    750-000616   S/N AA1535          1x OC-12 ATM, MM
PIC 3          REV 01    750-000616   S/N AA1519          1x OC-12 ATM, MM
FPC 1          REV 02    710-001611   S/N AA9523          FPC Type 2
CPU           REV 02    710-001217   S/N AA9571
PIC 0          REV 03    750-001900   S/N AA9626          1x STM-16 SDH, SMIR
PIC 1          REV 01    710-002381   S/N AD3633          2x G/E, 1000 BASE-SX
FPC 2          REV 03    710-001217   S/N AB3329          FPC Type OC192
CPU           REV 03    710-001217   S/N AB3329
PIC 0          REV 01    710-001217   S/N AB3329          1x OC-192 SM SR-2
```


**What It Means** The command output displays the PIC number, revision level, part number, serial number, and media type.

### Step 3: Locate the PIC Serial Number ID Label

**Action** To locate the PIC serial number ID label, do one of the following:


- With the PIC in horizontal position, look on the right side of the top of the PIC (see Figure 66).

**Figure 66: PIC Serial Number ID Label (Horizontal Orientation)**




- With the PIC in vertical position, look on the left side of the PIC (see Figure 67).

**Figure 67: PIC Serial Number ID Label (Vertical Orientation)**




For M320 routers, the serial number ID label is located on the right side of the PIC (see Figure 68) when the PIC is vertically oriented (as it would be installed in the router). The exact location may be slightly different on different PICs, depending on the placement of components on the PIC board.

**Figure 68: M320 Router Serial Number ID Label on PIC**



For T320 routers, the serial number ID label is located on the right side of the PIC (see Figure 69) when the PIC is vertically oriented (as it would be installed in the router). The exact location may be slightly different on different PICs, depending on the placement of components on the PIC board.


**Figure 69: T320 Router Serial Number ID Label on PIC**





For T640 routing nodes, the serial number label is located on the right side of the PIC (see Figure 70) when the PIC is vertically oriented (as it would be installed in the routing node). The exact location may be slightly different on different PICs, depending on the placement of components on the PIC board.

**Figure 70: T640 Routing Node Serial Number Label on PIC**



## Replacing a PIC

**Action** To remove a PIC, refer to the appropriate PIC guide.

For information about returning a PIC, see “Return the Failed Component” on page 86. To replace a PIC, see the appropriate router hardware guide or PIC guide.



## Chapter 17

# Monitoring the Craft Interface

You monitor and maintain the craft interface or Front Panel Module (FPM) to ensure that you can view the router status and perform management operations from the panel on the front of the chassis. (See Table 51.) You can also display craft interface information from the JUNOS software command-line interface (CLI).

**Table 51: Checklist for Monitoring the Craft Interface**

Monitor Craft Interface Tasks	Command or Action
<b>Understanding the Craft Interface on page 199</b>	
■ M5 and M10 Router Craft Interface on page 199	
■ M20 Router Craft Interface on page 200	
■ M40 Router Craft Interface on page 200	
■ M40e and M160 Router Craft Interface on page 201	
■ M320 Router Craft Interface on page 201	
■ T320 Router and T640 Routing Node Craft Interface on page 202	
<b>Monitoring the Craft Interface Status on page 203</b>	
1. View the Craft Interface Status on page 203	show chassis craft interface Physically check the craft interface panel.
2. Check the Craft Interface Environmental Status on page 203	show chassis environment (M40e, M160, and T320 routers and T640 routing node only) show chassis environment fpm
<b>Viewing Craft Interface Information from the Command Line on page 204</b>	show chassis craft-interface
<b>Verifying Craft Interface Failure on page 205</b>	
1. Display Craft Interface Alarms on page 206	show chassis alarms
2. Display Craft Interface Error Messages in the System Log File on page 207	show log messages
3. Display Craft Interface Messages in the Chassis Daemon Log File on page 208	show log chassisd
4. Display Craft Interface Hardware Information on page 208	show chassis hardware

Monitor Craft Interface Tasks	Command or Action
<b>Replacing the Craft Interface on page 209</b>	
1. Replace the M20 Router Craft Interface on page 209	1. Attach an ESD wrist strap to your wrist. 2. Unscrew the thumbscrews on the left and right sides of the craft interface. 3. Flip the ends of the two extractor clips towards the outside edges of the router. 4. Grasp both sides of the craft interface and slide it out of the chassis.
2. Replace the M40 Router Craft Interface on page 209	The craft interface is attached to the lower impeller tray. 1. Attach an ESD wrist strap to your wrist. 2. Unscrew the three screws at the bottom edge of the lower impeller tray. 3. Grasp the sides of the lower impeller tray, and slide it out of the chassis.
3. Replace the M40e and M160 Router Craft Interface on page 210	The craft interface is attached to the upper impeller assembly (front top blower). 1. Attach an ESD wrist strap to your wrist. 2. Undo the captive screws at the corners of the craft interface. 3. Grasp the craft interface and pull it out of the chassis.
4. Replace the M320 Router Craft Interface on page 211	The craft interface is located on the front of the chassis above the FPC card cage.
5. Replace the T320 Router and T640 Routing Node Craft Interface on page 212	The craft interface is located on the front of the chassis above the FPC card cage.
<b>Locating the Craft Interface Serial Number ID Label on page 213</b>	
1. Locate the M20 Router Craft Interface Serial Number ID Label on page 213	Remove the craft interface and look for the serial number ID label on the back of the unit.
2. Locate the M40 Router Craft Interface Serial Number ID Label on page 214	Remove the craft interface and look for the serial number ID label on the back of the unit.
3. Locate the M40e and M160 Router Craft Interface Serial Number ID Label on page 214	Remove the craft interface and look for the serial number ID label on the back of the unit.
4. Locate the M320 Router Craft Interface Serial Number ID Label on page 215	Remove the craft interface and look for the serial number ID on the back of the unit, behind the alarm LEDs.
5. Locate the T320 Router and T640 Routing Node Craft Interface Serial Number ID Label on page 215	Remove the craft interface and look for the serial number ID label on the back of the unit.
<b>Returning the Craft Interface on page 215</b>	
	See “Replacing a Failed Component” on page 122, or follow the procedure in the appropriate router hardware guide.

## Understanding the Craft Interface

**Purpose** Inspect the craft interface to ensure that you can monitor the status of the router and perform system management functions. The craft interface is also referred to as the Front Panel Module (FPM).

**What Is the Craft Interface** The craft interface, located on the front of the router chassis, provides status information, alarm indicators and contacts, Physical Interface Card (PIC) online and offline buttons, Flexible PIC Concentrator (FPC) online and offline buttons and LED status indicators, Routing Engine offline button and LED status indicators, and management access to the router.

You can display craft interface status information from the JUNOS software CLI.

The craft interface is hot-removable and hot-insertable. You can remove and replace it without powering down the router or disrupting routing functions.

For detailed information about how the router craft interface works, see the appropriate router hardware guide.

Figure 71 shows the M5 and M10 Internet router craft interface.

**Figure 71: M5 and M10 Router Craft Interface**




Figure 72 shows the M20 Internet router craft interface.

**Figure 72: M20 Router Craft Interface**




Figure 73 shows the M40 Internet router craft interface.

**Figure 73: M40 Router Craft Interface**




Figure 74 shows the M40e and M160 Internet router craft interface.

**Figure 74: M40e and M160 Router Craft Interface**




Figure 76 shows the M320 Internet router craft interface.

**Figure 75: M320 Router Craft Interface**




Figure 76 shows the T320 Internet router and T640 Internet routing node craft interface.

**Figure 76: T320 Router and T640 Routing Node Craft Interface**




Table 52 lists the craft interface characteristics for each routing platform.

**Table 52: Router Craft Interface Characteristics Per Routing Platform**

Characteristic	M5 /M10	M7i	M10i	M20	M40	M40e	M160	M320	T320	T640
Alarm LEDs	X	X	X	X	X	X	X	X	X	X
Lamp test button	X									
Alarm cutoff button				X		X	X	X	X	X
Alarm relay contacts				X	X					
Link and activity status lights	X	X		X						
LCD display and navigation buttons					X	X	X	X	X	X
Routing Engine ports	X			X	X					
Routing Engine LEDs				X	X			X		
Host module LEDs						X	X			
Switch Interface Board (SIB) LEDs								X		
Host subsystem LEDs	No Craft Interface	No Craft Interface	No Craft Interface						X	X
PIC online and offline buttons	X	X	X							
FPC LEDs				X	X	X	X	X	X	X
FPC offline buttons				X						
Power Supply LEDs								X		
HCM LEDs			X							

**See Also** “Monitoring the Router Chassis” on page 107

“Monitoring the CIP” on page 381



## Monitoring the Craft Interface Status

---

**Steps To Take** To monitor the craft interface status, follow these steps:

1. View the Craft Interface Status on page 203
2. Check the Craft Interface Environmental Status on page 203

### Step 1: View the Craft Interface Status

**Action** To view the craft interface status, look at the craft interface panel on the front of the router chassis. (See Figure 71 on page 199 through Figure 76 on page 202.)

When the craft interface fails, you might not see any lights on the craft interface panel and the LCD display will be blank. In addition, the buttons on the panel might not work as indicated.

**Alternative Action** You can view the craft interface information with the following CLI command:

```
user@host> show chassis craft-interface
```

If the craft interface fails, you can still view current craft interface information at the command line. A craft interface failure or removal generates a red alarm. See “Viewing Craft Interface Information from the Command Line” on page 204.

### Step 2: Check the Craft Interface Environmental Status

**Action** To check the craft interface status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output** For M5, M10, M20, and M40 routers:

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Misc  Craft Interface      OK
```

For M40e and M160 routers:

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
      FPM CMB              OK        32 degrees C / 89 degrees F
      FPM Display          OK        32 degrees C / 89 degrees F
[...Output truncated...]
```

For M40e and M160 routers:

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
      FPM GBUS             OK        28 degrees C / 82 degrees F
      FPM Display          OK        31 degrees C / 87 degrees F
[...Output truncated...]
```

**What It Means** For M5, M10, M20, and M40 routers, the command output displays the craft interface state, which can be **OK** or **Absent**.

For M40e and M160 routers, the command output displays the FPM Chassis Management Bus (CMB) status and the FPM display status, which can be **OK** or **Absent**.

For M320 routers, the command output displays the FPM CMB status only.

For T320 routers and T640 routing nodes, the command output displays the FPM circuitry and the FPM display status, which can be **OK** or **Absent**.

**Alternative Action** (For M40e, M160, M320, and T320 routers and the T640 routing node) To monitor the craft interface environmental status, use the following CLI command:

```
user@host> show chassis environment fpm
```

```
user@host> show chassis environment fpm
FPM status:
  State                               Online
  FPM CMB Voltage:
    5.0 V bias                        5030 mV
    8.0 V bias                        8083 mV
  FPM Display Voltage:
    5.0 V bias                        4998 mV
  FPM CMB temperature                 34 degrees C / 93 degrees F
  FPM Display temperature             35 degrees C / 95 degrees F
  CMB Revision                        12
```

The command output displays the status of the FPM or craft interface, which can be **Online** or **Offline**. It also displays information about the power supplied to the FPM CMB or FPM GBUS, information about the FPM display power supply, the temperature of the air flowing past the FPM CMB or FPM GBUS and the FPM display, and the CMB or GBUS revision level.

## Viewing Craft Interface Information from the Command Line

---

If the craft interface fails, you can still display the craft interface information from the CLI. The values reflect what would be visible if the craft interface were operating normally.

**Action** To display craft interface information, use the following CLI command:

```
user@host> show chassis craft-interface
```

```

Sample Output user@host> show chassis craft-interface
WARNING: Front panel not present. The following values
           reflect what would be currently visible.

Red alarm:      LED on, relay on
Yellow alarm:   LED on, relay on
Host OK LED:    On
Host fail LED:  Off

FPCs      0  1  2  3
-----
Green     .  .  *  *
Red       .  .  .  .

LCD screen:
+-----+
|myrouter      |
|2 Alarms active|
|R: fpx0: link down|
|Y: Bchip uCode ovflw|
+-----+

```

**What It Means** The command output displays the information that is currently displayed on the craft interface, including the alarm indicator status, the component status, and the alarm messages currently displayed on the LCD display. The command output is for an M20 router. A craft interface failure generates a red alarm, and you see an **fpx0: link down** alarm in the LCD screen output. The **fpx0** interface or the Ethernet management interface provides an out-of-band method of connecting to the router from the craft interface.

## Verifying Craft Interface Failure

When the craft interface fails, you might not see any lights on the craft interface panel and the LCD display will be blank. In addition, the buttons on the panel might not work as indicated.

On M5 and M10 routers, you can use the lamp test button to ensure that the alarm LED lights are working properly.

**Steps To Take** To verify craft interface failure, follow these steps:

1. Display Craft Interface Alarms on page 206
2. Display Craft Interface Error Messages in the System Log File on page 207
3. Display Craft Interface Messages in the Chassis Daemon Log File on page 208
4. Display Craft Interface Hardware Information on page 208

**Step 1: Display Craft Interface Alarms**

A craft interface failure generates a red or yellow alarm, or both. For information about conditions that trigger craft interface alarms, see “Gather Component Alarm Information” on page 60.

**Action** To display a craft interface alarm, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output** For an M20 router:

```
user@host> show chassis alarms
1 alarms currently active
Alarm time           Class  Description
2002-05-09 00:00:54 UTC Major  fpx0: ethernet link down
```

For M40e and M160 routers:

```
user@host> show chassis alarms
2 alarms currently active
Alarm time           Class  Description
2002-06-07 18:20:00 UTC Minor  Craft Failure
2002-06-07 18:20:00 UTC Minor  Front Top Fan Absent
```

**What It Means** (M20 router) If the craft interface fails or is removed, you see an alarm. For example, if you remove the craft interface, a major management Ethernet interface down alarm is generated. The Ethernet link to the router is down. The Ethernet management interface, or **fpx0**, provides an out-of-band method for connecting to the router. You can connect to the management interface over the network using utilities such as secure shell (SSH) and telnet. The Simple Network Management Protocol (SNMP) can use the management interface to gather statistics from the router.

(M40e and M160 routers) The craft interface is connected to the front top fan assembly. If the craft interface fails or is removed, a craft interface failure alarm and a front top fan absence alarm are generated.

## Step 2: Display Craft Interface Error Messages in the System Log File

**Action** To display craft interface error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output** For an M20 router:

```
user@host> show log messages
Jun  3 16:43:19 flitter ssb CM(0): ALARM SET: (Major) fxp0: ethernet link down
Jun  3 16:43:19 flitter craftd[582]: forwarding display request to chassisd:
type = 4, subtype = 43
Jun  3 16:43:19 flitter alarmd[581]: Alarm set: fxp0 color=RED, class=ETHER,
reason=fxp0: ethernet link down
Jun  3 16:43:19 flitter mib2d[586]: SNMP_TRAP_LINK_DOWN: ifIndex 1,
ifAdminStatus up(1), ifOperStatus down(2), ifName fxp0
Jun  3 16:43:21 flitter /kernel: fxp0: media DOWN 100Mb / full-duplex
```

For M40e and M160 routers:

```
user@host> show log messages
Jun  7 18:18:50 myrouter craftd[2654]: Minor alarm set, Front Top Fan Absent
Jun  7 18:18:50 myrouter chassisd[2652]: CHASSISD_BLOWERS_SPEED: blowers
being set to full speed [fan/blower missing]
Jun  7 18:18:50 myrouter alarmd[2653]: Alarm set: Fan color=YELLOW,
class=CHASSIS, reason=Front Top Fan Absent
Jun  7 18:18:50 myrouter craftd[2654]: fpm led error: Unknown error: -1
Jun  7 18:18:50 myrouter alarmd[2653]: Alarm set: Craft IF color=YELLOW,
class=CHASSIS, reason=Craft Failure
Jun  7 18:18:50 myrouter craftd[2654]: Minor alarm set, Craft Failure
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. Use the **show log messages** CLI command to browse error messages that are generated at least 5 minutes before and after an event. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events prior to the event.

For an M20 router, the **messages** file output shows that the Ethernet management interface (**fxp0**) that provides an out-of-band method for connecting to the router from the craft interface is down. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

For an M160 router, since the craft interface is attached to the front top fan, you see both craft interface and fan error messages.

### Step 3: Display Craft Interface Messages in the Chassis Daemon Log File

The chassis daemon (chassisd) log file keeps track of the state of each chassis component.

**Action** To display craft interface status messages in the chassisd log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```
user@host> show log chassisd
Jun  7 18:18:50 *** inventory change ***
Jun  7 18:18:50 fru 42 set alarm 0x2
Jun  7 18:18:50 alarm op fru 42 op 1 reason 2
Jun  7 18:18:50 send: yellow alarm set, class 100 obj 100 reason 2
Jun  7 18:18:50 front top blower removed
Jun  7 18:18:50 FPM set alarm 0x1
Jun  7 18:18:50 alarm op fru 33 op 1 reason 1
Jun  7 18:18:50 send: yellow alarm set, class 100 obj 106 reason 106
Jun  7 18:18:50 FPM removed
Jun  7 18:18:50 CHASSISD_BLOWERS_SPEED: blowers being set to full speed
[fan/blower missing]
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.

### Step 4: Display Craft Interface Hardware Information

**Action** To display the craft interface hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output** For M5, M10, M20, and M40 routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
[...Output truncated...]
Display       REV 07   710-000150   AA7812
```

For M40e, M160, M320, and T320 routers and T640 routing nodes:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
[...Output truncated...]
FPM CMB       REV 03   710-001642   AH5159
FPM Display   REV 01   710-001647   AA2920
[...Output truncated...]
```

**What It Means** For M5, M10, M20, and M40 routers, the command output displays the display version level, part number, and serial number. For M40e, M160, M320, and T320 routers and T640 routing nodes, the command output displays the hardware information for the FPM CMB or the FPM GBUS and the FPM display. If the craft interface has failed or is absent, you will not see the craft interface or FPM hardware information in the command output.

## Replacing the Craft Interface

The craft interface is hot-removable and hot-insertable. You can remove and replace it without powering down the router or disrupting routing functions.



**NOTE:** The M5 and M10 router craft interface is a part of the router chassis. You cannot remove it.

**Steps To Take** To replace the craft interface, do one of the following:

1. Replace the M20 Router Craft Interface on page 209
2. Replace the M40 Router Craft Interface on page 209
3. Replace the M40e and M160 Router Craft Interface on page 210
4. Replace the M320 Router Craft Interface on page 211
5. Replace the T320 Router and T640 Routing Node Craft Interface on page 212

### Step 1: Replace the M20 Router Craft Interface

**Action** To remove the M20 router craft interface, follow these steps:


1. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Unscrew the thumbscrews on the left and right sides of the card carrier to unseat the craft interface from the midplane.
3. Flip the ends of the two extractor clips, which are adjacent to the thumbscrews, toward the outside edges of the router.
4. Grasp both sides of the craft interface and slide it about three-quarters of the way out of the router.
5. Move one of your hands underneath the craft interface to support it, and slide the craft interface completely out of the chassis.

### Step 2: Replace the M40 Router Craft Interface

The craft interface is attached to the lower impeller tray.

**Action** To remove the M40 router craft interface, follow these steps:

1. Attach an ESD wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Unscrew the three screws at the bottom edge of the lower impeller tray.
3. Grasp the sides of the lower impeller tray and slide it out of the chassis. (See Figure 77 on page 210.)

**Figure 77: Removing the Lower Impeller Tray**

1023

**Step 3: Replace the M40e and M160 Router Craft Interface**


The craft interface is attached to the upper impeller assembly (front top blower).

**Action** To remove the M40e and M160 router craft interface, follow these steps:

1. Attach an ESD wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Unscrew the captive screws at the corners of the impeller assembly (the craft interface).
3. Grasp the impeller assembly and pull it halfway out of the chassis. (See Figure 78.)



**CAUTION:** If the impeller is still spinning, do not put your fingers or any tool into the impeller assembly as you pull it out. To avoid injury, wait until the impeller stops spinning before removing the assembly.

**Figure 78: Removing the Front Upper Impeller Assembly**

1215

4. Pull the impeller assembly completely out of the chassis.
5. Place the assembly top-side down (the lettering on the craft interface is upside down) on an antistatic mat on a flat, stable surface.



6. Using a Phillips screwdriver, loosen and remove the four screws that secure the bottom of the craft interface housing to the impeller assembly.
7. Turn the impeller assembly over so that the lettering on the craft interface is right side up.
8. Using a Phillips screwdriver, loosen and remove the four screws that secure the top of the craft interface housing to the impeller assembly.
9. Using a Phillips screwdriver, loosen and remove the screws located on the rear side of the craft interface at the side. There are two screws at each side, located near the holes for the captive screws that secure the impeller assembly to the chassis.
10. Grasp the sides of the craft interface and pull it straight off the front of the impeller assembly.

#### **Step 4: Replace the M320 Router Craft Interface**

The craft interface is located on the front of the chassis above the FPC card cage.


**Action** To remove the craft interface, follow these steps:



**NOTE:** Removing the front upper fan tray before you remove the craft interface might make it easier to grasp the craft interface as you remove it. For instructions on removing a front fan tray, see the appropriate router hardware guide.

---

1. Attach an ESD wrist strap to your bare wrist, and connect the wrist strap to one of the ESD points on the chassis.
2. Remove the upper cable guards by loosening the three captive screws on each cable guard.
3. Completely loosen the four captive screws that attach the craft interface to the chassis.
4. Grasp the craft interface by the left and right flanges and carefully pull it straight out of the chassis. (See Figure 75 on page 201.)

**Figure 79: Remove the Craft Interface**

### Step 5: Replace the T320 Router and T640 Routing Node Craft Interface

The craft interface is located on the front of the chassis above the FPC card cage.

**Action** To remove the craft interface, follow these steps:



**NOTE:** Removing the front upper fan tray before you remove the craft interface might make it easier to grasp the craft interface as you remove it. For instructions on removing a front fan tray, see the appropriate nrouter hardware guide.

1. Attach an ESD wrist strap to your bare wrist, and connect the wrist strap to one of the ESD points on the chassis.
2. Completely loosen the screws at the four corners of the craft interface.
3. Insert the blade of a flat-blade screwdriver into the slot on one side of the craft interface, then gently pry that side out from the chassis.
4. Repeat Step 3 for the other side of the craft interface.
5. Grasp the craft interface by the top and bottom edges and carefully pull it straight out of the chassis.

## Locating the Craft Interface Serial Number ID Label

If the craft interface has failed or is absent, it does not appear in the hardware list output when you use the `show chassis hardware` command. You must remove the craft interface and manually locate the craft interface serial number ID label.



**NOTE:** The M5 and M10 router craft interfaces are part of the chassis. You cannot remove them.


**Steps To Take** To locate the craft interface serial number ID label, do one of the following:

1. Locate the M20 Router Craft Interface Serial Number ID Label on page 213
2. Locate the M40 Router Craft Interface Serial Number ID Label on page 214
3. Locate the M40e and M160 Router Craft Interface Serial Number ID Label on page 214
4. Locate the M320 Router Craft Interface Serial Number ID Label on page 215
5. Locate the T320 Router and T640 Routing Node Craft Interface Serial Number ID Label on page 215

### Step 1: Locate the M20 Router Craft Interface Serial Number ID Label

**Action** To locate the M20 router craft interface serial number ID label, look on the back of the craft interface panel (see Figure 80).


**Figure 80: M20 Router Craft Interface Serial Number ID Label**



## Step 2: Locate the M40 Router Craft Interface Serial Number ID Label

**Action** To locate the M40 router craft interface serial number ID label, look on the back of the panel, above the connector (see Figure 81).


**Figure 81: M40 Router Craft Interface Serial Number ID Label**



## Step 3: Locate the M40e and M160 Router Craft Interface Serial Number ID Label

**Action** To locate the M40e and M160 router serial number ID label, look on the back of the panel, behind the alarm LEDs (see Figure 82).


**Figure 82: M40e and M160 Router Craft Interface Serial Number ID Label**



### Step 4: Locate the M320 Router Craft Interface Serial Number ID Label

**Action** To locate the M320 router serial number, look on the back of the craft interface panel, behind the alarm LEDs (see Figure 83).


**Figure 83: M320 Router Serial Number ID Label**



### Step 5: Locate the T320 Router and T640 Routing Node Craft Interface Serial Number ID Label

**Action** To locate the T320 router and T640 routing node serial number, look on the back of the craft interface panel, behind the alarm LEDs (see Figure 84).

**Figure 84: T320 Router and T640 Routing Node Serial Number ID Label**



## Returning the Craft Interface

The craft interface is hot-removable and hot-insertable. You can remove or replace a craft interface without powering down the system and disrupting routing functions.

**Action** To return the craft interface, see “Replacing a Failed Component” on page 122 or the appropriate router hardware guide.



## Chapter 18

# Monitoring Power Supplies

You monitor and maintain the power supplies to ensure that power is distributed to the router components. (See Table 53.)

**Table 53: Checklist for Monitoring Power Supplies**

Monitor Power Supply Tasks	Command or Action
<b>Understanding Power Supplies on page 218</b>	
■ M5/M10 Router Power Supplies on page 219	
■ M7i Router Power Supplies on page 220	
■ M10i Router Power Supplies on page 221	
■ M20 Router Power Supplies on page 222	
■ M40 Router Power Supplies on page 223	
■ M40e Router Power Supplies on page 224	
■ M160 Router Power Supplies on page 226	
■ M320 Router Power Supplies on page 227	
■ T320 Router Power Supplies on page 228	
■ T640 Routing Node Power Supplies on page 229	
<b>Checking the Power Supply Cables on page 229</b>	Check the power supply cables.
<b>Checking the Power Supply Status on page 230</b>	
1. Check the Power Supply Environmental Status on page 230	<code>show chassis environment</code> (M40e, M160, and T320 router and T640 routing node only) <code>show chassis environment pem slot</code>
2. Check the Power Supply LEDs on page 232	Check the LEDs on the power supply faceplate.
<b>Checking for Power Supply Alarms on page 235</b>	
1. Display Current Power Supply Alarms on page 235	<code>show chassis alarms</code>
2. Display Power Supply Error Messages in the System Log File on page 238	<code>show log messages   match "power supply"</code>
3. Display Power Supply Error Messages in the Chassis Daemon Log File on page 238	<code>show log chassisd   match pem</code>
<b>Verifying Power Supply Failure on page 239</b>	
1. Check the Power Supply Power Switch on page 239	Check the power supply power switch.
2. Check the Circuit Breaker on page 239	Make sure that the power switch is on.
3. Perform a Power Supply Swap Test on page 240	Replace the faulty power supply with one that works.
4. Check the Router Cooling System on page 240	<code>show chassis environment</code>

Monitor Power Supply Tasks	Command or Action
5. Test the Power Supply on page 241	Press the power supply self-test button.
<b>Getting Power Supply Hardware Information on page 241</b>	
1. Display the Power Supply Hardware Information on page 242	show chassis hardware
2. Locate the Power Supply Serial Number ID Label on page 242	Look on the power supply faceplate or look on the back of the power supply.
<b>Replacing the Power Supplies on page 250</b>	(M5, M10, M20, and M40 routers) Turn off the power to the individual power supply before removing it from the chassis.  (M40e, M160, and T320 routers and T640 routing node) Switch the corresponding circuit breaker off before removing the power supply. Follow the procedure in the appropriate router hardware guide.

## Understanding Power Supplies

**Purpose** Inspect the power supplies to ensure that they distribute power to the other router components according to their voltage requirements.

**What Is a Power Supply** The power supplies are internally connected to the midplane, which delivers the power input from the circuit breaker box and distributes the different output voltages produced by the power supplies to the router's components, depending on their voltage requirements.

Table 54 lists some router characteristics for each router type.

**Table 54: Router Power Supply Characteristics**

Power Supply Characteristic	M5/ M10	M7i/ M10i	M20	M40	M40e	M160	M320	T320	T640
Watts per AC/DC power supply	434 W	293 W	750 W	1500 W	AC 2900 W DC 3000 W	DC original 2600 W DC enhanced 3200 W	1750 W	3200 W	6500 W
Supports both AC and DC power supplies	Yes	Yes	Yes	Yes	Yes	No; original or enhanced DC only	Yes	No; DC only	No; DC only
Turn off power supply before removing	X	X	X	X					
Turn off circuit breaker before removing power supply					X	X	X	X	X

Power supplies in the router must be of the same type: either two AC or two DC power supplies. You cannot mix power supply types. The M160 router supports DC power supplies only.




The following sections describe each routing platform power supply location and type:

- M5/M10 Router Power Supplies on page 219
- M7i Router Power Supplies on page 220
- M10i Router Power Supplies on page 221
- M20 Router Power Supplies on page 222
- M40 Router Power Supplies on page 223
- M40e Router Power Supplies on page 224
- M160 Router Power Supplies on page 226
- M320 Router Power Supplies on page 227
- T320 Router Power Supplies on page 228
- T640 Routing Node Power Supplies on page 229

### **M5/M10 Router Power Supplies**

Two load-sharing, isolated power supplies are located at the bottom rear of the M5 and M10 router chassis. The routers use either AC or DC power. Figure 85 shows the M5 and M10 router power supplies and where they are installed in the chassis.

**Figure 85: M5 and M10 Router Power Supplies**



When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supply instantly begins providing all the power the router needs for normal functioning and can provide full power indefinitely.



**NOTE:** Mixing AC and DC power supplies is not supported. The two power supplies must be either both AC or both DC.

When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)


### M7i Router Power Supplies

Two load-sharing, isolated power supplies are located at the bottom rear of the M7i router chassis. The router uses either AC or DC power. Figure 86 shows the M7i router power supplies and where they are installed in the chassis.

When the power supplies are installed and operational, they automatically share the electrical load.

For full redundancy, two power supplies are required. If a power supply stops functioning for any reason, the second power supply instantly begins providing all the power the router needs for normal functioning. The second power supply can provide full power indefinitely.

**Figure 86: M7i Router Power Supplies**



**NOTE:** When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)


## M10i Router Power Supplies

The M10i router uses either AC or DC power. You can install up to four load-sharing power supplies at the bottom rear of the chassis. Figure 87 shows the M10i router power supplies and where they are installed in the chassis.

The AC power supplies are fully redundant. If one power supply fails or is removed, the remaining power supplies instantly assume the entire electrical load. Two power supplies can provide full power for as long as the router is operational. Three power supplies are required for redundancy. Power supplies must be present in slots P/S 0 and P/S 1 for the router to operate.

The DC power supplies are fully redundant. The DC power supplies in slots P/S 0 and P/S 1 can provide full power to the router. Likewise, the DC power supplies in slots P/S 2 and P/S 3 can also provide full power. The DC power supplies in slots P/S 2 and P/S 3 jointly serve as the backup to the DC power supplies in slots P/S 0 and P/S 1. Power supplies must be present in slots P/S 0 and P/S 1 for the router to operate.

**Figure 87: M10i Router Power Supplies**



**NOTE:** AC and DC power supplies are required in slots P/S 0 and P/S 1 for the router to operate.

The DC power supplies in slots P/S 0 and P/S 1 must be powered by dedicated power feeds derived from feed A, and the DC power supplies in slots P/S 2 and P/S 3 must be powered by dedicated power feeds derived from feed B. This configuration provides the commonly deployed A/B feed redundancy for the system.

## M20 Router Power Supplies

Two load-sharing, isolated power supplies are located at the bottom rear of the M20 router chassis. The router uses either AC or DC power. Figure 88 shows the M20 router power supplies and where they are installed in the chassis.


When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supplies instantly begin providing all the power the router needs for normal functioning, and can provide full power indefinitely.



**NOTE:** Mixing AC and DC power supplies is not supported. The two power supplies must be either both AC or both DC.

When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers and on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)

**Figure 88: M20 Router Power Supplies**




## M40 Router Power Supplies

The M40 router can use either AC or DC power. Two load-sharing power supplies install into the bays located at the bottom rear of the chassis. As viewed from the rear of the chassis, the supply on the left is referred to as supply A and the supply on the right as supply B. Figure 89 shows the M40 router power supplies and where they are installed in the chassis.


The power supplies are fully redundant. When both power supplies are operational, they automatically share the electrical load. If one power supply stops functioning for any reason, the remaining power supply instantly begins providing all the power the router needs for normal functioning, and can provide full power indefinitely.

**Figure 89: M40 Router Power Supplies**


**M40 router**



**DC power supply**



**AC power supply**



1765

## M40e Router Power Supplies


The M40e router uses either AC or DC power. Two load-sharing, pass-through power supplies are located at the bottom rear of the chassis. Figure 90 shows the M40e router power supplies and where they are installed in the chassis.

When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supplies instantly begin providing all the power the router needs for normal functioning, and can provide full power indefinitely.



**NOTE:** Mixing AC and DC power supplies is not supported and prevents the router from booting. If two power supplies are installed, they must be either both AC or both DC.

- A circuit breaker box must be installed on a DC-powered router, while a circuit breaker is incorporated into each AC power supply. Converting the router from AC to DC power or vice versa involves removing or installing the circuit breaker box. Only authorized service personnel should perform the conversion; this manual does not include instructions.
  - When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)
-


**Figure 90: M40e Router Power Supplies**

## M160 Router Power Supplies

The M160 router uses DC power. Two load-sharing, pass-through power supplies are located at the bottom rear of the chassis. Figure 91 shows the M160 router power supplies and where they are installed in the chassis.

When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supplies instantly begin providing all the power the router needs for normal functioning, and can provide full power indefinitely.

**Figure 91: M160 Router Power Supplies**



1767




## M320 Router Power Supplies

The M320 router uses either AC or DC power. Figure 92 shows the M320 router power supplies and where they are installed in the chassis.

**Figure 92: M320 Router Power Supplies**

M320 router rear



The M320 router supports four power supplies. The AC power supplies are fully redundant. If one power supply fails or is removed, the remaining power supplies instantly assume the entire electrical load. Three power supplies can provide full power for as long as the router is operational.

In the M320 router DC power supply configuration, the router has four DC power supplies, located at the lower rear of the chassis in slots **PEM0** through **PEM3** (top to bottom). The DC power supplies in slots **PEM0** and **PEM2** are load-sharing and provide power to the Flexible PIC Concentrators (FPCs) in slots **FPC3** through **FPC7**. The DC power supplies in slots **PEM1** and **PEM3** are load-sharing and provide power to the FPCs in slots **FPC0** through **FPC2**, Switch Interface Boards (SIBs), Control Boards, and Routing Engines. All DC power supplies provide power to the fan trays.



**NOTE:** The DC power supplies in slots **PEM0** and **PEM1** must be powered by dedicated power feeds derived from feed A, and the DC power supplies in slots **PEM2** and **PEM3** must be powered by dedicated power feeds derived from feed B. This configuration provides the commonly deployed A/B feed redundancy for the system.




**NOTE:** Each power supply must be connected to a dedicated AC power feed and a dedicated 15 A (250 VAC) circuit breaker.

### T320 Router Power Supplies


Figure 93 shows the T320 router power supplies and where they are installed in the chassis.

**Figure 93: T320 Router Power Supplies Location**

T320 router rear



DC power supply




g002106

## T640 Routing Node Power Supplies

Figure 94 shows the T640 routing node power supplies and where they are installed in the chassis.

**Figure 94: T640 Routing Node Power Supplies**



**See Also** ■ Monitoring Redundant Power Supplies on page 507

## Checking the Power Supply Cables

**Action** To check the power supply cables, follow these steps:

1. Verify that the power cable or power cord from the power source to the router is not damaged. If the insulation is cracked or broken, immediately replace the cord or cable.
2. Make sure that the power and ground cables on each DC power supply are arranged so that they do not obstruct access to the other power supply or to the Routing Engine.
3. Periodically inspect the site to ensure that the cables connected to the power supply are securely in place and are properly insulated.

## Checking the Power Supply Status

---

**Steps To Take** To check the power supply status, follow these steps:

1. Check the Power Supply Environmental Status on page 230
2. Check the Power Supply LEDs on page 232

### Step 1: Check the Power Supply Environmental Status

**Action** To check the power supply environmental status, use the following JUNOS command-line interface (CLI) operational mode command:

```
user@host> show chassis environment
```

**Sample Output** For M5, M10, M20, and M40 routers:

```
user@host> show chassis environment
Class Item                Status    Measurement
Power Power Supply A      OK
      Power Supply B      Absent
[...Output truncated...]
```

For M7i and M10i routers:

```
user@host> show chassis environment
Class Item                Status    Measurement
Power Power Supply 0      OK
      Power Supply 1      Absent
[...Output truncated...]
```

For M40e, M160, M320 and T320 routers and T640 routing nodes:

```
user@host> show chassis environment
Class Item                Status    Measurement
Power PEM 0                OK
      PEM 1                OK
[...Output truncated...]
```

**What It Means** The command output displays the status of both power supplies installed in the router.

For M5, M10, M7i, M10i, M20, and M40 routers, the command output displays the power supply slot number and status. The status can be **OK**, **Testing** (during initial power-on), **Failed**, or **Absent**. A **Failed** condition triggers the red alarm LED on the craft interface.

For M40e, M160, M320, and T320 routers and T640 routing nodes, the output displays the power supply slot number and status for the Power Entry Modules (PEMs). The status can be **OK**, **Absent**, or **Check**.

**Alternative Action** For the M40e, M160, M320, and T320 routers and the T640 routing node, to display the power supply status, use the following CLI command:

```
user@host> show chassis environment pem
```

```
user@host> show chassis environment pem
PEM 0 status:
  State                Online
  Temperature           OK
  DC input              OK
  DC output             OK
  Load                 Less than 20 percent
  Voltage:
    48.0 V input        69028 mV
    48.0 V fan supply   48839 mV
    5.0 V bias          5013 mV
    8.0 V bias          8253 mV
PEM 1 status:
  State                Online
  Temperature           OK
  DC input              OK
  DC output             OK
  Load                 Less than 20 percent
  Voltage:
    48.0 V input        69307 mV
    48.0 V fan supply   49170 mV
    5.0 V bias          4991 mV
    8.0 V bias          8263 mV
```

For each PEM, the command output displays the slot number, status, temperature, DC input and output, load percentage, and voltage. You can display the status of a particular power supply by specifying the *slot* number.

For T320 routers and T640 routing nodes, the command output displays the PEM slot number, status, temperature, DC input status, and DC output for each Flexible PIC Concentrator (FPC), SONET Clock Generator (SCG), Control Board, and Switch Interface Board (SIB). You can display the status of a particular power supply by specifying the *slot* number.

```
user@host> show chassis environment pem
PEM 1 status:
  State                Online
  Temperature           33 degrees C / 91 degrees F
  DC input:             OK
  DC Output:            Voltage    Current    Power    Load
    FPC 0               53783     3368      181     24
    FPC 1                0         0         0         0
    FPC 2                0         0         0         0
    FPC 3                0         0         0         0
    FPC 4               54041     3462     187     24
    FPC 5               53883     5187     279     37
    FPC 6                0         0         0         0
    FPC 7                0         0         0         0
  SCG/CB/SIB           54066     4031     217     18
```

## Step 2: Check the Power Supply LEDs

**Action** To check the power supply status, look at the four LEDs on the faceplate. Table 55 describes the M5 and M10 router output LED and self-test button for both the AC and DC power supplies.

**Table 55: M5 and M10 Router Power Supply LED and Self-Test Button**

Label	Color	State	Description
OUTPUT OK	Blue	On steadily	Power supply is functioning normally, input is occurring, outputs are within range, and the temperature is within range.
		Blinking	Power supply has failed.
SELF-TEST	(button)	–	Power supply is in self-test mode.

Table 56 describes the functions of the LED on both the M7i and M10 router AC and DC power supplies.

**Table 56: M7i and M10i Router AC/DC Power Supply LED**

Label	Color	State	Description
OUTPUT OK	Green	On steadily	Power supply is inserted and is functioning normally, input is occurring, outputs are within range, and the temperature is within range.
		Blinking	Power supply is not functioning, is starting up, or is not properly inserted, or airflow is not sufficient.

Table 57 describes the functions of the M20 router power supply LEDs.

**Table 57: M20 Router Power Supply LEDs**

Label	Color	State	Description
OK	Green	On steadily	Power supply is functioning normally, input is occurring, outputs are within range, temperature is within range, and fans are operational.
FAIL	Amber	On steadily	Power supply has failed.

Table 58 describes the functions of the M40 router power supply LEDs.

**Table 58: M40 Router Power Supply LEDs**

Label	Color	State	Description
OK	Green	On steadily	Power supply is functioning normally, input is occurring, outputs are within range, temperature is within range, and fans are operational.
FAIL	Red	On steadily	Power supply has failed.

Table 59 describes the functions of the M40e router AC power supply LED.

**Table 59: M40e Router AC Power Supply LED**

Label	Color	State	Description
OUTPUT OK	Green	On steadily	Power supply is inserted and is functioning normally.
		Blinking slowly	Power supply is not plugged in, or power switch is in the off position (when other AC power supply is functioning).
		Blinking rapidly	Power supply is starting up.

Table 60 describes the functions of the M40e router DC power supply LEDs.

**Table 60: M40e Router DC Power Supply LEDs**

Label	Color	State	Description
CB ON	Green	On steadily	Power supply is inserted correctly and is receiving power. Circuit breaker is on.
OUTPUT OK	Blue	On steadily	Power supply is inserted and is functioning normally.
		Blinking	Power supply is not functioning, is starting up, is not properly inserted, or airflow is not sufficient.
CB OFF	Amber	On steadily	Power supply is functioning, but the circuit breaker is off.

Table 61 describes the functions of the M160 router DC power supply LEDs.

**Table 61: M160 Router Power Supply LEDs**

LED	Color	State	Description
CB ON	Green	On steadily	Power supply is inserted correctly and is receiving power. Circuit breaker is on.
OUTPUT OK	Blue	On steadily	Power supply is inserted and is functioning normally.
		Blinking	Power supply is not functioning, is going through startup, is not properly inserted, or airflow is not sufficient.
		Off	Power supply is not functioning.
NO AIRFLOW (Original power supply only)	Amber	On steadily	Power supply is inserted, but airflow around the power supply is not sufficient.
CB OFF	Amber	On steadily	Power supply is functioning, but the circuit breaker is off.

Table 62 describes the functions of the M320 router AC and DC power supply LED.

**Table 62: M320 Router AC/DC Power Supply LED**

Label	Color	State	Description
OUTPUT OK	Blue	Off	No power applied to power supply.
		Blinking	<ul style="list-style-type: none"> <li>■ Power supply blinks for 5 seconds after initial power on.</li> <li>■ Power supply is installed, but not powered on, and is receiving bias power from a powerword on power supply.</li> <li>■ Input voltage is invalid</li> <li>■ Power supply has failed.</li> </ul>
		On steadily	Power supply is functioning normally.

Table 63 describes the functions of the M320 router AC and DC power supply LED.

**Table 63: T320 Router DC Power Supply LED**

Label	Color	State	Description
DC OK	Blue	On steadily	Power supply is installed correctly and is functioning normally.
		Blinking	Power supply is starting up, is not functioning, or is not properly installed.

Table 64 describes the functions of the T640 routing node DC power supply LEDs.

**Table 64: T640 Routing Node Power Supply LEDs**

LED	Color	State	Description
CB ON	Green	On steadily	Power supply is installed correctly and is functioning normally, is receiving power, and the circuit breaker is on.
CB TRIP	Amber	On steadily	Circuit breaker not turned on, or host subsystem has detected a failure and has turned the circuit breaker off.
OVER TEMP	Amber	On steadily	Power supply has exceeded the recommended temperature.
DC OK	Blue	On steadily	Power supply is installed correctly and is functioning normally.
		Blinking	Power supply is starting up, is not functioning, or is not properly installed.



**Alternative Actions** For M40e and M160 routers, if all LEDs are off on both power supplies, either someone has switched off power to the router or the system temperature has exceeded the acceptable maximum. The host module shuts down both power supplies. There is no power to the router, so the alarm LEDs on the craft interface are not lit and the LCD display is blank.

Excessive system temperature is almost always caused by excessive environmental temperature. Correct the environmental temperature before repowering the router.

If all LEDs on one power supply are off, but the LEDs on the other supply indicate that it is functioning properly, or the LEDs on both power supplies indicate a problem, do the following:

1. Check the current alarms by using the **show chassis alarms** CLI command or by looking at the router craft interface.
2. Check that the power switch is in the ON (I) position (on the circuit breaker box for a DC-powered router, or on the power supply faceplate for an AC-powered router).
3. Perform a swap test on the power supplies (see “Perform a Power Supply Swap Test” on page 240).

## Checking for Power Supply Alarms

---

For a listing of power supply alarm conditions, remedy, and alarm severity by routing platform type, see “Display the Current Router Alarms” on page 61.

**Steps To Take** To check for power supply alarms, follow these steps:

1. Display Current Power Supply Alarms on page 235
2. Display Power Supply Error Messages in the System Log File on page 238

### Step 1: Display Current Power Supply Alarms

**Action** To display power supply alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
4 alarms currently active
Alarm time      Class  Description
2002-04-08 15:25:12 PDT Major  Power Supply A 2.5 volt output failed
2002-04-08 15:25:12 PDT Major  Power Supply A 5 volt output failed
2002-04-08 15:25:12 PDT Major  Power Supply A 3.3 volt output failed
2002-04-08 15:25:12 PDT Major  Power Supply A fan failed
```

**What It Means** The command output displays the alarm date, time, severity level, and description. Table 65 shows the power supply alarm descriptions that you see on the craft interface LCD and the alarms that you see at the CLI. For information about conditions that trigger power supply alarms, see “Gather Component Alarm Information” on page 60.

**Table 65: Power Supply Alarms**

Power Supplies	Craft Interface LCD Short Version	CLI Long Version
M5 and M10	N/A	Power supply x not providing power
M7i and M10i	N/A	Power supply x not providing power
M20	N/A	Power supply x not providing power
	N/A	Power supply x 3.3V failed
	N/A	Power supply x 5V failed
	N/A	Power supply x 2.5V failed
M40	Supply x FAIL	Power supply x not providing power
	Supply x 3V FAIL	Power supply x 3.3V failed
	Supply x 5V FAIL	Power supply x 5V failed
	Supply x 2V FAIL	Power supply x 2.5V failed
M40e	PEM <i>pem-ID</i> Removed	YELLOW ALARM - PEM <i>pem-ID</i> Removed
	PEM <i>pem-ID</i> High Temp	RED ALARM - PEM <i>pem-ID</i> High Temperature
	PEM <i>pem-ID</i> Output Fail	RED ALARM - PEM <i>pem-ID</i> Output Failure
	PEM <i>pem-ID</i> Input Fail	RED ALARM - PEM <i>pem-ID</i> Input Failure
M160	PEM <i>pem-number</i> Removed	YELLOW ALARM - PEM <i>pem-number</i> Removed
	PEM <i>pem-number</i> High Temp	RED ALARM - PEM <i>pem-number</i> High Temperature
	PEM <i>pem-number</i> Output Fail	RED ALARM - PEM <i>pem-number</i> Output Failure
	PEM <i>pem-number</i> Input Fail	RED ALARM - PEM <i>pem-number</i> Input Failure

Power Supplies	Craft Interface LCD Short Version	CLI Long Version
T320	PEM <i>pem-number</i> Removed	YELLOW ALARM - PEM <i>pem-number</i> Removed
	PEM <i>pem-number</i> Over Temp	RED ALARM - PEM <i>pem-number</i> Over Temperature
	PEM <i>pem-number</i> Output Fail	RED ALARM - PEM <i>pem-number</i> Output Failure
	PEM <i>pem-number</i> Input Fail	RED ALARM - PEM <i>pem-number</i> Input Failure
T640	PEM <i>pem-number</i> Removed	YELLOW ALARM—PEM <i>pem-number</i> Removed
	PEM <i>pem-number</i> Over Temp	RED ALARM—PEM <i>pem-number</i> Over Temperature
	PEM <i>pem-number</i> Output Fail	RED ALARM—PEM <i>pem-number</i> Output Failure
	PEM <i>pem-number</i> Input Fail	RED ALARM—PEM <i>pem-number</i> Input Failure

For information about what conditions trigger power supply alarms and their remedy for each router type, see “Display the Current Router Alarms” on page 61.

**Alternative Action** To display current power supply alarms and the alarm indicator states, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
Red alarm:    LED on, relay on
Yellow alarm: LED off, relay off
Host OK LED:  On
Host fail LED: Off
```

```
FPCs      0  1  2  3
-----
Green     *  *  *  *
Red       .  .  .  .
```

LCD screen:

```
+-----+
|myrouter|
|4 Alarms active|
|R: Supply A 2v FAIL|
|R: Supply A 5v FAIL|
+-----+
```

**What It Means** The command output displays the alarm indicator status and the alarms that display on the craft interface LCD display.

(For M7i router) Check the red and yellow alarm LEDs on the FIC. Power supply failure or removal triggers an alarm that causes one or both of the LEDs to light.

## Step 2: Display Power Supply Error Messages in the System Log File

**Action** To display power supply error messages that are generated in the system log file, use the following CLI command:

```
user@host> show log messages | match "power supply"
```

**Sample Output**

```
user@host> show log messages | match "power supply"
Apr  8 14:00:15 myrouter scb CM: ALARM SET: (Major) Power Supply A fan failed
Apr  8 14:00:15 myrouter alarmd[584]: Alarm cleared: Pwr supply color=RED,
class=CHASSIS, myrouter=Power Supply A fan failed
Apr  8 14:00:18 myrouter scb CM: ALARM CLEAR: Power Supply A fan failed
Apr  8 14:00:21 myrouter alarmd[584]: Alarm set: Pwr supply color=RED,
class=CHASSIS, reason=Power Supply A fan failed
Apr  8 14:00:23 myrouter scb CM: ALARM SET: (Major) Power Supply A fan failed
Apr  8 14:05:16 myrouter alarmd[584]: Alarm set: Pwr supply color=RED,
class=CHASSIS, reason=Power Supply A fan failed
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. Use the `show log messages | match "power supply"` command to view only power supply error messages. Use this information to diagnose a power supply problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events prior to the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 3: Display Power Supply Error Messages in the Chassis Daemon Log File

**Action** To display power supply error messages in the chassisd log file, use the following CLI command:

```
user@host> show log chassisd | match pem
```

**Sample Output**

```
user@host> show log chassisd | match pem
Jul 15 11:18:59 CMB cmd to PEM#0 [0xf8], Amber LED Off [0x18]
Jul 15 11:18:59 PEM#0 - Amber LED Off
Jul 15 11:18:59 CMB cmd to PEM#0 [0xf8], Green LED Off [0x1a]
Jul 15 11:18:59 PEM#0 - Green LED Off
Jul 15 11:18:59 CMB cmd to PEM#0 [0xf8], Blue LED Off [0x16]
Jul 15 11:18:59 PEM#0 - Blue LED Off
Jul 15 11:18:59 CMB cmd to PEM#1 [0xf9], Amber LED Off [0x18]
Jul 15 11:18:59 PEM#1 - Amber LED Off
Jul 15 11:18:59 CMB cmd to PEM#1 [0xf9], Green LED Off [0x1a]
Jul 15 11:18:59 PEM#1 - Green LED Off
Jul 15 11:18:59 CMB cmd to PEM#1 [0xf9], Blue LED Off [0x16]
Jul 15 11:18:59 PEM#1 - Blue LED Off
Jul 15 11:19:02 PEM#0 added
Jul 15 11:19:02 reading PEM 0 initial state
Jul 15 11:19:02 PEM#1 added
Jul 15 11:19:02 reading PEM 1 initial state
Jul 15 11:19:18 CHASSISD_PEM_INPUT_BAD: PEM 1 - INPUT FAIL, status bits: 0xf2,
check breaker
Jul 15 11:19:18 CHASSISD_SNMP_TRAP: SNMP trap: FRU failure: jnxFruContentsIndex
2, jnxFruL1Index 2, jnxFruL2Index 0, jnxFruL3Index 0, jnxFruName PEM 1,
jnxFruType 7, jnxFruSlot 2, jnxFruOfflineReason 2, jnxFruLastPowerOff 0,
jnxFruLastPowerOn
26221491, jnxFruPowerUpTime 1484
Jul 15 11:19:23 CHASSISD_PEM_INPUT_BAD: PEM 1 - INPUT FAIL, status bits: 0xf2,
check breaker
```

```

Jul 15 11:19:28 CHASSISD_PEM_INPUT_BAD: PEM 1 - INPUT FAIL, status bits: 0xf2,
check breaker
Jul 15 11:19:33 CHASSISD_PEM_INPUT_BAD: PEM 1 - INPUT FAIL, status bits: 0xf2,
check breaker
Jul 15 11:19:38 CHASSISD_PEM_INPUT_BAD: PEM 1 - INPUT FAIL, status bits: 0xf2,
check breaker

```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.

## Verifying Power Supply Failure

---

**Steps To Take** To verify a power supply failure, follow these steps:

1. Check the Power Supply Power Switch on page 239
2. Check the Circuit Breaker on page 239
3. Perform a Power Supply Swap Test on page 240
4. Check the Router Cooling System on page 240
5. Test the Power Supply on page 241

### Step 1: Check the Power Supply Power Switch

**Action** If the OK power supply LED is off and no red alarm condition exists, check that the power switch is ON.

### Step 2: Check the Circuit Breaker

**Action** To check the circuit breaker, follow these steps:

1. Verify that the source DC or AC circuit breaker has the proper current rating. Each power supply in the router must be connected to a separate power source.
2. Make sure that the power switch is in the ON (I) position in the circuit breaker box for DC-powered routers. If the circuit breaker box has been tripped, reset it.

### Step 3: Perform a Power Supply Swap Test

**Action** To perform a swap test to determine whether a power supply is defective, follow the procedure in the appropriate router hardware guide to remove the faulty power supply and connect it to a different source with a new power cable. If the power supply does not power on, then the power supply is the source of the problem. Return the faulty power supply for replacement, as described in the appropriate router hardware guide.



**CAUTION:** When replacing a power supply, do not leave a slot empty for more than two minutes while the router is operational. The power supply must remain in the chassis for proper airflow.



**WARNING:** Do not touch the power connectors on the back side of the power supply. They can contain dangerous voltages.

### Step 4: Check the Router Cooling System

The power supplies require an unobstructed airflow.

If the NO AIRFLOW LED on one of the power supplies lights, check that the airflow around the power supply is sufficient.

**Action** To check the airflow, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@m40-host> show chassis environment
Class Item                Status    Measurement
Power Power Supply A      OK
        Power Supply B    Absent

[...Output truncated...]
Fans   Top Impeller           OK        Spinning at normal speed
        Bottom Impeller    OK        Spinning at normal speed
        Rear Fan 1         OK        Spinning at normal speed
        Rear Fan 2         OK        Spinning at normal speed
        Rear Fan 3         OK        Spinning at normal speed

[...Output truncated...]
```

**What It Means** The command output displays the power supply status and the cooling system status. When monitoring the power supplies, look at both the power supply status and the cooling system status. If the cooling system temperature is above a certain level, the power supplies are automatically cut off.

**Alternative Action** To check the power supply temperature on M40e and M160 routers, use the following CLI command:

```
user@host> show chassis environment pem
```

```
user@host> show chassis environment pem
PEM 0 status:
  State           Online
  Temperature      OK
  DC input         OK
  DC output        OK
  Load            Less than 20 percent
  Voltage:
    48.0 V input   69028 mV
    48.0 V fan supply 48839 mV
    5.0 V bias     5013 mV
    8.0 V bias     8253 mV
PEM 1 status:
  State           Online
  Temperature      OK
  DC input         OK
  DC output        OK
  Load            Less than 20 percent
  Voltage:
    48.0 V input   69307 mV
    48.0 V fan supply 49170 mV
    5.0 V bias     4991 mV
    8.0 V bias     8263 mV
```

The command output displays the temperature of the air flowing past the power supplies (PEMs). The status is either **OK** or **Failed**.

To check the status of a specific power supply, indicate the slot number. For example, type `show chassis environment pem slot`, where *slot* can be either 0 or 1.

## Step 5: Test the Power Supply

**Action** On certain power supplies (M5/M10, M40e, and M160 routers), a self-test button is used to test the power supply. It is located beneath the power supply LEDs. The self-test button is for use by qualified service personnel only.

## Getting Power Supply Hardware Information

---

**Steps To Take** To get the power supply hardware information, follow these steps:

1. Display the Power Supply Hardware Information on page 242
2. Locate the Power Supply Serial Number ID Label on page 242

## Step 1: Display the Power Supply Hardware Information

**Action** To display power supply hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output** For M5, M10, M20, M40, and M40e routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               2003          M20
Backplane     REV 07   710-001517   AA7940
Power Supply A Rev 02   740-001465   000497        AC
Power Supply B Rev 01   740-001465   000001        AC
[...Output truncated...]
```

For M160 and T320 routers and T640 routing nodes:

```
user@host> show chassis hardware
Item          Version  Part number  Serial number  Description
Chassis                               47          M160
Midplane     REV 02   710-001245   AB4113
FPM CMB      REV 01   710-001642   AA9721
FPM Display  REV 01   710-001647   AA2995
CIP          REV 02   710-001593   AA9886
PEM 0        Rev 01   740-001243   KJ35782        DC
PEM 1        Rev 01   740-001243   kj35756        DC
[...Output truncated...]
```

**What It Means** For all routers except the M160 and T320 routers and the T640 routing node, the command output displays the power supply slot number, revision level, part number, serial number, and the power supply type. When facing the back of the router, power supply A is located on the right and power supply B is located on the left.

For the M160 and T320 routers and the T640 routing node, the command output displays the power supply or PEM slot number, revision level, part number, serial number, and power supply type. When facing the back of the router, PEM 0 is located on the right and PEM 1 is located on the left.

## Step 2: Locate the Power Supply Serial Number ID Label

**Action** To locate the power supply serial number ID label, see Table 66 and Figure 95 on page 243 through Figure 101 on page 248.

**Table 66: Power Supply Serial Number ID Label Locations on M-series Routers**

Router	Power Supply Type	Serial Number ID Label Location
M5 and M10	AC, DC	Power supply faceplate
M7i and M10i	AC, DC	Power supply faceplate
M20	AC, DC	Right side of the power supply back
M40	AC, DC	Top of the power supply



Router	Power Supply Type	Serial Number ID Label Location
M40e	AC	Upper center of the power supply faceplate
	DC	Left center of the power supply faceplate
M160	DC	Left center of the power supply faceplate
M320	AC, DC	On the power supply faceplate under the circuit breaker switch
T320 and T640	DC	Left side of the power supply faceplate

Figure 95 shows the location of the serial number ID label on the power supplies for the M5 and M10 routers. The label is located on the power supply faceplate.

**Figure 95: M5 and M10 Router Power Supply Serial Number ID Label**




Figure 96 shows the location of the power supply serial number ID label. for the M7i router. The label is located on the power supply faceplate.


**Figure 96: M7i Router Power Supply Serial Number ID Label**

Figure 97 shows the location of the AC and DC power supply serial number ID labels for the M10i router. The labels are located on the power supply faceplate.


**Figure 97: M10i Router Power Supply Serial Number ID Labels**

Figure 98 shows the location of the serial number ID label on the power supplies for an M20 router. The label is located on the right side on the back of the power supply.

**Figure 98: M20 Router Power Supply Serial Number ID Label**




Figure 99 shows the location of the serial number ID label on the power supply for an M40 router. The label is located on the top of the power supply.

**Figure 99: M40 Router Power Supply Serial Number ID Label**




Figure 100 shows the location of the AC power supply serial number ID label for an M40e router. The label is located at the upper center of the faceplate.

**Figure 100: M40e Router AC Power Supply Serial Number ID Label**




Figure 101 shows the location of the DC power supply serial number ID label for the M40e and M160 routers. The label is located on the faceplate.

**Figure 101: M40e and M160 Router DC Power Supply Serial Number ID Label**




Figure 102 shows the location of the AC and DC power supply serial number ID labels for the M320 router. The serial number ID label is located on the power supply faceplate under the circuit breaker switch.

**Figure 102: M320 Router AC and DC Power Supply Serial Number ID Label**




Figure 103 shows the location of the DC power supply serial number ID label for the T320 router. The serial number ID label is located on the left side of the power supply faceplate.

**Figure 103: T320 Router DC Power Supply Serial Number ID Label**





Figure 104 shows the location of the DC power supply serial number ID label for the T640 routing node. The serial number ID label is located on the left side of the power supply faceplate.

**Figure 104: T640 Routing Node DC Power Supply Serial Number Label**



## Replacing the Power Supplies

The power supplies are hot-removable and hot-insertable. You can remove or replace a power supply without powering down the system and disrupting routing functions.

However, you must power down the power supply before removing it from the router. When one power supply is powered down, the other power supply automatically assumes the entire electrical load for the router.



**NOTE:** The circuit breaker box is not hot-removable or hot-pluggable. You must power down the router to remove the circuit breaker box.

**Action** To return a failed power supply, see “Return the Failed Component” on page 86. To replace the power supplies, see the appropriate router hardware guide.



## Chapter 19

# Monitoring the Cooling System

You monitor and maintain the cooling system to keep an acceptable operating temperature for the router chassis and its components. (See Table 67.)

**Table 67: Checklist for Monitoring the Cooling System**

Monitor Cooling System Tasks	Command or Action
<b>Understanding the Cooling System on page 252</b>	
■ M5 and M10 Router Cooling Systems on page 253	
■ M7i Router Cooling System on page 253	
■ M10i Router Cooling System on page 254	
■ M20 Router Cooling System on page 255	
■ M40 Router Cooling System on page 256	
■ M40e and M160 Router Cooling Systems on page 259	
■ M320 Router Cooling System on page 261	
■ T320 Router and T640 Routing Node Cooling Systems on page 263	
<b>Checking the Cooling System Status on page 267</b>	show chassis environment
<b>Checking the Cooling System Alarms on page 269</b>	
1. Check the Alarm Indicators on the Craft Interface on page 270	show chassis craft-interface Check the router craft interface.
2. Display Current Cooling System Alarms on page 270	show chassis alarms
3. Display Cooling System Error Messages in the System Log File on page 271	show log messages   match fan
<b>Maintaining the Air Filter on page 272</b>	Inspect the air filter. If dirty, clean it; if damaged, replace it.
<b>Verifying a Fan Failure on page 272</b>	Perform a swap test on the fan. If defective, replace it without powering down the router.
<b>Verifying an Impeller Failure on page 273</b>	Feel the impeller air exhaust. If no airflow, replace without powering down the router.
<b>Replacing a Cooling System Component on page 273</b>	Follow the procedure in the appropriate router hardware guide.

## Understanding the Cooling System

**Purpose** Inspect the router cooling system to ensure that air is flowing through the router to cool the components installed in the router chassis. If the router temperature exceeds the critical level, the router automatically shuts down.

**What Is the Cooling System** The cooling system includes the fans and impellers that provide cooling in the router chassis to keep the components operating at an acceptable temperature.

Table 68 describes the cooling system components for each routing platform.

**Table 68: Router Cooling System Components Per Routing Platform**

Power Supply Characteristic	M5/ M10	M7i	M10i	M20	M40	M40e	M160	M320	T320	T640
Fan tray	1 with 4 fans	1 with 4 fans	2 with 8 fans each	3 front 1 rear		1	1 lower fan tray	2 front, 1 rear	2 front 1 rear	2 front 1 rear
Power supply integrated fan	—	—	—	2	2	—	Cooled by air flowing through the chassis	—	—	—
Impellers	—	—	—	—	2 pairs	1 central impeller 1 rear upper impeller 1 rear lower impeller	1 upper impeller 2 rear impellers	—	—	—
Fan assemblies	—	—	—	—	3	—	—	—	—	—
Air filter	—	—	—	—	1	1	1	1 front, 1 rear	1 front 1 rear	1 front 1 rear

The following sections describe the various routing platform cooling systems:

- M5 and M10 Router Cooling Systems on page 253
- M7i Router Cooling System on page 253
- M10i Router Cooling System on page 254
- M20 Router Cooling System on page 255
- M40 Router Cooling System on page 256
- M40e and M160 Router Cooling Systems on page 259
- M320 Router Cooling System on page 261
- T320 Router and T640 Routing Node Cooling Systems on page 263


**M5 and M10 Router Cooling Systems**

The M5 and M10 router houses four fans, which draw room air into the chassis to keep the internal temperature below a maximum acceptable level. The air flows side-to-side in the chassis (see Figure 105).



**CAUTION:** Do not remove the fan tray for more than one minute while the router is operating. The fans are the sole source of cooling, and the router can overheat when they are absent.

**Figure 105: M5 and M10 Router Cooling System and Airflow**




**M7i Router Cooling System**

The M7i router cooling system consists of a fan tray, located along the left side of the chassis, that provides side-to-side cooling (see Figure 13). It connects directly to the router midplane. The fan tray is a single unit containing four individually fault-tolerant fans. If a single fan fails, the remaining fans continue to function indefinitely.

The cooling system draws in room air through the air intake vent on the left side of the chassis. After entering the chassis, the air stream separates into separate flows for the front and rear components (see Figure 106).

**Figure 106: M7i Router Cooling System and Airflow**




## M10i Router Cooling System

The M10i router cooling system consists of two fan trays, located along the left and right side of the chassis that provide side-to-side cooling. The fan trays house eight fans that draw room air into the chassis to maintain an acceptable operating temperature for the Routing Engine, Physical Interface Cards (PICs), Compact Forwarding Engine Board (CFEB), and other components. The fan trays connect directly to the router midplane. If a single fan fails, the remaining fans continue to function indefinitely (see Figure 107).

**Figure 107: M10i Router Cooling System and Airflow**

M10i




For proper airflow, the primary fan tray should be installed in slot 1 (the left slot looking at the chassis from the rear) and must be installed for proper cooling at all times. The redundant fan tray, if present, should be installed in slot 0 on the right. This fan tray provides additional cooling and redundancy.

## M20 Router Cooling System

The M20 router cooling system consists of the following components (see Figure 109):

- Three front fan trays—Cool the Flexible PIC Concentrators (FPCs) and the System and Switch Boards (SSBs). The fan trays are located on the left front side of the chassis. Each tray houses three fans.
- Routing Engine fan tray—Cools the Routing Engines. The fan tray is located behind the Routing Engine panel. It houses two fans.
- Power supply integrated fan—Cools each power supply. It is built into the supply.


**Figure 108: M20 Router Cooling System Components**



1770

The cooling system includes several fan trays that draw room air into the chassis to keep its internal temperature below a maximum acceptable level. The cooling subsystems have redundant components, which are controlled by the SSB. If a fan fails, the remaining fans provide sufficient cooling for the unit indefinitely (see Figure 109).

**Figure 109: M20 Router Cooling System and Airflow**



## M40 Router Cooling System

The M40 router cooling system consists of the following components:

- Air intake vent and air filter (see Figure 111 on page 257)—Provide an opening for room air to enter the router. They are located at the bottom of the chassis front, below the craft interface. The air filter prevents dust and other particles from entering the cooling system. For replacement instructions, see the M40 router hardware guide.



**CAUTION:** Do not remove the air filter for more than a minute while the router is operating. The fans and impellers are powerful enough to draw in foreign material, such as bits of wire, through the unfiltered air intake, which could damage router components.

- Upper and lower impeller assemblies (see Figure 110 on page 257)—Cool the Packet Forwarding Engine components (backplane, SCB, FPCs, and PICs). The lower impeller assembly is located behind the craft interface at the front the chassis, and the upper assembly is located above the fan tray at the rear of the chassis. Each assembly houses two impellers for redundancy. The assemblies are not interchangeable. For replacement instructions, see the M40 router hardware guide.
- Fan tray (see Figure 111 on page 257)—Cools the Routing Engine and backplane. The tray houses three fans for redundancy and is located above the Routing Engine at the upper rear of the chassis. For replacement instructions, see “Maintain and Replace the Fan Tray” on page 155.
- Power supply integrated fan—Cools the power supply. It is not field-replaceable.

Figure 110 shows the M40 router cooling system impeller trays.

**Figure 110: M40 Router Impeller Trays**






Figure 111 shows the M40 router air filter and fan tray.

**Figure 111: M40 Router Air Filter and Fan Tray**



The M40 router cooling system consists of separate subsystems (sets of fans and impellers) that draw room air into the chassis to keep its internal temperature below a maximum acceptable level. After entering the chassis, the air stream separates into separate flows for the front and rear subsystems, and the temperature of each flow is monitored independently. Figure 112 shows the M40 router cooling system airflow.

**Figure 112: M40 Router Cooling System and Airflow**





## M40e and M160 Router Cooling Systems

The M40e and M160 router cooling system has the following components:

- Air intake vent, air filter, and intake cover—Provide an opening for room air to enter the router. They are located at the bottom of the chassis front, below the cable management system, as shown in Figure 113 on page 260. The air filter is removable and covers the air intake vent, preventing dust and other particles from entering the cooling system. For maintenance and replacement instructions, see the M40e or M160 router hardware guide. The nonremovable air intake cover is located behind the air filter and provides EMC shielding.



**CAUTION:** Do not remove the air filter for more than a few minutes while the router is operating. The fans and impellers are powerful enough to draw in foreign material, such as bits of wire, through the unfiltered air intake, which could damage router components.


---

- Front cooling subsystem—Cools the FPCs, PICs, and midplane. It includes a fan tray located behind the cable management system and a large, central impeller behind the craft interface. For replacement instructions, see the M40e or M160 router hardware guide.
- Rear cooling subsystem—Cools the Switching and Forwarding Modules (SFMs), host module, Packet Forwarding Engine Clock Generator (PCGs), and power supplies. It includes one impeller located at the upper right of the chassis rear and another at the lower left. The upper and lower impellers are not interchangeable. For replacement instructions, see the M40e or M160 router hardware guide.


Figure 113 shows the M40e and M160 router cooling system components.

**Figure 113: M40e and M160 Router Cooling System Components**


**M40e and M160 router front**




**M40e and M160 router front**




**M40e and M160 router rear**



**M40e router rear**




**M160 router rear**



The cooling system draws in room air through the air intake vent located at the front of the chassis below the cable management system. After entering the chassis, the air stream separates into separate flows for the front and rear subsystems, and the Miscellaneous Control Subsystem (MCS) monitors the temperature of each flow independently.

Figure 114 shows the M40e and M160 router cooling system components and airflow.

**Figure 114: M40e and M160 Router Cooling System and Airflow**




### M320 Router Cooling System

The M320 cooling system consists of the following components (see Figure 115 on page 262):


- **Two front fan trays**—The front fan trays each contain four fans and are interchangeable. The front fan trays cool the components installed in the FPC card cage (the FPCs, PICs, Connector Interface Panel [CIP], and midplane).
- **Rear fan tray**—The rear fan tray contains seven fans and is not interchangeable with the front trays. The rear fan tray cools the components installed in the rear card cage (the Routing Engines, Control Boards, and the Switch Interface Boards [SIBs]).
- **Front and rear air filter**—Air filters for both the front and rear fan trays help keep dust and other particles from entering the cooling system.
- **Power supply fans**—Each power supply has two fans that cool that power supply.

**Figure 115: M320 Router Cooling System and Airflow**

M320 router front




M320 router rear



The host subsystem monitors the temperature of the router components. When the router is operating normally, the fans function at lower than full speed. If a fan fails or the ambient temperature rises above a threshold, the speed of the remaining fans is automatically adjusted to keep the temperature within the acceptable range. If the ambient maximum temperature specification is exceeded and the system cannot be adequately cooled, the Routing Engine shuts down some or all of the hardware components.

Figure 116 shows the M320 router airflow.

**Figure 116: M320 Router Cooling System and Airflow**



### T320 Router and T640 Routing Node Cooling Systems

The T320 cooling system consists of the following components:

- Two front fan trays—The front fan trays each contain six fans and are interchangeable. The fan trays in the front of the chassis, each with six fans, cool the components installed in the FPC card cage (the FPCs, PICs, CIP, and midplane).
- Rear fan tray—The rear fan tray contains five fans and is not interchangeable with the front trays. It cools the components installed in the rear card cage (the Routing Engines, Control Boards, PCGs, and SIBs).
- Front and rear air filter—Air filters for both the front and rear fan trays help keep dust and other particles from entering the cooling system.
- Power supply fans—The power supplies each have a fan that cools that power supply.

During normal operation, the fans in each fan tray function at less than full capacity. Temperature sensors on the midplane and the host subsystem control the speed of the fans. A fan failure triggers the red alarm LED on the craft interface. If the temperature passes a certain threshold, the JUNOS software turns off the power supplies.

Figure 117 shows the T320 router cooling system components.

**Figure 117: T320 Router Cooling System Components**




Figure 118 shows the T320 router airflow.

**Figure 118: T320 Router Cooling System and Airflow**




Figure 119 shows the T640 routing node airflow.

**Figure 119: T640 Routing Node Cooling System and Airflow**






Figure 120 shows the T640 routing node cooling system components.

**Figure 120: T640 Routing Node Cooling System Components**

**T640 front**



**T640 rear**



9003263

**See Also** “Monitoring Power Supplies” on page 217



## Checking the Cooling System Status

For the cooling system to operate properly, the clearance around the chassis must be sufficient for unobstructed airflow. For clearance and maintenance requirements, see the appropriate router hardware guide.

**Action** To check the cooling system status, use the following JUNOS command-line interface (CLI) operational mode command:

```
user@host> show chassis environment
```

**Sample Output** For M5 and M10 routers (see also Figure 105 on page 253):

```
user@host> show chassis environment
Class Item                Status      Measurement
[...Output truncated...]
Fans  Left Fan 1            OK          Spinning at normal speed
      Left Fan 2            OK          Spinning at normal speed
      Left Fan 3            OK          Spinning at normal speed
      Left Fan 4            OK          Spinning at normal speed
Misc  Craft Interface        OK
```

For M7i routers (see also Figure 106 on page 253):

```
user@host> show chassis environment
Class Item                Status      Measurement
[...Output truncated...]
Fans  Fan 1                  OK          Spinning at normal speed
      Fan 2                  OK          Spinning at normal speed
      Fan 3                  OK          Spinning at normal speed
      Fan 4                  OK          Spinning at normal speed
```

For M10i routers (see also Figure 107 on page 254):

```
user@host> show chassis environment
Class Item                Status      Measurement
[...Output truncated...]
Fans  Fan Tray 0 Fan 1        OK          Spinning at normal speed
      Fan Tray 0 Fan 2        OK          Spinning at normal speed
      Fan Tray 0 Fan 3        OK          Spinning at normal speed
      Fan Tray 0 Fan 4        OK          Spinning at normal speed
      Fan Tray 0 Fan 5        OK          Spinning at normal speed
      Fan Tray 0 Fan 6        OK          Spinning at normal speed
      Fan Tray 0 Fan 7        OK          Spinning at normal speed
      Fan Tray 0 Fan 8        OK          Spinning at normal speed
      Fan Tray 1 Fan 1        OK          Spinning at normal speed
      Fan Tray 1 Fan 2        OK          Spinning at normal speed
      Fan Tray 1 Fan 3        OK          Spinning at normal speed
      Fan Tray 1 Fan 4        OK          Spinning at normal speed
      Fan Tray 1 Fan 5        OK          Spinning at normal speed
      Fan Tray 1 Fan 6        OK          Spinning at normal speed
      Fan Tray 1 Fan 7        OK          Spinning at normal speed
      Fan Tray 1 Fan 8        OK          Spinning at normal speed
```

For an M20 router (see also Figure 109 on page 256):

```
user@host> show chassis environment
Class Item                Status      Measurement
[...Output truncated...]
Fans  Rear Fan              OK          Spinning at normal speed
      Front Upper Fan      OK          Spinning at normal speed
      Front Middle Fan     OK          Spinning at normal speed
      Front Bottom Fan     OK          Spinning at normal speed
Misc  Craft Interface      OK
```

For an M40 router (see also Figure 112 on page 258):

```
user@host> show chassis environment
Class Item                Status      Measurement
[...Output truncated...]
Fans  Top Impeller          OK          Spinning at normal speed
      Bottom impeller      OK          Spinning at normal speed
      Rear Left Fan        OK          Spinning at normal speed
      Rear Center Fan      OK          Spinning at normal speed
      Rear Right Fan       OK          Spinning at normal speed
Misc  Craft Interface      OK
```

For M40e and M160 routers (see also Figure 114 on page 261):

```
user@host> show chassis environment
Class Item                Status      Measurement
[...Output truncated...]
Fans  Rear Bottom Blower     OK          Spinning at normal speed
      Rear Top Blower      OK          Spinning at normal speed
      Front Top Blower     OK          Spinning at normal speed
      Fan Tray Rear Left   OK          Spinning at normal speed
      Fan Tray Rear Right  OK          Spinning at normal speed
      Fan Tray Front Left  OK          Spinning at normal speed
      Fan Tray Front Right OK          Spinning at normal speed
Misc  CIP                   OK
```

For M320 routers (see also Figure 116 on page 263):

```
user@host> show chassis environment
Class Item                Status      Measurement
Fan    Top Left Front fan    OK          Spinning at normal speed
      Top Right Rear fan  OK          Spinning at normal speed
      Top Right Front fan OK          Spinning at normal speed
      Top Left Rear fan   OK          Spinning at normal speed
      Bottom Left Front fan OK          Spinning at normal speed
      Bottom Right Rear fan OK          Spinning at normal speed
      Bottom Right Front fan OK          Spinning at normal speed
      Bottom Left Rear fan OK          Spinning at normal speed
      Rear Fan 1 (TOP)    OK          Spinning at normal speed
      Rear Fan 2          OK          Spinning at normal speed
      Rear Fan 3          OK          Spinning at normal speed
      Rear Fan 4          OK          Spinning at normal speed
      Rear Fan 5          OK          Spinning at normal speed
      Rear Fan 6          OK          Spinning at normal speed
      Rear Fan 7 (Bottom) OK          Spinning at normal speed
```

For T320 routers and T640 routing nodes (see also Figure 118 on page 264, Figure 117 on page 264, Figure 119 on page 265, and Figure 120 on page 266):

```
user@host> show chassis environment
```

Class	Item	Status	Measurement
Fans	Top Left Front fan	OK	Spinning at normal speed
	Top Left Middle fan	OK	Spinning at normal speed
	Top Left Rear fan	OK	Spinning at normal speed
	Top Right Front fan	OK	Spinning at normal speed
	Top Right Middle fan	OK	Spinning at normal speed
	Top Right Rear fan	OK	Spinning at normal speed
	Bottom Left Front fan	OK	Spinning at normal speed
	Bottom Left Middle fan	OK	Spinning at normal speed
	Bottom Left Rear fan	OK	Spinning at normal speed
	Bottom Right Front fan	OK	Spinning at normal speed
	Bottom Right Middle fan	OK	Spinning at normal speed
	Bottom Right Rear fan	OK	Spinning at normal speed
	Fourth Blower from top	OK	Spinning at normal speed
	Bottom Blower	OK	Spinning at normal speed
	Middle Blower	OK	Spinning at normal speed
	Top Blower	OK	Spinning at normal speed
	Second Blower from top	OK	Spinning at normal speed

**What It Means** The command output shows the fans, impellers, or blowers monitored for the router type. The command output displays the fan, impeller, or blower status and the spinning speed. **Top Left** and **Top Right** refer to fans in the upper front fan tray; **Bottom Left** and **Bottom Right** refer to fans in the lower front fan tray; **Blower** refers to fans in the rear fan tray. The status can be **OK**, **Testing** (during initial power-on), **Failed**, or **Absent**. Measurement indicates if the fan or impeller is spinning at normal or high speed.

## Checking the Cooling System Alarms

For a listing of cooling system alarm conditions, remedy, and alarm severity by routing platform type, see “Display the Current Router Alarms” on page 61.

**Steps To Take** To check for cooling system alarms, follow these steps:

1. Check the Alarm Indicators on the Craft Interface on page 270
2. Display Current Cooling System Alarms on page 270
3. Display Cooling System Error Messages in the System Log File on page 271

## Step 1: Check the Alarm Indicators on the Craft Interface

**Action** To check the craft interface alarm indicators, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output** user@host> **show chassis craft-interface**

```
Status      Measurement
Red alarm:   LED on, relay on
Yellow alarm: LED off, relay off
Host OK LED: On
Host fail LED: Off
```

[...Output truncated...]

LCD screen:

```
+-----+
|myrouter|
|2 Alarms active|
|R: Fan Failure|
|R: Fan Removed|
+-----+
```

**What It Means** The command output displays the alarm indicator status. The alarm indicators can be either On or Off. If an indicator is on, an alarm has occurred. The command output also displays the active alarms on the craft interface LCD display. To list the current alarms, use the **show chassis alarms** command.

**Alternative Action** You can also physically view the craft interface to see the alarm indicators and alarm descriptions displayed on the LCD display.

## Step 2: Display Current Cooling System Alarms

For information that triggers cooling system alarms in each router type, see “Gather Component Alarm Information” on page 60. For fan alarms by router type, see Table 69 on page 271.

**Action** To display the current cooling system alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output** user@host> **show chassis alarms**

```
2 alarms currently active
Alarm time      Class Description
2002-04-08 15:25:12 PDT Major Rear left fan stopped spinning
2002-04-08 15:25:12 PDT Major Rear left fan Failure
```

**What It Means** The command output displays the current cooling system alarms, including the time and date stamp, severity level, and description. Table 69 on page 271 shows the possible cooling system alarms for each router type. The alarm LCD short version appears on the craft interface LCD display. The alarm long version appears at the CLI when you use the **show chassis alarms** command.

**Table 69: Cooling System Alarm Messages**

Routing Platform	LCD Short Version	CLI Long Version
M5 and M10	N/A	<i>fan-name</i> stopped spinning
	N/A	<i>fan-name</i> removed
	N/A	Too few fans installed or working
M7i and M10i	N/A	<i>fan-name</i> stopped spinning
	N/A	<i>fan-name</i> removed
	N/A	Too few fans installed or working
M20	N/A	<i>fan-name</i> stopped spinning
	N/A	<i>fan-name</i> removed
	N/A	Too few fans installed or working
M40	<i>fan-name</i> FAIL	<i>fan-name</i> stopped spinning
	<i>fan-name</i> RMVD	<i>fan-name</i> removed
	Too few fans	Too few fans installed or working
M40e and M160	Fan Failure	RED ALARM - <i>fan-name</i> Failure
	Fan Removed	YELLOW ALARM - <i>fan-name</i> Removed
	Fans Missing	RED ALARM - Too many fans missing or failing
T320 and T640	Fan Failure	RED ALARM - <i>fan-name</i> Failure
	Fan Removed	YELLOW ALARM - <i>fan-name</i> Removed
	Fans Missing	RED ALARM - Too many fans missing or failing

### Step 3: Display Cooling System Error Messages in the System Log File

**Action** To view cooling system error messages in the system log file, use the following CLI command:

```
user@host> show log messages | match fan
```

**Sample Output**

```
user@host> show log messages | match fan
Apr  8 14:00:15 myrouter scb CM: ALARM SET: (Major) Power Supply A fan failed
Apr  8 14:00:15 myrouter alarmd[584]: Alarm cleared: Pwr supply color=RED,
class=CHASSIS, myrouter=Power Supply A fan failed
Apr  8 14:00:18 myrouter scb CM: ALARM CLEAR: Power Supply A fan failed
Apr  8 14:00:21 myrouter alarmd[584]: Alarm set: Pwr supply color=RED,
class=CHASSIS, reason=Power Supply A fan failed
Apr  8 14:00:23 myrouter scb CM: ALARM SET: (Major) Rear left fan stopped
spinning
Apr  8 14:05:16 myrouter alarmd[584]: Alarm set: Fan color=RED, class=CHASSIS,
reason=Rear left fan stopped spinning
```

**What It Means** The messages system log file records the time when the failure or event occurred, the severity level, a code, and a message description. Use the `show log messages | match fan` command to view only fan error messages. Use this information to diagnose a cooling system problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events prior to the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Maintaining the Air Filter

---

**Action** To maintain the air filter on M40, M40e, M160, and T320 routers and T640 routing nodes, follow these steps:

1. Check the air filter for dust, debris, or holes. If the air filter needs cleaning, clean it as described in the appropriate hardware guide.
2. If the air filter needs repair, replace it as described in the appropriate hardware guide.



**CAUTION:** Because the impellers and fans are quite powerful, it is important to keep the air filter in place while the router is operating. The impellers and fans could pull in foreign material, such as bits of wire, through an unfiltered air intake, resulting in damage to router components.

---

## Verifying a Fan Failure

---

**Action** To verify a fan failure, follow these steps:

1. Perform a swap test on the fan. Remove the problem fan tray and put it into another bay. If the fan tray does not work in the other bay, it is probably faulty and must be replaced. If the fan tray works in another bay, there is probably a problem with the power connectivity from the midplane.
2. Check the fan power connector.
3. Check the fan connector on the router midplane.
4. If the fan fails, replace it as described in the appropriate hardware guide. The fans are hot-removable and hot-insertable. You can replace the fans without powering down the router.



**NOTE:** The cooling system components (fans and impellers) do not have serial numbers. Therefore, you will not see a serial number listed in the hardware inventory or a serial number ID label on the component.

---

## Verifying an Impeller Failure

---

**Action** To verify an impeller failure, follow these steps:

1. Place your hand near the exhaust in the router chassis to determine whether the impellers are pushing air out. If you do not feel much air or no air at all, the impeller is not working.
2. If the impeller fails, replace it as described in the appropriate hardware guide. The impellers are hot-removable and hot-insertable. You can replace the fans without powering down the router.



**NOTE:** The cooling system components (fans and impellers) do not have serial numbers. Therefore, you will not see a serial number listed in the hardware inventory or a serial number ID label on the component.

---

## Replacing a Cooling System Component

---

The cooling system components are hot-removable and hot-insertable. You can remove or replace a cooling system component without powering down the system and disrupting routing functions. However, you should not operate a router for more than a few minutes without the air filter in place to avoid dust, particles, or other material being sucked into the router chassis.

**Action** To replace a cooling system component, see the appropriate router hardware guide.





## Chapter 20

# Maintaining the Cable Management System, Cables, and Connectors

You maintain the router cables in the cable management system to ensure that fiber-optic cables have the proper bend radius and to ensure that all cables are organized and securely in place.

You maintain the Physical Interface Card (PIC) cables and connectors to ensure that they transport incoming packets from the network and transmit outgoing packets to the network.

You maintain the power cables and connectors to ensure that power is supplied to the router.

You maintain the Routing Engine external cables and connectors to ensure that you can connect external devices to the router. (See Table 70.)

**Table 70: Checklist for Maintaining Cables and Connectors**

Maintain Cable and Connector Tasks	Command or Action
<b>Understanding the Cable Management System, Cables, and Connectors on page 276</b>	
■ M5 and M10 Router Cable Management System on page 277	
■ M10i Router Cable Management System on page 277	
■ M20 Router Cable Management System on page 278	
■ M40 Router Cable Management System on page 279	
■ M40e and M160 Router Cable Management System on page 280	
■ M320 Router Cable Management System on page 280	
■ T320 Router and T640 Routing Node Cable Management System on page 281	
<b>Maintaining the PIC Cables on page 281</b>	Use only specified cables and connectors.
<b>Maintaining the PIC Fiber-Optic Cable on page 282</b>	Follow all guidelines to ensure that fiber-optic cables transmit packets to and from the network.
<b>Cleaning the Transceivers on page 282</b>	Follow all procedures in the cleaning kit you use. See the appropriate router hardware guide and the PIC hardware guide.

Maintain Cable and Connector Tasks	Command or Action
<b>Checking the PIC Port Status on page 283</b>	
1. Check the PIC or FPC LED Status on page 283	Check the PIC LEDs.
2. Display the PIC Media Type on page 284	show chassis fpc pic-status show chassis pic pic-slot <i>number</i> fpc-slot <i>number</i>
<b>Maintaining the Power Cables on page 285</b>	Use the specified cables and connectors. Turn power off to the router, then reconnect power using the replacement cables.
<b>Maintaining Routing Engine External Cables on page 285</b>	Turn off the power switch, if necessary. Use the specified cable and connector.
<b>Replacing the Cable Management System on page 285</b>	See “Return the Failed Component” on page 86, or follow the procedure in the appropriate router hardware guide.

## Understanding the Cable Management System, Cables, and Connectors

**Purpose** Inspect the router cables in the cable management system to ensure that fiber-optic cables have the proper bend radius and that all cables are organized and securely in place.

Inspect the PIC cables and connectors to ensure that they transport incoming packets from the network and transmit outgoing packets to the network.

Inspect the power cables and connectors to ensure that power is supplied to the router.

Inspect the Routing Engine external cables and connectors to ensure that you can connect external devices to the router.

**What Is the Cable Management System** All Juniper Networks routers have a method of cable management. Although you are not required to use the cable management system, we recommend that you do so. The cable management system maintains the proper bend radius for fiber-optic PIC cables. It keeps installed cables organized, securely in place, and tangle free.


The following sections describe the location of the cable management system on each routing platform.

- M5 and M10 Router Cable Management System on page 277
- M10i Router Cable Management System on page 277
- M20 Router Cable Management System on page 278
- M40 Router Cable Management System on page 279
- M40e and M160 Router Cable Management System on page 280
- M320 Router Cable Management System on page 280
- T320 Router and T640 Routing Node Cable Management System on page 281

### **M5 and M10 Router Cable Management System**

The M5 and M10 router cable management system consists of two vertical pieces, each with a pair of metal hooks draped in a plastic shield, that attach to each side of the front of the chassis. (See Figure 121.)


**Figure 121: M5 and M10 Router Cable Management System**



### **M10i Router Cable Management System**

The M10 router cable management system consists of racks that attach vertically to each side of the chassis at the front, as shown in Figure 122. Pass PIC cables through the slots in the racks to keep the cables organized and securely in place, and to avoid bending optical cables beyond the proper bend radius. The cable management system evenly distributes the weight of a cable, so that it is not subjected to undue stress at the connector.


**Figure 122: M10i Router Cable Management System**



## M20 Router Cable Management System

The M20 router cable management system consists of two vertical pieces that attach to each side of the front of the chassis. Each piece consists of a row of staggered metal hooks, each draped with a rounded plastic shield. (See Figure 123.)


**Figure 123: M20 Router Cable Management System**



### M40 Router Cable Management System

The M40 router cable management system consists of a row of staggered metal hooks, each draped with a rounded plastic shield. The row of hooks is shielded by a removable cable management system cover. (See Figure 124.)


**Figure 124: M40 Router Cable Management System and Cover**



### M40e and M160 Router Cable Management System

The M40e and M160 router cable management system consists of a row of nine semicircular plastic bobbins mounted on the front of the chassis below the Flexible PIC Concentrator (FPC) card cage. PIC cables wrap around the bobbins, keeping the cables organized and securely in place. (See Figure 125.)

**Figure 125: M40e and M160 Routers Cable Management System**




### M320 Router Cable Management System

The M320 router cable management system consists of a row of nine semicircular plastic bobbins mounted on the front of the router below the FPC card cage (see Figure 126). The PIC cables pass between the bobbins and into the tray, keeping the cables organized and securely in place. The curvature of the bobbins also helps maintain the proper bend radius for optical PIC cables.

You can pull the cable management system up and outward to lock it into the maintenance position. This allows you to access the lower fan tray and the front air filter.


**Figure 126: M320 Router Cable Management System**



### T320 Router and T640 Routing Node Cable Management System

The T320 router and T640 routing node cable management system consists of a row of nine semicircular plastic bobbins mounted on the front of the chassis below the FPC card cage. PIC cables wrap around the bobbins, keeping the cables organized and securely in place. (See Figure 127.)

**Figure 127: T320 Router and T640 Routing Node Cable Management System**



### Maintaining the PIC Cables

**Action** To maintain the PIC cables, follow these guidelines:

- Make sure that you use the cable and connector type that is specified in the appropriate router hardware guide, especially for the cable and connectors that are not supplied, such as the single-mode interface (fiber) and multimode interface (fiber).
- Make sure that all cable connectors are securely connected. Securely screw in the cable connector screws.
- Use the cable management system to support cables and prevent them from being dislodged or developing stress points.
- Place excess cable out of the way in the cable management system and place fasteners on the loop to help to maintain the shape of the cables. Do not allow fastened loops of cable to dangle from the system, as this stresses the cable at the fastening point.
- Keep the cable connections clean and free of dust and other particles which can cause drops in the received power level. Always inspect cables and clean them if necessary before connecting an interface.
- Label all PIC cables to identify them. Label each end of the cable the same way.

## Maintaining the PIC Fiber-Optic Cable

---

**Action** To maintain the PIC fiber-optic cable, follow these guidelines:

- Avoid bending fiber-optic cable beyond its bend radius. An arc smaller than a few inches can damage the cable and cause problems that are difficult to diagnose.
- Anchor fiber-optic cable to avoid stress on the connectors. When attaching fiber to a PIC, secure the fiber so it is not supporting its own weight as it dangles to the floor. Never let fiber-optic cable hang free from the connector.
- When you unplug a fiber-optic cable from a PIC, always place a rubber safety plug over the connector.
- Keep fiber-optic cable connections clean using an appropriate fiber-cleaning device, such as the RIFOCS 945/946 Fiber-Optic Connector Cleaning System. Follow the guidelines in the appropriate router hardware guide.
- Frequent plugging and unplugging of fibers into or out of optical instruments, such as SONET or Asynchronous Transfer Mode (ATM) analyzers, can damage the instruments, which are expensive to repair. We recommend attaching a short fiber extension to the optical equipment. Any wear and tear due to frequent plugging and unplugging is then absorbed by the short fiber extension, which is easy and inexpensive to replace.
- If a fiber-optic cable is damaged, replace it as described in the appropriate router hardware guide.



**CAUTION:** If you do not have a replacement rubber plug in your hand, do not unplug the fiber-optic cable from a PIC. The safety plug keeps the connection clean and prevents accidental exposure to light that might be emitted, which can damage your eyes.

---



**CAUTION:** Do not look directly into the PICs installed in the FPC or into the ends of fiber-optic cable. PICs that use SONET/SDH or ATM single-mode fiber-optic cable contain laser light sources that can damage your eyes.

---

## Cleaning the Transceivers

---

To clean the transceivers, use an appropriate fiber-cleaning device, such as RIFOCS Fiber Optic Adaptor Cleaning Wands (part number 946). Follow the directions for the cleaning kit you use.

After you have cleaned the transceiver on the fiber-optic PIC, make sure that the connector tip of the fiber-optic cable is clean. Use only an approved alcohol-free fiber-optic cable cleaning kit, such as the Optex Cletop-S® Fiber Cleaner. Follow the directions for the cleaning kit you use.



## Checking the PIC Port Status

**Steps To Take** To check the PIC port status, follow these steps:

1. Check the PIC or FPC LED Status on page 283
2. Display the PIC Media Type on page 284

### Step 1: Check the PIC or FPC LED Status

**Action** To view the PIC port status, look at the PIC or FPC LEDs. You can also use the `show chassis fpc pic-status fpc-slot` or the `show chassis pic pic-slot number fpc-slot number` CLI commands.

For M5, M10, and M20 routers, each port on each PIC has one LED, which is located on the PIC faceplate above the optical transceiver. Each LED has four different states, described in Table 71. If the cable is installed properly, the PIC port LED is green.

For M5 and M10 routers, if the Forwarding Engine Board (FEB) detects a PIC failure, it sends an alarm to the Routing Engine.

**Table 71: M5, M10, and M20 Router PIC LEDs**

Color	State	Description
Red	Fail	PIC is online but the link has failed.
Green	Normal	Port is functioning normally.
Yellow	Problem detected; still functioning	To track the problem, use the command-line interface (CLI).
None	Not enabled	Port is not enabled.

For M7i and M10i routers, check the LEDs on the PIC faceplates. Most PIC faceplates have an LED labeled **STATUS**. Some PICs have additional LEDs, often one per port. The meaning of the LED states differs for various PICs. Each PIC has an LED on the PIC labeled **PICS ON/OFF** that shows whether the PIC is online.

For M20 routers, if the FPC that houses the PIC detects a PIC failure, the FPC informs the System and Switch Board (SSB), which in turn sends an alarm to the Routing Engine.

For M40 routers, each FPC has two LEDs that report its status as **OK** or **Fail**. The LEDs are located below each FPC, on the craft interface. If there is a PIC failure, the **FPC Fail LED** lights.

For M40e, M160, and T320 routers and T640 routing nodes, each of the eight FPC slots in the router has two LEDs and an offline button located directly above it on the craft interface. The green LED labeled **OK** and the red LED labeled **FAIL** indicate the FPC status, as described in Table 72 on page 284. The offline button, labeled with the FPC slot number (for example, **FPC4**), prepares the FPC for removal from the router when pressed. Press and hold the button for about 3 seconds until the **FAIL LED** lights.

Each FPC slot has two LEDs that indicate its status. The FPC LEDs, labeled FPC0 through FPC7, are located along the bottom of the craft interface. Table 72 describes the functions of the FPC LEDs. Each FPC also has a button that you use to take the FPC offline and bring it online. The button is located next to the FPC LEDs on the bottom of the craft interface.

**Table 72: M40e, M160, and T320 Routers and T640 Routing Node FPC LEDs**

Label	Color	State	Description
OK	Green	On steadily	FPC is functioning normally.
		Blinking	FPC is starting up.
FAIL	Red	On steadily	FPC has failed.

## Step 2: Display the PIC Media Type

**Action** To display the PIC media type, use the following JUNOS operational mode CLI command:

```
user@host> show chassis fpc pic-status
```

**Sample Output** user@host> show chassis fpc pic-status

```
Slot 0 Online
  PIC 0    1x OC-12 SONET, MM
  PIC 1    4x OC-3 SONET, SMIR
  PIC 2    4x E1, BNC
  PIC 3    1x CSTM1, SMIR
Slot 1 Online
  PIC 0    4x CT3
Slot 2 Online
  PIC 0    1x Tunnel
Slot 4 Online
Slot 5 Offline
Slot 6 Online
  PIC 0    1x OC-192 12xMM VSR
```

**What It Means** The command output displays the status for all FPCs installed in the router and a description of the PICs installed in each FPC, including the number of ports, media type, mode, and reach. The FPCs in slots 0, 1, 2, 4, and 6 are online. The FPC in slot 5 is offline. The PICs installed in the router include SONET, E1, Channelized STM1, CT3, Tunnel, and OC192 media PICs.

PIC 0 is one-port, SONET, OC12, and multimedia.

For more detailed information about PIC types, see the appropriate PIC guide.

**Alternative Action** To view a particular PIC status, use the `show chassis pic pic-slot number fpc-slot number` CLI command:

```
user@host> show chassis pic pic-slot 0 fpc-slot 1
PIC fpc slot 1 pic slot 0 information:
  Type                1x Tunnel
  ASIC type           Tunnel FPGA
  State               Online
  PIC version         1.2
  Uptime              4 hours, 40 minutes, 53 seconds
```

## Maintaining the Power Cables

---

**Action** To maintain the power cables, follow these guidelines:

- Make sure that the power and ground cables on each DC power supply are arranged so that they do not obstruct access to the other power supply or to other router components.
- Periodically inspect the site to ensure that the cables connected to the power supply are securely in place and are properly insulated.
- If power cables are damaged, replace them. To replace power cables, you must disconnect power to the router, then reconnect power using the replacement cables. Follow the guidelines in the appropriate router hardware guide.

## Maintaining Routing Engine External Cables

---

The CIP contains connectors for connecting the Routing Engines to a console, a network, an external management device, or an external alarm device.

**Action** To maintain the Console or Auxiliary Port cable, the Ethernet Management cable, or the alarm relay cables, see the appropriate router hardware guide.

## Replacing the Cable Management System

---

The cable management system is hot-removable and hot-insertable. You can remove or replace the cable management system without powering down the system and disrupting routing functions.

**Action** To replace the cable management system, see the appropriate router hardware guide.



## Part 4

# **Monitoring M320 and T320 Router and T640 Routing Node-Specific Components**

- Monitoring the Host Subsystem on page 289
- Monitoring the Control Board on page 301
- Monitoring the SCGs on page 315
- Monitoring the SIBs on page 325



## Chapter 21

# Monitoring the Host Subsystem

You monitor and maintain the host subsystem (the Routing Engine and the Control Board) on the routing platform, which provides the routing and system management functions for the router. (See Table 68.)

**Table 68: Checklist for Monitoring the Host Subsystem**

Monitor Host Subsystem Tasks	Command or Action
<b>Understanding the Host Subsystem on page 290</b>	
■ M320 and T320 Router and T640 Routing Node Routing Engines on page 291	
■ M320 and T320 Router and T640 Routing Node Control Boards on page 292	
■ Host Subsystem Location on page 294	
<b>Checking the Host Subsystem Status on page 295</b>	show chassis craft-interface Look at the LEDs on the craft interface or the component faceplate.
<b>Checking the Routing Engine Status on page 297</b>	show chassis routing-engine show chassis environment routing-engine
<b>Checking the Control Board Status on page 298</b>	show chassis environment cb

This chapter provides basic information about monitoring the host subsystem components: the Routing Engine and the Control Board. For more detailed information about monitoring the Routing Engine, see “Monitoring the Routing Engine” on page 125. For more detailed information about monitoring the Control Board, see “Monitoring the Control Board” on page 301.

## Understanding the Host Subsystem

---

**Purpose** Inspect the host subsystem to ensure that the Routing Engine and Control Board function properly.

**What Is a Host Subsystem** The host subsystem provides routing and system management functions on the M320 and T320 routers and the T640 routing node. The host subsystem is comprised of two components: the Routing Engine and the Control Board. For a host subsystem to function, both of these components must be installed and operational.

The Routing Engine maintains the routing tables used by the router and controls the routing protocols that run on the router.

The Control Board provides control and monitoring functions for the router—determining Routing Engine mastership, controlling power, performing reset and SONET clocking for the other router components, monitoring and controlling fan speed, and monitoring system status using I<sup>2</sup>C controllers.

You can install one or two host subsystems on the router. You can install one or two Routing Engines. The Routing Engines install into the upper rear of the chassis in the slots labeled **RE0** and **RE1**. If two Routing Engines are installed, one functions as master and the other acts as backup. If the master Routing Engine fails or is removed, and the backup is configured appropriately, the backup restarts and becomes master. The Routing Engines are hot-pluggable. Each Routing Engine requires that a Control Board be installed in the adjacent slot.

The Control Boards install into the upper rear of the chassis in the slots labeled **CB0** and **CB1**. If two Control Boards are installed, one functions as master and the other acts as backup. If the master Control Board fails or is removed, the backup restarts and becomes master. The Control Boards are hot-pluggable. Each Control Board requires a Routing Engine to be installed in the adjacent slot. **CB0** installs above **RE0**, and **CB1** installs below **RE1**. A Control Board does not function if no Routing Engine is present in the adjacent slot.




## M320 and T320 Router and T640 Routing Node Routing Engines

The following sections describe the Routing Engine component used on each routing platform.

### M320 Router Routing Engine

Figure 116 shows the Routing Engine component used on the M320 router.


**Figure 116: M320 Router Routing Engine Component**



### T320 Router and T640 Routing Node Routing Engine

Figure 117 shows the Routing Engine component used on the T320 router and T640 routing node.

**Figure 117: T320 Router and T640 Routing Node Routing Engine Component**




## M320 and T320 Router and T640 Routing Node Control Boards

The following sections describe the Control Board used on each routing platform.

### M320 Router Control Board

Figure 118 shows the Control Board component used on the M320 router.


**Figure 118: M320 Router Control Board Component**



### T320 Router Control Board

Figure 119 shows the T320 router Control Board component of the host subsystem.


**Figure 119: T320 Router Control Board Component**



### T640 Routing Node Control Board

Figure 120 shows the T640 routing node Control Board component of the host subsystem.


**Figure 120: T640 Routing Node Control Board Component**



## Host Subsystem Location

Figure 121 shows the location of the host subsystem components on the M320 and T320 routers and the T640 routing node.

**Figure 121: M320 and T320 Router and T640 Routing Node Host Subsystem Location**



You can install one or two host subsystems into the midplane from the rear of the chassis. Each host subsystem functions as a unit: the Routing Engine requires the corresponding Control Board to operate, and vice-versa. If the adjacent component is not present, the Routing Engine or Control Board will not function. RE0 installs below CB0, and RE1 installs above CB1 otherwise the circuit will not be connected.

You take the host subsystem offline and online as a unit. Before you replace a Routing Engine or a Control Board, you must take the host subsystem offline. The host subsystem is hot-pluggable.

- See Also**
- Monitoring the Routing Engine on page 125
  - Monitoring the Control Board on page 301
  - Host Redundancy Overview on page 463
  - Monitoring Redundant Routing Engines on page 491
  - Monitoring Redundant Control Boards on page 559

## Checking the Host Subsystem Status

Each host subsystem has three LEDs that display its status. The host subsystem LEDs are located on the right side of the craft interface.

To check the host subsystem status, use the following JUNOS command-line interface (CLI) operational mode command:

```
user@host> show chassis craft-interface
```

**Sample Output** m320@host> show chassis craft-interface

```
FPM Display contents:
+-----+
|router001|
|2 Alarms active      |
|R: PEM 1 Not OK      |
|R: PEM 0 Not OK      |
+-----+

Front Panel System LEDs:
Routing Engine    0    1
-----
OK                *    *
Fail              .    .
Master            *    .
[...Output truncated...]
```

**What It Means** On M320 and T320 routers and T640 routing nodes, the Front Panel System LEDs section of the command output shows the Routing Engine status. The state can be OK, Fail, or Master. An asterisk (\*) indicates the operating state.

**Alternative Actions** Check the LEDs on the Routing Engine and the Control Board faceplates at the rear of the router.

Check the Routing Engine or Host Subsystem LEDs on the craft interface. If the red LED is lit, look at the LCD display for more information about the cause of the problem.

Figure 122 shows the location of the Routing Engine LEDs on the M320 router craft interface.

**Figure 122: M320 Router Host Subsystem Craft Interface LEDs**




Table 69 describes the M320 router Routing Engine LED states.

**Table 69: M320 Router Routing Engine Craft Interface LEDs**

Label	Color	State	Description
FAIL	Red	On steadily	Host is offline.
OK	Green	On steadily	Host is online and is functioning normally.
MASTER	Green	On steadily	Host is functioning as master.

Figure 123 shows the location of the Host Subsystem LEDs on the T320 router and T640 routing node craft interface.

Each host subsystem has LEDs, located on the upper right of the craft interface, which indicate its status. The LEDs labeled **HOST0** show the status of the Routing Engine in slot **RE0** and the Control Board in slot **CB0**. The LEDs labeled **HOST1** show the status of the Routing Engine in slot **RE1** and the Control Board in slot **CB1**.

**Figure 123: T320 Router and T640 Routing Node Host Subsystem Craft Interface LEDs**




Table 70 describes the T320 router and T640 routing node host subsystem LED states.

**Table 70: T320 Router and T640 Routing Node Host Subsystem Craft Interface LEDs**

Label	Color	State	Description
OK	Green	On steadily	Host is online and functioning normally.
FAIL	Red	On steadily	Host is offline.
MASTER	Green	On steadily	Host is functioning as master.

## Checking the Routing Engine Status

This section provides a brief description of monitoring the Routing Engines as part of the host subsystem on the T320 router and T640 routing node. For more detailed information about monitoring the Routing Engine, see “Monitoring the Routing Engine” on page 125.

**Action** To check the Routing Engine status, use the following CLI command:

```
user@host> show chassis routing-engine
```

**Sample Output**

```
user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             28 degrees C / 82 degrees F
  CPU temperature         27 degrees C / 80 degrees F
  DRAM                    2048 MB
  Memory utilization      11 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                5 percent
    Interrupt             1 percent
    Idle                  94 percent
  Model                   RE-4.0
  Serial ID               P11123900322
  Start time              2004-09-25 19:32:31 PDT
  Uptime                  9 days, 20 hours, 53 minutes, 8 seconds
  Load averages:         1 minute 5 minute 15 minute
                        0.00      0.00      0.00

Routing Engine status:
Slot 1:
  Current state           Backup
  Election priority       Backup (default)
  Temperature             29 degrees C / 84 degrees F
  CPU temperature         30 degrees C / 86 degrees F
  DRAM                    2048 MB
  Memory utilization      10 percent
  CPU utilization:
  [...]Output truncated...
```

**What It Means** The command output displays the Routing Engine slot number, current state (**Master**, **Backup**, or **Disabled**), election priority (**Master** or **Backup**), and airflow temperature. The command output also displays the total DRAM available to the Routing Engine processor, the CPU utilization percentage, and the Routing Engine serial number for the slot. Additionally, the command output displays when the Routing Engine started running, how long the Routing Engine has been running, and the time, uptime, and load averages for the last 1, 5, and 15 minutes.

Check the **Uptime** to ensure that the Routing Engine has not rebooted since it started running.

**Alternative Actions** To check the Routing Engine environmental status information, such as the operating state, function, and operating temperature, use the following CLI command:

```
user@host> show chassis environment routing-engine
Routing Engine 0 status:
  State                Online Master
  Temperature           28 degrees C / 82 degrees F
Routing Engine 1 status:
  State                Online Standby
  Temperature           29 degrees C / 84 degrees F
```

Check the LCD display on the craft interface to view information about the router temperature and the status of the Routing Engines.

## Checking the Control Board Status

This section provides a brief description of monitoring the Control Board as part of the host subsystem on T320 routers and T640 routing nodes. For more information about monitoring the Control Board, see “Monitoring the Control Board” on page 301.

**Action** To monitor the Control Board environmental status, use the following CLI command:

```
user@host> show chassis environment cb
```

**Sample Output**

```
user@host> show chassis environment cb
CB 0 status:
  State                Online Master
  Temperature           32 degrees C / 89 degrees F
  Power:
    1.8 V               1807 mV
    2.5 V               2473 mV
    3.3 V               3312 mV
    4.6 V               4793 mV
    5.0 V               5008 mV
    12.0 V              11677 mV
    3.3 V bias          3294 mV
    8.0 V bias          7272 mV
  BUS Revision         16
  FPGA Revision        45
CB 1 status:
  State                Online Standby
  Temperature           31 degrees C / 87 degrees F
  Power:
    1.8 V               1809 mV
```



2.5 V	2448 mV
3.3 V	3305 mV
4.6 V	4765 mV
5.0 V	4989 mV
12.0 V	11633 mV
3.3 V bias	3284 mV
8.0 V bias	7301 mV
BUS Revision	16
FPGA Revision	45

**What It Means** The command output displays environmental information about both Control Boards installed in the router. It displays the Control Board slot, operating status, temperature of air flowing past the Control Board, power supply, and circuitry and field programmable gate array (FPGA) revision information.

The Control Board status can be **Present**, **Online**, **Offline**, or **Empty**. The command also indicates whether the Control Board is master.



## Chapter 22

# Monitoring the Control Board

You monitor and maintain the Control Boards that provide control and monitoring functions for the router. These functions include determining Routing Engine mastership, controlling power, performing reset and SONET clocking for the other router components, monitoring and controlling fan speed, and monitoring system status using I<sup>2</sup>C controllers. (See Table 71.)

For information on monitoring the Control Boards, see “Monitoring the Host Subsystem” on page 289.

**Table 71: Checklist for Monitoring the Control Board**

Monitor the Control Board Tasks	Command or Action
<b>Understanding the Control Board on page 303</b>	
■ M320 Router Control Board on page 303	
■ T320 Router Control Board on page 304	
■ T640 Routing Node Control Board on page 304	
■ M320 Router, T320 Router, and T640 Routing Node Control Board Location on page 305	
<b>Monitoring the Control Board Status on page 306</b>	
1. Check the Control Board Environmental Status on page 306	<code>show chassis environment cb</code>
2. Check the Control Board Status from the Craft Interface on page 307	<code>show chassis craft-interface</code> Check the LEDs on the Control Board faceplate. Check the Host Subsystem LEDs on the T320 router and the T640 routing node craft interface.
<b>Checking the Control Board Alarms on page 308</b>	
1. Display Control Board Alarms on page 308	<code>show chassis alarms</code> For conditions that trigger M320 router alarms, see Table 25 on page 74. For conditions that trigger T320 router alarms, see Table 26 on page 77. For conditions that trigger T640 routing node alarms, see Table 27 on page 80.
2. Check the Control Board LEDs on page 309	Look at the LEDs on the Control Board faceplate.
3. Display Control Board Error Messages in the System Log File on page 309	<code>show log messages   match cb</code>
4. Display Control Board Error Messages in the Chassis Daemon Log File on page 309	<code>show log chassisd   match cb</code>

Monitor the Control Board Tasks	Command or Action
<b>Verifying Control Board Failure on page 310</b>	
1. Check the Control Board Connection on page 310	1. Make sure that the Control Board is properly seated in the midplane. 2. Ensure that none of the pins are bent. 3. Check the thumbscrews on the ejector locking tabs.
2. Check the Control Board Fuses on page 311	The fuses for the Control Boards are located in the rear of the midplane behind the power supply in slot <b>PEMO</b> .
3. Perform a Control Board Swap Test on page 312	1. Take the host subsystem offline if the Control Board is master. 2. Replace the Control Board with one that you know works. 3. Bring the Control Board online. 4. Check the Control Board status.
4. Display the Control Board Hardware Information on page 313	<b>show chassis hardware</b>
5. Locate the Control Board Serial Number ID Label on page 314	Look on the bottom of the left side of the Control Board.
<b>Returning the Control Board on page 314</b>	Follow the procedure in the appropriate hardware guide.

## Understanding the Control Board


**Purpose** Inspect the Control Boards to ensure that control and monitoring functions occur for the router.

**What Is the Control Board** The Control Board works with an adjacent Routing Engine in the host subsystem on M320 and T320 routers and the T640 routing node to provide control and monitoring functions. These functions include determining Routing Engine mastership, controlling power, performing reset and SONET clocking for the other router components, monitoring and controlling fan speed, and monitoring system status using I<sup>2</sup>C controllers.

### M320 Router Control Board

Figure 124 shows the Control Board component used on the M320 router.


**Figure 124: M320 Router Control Board Component**



### **T320 Router Control Board**

Figure 125 shows the T320 router Control Board component of the host subsystem.


**Figure 125: T320 Router Control Board Component**



### **T640 Routing Node Control Board**

Figure 124 shows the T320 router Control Board component of the host subsystem.


**Figure 126: T640 Routing Node Control Board Component**



### **M320, T320 Router, and T640 Routing Node Control Board Location**

You can install one or two Control Boards in the router. The Control Boards install into the upper rear of the chassis in the slots labeled CB0 and CB1 (see Figure 127).

**Figure 127: M320 Router, T320 Router, and T640 Routing Node Control Board Location**



Each Control Board requires that a Routing Engine be installed in the adjacent slot. **CB0** installs above **RE0**, and **CB1** installs below **RE1**. A Control Board does not function if no Routing Engine is present in the adjacent slot.

If two Control Boards are installed, one functions as master and the other acts as backup. If the master Control Board fails or is removed, the backup restarts and becomes master.

The Control Boards are hot-pluggable.

- See Also**
- Monitoring the Control Board on page 301
  - Monitoring the Routing Engine on page 125
  - Monitoring the Host Subsystem on page 289

## Monitoring the Control Board Status

---

**Steps To Take** To check the Control Board status, follow these steps:

1. Check the Control Board Environmental Status on page 306
2. Check the Control Board Status from the Craft Interface on page 307

### Step 1: Check the Control Board Environmental Status

**Action** To check the Control Board environmental status, use the following CLI command:

```
user@host> show chassis environment cb
```

**Sample Output**

```
t640@host> show chassis environment cb
CB 0 status:
  State                Online Master
  Temperature          29 degrees C / 84 degrees F
  Power:
    1.8 V              1805 mV
    2.5 V              2501 mV
    3.3 V              3293 mV
    4.6 V              4725 mV
    5.0 V              5032 mV
    12.0 V             11975 mV
    3.3 V bias         3286 mV
    8.0 V bias         7589 mV
  GBUS Revision        40
  FPGA Revision        7
CB 1 status:
  State                Online Standby
  Temperature          32 degrees C / 89 degrees F
  Power:
    1.8 V              1802 mV
    2.5 V              2482 mV
    3.3 V              3289 mV
    4.6 V              4720 mV
    5.0 V              5001 mV
    12.0 V             11946 mV
    3.3 V bias         3274 mV
    8.0 V bias         7562 mV
  GBUS Revision        40
  FPGA Revision        7
```

**What It Means** The command output lists the Control Board state, redundancy status, temperature, power supply voltages, and circuitry revision level. If you do not specify a Control Board slot number, the command displays the environmental status for each Control Board installed in the router chassis. If you specify a Control Board slot number, the command displays the status for that slot only.



## Step 2: Check the Control Board Status from the Craft Interface

**Action** To check the Control Board operation status from the craft interface, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
t640@host> show chassis craft-interface
FPM Display contents:
[...Output truncated...]
CB LEDs:
  CB   0   1
-----
Amber  .   .
Green  *   *
Blue   *   .
[...Output truncated...]
```

**What It Means** The sample output shows that the routing platform has two Control Boards online and functioning normally. The Control Board installed in slot 0 is functioning as master. If an amber asterisk displays, the Control Board has failed.

**Alternative Action** To view the Control Board status, you can do one of the following:

- (T320 router and T640 routing node) Look at the router craft interface host module status or look at the LCD display for any Control Board alarms.

Table 72 describes the T320 router and T640 routing node host subsystem LED states.

**Table 72: T320 Router and T640 Routing Node Host Subsystem Craft Interface LEDs**

Label	Color	State	Description
OK	Green	On steadily	Host is online and functioning normally.
FAIL	Red	On steadily	Host is offline.
MASTER	Green	On steadily	Host is functioning as master.

- Look at the Control Board LEDs on the faceplate. See Figure 127 on page 305 for the Control Board location. For more information, see “Check the Control Board LEDs” on page 309.

## Checking the Control Board Alarms

**Steps To Take** To check for Control Board alarms, follow these steps:

1. Display Control Board Alarms on page 308
2. Display Control Board Error Messages in the System Log File on page 309
3. Display Control Board Error Messages in the Chassis Daemon Log File on page 309

### Step 1: Display Control Board Alarms

For a listing of the conditions that trigger Control Board alarms, see “M320 Router Chassis Component Alarm Conditions” on page 74, “T320 Router Chassis Component Alarm Conditions” on page 77, and “T640 Routing Node Chassis Component Alarm Conditions” on page 80.

Table 73 lists the Control Board alarm messages that display on the router craft interface LCD and at the CLI command line for the M320 and T320 routers and the T640 routing node.

**Table 73: Control Board Alarm Messages**

Component	LCD Short Version	CLI Long Version
Control Board	CB <i>CB-number</i> Failure	RED ALARM - CB <i>CB-number</i> Failure
	CB <i>CB-number</i> Removed	RED ALARM - CB <i>CB-number</i> Removed

**Action** To display any active Control Board alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1 alarms currently active
Alarm time           Class  Description
2004-01-07 17:35:03 PST Major CB 1 Failure
```

**What It Means** The command output displays the current FPC alarms, including the time the alarm occurred, the severity level, and the alarm description.

**Alternative Actions** To check for Control Board errors, you can also look at the `show chassis craft-interface` CLI command output or check the LEDs on the Control Board faceplate.

## Step 2: Check the Control Board LEDs

**Action** To check the Control Board LEDs, look at the three LEDs located on the Control Board faceplate. Figure 124 on page 303, Figure 125 on page 304, and Figure 129 on page 314 show the Control Board faceplates. Table 74 describes the functions of the Control Board LEDs.



**NOTE:** The online/offline button on the Control Board is currently nonfunctional.

**Table 74: Control Board LEDs**

Label	Color	State	Description
OK	Green	On steadily	Control Board is online and functioning normally.
FAIL	Amber	On steadily	Control Board has failed.
MASTER	Blue	On steadily	Control Board is functioning as master.

## Step 3: Display Control Board Error Messages in the System Log File

**Action** To check for Control Board error messages in the system log `messages` file, use the following CLI command:

```
user@host> show log messages | match cb
```

Check for messages at least 5 minutes before and after a Control Board alarm occurs.

**Sample Output**

```
user@host> show log messages | match cb
May 18 16:04:06 routerhost chassisd[4836]: CHASSISD_FRU_OFFLINE_NOTICE: CB 1
offline: Offlined
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match cb` command to see error messages that are generated when a Control Board fails or is offline. Use this information to diagnose a Control Board problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 4: Display Control Board Error Messages in the Chassis Daemon Log File

**Action** To display Control Board error messages in the `chassisd` log file, use the following CLI command:

```
user@host> show log chassisd | match cb
```

**Sample Output**

```
user@host> show log chassisd | match cb
May 18 16:04:06 CHASSISD_FRU_OFFLINE_NOTICE: Taking CB 1 offline: Offlined
```

```
May 18 16:04:06 GBUS cmd to CB#1 [0x9], Green LED Off [0x1a]
May 18 16:04:06 CB#1 - Green LED Off
May 18 16:04:06 hwdb: entry for cbd 296 at slot 1 deleted
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. You can search for multiple items in the chassisd log file by using the `| match cb` command to see error messages that are generated when a Control Board fails or is offline. Use this information to diagnose a Control Board problem and to let JTAC know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Verifying Control Board Failure

---

**Steps To Take** To verify a Control Board failure, follow these steps:

1. Check the Control Board Connection on page 310
2. Check the Control Board Fuses on page 311
3. Perform a Control Board Swap Test on page 312
4. Display the Control Board Hardware Information on page 313
5. Locate the Control Board Serial Number ID Label on page 314

### Step 1: Check the Control Board Connection


**Action** To check the Control Board connection, make sure that it is properly seated in the midplane. Ensure that none of the pins are bent. Check the captive screws on the Control Board ejector handles.

## Step 2: Check the Control Board Fuses

The M320 router requires fuses for the Control Board. The fuses for the Control Board, Switch Interface Boards (SIBs) and Flexible PIC Concentrators (FPCs) are located in the rear of the midplane behind the power supply in slot **PEM0**. When the fuse for a Control Board blows, the Control Board stops functioning even though it is installed correctly and the power supplies are providing power to the router.

Figure 128 shows the location of the fuses in the rear of the midplane for the Control Boards. (The labels shown in the figure do not appear on the actual fuses—the clear cover on every fuse reads BUSS GMT-X—and might not match the labels on the midplane. Ignore the labels on the midplane.)

**Figure 128: Component Fuses in the M320 Router Midplane**



### Step 3: Perform a Control Board Swap Test



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the Control Board for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a Control Board swap test, follow these steps:

1. Determine whether the host subsystem is functioning as master or backup, using one of the two following methods:
  - Check the host subsystem LEDs on the craft interface. If the green **MASTER** LED is lit, the corresponding host subsystem is functioning as master.
  - Display which host subsystem is functioning as master, using the following CLI command:

```
user@host> show chassis routing-engine
```

2. If the host subsystem is functioning as master, switch it to backup, using the following CLI command:

```
user@host> request chassis routing-engine master switch
```

When you switch the host subsystem from master to backup, the functioning of the routing node is interrupted for up to several minutes as the system reboots and the new master host subsystem downloads software to the SIBs.

3. Have ready an antistatic mat, placed on a flat, stable surface.
4. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the ESD points on the chassis.
5. Loosen the captive screws on the ejector handles on both sides of the Control Board faceplate.
6. Flip the ejector handles outwards to unseat the Control Board.
7. Grasp the ejector handles and slide the Control Board about halfway out of the chassis.
8. Move one of your hands underneath the Control Board to support it, and slide it completely out of the chassis.
9. Remove the replacement Control Board from its electrostatic bag.
10. Carefully align the sides of the Control Board with the guides inside the chassis.
11. Slide the Control Board all the way into the chassis.
12. Grasp both ejector handles and press them inwards to seat the Control Board.

13. Tighten the captive screws on the ejector handles.
14. To bring the Control Board online, press the online/offline button until the green ONLINE LED lights.

#### Step 4: Display the Control Board Hardware Information

**Action** To display the Control Board hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
t640@host> show chassis hardware
Hardware inventory:
Item              Version  Part number  Serial number  Description
Chassis           REV 05   710-009120   65565          M320
Midplane          REV 04   710-005928   RB0662         M320 Midplane
FPM GBUS          REV 05   710-009351   HV0996         VFPD
FPM Display       REV 04   710-005926   HV2440         SCP
CIP               Rev 03   740-009148   QD17663        DC Power Entry Module
PEM 0             Rev 03   740-009148   QD17664        DC Power Entry Module
PEM 1             Rev 03   740-009148   QD17662        DC Power Entry Module
PEM 2             Rev 03   740-009148   QD16006        DC Power Entry Module
PEM 3             Rev 03   740-009148   QD16006        DC Power Entry Module
Routing Engine 0  REV 05   740-008883   P11123900322   RE-4.0
Routing Engine 1 REV 05   740-008883   P11123900311   RE-4.0
CB 0              REV 07   710-009115   HW8716         M320 Control Board
CB 1              REV 07   710-009115   HW8693         M320 Control Board
[...Output truncated...]
```


**What It Means** The command output displays the Control Board slot number, revision level, part number, serial number, and description. The command output for this T640 routing node shows two Control Boards installed in slots CB0 and CB1.

## Step 5: Locate the Control Board Serial Number ID Label

**Action** To find the Control Board serial number ID label locations, do the following:


On the M320 router, look on the right side of the top of the Control Board (see Figure 129).

**Figure 129: M320 Router Control Board Serial Number ID Label Location**



On the T320 router and the T640 routing node, look on the bottom left side of the Control Board (see Figure 130).

**Figure 130: T320 Router and T640 Routing Node Control Board Serial Number ID Label**



## Returning the Control Board

**Action** To return the Control Board, see “Return the Failed Component” on page 86 or follow the procedure in the appropriate router hardware guide.



## Chapter 23

# Monitoring the SCGs

You monitor the SONET Clock Generators (SCGs) that provide a clock signal for the SONET/SDH interfaces on the T320 router and the T640 routing node. The SCGs select a clock signal from any Flexible PIC Concentrator (FPC). (See Table 75.)

**Table 75: Checklist for Monitoring the SCG**

Monitor SCG Tasks	Command or Action
<b>Understanding the SCG on page 316</b>	
<b>Monitoring the SCG Status on page 317</b>	
1. Monitor the SCG Environmental Status on page 317	show chassis environment show chassis environment scg
2. Display the SCG LED States at the Command Line on page 318	show chassis craft-interface
3. Look at the SCG LEDs on the Faceplate on page 319	
<b>Determining SCG Mastership on page 319</b>	
1. Display the SCG Master from the Craft Interface Output on page 319	show chassis craft-interface
2. Look at the SCG LEDs on the Faceplate on page 320	
<b>Displaying SCG Alarms on page 320</b>	
1. Display Current SCG Alarms on page 320	show chassis alarms
2. Display SCG Error Messages in the System Log File on page 321	show log messages
3. Display SCG Error Messages in the Chassis Daemon Log File on page 321	show log chassisd
<b>Verifying SCG Failure on page 322</b>	
1. Check the SCG Connection on page 322	1. Make sure the SCG is properly seated in the midplane. 2. Make sure none of the SCG pins are bent. 3. Check the thumbscrew on the right side of the SCG.
2. Perform an SCG Swap Test on page 322	1. Take the SCG offline. 2. Replace the SCG with one that you know works. 3. Bring the SCG online. 4. Check the SCG status.


Monitor SCG Tasks	Command or Action
<b>Getting SCG Hardware Information on page 323</b>	
1. Display the SCG Hardware Information on page 323	<code>show chassis hardware</code>
2. Locate the SCG Serial Number ID Label on page 324	Look on the top of the SCG, close to the midplane connector.
<b>Returning the SCG on page 324</b>	
	See “Return the Failed Component” on page 86, or follow the procedure in the appropriate router hardware guide.

## Understanding the SCG

**Purpose** You monitor the SCGs to ensure that they provide a clock signal for the SONET/SDH interfaces on the router and that they select a clock signal from any FPC, or from the external clock inputs.

**What Is an SCG** The SCGs provide a 19.44-MHz Stratum 3 clock signal for the SONET/SDH interfaces on the router. The SCGs can also select a clock signal from any FPC, or from the external clock inputs (see Figure 131).

**Figure 131: SCG Component**




Two SCGs are installed in the T320 router and the T640 routing node. The SCGs install into the upper rear of the chassis in the slots labeled **SCG0** and **SCG1**.

If both SCGs are installed and functioning normally, **SCG0** is master and **SCG1** is backup. Removing the backup SCG does not affect the functioning of the router or routing node. Taking the master SCG offline might result in a brief loss of SONET clock lock while the backup SCG becomes master.

The SCGs are hot-pluggable.

Figure 132 on page 317 shows the location of the SCGs on the T320 router and T640 routing node.

Figure 132: T320 Router and T640 Routing Node SCG Location



### Monitoring the SCG Status

**Steps To Take** To monitor the SCG status, follow these steps:

1. Monitor the SCG Environmental Status on page 317
2. Display the SCG LED States at the Command Line on page 318
3. Look at the SCG LEDs on the Faceplate on page 319

#### Step 1: Monitor the SCG Environmental Status

**Action** To monitor the SCG environment status, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis environment
```

**Sample Output**

```
t320@host> show chassis environment
Class Item           Status      Measurement
Power PEM 0          Absent
      PEM 1           OK
Temp  SCG 0           OK          30 degrees C / 86 degrees F
      SCG 1           OK          29 degrees C / 84 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the status and temperature for each SCG.

**Alternative Action** If there is a problem with the SCG status, you can display more detailed SCG environmental information with the following CLI command:

```
user@host> show chassis environment scg
```

The command output is as follows:

```
t320@host> show chassis environment scg
SCG 0 status:
  State                Online - Master clock
  Temperature          30 degrees C / 86 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3317 mV
    5.0 V               5072 mV
    5.6 V               5697 mV
    1.8 V bias          1794 mV
    3.3 V bias          3304 mV
    5.0 V bias          4991 mV
    8.0 V bias          7318 mV
  BUS Revision         40
SCG 1 status:
  State                Online - Standby
  Temperature          29 degrees C / 84 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3318 mV
    5.0 V               5084 mV
    5.6 V               5704 mV
    1.8 V bias          1782 mV
    3.3 V bias          3286 mV
    5.0 V bias          5003 mV
    8.0 V bias          7323 mV
  BUS Revision         40
```

The command output displays the status for each SCG slot 0 and 1. The operating status can be **Present**, **Online**, **Offline**, or **Empty**. If **Online**, it can be the clock source (**Master clock**) or backup (**Standby**). The command output displays the temperature of the air flowing past the SCG. The command output also displays information about the SCG power supplies and the SCG circuitry revision level.

## Step 2: Display the SCG LED States at the Command Line

**Action** To display the SCG LED states, use the following CLI command:

```
user@host> show chassis craft-interface
```

```
Sample Output t320@host> show chassis craft-interface
[...Output truncated...]
SCG LEDs:
  SCG  0  1
-----
Amber  .  .
Green  *  *
Blue   *  .
[...Output truncated...]
```

**What It Means** The command output displays the SCG LED status. The router has two SCGs installed. Asterisks (\*) indicate the operation status. The color represents the possible SCG operating states: **Amber** (Fail), **Green** (OK), and **Blue** (Master). Both SCGs are functioning properly (Green). The SCG in slot 0 is operating as master; the SCG in slot 1 is the backup.

### Step 3: Look at the SCG LEDs on the Faceplate

**Action** To view the SCG LEDs, remove the rear component cover and look on the SCG faceplate at the rear of the router chassis (see Figure 131 on page 316 and Figure 132, “T320 Router and T640 Routing Node SCG Location” on page 317). Table 76 describes the functions of these LEDs.

**Table 76: SCG LEDs**

Label	Color	State	Description
OK	Green	On steadily	SCG is online and functioning normally.
FAIL	Amber	On steadily	SCG has failed.
MASTER	Blue	On steadily	SCG is functioning as master.

## Determining SCG Mastership

If both SCGs are installed and functioning normally, **SCG0** is master and **SCG1** is backup. Removing the backup SCG does not affect the functioning of the routing node. Taking the master SCG offline might result in a brief loss of SONET clock lock while the backup SCG becomes master.

**Steps To Take** To determine which SCG is operating as the master, follow these steps:

1. Display the SCG Master from the Craft Interface Output on page 319
2. Look at the SCG LEDs on the Faceplate on page 320

### Step 1: Display the SCG Master from the Craft Interface Output

**Action** To determine the SCG master from the craft interface status information, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
[...Output truncated...]
SCG LEDs:
  SCG  0   1
-----
Amber  .   .
Green  *   *
Blue   *   .
[...Output truncated...]
```

**What It Means** The command output displays which SCG is operating as master. Asterisks (\*) indicate the operation status. The color represents the possible SCG operating states: Amber (Fail), Green (OK), and Blue (Master). The SCG in slot 0 is operating as master; the SCG in slot 1 is the backup.

## Step 2: Look at the SCG LEDs on the Faceplate

**Action** Check the blue MASTER LED on the SCG faceplate. If this LED is on steadily, the SCG is functioning as master. Table 76 describes the functions of these LEDs.

## Displaying SCG Alarms

**Steps To Take** To display SCG alarms and error messages, follow these steps:

1. Display Current SCG Alarms on page 320
2. Display SCG Error Messages in the System Log File on page 321
3. Display SCG Error Messages in the Chassis Daemon Log File on page 321

### Step 1: Display Current SCG Alarms

Table 77 describes the SCG alarms that display on the router craft interface LCD display at the CLI command line.

**Table 77: SCG Alarm Messages**

Component	LCD Short Version	CLI Long Version
<b>SCG</b>	SCG <i>SCG-number</i> Failure	RED ALARM—SCG <i>SCG-number</i> Failure
	SCG <i>SCG-number</i> Removed	RED ALARM—SCG <i>SCG-number</i> Failure
	SCG <i>SCG-number</i> Not Online	YELLOW ALARM—SCG <i>SCG-number</i> Not Online

For the conditions that trigger SCG alarms, see “T320 Router Chassis Component Alarm Conditions” on page 77 and “T640 Routing Node Chassis Component Alarm Conditions” on page 80.

**Action** To display the current SCG alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
t320@host> show chassis alarms
1 alarm currently active
Alarm time           Class  Description
2004-01-28 14:53:10 PST  Minor  SCG 0 Not Online
```

**What It Means** The command output displays the alarm date, time, severity level, and description.

## Step 2: Display SCG Error Messages in the System Log File

**Action** To display the SCG error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
t320@host> show log messages | match scg
Jan 28 14:53:10  utah chassisd[2384]: CHASSISD_FRU_OFFLINE_NOTICE: Taking SCG 0
offline - Offlined by cli command
Jan 28 14:53:10  utah craftd[2386]: Minor alarm set, SCG 0 Not Online
Jan 28 14:53:10  utah alarmd[2385]: Alarm set: SCG color=YELLOW, class=CHASSIS,
reason=SCG 0 Not Online
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match scgs` command to see error messages that are generated when an SCG fails or is offline. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 3: Display SCG Error Messages in the Chassis Daemon Log File

**Action** To display the SCG error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```
t320@host> show log chassisd
Dec 17 11:11:12 SCG 1 removed
Dec 17 11:11:12 CHASSISD_FRU_OFFLINE_NOTICE: Taking SCG 1 offline - Removal
Dec 17 11:11:12 CHASSISD_SNMP_TRAP7: SNMP trap: FRU removal: jnxFruContentsIndex
11, jnxFruL1Index 2, jnxFruL2Index 0, jnxFruL3Index 0, jnxFruName SCG 1,
jnxFruType 2, jnxFruSlot 2
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.

## Verifying SCG Failure

---

**Steps To Take** To verify SCG failure, follow these steps:

1. Check the SCG Connection on page 322
2. Perform an SCG Swap Test on page 322

### Step 1: Check the SCG Connection

**Action** To check the SCG connection, make sure the SCG is properly seated in the midplane. Make sure none of the SCG pins are bent. Check the thumbscrew on the right side of the SCG.

### Step 2: Perform an SCG Swap Test

---



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the SCG for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

---

**Action** To perform a swap test on a SCG, follow these steps:

1. Take the SCG offline by doing one of the following:
  - Use the following CLI command:
 

```
user@host> request chassis scg offline slot number
```
  - Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the ESD points on the chassis. Press the online/offline button on the SCG faceplate and hold it down until the LED goes out (about 5 seconds).
2. Loosen the captive screws on the edges of the SCG faceplate.
3. Grasp the SCG by the handle on the faceplate and slide it out of the chassis.
4. Place the SCG on the antistatic mat.
5. Remove the replacement SCG from its electrostatic bag.
6. Carefully align the sides of the SCG with the guides in the SCG slot.
7. Grasp the SCG by its handle and slide it straight into the chassis until it contacts the midplane.
8. Tighten the captive screws on the corners of the SCG faceplate.



9. Bring the SCG online by doing one of the following:

- Use the following CLI command:

```
user@host> request chassis scg online slot number
```

- Press the online/offline button until the green ONLINE LED lights.

10. Verify that the SCG is online by using the following CLI command:

```
user@host> request chassis scg online slot number
```

If the replaced SCG is online, the removed SCG has failed. Return the SCG as described in “Return the Failed Component” on page 86.

## Getting SCG Hardware Information

---

**Steps To Take** To get the SCG hardware information, follow these steps:

1. “Display the SCG Hardware Information” on page 323
2. “Locate the SCG Serial Number ID Label” on page 324

### Step 1: Display the SCG Hardware Information

**Action** To display the SCG hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               abcdef         T320
Midplane      REV 01   710-004339   AY4529
FPM GBUS      REV 02   710-004461   AY4511
FPM Display   REV 02   710-002897   HF6094
CIP           REV 05   710-002895   HC0468
PEM 1         Rev 01   740-004359   2708013        Power Entry Module
SCG 0         REV 06   710-004455   AY4526
SCG 1         REV 06   710-004455   AY4523
```

**What It Means** The command output displays the SCG slot number, revision level, part number, and serial number.

## Step 2: Locate the SCG Serial Number ID Label

**Action** The serial number is located on the top of the SCG, close to the midplane connector (see Figure 133).

**Figure 133: Serial Number Label on the SCG**



## Returning the SCG

The SCGs are hot-pluggable. If both SCGs are installed and functioning normally, **SCG0** is master and **SCG1** is backup. Removing the backup SCG does not affect the functioning of the routing node. Taking the master SCG offline might result in a brief loss of SONET clock lock while the backup SCG becomes master.

**Action** To return an SCG, see the appropriate router hardware guide.

## Chapter 24

# Monitoring the SIBs

You monitor the Switch Interface Boards (SIBs) that provide the switching function to the destination Flexible PIC Concentrator (FPC). The SIBs create the switch fabric for the routing platforms, providing up to a total of 640 million packets per second (Mpps) of forwarding. (See Table 78.)

**Table 78: Checklist for Monitoring the SIBs**

Monitor SIB Tasks	Command or Action
<b>Understanding the SIBs on page 326</b>	
<ul style="list-style-type: none"> <li>■ M320 Router, T320 Router, and T640 Routing Node SIB Location on page 328</li> <li>■ M320 Router SIBs on page 329</li> <li>■ T320 Router SIBs on page 329</li> <li>■ T640 Routing Node SIBs on page 329</li> </ul>	
<b>Monitoring the SIB Status on page 329</b>	
1. Display the SIB Summary Status on page 330	<code>show chassis sibs</code>
2. Display the SIB LED Status at the Command Line on page 330	<code>show chassis craft-interface</code>
3. Check the SIB LED Status on the Faceplate on page 330	Check the SIB faceplate at the back of the T320 router and the T640 routing node chassis.
4. Display the SIB Environmental Status on page 331	<code>show chassis environment</code> <code>show chassis environment sib slot</code>
<b>Displaying SIB Alarms on page 332</b>	
1. Display Current SIB Alarms on page 332	<code>show chassis alarms</code>
2. Display SIB Error Messages in the System Log File on page 333	<code>show log messages   match sib</code>
3. Display SIB Error Messages in the Chassis Daemon Log File on page 333	<code>show log chassisd   match sib</code>
<b>Verifying SIB Failure on page 334</b>	
1. Check the SIB Connection on page 334	1. Make sure that the SIB is properly seated in the midplane. 2. Ensure that none of the pins are bent. 3. Check the thumbscrews on the ejector locking tabs.
2. Check the SIB Fuses on page 334	The fuses for the SIBs are located in the rear of the midplane behind the power supply in slot PEM0.

Monitor SIB Tasks	Command or Action
3. Perform an SIB Swap Test on page 336	<ol style="list-style-type: none"> <li>1. Take the SIB offline.</li> <li>2. Replace the SIB with one that you know works.</li> <li>3. Bring the SIB online.</li> <li>4. Check the SIB status.</li> </ol>
<b>Getting SIB Hardware Information on page 337</b>	
1. Display SIB Hardware Information on page 337	show chassis hardware
2. Locate the SIB Serial Number ID Label on page 338	Look on the top left of the SIB component.
<b>Returning the SIB on page 338</b>	Follow the procedure in the appropriate router hardware guide.

## Understanding the SIBs

**Purpose** Inspect the SIBs to ensure that they provide the switching function to the destination FPCs.

**What Is an SIB** A SIB forwards packets to a destination FPC.

Table 79 shows the SIB characteristics for the M320 router, T320 router, and the T640 routing node.

**Table 79: SIB Packet Forwarding Characteristics**

Routing Platform	Million Packets per Second (Mpps) Forwarding	Number of SIBs per Chassis	Redundancy
M320	385	4	No
T320	320	3	Yes
T640	640	5	Yes

Figure 134 shows the M320 router SIB component.

**Figure 134: M320 Router SIB Component**




Figure 138 shows the T320 router and T640 routing node SIB component.

**Figure 135: T320 Router and T640 Routing Node SIB Component**





Figure 136 shows the location of the SIBs on the M320 router, T320 router, and the T640 routing node.

**Figure 136: M320 Router, T320 Router, and T640 Routing Node SIB Location**



### **M320 Router SIBs**

Four SIBs are installed in the M320 router. The SIBs are located at the center rear of the chassis in the slots labeled **SIB0** through **SIB3** (top to bottom). See Figure 136 on page 328. All four SIBs are active, and there is no backup.

### **T320 Router SIBs**

Three SIBs are installed in the router. The SIBs are located at the center rear of the chassis in the slots labeled **SIB0** through **SIB2** (see Figure 136 on page 328).

Each FPC has a dedicated ASIC with five high-speed links that connect to the SIBs. Two high-speed links connect to **SIB1** and **SIB2**. One high-speed link connects to **SIB0**. **SIB0** acts as a backup to **SIB1** and **SIB2**. In the event of a complete SIB failure, **SIB0** will become active. Because **SIB0** has only one high-speed link to each FPC, only three links will remain active. A slight degradation in forwarding capacity may occur. When the failed SIB is replaced, it will become active and **SIB0** will revert to backup. The router will regain full forwarding capacity.

### **T640 Routing Node SIBs**

Five SIBs are installed in the routing node. The SIBs are located at the center rear of the chassis in the slots labeled **SIB0** through **SIB4** (top to bottom). See Figure 136 on page 328.

Each FPC1 and FPC2 has a dedicated ASIC with five high-speed links that connect to the SIBs (one link per SIB). An FPC3 has two dedicated ASICs, and each ASIC has five high-speed links that connect to the SIBs (a total of 10 links). One of the five SIBs—usually **SIB4**—acts as a backup to the remaining four SIBs. In the event of a SIB failure, the backup SIB becomes active and traffic forwarding continues without any degradation. When the failed SIB is replaced, it becomes the new backup.

## **Monitoring the SIB Status**

---

**Steps To Take** To monitor the SIB status, follow these steps:

1. Display the SIB Summary Status on page 330
2. Display the SIB LED Status at the Command Line on page 330
3. Check the SIB LED Status on the Faceplate on page 330
4. Display the SIB Environmental Status on page 331

### Step 1: Display the SIB Summary Status

**Action** To display the SIB summary status, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis sibs
```

**Sample Output**

```
t640@host> show chassis sibs
Slot  State                Uptime
0      Spare
1      Online                4 hours, 5 minutes, 47 seconds
2      Online                4 hours, 5 minutes, 42 seconds
3      Online                4 hours, 5 minutes, 37 seconds
4      Online                4 hours, 5 minutes, 33 seconds
```

**What it Means** The command output displays the SIB slot number: 0, 1, 2, 3, and 4. The output also displays the operating status of each SIB as Online, Offline, or Empty, and how long each SIB has been online.

### Step 2: Display the SIB LED Status at the Command Line

**Action** To display the SIB LED status, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
t640@host> show chassis craft-interface
[...Output truncated...]
SIB LEDs:
  SIB  0    1    2    3    4
-----
Red    .    .    .    .    .
Green  *    *    *    *    *
```

**What it Means** The command output is for a T640 routing node. Asterisks (\*) represent the operating state. The status colors represent the possible SIB operating states: Red (Fail) and Green (OK). All SIBs are functioning normally.

### Step 3: Check the SIB LED Status on the Faceplate

**Action** To check the SIB LED status, remove the component cover and look on the SIB faceplate at the back of the T320 router and the T640 routing node (see Figure 135 on page 327).

Table 80 describes the SIB LED states.

**Table 80: SIB LEDs**

Label	Color	State	Description
OK	Green	On steadily	SIB is functioning normally.
		Blinking	SIB is starting up.
FAIL	Amber	On steadily	SIB has failed.
ACTIVE	Green	On steadily	SIB is in active mode.



## Step 4: Display the SIB Environmental Status

**Action** To display the SIB environmental information, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
T640@host> show chassis environment
Class Item                Status      Measurement
Temp  PEM 0                  Absent
      PEM 1                  OK          32 degrees C / 89 degrees F
      SCG 0                  OK          37 degrees C / 98 degrees F
      SCG 1                  Absent
      Routing Engine 0      OK          35 degrees C / 95 degrees F
      Routing Engine 1      Absent
      CB 0                   OK          36 degrees C / 96 degrees F
      SIB 0                  OK          44 degrees C / 111 degrees F
      SIB 1                  OK          50 degrees C / 122 degrees F
      SIB 2                  OK          50 degrees C / 122 degrees F
      SIB 3                  OK          50 degrees C / 122 degrees F
      SIB 4                  OK          52 degrees C / 125 degrees F
[...Output truncated...]
```

**What it Means** The command output displays each component installed in the router, including the operating status and temperature.

**Alternative Action** If there is a problem with the SIB status, you can display more detailed environmental information with the following CLI command:

```
user@host> show chassis environment sib
```

```
user@host> show chassis environment sib
SIB 0 status:
State                Spare
Temperature           44 degrees C / 111 degrees F
Power:
GROUND                0 mV
1.8 V                 1807 mV
2.5 V                 2478 mV
3.3 V                 3308 mV
1.8 V bias            1797 mV
3.3 V bias            3284 mV
5.0 V bias            5018 mV
8.0 V bias            7440 mV
SIB 1 status:
State                Online
Temperature           50 degrees C / 122 degrees F
Power:
GROUND                0 mV
1.8 V                 1814 mV
2.5 V                 2485 mV
3.3 V                 3321 mV
1.8 V bias            1794 mV
3.3 V bias            3313 mV
5.0 V bias            5028 mV
8.0 V bias            7553 mV
SIB 2 status:
[...Output truncated...]
SIB 3 status:
[...Output truncated...]
SIB 4 status:
[...Output truncated...]
```

The command output displays the SIB slot, status, and temperature of the air flowing past the SPP card and the power supply voltages.

You can display the environmental status of a particular SIB with the following CLI command:

```
user@host> show chassis environment sib slot
```

## Displaying SIB Alarms

**Steps To Take** To display SIB alarms and error messages, follow these steps:

1. Display Current SIB Alarms on page 332
2. Display SIB Error Messages in the System Log File on page 333
3. Display SIB Error Messages in the Chassis Daemon Log File on page 333

### Step 1: Display Current SIB Alarms

Table 81 lists the SIB alarms that display in the craft interface LCD display and at the CLI command line.

For conditions that trigger SIB alarms, see “T320 Router Chassis Component Alarm Conditions” on page 77 and “T640 Routing Node Chassis Component Alarm Conditions” on page 80.

**Table 81: SIB Alarm Messages**

Component	LCD Short Version	CLI Long Version
<b>SIB</b>	SIB <i>sib-number</i> Failure	RED ALARM—SIB <i>sib-number</i> Fault
	SIB <i>sib-number</i> Removed	RED ALARM—SIB <i>sib-number</i> Absent
	Spare SIB Failure	YELLOW ALARM—Spare SIB Fault
	Spare SIB Removed	YELLOW ALARM—Spare SIB Absent
	Check SIB	YELLOW ALARM—Check SIB

**Action** To display the current SIB alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1alarms currently active
Alarm time           Class  Description
2004-01-29 18:37:09 PST  Minor  SIB 2 Not Online
```

**What it Means** The command output displays the alarm date, time, severity level, and description.

## Step 2: Display SIB Error Messages in the System Log File

**Action** To display the SIB error messages in the system log file, use the following CLI command:

```
user@host> show log messages | match sib
```

**Sample Output**

```
user@host> show log messages | match sib
Jan 29 18:37:07 toto spmb0 CMGSIB: SIB #2 state transition SIB_STATE_ONLINE ->
SIB_STATE_OFFLINE_ACK_WAIT
Jan 29 18:37:09 toto spmb0 CMGSIB: SIB #2 state transition SIB_STATE_OFFLINE_AC
K_WAIT -> SIB_STATE_OFFLINE
Jan 29 18:37:09 toto spmb0 CMGSIB: SIB #0 state transition SIB_STATE_SPARE -> S
IB_STATE_ONLINE_WAIT
```

**What it Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match sib` command to see error messages that are generated when an SIB fails or is offline. Use this information to diagnose an SIB problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 3: Display SIB Error Messages in the Chassis Daemon Log File

The chassis daemon (chassisd) log file keeps track of the state of each chassis component.

**Action** To display the SIB error messages logged in the chassis daemon log file, use the following CLI command:

```
user@host> show log chassisd | match sib
```

**Sample Output**

```
user@host> show log chassisd | match sib
Jan 29 18:37:07 CHASSISD_FRU_OFFLINE_NOTICE: Taking SIB 2 offline - Offlined by
cli command
Jan 29 18:37:07 CHASSISD_SNMP_TRAP10: SNMP trap: FRU power off: jnxFruContentsIn
dex 15, jnxFruL1Index 3, jnxFruL2Index 0, jnxFruL3Index 0, jnxFruName SIB 2, jnx
FruType 9, jnxFruSlot 3, jnxFruOfflineReason 7, jnxFruLastPowerOff 1701082, jnxF
ruLastPowerOn 3250
Jan 29 18:37:09 send: yellow alarm set, device SIB 2, reason SIB 2 Not Online
Jan 29 18:37:09 fm_rcv_hsl_start_sib_ack plane case. Checking plane control to
all line cards?
Jan 29 18:37:09 fm_rcv_hsl_start_sib_ack: Awaiting spmb ack for LC#0!
Jan 29 18:37:09 fm_rcv_hsl_start_sib_ack plane case. Checking plane control to
all line cards?
Jan 29 18:37:09 fm_rcv_hsl_start_sib_ack: Awaiting spmb ack for LC#0!
Jan 29 18:37:09 fm_rcv_hsl_start_sib_ack plane case. Checking plane control to
all line cards?
Jan 29 18:37:09 fm_rcv_hsl_start_sib_ack plane case. Sending plane control to a
ll line cards!
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. You can search for multiple items in the chassisd log file by using the | **match sib** command to see error messages that are generated when an SIB fails or is offline. Use this information to diagnose an SIB problem and to let JTAC know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Verifying SIB Failure

---

**Steps To Take** To verify SIB failure, follow these steps:

1. Check the SIB Connection on page 334
2. Check the SIB Fuses on page 334
3. Perform an SIB Swap Test on page 336

### Step 1: Check the SIB Connection


**Action** To check the SIB connection, make sure that it is properly seated in the midplane. Ensure that none of the pins are bent. Check the thumbscrews on the ejector locking tabs.

### Step 2: Check the SIB Fuses

The M320 router requires fuses for the SIBs. The fuses for the Control Board, SIBs, and FPCs are located in the rear of the midplane behind the power supply in slot PEM0. When the fuse for an SIB blows, the SIB stops functioning even though it is installed correctly and the power supplies are providing power to the router.

Figure 137 shows the location of the fuses in the rear of the midplane for the SIBs. (The labels shown in the figure do not appear on the actual fuses—the clear cover on every fuse reads BUSS GMT-X—and might not match the labels on the midplane. Ignore the labels on the midplane.)

**Figure 137: Component Fuses in the M320 Router Midplane**



### Step 3: Perform an SIB Swap Test

SIBs are hot-insertable and hot-removable.



**NOTE:** Before performing a swap test, always check for bent pins in the midplane and check the SIB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an SIB, follow these steps:

1. Take the SIB offline by doing one of the following
  - Use the following CLI command:
 

```
user@host> request chassis sib slot number offline
```
  - Press the online/offline button on the SIB faceplate. Press and hold down the button until the green **ONLINE** LED goes out (about 5 seconds).
2. Have ready an antistatic mat placed on a stable, flat surface.
3. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the ESD points on the chassis.
4. Loosen the captive screws on the ejector handles on each side of the SIB faceplate.
5. Flip the ejector handles outward to unseat the SIB.
6. Grasp both ejector handles, pull firmly on the SIB, and slide the SIB about three-quarters of the way out of the chassis.
7. Move one of your hands underneath the SIB to support it, and slide it completely out of the chassis.
8. Hold the replacement SIB by placing one hand underneath to support it and the other hand on one of the ejector handles on the SIB faceplate.
9. Carefully align the sides of the SIB with the guides inside the chassis.
10. Slide the unit into the chassis, carefully ensuring that it is correctly aligned.
11. Grasp both ejector handles and press them inwards to seat the SIB.
12. Tighten the captive screws on the ejector handles.
13. Bring the SIB online by doing one of the following
  - Use the following CLI command:
 

```
user@host> request chassis sib slot number online
```
  - Press the offline/online button until the green **ONLINE** LED lights to bring the SIB online.

## Getting SIB Hardware Information

---

**Steps To Take** To get the hardware information you need to return a failed SIB, follow these steps:

1. Display SIB Hardware Information on page 337
2. Locate the SIB Serial Number ID Label on page 338

### Step 1: Display SIB Hardware Information

**Action** To display the SIB hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Item          Version  Part number  Serial number  Description
Chassis                               19061         T640
[...Output truncated...]
SIB 0         REV 05   710-003980   HF9603         SIB-I8
SIB 1         REV 05   710-003980   HF9577         SIB-I8
SIB 2         REV 05   710-003980   HF9540         SIB-I8
SIB 3         REV 05   710-003980   HF9550         SIB-I8
SIB 4         REV 05   710-003980   HF9592         SIB-I8
```


**What it Means** The command output displays the SIB slot number, revision level, part number, serial number, and description.

## Step 2: Locate the SIB Serial Number ID Label

**Action** To find the SIB serial number ID label locations, do the following:


On the M320 router, the SIB serial number label is located on the right side of the top of the component (see Figure 138).

**Figure 138: M320 Router SIB Serial Number ID Label location**



On the T320 router and the T640 routing node, the SIB serial number ID label is located on the left side of the top panel of the component (see Figure 139).

**Figure 139: Serial Number Label on the SIB**



## Returning the SIB

**Action** To return a failed SIB, see “Return the Failed Component” on page 86 or the appropriate router hardware guide.



## Part 5

# Monitoring M40e and M160 Internet Router-Specific Components

- Monitoring the Host Module on page 341
- Monitoring the SFMs on page 347
- Monitoring the MCS on page 359
- Monitoring the PCG on page 369
- Monitoring the CIP on page 381



## Chapter 25

# Monitoring the Host Module

You monitor and maintain the M40e and M160 router host module—the Routing Engine and the Miscellaneous Control Subsystem (MCS)—which constructs routing tables, performs system management functions, and generates the SONET/SDH clock signal for SONET/SDH interfaces. (See Table 82.)

**Table 82: Checklist for Monitoring the Host Module**

Monitor Host Module Tasks	Command or Action
<b>Understanding the Host Module on page 341</b>	
<b>Checking the Host Module Status on page 344</b>	show chassis craft-interface
<b>Checking the Routing Engine Status on page 345</b>	show chassis routing-engine
<b>Checking the MCS Status on page 346</b>	show chassis environment mcs

## Understanding the Host Module

<b>Purpose</b>	Inspect the host module to ensure that the Routing Engine and Miscellaneous Control Subsystem (MCS) function properly.
<b>What Is a Host Module</b>	<p>The host module is present on M40e and M160 routers. The host module constructs routing tables, performs system management functions, and generates the SONET/SDH clock signal for SONET/SDH interfaces.</p> <p>The host module is comprised of two components: the Routing Engine and the MCS. For a host module to function, both of these components must be installed and operational.</p>

Figure 140 shows the Routing Engine component of the host module.

**Figure 140: Routing Engine Component**





Figure 141 shows the MCS component of the host module.


**Figure 141: MCS Component**




One or two host modules can be installed into the midplane from the rear of the chassis (see Figure 142). The Routing Engine (slot RE0) is below the MCS slot (MCS0), while slot RE1 is above the MCS1 slot. RE0 must use MCS0 and RE1 must use MCS1 or the circuit will not be connected.

**Figure 142: M40e and M160 Router Host Module Location**

**M40e router rear**



**M160 router rear**



1842

This chapter provides basic information about monitoring the Routing Engine and the MCS. For more detailed information about monitoring the Routing Engine, see “Monitoring the Routing Engine” on page 125. For more detailed information about monitoring the MCS, see “Monitoring the MCS” on page 359.

- See Also**
- Monitoring the Host Module on page 341
  - Monitoring the MCS on page 359
  - Monitoring Redundant Routing Engines on page 491
  - Monitoring Redundant MCSs on page 567

## Checking the Host Module Status

**Action** To check the host module status, use the following JUNOS software command-line interface (CLI) operational mode command:

```
user@host> show chassis craft-interface
```

**Output** user@host> show chassis craft-interface

[...Output truncated...]

Front Panel System LEDs:

Host 0 1

-----

OK \* .

Fail . .

Master \* .

[...Output truncated...]

**What It Means** (M40e and M160 routers) The Front Panel System LEDs show the Routing Engine Host 0 and Host 1 LED state. The state can be OK, Fail, or Master. An asterisk (\*) indicates the operating state.

**Alternative Action** Look at the LEDs on the craft interface.

The host module LEDs are located on the upper right corner of the craft interface. Two sets of LEDs indicate the host module status: the set labeled **HOST0** reports the status of the Routing Engine in slot **RE0** and the MCS in slot **MCS0**, while the set labeled **HOST1** reports the status of the Routing Engine in slot **RE1** and the MCS in slot **MCS1**. Each set includes three LEDs: **MASTER** (green), **ONLINE** (green), and **OFFLINE** (red).

Figure 143 shows the M40e and M160 router craft interface LEDs.

**Figure 143: M40e and M160 Router Host Module LEDs on the Craft Interface**




Table 83 describes the M40e and M160 router host module LED states.

**Table 83: M40e and M160 Router Host Module LEDs**

Label	Color	State	Description
MASTER	Green	On steadily	Host module is functioning as master.
ONLINE	Green	On steadily	Host module components (Routing Engine and MCS) are installed and functioning normally.
		Blinking	Host module is starting up.
OFFLINE	Red	On steadily	One or both host module components are not installed or have failed.

## Checking the Routing Engine Status

This section provides a brief description of monitoring the Routing Engines as part of the host module on M40e and M160 routers. For more detailed information about monitoring the Routing Engine, see “Monitoring the Routing Engine” on page 125.

**Action** To check the Routing Engine status, use the following CLI command:

```
user@host> show chassis routing-engine
```

**Output**

```
user@host> show chassis routing-engine
Routing Engine status:
  Temperature                22 degrees C / 71 degrees F
  DRAM                       768 Mbytes
  CPU utilization:
    User                      0 percent
    Background                0 percent
    Kernel                    0 percent
    Interrupt                  0 percent
    Idle                      100 percent
  Model                      teknor
  Serial ID                   4d0000062b049501
  Start time                  2002-04-29 11:18:31 PDT
  Uptime                      5 hours, 20 minutes, 17 seconds
  Load averages:             1 minute  5 minute 15 minute
                              0.06      0.03    0.00
```

**What It Means** The command output displays the Routing Engine slot number, current state (Master, Backup, or Disabled), election priority (Master or Backup), and the airflow temperature. The command output also displays the total DRAM available to the Routing Engine processor, the CPU utilization percentage, and the Routing Engine serial number for the slot. Additionally, the command output displays when the Routing Engine started running, how long the Routing Engine has been running, and the time, uptime, and load averages for the last 1, 5, and 15 minutes.

Check the **Uptime** to ensure that the Routing Engine has not rebooted since it started running.

## Checking the MCS Status

---

This section provides a brief description of monitoring the MCS as part of the host module on M40e and M160 routers. For a more information about monitoring the MCS, see “Monitoring the MCS” on page 359.

**Action** To monitor the MCS status, use the following CLI command:

```
user@host> show chassis environment mcs
```

**Output** user@host> show chassis environment mcs

```
MCS 0 status:
  State                Online Master
  Temperature          43 degrees C / 109 degrees F
  Power:
    3.3 V              3318 mV
    5.0 V              4974 mV
    12.0 V             11824 mV
    5.0 V bias         4974 mV
    8.0 V bias         8212 mV
  BUS Revision         12
  FPGA Revision        13

MCS 1 status:
  State                Online Standby
  Temperature          58 degrees C / 136 degrees F
  Power:
    3.3 V              3317 mV
    5.0 V              5006 mV
    12.0 V             11843 mV
    5.0 V bias         4998 mV
    8.0 V bias         8195 mV
  BUS Revision         12
  FPGA Revision        255
```

**What It Means** The show chassis environment mcs CLI command is available on the M40e and M160 routers only. The command output displays environmental information about both MCSs installed in the router or about an individual MCS. It displays the MCS status: **Present**, **Online**, **Offline**, or **Empty**. The command also indicates whether the MCS is master. The command output displays the temperature of the air flowing past the MCS, information about MCS power supplies, field programmable gate array (FPGA) revision information, and the revision level of the chassis management bus (CMB) slave.



## Chapter 26

# Monitoring the SFMs

You monitor the Switching and Forwarding Modules (SFMs) to ensure that traffic transiting the router is handled properly. (See Table 84.)

**Table 84: Checklist for Monitoring the SFMs**

Monitor SFM Tasks	Command or Action
<b>Understanding the SFMs on page 348</b>	
<b>Monitoring the SFM Status on page 349</b>	
1. Display the SFM Summary Status on page 349	<code>show chassis sfm sfm-slot</code> <code>show chassis sfm detail sfm-slot</code>
2. Display the SFM LED Status at the Command Line on page 351	<code>show chassis craft-interface</code>
3. Check the SFM LED Status on the Faceplate on page 351	Check the SFM faceplate at the back of the M40e and M160 router chassis.
4. Display the SFM Environmental Status on page 351	<code>show chassis environment</code> <code>show chassis environment sfm sfm-slot</code>
<b>Displaying SFM Alarms on page 353</b>	
1. Display Current SFM Alarms on page 353	<code>show chassis alarms</code>
2. Display SFM Error Messages in the System Log File on page 353	<code>show log messages</code>
3. Display SFM Error Messages in the Chassis Daemon Log File on page 354	<code>show log chassisd</code>
<b>Verifying SFM Failure on page 355</b>	
1. Check the SFM Connection on page 355	Check the thumbscrews on the SFM ejector locking tabs.
2. Check the SFM Fuses on page 355	The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly.
3. Perform an SFM Swap Test on page 356	1. Take the SFM offline. 2. Replace the SFM with one that you know works. 3. Bring the SFM online. 4. Check the SFM status.
<b>Getting SFM Hardware Information on page 357</b>	
1. Display SFM Hardware Information on page 357	<code>show chassis hardware</code>

Monitor SFM Tasks	Command or Action
2. Locate the SFM Serial Number ID Label on page 357	Look on the top left of the SFM component.
Replacing the SFM on page 358	See “Return the Failed Component” on page 86, or follow the procedure in the appropriate router hardware guide.


Understanding the SFMs

- Purpose

Inspect the SFMs to ensure that all traffic leaving the Flexible PIC Concentrators (FPCs) is handled properly.
- What Is an SFM


The SFM is a control board that handles traffic transiting the router (see Figure 144). There are two SFMs on the M40e router and four SFMs on the M160 router (see Figure 145).

Figure 144: SFM Component



The SFMs provide route lookup, filtering, and switching. When the serial stream of bits leaves the FPC, it is directed to one of the SFMs. Each SFM effectively handles one-half or one-quarter of the traffic on each FPC. The SFMs handle a total of 160 million packets per second (Mpps) of forwarding.

Figure 145: M40e and M160 Router SFM Location



The SFMs are hot-removable and hot-insertable. Inserting or removing an SFM causes a brief interruption in forwarding performance (about 500 ms) as the Packet Forwarding Engine reconfigures the distribution of packets across the remaining SFMs.

## Monitoring the SFM Status

To monitor the SFM status, follow these steps:

- Steps To Take**
1. Display the SFM Summary Status on page 349
  2. Display the SFM LED Status at the Command Line on page 351
  3. Check the SFM LED Status on the Faceplate on page 351
  4. Display the SFM Environmental Status on page 351

### Step 1: Display the SFM Summary Status

**Action** To display the SFM summary status, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis sfm
```

**Sample Output**

```
user@host> show chassis sfm
Temp  CPU Utilization (%)  Memory  Utilization (%)
Slot State             (C) Total Interrupt  DRAM (MB) Heap      Buffer
0  Online              41      2      0      64      16      46
1  Offline              --- Hard FPC error ---
2  Online              43      2      0      64      16      46
3  Online              44      2      0     128      7      46
```

**What it Means** The command output displays the SFM slot number: 0, 1, 2, or 3. The output also displays the operating status of each SFM as **Online**, **Offline**, or **Empty**.

In the sample output, the root cause of the **SFM1** failure may be an FPC problem.

The command output displays the temperature of air passing by the SFM, in degrees Centigrade. It displays the SFM CPU usage, including the total percentage used by the SFM processor and the percentage used for interrupts.

The command output also displays the percentage of memory usage, including the total DRAM available to the SFM processor, in megabytes (MB), and the percentage of heap space (dynamic memory) being used by the SFM processor. Heap utilization greater than 80 percent can indicate a software problem (memory leak). The output shows the percentage of buffer space being used by the SFM processor for buffering internal messages.

**Alternative Action** If the SFM summary command output indicates that there is a problem, you can display more detailed SFM status information with the following CLI command:

```
user@host> show chassis sfm detail
```

The command output displays the following information:

**Sample Output**

```
user@host> show chassis sfm detail
SFM status:
Slot 0 information:
  State                               Online
  SPP Temperature                     36 degrees C / 96 degrees F
  SPR Temperature                     45 degrees C / 113 degrees F
  Total CPU DRAM                      64 Mbytes
  Total SRAM                          4 Mbytes
  Internet Processor I                Version 1, Foundry IBM, Part number 3
  Start time:                         2001-12-03 05:08:45 PST
  Uptime:                             6 hours, 41 minutes, 17 seconds
Slot 1 information:
  [...Output truncated...]
Slot 2 information:
  [...Output truncated...]
Slot 3 information:
  [...Output truncated...]

Packet scheduling mode: Disabled
```

**What It Means** In addition to the command output displayed for the `show chassis sfm` command, the `show chassis sfm detail` command displays the temperature of air passing by the Switch Plane Processor (SPP) card and the Switch Plane Router (SPR) card (the two SFM serial components) in degrees Centigrade. The command output displays the total CPU DRAM and SRAM being used by the SFM processor. It also displays the time when the SFM became active and how long the SFM has been up and running. A small uptime means that the SFM came online a short time ago and could indicate a possible SFM error condition.

**Alternative Action** To display the status of a particular SFM, use the following CLI command:

```
user@host> show chassis sfm sfm-slot
```

**Alternative Action** To display detailed status information about a particular SFM, use the following CLI command:

```
user@host> show chassis sfm detail sfm-slot
```

## Step 2: Display the SFM LED Status at the Command Line

**Action** To display the SFM LED status, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output** user@host> show chassis craft-interface

```
[...Output truncated...]
```

```
SFM LEDs:
```

```
SFM  0    1    2    3
```

```
-----
```

```
Amber  .    .    *    .
```

```
Green  *    *    .    *
```

```
Blue   *    *    .    *
```

**What it Means** The command output is for an M160 router. The SFMs in slots 0 and 1 are online and are functioning normally. The status colors represent the possible SFM operating states: Amber (Fail), Green (OK), and Blue (Master). The (\*) indicates the current operating state. There are no SFMs in slots 2 and 3.

## Step 3: Check the SFM LED Status on the Faceplate

**Action** To check the SFM LED status, remove the component cover and look on the SFM faceplate at the back of the M40e and M160 routers (see Figure 144 on page 348). Table 85 describes the SFM LED states.

**Table 85: SFM LEDs**

Color	Label	State	Description
Green	OK	On steadily	SFM is functioning normally.
		Blinking	SFM is starting up.
Amber	FAIL	On steadily	SFM has failed.

## Step 4: Display the SFM Environmental Status

**Action** To display the SFM environmental information, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output** user@host> show chassis environment

```
Class Item          Status  Measurement
```

```
Power PEM 0         OK
```

```
Power PEM 1         OK
```

```
Temp
```

```
[...Output truncated...]
```

```
SPP 0              OK      37 degrees C / 98 degrees F
```

```
SPR 0              OK      46 degrees C / 114 degrees F
```

```
SPP 1              OK      38 degrees C / 100 degrees F
```

```
SPR 1              OK      48 degrees C / 118 degrees F
```

```
SPP 2              OK      39 degrees C / 102 degrees F
```

```
SPR 2              OK      54 degrees C / 129 degrees F
```

```
SFM 3              Offline
```

```
[...Output truncated...]
```

**What it Means** The command output displays the status and temperature for the SFM and its two serialized components: the SPP card and the SPR card.

**Alternative Action** If there is a problem with the SFM status, you can display more detailed environmental information with the following CLI command:

```
user@host> show chassis environment sfm
```

```
user@host> show chassis environment sfm
SFM 0 status:
  State                               Online
  SPP temperature                     36 degrees C / 96 degrees F
  SPR temperature                     45 degrees C / 113 degrees F
  SPP Power:
    1.5 V                             1501 mV
    2.5 V                             2485 mV
    3.3 V                             3291 mV
    5.0 V                             5020 mV
    5.0 V bias                        4974 mV
  SPR Power:
    1.5 V                             1501 mV
    2.5 V                             2492 mV
    3.3 V                             3301 mV
    5.0 V                             5028 mV
    5.0 V bias                        4986 mV
    8.0 V bias                        8305 mV
  CMB Revision                        12
SFM 1 status:
  [...Output truncated...]
SFM 2 status:
  [...Output truncated...]
SFM 3 status:
  State                               Offline
  - Hard FPC error
  [...Output truncated...]
```

The command output displays the SFM slot, status, and temperature of the air flowing past the SPP card and the SPR card. It also displays information about the SFM power supplies. The chassis management bus (CMB) slave revision level is also displayed.

You can display the environmental status of a particular SFM with the following CLI command:

```
user@host> show chassis environment sfm sfm-slot
```

## Displaying SFM Alarms

---

**Steps To Take** To display SFM alarms and error messages, follow these steps:

1. Display Current SFM Alarms on page 353
2. Display SFM Error Messages in the System Log File on page 353
3. Display SFM Error Messages in the Chassis Daemon Log File on page 354

### Step 1: Display Current SFM Alarms

**Action** To display the current SFM alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
4 alarms currently active
Alarm time           Class Description
2002-05-14 09:23:58 PDT Major SFM Failure
2002-05-14 09:23:55 PDT Major SFM Failure
2002-05-14 09:23:53 PDT Major SFM Failure
2002-05-14 09:20:51 PDT Major No SFM Online, the box is not forwarding
```

**What it Means** The command output displays the alarm date, time, severity level, and description.

### Step 2: Display SFM Error Messages in the System Log File

**Action** To display the SFM error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Jun 11 20:31:11 hissy-re0 craftdd[556]: Major alarm set, No SFM Online, the box
is not forwarding
Jun 11 20:31:11 hissy-re0 alarmd[555]: Alarm set: SFM color=RED, class=CHASSIS,
reason=No SFM Online,
the box is not forwarding
```

**What it Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match sfm` command to see error messages that are generated when an SFM fails or is offline. Use this information to diagnose a power supply problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

### Step 3: Display SFM Error Messages in the Chassis Daemon Log File

The chassis daemon (chassisd) log file keeps track of the state of each chassis component.

**Action** To display the SFM error messages logged in the chassis daemon, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```
user@host> show log chassisd
Jun 11 20:50:16 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:50:16 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x0
Jun 11 20:50:16 bp_handle_button_intr button status 0x0
Jun 11 20:50:16 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:50:16 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x8
Jun 11 20:50:16 bp_handle_button_intr button status 0x8
Jun 11 20:50:16 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:50:16 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x8
Jun 11 20:50:16 bp_handle_button_intr button status 0x8
Jun 11 20:50:16 received second FPM key press, clearing timer!
Jun 11 20:50:18 bp_button_timer: taking sfm 1 offline
Jun 11 20:50:18 take_sfm_offline - slot 1 reason 7
Jun 11 20:50:18 cleaning up sfm 1 connection
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Blue LED Off [0x16]
Jun 11 20:50:18 SPP 1 - Blue LED Off
Jun 11 20:50:18 send: fpc 0, sfm 1 offline
Jun 11 20:50:18 send: fpc 1, sfm 1 offline
Jun 11 20:50:18 send: fpc 2, sfm 1 offline
Jun 11 20:50:18 send: fpc 6, sfm 1 offline
Jun 11 20:50:18 send: fpc 7, sfm 1 offline
Jun 11 20:50:18 fpc 2, sfm 1 offline ack
Jun 11 20:50:18 fpc 2, sfm 1 offline ack, online 0xc7 online-acks 0x4
Jun 11 20:50:18 fpc 1, sfm 1 offline ack
Jun 11 20:50:18 fpc 1, sfm 1 offline ack, online 0xc7 online-acks 0x6
Jun 11 20:50:18 fpc 0, sfm 1 offline ack
Jun 11 20:50:18 fpc 0, sfm 1 offline ack, online 0xc7 online-acks 0x7
Jun 11 20:50:18 fpc 7, sfm 1 offline ack
Jun 11 20:50:18 fpc 7, sfm 1 offline ack, online 0xc7 online-acks 0x87
Jun 11 20:50:18 fpc 6, sfm 1 offline ack
Jun 11 20:50:18 fpc 6, sfm 1 offline ack, online 0xc7 online-acks 0xc7
Jun 11 20:50:18 sfm_offline_now plane 1 conn 0x8152638
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Assert PLL Bypass [0x13]
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Assert Board Reset [0x2e]
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Assert ASIC Reset [0x28]
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Disable Power [0x10]
Jun 11 20:50:18 SPP 1 - Disable Power [addr 0x9 cmd 0x10]
Jun 11 20:50:18 CMB readback SPP 1 [0xe9, 0xf2] -> 0x26
Jun 11 20:50:18 power disable verified, SPP 1
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Blue LED Off [0x16]
Jun 11 20:50:18 SPP 1 - Blue LED Off
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Green LED Off [0x1a]
Jun 11 20:50:18 SPP 1 - Green LED Off
Jun 11 20:50:18 check_sfm_online_alarm: present 0xf waiting 0x0 online 0xd
Jun 11 20:50:18 send_pfe_status(): sfm 0, sfm_online_mask 0xd fpc_online_mask 0xc7
Jun 11 20:50:18 send_pfe_status(): sfm 2, sfm_online_mask 0xd fpc_online_mask 0xc7
[...Output truncated...]
```



**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. You can search for multiple items in the chassisd log file by using the | match “item |item |item” command. For example, | match “sfm|kernel|tnp” is a search for error messages for the SFM, kernel, and Trivial Networking Protocol (TNP), and indicates communication issues between the Routing Engine and the Packet Forwarding Engine components.

Verifying SFM Failure

- Steps To Take** To verify SFM failure, follow these steps:
- 1. Check the SFM Connection on page 355
  - 2. Check the SFM Fuses on page 355
  - 3. Perform an SFM Swap Test on page 356

Step 1: Check the SFM Connection

**Action** To check the SFM connection, make sure that it is properly seated in the midplane. Check the thumbscrews on the ejector locking tabs.

Step 2: Check the SFM Fuses


**Action** Check for blown SFM fuses.

The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly. You must remove the lower impeller assembly to access the fuses, as described in the *M40e Router Hardware Guide*.

When the fuse for an SFM blows, the SFM stops functioning even though it is installed correctly and the power supplies are providing power to the router.

For the M40e and M160 routers, when a fuse has blown but the power supplies are still delivering power to router, the amber LED adjacent to the fuse lights. See Figure 146.

Figure 146: M40e M160 Router Fuses



Another indication that a fuse has blown is that the colored indicator bulb inside it becomes visible through the clear cover on the fuse. For information about the indicator bulb color for each fuse type, see the appropriate router hardware guide.

A blown fuse can cause a component to fail even though it is correctly installed and the power supplies are functioning. Check for a blown fuse in the following circumstances:

- The LED that indicates normal operation for the component fails to light.
- The appropriate CLI **show chassis environment** command indicates that the component is installed but is not receiving power.

### Step 3: Perform an SFM Swap Test



**NOTE:** Before performing a swap test, always check for bent pins in the midplane and check the SFM for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an SFM, follow these steps:

1. Remove the chassis rear component cover by loosening the screws on the corners of the cover and pulling it straight out from the chassis.
2. Remove the SFM, as described in the M40e and M160 router hardware guides.
3. Take the SFM offline by doing one of the following:
  - Use the following CLI command:
 

```
user@host> request chassis sfm slot slot-number offline
```
  - Press and hold the offline button on the SFM faceplate at the rear of the router until the **SFM OK** LED turns off (about 5 seconds).
4. Replace the SFM with one that you know works.
5. Bring the SFM online by doing one of the following:
  - Use the following CLI command:
 

```
user@host> request chassis sfm slot slot-number online
```
  - Press and hold the offline button on the SFM faceplate until the green OK LED lights (about 5 seconds).
6. Reinstall the rear component cover and tighten the screws to secure it to the chassis.
7. Check the SFM status. See “Display the SFM Summary Status” on page 349.

## Getting SFM Hardware Information

**Steps To Take** To get the hardware information you need to return a failed SFM, follow these steps:

1. Display SFM Hardware Information on page 357
2. Locate the SFM Serial Number ID Label on page 357

### Step 1: Display SFM Hardware Information

**Action** To display the SFM hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Item          Version  Part number  Serial number  Description
Chassis                                     20079         M160
[...Output truncated...]
SFM 0 SPP      REV 04    710-001228   AA2860
SFM 0 SPR      REV 01    710-001224   AB0139         Internet Processor I
SFM 1 SPP      REV 04    710-001228   AA2859
SFM 1 SPR      REV 02    710-001224   AA9861         Internet Processor I
SFM 2 SPP      REV 06    710-001228   AB3082
SFM 2 SPR
SFM 3 SPP      REV 04    710-001228   AA1998
SFM 3 SPR      REV 01    710-001224   AB0137         Internet Processor I
[...Output truncated...]
```

**What it Means** The command output displays the SFM slot number and SFM serial component (SPP and SPR) card names, SFM revision level, part number, serial number, and description.

### Step 2: Locate the SFM Serial Number ID Label

**Action** To locate the SFM serial number ID label, look on the left side of the SFM top panel (see Figure 147).

**Figure 147: SFM Serial Number ID Label**



## Replacing the SFM

---

The SFMs are hot-removable and hot-insertable. You can remove and replace SFMs without powering down the router or disrupting the routing functions. However, you must take an SFM offline before replacing it.

Inserting or removing an SFM causes a brief interruption in forwarding performance (about 500 ms) as the Packet Forwarding Engine reconfigures the distribution of packets across the remaining SFMs.

**Action** To replace an SFM, see “Return the Failed Component” on page 86, or the procedure to return a field-replaceable unit in the M40e or M160 router hardware guide.

## Chapter 27

# Monitoring the MCS

You monitor and maintain the Miscellaneous Control Subsystem (MCS) to provide control and monitoring functions for router components and to provide SONET/SDH clocking for the M40e and M160 routers. (See Table 86.)

**Table 86: Checklist for Monitoring the MCS**


Monitor MCS Tasks	Command or Action
<b>Understanding the MCS on page 360</b>	
<b>Checking the MCS Status on page 362</b>	
1. Check the MCS Environmental Status on page 362	<code>show chassis environment mcs</code>
2. Check the MCS Status from the Craft Interface on page 363	<code>show chassis craft-interface</code>
3. Check the MCS LEDs on page 364	Check the LEDs on the MCS faceplate.
<b>Verifying MCS Failure on page 365</b>	
1. Check the MCS Fuses on page 365	The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly.
2. Perform an MCS Swap Test on page 366	Remove the MCS and replace it with one that you know works.
<b>Getting MCS Hardware Information on page 367</b>	
1. Display the MCS Hardware Information on page 367	<code>show chassis hardware</code>
2. Locate the MCS Serial Number ID Label on page 368	Look at the bottom left of the MCS board.
<b>Returning the MCS on page 368</b>	See “Return the Failed Component” on page 86, or follow the procedure in the M40e or M160 router hardware guide.

## Understanding the MCS

**Purpose** Inspect the MCS to ensure that control and monitoring functions for router components and SONET/SDH clocking for the router function normally.

**What Is an MCS** The MCS is a component of the host module on M40e and M160 routers (see Figure 148). The MCS works with the Routing Engine to provide control and monitoring functions for router components and to provide SONET/SDH clocking for the router.

**Figure 148: MCS Component**



The router can be equipped with up to two MCSs for redundancy. If two MCSs are installed, one acts as the master MCS and the other acts as a backup. If the master MCS fails or is removed, the backup MCS restarts and becomes the master MCS.




**NOTE:** The host modules (RE0 working with MCS0 and RE1 working with MCS1) actually have the master and backup role.

Each MCS requires a Routing Engine to be installed in an adjacent slot. MCS0 installs above RE0, and MCS1 installs below RE1. Even if an MCS is physically installed in the chassis, it does not function if there is no Routing Engine present in the adjacent slot.


The MCS installs into the midplane from the back of the chassis (see Figure 149).

**Figure 149: M40e and M160 Router MCS Location**

**M40e router rear**



**M160 router rear**



- See Also**
- Monitoring the Host Module on page 341
  - Monitoring the Routing Engine on page 125
  - Monitoring Redundant Routing Engines on page 491
  - Monitoring Redundant MCSs on page 567

## Checking the MCS Status

---

**Steps To Take** To check the MCS status, follow these steps:

1. Check the MCS Environmental Status on page 362
2. Check the MCS Status from the Craft Interface on page 363
3. Check the MCS LEDs on page 364

### Step 1: Check the MCS Environmental Status

**Action** To check the MCS environmental status, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis environment mcs
```

**Sample Output**

```
user@host> show chassis environment mcs
MCS 0 status:
  State                Online Master
  Temperature          43 degrees C / 109 degrees F
  Power:
    3.3 V              3318 mV
    5.0 V              4974 mV
    12.0 V on          12
  FPGA Revision        13
MCS 1 status:
  State                Online Standby
  Temperature          58 degrees C / 136 degrees F
  Power:
    3.3 V              3317 mV
    5.0 V              5006 mV
    12.0 V             11843 mV
    5.0 V bias         4998 mV
    8.0 V bias         8195 mV
  BUS Revision         12
  FPGA Revision        255
```

**What It Means** The `show chassis environment mcs` command is available on the M40e and M160 routers only. The command output displays environmental information about both MCSs installed in the router or about an individual MCS. The MCS status can be **Present**, **Online**, **Offline**, or **Empty**. The command also indicates that the MCS is the master MCS. The command output also displays the temperature of the air flowing past the MCS, information about MCS power supplies, field-programmable gate array (FPGA) revision information, and the revision level of the chassis management bus (CMB) slave.

**Alternative Action** To display the environmental status of a particular MCS, use the following JUNOS CLI operational mode command:

```
user@host> show chassis environment mcs slot
```



## Step 2: Check the MCS Status from the Craft Interface

**Action** To display the MCS LED status from the craft interface, use the following JUNOS software operational mode CLI command:

```
user@host> show chassis craft-interface
```


**Sample Output** user@host> **show chassis craft-interface**  
[...Output truncated...]

```
MCS and SFM LEDs:
MCS   0   1   SFM   0   1   2   3
-----
Amber      .           .   .
Green      .           .   .
Blue       *           *   *
```

**What It Means** If the amber FAIL LED is on, check for current MCS alarms.

**Alternative Action** Look at the Host Module LEDs on the craft interface. The LEDs indicate the MCS status. (See Figure 150.)




**Figure 150: M40e and M160 Router Craft Interface Host Module LEDs**



Three host module LEDs—one green **MASTER**, one green **ONLINE**, and one red **OFFLINE**—located on the upper right of the craft interface indicate the status of each host module. The LEDs marked **HOST0** show the status of the Routing Engine in slot **RE0** and the MCS in slot **MCS0**. The LEDs marked **HOST1** show the status of the Routing Engine in slot **RE1** and the MCS in slot **MCS1**.

Table 87 describes the functions of the host module LEDs.

**Table 87: Host Module LEDs**

Label	Shape	Color	State	Description
MASTER		Green	On steadily	Host module (Routing Engine and MCS) is functioning as master.
ONLINE		Green	On steadily	Host module is present and operational.
			Blinking	Host module is starting up.
OFFLINE		Red	On steadily	Host module is not present, or is present but not operational.

### Step 3: Check the MCS LEDs

**Action** To check the MCS status, look at the LEDs on the MCS faceplate.

Table 88 describes the functions of these LEDs.

**Table 88: MCS LEDs**

Color	Label	State	Description
Blue	MASTER	On steadily	MCS is master.
Green	OK	On steadily	MCS is operating normally.
		Blinking	MCS is starting up.
Amber	FAIL	On steadily	MCS has failed.

When the MCS is functioning normally, the green **OK** LED remains on steadily. If the amber **FAIL** LED is on, check for MCS alarms.

Verifying MCS Failure

- Steps To Take** To verify MCS operation failure, follow these steps:
- 1. Check the MCS Fuses on page 365
  - 2. Perform an MCS Swap Test on page 366

Step 1: Check the MCS Fuses


**Action** Check the MCS fuses to check for failure.

The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly. You must remove the lower impeller assembly to access the fuses, as described in the appropriate router hardware guide.

When the fuse for an MCS blows, the MCS stops functioning even though it is installed correctly and the power supplies are providing power to the router.

For the M40e and M160 routers, when a fuse has blown but the power supplies are still delivering power to router, the amber LED adjacent to the fuse lights. See Figure 151.

Figure 151: M40e M160 Router Fuses



Another indication that a fuse has blown is that the colored indicator bulb inside it becomes visible through the clear cover on the fuse. For information about the indicator bulb color for each fuse type, see the appropriate router hardware guide.

A blown fuse can cause a component to fail even though it is correctly installed and the power supplies are functioning. Check for a blown fuse in the following circumstances:

- The LED that indicates normal operation for the component fails to light.
- The appropriate CLI `show chassis environment` command indicates that the component is installed but is not receiving power.

## Step 2: Perform an MCS Swap Test

The MCS can fail and not start, or it can cause a connectivity problem between the Routing Engine and the Packet Forwarding Engine components, such as the Flexible PIC Concentrator (FPC) and Switching and Forwarding Module (SFM). You can perform a swap test on the MCS to try to pinpoint the problem.



**CAUTION:** The MCS is hot-pluggable. Routing functions are interrupted until a replacement is installed. You should perform a swap test during a maintenance window.

Before performing a swap test, always check for bent pins in the midplane and check the MCS for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an MCS, remove it and replace it with one that you know works.

Normally, if two host modules are installed in the router, **HOST0** functions as the master and **HOST1** as the backup. You can remove the backup host module (or either of its components) without interrupting the functioning of the router. If you take the master host module offline, the router reboots and the backup host module becomes the master. If the router has only one host module, taking it offline causes the router to shut down.

The host module is taken offline and brought back online as a unit. Before you replace the Routing Engine or an MCS, you must take the host module offline; the host module is hot-pluggable.

To remove an MCS, follow these steps:

1. Place an electrostatic bag or antistatic mat on a flat, stable surface to receive the Routing Engine.
2. Attach an electrostatic discharge (ESD) strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
3. Remove the rear component cover by loosening the screws at the corners of the cover and pulling it straight off of the chassis.
4. If two host modules are installed, check whether the MCS you are removing belongs to the master host module. Use the `show chassis environment mcs` CLI command or check the MCS LEDs. If it does, switch mastership to the standby host module. You can change the default mastership by including the `routing-engine` statement at the `[edit chassis redundancy]` hierarchy level in the configuration, as described in the *JUNOS System Basics Configuration Guide*.

5. On the console or other management device connected to the Routing Engine that is paired with the MCS you are removing, enter CLI operational mode and issue the following command. The command shuts down the Routing Engine cleanly, so its state information is preserved.

```
user@host> request system halt
```

Wait to continue until all software processes have shut down.

6. Flip the ends of the extractor clips outward.
7. Grasp the extractor clips and slide the unit about halfway out of the chassis.
8. Place one hand under the MCS to support it, slide it completely out of the chassis, and place it on the antistatic mat or in the electrostatic bag.
9. Align the rear of the MCS with the guides inside the chassis and slide it in completely.
10. Press the extractor clips on the left and right sides of the MCS inward.
11. Verify that the green LED labeled **OK** on the MCS faceplate is lit. Also check the host module LEDs on the craft interface to verify that the green LED labeled **ONLINE** is lit for the host module to which the MCS belongs.

You can also verify correct MCS functioning by using the `show chassis environment mcs` command.

12. Reinstall the rear component cover and tighten the screws at the corners to secure it to the chassis.

## Getting MCS Hardware Information

---

**Steps To Take** To get MCS hardware information, follow these steps:

1. Display the MCS Hardware Information on page 367
2. Locate the MCS Serial Number ID Label on page 368

### Step 1: Display the MCS Hardware Information

**Action** To display the MCS hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis
[...Output truncated...]
Routing Engine 0
MCS 0         REV 11    710-001226   AS4709        RE-2.0
[...Output truncated...]
```

**What It Means** The command output displays the MCS slot number, revision level, part number, and serial number. Give this information to the Juniper Networks Technical Assistance Center (JTAC) if the MCS fails.

## Step 2: Locate the MCS Serial Number ID Label

**Action** To locate the MCS serial number ID label, look on the bottom left side of the board, as shown in Figure 152.

**Figure 152: MCS Serial Number ID Label**



## Returning the MCS

**Action** To return the MCS, see “Replacing a Failed Component” on page 122, or the procedure to return a field-replaceable unit in the M40e or M160 router hardware guide.

## Chapter 28

# Monitoring the PCG

You monitor the Packet Forwarding Engine Clock Generator (PCG) to ensure that a clocking signal is generated to synchronize the internal M40e and M160 router Packet Forwarding Engine components. (See Table 89.)

**Table 89: Checklist for Monitoring the PCG**

Monitor PCG Tasks	Command or Action
<b>Understanding the PCG on page 370</b>	
<b>Monitoring the PCG Status on page 371</b>	
1. Monitor the PCG Environmental Status on page 371	show chassis environment show chassis environment pcg
2. Display the PCG LED States at the Command Line on page 372	show chassis craft-interface
3. Look at the PCG LEDs on the Faceplate on page 373	Remove the rear component cover and look on the PCG faceplate at the back of the M40e or M140 router chassis.
<b>Determining PCG Mastership on page 373</b>	
1. Display the PCG Master in the Craft Interface Output on page 373	show chassis craft-interface
2. Look at the PCG LEDs on the Faceplate on page 374	Remove the rear component cover and look on the PCG faceplate at the rear of the M40e or M160 router chassis.
3. Display the Packet Forwarding Engine Current Clock Source on page 374	show chassis clocks
<b>Displaying PCG Alarms on page 375</b>	
1. Display Current PCG Alarms on page 375	show chassis alarms
2. Display PCG Error Messages in the System Log File on page 375	show log messages
3. Display PCG Error Messages in the Chassis Daemon Log File on page 375	show log chassisd
<b>Verifying PCG Failure on page 376</b>	
1. Check the PCG Connection on page 376	Check the thumbscrew on the right side of the PCG.
2. Check the PCG Fuses on page 377	The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly.


Monitor PCG Tasks	Command or Action
3. Perform a PCG Swap Test on page 378	<ol style="list-style-type: none"> <li>1. Take the PCG offline.</li> <li>2. Replace the PCG with one that you know works.</li> <li>3. Bring the PCG online.</li> <li>4. Check the PCG status.</li> </ol>
<b>Getting PCG Hardware Information on page 378</b>	
1. Display the PCG Hardware Information on page 379	<code>show chassis hardware</code>
2. Locate the PCG Serial Number ID Label on page 379	Look on the top of the PCG, close to the midplane connector.
<b>Replacing the PCG on page 379</b>	See “Return the Failed Component” on page 86, or follow the procedure in the M40e or M160 router hardware guide.

## Understanding the PCG

**Purpose** You monitor the PCGs to ensure that they generate a clock signal to synchronize the modules and application-specific integrated circuits (ASICs) that make up the Packet Forwarding Engine.

**What Is a PCG** The PCG supplies a 125-MHz system clock to synchronize the modules and ASICs that make up the Packet Forwarding Engine (see Figure 153).

**Figure 153: PCG Component**



A router has two PCGs. They are located at the rear of the chassis in the slots labeled **PCG0** and **PCG1**, to the right of the Routing Engine slots.

Both PCGs send clock signals to the Packet Forwarding Engine modules, along with a signal indicating which is the master clock source. The master Routing Engine controls which PCG is master and which is backup.


The PCGs are field-replaceable and hot-pluggable. You can remove and replace them without powering down the router; however, the routing functions of the system are interrupted when a PCG is removed.

Removing the backup PCG does not affect the functioning of the router. Taking the master PCG offline causes the Flexible PIC Concentrators (FPCs) and Switching and Forwarding Modules (SFMs) to power down and restart with the other PCG selected as master. The forwarding and routing functions are interrupted during this process.



Figure 154 shows the location of the PCGs on the M40e and M160 router chassis.

**Figure 154: M40e and M160 Router PCG Location**



## Monitoring the PCG Status

**Steps To Take** To monitor the PCG status, follow these steps:

1. Monitor the PCG Environmental Status on page 371
2. Display the PCG LED States at the Command Line on page 372
3. Look at the PCG LEDs on the Faceplate on page 373

### Step 1: Monitor the PCG Environmental Status

**Action** To monitor the PCG environment status, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@host> show chassis environment
Class Item          Status      Measurement
Power PEM 0          OK
          PEM 1          OK
Temp  PCG 0          OK          41 degrees C / 105 degrees F
          PCG 1          OK          39 degrees C / 102 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the status and temperature for each PCG.

**Alternative Action** If there is a problem with the PCG status, you can display more detailed PCG environmental information with the following CLI command:

```
user@host> show chassis environment pcg
```

The command output is as follows:

```
user@host> show chassis environment pcg
PCG 0 status:
  State                Online - PFE clock source
  Temperature           41 degrees C / 105 degrees F
  Frequency:
    Setting             125.00 MHz
    Measurement         125.03 MHz
  Power:
    3.3 V               3266 mV
    5.0 V bias          4981 mV
    8.0 V bias          8168 mV
  CMB Revision          12
PCG 1 status:
  State                Online
  Temperature           39 degrees C / 102 degrees F
  Frequency:
    Setting             125.00 MHz
    Measurement         125.03 MHz
  Power:
    3.3 V               3271 mV
    5.0 V bias          4971 mV
    8.0 V bias          8175 mV
  CMB Revision          12
```

The command output displays the status for each PCG slot 0 and 1. The operating status can be **Present**, **Online**, **Offline**, or **Empty**. If **Online**, it can be the current PFE clock source or backup. The command output displays the temperature of the air flowing past the PCG and the frequency setting and measurement for the PCG. The command output also displays information about the PCG power supplies and the revision level of the chassis management bus (CMB) slave.

## Step 2: Display the PCG LED States at the Command Line

**Action** To display the PCG LED states, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
[...Output truncated...]
PCG LEDs:
  PCG  0  1
  -----
Amber   .  .
Green  *  *
Blue   *  .

[...Output truncated...]
```

**What It Means** The command output is for an M160 router. The PCGs in slots 0 and 1 are online and are functioning normally. The status colors represent the possible PCG operating states: **Amber** (Fail), **Green** (OK), and **Blue** (Master). The (\*) indicates the current operating state.

### Step 3: Look at the PCG LEDs on the Faceplate

**Action** To view the PCG LEDs, remove the rear component cover and look on the PCG faceplate at the rear of the M40e or M160 router chassis (see Figure 153 on page 370 and Figure 154 on page 371). Table 90 describes the functions of these LEDs.

**Table 90: PCG LEDs**

Color	Label	State	Description
Blue	MASTER	On steadily	PCG is master.
Green	OK	On steadily	PCG is operating normally.
		Blinking	PCG is starting up.
Amber	FAIL	On steadily	PCG has failed.

## Determining PCG Mastership

The PCGs function as redundant components. For information about monitoring redundant PCGs, see “Monitoring Redundant PCGs” on page 595.

- Steps To Take** To determine which PCG is operating as the master, follow these steps:
1. Display the PCG Master in the Craft Interface Output on page 373
  2. Look at the PCG LEDs on the Faceplate on page 374
  3. Display the Packet Forwarding Engine Current Clock Source on page 374

### Step 1: Display the PCG Master in the Craft Interface Output

**Action** To determine the PCG master from the craft interface status information, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
[...Output truncated...]
PCG LEDs:
  PCG  0    1
-----
Amber  .    .
Green  *    *
Blue   *    .

[...Output truncated...]
```

**What It Means** The command output shows that PCG 0 is the master because the blue MASTER LED is on.

**Step 2: Look at the PCG LEDs on the Faceplate**

**Action** To check the PCG LEDs, look on the PCG faceplate at the rear of the M40e or M160 router chassis (see Figure 153 on page 370 and Figure 154 on page 371). Table 90 describes the PCG LED states. If the blue **MASTER** LED on the PCG faceplate is on steadily, the PCG is functioning as master.

**Step 3: Display the Packet Forwarding Engine Current Clock Source**

The Packet Forwarding Engine current clock source is the master PCG.

**Action** To display the PCG master from the Packet Forwarding Engine clock source output, use the following CLI command:

```
user@host> show chassis clocks
```

**Sample Output**

```
user@host> show chassis clocks
PFE clock status:
  Current source      PCG 0
  Measured frequency  125.03 MHz
Reference clock status:
  Current source      Primary
  Primary source      Internal
  Secondary source    Internal
  Tertiary source     Internal
  Rollover algorithm  Holdover
  PLL mode            Free-running
  PLL errors          0
  Sync message current 0x00
  Sync message normal 0x00
  Sync message override 0x00
```

**What It Means** The command output shows that the PCG in slot 0 is the primary clock source.

## Displaying PCG Alarms

---

**Steps To Take** To display PCG alarms and error messages, follow these steps:

1. Display Current PCG Alarms on page 375
2. Display PCG Error Messages in the System Log File on page 375
3. Display PCG Error Messages in the Chassis Daemon Log File on page 375

### Step 1: Display Current PCG Alarms

**Action** To display the current PCG alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
2 alarms currently active
Alarm time          Class  Description
2002-06-11 20:30:29 PDT  Minor PCG 0 Not Online
2002-06-11 20:30:32 PDT  Minor No PCGs Online
```

**What It Means** The command output displays the alarm date, time, severity level, and description.

### Step 2: Display PCG Error Messages in the System Log File

**Action** To display the PCG error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Jun 11 20:31:31 myrouter chassisd[553]: CHASSISD_NO_GOOD_PCGS:
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match pcgs` command to see error messages that are generated when a PCG fails or is offline. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

### Step 3: Display PCG Error Messages in the Chassis Daemon Log File

**Action** To display the PCG error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```

user@host> show log chassisd
Jun 11 20:31:17 FPC 7 - Disable Power [addr 0x17 cmd 0x10]
Jun 11 20:31:17 CMB readback FPC 7 [0xf7, 0xf2] -> 0x26
Jun 11 20:31:17 power disable verified, FPC 7
Jun 11 20:31:17 CHASSISD_IFDEV_DETACH: ifdev_detach(7)
Jun 11 20:31:17 ifd so-7/0/0 marked as gone
Jun 11 20:31:19 PCG 0 set alarm 0x3
Jun 11 20:31:19 alarm op fru 1 op 1 reason 3
Jun 11 20:31:19 send: yellow alarm set, class 100 obj 110 reason 3
Jun 11 20:31:19 CMB cmd to PCG 0 [0xe2], Disable Power [0x10]
Jun 11 20:31:19 PCG 0 - Disable Power [addr 0x2 cmd 0x10]
Jun 11 20:31:19 CMB readback PCG 0 [0xe2, 0xf2] -> 0x6
Jun 11 20:31:19 power disable verified, PCG 0
Jun 11 20:31:19 CMB cmd to PCG 0 [0xe2], Blue LED Off [0x16]
Jun 11 20:31:19 PCG 0 - Blue LED Off
Jun 11 20:31:19 CMB cmd to PCG 0 [0xe2], Green LED Off [0x1a]
Jun 11 20:31:19 PCG 0 - Green LED Off
Jun 11 20:31:19 CMB cmd to PCG 0 [0xe2], Amber LED Off [0x18]
Jun 11 20:31:19 PCG 0 - Amber LED Off
Jun 11 20:31:19 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:31:19 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x0
Jun 11 20:31:19 bp_handle_button_intr button status 0x0
Jun 11 20:31:21 reading FPC 0 initial state
Jun 11 20:31:21 CMB readback FPC 0 [0xf0, 0xff] -> 0xc
Jun 11 20:31:21 reading FPC 0 ideeprom
Jun 11 20:31:21 reading FPC 1 initial state
Jun 11 20:31:21 CMB readback FPC 1 [0xf1, 0xff] -> 0xc
Jun 11 20:31:21 reading FPC 1 ideeprom
Jun 11 20:31:21 reading FPC 2 initial state
Jun 11 20:31:21 CMB readback FPC 2 [0xf2, 0xff] -> 0xc
Jun 11 20:31:21 reading FPC 2 ideeprom
Jun 11 20:31:21 reading FPC 6 initial state
Jun 11 20:31:21 CMB readback FPC 6 [0xf6, 0xff] -> 0xc
Jun 11 20:31:21 reading FPC 6 ideeprom
Jun 11 20:31:21 reading FPC 7 initial state
Jun 11 20:31:21 CMB readback FPC 7 [0xf7, 0xff] -> 0xc
Jun 11 20:31:21 reading FPC 7 ideeprom
Jun 11 20:31:21 gen_sfm_wait_mask 0x0
Jun 11 20:31:21 ...power sequencer started...

```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.

## Verifying PCG Failure

---

**Steps To Take** To verify PCG failure, follow these steps:

1. Check the PCG Connection on page 376
2. Perform a PCG Swap Test on page 378

### Step 1: Check the PCG Connection

**Action** To check the PCG connection, make sure the PCG is properly seated in the midplane. Check the thumbscrew on the right side of the PCG.

## Step 2: Check the PCG Fuses


**Action** Check the PCG fuses to check for failure.

The M40e and M160 router fuses are located in a fuse box at the rear of the midplane, behind the lower rear impeller assembly. You must remove the lower impeller assembly to access the fuses, as described in the appropriate router hardware guide.

When the fuse for an PCG blows, the PCG stops functioning even though it is installed correctly and the power supplies are providing power to the router.

For the M40e and M160 routers, when a fuse has blown but the power supplies are still delivering power to router, the amber LED adjacent to the fuse lights. See Figure 155 on page 377.

**Figure 155: M40e M160 Router Fuses**



Another indication that a fuse has blown is that the colored indicator bulb inside it becomes visible through the clear cover on the fuse. For information about the indicator bulb color for each fuse type, see the appropriate router hardware guide.

A blown fuse can cause a component to fail even though it is correctly installed and the power supplies are functioning. Check for a blown fuse in the following circumstances:

- The LED that indicates normal operation for the component fails to light.
- The appropriate CLI **show chassis environment** command indicates that the component is installed but is not receiving power.

### Step 3: Perform a PCG Swap Test

---



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the PCG for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

---

**Action** To perform a swap test on a PCG, follow these steps:

1. Have an antistatic mat ready.
2. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
3. Remove the rear component cover by loosening the screws on the corners of the cover and pulling it straight out from the chassis.
4. Press the offline button on the faceplate of the PCG and hold it down until the Red **FAIL** LED lights (about 3 seconds).
5. Loosen the thumbscrew on the right side of the PCG.
6. Grasp the thumbscrew and slide out the PCG.
7. Align the rear of the PCG with the guides inside the chassis.
8. Slide the PCG all the way into the card cage until it contacts the midplane.
9. Tighten the thumbscrew on the right side of the PCG faceplate.
10. Verify that the PCG is properly installed by looking at the LEDs on the PCG faceplate. The green **OK** LED should light steadily.

### Getting PCG Hardware Information

---

**Steps To Take** To get the PCG hardware information, follow these steps:

1. Display the PCG Hardware Information on page 379
2. Locate the PCG Serial Number ID Label on page 379



## Step 1: Display the PCG Hardware Information

**Action** To display the PCG hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis          REV 03   710-001245   20079          M160
Midplane         REV 02   710-001642   AB4132
FPM CMB          REV 02   710-001642   AB3264
FPM Display      REV 02   710-001647   AB3046
CIP              REV 04   710-001593   AB3284
PEM 0            Rev 03   740-001243   KM28409        DC
PEM 1            Rev 03   740-001243   KM13359        DC
PCG 0            REV 02   710-001568   AB3013
PCG 1            REV 02   710-001568   AB3000
```

**What It Means** The command output displays the PCG slot number, revision level, part number, and serial number.

## Step 2: Locate the PCG Serial Number ID Label

**Action** To locate the PCG serial number ID label, look on the top of the PCG, close to the midplane connector.

**Figure 156: PCG Serial Number ID Label**



## Replacing the PCG

The PCGs are hot-pluggable. You can remove and replace them without powering down the router, but the routing functions of the system are interrupted when the PCG is removed.

If both PCGs are installed and functioning normally, PCG0 is the master PCG and PCG1 is the backup by default.

Removing the backup PCG does not affect the functioning of the router. Taking the master PCG offline causes the FPCs and SFMs to power down and restart, with the other PCG selected as master. The forwarding and routing functions are interrupted during this process.

**Action** To replace a PCG, see “Return the Failed Component” on page 86, or the procedure to return a field-replaceable unit in the M40e or M160 router hardware guide.

## Chapter 29

# Monitoring the CIP

You monitor the Connector Interface Panel (CIP) to ensure management connection to the M40e, M160, M320, T320, and T640 routing node Routing Engines, Building Integrated Timing Source (BITS) interfaces for the Miscellaneous Control Subsystem (MCS), and alarm relay contacts. (See Table 91.)

**Table 91: Checklist for Monitoring the CIP**


Tasks for Monitoring the CIP	Command or Action
<b>Understanding the CIP on page 382</b>	
<b>Monitoring the CIP Status on page 384</b>	show chassis environment
<b>Checking for CIP Alarms on page 385</b>	
1. Display Current CIP Alarms on page 385	show chassis alarms
2. Display CIP Error Messages in the System Log File on page 385	show log messages
3. Display CIP Error Messages in the Chassis Daemon Log File on page 386	show log chassisd
<b>Verifying CIP Failure on page 386</b>	
1. Check the CIP Connection on page 386	Check the connector screws on the CIP faceplate.
2. Check the Ethernet Port Functionality on page 386	1. Connect to the Ethernet port. 2. Check the LINK LED. 3. Run the JUNOS software CLI.
3. Performing a CIP Swap Test on page 387	1. Power down the router. 2. Remove the CIP. 3. Replace the CIP with one that you know works. 4. Power on the router.
<b>Getting CIP Hardware Information on page 388</b>	
1. Display CIP Hardware Information on page 388	show chassis hardware
2. Locating the CIP Serial Number ID Label on page 389	Look on the top of the left side of the CIP.
<b>Replacing the CIP on page 389</b>	Power down the router. To replace and return a CIP, follow the instructions in the M40e or M160 router hardware guide.

## Understanding the CIP

**Purpose** Inspect the CIP to ensure connection to the Routing Engines, BITS interfaces for the MCS, and alarm relay contacts.

**What Is the CIP** The CIP provides an interface through which you can connect to the M40e and M160 Routing Engines, BITS interfaces for the MCS, and alarm relay contacts (see Figure 157).

**Figure 157: CIP Component**



The CIP has two sets of ports you use to connect the Routing Engines to external management devices. From these management devices, you can use the JUNOS software command-line interface (CLI) to configure and monitor the router.

The upper set of ports, labeled **HOST0**, connect to the Routing Engine in slot **RE0**, and the lower set of ports, labeled **HOST1**, connect to the Routing Engine in slot **RE1**.

Each **HOST** port set includes the following ports:


- **ETHERNET**—Connects the Routing Engine through an Ethernet connection to a management LAN (or any other device that plugs into an Ethernet connection) for out-of-band management. The port uses an autosensing RJ-45 connector to support both 10-Mbps and 100-Mbps connections. Two small LEDs on the left edge of the port indicate the connection in use: the amber LED lights for a 10-Mbps connection and the green LED lights for a 100-Mbps connection.
- **CONSOLE**—Connects the Routing Engine to a system console through an RS-232 (EIA-232) serial cable.
- **AUXILIARY**— Connects the Routing Engine to a laptop, modem, or other auxiliary device through an RS-232 (EIA-232) serial cable.

At the center of the CIP are two ports labeled **BITS A** and **BITS B**. These are the BITS connectors to the MCS. The router does not support BITS input, so these ports currently do not function.

The CIP has two sets of alarm relay contacts for connecting the router to external alarm devices. Whenever a system condition triggers either the red or yellow alarm on the craft interface, the alarm relay contacts are also activated. The alarm relay contacts are located below the BITS interface ports.

The CIP is located on the left side of the M40e and M160 router Flexible PIC Concentrator (FPC) card cage (see Figure 158).

**Figure 158: M40e and M160 Router CIP Location**



The CIP is field-replaceable, but is not hot-removable, hot-insertable, or hot-pluggable. You must power down the router before removing or installing it.

- See Also**
- Maintaining the Cable Management System, Cables, and Connectors on page 275
  - Monitoring the Routing Engine on page 125

## Monitoring the CIP Status

**Action** To monitor the CIP status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@host> show chassis environment
Class Item              Status      Measurement
[...Output truncated...]
Misc  CIP                  OK
```

**What It Means** The command output displays the status for the CIP, which can be OK, Absent, or Failed.

## Checking for CIP Alarms

---

**Steps To Take** To check for CIP alarms, follow these steps:

1. Display Current CIP Alarms on page 385
2. Display CIP Error Messages in the System Log File on page 385
3. Display CIP Error Messages in the Chassis Daemon Log File on page 386

### Step 1: Display Current CIP Alarms

**Action** To display the current CIP alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
2 alarms currently active
Alarm time           Class  Description
2002-06-11 20:45:08 UTC Major  Connector Interface Panel Missing
2002-06-11 20:45:07 UTC Major  fxp0: ethernet link down
```

**What It Means** The command output displays the alarm date, time, severity level, and description. fxp0 is the Ethernet connection to a management LAN.

### Step 2: Display CIP Error Messages in the System Log File

**Action** To display the CIP error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Jun 11 20:45:07 hissy-re0 /kernel: fxp0: link media DOWN 10Mb / half-duplex
Jun 11 20:45:07 hissy-re0 craftd[556]: Major alarm set, fxp0: ethernet link
down
Jun 11 20:45:07 hissy-re0 alarmd[555]: Alarm set: fxp0 color=RED, class=ETHER,
reason=fxp0: ethernet link down
Jun 11 20:45:07 hissy-re0 mib2d[560]: SNMP_TRAP_LINK_DOWN: ifIndex 1,
ifAdminStatus up(1), ifOperStatus down(2), ifName fxp0
Jun 11 20:45:08 hissy-re0 craftd[556]: Major alarm set, Connector Interface
Panel Missing
Jun 11 20:45:08 hissy-re0 alarmd[555]: Alarm set: CIP color=RED, class=CHASSIS,
reason=Connector Interface Panel Missing
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match cip` command to see specific error messages that are generated when a CIP fails or is offline. Use this information to diagnose a power supply problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

### Step 3: Display CIP Error Messages in the Chassis Daemon Log File

**Action** To display CIP error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```
user@host> show log chassisd
Jun 11 20:45:08 *** inventory change ***
Jun 11 20:45:08 CIP set alarm 0x1
Jun 11 20:45:08 alarm op fru 34 op 1 reason 1
Jun 11 20:45:08 send: red alarm set, class 100 obj 112 reason 1
Jun 11 20:45:08 CIP removed
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.

## Verifying CIP Failure

---

**Steps To Take** To verify CIP failure, follow these steps:

1. Check the CIP Connection on page 386
2. Check the Ethernet Port Functionality on page 386
3. Performing a CIP Swap Test on page 387

### Step 1: Check the CIP Connection

If the CIP is not seated properly, it will not function.

**Action** To check the CIP connection, check the screws on the top and bottom of the CIP faceplate and make sure that the CIP is properly seated in the slot.

### Step 2: Check the Ethernet Port Functionality

**Action** To check the Ethernet port, plug an Ethernet cable into the Ethernet port on the CIP.

If the host module is operational, the LINK LED (either the yellow 10-Mbps LED or the green 100-Mbps LED) will flash to register Ethernet activity. If you can run the CLI, the CIP is installed correctly.



### Step 3: Performing a CIP Swap Test



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the CIP for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on a CIP, follow these steps:

1. Place an electrostatic bag or antistatic mat on a flat, stable surface to receive the CIP.
2. Attach an electrostatic discharge (ESD) strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
3. On the console or other management device connected to each Routing Engine, enter CLI operational mode and issue the following command to shut down the router software. For more information, see the *JUNOS Protocols, Class of Service, System Basics Command Reference*.

user@host> **request system halt**

Do not continue until all software processes have shut down.

4. Flip both circuit breaker switches on the circuit breaker box to the **OFF (O)** position.
5. Disconnect any external devices connected to the CIP.
6. Loosen the screws on the top and bottom of the CIP faceplate.
7. Grasp the CIP and slide it out of the chassis.
8. Check the CIP connector to the router chassis midplane. Look for bent pins.
9. Place the CIP in the electrostatic bag or on the antistatic mat prepared in Step 1.



**CAUTION:** Be sure to slide the CIP straight out of the slot to avoid damaging the connecting pins on the front of the midplane.

10. Carefully insert the CIP into the left side of the FPC card cage, following the guides on the top and bottom of the card cage.



**NOTE:** The components on the CIP are on the left side of the board, unlike the components of an FPC, which are on the right side. Verify that the components are on the left before inserting the CIP.

11. Slide the CIP into the chassis until it contacts the midplane.



**CAUTION:** Be sure to slide the CIP straight into the slot to avoid damaging the connecting pins on the front of the midplane.

12. Tighten the screws on the top and bottom of the CIP faceplate.
13. Reattach any external devices connected to the CIP.
14. Power on the router. See the instructions in the M40e or M160 router hardware guide.
15. To verify that the CIP is installed correctly, plug an Ethernet cable into the CIP port labeled **ETHERNET** for the appropriate host module.

When the host module is operational, one of the activity indicator LEDs on the Ethernet port (either the amber 10-Mbps LED or the green 100-Mbps LED) will flash to indicate activity. If you can issue CLI commands over the connection, the CIP is installed correctly.

## Getting CIP Hardware Information

---

**Steps To Take** To get the CIP hardware information, follow these steps:

1. Display CIP Hardware Information on page 388
2. Locating the CIP Serial Number ID Label on page 389

### Step 1: Display CIP Hardware Information

**Action** To display the CIP hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item           Version  Part number  Serial number  Description
Chassis
[...Output truncated...]
CIP             REV 02   710-001593   AA9564
[...Output truncated...]
```

**What It Means** The command output displays the CIP slot number, revision level, part number, and serial number.

## Step 2: Locating the CIP Serial Number ID Label

**Action** To locate the CIP serial number ID label, look on the top of the left side of the CIP (see Figure 159).

**Figure 159: CIP Serial Number ID Label**



## Replacing the CIP

The CIP is field-replaceable, but is not hot-removable, hot-insertable, or hot-pluggable. You must power down the router before removing or installing it.

**Action** To replace a the CIP, see “Return the Failed Component” on page 86, or the procedure to return a field-replaceable unit in the M40e or M160 router hardware guide.



## Part 6

# Monitoring M40 Internet Router-Specific Components

- Monitoring the SCB on page 393



## Chapter 30

# Monitoring the SCB

You monitor and maintain the M40 router System Control Board (SCB), the control board for the Packet Forwarding Engine, to ensure that it provides route lookups, system component monitoring, exception and control packet transfer, and Flexible PIC Concentrator (FPC) operation and reset control. (See Table 92.)

**Table 92: Checklist for Monitoring the SCB**


Monitor SCB Tasks	Command or Action
<b>Understanding the SCB on page 394</b>	
<b>Monitoring the SCB Status on page 395</b>	
1. Display the SCB Environmental Status on page 396	show chassis environment
2. Display the SCB Detailed Status on page 396	show chassis scb
3. Check the SCB LED Status on page 397	Check the LEDs on the SCB faceplate.
<b>Checking for SCB Alarms on page 398</b>	
1. Display SCB Error Messages in the System Log File on page 398	show log messages
2. Display SCB Error Messages in the Chassis Daemon Log File on page 399	show log chassisd
<b>Verifying SCB Failure on page 400</b>	
1. Check the SCB Connection on page 400	Ensure that the SCB is securely seated. Tighten the captive screws at the top and bottom of the SCB card carrier.
2. Perform an SCB Swap Test on page 400	Remove the failed SCB and replace it with one that you know works.
<b>Getting SCB Hardware Information on page 401</b>	
1. Display the SCB Hardware Information on page 401	show chassis hardware
2. Locate the SCB Serial Number ID Label on page 402	Look on the front of the SCB board near the faceplate.
3. Display the SCB Firmware Version on page 402	show chassis firmware
<b>Returning the SCB on page 402</b>	See “Return the Failed Component” on page 86, or follow the return procedure in the <i>M40 Internet Router Hardware Guide</i> .

## Understanding the SCB

**Purpose** Inspect the SCB, the control board for the Packet Forwarding Engine, to ensure that it provides route lookups, system component monitoring, exception and control packet transfer, and FPC operation and reset control.

**What Is the SCB** The SCB is the control board for the M40 router Packet Forwarding Engine (see Figure 160).

**Figure 160: SCB Component**




The SCB performs four major functions:

- **Route lookups**—The Internet Processor application-specific integrated circuit (ASIC) on the SCB performs route lookups using the forwarding table stored in synchronous SRAM (SSRAM). After performing the lookup, the Internet Processor informs the backplane of the forwarding decision, and the backplane forwards the decision to the appropriate outgoing interface.
- **System component monitoring**—The SCB monitors other system components for failure and alarm conditions. It collects statistics from all sensors in the system and relays them to the Routing Engine, which sets the appropriate alarm.
- **Exception and control packet transfer**—The Internet Processor ASIC on the SCB passes exception packets to a microprocessor on the SCB, which processes almost all of them. The remaining packets are sent to the Routing Engine for further processing. Any errors originating in the Packet Forwarding Engine and detected by the SCB are sent to the Routing Engine using **SYSLOG** messages.
- **FPC reset control**—The SCB monitors the operation of the FPCs. If it detects errors in an FPC, the SCB attempts to reset the FPC. After three unsuccessful resets, the SCB takes the FPC offline and informs the Routing Engine. Other FPCs are unaffected, and normal system operation continues.



The SCB occupies the center slot of the card cage, and is installed into the backplane from the front of the chassis (see Figure 161).

**Figure 161: M40 Router SCB Location**



The SCB is field-replaceable and hot-pluggable. You can remove and replace it without powering down the system; however, this causes major impact to the system. While the SCB is out of the router, route lookups, system component monitoring, exception and control packet transfer, and FPC operation and reset control cannot occur.

When you replace the SCB, it is rebooted by flash EEPROM.

## Monitoring the SCB Status

If the SCB fails, no information about chassis components is available through the JUNOS software command-line interface (CLI).

**Steps To Take** To monitor the SCB status, follow these steps:

1. Display the SCB Environmental Status on page 396
2. Display the SCB Detailed Status on page 396
3. Check the SCB LED Status on page 397

**Step 1: Display the SCB Environmental Status**

**Action** To display the SCB environment status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@host> show chassis environment
Class Item                Status      Measurement
Power Power Supply A      OK
        Power Supply B    Absent
Temp  FPC 0                OK          29 degrees C / 84 degrees F
        FPC 1              OK          25 degrees C / 77 degrees F
        FPC 5              OK          27 degrees C / 80 degrees F
        SCB                OK          26 degrees C / 78 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the SCB status and temperature. The SCB status can be OK, Failed, or Absent.

**Step 2: Display the SCB Detailed Status**

**Action** To display more detailed SCB status information, use the following CLI command:

```
user@host> show chassis scb
```

**Sample Output**

```
user@host> show chassis scb
SCB status:
  Temperature                27 degrees C / 80 degrees F
  CPU utilization             2 percent
  Interrupt utilization       0 percent
  Heap utilization            16 percent
  Buffer utilization           44 percent
  Total CPU DRAM              64 Mbytes
  Internet Processor II       Version 1, Foundry IBM, Part number 9
  Start time:                 2001-12-07 08:59:04 PST
  Uptime:                     4 hours, 40 minutes, 28 seconds
```

**What It Means** The command output displays the temperature of the air passing by the SCB, in degrees Centigrade and Fahrenheit. It displays the total percentage of CPU being used by the SCB processor and the percentage being used for interrupts, the percentage of heap space and buffer space being used by the SCB processor, the total DRAM available to the SCB processor, the time when the SCB started running, and how long the SCB has been running. The Internet Processor version and part number are also displayed.

### Step 3: Check the SCB LED Status

**Action** To check the SCB status, look at the LEDs on the SCB faceplate (see Figure 162).

**Figure 162: SCB LEDs**




Table 93 describes the SCB LED states.

**Table 93: SCB LEDs**

Color	Label	State	Description
Green	ACTIVE	Flashing (pulsed with out-time proportional to traffic)	I/O interrupts are occurring.
Green	RUN	Blinking (slow and steady)	SCB processor is running. Normally, the blinking is faint and becomes bright only when the SCB is processing many exceptions.
Amber	STAT1	Flashing	Internal diagnostics are running.
Amber	STAT2	Flashing	Internal diagnostics are running.

If all four SCB LEDs are on, but dimly lit, the SCB is probably not seated properly. Tighten the captive screws at the top and bottom of the SCB card carrier.

If the green RUN LED on the SCB is not blinking, the SCB processor is not functioning normally. The SCB might not be connected properly to the backplane. Tighten the screws at the top and bottom of the SCB card carrier. If that does not work, reinstall the SCB.

The SCB has a reset switch on its faceplate above the LEDs. You normally do not use the reset switch. Pushing the reset switch results in a cold restart of the Packet Forwarding Engine, which causes a service interruption for a minute or two. To trip the reset switch, you must access it through a hole in the faceplate with a paper clip or other small probe.

## Checking for SCB Alarms

---

**Steps To Take** To check for SCB alarms, follow these steps:

1. Display SCB Error Messages in the System Log File on page 398
2. Display SCB Error Messages in the Chassis Daemon Log File on page 399

### Step 1: Display SCB Error Messages in the System Log File

An SCB failure can cause the fpx0 interface, the Ethernet connection to a management LAN, to go up and down.

**Action** To display SCB error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Nov 19 04:35:29 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:29 host rpd[355]: task_connect: task BGP_209.192.168.0.21+179 addr
192.168.0.21+179: No route to host
Nov 19 04:35:29 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:29 host rpd[355]: bgp_connect_start: connect 192.168.0.21 (Internal
AS 209): No route to host
Nov 19 04:35:29 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:29 host last message repeated 9 times
Nov 19 04:35:29 host tnp.bootpd[369]: BOOTPD_BOOTSTRING: boot 1 scb.jbf
Nov 19 04:35:29 host tnp.tftpd[389]: TFTPD_INFO: tftp read from addr 2 po
rt 1024 file scb.jbf
Nov 19 04:35:31 host tnp.tftpd[389]: TFTPD_INFO: sent 1348 blocks of 1024 and 1
block of 780 for file /usr/share/pfe/scb.jbf
Nov 19 04:35:32 host mgd[387]: UI_CMDLINE_READ_LINE: user 'user', command 'show
chassis scb '
Nov 19 04:35:34 host /kernel: fpx1: link media DOWN 10Mb / half-duplex
Nov 19 04:35:34 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:34 host rpd[355]: EVENT <UpDown> fpx1.0 index 1 <Broadcast
Multicast> address #0 0.80.82.18.14.83
Nov 19 04:35:34 host mib2d[354]: SNMP_TRAP_LINK_DOWN: ifIndex 2, ifAdminStatus
up(1), ifOperStatus down(2), ifName fpx1
Nov 19 04:35:34 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:34 host last message repeated 4 times
Nov 19 04:35:35 host /kernel: fpx1: media DOWN 100Mb / half-duplex
Nov 19 04:35:36 host /kernel: fpx1: link UP 100Mb / half-duplex
Nov 19 04:35:36 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:36 host rpd[355]: EVENT <UpDown> fpx1.0 index 1 <Up Broadcast
Multicast> address #0 0.80.82.18.14.83
Nov 19 04:35:36 host mib2d[354]: SNMP_TRAP_LINK_UP: ifIndex 2, ifAdminStatus
up(1), ifOperStatus up(1), ifName fpx1
Nov 19 04:35:36 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:36 host last message repeated 4 times
Nov 19 04:35:37 host /kernel: fpx1: link media DOWN 10Mb / half-duplex
Nov 19 04:35:37 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
```

```

sendto: No route to host
Nov 19 04:35:37 host rpd[355]: EVENT <UpDown> fxp1.0 index 1 <Broadcast
multicast> address #0 0.80.82.18.14.83
Nov 19 04:35:37 host mib2d[354]: SNMP_TRAP_LINK_DOWN: ifIndex 2, ifAdminStatus
up(1), ifOperStatus down(2), ifName fxp1
Nov 19 04:35:37 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host
Nov 19 04:35:37 host last message repeated 4 times
Nov 19 04:35:38 host /kernel: fxp1: media DOWN 100Mb / full-duplex
Nov 19 04:35:38 host /kernel: fxp1: link UP 100Mb / full-duplex
Nov 19 04:35:38 host snmpd[353]: SNMPD_SEND_FAILURE: trap_io_send_trap_now:
sendto: No route to host

```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. When the SCB fails, the **fxp1** interface keeps going up and down. You can use the **show log messages | match scb** command to see error messages that are generated when an SCB fails or is offline. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 2: Display SCB Error Messages in the Chassis Daemon Log File

**Action** To display SCB error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```

user@host> show log chassisd
Nov 19 04:09:02 closing alarmd connection.
Nov 19 04:09:02 closing craftd connection.
Nov 19 04:09:02 rcv: chassisd_ipc_dispatch() null ipc_pipe_read, closing connect
ion
Nov 19 04:09:02 alarmd connection completed
Nov 19 04:09:02 craftd connection completed
Nov 19 04:09:30 rcv reply: SCB Restart
Nov 19 04:09:30 send: scb config cmd
Nov 19 04:09:30 send: display hostname <ewr-edge-03>, uptime 16182073 seconds
Nov 19 04:09:30 send: password = nnection.
Nov 19 04:09:30 send: display unlockction.
Nov 19 04:09:30 send: clear all chassis class alarmsc_pipe_read, closing connect
Nov 19 04:09:30 send: set boolean type 0 slot 0 which 1 off
Nov 19 04:09:30 rcv reply: Backplane MAC addrs recieved
Nov 19 04:09:30 rcv reply: Backplane SRAM size 8388608 banks[ 1 1 1 1 ]
Nov 19 04:09:30 jtree init (2097152 4)
Nov 19 04:09:35 repead pid 15567, status 0
Nov 19 04:09:41 rcv reply: chassis info
Nov 19 04:09:49 CHASSISD_EVENT: slot 0 restart
Nov 19 04:09:50 pic online req, pic 0 type 515, fpc 0
Nov 19 04:09:50 send: fpc 0 pic 0 online ack
Nov 19 04:09:51 CHASSISD_EVENT: slot 0 attach
Nov 19 04:09:51 rcv reply: PIC attach fpc 0 pic 0 type 515 version 260
Nov 19 04:09:52 CHASSISD_EVENT: slot 1 restart
Nov 19 04:09:53 pic online req, pic 0 type 515, fpc 1
Nov 19 04:09:53 send: fpc 1 pic 0 online ack
Nov 19 04:09:54 CHASSISD_EVENT: slot 2 restart
Nov 19 04:09:55 pic online req, pic 0 type 518, fpc 2
Nov 19 04:09:55 send: fpc 2 pic 0 online ack
Nov 19 04:09:55 pic online req, pic 1 type 518, fpc 2

```

```

Nov 19 04:09:55 send: fpc 2 pic 1 online ack
Nov 19 04:09:55 pic online req, pic 2 type 518, fpc 2 515 version 260
Nov 19 04:09:55 send: fpc 2 pic 2 online ackrt
Nov 19 04:09:57 CHASSISD_EVENT: slot 3 restart, fpc 1
Nov 19 04:09:58 CHASSISD_EVENT: slot 4 restart
Nov 19 04:09:58 CHASSISD_EVENT: slot 1 attach
Nov 19 04:09:59 pic online req, pic 0 type 518, fpc 4

```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. You can search for multiple items in the chassisd log file by using the `| match "item | item | item"` command. For example, `| match "scb | kernel | tnp"` is a search for error messages for the SCB, kernel, and Trivial Networking Protocol (TNP), and indicates communication issues between the Routing Engine and the Packet Forwarding Engine components.

## Verifying SCB Failure

---

**Steps To Take** To verify SCB failure, follow these steps:

1. Check the SCB Connection on page 400
2. Perform an SCB Swap Test on page 400

### Step 1: Check the SCB Connection

If the SCB is not seated properly, it will not function.

**Action** To check the SCB connection, make sure that the SCB is properly seated in the slot. Tighten the captive screws at the top and bottom of the SCB card carrier.

### Step 2: Perform an SCB Swap Test



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the SCB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an SCB, follow these steps:

1. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Unscrew the thumbscrews at the top and bottom of the card carrier.
3. Flip the ends of the two extractor clips, which are adjacent to the thumbscrews, away from each other to unseat the SCB from the backplane.
4. Grasp both sides of the card carrier and slide the SCB about three-quarters of the way out of the router.
5. Move one of your hands underneath the SCB to support it, and slide it completely out of the chassis.

6. Replace the SCB with one that you know works.
7. Grasp the front of the SCB card carrier with both hands and align the back of the working SCB card carrier with the slide guides on the chassis.
8. Slide the SCB card carrier all the way into the card cage until it contacts the backplane.
9. Flip the extractor clips, located on the top and bottom of the card carrier, towards each other to lodge the SCB in place.
10. Tighten the thumbscrews on the card carrier to seat the SCB.



**NOTE:** To seat the SCB properly, be sure to tighten the screws securely. If the SCB is not seated properly, it will not function.

## Getting SCB Hardware Information

**Steps To Take** To obtain SCB hardware information, follow these steps:

1. Display the SCB Hardware Information on page 401
2. Locate the SCB Serial Number ID Label on page 402
3. Display the SCB Firmware Version on page 402

### Step 1: Display the SCB Hardware Information

**Action** To display the SCB hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item           Version  Part number  Serial number  Description
Chassis                REV 10    710-000073   AA2220         M40
Backplane              REV A1    740-000234   000134         AC
Power Supply A         REV 07    710-000229   AA6957
Maxicab                REV 03    710-000482   AA3324
Minicab                REV 07    710-000150   AA7798
Display               REV 11    710-000075   AA7244         RE-1.0
Routing Engine
SCB                    REV 11    710-000075   AA7244         Internet Processor I
[...Output truncated...]
```

**What It Means** The command output displays the SCB version level, part number, serial number, and description.

## Step 2: Locate the SCB Serial Number ID Label

**Action** To locate the SCB serial number ID label, look on the SCB board toward the front panel.

**Figure 163: SSB Serial Number ID Label**



## Step 3: Display the SCB Firmware Version

**Action** To display the version of firmware running on the SCB, use the following CLI command:

```
user@host> show chassis firmware
```

**Sample Output**

```
user@host> show chassis firmware
Part                Type      Version
[...Output truncated...]
SCB 0               ROM       Juniper ROM Monitor Version 3.0b1
                   O/S       Version 5.5-20020613-cqPqI7 by builder on 2
```

**What It Means** The command output displays the type and version level of the firmware running on the SCB.

## Returning the SCB

The SCB is field-replaceable and hot-pluggable. You can remove and replace it without powering down the system; however this causes major impact to the system. While the SCB is out of the router, route lookups, system component monitoring, exception and control packet transfer, and FPC operation monitoring cannot occur.

**Action** To return the SCB, see “Return the Failed Component” on page 86, or the return procedure in the *M40 Internet Router Hardware Guide*.



## Part 7

# Monitoring M20 Internet Router-Specific Components

- Monitoring the SSB on page 405



## Chapter 31

# Monitoring the SSB

You monitor the M20 router System and Switch Board (SSB) to ensure that it provides allocation of incoming data packets throughout shared memory on the Flexible PIC Concentrators (FPCs), transfers outgoing data cells to the FPCs for packet reassembly, performs route lookups using the forwarding table, monitors system components for failure and alarm conditions, and monitors FPC operation and reset. (See Table 94.)

**Table 94: Checklist for Monitoring the SSB**

Monitor SSB Tasks	Command or Action
<b>Understanding the SSB on page 406</b>	
<b>Monitoring the SSB Status on page 408</b>	
1. Display the SSB Environmental Status on page 408	show chassis environment
2. Display the SSB Detailed Status on page 409	show chassis ssb
3. Check the SSB LEDs on page 409	Check the LEDs on the SCB faceplate.
<b>Checking for SSB Alarms on page 410</b>	
1. Display SSB Error Messages in the System Log File on page 410	show log messages
2. Display SSB Error Messages in the Chassis Daemon Log File on page 411	show log chassisd   match ssb
<b>Verifying SSB Failure on page 411</b>	
1. Check the SSB Connection on page 411	Check the thumbscrews on the left and right sides of the SSB.
2. Perform a Swap Test on the SSB on page 412	1. Take the SSB offline. 2. Remove the SSB. 3. Replace the SSB with one that you know works.
<b>Getting SSB Hardware Information on page 413</b>	
1. Display the SSB Hardware Information on page 413	show chassis hardware
2. Locate the SSB Serial Number ID Label on page 413	Look for the SSB serial number label located on the top of the SSB adjacent to the SDRAM memory bank.
3. Display the SSB Firmware Version on page 414	show chassis firmware
<b>Replacing the SSB on page 414</b>	See “Return the Failed Component” on page 86, or follow the procedure in the <i>M20 Internet Router Hardware Guide</i> .


## Understanding the SSB

---

**Purpose** Inspect the SSB to ensure that it provides allocation of incoming data packets throughout shared memory on the FPCs, transfers outgoing data cells to the FPCs for packet reassembly, performs route lookups using the forwarding table, monitors system components for failure and alarm conditions, and monitors FPC operation and reset.

**What Is the SSB** The SSB is a component of the Packet Forwarding Engine and performs the following major functions (see Figure 164 on page 407):

- Shared memory management on the FPCs—The Distributed Buffer Manager application-specific integrated circuit (ASIC) on the SSB uniformly allocates incoming data packets throughout shared memory on the FPCs.
- Outgoing data cell transfer to the FPCs—A second Distributed Buffer Manager ASIC on the SSB passes data cells to the FPCs for packet reassembly when the data is ready to be transmitted.
- Route lookups—The Internet Processor ASIC on the SSB performs route lookups using the forwarding table stored in synchronous SRAM (SSRAM). After performing the lookup, the Internet Processor ASIC informs the midplane of the forwarding decision, and the midplane forwards the decision to the appropriate outgoing interface.
- System component monitoring—The SSB monitors other system components for failure and alarm conditions. It collects statistics from all sensors in the system and relays them to the Routing Engine, which sets the appropriate alarm. For example, if a temperature sensor exceeds the first internally defined threshold, the Routing Engine issues a “high temp” alarm. If the sensor exceeds the second threshold, the Routing Engine initiates a system shutdown.
- Exception and control packet transfer—The Internet Processor ASIC passes exception packets to a microprocessor on the SSB, which processes almost all of them. The remaining packets are sent to the Routing Engine for further processing. Any errors originating in the Packet Forwarding Engine and detected by the SSB are sent to the Routing Engine using system log messages.
- FPC reset control—The SSB monitors the operation of the FPCs. If it detects errors in an FPC, the SSB attempts to reset the FPC. After three unsuccessful resets, the SSB takes the FPC offline and informs the Routing Engine. Other FPCs are unaffected, and normal system operation continues.


**Figure 164: SSB Component**

1151

You can install two SSBs in the M20 router. The SSBs occupy the two top slots of the card cage (SSB0 and SSB1), and are installed into the midplane from the front of the chassis. (See Figure 165.)

**Figure 165: M20 Router SSB Location**

M20 Router  
front



1785

The SSB houses the Internet Processor ASIC and two Distributed Buffer Manager ASICs.

The SSB is hot-pluggable. You can remove and replace it without powering down the system; however, this causes major impact to the system. While the SSB is out of the router, route lookups, system component monitoring, exception and control packet transfer, and FPC resets cannot occur.

When the SSB is removed, all packet forwarding stops immediately and the Routing Engine responds by generating alarms. When the SSB is replaced, it is rebooted by flash EEPROM.

If you have removed the Routing Engine, the SSB enters a warm shutdown mode and continues its forwarding process for a limited time using a frozen forwarding table. The time limit is determined by a timer in the SSB. If you replace the Routing Engine during the warm shutdown period, the SSB unfreezes its forwarding tables and resumes normal functioning. Otherwise, the SSB shuts down.

## Monitoring the SSB Status

If the SSB fails, no information about the chassis components is available through the JUNOS software command-line interface (CLI).

**Steps To Take** To monitor the SSB, follow these steps:

1. Display the SSB Environmental Status on page 408
2. Display the SSB Detailed Status on page 409
3. Check the SSB LEDs on page 409

### Step 1: Display the SSB Environmental Status

**Action** To display the SSB environmental status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@host> show chassis environment
Class Item                Status    Measurement
Power Power Supply A      Failed
Power Power Supply B      OK
Temp  FPC Slot 0              OK        27 degrees C / 80 degrees F
      FPC Slot 1          OK        30 degrees C / 86 degrees F
      FPC Slot 2          OK        26 degrees C / 78 degrees F
      FPC Slot 3          OK        25 degrees C / 77 degrees F
      Power Supply A      OK        28 degrees C / 82 degrees F
      Power Supply B      OK        24 degrees C / 75 degrees F
      SSB Slot 0          OK        25 degrees C / 77 degrees F
      Backplane           OK        21 degrees C / 69 degrees F
Fans  Rear Fan             OK        Spinning at normal speed
      Upper Fan           OK        Spinning at normal speed
      Middle Fan          OK        Spinning at normal speed
      Bottom Fan          OK        Spinning at normal speed
Misc  Craft Interface       OK
```

**What It Means** The command output displays the SSB status and temperature. The SSB status can be OK, Failed, or Absent.

## Step 2: Display the SSB Detailed Status

**Action** To display more detailed SSB status information, use the following CLI command:

```
user@host> show chassis ssb
```

**Sample Output**

```
user@host> show chassis ssb
SSB status:
  Failover:                0 time
  Slot 0:
    State:                  Master
    Temperature:            33 Centigrade
    CPU utilization:        0 percent
    Interrupt utilization:   0 percent
    Heap utilization:       0 percent
    Buffer utilization:      6 percent
    DRAM:                   64 Mbytes
    Start time:             1999-01-15 22:05:36 UTC
    Uptime:                 21 hours, 21 minutes, 22 seconds
  Slot 1:
    State:                  Backup
```

**What It Means** The command output displays the number of times the mastership has changed, the SSB slot number 0 or 1, and the current state of the SSB: **Master**, **Backup**, or **Empty**. The command output displays the temperature of the air passing by the SSB, in degrees Centigrade. It also displays the total percentage of CPU, interrupt, heap space, and buffer space being used by the SSB processor, including the total DRAM available to the SSB processor. The command output displays the time when the SSB started running and how long the SSB has been running.

**Alternative Action** To display the status for a particular SSB, use the following CLI command:


```
user@host> show chassis ssb slot
```

## Step 3: Check the SSB LEDs

Periodically check the SSB LEDs to verify that the SSB is online or offline and the type of task it is performing.

**Action** To check the SSB LEDs, look on the faceplate at the front of the router (see Figure 166).

**Figure 166: SSB LEDs**



The SSB has two groups of LEDs: online/offline LEDs and status LEDs. The online/offline LEDs indicate whether the SSB is online or offline. The status LEDs indicate what type of task the SSB is performing. Table 95 describes the LED states.

**Table 95: SSB LEDs**

Label	Color	State	Description
OFFLINE	Amber	On steadily	SSB is offline.
ONLINE	Green	On steadily	SSB processor is running.
MASTER	Blue	On steadily	SSB is master.
STATUS (left)	Green	Blinking	SSB processor is running. Normally, the blinking is faint and becomes bright only when the SSB is processing many exceptions.
STATUS (right)	Green	Flashing	I/O interrupts are occurring.

## Checking for SSB Alarms

**Steps To Take** To check for SSB alarms, follow these steps

1. Display SSB Error Messages in the System Log File on page 410
2. Display SSB Error Messages in the Chassis Daemon Log File on page 411

### Step 1: Display SSB Error Messages in the System Log File

Periodically check the **SYSLOG** messages on the management console for messages sent by the SSB. During normal operation, the SSB notifies the Routing Engine of any errors it detects.

**Action** To display the SSB error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Jul 10 13:28:45 myrouter /kernel: fxp1: media DOWN 100Mb / full-duplex
Jul 10 13:28:45 myrouter /kernel: fxp1: media DOWN 10Mb / half-duplex
Jul 10 13:28:45 myrouter /kernel: fxp1: media DOWN 100Mb / full-duplex
Jul 10 13:28:45 myrouter /kernel: fxp1: link UP 100Mb / full-duplex
Jul 10 13:28:45 myrouter rpd[564]: EVENT <UpDown> fxp1.0 index 1 <Up Broadcast
Multicast> address #0 0.a0.a5.12.1d.6d
Jul 10 13:28:45 myrouter mib2d[563]: SNMP_TRAP_LINK_UP: ifIndex 2, ifAdminStatus
up(1), ifOperStatus up(1), ifName fxp1
[...Output truncated...]
```



**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match ssb` command to see error messages that are generated when an SSB fails or is offline. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what the error messages are and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 2: Display SSB Error Messages in the Chassis Daemon Log File

**Action** To display the SSB error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd | match ssb
```

**Sample Output**

```
user@host> show log chassisd |match ssb
Jul 10 13:27:28 SSB0 is now not present
Jul 10 13:27:28 Assert reset on SSB0
Jul 10 13:27:28 Turn on ethernet loop
[...Output truncated...]
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. You can search for multiple items in the chassisd log file by using the `| match "item | item | item"` command. For example, `| match "ssb | kernel | tnp"` is a search for error messages for the SSB, kernel, and Trivial Networking Protocol (TNP), and indicates communication issues between the Routing Engine and the Packet Forwarding Engine components.

## Verifying SSB Failure

---

**Steps To Take** To verify SSB failure, follow these steps:

1. Check the SSB Connection on page 411
2. Perform a Swap Test on the SSB on page 412

### Step 1: Check the SSB Connection

If the SSB is not seated properly, it will not function.

**Action** To check the SSB connection, make sure that the SSB is properly seated in the slot. To seat the SSB properly, securely tighten the screws on the left and right sides of the card carrier.

## Step 2: Perform a Swap Test on the SSB



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the SSB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an SSB, follow these steps:

1. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Locate the SSB offline switch on the front panel and press and hold the switch for 5 seconds to take the SSB offline.



**CAUTION:** If you take the SSB offline, packet forwarding will be affected.

3. Unscrew the thumbscrews on the left and right sides of the card carrier to unseat the SSB from the midplane.
4. Flip the ends of the two extractor clips, which are adjacent to the thumbscrews, towards the outside edges of the router.
5. Grasp both sides of the card carrier and slide the SSB about three-quarters of the way out of the router.
6. Move one of your hands underneath the SSB to support it, and slide it completely out of the chassis.
7. Replace the SSB with one that you know works.
8. Grasp the front of the SSB card carrier with both hands and align the back of the card carrier with the slide guides on the chassis.
9. Slide the SSB card carrier all the way into the card cage until it contacts the midplane.
10. Flip the extractor clips, located on the left and right sides of the card carrier, towards each other to secure the SSB in place.
11. Tighten the thumbscrews on the left and right sides of the card carrier to seat the SSB.



**NOTE:** To seat the SSB properly, be sure to tighten the screws securely. If the SSB is not seated properly, it will not function.

## Getting SSB Hardware Information

- Steps To Take**
1. Display the SSB Hardware Information on page 413
  2. Locate the SSB Serial Number ID Label on page 413
  3. Display the SSB Firmware Version on page 414

### Step 1: Display the SSB Hardware Information

**Action** To display the SSB hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
[...Output truncated...]
SSB slot 0    REV 01   710-001951   AD5904         Internet Processor II
SSB slot 1    N/A      N/A          N/A            backup
[...Output truncated...]
```

**What It Means** The command output displays the SSB version level, part number, serial number, and description.

### Step 2: Locate the SSB Serial Number ID Label

**Action** To locate the SSB serial number ID label, look on the top of the SSB adjacent to the SDRAM memory bank.

**Figure 167: SSB Serial Number ID Label**



### Step 3: Display the SSB Firmware Version

**Action** To display the version of firmware running on the SSB, use the following CLI command:

```
user@host> show chassis firmware
```

**Sample Output**

```
user@host> show chassis firmware
Part                               Type      Version
[...Output truncated...]
SSB 0                             ROM       Juniper ROM Monitor Version 4.2b1
                                   O/S      Version 5.4I20020626_0216_mtiwari by mtiwar
SSB 1
```

**What It Means** The command output displays the type and version level of the firmware running on the SSB.

## Replacing the SSB

---

The SSB is hot-pluggable. When the SSB is removed, all packet forwarding stops immediately and the Routing Engine responds by sending alarms through the Ethernet channel to the management console. When the SSB is replaced, it is rebooted by flash EEPROM.

**Action** If the SSB fails, replace it as described in the *M20 Internet Router Hardware Guide*.

## Part 8

# Monitoring M7i and M10i Router-Specific Components

- Monitoring the CFEs on page 417
- Monitoring the HCM on page 431
- Monitoring the FIC on page 443



## Chapter 32

# Monitoring the CFEBs

You monitor the Compact Forwarding Engine Board (CFEB), which provides route lookup, filtering, and switching on incoming data packets, then directs outbound packets to the appropriate interface for transmission to the network. (See Table 96.)

The M7i router CFEB can process 8 million packets per second (Mpps); the M10i router CFEB can process 16 Mpps.

The CFEB communicates with the Routing Engine using a dedicated 100-Mbps Fast Ethernet link that transfers routing table data from the Routing Engine to the forwarding table in the integrated ASIC. The link is also used to transfer from the CFEB to the Routing Engine routing link-state updates and other packets destined for the router that have been received through the router interfaces.

**Table 96: Checklist for Monitoring the CFEB**

Monitor CFEB Tasks	Command or Action
<b>Understanding the CFEB on page 419</b>	
■ M7i Router CFEB on page 419	
■ M7i Router CFEB with ASP-I on page 420	
■ M10i Router CFEB Component on page 421	
■ M7i and M10i Router CFEB Location on page 421	
<b>Monitoring the CFEB Status on page 421</b>	
1. Display the CFEB Environmental Status on page 422	show chassis environment
2. Display the CFEB Detailed Status on page 422	show chassis cfeb
3. Check CFEB LEDs on page 423	Look at the LEDs on the CFEB faceplate located on the rear of the router above the power supplies.
<b>Checking for CFEB Alarms on page 423</b>	
1. Display CFEB Alarms on page 423	show chassis alarms (M7i router) Look at the alarm LEDs on the right side of the Fixed Interface Card (FIC). (M10i router) Look at the alarm LEDs on the right side of the High-Availability Chassis Manager (HCM). For a listing of the conditions that trigger CFEB alarms, see “M7i or M10i Router Chassis Component Alarm Conditions” on page 65.
2. Check the CFEB LEDs on page 424	Look at the three LEDs located on the component faceplate. The CFEB is located on the rear of the router above the power supplies.

Monitor CFEB Tasks	Command or Action
3. Display CFEB Error Messages in the System Log File on page 424	<code>show log messages   match cfeb</code>
4. Display CFEB Error Messages in the Chassis Daemon Log File on page 425	<code>show log chassisd   match cfeb</code>
<b>Verifying CFEB Failure on page 426</b>	
1. Check the CFEB Uptime on page 426	<code>show chassis cfeb</code>
2. Check the System Uptime on page 427	<code>show system uptime</code>
3. Check the CFEB Connection on page 427	Check that the thumbscrews on each CFEB ejector lever are securely tightened.
4. Perform a Swap Test on the CFEB on page 427	<ul style="list-style-type: none"> <li>■ Before performing a swap test, always check for bent pins in the midplane and check the CFEB for stuck pins in the connector.</li> <li>■ Power down the CFEB before removing it by pressing and holding down the offline button on the faceplate until the amber LED labeled <b>FAIL</b> lights, or by using the <code>request chassis cfeb offline</code> CLI command.</li> <li>■ Power up the CFEB after installing it by pressing and holding down the offline button on the CFEB faceplate until the green LED labeled <b>Output OK</b> lights steadily, or by using the <code>request chassis cfeb online</code> CLI command.</li> <li>■ Follow the procedure in the appropriate router hardware guide for replacing and installing a CFEB.</li> </ul>
<b>Getting CFEB Hardware Information on page 429</b>	
1. Display the CFEB Hardware Information on page 429	<code>show chassis hardware</code>
2. Display the CFEB Firmware Information on page 430	<code>show chassis firmware</code>
3. Locate the CFEB Serial Number ID Label on page 430	Look on the right side of the CFEB top panel.
<b>Returning the CFEB on page 430</b>	See “Return the Failed Component” on page 86 or follow the procedure in the appropriate router hardware guide.



## Understanding the CFEB

**Purpose** Monitor the CFEB so that it can provide route lookup, filtering, and switching on incoming data packets and direct outbound packets to the appropriate interface for transmission to the network.

**What Is an CFEB** The CFEB processes 16 Mpps. The CFEB performs the following functions:

- Route lookups—Performs route lookups using the forwarding table stored in synchronous SRAM (SSRAM).
- Management of shared memory —Uniformly allocates incoming data packets throughout the router's shared memory.
- Transfer of outgoing data packets—Passes data packets to the destination FIC or Physical Interface Card (PIC) when the data is ready to be transmitted.
- Transfer of exception and control packets—Passes exception packets to the microprocessor on the CFEB, which processes almost all of them. The remainder are sent to the Routing Engine for further processing. Any errors originating in the Packet Forwarding Engine and detected by the CFEB are sent to the Routing Engine using system log messages.
- (M7i router only) Built-in tunnel interface—Encapsulates arbitrary packets inside a transport protocol, providing a private, secure path through an otherwise public network.

The built-in tunnel interface on the CFEB is configured the same way as a PIC. For information about configuring the built-in tunnel interface, see the *JUNOS Services Interfaces Configuration Guide*.

- (M7i router only) Optional Adaptive Services PIC—Integrated (ASP-I)—Provides one or more services on one PIC. See “Adaptive Services PIC—Integrated (ASP-I)” on page 11 for more information.

Figure 168 shows the M7i router CFEB component.

**Figure 168: M7i Router CFEB**





Figure 169 shows the M7i router CFEB with ASP-I.

**Figure 169: M7i Router CFEB with ASP-I**




The ASP-I is an optional component of the CFEB. The ASP-I is similar to the standalone Adaptive Services PIC, but operates at a reduced bandwidth. The ASP-I enables you to perform one or more services on the same PIC by configuring a set of services and applications.

The ASP-I provides the following services:


- Stateful firewall—A type of firewall filter that considers state information derived from previous communications and other applications when evaluating traffic.
- Network Address Translation (NAT)—A security procedure for concealing host addresses on a private network behind a pool of public addresses.
- Intrusion detection services (IDS)—A set of tools for detecting, redirecting, and preventing certain kinds of network attack and intrusion.

The configuration for these three services comprises a series of rules that you can arrange in order of precedence as a rule set. Each rule follows the structure of a firewall filter, with a **from** statement containing input or match conditions and a **then** statement containing actions to be taken if the match conditions are met. For information about configuring interfaces on the ASP-I, see the *JUNOS Services Interfaces Configuration Guide*.

Figure 170 shows the M10i router CFEB component.

**Figure 170: M10i Router CFEB Component**

You can install one CFEB in the M7i router from the rear of the router above the power supplies. You can install one or two CFEBs from the rear of the M10i router chassis above the fan tray (see Figure 171).

**Figure 171: M7i and M10i Router CFEB Location**

## Monitoring the CFEB Status

**Steps To Take** To monitor the CFEB status, follow these steps:

1. Display the CFEB Environmental Status on page 422
2. Display the CFEB Detailed Status on page 422
3. Check CFEB LEDs on page 423

## Step 1: Display the CFEB Environmental Status

**Action** To display the CFEB environmental status, use the following command-line interface (CLI) command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@m5-host> show chassis environment
Class Item                Status      Measurement
Power Power Supply 0      OK
        Power Supply 1    Absent
Temp  Intake              OK          22 degrees C / 71 degrees F
        FPC 0             OK          23 degrees C / 73 degrees F
        Power Supplies    OK          23 degrees C / 73 degrees F
        CFEB Intake       OK          24 degrees C / 75 degrees F
        CFEB Exhaust      OK          30 degrees C / 86 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the temperature and status of the CFEB intake and exhaust, which can be OK, Failed, or Absent.

## Step 2: Display the CFEB Detailed Status

**Action** To display more detailed CFEB status, use the following CLI command:

```
user@host> show chassis cfeb
```

**Sample Output**

```
user@host> show chassis cfeb
CFEB status:
Slot 0 information:
  State                Master
  Intake temperature    29 degrees C / 84 degrees F
  Exhaust temperature   38 degrees C / 100 degrees F
  CPU utilization        3 percent
  Interrupt utilization  0 percent
  Heap utilization       10 percent
  Buffer utilization      22 percent
  Total CPU DRAM         128 MB
  Internet Processor II  Version 1, Foundry IBM, Part number 164
  Start time:           2004-09-28 03:07:54 PDT
  Uptime:                9 days, 18 hours, 36 minutes, 15 seconds
Slot 1 information:
  State                Backup
```

**What It Means** The command output displays the temperature of the air passing by the CFEB intake and exhaust, in degrees Centigrade. It displays the total percentage of CPU, interrupt, heap space, and buffer space being used by the CFEB processor, including the total DRAM available to the CFEB processor. The command output displays the time when the CFEB started running and how long the CFEB has been running. A short uptime can indicate that there is a CFEB problem.

### Step 3: Check CFEB LEDs

Three LEDs—a green LED labeled **OK**, a red LED labeled **FAIL**, and a blue LED labeled **MASTER**—indicate CFEB status.

**Action** Look at the LEDs on the CFEB faceplate. The CFEB is located on the rear of the router above the power supplies (see Figure 171 on page 421). Table 97 describes the CFEB LED states.

**Table 97: CFEB LEDs**

Label	Color	State	Description
OK	Green	On steadily	CFEB is running normally.
		Blinking	CFEB is starting up.
FAIL	Red	On steadily	CFEB is not operational or is in reset mode.
MASTER	Blue	On steadily	CFEB is functioning as master.

### Checking for CFEB Alarms

For a listing of the conditions that trigger CFEB alarms, see “M7i or M10i Router Chassis Component Alarm Conditions” on page 63.

**Steps To Take** To check for CFEB alarms, follow these steps:

1. Display CFEB Alarms on page 423
2. Check the CFEB LEDs on page 424
3. Display CFEB Error Messages in the System Log File on page 424
4. Display CFEB Error Messages in the Chassis Daemon Log File on page 425

### Step 1: Display CFEB Alarms

For conditions that trigger CFEB alarms, see “Display the Current Router Alarms” on page 61.

**Action** To display CFEB alarms, use the following CLI command:

```
user @host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1 alarms currently active
Alarm time           Class  Description
2004-10-08 00:29:02 PDT Major  CFEB not online, the box is not forwarding
```

**What It Means** The command output displays the alarm date, time, severity level, and description.

**Alternative Action** The CFEB generates a red alarm. Table 98 displays the CFEB alarms, severity, and remedies.

**Table 98: CFEB Alarms, Remedies, and Severity**

Chassis Component	Alarm Condition	Remedy	Alarm Severity
CFEB	The router has an optional internal flash drive and boots from an alternate boot device. If you configure your router to boot from the hard disk, ignore this alarm condition.	Replace the failed or missing CFEB.	Red
	Both CFEBs have been removed or have failed.	Replace the failed or missing CFEB.	Red
	Too many hard errors in CFEB memory.	Replace the failed CFEB.	Red
	A CFEB microcode download has failed.	Replace the failed CFEB.	Red

(M7i router) Look at the alarm LEDs on the right side of the FIC.

(M10i router) Look at the alarm LEDs on the right side of the HCM.

## Step 2: Check the CFEB LEDs

**Action** To check the CFEB LEDs, see “Check CFEB LEDs” on page 423.

**Table 99: CFEB LEDs**

Label	Color	State	Description
OK	Green	On steadily	CFEB is running normally.
		Blinking	CFEB is starting up.
FAIL	Red	On steadily	CFEB is not operational or is in reset mode.
MASTER	Blue	On steadily	CFEB is functioning as master.

## Step 3: Display CFEB Error Messages in the System Log File

Check for messages at least 5 minutes before and after a CFEB alarm occurs.

**Action** To check for CFEB error messages in the system log `messages` file, use the following CLI command:

```
user@host> show log messages | match cfeb
```

**Sample Output**

```
user@host> show log messages | match cfeb
Sep 14 11:00:01 clinton cfeb CM: ALARM SET: (Major) Slot 0: CFEB not online,
the box is not forwarding
Sep 14 11:00:11 clinton craftd[4896]: Major alarm cleared, CFEB not online, the
box is not forwarding
Sep 14 11:00:11 clinton alarmd[4893]: Alarm cleared: CFEB color=RED, class=
CHASSIS, reason=CFEB not online, the box is not forwarding
Sep 14 11:00:12 clinton cfeb CM: ALARM CLEAR: Slot 0: CFEB not online, the box
is not forwarding
Oct 8 00:29:02 clinton craftd[4896]: Major alarm set, CFEB not online, the
```

```

box is not forwarding
Oct 8 00:29:02 clinton chassisd[4891]: CHASSISD_SHUTDOWN_NOTICE: Shutdown
reason: CFEB connection lost
Oct 8 00:29:02 clinton alarmd[4893]: Alarm set: CFEB color=RED, class=CHASSIS,
reason=CFEB not online, the box is not forwarding

```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match cfeb` command to see error messages that are generated when a Control Board fails or is offline. Use this information to diagnose a Control Board problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

#### Step 4: Display CFEB Error Messages in the Chassis Daemon Log File

**Action** To display CFEB error messages in the chassisd log file, use the following CLI command:

```
user@host> show log chassisd | match cfeb
```

**Sample Output**

```

user@host> show log chassisd | match cfeb
Apr 28 03:25:13 Resetting CFEB 0
Apr 28 03:25:26 send: red alarm set, device CFEB 0, reason CFEB Not Online
Apr 28 03:25:26 Resetting CFEB 0
Apr 28 03:25:27 CFEB 0 added
Apr 28 03:25:27 CHASSISD_SNMP_TRAP7: SNMP trap generated: FRU insertion (jnxFruC
ontentsIndex 6, jnxFruL1Index 1, jnxFruL2Index 0, jnxFruL3Index 0, jnxFruName
CFEB, jnxFruType 4, jnxFruSlot 1)
Apr 28 03:25:46 Resetting CFEB 0
Apr 28 03:28:42 send: red alarm set, device CFEB 0, reason CFEB Not Online
Apr 28 03:28:42 Resetting CFEB 0
Apr 28 03:28:43 CFEB 0 added
Apr 28 03:28:43 CHASSISD_SNMP_TRAP7: SNMP trap generated: FRU insertion (jnxFruC
ontentsIndex 6, jnxFruL1Index 1, jnxFruL2Index 0, jnxFruL3Index 0, jnxFruName
CFEB, jnxFruType 4, jnxFruSlot 1)
Apr 28 03:29:17 rcv reply: CFEB Restart
Apr 28 03:29:17 CHASSISD_SNMP_TRAP9: SNMP trap generated: FRU power on (jnxFruCo
ntentsIndex 6, jnxFruL1Index 1, jnxFruL2Index 0, jnxFruL3Index 0, jnxFruName
CFEB, jnxFruType 4, jnxFruSlot 1, jnxFruOfflineReason 2, jnxFruLastPowerOff
5526, jnxFruLastPowerOn 5526)
Apr 28 03:29:17 sending 1 queued messages to CFEB 0
Apr 28 03:29:17 missing ctm for CFEB 0 -- timerid 0x0, timerset 0
Apr 28 03:29:17 send: CFEB config cmd
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting debugmode off
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting coredump on
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting source-route on
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting mtu-check off
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting soft-restart on
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting pfeman-reconnect off
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting l2cache on
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting no-load-balancing-clone off
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting equal-weighted-mode off
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting ipv4-key-hash-L3 on
Apr 28 03:29:17 send: set_boolean_cmd CFEB 0 setting mpls-key-hash-2label off
Apr 28 03:29:27 send: red alarm clear, device CFEB 0, reason CFEB Not Online

```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed. You can search for multiple items in the chassisd log file by using the `show log chassisd | match cfeb` command to see error messages that are generated when a Control Board fails or is offline. Use this information to diagnose a Control Board problem and to let JTAC know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Verifying CFEB Failure

**Steps To Take** To verify CFEB failure, follow these steps:

1. Check the CFEB Uptime on page 426
2. Check the System Uptime on page 427
3. Check the CFEB Connection on page 427
4. Perform a Swap Test on the CFEB on page 427

### Step 1: Check the CFEB Uptime

**Action** To check the CFEB uptime, use the following CLI command:

```
user@host> show chassis cfeb
```

**Sample Output**

```
user@host> show chassis cfeb
CFEB status:
Slot 0 information:
  State                Master
  Intake temperature    29 degrees C / 84 degrees F
  Exhaust temperature   38 degrees C / 100 degrees F
  CPU utilization        3 percent
  Interrupt utilization  0 percent
  Heap utilization       10 percent
  Buffer utilization     22 percent
  Total CPU DRAM        128 MB
  Internet Processor II  Version 1, Foundry IBM, Part number 164
  Start time:           2004-09-28 03:07:54 PDT
  Uptime:                9 days, 18 hours, 41 minutes, 32 seconds
Slot 1 information:
  State                Backup
```

**What It Means** The command output displays how long the CFEB has been operating. A short uptime can indicate a CFEB failure. Look for error messages that were generated at least 5 minutes prior to the failure event by using the following CLI command:

```
user@host> show log messages | match cfeb
```



**Step 2: Check the System Uptime**

**Action** To check the system uptime, use the following CLI command:

user@host> **show system uptime**

**Sample Output** user@host> **show system uptime**  
Current time: 2002-07-17 16:43:45 PDT  
System booted: 2002-07-12 17:29:12 PDT (4d 23:14 ago)  
Protocols started: 2002-07-12 17:29:56 PDT (4d 23:13 ago)  
Last configured: 2002-07-10 23:10:27 PDT (6d 17:33 ago) by regress  
4:43PM up 4 days, 23:15, 2 users, load averages: 0.07, 0.02, 0.00


**What It Means** The command output displays the time when the system was last booted, in days and hours. If the boot time is short, it can indicate a Routing Engine or a CFEB failure. Look for error messages that were generated at least 5 minutes prior to the failure event by using the following CLI command:

user@host> **show log messages | match cfeb**

**Step 3: Check the CFEB Connection**

**Action** Make sure the CFEB is properly seated in the midplane. Check that the thumbscrews on each CFEB ejector lever are securely tightened. Use a Phillips screwdriver to ensure that the screws are securely tightened.

**Step 4: Perform a Swap Test on the CFEB**



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the CFEB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

You must power down the CFEB before removing it by pressing and holding down the offline button on the faceplate until the amber LED labeled **FAIL** lights, or by using the **request chassis cfeb offline** CLI command.

You must power up the CFEB upon installation by pressing and holding down the offline button on the CFEB faceplate until the green LED labeled **Output OK** lights steadily, or by using the **request chassis cfeb online** CLI command.

**Action** To perform a swap test on a CFEB, follow the procedure in the appropriate routing hardware guide for replacing and installing a CFEB.

**Step 5: Perform a Swap Test on the CFEB**

**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the CFEB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

To perform a swap test on an CFEB, follow the procedure in the *M10i Internet Router Hardware Guide* for replacing and installing a CFEB.

One or two CFEBs can install into the uppermost slots in the rear of the chassis. Only one CFEB is active at a time, with the optional second CFEB in reset mode. CFEBs are hot-pluggable. Removing the standby CFEB has no effect on router function.

If the active CFEB fails or is removed from the chassis, the effect depends on whether two CFEBs are installed:

- If there is only one CFEB, forwarding halts until the CFEB is replaced and functioning again.
- If there are two CFEBs, forwarding halts until the standby CFEB boots and becomes active.

In both cases, all components in the Packet Forwarding Engine reset, and it takes approximately one minute for the new CFEB to become active; synchronizing router configuration information can take additional time, depending on the complexity of the configuration.

**Action** To perform a swap test on a CFEB, follow these steps:

1. Place an electrostatic bag or antistatic mat on a flat, stable surface.
2. Attach an electrostatic discharge (ESD) grounding strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
3. If you are removing the active CFEB, press and hold the offline button on the faceplate until the amber LED labeled FAIL lights, which takes about 5 seconds. (The effect of removing the active CFEB depends on whether a second CFEB is installed.
4. Loosen the thumbscrew on each ejector lever using a Phillips screwdriver if necessary.
5. Pull the end of each ejector lever outward until it is nearly perpendicular to the CFEB faceplate.
6. Grasp the ejector levers and pull firmly to slide the CFEB about halfway out of the chassis.

7. Place one hand under the CFEB to support it, slide it completely out of the chassis, and place it on the antistatic mat or in the electrostatic bag.



**CAUTION:** When a CFEB is out of the chassis, do not hold it by the ejector levers. They cannot support the weight of the CFEB.

Do not stack CFEBs on top of or under other components. Place each one individually in an electrostatic bag or on its own antistatic mat on a flat, stable surface.

8. Verify that the ends of the ejector levers are pulled outward to a position nearly perpendicular to the faceplate of the CFEB.
9. Place one hand under the CFEB to support it and grasp one of the ejector levers at the front with the other hand.
10. Align the rear of the CFEB with the guides inside the chassis and slide it in completely.
11. Press the ejector lever at each end of the CFEB inward.

## Getting CFEB Hardware Information

**Steps To Take** To display CFEB hardware information, follow these steps:

1. Display the CFEB Hardware Information on page 429
2. Display the CFEB Firmware Information on page 430
3. Locate the CFEB Serial Number ID Label on page 430

### Step 1: Display the CFEB Hardware Information

**Action** To display the CFEB hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item              Version  Part number  Serial number  Description
Chassis                               30512         M7i
Midplane          REV 04   710-008761   CB9213        M7i Midplane
Power Supply 0    Rev 02   740-008985   QB12884       DC Power Supply
Routing Engine    REV 09   740-009459   1000482742    RE-5.0
CFEB              REV 04   750-010112   CB8664        Internet Processor II
FPC 0
FPC 1
PIC 2             BUILTIN  BUILTIN      1x Tunnel
PIC 3             REV 04   750-009099   CB9103        1x G/E, 1000 BASE
```

**What It Means** The command output displays the CFEB version level, part number, serial number, and description.

## Step 2: Display the CFEB Firmware Information

**Action** To display the firmware running on the CFEB, use the following CLI command:

```
user@host> show chassis firmware
```

**Sample Output**


```
user@host> show chassis firmware
Part                Type      Version
[...Output truncated...]
CFEB                ROM       Juniper ROM Monitor Version 6.0b12
                   O/S       Version 7.0I14 by bharani on 2004-09-14 17:
```

**What It Means** The command output displays the type and version level of the firmware running on the CFEB.

## Step 3: Locate the CFEB Serial Number ID Label

**Action** To locate the CFEB serial number ID label, look on the right side of the top panel (see Figure 172).

**Figure 172: CFEB Serial Number ID Label**



## Returning the CFEB

**Action** To return the CFEB, see “Return the Failed Component” on page 86 or follow the procedure in the appropriate router hardware guide.

## Chapter 33

# Monitoring the HCM

You monitor the High-Availability Chassis Manager (HCM) on the M10i router to ensure that it works with its companion Routing Engine to provide control and monitoring functions for router components. You also monitor the HCM to ensure that it displays alarm status and takes Physical Interface Cards (PICs) online and offline. (See Table 100.)

**Table 100: Checklist for Monitoring the HCM**

Monitor HCM Tasks	Command or Action
<b>Understanding the HCM on page 433</b>	
<b>Monitoring the HCM Status on page 434</b>	
1. Check HCM LEDs on page 435	Look at the LEDs on the HCM component faceplate.
2. Check HCM Environmental Status on page 435	<code>show chassis environment hcm</code>
3. Check the Companion Routing Engine Status on page 435	<code>show chassis routing-engine</code>
<b>Displaying HCM Alarms on page 437</b>	<code>show chassis alarms</code>
<b>Performing A Swap Test on page 438</b>	
1. Remove An HCM on page 438	<p>Remove the HCM and replace it with one that you know works.</p> <p>Follow the procedure in the <i>M10i Internet Router Hardware Guide</i> to remove an HCM.</p> <ol style="list-style-type: none"><li>1. If two HCMs are installed, determine which HCM is master using the <code>show chassis environment hcm</code> CLI command.</li><li>2. Switch HCM mastership using the <code>request chassis routing-engine master switch</code> CLI command.</li><li>3. Shut down the router software using the <code>request system halt</code> CLI command.</li><li>4. Remove the Routing Engine.</li><li>5. Remove the failed HCM.</li></ol>
6. Install an HCM on page 440	<ol style="list-style-type: none"><li>1. Install the HCM that works.</li><li>2. Install the Routing Engine.</li><li>3. Ensure that the HCM is functioning properly using the <code>show chassis environment hcm</code> CLI command.</li></ol> <p>If the HCM still doesn't work, return it. See "Return the Failed Component" on page 86 or follow the procedure described in the <i>M10i Internet Router Hardware Guide</i>.</p>

Monitor HCM Tasks	Command or Action
<b>Getting HCM Hardware Information on page 441</b>	
1. Display the HCM Hardware Information on page 441	<code>show chassis hardware</code>
2. Locate the HCM Serial Number ID Label on page 442	Look near the front of the component on the right side.
<b>Returning the HCM on page 442</b>	See “Return the Failed Component” on page 86, or follow the procedure in the <i>M10i Internet Router Hardware Guide</i> .

## Understanding the HCM


**Purpose** Inspect the HCM to ensure that it works with its companion Routing Engine to provide control and monitoring functions for routing components. Also, inspect the HCM to ensure that it displays alarm status and takes the PIC online and offline.

**What Is an HCM** The HCM on the M10i router performs the following functions:

- **Monitoring and control of router components**—The HCM collects statistics from all sensors in the system. When it detects a failure or alarm condition, it sends a signal to the Routing Engine, which generates control messages or sets an alarm. The HCM also relays control messages from the Routing Engine to the router components.
- **Controlling component power-up and power-down**—The HCM controls the power-up sequence of router components as they start and powers down components when their offline buttons are pressed.
- **Signaling of mastership**—In a router with more than one Routing Engine, the HCM signals to all router components which Routing Engine is the master and which is the standby.
- **Alarm display**—The HCM provides status and troubleshooting information at a glance. It is located on the front of the chassis below the FPC card cage, as shown in Figure 174. The LEDs on the HCM include two alarm LEDs. The circular red alarm LED at the upper right of the craft interface indicates a critical condition that can result in a system shutdown. The triangular yellow alarm below it indicates a less severe condition that requires monitoring or maintenance. Both alarms can occur simultaneously.
- **PIC removal**—If a PIC offline button is pressed, the HCM relays the request to the Compact Forwarding Engine Board (CFEB), which takes the PIC offline and informs the Routing Engine. Other PICs are unaffected, and system operation continues. For more information, see “PIC Offline Buttons” on page 21.

Figure 173 shows the M10i router HCM component.

**Figure 173: M10i Router HCM Component**




The HCM has the following components:

- 100-Mbps Fast Ethernet switch—Carries signals and monitoring data between router components.
- Two LEDs—Indicate HCM status. The green LED is labeled **PWR** and the blue LED labeled **MSTR**. See “HCM LEDs” on page 435 for a description of the LED states.
- Alarm LEDs—Display alarm conditions, if any exist.
- PIC offline buttons—Relay a request to the CFEB, which prepares a PIC for removal from the router, or brings the PIC online when it is replaced.

Two HCMs are installed into the midplane from the front of the chassis, as shown in Figure 174. The master HCM performs all functions and provides PIC removal buttons for the first FPC. The standby HCM provides PIC removal buttons for the second FPC. The HCM in the slot labeled **HCM0** is paired with the Routing Engine in the slot labeled **RE0**. Likewise, the HCM in the slot labeled **HCM1** is paired with the Routing Engine in the slot labeled **RE1**. By default, the HCM in the slot labeled **HCM0** is the master.

**Figure 174: M10i Router HCM Location**

M10i front



The HCM is hot-pluggable.

## Monitoring the HCM Status

**Steps To Take** To monitor the HCM status, follow these steps:

1. Check HCM LEDs on page 435
2. Check HCM Environmental Status on page 435



3. Check the Companion Routing Engine Status on page 435

### Step 1: Check HCM LEDs

**Action** To check the HCM LEDs, look at the component faceplate at the bottom left front of the M10i router chassis (see Figure 174 on page 434).

Two LEDs indicate HCM status—a green PWR LED and a blue MSTR LED. Table 101 describes the LED states.

**Table 101: HCM LEDs**

Label	Color	State	Description
PWR	Green	On steadily	HCM is functioning normally.
		Blinking	HCM is starting up.
MSTR	Blue	On steadily	HCM is master.

### Step 2: Check HCM Environmental Status

**Action** To check the HCM environmental status, use the following CLI command:

```
user@host: show chassis environment hcm
```

**Sample Output**

```
user@host> show chassis environment hcm
HCM 0 status:
  State           Online Master
  FPGA Revision   27
HCM 1 status:
  State           Present Standby
  FPGA Revision   27
```

**What It Means** The command output shows that the HCM status, including slot number, operating state, and field programmable gate array (FPGA) revision.

**Alternative Action** To display the environmental status of a particular HCM, use the following CLI command:

```
m10i@host> show chassis environment hcm slot
```

### Step 3: Check the Companion Routing Engine Status

The HCM in the slot labeled HCM0 is paired with the Routing Engine in the slot labeled RE0. Likewise, the HCM in the slot labeled HCM1 is paired with the Routing Engine in the slot labeled RE1. By default, the HCM in the slot labeled HCM0 is the master.

When HCM mastership changes because of failure, Routing Engine mastership changes as well.

**Action** To check Routing Engine status, use the following CLI command:

```
user@host> show chassis routing-engine
```

**Sample Output**

```
user@host> show chassis routing-engine
```

```

Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             36 degrees C / 96 degrees F
  CPU temperature         35 degrees C / 95 degrees F
  DRAM                   256 MB
  Memory utilization      37 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                6 percent
    Interrupt             0 percent
    Idle                  93 percent
  Model                  RE-5.0
  Serial ID              1000488824
  Start time             2004-09-28 03:06:10 PDT
  Uptime                 13 days, 10 hours, 36 minutes, 22 seconds
  Load averages:        1 minute   5 minute   15 minute
                        0.22       0.06       0.02

Routing Engine status:
Slot 1:
  Current state           Backup
  Election priority       Backup (default)
  Temperature             35 degrees C / 95 degrees F
  CPU temperature         32 degrees C / 89 degrees F
  DRAM                   256 MB
  Memory utilization      28 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                1 percent
    Interrupt             0 percent
    Idle                  99 percent
  Model                  RE-5.0
  Serial ID              1000485860
  Start time             2004-09-11 01:01:02 PDT
  Uptime                 30 days, 12 hours, 41 minutes, 15 seconds

```

**What It Means** The command output displays the operating state of both Routing Engines installed in the router chassis, including slot number, current state, and default election priority—master or backup. The command output also displays the Routing Engine temperature, amount of memory, and the percentage of memory and CPU utilization. The command output displays the Routing Engine model number, serial number ID, start time, and total operating time.

**Alternative Action** Look at the Routing Engine LEDs by using the `show chassis routing-engine` CLI command or by looking at the component faceplate at the front of the router. The Routing Engine has four LEDs that tell operating status: a green LED labeled **HDD**, a blue LED labeled **MASTER**, a red LED labeled **FAIL**, and a green LED labeled **ONLINE**. Table 102 describes the Routing Engine LED states.

**Table 102: Routing Engine LEDs**

Label	Color	State	Description
HDD	Green	Blinking	There is read/write activity on the PC card.
MASTER	Blue	On steadily	Routing Engine is functioning as master.

Label	Color	State	Description
FAIL	Red	On steadily	Routing Engine is not operational..
ONLINE	Green	On steadily	Routing Engine is running normally.

## Displaying HCM Alarms

If a router with a single HCM fails, no alarm can be sent. If a master HCM fails on a router with dual HCMs and the backup HCM takes over mastership, an alarm is reported on the backup Routing Engine.

When HCM mastership changes because of failure, Routing Engine mastership changes as well.

**Action** To view HCM alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
4 alarms currently active
Alarm time           Class  Description
2005-02-16 22:10:27 UTC  Minor  Backup RE Active
```

**What It Means** The command output displays a minor alarm indicating that the backup Routing Engine is active or is master. Since the HCM is a companion component of the Routing Engine, the backup HCM is also active. The command output displays the date and time of the alarm.

To verify that the backup HCM has taken over mastership, use the show chassis routing-engine CLI command.

```
user@host> show chassis routing-engine
```

**Sample Output**

```
user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Backup
  Election priority       Master (default)
  Temperature             33 degrees C / 91 degrees F
  DRAM                   2048 MB
  Memory utilization      13 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                 0 percent
    Interrupt              0 percent
    Idle                  100 percent
  Model                   RE-3.0
  Serial ID               P10865703096
  Start time              2005-02-16 22:13:19 UTC
  Uptime                  2 hours, 13 minutes, 57 seconds
Routing Engine status:
Slot 1:
  Current state           Master
  Election priority       Backup (default)
  Temperature             33 degrees C / 91 degrees F
  CPU temperature         29 degrees C / 84 degrees F
  DRAM                   2048 MB
```

Memory utilization	12 percent
CPU utilization:	
User	0 percent
Background	0 percent
Kernel	3 percent
Interrupt	0 percent
Idle	97 percent
Model	RE-3.0
Serial ID	P10865701255
Start time	2005-02-03 03:13:39 UTC
Uptime	13 days, 21 hours, 12 minutes, 35 seconds
Load averages:	1 minute    5 minute    15 minute
	0.00        0.03        0.01

**What It Means** The HCM in the slot labeled **HCM0** is paired with the Routing Engine in the slot labeled **RE0**. Likewise, the HCM in the slot labeled **HCM1** is paired with the Routing Engine in the slot labeled **RE1**. By default, the HCM in the slot labeled **HCM0** is the master. However, in this instance, the Routing Engine in slot **RE1** has taken over mastership, indicating that the HCM in slot **HCM1** is also master.

## Performing A Swap Test



**NOTE:** although steps to remove and install an HCM are provided here, ensure that you refer to the appropriate hardware guide for the latest information.

Before performing a swap test, always check for bent pins in the midplane and check the HCM for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

The HCM is hot-pluggable. You can perform a swap test on an HCM to pinpoint the problem.

**Action** To perform a swap test and verify HCM failure, follow these steps:

- Steps To Take**
1. Remove An HCM on page 438
  2. Install an HCM on page 440

### Step 1: Remove An HCM

The HCM is hot-pluggable. You can perform a swap test on an HCM to try to pinpoint the problem.

**Action** To remove an HCM, follow these steps:

1. Place an electrostatic bag or antistatic mat on a flat, stable surface.
2. If a Routing Engine is installed in the same row as the HCM you are removing, remove the Routing Engine first. If two Routing Engines are installed, use one of the following two methods to determine which HCM is functioning as master:
  - Note which of the blue **MASTER** LEDs is lit on the Routing Engine faceplates.
  - Use the following CLI command:

```
user@host> show chassis environment hcm
```

```
HCM 0 status:
  State                Online Master
  FPGA Revision        27
HCM 1 status:
  State                Online Standby
  FPGA Revision        27
```

The master HCM is designated Master in the **State** field.

3. If you are removing the master Routing Engine and a second Routing Engine is installed, issue the following CLI command to switch mastership to the standby host module:

```
user@host> request chassis routing-engine master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between routing engines ? [yes,no] (no) yes
```

```
Resolving mastership...
```

If the Routing Engines are running JUNOS Release 6.0 or later and are configured for graceful switchover, the standby Routing Engine immediately assumes Routing Engine functions and there is no interruption to packet forwarding. Otherwise, packet forwarding halts while the standby Routing Engine becomes the master and the Packet Forwarding Engine components reset and connect to the new master Routing Engine. For information about configuring graceful switchover, see the section about Routing Engine redundancy in the *JUNOS System Basics Configuration Guide*.



**NOTE:** Router performance might change if the standby Routing Engine's configuration differs from the former master's configuration. For the most predictable performance, configure the two Routing Engines identically, except for parameters unique to a Routing Engine, such as the hostname defined at the **[edit system]** hierarchy level and the management interface (**fxp0** or equivalent) defined at the **[edit interfaces]** hierarchy level.

To configure Routing Engine-specific parameters and still use the same configuration on both Routing Engines, include the appropriate configuration statements under the **re0** and **re1** statements at the **[edit groups]** hierarchy level and use the **apply-groups** statement. For instructions, see the *JUNOS System Basics Configuration Guide*.

---

4. On the console or other management device connected to the Routing Engine, enter CLI operational mode and use the following command to shut down the router software cleanly and preserve Routing Engine state information:

```
user@host> request system halt
```

Wait until a message appears on the console confirming that the operating system has halted.

For more information about the command, see the *JUNOS Protocols, Class of Service, and System Basics Command Reference*.



**NOTE:** The router might continue forwarding traffic for a few minutes after the request system halt command has been issued.

5. Attach an electrostatic discharge (ESD) grounding strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
6. Loosen the thumbscrews located at each end of the Routing Engine faceplate, using a Phillips screwdriver if necessary.
7. Grasp the handle and slide the unit about halfway out of the chassis.



**CAUTION:** Slide the Routing Engine straight out of the chassis. Damage can result if it gets lodged because of uneven movement.

8. Place one hand under the Routing Engine to support it, slide it completely out of the chassis, and place it on the antistatic mat or in the electrostatic bag.
9. Grasp the handle of the HCM and slide the unit about halfway out of the chassis.



**CAUTION:** Slide the HCM straight out of the chassis. Damage can result if it gets lodged because of uneven movement.

10. Place one hand under the HCM to support it, slide it completely out of the chassis, and place it on the antistatic mat or in the electrostatic bag.

## Step 2: Install an HCM

**Action** To install an HCM, follow these steps:

1. Attach an ESD grounding strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
2. Place one hand under the HCM to support it and grasp the handle on the faceplate with the other hand.
3. Align the rear of the HCM with the guide rails inside the chassis and slide it in completely.



**CAUTION:** Align the HCM carefully with the guide rails and push it in evenly. Damage can result if it gets lodged in the rails because of uneven movement.

4. Place one hand under the Routing Engine to support it and grasp the handle on the faceplate with the other hand.

- 5. Align the rear of the Routing Engine with the guide rails inside the chassis and slide it in completely.



**CAUTION:** Align the Routing Engine carefully with the guide rails and push it in evenly. Damage can result if it gets lodged in the rails because of uneven movement.

- 6. Tighten the thumbscrews on the Routing Engine faceplate to secure the Routing Engine.
- 7. Use the `show chassis environment hcm` CLI command to verify that the HCM is functioning correctly.

### Getting HCM Hardware Information

**Steps To Take** To obtain HCM hardware information, follow these steps:

- 1. Display the HCM Hardware Information on page 441
- 2. Locate the HCM Serial Number ID Label on page 442

#### Step 1: Display the HCM Hardware Information

**Action** To display the HCM hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**


```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               30700         M10i
Midplane      REV 04   710-008920   CB8867         M10i Midplane
Power Supply 0 Rev 05   740-008537   QB12637        AC Power Supply
Power Supply 1 Rev 05   740-008537   QB12537        AC Power Supply
HCM slot 0     REV 05   710-008661   CC1145         M10i HCM
HCM slot 1     REV 05   710-008661   CC1138         M10i HCM
[...Output truncated...]
```

**What It Means** The command output displays the HCM version level, part number, serial number, and description.

## Step 2: Locate the HCM Serial Number ID Label

**Action** To locate the HCM serial number ID label, look near the front of the component on the right side (see Figure 175).

**Figure 175: M10i Router HCM Serial Number ID Label**



## Returning the HCM

**Action** To return the HCM, see “Return the Failed Component” on page 86 or follow the instructions in the *M10i Internet Router Hardware Guide*.



## Chapter 34

# Monitoring the FIC

You monitor the Fixed Interface Card (FIC), which receives incoming packets from the network and transmits outgoing packets to the network, providing support for Fast Ethernet ports or Gigabit Ethernet interfaces, depending on which version of the FIC is installed in the M7i router. You also monitor the FIC to view alarm status, and to perform some system control functions, such as taking Physical Interface Cards (PICs) online and offline. (See Table 103.)

**Table 103: Checklist for Monitoring the FIC**

Monitor FIC Tasks	Command or Action
<b>Understanding the FIC on page 444</b>	
■ M7i Router FIC with Fast Ethernet Ports on page 444	
■ M7i Router FIC with Gigabit Ethernet Port on page 444	
■ M7i Router FIC Location on page 444	
■ FIC Numbering on page 445	
<b>Monitoring the FIC Status on page 445</b>	
1. Understand FIC Slot Numbering on page 445	The FIC is located in FPC 1 slot 3.
2. Display FIC Status at the Command Line on page 445	<code>show chassis pic pic-slot 3 fpc-slot 1</code>
3. Check FIC LEDs on page 446	Look at the FIC faceplate LEDs.
<b>Displaying FIC Alarms on page 446</b>	
1. Display the FIC Status on page 446	<code>show chassis pic pic-slot 3 fpc-slot 1</code>
2. Display FIC Errors In the nmessages Log File on page 446	<code>show log messages   match PIC 3</code>
3. Display FIC Errors In the chassisd Log File on page 447	<code>show log chassisd   match PIC 3</code>
<b>Verifying FIC Failure on page 447</b>	Look at the FIC faceplate LEDs.
<b>Displaying FIC Hardware Information on page 448</b>	
1. Display the FIC Hardware Information on page 448	<code>show chassis hardware</code>
2. Display the M7i Router Chassis Serial Number on page 448	<code>show chassis hardware</code>
<b>Removing the FIC on page 449</b>	You cannot remove the FIC. It is built into the M7i router chassis.
<b>Returning the FIC on page 449</b>	See “Return the Failed Component” on page 86, or follow the procedure in the <i>M7i Hardware Guide</i> .

## Understanding the FIC

**Purpose** Inspect the FIC to ensure that it receives incoming packets from the network, transmits outgoing packets to the network, provides support for Ethernet ports, displays system alarms, and takes PICs online or offline as needed.

**What Is an FIC** A FIC is a component, built into the M7i router chassis, that receives incoming packets from the network and transmits outgoing packets to the network, providing support for Fast Ethernet ports or Gigabit Ethernet interfaces, depending on which version of the FIC is installed in the M7i router. You also monitor the FIC to view alarm status, and to perform some system control functions, such as taking PICs online and offline.

There are two types of FICs: with fast Ethernet ports and with a Gigabit Ethernet port. Figure 176 shows the FIC with Fast Ethernet ports.

**Figure 176: M7i Router FIC with Fast Ethernet Ports**





Figure shows the FIC with a Gigabit Ethernet port.


**Figure 177: M7i Router FIC with Gigabit Ethernet Port**



The FIC is located on the front of the chassis to the left of the Routing Engine and is not a field-replaceable unit (FRU) (see Figure 178).

**Figure 178: M7i Router FIC Location**

M7i front



## Monitoring the FIC Status


If the FIC fails, no information about chassis components is available through the JUNOS software command-line interface (CLI).

**Steps To Take** To monitor the FIC status, follow these steps:

- 1. Understand FIC Slot Numbering on page 445
- 2. Display FIC Status at the Command Line on page 445
- 3. Check FIC LEDs on page 446

### Step 1: Understand FIC Slot Numbering

Figure 179 shows the FIC location and numbering in the M7i router. The FIC is located in FPC 1 slot 3.



### Step 2: Display FIC Status at the Command Line

**Action** To display the FIC status, use the following CLI command:

```
user@host> show chassis pic pic-slot 3 fpc-slot 1
```

**Sample Output**

```
user@host> show chassis pic pic-slot 3 fpc-slot 1
PIC fpc slot 1 pic slot 3 information:
  Type                1x G/E, 1000 BASE
  ASIC type            QGE FPGA
  State                Online
  PIC version          1.4
  Uptime               12 hours, 11 minutes, 39 seconds

PIC Port Information:
  Port      Cable      SFP      SFP Vendor
  Number    Type          Vendor Name  Part Number
  0          UNKNOWN CABLE
```

**What It Means** Since the FIC is located in FPC 1 slot 3, you must specify its location with the `show chassis pic` CLI command. The command output displays the FIC information, such as the FIC type, ASIC type, operating status, PIC version, and the amount of time the FIC has been online. The command output also displays port cable information.

### Step 3: Check FIC LEDs

Table 6 describes the FIC interface LEDs located on the FIC faceplate.

**Table 104: Table 6: FIC Interface LEDs**

Label	Color	State	Description
LINK	Green	On steadily	The port is online.
ACTIVITY	Green	Blinking	The port is receiving data.
		Off	The port might be on, but is not receiving data.

## Displaying FIC Alarms

**Steps To Take** To determine whether the FIC is offline, follow these steps:

1. Display the FIC Status on page 446
2. Display FIC Errors In the nmessages Log File on page 446
3. Display FIC Errors In the chassisd Log File on page 447

### Step 1: Display the FIC Status

**Action** To view the FIC status, use the following CLI command:

```
user@host> show chassis pic pic-slot 3 fpc-slot 1
```

**Sample Output**

```
user@host> show chassis pic pic-slot 3 fpc-slot 1
PIC fpc slot 1 pic slot 3 information:
State                                     Offline
```

**What It Means** The FIC in fpc slot 1 pic slot 3 is offline.

### Step 2: Display FIC Errors In the nmessages Log File

**Action** To display the FIC errors recorded in the messages log file, use the following CLI command:

```
user@host> show log messages | match PIC 3
```

**Sample Output**

```
user@host> show log messages | match PIC 3 in FPC 1
Feb 22 05:50:58 noah chassisd[4738]: CHASSISD_PIC_OFFLINE_NOTICE: Taking PIC 3
in FPC 1 offline: Offlined by cli command
Feb 22 05:50:58 noah cfeb CMFPC: Offline CMD request for PIC 1/3
Feb 22 05:50:58 noah chassisd[4738]: CHASSISD_IFDEV_DETACH_PIC:
ifdev_detach_pic(1/3)
Feb 22 05:50:58 noah chassisd[4738]: CHASSISD_SNMP_TRAP9: SNMP trap generated:
FRU power off (jnxFruContentsIndex 8, jnxFruL1Index 2, jnxFruL2Index 4,
jnxFruL3Index 0, jnxFruName PIC: 2x F/E, 100 BASE-TX @ 1/3/*, jnxFruType 11,
jnxFruSlot 2, jnxFruOfflineReason 7, jnxFruLastPowerOff 30713054,
jnxFruLastPowerOn 407915)
```

**What It Means** The messages log file records the error events during the time the FIC went offline. The messages log file records the time and date and the SNMP trap message generated.

### Step 3: Display FIC Errors In the chassisd Log File

**Action** To display FIC errors in the chassisd log file, follow these steps:

```
user@host> show log chassisd | match PIC 3
```

**Sample Output**

```
user@host> show log messages | match PIC 3 in FPC 1
Feb 22 05:57:02 PIC message op 1
Feb 22 06:04:35 CHASSISD_PIC_OFFLINE_NOTICE: Taking PIC 3 in FPC 1 offline:
Offlined by cli command
Feb 22 06:04:35 send: fpc 1 pic 3 offline cmd
Feb 22 06:04:36 pic offline req, pic 3, fpc 1
Feb 22 06:04:36 CHASSISD_IFDEV_DETACH_PIC: ifdev_detach_pic(1/3)
Feb 22 06:04:36 send pic_offline_ack fpc 1 pic 3 accept 1
Feb 22 06:04:36 CHASSISD_SNMP_TRAP9: SNMP trap generated: FRU power off
(jnxFruContentsIndex 8, jnxFruL1Index 2, jnxFruL2Index 4, jnxFruL3Index 0,
jnxFruName PIC: 2x F/E, 100 BASE-TX @ 1/3/*, jnxFruType 11, jnxFruSlot 2,
jnxFruOfflineReason 7, jnxFruLastPowerOff 30794800, jnxFruLastPowerOn 30749381)
Feb 22 06:04:36 PIC message op 2
Feb 22 06:04:36 Time to clean up PIC FPC 1, PIC 3
Feb 22 06:04:36 PIC message op 3
Feb 22 06:04:36 pic_handle_message: PIC fpc 1 pic 3 got deleted
Feb 22 06:04:36 pic detach, pic 3, fpc 1
```

**What It Means** The chassisd log file records the time and date of FIC errors. nlt displays the SNMP trap error message generated.

## Verifying FIC Failure

**Action** To check the status of each port on a FIC or PIC, look at the LED located on the faceplate. See “Check FIC LEDs” on page 446 for more information. For information about the meaning of LED states on different PICs, see the *M7i Internet Router PIC Guide*.

## Displaying FIC Hardware Information

---

**Steps To Take** To display FIC hardware information, do the following:

1. Display the FIC Hardware Information on page 448
2. Display the M7i Router Chassis Serial Number on page 448

### Step 1: Display the FIC Hardware Information

**Action** To display the FIC hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               30512          M7i
Midplane      REV 04   710-008761   CB9213         M7i Midplane
Power Supply 0 Rev 02   740-008985   QB12884        DC Power Supply
Routing Engine REV 09   740-009459   1000482742     RE-5.0
CFEB          REV 04   750-010112   CB8664         Internet Processor II
FPC 0
FPC 1
PIC 2                               BUILTIN       BUILTIN        1x Tunnel
PIC 3          REV 04   750-009099   CB9103         1x G/E, 1000 BASE
```

**What It Means** The command output displays the hardware revision level, part number, serial number, and description for the FIC located at FPC 1 PIC 3.

### Step 2: Display the M7i Router Chassis Serial Number

If the FIC fails, you have to return the M7i router chassis. To return the M7i router, you must provide the midplane serial number.

**Action** To display the M7i router chassis serial number, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               31898          M7i
Midplane      REV 04   710-008761   CC7798         M7i Midplane
Power Supply 0 Rev 05   740-008537   QE16641        AC Power Supply
Routing Engine REV 09   740-009459   1000513705     RE-5.0
[...Output truncated...]
```

**What It Means** The M7i router midplane serial number is CC7798.

## Removing the FIC

---



**NOTE:** You cannot remove the FIC. It is built into the M7i router chassis.

---

## Returning the FIC

---

**Action** The FIC is built into the M7i router. If the FIC fails, return the M7i router chassis. To replace the M7i router, see “Return the Failed Component” on page 86 or follow the procedure for returning the chassis in the *M7i Internet Router Hardware Guide*.





## Part 9

# Monitoring M5 and M10 Router-Specific Components

- Monitoring the FEB on page 453



## Chapter 35

# Monitoring the FEB

You monitor the Forwarding Engine Board (FEB) on an M5 and M10 router to ensure that forwarding processes occur, such as route lookups, incoming data packet allocation, outgoing data packet transfer, and exception and control packet transfer. (See Table 105.)

**Table 105: Checklist for Monitoring the FEB**

Monitor FEB Tasks	Command or Action
<b>Understanding the FEB on page 454</b>	
<b>Monitoring the FEB Status on page 455</b>	
1. Display the FEB Environmental Status on page 455	show chassis environment
2. Display the FEB Detailed Status on page 456	show chassis feb
<b>Verifying FEB Failure on page 456</b>	
1. Check the FEB Uptime on page 457	show chassis feb
2. Check the System Uptime on page 457	show system uptime
3. Check the FEB Connection on page 457	Check that the screws at the top of the FEB are securely tightened.
4. Perform a Swap Test on the FEB on page 458	1. Power down the router. 2. Remove the FEB. 3. Replace the FEB with one that you know works.
<b>Getting FEB Hardware Information on page 459</b>	
1. Display the FEB Hardware Information on page 459	show chassis hardware
2. Display the FEB Firmware Information on page 459	show chassis firmware
3. Locate the FEB Serial Number ID Label on page 460	Look near the back on the right side of the FEB.
<b>Returning the FEB on page 460</b>	See “Return the Failed Component” on page 86, or follow the procedure in the <i>M5 and M10 Internet Router Hardware Guide</i> .


## Understanding the FEB

**Purpose** Inspect the FEB to ensure that communication occurs with the Routing Engine.

**What Is an FEB** The FEB is a control board for the M5 and M10 routers (see Figure 180). The FEB communicates with the Routing Engine using a dedicated 100-Mbps link that transfers routing table data from the Routing Engine to the forwarding table in the Internet Processor II application-specific integrated circuit (ASIC). The link is also used to transfer routing link-state updates and other packets destined for the router from the FEB to the Routing Engine. The FEB provides the following functions:

- Route lookups—The Internet Processor II ASIC on the FEB performs route lookups using the forwarding table stored in synchronous SRAM (SSRAM).
- Shared memory management—One Distributed Buffer Manager ASIC on the FEB uniformly allocates incoming data packets throughout the router's shared memory.
- Outgoing data packet transfer—A second Distributed Buffer Manager ASIC on the FEB passes data packets to the destination Physical Interface Card (PIC) when the data is ready to be transmitted.
- Exception and control packet transfer—The Internet Processor II ASIC passes exception packets to the microprocessor on the FEB, which processes almost all of them. The remaining packets are sent to the Routing Engine for further processing. Any errors originating in the Packet Forwarding Engine and detected by the FEB are sent to the Routing Engine using system log messages.

**Figure 180: FEB Component**




1307

The FEB is located on the rear of the router above the power supplies (see Figure 181).

**Figure 181: M5 and M10 Router FEB Location**

M5 and M10 router  
rear



The FEB is field-replaceable, but is not hot-removable or hot-pluggable. You must power down the router before removing or replacing the FEB.

## Monitoring the FEB Status

If the FEB fails, no information about chassis components is available through the JUNOS software command-line interface (CLI).

**Steps To Take** To monitor the FEB status, follow these steps:

1. Display the FEB Environmental Status on page 455
2. Display the FEB Detailed Status on page 456

### Step 1: Display the FEB Environmental Status

**Action** To display the FEB environmental status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@m5-host> show chassis environment
Class Item                Status    Measurement
-----
Power Power Supply A      OK
       Power Supply B      OK
Temp  FPC Slot 0             OK        32 degrees C / 89 degrees F
       FEB                 OK        31 degrees C / 87 degrees F
       PS Intake            OK        26 degrees C / 78 degrees F
       PS Exhaust           OK        31 degrees C / 87 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the temperature and status of the FEB, which can be OK, Failed, or Absent.

## Step 2: Display the FEB Detailed Status

**Action** To display more detailed FEB status, use the following CLI command:

```
user@host> show chassis feb
```

**Sample Output**

```
user@host> show chassis feb
FEB status:
  Temperature           37 Centigrade
  CPU utilization        0 percent
  Interrupt utilization  0 percent
  Heap utilization       16 percent
  Buffer utilization      43 percent
  DRAM                   64 Mbytes
  Internet Processor II  Version 1, Foundry IBM, Part number 9
  Start time             1999-01-24 16:24:42 UTC
  Uptime                 2 hours, 21 minutes, 28 seconds
```

**What It Means** The command output displays the temperature of the air passing by the FEB, in degrees Centigrade. It displays the total percentage of CPU, interrupt, heap space, and buffer space being used by the FEB processor, including the total DRAM available to the FEB processor. The command output displays the time when the FEB started running and how long the FEB has been running. A short uptime can indicate that there is an FEB problem.

## Verifying FEB Failure

---

The FEB will either restart, keep crashing, or fail completely. If the FEB fails, you will lose the router interface connections.

**Steps To Take** To verify FEB failure, follow these steps:

1. Check the FEB Uptime on page 457
2. Check the System Uptime on page 457
3. Check the FEB Connection on page 457
4. Perform a Swap Test on the FEB on page 458

### Step 1: Check the FEB Uptime

**Action** To check the FEB uptime, use the following CLI command:

```
user@host> show chassis feb
```

**Sample Output**

```
user@host> show chassis feb
FEB status:
  Temperature           24 degrees C / 75 degrees F
  CPU utilization        1 percent
  Interrupt utilization  0 percent
  Heap utilization       17 percent
  Buffer utilization      44 percent
  Total CPU DRAM         64 MB
  Internet Processor II  Version 1, Foundry IBM, Part number 9
  Start time:            2002-07-12 17:30:43 PDT
  Uptime:                0 days, 0 hours, 1 minutes, 0 seconds
```

**What It Means** The command output displays how long the FEB has been operating. A short uptime can indicate an FEB failure. Look for error messages that were generated at least 5 minutes prior to the failure event by using the following CLI command:

```
user@host> show log messages
```

### Step 2: Check the System Uptime

**Action** To check the system uptime, use the following CLI command:

```
user@host> show system uptime
```

**Sample Output**

```
user@host> show system uptime
Current time:      2002-07-17 16:43:45 PDT
System booted:     2002-07-12 17:29:12 PDT (4d 23:14 ago)
Protocols started: 2002-07-12 17:29:56 PDT (4d 23:13 ago)
Last configured:   2002-07-10 23:10:27 PDT (6d 17:33 ago) by regress
4:43PM up 4 days, 23:15, 2 users, load averages: 0.07, 0.02, 0.00
```

**What It Means** The command output displays the time when the system was last booted, in days and hours. If the boot time is short, it can indicate a Routing Engine or an FEB failure. Look for error messages that were generated at least 5 minutes prior to the failure event by using the following CLI command:

```
user@host> show log messages
```

### Step 3: Check the FEB Connection

**Action** Make sure the FEB is properly seated in the midplane. Use a Phillips screwdriver to ensure that the screws at the top of the FEB are securely tightened.

**Step 4: Perform a Swap Test on the FEB**

**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the FEB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

You must power down the router to remove and replace the FEB.

**Action** To perform a swap test on an FEB, follow these steps:

1. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Turn off power to the router. For information on powering down the router, see the *M5 and M10 Internet Router Hardware Guide*.
3. Unscrew the five screws holding the rear chassis component cover in place, and remove the cover. Be sure to save the screws for when you reinstall the cover.
4. Flip the ends of the two ejector levers towards the outside edges of the router.
5. Grasp both sides of the FEB and slide it about three-quarters of the way out of the router.
6. Move one hand underneath the FEB to support it and slide it completely out of the chassis.
7. Remove the Routing Engine from the FEB.

Unscrew the screws on the outside edges of the extractor clips to unseat the Routing Engine from the FEB. Press in on the red tabs on the extractor clips, then flip the ends of the extractor clips toward the outside edges of the router to release the Routing Engine. Grasp both sides of the Routing Engine and slide it evenly out of the FEB.

8. Replace the Routing Engine in the FEB.

Align the rear of the unit with the guides inside the chassis. Slide the Routing Engine all the way in until it contacts the connectors on the FEB. Flip the ends of the extractor clips toward the center of the router to seat the Routing Engine onto the FEB. Using a screwdriver, tighten the screws on the outside edges of the extractor clips. Slide the Routing Engine into the slot evenly.

9. Use both hands to grasp the front of the replacement FEB that works and align the rear of the FEB with the guides on the chassis.
10. To ensure proper seating of the ejector levers, move them to an outward position slightly less than perpendicular to the faceplate before seating the FEB in the slot.
11. Slide the FEB all the way into the chassis until it contacts the midplane.
12. Grasp the ejector levers and carefully push the FEB to seat it onto the midplane.
13. Flip the ejector levers toward each other to lodge the FEB in place.



## Getting FEB Hardware Information

---

**Steps To Take** To obtain FEB hardware information, follow these steps:

1. Display the FEB Hardware Information on page 459
2. Display the FEB Firmware Information on page 459
3. Locate the FEB Serial Number ID Label on page 460

### Step 1: Display the FEB Hardware Information

**Action** To display the FEB hardware information, use the following CLI command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis
Midplane         REV 03   710-001950   HA9949
Power Supply A   Rev 03   740-002498   LK33316        DC
Display          REV 04   710-001995   HB2079
Routing Engine
FEB              REV 11   710-001948   HE6497         RE-2.0
Internet Processor II
[...Output truncated...]
```

**What It Means** The command output displays the FEB version level, part number, serial number, and description.

### Step 2: Display the FEB Firmware Information

**Action** To display the firmware running on the FEB, use the following CLI command:

```
user@host> show chassis firmware
```

**Sample Output**


```
user@host> show chassis firmware
Part             Type      Version
Forwarding engine board ROM       Juniper ROM Monitor Version 4.1b2
O/S              Version 4.1I1 by tlim on 2000-04-24 11:27
```

**What It Means** The command output displays the type and version level of the firmware running on the FEB.

### Step 3: Locate the FEB Serial Number ID Label

**Action** To locate the FEB serial number ID label, look near the back on the right side of the FEB (see Figure 182).

**Figure 182: FEB Serial Number ID Label**



### Returning the FEB

---

**Action** To replace the FEB, see “Return the Failed Component” on page 86 or the *M5 and M10 Internet Router Hardware Guide*.

## Part 10

# Monitoring Redundant Router Components

- Host Redundancy Overview on page 463
- Monitoring Redundant Routing Engines on page 491
- Monitoring Redundant Power Supplies on page 507
- Monitoring Redundant Cooling System Components on page 523
- Monitoring Redundant SIBs on page 543
- Monitoring Redundant SCGs on page 551
- Monitoring Redundant Control Boards on page 559
- (For M40e and M160 routers) Monitoring Redundant MCSs on page 567
- (For M40e and M160 routers) Monitoring Redundant SFMs on page 577
- (For M40e and M160 routers) Monitoring Redundant PCGs on page 595
- (For the M20 router) Monitoring Redundant SSBs on page 605
- (For the M10i router) Monitoring Redundant CFEBs on page 617
- (For the M10i router) Monitoring Redundant HCMs on page 623



## Chapter 36

# Host Redundancy Overview

You monitor redundant Routing Engines, host modules, and host subsystems to provide a standby Routing Engine and controller component that will switch from standby to active, assuming mastership, with limited running downtime when a failure occurs.

This chapter provides an overview of how redundant host modules, host subsystems, and Routing Engines work on various routing platforms. Additionally, it describes the topics as listed in Table 106.

**Table 106: Checklist for Host Redundancy**

Monitor Redundant Routing Engine Tasks	Command or Action
<b>Understanding Redundancy for the Routing Engine, Host Module, and Host Subsystem on page 465</b>	
■ M10i Router Redundant Routing Engines and HCMs on page 465	
■ M20 Router Redundant Routing Engines and SSBs on page 466	
■ M40e and M160 Router Redundant Host Modules on page 467	
■ M320 Router, T320 Router, and T640 Routing Node Redundant Host Subsystems on page 468	
<b>Routing Engine, Host Module, and Host Subsystem Redundancy Connections on page 469</b>	
■ Redundancy Connection for an M10i Router on page 470	
■ Redundancy Connection for an M20 Router on page 471	
■ Redundancy Connection for an M40e or M160 Router on page 472	
■ Redundancy Connection for an M320 Router on page 473	
■ Redundancy Connection for a T320 Router and T640 Routing Node on page 474	
<b>Determining Which Routing Engine You Are Logged In To on page 475</b>	
1. Display Routing Engine Status on page 476	show chassis routing-engine
2. Display the Router Hardware on page 476	show chassis hardware
<b>Determining Routing Engine Mastership on page 477</b>	
1. Determine the Routing Engine Mastership By Checking Status on page 477	show chassis routing-engine
2. Determine Routing Engine Mastership By Checking the LEDs on page 478	Physically check the LEDs on either the craft interface or the Routing Engine (depending on which chassis the Routing Engine is installed).
3. Log In To Backup Routing Engine If graceful-switchover is Configured on page 478	request routing-engine login other-routing-engine

Monitor Redundant Routing Engine Tasks	Command or Action
<b>Manually Configuring Master and Backup Routing Engines on page 478</b>	For slot 0: [edit] set chassis redundancy routing-engine 1 master commit For slot 1: [edit] set chassis redundancy routing-engine 0 backup commit
<b>Manually Switching Routing Engine Mastership on page 481</b>	request chassis routing-engine master (acquire   release   switch)
<b>Determining Why Mastership Switched on page 482</b>	show log mastership
<b>Configuring the Backup Routing Engine to Assume Mastership on Failure of Keepalives on page 485</b>	[edit] set chassis redundancy failover on-loss-of-keepalives set chassis redundancy keepalive-time 300 commit
<b>Avoiding Redundancy Problems on page 486</b>	
1. Operate the Same Type of Routing Engine and JUNOS Software on page 486	The active and standby Routing Engines must be the same type of Routing Engine and must operate the same version of JUNOS software.
2. Use the Groups Configuration on page 486	[edit] set groups <i>group-name</i>
3. Synchronize Configurations on page 488	[edit] commit synchronize
4. Copy a Configuration File from One Routing Engine to Another on page 488	file copy <source> <destination>
5. Use the Proper Shutdown Process on a Backup Routing Engine on page 489	request system halt

- See Also**
- Monitoring Redundant MCSs on page 567
  - Monitoring Redundant Routing Engines on page 491
  - Monitoring Redundant Control Boards on page 559

## Understanding Redundancy for the Routing Engine, Host Module, and Host Subsystem

**Purpose** To learn how redundant Routing Engines, host modules, and host subsystems work on various routing platforms. You monitor these components to provide a standby Routing Engine and controller component that will switch from standby to active, assuming mastership when a failure brings down the active master Routing Engine.

### What Is a Routing Engine, Host Module, and Host Subsystem Redundancy

Redundant Routing Engines are two Routing Engines that are installed in the same routing platform. One functions as the master, while the other stands by as a backup should the master Routing Engine fail. (See “M10i Router Redundant Routing Engines and HCMs” on page 465 and “M20 Router Redundant Routing Engines and SSBs” on page 466.)

Redundant host modules are two Routing Engine and Miscellaneous Control Subsystem (MCS) pairs installed in the same routing platform. One pair functions as master, while the other stands by as a backup should the master Routing Engine fail. (See “M40e and M160 Router Redundant Host Modules” on page 467.)


Redundant host subsystems are two Routing Engine and Control Board pairs installed in the same routing platform. One pair functions as master, while the other stands by as backup should the master Routing Engine fail. (See “M320 Router, T320 Router, and T640 Routing Node Redundant Host Subsystems” on page 468.)

The M5, M10, M7i, and M40 routers do not support Routing Engine, host module, or host subsystem redundancy.

### M10i Router Redundant Routing Engines and HCMs

On the M10i router, the High-Availability Chassis Manager (HCM) works with its companion Routing Engine to provide control and monitoring functions for router components. The router can have one or two HCMs and Routing Engines. (See Figure 183 and “Redundancy Connection for an M10i Router” on page 470.)


**Figure 183: M10i Router Redundant Routing Engines and HCMs**



## M20 Router Redundant Routing Engines and SSBs

The M20 router can have one or two Routing Engines. The System and Switch Boards (SSBs) communicate with the Routing Engines. (See Figure 184 and “Redundancy Connection for an M20 Router” on page 471.)

**Figure 184: M20 Router Redundant Routing Engines and SSBs**






### M40e and M160 Router Redundant Host Modules

On M40e and M160 routers, the host module consists of a paired Routing Engine and MCS. One pair functions as master, while the other stands by as a backup should the master Routing Engine fail. (See Figure 185 and “Redundancy Connection for an M40e or M160 Router” on page 472.)


**Figure 185: M40e and M160 Router Redundant Host Modules**



### M320 Router, T320 Router, and T640 Routing Node Redundant Host Subsystems

On the M320 router, T320 router, and the T640 routing node, the host subsystem consists of a Routing Engine and Control Board functioning as a unit. Two host subsystems can be installed in each routing platform. One pair functions as master, while the other stands by as backup should the master Routing Engine fail. (See Figure 186, “Redundancy Connection for an M320 Router” on page 473, and “Redundancy Connection for a T320 Router and T640 Routing Node” on page 474.)

**Figure 186: M320 Router, T320 Router, and T640 Routing Node Redundant Host Subsystems**



g002294

## Routing Engine, Host Module, and Host Subsystem Redundancy Connections

---

It is important to understand how a redundant Routing Engine, redundant host module, or redundant subsystem communicates with its active counterparts to avoid severing the connection used for communication. Severing the connection can potentially trigger a failover protection.

For example, the M160 router active host module (the Routing Engine and the MCS) has the running configuration on it and communicates with the MCS, which in turn communicates with the Flexible PIC Concentrator (FPC) and the Switching and Forwarding Modules (SFMs). The host modules send keepalive messages to each other, checking the operating state. Each host module issues keepalive responses, letting the other host module know that it is up and operating. If keepalive responses are not returned to the standby host module (response times will vary depending upon the time settings specified in the **set chassis redundancy keepalive-time** statement), the standby host module can become the active host module. (See “Redundancy Connection for an M40e or M160 Router” on page 472.)

You also can configure failover on the router to switch mastership if a critical process fails. If a critical process on the active host module terminates, the standby host module routing becomes the active host module. You can configure processes for which this should happen. For example, you can use the **set interface-control failover other-routing-engine** statement at the [edit system processes] hierarchy level to configure failover for the interface control daemon.

For information about setting keepalive parameters, see “Configuring the Backup Routing Engine to Assume Mastership on Failure of Keepalives” on page 485.


This section includes the following information:

- Redundancy Connection for an M10i Router on page 470
- Redundancy Connection for an M20 Router on page 471
- Redundancy Connection for an M40e or M160 Router on page 472
- Redundancy Connection for an M320 Router on page 473
- Redundancy Connection for a T320 Router and T640 Routing Node on page 474

### Redundancy Connection for an M10i Router

Figure 187 shows the connection between the master and backup Routing Engines on an M10i router. Keepalive messages are sent between Routing Engines via the interconnected HCM switches. In this way, the master and the backup Routing Engines exchange state information.


**Figure 187: Redundancy Connection for an M10i Router**



### Redundancy Connection for an M20 Router

Figure 188 shows the connection between the master and backup Routing Engines on an M20 router. Keepalive messages are sent between the master and backup Routing Engine through the switch on the SSB. In this way, the master and the backup Routing Engines exchange state information.


**Figure 188: Redundancy Connection for an M20 Router**



### Redundancy Connection for an M40e or M160 Router

Figure 189 shows the connection between the master and backup host modules on an M40e or M160 router. Keepalive messages are sent from one Routing Engine to the other over the **fpx2** interface found across the Peripheral Component Interconnect (PCI) bridge. The keepalive message is received by the other host module via the **fpx1** interface. A keepalive response is sent back over the **fpx2** interface to the other Routing Engine. In this way, the master and the backup host modules exchange state information.


**Figure 189: Redundancy Connection for an M40e or M160 Router**



### Redundancy Connection for an M320 Router

Figure 190 shows the connection between the master and backup host subsystems on an M320 router. Keepalive messages are sent from the Routing Engine over the em0 interface. The keepalive message is forwarded to the other host subsystem via the bcm0 interface on the Control Board. A keepalive response is sent back over the em0 interface to the other Routing Engine. In this way, the master and the backup host subsystems exchange state information.

**Figure 190: Redundancy Connection for an M320 Router**



### Redundancy Connection for a T320 Router and T640 Routing Node

Figure 191 shows the connection between the master and backup host modules on a T320 router or a T640 routing node with a Routing Engine 600 (RE-600). Keepalive messages are sent from one Routing Engine to the other over the `fxp2` interface found on the Routing Engine. The keepalive message is received by the other host module via the `fpx1` interface. A keepalive message is sent back over the `fxp2` interface of the other Routing Engine. In this way, the master and the backup host subsystems exchange state information.

**Figure 191: Redundancy Connection for a T320 Router or T640 Routing Node (RE-600)**







Figure 192 shows the connection between the master and backup host modules on a T320 router or a T640 routing node with a Routing Engine 1600 (RE-1600).

**Figure 192: Redundancy Connection for a T320 Router or T640 Routing Node (RE-1600)**



## Determining Which Routing Engine You Are Logged In To

- Steps To Take**
1. Display Routing Engine Status on page 476
  2. Display the Router Hardware on page 476

## Step 1: Display Routing Engine Status

**Action** To determine which Routing Engine you are logged in to, use the following CLI command:

```
user@host> show chassis routing-engine
```

**Sample Output** user@host> show chassis routing-engine

```
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             29 degrees C / 84 degrees F
  DRAM                    2048 MB
  Memory utilization       11 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                 2 percent
    Interrupt              0 percent
    Idle                   98 percent
  Model                   RE-3.0
  Serial ID               P10865701859
  Start time              2004-04-15 18:45:12 UTC
  Uptime                  6 days, 3 hours, 56 minutes, 8 seconds

Routing Engine status:
Slot 1:
  Current state           Backup
  Election priority       Backup (default)
  Temperature             26 degrees C / 78 degrees F
  DRAM                    2048 MB
  Memory utilization       10 percent
  CPU utilization:
  [...]Output Truncated...
```

**What It Means** The output from the show chassis hardware command indicates that you are logged in to the master Routing Engine because this command can only be used on the master Routing Engine.

If you are not logged in to the master Routing Engine, you will see the following command output:

```
user@host> show chassis hardware
```

```
error: Aborted! This command can only be used on the master routing engine.
```

## Step 2: Display the Router Hardware

**Action** To determine which Routing Engine you are logged in to, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

```
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               65565         M320
Midplane      REV 05   710-009120   RB0662        M320 Midplane
FPM GBUS      REV 04   710-005928   HV7564        M320 Board
FPM Display   REV 05   710-009351   HY0996        M320 FPM Display
```

```

CIP                REV 04    710-005926    HV2440                M320 CIP
PEM 0              Rev 03    740-009148    QD17663              DC Power Entry Module
PEM 1              Rev 03    740-009148    QD17664              DC Power Entry Module
PEM 2              Rev 03    740-009148    QD17662              DC Power Entry Module
PEM 3              Rev 03    740-009148    QD16006              DC Power Entry Module
Routing Engine 0   REV 05    740-008883    P11123900322         RE-4.0
Routing Engine 1   REV 05    740-008883    P11123900311         RE-4.0
CB 0               REV 07    710-009115    HW8716               M320 Control Board
CB 1               REV 07    710-009115    HW8693               M320 Control Board
[...Output truncated...]

```

**What it Means** The output from the `show chassis hardware` command indicates that you are logged in to the master Routing Engine because this command can only be used on the master Routing Engine.

If you are not logged in to the master Routing Engine, you will see the following command output:

```
user@host> show chassis hardware
```

```
error: Aborted! This command can only be used on the master routing engine.
```

## Determining Routing Engine Mastership

**Steps To Take** To determine Routing Engine mastership, follow these steps:

1. Determine the Routing Engine Mastership By Checking Status on page 477
2. Determine Routing Engine Mastership By Checking the LEDs on page 478
3. Log In To Backup Routing Engine If graceful-switchover is Configured on page 478

### Step 1: Determine the Routing Engine Mastership By Checking Status

**Action** To determine Routing Engine mastership, use the following CLI command:

```
user@host> show chassis routing-engine
```

**Sample Output** user@host> `show chassis routing-engine`

```

Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             29 degrees C / 84 degrees F
  DRAM                    2048 MB
  Memory utilization      11 percent
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                2 percent
    Interrupt             0 percent
    Idle                  98 percent
  Model                  RE-3.0
  Serial ID              P10865701859

```

```

      Start time                2004-04-15 18:45:12 UTC
      Uptime                    6 days, 3 hours, 56 minutes, 8 seconds
Routing Engine status:
Slot 1:
  Current state                Backup
  Election priority            Backup (default)
  Temperature                  26 degrees C / 78 degrees F
  DRAM                        2048 MB
  Memory utilization           10 percent
  CPU utilization:
[...Output Truncated...]

```

**What It Means** The command output displays which Routing Engine is master (the one in Slot 0 RE0) and which is backup (the one in Slot 1 RE1) plus other hardware and operational status information.

## Step 2: Determine Routing Engine Mastership By Checking the LEDs

**Action** Physically check the LEDs on either the craft interface or the Routing Engine (depending on which chassis the Routing Engine is installed). The Routing Engine that displays an illuminated Master LED is the master Routing Engine. For the location and interpretation of LEDs, see “Monitoring the Routing Engine Status” on page 136.

## Step 3: Log In To Backup Routing Engine If graceful-switchover is Configured

If graceful-switchover is configured, the CLI command prompt will look as follows:

```

{backup}
user@host-re0>

{master}
user@host-re1>

```

With RE1 as master and RE0 as backup.

**Action** If you are logged in to the master Routing Engine, log in to the backup Routing Engine by using the following CLI command:

```
user@host> request routing-engine login other-routing-engine
```

**Sample Output**

```

user@host> request routing-engine login other-routing-engine
€Password: #####
{backup}
user@host-re0>

```

**What It Means** You are now logged in to the backup Routing Engine in slot RE0.

## Manually Configuring Master and Backup Routing Engines

For routers with two Routing Engines, you can configure which Routing Engine is the master and which is the backup. By default, the Routing Engine in slot 0 is the master (RE0) and the one in slot 1 is the backup (RE1).

To modify the default configuration, include the **routing-engine** statement at the [edit chassis redundancy] hierarchy level:

```
[edit chassis redundancy]
routing-engine slot-number (master | backup | disabled);
```

*slot-number* can be 0 or 1. To configure the Routing Engine to be the master, specify the **master** option. To configure it to be the backup, specify the **backup** option. To switch between the master and the backup Routing Engines, you must modify the configuration and then activate it by issuing the **commit** command.

The running state of a Routing Engine (master, backup, or disabled) is determined by mastership election upon system boot.

- **Master**—If a Routing Engine is configured as master, it has full functionality. It receives and transmits routing information, builds and maintains routing tables, communicates with interfaces and Packet Forwarding Engine components, and has full control over the chassis. Once a Routing Engine becomes master, it resets the switch plane (SSB, SCB, and SFM) and downloads its current version of the microkernel to the Packet Forwarding Engine components, guaranteeing software compatibility.
- **Backup**—If a Routing Engine is configured to be the backup, it does not maintain routing tables or communicate with Packet Forwarding Engine or chassis components. However, it runs through its memory check and boot sequence to the point of displaying a login prompt. A backup Routing Engine supports full management access through the Ethernet, console, and auxiliary ports, and can communicate with the master Routing Engine. Additionally, a backup Routing Engine responds to the Routing Engine **request chassis routing-engine master switch** command. The backup Routing Engine maintains a connection with the master Routing Engine and monitors the master Routing Engine. If the connection is broken, you can switch mastership by entering the **switchover** command. If the master Routing Engine is hot-swapped out of the system, the backup takes over control of the system as the new master Routing Engine. Once a Routing Engine becomes master, it resets the switch plane and downloads its own version of the microkernel to the Packet Forwarding Engine components.
- **Disabled**—A disabled Routing Engine has progressed through its memory check and boot sequence to the point of displaying a login prompt (similar to backup state) but does not respond to a **request chassis routing-engine master switch** command. A Routing Engine in disabled state supports full management access through the Ethernet, console, and auxiliary ports, and can communicate with the master Routing Engine. A disabled Routing Engine does not participate in a mastership election. To move from disabled state to backup state, the Routing Engine must be reconfigured to be the backup Routing Engine.

**Action** To configure RE1 to be the default master, issue the following CLI command in configuration mode at the [edit] hierarchy level:

For slot 0:

```
[edit]
user@host# set chassis redundancy routing-engine 1 master
```

```
[edit]
user@host# commit
```

For slot 1:

```
[edit]
user@host# set chassis redundancy routing-engine 0 backup
```

```
[edit]
user@host# commit
```

**Action** To view the Routing Engine mastership/backup status, use the following CLI command in operational mode:

```
user@host> show chassis routing-engine
```

**Sample Output**

```
user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state      Backup
  Election priority  Backup (default)
  Temperature        26 degrees C / 78 degrees F
  DRAM               2048 MB
  Memory utilization 12 percent
  CPU utilization:
    User             0 percent
    Background       0 percent
    Kernel           1 percent
    Interrupt        0 percent
    Idle             99 percent
  Serial ID          210929000142
  Start time         2004-05-12 13:14:30 PDT
  Uptime             5 days, 22 hours, 7 minutes, 9 seconds
  Load averages:    1 minute 5 minute 15 minute
                   0.07      0.02      0.00

Routing Engine status:
Slot 1:
  Current state      Master
  Election priority  Master (default)
  Temperature        27 degrees C / 80 degrees F
  DRAM               2048 MB
  Memory utilization 13 percent
  CPU utilization:
    User             0 percent
    Background       0 percent
    Kernel           0 percent
    Interrupt        0 percent
    Idle            100 percent
  Serial ID          210929000143
  Start time         2004-04-05 17:08:41 PDT
  Uptime             42 days, 18 hours, 12 minutes, 45 seconds
```

**What It Means** Each Routing Engine only checks its own configuration. Therefore, you must configure the redundancy settings on both Routing Engines correctly for the system to operate properly.

If both Routing Engines are configured as master, whichever Routing Engine comes up first will be the master. When the second Routing Engine comes up, it will try to assume mastership. However, the current master Routing Engine will reject this request, and the second Routing Engine will become the backup.

If both Routing Engines are configured as backup and come up after bootup, neither Routing Engine becomes master. The only way for either to become master is if one of the host module components (such as the Routing Engine) is physically removed, or if a Routing Engine has **failover on-loss-of-keepalives** configured and the connection between Routing Engines is interrupted for a period of time. The resulting timeout due to a loss of keepalives will force one of the Routing Engines to become the master. See “Configuring the Backup Routing Engine to Assume Mastership on Failure of Keepalives” on page 485 for more information.

## Manually Switching Routing Engine Mastership

---

**Action** To manually switch the Routing Engine mastership, use one of the following CLI commands.

- From the backup Routing Engine, request the backup Routing Engine to acquire mastership:

```
user@host> request chassis routing-engine master acquire
```

```
user@host> request chassis routing-engine master acquire
warning: Traffic will be interrupted while the PFE is re-initialized
Attempt to become the master routing engine ? [yes,no] (no)
```

```
Resolving mastership...
Complete. The local routing engine becomes the master.
```

- From the master Routing Engine, request the backup Routing Engine to acquire mastership:

```
user@host> request chassis routing-engine master release
```

```
user@host> request chassis routing-engine master release
```

```
Traffic will be interrupted while the PFE is re-initialized
Request the other routing engine become master ? [yes,no] (no)
```

```
Resolving mastership...
Complete. The other routing engine becomes the master.
```

- Switch mastership from either the backup or master Routing Engine:

```
user@host> request chassis routing-engine master switch
```

If graceful-switchover is not configured, the command output looks as follows:

```
user@host> request chassis routing-engine master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between routing engines ? [yes,no] (no) yes
```

```
Resolving mastership...
Complete. The local routing engine becomes the master.
```

```
user@host> request chassis routing-engine master switch
```

If graceful-switchover is configured the command output looks as follows:

```
Toggle mastership between routing engines ? [yes,no] (no) yes
```

```
Resolving mastership...
```

```
Complete. The other routing engine becomes the master.
```

**What It Means** When you enter the `request chassis routing-engine master acquire` command on the backup Routing Engine, you see the following:

```
warning: Traffic will be interrupted while the PFE is re-initialized
```

```
Attempt to become the master routing engine ? [yes,no] (no).
```

The master Routing Engine gives up control of the system bus and goes into the backup state. The backup Routing Engine becomes master and restarts the Packet Forwarding Engine. You can then diagnose the original master Routing Engine for problems or prepare it for upgrade or reconfiguration. When switchover occurs, the backup Routing Engine does not run through its full boot cycle (only the packet forwarding components run through a full boot cycle).

When you enter the `request chassis routing-engine master release` command on the master Routing Engine, the system passes mastership to the backup Routing Engine. The master Routing Engine gives up control of the system bus and goes into the backup state. The backup Routing Engine becomes master and restarts the Packet Forwarding Engine. You can then diagnose the original master Routing Engine for problems or prepare it for upgrade or reconfiguration.

In all cases, once the switchover occurs, the new master Routing Engine reestablishes routing adjacencies, populates the routing table, and transfers forwarding table information to the Packet Forwarding Engine. When Routing Engine mastership changes, the Packet Forwarding Engine components are rebooted to reestablish communication links and download the microkernel to each component. When this occurs, forwarding is interrupted and packet buffers are flushed.

## Determining Why Mastership Switched

---

Mastership can switch between the master Routing Engine and the backup Routing Engine for the following reasons:

- Hardware problems.
- The master Routing Engine is pulled.
- Software issues, such as a Routing Engine kernel crash.

**Action** View the log file `/var/log/mastership` for redundancy logging. This file contains hardware and software transitions to help debug auto-redundancy issues.

```
user@host> show log mastership
```



Table 107 lists the event codes that can be displayed in the mastership log.

**Table 107: Logging Events**

Event Code	Description
E_NULL = 0	The event is a null event.
E_CFG_M	The Routing Engine is configured as master.
E_CFG_B	The Routing Engine is configured as backup.
E_CFG_D	The Routing Engine is configured as disabled.
E_MAXTRY	The maximum number of tries to acquire or release mastership was exceeded.
E_REQ_C	A claim mastership request was sent.
E_ACK_C	A claim mastership acknowledgement was received.
E_NAK_C	A claim mastership request was not acknowledged.
E_REQ_Y	Confirmation of mastership is requested.
E_ACK_Y	Mastership is acknowledged.
E_NAK_Y	Mastership is not acknowledged.
E_REQ_G	A giveup mastership request was sent by a Routing Engine.
E_ACK_G	The Routing Engine acknowledges giveup of mastership.
E_CMD_A	The command <code>request chassis routing-engine master acquire</code> was issued from the backup Routing Engine.
E_CMD_F	Force switchover command was issued.
E_CMD_R	The command <code>request chassis routing-engine master release</code> was issued from the master Routing Engine.
E_CMD_S	The command <code>request chassis routing-engine master switch</code> was issued from a Routing Engine.
E_NO_ORE	No other Routing Engine is detected.
E_TMOUT	A request timed out.
E_NO_IPC	Routing Engine connection was lost.
E_ORE_M	Other Routing Engine state was changed to master.
E_ORE_B	Other Routing Engine state was changed to backup.
E_ORE_D	Other Routing Engine state was changed to disabled.

**Sample Output**

```

user@host> show log mastership
Jan 12 21:50:05 clear-log[865]: logfile cleared
Jan 12 21:50:18 failed to receive keepalives from other RE for the last 60 sec
Jan 12 21:50:23 failed to send RE info/keepalive: errno=22, total=6 in the last
20 sec
Jan 12 21:50:23 failed to send RE info/keepalive: errno=22, total=6 in the last
20 sec
Jan 12 21:50:34 event = E_CMD_R, state = master, param = 0x0 Jan 12 21:50:34
send "you are the master" request Jan 12 21:50:34 Failed to send RE mastership
cmd. err = 65 Jan 12 21:50:34 Currentstate: master NextState:giveup
reason_code: 1
Jan 12 21:50:34 timestamp: Wed Jan 12 21:50:34 2000
Jan 12 21:50:34 new state = giveup
Jan 12 21:50:36 event = E_TMOUT, state = giveup, param = 0x0 Jan 12 21:50:36
send "you are the master" request
Jan 12 21:50:36 Failed to send RE mastership cmd. err = 65 Jan 12 21:50:36

```

```

Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:36 new state = giveup
Jan 12 21:50:38 event = E_TMOUT, state = giveup, param = 0x0
Jan 12 21:50:38 send "you are the master" request
Jan 12 21:50:38 Failed to send RE mastership cmd. err = 65
Jan 12 21:50:38 Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:38 new state = giveup
Jan 12 21:50:40 failed to receive keepalives from other RE for the last 80 sec
Jan 12 21:50:41 event = E_TMOUT, state = giveup, param = 0x0
Jan 12 21:50:41 send "you are the master" request
Jan 12 21:50:41 Failed to send RE mastership cmd. err = 65
Jan 12 21:50:41 Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:41 new state = giveup
Jan 12 21:50:43 event = E_TMOUT, state = giveup, param = 0x0
Jan 12 21:50:43 send "you are the master" request
Jan 12 21:50:43 Failed to send RE mastership cmd. err = 65
Jan 12 21:50:43 Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:43 new state = giveup
Jan 12 21:50:46 failed to send RE info/keepalive: errno=35, total=7 in the last
20 sec
Jan 12 21:50:46 failed to send RE info/keepalive: errno=35, total=7 in the last
20 sec
Jan 12 21:50:46 event = E_TMOUT, state = giveup, param = 0x0
Jan 12 21:50:46 send "you are the master" request
Jan 12 21:50:46 Failed to send RE mastership cmd. err = 65
Jan 12 21:50:46 Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:46 new state = giveup
Jan 12 21:50:48 event = E_TMOUT, state = giveup, param = 0x0
Jan 12 21:50:48 send "you are the master" request
Jan 12 21:50:48 Failed to send RE mastership cmd. err = 65
Jan 12 21:50:48 Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:48 new state = giveup
Jan 12 21:50:50 event = E_TMOUT, state = giveup, param = 0x0
Jan 12 21:50:50 send "you are the master" request
Jan 12 21:50:50 Failed to send RE mastership cmd. err = 65
Jan 12 21:50:50 Currentstate: giveup NextState:giveup
    reason_code: 1
Jan 12 21:50:50 new state = giveup
Jan 12 21:50:53 event = E_MAXTRY, state = giveup, param = 0x0
Jan 12 21:50:53 Currentstate: giveup NextState:master
    reason_code: 1
Jan 12 21:50:53 timestamp: Wed
Jan 12 21:50:53 2000
Jan 12 21:50:53 new state = master
Jan 12 21:51:01 failed to receive keepalives from other RE for the last 100 sec
Jan 12 21:51:06 failed to send RE info/keepalive: errno=65, total=7 in the last
20 sec
Jan 12 21:51:06 failed to send RE info/keepalive: errno=65, total=7 in the last
20 sec
Jan 12 21:51:21 failed to receive keepalives from other RE for the last 120 sec
Jan 12 21:51:26 failed to send RE info/keepalive: errno=22, total=6 in the last
20 sec
Jan 12 21:51:26 failed to send RE info/keepalive: errno=22, total=6 in the last
20 sec

```

**What It Means** The beginning of the log shows that keepalives are not being responded to and the state of the Routing Engine changed from **master** to **giveup** after the **request chassis routing-engine master release** command was issued. However, the other Routing Engine is not taking over mastership because it is unreachable. Eventually a timeout (**E\_TMOUT**) occurs until the Routing Engine reaches the maximum number of attempts permitted (**E\_MAXTRY**). The output then shows the Routing Engine state changing from **giveup** back to **master**.

The output doesn't indicate why the mastership switchover did not work. However, it is clear that the backup Routing Engine is unreachable.

## Configuring the Backup Routing Engine to Assume Mastership on Failure of Keepalives

**Action** Configure the backup Routing Engine to automatically assume mastership if it detects a loss of keepalive responses with the **set chassis routing-engine** statement at the **[edit]** hierarchy level:

```
[edit]
user@host# set chassis redundancy failover on-loss-of-keepalives
```



**NOTE:** By default, a backup Routing Engine does not assume mastership when a loss of keepalive responses occurs.

**Sample Output**

```
[edit]
user@host# set chassis redundancy failover on-loss-of-keepalives

[edit]
user@host# set chassis redundancy keepalive-time 300

[edit]
user@host# commit
commit complete
```

**What it Means** The results of issuing this command on the backup Routing Engine are as follows:

- Every 20 seconds of keepalive loss, a message is added to the `/var/log/mastership` file.
- After **keepalive-time** passes, the backup Routing Engine attempts to claim mastership.
- When the backup Routing Engine claims mastership, it continues to be master even after the other Routing Engine configured as master has successfully resumed operation. Therefore, if the backup Routing Engine claims mastership, you must manually switch mastership.
- The default time before failover will occur is set to 300 seconds (5 minutes). You can change the default keepalive time period with the **set chassis redundancy keepalive-time *time-in-seconds*** command (the range for **keepalive-time** is from 2 to 10,000 seconds).
- Keepalive messages are sent every second.

## Avoiding Redundancy Problems

---

Problems with reliable redundancy are more often caused by poor management of software rather than by hardware failure. The following operating guidelines reduce the likelihood of significant downtime due to Routing Engine redundancy conflicts.

- Steps To Take**
1. Operate the Same Type of Routing Engine and JUNOS Software on page 486
  2. Use the Groups Configuration on page 486
  3. Synchronize Configurations on page 488
  4. Copy a Configuration File from One Routing Engine to Another on page 488
  5. Use the Proper Shutdown Process on a Backup Routing Engine on page 489

### Step 1: Operate the Same Type of Routing Engine and JUNOS Software

The active and standby Routing Engines must be the same type of Routing Engine and must operate the same version of JUNOS software; otherwise, anomalies in operation can occur.

### Step 2: Use the Groups Configuration

**Action** Apply a single configuration file to both Routing Engines using the **groups** *group-name* statement at the [edit] hierarchy level:

```
[edit]
user@host# set groups group-name
```

Where *group-name* is the name of the configuration group. To configure multiple groups, specify more than one *group-name*. On routers that support multiple Routing Engines, you can also specify two special group names:

- **re0**—Configuration statements that are applied to the Routing Engine in slot 0.
- **re1**—Configuration statements that are applied to the Routing Engine in slot 1.

The configuration specified in group **re0** is only applied if the current Routing Engine is in slot 0; likewise, the configuration specified in group **re1** is only applied if the current Routing Engine is in slot 1. Therefore, both Routing Engines can use the same configuration file, each using only the configuration statements that apply to it. Each **re0** or **re1** group contains at a minimum the configuration for the hostname and the management interface (**fxp0**). If each Routing Engine uses a different management interface, the group also should contain the configuration for the backup router and static routes.

To view the existing **groups** configuration, use the following CLI command in configuration mode:

```
[edit]
user@host# groups
user@host# show
```

**Sample Output**

```
[edit groups]
user@host# show
re0 {
    system {
        host-name foo-re0;
    }
    interfaces {
        fxp0 {
            unit 0 {
                family inet {
                    address 10.0.0.1/24;
                }
            }
        }
    }
}
re1 {
    system {
        host-name foo-re1;
    }
    interfaces {
        fxp0 {
            unit 0 {
                family inet {
                    address 10.0.0.2/24;
                }
            }
        }
    }
}
```

**What it Means** Use the already-existing **groups** statement, and use **re0** and **re1** as keyword group names. Each Routing Engine applies the slot-specific group configuration information to its configurations.

In the main configuration body, add the rest of the configuration that will be the same on both Routing Engines. Do not include the configuration statements that you made in the group configurations (such as configurations for **fxp0**). If you configure items in the body of the statement that also exist in the **groups** statement, the configuration in the body takes precedence—the configuration from the **group** statement will not be inherited.

**Action** Display the groups that were applied using the following configuration mode CLI command:

```
[edit]
user@host# show apply-groups
```

**Sample Output**

```
user@host# show apply-groups
apply-groups [ re0 re1 ];
```

### Step 3: Synchronize Configurations

**Action** Synchronize configurations between two Routing Engines using the `synchronize` statement at the `[edit]` hierarchy level:

```
[edit]
user@host# commit synchronize
```

**Sample Output**

```
[edit]
root# commit synchronize
re1: configuration check succeeds
re0: configuration check succeeds
re1: commit complete
re0: commit complete
```

**What it Means** When this statement is selected, the configuration file is copied to the other Routing Engine, followed by a load override and a `commit`. No user intervention is required.



**NOTE:** Both Routing Engines must be running JUNOS software Release 5.1 or higher. Use the `groups` statement to ensure that differences in the configurations for RE0 and RE1 are applied.

### Step 4: Copy a Configuration File from One Routing Engine to Another

**Action** You can copy a configuration file from one Routing Engine to another using the `file copy` command. The file is transferred through the internal Ethernet interface (FXP1 or FXP2, depending on the router):

```
user@host> file copy <source> <destination>
```



**NOTE:** Both Routing Engines must have jbase version 4.1 or higher loaded.

**Sample Output** Copy a file on RE0 to RE1:

```
user@re0> file copy /var/tmp/jinstall-6.0R3.3-domestic-signed.tgz
re1:/var/tmp1/
```

Check the result on RE1:

```
user@re1> file list /var/tmp/
.pccardd=
jbundle-5.5R3.1-domestic.tgz*
jinstall-6.0R3.3-domestic-signed.tgz
sampled.pkts
```

**What it Means** The file `jinstall-6.0R3.3-domestic-signed.tgz` is copied from RE0 to RE1.

### **Step 5: Use the Proper Shutdown Process on a Backup Routing Engine**

**Action** The `request system halt` command only shuts down the Routing Engine you are logged in to; the other Routing Engine is still running and may be performing file management or some other task that could create anomalies.

```
user@re0> request system halt
```

**Sample Output**

```
user@re0> request system halt
warning: This command will not halt the other routing-engine.
If planning to switch off power, use the both-routing-engines option.
Halt the system ? [yes,no] (no)

*** FINAL System shutdown message from root@utah ***
System going down IMMEDIATELY
```

```
shutdown: [pid 8669]
Shutdown NOW!
```

**What It Means** This command only shuts down the Routing Engine you are logged in to. To shut down both Routing Engines, use the `both-routing-engines` option or log in to the other Routing Engine and perform the shutdown again.





## Chapter 37

# Monitoring Redundant Routing Engines

You monitor redundant Routing Engines to ensure that system processes function normally, such as routing protocols, packet forwarding tables, router interfaces, system management, JUNOS software and file system storage, and monitoring functions. (See Table 108.)

This chapter describes how to monitor redundant Routing Engines. For more information about monitoring Routing Engines, see “Monitoring the Routing Engine” on page 125. See also the applicable router hardware installation guide.

**Table 108: Checklist for Monitoring Redundant Routing Engines**

Monitor Redundant Routing Engine Tasks	Command or Action
<b>Understanding Redundant Routing Engines on page 493</b>	
Redundant Routing Engine Characteristics on page 493	
■ M10i Router Routing Engine Redundancy on page 494	
■ M20 Router Routing Engine Redundancy on page 495	
■ M40e and M160 Router Routing Engine Redundancy on page 496	
■ M320 Router Routing Engine Redundancy on page 497	
■ T320 Router and T640 Routing Node Routing Engine Redundancy on page 498	
<b>Understanding the Redundant Routing Engine Configuration on page 500</b>	[edit] [edit chassis redundancy] show  or  show chassis redundancy
<b>Understanding Redundant Routing Engine Automatic Failover on page 501</b>	
<b>Understanding the Default Routing Engine Redundancy Behavior on page 501</b>	
<b>Displaying the Redundant Routing Engines Installed in the Router on page 502</b>	show chassis hardware  show chassis routing-engine
<b>Checking the Redundant Routing Engine Status on page 503</b>	See “Monitoring the Routing Engine Status” on page 136.
<b>Displaying Redundant Routing Engine Mastership and Backup on page 503</b>	show chassis routing-engine
<b>Displaying Redundant Routing Engine Errors on page 504</b>	show log mastership

Monitor Redundant Routing Engine Tasks	Command or Action
<b>Manually Switching from Master to Backup Routing Engine on page 504</b>	request chassis routing-engine master release request chassis routing-engine master switch
<b>Replacing a Redundant Routing Engine on page 506</b>	See “Removing a Routing Engine” on page 161.

- See Also**
- Monitoring the Host Module on page 341
  - Monitoring the Routing Engine on page 125
  - Monitoring the MCS on page 359
  - Host Redundancy Overview on page 463
  - Monitoring Redundant MCSs on page 567
  - Monitoring Redundant Control Boards on page 559

## Understanding Redundant Routing Engines

<b>Purpose</b>	Inspect redundant Routing Engines to minimize system process failures.
<b>What Are Redundant Routing Engines</b>	Redundant Routing Engines are two Routing Engines that are installed in the same router. One functions as the master, while the other stands by as a backup should the master Routing Engine fail. By default, the Routing Engine in slot 0 is the master (RE0) and the one in slot 1 is the backup (RE1).

### Redundant Routing Engine Characteristics

Table 109 describes redundant Routing Engine characteristics for routing platforms.

**Table 109: M-series Platform Redundant Routing Engine Characteristics**

Component	M10i	M20	M40	M40e	M160	M320	T320/ T640
Redundant Routing Engine	X	X					
Redundant host modules with Routing Engine and MCS				X	X		
Redundant host subsystems with Routing Engine and Control Board						X	
Redundant host modules with Routing Engine and Control Board							X

The following sections describe the various routing platform Routing Engines:


- M10i Router Routing Engine Redundancy on page 494
- M20 Router Routing Engine Redundancy on page 495
- M40e and M160 Router Routing Engine Redundancy on page 496
- M320 Router Routing Engine Redundancy on page 497
- T320 Router and T640 Routing Node Routing Engine Redundancy on page 498

## M10i Router Routing Engine Redundancy

The M10i router has redundant Routing Engines. The M10i router has one Routing Engine in slot **RE0** and another in slot **RE1** (see Figure 193). By default, the Routing Engine in slot **RE0** is the master and the one in slot **RE1** is the backup. If one Routing Engine fails, the other one assumes the routing functions.

The M10i router Routing Engine faceplate has LEDs that indicate redundant Routing Engine operating status and mastership. (See “Check the M10i Router Routing Engine LEDs” on page 139.)

**Figure 193: M10i Router Redundant Routing Engine**




## M20 Router Routing Engine Redundancy

The M20 router has one Routing Engine in slot RE0 and another in slot RE1 (see Figure 194). By default, the Routing Engine in slot RE0 is the master and the one in slot RE1 is the backup. If one Routing Engine fails, the other one assumes the routing functions.

The M20 router Routing Engine panel has LEDs that indicate redundant Routing Engine operating status and mastership. The craft interface also has LEDs that indicate redundant Routing Engine status and mastership. (See “Check the M20 Router Routing Engine LEDs” on page 140.)

**Figure 194: M20 Router Redundant Routing Engine**




## M40e and M160 Router Routing Engine Redundancy

The M40e and M160 routers have redundant Routing Engines that are components of the host module (see Figure 195). The host module consists of a Routing Engine and a Miscellaneous Control Subsystem (MCS). You can install two host modules in the M40e and M160 routers. For more information about monitoring redundant MCSs, see “Monitoring Redundant MCSs” on page 567.

Both the Routing Engine and the MCS must be installed for the host module to function. When two host modules are installed in the router, both are powered on, but only one is the master; the second host module is the backup and performs no functions. By default, the master host module has components installed in slots RE0 and MCS0; the backup host module has components installed in slots RE1 and MCS1.

The M40e and M160 router craft interface LEDs indicate the Routing Engine operating status and mastership. (See “Check the M40e and M160 Router Routing Engine LEDs” on page 143.)

**Figure 195: M40e and M160 Router Redundant Routing Engines**



1689

## M320 Router Routing Engine Redundancy


The M320 router has a redundant Routing Engine that is a component of the host subsystem (see Figure 196). The host subsystem consists of a Routing Engine and a Control Board. Two host subsystems can be installed in the M320 router. For more information about monitoring redundant Control Boards, see “Monitoring Redundant Control Boards” on page 559.

Both the Routing Engine and the Control Board must be installed for the host subsystem to function. When two host subsystems are installed in the router, both are powered on, but only one is the master; the second host subsystem is the backup and performs no functions. By default, the master host module has components installed in slots RE0 and CB0; the backup host module has components installed in slots RE1 and CB1. The Routing Engines are hot-pluggable.

The M320 router craft interface LEDs indicate the Routing Engine operating status and mastership. (See “Check the M320 Router Routing Engine LEDs” on page 144.)

**Figure 196: M320 Router Redundant Routing Engines**

M320 router rear



### ***T320 Router and T640 Routing Node Routing Engine Redundancy***

Figure 197 shows the T320 router redundant Routing Engines that are components of the host subsystem.

**Figure 197: T320 Router Routing Engines**







Figure 198 shows the T640 routing node redundant Routing Engines that are components of the host subsystem.

**Figure 198: T640 Routing Node Routing Engines**

T640 router rear



The host subsystem consists of a Routing Engine and a Control Board. You can install two host subsystems in the T320 router and T640 routing node. For more information about monitoring redundant Control Boards, see “Monitoring Redundant Control Boards” on page 559.

Both the Routing Engine and the Control Board must be installed for the host subsystem to function. When two host subsystems are installed in the router, both are powered on, but only one is the master; the second host subsystem is the backup and performs no functions. By default, the master host subsystem has components installed in slots **RE0** and **CB0**; the backup host module has components installed in slots **RE1** and **CB1**. If one Routing Engine physically fails, the other one assumes the routing functions. If a software failure occurs, the other backup Routing Engine assumes routing functions if some preliminary configuration has been done. For more information, see “Host Redundancy Overview” on page 463.

The T320 router and T640 routing node craft interface LEDs indicate the Routing Engine operating status and mastership. (See “Check the T320 Router Routing Engine LEDs” on page 144 and “Check the T640 Routing Node Routing Engine LEDs” on page 145.)

## Understanding the Redundant Routing Engine Configuration

For routers with redundant Routing Engines, you can configure a master and backup Routing Engine. By default, the Routing Engine in slot **RE0** is the master, and the Routing Engine in slot **RE1** is the backup. Once configured, you can specify the Routing Engine to assume mastership automatically if it detects loss of the keepalive signal from the master. You can configure Routing Engine redundancy in the JUNOS software command-line interface (CLI) configuration mode at the **[edit chassis redundancy]** hierarchy level.



**NOTE:** We recommend that both Routing Engines have the same configuration. When changing the configuration on a Routing Engine, commit it to both Routing Engines using the **commit synchronize** statement at the **[edit]** hierarchy level. For more information about synchronizing configurations, see “Host Redundancy Overview” on page 463.

You can configure redundant Routing Engine automatic failover for the backup Routing Engine with a specified failover time. By default, automatic failover is disabled. To enable it, include the **failover on-loss-of-keepalives** statement at the **[edit chassis redundancy]** hierarchy level. By default, failover will occur after 300 seconds (5 minutes) unless a different time is specified. The failover time is indicated by the **keepalive-timesecs** statement at the **[edit chassis redundancy]** hierarchy level. The range for the keepalive time is from 2 to 10,000 seconds.

To display the current Routing Engine redundancy configuration, follow these steps:

1. Enter the CLI configuration mode using the following command:

```
user@host# configure
```

2. From the **[edit chassis redundancy]** hierarchy level, show the configuration using the following command:

```
user@host# show
```

**Alternative Action** To display the current Routing Engine configuration, you can also use the following CLI command:

```
user@host> show chassis redundancy
```

**Sample Output**

```
user@host> show chassis redundancy
routing-engine 0 master;
routing-engine 1 backup;
failover on-loss-of-keepalives;
keepalive-time 300;
```

## Understanding Redundant Routing Engine Automatic Failover

---

If the keepalive time is configured for 2 seconds, the sequence of events is as follows:

1. After 2 seconds of keepalive loss, a message is logged.
2. After 2 seconds of keepalive loss, the backup Routing Engine attempts to assume mastership. An alarm is generated whenever the backup Routing Engine is active, and the display is updated with the current status.
3. Once the backup Routing Engine assumes mastership, it continues to function as master even after the originally configured master Routing Engine has successfully resumed operation. You must manually restore it to its previous backup status. However, if at any time one of the Routing Engines is not present, the other Routing Engine becomes master automatically, regardless of how redundancy is configured.

## Understanding the Default Routing Engine Redundancy Behavior

---

By default, the JUNOS software uses RE0 as the master Routing Engine and RE1 as the backup Routing Engine. Unless otherwise specified in the configuration, RE0 will always assume mastership if the acting master Routing Engine is rebooted.

To see how the default Routing Engine redundancy setting works, follow these steps:



**WARNING:** Do not try this procedure on a production network.

1. Make sure the router is running on RE0 as the master Routing Engine (see “Displaying Redundant Routing Engine Mastership and Backup” on page 503).
2. To manually switch the state of the Routing Engine mastership, use the **request chassis routing-engine master** command. RE0 is now the backup Routing Engine and RE1 is the master Routing Engine. If you use this command to change the master Routing Engine, and then restart the chassis software for any reason, the master reverts to the default setting. For information about switching Routing Engine mastership, see the **request chassis routing-engine master** command in the *JUNOS Protocols, Class of Service, and System Basics Command Reference*.



**NOTE:** On the next reboot of the master Routing Engine, the JUNOS software returns the router to the default state because you have not configured the Routing Engines to maintain this state after a reboot.

3. Reboot the master Routing Engine RE1. When you do this, the Routing Engine boots up and reads the configuration. If you have not specified in the configuration which Routing Engine is the master, RE1 uses the default configuration as the backup. Now both RE0 and RE1 are in a backup state. The JUNOS software detects this conflict and, to prevent a no-master state, reverts to the default configuration with RE0 assuming mastership.

## Displaying the Redundant Routing Engines Installed in the Router

**Action** To determine whether a router has redundant Routing Engines, use the following CLI command:

```
user@host> show chassis hardware
```



**NOTE:** If the `show chassis hardware` CLI command displays no hardware information, check to see which Routing Engine you are logged in to. If you are logged in to the backup Routing Engine, no hardware information is displayed or there are errors.

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis                               22196         M20
Backplane        REV 07   710-001517   AL2873
Power Supply A   REV 04   740-001466   001043         DC
Power Supply B   REV 04   740-001466   000671         DC
Display         REV 04   710-001519   AJ7282
Host 0                               c800000749a9db01 Present
Host 1                               9a00000749b14301 Present
[...Output truncated...]
```

**What It Means** The command output displays the Routing Engine slot number, revision level, part number, serial number, and type.

**Alternative Action** To display more detailed information about the Routing Engines installed in a router, use the following CLI command:

```
user@host> show chassis routing-engine
```

```
user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state           Master
  Election priority       Master (default)
  Temperature             29 degrees C / 84 degrees F
  DRAM                    768 Mbytes
  CPU utilization:
    User                  0 percent
    Background            0 percent
    Kernel                 1 percent
    Interrupt              0 percent
    Idle                   98 percent
  Serial ID               c800000749a9db01
  Start time              2002-06-18 13:53:12 UTC
  Uptime                  70 days, 52 minutes, 40 seconds
  Load averages:         1 minute  5 minute  15 minute
                        0.08      0.02      0.01

Routing Engine status:
Slot 1:
  Current state           Backup
  Election priority       Backup (default)
  Temperature             30 degrees C / 86 degrees F
  DRAM                    805306368 Mbytes
```

```

CPU utilization:
  User          0 percent
  Background    0 percent
  Kernel        0 percent
  Interrupt     0 percent
  Idle          99 percent
Serial ID       9a00000749b14301
Start time     2002-06-18 13:54:05 UTC
Uptime         70 days, 51 minutes, 50 seconds

```

## Checking the Redundant Routing Engine Status

---

**Action** For more information about monitoring Routing Engine status, see “Monitoring the Routing Engine Status” on page 136.

## Displaying Redundant Routing Engine Mastership and Backup

---

**Action** To display which Routing Engine is master and backup, use the following CLI command:

```
user@host> show chassis routing-engine
```

**Sample Output**

```

user@host> show chassis routing-engine
Routing Engine status
Slot 0
  Current state: Master
  Election priority: Master
  Temperature      41 C / 105 degrees F
  DRAM             765 Mbytes
  CPU utilization
    User          0 percent
    Background    0 percent
    Kernel        0 percent
    Interrupt     0 percent
    Idle          100 percent
  Serial ID       39000004f8bdec01
  Start time     2000-01-04 22:02:58 UTC
  Uptime         14 hours, 45 minutes, 40 seconds
  Load averages   1 minute  5 minute 15 minute
                  0.05      0.04      0.01

Slot 1
  Current state   Backup
  Election priority Backup (default)
  Temperature     41 C / 105 degrees F
[...Output truncated...]

```

**What It Means** The command output shows the status of the Routing Engines: RE0 is Master and RE1 is Backup.

**Alternative Actions** You can also use the `show chassis environment routing-engine` command; for more information see “Monitoring the Routing Engine Status” on page 136. The **Current State** field indicates which Routing Engine is master and which is backup.

For M40e and M160 routers, you can also use the `show chassis craft-interface` command. The command output shows the master and backup Routing Engine LED status; for more information, see “Monitoring the Routing Engine Status” on page 136.

## Displaying Redundant Routing Engine Errors

---

**Action** To view redundancy log messages, use the following CLI command:

```
user@host> show log mastership
```

**Sample Output**

```
user@host> show log mastership
[...Output truncated...]
May 13 11:18:31 RE mastership msg error: subtype 52
May 13 11:18:32 failed to receive loss of keepalives from other RE for the last
20 sec
[...Output truncated...]
```

**What It Means** The `/var/log/mastership` file records error messages from redundancy logging. The file records the time of the message and a description of the message. A message is logged after 20 seconds of keepalive loss.

## Manually Switching from Master to Backup Routing Engine

---

**Action** To manually switch from master to backup Routing Engine, or to force the backup Routing Engine to become master, use the following CLI command:

```
user@host> request chassis routing-engine master release
```

You can also use the following CLI command:

```
user@host> request chassis routing-engine master switch
```

For routers with multiple Routing Engines only, you can control which Routing Engine is the master.



**WARNING:** For routers that have two Routing Engines, both Routing Engines must be running JUNOS Release 4.0 or later. Do not run JUNOS Release 3.4 on one of the Routing Engines and Release 4.0 on the other. JUNOS software Release 3.4 does not support Routing Engine redundancy. If you are using this release of the software, only one Routing Engine can be installed in either slot in the router.

By default, the Routing Engine in slot 0 (RE0) is the master and the Routing Engine in slot 1 (RE1) is the backup. To change the default master Routing Engine, include the `routing-engine` statement at the `[edit chassis redundancy]` hierarchy level in the configuration. For more information, see the *JUNOS System Basics Configuration Guide*.

When you force the backup Routing Engine to become the master Routing Engine with the `request chassis routing-engine master` command and then restart the chassis software for any reason, the master reverts to the default setting.



**NOTE:** The configurations on the two Routing Engines do not have to be the same, and they are not automatically synchronized. If you configure both Routing Engines as masters, when the chassis software restarts for any reason, the Routing Engine in slot 0 becomes the master and the Routing Engine in slot 1 becomes the backup.

We recommend making both configurations the same.

When both Routing Engines have the same configuration and come up at the same time, the Routing Engine in slot 0 takes precedence over the Routing Engine in slot 1. Table 110 indicates which Routing Engine becomes master based on the configuration of both Routing Engines.

**Table 110: Routing Engine Mastership Election**

Slot 0 Configuration				
		Master	Backup	Disabled
Slot 1 Configuration	Master	Slot 0: master Slot 1: backup	Slot 0: backup Slot 1: master	Slot 0: disabled Slot 1: master
		Slot 0: master Slot 1: backup	Slot 0: master Slot 1: backup	Slot 0: disabled Slot 1: master
	Backup	Slot 0: master Slot 1: disabled	Slot 0: master Slot 1: disabled	Slot 0: disabled Slot 1: disabled
		Slot 0: master Slot 1: disabled	Slot 0: master Slot 1: disabled	Slot 0: disabled Slot 1: disabled
	Disabled	Slot 0: master Slot 1: disabled	Slot 0: master Slot 1: disabled	Slot 0: disabled Slot 1: disabled
		Slot 0: master Slot 1: disabled	Slot 0: master Slot 1: disabled	Slot 0: disabled Slot 1: disabled

**Sample Output** The following command output displays when you attempt to have the backup Routing Engine become master:

```
user@m20-host> request chassis routing-engine master acquire
```

```
warning: Traffic will be interrupted while the PFE is re-initialized
```

```
warning: The other routing engine's file system could be corrupted
Reset other routing engine and become master ? [yes,no] (no)
```

The following command output displays when you switch the mastership from the master Routing Engine to the backup:

```
user@m20-host-0> request chassis routing-engine master switch
```

```
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between Routing Engines ? [yes,no] (no) yes
```

```
Resolving mastership...
```

```
Complete. The other Routing Engine becomes the master.
```

```
root@m20-host-0>
```

The following command output displays when you switch the mastership from the backup to the master Routing Engine:

```
root@m20-host-0> request chassis routing-engine master switch

warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between routing engines ? [yes,no] (no) yes

Resolving mastership...
Complete. The local routing engine becomes the master.
root@m20-host-0>
```

**What It Means** The command output indicates that traffic will be interrupted during the Routing Engine mastership switch process. The command output confirms whether you really want to continue with the mastership switch process, and indicates when the mastership switch process is complete.

**Syntax** `request chassis routing-engine master <acquire <no-confirm>| release | switch>`

`acquire`—(Optional) Attempt to become the master Routing Engine.

`no-confirm`—(Optional) Do not request confirmation.

`release`—(Optional) Request the other Routing Engine to become the master.

`switch`—(Optional) Toggle mastership between Routing Engines.

## Replacing a Redundant Routing Engine

---

If you have a router with two Routing Engines and you want to shut the power off to the router or remove a Routing Engine, you must first halt the backup Routing Engine (if it has been upgraded), then halt the master Routing Engine. To halt a Routing Engine, issue the `request system halt` command. You can also halt both Routing Engines at the same time by issuing the `request system halt both-routing-engines` command.



**NOTE:** When you halt both Routing Engines, a message displays to press Enter to restart or to halt. If you press Enter on the master Routing Engine to restart, it will restart. However the backup Routing Engine will not restart. It will wait at the message to restart or to halt. You then have to press Enter on the console of the backup Routing Engine for it to restart.

**Action** To replace a redundant Routing Engine, see “Removing a Routing Engine” on page 161.



## Chapter 38

# Monitoring Redundant Power Supplies

You monitor and maintain redundant power supplies to ensure that power is distributed to the router components without interruption. (See Table 111.)

**Table 111: Checklist for Monitoring Redundant Power Supplies**

Monitor Redundant Power Supply Tasks	Command or Action
<b>Understanding Redundant Power Supplies on page 508</b>	
■ M5/M10 Router Redundant Power Supplies on page 508	
■ M7i Router Redundant Power Supplies on page 509	
■ M10i Router Redundant Power Supplies on page 510	
■ M20 Router Redundant Power Supplies on page 511	
■ M40 Router Redundant Power Supplies on page 512	
■ M40e Router Power Supplies nand Location on page 513	
■ M160 Router Redundant Power Supplies on page 515	
■ M320 Router Redundant Power Supplies on page 516	
■ T320 Router Redundant Power Supplies on page 517	
■ T640 Routing Node Redundant Power Supplies on page 518	
<b>Displaying Redundant Power Supplies Installed In The Router on page 519</b>	show chassis hardware
<b>Checking the Redundant Power Supply Status on page 521</b>	For more information about monitoring power supplies, see “Checking the Power Supply Status” on page 230.
<b>Checking for Power Supply Alarms on page 521</b>	For more information about checking for power supply alarms, see “Checking for Power Supply Alarms” on page 235.
<b>Verifying Power Supply Failure on page 521</b>	
<b>Getting Power Hardware Information on page 521</b>	For more information about removing a power supply, see “Replacing the Power Supplies” on page 250.
<b>Replacing a Power Supply on page 521</b>	

**See Also** ■ Monitoring Power Supplies on page 217

## Understanding Redundant Power Supplies

**Purpose** Inspect redundant power supplies to ensure that they distribute power to the other router components according to their voltage requirements.

**What Are Redundant Power Supplies** With redundant power supplies, two power supplies are installed in a router and perform load sharing during normal operation. When one power supply fails or is switched off, the other power supply immediately and automatically assumes the entire electrical load. Table 112 lists some router characteristics for each M-series router platform type.

The power supplies are internally connected to the midplane, which delivers the power input from the circuit breaker box and distributes the different output voltages produced by the power supplies to the router's components, depending on their voltage requirements.


**Table 112: Router Power Supply Characteristics Per Routing Platform**

Power Supply Characteristic	M5/ M10	M7i/ M10i	M20	M40	M40e	M160	M320	T320	T640
Number. of power supplies	2	2/4	2	2	2	2	4	2	2
Watts per AC/DC power supply	434 W	AC 293 W DC DC 293 W	750 W	1500 W	AC 2900 W DC 3000 W	DC original 2600 W DC enhanced 3200 W	AC 1750 W DC 2000 W	3200 W DC enhanced 3200 W	6500W DC enhanced 3200 W
Supports both AC and DC power supplies	Yes	Yes	Yes	Yes	Yes	No; original or enhanced DC only	Yes	No DC only	No DC only

### M5/M10 Router Redundant Power Supplies

Two load-sharing, isolated power supplies are located at the bottom rear of the M5 and M10 router chassis. The routers use either AC or DC power. Figure 199 shows the M5 and M10 router power supplies and where they are installed in the chassis.

**Figure 199: M5 and M10 Router Redundant Power Supplies**



When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supply instantly begins providing all the power the router needs for normal functioning and can provide full power indefinitely.



**NOTE:** Mixing AC and DC power supplies is not supported. The two power supplies must be either both AC or both DC.

When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)


### M7i Router Redundant Power Supplies

Two load-sharing, isolated power supplies are located at the bottom rear of the M7i router chassis. The router uses either AC or DC power. Figure 200 shows the M7i router power supplies and where they are installed in the chassis.

When the power supplies are installed and operational, they automatically share the electrical load.

For full redundancy, two power supplies are required. If a power supply stops functioning for any reason, the second power supply instantly begins providing all the power the router needs for normal functioning. The second power supply can provide full power indefinitely.

**Figure 200: M7i Router Redundant Power Supplies**



**NOTE:** When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)


## M10i Router Redundant Power Supplies

The M10i router uses either AC or DC power. You can install up to four load-sharing power supplies at the bottom rear of the chassis. Figure 201 shows the M10i router power supplies and where they are installed in the chassis.

The AC power supplies are fully redundant. If one power supply fails or is removed, the remaining power supplies instantly assume the entire electrical load. Two power supplies can provide full power for as long as the router is operational. Three power supplies are required for redundancy. Power supplies must be present in slots P/S 0 and P/S 1 for the router to operate.

The DC power supplies are fully redundant. The DC power supplies in slots P/S 0 and P/S 1 can provide full power to the router. Likewise, the DC power supplies in slots P/S 2 and P/S 3 can also provide full power. The DC power supplies in slots P/S 2 and P/S 3 jointly serve as the backup to the DC power supplies in slots P/S 0 and P/S 1. Power supplies must be present in slots P/S 0 and P/S 1 for the router to operate.

**Figure 201: M10i Router Redundant Power Supplies**



**NOTE:** AC and DC power supplies are required in slots P/S 0 and P/S 1 for the router to operate.

The DC power supplies in slots P/S 0 and P/S 1 must be powered by dedicated power feeds derived from feed A, and the DC power supplies in slots P/S 2 and P/S 3 must be powered by dedicated power feeds derived from feed B. This configuration provides the commonly deployed A/B feed redundancy for the system.

## M20 Router Redundant Power Supplies

Two load-sharing, isolated power supplies are located at the bottom rear of the M20 router chassis. The router uses either AC or DC power. Figure 202 shows the M20 router power supplies and where they are installed in the chassis.


When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supplies instantly begin providing all the power the router needs for normal functioning, and can provide full power indefinitely.



**NOTE:** Mixing AC and DC power supplies is not supported. The two power supplies must be either both AC or both DC.

When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers and on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)

**Figure 202: M20 Router Redundant Power Supplies**




## M40 Router Redundant Power Supplies

The M40 router can use either AC or DC power. Two load-sharing power supplies install into the bays located at the bottom rear of the chassis. As viewed from the rear of the chassis, the supply on the left is referred to as supply A and the supply on the right as supply B. Figure 203 shows the M40 router power supplies and where they are installed in the chassis.

The power supplies are fully redundant. When both power supplies are operational, they automatically share the electrical load. If one power supply stops functioning for any reason, the remaining power supply instantly begins providing all the power the router needs for normal functioning, and can provide full power indefinitely.

**Figure 203: M40 Router Redundant Power Supplies**



1765

### **M40e Router Power Supplies and Location**

The M40e router uses either AC or DC power. Two load-sharing, pass-through power supplies are located at the bottom rear of the chassis. Figure 204 on page 514 shows the M40e router power supplies and where they are installed in the chassis.




When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supplies instantly begin providing all the power the router needs for normal functioning, and can provide full power indefinitely.



---

**NOTE:** Mixing AC and DC power supplies is not supported and prevents the router from booting. If two power supplies are installed, they must be either both AC or both DC.

- A circuit breaker box must be installed on a DC-powered router, while a circuit breaker is incorporated into each AC power supply. Converting the router from AC to DC power or vice versa involves removing or installing the circuit breaker box. Only authorized service personnel should perform the conversion: this manual does not include instructions.
  - When two power supplies are installed, at least one Routing Engine and one FPC must also be installed for both power supplies to power on. In the absence of this minimum load, only one power supply starts. (The router powers on and operates correctly with one power supply, but without the redundancy benefit of having a second power supply installed.)
-

**Figure 204: M40e Router Redundant Power Supplies****AC power supply****DC power supply**

1766




**M160 Router Redundant Power Supplies**

The M160 router uses DC power. Two load-sharing, pass-through power supplies are located at the bottom rear of the chassis. Figure 205 shows the M160 router power supplies and where they are installed in the chassis.

When the power supplies are installed and operational, they automatically share the electrical load. If a power supply stops functioning for any reason, the remaining power supplies instantly begin providing all the power the router needs for normal functioning, and can provide full power indefinitely.

**Figure 205: M160 Router Redundant Power Supplies**




## M320 Router Redundant Power Supplies

The M320 router uses either AC or DC power. Figure 206 shows the M320 router power supplies and where they are installed in the chassis.

**Figure 206: M320 Router Redundant Power Supplies**

M320 router rear



The M320 router supports four power supplies. The AC power supplies are fully redundant. If one power supply fails or is removed, the remaining power supplies instantly assume the entire electrical load. Three power supplies can provide full power for as long as the router is operational.

In the M320 router DC power supply configuration, the router has four DC power supplies, located at the lower rear of the chassis in slots PEM0 through PEM3 (top to bottom). The DC power supplies in slots PEM0 and PEM2 are load-sharing and provide power to the Flexible PIC Concentrators (FPCs) in slots FPC3 through FPC7. The DC power supplies in slots PEM1 and PEM3 are load-sharing and provide power to the FPCs in slots FPC0 through FPC2, Switch Interface Boards (SIBs), Control Boards, and Routing Engines. All DC power supplies provide power to the fan trays.



**NOTE:** The DC power supplies in slots PEM0 and PEM1 must be powered by dedicated power feeds derived from feed A, and the DC power supplies in slots PEM2 and PEM3 must be powered by dedicated power feeds derived from feed B. This configuration provides the commonly deployed A/B feed redundancy for the system.




**NOTE:** Each power supply must be connected to a dedicated AC power feed and a dedicated 15 A (250 VAC) circuit breaker.

### T320 Router Redundant Power Supplies


Figure 207 shows the T320 router power supplies and where they are installed in the chassis.

**Figure 207: T320 Router Redundant Power Supplies Location**

T320 router rear



DC power supply




g002106

## T640 Routing Node Redundant Power Supplies

Figure 208 shows the T640 routing node power supplies and where they are installed in the chassis.

**Figure 208: T640 Routing Node Redundant Power Supplies**



**See Also** ■ Monitoring Power Supplies on page 217

## Displaying Redundant Power Supplies Installed In The Router

**Action** To display hardware information about the redundant power supplies installed in a router, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output** For M5, M10, M20, M40, and M40e routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               2003          M20
Backplane     REV 07   710-001517   AA7940
Power Supply A Rev 02   740-001465   000497         AC
Power Supply B Rev 01   740-001465   000001         AC
```

For M7i routers:

```
user@host> show chassis hardware

user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               19127         M7i
Midplane     REV 02   710-008761   CA0201
Power Supply 1 Rev 04   740-008537   PD10284         AC
[...Output truncated...]
```

For M10i routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               M10i
Midplane     REV 02   710-008920   CA0353
Power Supply 0 Rev 04   740-008537   PE18594         AC
Power Supply 1 Rev 04   740-008537   PE18611         AC
Power Supply 2 Rev 04   740-008537   PE18617         AC
Power Supply 3 Rev 04   740-008537   PE18633         AC
[...Output truncated...]
```

For M160 routers:

```
user@host> show chassis hardware
Item          Version  Part number  Serial number  Description
Chassis                               47           M160
Midplane     REV 02   710-001245   AB4113
FPM CMB      REV 01   710-001642   AA9721
FPM Display  REV 01   710-001647   AA2995
CIP          REV 02   710-001593   AA9886
PEM 0        Rev 01   740-001243   KJ35782         DC
PEM 1        Rev 01   740-001243   kj35756         DC
[...Output truncated...]
```

For M320 routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               19206         M320
Midplane      REV 01   710-009120   RA1277
FPM GBUS      REV 02   710-005928   HL7863
FPM Display   REV 01   710-009351   HP8406
CIP           REV 02   710-005926   BE1813
PEM 0
PEM 1         Rev X1   740-009148   0000005
Routing Engine 0 REV 01   740-008883   212047100102 RE-4.0
Routing Engine 1 REV 01   740-008883   212047100107 RE-4.0
CB 0          REV 01   710-009115   HK0109
CB 1          REV 01   710-009115   HK0110
FPC 0         REV 01   710-008994   HP1418         FPC Type 1
  CPU         REV 01   710-009141   HL7870
  PIC 0       REV 04   750-001894   HE5409         1x G/E, 1000 BASE-SX
  PIC 1       REV 01   750-010240   CB5373         1x G/E SFP, 1000 BASE
  SFP 0       REV 01   740-007326   P11EAW5        SFP-SX
  PIC 3       REV 02   750-002332   AG1661         1x COC12, SMIR
SIB 0         REV 03   750-004762   HL9370         SIB-I-M
SIB 1         REV 03   710-009184   HP8459         SIB-I-M
```

For T320 routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               27714         T320
Midplane      REV 07   710-004339   BF3538
FPM GBUS      REV 04   710-004461   BF5649
FPM Display   REV 04   710-002897   BE9730
CIP           REV 06   710-002895   BF0739
PEM 1         Rev 01   740-004359   NB12576        Power Entry Module
```

For T640 routing nodes:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               55056         T640
Midplane      REV 01   710-005608   BE0888
FPM GBUS      REV 08   710-002901   RA0151
FPM Display   REV 04   710-002897   RA0135
CIP           REV 06   710-002895   HF8317
PEM 0         Rev 06   740-002595   NM17794        Power Entry Module
PEM 1         Rev 04   740-002595   NE15421        Power Entry Module
[...Output truncated...]
```

**What It Means** For all routers except the M160 router, T320 router, and T640 routing node, the command output displays the power supply slot number, revision level, part number, serial number, and the power supply type.

For the M160 router, T320 router, and the T640 routing node, the command output displays the power supply or Power Entry Module (PEM) slot number, revision level, part number, serial number, and power supply type. When facing the back of the router, PEM0 is located on the right and PEM1 is located on the left.

## Checking the Redundant Power Supply Status

---

**Action** For more information about monitoring power supplies, see “Checking the Power Supply Status” on page 230.

## Checking for Power Supply Alarms

---

**Action** For more information about checking for power supply alarms, see “Checking for Power Supply Alarms” on page 235.

## Verifying Power Supply Failure

---

**Action** For more information about verifying power supply failure, see “Verifying Power Supply Failure” on page 239.

## Getting Power Hardware Information

---

**Action** For more information about displaying power supply hardware information, see “Getting Power Supply Hardware Information” on page 241.

## Replacing a Power Supply

---

**Action** For more information about replacing a power supply, see “Replacing a Power Supply” on page 521





## Chapter 39

# Monitoring Redundant Cooling System Components

You monitor and maintain redundant cooling system components to keep an acceptable operating temperature for the router chassis and its components. (See Table 113.)

**Table 113: Checklist for Monitoring Redundant Cooling System Components**

Monitor Redundant Cooling System Component Tasks	Command or Action
<b>Understanding Redundant Cooling System Components on page 524</b>	
■ M5 and M10 Router Redundant Cooling System Components on page 525	
■ M7i Router Redundant Cooling System Components on page 526	
■ M10i Router Redundant Cooling System Components on page 527	
■ M20 Router Redundant Cooling System Components on page 527	
■ M40 Router Redundant Cooling System Components on page 529	
■ M40e and M160 Router Redundant Cooling System Components on page 531	
■ M320 Router Redundant Cooling System Components on page 533	
■ T320 Router Redundant Cooling System Components on page 534	
■ T640 Routing Node Redundant Cooling System Components on page 537	
<b>Displaying Redundant Cooling System Components on page 539</b>	show chassis environment
<b>Checking the Redundant Cooling System Status on page 541</b>	See “Checking the Cooling System Status” on page 267.
<b>Checking the Redundant Cooling System Alarms on page 541</b>	See “Checking the Cooling System Alarms” on page 269 and “Display the Current Router Alarms” on page 61.
<b>Removing a Cooling System Component on page 541</b>	See “Replacing a Cooling System Component” on page 273.
<b>Returning Redundant Cooling System Components on page 541</b>	See “Return the Failed Component” on page 86, or follow the procedure in appropriate router hardware guide.

## Understanding Redundant Cooling System Components

**Purpose** Inspect the router redundant cooling system components to ensure that air is flowing through the router to cool the components installed in the router chassis. If the router temperature exceeds a critical level, the router automatically shuts down.

**What Are Redundant Cooling System Components** Redundant cooling system components are more than just one fan or impeller installed in a router to ensure that the air is flowing through the router and that an acceptable temperature is maintained to cool the components installed in the chassis.

Table 114 describes the redundant cooling system components and characteristics for each routing platform.

**Table 114: Redundant Cooling System Components Characteristics Per Routing Platform**

Cooling System Component	M5 and M10	M7i	M10i	M20	M40	M40e	M160	M320/T320 /T640
Fan tray	1 fan tray with 4 fans	1	2	3 front 1 rear		1	1 lower	2 front 1 rear
Power supply integrated fan	–	–	–	2	2	–	Cooled by air flowing through the chassis	Cooled by air flowing through the chassis
Impellers	–	–	–	–	2 pairs	1 central 1 rear upper 1 rear lower	1 upper 2 rear	–
Fan assemblies	–	–	–	–	3	–	–	–
Air filter	–	–	–	–	1	1	1	1 front 1 rear

The following sections describe the various routing platform cooling systems:

- M5 and M10 Router Redundant Cooling System Components on page 525
- M7i Router Redundant Cooling System Components on page 526
- M10i Router Redundant Cooling System Components on page 527
- M20 Router Redundant Cooling System Components on page 527
- M40 Router Redundant Cooling System Components on page 529
- M40e and M160 Router Redundant Cooling System Components on page 531
- M320 Router Redundant Cooling System Components on page 533
- T320 Router Redundant Cooling System Components on page 534
- T640 Routing Node Redundant Cooling System Components on page 537

### M5 and M10 Router Redundant Cooling System Components

The M5 and M10 router cooling system consists of a fan tray containing four fans that inserts into the left side of the chassis (left fans 1 through 4). The fan tray connects to the router midplane and provides side-to-side cooling. (See Figure 209.)


The fan tray is hot-removable and hot-insertable. You can remove and replace these components without powering down the system and disrupting routing functions.

The cooling system is fault-tolerant. The router can tolerate the failure of a single fan for approximately 36 hours. If a fan fails, the router issues a yellow alarm and the yellow alarm LED on the craft interface lights. If the router temperature exceeds the critical level, the router automatically shuts down.



**CAUTION:** Do not operate the router for more than 1 minute without a fan tray.

**Figure 209: M5 and M10 Router Cooling System and Airflow**



1768

## M7i Router Redundant Cooling System Components

The M7i router cooling system consists of a fan tray containing four individually fault-tolerant fans. The fan tray inserts into the left side of the chassis (left fans 1 through 4) and connects directly to the router midplane. If a single fan fails, the remaining fans continue to function indefinitely. The fan tray provides side-to-side cooling. (See Figure 210.)


The fan tray is hot-removable and hot-insertable. You can remove and replace these components without powering down the system and disrupting routing functions.

The cooling system is fault-tolerant. The router can tolerate the failure of a single fan for approximately 36 hours. If a fan fails, the router issues a yellow alarm and the yellow alarm LED on the craft interface lights. If the router temperature exceeds the critical level, the router automatically shuts down.



**CAUTION:** Do not operate the router for more than 1 minute without a fan tray.

**Figure 210: M7i Router Cooling System and Airflow**




### M10i Router Redundant Cooling System Components

The M10i router cooling system consists of two fan trays, located along the left and right side of the chassis, that provide side-to-side cooling (see Figure 211). They connect directly to the router midplane. Each fan tray is a single unit containing eight individually fault-tolerant fans. If a single fan fails, the remaining fans continue to function indefinitely. For proper airflow, the primary fan tray should be installed in slot 1 (the left slot looking at the chassis from the rear) and must be installed for proper cooling at all times. The redundant fan tray, if present, should be installed in slot 0 on the right. This fan tray provides additional cooling and redundancy. The fan tray is hot-removable and hot-insertable.



**CAUTION:** Do not remove both fan trays for more than one minute while the router is operating. The fans are the sole source of cooling, and the router will overheat when they are absent.

**Figure 211: M10i Router Cooling System Components and Airflow**



### M20 Router Redundant Cooling System Components


The M20 router cooling system includes:

- Three front fan trays—Cool the Flexible PIC Concentrators (FPCs) and the System and Switch Board (SSB). These fan trays are located on the left front side of the chassis.
- One rear fan tray—Cools the Routing Engine. This fan tray is located immediately to the right of the Routing Engine.
- Power supply integrated fan—A built-in fan cools each power supply.

The four fan trays plug directly into the router midplane and work together to provide side-by-side cooling.


The fans operate in unison to maintain an acceptable operating temperature for the Routing Engine and midplane. Each cooling subsystem maintains a separate airflow, and each is monitored independently for temperature control. Figure 212 shows the M20 router cooling system components and airflow.

**Figure 212: M20 Router Cooling System and Airflow**



Both front and rear fan trays are hot-removable and hot-insertable. You can remove and replace these components without powering down the system and disrupting routing functions. Figure 213 shows the M20 router cooling system components.

**Figure 213: M20 Router Cooling System Components**



## M40 Router Redundant Cooling System Components

The M40 router cooling system consists of three separate subsystems (see Figure 214):

- Impellers—Two redundant pairs of impellers (top impeller and bottom impeller) cool the Packet Forwarding Engine components (backplane, System Control Board [SCB], FPCs, and Physical Interface Cards [PICs]). During normal operation, both pairs of impellers function at less than full capacity.
- Triple fan assemblies—Three load-sharing fans cool the backplane and the Routing Engine (rear left fan, rear center fan, and rear right fan).
- Power supply integrated fan—A built-in fan cools each power supply.

Each cooling subsystem maintains a separate airflow, and each is monitored independently for temperature control. Figure 214 shows the M40 router cooling system airflow.

Temperature sensors on the backplane, the SCB, and the FPCs control the speed of the impellers. Impeller failure triggers the red alarm LED on the craft interface. If the temperature passes a certain threshold, the JUNOS software turns off the power supplies.

The M40 router is designed to run normally with all three fans sharing the load equally and running at half speed.

**Figure 214: M40 Router Cooling System and Airflow**




Figure 215 shows the M40 router cooling system impeller trays.

**Figure 215: M40 Router Impeller Trays**





Figure 216 shows the M40 router air filter and fan tray.

**Figure 216: M40 Router Air Filter and Fan Tray**





### M40e and M160 Router Redundant Cooling System Components

The M40e and M160 routers include the following cooling system components:

- Front cooling subsystem—Cools the FPCs, PICs, and midplane. It includes a fan tray located behind the cable management system and a large, central impeller behind the craft interface (fan tray front left, fan tray front right, fan tray rear left, fan tray rear right, and front top blower).
- Rear cooling subsystem—Cools the Switching and Forwarding Modules (SFMs), host module, PFE Clock Generators (PCGs), and power supplies. It includes one impeller located at the upper right of the chassis rear and another at the lower left, as shown in Figure 217 (rear top blower and rear bottom blower). The upper and lower impellers are not interchangeable.

Figure 217 shows the M40e and M160 router cooling system components and airflow.

**Figure 217: M40e and M160 Router Cooling System and Airflow**






Figure 218 shows the M40e and M160 router cooling system components.

**Figure 218: M40e and M160 Router Cooling System Components**


**M40e and M160 router front**




**M40e and M160 router front**




**M40e and M160 router rear**



**M40e router rear**



**M160 router rear**



**See Also** ■ Monitoring Power Supplies on page 217

### M320 Router Redundant Cooling System Components

The M320 router includes the following cooling system components:

- Two front fan trays
- Front air filter
- Rear fan tray
- Rear air filter

The cooling system components work together to keep all router components within the acceptable temperature range. All fan trays and filters are hot-insertable and hot-removable. The two front fan trays are interchangeable. The front and rear fan trays are not interchangeable.

Figure 219 shows the M320 router cooling system airflow.

**Figure 219: M320 Router Cooling System and Airflow**





Figure 220 shows the M320 router cooling system components.

**Figure 220: M320 Router Cooling System Components**



The host subsystem monitors the temperature of the router components. When the router is operating normally, the fans function at lower than full speed. If a fan fails or the ambient temperature rises above a threshold, the speed of the remaining fans is automatically adjusted to keep the temperature within the acceptable range. If the ambient maximum temperature specification is exceeded and the system cannot be adequately cooled, the Routing Engine shuts down some or all of the hardware components.


### **T320 Router Redundant Cooling System Components**

The T320 router cooling system includes:

- Two front fan trays
- Front air filter
- Rear fan tray
- Rear air filter

The cooling system components work together to keep all router components within the acceptable temperature range (see Figure 221 on page 535). All fan trays and filters are hot-insertable and hot-removable. The two front fan trays are interchangeable. The front and rear fan trays are not interchangeable.


**Figure 221: T320 Router Cooling System and Airflow**



The cooling system has redundant components, which are controlled by the host subsystem. If one of the fans fails, the host subsystem increases the speed of the remaining fans to provide sufficient cooling for the router indefinitely.

The host subsystem monitors the temperature of the router components. When the router is operating normally, the fans function at lower than full speed. If a fan fails, the speed of the remaining fans is automatically adjusted to keep the temperature within the acceptable range. Cooling system components can be removed and replaced without powering down or disconnecting power to the router. Figure 222 shows the T320 router cooling system components.

**Figure 222: T320 Router Cooling System Components**



g003283


## T640 Routing Node Redundant Cooling System Components

The T640 routing node cooling system includes:

- Two front fan trays
- Front air filter
- Rear fan tray
- Rear air filter

The cooling system components work together to keep all router components within the acceptable temperature range (see Figure 223). All fan trays and filters are hot-insertable and hot-removable. The two front fan trays are interchangeable. The front and rear fan trays are not interchangeable.

**Figure 223: T640 Routing Node Cooling System and Airflow**




The cooling system has redundant components, which are controlled by the host subsystem. If one of the fans fails, the host subsystem increases the speed of the remaining fans to provide sufficient cooling for the router indefinitely.


The host subsystem monitors the temperature of the router components. When the router is operating normally, the fans function at lower than full speed. If a fan fails, the speed of the remaining fans is automatically adjusted to keep the temperature within the acceptable range. Cooling system components can be removed and replaced without powering down or disconnecting power to the router. Figure 224 on page 538 shows the T640 routing node cooling system components.

**Figure 224: T640 Routing Node Cooling System Components**

Front



Rear





## Displaying Redundant Cooling System Components

**Action** To display the redundant cooling system components that are installed in a routing platform, use the following command-line interface (CLI) command:

```
user@host> show chassis environment
```

**Sample Output** For M5 and M10 routers (see also Figure 209 on page 525):

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Fans  Left Fan 1            OK        Spinning at normal speed
      Left Fan 2            OK        Spinning at normal speed
      Left Fan 3            OK        Spinning at normal speed
      Left Fan 4            OK        Spinning at normal speed
Misc  Craft Interface        OK
```

For an M7i router (see also Figure 210 on page 526):

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Fans  Fan 1                  OK        Spinning at normal speed
      Fan 2                  OK        Spinning at normal speed
      Fan 3                  OK        Spinning at normal speed
      Fan 4                  OK        Spinning at normal speed
```

For an M10i router (see also Figure 211 on page 527):

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Fans  Fan Tray 0 Fan 1        OK        Spinning at normal speed
      Fan Tray 0 Fan 2        OK        Spinning at normal speed
      Fan Tray 0 Fan 3        OK        Spinning at normal speed
      Fan Tray 0 Fan 4        OK        Spinning at normal speed
      Fan Tray 0 Fan 5        OK        Spinning at normal speed
      Fan Tray 0 Fan 6        OK        Spinning at normal speed
      Fan Tray 0 Fan 7        OK        Spinning at normal speed
      Fan Tray 0 Fan 8        OK        Spinning at normal speed
      Fan Tray 1 Fan 1        OK        Spinning at normal speed
      Fan Tray 1 Fan 2        OK        Spinning at normal speed
      Fan Tray 1 Fan 3        OK        Spinning at normal speed
      Fan Tray 1 Fan 4        OK        Spinning at normal speed
      Fan Tray 1 Fan 5        OK        Spinning at normal speed
      Fan Tray 1 Fan 6        OK        Spinning at normal speed
      Fan Tray 1 Fan 7        OK        Spinning at normal speed
      Fan Tray 1 Fan 8        OK        Spinning at normal speed
```

For an M20 router (see also Figure 212 on page 528):

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Fans  Rear Fan                OK        Spinning at normal speed
      Front Upper Fan        OK        Spinning at normal speed
      Front Middle Fan       OK        Spinning at normal speed
      Front Bottom Fan       OK        Spinning at normal speed
Misc  Craft Interface        OK
```

For an M40 router (see also Figure 214 on page 529):

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Fans  Top Impeller           OK        Spinning at normal speed
      Bottom impeller      OK        Spinning at normal speed
      Rear Left Fan        OK        Spinning at normal speed
      Rear Center Fan      OK        Spinning at normal speed
      Rear Right Fan       OK        Spinning at normal speed
Misc  Craft Interface       OK
```

For M40e and M160 routers (see also Figure 217 on page 531):

```
user@host> show chassis environment
Class Item                Status    Measurement
[...Output truncated...]
Fans  Rear Bottom Blower     OK        Spinning at normal speed
      Rear Top Blower      OK        Spinning at normal speed
      Front Top Blower     OK        Spinning at normal speed
      Fan Tray Rear Left   OK        Spinning at normal speed
      Fan Tray Rear Right  OK        Spinning at normal speed
      Fan Tray Front Left  OK        Spinning at normal speed
      Fan Tray Front Right OK        Spinning at normal speed
Misc  CIP                     OK
```

For an M320 router (see also Figure 219 on page 533):

```
user@host> show chassis environment
Class Item                Status    Measurement
Fan    Top Left Front fan      OK        Spinning at normal speed
      Top Right Rear fan   OK        Spinning at normal speed
      Top Right Front fan  OK        Spinning at normal speed
      Top Left Rear fan    OK        Spinning at normal speed
      Bottom Left Front fan OK        Spinning at normal speed
      Bottom Right Rear fan OK        Spinning at normal speed
      Bottom Right Front fan OK        Spinning at normal speed
      Bottom Left Rear fan OK        Spinning at normal speed
      Rear Fan 1 (TOP)     OK        Spinning at normal speed
      Rear Fan 2           OK        Spinning at normal speed
      Rear Fan 3           OK        Spinning at normal speed
      Rear Fan 4           OK        Spinning at normal speed
      Rear Fan 5           OK        Spinning at normal speed
      Rear Fan 6           OK        Spinning at normal speed
      Rear Fan 7 (Bottom)  OK        Spinning at normal speed
```

For T320 routers and T640 routing nodes (see also Figure 221 on page 535, Figure 222 on page 536, Figure 223 on page 537, and Figure 224 on page 538):

```
user@host> show chassis environment
Class Item                Status    Measurement
Fans  Top Left Front fan      OK        Spinning at normal speed
      Top Left Middle fan  OK        Spinning at normal speed
      Top Left Rear fan    OK        Spinning at normal speed
      Top Right Front fan  OK        Spinning at normal speed
      Top Right Middle fan OK        Spinning at normal speed
      Top Right Rear fan   OK        Spinning at normal speed
      Bottom Left Front fan OK        Spinning at normal speed
      Bottom Left Middle fan OK        Spinning at normal speed
      Bottom Left Rear fan OK        Spinning at normal speed
      Bottom Right Front fan OK        Spinning at normal speed
```

Bottom Right Middle fan	OK	Spinning at normal speed
Bottom Right Rear fan	OK	Spinning at normal speed
Fourth Blower from top	OK	Spinning at normal speed
Bottom Blower	OK	Spinning at normal speed
Middle Blower	OK	Spinning at normal speed
Top Blower	OK	Spinning at normal speed
Second Blower from top	OK	Spinning at normal speed

**What It Means** The command output shows the fans, impellers, or blowers monitored for the router type. The command output displays the fan, impeller, or blower status and the spinning speed. The status can be **OK**, **Testing** (during initial power-on), **Failed**, or **Absent**. Measurement indicates if the fan or impeller is spinning at normal or high speed.

## Checking the Redundant Cooling System Status

---

**Action** For more information about checking the status of cooling system components, see “Checking the Cooling System Status” on page 267.

## Checking the Redundant Cooling System Alarms

---

**Action** For more information about checking the cooling system alarms, see “Checking the Cooling System Alarms” on page 269. For more information about conditions that trigger cooling system alarms, see “Display the Current Router Alarms” on page 61.

## Removing a Cooling System Component

---

For more information about removing or swap testing cooling system components, see “Replacing a Cooling System Component” on page 273.

## Returning Redundant Cooling System Components

---

**Action** To return a cooling system component, see “Return the Failed Component” on page 86 or the appropriate router hardware guide.



## Chapter 40

# Monitoring Redundant SIBs

You monitor and maintain redundant Switch Interface Boards (SIBs) installed in the M320 and T320 routers and the T640 Internet routing node to ensure that there is no interruption of switching function to the destination Flexible PIC Concentrator (FPC). The SIBs create the switch fabric, providing up to a total of 640 million packets per second (Mpps) of forwarding.

Table 115 provides a checklist of tasks for you to perform to monitor redundant SIBs.

**Table 115: Checklist for Monitoring Redundant SIBs**

Monitor Redundant SIB Tasks	Command or Action
<b>Understanding Redundant SIBs on page 544</b>	
■ M320 Router SIBs on page 546	
■ T320 Router SIBs on page 546	
■ T640 Routing Node SIBs on page 546	
<b>Displaying Redundant SIB Hardware Information on page 547</b>	show chassis hardware
<b>Displaying SIB Redundancy Information on page 547</b>	show chassis sib show chassis environment sib
<b>Monitoring Redundant SIB Status on page 548</b>	See “Monitoring the SIB Status” on page 329.
<b>Displaying SIB Alarms on page 548</b>	See “Monitoring the SIB Status” on page 329
<b>Performing a Swap Test on a SIB on page 549</b>	See “Verifying SIB Failure” on page 334.
<b>Returning the SIB on page 549</b>	Locate the serial number label on the left side of the SIB top panel, and follow the procedure “Return the Failed Component” on page 86. Or follow the procedure in the appropriate router hardware guide.

## Understanding Redundant SIBs

---

**Purpose** Inspect redundant SIBs to ensure that they provide the switching function to the destination FPCs.

**What Are Redundant SIBs** Redundant SIBs are multiple SIBs that are installed in the M320 router, T320 router, and the T640 routing node. In the event of a failure, one of the SIBs acts as backup for the failed SIB. For more information, see “SIB Location and Redundancy” on page 545.

Table 116 shows the SIB characteristics for the M320 router, T320 router, and the T640 routing node.


**Table 116: SIB Packet Forwarding Characteristics**

Routing Platform	Million Packets per Second (Mpps) Forwarding	Number of SIBs per Chassis	Redundancy
M320	385	4	No
T320	320	3	Yes
T640	640	5	Yes

## SIB Location and Redundancy

Figure 225 shows the location of the SIBs in the M320 router, T320 router, and T640 routing node.

**Figure 225: M320 Router, T320 Router, and T640 Routing Node SIB Location**



The following sections describe SIB redundancy on various routing platforms:

- M320 Router SIBs on page 546
- T320 Router SIBs on page 546
- T640 Routing Node SIBs on page 546

### **M320 Router SIBs**

Four SIBs are installed in the M320 router. The SIBs are located at the center rear of the chassis in the slots labeled **SIB0** through **SIB3** (top to bottom). (See Figure 225 on page 545.) All four SIBs are active, and there is no backup.

### **T320 Router SIBs**

Three SIBs are installed in the router. The SIBs are located at the center rear of the chassis in the slots labeled **SIB0** through **SIB2**. (See Figure 225 on page 545.)

Each FPC has a dedicated ASIC with five high-speed links that connect to the SIBs. Two high-speed links connect to **SIB1** and **SIB2**. One high-speed link connects to **SIB0**. **SIB0** acts as a backup to **SIB1** and **SIB2**. In the event of a complete SIB failure, **SIB0** will become active. Because **SIB0** has only one high-speed link to each FPC, only three links will remain active. A slight degradation in forwarding capacity may occur. When the failed SIB is replaced, it will become active and **SIB0** will revert to backup. The router will regain full forwarding capacity.

### **T640 Routing Node SIBs**

Five SIBs are installed in the routing node. The SIBs are located at the center rear of the chassis in the slots labeled **SIB0** through **SIB4** (top to bottom). (See Figure 225 on page 545.)

Each FPC1 and FPC2 has a dedicated ASIC with five high-speed links that connect to the SIBs (one link per SIB). An FPC3 has two dedicated ASICs, and each ASIC has five high-speed links that connect to the SIBs (a total of 10 links). One of the five SIBs—usually **SIB4**—acts as a backup to the remaining four SIBs. In the event of a SIB failure, the backup SIB becomes active and traffic forwarding continues without any degradation. When the failed SIB is replaced, it becomes the new backup.

The SIBs are hot-insertable and hot-removable.

- See Also**
- Monitoring the Host Subsystem on page 289
  - Monitoring the SIBs on page 325



## Displaying Redundant SIB Hardware Information

**Action** To display the redundant SIB hardware information, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Item          Version  Part number  Serial number  Description
Chassis
[...Output truncated...]
SIB 0          REV 05    710-003980   HF9603         SIB-I8
SIB 1          REV 05    710-003980   HF9577         SIB-I8
SIB 2          REV 05    710-003980   HF9540         SIB-I8
SIB 3          REV 05    710-003980   HF9550         SIB-I8
SIB 4          REV 05    710-003980   HF9592         SIB-I8
```

**What it Means** The command output is for a T640 routing node. The command output displays the SIB slot number, revision level, part number, serial number, and description. By default, SIB0 is the redundant SIB.

## Displaying SIB Redundancy Information

**Action** To display the redundant SIB state, use the following CLI command:

```
user@host> show chassis sib
```

**Sample Output**

```
t320@host> show chassis sibs
Slot  State          Uptime
0     Spare
1     Online          2 days, 7 hours, 10 minutes, 13 seconds
2     Online          2 days, 7 hours, 10 minutes, 13 seconds

t640@host> show chassis sibs
Slot  State          Uptime
0     Spare
1     Online          4 hours, 5 minutes, 47 seconds
2     Online          4 hours, 5 minutes, 42 seconds
3     Online          4 hours, 5 minutes, 37 seconds
4     Online          4 hours, 5 minutes, 33 seconds
```

**What it Means** The command output is for a T320 router and a T640 routing node. On the T320 router, SIB1 and SIB2 are active (Online), while SIB0 is backup (Spare). On the T640 routing node, SIB1, SIB2, SIB3, and SIB4 are active, while SIB0 is the backup. The possible states are Spare, Online, Offline, or Empty. The command output also displays how long each SIB has been online in hours, minutes, and seconds.

**Alternative Action** You can also view redundant SIB status by using the following CLI command:

```
user@host> show chassis environment sib
```

```
user@host> show chassis environment sib
```

```

SIB 0 status:
State          Spare
Temperature    44 degrees C / 111 degrees F
Power:
  GROUND       0 mV
  1.8 V        1807 mV
  2.5 V        2478 mV
  3.3 V        3308 mV
  1.8 V bias   1797 mV
  3.3 V bias   3284 mV
  5.0 V bias   5018 mV
  8.0 V bias   7440 mV
SIB 1 status:
State          Online
Temperature    50 degrees C / 122 degrees F
Power:
  GROUND       0 mV
  1.8 V        1814 mV
  2.5 V        2485 mV
1.8 V bias     1794 mV
  3.3 V bias   3313 mV
  5.0 V bias   5028 mV
  8.0 V bias   7553 mV
SIB 2 status:
[...Output truncated...]
SIB 3 status:
[...Output truncated...]
SIB 4 status:
[...Output truncated...]

```

The command output displays the SIB slot, status, and the temperature of the air flowing past the SPP card and the power source information. Notice that SIB0 status is displayed as **Spare**, or backup.

You can display the environmental status of a particular SIB with the following CLI command:

```
user@host> show chassis environment sib slot
```

## Monitoring Redundant SIB Status

---

**Action** To monitor the SIB status, see “Monitoring the SIB Status” on page 329.

## Displaying SIB Alarms

---

**Action** To display SIB alarms, see “Displaying SIB Alarms” on page 332.

## Performing a Swap Test on a SIB

---

SIBs are hot-insertable and hot-removable.

**Action** To perform a swap test on a SIB, see “Verifying SIB Failure” on page 334.

## Returning the SIB

---

**Action** To return a SIB, locate the serial number label on the left side of the SIB top panel, then follow the procedure “Return the Failed Component” on page 86. You can also refer to the procedure to return a field-replaceable unit in the M320 router, T320 router, or the T640 routing node hardware guide.



## Chapter 41

# Monitoring Redundant SCGs

You monitor and maintain redundant SONET Clock Generators (SCGs) installed in the T320 router and the T640 routing node to ensure that there is no interruption of function. SCGs provide a clock signal for SONET/SDH, and select a clock signal from any Flexible PIC Concentrator (FPC), or from the external clock inputs.

Table 117 lists the tasks you perform to monitor redundant SCGs.

**Table 117: Checklist for Monitoring the Redundant SCG**

Monitor SCG Tasks	Command or Action
<b>Understanding Redundant SCGs on page 552</b>	
<b>Displaying Redundant SCG Hardware Information on page 553</b>	show chassis hardware
<b>Monitoring Redundant SCG Status on page 553</b>	
1. Monitor the Redundant SCG Environmental Status on page 553	show chassis environment show chassis environment scg
2. Display the Redundant SCG LED States at the Command Line on page 555	show chassis craft-interface
3. View the Redundant SCG LEDs on page 555	Remove the rear component cover and look on the SCG faceplate at the back of the T320 router or T640 routing node chassis.
<b>Displaying Redundant SCG Mastership on page 555</b>	
1. Display the SCG Master and Standby from the Craft Interface Output on page 556	show chassis craft-interface
2. View the SCG LEDs on page 556	Remove the rear component cover and look on the SCG faceplate at the rear of the T320 router or T640 routing node chassis.
<b>Performing a Swap Test on a Redundant SCG on page 556</b>	
	1. Take the SCG offline. request chassis scg offline slot number
	2. Replace the SCG with one that you know works.
	3. Bring the SCG online. request chassis scg offline slot number
	4. Verify the SCG status. request chassis scg offline slot number
<b>Returning the SCG on page 557</b>	See “Return the Failed Component” on page 86, or follow the procedure in the M40e or M160 router hardware guide.

## Understanding Redundant SCGs

**Purpose** Inspect redundant SCGs to ensure that they provide a clock signal for the SONET/SDH interfaces on the router and that they select a clock signal from any FPC, or from the external clock inputs.


**What Are Redundant SCGs** Two SCGs are installed in the T320 router and the T640 routing node. The SCGs install into the upper rear of the chassis in the slots labeled **SCG0** and **SCG1**.

If both SCGs are installed and functioning normally, **SCG0** is master and **SCG1** is backup. Removing the backup SCG does not affect the functioning of the routing node. Taking the master SCG offline can result in a brief loss of SONET clock lock while the backup SCG becomes master.

The SCGs are hot-pluggable.

Figure 226 shows the location of the SCGs on the T320 router and the T640 routing node.

**Figure 226: T320 Router and T640 Routing Node Redundant SCG Location**



**See Also**

- Monitoring the Host Subsystem on page 289
- Monitoring Redundant SCGs on page 551

## Displaying Redundant SCG Hardware Information

**Action** To display the redundant SCG hardware information, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis
Midplane         REV 01   710-004339   AY4529
FPM GBUS         REV 02   710-004461   AY4511
FPM Display      REV 02   710-002897   HF6094
CIP              REV 05   710-002895   HC0468
PEM 1            Rev 01   740-004359   2708013        Power Entry Module
SCG 0            REV 06   710-004455   AY4526
SCG 1            REV 06   710-004455   AY4523
```

**What It Means** The command output displays the SCG slot number, revision level, part number, and serial number.

## Monitoring Redundant SCG Status

**Steps To Take** To monitor the redundant SCG status, follow these steps:

1. Monitor the Redundant SCG Environmental Status on page 553
2. Display the Redundant SCG LED States at the Command Line on page 555
3. View the Redundant SCG LEDs on page 555

### Step 1: Monitor the Redundant SCG Environmental Status

**Action** To check the redundant SCG environment status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
t320@host> show chassis environment
Class Item             Status  Measurement
Power PEM 0            Absent
      PEM 1            OK
Temp  SCG 0            OK      30 degrees C / 86 degrees F
      SCG 1            OK      29 degrees C / 84 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the status and temperature for each SCG.

**Alternative Action** If there is a problem with the SCG status, you can display more detailed SCG environmental information with the following CLI command:

```
user@host> show chassis environment scg
```

The command output is as follows:

```
t320@host> show chassis environment scg
SCG 0 status:
  State                Online - Master clock
  Temperature          30 degrees C / 86 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3317 mV
    5.0 V               5072 mV
    5.6 V               5697 mV
    1.8 V bias          1794 mV
    3.3 V bias          3304 mV
    5.0 V bias          4991 mV
    8.0 V bias          7318 mV
  BUS Revision         40
SCG 1 status:
  State                Online - Standby
  Temperature          29 degrees C / 84 degrees F
  Power:
    GROUND              0 mV
    3.3 V               3318 mV
    5.0 V               5084 mV
    5.6 V               5704 mV
    1.8 V bias          1782 mV
    3.3 V bias          3286 mV
    5.0 V bias          5003 mV
    8.0 V bias          7323 mV
  BUS Revision         40
```

The command output displays the status for each SCG slot 0 and 1. The operating status can be **Present**, **Online**, **Offline**, or **Empty**. If **Online**, it can be the clock source (**Master clock**) or backup (**Standby**). As shown in the output, the redundant SCG is **SCG1**, with a status of **Standby**. The command output displays the temperature of the air flowing past the SCG. The command output also displays information about the SCG power supplies and the SCG circuitry revision level.



## Step 2: Display the Redundant SCG LED States at the Command Line

**Action** To display the redundant SCG LED states, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
t320@host> show chassis craft-interface
[...Output truncated...]
SCG LEDs:
  SCG  0    1
-----
Amber   .    .
Green  *    *
Blue   *    .
[...Output truncated...]
```

**What It Means** The command output displays the SCG LED status. The router has two SCGs installed. Asterisks (\*) indicate the operation status. The color represents the possible SCG operating states: Amber (Fail), Green (OK), and Blue (Master). Both SCGs are functioning properly (Green). The SCG in slot 0 is operating as master; the SCG in slot 1 is the backup.

## Step 3: View the Redundant SCG LEDs

**Action** To view the redundant SCG LEDs, remove the rear component cover and look on the SCG faceplate at the rear of the router chassis. Table 118 describes the functions of these LEDs.

**Table 118: SCG LEDs**

Label	Color	State	Description
OK	Green	On steadily	SCG is online and is functioning normally.
FAIL	Amber	On steadily	SCG has failed.
MASTER	Blue	On steadily	SCG is functioning as master.

## Displaying Redundant SCG Mastership

If both SCGs are installed and functioning normally, SCG0 is master and SCG1 is backup. Removing the backup SCG does not affect the functioning of the routing node. Taking the master SCG offline might result in a brief loss of SONET clock lock while the backup SCG becomes master.

**Steps To Take** To determine which SCG is operating as the master and which is operating as the standby, follow these steps:

1. Display the SCG Master and Standby from the Craft Interface Output on page 556
2. View the SCG LEDs on page 556

## Step 1: Display the SCG Master and Standby from the Craft Interface Output

**Action** To determine the SCG master and SCG standby from the craft interface status information, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
[...Output truncated...]
SCG LEDs:
  SCG  0   1
-----
Amber   .   .
Green  *   *
Blue   *   .
[...Output truncated...]
```

**What It Means** The command output displays which SCG is operating as master. Asterisks (\*) indicate the operation status. The color represents the possible SCG operating states: Amber (Fail), Green (OK), and Blue (Master). The SCG in slot 0 is operating as master; the SCG in slot 1 is the backup.

## Step 2: View the SCG LEDs

**Action** Check the blue MASTER LED on the SCG faceplate. If this LED is on steadily, the SCG is functioning as master. Table 118 on page 555 describes the functions of the SCG LEDs.

## Performing a Swap Test on a Redundant SCG



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the SCG for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on a redundant SCG, follow these steps:

1. Take the SCG offline by doing one of the following:
  - Use the following CLI command:
 

```
user@host> request chassis scg offline slot number
```
  - Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the ESD points on the chassis. Press the online/offline button on the SCG faceplate and hold it down until the LED goes out (about 5 seconds).
2. Loosen the captive screws on the edges of the SCG faceplate.
3. Grasp the SCG by the handle on the faceplate and slide it out of the chassis.
4. Place the SCG on the antistatic mat.

5. Remove the replacement SCG from its electrostatic bag.
6. Carefully align the sides of the SCG with the guides in the SCG slot.
7. Grasp the SCG by its handle and slide it straight into the chassis until it contacts the midplane.
8. Tighten the captive screws on the corners of the SCG faceplate.
9. Bring the SCG online by doing one of the following:
  - Use the following CLI command:
 

```
user@host> request chassis scg online slot number
```
  - Press the online/offline button until the green ONLINE LED lights.
10. Verify that the SCG is online by using the following CLI command:
 

```
user@host> request chassis scg online slot number
```

If the replaced SCG is online, the removed SCG has failed. Return the SCG as described in “Return the Failed Component” on page 86.

## Returning the SCG

---

**Action** To return an SCG, locate the serial number on the top of the SCG, close to the midplane connector. See “Return the Failed Component” on page 86, or the procedure to return a field-replaceable unit in the T320 router or T640 routing node hardware guide.



## Chapter 42

# Monitoring Redundant Control Boards

You monitor and maintain redundant Control Boards installed in the M320 router, T320 router, or T640 routing node to ensure that there is no interruption of functions such as the following:

- Router component monitoring and control for failure and alarm conditions
- Component power-up and power-down control
- Redundant Routing Engine and Control Board mastership control
- Flexible PIC Concentrator (FPC) error detection and reset control
- SONET clock source generation and monitoring
- SONET reference clock monitoring (from the FPC and BIT interfaces)
- I<sup>2</sup>C controller monitoring
- Fan speed monitoring and control

For more information about monitoring a single Control Board, see “Monitoring the Control Board” on page 301.

Table 119 provides a checklist of tasks you perform to monitor redundant Control Boards.

**Table 119: Checklist for Monitoring Redundant Control Boards**

Monitor Redundant Control Board Tasks	Command or Action
<b>Understanding Redundant Control Boards on page 561</b>	
<b>Displaying Redundant Control Board Hardware Information on page 563</b>	show chassis hardware
<b>Displaying Redundant Control Board Mastership on page 563</b>	
1. Check the Redundant Control Board Environmental Status on page 564	show chassis environment cb
2. Check the Redundant Control Board Status from the Craft Interface on page 565	show chassis craft-interface
3. Check the Redundant Control Board LED Status on page 565	Examine the LEDs on the Control Board faceplate.

Monitor Redundant Control Board Tasks	Command or Action
<b>Switching Control Board Mastership on page 565</b>	Press the Control Board offline button on the component faceplate.
<b>Checking the Control Board Alarms on page 565</b>	See “Checking the Control Board Alarms” on page 308. For conditions that trigger Control Board alarms, see “Display the Current Router Alarms” on page 61.
<b>Replacing a Control Board on page 566</b>	<ol style="list-style-type: none"><li>1. Determine whether the host subsystem is functioning as master or as backup by using the <code>show chassis routing-engine</code> command.</li><li>2. Take the host subsystem offline if the Control Board is master by using the <code>request chassis routing-engine master switch</code> command.</li><li>3. Replace the Control Board with a known working one.</li><li>4. Check the Control Board status by examining the LEDs on the Control Board faceplate, or by using the <code>show chassis hardware</code> command.</li></ol>
<b>Returning the Control Board on page 566</b>	Locate the Control Board serial number ID label. See “Return the Failed Component” on page 86 or the appropriate hardware guide.

## Understanding Redundant Control Boards

---




**Purpose** Inspect redundant Control Boards to ensure that router component functions are uninterrupted. Each Control Board works with an adjacent Routing Engine to provide control and monitoring functions for the router. These include determining Routing Engine mastership; controlling power, reset, and SONET clocking for the other router components; monitoring and controlling fan speed; and monitoring system status.

**What Are Redundant Control Boards** Redundant Control Boards are two Control Boards installed in the M320 router, T320 router, or the T640 routing node.

The Control Board is a component of the host module. Each Control Board requires a Routing Engine to be installed in an adjacent slot. The Control Board in slot **CB0** installs above the Routing Engine in slot **RE0**, and the Control Board in slot **CB1** installs below the Routing Engine in slot **RE1**. Even if a Control Board is physically installed in the chassis, it does not function if there is no Routing Engine present in the adjacent slot.

If two Control Boards are installed, by default, **CB0** acts as the master Control Board and **CB1** acts as a backup. If the master Control Board (**CB0**) fails or is removed, the backup (**CB1**) restarts and becomes the master Control Board.

The Control Boards install into the midplane from the back of the chassis (see Figure 227 on page 562). The Control Boards are hot-pluggable.

**Figure 227: M320 Router, T320 Router, and T640 Routing Node Control Board Location****M320 Router rear****T320 Router rear****T640 Router rear**

9003285

- See Also**
- Monitoring the Host Subsystem on page 289
  - Monitoring the Routing Engine on page 125
  - Monitoring the Control Board on page 301



## Displaying Redundant Control Board Hardware Information

To display whether redundant Control Boards are installed in a router and to obtain hardware information, use the following JUNOS software command-line interface (CLI) command:

user@host> **show chassis hardware**

**Sample Output** t640@host> **show chassis hardware**  
Hardware inventory:

Item	Version	Part number	Serial number	Description
Chassis			abcdef	T320
Midplane	REV 01	710-004339	AY4529	
FPM GBUS	REV 02	710-004461	AY4511	
FPM Display	REV 02	710-002897	HF6094	
CIP	REV 05	710-002895	HC0468	
PEM 1	Rev 01	740-004359	2708013	Power Entry Module
SCG 0	REV 06	710-004455	AY4526	
SCG 1	REV 06	710-004455	AY4523	
Routing Engine 0	REV 01	740-005022	210929000142	RE-3.0
Routing Engine 1	REV 01	740-005022	210929000143	RE-3.0
CB 0	REV 06	710-002728	HC0065	
CB 1	REV 05	710-002728	HE3623	

[...Output truncated...]

**What It Means** The command output displays the Control Boards installed in the router chassis, including the slot number, revision level, part number, serial number, and a brief description of the component. Give this information to the Juniper Networks Technical Assistance Center (JTAC) if a Control Board fails. The command output for this T640 routing node shows that two Control Boards are installed. By default, CB1 is the redundant Control Board.

## Displaying Redundant Control Board Mastership

**Steps To Take** To display Control Board mastership, do one of the following:

1. Check the Redundant Control Board Environmental Status on page 564
2. Check the Redundant Control Board Status from the Craft Interface on page 565
3. Check the Redundant Control Board LED Status on page 565

**Step 1: Check the Redundant Control Board Environmental Status**

**Action** To check the redundant Control Board environmental status, use the following CLI command:

```
user@host> show chassis environment cb
```

**Sample Output**

```
t640@host> show chassis environment cb
CB 0 status:
  State                               Online Master
  Temperature                         29 degrees C / 84 degrees F
  Power:
    1.8 V                             1805 mV
    2.5 V                             2501 mV
    3.3 V                             3293 mV
    4.6 V                             4725 mV
    5.0 V                             5032 mV
    12.0 V                            11975 mV
    3.3 V bias                        3286 mV
    8.0 V bias                        7589 mV
  GBUS Revision                       40
  FPGA Revision                       7
CB 1 status:
  State                               Online Standby
  Temperature                         32 degrees C / 89 degrees F
  Power:
    1.8 V                             1802 mV
    2.5 V                             2482 mV
    3.3 V                             3289 mV
    4.6 V                             4720 mV
    5.0 V                             5001 mV
    12.0 V                            11946 mV
    3.3 V bias                        3274 mV
    8.0 V bias                        7562 mV
  GBUS Revision                       40
  FPGA Revision                       7
```

**What It Means** The command output displays which Control Board is master and standby. Additionally, the command output displays the Control Board state, redundancy status, temperature, power source, and circuitry revision level for each Control Board installed in the router chassis. **CB1** is shown in standby mode, and is the redundant Control Board.

**Alternative Action** To display the environmental status of a particular Control Board, use the following JUNOS CLI operational mode command:

```
t640@host> show chassis environment cb slot
```

## Step 2: Check the Redundant Control Board Status from the Craft Interface

**Action** If you are near the router, physically look at the craft interface for the Control Board LEDs. To display redundant Control Board status from the craft interface, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
t640@host> show chassis craft-interface
FPM Display contents:
[...Output truncated...]
CB LEDs:
  CB    0    1
-----
Amber   .
Green  *
Blue   *
```

[...Output truncated...]

**What It Means** The CB LEDs section of the command output indicates the status of the redundant Control Board. An asterisk (\*) indicates the current operating state: **Amber** (offline), **Green** (online), and **Blue** (Master). In the above output, no redundant Control Board is installed—the output under CB1 is blank.

## Step 3: Check the Redundant Control Board LED Status

**Action** To check the redundant Control Board LED status, look at the three LEDs located on the Control Board faceplate. Table 120 describes the Control Board LED states.

**Table 120: Control Board LEDs**

Label	Color	State	Description
OK	Green	On steadily	Control Board is online and is functioning normally.
FAIL	Amber	On steadily	Control Board has failed.
MASTER	Blue	On steadily	Control Board is functioning as master.

## Switching Control Board Mastership

**Action** To switch the Control Board master to backup or the Control Board backup to master, take the Control Board offline by pressing the Control Board offline button on the component faceplate. The backup Control Board will automatically start up. To remove the Control Board, see “Replacing a Control Board” on page 566.

## Checking the Control Board Alarms

**Action** To check for the Control Board alarms, see “Checking the Control Board Alarms” on page 308. For conditions that trigger Control Board alarms, see “Display the Current Router Alarms” on page 61.

## Replacing a Control Board

---

The Control Board can fail and not start, or it can cause a connectivity problem between the Routing Engine and the Packet Forwarding Engine components. You can perform a swap test on the Control Board to try to pinpoint the problem.

**Action** To replace a Control Board, see “Component Fuses in the M320 Router Midplane” on page 311.



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the Control Board for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

---

## Returning the Control Board

---

**Action** To return the Control Board, follow these steps:

1. Locate the serial number ID label on the bottom of the left side of the Control Board (see “Locate the Control Board Serial Number ID Label” on page 314).
2. Follow the procedure “Return the Failed Component” on page 86. You can also refer to the procedure to return a field-replaceable unit in the M320 router, T320 router, or the T640 routing node hardware guides.

## Chapter 43

# Monitoring Redundant MCSs

You monitor and maintain redundant Miscellaneous Control Subsystems (MCSs) installed in the M40e or M160 router to ensure that there is no interruption of functions such as the following:

- Router component monitoring and control for failure and alarm conditions
- Component power-up and power-down control
- Redundant Routing Engine, MCS, and PFE Clock Generator (PCG) mastership control
- Flexible PIC Concentrator (FPC) error detection and reset control
- SONET clock source generation and monitoring
- SONET reference clock (from the FPC and BIT interfaces) monitoring
- System clocks (from the PCG) monitoring

For more information about monitoring a single MCS, see “Monitoring the MCS” on page 359.

Table 121 provides a checklist of tasks you perform to monitor redundant MCSs.

**Table 121: Checklist for Monitoring Redundant MCSs**

Monitor Redundant MCS Tasks	Command or Action
<b>Understanding Redundant MCSs on page 569</b>	
<b>Displaying Redundant MCS Hardware Information on page 570</b>	show chassis hardware
<b>Monitoring Redundant MCS Status on page 570</b>	
1. Check the Redundant MCS Environmental Status on page 571	show chassis environment mcs
2. Check the Redundant MCS Status from the Craft Interface on page 572	show chassis craft-interface
3. Check the Redundant MCS LED Status on page 573	Check the LEDs on the MCS faceplate.

Monitor Redundant MCS Tasks	Command or Action
<b>Displaying Redundant MCS Mastership on page 573</b>	
1. Check the Redundant MCS Environmental Status on page 571	show chassis environment mcs
2. Check the Redundant MCS Status from the Craft Interface on page 572	show chassis craft-interface
3. Check the Redundant MCS LED Status on page 573	Check the LEDs on the MCS faceplate.
<b>Switching MCS Mastership on page 573</b>	Manually take the MCS offline by pressing the offline button on the component faceplate.
<b>Performing a Swap Test on a Redundant MCS on page 573</b>	1. Take the host module offline. 2. Take the MCS offline. 3. Remove the MCS and replace it with one that you know works.
<b>Returning an MCS on page 575</b>	See “Return the Failed Component” on page 86, or follow the procedure in the M40e or M160 router hardware guide.

## Understanding Redundant MCSs

**Purpose** Inspect redundant MCSs to ensure that functions are interrupted, such as component alarm messages; component power-up and power-down; Routing Engine, MCS, and PCG mastership control; SONET clock generation and monitoring; and system clock monitoring.

**What Are Redundant MCSs** Redundant MCSs are two MCSs installed in the M40e or M160 router.


The MCS is a component of the host module. Each MCS requires a Routing Engine to be installed in an adjacent slot. **MCS0** installs above slot **RE0**, and **MCS1** installs below slot **RE1**. Even if an MCS is physically installed in the chassis, it does not function if there is no Routing Engine present in the adjacent slot.

If two MCSs are installed, **MCS0** acts as the master MCS and **MCS1** acts as a backup. If the master MCS fails or is removed, the backup restarts and becomes the master MCS.


The MCSs install into the midplane from the back of the chassis (see Figure 228).

**Figure 228: M40e and M160 Router Redundant MCSs**

**M40e router rear**



**M160 router rear**



- See Also**
- Monitoring the Host Module on page 341
  - Monitoring the MCS on page 359
  - Monitoring Redundant Routing Engines on page 491

## Displaying Redundant MCS Hardware Information

---

**Action** To display whether there are redundant MCSs installed in a router and to get hardware information, use the following command-line interface (CLI) command:

```
user@ host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item              Version  Part number  Serial number  Description
Chassis                               51029         M160
Midplane          REV 05   710-001245   AW3223
FPM CMB           REV 03   710-001642   AH5190
FPM Display       REV 03   710-001647   AW2021
CIP               REV 04   710-002649   AG5779
PEM 0             Rev 03   740-001243   LK16612        Power Entry Module
PEM 1             Rev 03   740-001243   LK16604        Power Entry Module
PCG 0             REV 07   710-001568   HF1164
PCG 1             REV 07   710-001568   HF1159
Routing Engine 0  REV 01   740-003239   AARCH00        RE-2.0
Routing Engine 1  REV 01   740-003239   AARCH00        RE-2.0
MCS 0             REV 11   710-001226   AV4425
MCS 1             REV 11   710-001226   HD2842
[...Output truncated...]
```

**What It Means** The command output displays the MCS slot number, revision level, part number, and serial number. Give this information to the Juniper Networks Technical Assistance Center (JTAC) if an MCS fails.

## Monitoring Redundant MCS Status

---

**Steps To Take** To monitor redundant MCSs, do one of the following:

1. Check the Redundant MCS Environmental Status on page 571
2. Check the Redundant MCS Status from the Craft Interface on page 572
3. Check the Redundant MCS LED Status on page 573



## Step 1: Check the Redundant MCS Environmental Status

**Action** To check the redundant MCS status, use the following CLI command:

```
user@host> show chassis environment mcs
```

**Sample Output**

```
user@host> show chassis environment mcs
MCS 0 status:
  State                      Online Master
  Temperature                 0 degrees C / 32 degrees F
  Power:
    3.3 V                     3318 mV
    5.0 V                     5001 mV
    12.0 V                    11833 mV
    5.0 V bias                4991 mV
    8.0 V bias                8341 mV
  CMB Revision                12
  FPGA Revision               12
MCS 1 status:
  State                      Present
  Power:
    3.3 V                     3308 mV
    5.0 V                     5013 mV
    12.0 V                    11809 mV
    5.0 V bias                4952 mV
    8.0 V bias                8346 mV
  CMB Revision                12
```

**What It Means** The show chassis environment mcs CLI command is available on the M40e and M160 routers only. The command output displays environmental information about both MCSs installed in the router or about an individual MCS. The MCS status can be **Present**, **Online**, **Offline**, or **Empty**. The command also indicates that the MCS is the master MCS. The command output also displays the temperature of the air flowing past the MCS, information about MCS power supplies, field-programmable gate array (FPGA) revision information, and the revision level of the chassis management bus (CMB) slave.

**Alternative Action** To display the environmental status of a particular MCS, use the following JUNOS CLI operational mode command:

```
user@host> show chassis environment mcs slot
```

**Step 2: Check the Redundant MCS Status from the Craft Interface**

**Action** To display redundant MCS status from the craft interface, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
FPM Display contents:
```

```
+-----+
|myrouter      |
|3 Alarms active|
|R: Hard errors |
|R: PEM 1 Input Fail|
+-----+
```

Front Panel System LEDs:

```
Routing Engine    0    1
```

```
-----
OK                *    *
Fail              .    .
Master            *    .
```

Front Panel Alarm Indicators:

```
-----
Red LED          *
Yellow LED       *
Major relay      *
Minor relay      *
```

Front Panel FPC LEDs:

```
FPC    0    1    2    3    4    5    6    7
```

```
-----
Red     *    .    .    .    *    .    .    .
Green   .    *    .    *    .    *    *    .
```

MCS LEDs:

```
MCS    0    1
```

```
-----
Amber   .    .
Green  *    *
Blue   *    .
```

[...Output truncated...]

**What It Means** The MCS LEDs section of the command output indicates the status of the redundant MCSs. An asterisk (\*) indicates the current operating state: **Amber** (offline), **Green** (online), and **Blue** (Master).

### Step 3: Check the Redundant MCS LED Status

**Action** To check redundant MCS LED status, look on the faceplate of the MCS at the rear of the router. Table 122 describes the LED states.

**Table 122: MCS LEDs**

Color	Label	State	Description
Blue	MASTER	On steadily	MCS is master.
Green	OK	On steadily	MCS is operating normally.
		Blinking	MCS is starting up.
Amber	FAIL	On steadily	MCS has failed.

When the MCS is functioning normally, the green OK LED remains on steadily.

### Displaying Redundant MCS Mastership

**Steps To Take** To display which MCS is master and which is backup, do one of the following:

1. Check the Redundant MCS Environmental Status on page 571
2. Check the Redundant MCS Status from the Craft Interface on page 572
3. Check the Redundant MCS LED Status on page 573

Each step displays the master and backup MCS.

### Switching MCS Mastership

**Action** To switch the MCS master to backup or the MCS backup to master, take the MCS offline by pressing the MCS offline button on the component faceplate. The backup MCS will automatically start up. To remove the MCS, see “Performing a Swap Test on a Redundant MCS” on page 573.

### Performing a Swap Test on a Redundant MCS

The MCS can fail and not start, or it can cause a connectivity problem between the Routing Engine and the Packet Forwarding Engine components, such as the FPC and Switching and Forwarding Module (SFM). You can perform a swap test on the MCS to try to pinpoint the problem.



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the MCS for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on the MCS, remove it and replace it with one that you know works.

Normally, if two host modules are installed in the router, **HOST0** functions as the master and **HOST1** as the backup. You can remove the backup host module (or either of its components) without interrupting the functioning of the router. If you take the master host module offline, the router reboots and the backup host module becomes the master. If the router has only one host module, taking it offline causes the router to shut down.

The host module is taken offline and brought back online as a unit. Before you replace the Routing Engine or an MCS, you must take the host module offline. The host module is hot-pluggable.

To remove an MCS, follow these steps:

1. Lay an electrostatic bag or antistatic mat on a flat, stable surface to receive the Routing Engine.
2. Attach an electrostatic discharge (ESD) strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
3. Remove the rear component cover by loosening the screws at the corners of the cover and pulling it straight off of the chassis.
4. If two host modules are installed, check whether the MCS you are removing belongs to the master host module with the following CLI command:

```
user@host> show chassis environment mcs
```

Or you can check the MCS LEDs. If the MCS belongs to the master host module, switch mastership to the standby host module by including the **routing-engine** statement at the **[edit chassis redundancy]** hierarchy level in the configuration, as described in the *JUNOS System Basics Configuration Guide*.

5. On the console or other management device connected to the Routing Engine that is paired with the MCS you are removing, enter CLI operational mode and issue the following command:

```
user@host> request system halt
```

The command shuts down the Routing Engine cleanly, so its state information is preserved.

Wait to continue until all software processes have shut down.

6. Flip the ends of the extractor clips outward.
7. Grasp the extractor clips and slide the unit about halfway out of the chassis.
8. Place one hand under the MCS to support it, slide it completely out of the chassis, and place it on the antistatic mat or in the electrostatic bag.
9. Align the rear of the MCS with the guides inside the chassis and slide it in completely.

10. Press the extractor clips on the left and right sides of the MCS inward.
11. Verify that the green LED labeled **OK** on the MCS faceplate is lit. Also check the host module LEDs on the craft interface to verify that the green LED labeled **ONLINE** is lit for the host module to which the MCS belongs.
12. Verify correct MCS functioning by using the **show chassis environment mcs** command.

If the replacement MCS works, you can be certain that the replaced MCS failed. To return the MCS, see “Returning an MCS” on page 575.

## Returning an MCS

---

**Action** To return an MCS, see “Return the Failed Component” on page 86, or the procedure to return a field-replaceable unit in the M40e or M160 router hardware guide.



## Chapter 44

# Monitoring Redundant SFMs

You monitor redundant Switching and Forwarding Modules (SFMs) to ensure that traffic transiting the router is handled properly. SFMs contain the Internet Processor II application-specific integration circuits (ASICs), which make forwarding decisions, and the Distributed Buffer Manager ASICs, which distribute data cells throughout memory and forward notification of outgoing packets. (See Table 123.)

**Table 123: Checklist for Monitoring Redundant SFMs**

Monitor Redundant SFM Tasks	Command or Action
<b>Understanding Redundant SFMs on page 579</b>	
<b>Understanding M40e Router Redundant SFM Configuration on page 580</b>	
<b>Understanding M40e Router Redundant SFM Operation on page 580</b>	
<b>Understanding M160 Router Redundant SFM Operation on page 580</b>	
<b>Displaying Redundant SFM Hardware Information on page 581</b>	show chassis hardware
<b>Monitoring Redundant SFM Status on page 581</b>	
1. Display the SFM Summary Status on page 582	show chassis sfm <i>sfm-slot</i> show chassis sfm detail <i>sfm-slot</i>
2. Display the SFM LED Status at the Command Line on page 584	show chassis craft-interface
3. Check the SFM LED Status on the Faceplate on page 584	Check the SFM faceplate at the back of the M40e and M160 router chassis.
4. Display the SFM Environmental Status on page 585	show chassis environment show chassis environment sfm <i>slot</i>
<b>Displaying Redundant SFM Mastership on page 587</b>	
1. Display SFM Mastership at the Command Line on page 587	show chassis sfm
2. Display SFM Mastership Information from the Craft Interface on page 588	show chassis craft-interface
<b>Displaying Redundant SFM Alarms on page 588</b>	
1. Display the Current Redundant SFM Alarms on page 588	show chassis alarms
2. Display SFM Error Messages in the System Log File on page 589	show log messages
3. Display SFM Error Messages in the Chassis Daemon Log File on page 589	show log chassisd   match sfm

Monitor Redundant SFM Tasks	Command or Action
<b>Verifying SFM Failure on page 590</b>	
1. Check the SFM Connection on page 590	Check the thumbscrews on the SFM ejector locking tabs.
2. Restart the SFM on page 590	<code>request chassis sfm slot <i>slot-number</i> restart</code>
3. Perform an SFM Swap Test on page 591	<ol style="list-style-type: none"> <li>1. Take the SFM offline.</li> <li>2. Replace the SFM with one that you know works.</li> <li>3. Bring the SFM online.</li> <li>4. Check the SFM status by using the <code>show chassis sfm</code> CLI command.</li> </ol>
<b>Controlling Redundant SFMs on page 591</b>	
1. Take an SFM Offline on page 592	<code>request chassis sfm slot <i>slot-number</i> offline</code>
2. Bring an SFM Online on page 592	<code>request chassis sfm slot <i>slot-number</i> online</code>
3. Switch SFM Mastership on page 593	(M40e router only) <code>request chassis sfm master switch &lt;no-confirm&gt;</code>
<b>Replacing an SFM on page 593</b>	
	<ol style="list-style-type: none"> <li>1. Take the SFM offline.</li> <li>2. Remove the failed SFM.</li> <li>3. Install a new SFM.</li> <li>4. Bring the SFM online.</li> <li>5. Verify that SFM is online by using the <code>show chassis sfm</code> CLI command.</li> </ol>



## Understanding Redundant SFMs

**Purpose** Inspect redundant SFMs to ensure that all traffic leaving the Flexible PIC Concentrators (FPCs) is handled properly.


**What Are Redundant SFMs** SFMs are control boards that handle traffic transiting the router. The SFMs provide route lookup, filtering, and switching.

Up to four interconnected SFMs can be installed in the M160 router, providing a total of 160 million packets per second (Mpps) of forwarding. Up to two SFMs can be installed in the M40e router. Each SFM can process 40 Mpps.

The SFM is a two-board system containing the Switch Plane Processor (SPP) card and the Switch Plane Router (SPR) card. When the serial stream of bits leaves the FPC, it is directed to one of the SFMs. The Distributed Buffer Manager ASIC on the SFM distributes the data cells throughout memory banks that are shared over all FPCs. The Internet Processor II ASIC on the SFM performs route lookups and makes forwarding decisions. The Internet Processor II ASIC notifies a second Distributed Buffer Manager ASIC SFM, which forwards the notifications to the outbound interface. Each SFM effectively handles from one-half to one-quarter of the traffic on each FPC.

The SFMs are hot-removable and hot-insertable. Inserting or removing an SFM causes a brief interruption in forwarding performance (about 500 ms) as the Packet Forwarding Engine reconfigures the distribution of packets across the remaining SFMs.

**Figure 229: M40e and M160 Router SFM Location**



## Understanding M40e Router Redundant SFM Configuration

---

You can configure which SFM is the master and which is the backup. By default, the SFM in slot 0 is the master and the SFM in slot 1 is the backup. You can modify the default configuration by including the `sfm` statement at the `[edit chassis redundancy]` hierarchy level.



**NOTE:** We recommend that both Routing Engines have the same configuration.

---

To display the current SFM redundancy configuration, follow these steps:

1. Enter the CLI configuration mode using the following command:

```
user@host# configure
```

2. Go to the `[edit chassis redundancy]` hierarchy level.

3. Show the SFM configuration using the following command:

```
user@host# show
```

## Understanding M40e Router Redundant SFM Operation

---

One or two SFMs can be installed into the midplane from the rear of the M40e router chassis, as shown in Figure 229 on page 579. Only one SFM is active at a time, with the optional second SFM in standby mode. Removing the standby SFM has no effect on router function. If the active SFM fails or is removed from the chassis, what happens depends on the number of SFMs installed:

- If there is only one SFM, forwarding halts until the SFM is replaced and online.
- If there are two SFMs, forwarding halts until the standby SFM boots and becomes active.

It takes approximately 1 minute for the new SFM to become active. Synchronizing router configuration information can take additional time, depending on the complexity of the configuration.

## Understanding M160 Router Redundant SFM Operation

---

Up to four SFMs can be installed into the midplane from the rear of the M160 router chassis, as shown in Figure 229 on page 579. All SFMs are active at the same time. A failure or taking an SFM offline has no effect on router function unless it is the only SFM installed. If only one SFM is installed, forwarding halts until the SFM is replaced and is back online. If two or more SFMs are installed, forwarding continues uninterrupted.

## Displaying Redundant SFM Hardware Information

**Action** To display redundant SFM hardware information, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output** For M40e routers:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis
[...Output truncated...]
SFM 0 SPP      REV 07   710-001228   AF2247
SFM 0 SPR      REV 05   710-002189   AF1847          Internet Processor II
SFM 1 SPP      REV 07   710-001228   BE0175
SFM 1 SPR      REV 05   710-002189   BE0201          Internet Processor II
```

For M160 routers:

```
user@host> show chassis hardware
Item          Version  Part number  Serial number  Description
Chassis
[...Output truncated...]
SFM 0 SPP      REV 04   710-001228   AA2860
SFM 0 SPR      REV 01   710-001224   AB0139          Internet Processor I
SFM 1 SPP      REV 04   710-001228   AA2859
SFM 1 SPR      REV 02   710-001224   AA9861          Internet Processor I
SFM 2 SPP      REV 06   710-001228   AB3082
SFM 2 SPR
SFM 3 SPP      REV 04   710-001228   AA1998
SFM 3 SPR      REV 01   710-001224   AB0137          Internet Processor I
[...Output truncated...]
```

**What it Means** The command output displays the SFM slot number and SFM serial component (SPP and SPR) card names, and the SFM revision level, part number, serial number, and description.

## Monitoring Redundant SFM Status

**Steps To Take** To monitor the SFM status, follow these steps:

1. Display the SFM Summary Status on page 582
2. Display the SFM LED Status at the Command Line on page 584
3. Check the SFM LED Status on the Faceplate on page 584
4. Display the SFM Environmental Status on page 585

## Step 1: Display the SFM Summary Status

**Action** To display the SFM summary status, use the following CLI command:

```
user@host> show chassis sfm
```

**Sample Output** For M40e routers:

```
user@host> show chassis sfm
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Online 37 3 0 64 16 46
1 Online - Standby 41 3 0 64 16 46
```

For M160 routers:

```
user@host> show chassis sfm
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Online 41 2 0 64 16 46
1 Offline --- Hard FPC error ---
2 Online 43 2 0 64 16 46
3 Online 44 2 0 128 7 46
```

**What it Means** The command output displays the SFM slot number and the operating status of each SFM as Online, Offline, Present, or Empty.

The command output displays the temperature of air passing by the SFM, in degrees Centigrade. It displays the SFM CPU usage, including the total percentage used by the SFM processor and the percentage used for interrupts.

The command output also displays the percentage of memory usage, including the total DRAM available to the SFM processor, in megabytes (MB), and the percentage of heap space (dynamic memory) being used by the SFM processor. Heap utilization greater than 80 percent can indicate a software problem (memory leak). The output shows the percentage of buffer space being used by the SFM processor for buffering internal messages.

**Alternative Action** If the SFM summary command output indicates that there is a problem, you can display more detailed SFM status information with the following CLI command:

```
user@host> show chassis sfm detail
```

For M40e routers:

```
user@host> show chassis sfm detail
Slot 0 information:
State Online
SPP Temperature 37 degrees C / 98 degrees F
SPR Temperature 41 degrees C / 105 degrees F
Total CPU DRAM 64 MB
Total SSRAM 8 MB
Internet Processor II Version 1, Foundry IBM, Part number 9
Start time: 2002-09-03 19:55:51 PDT
Uptime: 3 hours, 47 minutes, 46 seconds
```

```

Slot 1 information:
  State                Online - Standby
  SPP Temperature      41 degrees C / 105 degrees F
  SPR Temperature      40 degrees C / 104 degrees F
  Total CPU DRAM       64 MB
  Total SSRAM          8 MB
  Internet Processor II Version 1, Foundry IBM, Part number 9

```

For M160 routers:

```

Slot 0 information:
  State                Online
  SPP Temperature      39 degrees C / 102 degrees F
  SPR Temperature      41 degrees C / 105 degrees F
  Total CPU DRAM       64 MB
  Total SSRAM          4 MB
  Internet Processor I  Version 1, Foundry IBM, Part number 3
  Start time:          2002-06-27 18:49:44 PDT
  Uptime:              68 days, 4 hours, 55 minutes, 5 seconds
Slot 1 information:
  State                Online
[...Output truncated...]
Slot 2 information:
  State                Offline
[...Output truncated...]
Slot 3 information:
  State                Online
[...Output truncated...]

```

Packet scheduling mode : Disabled

In addition to the command output displayed for the **show chassis sfm** command, the **show chassis sfm detail** command displays the temperature of air passing by the SPP and SPR cards (the two SFM serial components), in degrees Centigrade. It displays the total CPU DRAM and SRAM being used by the SFM processor. The command output displays the time that the SFM became active and how long the SFM has been up and running. A small uptime means that the SFM came online a short time ago and could indicate a possible SFM error condition.

To display the status of a particular SFM, use the following CLI command:

```
user@host> show chassis sfm sfm-slot
```

To display detailed status information about a particular SFM, use the following CLI command:

```
user@host> show chassis sfm detail sfm-slot
```

## Step 2: Display the SFM LED Status at the Command Line

**Action** To display the SFM LED status, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output** For M40e routers:

```
user@host> show chassis craft-interface
[...Output truncated...]
SFM LEDs:
  SFM  0   1
-----
Amber   .   .
Green  *   *
Blue   *   .
```

For M160 routers:

```
user@host> show chassis craft-interface
[...Output truncated...]
SFM LEDs:
  SFM  0   1   2   3
-----
Amber   .   .   *   .
Green  *   *   .   *
Blue   *   *   .   *
```

**What it Means** In the sample output for an M160 router, the SFMs in slots 0 and 1 are online and functioning normally. The status colors represent the possible SFM operating states: Amber (Fail), Green (OK), and Blue (Master). The (\*) indicates the current operating state. There are no SFMs in slots 2 and 3.

## Step 3: Check the SFM LED Status on the Faceplate

**Action** To check the SFM LED status, remove the component cover and look on the SFM faceplate at the back of the M40e or M160 router. Table 124 describes the SFM LED states.

**Table 124: SFM LEDs**

Color	Label	State	Description
Green	OK	On steadily	SFM is functioning normally.
		Blinking	SFM is starting up.
Amber	FAIL	On steadily	SFM has failed.

## Step 4: Display the SFM Environmental Status

**Action** To display the SFM environmental information, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output** For M40e routers:

```
user@host> show chassis environment
Class Item                Status      Measurement
Power PEM 0                OK
      PEM 1                Check
Temp  PCG 0                OK          37 degrees C / 98 degrees F
      PCG 1                OK          37 degrees C / 98 degrees F
      Routing Engine 0    OK          29 degrees C / 84 degrees F
      MCS 0                OK          40 degrees C / 104 degrees F
      SFM 0 SPP           OK          37 degrees C / 98 degrees F
      SFM 0 SPR           OK          41 degrees C / 105 degrees F
      SFM 1 SPP           OK          41 degrees C / 105 degrees F
      SFM 1 SPR           OK          40 degrees C / 104 degrees F
[...Output truncated...]
```

For M160 routers:

```
user@host> show chassis environment
Class Item                Status      Measurement
Power PEM 0                OK
      PEM 1                OK
Temp  [...Output truncated...]
      SPP 0                OK          37 degrees C / 98 degrees F
      SPR 0                OK          46 degrees C / 114 degrees F
      SPP 1                OK          38 degrees C / 100 degrees F
      SPR 1                OK          48 degrees C / 118 degrees F
      SPP 2                OK          39 degrees C / 102 degrees F
      SPR 2                OK          54 degrees C / 129 degrees F
      SFM 3                Offline
[...Output truncated...]
```

**What it Means** The command output displays the status and temperature for the SFM and its two serialized components: the SPP and SPR cards.

**Alternative Actions** If there is a problem with the SFM status, you can display more detailed environmental information with the following CLI command:

```
user@host> show chassis environment sfm
```

For M40e routers:

```
SFM 0 status:
State                Online
SPP temperature      37 degrees C / 98 degrees F
SPR temperature      41 degrees C / 105 degrees F
SPP Power:
  1.5 V              1501 mV
  2.5 V              2495 mV
  3.3 V              3293 mV
  5.0 V              5042 mV
  5.0 V bias         4998 mV
```

```

SPR Power:
  1.5 V      1504 mV
  2.5 V      2499 mV
  3.3 V      3297 mV
  5.0 V      5050 mV
  5.0 V bias 5008 mV
  8.0 V bias 8288 mV
CMB Revision      12
SFM 1 status:
State              Online - Standby
SPP temperature    41 degrees C / 105 degrees F
SPR temperature    40 degrees C / 104 degrees F
SPP Power:
  1.5 V      1498 mV
  2.5 V      2468 mV
  3.3 V      3296 mV
  5.0 V      5042 mV
  5.0 V bias 4993 mV
SPR Power:
  1.5 V      1496 mV
  2.5 V      2471 mV
  3.3 V      3299 mV
  5.0 V      5037 mV
  5.0 V bias 4996 mV
  8.0 V bias 8266 mV
CMB Revision      12

```

For M160 routers:

```

SFM 0 status:
State              Online
SPP temperature    36 degrees C / 96 degrees F
SPR temperature    45 degrees C / 113 degrees F
SPP Power:
  1.5 V      1501 mV
  2.5 V      2485 mV
  3.3 V      3291 mV
  5.0 V      5020 mV
  5.0 V bias 4974 mV
SPR Power:
  1.5 V      1501 mV
  2.5 V      2492 mV
  3.3 V      3301 mV
  5.0 V      5028 mV
  5.0 V bias 4986 mV
  8.0 V bias 8305 mV
CMB Revision      12
SFM 1 status:
[...Output truncated...]
SFM 2 status:
[...Output truncated...]
SFM 3 status:
State              Offline
- Hard FPC error
[...Output truncated...]

```



The command output displays the SFM slot, status, and the temperature of the air flowing past the SPP and SPR cards. It also displays information about the SFM power supplies. The chassis management bus (CMB) slave revision level is also displayed.

You can display the environmental status of a particular SFM with the following CLI command:

```
user@host> show chassis environment sfm slot
```

## Displaying Redundant SFM Mastership

**Steps To Take** (For M40e routers only) To display which SFM is master, follow these steps:

1. Display SFM Mastership at the Command Line on page 587
2. Display SFM Mastership Information from the Craft Interface on page 588

### Step 1: Display SFM Mastership at the Command Line

**Action** To display the SFM summary status at the command line, use the following CLI command:

```
user@host> show chassis sfm
```

**Sample Output** For M40e routers:

```
user@host> show chassis sfm
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Online 37 3 0 64 16 46
1 Online - Standby 41 3 0 64 16 46
```

For M160 routers:

```
user@host> show chassis sfm
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Online 41 2 0 64 16 46
1 Offline --- Hard FPC error ---
2 Online 43 2 0 64 16 46
3 Online 44 2 0 128 7 46
```

**What It Means** The command output displays the SFM slot number and the operating status of each SFM as Online, Offline, Present, or Empty.

The command output displays the temperature of air passing by the SFM, in degrees Centigrade. It displays the SFM CPU usage, including the total percentage used by the SFM processor and the percentage used for interrupts.

The command output also displays the percentage of memory usage, including the total DRAM available to the SFM processor, in MB, and the percentage of heap space (dynamic memory) being used by the SFM processor. Heap utilization greater than 80 percent can indicate a software problem (memory leak). The output shows the percentage of buffer space being used by the SFM processor for buffering internal messages.

## Step 2: Display SFM Mastership Information from the Craft Interface

**Action** To display SFM mastership information from the craft interface, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
SFM LEDs:
  SFM  0    1
-----
Amber   .    .
Green  *    *
Blue   *    .
```

**What It Means** The command output shows that the SFM in slot 0 is online and functioning as the master. The status colors represent the possible SFM operating states: **Amber** (Fail), **Green** (OK), and **Blue** (Master). The (\*) indicates the current operating state.

## Displaying Redundant SFM Alarms

---

**Steps To Take** To display SFM alarms and error messages, follow these steps:

1. Display the Current Redundant SFM Alarms on page 588
2. Display SFM Error Messages in the System Log File on page 589
3. Display SFM Error Messages in the Chassis Daemon Log File on page 589

### Step 1: Display the Current Redundant SFM Alarms

**Action** To display the current SFM alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
4 alarms currently active
Alarm time          Class  Description
2002-05-14 09:23:58 PDT Major  SFM Failure
2002-05-14 09:23:55 PDT Major  SFM Failure
2002-05-14 09:23:53 PDT Major  SFM Failure
2002-05-14 09:20:51 PDT Major  No SFM Online, the box is not forwarding
```

**What It Means** The command output displays the alarm date, time, severity level, and description.

## Step 2: Display SFM Error Messages in the System Log File

**Action** To display the SFM error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Jun 11 20:31:11 hissy-re0 craftd[556]: Major alarm set, No SFM Online, the box
is not forwarding
Jun 11 20:31:11 hissy-re0 alarmd[555]: Alarm set: SFM color=RED, class=CHASSIS,
reason=No SFM Online, the box is not forwarding
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match sfm` command to see error messages that are generated when an SFM fails or is offline. Use this information to diagnose a power supply problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 3: Display SFM Error Messages in the Chassis Daemon Log File

The chassis daemon (chassisd) log file keeps track of the state of each chassis component.

**Action** To display the SFM error messages logged in the chassis daemon log file, use the following CLI command:

```
user@host> show log chassis | match sfm
```

**Sample Output**

```
user@host> show log chassisd | match sfm
Jun 11 20:50:16 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:50:16 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x0
Jun 11 20:50:16 bp_handle_button_intr button status 0x0
Jun 11 20:50:16 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:50:16 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x8
Jun 11 20:50:16 bp_handle_button_intr button status 0x8
Jun 11 20:50:16 mcs_intr_handler fpm_mcsfd 10
Jun 11 20:50:16 mcs_intr mcs_ints_pending 0x7cbf20 button_status 0x8
Jun 11 20:50:16 bp_handle_button_intr button status 0x8
Jun 11 20:50:16 received second FPM key press, clearing timer!
Jun 11 20:50:18 bp_button_timer: taking sfm 1 offline
Jun 11 20:50:18 take_sfm_offline - slot 1 reason 7
Jun 11 20:50:18 cleaning up sfm 1 connection
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Blue LED Off [0x16]
Jun 11 20:50:18 SPP 1 - Blue LED Off
Jun 11 20:50:18 send: fpc 0, sfm 1 offline
Jun 11 20:50:18 send: fpc 1, sfm 1 offline
Jun 11 20:50:18 send: fpc 2, sfm 1 offline
Jun 11 20:50:18 send: fpc 6, sfm 1 offline
Jun 11 20:50:18 send: fpc 7, sfm 1 offline
Jun 11 20:50:18 fpc 2, sfm 1 offline ack
Jun 11 20:50:18 fpc 2, sfm 1 offline ack, online 0xc7 online-acks 0x4
Jun 11 20:50:18 fpc 1, sfm 1 offline ack
Jun 11 20:50:18 fpc 1, sfm 1 offline ack, online 0xc7 online-acks 0x6
Jun 11 20:50:18 fpc 0, sfm 1 offline ack
Jun 11 20:50:18 fpc 0, sfm 1 offline ack, online 0xc7 online-acks 0x7
```

```

Jun 11 20:50:18 fpc 7, sfm 1 offline ack
Jun 11 20:50:18 fpc 7, sfm 1 offline ack, online 0xc7 online-acks 0x87
Jun 11 20:50:18 fpc 6, sfm 1 offline ack
Jun 11 20:50:18 fpc 6, sfm 1 offline ack, online 0xc7 online-acks 0xc7
Jun 11 20:50:18 sfm_offline_now plane 1 conn 0x8152638
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Assert PLL Bypass [0x13]
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Assert Board Reset [0x2e]
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Assert ASIC Reset [0x28]
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Disable Power [0x10]
Jun 11 20:50:18 SPP 1 - Disable Power [addr 0x9 cmd 0x10]
Jun 11 20:50:18 CMB readback SPP 1 [0xe9, 0xf2] -> 0x26
Jun 11 20:50:18 power disable verified, SPP 1
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Blue LED Off [0x16]
Jun 11 20:50:18 SPP 1 - Blue LED Off
Jun 11 20:50:18 CMB cmd to SPP 1 [0xe9], Green LED Off [0x1a]
Jun 11 20:50:18 SPP 1 - Green LED Off

```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.

## Verifying SFM Failure

---

**Steps To Take** To verify SFM failure, follow these steps:

1. Check the SFM Connection on page 590
2. Restart the SFM on page 590
3. Perform an SFM Swap Test on page 591

### Step 1: Check the SFM Connection

**Action** To check the SFM connection, make sure that it is properly seated in the midplane. Check the thumbscrews on the ejector locking tabs.

### Step 2: Restart the SFM

**Action** To restart an SFM, use the following CLI command:

```
user@host> request chassis sfm slot slot-number restart
```

**Sample Output** For M40e routers:

```

user@host> request chassis sfm slot 0 restart
error: SFM 0 is transitioning to online state.

```

For M160 routers:

```

user@host> request chassis sfm slot 0 restart
Restart initiated, use "show chassis sfm" to verify

```

```

user@host> show chassis sfm
Temp  CPU Utilization (%)  Memory  Utilization (%)
Slot State              (C)  Total  Interrupt  DRAM (MB) Heap  Buffer
0 Ready                  0      0      0          0      0      0
1 Online                 38      1      0          64      8      46
2 Offline                --- Unresponsive ---
3 Online                 39      1      0          64      8      46

```

**What It Means** The command output shows that the SFM restart has been initiated. On the M160 router, the command output indicates to use the `show chassis sfm` CLI command to verify that the SFM has been restarted. The SFM status information shows that the SFM is ready and that the status values are 0 for approximately 5 seconds until the SFM is active.

### Step 3: Perform an SFM Swap Test



**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the SFM for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on an SFM, follow these steps:

1. Remove the chassis rear component cover by loosening the screws on the corners of the cover and pulling it straight out from the chassis.
2. Remove the SFM, as described in the M40e and M160 router hardware guides.
3. Take the SFM offline by using the `request chassis sfm slot slot-number offline` CLI command. You can also press and hold the offline button on the SFM faceplate at the rear of the router until the **SFM OK** LED turns off (about 5 seconds).
4. Replace the SFM with one that you know works.
5. Bring the SFM online. Press and hold the offline button on the SFM faceplate until the green **OK** LED lights (about 5 seconds). You can also use the `request chassis sfm slot slot-number online` CLI command.
6. Reinstall the rear component cover and tighten the screws to secure it to the chassis.
7. Check the SFM status. See “Display the SFM Summary Status” on page 582.

### Controlling Redundant SFMs

**Steps To Take** To control the operation of an SFM, follow these steps:

1. Take an SFM Offline on page 592
2. Bring an SFM Online on page 592
3. Switch SFM Mastership on page 593

## Step 1: Take an SFM Offline

**Action** To take an SFM offline, use the following CLI command:

```
user@host> request chassis sfm slot slot-number offline
```

**Sample Output** user@host> **request chassis sfm slot 0 offline**  
Offline initiated, use "show chassis sfm" to verify

For M40e routers:

```
user@host> show chassis sfm
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Offline --- Offlined by cli command ---
1 Online - Standby 41 4 0 64 16 46
```

For M160 routers:

```
user@host> show chassis sfm
Temp CPU Utilization (%) Memory Utilization (%)
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Online 41 3 0 64 17 46
1 Online 44 4 0 64 17 46
2 Online 44 4 0 64 17 46
3 Offline --- Offlined by cli command ---
```

Packet scheduling mode: Disabled

**What It Means** The sample output confirms that the SFM offline command has been initiated and specifies to use the `show chassis sfm` CLI command to verify that the SFM is offline. The command output for both the M40e and M160 routers shows that the SFM is offline and that this state was generated by running the CLI command.

## Step 2: Bring an SFM Online

**Action** To bring an SFM online, use the following CLI command:

```
user@host> request chassis sfm slot slot-number online
```

**Sample Output** user@host> **request chassis sfm slot 0 online**  
Online initiated, use "show chassis sfm" to verify

For M40e routers:

```
user@host> show chassis sfm
Slot State (C) Total Interrupt DRAM (MB) Heap Buffer
0 Present 0 0 0 0 0
1 Online - Standby 41 4 0 64 16 46
```

For M160 routers:

```
user@host> show chassis sfm
Temp  CPU Utilization (%)  Memory  Utilization (%)
Slot State              (C)  Total  Interrupt  DRAM (MB) Heap  Buffer
0  Online                41    3      0         64    17    46
1  Online                44    3      0         64    17    46
2  Online                44    3      0         64    17    46
3  Present               0     0      0         0     0     0

Packet scheduling mode: Disabled
```

**What It Means** The sample output confirms that the SFM `online` command has been initiated and specifies to use the `show chassis sfm` CLI command to verify that the SFM is online. The command output shows that the SFM is present and that the values for the SFM status are 0 for approximately 5 seconds until the SFM is active.

### Step 3: Switch SFM Mastership

**Purpose** You can switch SFM mastership on M40e routers only. By default, the SFM in slot 0 (SFM0) is the master and the SFM in slot 1 (SFM1) is the backup.

To change the default master SFM, include the `sfm` statement at the `[edit chassis redundancy]` hierarchy level in the configuration. For more information, see the *JUNOS System Basics Configuration Guide*.

**Action** To switch SFM mastership, use the following CLI command:

```
user@host> request chassis sfm master switch <no-confirm>
```

**Sample Output**

```
user@host> request chassis sfm master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between system forwarding module? [yes,no] (no) yes
Switch initiated, use "show chassis sfm" to verify
```

The following command output displays if you use the `no-confirm` option:

```
user@host> request chassis sfm master switch no-confirm
Switch initiated, use "show chassis sfm" to verify
```

## Replacing an SFM

**Action** To replace an SFM, follow these steps:

1. Have ready an antistatic mat for the SFM.
2. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
3. Remove the router rear component cover by loosening the screws on the corners of the cover and pulling it straight out from the chassis.
4. Press the offline button on the SFM faceplate and hold it down until the red **FAIL** LED lights (about 5 seconds).

5. Loosen the thumbscrews on the ejector locking tabs joining the two SFM boards.
6. Flip the ends of the ejector handles outward.
7. Grasp the handles, pull firmly on the SFM, and slide the unit about three-quarters of the way out of the chassis.
8. Move one of your hands underneath the SFM to support it, and slide it completely out of the chassis.
9. Hold the new SFM by placing one hand underneath to support it and the other hand on one of the ejector handles on the front of the unit.
10. Align the rear of the SFM with the guides inside the chassis.
11. Slide the unit completely into the chassis.
12. Press the ejector handles on the left and right sides of the SFM inward.
13. Tighten the thumbscrews on the ejector locking tabs.
14. Press the offline button on the SFM faceplate and hold it down until the green OK LED lights (about 5 seconds).
15. Reinstall the rear component cover and tighten the screws on the covers of the corner to secure it to the chassis.



## Chapter 45

# Monitoring Redundant PCGs

You monitor redundant Packet Forwarding Engine clock generators (PCGs) to ensure that a clocking signal is generated to synchronize the internal M40e and M160 router Packet Forwarding Engine components. (See Table 125.)

**Table 125: Checklist for Monitoring Redundant PCGs**

Monitor Redundant PCG Tasks	Command or Action
<b>Understanding Redundant PCGs on page 596</b>	
<b>Displaying Redundant PCG Hardware Information on page 597</b>	show chassis hardware
<b>Monitoring Redundant PCG Status on page 597</b>	
1. Monitor the Redundant PCG Environmental Status on page 597	show chassis environment show chassis environment pcg
2. Display the Redundant PCG Status from the Craft Interface on page 598	show chassis craft-interface
3. Check the PCG LED Status on the Faceplate on page 599	Remove the rear component cover and look on the PCG faceplate at the back of the M40e or M160 router chassis.
<b>Determining Redundant PCG Mastership on page 599</b>	
1. Display the PCG Master from the Craft Interface on page 599	show chassis craft-interface
2. Check the PCG LEDs on the Faceplate on page 600	Remove the rear component cover and look on the PCG faceplate at the rear of the M40e or M160 router chassis.
3. Display the Packet Forwarding Engine Current Clock Source on page 600	show chassis clocks
<b>Displaying PCG Failure Alarms on page 600</b>	show chassis alarms
<b>Replacing a PCG on page 601</b>	See “Return the Failed Component” on page 86, or follow the procedure in the M40e or M160 router hardware guide.
<b>Bringing the Replaced PCG Online on page 602</b>	request chassis pcg slot <i>slot-number</i> online
<b>Verifying That the Replaced PCG Is Online on page 602</b>	
1. Display the Replaced PCG Environmental Status on page 602	show chassis environment pcg
2. Display PCG Messages in the System Log File on page 603	show log messages   match PCG
3. Display PCG Error Messages in the Chassis Daemon Log File on page 603	show log chassisd   match PCG

**See Also** ■ Monitoring the PCG on page 369


## Understanding Redundant PCGs

**Purpose** You monitor redundant PCGs to ensure that they generate a clock signal to synchronize the modules and application-specific integrated circuits (ASICs) that make up the Packet Forwarding Engine.

**What Are Redundant PCGs** Redundant PCGs are two PCGs installed in a router. The PCG supplies a 125-MHz system clock to synchronize the modules and ASICs that make up the Packet Forwarding Engine.

The M40e and M160 routers have two PCGs located at the rear of the chassis in the slots labeled PCG0 and PCG1, to the right of the Routing Engine slots (see Figure 230).

**Figure 230: M40e and M160 Router PCG Location**



During normal operation, both PCGs generate a 125-MHz clock signal to the Packet Forwarding Engine modules, along with a signal indicating which is the master clock source. One PCG is designated as the master. The master Routing Engine controls which PCG is master and which is backup.

The modules and ASICs in the Packet Forwarding Engine that use the clock signal to gate packet processing use only the signal from the master PCG.

The PCGs are field-replaceable and hot-pluggable. You can remove and replace them without powering down the router, but the routing functions of the system are interrupted when a PCG is removed.

If the master PCG fails or you remove it from the chassis, the Packet Forwarding Engine resets so that the components start using the signal from the other PCG (which becomes the master). Packet forwarding halts while there is no clock signal because the Packet Forwarding Engine does not accept incoming packets. If the backup PCG fails or is removed, router function is not affected.

## Displaying Redundant PCG Hardware Information

**Action** To display redundant PCG hardware information, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis                               20079          M160
Midplane         REV 03   710-001245   AB4132
FPM CMB          REV 02   710-001642   AB3264
FPM Display      REV 02   710-001647   AB3046
CIP              REV 04   710-001593   AB3284
PEM 0            Rev 03   740-001243   KM28409        DC
PEM 1            Rev 03   740-001243   KM13359        DC
PCG 0            REV 02   710-001568   AB3013
PCG 1            REV 02   710-001568   AB3000
[...Output truncated...]
```

**What It Means** The command output displays the PCG slot number, revision level, part number, and serial number.

## Monitoring Redundant PCG Status

**Steps To Take** To monitor the PCG status, follow these steps:

1. Monitor the Redundant PCG Environmental Status on page 597
2. Display the Redundant PCG Status from the Craft Interface on page 598
3. Check the PCG LED Status on the Faceplate on page 599

### Step 1: Monitor the Redundant PCG Environmental Status

**Action** To monitor the PCG environment status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@host> show chassis environment
Class Item             Status  Measurement
Power PEM 0            OK
      PEM 1            OK
Temp  PCG 0            OK      41 degrees C / 105 degrees F
      PCG 1            OK      39 degrees C / 102 degrees F
[...Output truncated...]
```

**What It Means** The command output displays the slot number, status, and temperature of each PCG.

**Alternative Action** If there is a problem with the PCG status, you can display more detailed PCG environmental information with the following CLI command:

```
user@host> show chassis environment pcg
```

The command output is as follows:

```
PCG 0 status:
State                Online - PFE clock source
Temperature           41 degrees C / 105 degrees F
Frequency:
  Setting             125.00 MHz
  Measurement         125.03 MHz
Power:
  3.3 V               3266 mV
  5.0 V bias          4981 mV
  8.0 V bias          8168 mV
CMB Revision         12
PCG 1 status:
State                Online
Temperature           39 degrees C / 102 degrees F
Frequency:
  Setting             125.00 MHz
  Measurement         125.03 MHz
Power:
  3.3 V               3271 mV
  5.0 V bias          4971 mV
  8.0 V bias          8175 mV
CMB Revision         12
```

The command output displays the status for each PCG. The operating status can be **Present**, **Online**, **Offline**, or **Empty**. If **Online**, it can be the current PFE clock source (master) or backup. The command output displays the temperature of the air flowing past the PCG and the frequency setting and measurement for the PCG. The command output also displays information about the PCG power supplies and the revision level of the chassis management bus (CMB) slave.

## Step 2: Display the Redundant PCG Status from the Craft Interface

**Action** To display the PCG LED states, use the following CLI command:

```
user@host> show chassis craft-interface
```

```
Sample Output user@host> show chassis craft-interface
[...Output truncated...]
PCG LEDs:
  PCG  0  1
-----
Amber  .  .
Green  *  *
Blue   *  .

[...Output truncated...]
```

**What It Means** The command output is for an M160 router. The PCGs in slots 0 and 1 are online and are functioning normally. The status colors represent the possible PCG operating states: **Amber** (Fail), **Green** (OK), and **Blue** (Master). The (\*) indicates the current operating state.

### Step 3: Check the PCG LED Status on the Faceplate

**Action** To check the PCG LEDs, remove the rear component cover and look on the PCG faceplate at the rear of the M40e or M160 router chassis.

Table 126 describes the functions of these LEDs.

**Table 126: PCG LEDs**

Color	Label	State	Description
Blue	MASTER	On steadily	PCG is master.
Green	OK	On steadily	PCG is operating normally.
		Blinking	PCG is starting up.
Amber	FAIL	On steadily	PCG has failed.

## Determining Redundant PCG Mastership

If both PCGs are installed and functioning normally, PCG0 is the master and PCG1 is the backup by default.

- Steps To Take** To determine which PCG is operating as the master, follow these steps:
1. Display the PCG Master from the Craft Interface on page 599
  2. Check the PCG LEDs on the Faceplate on page 600
  3. Display the Packet Forwarding Engine Current Clock Source on page 600

### Step 1: Display the PCG Master from the Craft Interface

**Action** To determine the PCG master from the craft interface status information, use the following CLI command:

```
user@host> show chassis craft-interface
```

**Sample Output**

```
user@host> show chassis craft-interface
[...Output truncated...]
PCG LEDs:
  PCG  0    1
-----
Amber   .    .
Green  *    *
Blue   *    .

[...Output truncated...]
```

**What It Means** The command output shows that PCG0 is the master because the blue MASTER LED is on.

**Step 2: Check the PCG LEDs on the Faceplate**

**Action** To check the PCG LEDs, look on the PCG faceplate at the rear of the M40e or M160 router chassis. Table 126 on page 599 describes the PCG LED states. If the blue MASTER LED on the PCG faceplate is on steadily, the PCG is functioning as master.

**Step 3: Display the Packet Forwarding Engine Current Clock Source**

The Packet Forwarding Engine current clock source is the master PCG.

**Action** To display the PCG master from the Packet Forwarding Engine clock source output, use the following CLI command:

```
user@host> show chassis clocks
```

**Sample Output**

```
user@host> show chassis clocks
PFE clock status:
  Current source          PCG 0
  Measured frequency      125.03 MHz
Reference clock status:
  Current source          Primary
  Primary source          Internal
  Secondary source        Internal
  Tertiary source         Internal
  Rollover algorithm      Holdover
  PLL mode                Free-running
  PLL errors              0
  Sync message current    0x00
  Sync message normal     0x00
  Sync message override   0x00
```

**What It Means** The command output shows that the PCG in slot 0 is the primary clock source or master.

**Displaying PCG Failure Alarms**

**Action** To display the current PCG alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
2 alarms currently active
Alarm time          Class Description
2002-06-11 20:30:29 PDT Minor PCG 0 Not Online
2002-06-11 20:30:32 PDT Minor No PCGs Online
```

**What It Means** The command output displays the alarm date, time, severity level, and description.

## Replacing a PCG

---

The PCGs are hot-pluggable. You can remove and replace them without powering down the router; however, the routing functions of the system are interrupted when the PCG is removed.

If both PCGs are installed and functioning normally, **PCG0** is the master PCG and **PCG1** is the backup by default.

Removing the backup PCG does not affect the functioning of the router. Taking the master PCG offline causes the Flexible PIC Concentrators (FPCs) and Switching and Forwarding Modules (SFMs) to power down and restart, with the other PCG selected as master. The forwarding and routing functions are interrupted during this process.

**Action** To remove and replace a PCG, follow these steps:

1. Lay an electrostatic bag or antistatic mat on a flat, stable surface to receive the PCG.
2. Attach an electrostatic discharge (ESD) strap to your bare wrist and connect the strap to one of the ESD points on the chassis.
3. Remove the rear component cover by loosening the screws at the corners of the cover and pulling it straight off of the chassis.
4. Press and hold the offline button on the PCG faceplate until the amber LED labeled **FAIL** lights, which takes about 3 seconds.

If you are removing the master PCG, forwarding halts while the Packet Forwarding Engine resets so that the components start using the clock signal from the other PCG, which becomes the master.

5. Loosen the mounting screw on the right edge of the PCG faceplate, using a Phillips screwdriver if necessary.
6. Grasp the screw and slide the PCG about halfway out of the chassis.



**CAUTION:** Be careful to slide the PCG straight out of the chassis to avoid bending any of the pins on the underside of the board.

---

7. Place one hand under the PCG to support it, slide it completely out of the chassis, and place it on the antistatic mat or in the electrostatic bag.
8. Slide the PCG all the way into the card cage until it contacts the midplane.
9. Tighten the thumbscrew on the right side of the PCG faceplate.
10. Verify that the PCG is properly installed by looking at the LEDs on the PCG faceplate. The green **OK** LED should light steadily.
11. Reinstall the rear component cover and tighten the thumbscrews on the corners of the cover to secure it to the chassis.

## Bringing the Replaced PCG Online

---

**Action** To bring the replaced PCG online, use the following CLI command:

```
user@host> request chassis pcg slot slot-number online
```

**Sample Output** user@host> request chassis pcg slot 0 online  
Online initiated, use 'show chassis environment pcg' to verify

**What It Means** The PCG in slot 0 is brought online.

## Verifying That the Replaced PCG Is Online

---

**Steps To Take** To verify that the replaced PCG is online, follow these steps:

1. Display the Replaced PCG Environmental Status on page 602
2. Display PCG Messages in the System Log File on page 603
3. Display PCG Error Messages in the Chassis Daemon Log File on page 603

### Step 1: Display the Replaced PCG Environmental Status

**Action** To verify that the replaced PCG is online, use the following CLI command:

```
user@host> show chassis environment pcg
```

**Sample Output**

```
user@host> show chassis environment pcg
PCG 0 status:
  State                Online
  Temperature          30 degrees C / 86 degrees F
  Frequency:
    Setting             125.00 MHz
    Measurement         125.01 MHz
  Power:
    3.3 V               3278 mV
    5.0 V bias          4986 mV
    8.0 V bias          8222 mV
  CMB Revision         12
PCG 1 status:
  State                Online - PFE clock source
  Temperature          43 degrees C / 109 degrees F
  Frequency:
    Setting             125.00 MHz
    Measurement         124.95 MHz
  Power:
    3.3 V               3269 mV
    5.0 V bias          4991 mV
    8.0 V bias          8222 mV
  CMB Revision         12
```

**What It Means** When the replaced PCG is brought online, it does not automatically become master. It remains as the backup PCG until the master PCG fails, or you manually switch it to master by using the request chassis pcg online slot 1 CLI command.



## Step 2: Display PCG Messages in the System Log File

**Action** To display the PCG error messages in the system log file to verify that a replaced PCG is online, use the following CLI command:

```
user@host> show log messages | match PCG
```

**Sample Output**

```
user@host> show log messages | match PCG
Aug 27 15:20:52 myrouter craftd[563]: Minor alarm cleared, PCG 0 Not Online
Aug 27 15:20:52 myrouter alarmd[562]: Alarm cleared: PCG color=YELLOW,
class=CHASSIS, reason=PCG 0 Not Online
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match pcg` command to see error messages that are generated when a PCG fails or is offline. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

## Step 3: Display PCG Error Messages in the Chassis Daemon Log File

**Action** To display the PCG error messages in the chassis daemon (chassisd) log file and verify that a replaced PCG is online, use the following CLI command:

```
user@host> show log chassisd | match PCG
```

**Sample Output**

```
user@host> show log chassisd | match PCG
Aug 27 15:20:51 PCG 0 power verified on in 16 ms
Aug 27 15:20:52 reading PCG 0 initial state
Aug 27 15:20:52 CMB readback PCG 0 [0xe2, 0xff] -> 0xc
Aug 27 15:20:52 reading PCG 0 ideeprom
Aug 27 15:20:52 CMB cmd to PCG 0 [0xe2], Green LED On [0x1b]
Aug 27 15:20:52 PCG 0 - Green LED On
Aug 27 15:20:52 PCG 0 clear alarm 0x3
Aug 27 15:20:52 alarm op fru 1 op 0 reason 3
Aug 27 15:20:52 send: yellow alarm clear, class 100 obj 110 reason 3.
```

**What It Means** The chassisd database provides the date, time, and a component status message. The chassisd database is dynamic. It is initialized at router startup and is updated when components are added or removed.



## Chapter 46

# Monitoring Redundant SSBs

You monitor redundant M20 router System and Switch Boards (SSBs) to ensure that they do the following (see Table 127):

- Provide allocation of incoming data packets throughout shared memory on the Flexible PIC Concentrators (FPCs)
- Transfer outgoing data cells to the FPCs for packet reassembly
- Perform route lookups using the forwarding table, and monitor system components for failure and alarm conditions
- Monitor FPC operation and reset

**Table 127: Checklist for Monitoring Redundant SSBs**

Monitor Redundant SSB Tasks	Command or Action
<b>Understanding Redundant SSBs on page 606</b>	
<b>Displaying Redundant SSB Configuration on page 608</b>	configure show
<b>Displaying Redundant SSB Hardware Information on page 608</b>	show chassis hardware
<b>Monitoring Redundant SSB Status on page 609</b>	
1. Display the Redundant SSB Environmental Status on page 609	show chassis environment
2. Display the Redundant SSB Detailed Status on page 610	show chassis ssb slot
3. Check the Redundant SSB LEDs on page 610	Check the LEDs on the SSB faceplate.
<b>Displaying Redundant SSB Mastership on page 611</b>	
1. Display SSB Mastership from the Command Line on page 611	show chassis ssb
2. Check the SSB Mastership from the LEDs on page 612	Check the LEDs on the SSB panel of the craft interface.
<b>Checking for SSB Alarms on page 612</b>	
1. Display the Current SSB Alarms on page 612	show chassis alarms
2. Display SSB Error Messages in the System Log File on page 612	show log messages
3. Display SSB Error Messages in the Chassis Daemon Log File on page 613	show log chassisd

Monitor Redundant SSB Tasks	Command or Action
<b>Verifying SSB Failure on page 613</b>	
1. Check the SSB Connection on page 614	Check the thumbscrews on the left and right sides of the SSB.
2. Perform a Swap Test on the SSB on page 614	<ol style="list-style-type: none"> <li>1. Take the SSB offline.</li> <li>2. Remove the SSB.</li> <li>3. Replace the SSB with one that you know works.</li> <li>4. Verify that the new SSB works by using the <code>show chassis ssb</code> CLI command.</li> </ol>
<b>Switch SSB Mastership on page 615</b>	<code>request chassis ssb master switch &lt;no-confirm&gt;</code>
<b>Replacing the SSB on page 616</b>	
	<ol style="list-style-type: none"> <li>1. Take the SSB offline.</li> <li>2. Remove the SSB.</li> <li>3. Install a new SSB.</li> <li>4. Verify that the new SSB works by using the <code>show chassis ssb</code> CLI command.</li> </ol>

## Understanding Redundant SSBs

**Purpose** Inspect redundant SSBs to ensure that they provide allocation of incoming data packets throughout shared memory on the FPCs, transfer outgoing data cells to the FPCs for packet reassembly, perform route lookups using the forwarding table, monitor system components for failure and alarm conditions, and monitor FPC operation and reset.


**What Are Redundant SSBs** SSBs are redundant when two SSBs are installed in the M20 router. The SSBs occupy the two top slots of the card cage (**SSB0** and **SSB1**), and are installed into the midplane from the front of the chassis (see Figure 231 on page 607). By default, **SSB0** is the master SSB and **SSB1** is the backup. When the master SSB fails, automatic failover occurs and the backup SSB becomes the master. You can control which SSB is the master by including the `ssb` statement at the `[edit chassis redundancy]` hierarchy level in the configuration. For more information, see the *JUNOS System Basics Configuration Guide*.

The SSB performs the following major functions:

- Shared memory management on the FPCs—The Distributed Buffer Manager application-specific integrated circuit (ASIC) on the SSB uniformly allocates incoming data packets throughout shared memory on the FPCs.
- Outgoing data cell transfer to the FPCs—A second Distributed Buffer Manager ASIC on the SSB passes data cells to the FPCs for packet reassembly when the data is ready to be transmitted.
- Route lookups—The Internet Processor ASIC on the SSB performs route lookups using the forwarding table stored in synchronous SRAM (SSRAM). After performing the lookup, the Internet Processor ASIC informs the midplane of the forwarding decision, and the midplane forwards the decision to the appropriate outgoing interface.

- **System component monitoring**—The SSB monitors other system components for failure and alarm conditions. It collects statistics from all sensors in the system and relays them to the Routing Engine, which sets the appropriate alarm. For example, if a temperature sensor exceeds the first internally defined threshold, the Routing Engine issues a “high temp” alarm. If the sensor exceeds the second threshold, the Routing Engine initiates a system shutdown.
- **Exception and control packet transfer**—The Internet Processor ASIC passes exception packets to a microprocessor on the SSB, which processes almost all of them. The remaining packets are sent to the Routing Engine for further processing. Any errors that originate in the Packet Forwarding Engine and are detected by the SSB are sent to the Routing Engine using system log messages.
- **FPC reset control**—The SSB monitors the operation of the FPCs. If it detects errors in an FPC, the SSB attempts to reset the FPC. After three unsuccessful resets, the SSB takes the FPC offline and informs the Routing Engine. Other FPCs are unaffected, and normal system operation continues.

**Figure 231: M20 Router Redundant SSB Location**



The SSB houses the Internet Processor ASIC and two Distributed Buffer Manager ASICs.

The SSB is hot-pluggable. You can remove and replace it without powering down the system; however this causes major impact to the system. The following functions cannot occur while the SSB is removed from the router:

- Route lookups
- System component monitoring
- Exception and control packet monitoring
- FPC resets

When you remove the SSB, all packet forwarding stops immediately and the Routing Engine responds by generating alarms. When you replace the SSB, it is rebooted by flash EEPROM.

If you remove the Routing Engine, the SSB enters a warm shutdown mode and continues its forwarding process for a limited time using a frozen forwarding table. The time limit is determined by a timer in the SSB. If you replace the Routing Engine during the warm shutdown period, the SSB unfreezes its forwarding tables and resumes normal functioning. Otherwise, the SSB shuts itself down.

## Displaying Redundant SSB Configuration

You can configure which SSB is the master and which is the backup. By default, the SSB in slot 0 is the master and the SSB in slot 1 is the backup. You can modify the default configuration by including the **ssb** statement at the [edit chassis redundancy] hierarchy level.



**NOTE:** We recommend that both Routing Engines have the same configuration.

To display the current SFM redundancy configuration, follow these steps:

1. Enter the CLI configuration mode using the following command:

```
user@host# configure
```

2. Go to the [edit chassis redundancy] hierarchy level.

3. Show the SFM configuration using the following command:

```
user@host# show
```

## Displaying Redundant SSB Hardware Information

**Action** To display the SSB hardware information, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output** user@host> **show chassis hardware**

```
Hardware inventory:
Item           Version  Part number  Serial number  Description
[...Output truncated...]
SSB slot 0     REV 01   710-001951   AD5904         Internet Processor II
SSB slot 1     N/A     N/A         N/A            backup
[...Output truncated...]
```

**What It Means** The command output displays the SSB version level, part number, serial number, and description.

## Monitoring Redundant SSB Status

---

**Steps To Take** To monitor the SSB, follow these steps:

1. Display the Redundant SSB Environmental Status on page 609
2. Display the Redundant SSB Detailed Status on page 610
3. Check the Redundant SSB LEDs on page 610

### Step 1: Display the Redundant SSB Environmental Status

**Action** To display the SSB environmental status, use the following CLI command:

```
user@host> show chassis environment
```

**Sample Output**

```
user@host> show chassis environment
Class Item                Status      Measurement
Power Power Supply A      Failed
        Power Supply B      OK
Temp  FPC Slot 0              OK          27 degrees C / 80 degrees F
        FPC Slot 1          OK          30 degrees C / 86 degrees F
        FPC Slot 2          OK          26 degrees C / 78 degrees F
        FPC Slot 3          OK          25 degrees C / 77 degrees F
        Power Supply A      OK          28 degrees C / 82 degrees F
        Power Supply B      OK          24 degrees C / 75 degrees F
        SSB Slot 0          OK          25 degrees C / 77 degrees F
        Backplane           OK          21 degrees C / 69 degrees F
Fans  Rear Fan              OK          Spinning at normal speed
        Upper Fan           OK          Spinning at normal speed
        Middle Fan          OK          Spinning at normal speed
        Bottom Fan          OK          Spinning at normal speed
Misc  Craft Interface        OK
```

**What It Means** The command output displays the SSB status and temperature. The SSB status can be OK, Failed, or Absent.

## Step 2: Display the Redundant SSB Detailed Status

**Action** To display more detailed SSB status information, use the following CLI command:

```
user@host> show chassis ssb
```

**Sample Output**

```
user@host> show chassis ssb
SSB status:
  Failover:                0 time
  Slot 0:
    State:                  Master
    Temperature:            33 Centigrade
    CPU utilization:        0 percent
    Interrupt utilization:   0 percent
    Heap utilization:        0 percent
    Buffer utilization:       6 percent
    DRAM:                   64 Mbytes
    Start time:              1999-01-15 22:05:36 UTC
    Uptime:                  21 hours, 21 minutes, 22 seconds
  Slot 1:
    State:                  Backup
```

**What It Means** The command output displays the number of times the mastership has changed, the SSB slot number 0 or 1, and the current state of the SSB: **Master**, **Backup**, or **Empty**. The command output displays the temperature of the air passing by the SSB, in degrees Centigrade. It also displays the total percentage of CPU, interrupt, heap space, and buffer space being used by the SSB processor, including the total DRAM available to the SSB processor. The command output displays the time when the SSB started running and how long it has been running.

**Alternative Action** To display the status for a particular SSB, use the following CLI command:


```
user@host> show chassis ssb slot
```

## Step 3: Check the Redundant SSB LEDs

Periodically check the SSB LEDs to verify that the SSB is online or offline and the type of task it is performing.

**Action** To check the SSB LEDs, look on the faceplate at the front of the router (see Figure 232).

**Figure 232: SSB LEDs**





The SSB has two groups of LEDs: online/offline LEDs and status LEDs. The online/offline LEDs indicate whether the SSB is online or offline. The status LEDs indicate what type of task the SSB is performing. Table 128 describes the SSB LEDs.

**Table 128: SSB LED States**

Label	Color	State	Description
OFFLINE	Amber	On steadily	SSB is offline.
ONLINE	Green	On steadily	SSB processor is running.
MASTER	Blue	On steadily	SSB is master.
STATUS (left)	Green	Blinking	SSB processor is running. Normally, the blinking is faint and becomes bright only when the SSB is processing many exceptions.
STATUS (right)	Green	Flashing	I/O interrupts are occurring.

## Displaying Redundant SSB Mastership

**Steps To Take** To display the SSB mastership information, follow these steps:

1. Display SSB Mastership from the Command Line on page 611
2. Check the SSB Mastership from the LEDs on page 612

### Step 1: Display SSB Mastership from the Command Line

**Action** To display more detailed SSB status information, use the following CLI command:

```
user@host> show chassis ssb
```

**Sample Output**

```
user@host> show chassis ssb
SSB status:
  Failover:                                0 time
  Slot 0:
    State:                                Master
    Temperature:                          33 Centigrade
    CPU utilization:                       0 percent
    Interrupt utilization:                 0 percent
    Heap utilization:                     0 percent
    Buffer utilization:                     6 percent
    DRAM:                                 64 Mbytes
    Start time:                           1999-01-15 22:05:36 UTC
    Uptime:                               21 hours, 21 minutes, 22 seconds
  Slot 1:
    State:                                Backup
```

**What It Means** The command output displays the number of times the mastership has changed, the SSB slot number 0 or 1, and the current state of the SSB: **Master**, **Backup**, or **Empty**. The command output displays the temperature of the air passing by the SSB, in degrees Centigrade. It also displays the total percentage of CPU, interrupt, heap space, and buffer space being used by the SSB processor, including the total DRAM available to the SSB processor. The command output displays the time when the SSB started running and how long it has been running.

## Step 2: Check the SSB Mastership from the LEDs

**Action** To check the SSB mastership from the LEDs, look on the faceplate at the front of the router (see Figure 232 on page 610).

The SSB has two groups of LEDs: online/offline LEDs and status LEDs. The online/offline LEDs indicate whether the SSB is online or offline. The status LEDs indicate what type of task the SSB is performing. Table 128 on page 611 describes the SSB LEDs.

## Checking for SSB Alarms

---

**Steps To Take** To check for SSB alarms, follow these steps:

1. Display the Current SSB Alarms on page 612
2. Display SSB Error Messages in the System Log File on page 612
3. Display SSB Error Messages in the Chassis Daemon Log File on page 613

## Step 1: Display the Current SSB Alarms

**Action** To display the current SSB alarms, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
2 alarms currently active
Alarm time           Class  Description
2002-06-05 19:55:57 UTC Major  fxp0: ethernet link down
```

**What It Means** The command output displays the alarm date, time, severity level, and description. An SSB failure or removal generates an **fxp0** link alarm. The **fxp0** link is the dedicated 100-Mbps Fast Ethernet link between the SSB and the Routing Engine. This link transfers routing table data from the Routing Engine to the forwarding table in the Internet Processor ASIC. The link also transfers, from the SSB to the Routing Engine, routing link-state updates and other packets destined for the router that have been received through the router interfaces.

## Step 2: Display SSB Error Messages in the System Log File

Periodically check the system log messages on the management console for messages sent by the SSB. During normal operation, the SSB notifies the Routing Engine of any errors it detects.

**Action** To display the SSB error messages in the system log file, use the following CLI command:

```
user@host> show log messages
```

**Sample Output**

```
user@host> show log messages
Jul 10 13:28:45 myrouter /kernel: fxp1: media DOWN 100Mb / full-duplex
Jul 10 13:28:45 myrouter /kernel: fxp1: media DOWN 10Mb / half-duplex
Jul 10 13:28:45 myrouter /kernel: fxp1: media DOWN 100Mb / full-duplex
Jul 10 13:28:45 myrouter /kernel: fxp1: link UP 100Mb / full-duplex
Jul 10 13:28:45 myrouter rpd[564]: EVENT <UpDown> fxp1.0 index 1 <Up Broadcast Multicast> address #0 0.a0.a5.12.1d.6d
Jul 10 13:28:45 myrouter mib2d[563]: SNMP_TRAP_LINK_UP: ifIndex 2, ifAdminStatus up(1), ifOperStatus up(1), ifName fxp1
[...Output truncated...]
```

**What It Means** The messages system log file records the time the failure or event occurred, the severity level, a code, and a message description. You can also use the `show log messages | match ssb` command to see error messages that are generated when an SSB fails or is offline. Use this information to diagnose a problem and to let the Juniper Networks Technical Assistance Center (JTAC) know what error messages were generated and the router events that occurred before and after the problem. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

### Step 3: Display SSB Error Messages in the Chassis Daemon Log File

**Action** To display the SSB error messages in the chassis daemon (chassisd) log file, use the following CLI command:

```
user@host> show log chassisd
```

**Sample Output**

```
user@host> show log chassisd
Jul 10 13:27:28 SSB0 is now not present
Jul 10 13:27:28 Assert reset on SSB0
Jul 10 13:27:28 Turn on ethernet loop
[...Output truncated...]
```

**What It Means** The command output displays the SSB hardware version level, part number, and serial number.

## Verifying SSB Failure

**Steps To Take** To verify SSB failure, follow these steps:

1. Check the SSB Connection on page 614
2. Perform a Swap Test on the SSB on page 614

**Step 1: Check the SSB Connection**

If the SSB is not seated properly, it will not function.

**Action** To check the SSB connection, make sure that the SSB is properly seated in the slot. To seat the SSB properly adequately, tighten the screws on the left and right sides of the card carrier.

**Step 2: Perform a Swap Test on the SSB**

**CAUTION:** Before performing a swap test, always check for bent pins in the midplane and check the SCB for stuck pins in the connector. Pins stuck in the component connector can damage other good slots during a swap test.

**Action** To perform a swap test on the SSB, follow these steps:

1. Attach an electrostatic discharge (ESD) wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Locate the SSB offline switch on the front panel and press and hold the switch for 5 seconds to take the SSB offline.



**CAUTION:** If you take the SSB offline, packet forwarding will be affected.

3. Unscrew the thumbscrews on the left and right sides of the card carrier to unseat the SSB from the midplane.
4. Flip the ends of the two extractor clips, which are adjacent to the thumbscrews, towards the outside edges of the router.
5. Grasp both sides of the card carrier and slide the SSB about three-quarters of the way out of the router.
6. Move one of your hands underneath the SSB to support it, and slide it completely out of the chassis.
7. Replace the SSB with one that you know works.
8. Grasp the front of the SSB card carrier with both hands and align the back of the card carrier with the slide guides on the chassis.
9. Slide the SSB card carrier all the way into the card cage until it contacts the midplane.
10. Flip the extractor clips, located on the left and right sides of the card carrier, towards each other to secure the SSB in place.

11. Tighten the thumbscrews on the left and right sides of the card carrier to seat the SSB.



**NOTE:** To seat the SSB properly, be sure to tighten the screws adequately. If the SSB is not seated properly, it will not function.

12. Verify that the SSB works by using the `show chassis ssb` CLI command. (See “Display the Redundant SSB Detailed Status” on page 610.)

## Switch SSB Mastership

**Purpose** To change the default master SSB, include the `ssb` statement at the `[edit chassis redundancy]` hierarchy level in the configuration. For more information, see the *JUNOS System Basics Configuration Guide*.

**Action** To control which SSB is master, use the following CLI command:

```
user@host> request chassis ssb master switch <no-confirm>
```

**Sample Output**

```
user@host> request chassis ssb master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between system switch boards ? [yes,no] (no) yes
Switch initiated, use "show chassis ssb" to verify
```

If you use the `no-confirm` option, the command output is as follows:

```
user@host> request chassis ssb master switch no-confirm
Switch initiated, use "show chassis ssb" to verify
```

**What It Means** By default, the SSB in slot 0 (SSB0) is the master and the SSB in slot 1 (SSB1) is the backup.



**NOTE:** For routers that have two SSBs, both SSBs must be running JUNOS Release 4.0 or later. Do not run JUNOS Release 3.4 on one of the SSBs and JUNOS Release 4.0 or later on the other.

JUNOS Release 3.4 does not support SSB redundancy; if you are using this release of the software, only one SSB can be installed in the router. It can be installed in either slot.

The configurations on the two SSBs do not have to be the same, and they are not automatically synchronized. If you configure both SSBs as masters, when the chassis software restarts for any reason, the SSB in slot 0 becomes the master and the SSB in slot 1 becomes the backup.

## Replacing the SSB

---

**Purpose** The SSB is hot-pluggable. When the SSB is removed, all packet forwarding stops immediately and the Routing Engine responds by sending alarms through the Ethernet channel to the management console. When the SSB is replaced, it is rebooted by flash EEPROM.

**Action** To replace a failed SSB, follow these steps:

1. Attach an ESD wrist strap to your bare wrist, and connect the wrist strap to one of the two ESD points on the chassis.
2. Locate the SSB offline switch on the front panel and press and hold the switch for 5 seconds to take the SSB offline.



**CAUTION:** If you take the SSB offline, packet forwarding will be affected.

---

3. Unscrew the thumbscrews on the left and right sides of the card carrier to unseat the SSB from the midplane.
4. Flip the ends of the two extractor clips, which are adjacent to the thumbscrews, towards the outside edges of the router.
5. Grasp both sides of the card carrier and slide the SSB about three-quarters of the way out of the router.
6. Move one of your hands underneath the SSB to support it, and slide it completely out of the chassis.
7. Replace the SSB with one that you know works.
8. Grasp the front of the SSB card carrier with both hands and align the back of the card carrier with the slide guides on the chassis.
9. Slide the SSB card carrier all the way into the card cage until it contacts the midplane.
10. Flip the extractor clips, located on the left and right sides of the card carrier, towards each other to secure the SSB in place.
11. Tighten the thumbscrews on the left and right sides of the card carrier to seat the SSB.



**NOTE:** To seat the SSB properly, be sure to tighten the screws adequately. If the SSB is not seated properly, it will not function.

---

12. Verify that the SSB works by using the `show chassis ssb` CLI command. (See “Display the Redundant SSB Detailed Status” on page 610.)

## Chapter 47

# Monitoring Redundant CFEBs

You monitor redundant Compact Forwarding Engine Boards (CFEBs) in the M10i router. A CFEB provides route lookup, filtering, and switching on incoming data packets, then directs outbound packets to the appropriate interface for transmission to the network. (See Table 129.)

The M10i router CFEB can process 16 million packets per second (Mpps).

The CFEB communicates with the Routing Engine using a dedicated 100-Mbps Fast Ethernet link that transfers routing table data from the Routing Engine to the forwarding table in the integrated ASIC. The link is also used to transfer from the CFEB to the Routing Engine routing link-state updates and other packets destined for the router that have been received through the router interfaces.

**Table 129: Checklist for Monitoring the CFEB**

Monitor CFEB Tasks	Command or Action
<b>Understanding Redundant CFEBs on page 618</b>	
<b>Displaying Redundant CFEB Hardware Information on page 620</b>	show chassis hardware
<b>Displaying CFEB Mastership on page 620</b>	
1. Check CFEB LEDs on page 620	Look at the LEDs on the CFEB faceplate located on the rear of the router above the power supplies.
2. Display the CFEB Status on page 621	show chassis cfeb
<b>Display CFEB Alarms on page 621</b>	See “Checking for CFEB Alarms” on page 423. For conditions that trigger CFEB alarms, see “Display the Current Router Alarms” on page 61.
<b>Verifying CFEB Failure on page 621</b>	See “Verifying CFEB Failure” on page 621.
<b>Returning the CFEB on page 621</b>	See “Return the Failed Component” on page 86 or follow the procedure in the appropriate hardware guide.

## Understanding Redundant CFEBs

---

**Purpose** Monitor redundant CFEBs so they can provide route lookup, filtering, and switching on incoming data packets and direct outbound packets to the appropriate interface for transmission to the network.

**What Are Redundant CFEBs** Two CFEBs are installed in the M10i router. The M10i router CFEB processes 16 Mpps.

The CFEB performs the following functions:


- Route lookups—Performs route lookups using the forwarding table stored in the synchronous SRAM (SSRAM).
- Shared memory management—Uniformly allocates incoming data packets throughout the router's shared memory.
- Outgoing data packets transfer—Passes data packets to the destination FIC or PIC when the data is ready to be transmitted.
- Exception and control packet transfer—Passes exception packets to the microprocessor on the CFEB, which processes almost all of them. The rest are sent to the Routing Engine for further processing. Any errors originating in the Packet Forwarding Engine and detected by the CFEB are sent to the Routing Engine using system log messages.
- (M7i router only) Built-in tunnel interface—Encapsulates arbitrary packets inside a transport protocol, providing a private, secure path through an otherwise public network.

The built-in tunnel interface on the CFEB is configured the same way as a PIC. For information about configuring the built-in tunnel interface, see the *JUNOS Network Interfaces and Class of Service Configuration Guide*.

- (M7i router only) Optional Adaptive Services PIC–Integrated (ASP–I)—Provides one or more services on one PIC. See “Adaptive Services PIC–Integrated (ASP–I)” on page 11 for more information.

One or two CFEBs can be installed into the midplane from the rear of the chassis, as shown in Figure 233 on page 619. Only one CFEB is active at a time; the optional second CFEB is in standby mode. By default, the CFEB in slot **CFEB 0** is active. To modify the default, include the appropriate **cfep** statement at the [edit chassis redundancy] hierarchy level of the configuration, as described in the section about CFEB redundancy in the *JUNOS System Basics Configuration Guide*.



**Figure 233: M10i Router CFEB Location**

CFEBs are hot-pluggable. Removing the standby CFEB has no effect on router function. If the active CFEB fails or is removed from the chassis, the effect depends on how many CFEBs are installed:

- If there is one CFEB, forwarding halts until the CFEB is replaced and functioning again. It takes approximately one minute for the replaced CFEB to boot and become active. Reading in router configuration information can take additional time, depending on the complexity of the configuration.
- If there are two CFEBs, forwarding halts while the standby CFEB boots and becomes active, which takes approximately one minute. Synchronizing router configuration information can take additional time, depending on the complexity of the configuration.

- See Also**
- Host Redundancy Overview on page 463
  - Monitoring the CFEBs on page 417
  - Monitoring Redundant CFEBs on page 617
  - Monitoring the Routing Engine on page 125
  - Monitoring Redundant Routing Engines on page 491

## Displaying Redundant CFEB Hardware Information

**Action** To view redundant CFEB hardware information, use the following command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item              Version  Part number  Serial number  Description
Chassis           31655
Midplane          REV 04    710-008920   CD7925         M10i Midplane
Power Supply 0    Rev 05    740-008537   QE16399        AC Power Supply
Power Supply 1    Rev 05    740-008537   QF11145        AC Power Supply
HCM slot 0        REV 01    710-010580   CE1729         M10i HCM
HCM slot 1        REV 01    710-010580   CE1769         M10i HCM
Routing Engine 0  REV 00    740-011202   1000525660     RE-850
Routing Engine 1  REV 00    740-011202   1000540499     RE-850
CFEB slot 0       REV 03    750-010465   CC7348         Internet Processor II
CFEB slot 1       REV 03    750-010470   CC7350         Backup
[...Output truncated...]
```

**What It Means** The command output shows that two CFEBs are installed in the M10i router. The command output also displays the CFEB version level, part number, serial number, and description.

## Displaying CFEB Mastership

**Steps To Take** To display CFEB mastership, follow these steps:

1. Check CFEB LEDs on page 620
2. Display the CFEB Status on page 621

### Step 1: Check CFEB LEDs

Three LEDs—a green LED labeled **OK**, a red LED labeled **FAIL**, and a blue LED labeled **MASTER**—indicate CFEB status.

**Action** Look at the LEDs on the CFEB faceplate. The CFEB is located on the rear of the router above the power supplies (see Figure 233 on page 619). Table 130 describes the CFEB LED states.

**Table 130: CFEB LEDs**

Label	Color	State	Description
OK	Green	On steadily	CFEB is running normally.
		Blinking	CFEB is starting up.
FAIL	Red	On steadily	CFEB is not operational or is in reset mode.
MASTER	Blue	On steadily	CFEB is functioning as master.

## Step 2: Display the CFEB Status

**Action** To display CFEB status to show mastership, use the following CLI command:

```
user@host> show chassis cfeb
```

**Sample Output**

```
user@host> show chassis cfeb
CFEB status:
Slot 0 information:
  State                Master
  Intake temperature    29 degrees C / 84 degrees F
  Exhaust temperature   38 degrees C / 100 degrees F
  CPU utilization        3 percent
  Interrupt utilization  0 percent
  Heap utilization      10 percent
  Buffer utilization     22 percent
  Total CPU DRAM        128 MB
  Internet Processor II  Version 1, Foundry IBM, Part number 164
  Start time:           2004-09-28 03:07:54 PDT
  Uptime:               9 days, 18 hours, 36 minutes, 15 seconds
Slot 1 information:
  State                Backup
  Intake temperature    29 degrees C / 84 degrees F
  Exhaust temperature   38 degrees C / 100 degrees F
  CPU utilization        3 percent
  Interrupt utilization  0 percent
  Heap utilization      10 percent
  Buffer utilization     22 percent
  Total CPU DRAM        128 MB
  Internet Processor II  Version 1, Foundry IBM, Part number 164
  Start time:           2004-09-28 03:07:54 PDT
  Uptime:               9 days, 18 hours, 36 minutes, 15 seconds
```

**What It Means** The command output displays which CFEB is master and backup, as well as other environmental and memory information.

## Display CFEB Alarms

---

**Action** To display CFEB alarms, see “Checking for CFEB Alarms” on page 423. For conditions that trigger CFEB alarms, see “Display the Current Router Alarms” on page 61.

## Verifying CFEB Failure

---

**Action** To verify CFEB failure, see “Verifying CFEB Failure” on page 621.

## Returning the CFEB

---

**Action** To replace the CFEB, see “Return the Failed Component” on page 86, or follow the procedure in the *M10i Internet Router Hardware Guide*.



## Chapter 48

# Monitoring Redundant HCMs

You monitor redundant High-Availability Chassis Managers (HCMs) on the M10i router so they can work with a companion Routing Engine to provide control and monitoring functions for router components. The HCMs also display alarm status and take Physical Interface Cards (PICs) online and offline.

Table 131 provides a checklist of tasks for you to perform to monitor redundant HCMs.

**Table 131: Checklist for Monitoring Redundant HCMs**

Monitor Redundant HCM Tasks	Command or Action
<b>Understanding Redundant HCMs on page 624</b>	
<b>Displaying Redundant HCM Hardware Information on page 625</b>	show chassis hardware
<b>Displaying HCM Status and Mastership on page 625</b>	
1. Check the HCM LEDs on page 625	Look at the LEDs on the HCM faceplate. The master HCM LED light flashes blue.
2. Check the HCM Environmental Status on page 626	show chassis environment hcm
<b>Switching HCM Mastership on page 627</b>	request chassis routing-engine master switch
<b>Displaying HCM Alarms on page 628</b>	show chassis alarms
<b>Performing a Swap Test on an HCM on page 629</b>	See “Performing A Swap Test” on page 438.
<b>Returning an HCM on page 629</b>	
	Find the serial number ID label, then see “Return the Failed Component” on page 86. See also the <i>M10i Internet Router Hardware Guide</i> .

## Understanding Redundant HCMs


**Purpose** You monitor and maintain HCMs on the M10i router so that they can monitor and control router components, control component power-up and power-down, signal which Routing Engine is master, display alarm conditions, and take PICs offline.

**What Are Redundant HCMs** Two HCMs are installed in an M10i router. Each HCM works with a companion Routing Engine.

Two HCMs are installed into the midplane from the front of the chassis, as shown in Figure 234. The master HCM performs all functions and provides PIC removal buttons for the first Flexible PIC Concentrator (FPC). The standby HCM provides PIC removal buttons for the second FPC. The HCM in the slot labeled **HCM0** is paired with the Routing Engine in the slot labeled **RE0**. Likewise, the HCM in the slot labeled **HCM1** is paired with the Routing Engine in the slot labeled **RE1**. By default, the HCM in the slot labeled HCM0 is the master.

**Figure 234: Redundant HCMs**

M10i front



When HCM mastership changes because of failure, Routing Engine mastership also changes.

The HCM is hot-pluggable.

- See Also**
- M10i Internet Router Overview on page 11
  - Monitoring the HCM on page 431
  - Host Redundancy Overview on page 463
  - Monitoring Redundant Routing Engines on page 491

## Displaying Redundant HCM Hardware Information

**Action** To display the redundant HCM hardware information, use the following JUNOS software command-line interface (CLI) command:

```
user@host> show chassis hardware
```

**Sample Output**

```
user@host> show chassis hardware
Hardware inventory:
Item             Version  Part number  Serial number  Description
Chassis          Chassis  31875        M10i
Midplane         REV 04   710-008920   CE1044         M10i Midplane
Power Supply 0   Rev 05   740-008537   QE16425        AC Power Supply
Power Supply 1   Rev 05   740-008537   QE16644        AC Power Supply
HCM slot 0       REV 01   710-010580   CC7625         M10i HCM
HCM slot 1       REV 01   710-010580   CC7629         M10i HCM
Routing Engine 0 REV 09   740-009459   1000513670     RE-5.0
Routing Engine 1 REV 09   740-009459   1000513630     RE-5.0
```

**What it Means** The command output shows that on this M10i router, two HCMs are installed in slots 0 (HCM0) and 1 (HCM1) along with their companion Routing Engines. By default, the HCM in the slot labeled HCM0 is the master.

## Displaying HCM Status and Mastership

By default, the HCM in the slot labeled HCM0 is the master.

**Steps To Take** To display the redundant HCM status and mastership, follow these steps:

1. Check the HCM LEDs on page 625
2. Check the HCM Environmental Status on page 626

### Step 1: Check the HCM LEDs

**Action** To see which HCM is functioning as master, look at the LEDs on the HCM faceplate. On the HCM faceplate, two LEDs indicate HCM status—a green PWR LED and a blue MSTR LED. Table 132 describes the LED states.

**Table 132: HCM LEDs**

Label	Color	State	Description
PWR	Green	On steadily	HCM is functioning normally.
		Blinking	HCM is starting up.
MSTR	Blue	On steadily	HCM is master.

## Step 2: Check the HCM Environmental Status

**Action** To check the HCM environmental status and view which HCM is functioning as master, use the following CLI command:

```
user@host> show chassis environment hcm
```

**Sample Output**

```
user@host> show chassis environment hcm
HCM 0 status:
  State                Online Master
  FPGA Revision        27
HCM 1 status:
  State                Online Standby
  FPGA Revision        27
```

**What it Means** The command output shows that both HCMs (HCM0 and HCM1) are online. HCM0 is functioning as master, and HCM1 is functioning as standby. The command output also gives the Field Programmable Gate Array (FPGA) revision level. The FPGA is a gate on the chip used in the HCM.

**Alternative Action** To display the status of an HCM in a certain slot, use the following CLI command:

```
user@host> show chassis environment hcm 1
```

**Sample Output**

```
user@host> show chassis environment hcm 1
HCM 1 status:
  State                Online Standby
  FPGA Revision        27
```



## Switching HCM Mastership

When HCM mastership changes because of failure, Routing Engine mastership will change as well.

If the Routing Engines are running JUNOS Release 6.0 or later and are configured for graceful switchover, the standby Routing Engine immediately assumes Routing Engine functions and there is no interruption to packet forwarding. Otherwise, packet forwarding halts while the standby Routing Engine becomes the master and the Packet Forwarding Engine components reset and connect to the new master Routing Engine. For information about configuring graceful switchover, see the section about Routing Engine redundancy in the *JUNOS System Basics Configuration Guide*.



**NOTE:** Router performance might change if the standby Routing Engine's configuration differs from the former master's configuration. For the most predictable performance, configure the two Routing Engines identically, except for parameters unique to a Routing Engine, such as the hostname defined at the [edit system] hierarchy level and the management interface (fxp0 or equivalent) defined at the [edit interfaces] hierarchy level.

To configure Routing Engine-specific parameters and still use the same configuration on both Routing Engines, include the appropriate configuration statements under the **re0** and **re1** statements at the [edit groups] hierarchy level and use the **apply-groups** statement. For instructions, see the *JUNOS System Basics Configuration Guide*.

**Action** To switch HCM mastership to the backup HCM, use the following CLI command:

```
user@host> request chassis routing-engine master switch
```

**Sample Output**

```
user@host> request chassis routing-engine master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between routing engines ? [yes,no] yes
```

```
Resolving mastership...
Complete. The other routing engine becomes the master.
```

**What It Means** The HCM that was master is now the backup HCM.

**Action** To check HCM status and mastership after a switchover, use the following CLI command:

```
user@host> show chassis environment hcm
```

**Sample Output**

```
user@host> show chassis environment hcm
HCM 0 status:
  State                Online Standby
  FPGA Revision        27
HCM 1 status:
  State                Online Master
  FPGA Revision        27
```

**Action** To switch HCM mastership from the backup to the default master, use the following CLI command

```
user@host> request chassis routing-engine master switch
warning: Traffic will be interrupted while the PFE is re-initialized
Toggle mastership between routing engines ? [yes,no] (no) yes

Resolving mastership...

Message from syslogd@host cfeb at Jan 28 15:10:37 ...
argh cfeb RDP: Remote side reset connection:
rdp.(scb:17408).(serverRouter:chassis)

Message from syslogd@host cfeb at Jan 28 15:10:37 ...
argh cfeb RDP: Remote side reset connection: rdp.(scb:17409).(serverRouter:pfe)

Message from syslogd@host cfeb at Jan 28 15:10:37 ...
argh cfeb CM: ALARM SET: (Major) RE chassis socket closed abruptly
Complete. The local routing engine becomes the master.
```

## Displaying HCM Alarms

---

If a single HCM installed in a routing platform fails, no alarm can be sent. However, if it is a dual system, the following alarm is displayed when the backup Routing Engine takes over.

**Action** To view an HCM alarm when the backup Routing Engine takes over, use the following CLI command:

```
user@host> show chassis alarms
```

**Sample Output**

```
user@host> show chassis alarms
1 alarm currently active
Alarm time          Class  Description
2005-02-16 22:10:27 UTC  Minor  Backup RE Active
```

## Verifying HCM Failure

---

**Action** To view current HCM status when the backup Routing Engine takes over, use the following CLI command.

```
user@host> show chassis routing-engine
```

**Sample Output**

```
user@host> show chassis routing-engine
Routing Engine status:
Slot 0:
  Current state          Backup
  Election priority      Master (default)
  Temperature            33 degrees C / 91 degrees F
  DRAM                   2048 MB
  Memory utilization     13 percent
  CPU utilization:
    User                 0 percent
    Background           0 percent
    Kernel               0 percent
    Interrupt            0 percent
    Idle                 100 percent
```

```

Model RE-3.0
Serial ID P10865703096
Start time 2005-02-16 22:13:19 UTC
Uptime 2 hours, 13 minutes, 57 seconds
Routing Engine status:
Slot 1:
Current state Master
Election priority Backup (default)
Temperature 33 degrees C / 91 degrees F
CPU temperature 29 degrees C / 84 degrees F
DRAM 2048 MB
Memory utilization 12 percent
CPU utilization:
User 0 percent
Background 0 percent
Kernel 3 percent
Interrupt 0 percent
Idle 97 percent
Model RE-3.0
Serial ID P10865701255
Start time 2005-02-03 03:13:39 UTC
Uptime 13 days, 21 hours, 12 minutes, 35 seconds
Load averages: 1 minute 5 minute 15 minute
                0.00 0.03 0.01

```

**What It Means** The Routing Engine in slot RE0 and companion HCM in slot HCM0 are backup. The Routing Engine in slot RE1 and companion HCM in slot HCM1 are master.

**Alternative Method** To verify an HCM failure, you can also use the following CLI command:

```
user@host> show chassis environment hcm
```

**Sample Output**

```

user@host> show chassis environment hcm
HCM 0 status:
State Offline
FPGA Revision 27
HCM 1 status:
State Online Master
FPGA Revision 27

```

**What It Means** The HCM in slot HCM0 is offline. The HCM in slot HCM1 has taken over as master.

## Performing a Swap Test on an HCM

---

**Action** To perform a swap test on a HCM, see “Performing A Swap Test” on page 438.

## Returning an HCM

---

**Action** To return an HCM, find the serial number ID label (see “Locate the HCM Serial Number ID Label” on page 442), then follow the procedure as described in the *M10i Internet Router Hardware Guide*, or see “Return the Failed Component” on page 86.



## Part 11

# Appendices

- Command-Line Interface Overview on page 633



## Appendix A

# Command-Line Interface Overview

This chapter provides an overview of the JUNOS software command-line interface (CLI). For more detailed information about using the JUNOS software CLI, see the *JUNOS System Basics Configuration Guide* and the *JUNOS Protocols, Class of Service, and System Basics Command Reference*.

The CLI is the interface to the software that you use whenever you access the router—whether from the console or through a remote network connection. The CLI, which automatically starts after the router finishes booting, provides commands that you use to perform various tasks, including configuring the JUNOS software, and monitoring and troubleshooting the software, network connectivity, and the router hardware.

The CLI has two modes:

- CLI Operational Mode on page 633
- CLI Configuration Mode on page 639

## CLI Operational Mode

---

In operational mode you enter commands to monitor and troubleshoot the software, network connectivity, and router by entering commands.

When you log in to the router and the CLI starts, you are at the top level of the CLI operational mode. At this level, there are several broad groups of CLI commands (see Table 133).

**Table 133: CLI Operational Mode Top-Level Commands**

Command	Description
clear	Clear statistics and protocol database information.  Syntax: clear <arp   bfd   bgp   firewall   helper   igmp   ike   ilmi   interfaces   ipv6   isis   ldp   log   mld   mpls   msdp   multicast   ospf   pim   rip   ripng   route   rsvp   services   snmp   system   vrrp>
configure	Enter CLI configuration mode.  Alternative commands: configure <exclusive   private>

Command	Description
file	<p>Perform file manipulation operations, such as copy, delete, list, rename, and show.</p> <p>Syntax: file &lt;archive source destination   compare   compress source destination   copy   delete   list   rename   show&gt;</p>
help	<p>Provide help information.</p> <p>Syntax: help &lt;reference   syslog   topic&gt;</p>
monitor	<p>Monitor a log file or interface traffic in real time.</p> <p>Syntax: monitor &lt;interface&gt; &lt;start   stop   list&gt; &lt;traffic&gt;</p>
mtrace	<p>Display trace information about a multicast path from a source to a receiver.</p> <p>Syntax: mtrace &lt;source-name&gt; &lt;from-source   monitor   to-gateway&gt;</p>
ping	<p>Verify IP connectivity to another IP host or Asynchronous Transfer Mode (ATM) connectivity (ping ATM) using Operation Administration and Maintenance (OAM) cells to an ATM endstation.</p> <p>Syntax: ping <i>host-name</i> &lt;interface <i>source-interface</i>&gt; &lt;bypass-routing&gt; &lt;count requests&gt; &lt;detail&gt; &lt;do-not-fragment&gt; &lt;inet   inet6&gt; &lt;interval seconds&gt; &lt;logical-router <i>logical-router-name</i>&gt; &lt;loose-source value&gt; &lt;pattern string&gt; &lt;rapid&gt; &lt;record-route&gt; &lt;routing-instance <i>routing-instance-name</i>&gt; &lt;size bytes&gt; &lt;strict strict-source value&gt; &lt;tos type-of-service&gt; &lt;ttl value&gt; &lt;verbose&gt; &lt;via route&gt; &lt;wait seconds&gt;</p> <p>Syntax: ping atm interface <i>interface</i> &lt;count <i>count</i>&gt; &lt;end-to-end   segment&gt; &lt;interval <i>interval</i>&gt; &lt;sequence-number <i>sequence-number</i>&gt; &lt;vci <i>vci</i>&gt; &lt;brief&gt;</p> <p>Syntax: ping vpn-interface <i>vpn-interface</i> <i>host</i> &lt;local <i>echo-address</i>&gt;</p>
pipe	<p>Filter the output of an operational mode or configuration mode command.</p> <p>Syntax:   &lt;compare &lt;filename   rollback <i>n</i>&gt;   count   display &lt;detail   inheritance   xml&gt;   except pattern   find pattern   hold   last   match pattern   no-more   resolve &lt;full-names&gt;   save filename   trim columns&gt;</p>
quit	<p>Log out from the CLI process.</p> <p>Syntax: quit</p>
request	<ul style="list-style-type: none"> <li>■ Stop or reboot router components, switch between primary and backup components, display messages, and display system information.</li> </ul> <p>Syntax: request &lt;chassis   ipsec switch   message   routing-engine   security   services flow-collector   support information&gt;</p> <ul style="list-style-type: none"> <li>■ Stop or reboot the router, load software packages, and back up the router's file systems.</li> </ul> <p>Syntax: request &lt;chassis   ipsec switch   message   routing-engine   security   services&gt;</p>
restart	<p>Restart the router hardware or software processes.</p> <p>Syntax: restart &lt;adaptive-services   chassis-control   class-of-service   disk-monitoring   ecc-error-logging   firewall   interface-control   kernel-replication   l2tp-service   mib-process   network-access-service   pgm   pic-services-logging   remote-operations routing   sampling   snmp&gt; &lt;gracefully   immediately   soft&gt;</p>
set	<p>Set CLI properties, the router's date and time, and the craft interface display text.</p> <p>Syntax: set &lt;chassis   cli   date   date ntp&gt;</p>



Command	Description
show	<p>Show information about all aspects of the software, including interfaces and routing protocols.</p> <p>Syntax: show &lt;accounting   aps   arp   as-path   bgp   chassis   class-of-service   cli   configuration   connections   dvmrp   firewall   helper   host   igmp   ike   ilmi   interfaces   ipsec   ipv6   isis   l2circuit   l2vpn   ldp   link-management   log   mpls   msdp   multicast   ntp   ospf   ospf3   passive monitoring   pfe   pim   policer   policy   rip   ripng   route   rsvp   sap   services   snmp   system   task   ted   version   vrrp&gt;</p>
ssh	<p>Open a secure shell to another host.</p> <p>Syntax: ssh <i>host-name</i> &lt;bypass-routing&gt; &lt;interface <i>interface-name</i>&gt; &lt;inet   inet6&gt; &lt;routing instance <i>routing-instance-name</i>&gt; &lt;source <i>source-name</i>&gt; &lt;v1   v2&gt; &lt;vpn-interface <i>vpn-interface-name</i>&gt;</p>
start	<p>Start a software process.</p> <p>Syntax: start shell</p>
telnet	<p>Start a telnet session to another host.</p> <p>Syntax: telnet <i>host-name</i> &lt;8bit&gt; &lt;bypass-routing&gt; &lt; inet   inet6&gt; &lt;interface <i>interface-name</i>&gt; &lt;logical-router <i>logical-router-name</i>&gt; &lt;noresolve&gt; &lt;port <i>port-number</i>&gt; &lt;routing-instance <i>routing-instance-name</i>&gt; &lt;source <i>source-address</i>&gt;</p>
test	<p>Run various diagnostic debugging commands.</p> <p>Syntax: test configuration (filename   terminal)</p>
traceroute	<p>Trace the route to a remote host.</p> <p>Syntax: traceroute <i>host-name</i> &lt;as-number-lookup&gt; &lt;bypass-routing&gt; &lt;gateway address&gt; &lt;inet&gt;&lt;inet6&gt; &lt;logical-router <i>logical-router-name</i>&gt; &lt;noresolve&gt; &lt;routing-instance <i>routing-instance-name</i>&gt; &lt;source address&gt; &lt;tos value&gt; &lt;ttl value&gt; &lt;interface <i>interface-name</i>&gt; &lt;wait <i>seconds</i>&gt;</p>

## Using the CLI Operational Mode

This section describes how to use the CLI operational mode. You can do the following:

- Entering the CLI Operational Mode on page 636
- Getting Help on Commands at a Hierarchy Level on page 636
- Getting Help About Commands on page 636
- Having the CLI Complete Commands on page 638
- Using CLI Command Completion on page 638
- Displaying CLI Command History on page 639

## Entering the CLI Operational Mode

To enter the JUNOS software CLI, use the following command:

```
user@host> cli
```

You are in the CLI when you see the > prompt, which is preceded by a string that defaults to the name of the user and the name of the router. For example:

```
user@host>
```

## Getting Help on Commands at a Hierarchy Level

The CLI provides context-sensitive help at every level of the command hierarchy. The help information tells you which commands are available at the current level in the hierarchy and provides a brief description of each.

To get help while in the CLI, type ?. You do not need to press **Enter** after typing the question mark. You have the following options:

- If you type the question mark at the command-line prompt, the CLI lists the available commands and options.
- If you type the question mark after entering the complete name of a command or command option, the CLI lists the available commands and options, then redisplay the command names and options that you typed.
- If you type the question mark in the middle of a command name, the CLI lists possible command completions that match the letters you have entered so far, then redisplay the letters that you typed.

## Getting Help About Commands

To get help about operational mode CLI commands, you can do the following:

- Listing Top-Level Operational Mode CLI Commands on page 637
- Listing CLI Commands That Start with a Particular Letter on page 637
- Listing All Available Commands of a Particular Type on page 637

**Listing Top-Level Operational Mode CLI Commands**

To list all available commands at the top level of the CLI operational mode, use the following command (see Table 133):

```
user@host> ?
```

Possible completions:

clear	Clear information in the system
configure	Manipulate software configuration information
file	Perform file operations
help	Provide help information
monitor	Show real-time debugging information
mtrace	Trace multicast path from source to receiver
ping	Ping remote target
quit	Exit the management session
request	Make system-level requests
restart	Restart software process
set	Set CLI properties, date/time, craft interface message
show	Show system information
ssh	Start secure shell on another host
start	Start shell
telnet	Telnet to another host
test	Perform diagnostic debugging
tracert	Trace route to remote host

**Listing CLI Commands That Start with a Particular Letter**

To list all commands that start with the letter c, use the following CLI command:

```
user@host> c?
```

Possible completions:

clear	Clear information in the system
configure	Manipulate software configuration information

```
user@host> c
```

**Listing All Available Commands of a Particular Type**

To list all available clear commands, use the following CLI command:

```
user@host> clear ?
```

Possible completions:

arp	Clear address resolution information
bfd	Clear Bidirectional Forwarding Detection information
bgp	Clear Border Gateway Protocol information
cli	Clear command-line interface settings
esis	Clear end system-to-intermediate system information
firewall	Clear firewall counters
helper	Clear port-forwarding helper information
igmp	Clear Internet Group Management Protocol information
ike	Clear IKE information
ilmi	Clear interim local management interface statistics
interfaces	Clear interface information
ipsec	Clear IP Security information
ipv6	Clear IP version 6 information
isis	Clear Intermediate System-to-Intermediate System
information	
ldp	Clear Label Distribution Protocol information
log	Clear contents of log file

mld	Clear multicast listener discovery information
mpls	Clear Multiprotocol Label Switching information
msdp	Clear Multicast Source Discovery Protocol information
multicast	Clear multicast information
ospf	Clear Open Shortest Path First information
ospf3	Clear Open Shortest Path First version 3 information
pgm	Clear Pragmatic Generalized Multicast information
pim	Clear Protocol Independent Multicast information
rip	Clear Routing Information Protocol information
ripng	Clear Routing Information Protocol for IPv6 information
rsvp	Clear Resource Reservation Protocol information
services	
snmp	Clear Simple Network Management Protocol information
system	Clear system information
vpls	Clear VPLS information
vrrp	Clear Virtual Router Redundancy Protocol statistics

## Having the CLI Complete Commands

You do not always have to remember or type the full command or option name for the CLI to recognize it. To display all possible command or option completions, type the partial command followed by a question mark.

To complete a command or option that you have partially typed, press the **Tab** key or the spacebar. If the partially typed letters begin a string that uniquely identifies a command, the complete command name appears. Otherwise, a beep indicates that you have entered an ambiguous command, and the possible completions are displayed.

Command completion also applies to other strings, such as filenames and usernames. To display all possible values, type a partial string followed by a question mark. However, to complete these strings, press the **Tab** key; pressing the space bar does not work.

## Using CLI Command Completion

To complete the `show interfaces` command, do the following:

```
user@host> show in<Spacebar>terfaces <Enter>
```

```
Physical interface: at-0/1/0, Enabled, Physical link is Up
Interface index: 11, SNMP ifIndex: 65
Link-level type: ATM-PVC, MTU: 4482, Clocking: Internal, SONET mode
Speed: OC12, Loopback: None, Payload scrambler: Enabled
Device flags   : Present Running
Link flags     : 0x01
[...Output truncated...]
```

To display a list of all log files whose names start with the string “messages,” and then display the contents of one of the files, do the following:

```
user@host> show log mes?
```

Possible completions:

<filename>	Log file to display
messages	Size: 1417052, Last changed: Mar 3 00:33
messages.0.gz	Size: 145575, Last changed: Mar 3 00:00
messages.1.gz	Size: 134253, Last changed: Mar 2 23:00
messages.10.gz	Size: 137022, Last changed: Mar 2 14:00
messages.2.gr	Size: 137112, Last changed: Mar 2 22:00
messages.3.gz	Size: 121633, Last changed: Mar 2 21:00
messages.4.gz	Size: 135715, Last changed: Mar 2 20:00
messages.5.gz	Size: 137504, Last changed: Mar 2 19:00
messages.6.gz	Size: 134591, Last changed: Mar 2 18:00
messages.7.gz	Size: 132670, Last changed: Mar 2 17:00
messages.8.gz	Size: 136596, Last changed: Mar 2 16:00
messages.9.gz	Size: 136210, Last changed: Mar 2 15:00

```
user@host> show log mes<Tab>sages.4<Tab>.gz<Enter>
Jan 15 21:00:00 myhost newsyslog[1381]: logfile turned over
[...Output truncated...]
```

## Displaying CLI Command History

You can display a list of recent commands that you issued. To display the command history, use the `show cli history` command:

```
user@host> show cli history
```

```
03-03 01:00:50 -- show cli history
03-03 01:01:12 -- show interfaces terse
03-03 01:01:22 -- show interfaces lo0
03-03 01:01:44 -- show bgp next-hop-database
03-03 01:01:51 -- show cli history
```

By default, this command displays the last 100 commands issued in the CLI. Specify a number with the command to display that number of recent commands. For example:

```
user@host> show cli history 3
```

```
01:01:44 -- show bgp next-hop-database
01:01:51 -- show cli history
01:02:51 -- show cli history 3
```

## CLI Configuration Mode

In configuration mode, you configure the JUNOS software by creating a hierarchy of configuration statements. You can do this by using the CLI or by creating a text (ASCII) file that contains the statement hierarchy. (The statement hierarchy is identical in both the CLI and text configuration file.) You can configure all properties of the JUNOS software, including interfaces, general routing information, routing protocols, and user access, as well as several system hardware properties. When you have finished entering the configuration statements, you commit them, which activates the configuration on the router.

Table 134 explains each CLI configuration mode command. The commands are organized alphabetically.

**Table 134: CLI Configuration Mode Commands**

Command	Description
activate	Remove the <code>inactive:</code> tag from a statement, effectively reading the statement or identifier to the configuration. Statements or identifiers that have been activated take effect when you next issue the <code>commit</code> command. Syntax: <code>activate (statement-path   identifier)</code>
annotate	Add comments to a configuration. Syntax: <code>annotate statement-path "comment-string"</code>
commit	Commit the set of changes to the database and cause the changes to take operational effect. Syntax: <code>commit &lt;&lt;at &lt;string&gt;&gt; &lt;and-quit&gt; &lt;check&gt; &lt;confirmed &lt;minutes&gt;&gt; &lt;synchronize&gt;</code>
copy	Make a copy of an existing statement in the configuration. Syntax: <code>copy existing-statement-path to new-statement-path</code>
deactivate	Add the <code>inactive:</code> tag to a statement, effectively commenting out the statement or identifier from the configuration. Statements or identifiers marked as inactive do not take effect when you issue the <code>commit</code> command. Syntax: <code>deactivate (statement-path   identifier)</code>
delete	Delete a statement or identifier. All subordinate statements and identifiers contained within the specified statement path are deleted with it. Syntax: <code>delete (statement-path   identifier)</code>
edit	Move inside the specified statement hierarchy. If the statement does not exist, it is created. Syntax: <code>edit statement-path</code>
exit	Exit the current level of the statement hierarchy, returning to the level prior to the last edit command, or exit from configuration mode. The <code>quit</code> and <code>exit</code> commands are synonyms. Syntax: <code>exit (configuration-mode)</code>
help	Display help about available configuration statements. Syntax: <code>help (apropos   topic   reference) &lt;string&gt;</code>
insert	Insert an identifier into an existing hierarchy. Syntax: <code>insert (statement-path) identifier1 (before   after) identifier2</code>
load	Load a configuration from an ASCII configuration file or from terminal input. Your current location in the configuration hierarchy is ignored when the load operation occurs. Syntax: <code>load (merge   override   patch   replace) (filename   terminal)</code>
quit	Exit the current level of the statement hierarchy, returning to the level prior to the last edit command, or exit from configuration mode. The <code>quit</code> and <code>exit</code> commands are synonyms. Syntax: <code>quit configuration-mode</code>
rename	Rename an existing configuration statement or identifier. Syntax: <code>rename &lt;statement-path&gt; identifier1 to identifier2</code>

Command	Description
rollback	<p>Return to a previously committed configuration. The software saves the last 10 committed configurations, including the rollback number, date, time, and name of the user who issued the commit configuration command.</p> <p><b>rollback 0</b> erases any configuration changes made to the current candidate configuration. The currently operational JUNOS software configuration is stored in the file <code>juniper.conf</code>, and the last three committed configurations are stored in the files <code>juniper.conf.1.gz</code>, <code>juniper.conf.2.gz</code>, and <code>juniper.conf.3.gz</code>. These four files are located in the directory <code>/config/</code>, which is on the router's flash drive. The remaining six previous committed configurations, the files <code>juniper.conf.4.gz</code> through <code>juniper.conf.9.gz</code>, are stored in the directory <code>/var/db/config/</code>, which is on the router's hard disk.</p> <p>Syntax: <code>rollback &lt;number&gt;</code></p>
run	<p>Run a CLI command without exiting from configuration mode.</p> <p>Syntax: <code>run command</code></p>
save	<p>Save the configuration to an ASCII file, by default in the users home directory. The contents of the current level of the statement hierarchy (and below) are saved, along with the statement hierarchy containing it. This allows a section of the configuration to be saved, while fully specifying the statement hierarchy.</p> <p>Syntax: <code>save filename</code></p>
set	<p>Create a statement hierarchy and set identifier values. This is similar to <code>edit</code> except that your current level in the hierarchy does not change, and you can set identifier values whereas <code>edit</code> only allows access to a statement-path.</p> <p>Syntax: <code>set (statement-path   identifier)</code></p>
show	<p>Display the current configuration.</p> <p>Syntax: <code>show (statement-path   identifier)</code></p>
status	Display the users currently editing the configuration.
top	<p>Return to the top level of configuration command mode, which is indicated by the <code>[edit]</code> banner, or execute a command from the top level of the configuration.</p> <p>Syntax: <code>top &lt;configuration-command&gt;</code></p>
up	<p>Move up one level in the statement hierarchy.</p> <p>Syntax: <code>up &lt;number&gt;</code></p>
update	Update a private database.

## Configuration Statements and Identifiers

You configure all router properties by including statements in the configuration. A statement consists of a keyword, which is fixed text, and, optionally, an identifier. An identifier is an identifying name that you define, such as the name of an interface, or a username, which allows you and the CLI to discriminate among a collection of statements.

The following list shows the statements available at the top level of the configuration mode (that is, the trunk of the hierarchy tree). Table 135 on page 642 describes each statement.

```
[edit]
user@host# set ?
Possible completions:
> access           Network access configuration
```

> accounting-options	Accounting data configuration
> applications	Define applications by protocol characteristics
+ apply-groups	Groups from which to inherit configuration data
> chassis	Chassis configuration
> class-of-service	Class-of-service configuration
> firewall	Define a firewall configuration
> forwarding-options	Configure options to control packet sampling
> groups	Configuration groups
> interfaces	Interface configuration
> isdn	ISDN process configuration
> logical-routers	Logical routers
> policy-options	Routing policy option configuration
> protocols	Routing protocol configuration
> routing-instances	Routing instance configuration
> routing-options	Protocol-independent routing option configuration
> security	Security configuration
> services	Service PIC applications settings
> snmp	Simple Network Management Protocol configuration
> system	System parameters

An angle bracket ( > ) before the statement name indicates that it is a container statement and you can define other statements at levels below it.

If there is no angle bracket ( > ) before the statement name, the statement is a leaf statement; you cannot define other statements at hierarchy levels below it.

A plus sign ( + ) before the statement name indicates that it can contain a set of values. To specify a set, include the values in brackets. For example:

```
[edit]
user@host# set policy-options community my-as1-transit members [65535:10
65535:11]
```

In some statements, you can include an identifier. For some identifiers, such as interface names, you must specify the identifier in a precise format. For example, the interface name `so-0/0/0` refers to a SONET/SDH interface that is on the Flexible PIC Concentrator (FPC) in slot 0, in the first Physical Interface Card (PIC) location, and in the first port on the PIC. For other identifiers, such as interface descriptive text, policy, and firewall term names, you can specify any name, including special characters, spaces, and tabs.

You must enclose in quotation marks (double quotes) identifiers and any strings that include the following characters: space tab ( ) [ ] { } ! @ # \$ % ^ & | ' = ?

Table 135 describes each top-level CLI configuration mode statement.

**Table 135: Configuration Mode Top-Level Statements**

Statement	Description
accounting-options	Configure accounting statistics data collection for interfaces and firewall filters. For information about the statements in this hierarchy, see the <i>JUNOS Configuration Guide: Network Management</i> .
chassis	Configure properties of the router chassis, including the clock source, conditions that activate alarms, and SONET/SDH framing and concatenation properties. For information about the statements in this hierarchy, see the <i>JUNOS Interfaces and Class of Service .Configuration Guide</i>




Statement	Description
class-of-service	Configure class-of-service parameters. For information about the statements in this hierarchy, see the <i>JUNOS Interfaces and Class of Service Configuration Guide</i> .
firewall	Define filters that select packets based on their contents. For information about the statements in this hierarchy, see the <i>Policy Framework Configuration Guide</i> .
forwarding-options	Define forwarding options, including traffic sampling options. For information about the statements in this hierarchy, see the <i>JUNOS Interfaces and Class of Service Configuration Guide</i> .
groups	Configure configuration groups.
interfaces	Configure interface information, such as encapsulation, interfaces, virtual channel identifiers (VCIs), and data-link channel identifiers (DLCIs). For information about the statements in this hierarchy, see the <i>JUNOS Interfaces and Class of Service Configuration Guide</i> .
policy-options	Define routing policies, which allow you to filter and set properties in incoming and outgoing routes. For information about the statements in this hierarchy, see the <i>JUNOS Routing and Routing Protocols Configuration Guide</i> .
protocols	Configure routing protocols, including Border Gateway Protocol (BGP), Intermediate System-to-Intermediate System (IS-IS), Open Shortest Path First (OSPF), Routing Information Protocol (RIP), Multiprotocol Label Switching (MPLS), Label Distribution Protocol (LDP), and Resource Reservation Protocol (RSVP). For information about the statements in this hierarchy, see the chapters that discuss how to configure the individual routing protocols in the <i>JUNOS Routing and Routing Protocols Configuration Guide</i> and the <i>JUNOS MPLS Applications Configuration Guide</i> .
routing-instances	Configure multiple routing instances. For information about the statements in this hierarchy, see the <i>JUNOS Routing and Routing Protocols Configuration Guide</i> .
routing-options	Configure protocol-independent routing options, such as static routes, autonomous system (AS) numbers, confederation members, and global tracing (debugging) operations to log. For information about the statements in this hierarchy, see the <i>JUNOS Routing and Routing Protocols Configuration Guide</i> .
snmp	Configure Simple Network Management Protocol (SNMP) community strings, interfaces, traps, and notifications. For information about the statements in this hierarchy, see the <i>JUNOS Network Management Configuration Guide</i> .
system	Configure systemwide properties, including the hostname, domain name, Domain Name System (DNS) server, user logins and permissions, mappings between hostnames and addresses, and software processes.

## Configuration Statement Hierarchy

The JUNOS software configuration consists of a hierarchy of *statements*. There are two types of statements: *container statements*, which are statements that contain other statements, and *leaf statements*, which do not contain other statements (see Figure 235). All of the container and leaf statements together form the *configuration hierarchy*.

**Figure 235: Configuration Mode Hierarchy of Statements**



Each statement at the top level of the configuration hierarchy resides at the trunk (or root level) of a hierarchy tree. The top-level statements are container statements, containing other statements that form the tree branches. The leaf statements are the leaves of the hierarchy tree. An individual hierarchy of statements, which starts at the trunk of the hierarchy tree, is called a *statement path*. Figure 235 illustrates the hierarchy tree, showing a statement path for the portion of the protocol configuration hierarchy that configures the hello interval on an interface in an OSPF area.

The **protocols** statement is a top-level statement at the trunk of the configuration tree. The **ospf**, **area**, and **interface** statements are all subordinate container statements of a higher statement (they are branches of the hierarchy tree), and the **hello-interval** statement is a leaf on the tree, which, in this case, contains a data value: the length of the hello interval in seconds.

The CLI represents the statement path shown in Figure 235 as `[protocols ospf area area-number interface interface-name]`, and displays the configuration as follows:

```

protocols {
  ospf {
    area 0.0.0.0 {
      interface so-0/0/0 {
        hello-interval 5;
      }
      interface so-0/0/1 {
        hello-interval 5;
      }
    }
  }
}

```

The CLI indents each level in the hierarchy to indicate each statement's relative position in the hierarchy and generally sets off each level with braces, using an open brace at the beginning of each hierarchy level and a closing brace at the end. If the statement at a hierarchy level is empty, the braces are not printed. Each leaf statement ends with a semicolon. If the hierarchy does not extend as far as a leaf statement, the last statement in the hierarchy ends with a semicolon.

The CLI uses this indented representation when it displays the current system configuration, and you use this format when creating ASCII files that contain the software configuration. However, the format of ASCII configuration files is not as strict as the CLI output of the configuration. Although the braces and semicolons are required, the indentation and use of new lines, as shown above, are not required in ASCII configuration files.

## Using the CLI Configuration Mode

This section describes how to use the CLI configuration mode. You can do the following:

- Entering Configuration Mode on page 646
- Exiting Configuration Mode on page 647
- Moving Among Levels of the Hierarchy on page 647
- Displaying the Current Configuration on page 647
- Modifying the Configuration on page 649
- Removing a Statement on page 649
- Running Operational Mode CLI Commands from Configuration Mode on page 649
- Displaying Configuration Mode Command History on page 650
- Committing a Configuration on page 650
- Saving a Configuration to a File on page 651

- Returning to a Previously Committed Configuration on page 651
- Getting Help About Statements on page 653

## Entering Configuration Mode

If many users enter configuration mode at the same time, everyone can make configuration changes and commit all changes. If one user enters configuration mode when another user is also in configuration mode, a message indicates who the user is and what portion of the configuration that user is viewing or editing. To enter configuration mode, use the following CLI command:

```
user@host> configure
```

```
Entering configuration mode
Current configuration users:
  root terminal p3 (pid 1088) on since 1999-05-13 01:03:27 EDT
    [edit interfaces so-3/0/0 unit 0 family inet]
The configuration has been changed but not committed
```

- If, when you enter configuration mode, the configuration contains changes that have not been committed, a message appears:

```
user@host> configure
```

```
Entering configuration mode
The configuration has been changed but not committed
```

- If, while in configuration mode, you try to make a change while the configuration is locked by another user, a message indicates that the configuration database is locked, who the user is, and what portion of the configuration the user is viewing or editing:

```
[edit]
user@host# set system host-name ipswitch
```

```
error: configuration database locked by:
  user2 terminal d0 (pid 1828) on since 19:47:58 EDT, idle 00:02:11
    exclusive [edit protocols]
```

- If you enter configuration mode with the **configure exclusive** command, you lock the candidate configuration for as long as you remain in configuration mode, allowing you to make changes without interference from other users. If another user is also in configuration mode and has the configuration locked, a message indicates who the user is and what portion of the configuration the user is viewing or editing:

```
user@host> configure exclusive
```

```
Entering configuration mode
Users currently editing the configuration:
  root terminal p3 (pid 1088) on since 2000-10-30 19:47:58 EDT, idle
  00:00:44
    exclusive [edit interfaces so-3/0/0 unit 0 family inet]
```

## Exiting Configuration Mode

To exit configuration mode, use the `exit configuration-mode` configuration mode command from any level or use the `exit` command from the top level. If you try to exit from configuration mode using the `exit` command and the configuration contains changes that have not been committed, you see a message and prompt:

```
[edit]
user@host# exit
```

```
The configuration has been changed but not committed
Exit with uncommitted changes? [yes,no] (yes) <Enter>
Exiting configuration mode
user@host>
```

To exit with uncommitted changes without having to respond to a prompt, use the `exit configuration-mode` command.

## Moving Among Levels of the Hierarchy

The CLI commands in Table 136 help you navigate the levels of the configuration statement hierarchy.

**Table 136: CLI Configuration Mode Navigation Commands**

Command	Description
<code>edit</code>	To move down through an existing configuration command hierarchy, or to create a hierarchy and move down to that level, use the <code>edit</code> configuration mode command, specifying the hierarchy level at which you want to be.
<code>exit</code>	To move up the hierarchy, use the <code>exit</code> configuration mode command. This command is, in effect, the opposite of the <code>edit</code> command.
<code>up</code>	To move up the hierarchy one level at a time, use the <code>up</code> configuration mode command.
<code>top</code>	To move directly to the top level, use the <code>top</code> configuration mode command.

## Displaying the Current Configuration

You can display the following information about the current configuration:

- Displaying the Configuration at the Current Hierarchy Level on page 648
- Displaying the Last Committed Current Configuration on page 648
- Displaying Users Currently Editing the Configuration on page 648

**Displaying the Configuration at the Current Hierarchy Level**

To display the configuration at the current hierarchy level or at the specified level, use the **show** configuration mode command.

```
user@host> show <statement-path>
```

The configuration statements appear in a fixed order. The CLI indents each level in the hierarchy to indicate each statement's relative position in the hierarchy and generally sets off each level with braces, using an open brace at the beginning of each hierarchy level and a closing brace at the end. If the statement at a hierarchy level is empty, the braces are not printed. Each leaf statement ends with a semicolon. If the hierarchy does not extend as far as a leaf statement, the last statement in the hierarchy ends with a semicolon. Interfaces appear alphabetically by type, and then in numerical order by slot number, PIC number, and port number.

**Displaying the Last Committed Current Configuration**

You also can use the CLI operational mode **show configuration** command to display the last committed current configuration, which is the configuration currently running on the router:

```
user@host> show configuration
```

**Displaying Users Currently Editing the Configuration**

To display the users currently editing the configuration, use the **status configuration** mode command:

```
[edit]
user@host# status
```

```
Current configuration users:
  user terminal p0 (pid 518) on since 2002-03-12 18:24:27 PST
    [edit protocols]
```

The system displays who is editing the configuration (**user**), how the user is logged in (**terminal p0**), the date and time the user logged in (**2002-03-12 18:24:27 PST**), and what level of the hierarchy the user is editing (**[edit protocols]**).

## Modifying the Configuration

To configure the router or to modify an existing router configuration, you add statements to the configuration. For each statement hierarchy, you create the hierarchy starting with a statement at the top level and continuing with statements that move progressively lower in the hierarchy.

To modify the hierarchy, you use two configuration mode commands:

- **set**—Creates a statement hierarchy and sets identifier values. After you issue a **set** command, you remain at the same level in the hierarchy. The **set** command has the following syntax:

```
set <statement-path> statement <identifier>
```

*statement-path* is the hierarchy to the configuration statement and the statement itself. If you have already moved to the statement's hierarchy level, you omit this. *statement* is the configuration statement itself. *identifier* is a string that identifies an instance of a statement.

- **edit**—Moves to a particular hierarchy level. If that hierarchy level does not exist, the **edit** command creates it and then moves to it. The **edit** command has the following syntax:

```
edit <statement-path> statement <identifier>
```

## Removing a Statement

To delete a statement or identifier, use the **delete** configuration mode command. Deleting a statement or an identifier effectively “unconfigures” the functionality associated with that statement or identifier, returning that functionality to its default condition. When you delete a statement, the statement and all its subordinate statements and identifiers are removed from the configuration.

```
delete <statement-path> <identifier>
```

To delete the entire hierarchy starting at the current hierarchy level, do not specify a statement or an identifier in the **delete** command:

```
[edit]
user@host# delete
```

```
Delete everything under this level? [yes, no] (no) ?
```

```
Possible completions:
```

```
no          Don't delete everything under this level
yes         Delete everything under this level
```

```
Delete everything under this level? [yes, no] (no)
```

## Running Operational Mode CLI Commands from Configuration Mode

To display the output of an operational mode **show** or other command while configuring the software, you can execute a single operational mode command by issuing the **run** configuration mode command and specifying the operational mode command:

```
[edit]
user@host# run operational-mode-command
```

### Displaying Configuration Mode Command History

To display a list of the recent commands you issued while in configuration mode, use the `run show cli history` command. By default, this command displays the last 100 commands issued in the CLI.

```
[edit]
user@host# run show cli history

12:40:08 -- show
12:40:17 -- edit protocols
12:40:27 -- set isis
12:40:29 -- edit isis
12:40:40 -- run show cli history
```

### Committing a Configuration

To commit a configuration, you can do the following:

- Saving Configuration Changes and Activating the Configuration on page 650
- Saving Configuration Changes, Activating the Configuration, and Exiting Configuration Mode on page 650

#### ***Saving Configuration Changes and Activating the Configuration***

To save software configuration changes to the configuration database and activate the configuration on the router, use the `commit` configuration mode command:

```
[edit]
user@host# commit

commit complete
```

The configuration is checked for syntax errors. If the syntax is correct, the configuration is activated and becomes the current, operational router configuration. If the configuration contains syntax errors, a message indicates the location of the error and the configuration is not activated. You must correct the error before recommitting the configuration.

#### ***Saving Configuration Changes, Activating the Configuration, and Exiting Configuration Mode***

To save software configuration changes, activate the configuration on the router, and exit configuration mode, use the `commit and-quit` configuration mode command. This command succeeds only if the configuration contains no errors.

```
[edit]
user@host# commit and-quit

commit complete
exiting configuration mode
user@host>
```



### **Saving a Configuration to a File**

To save the configuration to a text (ASCII) file so that you can edit it with a text editor of your choice, use the **save** configuration mode command. By default, the configuration is saved to that file in your home directory, which is on the flash disk.

```
[edit]
user@host# save filename
Wrote 475 lines of configuration to 'filename'
```

### **Returning to a Previously Committed Configuration**

To return to a previously committed configuration, you can do the following:

- Returning to the Most Recently Committed Configuration on page 651
- Activating the Configuration You Loaded on page 651
- Returning to a Configuration Prior to the Most Recently Committed One on page 651
- Displaying Previous Configurations on page 652

### **Returning to the Most Recently Committed Configuration**

To return to the most recently committed configuration and load it into configuration mode without activating it, use the **rollback** configuration mode command:

```
[edit]
user@host# rollback

load complete
```

### **Activating the Configuration You Loaded**

To activate the configuration that you loaded, use the **commit** command:

```
[edit]
user@host# rollback
load complete
[edit]
user@host# commit
```

### **Returning to a Configuration Prior to the Most Recently Committed One**

To return to a configuration prior to the most recently committed one, include the number in the **rollback** command. *number* can be a number in the range 0 through 9. The most recently saved configuration is number 0 (which is the default configuration to which the system returns), and the oldest saved configuration is number 9.

```
[edit]
user@host# rollback number
load complete
```

**Displaying Previous Configurations**

To display previous configurations, including the rollback number, date, time, the name of the user who committed changes, and the method of commit, use the `rollback ?` command.

```
[edit]
user@host# rollback ?
```

Possible completions:

<[Enter]> Execute this command

<number> Numeric argument

```
0      2005-02-27 12:52:10 PST by abc via cli
1      2005-02-26 14:47:42 PST by def via cli
2      2005-02-14 21:55:45 PST by ghi via cli
3      2005-02-10 16:11:30 PST by jkl via cli
4      2005-02-10 16:02:35 PST by mno via cli
5      2005-03-16 15:10:41 PST by pqr via cli
6      2005-03-16 14:54:21 PST by stu via cli
7      2005-03-16 14:51:38 PST by vwx via cli
8      2005-03-16 14:43:29 PST by yzz via cli
9      2005-03-16 14:15:37 PST by abc via cli
10     2005-03-16 14:13:57 PST by def via cli
11     2005-03-16 12:57:19 PST by root via other
12     2005-03-16 10:45:23 PST by root via other
13     2005-03-16 10:08:13 PST by root via other
14     2005-03-16 01:20:56 PST by root via other
15     2005-03-16 00:40:37 PST by ghi via cli
16     2005-03-16 00:39:29 PST by jkl via cli
17     2005-03-16 00:32:36 PST by mno via cli
18     2005-03-16 00:31:17 PST by pqr via cli
19     2005-03-15 19:59:00 PST by stu via cli
20     2005-03-15 19:53:39 PST by vwx via cli
21     2005-03-15 18:07:19 PST by yzz via cli
22     2005-03-15 17:59:03 PST by abc via cli
23     2005-03-15 15:05:14 PST by def via cli
24     2005-03-15 15:04:51 PST by ghi via cli
25     2005-03-15 15:03:42 PST by jkl via cli
26     2005-03-15 15:01:52 PST by mno via cli
27     2005-03-15 14:58:34 PST by pqr via cli
28     2005-03-15 13:09:37 PST by root via other
29     2005-03-12 11:01:20 PST by stu via cli
30     2005-03-12 10:57:35 PST by vwx via cli
31     2005-03-11 10:25:07 PST by yzz via cli
32     2005-03-10 23:40:58 PST by abc via cli
33     2005-03-10 23:40:38 PST by def via cli
34     2005-03-10 23:14:27 PST by ghi via cli
35     2005-03-10 23:10:16 PST by jkl via cli
36     2005-03-10 23:01:51 PST by mno via cli
37     2005-03-10 22:49:57 PST by pqr via cli
38     2005-03-10 22:24:07 PST by stu via cli
39     2005-03-10 22:20:14 PST by vwx via cli
40     2005-03-10 22:16:56 PST by yzz via cli
41     2005-03-10 22:16:41 PST by abc via cli
42     2005-03-10 20:44:00 PST by def via cli
43     2005-03-10 20:43:29 PST by ghi via cli
44     2005-03-10 20:39:14 PST by jkl via cli
45     2005-03-10 20:31:30 PST by root via other
46     2005-03-10 18:57:01 PST by mno via cli
47     2005-03-10 18:56:18 PST by pqr via cli
48     2005-03-10 18:47:49 PST by stu via cli
49     2005-03-10 18:47:34 PST by vw via cli
```

```
| Pipe through a command
[edit]
```

## Getting Help About Statements

In configuration mode, you can use the **help** command to display help based on a text string contained in a statement name. This command displays help for statements at the current hierarchy level and below.

```
user@host# help string
```

You can also display help based on a text string contained in a statement name using the **help topic** and **help reference** commands. The **help topic** command displays usage guidelines for the statement, whereas the **help reference** command displays summary information about the statement.

```
user@host# help topic ?
access          Network access control
accounting-options  Accounting data collection
applications      Application protocols
bgp              Border Gateway Protocol
chassis          Platform
class-of-service  Class of service (CoS)
connections      Circuit cross-connect (CCC)
dvmrp            Distance Vector Multicast Routing Protocol
firewall         Firewalls and filters
forwarding-options Packet sampling
groups           Configuration groups
igmp             Internet Group Management Protocol
interfaces       Interfaces
isis             Intermediate System-to-Intermediate System
l2circuit        Layer 2 virtual circuits
layer2-vpns      Layer 2 VPNs
layer3-vpns      Layer 3 VPNs
ldp              Label Distribution Protocol
link-management  Link Management Protocol
logical-routers  Logical routers
mld              Multicast Listener Discovery protocol
mpls             Multiprotocol Label Switching
msdp             Multicast Source Discovery Protocol
ospf             Open Shortest Path First protocol
pgm              Pragmatic Generalized Multicast
pim              Protocol-Independent Multicast and data MDT
policy-options   Routing policy
rip              Routing Information Protocol
ripng            Routing Information Protocol Next Generation
rmon             Remote Monitoring
router-advertisement Neighbor discovery
router-discovery Internet Control Message Protocol router discovery
routing-instances Routing instances
routing-options  Protocol-independent routing options
rsvp             Resource Reservation Protocol
sap              Session Advertisement Protocol
security         Internet Protocol security (IPSec)
services         Service sets for Adaptive Services PIC
snmp             Simple Network Management Protocol
system           System parameters
```

vpls	Virtual private LAN service
vpns	Virtual private networks

```
[edit]
user@help# help topic access ?
```

Possible completions:

```
examples
l2tp          Overview of Layer 2 Tunneling Protocol configuration
point-to-point Overview of Point-to-Point Protocol configuration
radius-disconnect-port Port number for RADIUS disconnect server
radius-server  RADIUS server configuration
traceoptions   Trace options for access processes
tunnel-profile Join multilink bundles based on endpoint discriminator
```

```
[edit]
user@host# help topic access point-to-point
Configuring the Point-to-Point Protocol
```

To configure the Point-to-Point Protocol (PPP), do the following:

- \* Configuring the Challenge Handshake Authentication Protocol
- \* Configuring the Authentication Order

```
user@host# help reference string
```

If you do not type an option for a statement that requires one, a message indicates the type of information expected. In this example, you need to type an area number to complete the command:

```
[edit]
user@host# set protocols ospf area<Enter>
```

syntax error, expecting *<identifier>*.

In this example, you need to type a value for the hello interval to complete the command:

```
[edit]
user@host# set protocols ospf area 45 interface so-0/0/0
             hello-interval<Enter>
```

syntax error, expecting *<data>*

If you have omitted a required statement at a particular hierarchy level, when you attempt to move from that hierarchy level or when you issue the **show** command in configuration mode, a message indicates which statement is missing. For example:

```
[edit protocols pim interface so-0/0/0]
user@host# top
Warning: missing mandatory statement: 'mode'
[edit]
user@host# show
protocols {
  pim {
    interface so-0/0/0 {
```

```
priority 4;  
version 2;  
# Warning: missing mandatory statement(s): 'mode'  
}  
}  
}
```



## Part 12

# Index

- Index on page 659





# Index

## Symbols

+ , statement value indicator .....	642
/ directory mount point .....	155
/config directory mount point .....	155
/var directory mount point .....	155
> , container statement indicator .....	642
?, help command .....	636
match filter command	
chassis errors, searching for .....	121
CIP errors, searching for .....	385
cooling system errors, searching for .....	272
PCG errors, searching for .....	375
PIC errors, searching for .....	190
power supply errors	
in chassisd log file .....	238
searching for .....	238
redundant PCG errors, searching for .....	603
Routing Engine errors, searching for .....	156
SCB errors, searching for .....	399
SCG errors, searching for .....	321
SFM errors, searching for .....	353, 589
SIB errors, searching for .....	309, 333, 425
SSB errors	
searching for .....	411
SSB errors, searching for .....	613

## A

activate command .....	640
Adaptive Services PIC description (M7i router) .....	7
air filter	
alarm conditions	
M320 router .....	74
M40 router .....	68
M40e and M160 routers .....	71
T320 router .....	77
T640 routing node .....	80
M40 router .....	257
maintaining .....	272
alarm LEDs	
M10i router .....	424
M7i router .....	424
alarm mode	
craft interface LCD display .....	121

## alarms

chassis, displaying .....	120
CIP .....	385
cooling system	
current .....	270
table .....	271
craft interface .....	206
FPC .....	169
HCM .....	628
messages .....	308
PIC .....	189
power supply .....	235
redundant cooling system components .....	541
redundant PCG .....	600
redundant SFM .....	588
redundant SSB .....	612
Routing Engine .....	155
SCG messages .....	320
SFM .....	353
SIB .....	332
SIB messages .....	332

## alternative media

alarm conditions	
M20 router .....	65
M320 router .....	74
M40 router .....	68
M40e and M160 routers .....	71
M5 and M10 routers .....	61
M7i and M10i routers .....	63
T320 router .....	77
T640 routing node .....	80
annotate command .....	640

## B

backup Routing Engine	
configure to assume mastership on loss of	
keepalives .....	485
configuring .....	478
description .....	479
log in from master .....	478
mastership, acquiring from backup .....	481
release mastership from backup .....	481
results of failover on loss of keepalives on .....	485
boot disk, checking router .....	154

**C**

cable management	
FPC LEDs, checking .....	283
optical equipment .....	282
PIC	
cables .....	281
fiber-optic cable .....	282
LEDs, checking .....	283
power cables .....	285
Routing Engine external cables .....	285
system, replacing .....	285
cable management system	
description .....	276
M10i router .....	277
M20 router .....	278
M40 router .....	279
M40e and M160 routers .....	280
M5 and M10 routers .....	277
replacing .....	285
T320 router and T640 routing node .....	281
cables	
checklist for maintaining .....	275
fiber-optic, maintaining .....	282
FPC LEDs .....	283
PIC, maintaining .....	281
power, maintaining .....	285
CB <i>See</i> Control Boards	
CFEB	
Adaptive Services PIC description (M7i router) .....	7
alarm conditions	
M7i and M10i routers .....	63
remedy, severity .....	424
checklist for monitoring .....	417
commands for monitoring .....	417
show chassis alarms .....	423
show chassis cfep .....	426
show chassis environment .....	422
show chassis feb .....	422
show chassis firmware command .....	430
show chassis hardware .....	429
show log chassisd .....	425
show log messages .....	424
show system uptime .....	427
component	
returning .....	430
uptime, checking .....	426
description .....	618
M10i router .....	11
M7i router .....	7
environmental status .....	422
errors	
in messages log file .....	424
failure, verifying .....	427
firmware version .....	430
hardware information .....	429
hot-pluggable FRU	
M10i router .....	12
M7i router .....	8
LEDs .....	423, 424
powering down .....	427
powering up .....	427
removal, what happens .....	619
serial number ID label, location .....	430
status, detailed .....	422
swap test .....	427
system uptime, checking .....	427
tunnel interface description (M7i router) .....	7
CFEBs	
commands for monitoring	
show chassis environment .....	417
chassis	
alarm messages .....	308
checklist for monitoring .....	107
commands for monitoring .....	107
show chassis alarms .....	120
show chassis craft-interface .....	118
show chassis environment .....	118
show chassis hardware .....	117, 122
show log messages .....	121, 122
component alarms, displaying .....	120
components installed, displaying .....	117
description .....	108
M10 router .....	11
M160 router .....	113, 116
M20 router .....	15, 109, 110
M320 router .....	31, 114
M40 router .....	19, 111
M40e router .....	23, 112
M5 and M10 routers .....	3, 109
M7i router .....	7
T320 router .....	115
chassis temperature	
alarm conditions	
M20 router .....	67
M320 router .....	76
M40 router .....	70
M40e and M160 routers .....	73
M7i and M10i routers .....	64
T320 router .....	79
T640 routing node .....	82
chassisd log file	
CIP errors .....	386
component error messages, displaying .....	83
craft interface errors .....	208
description .....	122
error messages, component, displaying .....	122
FIC errors, displaying .....	447
FPC errors .....	171

- monitor in real time.....83
- multiple items, searching for.....83
- PCG errors.....375
- power supply errors.....238
- redundant PCGs, verifying online.....603
- redundant SFM errors.....589
- redundant SSB errors.....613
- SCB errors.....399
- SCG errors.....321
- SFM errors.....354
- SIB errors.....333
- specific information, searching for.....83
- SSB errors.....411
- checklist for monitoring
  - cables.....275
  - CFEB.....417
  - chassis.....107
  - CIP.....381
  - Control Boards.....301
  - cooling system.....251, 301, 559
  - craft interface.....197
  - FEB.....453
  - FIC.....443
  - FPCs.....163
  - HCM.....431
  - host module.....289, 341
  - MCS.....359
  - PCGs.....369
  - PICs.....183
  - power supplies.....217
  - redundant CFEBs.....617
  - redundant Control Boards.....559
  - redundant cooling system components.....523
  - redundant HCMs.....623
  - redundant hosts.....463
  - redundant MCSs.....567
  - redundant PCGs.....595
  - redundant power supplies.....507
  - redundant Routing Engines.....491
  - redundant SFMs.....577
  - redundant SIBs.....543
  - redundant SSBs.....605
  - Routing Engine.....125
  - SCB.....393
  - SCGs.....315, 551
  - SFMs.....347
  - SIBs.....325
  - SSB.....405
- CIP
  - alarm conditions
    - M320 router.....74
    - M40e and M160 routers.....71
    - T320 router.....77
    - T640 routing node.....80
  - alarms.....385
  - checklist for monitoring.....381
  - commands for monitoring.....381
    - show chassis alarms.....381, 385
    - show chassis environment.....381, 384
    - show chassis hardware.....381, 388
    - show log chassisd.....381, 386
    - show log messages.....381
  - component figure.....382
  - description.....382
  - environmental status.....384
  - errors.....385
    - in chassisd log file.....386
    - in messages log file.....385
  - failure, verifying.....386
  - FRU requiring router shutdown.....24, 28, 36
  - hardware information.....388
  - hot-pluggable FRU
    - M320 router.....32
    - T640 routing node.....41
  - M40e and M160 router location.....384
  - replacing.....389
  - serial number ID label location.....389
  - swap test.....387
- circuit breaker, checking.....239
- clear command.....633
- CLI
  - commands
    - router monitoring, common.....53
  - configuration mode
    - + , statement value indicator.....642
    - > , container statement indicator.....642
    - changes, uncommitted, exiting with.....647
    - characters requiring quotation marks.....642
    - command history, displaying list of.....650
    - commands, table.....640
    - configuration *See* configuration, router
    - description.....639
    - entering.....646
    - example configuration.....645
    - exiting.....647
    - help, displaying.....653
    - hierarchy tree, description.....644
    - navigation commands, table.....647
    - operational mode commands, running
      - within.....649
    - statement path, example.....645
    - top-level commands, table.....641
    - top-level statements, table.....642
  - description.....633
  - JUNOS software
    - configuration mode.....50
    - operational mode.....50
  - operational mode.....639

- command completion ..... 638
- command history, displaying ..... 639
- commands, table ..... 633
- description ..... 633
- entering ..... 636
- help ..... 636
- top-level commands, table ..... 637
- using ..... 635
- command prompt
  - format if graceful-switchover is configured ..... 478
- command-line interface *See* CLI
- commands
  - configuration mode CLI, table ..... 640
  - operational mode CLI, table ..... 633
- commands for monitoring
  - CFEB ..... 417
  - chassis ..... 107
  - CIP ..... 381
  - Control Boards ..... 298, 301
  - cooling system ..... 251, 301, 559
  - craft interface ..... 197
  - FEB ..... 453
  - FIC ..... 443
  - FPCs ..... 163
  - HCM ..... 431
  - host module ..... 289, 341
  - MCS ..... 346, 359
  - PCGs ..... 369
  - PICs ..... 183
  - power supplies ..... 217
  - redundant CFEBs ..... 617
  - redundant Control Boards ..... 559
  - redundant cooling system components ..... 523
  - redundant HCMs ..... 623
  - redundant hosts ..... 463
  - redundant MCSs ..... 567
  - redundant PCGs ..... 595
  - redundant power supplies ..... 507
  - redundant Routing Engines ..... 491
  - redundant SFMs ..... 577
  - redundant SIBs ..... 543
  - redundant SSBs ..... 605
  - Routing Engine ..... 125, 297, 298, 345
  - SCB ..... 393
  - SCGs ..... 315, 551
  - SFMs ..... 347
  - SIBs ..... 325
  - SSB ..... 405
- commit command ..... 640, 650
- compact flash disk
  - file system
    - description ..... 155
- Compact Forwarding Engine Board *See* CFEB
- components
  - alarms, displaying ..... 61, 120
  - built-in
    - FIC (M7i router) ..... 8
    - FPC ..... 12
  - CLI commands for monitoring, common ..... 53
  - environmental status ..... 118
    - CLI commands ..... 59
    - displaying detailed ..... 59
  - error messages
    - displaying in chassisd log file ..... 122
    - in chassisd log file ..... 83
    - in messages log file ..... 83
  - failure
    - verifying ..... 84
  - FRUs requiring router shutdown
    - CIP ..... 24, 28, 36
    - FEB ..... 4
    - Routing Engine ..... 4
  - hot-pluggable FRUs ..... 36
    - CFEB ..... 8, 12
    - CIP ..... 32, 41
    - Control Board ..... 32
    - cooling system ..... 8
    - HCM (M10i router) ..... 12
    - host module ..... 24, 28
    - host subsystem ..... 32
    - MCS ..... 24, 28
    - PCG ..... 24, 28
    - Routing Engine ..... 8, 12, 16, 20, 24, 29
    - SCB ..... 20
    - SCG ..... 37, 42
    - SFM ..... 24
    - SSB ..... 16
  - hot-removable and hot-insertable FRUs
    - cooling system ..... 12, 16, 20, 24, 32, 36, 41
    - craft interface ..... 20, 24, 28, 32, 37, 41
    - FPC (T320 router) ..... 41
    - FPCs ..... 16, 20, 24, 28, 32, 37
    - PICs ..... 8, 12, 16, 20, 24, 28, 32, 37, 41
    - power supplies ..... 8, 12, 16, 24, 28, 32, 37, 41
    - Routing Engine ..... 32, 37, 41
    - SFM ..... 29
    - SFP ..... 12
    - SIB ..... 32, 37, 42
  - hot-removable FRUs
    - cooling system ..... 28
  - installed in router chassis, displaying ..... 117
  - key ..... 92
    - Packet Forwarding Engine ..... 91, 92
    - Routing Engine ..... 91, 92
  - LED
    - locations per routing platform ..... 52, 58
    - status, checking ..... 57
  - M10 router ..... 11

- M10i router ..... 12
- M160 router ..... 27, 28, 36
- M20 router ..... 15, 16
- M320 router ..... 31, 32
- M40 router ..... 19, 20
- M40e router ..... 23, 24
- M5 and M10 routers ..... 3, 4
- M7i router ..... 7, 8
- monitoring
  - method ..... 47
  - tools ..... 49
- operational status, detailed, CLI commands ..... 60
- part number, displaying ..... 122
- problems
  - solving ..... 84
- redundant
  - cooling system (M5 and M10 routers) ..... 4
  - power supplies (M5 and M10 routers) ..... 4
- returning ..... 123
- serial number, displaying ..... 122
- status, displaying from craft interface ..... 118
- swap testing ..... 122
- T320 router ..... 35
- T640 routing node ..... 40, 41
- version number, displaying ..... 122
- configuration mode, CLI
  - + , statement value indicator ..... 642
  - > , statement container indicator ..... 642
- command
  - table ..... 640
- command history, displaying ..... 650
- commands
  - activate ..... 640
  - annotate ..... 640
  - commit ..... 640
  - copy ..... 640
  - deactivate ..... 640
  - delete ..... 640
  - edit ..... 640
  - exit ..... 640
  - help ..... 640
  - insert ..... 640
  - load ..... 640
  - quit ..... 640
  - rename ..... 640
  - rollback ..... 641
  - run ..... 641
  - save ..... 641
  - set ..... 641
  - show ..... 641
  - status ..... 641
  - top ..... 641
  - top-level, table ..... 641
  - up ..... 641
  - update ..... 641
  - configuration hierarchy, description ..... 644
  - configuration *See* configuration, router
  - description ..... 639
  - entering ..... 646
  - example configuration ..... 645
  - help about statements, getting ..... 653
  - hierarchy tree, description ..... 644
  - identifier, description ..... 641
  - messages
    - locked database ..... 646
    - uncommitted changes ..... 646
    - user editing locked configuration ..... 646
  - navigation commands, table ..... 647
  - operational mode commands, running
    - within ..... 649
  - statement
    - characters requiring quotation marks ..... 642
    - container ..... 644
    - deleting ..... 649
    - description ..... 641
    - hierarchy, figure ..... 644
    - leaf ..... 644
  - statement path
    - example ..... 645
  - statements, top-level
    - accounting-options ..... 642
    - chassis ..... 642
    - class-of-service ..... 643
    - firewall ..... 643
    - forwarding-options ..... 643
    - groups ..... 643
    - interfaces ..... 643
    - policy-options ..... 643
    - protocols ..... 643
    - routing-instances ..... 643
    - routing-options ..... 643
    - snmp ..... 643
    - system ..... 643
    - table ..... 642
    - uncommitted changes, exiting with ..... 647
- configuration, router
  - activating ..... 651
  - at a specific level, displaying ..... 648
  - at current hierarchy level, displaying ..... 648
  - changing while configuration is locked ..... 646
  - committed, most recent, returning to
    - and loading without activating ..... 651
  - currently running on the router, displaying ..... 648
  - edit command, using ..... 649
  - entire hierarchy, deleting starting at current
    - hierarchy level ..... 649
  - example ..... 645
  - file, saving ..... 651

format.....	648	hot-removable and hot-insertable	
last current committed, displaying.....	648	FRUs .....	4, 8, 12, 16, 20, 24, 32, 36, 41
modifying.....	649	hot-removable FRU .....	28
previous, displaying.....	652	impeller failure, verifying.....	273
prior to most recently committed, returning		M20 router	
to.....	651	airflow .....	253, 254, 256, 262
saving		components.....	255
activating, and exiting.....	650	location.....	255
and activating.....	650	M40 router	
to a text file .....	651	air filter.....	257
set command, using .....	649	airflow .....	258
statement, deleting .....	649	components.....	257
syntax checking .....	650	location.....	257
uncommitted changes, exiting with .....	647	M40e and M160 routers	
users currently editing the configuration,		airflow .....	261, 263, 264, 265
displaying .....	648	components.....	260, 264, 266
configure command.....	633	location.....	260, 264, 266
Connector Interface Panel <i>See</i> CIP		M5 and M10 routers	
Control Boards .....	32	airflow .....	253
alarm conditions		components.....	253
M320 router.....	74	location.....	253
T320 router.....	77	redundancy.....	4, 12, 16, 20, 24, 28, 32, 36, 41, 524
T640 routing node .....	80	copy command.....	640
commands for monitoring		craft interface	
show chassis alarms.....	301	alarm conditions .....	61
show chassis craft-interface .....	301	M20 router .....	65
show chassis environment cb .....	289, 298, 301	M320 router.....	74
show chassis hardware .....	302	M40 router .....	68
show log messages .....	301	M40e and M160 router .....	71
hot-pluggable FRU.....	32, 36	T320 router.....	77
LEDs.....	309, 565	T640 routing node .....	80
redundancy.....	36, 41, 561	alarm mode .....	169
T320 router.....	32	alarms.....	206
replacing .....	566	characteristics per routing platform .....	57, 202
status, displaying .....	298	checklist for monitoring .....	197
T320 router.....	36	CLI command output per routing platform.....	56
conventions, documentation .....	xxix	commands for monitoring.....	197
cooling system .....	32, 257	show chassis alarms.....	206
air filter, maintaining.....	272	show chassis craft-interface.....	203, 204
alarms		show chassis environment .....	203
craft interface, checking from.....	270	show chassis environment fpm .....	204
current, displaying.....	270	show log chassisd .....	208
table.....	271	show log messages .....	207
checklist for monitoring.....	251, 301, 559	component status, displaying at the	
commands for monitoring.....	251, 301, 559	command line .....	118
show chassis alarms.....	251, 270	description .....	199
show chassis craft-interface .....	251, 270	environmental status.....	203
show chassis environment .....	251, 267, 539	errors	
show log messages .....	251, 271	in chassisd log file.....	208
components, replacing.....	273	in messages log file.....	207
description .....	252	failure	
environmental status.....	267	symptoms .....	203
errors in messages log file .....	271	verifying.....	205
fan failure, verifying .....	272	front panel module environmental status.....	204

- hardware information .....208
  - hot-removable and hot-insertable
    - FRUs ..... 16, 20, 24, 28, 32, 41
  - information, displaying .....204
  - items on faceplate per routing platform ..... 51
  - LCD display, alarm mode ..... 121
  - LEDs
    - host module, M40e and M160
      - routers .....296, 344
    - redundant host module .....143
  - M20 router .....200
  - M40 router .....200
  - M40e and M160 routers .....201, 202
  - M5 and M10 router ..... 4
  - M5 and M10 routers ..... 199
  - replacing .....209
    - M20 router .....209
    - M40 router .....209
    - M40e and M160 routers .....210
  - returning .....215
  - serial number ID label location
    - M20 router .....213
    - M40 router .....214
    - M40e and M160 routers .....214
  - status
    - displaying at the command line .....203
    - displaying from craft interface .....203
  - use to monitor router status ..... 56
  - craft-interface
    - hot-removable and hot-insertable FRU .....37
  - customer support
    - contacting ..... xxxiii, 53
- D**
- DC power supplies
    - T320 router .....36
  - deactivate command .....640
  - delete command .....640
  - detailed operational status commands, table ..... 60
  - disabled Routing Engine, description .....479
  - documentation conventions ..... xxix
- E**
- edit command .....640, 649
  - end-of-service announcement
    - M40 router ..... 19, 132
    - M5 and M10 routers .....3
  - environmental status
    - commands, table .....59
    - components, checking .....118
    - displaying detailed .....59
  - error messages, component
    - displaying in chassisd log file .....83, 122
    - displaying in messages log file .....83
- errors
- CFEB
    - in messages log file .....424
  - CIP
    - in chassisd log file .....386
    - in messages log file .....385
    - searching for with | match filter
      - command .....385
  - craft interface
    - in chassisd log file .....208
    - in messages log file .....207
  - FPC .....171
    - in chassisd log file .....171
    - in messages log file .....170
  - PCG
    - in chassisd log file .....375
    - in messages log file .....375
    - searching for with | match filter
      - command .....375
  - power supply
    - in chassisd log file .....238
    - in messages log file .....238
    - searching for with | match filter
      - command .....238
  - redundant Routing Engine, in mastership
    - log file .....504
  - redundant SFMs
    - in chassisd log file .....589
    - in messages log file .....589
  - redundant SSBs
    - in chassisd log file .....613
    - messages log file .....613
  - SCB
    - in chassisd log file .....399
    - in messages log file .....398
    - searching for with | match filter
      - command .....399
  - SCG
    - in chassisd log file .....321
    - in messages log file .....321
    - searching for with | match filter
      - command .....321
  - SFM
    - in chassisd log file .....354
    - in messages log file .....353
    - searching for with | match filter
      - command .....353
  - SIB
    - in chassisd log file .....333
    - in messages log file .....333
    - searching for with | match filter
      - command .....309, 333, 425
  - SSB
    - in chassisd log file .....411

in messages log file .....	410	FRU requiring router shutdown.....	4
searching for with   match filter		hardware information .....	459
command.....	411	location on M5 and M10 routers.....	421, 455
exit command.....	640	replacing.....	429, 430, 449, 455, 458, 460, 621
exit configuration-mode command.....	647	status, detailed .....	456, 621
		swap test .....	428, 458
		system uptime, checking .....	457
<b>F</b>		<b>FIB</b>	
failover, automatic		checklist for monitoring .....	443
configure .....	469	fiber-optic cable	
description .....	469	cleaning .....	282
fan assemblies, triple, M40 router .....	529	maintaining.....	282
fan tray		safety guidelines.....	282
alarm conditions		<b>FIC</b>	
M20 router .....	65	commands for monitoring.....	443
M320 router.....	74	show chassis hardware .....	443
M40 router .....	68	show chassis pic pic-slot 3 fpc-slot 1 .....	443
M40e and M160 routers .....	71	show log chassisd .....	443
M5 and M10 routers.....	61	show log messages .....	443
M7i and M10i routers.....	63	description .....	8, 444
T320 router.....	77	errors	
T640 routing node .....	80	display in chassisd log file .....	447
M10i router .....	527	display in messages log file .....	446
M20 router .....	527	Fast Ethernet ports.....	444
M40 router .....	257	Gigabit Ethernet ports.....	444
M5 and M10 routers .....	525	LEDs.....	446
M7i router .....	526	location.....	444
fans		M7i router .....	8
checklist for monitoring.....	251, 301, 559	slot numbering .....	445
commands for monitoring.....	251, 301, 559	status .....	445
show chassis alarms.....	270	status, displaying at the command line.....	446
show chassis craft-interface .....	270	<b>Field Replaceable Units <i>See</i> FRUs</b>	
show chassis environment .....	267, 539	figure .....	140, 142, 144, 145
show log messages .....	271	file command.....	634
environmental status, displaying.....	267, 539	file system	
failure, verifying.....	272	router, checking .....	154
<b>FEB</b>		filenames, listing.....	639
alarm condition		firmware version	
M5 and M10 routers.....	61	CFEB .....	430
checklist for monitoring .....	453	FEB.....	459
commands for monitoring.....	453	SSB .....	414
show chassis environment .....	445, 446, 455	<b>Fixed Interface Card <i>See</i> FIC</b>	
show chassis feb .....	456, 621	<b>Flexible PIC Concentrators <i>See</i> FPCs</b>	
show chassis firmware command .....	459	<b>Forwarding Engine Board <i>See</i> FEB</b>	
show chassis hardware .....	459	FPC1 description .....	35
show system uptime .....	457	FPC2 description .....	35
component		FPC3 description .....	36
figure .....	421	<b>FPCs</b>	
uptime, checking .....	457	alarm conditions	
description .....	419, 454	M20 router .....	65
description (M5 and M10 routers) .....	4	M320 routers .....	74
environmental status .....	455	M40 router .....	68
failure, verifying.....	457	M40e and M160 routers.....	71
figure .....	444, 454	M5 and M10 routers.....	61
firmware version.....	459		



- T320 router ..... 77
  - T640 routing node ..... 80
  - alarms ..... 169
  - bringing online ..... 173
  - characteristics for M-series routers ..... 164
  - checklist for monitoring ..... 163
  - commands for monitoring ..... 163
    - show chassis fpc pic-status ..... 284
  - description ..... 164
  - errors
    - in chassisd log file ..... 171
    - in messages log file ..... 170
  - failure, documenting ..... 173
  - hardware information ..... 177
  - hot-removable and hot-insertable FRU.... 16, 20, 24, 28, 32, 37, 41
  - kernel software version ..... 176
  - LEDs ..... 168, 284
  - M10i router ..... 12
  - M160 router ..... 27
  - M40e router ..... 24
  - numbering in M-series routers ..... 165
  - offline button ..... 283
  - replacing ..... 181
  - serial number ID label ..... 177
  - slot numbering ..... 165
  - status ..... 166, 167
  - swap test ..... 176
  - T320 router ..... 35
  - taking offline ..... 175
  - temperature ..... 167
  - uptime ..... 167
  - utilization ..... 166
  - front cooling subsystem, M40e and M160 routers ..... 531
  - front panel module, status ..... 204
  - FRUs
    - CFEB
      - M10i router ..... 12
    - CIP
      - M40e router ..... 24
    - cooling system (M10i router) ..... 12
    - cooling system (M40e router) ..... 24
    - craft interface
      - M20 router ..... 16
    - craft interface (M40e router) ..... 24
    - craft-interface
      - M5 and M10 routers ..... 4
    - FIC
      - M7i router ..... 8
    - FPC (M10i router) ..... 12
    - FPCs
      - M20 router ..... 16
    - FPCs (M40e router) ..... 24
  - HCMs
    - M10i router ..... 12
    - host module (M40e router) ..... 24
    - hot-pluggable ..... 5
    - hot-removable and hot-insertable ..... 5
    - M160 router ..... 28, 36
    - M20 router ..... 16
    - M320 router ..... 32
    - M40 router ..... 20
    - M40e router ..... 24
    - M5 and M10
      - cooling system ..... 4
      - craft-interface ..... 4
      - FEB ..... 4
      - power supplies ..... 4
      - Routing Engine ..... 4
    - M5 and M10 routers ..... 4, 8, 12
    - M7i router
      - cooling system ..... 8
    - MCS (M40e router) ..... 24
    - PCG (M40e router) ..... 24
    - PICs (M10i router) ..... 12
    - PICs (M40e router) ..... 24
    - power supplies ..... 12, 16
    - power supplies (M40e router) ..... 24
    - requiring router shutdown ..... 5
    - Routing Engine ..... 16
    - Routing Engine (M10i router) ..... 12
    - Routing Engine (M40e router) ..... 24
    - SFM (M40e router) ..... 24
    - SFP ..... 12
    - SSB
      - M20 router ..... 16
    - T640 routing node ..... 41
  - FRUs requiring router shutdown
    - CIP ..... 36
      - M40e router ..... 24
    - CIP (M160 router) ..... 28
    - description ..... 5, 9, 13, 16, 21, 25, 29, 33, 37, 42
    - FEB ..... 4
    - Routing Engine
      - M5 and M10 routers ..... 4
- G**
- graceful-switchover, command prompt format if configured ..... 478
- H**
- hard drive, file system ..... 155
  - HCM
    - alarms ..... 437, 628
    - checklist for monitoring ..... 431
    - commands for monitoring ..... 431
      - show chassis alarms ..... 431, 432, 437, 628

show chassis environment hcm .....	435, 439
show chassis hardware .....	441
show chassis routing-engine .....	431, 435
companionship with Routing Engine .....	135
component figure .....	433
components .....	434
description .....	433
description (M10i router) .....	11
failed component, returning .....	629
failure, verifying .....	628
hardware information .....	441
hot-pluggable component .....	434
hot-pluggable FRU .....	12
installing .....	440
LEDs description .....	435
LEDs, checking .....	435
location .....	434
mastership .....	
Routing Engine LEDs .....	438
mastership, displaying .....	437
mastership, switch .....	439
removal .....	438
returning .....	442
Routing Engine status, checking .....	435
serial number ID label .....	629
serial number ID label, location .....	442
status, checking using Routing Engine LEDs .....	436
swap testing .....	629
HCMs .....	
commands for monitoring .....	
show chassis routing-engine .....	431
help .....	
command .....	634, 640
reference command .....	653
topic command .....	653
High-Availability Chassis Manager <i>See</i> HCM .....	
host module .....	
commands for monitoring .....	289, 341
show chassis craft-interface .....	341
show chassis environment .....	341
show chassis routing-engine .....	341
description .....	341
M40e router .....	24
hot-pluggable FRU .....	24, 28
LEDs .....	143, 344, 345, 363
on craft interface, M40e and M160 .....	
routers .....	296, 344
status, displaying on craft interface .....	363
location on M40e and M160 routers .....	343
M160 router .....	28, 106
M40e router .....	106
redundancy .....	24, 28, 343
redundant .....	
connection between (M40e and M160 routers) .....	472
connection between (T320 router) .....	474
connection between (T640 routing node .....	474
Routing Engine and MCS (M40e and .....	
M160 router) .....	135
status .....	
checking at the command line .....	344
checking from craft interface .....	344
host redundancy .....	469
host subsystem .....	32
commands for monitoring .....	
show chassis craft-interface .....	289
show chassis environment cb .....	289
show chassis environment routing-engine .....	289
show chassis routing-engine .....	289
hot-pluggable FRU .....	32
M320 router .....	106
redundancy .....	
M320 router .....	32
redundant .....	
connection between (M320 router) .....	473
T320 router .....	36, 106
T640 routing node .....	106
hot swapping .....	
alarm conditions .....	
M20 router .....	65
M320 router .....	75
M40 router .....	68
M40e and M160 routers .....	71
M7i and M10i routers .....	63
T640 routing node .....	81
alarm conditons .....	
T320 router .....	78
hot-pluggable FRUs .....	
CFEB .....	12, 619
M7i router .....	8, 12
CIP .....	32
T640 routing node .....	41
Control Board .....	32, 36, 41
description .....	5, 9, 13, 16, 20, 25, 29, 33, 37, 42
HCM .....	12, 434
host module .....	24, 28
host subsystem .....	32
MCS .....	24, 28
PCG .....	24, 28
redundant SSBs .....	607
Routing Engine .....	12, 16, 20, 24, 29
M7i router .....	8
SCB .....	20
SCG .....	37
T640 routing node .....	42
SFM .....	24
SSB .....	16

hot-removable and hot-insertable FRUs	
cable management system .....	285
cooling system .....	12, 16, 20, 24, 32, 36, 41
(M5 and M10 routers) .....	4
M7i router .....	8
craft interface .....	16, 20, 24, 28, 32, 37, 41
description .....	5, 9, 13, 16, 20, 25, 29, 33, 37, 42
fan tray	
M20 router .....	528
M5 and M10 routers .....	525, 526
T320 router .....	536, 537
FPCs .....	16, 20, 24, 28, 32, 37, 41
PICs .....	12, 16, 20, 24, 28, 32, 37, 41
M5 and M10 routers .....	4
M7i router .....	8
power supplies .....	4, 8, 12, 16, 24, 28, 32, 37, 41
Routing Engine .....	32, 37, 41
SFM .....	29
SFP .....	12
SIB .....	32, 37, 42
hot-removable FRUs	
cooling system .....	28
hot-swapping alarm condition .....	61

## I

icons defined, notice .....	xxix
impellers	
failure, verifying .....	273
M40 router .....	257, 529
insert command .....	640
interface status .....	187

## J

JUNOS software	
access tools .....	49
control tools .....	49

## K

kernel, software version .....	176
--------------------------------	-----

## L

LEDs	
alarm (M10i router) .....	424
alarm (M7i router) .....	424
CFEB .....	423, 424
CFEB mastership, viewing .....	620
Control Board .....	309, 565
FIC .....	446
FPCs .....	168
M40 router .....	283
M40e and M160 routers .....	283
states, M40e and M160 routers .....	284
host module .....	143, 363
M40e and M160 routers .....	345

MCS .....	364
PCGs .....	372, 373
PICs .....	188
port status .....	283
states, M20 router .....	283
states, M5 and M10 routers .....	283
redundant host modules .....	143
redundant MCSs .....	573
redundant PCGs .....	599
redundant Routing Engines .....	143
redundant SFM states .....	584
Routing Engine .....	143, 363
HCM mastership, determining .....	438
M10i router .....	139
M160 router .....	143
M20 router .....	140
M320 router .....	144
M40 router .....	142
M40e router .....	143
M7i router .....	139, 140
T320 router .....	144, 145
T640 routing node .....	145
SCGs .....	318, 319, 555
SFM .....	351
SSB .....	410
load command .....	640

## M

M10 router	
chassis	
figure .....	11
components	
figure .....	11
FPC slot numbering .....	165
PIC numbering .....	185
Routing Engine	
supported .....	128
M10i router	
CFEB .....	12
CFEB description .....	11
components .....	12
cooling system .....	12
cooling system, redundant .....	12
fan tray .....	527
FPCs .....	12
HCM .....	12
component figure .....	433
description .....	11, 433
overview .....	11
Packet Forwarding Engine, data flow through .....	96
PICs .....	12
PICs, supported .....	11
power supplies .....	12
power supplies, redundant .....	12

redundant power supplies, location, figure	221, 510
Routing Engine	12
redundant, connection between	470
supported	128
Routing Engine LEDs	
figure	139
table	139
SFP	12
SFPs	11
M160 router	
air filter, maintaining	272
chassis, figure	27, 113
CIP	28
components	
figure	27
table	28, 36
cooling system	28
cooling system redundancy	28
craft interface	28
DC power supply	27
FPCs	28
bringing online	173
serial number ID label	178
slot numbering	165
status	167
FPCs supported	27
host module	28, 106, 469
host module redundancy	28
LEDs	
power supply	233, 234
MCS redundancy	28
MCSs	28
overview	27
Packet Forwarding Engine, data flow through	100
packet forwarding rate	28
PCG redundancy	28
PCGs	28
PIC	
numbering	185
supported	28
PICs	28
power supplies	28
power supply redundancy	28
redundant power supplies	
figure	226, 515
location	226, 515
redundant SFM operation	580
Routing Engine	
LEDs	143
location	133, 134
status	138
Routing Engine supported	128
Routing Engines	29
redundancy	29
SFM redundancy	29
SFM	28
M20 router	
airflow	253, 254, 256, 262, 528
cable management system	278
chassis, figure	15, 109, 110
component alarm conditions	65
components	16
figure	15
table	16
cooling system	16
alarm messages	271
components	255, 528
location	255
craft interface	16, 200
serial number ID label	213
fan trays	527
FPC	16
serial number ID label	177
slot numbering	165
LEDs	
power supply	232
overview	15
Packet Forwarding Engine, data flow through	97
packet forwarding rate	16
PICs	16
LEDs	283
numbering	185
power supply	16
integrated fan	527
serial number ID label location	244, 245
rear fan tray	527
redundant cooling system components	527
redundant power supplies, location, figure	222, 511
redundant Routing Engines	495
redundant SSB location	607
Routing Engine	16
LEDs	140, 142
location	130
panel	141
redundant, connection between	471
Routing Engine supported	128
SSB	16
M320 router	
chassis	
figure	31, 114
CIP	32
components	
alarm conditions	74
figure	31
table	32
host subsystem	106

- redundancy ..... 32
    - redundant, connection between ..... 473
  - overview ..... 31
  - Packet Forwarding Engine, data flow
    - through ..... 101
  - packet forwarding rate ..... 20
  - redundant cooling system components ..... 533
  - redundant power supplies
    - figure ..... 227, 516
    - location ..... 227, 516
  - Routing Engine
    - LEDs ..... 144
  - Routing Engine LEDs ..... 144
  - Routing Engine supported ..... 128
  - SIBs, redundant ..... 546
- M40 router
- air filter
    - figure ..... 257
    - maintaining ..... 272
  - airflow ..... 529
  - cable management system ..... 279
  - chassis, figure ..... 19, 111
  - component alarm conditions ..... 68
  - components ..... 20
    - figure ..... 19
    - table ..... 20
  - cooling system
    - airflow ..... 258
    - alarm messages ..... 271
    - components ..... 529
    - fan tray ..... 257
    - impeller trays ..... 257
  - craft interface
    - figure ..... 200
    - serial number ID label ..... 214
  - end-of-service announcement ..... 132
  - FPCs
    - LEDs ..... 283
    - serial number ID label ..... 178
    - slot numbering ..... 165
  - impellers ..... 529
  - LEDs
    - power supply ..... 232
  - overview ..... 19
  - PICs
    - media types, supported ..... 20
    - numbering ..... 185
  - power supplies
    - serial number ID label location ..... 246
  - power supply integrated fan ..... 529
  - redundant cooling system components ..... 529
  - redundant power supplies
    - figure ..... 223, 512
    - location ..... 223, 512
  - Routing Engine
    - LEDs ..... 142
    - models supported ..... 132
    - supported ..... 128
  - Routing Engine LEDs ..... 142
  - Routing Engine supported ..... 128
  - SCB description ..... 19
  - triple fan assemblies ..... 529
- M40e and M160 routers
- airflow ..... 531
  - cable management system ..... 280, 281
  - component alarm conditions ..... 71
  - cooling system
    - airflow ..... 261, 263, 264, 265
    - alarms, table ..... 271
    - components ..... 260, 264, 266
  - craft interface
    - figure ..... 201, 202
    - serial number ID label ..... 214
  - front cooling subsystem ..... 531
  - host modules, redundant, connection
    - between ..... 472
  - LEDs
    - FPC ..... 283
    - host module ..... 143, 345
  - power supply serial number ID label location ..... 248
  - rear cooling subsystem ..... 531
  - redundant cooling system components ..... 531
    - figure ..... 532
  - redundant PCG location ..... 596
  - redundant Routing Engines ..... 496, 497
  - redundant SFM location ..... 579
- M40e router
- air filter, maintaining ..... 272
  - chassis, figure ..... 23, 112
  - CIP ..... 24
  - components
    - figure ..... 23
    - table ..... 24
  - cooling system ..... 24
    - redundancy ..... 24
  - craft interface ..... 24
  - DC power supply, serial number ID label
    - location ..... 247
  - FPCs ..... 24
    - bringing online ..... 173
    - serial number ID label ..... 178
    - slot numbering ..... 165
    - status ..... 167
    - supported ..... 24
  - host module ..... 24, 106
    - redundancy ..... 24
  - LEDs
    - AC power supply ..... 232, 233, 234

DC power supply .....	233	redundant cooling system components ....	525, 526, 527
MCS.....	24	redundant power supplies	
MCS redundancy .....	24	figure .....	219, 508
overview.....	23	location.....	219, 508
Packet Forwarding Engine, data flow through .....	99	Routing Engine location .....	130
packet forwarding rate .....	24	M5 router	
PCG .....	24	FPC slot numbering .....	165
PCG redundancy .....	24	PIC	
PICs .....	24	numbering .....	185
numbering .....	185	Routing Engine supported.....	128
PICs supported .....	24	M7i and M10i routers	
power supplies .....	24	CFEB	
supported.....	23	LEDs .....	424
power supply redundancy .....	24	component alarm conditions .....	63
redundant power supplies		LEDs	
figure .....	225, 514	CFEB .....	423
location .....	224, 513	M7i router	
redundant SFM		airflow.....	526, 527
configuration .....	580	CFEB	
operation.....	580	Adaptive Services PIC description .....	7
Routing Engine .....	24	tunnel interface description.....	7
LEDs .....	143	CFEB description.....	7
location .....	133, 134	chassis	
status, checking.....	138	figure .....	7
Routing Engine redundancy .....	24	components .....	8
Routing Engine supported .....	128	figure .....	7
SFM .....	24	cooling system.....	8, 526, 527
SFM redundancy .....	24	fan tray .....	526
SFMs .....	23	FIC.....	8, 444
M5 and M10 routers		location.....	444
airflow .....	253, 525	slot numbering .....	445
cable management system.....	277	FIC description .....	8
chassis		overview.....	7
figure .....	3	Packet Forwarding Engine	
chassis, figure .....	109	data flow through.....	98
component alarm conditions .....	61	packet forwarding rate .....	8
components.....	4	PICs .....	8
figure .....	3	PICs supported .....	8
table.....	4, 8, 12	power supplies .....	8
cooling system .....	525	redundant power supplies	
alarms, table.....	271	location.....	220, 509
components.....	253	Routing Engine LEDs	
craft interface .....	4, 199	table .....	139, 140
end-of life announcement.....	3	Routing Engine supported.....	128
fan tray .....	525	M7i routers	
FEB, description .....	4	Packet Forwarding Engine	
LEDs		data flow through.....	95
power supply.....	232, 620	management port, descriptions .....	49
Packet Forwarding Engine, data flow through ....	94	master Routing Engine	
packet forwarding rate .....	4	configuring.....	478
PICs, LEDs.....	283	description .....	479
power supplies		mastership, switch from backup or master	
serial number ID label location .....	243	Routing Engine.....	481
product overview .....	3		

match filter command  
     FPC errors, searching for ..... 171

MCS  
     alarm conditions  
         M40e and M160 routers ..... 72  
     checklist for monitoring ..... 359  
     commands for monitoring ..... 359  
         show chassis environment mcs .... 341, 346, 359, 362  
         show chassis hardware ..... 359, 367  
     companionship with Routing Engine ..... 135  
     description ..... 360  
     environmental status ..... 362  
     figure ..... 292, 303, 304, 342, 360  
     hardware information ..... 367  
     hot-pluggable FRU ..... 24, 28  
     LEDs ..... 364  
         at the command line ..... 363  
         on craft interface ..... 363  
         states ..... 364  
     location on M40e and M160 routers ..... 343, 361  
     redundancy ..... 24, 28, 360, 569  
     replacing ..... 366  
     returning ..... 368  
     serial number ID label location ..... 368  
     status, displaying ..... 346  
     swap test ..... 366

messages log file  
     CFEB errors ..... 424  
     CIP errors ..... 385  
     component error messages, displaying ..... 83  
     cooling system errors ..... 271  
     craft interface errors ..... 207  
     description ..... 83  
     display in messages log file ..... 446  
     FPC errors ..... 170  
     monitoring in real time ..... 83  
     multiple items, searching for ..... 83  
     PCG errors ..... 321, 375  
     PIC errors ..... 190  
     power supply ..... 238  
     redundant PCGs, verifying online ..... 603  
     redundant SFM errors ..... 589  
     redundant SSB errors ..... 613  
     Routing Engine errors ..... 155  
     SCB errors ..... 398  
     SFM errors ..... 353  
     SIB errors ..... 333  
     specific information, searching for ..... 83  
     SSB errors ..... 410  
     what to display ..... 83

Miscellaneous Control Subsystem *See* MCS

monitor command ..... 634

mtrace command ..... 634

## N

notice icons defined ..... xxix

## O

operational mode, CLI  
     command completion ..... 638  
     command history, displaying ..... 639  
     commands  
         all available, listing ..... 637  
         clear ..... 633  
         configure ..... 633  
         file ..... 634  
         help ..... 634, 636  
         monitor ..... 634  
         mtrace ..... 634  
         of a particular letter, listing ..... 637  
         ping ..... 634  
         pipe ..... 634  
         quit ..... 634  
         request ..... 634  
         restart ..... 634  
         set ..... 634  
         show ..... 635  
         ssh ..... 635  
         start ..... 635  
         table ..... 633  
         telnet ..... 635  
         test ..... 635  
         top-level, listing ..... 637  
         traceroute ..... 635  
     description ..... 633  
     entering ..... 636  
     exiting ..... 647  
     filenames, listing ..... 639  
     using ..... 635

optical equipment, maintaining ..... 282

## P

Packet Forwarding Engine  
     clock source, displaying ..... 374  
     components per routing platform ..... 93  
     data flow through  
         M10i router ..... 96  
         M160 router ..... 100  
         M20 router ..... 97  
         M320 router ..... 101  
         M40 router ..... 98  
         M40e router ..... 99  
         M5 and M10 routers ..... 94  
         M7i router ..... 95  
         T320 router ..... 103  
     description ..... 92  
     packet forwarding rates ..... 92  
     T320 router ..... 36

packet forwarding rate.....	16	description .....	184
M160 router.....	28	errors, in messages log file .....	190
M320 router.....	20	FPC status .....	187
M40e router.....	24	hardware information .....	187
M5 and M10 routers.....	4	hot-removable and hot-insertable	
M7i router.....	8	FRU.....	4, 8, 12, 16, 20, 24, 28, 32, 37, 41
routing platforms.....	92	interface status, displaying .....	187
T320 router.....	35	LEDs.....	188
T640 routing node.....	39	port status .....	283
PCGs		states, M5 and M10 routers.....	283
alarm conditions		M40e router.....	24
M40e and M160 routers .....	72	M7i router	
alarms.....	375	supported.....	8
checklist for monitoring.....	369	media types .....	186, 284
commands for monitoring.....	369	checking for a particular FPC .....	187
show chassis alarms.....	369, 375	supported.....	20, 184
show chassis clocks.....	369, 374	numbering for M-series routers.....	185
show chassis craft-interface .....	369, 372, 373	row and slot numbering.....	185
show chassis environment .....	369, 371	serial number ID label location .....	192
show chassis environment pcg.....	369, 372	SFPs.....	11
show chassis hardware .....	370, 379	status .....	186
show log chassisd .....	369, 375	supported	
show log messages .....	369, 375	M10i router.....	11
description .....	370	M160 router.....	28
environmental status.....	371	supported media types.....	15
detailed .....	372	M5 and M10 routers.....	4
errors		swap test.....	190
in chassisd log file.....	375	ping command.....	634
in messages log file .....	375	pipe command.....	634
searching for with   match filter		power cables, maintaining .....	285
command.....	375	power supplies .....	20, 32
failure, verifying.....	376	alarm conditions .....	72
hardware information .....	379	M20 router.....	66
hot-pluggable FRU.....	24, 28	M320 router.....	75
LEDs		M40 routers .....	69
at the command line .....	372	M5 and M10 .....	62
states .....	373	M7i and M10i routers.....	63
mastership		T320 router.....	78
checking on component faceplate.....	374	T640 routing node .....	81
displaying at the command line .....	373	alarms	
displaying from primary clock source.....	374	displaying.....	235
redundancy.....	24, 28, 370, 596	from craft interface.....	237
replacement.....	324, 370, 380	M-series routers, table .....	236
serial number ID label.....	379	cables, checking .....	229
swap test.....	378	characteristics by routing platform .....	218, 508
PFE Clock Generators <i>See</i> PCGs		checklist for monitoring.....	217
Physical Interface Cards <i>See</i> PICs		circuit breaker, checking.....	239
PICs		commands for monitoring.....	217
alarms.....	189	(M40e and M160 routers) show chassis	
cables, maintenance.....	281	environment pem .....	231
characteristics for M-series routers.....	184	show chassis alarms .....	235
checklist for monitoring.....	183	show chassis craft-interface.....	237
commands for monitoring.....	183	show chassis environment .....	240
show chassis fpc pic-status.....	276, 284	show chassis environment command.....	230



show chassis environment pem.....	241
show chassis hardware .....	242
show log chassisd .....	238
show log messages .....	238
cooling system, checking router .....	240
DC	
M160 router.....	27
T320 .....	36
description .....	218, 508
errors	
in chassisd log file.....	238
in messages log file.....	238
searching for with   match filter	
command.....	238
failure (M40e and M160 routers)	
symptoms .....	235
hardware information .....	242
hot-removable and hot-insertable	
FRU.....	8, 16, 24, 28, 41
hot-removable and hot-insertable FRUs.....	12, 32
LEDs	
M160 router.....	233, 234
M20 router .....	232
M40 router .....	232
M40e router, AC.....	232, 233, 234
M40e router, DC.....	233
M5 and M10 routers.....	232, 620
location	
M40 router .....	223, 512
M5 and M10 routers	
hot-removable and hot-insertable FRU .....	4
power switch, checking.....	239
redundancy .....	4, 8, 12, 16, 20, 24, 28, 32, 41, 508
replacing.....	250
serial number ID label location	
M20 router .....	244, 245
M40 router .....	246
M40 router AC.....	247
M40e and M160 routers DC .....	248
M5 and M10 routers.....	243
status .....	230
testing.....	241
power supplies (DC) .....	37
hot-removable and hot-insertable FRU.....	37
redundancy	
T320 router.....	37
power supply integrated fan	
M20 router .....	527
M40 router .....	529

## Q

quit command .....	634, 640
--------------------	----------

## R

rear cooling subsystem	
M40e and M160 routers.....	531
redundant CFEs	
checklist for monitoring.....	617
commands for monitoring.....	617
show chassis cfeb.....	617
show chassis hardware .....	617, 620
description .....	618
hardware information.....	620
LEDs.....	620
location.....	619
redundant components.....	20, 32, 37
control board	
T320 router .....	36
T640 routing node .....	41
cooling system.....	4, 12, 16, 20, 524
M160 router .....	28
M40e router .....	24
T320 router .....	36
T640 routing node .....	41
host module	
M160 router .....	28
host modules	
M40e router .....	24
hosts.....	469
MCS.....	469, 561, 569
M160 router .....	28
M40e router .....	24
PCGs.....	596
M160 router .....	28
M40e router .....	24
power supplies.....	4, 8, 12, 16, 508
M160 router .....	28
M40e router .....	24
T640 routing node .....	41
Routing Engine .....	16, 469, 493
M160 router .....	29
M40e router .....	24
T640 routing.....	41
SCG	
T640 routing node .....	42
SFMs .....	579
M160 router .....	29
M40e router .....	24
SIB	
T640 routing node .....	42
SSB .....	16, 606
redundant Control Board	
environment status .....	564
redundant Control Boards .....	561
alarms.....	565
commands for monitoring	
show chassis craft-interface.....	559, 565

show chassis environment cb .....	559, 564	redundant hosts	
show chassis hardware .....	559	checklist for monitoring .....	463
mastership, switching .....	565	commands for monitoring .....	463
redundant cooling system components		description .....	469
alarms .....	541	redundant MCSs	
by routing platforms .....	524	checklist for monitoring .....	567
checklist for monitoring .....	523	commands for monitoring .....	567
commands for monitoring .....	523	show chassis craft-interface .....	572
description .....	524	show chassis environment mcs .....	571
M20 router .....	527	show chassis hardware .....	570
airflow .....	528	description .....	561, 569
components .....	528	hardware information .....	570
M320 router .....	533	LED	
M40 router .....	529	states .....	143, 573
airflow .....	529	states from craft interface .....	572
components .....	529	location in M40e and M10 routers .....	569
M40e and M160 routers .....	531	mastership, switching .....	573
airflow .....	531	returning .....	575
figure .....	532	status, environmental .....	571
M5 and M10 routers .....	525, 526, 527	swap test .....	574
airflow .....	525, 526, 527	redundant PCGs	
components .....	525	alarms .....	600
M7i router		bringing online .....	602
components .....	527	checklist for monitoring .....	595
M7i router, components .....	526	commands for monitoring .....	595
replacing .....	541	request chassis pcg slot online .....	602
status .....	541	request chassis pcg slot slot-number	
T320 router .....	534, 537	online .....	595
airflow .....	535	show chassis alarms .....	595, 600
components .....	535	show chassis clocks .....	595, 600
T640 routing node		show chassis craft-interface .....	595, 598, 599
airflow .....	537	show chassis environment .....	595, 597, 598
components .....	537	show chassis environment pcg .....	595, 602
redundant HCMs		show chassis hardware .....	595, 597
commands for monitoring		show log chassisd .....	595
request chassis routing-engine-master switch ...		show log messages .....	595, 603
627		description .....	596
show chassis environment hcm ....	623, 626, 627	errors, searching for with   match filter	
show chassis environment hcm		command .....	603
slot-number .....	626	hardware information .....	597
show chassis hardware .....	625	LED states .....	598, 599
show chassis routing-engines .....	628	location in M40e and M160 routers, figure .....	596
environmental status of specified slot .....	626	mastership .....	599
failure, verifying .....	628	displaying .....	600
hardware information .....	625	from Packet Forwarding Engine clock	
location .....	434	source .....	600
mastership		online	
LEDs, viewing .....	625	verifying using chassisd log file .....	603
mastership status .....	627	verifying using environmental status .....	602
mastership, switching .....	627	verifying using messages log file .....	603
redundant host modules		replacing .....	601
LEDs .....	143	status	
figure .....	143	detailed environmental .....	598
states .....	143	environmental .....	597

- redundant power supplies
  - checklist for monitoring .....507
  - commands for monitoring .....507
    - show chassis hardware .....519
  - description .....508
  - hardware information .....519
  - M10i router .....221, 510
  - M160 router .....226, 515
  - M20 router .....222, 511
  - M320 router .....227, 516
  - M40 router .....223, 512
  - M40e router .....224, 225, 513, 514
  - M5 and M10 routers .....219, 508
  - M7i router .....220, 509
  - T320 router .....228, 517
  - T640 routing node .....229, 518
- redundant Routing Engines .....480, 485
  - apply groups, displaying .....487
  - automatic failover .....501
  - backup
    - configure to assume mastership on loss
      - of keepalives .....485
    - configuring .....478
    - description .....479
    - display .....480
  - behavior, default .....501
  - checklist for monitoring .....491
  - commands for monitoring .....491
    - request chassis routing-engine master
      - acquire .....505
    - request chassis routing-engine master
      - switch .....505
    - show chassis craft-interface .....146
    - show chassis hardware .....463, 476, 491, 502
    - show chassis redundancy .....491
    - show chassis routing-engine..476, 477, 480, 491, 502, 503
    - show log mastership .....464, 482, 491, 504
  - configuration .....500, 580, 608
  - configure
    - backup .....479
    - master .....479
  - configured groups, displaying .....486
  - description .....493
  - determining which one you are logged in to .....476
  - disabled description .....479
  - errors, in mastership log .....504
  - groups, configuring .....486
  - hardware information .....502
  - LEDs .....143
    - on M20 router craft interface .....140
    - states .....143
  - M20 router, figure .....495
  - M40e and M160 routers .....496, 497
- master
  - configuring .....478
  - description .....479
  - to backup switchover, manual .....481, 504
  - to backup switchover, reasons for .....482
- mastership
  - checking LEDs for .....478
  - checking Routing Engine LEDs for .....478
  - displaying .....477, 503
  - election .....505
- mastership log
  - event codes .....483
  - viewing .....482
- problems, avoiding .....486
  - configuration file, copy from one Routing Engine to another .....488
  - configurations, synchronize .....488
  - proper shutdown process on backup
    - Routing Engine, using .....489
    - same Routing Engine type, using .....486
    - same version of JUNOS software, using .....486
- redundancy log messages .....504
- status .....146
  - detailed .....502
- redundant SCGs
  - commands for monitoring
    - request chassis scg offline slot number .....551
    - show chassis craft-interface .....551, 555, 556
    - show chassis environment .....551, 553
    - show chassis environment scg .....551, 554
    - show chassis hardware .....551
  - environmental status .....553
    - detailed .....554
  - hardware information .....553
  - LEDs, states .....555
  - mastership, displaying at the command line .....556
  - returning .....557
  - swap test .....556
- redundant SFMs
  - alarms .....588
  - bringing online .....592
  - checklist for monitoring .....577
  - commands for monitoring .....577, 592
    - request chassis sfm master switch .....593
    - request chassis sfm slot online .....592
    - request chassis sfm slot restart .....590
    - show chassis alarms .....588
    - show chassis craft-interface .....584, 588
    - show chassis environment .....585
    - show chassis environment sfm .....585
    - show chassis hardware .....581
    - show chassis sfm .....582, 587
    - show chassis sfm detail .....582
    - show log chassisd .....589

show log messages .....	589	hardware information .....	608
configuring .....	580	hot-pluggable FRU .....	607
description .....	579	LEDs .....	610
environmental status .....	585	location on M20 router .....	607
detailed .....	585	mastership .....	611
errors .....		switching .....	615
in chassisd log file .....	589	removing .....	607
in messages log file .....	589	replacing .....	616
failure, verifying .....	590	status .....	
hardware information .....	581	detailed environmental .....	610
LEDs .....		environmental .....	609
states .....	584	swap test .....	614
status from craft interface information .....	584	Redundant Switching Interface Board <i>See</i> SIB	
location on M40e and M160 routers .....	579	rename command .....	640
mastership .....		request chassis fpc command .....	
from craft interface information .....	588	FPC, bringing online .....	173
from summary status .....	587	request chassis pcg slot online command .....	
switching .....	593	redundant PCGs, bringing online .....	602
operation .....		request chassis routing-engine master acquire command .....	
on M160 router .....	580	backup to master Routing Engine .....	
on M40e router .....	580	switchover .....	481
replacing .....	593	redundant Routing Engines, backup-to-master switch .....	505
restarting .....	590	request chassis routing-engine master release command .....	
status .....		backup to master switchover, from master Routing Engine .....	481
detailed .....	582	request chassis routing-engine master switch command .....	
summary .....	582	mastership from either backup or master Routing Engine .....	481
swap test .....	591	redundant Routing Engines, master-to-backup switch .....	505
taking offline .....	592	switch Routing Engine mastership .....	439
redundant SIBs .....		request chassis routing-engine-master switch command .....	
commands for monitoring .....		redundant HCMs, switch mastership .....	627
show chassis environment sib .....	543	request chassis sfm master switch command .....	
show chassis environment sib .....	547	redundant SFM mastership, switching .....	593
show chassis hardware .....	543, 547	request chassis sfm slot offline command .....	592
show chassis sib .....	543, 547	redundant SFMs, taking offline .....	592
hardware information .....	547	request chassis sfm slot online command .....	
M320 router .....	546	redundant SFMs, bringing online .....	592
swap test, performing .....	549	request chassis sfm slot restart command .....	
T320 router .....	546	redundant SFMs, restarting .....	590
T640 routing node .....	546	request command .....	634
redundant SSBs .....		request system halt command .....	
alarms .....	612	CIP, using to shut down router software .....	387
checklist for monitoring .....	605	router software, shut down .....	439
commands for monitoring .....	605	restart command .....	634
show chassis alarms .....	612	rollback command .....	641
show chassis environment .....	609	router .....	
show chassis hardware .....	608	system architecture .....	
show chassis ssb .....	610, 611		
show log chassisd .....	613		
show log messages .....	613		
description .....	606		
errors .....			
in chassisd log file .....	613		
in messages log file .....	613		
failure, verifying .....	614		

- figure ..... 92
- Routing Engine..... 37
  - alarm conditions
    - M20 router ..... 66
    - M320 router..... 75
    - M40 router ..... 69
    - M40e and M160 routers..... 72
    - M5 and M10 routers..... 62
    - M7i and M10i routers..... 64
    - T320 router..... 78
    - T640 routing node ..... 81
  - alarms, displaying ..... 155
  - architecture, figure ..... 105
  - backup description..... 479
  - backup, configure to assume mastership on
    - loss of keepalives ..... 485
  - cables, maintaining external ..... 285
  - checklist for monitoring ..... 125
  - commands for monitoring..... 125
    - show chassis environment routing-engine .. 125, 138, 289, 298
    - show chassis hardware ..... 157
    - show chassis routing-engine.. 125, 137, 289, 297, 341, 345
    - show log messages ..... 155
  - companionship
    - with MCS (M40e and M160 routers)..... 135
  - compantionship
    - with HCM (M10i router) ..... 135
  - components ..... 127
  - description ..... 92, 104, 127
  - disabled description..... 479
  - error messages, displaying in messages
    - log file..... 155
  - failure events, documenting ..... 156
  - figure..... 291, 342
  - forwarding table..... 106
  - FRU requiring router shutdown..... 4
  - functions..... 105
  - hot-pluggable FRU ..... 8, 12, 16, 20, 24, 29
  - hot-removable and hot-insertable FRU..... 37, 41
  - hot-removable and hot-insertable FRUs..... 32
  - LEDs..... 143, 363
    - HCM mastership, determining..... 438
    - M160 router..... 143
    - M40 router ..... 142
    - M40e router ..... 143
  - LEDs, checking HCM status ..... 436
  - location
    - M10 router ..... 130, 131
    - M10i router ..... 131
    - M160 router..... 133, 134
    - M20 router ..... 130, 131
    - M40 router ..... 132
    - M40e and M160 routers..... 343
    - M40e router ..... 133, 134
    - M5 router ..... 130, 131
    - M7i router ..... 131
    - M10 router ..... 128
    - M10i router ..... 128
    - M160 router ..... 128
    - M20 router ..... 128
    - M320 router ..... 128
    - M40 router ..... 128
    - M40e router ..... 128
    - M5 router ..... 128
    - M7i router..... 128
    - master description ..... 479
    - mastership, displaying..... 437, 477
    - mastership, switch ..... 439
    - models supported (M40 router)..... 132
    - monitoring commands..... 125
    - panel, M20 router..... 141
    - panel, table, M20 router ..... 141
    - RE-1600
      - host modules, redundant, connection
        - between..... 475
    - RE-600
      - host modules, redundant, connection
        - between..... 474
    - redundancy ..... 16, 24, 29, 32, 41, 493
      - T320 router ..... 37
    - redundancy per routing platform..... 135
    - redundant
      - connection between (M20 router)..... 471
      - connection between M10 router ..... 470
      - displaying which one you are logged in
        - to ..... 476
    - serial number ID label, location ..... 158
    - status
      - detailed..... 137
      - displaying..... 297, 345
      - M160 router ..... 138
      - M40e router ..... 138
      - T320 router ..... 36, 128
      - T640 router ..... 128
      - types ..... 128
  - routing platforms
    - component LED locations ..... 52, 58
    - component monitoring method ..... 47
    - cooling system alarms ..... 271
    - craft interface characteristics..... 57, 202
    - FPC
      - characteristics ..... 164
      - numbering ..... 165
    - M10i..... 11
    - M160..... 27
    - M20 ..... 15

M320 .....	31	swap test .....	400
M40.....	19	SCG.....	37
M40e.....	23	alarm conditions	
M5 and M10 .....	3	T640 routing node .....	81
M7i.....	7	hot-pluggable FRU .....	37
management port locations.....	49	T640 routing node .....	42
Packet Forwarding Engine components .....	93	redundancy.....	42
packet forwarding rates .....	92	T320 router.....	37
PIC		SCGs	
numbering, row and slot .....	185	alarm messages.....	320
PIC characteristics.....	184	alarms.....	320
power supply		checklist for monitoring .....	315, 551
alarms, table.....	236	commands for monitoring.....	315, 551
characteristics .....	508	show chassis alarms.....	315, 320
serial number ID label locations .....	242	show chassis craft-interface.....	315, 318, 319
redundant cooling system characteristics.....	524	show chassis environment .....	315, 317
Routing Engine redundancy .....	135	show chassis environment scg.....	315, 318
Routing Engines supported.....	128	show chassis hardware .....	316, 323, 553
show chassis craft-interface output .....	56	show log chassisd .....	315, 321
T320 router.....	35	show log messages .....	315, 321
T640 routing node .....	39	description .....	316
run command .....	641, 649	environmental status.....	317
		detailed.....	318
<b>S</b>		errors	
save command .....	641, 651	in chassisd log file.....	321
SCB		in messages log file.....	321
commands for monitoring		searching for with   match filter	
show chassis environment .....	396	command.....	321
show chassis firmware.....	402	failure, verifying .....	322
show chassis hardware .....	401	hardware information .....	323
show chassis scb.....	396	LEDs	
show log chassisd .....	399	at the command line .....	318, 555
show log messages .....	398	states .....	319
description .....	19, 394	mastership	
errors		displaying at the command line.....	319
in chassisd log file.....	399	swap test .....	322
in messages log file .....	398	serial number ID label	
searching for with   match filter		FPC.....	177
command.....	399	PIC	
failure, verifying .....	400	horizontal.....	192
firmware version.....	402	vertical.....	192
hardware information .....	401	power supplies, location on M-series	
hot-pluggable FRU.....	20	routers .....	242
LEDs		Routing Engine .....	158
location on component .....	397	SFM .....	357
states .....	397	SSB .....	413
location on M40 router.....	395	set command .....	634, 641, 649
replacing .....	395	SFM	
reset switch.....	397	alarm conditions	
returning .....	402	M40e and M160 routers.....	73
serial number ID label location .....	402	SFMs	
status		alarms.....	353
detailed .....	396	commands for monitoring	
environmental.....	396	show chassis alarms .....	347, 353

- show chassis craft-interface.....347, 351
- show chassis environment .....347, 351
- show chassis environment sfm .....347, 352
- show chassis hardware .....347, 357
- show chassis sfm .....347, 349
- show chassis sfm detail.....347, 350
- show log chassisd .....347, 354
- show log messages .....347, 353
- description .....23, 348
- environmental status
  - detailed.....352
  - displaying.....351
- errors
  - in chassisd log file.....354
  - in messages log file.....353
  - searching for with | match filter command..353
- failure, verifying .....355
- figure.....348
- hardware information .....357
- hot-pluggable FRU.....24
- hot-removable and hot-insertable FRU.....29
- LEDs.....351
  - displaying from command line .....351
  - status, displaying from the component
    - faceplate.....351
- location on M40e and M160 routers .....348
- M160 router.....28
- redundancy .....23, 24, 29, 348, 579
  - configuring.....580
- replacement.....358
- serial number ID label location .....357
- status
  - detailed, displaying.....350
  - displaying.....349
- swap test, performing.....356
- SFP
  - description (M10i router) .....11
  - hot-removable and hot-insertable FRUs.....12
- show chassis alarms command
  - CFEB alarms, displaying.....423
  - CIP alarms, displaying.....385
  - component alarms, displaying.....120
  - cooling system alarms, displaying.....270
  - craft interface alarms, displaying.....206
  - FPC alarms, displaying.....169
  - HCM alarms .....437
  - HCMS, alarms .....628
  - PCG alarms, displaying.....375
  - PIC alarms, displaying.....189
  - power supply alarms, displaying.....235
  - redundant PCG alarms, displaying.....600
  - redundant SFM alarms, displaying .....588
  - redundant SSB, alarms, displaying .....612
  - SCG alarms, displaying.....320
  - SFM alarms, displaying.....353
  - SIB alarms, displaying.....332
- show chassis cfeb command
  - CFEB uptime .....426
- show chassis clocks command .....600
  - PCGs, mastership, from primary clock
    - source .....374
- show chassis craft interface command
  - Control Boards LED status .....565
- show chassis craft-interface command
  - CLI output per routing platform .....56
  - craft interface status, displaying.....203, 204
  - fan alarms, checking.....270
  - FPC LED status, displaying.....168
  - host module status, displaying .....344
  - PCG LED status, displaying .....372
  - PCG mastership, displaying .....373
  - PIC alarms, displaying .....189
  - power supply alarms, displaying.....237
  - redundant MCS LEDs status, displaying.....572
  - redundant PCG LEDs states, displaying.....598
  - redundant PCG mastership, displaying .....599
  - redundant Routing Engine status, displaying ....146
  - redundant SCG LED status, displaying .....555
  - redundant SCG mastership, displaying.....556
  - redundant SFM LED states, displaying .....584
  - redundant SFM mastership, displaying .....588
  - router status from craft interface, displaying ....118
  - SCG LED status, displaying .....318
  - SCG mastership, displaying.....319
  - SFM LED status, displaying.....351
  - SIB LED status, displaying.....330
- show chassis environment cb command
  - Control Board environmental status.....564
  - Control Board status, displaying.....298
- show chassis environment command
  - CFEB environmental status.....422
  - CIP environmental status, displaying .....384
  - component environmental status, displaying ...118
  - craft interface status, displaying.....203
  - fan environmental status, displaying.....267, 539
  - FEb environmental status .....445, 446, 455
  - FPC environmental status .....167
  - MCS status, displaying.....346
  - PCG environmental status, displaying .....371
  - power supply airflow, checking.....240
  - power supply environmental status,
    - displaying.....230
  - redundant PCG environmental status,
    - displaying.....597
  - redundant SCG environmental status,
    - displaying.....553
  - redundant SFM environmental status,
    - displaying.....585

redundant SSB environmental status, displaying .....	609	FEB status, detailed, displaying.....	621
SCB environmental status, displaying .....	396	FEB status, displaying detailed .....	456
SCG environmental status, displaying .....	317	show chassis firmware command	
SFM environmental status, displaying .....	351	CFEB firmware version, displaying.....	430
SIB environmental status, displaying .....	331	FEB firmware version, displaying .....	459
SSB environmental status, displaying .....	408	firmware version .....	414
show chassis environment fpm command		SCB firmware version, displaying .....	402
M40e and M160 craft interface status, displaying .....	204	show chassis fpc command	
show chassis environment hcm		FPC status and utilization, displaying.....	166
HCM status .....	435	show chassis fpc detail command	
show chassis environment hcm command		FPCs	
HCM environmental status .....	439	detailed status, displaying .....	173
redundant HCMs status .....	626	status and uptime, displaying .....	167
redundant HCMs, environmental status .....	627	show chassis fpc pic-status command	
show chassis environment hcm slot-number command		FPC status, displaying .....	186, 284
redundant HCMs status of specified slot.....	626	PIC media type, displaying .....	186, 284
show chassis environment mcs command		show chassis hardware command	
MCS, environmental status, displaying.....	362	CFEB hardware information .....	429
redundant MCS environmental status, displaying .....	571	chassis hardware inventory, displaying .....	117, 122
show chassis environment pcg command		CIP hardware information, displaying.....	388
PCG environmental status, displaying detailed .....	372	craft interface hardware information, displaying.....	208
redundant PCG detailed environmental status, displaying .....	598	FEB hardware information .....	459
redundant PCG, verifying online.....	602	FPC hardware information .....	177
show chassis environment pem command		HCM hardware information .....	441
(M40e and M160 routers) power supply displaying detailed.....	231	MCS hardware information, displaying .....	367
(M40e and M160 routers) power supply status, displaying .....	241	PCG hardware information, displaying .....	379
show chassis environment routing-engine command		power supply hardware information, displaying.....	242
Routing Engine		redundant CFEB hardware information .....	620
status, displaying .....	298	redundant HCMs hardware information, displaying.....	625
Routing Engine, environmental status, displaying detailed.....	138	redundant MCS hardware information, displaying.....	570
show chassis environment scg command		redundant PCGs hardware information, displaying.....	597
redundant SCG environmental status, displaying detailed.....	554	redundant power supplies hardware information, displaying .....	519
SCG environmental status, detailed, displaying .....	318	redundant Routing Engine hardware information, displaying .....	502
show chassis environment sfm command		redundant Routing Engines hardware information, displaying .....	491
redundant SFM detailed environmental status, displaying .....	585	redundant SFM hardware information, displaying.....	581
SFM detailed environmental status, displaying .....	352	redundant SSB hardware information, displaying.....	608
show chassis environment sib command		Routing Engine hardware information, displaying.....	157
SIB detailed environmental status, displaying .....	331, 547	Routing Engine, displaying which one you are logged in to .....	476
show chassis feb command		SCB hardware information, displaying.....	401
CFEB status, displaying detailed .....	422	SCG hardware information, displaying .....	323, 553
		SFM hardware information, displaying .....	357
		SIB hardware information, displaying .....	337, 547



- SSB hardware information, displaying .....413
- show chassis redundancy command
  - redundant Routing Engine configuration, displaying.....491
- show chassis routing engine
  - HCM environmental status .....435
- show chassis routing-engine command
  - displaying which one you are logged in to .....476
  - HCMs, verifying failure .....628
  - mastership, displaying .....477, 480
  - redundant Routing Engines
    - detailed status, displaying.....502
    - mastership, displaying .....503
  - redundant Routing Engines configuration, displaying.....491
  - Routing Engine
    - detailed status, displaying.....137
    - status, displaying .....297, 345
- show chassis scb command
  - SCB status, displaying detailed.....396
- show chassis sfm command
  - redundant SFM mastership, displaying.....587
  - redundant SFM summary status, displaying .....582
  - SFM status, displaying .....349
- show chassis sfm detail command
  - redundant SFM detailed status, displaying .....582
  - SFM status, detailed, displaying .....350
- show chassis sib command
  - SIB status, displaying .....330, 547
- show chassis ssb command
  - redundant SSB, environmental status, detailed, displaying.....610
  - redundant SSBs, mastership, displaying.....611
  - SSB status, detailed, displaying.....409
- show cli history command .....650
- show command .....635, 641, 648
- show configuration command .....648
- show file messages command
  - PIC errors, displaying .....190
- show interface brief command
  - interface status, displaying .....188
- show interface descriptions command
  - interface status and description, displaying .....188
- show interfaces terse command
  - interface status, displaying .....187
- show log chassisd command
  - CFEB errors, in chassisd log file .....425
  - chassis component errors, displaying .....122
  - CIP errors, in chassisd log file .....386
  - craft interface errors, displaying .....208
  - PCG errors, in chassisd log file .....375
  - power supply errors, in chassisd log file .....238
  - redundant SFM errors, in chassisd log file.....589
  - redundant SSB, errors in chassisd log file.....613
  - SCB errors, in chassisd log file.....399
  - SCG errors, in chassisd log file.....321
  - SFM errors, in chassisd log file .....354
  - SIB errors, in chassisd log file .....333
  - SSB errors, in chassisd log file .....411
- show log mastership
  - redundancy log, viewing .....482
- show log mastership command
  - redundancy log messages, displaying .....504
  - redundant Routing Engines errors, displaying.....491
- show log messages command
  - CFEB errors, in messages log file .....424
  - chassis component errors, displaying .....121
  - craft interface errors, in messages log file .....207
  - fan errors, in messages log file .....271
  - FPC errors, displaying.....170, 171
  - PCG errors, in messages log file .....375
  - power supply errors, in messages log file .....238
  - redundant PCG, online, verifying.....603
  - redundant SFM errors, in messages log file.....589
  - redundant SSB errors, in messages log file.....613
  - Routing Engine compact flash disk errors, displaying.....155
  - SCB errors, in messages log file .....398
  - SCG errors, in messages log file .....321
  - SFM errors, in messages log file .....353
  - SIB errors, in messages log file .....333
  - SSB errors, in messages log file .....410
- show system uptime command
  - system uptime, displaying .....427, 457
- show version brief command
  - kernel software version, displaying .....176
- SIB .....32, 37
  - alarm conditions
    - M320 router .....75
    - T320 router .....78
    - T640 routing node .....82
  - hot-removable and hot-insertable FRU.....37, 42
  - hot-removable and hot-insertable FRUs .....32
  - redundancy .....32, 42
    - T320 router .....37
- SIBs
  - alarm messages.....332
  - alarms, displaying .....332
  - commands for monitoring
    - show chassis alarms .....325, 332
    - show chassis craft-interface.....325, 330
    - show chassis environment.....325, 331
    - show chassis environment sib .....325, 331
    - show chassis hardware .....326, 337
    - show chassis sib .....325, 330
    - show log chassisd.....325, 333
    - show log messages .....325, 333

description .....	326	firmware version .....	414
environmental status		hardware information .....	413
detailed .....	331, 547	hot-pluggable FRU .....	16
displaying .....	331	LEDs	
errors		checking on component faceplate .....	409
in chassisd log file .....	333	states .....	410
in messages log file .....	333	location on M20 router .....	407
searching for with   match filter command .....	309, 333, 425	redundancy .....	16, 606
failure, verifying .....	310, 334	replacing .....	414
hardware information .....	337	serial number ID label location .....	413
LEDs		status, detailed .....	409
displaying from command line .....	330, 626	swap test .....	412
status, displaying from the component faceplate .....	330	troubleshooting .....	407, 608
location on T320 router and T640 routing node .....	328, 545	ssh command .....	635
summary status		start command .....	635
displaying .....	330, 547	statements	
swap test, performing .....	336	configuration mode CLI, top-level .....	642
T320 router .....	36	status command .....	641
Simple Network Management Protocol <i>See</i> SNMP		support, technical	
Small Form Factor Pluggables <i>See</i> SFPs		customer support, contacting .....	xxxiii, 53
SNMP		swap test	
agent, description .....	48	CFEB .....	427
MIB, description .....	48	CIP .....	387
network manager software, description .....	48	FEB .....	428, 458
trap, description .....	48	FPC .....	176
software, router shutdown .....	387	MCS .....	366
SONET Clock Generators <i>See</i> redundant SCGs		PCGs .....	378
SONET Clock Generators <i>See</i> SCGs		PIC failure, verifying .....	190
SPMB		power supplies .....	240
alarm conditions, T640 routing node .....	82	redundant MCSs .....	574
SSB		redundant SCGs .....	556
alarm condition		redundant SFMs .....	591
M20 router .....	66	redundant SIB .....	549
M40 router .....	69	redundant SSBs .....	614
checklist for monitoring .....	405	SCB .....	400
commands for monitoring .....	405	SCGs .....	322
show chassis environment .....	405, 408	SFM .....	356
show chassis firmware .....	405, 414	SIB .....	336
show chassis hardware .....	405, 413	SSB .....	412
show chassis ssb .....	405, 409	swap testing	
show log chassisd .....	405, 411	HCMs .....	629
show log messages .....	405, 410	Switching and Forwarding Module <i>See</i> SFM	
description .....	15, 406	Switching Interface Board <i>See</i> SIB	
environmental status .....	408	System and Switch Board <i>See</i> SSB	
errors		System Control Board <i>See</i> SCB	
in chassisd log file .....	411	<b>T</b>	
in messages log file .....	410	T320 router .....	32
searching for .....	613	airflow .....	535
errors, searching for .....	411	chassis, figure .....	35, 115
failure, verifying .....	411	CIP .....	36
figure .....	394, 407	component alarm conditions .....	77
		components	
		figure .....	35

- Control Board .....36
- control board redundancy .....36
- Control Boards.....32
- cooling system.....32, 36, 41
  - components.....535
- cooling system redundancy .....36
- craft interface .....32, 37, 41
- DC power supplies .....36
- FPC.....37, 41
- FPC1 support .....35
- FPC2 support .....35
- FPC3 support .....36
- FPCs.....32, 35
- host modules, redundant, connection
  - between .....474
- host subsystem.....36, 106
- overview .....35
- Packet Forwarding Engine .....36
  - data flow through.....103
- packet forwarding rate .....35
- PIC.....37, 41
- power supplies.....41
- power supplies (DC).....37
- redundant cooling system components .....534, 537
- redundant power supplies
  - location.....228, 517
- Routing Engine .....37, 41
- Routing Engine LEDs .....144, 145
- Routing Engine supported.....128
- Routing Engines .....36
- SCG .....37
- SIB.....37, 42
- SIBs .....36
- SIBs, redundant .....546
- T320 router Control Boards.....36
- T640 router
  - host subsystem.....106
  - Routing Engine supported.....128
- T640 routing node
  - airflow.....537
  - chassis, figure .....40, 116
  - CIP.....41
  - component alarm conditions.....80
  - components .....41
    - figure .....40
  - control board redundancy .....41
  - cooling system
    - components.....537
  - cooling system redundancy .....41
  - host modules, redundant, connection between 474
  - overview .....39
  - packet forwarding rate .....39
  - power supply redundancy .....41
  - redundant power supplies
    - location.....229, 518
  - Routing Engine LEDs .....145
  - Routing Engine redundancy.....41
  - SCG.....42
  - SCG redundancy .....42
  - SIB redundancy .....42
  - SIBs, redundant .....546
  - table.....142, 144, 145
  - technical support
    - customer support, contacting .....xxxiii, 53
  - telnet command.....635
  - temperature, chassis
    - alarm conditions
      - M5 and M10 routers .....62
  - test command .....635
  - tools, router monitoring
    - chassisd log file.....52
    - CLI commands.....50
    - component LEDs.....52
    - craft interface.....51
    - JTAC .....53
    - JUNOS software .....49
    - messages log file .....52
    - SNMP agent.....49
    - SNMP MIBs.....49
    - SNMP traps.....49
    - swap test, component .....53
  - top command.....641
  - traceroute command.....635
  - typefaces, documentation conventions .....xxix
- U**
- up command .....641
- update command .....641

