

Junos[®] Space

Connectivity Services Director User Guide

Published
2022-05-24

Release
5.0R1

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Junos[®] Space Connectivity Services Director User Guide

5.0R1

Copyright © 2022 Juniper Networks, Inc. All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <https://support.juniper.net/support/eula/>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

About the Documentation | xlix

Documentation and Release Notes | xlix

Documentation Conventions | xlix

Documentation Feedback | lii

Requesting Technical Support | lii

Self-Help Online Tools and Resources | liii

Creating a Service Request with JTAC | liii

1

Overview

Working with Connectivity Services Director | 2

Connectivity Services Overview | 2

Getting Started with Connectivity Services Director | 4

Connectivity Services Director REST API Overview | 7

Format and Conventions of RESTful Web Services | 9

Payload and Response Types Supported in XML and JSON Formats | 10

Conversion of XML Format to JSON Format | 11

Understanding the Need for Connectivity Services Director for Managing Services | 12

Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14

Connectivity Services Director Overview | 15

Understanding the Connectivity Services Director User Interface | 16

Connectivity Services Director Banner | 17

View pane | 18

Views list | 19

Tasks Pane | 19

Main Window or Workspace | 19

Filtering the Network Tree | 20

Expanding or Collapsing Nodes in the Network Tree | 21

Searching the Network Tree | 21

Tables in Connectivity Services Director | 21**Moving and Resizing Columns | 22****Navigating Pages | 22****Displaying the Column list | 22****Sorting a Column | 22****Hiding and Exposing Columns | 22****Searching Table Contents | 23****Filtering Table Contents | 23****Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24****Understanding Task Categories in Connectivity Services Director | 26****Understanding Connectivity Services Director User Administration | 28****Logging In to Connectivity Services Director | 29****Changing Your Password for Connectivity Services Director | 30****Logging Out of Connectivity Services Director | 32****Getting Started Assistant Overview in Services Activation Director | 33****Service View Tasks and Lifecycle Modes | 35****Understanding the Service View Tasks Pane in Build Mode | 35****Understanding the Service View Tasks Pane in Deploy Mode | 38****Understanding the Service View Tasks Pane in Monitor Mode | 40****Understanding the Service View Tasks Pane in Fault Mode | 43****About Build Mode in Service View of Connectivity Services Director | 44****Manage Service Definitions | 44****Prestage Devices | 44****Prestage Services | 45****Service Definition Operations | 45****Audit and Troubleshooting of Services | 45****About Deploy Mode in Service View of Connectivity Services Director | 45****Manage Network Services | 46****Manage Deployment of Service Orders | 46****About Fault Mode in All Views of Connectivity Services Director | 47****About Monitor Mode in Service View of Connectivity Services Director | 48****Quick Access to Important Troubleshooting Details | 48****Performance Monitoring | 49**

View and Clear Interface Information | 49

View Interface Status | 49

View Routing Table | 49

View MAC Table | 49

Traceroute for an MPLS LSP | 50

MPLS Ping | 50

Network Services Overview | 51

Getting Started with Connectivity Services Director | 52

Prestaging Devices Overview | 55

Junos Space Layer 2 Services Overview | 56

E-Line Services | 58

Port-to-Port Service | 58

Single VLAN Service Using 802.1Q Interfaces | 59

All Traffic Service Using Q-in-Q Interface | 59

Range of VLANs Service with Q-in-Q Interfaces | 60

E-LAN Services | 61

Service Autodiscovery | 63

VPLS and Normalization | 65

Junos Space Layer 3 Services Overview | 66

Overview | 67

Layer 3 VPN Platform Support | 67

Layer 3 VPN Attributes | 67

Device Configuration for a Layer 3 VPN | 68

Provisioning Process Overview | 68

Network Operator Tasks—Provisioning Prerequisites | 69

Service Designer Tasks | 70

Service Provisioner Tasks | 70

Seamless MPLS Support in Junos Space Overview | 72

Service Attributes Overview | 74

General Attributes | 74

Service Type | 75

Signaling | 75

Comments | 75

Service Template	75
Interface Type	75
Enabling Additional Features	76
Customer	76
Enable QoS	76
UNI Settings	76
Ethernet Options	77
Interface	77
MTU	78
Customer Traffic Type	78
Customer VLAN ID	78
Service VLAN ID and VLAN ID Range	78
Physical Encapsulation	79
Logical Encapsulation	79
Rate Limiting and Bandwidth	80
UNI Settings for TDM Interfaces	80
UNI Settings for ATM Interfaces	81
Connectivity Settings	81
Virtual Private LAN Service Identifier (VPLS ID)	81
Auto Discovery	81
Virtual Circuit Identifier (VCID) (E-Line Services Only)	81
Route Targets and Route Distinguishers	82
Normalized VLAN (Multipoint Services Only)	82
MAC Learning	83
Advanced Settings	83
Tunnel Services	84
Local Switching	84
Fast Reroute Priority	84
Label Block Size	84
Connectivity Type	85
Node Settings	85
Static Routes	85
PIM Settings	86
MVPN Settings	87

MAC Settings	89
Topology Settings	89
Service Order States and Service States Overview	90
Service Order States	90
Service States	91
Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services	92
VLAN Translation (Normalization) for E-LAN Services	93
VLAN Mapping for VPLS Services	93
Sample VLAN Configuration on MX Series and M Series PE Routers	96
VLAN Pool Profiles Overview	97
Redundant Pseudowires for Layer 2 Circuits and VPLS	98
Types of Redundant Pseudowire Configurations	98
Pseudowire Failure Detection	99
VPLS over GRE Overview	99
Junos Space Network Topology Overview	100
Service Recovery Overview	102
Multicast L3VPN Overview	103
Multi-Chassis Automatic Protection Switching Overview	104
Inverse Multiplexing for ATM Overview	104
Rendezvous Point	105
Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees	106
Understanding PIM Sparse Mode	108
Rendezvous Point	109
RP Mapping Options	110
Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs	111
Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs	113
Configuring VRF Route Targets for Routing Instances for an MBGP MVPN	115
Static Pseudowire Provisioning for VPLS Services	116

Getting Started With Connectivity Services Director

Understanding Connectivity Services Director System Administration and Preferences | 118

Understanding Connectivity Services Director User Administration | 118

Understanding the System Tasks Pane | 119

Audit Logs Overview	120
Viewing Audit Logs From Connectivity Services Director	121
Managing Jobs	122
Collecting Logs for Troubleshooting	124
Setting Up User and System Preferences	125
Accessing the Preferences page	126
Choosing Server Time or Local Time	126
Specifying Search Preferences	127
Retaining Connectivity Services Director Reports	127
Modifying Services Activation Parameter Settings	127
Specifying Topology Preferences	134
Changing Monitor Mode Settings	134
Disabling Data Collection for Monitors	135
Changing the Polling Interval	136
Specifying Database History Retention	137
Changing Alarm Settings	137
Configuring Global Alarm Notifications	138
Retaining Alarm History	138
Specifying Event History	138
Enabling Alarms	138
Changing the Severity of Individual Alarms	164
Configuring Individual Alarm Notifications	165
Disabling Optical Performance Monitoring	165
Specifying NorthStar Controller Preferences	166

3

Working with the Dashboard

About the Dashboard | 168

Understanding the Dashboard | 168

Using the Dashboard | 169

Using Dashboard Widgets | 169

Dashboard Widget Reference | 171

Device Alarms Widget | 171

Service Alarms by Severity Widget | 172

Config Deployment Jobs Status Widget | 173

Config Deployment Jobs Status Widget Summary | 173

Config Deployment Jobs Status Widget Details | 173

Device & Port Utilization Heatmap Widget | 174

Using the Global Controls | 174

Interacting with the Heat Maps | 175

Viewing Active Flows on a Port | 175

Flow Analysis Details Window | 176

Port Status - Physical Widget | 178

Port Status - Physical Widget Summary | 178

Port Status - Physical Widget Details | 179

Working in Build Mode

About Build Mode | 181

Understanding Build Mode in Views Other than Service View of Connectivity Services Director | 181

Discovering Devices | 181

Building the Custom View | 182

Configuring Devices | 182

Deploying Device Configurations | 183

Importing Device Configurations | 183

Out-of-Band Configuration Changes | 183

Managing Devices | 184

Understanding the Build Mode Tasks Pane in Views Other than Service View | 184

Discovering Devices | 188

Discovering Devices | 188

Troubleshooting Device Discovery Error Messages | 190

Viewing the Brownfield Job | 192

Creating Custom Device Groups | 194

Understanding Custom Device Groups | 194

Where Is the Custom Group Function Located in Connectivity Services Director? | 195

How Do Custom Group Rules Work? | 195

What Happens When I Edit a Custom Group Rule? | 196

When Are Rules Executed? | 196

Creating Custom Device Groups | 196

Creating Custom Groups | 197

Creating a Custom Group | 197

Configuring Quick Templates | 202

Understanding Quick Templates | 202

Configuring and Managing Quick Templates | 203

Creating a Quick Template | 205

Applying Templates to Devices | 206

Editing a Quick Template | 207

Deleting a Quick Template | 207

Cloning a Quick Template | 208

Using the Quick Template Details Window | 208

Viewing Deployed Quick Templates | 208

Configuring Device Settings | 210

Understanding Device Common Settings Profiles | 210

Creating and Managing Device Common Settings | 211

Managing Device Common Settings | 211

Creating a Device Common Settings Profile | 213

Specifying Basic Settings for Device Common Settings | 215

Specifying Management Settings for Routing Device Common Settings | 218

Specifying Protocol Settings for Routing Device Common Settings | 221

Reviewing and Saving a Device Common Settings Configuration | 223

What to Do Next | 224

Assigning Device Common Settings to Devices | 224

Assigning Device Common Settings | 225

Editing the Assignments of the Device Common Setting | 227

Configuring Class of Service (CoS) | 228

Understanding Class of Service (CoS) Profiles | 228

How Would I Use CoS (also known as QoS)? | 229

How Do I Create CoS Groups? | 229

How Is CoS Different From QoS? | 229

How Does CoS Work? | 230

What CoS Parameters Can I Control? | 231

What Are the Default CoS Traffic Types? | 231

Data Center Switching CoS Configuration | 232

How Do I Implement Class of Service? | 232

Editing Discovered CoS Profiles | 232

Creating and Managing Wired CoS Profiles | 233

Managing Wired CoS Profiles | 234

Using the Default CoS Profiles for Routers | 235

Using the Default CoS Profiles for Campus Switching ELS with Hierarchical Port Scheduling | 235

Using the Default CoS Profiles for Data Center Switching | 235

Creating a Wired CoS Profile | 236

Specifying Settings for a Routing, Switching, and Campus Switching ELS CoS Profile | 237

Specifying Settings for a Campus Switching ELS CoS Profile with Hierarchical Port Scheduling (ETS) | 241

Specifying Settings for a Data Center Switching CoS Profile | 246

What to Do Next | 255

Configuring Link Aggregation Groups (LAGs) | 256

Understanding Link Aggregation | 256

Managing and Creating a Link Aggregation Group | 256

Link Aggregation Group Options | 257

Creating a Link Aggregation Group | 259

What To Do Next | 260

Managing Network Devices | 261

Viewing the Device Inventory Page in Device View of Connectivity Services Director | **262**

Viewing the Physical Inventory of Devices | **264**

Viewing Licenses With Connectivity Services Director | **265**

Viewing a Device's Current Configuration from Connectivity Services Director | **267**

Accessing a Device's CLI from Connectivity Services Director | **267**

Accessing a Device's Web-Based Interface from Connectivity Services Director | **268**

Deleting Devices | **270**

Rebooting Devices | **270**

Building a Topology View of the Network

Downloading and Installing CSD-Topology | 273

CSD-Topology Installation and Configuration Overview | **273**

Installation Prerequisites | **274**

Installing the CSD-Topology Software Using the RPM Bundle | **275**

Minimum Hardware and Software Requirements for Junos VM on VMWare | **276**

Installing the JunosVM for CSD-Topology | **276**

Setting Up the Datastore | **278**

Creating VRR VMs | **280**

Configuring the JunosVM | **289**

Configuring the CSD-Topology Server with the JunosVM IP Address | **291**

Verifying the Connectivity Between the CSD-Topology Server and JunosVM | **291**

Verifying That the CSD-Topology Services Are Running | **292**

Stopping Firewall on the CSD-Topology Server | **292**

Configuring Peer Routers and Topology Acquisition on the JunosVM | **293**

Specifying the Topology Details in the Connectivity Services Director GUI | **295**

Connecting an x86 Server to the Network | **296**

Interactive Method of Installing the RPM Image and CSD-Topology Software from a USB or DVD Drive | **301**

Configuring Topology Acquisition and Connectivity Between the CSD-Topology and Path Computation Clients | 305

Configuring PCEP on a PE Router (from CLI) | **305**

Configuring Connectivity for BGP-LS Topology Acquisition | **308**

Configuring BGP-LS Topology Acquisition on the CSD-Topology | **309**

Configuring Topology Acquisition on the PCC Routers | **310**

Configuring Connectivity for OSPF Topology Acquisition | **311**

Configuring OSPF on the CSD-Topology | **311**

Configuring OSPF Over GRE on the CSD-Topology | **312**

Configuring Connectivity for IS-IS Topology Acquisition | **313**

Configuring IS-IS on the CSD-Topology | **313**

Configuring IS-IS Over GRE on the CSD-Topology | **314**

Accessing the Topology View of CSD-Topology | 315

Understanding the Network Topology in Connectivity Services Director | **316**

Monitoring the Topology of Network Elements Managed by CSD-Topology Overview | **317**

Specifying Topology Preferences | **318**

CSD-Topology Topology Map Window Overview | **320**

Working with the Graphical Image in the Topology View Window | **322**

Expanding and Collapsing Groups by Using the Topology Map Grouping Shortcut Menu | **325**

Filtering Links, LSPs, and Services by Using the Topology Map Node Shortcut Menu | **326**

Removing the Highlighted LSPs by Using the Topology Map LSPs Shortcut Menu | **327**

Viewing the Service Path by Using the Topology Map Service Shortcut Menu | **328**

Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View | **330**

Segregating the Displayed Devices by Searching the Entire Topology View | **331**

Resynchronizing the Topology View | **332**

Viewing Device Details of a CSD-Topology for Examining Traffic Transmission | **333**

Viewing LSP Details of a CSD-Topology for Analyzing Network Changes | **335**

Viewing Link Details of a CSD-Topology for Determining the Operational Status | **338**

Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters | **339**

Viewing Topology Map Group Details in a Pop-Up Dialog Box | **342**

- Viewing Topology Map Device Details in a Pop-Up Dialog Box | 344
- Viewing Topology Map Link Details in a Pop-Up Dialog Box | 346
- Viewing Topology Map LSP Details in a Pop-Up Dialog Box | 348
- Viewing Topology Map Service Details in a Pop-Up Dialog Box | 350
- Enabling the Collection of LSP and Service Association Details | 352
- Using Custom Grouping for Devices in a CSD Topology | 352
- Viewing Generated Alarms for Services in the Topology View | 353
- Viewing the Optical Link Details for Examining the Performance of Optical Links | 354

Prestaging

Prestaging Devices Overview | 357

Prestaging Devices Process Overview | 358

Prestaging Workflow in Connectivity Services Director | 361

- Auto-Discovery and Auto Prestaging of Devices | 361
- Parallel Prestaging Jobs | 362
- Auto Prestaging Jobs When a Manual Prestaging Job is Running | 362
- Manual Prestaging Jobs When an Auto Prestaging Job is Running. | 362
- Multiple Auto Prestaging Jobs for a Device | 363
- Scenarios With a Clustered Environment | 363
- Types of Prestaging | 363

Prerequisites for Prestaging Devices in Connectivity Services Director | 364

Discovering and Assigning All N-PE Devices | 366

- Discovering Device Roles | 366
- Assigning Device Roles | 367

Discovering and Assigning N-PE Devices with Exceptions | 367

- Including Interfaces in UNI Role Assignments | 368
- Committing Your Prestaging Choices | 369

Prestaging ATM and TDM Pseudowire Devices | 370

Discovering and Assigning Provider Role or LSP Role for Devices with Exceptions | 375

- Including Interfaces in UNI Role Assignments | 375
- Committing Your Prestaging Choices | 376

Discovering and Assigning All Provider or LSP Devices | 377

- Discovering LSP Device Roles | 378
- Assigning Provider Device Roles | 378

Prestaging Rules | 380

- N-PE Device Classification Rules | 380
- UNI Classification Rules | 380
- VLAN Pool Profile Classification Rules | 382
- Auto Discovery Only | 382

Prestaging: Managing Devices and Device Roles | 384

- Discovering Tunnel Devices | 384
- Adding a UNI | 386
- Unassigning Device Roles | 387
- Deleting UNIs | 388
- Discovering Device Roles | 390
- Excluding Devices from N-PE Role Assignment | 391
- Excluding Interfaces from UNI Role Assignments | 392
- Unassigning N-PE Devices | 393
- Viewing N-PE Devices | 394
 - Viewing N-PE Devices in a Table | 394
- Viewing Prestaging Statistics | 395
 - Viewing the Prestaged Device Details | 396
 - Viewing Services for Devices and Device Roles in a Graphical Form | 396
- Viewing Prestaging Rules | 397
 - Viewing Prestaging Rules in a Table | 397
- Managing Prestage Device Jobs | 398
- Specifying the Wait and Idle Times for Prestaging Devices | 401

Prestaging: Managing IP Addresses | 403

- Creating an IP Address Pool | 404
- Managing Resources | 406
- Specifying IPv4 Addressing Assignment in IP Service Definitions | 409

Device Configuration Prerequisites to Prestaging Examples | 411

- Example: Base Configuration for N-PE Device in a Multipoint Service | 411
- Example: Base Configuration for N-PE Device in an E-Line (LDP) Service | 413
- Example: Base Configuration for a P Router | 415

Prestaging Services | 418

Creating and Handling a Service Recovery Request | 419

Selecting a Service Definition in the Wizard for Creating a Service Recovery Request | 421

Specifying Devices and Filters in the Wizard for Creating a Service Recovery Request | 423

Reviewing the Configured Settings in the Wizard for Creating a Service Recovery Request | 426

Viewing Service Recovery Report | 428

Performing a Service Recovery on a Defined Service | 429

Processing of Device Change Notifications Overview | 431

- XPaths of Relevance to Connectivity Services Director | 432

- Processing of XPath Notifications for Out-of-Band Configuration Changes | 432

Handling of Out-of-Band Notifications for Service Recovery | 434

Viewing Service Recovery Instance Details | 434

Managing Out-of-Band Notifications for Recovered Services | 439

Viewing Details of an Out-of-Band Notification for Recovered Services | 441

Viewing Services Rejected During a Service Recovery | 443

Viewing Service Recovery Jobs | 445

Performing a Configuration Audit for Recovered Services | 447

Viewing Configuration Audit Results of Recovered Services | 449

Recovering Modifications and Deletions Performed for Existing Endpoints | 452

- Recovering Parameters for E-Line Services | 452

- Recovering Parameters for IP Services | 453

- Recovering Parameters for E-LAN Services | 455

- Recovering Endpoint Deletions from a Service | 456

REST API Changes in Connectivity Services Director for Service Recovery | 457

Sample XPath Notifications Received on Devices for Deleted Endpoints | 457

Sample XPath Notifications Received on Devices for a Modified E-LAN Service | 461

Sample XPath Notifications Received on Devices for a Created E-LAN Service | 467

Sample XPath Notifications Received on Devices for a Created IP Service | 471

Sample XPath Notifications Received on Devices for a Created E-Line Service | 473

Sample XPath Notifications Received on Devices for CFM Profiles Associated with an E-Line Service | 475

Sample XPath Notifications Received on Devices for CoS Profiles Associated with an E-Line Service | 477

Service Design: Working with Service Definitions

Service Design: Predefined Service Definitions | 479

Predefined Service Definitions | 479

E-Line Predefined Service Definitions | 479

- ELine-Dot1q-SingleVLAN | 482
- ELine-Dot1q-SingleVLAN-CCC | 485
- ELine-Dot1q-SingleVLAN-Ext-CCC | 488
- ELine-PortBased | 491
- ELine-QinQ-AllVLAN | 494
- ELine-QinQ-AllVLAN-CCC | 497
- ELine-QinQ-AllVLAN-Ext-CCC | 500
- ELine-QinQ-VLANRange | 503
- ELine-QinQ-VLANRange-CCC | 506
- ELine-QinQ-VLANRange-Ext-CCC | 509

Multipoint-to-Multipoint Predefined Service Definitions | 511

- ELAN-BGP-Dot1q-Normalized-VLAN-None | 514
- ELAN-BGP-Dot1Q-SingleVLAN | 519
- ELAN-BGP-PortBased | 523
- ELAN-BGP-QinQ-AllVLAN | 528
- ELAN-BGP-QinQ-AllVLAN-Normalized-All | 532
- ELAN-BGP-QinQ-AllVLAN-Normalized-None | 537
- ELAN-BGP-QinQ-Range-Normalized-VLAN | 541

Point-to-Multipoint Service Definitions | 544

- ELAN-Hub-Spoke-QinQ-AllVLAN | 546
- ELAN-Hub-Spoke-QinQ-AllVLAN-No | 547

Predefined E-Line Service Definitions | 548

ELine-Dot1q-SingleVLAN Service Definition | 552

- Configuration on Endpoint A | 553
- Configuration on Endpoint Z | 554

ELine-Dot1q-SingleVLAN-CCC Service Definition | 555

- Configuration on Endpoint A | 555
- Configuration on Endpoint Z | 557

ELine-Dot1q-SingleVLAN-Ext-CCC Service Definition | 558

Configuration on Endpoint A | 558

Configuration on Endpoint Z | 560

ELine-PortBased Service Definition | 561

Configuration on Endpoint A | 561

Configuration on Endpoint Z | 562

ELine-QinQ-AllVLAN Service Definition | 564

Configuration on Endpoint A | 564

Configuration on Endpoint Z | 565

ELine-QinQ-AllVLAN-CCC Service Definition | 567

Configuration on Endpoint A | 567

Configuration on Endpoint Z | 568

ELine-QinQ-AllVLAN-Ext-CCC Service Definition | 570

Configuration on Endpoint A | 570

Configuration on Endpoint Z | 571

ELine-QinQ-VLANRange Service Definition | 573

Configuration on Endpoint A | 573

Configuration on Endpoint Z | 574

ELine-QinQ-VLANRange-CCC Service Definition | 576

Configuration on Endpoint A | 576

Configuration on Endpoint Z | 577

ELine-QinQ-VLANRange-Ext-CCC Service Definition | 579

Configuration on Endpoint A | 579

Configuration on Endpoint Z | 580

ELine-BGP-Port-Based | 582

Configuration on Endpoint A | 582

Configuration on Endpoint Z | 583

ELine-BGP-Dot1q-SingleVLAN | 585

Configuration on Endpoint A | 585

Configuration on Endpoint Z | 587

ELine-BGP-QinQ-AllVLAN | 588

Configuration on Endpoint A | 588

Configuration on Endpoint Z | 590

Predefined Multipoint-to-Multipoint Ethernet Service Definitions | 592**ELAN-BGP-Dot1q-Normalized-VLAN-None Service Definition | 595****Configuration on Endpoint A | 595****Configuration on Endpoint B | 596****Configuration on Endpoint Z | 598****ELAN-BGP-Dot1Q-SingleVLAN Service Definition | 599****Configuration on Endpoint A | 600****Configuration on Endpoint B | 601****Configuration on Endpoint Z | 602****ELAN-BGP-PortBased Service Definition | 604****Configuration on Endpoint A | 604****Configuration on Endpoint B | 605****Configuration on Endpoint Z | 607****ELAN-BGP-QinQ-AllVLAN Service Definition | 608****Configuration on Endpoint A | 608****Configuration on Endpoint B | 610****Configuration on Endpoint Z | 611****ELAN-BGP-QinQ-AllVLAN-Normalized-All Service Definition | 613****Configuration on Endpoint A | 613****Configuration on Endpoint B | 614****Configuration on Endpoint Z | 616****ELAN-BGP-QinQ-AllVLAN-Normalized-None Service Definition | 617****Configuration on Endpoint A | 618****Configuration on Endpoint B | 619****Configuration on Endpoint Z | 620****ELAN-BGP-QinQ-Range-Normalized-VLAN Service Definition | 622****Configuration on Endpoint A | 622****Configuration on Endpoint Z | 624****Predefined Point-to-Multipoint Ethernet Service Definitions | 625****ELAN-Hub-Spoke-QinQ-AllVLAN-Normalized-All Service Definition | 627****Configuration on Endpoint A | 628****Configuration on Endpoint B | 630**

Configuration on Endpoint Z	632
ELAN-Hub-Spoke-QinQ-AllVLAN Service Definition	634
Configuration on Endpoint A	635
Configuration on Endpoint B	638
Configuration on Endpoint Z	640
Predefined Full Mesh IP Service Definitions	642
Predefined Hub-and Spoke IP Service Definitions	643
Service Design: Managing E-Line Service Definitions 	645
Choosing a Predefined Service Definition or Creating a New Service Definition	645
Choosing a Predefined Service Definition	646
Creating an E-Line Service Definition	652
Specifying General Information	652
Specifying UNI Settings	656
Specifying Connectivity Information When Signaling Is LDP	669
Specifying Connectivity Information When Signaling Is BGP	672
Reviewing the Configured Settings	674
Creating an E-Line ATM or TDM Pseudowire Service Definition	675
Specifying General Information for the ATM or TDM Service	675
Specifying UNI Settings for ATM and TDM Service Definitions	678
Specifying UNI Settings for ATM Interfaces	678
Specifying UNI Settings for TDM Interfaces	678
Specifying Connectivity Information for an ATM or a TDM Service	679
Reviewing the Configured Settings	681
Monitoring Performance Management Statistics	682
Monitoring Statistics for an E-Line Service	683
Monitoring Statistics for an E-LAN Service	685
Modifying a Custom Service Definition	688
Publishing a Custom Service Definition	690
Unpublishing a Custom Service Definition	691
Deleting a Customized Service Definition	691
Viewing Service Definitions	692
Tabular View	693
Searching for Service Definitions	694

Viewing Service Definition Details | 694

Performing Actions on Service Definitions | 694

Service Design: Managing E-LAN Service Definitions | 696

Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696

Specifying General Information for Multipoint-to-Multipoint E-LAN Service Definitions | 697

Specifying Advanced Settings | 701

Specifying Site Settings for Multipoint-to-Multipoint E-LAN Service Definitions | 705

UNI or Site Settings for Port-to-Port Interfaces in E-LAN Services | 705

UNI or Site Settings for 802.1Q Interfaces in E-LAN Services | 708

UNI or Site Settings for Q-in-Q Interfaces in E-LAN Services | 713

UNI Settings for Services with Flexible VLAN Tagging (Asymmetric Interface Types) | 719

Reviewing the Configured Settings | 725

Creating a Point-to-Multipoint E-LAN Service Definition | 726

Specifying General Information for Point-to-Multipoint E-LAN Service Definitions | 727

Specifying Advanced Settings | 734

Specifying UNI or Site Settings for Point-to-Multipoint E-LAN Service Definitions | 737

UNI or Site Settings for Port-to-Port Interfaces in E-LAN Services | 737

UNI or Site Settings for 802.1Q Interfaces in E-LAN Services | 740

UNI or Site Settings for Q-in-Q Interfaces in E-LAN Services | 747

UNI or Site Settings for Services with Flexible VLAN Tagging (Asymmetric Interface Types) | 753

Reviewing the Configured Settings | 759

Creating a Service Definition for VPLS Access into Layer 3 Networks | 760

Service Design: Managing IP Service Definitions | 765

Creating a Full-Mesh IP Service Definition | 765

Specifying General Settings Information | 765

Specifying Site or UNI Settings | 769

Reviewing the Configured Settings | 775

Creating a Hub-and-Spoke (One Interface) IP Service Definition | 776

Specifying General Information | 777

Specifying UNI or Site Settings | 780

Reviewing the Configured Settings | 787

Creating a Service Definition for E-Line Pseudowire Access into a Layer 3 VPN | 788

Creating a Multicast VPN Service Definition | 791

8

Service Provisioning: Working with Customers

Service Provisioning: Managing Customers | 795

Adding a New Customer | 795

Deleting Customers | 796

Modifying an Existing Customer | 797

Viewing Customer Details | 798

9

Working in Deploy Mode

About Deploy Mode | 801

Understanding Deploy Mode in Views Other than Service View of Connectivity Services Director | 801

Deploying Configuration Changes | 801

Managing Software Images | 803

Managing Devices | 803

Managing Device Configuration Files | 804

Managing Baseline Configuration | 804

Understanding the Deploy Mode Tasks Pane in Views Other than Service View | 805

Deploying and Managing Device Configurations | 808

Deploying Configuration to Devices | 808

Selecting Configuration Deployment Options | 809

Using the Change Request Details Page | 813

Creating a Change Request | 814

Validating Configuration | 814

Discarding the Pending Configurations | 815

Viewing Pending Configuration Changes | 815

Using the Pending Changes Window | 815

Using the Configuration or Pending Configuration Window | 816

Using the Deploy Configuration Errors/Warnings Window | 817

Using the Configuration Validation Window | 817

Deploying Configuration Changes to Devices Immediately | 817

Scheduling Configuration Deployment	817
Specifying Configuration Deployment Scheduling Options	818
Editing Change Requests	819
Deleting Change Request	820
Resubmitting a Change Request	820
Performing a Rollback	821
Managing Configuration Deployment Jobs	821
Selecting Configuration Deployment Job Options	822
Viewing Configuration Deployment Job Details	823
Canceling Configuration Deployment Jobs	823
Deploy Configuration Window	824
Approving Change Requests	825
Enabling SNMP Categories and Setting Trap Destinations	827
Viewing Eligible Devices for Trap Forwarding	828
Enabling Trap Forwarding	829
Deploying SNMP Trap Configurations	829
Understanding Resynchronization of Device Configuration	833
The Resynchronize Device Configuration Task	834
How Resynchronization Works in NSOR Mode	835
How Resynchronization Works in SSOR Mode	837
How Connectivity Services Director Resynchronizes the Build Mode Configuration	839
Resynchronizing Device Configuration	839
The Resynchronize Device Configuration List of Devices	840
Resynchronizing Devices When Junos Space Is in NSOR Mode	842
Resynchronizing Devices When Junos Space Is in SSOR Mode	842
Resynchronizing Devices in Manual Approval Mode	843
Viewing the Network Changes	843
Viewing Resynchronization Job Status	844
Managing Device Configuration Files	844
Selecting Device Configuration File Management Options	845
Backing Up Device Configuration Files	846
Restoring Device Configuration Files	846
Viewing Device Configuration Files	847
Comparing Device Configuration Files	847

Deleting Device Configuration Files | 848

Managing Device Configuration File Management Jobs | 848

Enabling or Disabling Network Ports on Routers | 849

Deploying and Managing Software Images | 851

Managing Software Images | 851

Selecting Software Image Management Options | 852

Adding Software Images to the Repository | 852

Using the Device Image Upload Window | 853

Viewing Software Image Details | 853

Using the Device Image Summary Window | 853

Deleting Software Images | 854

Deploying Software Images | 854

Specifying Software Deployment Job Options | 855

Selecting Software Images To Deploy | 855

Selecting Options for Software Deployment | 856

Summary of Software Deployment | 858

Managing Software Image Deployment Jobs | 858

Selecting Software Image Management Options | 859

Viewing Software Image Job Details | 860

Using the Device Image Staging Window | 860

Canceling Software Image Jobs | 861

Service Provisioning: Working with Service Orders

Service Provisioning: Viewing the Configured Services and Service Orders | 863

Viewing Service Orders | 863

Viewing Service Orders in a Table | 863

Viewing Service Order and Service Details | 865

Viewing Services | 869

Viewing Services in a Table | 869

Viewing the Configured E-Line, IP, and E-LAN Services | 871

Viewing the Configuration Details of VPN Services | 874

Service Provisioning: Managing E-Line Service Orders | 876

Creating a Service Order | 876

Creating an E-Line ATM or TDM Pseudowire Service Order | 877

Selecting the Service Definition | 877

Entering General/Connectivity Settings Information | 879

Specifying Endpoint Information | 881

Specifying Template Settings | 884

Reviewing the Configured Settings | 885

Deploying the New Service | 886

Creating an E-Line Multisegment Pseudowire Service Order | 886

Selecting the Service Definition | 887

Entering General/Connectivity Settings Information | 888

Specifying Endpoint A Information | 890

Specifying Endpoint Z Information | 892

Specifying Stitching Endpoint(s) Settings | 893

Reviewing the Configured Settings | 894

Creating an E-Line Service Order | 895

Selecting the Service Type | 896

Entering General Settings Information | 897

Specifying the Connectivity | 898

Specifying QoS Settings | 900

Specifying CFM Settings | 901

Specifying Endpoint Information | 901

Specifying Template Settings	906
Reviewing the Configured Settings	907
Specifying Connectivity and Endpoint Information for Managing VLANs	908
Deploying and Monitoring the Progress of the New Service	908
Creating a Bulk-Provisioning Service Order for Pseudowire Services	909
Creating an Inverse Multiplexing for ATM Service Order	912
Provisioning a Single-Ended E-Line Service	916
Selecting Specific LSPs for Connectivity Services	918
Associating an LSP with an E-Line Service	918
Viewing LSP Details in a Service Order	919
Viewing LSP Details in a Service	919
Viewing LSP Configuration Details	920
Stitching Two E-Line Pseudowires	920
Using Print Page	922
Deactivating a Service	923
Reactivating a Service	925
Force-Deploying a Service	927
Recovering a Service Definition through Force Upload	930
Decommissioning a Service	931
Viewing Alarms for a Service	934
Inline Editing of E-LAN and IP Service Orders	935
Interconnecting an IP Service with an E-LAN Service	939
Changing the Logical Loopback Interface for Provisioning	941
Service Provisioning: Managing E-LAN Service Orders 	943
Creating a Multipoint-to-Multipoint E-LAN Service Order	943
Selecting the Service Definition	943
Entering Service Parameters Information	945
Specifying CFM Settings	952
Selecting N-PE Devices	952
Specifying Node Settings	953
Setting Attributes for Nodes or Devices on a Service	953
Setting Attributes for Nodes or Devices on a Service with Flexible VLAN Tagging	956
Modifying Site Settings	957

Specifying QoS Settings	960
Specifying Template Settings	960
Reviewing the Configured Settings	962
Deploying the New Service	963
Creating a Point-to-Multipoint E-LAN Service Order	964
Selecting the Service Definition	964
Entering Service Parameters Information	966
Specifying CFM Settings	971
Selecting N-PE Devices	972
Specifying Node Settings	973
Setting Attributes for Nodes or Devices on a Service	973
Setting Attributes for Nodes or Devices on a Service with Flexible VLAN Tagging	978
Modifying Site Settings	978
Specifying QoS Settings	982
Specifying Template Settings	982
Reviewing the Configured Settings	983
Deploying the New Service	984
Creating a Service Order for VPLS Access into Layer 3 Networks	985
Creating an E-LAN Service Order with CFM	987
Interconnecting an E-LAN Service with an IP Service	990
Service Provisioning: Managing IP Service Orders 	993
Stitching a Pseudowire to an IP Service	993
Creating a Full Mesh IP Service Order	995
Selecting the Service Definition	996
Configuring Service Parameters Information	997
Specifying General Settings	997
Specifying PE-CE Settings Information	1001
Selecting N-PE Devices or Nodes	1002
Setting Attributes for Endpoints or Nodes	1003
Adding and Deleting UNI Interfaces	1009
Setting Attributes for UNIs or Sites	1009
Specifying QoS Settings	1016
Specifying Template Settings	1017

Reviewing the Configured Settings	1018
Deploying the New Service	1018
Creating a Hub-and-Spoke IP Service Order	1019
Selecting the Service Definition	1020
Configuring Service Parameters Information	1021
Specifying General Settings	1021
Specifying PE-CE Settings Information	1025
Selecting N-PE Devices or Nodes	1026
Setting Attributes for Endpoints or Nodes	1027
Adding and Deleting UNI Interfaces	1033
Setting Attributes for UNIs or Sites	1034
Specifying QoS Settings	1041
Specifying Template Settings	1042
Reviewing the Configured Settings	1043
Deploying the New Service	1043
Selecting a Published IP Service Definition for a Service Order	1044
Entering IP Service Order Information	1045
Setting General Settings	1045
Entering VPN and Connectivity Settings Information	1046
Entering PE-CE Settings	1047
Selecting Endpoint PE Devices or Nodes	1048
Creating a Service Order Based on a Service Definition with a Template	1049
Deploying an IP Service Order	1051
Creating a Multicast VPN Service Order	1053
Creating Policies for an IP Service	1057
Service Provisioning: Performing RFC 2544 Benchmark Testing 	1060
RFC 2544 Testing Overview	1060
Supported Devices for RFC2544	1061
Performing an RFC 2544 test for a Service	1062

Performing an RFC 2544 Test Between Devices | 1062

Creating an RFC 2544 Test Profile for Services | 1063

Creating an RFC 2544 Test Profile for Devices | 1070

Deploying RFC 2544 Tests | 1076

Viewing RFC 2544 Test Results | 1076

Service Provisioning: Working with Services Deployment

Service Provisioning: Managing Deployed Services | 1080

Managing Service Configuration Deployment Jobs | 1080

Selecting Service Configuration Deployment Job Options | 1081

Viewing Service Configuration Deployment Job Details | 1082

Canceling Service Configuration Deployment Jobs | 1082

Deploying Services Configuration to Devices | 1083

Selecting Configuration Deployment Options | 1085

Validating Configuration | 1085

Deleting the Partial Service Configurations | 1087

Discarding the Pending Configurations | 1088

Deploying Configuration Changes to Devices Immediately | 1089

Scheduling Configuration Deployment | 1089

Specifying Configuration Deployment Scheduling Options | 1090

Deploy Configuration Window | 1090

Deleting a Partial Configuration of an LSP Service Order | 1091

Deleting a Service Order | 1092

Deploying a Service | 1094

Validating the Pending Configuration of a Service Order | 1096

Viewing the Configuration of a Pending Service Order | 1098

Viewing Decommissioned E-Line, E-LAN, and IP Service Orders | 1100

Modifying an E-Line Service | 1102

Modifying a Multipoint-to-Multipoint Ethernet Service | 1104

Adding an Endpoint | 1105

Adding a UNI Interface | 1106

Deleting a UNI Interface and Deleting an Endpoint | 1108

Changing the Endpoint Bandwidth | 1109

Changing Advanced Settings for an Endpoint | 1110

Modifying a Point-to-Multipoint Ethernet Service | 1111

- Adding a Spoke | 1112
- Adding a Hub | 1113
- Changing a Spoke to a Hub | 1114
- Changing a Hub to a Spoke | 1115
- Adding a UNI Interface | 1116
- Deleting a UNI Interface or Deleting an Endpoint | 1117
- Changing the Endpoint Bandwidth | 1118
- Changing Advanced Settings for an Endpoint | 1119

Modifying a Hub-and-Spoke IP Service Order | 1120

- Viewing the Service Definition | 1121
- Configuring Service Parameters Information | 1122
 - Specifying General Settings | 1122
 - Specifying PE-CE Settings Information | 1127
- Selecting N-PE Devices or Nodes | 1128
- Setting Attributes for Endpoints or Nodes | 1129
- Adding and Deleting UNI Interfaces | 1132
- Setting Attributes for UNIs or Sites | 1133
- Deploying the New Service | 1136

Modifying a Full Mesh IP Service | 1137

- Adding an Endpoint | 1138
- Adding a UNI Interface | 1139
- Deleting a UNI Interface and Deleting an Endpoint | 1141

Understanding Service Validation | 1142**Highlighting of Endpoints in the IP, RSVP LSP, and E-LAN Service Modification Wizards | 1143****Auditing Services and Viewing Audit Results****Service Provisioning: Auditing Services | 1145**

- Performing a Functional Audit | 1145
- Performing a Configuration Audit | 1156
- Troubleshooting N-PE Devices Before Provisioning a Service | 1158

Modifying the Application Settings of Connectivity Services Director | **1161**

Troubleshooting the Endpoints of Services | **1168**

 Troubleshooting Services Using Operational Scripts | **1171**

Basic Requirements of Operational Scripts | **1174**

 Predefined Scripts for Troubleshooting | **1176**

 E-Line LDP Service | **1176**

 E-Line BGP Service | **1176**

 E-LAN Service | **1176**

 IP Service | **1177**

 RSVP LSP Service | **1177**

Viewing Configuration Audit Results | **1177**

Viewing Functional Audit Results | **1180**

Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | **1184**

Modifying a Saved Service Order | **1184**

Viewing Service-Level Alarms | **1189**

Troubleshooting Devices and Services | 1192

Performance Management Overview | **1192**

 Monitoring Performance Statistics | **1192**

 On-Demand Mode | **1193**

 Proactive Mode | **1193**

 Performance Management of Test Traffic | **1193**

Monitoring Performance Management Statistics | **1194**

 Monitoring Statistics for an E-Line Service | **1195**

 Monitoring Statistics for an E-LAN Service | **1197**

Viewing Performance Management Statistics | **1198**

 Viewing Y.1731 Performance Monitoring Statistics for E-Line Services | **1199**

 Viewing Y.1731 Performance Monitoring Statistics for E-LAN Services | **1201**

Service Troubleshooting Overview | **1204**

Working in Monitor Mode

About Monitor Mode | 1207

Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director | 1207

Scope and Monitor Tab Availability | 1208

Monitors and Tasks | 1208

Scope and Data Aggregation | 1208

How Connectivity Services Director Collects and Displays Monitoring Data | 1209

How Connectivity Services Director Displays and Stores Trend Data | 1209

More About the Monitor Tabs | 1210

The Summary Tab | 1210

The Traffic Tab | 1210

Understanding the Monitor Mode Tasks Pane in Views Other than Service View | 1211

Monitoring Traffic | 1213

Monitoring Traffic on Devices | 1213

Monitoring Port Traffic Statistics | 1214

Procedure for Monitoring Port Traffic Statistics | 1214

Port on Device Window | 1214

Port Traffic Stats Window | 1215

Monitoring Traffic on Layer 3 VLANs | 1216

Procedure for Monitoring Layer 3 VLAN Traffic Statistics | 1216

L3 VLAN Traffic Stats Window | 1217

Monitoring Port Utilization | 1218

How to Access the Port Utilization Task | 1218

Port Utilization Details Window | 1219

Utilization for Device Window | 1219

Device View | 1219

Port View | 1220

Utilization for IP Fabric Window | 1220

Device View | 1221

Port View | 1221

Monitoring Routing Instances | 1222

- Procedure for Monitoring Routing Instances | 1223

- Show Routing Instances Window | 1223

- Show Interfaces Window | 1224

- Show Bridge Domains Window | 1225

- Show Connections | 1226

- Show Routing Tables | 1229

- Show MAC Table | 1231

Viewing Congestion Events | 1232**Monitoring Devices | 1234****Comparing Device Statistics | 1234**

- Procedure for Comparing Device Statistics | 1234

- Compare Interfaces Window | 1235

Showing ARP Table Information | 1235

- Procedure for Showing ARP Table Information | 1236

- Show ARP Table Information Window | 1236

General Monitoring | 1237

- Selecting Monitors To Display on the Summary Tab | 1237

- Changing Monitor Polling Interval and Data Collection | 1238

- Pinging Host Devices | 1238

- Troubleshooting Network Connections Using Traceroute | 1240

Monitor Reference | 1241**Error Trend Monitor | 1241**

- Error Trend | 1241

- Error Trend Details | 1242

Equipment Status Summary Monitor | 1243**Equipment Summary By Type Monitor | 1244**

- Equipment Summary By Type | 1244

- Equipment Summary By Type Details | 1244

Port Status Monitor | 1245

- Port Status Summary | 1245

- Port Status Details | 1245

Port Utilization Monitor | 1247

Status Monitor for Routers | 1247

Traffic Trend Monitor | 1248

Unicast vs Broadcast/Multicast Monitor | 1249

Unicast vs Broadcast/Multicast Trend Monitor | 1249

Detecting and Examining the Health and Performance of Services | 1251

Service Monitoring Capabilities in Connectivity Services Director | 1252

Computation of Statistics Polled from Devices for Display in Widgets on Monitoring Pages | 1253

Configuring the Aggregation Method for Viewing Monitoring Details | 1255

Viewing the Service Monitoring Summary Page for a Consolidated Listing of Services | 1257

Monitoring the Service Summary Details of E-Line Services for Optimal Debugging | 1259

Service Status | 1260

Connections | 1261

Traffic Summary | 1261

Section | ?

Monitoring the Service Summary Details of E-LAN Services for Optimal Debugging | 1262

Service Status | 1263

Connections | 1264

Traffic Summary | 1264

Monitoring the Service Summary Details of IP Services for Optimal Debugging | 1265

Service Status | 1267

VPN Routes | 1267

VPN Traffic Trend | 1267

Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268

Traffic Graph | 1269

Pseudowire Traffic | 1270

Interface Traffic Statistics/Endpoint Users | 1270

Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters | 1271

Traffic Matrix | 1273

Interface Statistics | 1273

Traffic Pattern | 1273

Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | **1274**

Interface Statistics | **1275**

VPN Traffic Trend | **1275**

Monitoring the Service Transport Details of E-Line Services for Easy Analysis | **1276**

Connections | **1277**

LSP Information | **1278**

LSP Traffic | **1279**

Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | **1279**

Connections | **1280**

LSP Information | **1281**

LSP Traffic | **1281**

Monitoring the Service Transport Details of IP Services for Easy Analysis | **1282**

Transport Statistics | **1283**

VPN Routes | **1284**

Label/LSP Information | **1284**

LSP Traffic | **1286**

Viewing Y.1731 Performance Monitoring Statistics for E-Line Services | **1286**

Connections | **1287**

Loss Measurement | **1288**

Delay Measurement | **1288**

Delay Variation | **1289**

Viewing Y.1731 Performance Monitoring Statistics for E-LAN Services | **1289**

Connections | **1290**

Loss Measurement | **1291**

Delay Measurement | **1291**

Delay Variation | **1292**

Clearing Interface Statistics | **1292**

Viewing MAC Table Details | **1294**

Viewing Interface Statistics | **1295**

Viewing Interface Status Details | **1297**

MPLS Connectivity Verification and Troubleshooting Methods | **1299**

Using MPLS Ping | **1300**

Pinging VPNs, VPLS, and Layer 2 Circuits | **1303**

Monitoring Network Reachability by Using the MPLS Ping Capability | **1304**

Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306

Routing Table Overview | 1308

Viewing Routing Table Details | 1309

Working in Fault Mode

About Fault Mode | 1314

About Fault Mode in All Views of Connectivity Services Director | 1314

Understanding the Tasks Pane in Fault Mode | 1315

Using Fault Mode | 1317

Using Fault Management Monitors | 1317

What Are Events and Alarms? | 1318

Alarm Severity | 1318

Alarm Classification | 1318

Alarm State | 1320

Alarm Notifications | 1320

Alarm Severities and States Overview | 1321

Alarm Severity | 1321

Alarm State | 1321

Events and Alarms Overview | 1322

Alarm Severity | 1322

Customizing Alarms | 1322

Changing Alarm State | 1323

Searching Alarms | 1324

Fault Reference | 1327

Alarm Detail Monitor (All Views Except Service View) | 1327

Finding Specific Alarms | 1328

Sorting Alarms | 1329

Reading Events | 1330

Investigating Event Attributes | 1331

Changing the Alarm State | 1331

Alarm Detail Monitor (Service View) | 1331

Finding Specific Alarms | 1332

Sorting Alarms | 1333

Reading Events | 1333

Investigating Event Attributes | 1334

Changing the Alarm State | 1334

Current Active Alarms Monitor (Service View) | 1335

Alarms by Category Monitor | 1337

Alarms by Severity Monitor (Service View) | 1337

Alarms by State Monitor | 1338

Alarm Trend Monitor (Service View) | 1339

Alarms by Severity Monitor (All Views Except Service View) | 1339

Alarms by State Monitor (All Views Except Service View) | 1340

Current Active Alarms Monitor (All Views Except Service View) | 1340

Alarm Trend Monitor (All Views Except Service View) | 1342

End-to-End Configuration Examples

Configuration Scenarios | 1344

Example: Configuring and Deploying an E-Line Service | 1344

Preparing Devices for Discovery | 1345

Discovering Devices | 1345

Preparing Devices for Prestaging | 1347

Discovering and Assigning N-PE Roles | 1348

Choosing or Creating a Service Definition | 1349

Creating a Customer | 1351

Creating and Deploying an E-Line Service Order | 1352

Performing a Functional Audit and a Configuration Audit | 1353

Example: Configuring and Deploying a Multipoint-to-Multipoint E-LAN Service | 1355

Preparing Devices for Discovery | 1356

Discovering Devices | 1357

Preparing Devices for Prestaging | 1358

Discovering and Assigning N-PE Roles | 1361

Choosing or Creating a Service Definition | 1362

Creating a Customer | 1365

Creating and Deploying a Multipoint-to-Multipoint Service Order | 1366

Performing a Functional Audit and a Configuration Audit | 1367

Example: Configuring and Deploying an IP Full-Mesh Service | 1369

Preparing Devices for Discovery | 1370

Discovering Devices | 1371

Preparing Devices for Prestaging | 1372

Discovering and Assigning N-PE Roles | 1374

Choosing or Creating a Service Definition | 1375

Creating a Customer | 1376

Creating and Deploying an IP Service Order | 1377

Performing a Functional Audit and a Configuration Audit | 1379

Working with Chassis View

Working with Devices | 1383

About Chassis View | 1383

Accessing the Chassis View from the Physical Inventory Page | 1384

Viewing a Graphical Image of the Chassis and Components | 1385

Deleting Devices from Chassis View | 1393

Rebooting Devices After Examining the Status in Chassis View | 1394

Managing CLI Configlets | 1396

CLI Configlets Overview | 1396

Configlet Variables | 1397

Default Variables | 1397

User-defined Variables | 1398

Predefined Variables | 1398

Velocity Templates | 1398

Directives | 1398

CLI Configlets Workflow | 1399

Configlet Context | 1403

Context of an Element | 1404

Context filtering | 1406

Creating a CLI Configlet | 1409

Modifying a CLI Configlet | 1412

Deleting CLI Configlets | 1413

Viewing CLI Configlets | 1414

Creating a Parameter for a CLI Configlet | 1416

Applying a CLI Configlet to Devices | 1418

Deploying CLI Configlet Details | 1422

Managing Optical Interfaces, OTUs, ODUs, ILAs, and IPLCs on MX Series and PTX Series Routers

Overview of Optical Interfaces, OTUs, and ODUs | 1426

Optical Interfaces Management and Monitoring on MX Series and PTX Series Routers
Overview | 1427

Ethernet DWDM Interface Wavelength Overview | 1429

Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview | 1429

Understanding Pre-FEC BER Monitoring and BER Thresholds | 1430

DWDM Controllers Overview | 1434

PTX5000 PIC Description | 1434

PTX5000 PIC Slots | 1435

PTX5000 PIC Function | 1435

PICs Supported on the PTX5000 | 1435

PTX5000 PIC Components | 1435

PTX3000 PIC Description | 1436

PIC Slots | 1437

PIC Function | 1438

PICs Supported | 1438

PIC Components | 1438

100-Gigabit Ethernet OTN Optical Interface Specifications | 1439

OTU4 4I1-9D1F Optical Interface Specifications | 1440

100-Gigabit DWDM OTN PIC Optical Interface Specifications | 1441

100-Gigabit DWDM OTN PIC (PTX Series) | 1445

Software Release | 1446

Hardware Features | 1447

Software Features | 1447

Cables and Connectors | 1449

LEDs | 1449

Alarms, Errors, and Events | **1450**

100-Gigabit Ethernet OTN PIC with CFP2 (PTX Series) | **1455**

Software Release | **1456**

Hardware Features | **1456**

Software Features | **1456**

Cables and Connectors | **1457**

LEDs | **1457**

100-Gigabit Ethernet PIC with CFP2 (PTX Series) | **1458**

Software Release | **1459**

Hardware Features | **1459**

Software Features | **1460**

Cables and Connectors | **1460**

LEDs | **1461**

Alarms, Errors, and Events | **1462**

100-Gigabit Ethernet PIC with CFP (PTX Series) | **1462**

Software Release | **1463**

Hardware Features | **1464**

Software Features | **1464**

Cables and Connectors | **1466**

LEDs | **1467**

Alarms, Errors, and Events | **1468**

100GbE PICs for PTX Series Routers | **1469**

Architecture and Key Components | **1469**

P2-10G-40G-QSFPP PIC Overview | **1470**

Understanding Dual Configuration on P2-10G-40G-QSFPP PIC | **1471**

Port Numbering on P2-10G-40G-QSFPP PIC | **1472**

10-Gigabit Ethernet Mode | **1474**

40-Gigabit Ethernet Mode | **1474**

Understanding the P2-100GE-OTN PIC | **1475**

Interface Features | **1475**

Layer 2 and Layer 3 Features | **1477**

OTN Alarms and Defects | **1478**

TCA Alarms | **1479**

100-Gigabit DWDM OTN PIC with CFP2 (PTX Series) | 1479

Software Release | 1480

Hardware Features | 1480

Software Features | 1481

Cables and Connectors | 1483

LEDs | 1483

Alarms, Errors, and Events | 1484

100-Gigabit DWDM OTN MIC with CFP2 | 1491

100-Gigabit Ethernet OTN Options Configuration Overview | 1499

Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength | 1501

Overview of Optical ILAs and IPLCs | 1504

Optical ILA Hardware Component Overview | 1504

Optical ILA Cooling System Description | 1505

Fan Modules | 1506

Optical ILA AC Power Supply Description | 1507

Optical ILA DC Power Supply Description | 1508

Optical ILA Chassis Status LEDs | 1509

Optical ILA Component Redundancy | 1512

Optical ILA Field-Replaceable Units | 1512

Optical ILA Management Panel | 1514

Optical ILA Management Port LEDs | 1515

Optical Inline Amplifier Description | 1516

Front Panel | 1517

FRU Panel | 1518

Optical ILA Power Supply LEDs | 1518

PTX3000 IPLC Description | 1521

IPLC Base Module | 1522

IPLC Base Module Components | 1523

IPLC Expansion Module | 1525

IPLC Components | 1526

IPLC Architecture and Functional Components Overview	1529
Architecture Overview	1529
Single Node Two Optical Line Terminations	1529
Functional Component Overview	1530
IPLC Base Module Functional Components	1530
IPLC Expansion Module Functional Components	1531
Understanding IPLC Base and Expansion Modules	1532
Overview	1532
Configuring, Managing, and Monitoring the IPLC	1533
SNMP	1533
Connectivity Services Director	1533
Optical Supervisory Channel	1533
High Availability, Resiliency, and Integrity	1533
Usability, Serviceability, Security and Troubleshooting	1533
Performance Monitors	1534
Usage Scenarios	1534
Optical Bypass Node Configuration	1534
Understanding the IPLC Configuration	1535
Understanding the Front Panel Connections	1535
Slot Placement in the Chassis	1535
Understanding How to Configure the Add and Drop Ports	1536
Frequency, Wavelength, and Port Default Mapping Configuration	1537
PTX3000 IPLC LED	1541
Communication of SNMP Traps Between Optical ILA and NMS Systems	1542
Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS	1543
Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI	1543
Configuration Settings Performed Using the CLI	1544
Set Parameters for SNMP	1544
Get Parameters for SNMP	1544
Alarms	1545
IPLC Specifications	1545
Understanding the Performance Monitors and TCAs for IPLCs	1546

Configuring and Monitoring Optical Interfaces, OTUs, and ODUs | 1553

Viewing a Graphical Image of the Optical Interface Components | **1553**

Configuring and Managing OTN Port Details of MX Series and PTX Series Routers for Easy Administration | **1563**

Configuring and Managing OTU Details of MX Series and PTX Series Routers for Simplified Management | **1571**

Configuring and Managing ODU Details of MX Series and PTX Series Routers for Simplified Management | **1577**

Configuring and Managing Optical PIC Details for Effective Provisioning | **1581**

Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | **1583**

Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | **1585**

Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | **1587**

Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | **1589**

Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | **1595**

Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | **1600**

Viewing a Graphical Image of the Chassis of PTX Series Routers | **1604**

Diagnosing, Examining, and Correcting Optical Interface Problems | **1609**

Optical Alarms, 24 Hour Threshold-Crossing Alarms (TCA), and 15 Minute Threshold-Crossing Alarms (TCA) | **1610**

OTU Alarms, 24 Hour Threshold-Crossing Alarms (TCA), and 15 Minute Threshold-Crossing Alarms (TCA) | **1611**

ODU Alarms, 24 Hour Threshold-Crossing Alarms (TCA), and 15 Minute Threshold-Crossing Alarms (TCA) | **1612**

Changing Alarm Settings for the Optics and OTN Interfaces | **1614**

Alarms for Optical Interfaces | **1614**

Alarms for OTN Interfaces | **1619**

Configuring Global Alarm Notifications | **1624**

Retaining Alarm History | **1625**

Specifying Event History | **1625**

Enabling Alarms | **1625**

Changing the Severity of Individual Alarms | **1625**

Configuring Individual Alarm Notifications | **1626**

Configuring and Monitoring Optical Inline Amplifiers | 1627

Viewing a Graphical Image of Optical Inline Amplifier | 1627

Viewing Optical ILA Configuration and Status Details for Simplified Administration | 1630

Viewing Performance Monitoring Details of Optical ILAs for Detecting and Diagnosing Faults | 1634

Configuring Threshold-Crossing Alarms for Optical ILAs for Monitoring Link Performance | 1642

Changing Alarm Settings for the Optical ILAs | 1644

- Alarms for Optical ILAs | 1645

- Configuring Global Alarm Notifications | 1647

- Retaining Alarm History | 1647

- Specifying Event History | 1648

- Enabling Alarms | 1648

- Changing the Severity of Individual Alarms | 1648

- Configuring Individual Alarm Notifications | 1649

Configuring and Monitoring Optical Integrated Photonic Line Cards | 1650

Viewing a Graphical Image of the Optical Integrated Photonic Line Card | 1650

Configuring Optical IPLC for Easy and Optimal Deployment | 1654

Viewing Performance Monitoring Details of Optical IPLCs for Detecting and Diagnosing Faults | 1661

Configuring Threshold-Crossing Alarms for Optical IPLCs for Monitoring Link Performance | 1668

Increasing the Add and Drop Port Capacity of the IPLC Node to 64 Channels | 1670

Configuring a Two-Degree IPLC Node for Express Traffic by Increasing the Line Capacity | 1672

Configuring Optical IPLC Line Connectivity for Interoperation with Optical ILAs | 1674

Configuring the Wavelengths That Are Added and Dropped by the IPLC | 1679

Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on a Remote Chassis | 1684

Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on the Same Chassis | 1686

Bypassing a Wavelength on the IPLC | 1687

Changing Alarm Settings for the Optical IPLCs | 1689

- Alarms for Optical IPLCs | 1690

- Configuring Global Alarm Notifications | 1695

- Retaining Alarm History | 1695

- Specifying Event History | 1695

- Enabling Alarms | 1695

- Changing the Severity of Individual Alarms | 1695

Configuring Individual Alarm Notifications | 1696

Viewing Routing Engine Switchover Indicators in the Chassis Image | 1697

Routing Engine Redundancy Overview | 1697

Conditions That Trigger a Routing Engine Failover | 1698

Viewing Alarm Indicators in the Chassis Image | 1699

Viewing Port Statistics for OTN PICs | 1700

Example: Configuring Two Fiber Line Terminations Using IPLCs for Optical Amplification in a Metro Linear Packet Optical Network | 1704

18

Working with User Roles

Managing User Roles | 1723

Creating a User-Defined Role | 1723

Managing Roles | 1725

Viewing User Role Details | 1725

Performing Manage Roles Commands | 1726

19

Working with Tunnel Services

Tunnel Services Overview | 1729

Tunnel Services Overview | 1729

Traffic Engineering Capabilities | 1730

Components of Traffic Engineering | 1731

Packet Forwarding Component | 1732

Packet Forwarding Based on Label Swapping | 1732

How a Packet Traverses an MPLS Backbone | 1732

Information Distribution Component | 1733

Path Selection Component | 1733

Signaling Component | 1734

Routers in an LSP | 1735

How a Packet Travels Along an LSP | 1735

Types of LSPs | 1735

Scope of LSPs | 1736

Constrained-Path LSP Computation | 1736

How CSPF Selects a Path | 1738

CSPF Path Selection Tie-Breaking | 1738

Computing CSPF Paths Offline | 1739

MPLS and RSVP Overview | 1740

 RSVP Overview | 1741

Fast Reroute Overview | 1742

Point-to-Multipoint LSPs Overview | 1745

RSVP Operation Overview | 1747

 RSVP Hello Packets and Timers | 1748

 RSVP Message Types | 1749

 Path Messages | 1749

 Resv Messages | 1750

 PathTear Messages | 1750

 ResvTear Messages | 1750

 PathErr Messages | 1750

 ResvErr Messages | 1750

 ResvConfirm Messages | 1750

 MTU Signaling in RSVP | 1751

Link Protection and Node Protection | 1752

 Node Protection | 1753

 LSP Protection Overview | 1754

 LSP Protection Types Comparison | 1755

 One-to-One Backup Implementation | 1755

 Facility Backup Implementation | 1756

Connectivity Services Director–NorthStar Controller Integration Overview | 1759

Service Design and Provisioning: Managing and Deploying Tunnel Services | 1760

Managing Devices and Tunnel Services Overview | 1761

Discovering Tunnel Devices | 1761

Creating an LSP Service Definition | 1763

 Specifying General Settings | 1763

 Specifying Path Settings | 1767

 Specifying BFD Settings | 1771

Reviewing the Configured Settings	1774
Creating an LSP Service Order	1775
Configuring LSP Service Order General Settings	1776
Configuring LSP Service Order Advanced Settings	1779
Configuring Common Settings	1780
Configuring LSP Path Settings in the Service Order	1784
Configuring BFD Settings for LSPs in the Service Order	1790
Creating a Name Pattern for LSPs in the Service Order	1794
Configuring Node Parameters for LSPs in the Service Order	1795
Configuring MPLS Path Settings	1797
Configuring LSP Primary Path Settings	1802
Configuring LSP Secondary Path Settings	1803
Reviewing the Configured Settings	1804
Creating Public and Private LSPs	1804
Managing Public LSPs by using NorthStar Controller	1804
Creating Private LSPs by Using Connectivity Services Director	1805
Viewing the Configured LSP Services	1806
Modifying an Explicit Path in RSVP LSP Services	1808
Modifying an RSVP LSP Service	1810
Viewing LSP Services in Deploy Mode	1811
Viewing LSP Service Orders in a Table	1813
Deactivating an LSP Service	1814
Reactivating an LSP Service	1816
Force-Deploying an LSP Service	1817
Viewing Alarms for an LSP Service	1819
Managing Deployment of LSP Services Configuration to Devices	1820
Selecting Configuration Deployment Options	1822
Discarding the Pending Configurations	1822
Deploying Service Configuration Changes to Devices Immediately	1823
Scheduling Configuration Deployment of Services	1824
Specifying Configuration Deployment Scheduling Options	1825
Deploying an LSP Service	1825
Deleting a Partial Configuration of an LSP Service Order	1827
Deleting an LSP Service Order	1828

Validating the Pending Configuration of an LSP Service Order | **1829**

Viewing the Configuration of a Pending LSP Service Order | **1830**

Viewing the Configuration Details of RSVP LSP Services | **1832**

Viewing Decommissioned LSP Service Orders | **1833**

Monitoring and Troubleshooting Tunnel Services | 1835

Performing a Functional Audit for LSP Services | **1835**

Viewing Functional Audit Results for LSP Services | **1842**

Examining the LSP Summary Details for Effective Troubleshooting | **1845**

Operational Status | **1846**

Status Matrix | **1847**

LSP Information | **1847**

LSP Traffic | **1848**

Troubleshooting the Endpoints of RSVP LSP Services | **1849**

Troubleshooting Services Using Operational Scripts | **1851**

Clearing LSP Statistics | **1853**

Monitoring Network Reachability by Using the MPLS Traceroute Capability | **1854**

Monitoring Network Reachability by Using the MPLS Ping Capability for RSVP LSPs | **1856**

About the Documentation

IN THIS SECTION

- Documentation and Release Notes | xlix
- Documentation Conventions | xlix
- Documentation Feedback | lii
- Requesting Technical Support | lii

Use this guide to understand the Junos Space Connectivity Services Director application, design and provision connectivity services, and manage devices like ACX Series routers, M Series routers, MX Series routers, PTX Series routers, and TCA Series Timing Appliances, in your networks.

Documentation and Release Notes

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <https://www.juniper.net/documentation/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <https://www.juniper.net/books>.

Documentation Conventions

Table 1 on page i defines notice icons used in this guide.

Table 1: Notice Icons







Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 2 on page I defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

Convention	Description	Examples
Bold text like this	Represents text that you type.	To enter configuration mode, type the configure command: user@host> configure
Fixed-width text like this	Represents output that appears on the terminal screen.	user@host> show chassis alarms No alarms currently active
<i>Italic text like this</i>	<ul style="list-style-type: none"> Introduces or emphasizes important new terms. Identifies guide names. Identifies RFC and Internet draft titles. 	<ul style="list-style-type: none"> A policy <i>term</i> is a named structure that defines match conditions and actions. <i>Junos OS CLI User Guide</i> RFC 1997, <i>BGP Communities Attribute</i>

Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
<i>Italic text like this</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i>
Text like this	Represents names of configuration statements, commands, files, and directories; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none">• To configure a stub area, include the stub statement at the [edit protocols ospf area area-id] hierarchy level.• The console port is labeled CONSOLE.
< > (angle brackets)	Encloses optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Encloses a variable for which you can substitute one or more values.	community name members [<i>community-ids</i>]
Indentation and braces ({ })	Identifies a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
; (semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
GUI Conventions		


Table 2: Text and Syntax Conventions (*continued*)

Convention	Description	Examples
Bold text like this	Represents graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> In the Logical Interfaces box, select All Interfaces. To cancel the configuration, click Cancel.
> (bold right angle bracket)	Separates levels in a hierarchy of menu selections.	In the configuration editor hierarchy, select Protocols>Ospf .

Documentation Feedback

We encourage you to provide feedback so that we can improve our documentation. You can use either of the following methods:

- Online feedback system—Click TechLibrary Feedback, on the lower right of any page on the [Juniper Networks TechLibrary](#) site, and do one of the following:



- Click the thumbs-up icon if the information on the page was helpful to you.
- Click the thumbs-down icon if the information on the page was not helpful to you or if you have suggestions for improvement, and use the pop-up form to provide feedback.
- E-mail—Send your comments to techpubs-comments@juniper.net. Include the document or topic name, URL or page number, and software version (if applicable).

Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active Juniper Care or Partner Support Services support contract, or are

covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <https://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <https://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <https://www.juniper.net/customers/support/>
- Search for known bugs: <https://prsearch.juniper.net/>
- Find product documentation: <https://www.juniper.net/documentation/>
- Find solutions and answer questions using our Knowledge Base: <https://kb.juniper.net/>
- Download the latest versions of software and review release notes: <https://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <https://kb.juniper.net/InfoCenter/>
- Join and participate in the Juniper Networks Community Forum: <https://www.juniper.net/company/communities/>
- Create a service request online: <https://myjuniper.juniper.net>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://entitlementsearch.juniper.net/entitlementsearch/>

Creating a Service Request with JTAC

You can create a service request with JTAC on the Web or by telephone.

- Visit <https://myjuniper.juniper.net>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <https://support.juniper.net/support/requesting-support/>.

1

PART

Overview

Working with Connectivity Services Director | 2

Service View Tasks and Lifecycle Modes | 35

Network Services Overview | 51

Working with Connectivity Services Director

IN THIS CHAPTER

- [Connectivity Services Overview | 2](#)
- [Getting Started with Connectivity Services Director | 4](#)
- [Connectivity Services Director REST API Overview | 7](#)
- [Understanding the Need for Connectivity Services Director for Managing Services | 12](#)
- [Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14](#)
- [Connectivity Services Director Overview | 15](#)
- [Understanding the Connectivity Services Director User Interface | 16](#)
- [Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)
- [Understanding Task Categories in Connectivity Services Director | 26](#)
- [Understanding Connectivity Services Director User Administration | 28](#)
- [Logging In to Connectivity Services Director | 29](#)
- [Changing Your Password for Connectivity Services Director | 30](#)
- [Logging Out of Connectivity Services Director | 32](#)
- [Getting Started Assistant Overview in Services Activation Director | 33](#)

Connectivity Services Overview

Connectivity services include Layer 2 VPN and Layer 3 VPN services, quality-of-service (QoS) profile services, timing synchronization services, tunneling and label-switched path (LSP) services, and connectivity fault management (CFM) services.

With connectivity services, you can perform the following tasks in your deployment:

- Design, provision, and monitor Label Discovery Protocol (LDP) and Border Gateway Protocol (BGP) services, and VPN services, for the management of Layer 2 and Layer 3 protocols, on devices.
- Configure the Operation, Administration and Maintenance (OAM) functionality on all devices and monitor, detect, isolate, and troubleshoot networking faults. The supported OAM features include link fault management (LFM), CFM, and real-time performance monitoring (RPM).

- Configure Precision Time Protocol (PTP) and synchronous Ethernet services, which are timing functionalities for devices.
- Design, provision, and deploy MPLS-dynamic, RSVP-signaled LSP, and static LSP services on devices.
- Configure QoS or class-of-service (CoS) capabilities for services on devices.

To enable you to design and provision connectivity services in your network, you can use Connectivity Services Director, which is a robust and highly-intuitive next-generation application that runs on the Junos Space Network Management Platform. This application also enables validation and monitoring of service performance, and management of timing and clock synchronization.

RELATED DOCUMENTATION

Understanding the Need for Connectivity Services Director for Managing Services	 12
Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director	 14
Connectivity Services Director Overview	 15
Understanding the Connectivity Services Director User Interface	 16
Understanding the Usage and Layout of Connectivity Services Director Views and Tasks	 24
Understanding Task Categories in Connectivity Services Director	 26
Understanding Connectivity Services Director User Administration	 28
Logging In to Connectivity Services Director	 29
Logging Out of Connectivity Services Director	 32

Getting Started with Connectivity Services Director

Based on your network deployment needs and configuration settings, you might require different service types, such as E-Line, IP, E-LAN, or RSVP LSP services, to be applied on devices in your topology. It is essential to discover or add the devices that you want to be administered using Connectivity Services Director to the application database, before you can enable and define services. You must configure the basic and mandatory device settings such as routing instances, routing protocols, and administrative groups before they are imported or discovered for additional modifications, such as configuration of services and using the network management application.

When you install Connectivity Services Director, the single application package installs the capabilities for configuring network services, such as E-Line, IP, and E-LAN, configuring MPLS and RSVP label-switched path (LSP) services, configuring Precision Time Protocol (PTP) and synchronous Ethernet services, configuring the OAM (Operations, Administration and Maintenance) functionality, and configuring class of service (CoS) profiles. To install Connectivity Services Director, see the *Installation Instructions for Connectivity Services Director, Release 2.1* section in [Junos Space Connectivity Services Director Release Notes, Release 2.1](#).

The following workflow describes the tasks that you need to perform after the installation of the application to enable effective and streamlined management, provisioning, and troubleshooting of devices and services configured using Connectivity Services Director.

After you install the Connectivity Services Director application, follow the tasks given below to enable effective management, provisioning, and troubleshooting of devices and services using the application:

1. Discover devices using Connectivity Services Director GUI or the Junos Space Platform workspace. See [“Discovering Devices” on page 188](#) for instructions on discovering devices using Connectivity Services Director. See *Discovering Devices* in the *Junos Space Network Management Platform User Guide* for instructions on discovering devices using the Junos Space Platform workspace.

NOTE:

Ensure the following before you add a device using device discovery:

- SSH v2 is enabled on the device. To enable SSH v2 on a device, run the following CLI command:


```
set system services ssh protocol-version v2
```
- The NETCONF protocol over SSH is enabled on the device. To enable the NETCONF protocol over SSH on a device, run the following CLI command:


```
set system services netconf ssh
```
- The device is configured with a static management IP address that is reachable from the Junos Space server. The IP address can be in-band or out-of-band.
- A user with full administrative privileges is created on the device for the Junos Space administrator.
- If you use SNMP to probe devices as part of device discovery, ensure that SNMP is enabled on the device with appropriate read-only V1/V2C/V3 credentials.

2. Discover the roles of devices and assign network-provider edge (N-PE) roles as necessary. To prestage devices and assign device roles, see [“Discovering Device Roles” on page 390](#) and [“Excluding Devices from N-PE Role Assignment” on page 391](#).
3. Create service templates. Templates provide a powerful mechanism to configure advanced service-related options that are not exposed via the service order creation workflow. Templates are attached to a service definition. To work with service templates, see *Service Templates Workflow* and *Applying a Service Template to a Service Definition*.
4. Review predefined service definitions that are available by default, and determine whether you want to create a new customized service definition. A service definition specifies the attributes that are common among a group of service orders that have similar service requirements. To work with service definitions, see [“Predefined Service Definitions” on page 479](#), *Creating an E-Line Service Definition*, [“Creating a Multipoint-to-Multipoint E-LAN Service Definition” on page 696](#), [“Creating a Point-to-Multipoint E-LAN Service Definition” on page 726](#), [“Creating a Full-Mesh IP Service Definition” on page 765](#), and [“Creating a Hub-and-Spoke \(One Interface\) IP Service Definition” on page 776](#).

5. Create customers that denote the users to be associated with service orders. New customers must be identified to the system before you can provision and activate a service order for them. To create customers, see [“Adding a New Customer” on page 795](#).
6. Create class-of-service profiles to prioritize the traffic flow and define policies for handling received packets to avoid network congestion and traffic disruption. See [“Creating and Managing Wired CoS Profiles” on page 233](#).
7. Create service orders for the types of protocols that your network environment requires for optimal and cohesive management of large numbers of devices. A service order is an instance of the service definition that completes the definition for a specific customer’s use. To work with service orders, see [“Creating a Service Order” on page 876](#).
8. Deploy service orders to propagate the service configuration to the corresponding devices. To transfer service order configurations to devices and apply the settings on the devices, see [“Deploying Services Configuration to Devices” on page 1083](#) and [“Managing Service Configuration Deployment Jobs” on page 1080](#).
9. Perform audit operations, such as functional and configuration audit, to examine the status of interfaces, LDP sessions, neighbor links, and endpoints of E-Line services. You can also identify whether the service configuration on the device has been changed out of band. In addition, you can use op scripts to perform any function available through the remote procedure calls (RPCs) supported by either the Junos XML management protocol or the Junos XML API. For more information, see [“Performing a Functional Audit” on page 1145](#), [“Performing a Configuration Audit” on page 1156](#), and [“Troubleshooting N-PE Devices Before Provisioning a Service” on page 1158](#).
10. Monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services. Several monitors or widgets are displayed to enable you to track, diagnose, and rectify problems and discrepancies associated with services configured on devices. To evaluate and diagnose the services, traffic-flow, and device states, see [“Service Monitoring Capabilities in Connectivity Services Director” on page 1252](#).
11. View information about the health of your network and changing conditions of your equipment. Use Fault mode to find problems with equipment, pinpoint security attacks, or to analyze trends and categories of errors. For example, if you find that a particular device or a service has recorded a large number of critical or major alarms, you can then navigate to the appropriate device settings page or service order page to correct and modify the attributes or diagnose the problems that might be generating the alarms. To view alarms and events, see [“Understanding Fault Mode in Connectivity Services Director” on page 47](#).

RELATED DOCUMENTATION

[Prestaging Devices Overview | 55](#)

[Junos Space Layer 2 Services Overview | 56](#)

[Junos Space Layer 3 Services Overview | 66](#)

[Provisioning Process Overview | 68](#)

[Seamless MPLS Support in Junos Space Overview | 72](#)

[Service Attributes Overview | 74](#)

[Service Order States and Service States Overview | 90](#)

Connectivity Services Director REST API Overview

The Juniper Networks Connectivity Services Director APIs are based on the Representational State Transfer (REST) standards. REST defines a set of principles for defining Web services, including how a system's resource states are transferred over HTTP. Clients can be written in any language that sends HTTP requests.

You use standard HTTP methods to access the Connectivity Services Director APIs. For example, HTTP GET is used by a client application to retrieve a resource, get data from a Web server or to execute a query. Common HTTP methods for REST are:

- GET – Retrieve a resource from the server.
- POST – Update a resource on the server.
- PUT – Create a resource state on the server.
- DELETE – Remove a resource state on the server.

The following media types are supported:

- For APIs that employ the GET method—Accept is used because a Response is the only involved operation here. The Accept type determines the type of the Response obtained. The Response can be either in XML or in JSON format.
- For APIs that employ the POST method—Content-type that determines the type of the input payload or request that is sent, is used.
- For APIs that employ the PUT method—Content-type that determines the type of the input payload or request that is sent, is used.
- For APIs that employ the DELETE method—Accept is used because a Response is the only involved operation here.

The Accept type determines the type of the response obtained. The Response can be either in XML or in JSON format. For example, for the Add Customer API, the Content and Accept types for XML are as follows:

Content-Type—application/vnd.net.juniper.space.customer-management.customers+xml

Accept—application/vnd.net.juniper.space.customer-management.customers-status+xml

Retrieved resources are displayed in human-readable format. Connectivity Services Director APIs return data in XML or JavaScript Object Notation (JSON).

The following RESTful Web Services are exposed under the Junos Space Connectivity Services Director root URI:

- Customers
- Provider edge (PE) devices
- Prestage devices
- Resource pools
- Service definitions for E-Line , E-LAN, and IP services
- Service orders for E-Line , E-LAN, and IP services
- Service operations for E-Line , E-LAN, and IP services
- Service templates for E-Line , E-LAN, and IP services
- Bulk operations for E-Line services
- Functional and configuration audit
- CFM profiles for services
- Performance management (PM) statistics
- Service definitions and service orders for LSP services
- OAM services for LFM, CFM, and SLA iterators
- Services for RFC 2544-based benchmarking tests
- Timing services for synchronous Ethernet and PTP

Connectivity Services Director RESTful Web Services provide programmatic access to the resources that are defined in Junos Space Connectivity Services Director. Connectivity Services Director RESTful Web Services follow the same standards and conventions as the Junos Space Network Application Platform RESTful Web Services. T

NOTE: Connectivity Services Director-related RESTful Web Services are exposed under the [/api/juniper/space](#) URI.

Example resource returned in XML format

```

<Data xmlns="services.schema.networkapi.jmp.juniper.net">
  <Customers>
    <Customer>
      <Common>
        <Name>Customer_005</Name>
      </Common>
      <AccountNo>40132324005</AccountNo>
      <ContactName>customer005</ContactName>
      <ContactEmail>customer005@example.com</ContactEmail>
    </Customer>
  </Customers>
</Data>

```

Example resource returned in JSON format

```

{ "Data" : { "Customers" : { "Customer" : { "AccountNo" : 40132324005,
      "Common" : { "Name" : "Customer_005" },
      "ContactEmail" : "customer005@example.com",
      "ContactName" : "customer005"
    } } } }

```

Format and Conventions of RESTful Web Services

The media type for the Connectivity Services Director application must be in the following format:

application/vendor.space.service.type+syntax;version=version number or

vendor.space.service.type+syntax;version=version number

For example, `application/vnd.net.juniper.space.monitoring.alarmscount+json;version=1`

[Table 3 on page 10](#) describes these parameters.

Table 3: Media parameters

Parameter	Description
vendor	<p>Vendor of the media type.</p> <p>Media types defined by Juniper Networks use vnd.net.juniper. Third-parties must use their own vendor string when defining web services in applications that are deployed on Junos Space.</p>
service	<p>Name of the Junos Space-specific service.</p> <p>Service names are lowercase alphanumeric tokens with hyphen separators; for example, device-management, incident-management.</p>
type	<p>Type of resource.</p> <p>Types are all lowercase alphanumeric tokens with hyphen separators; for example, device, incident.</p>
syntax	Representation of the resource. For example, xml.
version	Version of the API; versions begin with the numeral 1.

REST standards are well-described in books and on the Internet. It is not the intent of this guide to discuss the RESTful architecture. This document deals with the REST APIs exposed by Connectivity Services Director.

For information about Junos Space SDK, see [Junos Space SDK](#).

Payload and Response Types Supported in XML and JSON Formats

Payload or request can be in both XML format and JSON format, although this reference guide illustrates only the XML type input or payload in the sample APIs. An API is available for converting any given XML payload into a JSON payload. See [“Conversion of XML Format to JSON Format” on page 11](#), for detailed information on converting the XML format into a JSON format. Responses to the API request calls can be in both the XML format and JSON format, although this reference guide describes only the XML type responses in the samples.

Conversion of XML Format to JSON Format

For the ease of the users, an additional API has been provided for converting the XML inputs to JSON format. If the XML inputs pertaining to the NetworkAppsAPI are given as input, then the corresponding JSON format output can be obtained from the API.

URI	api/space/nsas/xml-json/convert">
HTTP Method	GET
Consumes	application/xml
Content-Type	application/json
Produces	Collects all the configured E-LINE LDP service orders.

Input (Converting the AddCustomer XML-Input to JSON-Input)

Sample XML Input

```
<Data xmlns="services.schema.networkapi.jmp.juniper.net">
<Data xmlns="services.schema.networkapi.jmp.juniper.net">
<Customers>
  <Customer>
    <Common>
      <Name>Customer_005</Name>
    </Common>
    <AccountNo>40132324005</AccountNo>
    <ContactName>customer005</ContactName>
    <ContactEmail>customer005@example.com</ContactEmail>
  </Customer>
</Customers>
</Data>
```

Output (JSON Format of the Preceding Input)

Sample XML Output

```
<Data xmlns="services.schema.networkapi.jmp.juniper.net">
  {"Data":{"Customers":{"Customer":{"Common":{"Name":"Customer_005"},
    "AccountNo":40132324005,"ContactName":"customer005",
    "ContactEmail":"customer005@example.com"}}}}}
</Data>
```

NOTE: Read this guide in conjunction with the [Network Director API Reference](#) for information about the REST APIs that you can configure for some of the functionalities available in views other than Service view of Connectivity Services Director. These APIs also define the fault and alarm notification APIs.

Understanding the Need for Connectivity Services Director for Managing Services

An important aspect of any network management system is to monitor, control, and plan network infrastructure. With networks constantly increasing in size, heterogeneity, and complexity, effective management and planning of networks become more important.

The following network management capabilities are essential for effective management of services on devices:

- Network management systems must be able to manage hybrid networks that offer both legacy TDM and next-generation IP-based services.. Simplification of essential tools required to set up, configure, provision, and operate devices and the services that run on them are key to keeping operational costs down and achieving efficiency.
- A network management system must offer simple and efficient tools to detect service faults and performance so that service levels are assured. Such a system includes tools to correlate faults with the alarms and traps generated on devices, and provide a real-time view of the complete operational status of a network.
- Any new network management system needs to provide seamless support for legacy functions while enabling new features to support packet-based networks. This may require the use of standards-based open interfaces to enable such OAM systems to query, configure, provision, and manage the new devices and services being deployed.
- An ideal network management system should present a unified device management interface for all devices from the access network to the core network. In the context of mobile backhaul, a unified

network device management interface is essential to efficiently deploy a large number of devices such as cell site gateways.

Assuming that these devices are hosted in remote locations, after the device is deployed, it is essential to ensure that the device management interfaces (DMIs) provide the right level of automation to reduce the time required to set up and configure each device without requiring additional manual intervention at the site.

- Network Management systems must be standards compliant and provide open interfaces for interoperability with existing systems in an operator's network. Standards-based northbound interfaces that use REST APIs are becoming the norm for such interoperability. Mobile backhaul networks typically contain tens of thousands of cell sites connected to aggregation devices and further, into the core network.
- Network management systems must be able to scale and offer efficient, user-friendly mechanisms to provision services in bulk. For example, reduction in the number of steps required to provision a pseudowire from end to end greatly improves the efficiency of a network provisioner, while also reducing the number of provisioning errors.

NOTE: Starting from Release 2.0, Connectivity Services Director supports E-Line services, VPN services, E-LAN services, and RSVP LSP services.

RELATED DOCUMENTATION

[Connectivity Services Overview | 2](#)

[Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

[Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)

[Understanding Task Categories in Connectivity Services Director | 26](#)

[Understanding Connectivity Services Director User Administration | 28](#)

[Getting Started Assistant Overview in Services Activation Director | 33](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director

Junos Space Connectivity Services Director application helps you configure, monitor, and deploy Layer 2 and Layer 3 services.

The following are the salient benefits and capabilities of the Connectivity Services Director application:

- The Connectivity Services Director UI helps you manage, administer, and handle activities and service deployments through various stages and phases on your device.
- You can install this application to leverage Layer 2, Layer 3, label-switched path (LSP), and class of service (CoS) functionalities on devices in your network based on your deployment needs and device models to be managed.
- If you are deploying the network management utility in your topology for the first time for routing and tunnel services provisioning, and if you have previously deployed Network Director for the administration of devices, such as EX Series switches and QFX Series switches, you can seamlessly install the Connectivity Services Director application. You can install the Connectivity Services Director software package on different appliances to perform Layer 2 through Layer 3 services management on several platforms, such as ACX Series routers, M Series routers, MX Series routers, PTX Series routers, and TCA Series Timing Appliances.

NOTE: Network Director cannot be installed on the same system as Connectivity Services Director.

RELATED DOCUMENTATION

[Connectivity Services Overview | 2](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

[Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)

[Understanding Task Categories in Connectivity Services Director | 26](#)

[Understanding Connectivity Services Director User Administration | 28](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Connectivity Services Director Overview

Service providers and enterprises must be able to rapidly provision and offer new MPLS and Carrier Ethernet services across their networks. In order to reduce operational costs and enable quick service rollouts, network operators need an intelligent provisioning application that facilitates the design, deployment, and management of services. Junos Space Connectivity Services Director facilitates lifecycle management of connectivity services such as E-Line, E-LAN, L2VPN, IP, and RSVP LSP services, QoS profile configuration, service performance validation and monitoring, and synchronization management. In addition to an intuitive graphical user interface, the application also supports a rich set of API functions to enable northbound interface integration and service orchestration with other operations support systems (OSS) platforms.

Telecommunication establishments and organizations worldwide that offer MPLS and Carrier Ethernet services face common business challenges such as controlling capital and operating expenses, accelerating time to market, and increasing customer satisfaction. At the same time, these companies also have to deal with the following technical challenges:

- Provisioning a customer service rapidly and accurately
- Scaling to keep up with customer demand
- Tracking site-specific quality of service (QoS)
- Troubleshooting and pinpointing problems in the network
- Finding trained personnel with expertise in networking and MPLS technologies

Junos Space Connectivity Services Director allows service providers and enterprises to rapidly enable new service offerings. It facilitates an automated and streamlined approach to the service design and provisioning process, and helps reduce fallout from misconfigured customer services. Besides automating key provisioning tasks, Junos Space Connectivity Services Director also provides a complete network management solution, including automated service discovery, MPLS resource management, point-and-click service provisioning, validation, and troubleshooting for MPLS and carrier Ethernet service environments.

Junos Space Connectivity Services Director is a Junos Space application for unified management of the ACX Series routers, M Series routers, MX Series routers, PTX Series routers, and TCA Series Timing Appliances in your network.

Junos Space Connectivity Services Director essentially manages the lifecycle of Layer 2 and Layer 3 services. The application helps in resource pool management, service design and provisioning, troubleshooting and performance monitoring, and service decommissioning.

The Connectivity Services Director application helps in:

- Automating the design of Layer 2 and IP services, activating and provisioning services, validating Layer 2 and IP services across MPLS and Carrier Ethernet networks, enabling service providers to efficiently and cost-effectively manage deployments while reducing fallout from misconfigured services.
- Designing, provisioning, and activating RSVP-signaled label-switched paths (LSPs), as well as static LSPs, which can be configured as end-to-end, point-to-point, point-to-multipoint, or full-mesh LSPs.
- Monitoring faults and performance of VPN services using standards-based protocols and technologies such as Ethernet connectivity fault management (CFM), Ethernet link-level fault detection and management, and Bidirectional Forward Detection (BFD).
- Configuring and applying class-of-service (CoS) profiles to interfaces of devices.
- Provisioning synchronization of interfaces such as IEEE1588- 2008 (PTP) and Synchronous Ethernet.

RELATED DOCUMENTATION

[Connectivity Services Overview | 2](#)

[Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

[Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)

[Understanding Task Categories in Connectivity Services Director | 26](#)

[Understanding Connectivity Services Director User Administration | 28](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Understanding the Connectivity Services Director User Interface

IN THIS SECTION

● [Connectivity Services Director Banner | 17](#)

● [View pane | 18](#)

● [Views list | 19](#)

● [Tasks Pane | 19](#)

● [Main Window or Workspace | 19](#)

- Filtering the Network Tree | 20
- Tables in Connectivity Services Director | 21

Junos Space Connectivity Services Director provides a simple-to-use, HTML5-based, Web 2.0 user interface that you can access through standard Web browsers. The user interface uses task-based workflows to help you accomplish administrative tasks quickly and efficiently. It provides you with the flexibility to work with single or multiple devices grouped by logical relationship, location, or device type. You can filter, sort, and select columns in tables, making looking for specific information easy.

This topic describes:

Connectivity Services Director Banner

Use the Connectivity Services Director banner to select the working mode. You can also use the Connectivity Services Director banner to perform other global tasks, such as setting up your preferences or accessing Junos Space. [Table 4 on page 17](#) describes the functions available to you on the banner.

Table 4: Connectivity Services Director Banner Functions

Item	Function
Accessing Junos Space Network Management Platform	<p>Click the Junos Space logo to access the Junos Space Network Management Platform application.</p> <p>Select Connectivity Services Director from the Applications list to access the CSD application.</p> <p>NOTE: You can switch back and forth between Connectivity Services Director and Junos Space Network Management Platform without logging in again.</p>
Views	<p>Select the network view that you want to work in. You can choose any one of the following views from the Views list:</p> <ul style="list-style-type: none"> ● Dashboard View ● Service View ● Device View ● Custom Group View ● Topology View

Table 4: Connectivity Services Director Banner Functions (*continued*)

Item	Function
Task Categories	<p>Select the task category you want to work in. You can select any one of the following task categories to work in:</p> <ul style="list-style-type: none"> • Build • Deploy • Monitor • Fault • Report <p>NOTE: You might not have access to all the Connectivity Services Director task categories. Your user role determines the task categories you have access to.</p>
User	Displays the username you use to log in to Connectivity Services Director.
System	Click the System button to view Audit Logs pane.
Preferences	Click the arrow next to the System button and select Preferences to access and update system and user preferences.
About	Click the arrow next to the System button and select About from the list to view the version number and licensing information of your Connectivity Services Director application.
Help	Click the arrow next to the System button and select Help from the list to access the Connectivity Services Director Online Help page.
Logout	Click the arrow next to the username and select Logout to log out of Connectivity Services Director and Junos Space.

View pane

The Service pane provides you with a unified, hierarchal view of your networks in the form of a tree that is expandable and collapsible. By selecting a node from the tree, you indicate the *scope* over which you want an operation or task to occur. For example:

For example, by selecting the MX240 node in Device View, you indicate that the scope for a task is all MX240 routers in your network.

NOTE: The view pane displayed depends on the network view you choose from the Views list.

Views list

You can use the Views list on the Connectivity Services Director banner to choose any one of the following network views:

- **Dashboard View**—This is a customizable view that provides information about your network. You can select and add monitoring widgets to the Dashboard View based on your requirements. This is the default view that opens when you log in to Connectivity Services Director.
- **Service View**—You can create services, policies, and filters for devices that are managed by Connectivity Services Director. The service templates and attributes for services, policies, and filters help you classify and control the way packets are handled by the various services.
- **Device View**—Devices are organized by device type: routers. Within each device type displayed in the Device View pane, devices are organized by device model. For example, all models of MX240 routers are grouped together under one node in the tree.
- **Custom Group View**—If you have defined one or more custom groups, Connectivity Services Director displays groups in this view. You can manually add devices to a custom group or define a rule to automatically add devices to the custom group after they are discovered in Connectivity Services Director.
- **Topology View**—This view displays a graphical representation of the discovered devices in your network, organized by groups or zones. The topology map window displays important links and node properties. Links are color coded according to utilization. You can also view physical and logical connectivity between various discovered interconnected devices.

Tasks Pane

The Tasks pane is available in the Service View, Device View, and Custom Group View of the Views list. The Task pane lists tasks specific to that view. In addition to changing according to the view selected, tasks listed in the Tasks pane can change. For example, some tasks are appropriate only at the device level and thus appear only when you have selected an individual device. Clicking a task brings up task-specific content in the main window. To perform a task in Connectivity Services Director, you navigate to the task.

Main Window or Workspace

The main window or workspace displays content relevant to a particular view, scope, and task you have selected. When you log in to Connectivity Services Director, the main window displays the dashboard. The dashboard enables you to allow users who are assigned roles to quickly monitor health and status of the managed devices. The sections of the dashboard allows the operator to understand the device problem

or fault at the macro level (comprehensive and widespread network health and status) and the micro level (individual device health and status).

Filtering the Network Tree

IN THIS SECTION

- [Expanding or Collapsing Nodes in the Network Tree | 21](#)
- [Searching the Network Tree | 21](#)

To make it easier for you to focus on selected aspects of your network, you can apply predefined filters to your network tree so that only nodes and devices that meet the filter criteria are shown.

To apply filters:

1. From the View pane, click the filter icon:

The Filters page is displayed.

NOTE: The view pane displayed depends on the network view you choose from the Views list. The filter feature is available only in the Service View and Device View.

2. From the Filters page, click **Show available filters**.

The Available Filters section of the page appears.

3. From the **Available Filters** page, select the tab for the view you want to use to define your filter. For example, if you want to filter devices, click the **Device** tab.

The filters that you can apply are listed below the Device tab.

4. To select a filter, click the add (+) icon next to the device.

The filter appears on the Selected Filters section of the Filters page.

NOTE: You can add multiple filters at a time. Alternatively, you can remove a filter from the Selected Filters section of the Filters Page by clicking the trash can icon next to the device.

5. Click **Apply**.

The Filters dialog box closes and the filters are applied. The words '*Filter applied*' appears below the filter icon. Alternatively, you can click Clear (next to '*Filter applied*') to remove any filters applied. `

To remove a filter, click the filter icon, click the trash can next to the filter on the Selected Filters list, and click **Apply**.

Expanding or Collapsing Nodes in the Network Tree

To expand a node in the network tree, select the node and then click the **Expand All (+)** icon:

The node you selected and any child nodes under the selected node are expanded to show their contents.

Similarly, to collapse a node in the network tree, select the node and then click the **Collapse (-)** icon (next to the Expand icon). The node you selected is collapsed and no nodes under it are shown.

Searching the Network Tree

To quickly find and select a device or device group, use the search function.

To perform a search, type three or more characters in the search box and press **Enter**.

Connectivity Services Director finds the first instance of a node whose name contains the characters. You can use the arrows next to the search box to see the other instances..

NOTE: Searches are not case-sensitive: searching *wla115* or *WLA115* returns the same results. You can also use wildcard characters in search strings.

Tables in Connectivity Services Director

Tables are used throughout Connectivity Services Director to display data. These tables share common features. By becoming familiar with these features, you can navigate and manipulate tabular data quickly and efficiently.

The following sections describe:

- Moving and resizing columns
- Navigating pages

- Displaying column lists
- Sorting a column
- Hiding and exposing columns
- Searching table contents
- Filtering table contents

Moving and Resizing Columns

You can reposition and resize columns in a table. To move a column, drag the column head to the new location. Connectivity Services Director displays a green check mark when you mouse over a valid column location. To resize a column, mouse over the edge of a column until the cursor becomes two vertical lines with outward arrows. Drag the column width to the new size.

Navigating Pages

Controls at the bottom of a page allows you to navigate through entries on the pages when the inventory is too large to fit on one page. Using these controls, you can go to a specific page, navigate between pages, or refresh content in a page.

Displaying the Column list

A list allows you to perform additional operations on columns. To display the column list, mouse over the column head. An arrow appears. Click the arrow to display the list.

Sorting a Column

You can sort a table based on a column by clicking the column head—each click changes the direction of the sort. In addition, you can use the Sort Ascending and Sort Descending options on the list.

Connectivity Services Director uses a lexical sort for tabular data that is not strict numeric data, which means that data such as IP addresses do not sort in numerical sequence, as shown in [Table 5 on page 22](#).

Table 5: Numerical Sorts and Lexical Sorts

Numerical Sort	Lexical Sort
10.93.200.65	10.93.200.129
10.93.200.129	10.93.200.199
10.93.200.199	10.93.200.65

Hiding and Exposing Columns

You can customize your tables by hiding or exposing columns. This way, you can choose to see only relevant information.

To hide or unhide columns, display the column list of any column head and mouse over the Columns option. In the list that appears, select the check box beside a column head to unhide it. Clear the check box beside a column to hide it.

As a general rule, Connectivity Services Director displays all columns in a table by default. However, some tables have more columns that can fit easily within the page and columns are hidden by default.

Searching Table Contents

You can search for specific data in large tables by using search criteria.

To search for an item in a table, enter the search term in the text box within the table. Select ANY from the list to search for the term in all columns in the table. Every table has a predefined default column that the system searches before it searches other columns.

You can also choose to search a particular column for a term.

NOTE: When you enter a search expression, note the following:

- You must add a back slash “\” if you want to use the following special characters in the search text:

+ ~ && || ! () { } [] ^ “ ~ * ? : \

- Field names are case-sensitive.

For example, if you have a few systems running on Junos OS 12.3 Release 4.5, then `os: 12.3R4.5` returns search results, whereas `OS: 12.3R4.5` does not return search results. This is because the field name that is indexed is `os` and not `OS`.

- If you want to search for a term that includes a space, enclose the term within double quotation marks.

For example, to search for all devices that are synchronized (that is, In Sync), enter “In Sync” in the Search field.

- You must append “*” if you want to search using partial keywords. Otherwise, the search returns 0 (zero) matches or hits.
- If you want to search for more than one term at a time, separate each term with **AND**.

Filtering Table Contents

For large tables, it is helpful to be able to sort data to show only relevant entries. When you mouse over the Filters option on the column list, a fill-in box appears where you can type filter criteria. If you type a text string and click **GO**, entries that do not contain the text string (filter criterion) are removed from the table. The filter icon appears on the column head to indicate that the column has been filtered. To restore all entries to the table, clear the Filters checkbox in the list.

For example, to filter the Device Inventory page so that only devices in the **192.168.1.0** subnet are displayed:

1. Mouse over the IP Address column head and click the arrow.

The Column list is displayed.

2. Mouse over **Filters** to display the fill-in box.

3. Type **192.168.1.** in the field and click **Go**.

The devices in the **192.168.1.0** subnet are shown.

RELATED DOCUMENTATION

[Connectivity Services Overview | 2](#)

[Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)

[Understanding Task Categories in Connectivity Services Director | 26](#)

[Understanding Connectivity Services Director User Administration | 28](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Understanding the Usage and Layout of Connectivity Services Director Views and Tasks

The Connectivity Services Director user interface uses task-based workflows to help you accomplish tasks quickly and efficiently. The interface has five network views and five task categories that you can access from the application banner.

The View pane provides you a unified, hierarchical view of your networks in the form of a tree that is expandable and collapsible. You can select a network view from the Views list to display the workspaces and settings that you can define for network services and tunnel services. The view pane displayed depends on the network view you choose from the Views list.

The Task Categories displayed on the banner guides you through the different phases of configuration and monitoring that you can perform with Network View.

The Tasks pane lists tasks specific to that task category. In addition to tasks changing according to the task category selected, tasks listed on the Tasks pane can change based on the view you select from the Views list. Clicking a task brings up task-specific content in the main window.

See “[Understanding the Connectivity Services Director User Interface](#)” on page 16 for more information on the main components of the Connectivity Services Director GUI.

RELATED DOCUMENTATION

[Connectivity Services Overview](#) | 2

[Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director](#) | 14

[Connectivity Services Director Overview](#) | 15

[Understanding the Connectivity Services Director User Interface](#) | 16

[Understanding Task Categories in Connectivity Services Director](#) | 26

[Understanding Connectivity Services Director User Administration](#) | 28

[Logging In to Connectivity Services Director](#) | 29

[Logging Out of Connectivity Services Director](#) | 32

Understanding Task Categories in Connectivity Services Director

Connectivity Services Director enables automated design and provisioning of VPN services such as E-Line services, E-LAN services, and IP services; label-switched path (LSP) services such as MPLS, RSVP, and static LSP services; configuration of QoS profiles; validation and monitoring of service performance; and management of synchronization.

Connectivity Services Director application enables you to easily discover, configure, monitor, and manage devices in large networks.

The Connectivity Services Director user application uses task-based workflows to help you accomplish tasks quickly and efficiently. The interface has five task categories that you can access from the application banner.

NOTE: Task categories are not available in the Dashboard View and Topology View.

The task categories you can access are as follows:

- **Build**—You use Build task category to discover the devices in your network, to create and manage device configurations, and to manage devices. You can also organize your devices into hierarchical groups based on logical relationships or physical locations. To support flexible, large-scale deployment of devices, the Build task category enables you to apply configurations across multiple devices grouped by logical relationships, physical locations, or type.

In Build mode, you can create services for devices that are managed by Connectivity Services Director. You can define service templates and attributes of different services, and also specify policies and filters to classify and control the manner in which packets are handled by various services. You can define E-Line services to provide transport and encapsulation of Layer 2 Ethernet circuits between two endpoints. You can also configure E-LAN service, which in turn provides multipoint-to-multipoint services and point-to-multipoint services, and Layer 3 virtual private network (VPN) functionality by using IP service, which supports full-mesh and hub-and-spoke services. The service designer is responsible for creating service definitions that a service provisioner uses to create a service order.

- **Deploy**—The Deploy task category enables you to deploy service order configuration changes to devices. When you make configuration changes in Build task category, the changes are not deployed to devices automatically. You must manually deploy the changes to devices. Configuration changes are deployed to devices at the device level. When you deploy configuration changes to a device, all pending configuration changes for that device are deployed. You can do the following configuration deployment tasks on devices that have pending changes:
 - Run configuration deployment jobs immediately or schedule them for later.
 - Preview pending configuration changes before deploying the service settings to devices.

- Validate that the pending changes are compatible with the device configuration.
- Manage configuration deployment jobs.
- **Monitor**—Monitor task category in Connectivity Services Director enables you to view your network status and performance. The Connectivity Services Director application monitors its managed services on devices and maintains the information it collects from the devices in a database. Monitor task category displays this information in graphs and in tables that you can sort and filter, allowing you to quickly visualize the state of your network, spot trends developing over time, and find important details. The main purpose of monitoring functionalities is to allow the operators to quickly monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services.
- **Fault**—Fault task category in Connectivity Services Director enables you to view your network health. e. Fault task category displays alarms in graphs and in tables that you can sort and filter, enabling you to resolve system conditions that generate the alarms. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification (also called a trap) to the Connectivity Services Director application. Connectivity Services Director application correlates traps, describing a condition, into an alarm. To assist in diagnosing network problems and the operating efficiency of devices, the task category shows you information about the health of your network and changing conditions of your equipment.

NOTE: Starting in Release 2.0, the Report task category is disabled.

RELATED DOCUMENTATION

[Connectivity Services Overview | 2](#)

[Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

[Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)

[Understanding Connectivity Services Director User Administration | 28](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Understanding Connectivity Services Director User Administration

Connectivity Services Director application uses the user administration features of Junos Space Network Management Platform to add, delete, and edit user accounts and roles. For more information on user administration, see *Junos Space Network Application Platform User Guide*.

When you install the Connectivity Services Director application, additional user administration options specific to the application are available in Junos Space. In addition to the Super Administrator role, the following predefined roles are also available to Connectivity Services Director users:

- Device Manager role---allows an administrator to discover devices.
- Service Manager role--allows an administrator to perform device pre-staging actions including discovering and assigning device roles.
- Service Designer role--allows an administrator to create and publish a service definition.
- Service Activator (less privileged) role---allows an administrator to perform provisioning tasks including creating and managing customers, service orders, and services.

NOTE: You can create custom roles to grant users different access rights. Access is controlled at the task category level. If you grant a user access to a task category, the user has access to all tasks in that category.

Access to Connectivity Services Director system preferences is controlled by user access rights. For more information, see [“Setting Up User and System Preferences” on page 125](#)

If you try to log in to Connectivity Services Director by using an account that does not have access rights to any Connectivity Services Director task category, you are redirected to Junos Space instead.

RELATED DOCUMENTATION

[Connectivity Services Overview | 2](#)

[Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director | 14](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

[Understanding the Usage and Layout of Connectivity Services Director Views and Tasks | 24](#)

[Understanding Task Categories in Connectivity Services Director | 26](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Logging In to Connectivity Services Director

You connect to Connectivity Services Director using your Web browser. The following Web browsers are supported: Internet Explorer 9.0 and 10.0, Mozilla Firefox version 3.6 and later, and Google Chrome version 17 and later. The minimum screen resolution is 1280 x 1024.

To log in to Connectivity Services Director directly:

1. In the Address field of your browser, enter the following URL:

```
https://<n.n.n.n>/csd/
```

where *n.n.n.n* is the IP address of the Junos Space Web interface. You can bookmark the login page for future use.

2. Enter the login credentials, such as the username and password.

The default username and password are the same for both Junos Space and Connectivity Services Director:

- Username—super
- Password—juniper123

After successful login, the Dashboard page of Connectivity Services Director is displayed.

To log in to Connectivity Services Director through Junos Space:

1. In the Address field of your Web browser, enter the following URL:

```
https://<n.n.n.n>/mainui
```

where *n.n.n.n* is the IP address of the Junos Space Web interface.

The Junos Space login page is displayed.

2. In the **Username** text box, enter your username.

For information about how to change your username, consult your system administrator.

3. In the **Password** text box, enter your password.

The default username and password are the same for both Junos Space and Connectivity Services Director:

- Username—super
- Password—juniper123

For information about how to change your password, see [“Changing Your Password for Connectivity Services Director” on page 30](#).

4. (Optional) If the remote authentication server is configured for Challenge/Response, you are presented with the challenge questions. Provide valid responses to the challenge questions you are asked, to log in successfully.

5. Click **Log In**.

The Junos Space home page appears. If the home page is not set, the Junos Space Dashboard page is displayed.

If the home page is inaccessible due to role or domain restrictions, a warning message is displayed and the Junos Space Dashboard page is loaded.

NOTE: If you are a user with access to more than one domain, then an informational message about switching domains is displayed in a dialog box.

Do one of the following:

- To prevent the informational message from appearing again, ensure that the **Don't show again** check box is selected and click **OK**. The **Don't show again** check box is selected by default.
- To allow the informational message to continue appearing, clear the **Don't show again** check box and click **OK**.

You can then switch to the Connectivity Services Director interface by selecting Connectivity Services Director from the Applications list in the left pane of the Junos Space user interface.

RELATED DOCUMENTATION

[Logging Out of Connectivity Services Director | 32](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

Changing Your Password for Connectivity Services Director

Any user, regardless of user role, can change his or her password.

You use the same username and password that you use for Junos Space and Connectivity Services Director. To change your password:

1. From the Connectivity Services Director user interface, click the Junos Space icon on the Connectivity Services Director banner.

The Junos Space Platform user interface is displayed.

2. Click the **User Settings** icon on the Junos Space banner.

The **Change User Settings** dialog box appears.

3. In the **Old Password** text box, enter your old password.

NOTE: Mouse over the information icon (small blue *i*) next to the **New Password** text box to view the rules for password creation. For more information about the password rules, see *Modifying Junos Space Network Management Platform Settings*.

4. In the **New Password** text box, enter your new password. The minimum value for this field is 6 (the default) and the maximum value is 999. The password can include alphanumeric and special characters, but not control characters.

5. In the **Confirm Password** text box, enter your new password again to confirm it.

NOTE: The fields on the **X.509 Certificate** tab are applicable when you want to use certificate-based authentication. If you are using password-based authentication, you can ignore these fields. For more information about certificate-based authentication, see the *Certificate Management Overview* topic in the *Junos Space Network Management Platform Workspaces Feature Guide*.

6. (Optional) Select the **Manage objects from all assigned domains** check box on the **Object Visibility** tab to view and manage objects from all the domains for which you are assigned.

7. Click **OK**.

You are logged out of the system. To log in to Junos Space again, you must use your new password. Other sessions logged in with the same username are unaffected until the next login.

RELATED DOCUMENTATION

Logging Out of Connectivity Services Director

After you finish using Connectivity Services Director, log out to prevent unauthorized access. You can log out manually or set an automatic logout period for Connectivity Services Director to automatically log you out.

Logging out manually—To log out of Connectivity Services Director manually, click the down arrow next to the username on the Connectivity Services Director banner and select Logout from the list.

Logging out automatically—Connectivity Services Director automatically logs you out if you have not performed any action on it, such as by using keystrokes or mouse-clicks, for a set period of time. This automatic logout conserves server resources and protects the system from unauthorized access. By default, automatic logout occurs if a session has been idle for 60 minutes. You can change the setting on the Applications inventory page. Select **Administration > Applications > Network Management Platform > Modify Application Settings** (from the Actions menu) > **User**.

Connectivity Services Director uses the same automatic logout period as Junos Space.

To change the automatic logout period:

1. Click the System Platform icon on the Connectivity Services Director banner.

The logout page appears.

2. Click the **Click here to log in again** link on the logout page to log in to the system again.

3. Navigate to **Administration > Applications**.

The Applications page is displayed.

4. Right-click **Network Management Platform** and select **Modify Application Settings**.

The Modify Application Settings page appears.

5. In the Modify Network Management Settings page, select **User**.

The User page is displayed.

6. In the **Automatic logout after inactivity (minutes)** field, move the slider to modify the automatic logout setting.

The logout setting is modified.

7. Click **Modify** to save the setting.

You are returned to the Modify Applications page.

RELATED DOCUMENTATION

[Logging In to Connectivity Services Director | 29](#)

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

Getting Started Assistant Overview in Services Activation Director

The Getting Started assistant is a section in the sidebar that shows you how to perform common tasks. The tasks in the Getting Started assistant are workspace specific. The tasks displayed in this section vary according to the workspace. The Getting Started assistant provides instructions on how to perform tasks related to a device, service template, or a policy and filter template configuration.

The Getting Started topics are context- sensitive per application. Getting Started displays all the steps of a task. From a step in a task, you can jump to that point in the user interface to actually complete it. If **Show Getting Started on Startup** check box is selected, the Getting Started assistant automatically displays the tasks when you log in. If this check box was not selected, click the **Help** icon and click **Getting Started** from the resulting sidebar.

To use a Getting Started assistant:

1. Select an application from the **Applications** list above the task tree.
2. In the sidebar, expand **Getting Started**.

A main Getting Started topic link appears on the sidebar.

If the sidebar is not displayed, select the **Help** (?) icon at the right side of the Junos Space header. The sidebar appears.

3. Select a main topic.

For example, if you are in the Network Management Platform application user interface, click the **Increase Space Capacity** link. A list of required steps appears in the sidebar. Each step contains a task link and a link to Help.

4. Perform a specific step by clicking the link.

You jump to that point in the user interface. The assistant remains visible on the sidebar to aid navigation to subsequent tasks.

5. Access help for a specific step by clicking the Help icon next to that step.

RELATED DOCUMENTATION

[Connectivity Services Director Overview | 15](#)

[Understanding the Connectivity Services Director User Interface | 16](#)

[Logging In to Connectivity Services Director | 29](#)

[Logging Out of Connectivity Services Director | 32](#)

Service View Tasks and Lifecycle Modes

IN THIS CHAPTER

- [Understanding the Service View Tasks Pane in Build Mode | 35](#)
- [Understanding the Service View Tasks Pane in Deploy Mode | 38](#)
- [Understanding the Service View Tasks Pane in Monitor Mode | 40](#)
- [Understanding the Service View Tasks Pane in Fault Mode | 43](#)
- [About Build Mode in Service View of Connectivity Services Director | 44](#)
- [About Deploy Mode in Service View of Connectivity Services Director | 45](#)
- [About Fault Mode in All Views of Connectivity Services Director | 47](#)
- [About Monitor Mode in Service View of Connectivity Services Director | 48](#)

Understanding the Service View Tasks Pane in Build Mode

The Tasks pane in Service View contains all the operations that you can perform to create the network managed by Junos Space Connectivity Services Director by using the prestaging process that discovers devices in the Junos Space database and assigns roles to those devices and their interfaces. In Build mode, you can use the Tasks pane to define service definitions, which specify the service parameters for the devices or endpoints and associated interfaces for controlling traffic flow.

Click a specific task to begin that task. Not all tasks are available in the Service View when you launch it the first time. Depending on the service definitions that you create, those configured service definitions are displayed under the corresponding service trees, such as E-LAN or IP, in the task pane. Service View tasks are divided into the following categories in the Tasks pane.

- **Key Tasks**—Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. The most preferred tasks that you want to do while using the Service View are listed under Key Tasks. You can add tasks from the service task menu to the Key Tasks category. The Key Tasks category is a duplicate of the added tasks from the Service Provisioning and Service Design tasks menu. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can also modify this set of tasks to suit your requirements. This modification feature is available in the Task pane irrespective of your current mode, scope, or view.
- **Manage Service Templates** (accessible from the Services Activation Director GUI)—Provides a powerful mechanism to configure advanced service-related options that are not exposed via the service order creation workflow. Create and attach one or more service templates to a service definition to define any provisioning-related configuration option beyond the current coverage of Connectivity Services Director.
- **Service Design**—Enables you to create and manage service definitions and service templates. A service definition specifies the attributes that are common among a group of service orders that have similar service requirements. Service templates are specific to service definitions. Both are specific to service types, so that if you are dealing with an IP service type, for example, both your service definition and service template must be of that type.
- **Manage Service Definitions**—Provides a set of predefined service definitions for E-Line services, multipoint-to-multipoint (full mesh) services, point-to-multipoint (hub and spoke) services, and RSVP LSP services. These service definitions are capable of providing the basis for most of the service orders your organization will need to create.
- **View Services**—Enables you to view the configured E-Line, IP, and E-LAN services by the service types and the service statuses. In the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.
- **View LSPs**—Enables you to view the configured RSVP LSP services.

- **View Details**—Enables you to view comprehensive information about the configured parameters of a service.
- **Audit/Results**—Enables you to run configuration and functional audit operations, and view the results of the audit job.
 - **Configuration Audit**—Enables you to perform a configuration audit and view the results of the operation. A configuration audit can help you determine whether the service configuration on the device has been changed out of band.
 - **Functional Audit**—Enables you to perform a functional audit and view the results of the operation.
 - **Troubleshoot**—Enables you to run the operational scripts that are either created or imported to the platform from the local machine before you start troubleshooting the services or you can run the scripts that are of local type directly from the Functional Audit Result window by clicking the **Troubleshoot** button.
- **Prestage Devices**—Enables you to change the device and interface role assignments, view prestaging rules, and manage resource pools.
 - **Prestage Devices**—Enables you to assign network provider edge (N-PE) and provider (P) roles to devices and user-to-network interface (UNI) roles to interfaces.
 - **Prestage Rules**—Enables you to view the prestaging rule details.
 - **Manage Resources**—Enables you to view resource pools, such as IP addresses and VLANs, and create IP address pools to be used in services.
- **Customer**—Displays the tasks that you can perform to manage customers
 - **Add Customers**—Enables you to add new customers on the system before you can provision and activate a service order for each of them.
 - **Delete Customer**—Enables you to delete a previously created customer.
 - **View Customer**—Enables you to view customers for which service orders need to be configured and deployed.

RELATED DOCUMENTATION

[Understanding the Service View Tasks Pane in Deploy Mode | 38](#)

[Understanding the Service View Tasks Pane in Monitor Mode | 40](#)

[Understanding the Service View Tasks Pane in Fault Mode | 43](#)

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Fault Mode in All Views of Connectivity Services Director | 47](#)

Understanding the Service View Tasks Pane in Deploy Mode

The Tasks pane in Deploy mode lists the operations that you can perform in Service View to propagate and provision the configuration settings of the service orders to the corresponding devices. All Deploy mode tasks are always available, regardless of the scope selected in the View pane. Service View tasks are divided into the following categories in the Tasks pane.

- **Key Tasks**—Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. The most preferred tasks that you want to do while using the Service View are listed under Key Tasks. You can add tasks from the service task menu to the Key Tasks category. The Key Tasks category is a duplicate of the added tasks from the Service Provisioning and Service Design tasks menu. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can also modify this set of tasks to suit your requirements. This modification feature is available in the Task pane irrespective of your current mode, scope, or view.
- **Service Provisioning**—The tasks you do to create and manage service orders for the topology of your network. A service order is an instance of the service definition that completes the definition for a specific customer's use. The service order always specifies the customer and the endpoints that link the customer sites through the network.
- **Deploy Services: Manage Network Services and Manage LSP**—Enables you to modify, delete, validate, and deploy services to enable the configuration parameters to be propagated and provisioned on the managed devices. You can perform the following tasks from the Manage Network Services page:
 - **Create a New Service Order**—Creates a service order for E-Line, E-LAN, IP, and RSVP LSP protocols. A service order is an instance of the service definition that completes the definition for a specific customer's use. The service order always specifies the customer and the endpoints that link the customer sites through the network
 - **Modify a Service**—Modifies a previously configured service for E-Line, E-LAN, IP, and RSVP LSP protocols. When a service is based on a service definition that you created in the Service Design workflow (Build mode of Service View), you can edit only those parameters of a service that were marked as **Editable in Service Order** in the service definition.
 - **Reactivate a Service**—Reactivates a previously disabled service order for E-Line, E-LAN, IP, and RSVP LSP services. After you disable a service order to deactivate the configuration settings on devices mapped to the service, you might require the service settings to be reenabled after you have modified the service parameters, either directly on the device or using the Connectivity Services Director application.

- **Deactivate a Service**—Disables a service order for a particular protocol that you have previously created on the network. By disabling a service, the traffic processing for the traversed packets is impacted. In certain network topologies, you might require a service-related settings to be disabled for a certain period to perform troubleshooting or modification to the traffic-handling method.
- **Decommission a Service**—Decommissions a service that a customer no longer needs. You cannot decommission a service if a service order requesting action on that service is in the Requested, Scheduled, In Progress, or Invalid state.
- **Force-Deploy a Service**—Forcefully deploys the service to push the configuration to the device. Forceful deployment pushes the same configuration to the device that was pushed during the deployment of the service, thus allowing the operator to recover from a state in which the configuration on the device was lost or changed out-of-band.
- **Run Functional Audit**—Performs a functional audit and view the results of the operation. A functional audit determines whether a deployed service instance is functioning.
- **Run Configuration Audit**—Performs a configuration audit and view the results of the operation. A configuration audit can help you determine whether the service configuration on the device has been changed out of band.
- **View Alarms**—Displays the Alarm Detail monitor to locate a specific alarm, research the events causing the alarm, and to assign a disposition to the alarm. When an alarm is highlighted in the sorting sequence, the events contributing to the alarm are listed in the Event Details monitor and the variable settings are shown in the Event Attribute Detail table.
- **Deploy Services: Manage Service Orders and Manage LSP Deployment**—Schedule a service order for deployment on the network at a particular time, or propagate the service settings to devices for publishing and commissioning the settings immediately. You can perform the following tasks from the Manage Service Orders page:
 - **Modify a Service Order**—Enables you to modify a previously configured service order for E-Line, E-LAN, and IP protocols. When a service order is based on a service definition that you created in the Service Design workflow (Build mode of Service View), you can edit only those parameters of a service that were marked as **Editable in Service Order** in the service definition. The other attributes can be updated only in the service definition or service template.
 - **Deploy now**—Propagates the service settings and provisions them on the devices immediately.
 - **Schedule Deploy**—Commissions the service settings on the devices at a specified future time.
 - **Discard Pending Configuration**—Discards all the pending service configurations that were made on a device
 - **Validate Pending Configuration**—Performs analysis and validation checks to verify that the pending changes are compatible with a device when you deploy configuration changes to the device.
 - **View Pending Configuration**—Displays the configuration of a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state.

- **Delete Partial Configuration**—Removes the residual configuration for a failed service order of type Provisioning that can leave parts of the service configuration on the devices.
- **Deploy Configuration Changes**—Deploys pending configuration changes to devices.
- **View Deployment Jobs**—Manages configuration deployment jobs. When you deploy configuration changes or schedule a configuration deployment, a configuration deployment job is created. You can view the details of a service configuration deployment job or cancel a scheduled service configuration deployment job.

RELATED DOCUMENTATION

[Understanding the Service View Tasks Pane in Build Mode | 35](#)

[Understanding the Service View Tasks Pane in Monitor Mode | 40](#)

[Understanding the Service View Tasks Pane in Fault Mode | 43](#)

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Fault Mode in All Views of Connectivity Services Director | 47](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

Understanding the Service View Tasks Pane in Monitor Mode

The Tasks pane in Monitor mode displays a list of operations that you can perform to analyze and identify network conditions that require corrective action for the configured services on devices. A set of graphs and statistical details in tables are displayed to enable you to easily view the state of your network in an intuitive format. Connectivity Services Director monitors its managed services on devices and maintains the information it collects from the devices in a database. Service View tasks are divided into the following categories in the Tasks pane.

- **Key Tasks**—Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. The most preferred tasks that you want to do while using the Service View are listed under Key Tasks. You can add tasks from the service task menu to the Key Tasks category. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can also modify this set of tasks to suit your requirements. This modification feature is available in the Task pane irrespective of your current mode, scope, or view.
- **Service Summary**—Displays the consolidated and cumulative status of a service. This tab is applicable for E-Line, IP, and E-LAN services. The Connections monitor show the status of the connection or link

(up or down) between peer devices. In the table displayed for this monitor, the row represents the source device and the column denotes the destination device. The status of the link is displayed for E-Line and E-LAN services. The Traffic Summary monitor represents the total Egress (Packets out) traffic passing through all the UNI or CE interfaces that are part of the cumulative services. It is displayed for E-Line, IP, and VPLS services. The Current Active Alarms monitor shows any active alarm that has not yet been cleared.

- **Service Transport**—Displays the transport or packet statistics for data against time between the source and destination devices that you select, and based on the LSP that is used by the endpoint. The source device is the row selected in the Connection Matrix widget on the Service Transport tab. The destination device is chosen from the Traffic Statistics widget on the Service Transport tab. By default, no destination devices are selected. Service transport statistical values are displayed for E-Line, E-LAN, and IP services.
- **Service Traffic**—Displays the end-to-end traffic matrix that signifies the traffic between peer devices. You can view statistical counters and metrics for input packets, input bytes, output packets, and output bytes. The Interface Statistics monitor shows traffic data on all the user-to-network interfaces (UNI) or site interfaces that are part of the service. These values are on-demand statistical values and the data is retrieved from the device directly without being cached (polling at periodic intervals and displaying a snapshot). This tab is supported for E-Line, E-LAN, and IP services. The data is available only if queues are enabled on the interface.
- **Y1731**—Displays frame delay, frame loss, frame delay variation, and service availability. These measurements are achieved by triggering a one-way delay, two-way delay, or loss. The performance measurement is useful for generating periodic service-level agreement conformance reports from the deployed network and for studying traffic patterns in the network over a period of time. In proactive mode, SLA measurements are triggered by an iterator application. An iterator is designed to periodically transmit SLA measurement packets in form of ITU-Y.1731-compliant frames for two-way delay measurement or loss measurement for each of the connections registered to it. Iterators make sure that measurement cycles do not occur at the same time for the same connection to avoid CPU overload. The iterator profiles are configured on remote MEP for measurement of Ethernet frame delay measurement (ETH-DM), Ethernet frame loss measurement (ETH-LM), and statistical frame loss (SFL).

NOTE: Configuring iterator profile is not supported by Connectivity Service Director.

- **RFC2544**—Displays the RFC2544 test profiles created to measure throughput, latency, frame loss rate, and bursty frames. An RFC2544-based benchmarking test is performed by transmitting test packets from a device that functions as the generator or the initiator (which is also called the originator). These packets are sent to a device that functions as a reflector, which receives and returns the packets to the initiator. The test methodology enables you to define various parameters such as different frame sizes to be examined, the test time for each test iteration, and the frame format (UDP-over-IP).
- **LSP Summary**—Displays a comprehensive and cohesive view about the configured RSVP LSP service. The status of the LSP and the status of connections between the ingress router and egress routers in

an LSP are displayed. The LSP status details are shown for the ingress router. You can also view the ingress, egress, and transit LSP information, such as the primary and secondary states.

- **Clear Interface Statistics**—Deletes all of the interface-related counters and values associated with the selected service. It is effective for E-Line, E-LAN, and IP services.
- **Clear LSP Statistics**—Deletes all of the interface-related counters and values associated with the selected RSVP LSP service.
- **MPLS Ping**—Sends a probe from one endpoint to the other endpoint of a service, such as E-Line, IP, LSP, and E-LAN. Use the Ping MPLS functionality to diagnose the state of label-switched paths (LSPs), Layer 2 and Layer 3 virtual private networks (VPNs), and Layer 2 circuits. You can ping an MPLS endpoint using various options. You can send variations of ICMP echo request packets to the specified MPLS endpoint.
- **MPLS Traceroute**—Enables you to trace the route followed by an LDP-signaled LSP. LDP LSP traceroute is based on RFC 4379, Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures. This feature allows you to periodically trace all paths in a FEC.
- **Show Interface Statistics**—Displays the interface-related settings and parameters associated with the selected service, such as E-Line, IP, and E-LAN.
- **Show Interface Status**—Displays interface status details to monitor interface bandwidth utilization and traffic statistics associated with the selected service, such as E-Line, IP, and E-LAN.
- **Show Routing Table**—Displays the routing table information for the selected virtual routing instance. For IP services, you can determine which LSPs or tunnels are being used by looking at the routing tables.
- **Show MAC Table**—Displays the learned MAC address information for a device associated with a particular service:
- **OAM>Y1731**—Enables you to start and stop the collection of performance monitoring statistical details.
- **OAM>RFC2544**—Enables you to run RFC 2544 benchmarking tests.

RELATED DOCUMENTATION

[Understanding the Service View Tasks Pane in Build Mode | 35](#)

[Understanding the Service View Tasks Pane in Deploy Mode | 38](#)

[Understanding the Service View Tasks Pane in Fault Mode | 43](#)

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Fault Mode in All Views of Connectivity Services Director | 47](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

Understanding the Service View Tasks Pane in Fault Mode

The Tasks pane in Fault mode provides you with a set of tools for effectively managing alarms on your system. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director that are correlated and displayed as alarms.

From the Tasks pane, you can filter known alarms to locate a specific alarm or error condition by clicking Search Alarms. Use this task to isolate alarms that occurred during a known time-frame or that have annotations associated with them. Although each of the Fault mode monitors can sort the alarms, Search Alarms enable you to submit multiple search and sort arguments as part of your search query.

In addition, Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can modify this set of tasks to suit your requirements. This feature is available in Task pane irrespective of your current mode, scope, or view.

The following monitors are displayed in Fault mode:

- **Alarms by Severity**—Displays the fault alarm details sorted based on severity—that is in the following order: critical, major, minor, and info.
- **Alarms By Category**—Displays the fault alarm details sorted based on category—that is in the following order: active, acknowledged, and cleared.
- **Alarms By State**—Displays the fault alarm details sorted based on state—that is in the following order: active, acknowledged, and cleared.
- **Current Active Alarms**—Displays any active alarm that has not yet been cleared.

RELATED DOCUMENTATION

[Understanding the Service View Tasks Pane in Build Mode | 35](#)

[Understanding the Service View Tasks Pane in Deploy Mode | 38](#)

[Understanding the Service View Tasks Pane in Monitor Mode | 40](#)

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Fault Mode in All Views of Connectivity Services Director | 47](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

About Build Mode in Service View of Connectivity Services Director

IN THIS SECTION

- [Manage Service Definitions | 44](#)
- [Prestage Devices | 44](#)
- [Prestage Services | 45](#)
- [Service Definition Operations | 45](#)
- [Audit and Troubleshooting of Services | 45](#)

In Build mode, you can create services for devices that are managed by Connectivity Services Director. You can define service templates and attributes of different services, and also specify policies and filters to classify and control the manner in which packets must be handled by the various services.

Configuring a service has a major impact on the flow of routing information or packets within and through the router. For example, you can configure a routing service that does not allow routes associated with a particular customer to be placed in the routing table. As a result of this configured service, the customer routes are not used to forward data packets to various destinations and the routes are not advertised by the routing protocol to neighbors. The service designer uses the Build mode for managing the service definitions that the service provisioner uses as the basis for creating a service order. You can create a service definition that specifies the attributes that are common among a group of service orders that have similar service requirements, and a service order, which is an implementation object or a derivative of a service definition.

This topic describes the following functionalities that are available in Build mode of Service View:

Manage Service Definitions

Connectivity Services Director software provides a set of predefined service definitions for E-Line services, multipoint-to-multipoint (full mesh) services, and point-to-multipoint (hub and spoke) services. These service definitions are capable of providing the basis for most of the service orders your organization will need to create. In case these predefined service definitions are not adequate for all your needs, however, the Network Activate software enables you to create service definitions of your own.

Prestage Devices

Prestaging takes the devices already under Junos Space management and prepares them for service activation. The prestaging process discovers network provider edge (N-PE) devices in the Junos Space

database and assigns roles to those devices and their interfaces. N-PE routers and user-to-network interfaces (UNIs) are basic building blocks required for Layer 2 and Layer 3 provisioning

Prestage Services

The Service Recovery feature functions within the pre-staging operation of the Network Activate application. Service Recovery has two parts. First, Service Recovery parses each device's configuration searching for service configurations and existing Network Activate service elements (E-Line service, Layer 2 circuits, routing instances, firewalls, policy options, routing options, and OAM interface branches of Junos Space configurations that are being processed).

Service Definition Operations

You can perform several tasks on service definitions, such as editing, publishing, or unpublishing a service definition. You can modify a service definition to suit your network needs. The service designer must publish a customized service definition before a service provisioner can use that definition to create a service request. The service designer can unpublish a custom service definition to make it unavailable to service provisioners for creating a service request. You cannot unpublish a predefined service definition.

Audit and Troubleshooting of Services

After the service is deployed, a functional audit establishes whether the service is up or down. If the functional audit reports that the service is up, the customer can begin using the service. Once the service is active, the service provisioner can monitor the health of the service by running a functional audit or a configuration audit. Users assigned the Service Activator role can perform these service provisioning tasks.

RELATED DOCUMENTATION

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

About Deploy Mode in Service View of Connectivity Services Director

IN THIS SECTION

- [Manage Network Services | 46](#)
- [Manage Deployment of Service Orders | 46](#)

The Deploy mode enables you to deploy service order configuration changes to devices. When you make configuration changes in Build mode, the changes are not deployed to devices automatically. You must manually deploy the changes to devices in Deploy mode. Every time you make configuration changes in Build mode that affect a service, you must propagate the service order changes to the device by commissioning the configuration to the device. Configuration changes are deployed to devices at the device level. When you deploy configuration changes to a device, all pending configuration changes for that device are deployed.

This topic describes the following functionalities that are available in Deploy mode of Service View:

Manage Network Services

A service is an instance of the service order that defines the configuration parameters and attributes for transmission and management of traffic in a customer network. A service is created for a deployed service order. The service always specifies the customer and the endpoints that link the customer sites through the MPLS network. For each endpoint, the service provisioner specifies the network provider edge device and the UNI on that device that connects the customer site to the N-PE device. The service can also specify any additional attributes that are configured in the service definition as editable in the service order. These attributes might include the virtual circuit ID (VCID), maximum transmission unit (MTU) for the ingress or user-to-network interface (UNI), MTU for the connection across the network, VLAN-ID, rate limiting bandwidth, and so forth.

You can modify the properties of the service, conduct a functional or configuration audit, activate or deactivate the service, and view alarms associated with a particular service order for debugging and corrective action.

You can decommission a service that a customer no longer needs. You cannot decommission a service if a service order requesting action on that service is in the Requested or Draft, Scheduled, In Progress, or Invalid state.

Manage Deployment of Service Orders

A service order is an instance of the service definition that completes the definition for a specific customer's use. In Deploy mode, you can do the following configuration deployment tasks on devices for which service orders are configured to be provisioned or that have pending changes:

- Modify the parameters of a service order to suit your deployment needs or to resolve traffic-forwarding problems caused by service attributes.
- Validate the configuration of service orders.
- Delete partial configuration of services on devices.
- Discard the pending configuration of services from being deployed to devices.
- Run configuration deployment jobs immediately or schedule them for future times.

- Preview pending configuration changes before deploying.
- Manage configuration deployment jobs.

RELATED DOCUMENTATION

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

About Fault Mode in All Views of Connectivity Services Director

Fault mode in Connectivity Services Director provides you visibility into your network status and performance by displaying alarms and events generated on devices and configured services on devices. Connectivity Services Director monitors its managed devices and maintains the information it collects from the devices in a database. Fault mode displays this information in easy-to-understand graphs and in tables that you can sort and filter, allowing you to quickly visualize the state of your network, spot trends developing over time, and find important details. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director.

Connectivity Services Director correlates traps, describing a condition, into an alarm . For example, multiple power supply traps coming from a device are correlated into a single power supply alarm for the device. The main purpose and benefit of monitoring functionalities is to allow the operators to quickly monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services such as E-Line, E-LAN, and IP.

The monitoring mechanism is tool that enables the operator to understand the network health and status by drilling down to all the components of a device. The device status is marked as green, red, orange, or blue, based on the health, availability, performance and other important key performance indicators.

- Red denotes an emergency condition, which is a system panic or other conditions that cause the routing platform to stop functioning. It also indicates that the device is offline or turned down.
- Orange denotes an alert, which can be conditions that must be corrected immediately, such as a corrupted system database.
- Yellow indicates a notice, which signifies conditions that are not error conditions but are of interest or might warrant special handling. It can also include a severity level equivalent to informational or debugging messages.
- Blue denotes an informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

RELATED DOCUMENTATION

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

About Monitor Mode in Service View of Connectivity Services Director

IN THIS SECTION

- [Quick Access to Important Troubleshooting Details | 48](#)
- [Performance Monitoring | 49](#)
- [View and Clear Interface Information | 49](#)
- [View Interface Status | 49](#)
- [View Routing Table | 49](#)
- [View MAC Table | 49](#)
- [Traceroute for an MPLS LSP | 50](#)
- [MPLS Ping | 50](#)

Monitor mode in Connectivity Services Director provides you visibility into the transmission of packets between peer devices, health and traffic-handling capacity, and consolidated statistical details of important packet metrics based on the services configured. The Connectivity Services Director application monitors its managed services on devices and maintains the information it collects from the devices in a database. Monitor mode displays this information in easy-to-understand graphs and in tables that you can sort and filter, allowing you to quickly visualize the state of your network, spot trends developing over time, and find important details.

This topic describes the following functionalities that are available in Monitor mode of Service View:

Quick Access to Important Troubleshooting Details

The main purpose and benefit of monitoring functionalities is to allow the operators to quickly monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services. Several monitors or widgets are displayed to enable you to track, diagnose, and rectify problems and discrepancies associated with services configured on devices. For example, you might observe that an L3VPN service is reported as down from the summarized

information presented for that service on the monitoring page. This high-level view enables you to navigate to the settings for that service and tune them properly to function properly.

Performance Monitoring

You can employ the ITU-T Y.1731 standard-compliant Ethernet loss measurement (ETH-LM), Ethernet synthetic loss measurement (ETH-SLM), and Ethernet delay measurement (ETH-DM) capabilities to analyze and examine the operating efficiency and performance status. These performance monitoring functionalities can be run for E-Line and E-LAN services. You can start and stop the collection of performance monitoring statistics on the services that you want to monitor. The retrieval and computation of statistical details are performed using SNMP MIBs.

View and Clear Interface Information

You can view the learned MAC address information for a device associated with a particular service, the interface statistical counters and metrics, and the status of an interface. The functionalities available in Monitor mode of Service View are equivalents to the operational commands you can run from the Junos CLI interface to view interface information or MAC address details. You can also clear the interface statistics maintained on a device.

View Interface Status

You can view the interface status to monitor interface bandwidth utilization and traffic statistics on the device. When you view the interface status for a particular service, all the interfaces configured on the different devices associated the service are retrieved and displayed.

View Routing Table

The Routing Table window enables you view the routing table information for the selected virtual routing instance. For L3VPN services, you can determine which LSPs or tunnels are being used by looking at the routing tables.

View MAC Table

You can view the learned MAC address information for a device associated with a particular service. You can manage MAC entries more efficiently by viewing the configured aging time for a MAC entry, which is the maximum time that an entry can remain in the MAC address table before it is deleted because it has reached its maximum age

Traceroute for an MPLS LSP

You can perform a traceroute operation to examine the network reachability and identify connection failures from a source or ingress host to a remote host for an MPLS LSP signaled by RSVP. It is a debugging tool to locate MPLS label-switched path (LSP) forwarding issues in a network. (Currently supported for IPv4 packets only.)

MPLS Ping

You can use the MPLS ping application to examine the network reachability and identify any broken links for diagnostic purposes. In IP networks, the ping and traceroute functionalities enable you to verify network connectivity and find broken links or loops. In MPLS-enabled networks, you can use the ping capability to determine whether IP connectivity exists to a destination even when the ping packets must traverse multiple LSPs.

RELATED DOCUMENTATION

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Fault Mode in All Views of Connectivity Services Director | 47](#)

Network Services Overview

IN THIS CHAPTER

- [Getting Started with Connectivity Services Director | 52](#)
- [Prestaging Devices Overview | 55](#)
- [Junos Space Layer 2 Services Overview | 56](#)
- [Junos Space Layer 3 Services Overview | 66](#)
- [Provisioning Process Overview | 68](#)
- [Seamless MPLS Support in Junos Space Overview | 72](#)
- [Service Attributes Overview | 74](#)
- [Service Order States and Service States Overview | 90](#)
- [Understanding VLAN Manipulation \(Normalization and VLAN Mapping\) on Ethernet Services | 92](#)
- [VLAN Pool Profiles Overview | 97](#)
- [Redundant Pseudowires for Layer 2 Circuits and VPLS | 98](#)
- [VPLS over GRE Overview | 99](#)
- [Junos Space Network Topology Overview | 100](#)
- [Service Recovery Overview | 102](#)
- [Multicast L3VPN Overview | 103](#)
- [Multi-Chassis Automatic Protection Switching Overview | 104](#)
- [Inverse Multiplexing for ATM Overview | 104](#)
- [Rendezvous Point | 105](#)
- [Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees | 106](#)
- [Understanding PIM Sparse Mode | 108](#)
- [Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs | 111](#)
- [Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs | 113](#)
- [Configuring VRF Route Targets for Routing Instances for an MBGP MVPN | 115](#)
- [Static Pseudowire Provisioning for VPLS Services | 116](#)

Getting Started with Connectivity Services Director

Based on your network deployment needs and configuration settings, you might require different service types, such as E-Line, IP, E-LAN, or RSVP LSP services, to be applied on devices in your topology. It is essential to discover or add the devices that you want to be administered using Connectivity Services Director to the application database, before you can enable and define services. You must configure the basic and mandatory device settings such as routing instances, routing protocols, and administrative groups before they are imported or discovered for additional modifications, such as configuration of services and using the network management application.

When you install Connectivity Services Director, the single application package installs the capabilities for configuring network services, such as E-Line, IP, and E-LAN, configuring MPLS and RSVP label-switched path (LSP) services, configuring Precision Time Protocol (PTP) and synchronous Ethernet services, configuring the OAM (Operations, Administration and Maintenance) functionality, and configuring class of service (CoS) profiles. To install Connectivity Services Director, see the *Installation Instructions for Connectivity Services Director, Release 2.1* section in [Junos Space Connectivity Services Director Release Notes, Release 2.1](#).

The following workflow describes the tasks that you need to perform after the installation of the application to enable effective and streamlined management, provisioning, and troubleshooting of devices and services configured using Connectivity Services Director.

After you install the Connectivity Services Director application, follow the tasks given below to enable effective management, provisioning, and troubleshooting of devices and services using the application:

1. Discover devices using Connectivity Services Director GUI or the Junos Space Platform workspace. See [“Discovering Devices” on page 188](#) for instructions on discovering devices using Connectivity Services Director. See *Discovering Devices* in the *Junos Space Network Management Platform User Guide* for instructions on discovering devices using the Junos Space Platform workspace.

NOTE:

Ensure the following before you add a device using device discovery:

- SSH v2 is enabled on the device. To enable SSH v2 on a device, run the following CLI command:


```
set system services ssh protocol-version v2
```
- The NETCONF protocol over SSH is enabled on the device. To enable the NETCONF protocol over SSH on a device, run the following CLI command:


```
set system services netconf ssh
```
- The device is configured with a static management IP address that is reachable from the Junos Space server. The IP address can be in-band or out-of-band.
- A user with full administrative privileges is created on the device for the Junos Space administrator.
- If you use SNMP to probe devices as part of device discovery, ensure that SNMP is enabled on the device with appropriate read-only V1/V2C/V3 credentials.

2. Discover the roles of devices and assign network-provider edge (N-PE) roles as necessary. To prestage devices and assign device roles, see [“Discovering Device Roles” on page 390](#) and [“Excluding Devices from N-PE Role Assignment” on page 391](#).
3. Create service templates. Templates provide a powerful mechanism to configure advanced service-related options that are not exposed via the service order creation workflow. Templates are attached to a service definition. To work with service templates, see *Service Templates Workflow* and *Applying a Service Template to a Service Definition*.
4. Review predefined service definitions that are available by default, and determine whether you want to create a new customized service definition. A service definition specifies the attributes that are common among a group of service orders that have similar service requirements. To work with service definitions, see [“Predefined Service Definitions” on page 479](#), *Creating an E-Line Service Definition*, [“Creating a Multipoint-to-Multipoint E-LAN Service Definition” on page 696](#), [“Creating a Point-to-Multipoint E-LAN Service Definition” on page 726](#), [“Creating a Full-Mesh IP Service Definition” on page 765](#), and [“Creating a Hub-and-Spoke \(One Interface\) IP Service Definition” on page 776](#).

5. Create customers that denote the users to be associated with service orders. New customers must be identified to the system before you can provision and activate a service order for them. To create customers, see [“Adding a New Customer” on page 795](#).
6. Create class-of-service profiles to prioritize the traffic flow and define policies for handling received packets to avoid network congestion and traffic disruption. See [“Creating and Managing Wired CoS Profiles” on page 233](#).
7. Create service orders for the types of protocols that your network environment requires for optimal and cohesive management of large numbers of devices. A service order is an instance of the service definition that completes the definition for a specific customer’s use. To work with service orders, see [“Creating a Service Order” on page 876](#).
8. Deploy service orders to propagate the service configuration to the corresponding devices. To transfer service order configurations to devices and apply the settings on the devices, see [“Deploying Services Configuration to Devices” on page 1083](#) and [“Managing Service Configuration Deployment Jobs” on page 1080](#).
9. Perform audit operations, such as functional and configuration audit, to examine the status of interfaces, LDP sessions, neighbor links, and endpoints of E-Line services. You can also identify whether the service configuration on the device has been changed out of band. In addition, you can use op scripts to perform any function available through the remote procedure calls (RPCs) supported by either the Junos XML management protocol or the Junos XML API. For more information, see [“Performing a Functional Audit” on page 1145](#), [“Performing a Configuration Audit” on page 1156](#), and [“Troubleshooting N-PE Devices Before Provisioning a Service” on page 1158](#).
10. Monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services. Several monitors or widgets are displayed to enable you to track, diagnose, and rectify problems and discrepancies associated with services configured on devices. To evaluate and diagnose the services, traffic-flow, and device states, see [“Service Monitoring Capabilities in Connectivity Services Director” on page 1252](#).
11. View information about the health of your network and changing conditions of your equipment. Use Fault mode to find problems with equipment, pinpoint security attacks, or to analyze trends and categories of errors. For example, if you find that a particular device or a service has recorded a large number of critical or major alarms, you can then navigate to the appropriate device settings page or service order page to correct and modify the attributes or diagnose the problems that might be generating the alarms. To view alarms and events, see [“Understanding Fault Mode in Connectivity Services Director” on page 47](#).

RELATED DOCUMENTATION

[Prestaging Devices Overview | 55](#)

[Junos Space Layer 2 Services Overview | 56](#)

[Junos Space Layer 3 Services Overview | 66](#)

[Provisioning Process Overview | 68](#)

[Seamless MPLS Support in Junos Space Overview | 72](#)

[Service Attributes Overview | 74](#)

[Service Order States and Service States Overview | 90](#)

Prestaging Devices Overview

In the Junos Space Connectivity Services Director product, prestaging takes the devices already under Junos Space management and prepares them for service activation. The prestaging process discovers network provider edge (N-PE) devices in the Junos Space database and assigns roles to those devices and their interfaces. N-PE routers and user-to-network interfaces (UNIs) are basic building blocks required for Layer 2 and Layer 3 provisioning.

NOTE: The Connectivity Services Director application does not support provisioning for J Series devices.

The Junos Space software makes it easy to complete all the prestaging activities you need for up to several hundred devices.

Prestaging uses the Connectivity Services Director application to automatically determine the role of a router based on rules that exist in the system. If a router is an N-PE router, the Junos Space software assigns it the N-PE role. The Junos Space software qualifies each interface on the N-PE router to be a serviceable UNI.

N-PE and UNI recommendations made automatically by the Connectivity Services Director application are appropriate for most situations. In some networks, however, you might need to make some exceptions. You might have recommended N-PE devices that you don't want to assign the N-PE role for provisioning. In addition, you might want to exclude some interfaces from qualification as UNIs.

To prestage devices while accepting all recommendations made by the Connectivity Services Director application, see [“Discovering and Assigning All N-PE Devices” on page 366](#). To make exceptions to the Connectivity Services Director recommendations, see [“Discovering and Assigning N-PE Devices with Exceptions” on page 367](#).

NOTE: After a device is prestaged in Connectivity Services Director, the prestaging job is not initiated on the same device again. When a device notification is received by the application, Connectivity Services Director synchronizes the prestaging database on the UI interfaces. If a mismatch is detected in the UNI status of the interface in Connectivity Services Director database and the UNI status of the interface on the device (caused by the application being down or network accessibility problems), the synchronization of the UNI interface might not occur. In such a case, the synchronization operation occurs when a configuration- commit on the device is done the next time. To manually resolve this discrepancy in the UNI status of the interface, you can unassign the UNI role of the interface, which causes prestaging to perform a synchronization.

RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning All N-PE Devices | 366](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

[Prestaging Rules | 380](#)

Junos Space Layer 2 Services Overview

Junos Space Connectivity Services Director application enables you to provision the following types of services:

- E-Line services across networks that use LDP or BGP for signaling in the network core. These services use directed pseudowire virtual circuits across the network to establish point-to-point virtual private networks (VPNs). The provisioner must specify the addresses of the ingress and egress routers of the virtual circuits.
- Multipoint services across networks that use LDP or BGP signaling in the network core. The Connectivity Services Director application supports multipoint-to-multipoint (full mesh) services and point-to-multipoint (hub and spoke) services.

For details about Juniper Networks Layer 2 technologies, see the *Junos OS VPNs Configuration Guide*.

E-Line services and multipoint services support the following interface types:

- Port-to-port—All traffic is transported across the network.
- 802.1Q (dot1q)—Supports 802.1Q VLAN-tagged network traffic in an E-Line or multipoint Ethernet service. Network traffic is constrained using VLAN IDs.
- Q-in-Q—Supports double-tagged traffic in an E-Line or multipoint Ethernet service.
- Asymmetric tag depth—Allows port-based, 802.1Q and Q-in-Q interfaces for UNIs to coexist in a service.
- ATM—Supports the transmission of ATM cells through point-to-point connections in an ATM network.
- TDM—Supports configuring SAToP or CESoPSN physical encapsulation of packets for transmission over the TDM interface.

[Table 6 on page 57](#) provides a guide to selecting the appropriate type of Layer 2 service for a specific customer need.

Table 6: Selecting a Layer 2 Service

Customer Requirement	Provision This Service
Send all VLAN traffic from one site to other sites in the service.	Layer 2 VPN port-to-port service OR Layer 2 VPN Q-in-Q to Q-in-Q service for all traffic
Send traffic associated with one specific VLAN from one site to other sites in the service.	Layer 2 VPN 802.1Q-to-802.1Q service
Send traffic associated with a range of VLANs from one site to other sites in the service.	Layer 2 VPN Q-in-Q to Q-in-Q service for a range of VLANs

Juniper Networks refers to this kind of connection as a *Layer 2 circuit*. For details about Layer 2 circuits, see the *Junos OS VPNs Configuration Guide*.

The Connectivity Services Director application enables you to provision a range of services from the following service families for your enterprise customers:

- [E-Line Services on page 58](#)
- [E-LAN Services on page 61](#)

E-Line Services

IN THIS SECTION

- [Port-to-Port Service | 58](#)
- [Single VLAN Service Using 802.1Q Interfaces | 59](#)
- [All Traffic Service Using Q-in-Q Interface | 59](#)
- [Range of VLANs Service with Q-in-Q Interfaces | 60](#)

E-Line services provide transport and encapsulation of Layer 2 Ethernet circuits between two endpoints. To provision an E-Line service, the provisioner must select the network provider-edge (N-PE) routers that will be the service endpoints and configure the user-network interfaces (UNIs) at those endpoints. The Junos Space software automates the end-to-end provisioning of the pseudowire by establishing a virtual circuit between the N-PE routers using a unique virtual circuit ID (VC ID).

The IETF refers to these connections in RFC 4905, *Encapsulation Methods for Transport of Layer 2 Frames over MPLS Networks as emulated virtual circuits*, and in RFC 4447, *Pseudowire Setup and Maintenance Using the Label Distribution Protocol (LDP) as pseudowire emulation* (see IETF RFC 4447).

The Metro Ethernet Forum (MEF) refers to these connections as *E-Line services*. See *Metro Ethernet Services – A Technical Overview* by Ralph Santitoro.

The Junos Space software enables you to provision the following E-Line service options for your enterprise customers:


Port-to-Port Service

A port-to-port service transports all traffic on a port on a provider edge (N-PE) router across the network to a port of another N-PE router. enterprise customers needs to purchase only a single physical port for all their traffic. However, a single port might cost more than the bandwidth for a single VLAN or selected range of VLANs.

The service provider needs no knowledge of the enterprise customer's VLAN structure, because all the customer's traffic is transported.

[Figure 1 on page 59](#) shows an example in which a port-to-port connection transports all VLAN traffic for an enterprise customer from customer site A to customer site B across the network.

Figure 1: E-Line LDP Connection Transports Traffic




Single VLAN Service Using 802.1Q Interfaces

802.1Q services transport VLAN traffic from one site to another across the network. The selected payload is a single VLAN, so the enterprise customer needs to purchase only the bandwidth necessary to transport that VLAN. To implement this type of service, the service provider must exchange VLAN information with the enterprise customer.

Consider the example shown in [Figure 2 on page 59](#). VLAN 100 might be used for payroll and spans sites A and B. VLAN 200 is used by engineering and spans sites A and C. Payroll and engineering are securely separated by provisioning separate point-to-point connections for each VLAN, each on a separate VCID. Service multiplexing at customer site A allows multiple virtual circuits to share the same port, yet provide secure connections to separate sites.

Figure 2: E-Line Ethernet Services with 802.1Q Interfaces



All Traffic Service Using Q-in-Q Interface


This type of E-Line (LDP) service uses Q-in-Q interfaces and transports all customer traffic from one site to another across the network. The Q-in-Q interface adds a service provider tag to the frame, which isolates the enterprise customer's VLAN tags. The service provider does not need knowledge of the customer's VLAN structure because all traffic is transported to the destination site.

Range of VLANs Service with Q-in-Q Interfaces

This type of E-Line (LDP) service uses Q-in-Q interfaces and carries a range of VLANs across the network. The service provider must establish with the enterprise customer which VLANs are to be transported. The service provider allocates a service provider VLAN ID as a second tag to the selected VLAN ID range, which isolates the traffic on selected VLANs from other traffic.


Figure 3 on page 60 shows an example in which an enterprise customer has six VLANs with VLAN IDs 100, 200, 300, 400, 500, and 600. The service is provisioned to carry only VLANs 100, 200, and 300 by tagging them with the service provider VLAN ID of 2000. VLANs 400, 500, and 600 do not cross the network.

Figure 3: E-Line Service with Q-in-Q Interfaces for Range of VLANs.



You can use separate service VLAN IDs to segregate traffic into secure groups of VLAN IDs. For example, VLANs 100, 200, and 300 might all be part of an enterprise's engineering organization, while VLANs 400, 500, and 600 might exchange information with suppliers. In this example, VLANs 100, 200, and 300 can be double-tagged with service VLAN ID 2000 and get transported only to the remote engineering site, while VLANs 400, 500, and 600 might be tagged with the service VLAN ID of 2001 and get transported only to the supplier's site along a separate pseudowire, as shown in Figure 4 on page 61.

Figure 4: E-Line Service with Q-in-Q Interfaces for Range of VLANs on Separate Service Provider VLANs




E-LAN Services

The Connectivity Services Director application supports E-LAN service, which in turn provides multipoint-to-multipoint services and point-to-multipoint services.

The Metro Ethernet Forum (MEF) refers to these connections as *E-LAN services*. See *Metro Ethernet Services – A Technical Overview* by Ralph Santitoro.

[Figure 5 on page 62](#) shows an example of a multipoint service connecting four customer sites.


Figure 5: Multipoint-to-Multipoint E-LAN Service—Full Mesh



This full mesh design enables direct communication among all PE routers in the service. This topology is efficient for services in which all sites need to communicate with all other sites.

[Figure 6 on page 62](#) shows a point-to-multipoint service with a single hub. The service provides connectivity between the hub router (PE1) and each of the spokes (PE2, PE3, and PE4), but no connectivity exists among the spokes.


Figure 6: Point-to-Multipoint E-LAN Service with Single Hub



This kind of topology is effective for services in which one site needs to communicate with all other sites, but communication among spokes is not required. For example, the hub site might house corporate headquarters, while each of the spoke sites is a region.

Figure 7 on page 63 shows a point-to-multipoint service with two hubs. In this case, all spokes connect to both hubs.

Figure 7: Point-to-Multipoint E-LAN Service with Multiple Hubs



Typical use for dual hub routers is to provide redundancy in case of failure. For example, a data center might be duplicated at customer sites A and B, requiring access to both sites from each spoke for effective redundancy.


For all E-LAN topologies, route targets and route distinguishers designate the multipoint connectivity among the participating endpoints.

Service Autodiscovery

BGP uses autodiscovery to establish connectivity among the N-PE routers quickly and efficiently.

Figure 8 on page 64 shows an example.

Figure 8: Autodiscovery of Service Connectivity




In this example, device N-PE-1 is the first to be added to the service. It exports route target 100 and imports route target 100. When N-PE-2 is added to the service, it also exports and imports route target 100. The Junos OS on the device automatically makes the association and creates the connectivity path between the two devices. Similarly, when you add a third device to the service, so long as it exports/imports the same route targets as the N-PE devices in the existing service, the new device is added to the service and connectivity with both existing N-PE devices is established automatically.

For a point-to-multipoint service, route target/route distinguisher pairs have different values for import and export. These values for import and export are the same for all spokes, but reversed for the hub, thereby enabling communication between each spoke and the hub, but not among spokes.

[Figure 9 on page 64](#) shows an example. In this case, device N-PE-1 (the hub router) exports route target:route distinguisher pair 100:6 and imports 100:5. Each spoke imports 100:6 and exports 100:5 enabling communication with the hub, but not with each other.

Figure 9: Autodiscovery in a Point-to-Multipoint Service



VPLS and Normalization

Similar to E-Line services, the UNIs of E-LAN services can be port-to-port, 802.1Q, Q-in-Q, or asymmetric tag depth. The type of VLAN mapping—or normalization—is specified in the service definition. VLAN normalization applies only to MX Series devices.

Normalization supports automatic mapping of VLANs. Normalization performs operations on VLAN tags to achieve the desired translation. The Connectivity Services Director application supports the following forms of VLAN normalization:

- **Normalize to VLAN all**—The customer VLAN ID is preserved across the network. That is, the broadcast domain includes the interfaces that have the same VLAN ID across the E-LAN service. For double-tagged packets (Q-in-Q interfaces), a pop operation at ingress strips the service VLAN ID from the packet. A corresponding push operation at egress inserts the service VLAN ID known at the local site. Hence, the service VLAN ID at egress does not have to match the service VLAN ID at ingress.

For single-tagged packets (802.1Q interfaces), “Normalize to VLAN all” has no effect, because the packet has no service VLAN ID to pop or push.

- **Normalize to VLAN none**—The customer VLAN ID is not preserved across the network. The broadcast domain includes all VLANs at any site provisioned in the service. For single-tagged packets (802.1Q interfaces), a pop operation at ingress removes the customer VLAN ID from the packet. A corresponding push operation at egress adds a local customer VLAN ID.

For double-tagged packets (Q-in-Q interfaces), both customer VLAN ID and service VLAN ID are popped from the packet at ingress and pushed at egress.

- **Normalize to Dot1q tag**—The VLAN tag is preserved across the network. The broadcast domain includes all VLANs at any site provisioned in the service. For information about how frames are translated to provide the required VLAN tags for interfaces with different tag heights, see the section “VLAN Mapping for E-LAN Services” in [“Understanding VLAN Manipulation \(Normalization and VLAN Mapping\) on Ethernet Services” on page 92](#).
- **Normalize to QinQ tags**—The inner VLAN tag and outer VLAN tag are preserved across the network. The broadcast domain includes all VLANs at any site provisioned in the service. For information about how frames are translated to provide the required VLAN tags for interfaces with different tag heights, see the section “VLAN Mapping for E-LAN Services” in [“Understanding VLAN Manipulation \(Normalization and VLAN Mapping\) on Ethernet Services” on page 92](#).

Normalization works well with automatically assigned VLAN IDs, because the service provider does not need to specify the VLAN IDs that are popped and pushed. Without normalization, the service provider must specify explicitly the customer VLAN ID and the service VLAN ID.

- Normalization not required—If normalization is not used, then all customer VLAN IDs and all service VLAN IDs must match to be part of the same broadcast domain.

NOTE: For information on the VLAN normalization requirements for each Ethernet interface option, see the table in the topic [“Specifying Connectivity Information When Signaling Is BGP”](#) on page 672

RELATED DOCUMENTATION

[Junos Space Layer 3 Services Overview | 66](#)

[Provisioning Process Overview | 68](#)

[Seamless MPLS Support in Junos Space Overview | 72](#)

[Service Attributes Overview | 74](#)

Junos Space Layer 3 Services Overview

IN THIS SECTION

- [Overview | 67](#)
- [Layer 3 VPN Platform Support | 67](#)
- [Layer 3 VPN Attributes | 67](#)
- [Device Configuration for a Layer 3 VPN | 68](#)

To configure Layer 3 virtual private network (VPN) functionality, you must enable VPN support on the provider edge (PE) router. You must also configure any provider (P) routers that service the VPN, and you must configure the customer edge (CE) routers so that their routes are distributed into the VPN.

This topic covers:

Overview

RFC 4364 VPNs are also known as BGP/MPLS VPNs because BGP is used to distribute VPN routing information across the provider's backbone, and MPLS is used to forward VPN traffic across the backbone to remote VPN sites.

Customer networks, because they are private, can use either public addresses or private addresses, as defined in RFC 1918, Address Allocation for Private Internets. When customer networks that use private addresses connect to the public Internet infrastructure, the private addresses might overlap with the same private addresses used by other network users. MPLS/BGP VPNs solve this problem by adding a VPN identifier prefix to each address from a particular VPN site, thereby creating an address that is unique both within the VPN and within the public Internet. In addition, each VPN has its own VPN-specific routing table that contains the routing information for that VPN only.

Junos Space Connectivity Services Director application enables you to provision IP full mesh services.

For more information about Layer 3 VPNs, see the *Junos Software VPNs Configuration Guide*.

Layer 3 VPN Platform Support

Layer 3 VPNs are supported on most combinations of Juniper Networks routing platforms and PICs that are capable of running the Junos Software.

MX Series routers configured in Ethernet services mode can support some of the Junos OS Layer 3 VPN features. For Layer 3 VPNs, Ethernet services mode supports configuring a loopback interface for a VPN routing and forwarding (VRF) instance. You can configure up to two VRF instances in Ethernet services mode. Each VRF instance can handle up to 10,000 routes. The **ping mpls l3vpn** operational mode command is also supported.

Layer 3 VPN Attributes

Connectivity Services Director application supports the following Layer 3 VPN attributes. For more information, see the *Junos OS VPNs Configuration* technical documentation.

- **Target VPN**—Identifies a set of sites with a VPN to which a PE router distributes routes. This attribute is also called the *route target*. A PE egress router uses the route target to determine whether a received route is destined for a VPN that the router services.
- **Route distinguisher**—a 6-byte number that you can specify using one of the following formats:
 - *as-number:number*, where *as-number* is an AS number (a 2-byte value) and *number* is any 4-byte value. The AS number can be in the range 1 through 65,535. We recommend that you use an Internet Assigned Numbers Authority (IANA)-assigned, nonprivate AS number, preferably the Internet service provider's (ISP's) own or the customer's own AS number.

- *ip-address:number*, where *ip-address* is an IP address (a 4-byte value) and *number* is any 2-byte value. The IP address can be any globally unique unicast address. We recommend that you use the address that you configure in the router-id statement, which is a nonprivate address in your assigned prefix range.

Device Configuration for a Layer 3 VPN

To implement Layer 3 VPNs in the JUNOS Software, you configure one routing instance for each VPN. You configure the routing instances on PE routers only. Each VPN routing instance consists of the following components:

- VRF table—On each PE router, you configure one VRF table for each VPN.
- Set of interfaces that use the VRF table—The logical interface to each directly connected CE router must be associated with a VRF table. You can associate more than one interface with the same VRF table if more than one CE router in a VPN is directly connected to the PE router.
- Policy rules—These control the import of routes into and the export of routes from the VRF table.
- One or more routing protocols that install routes from CE routers into the VRF table—You can use the BGP and OSPF routing protocols and static routes.

RELATED DOCUMENTATION

[Junos Space Layer 2 Services Overview | 56](#)

[Provisioning Process Overview | 68](#)

[Seamless MPLS Support in Junos Space Overview | 72](#)

[Service Attributes Overview | 74](#)

Provisioning Process Overview

Provisioning is a multistep process that makes services available to customers. Dividing the provisioning process into distinct activities allows you to use role-based access control to configure which type of user is allowed to perform each step. Complete the following tasks to provision a service:

1. Discover Devices
2. Discover Roles
3. Assign NPE Role
4. Review Predefined Service Definitions or Create Service Definition

5. Create Customer
6. Create Service Order
7. Deploy Service Order
8. Perform Configuration Audit
9. Perform Functional Audit
- 10.(Optional) View Provisioned Services
- 11.(Optional) Decommission Provisioned Services

Steps in the sequence are often performed by users with different levels of privilege. The Junos Space software provides predefined administrator roles that provide the necessary privilege for each step in the sequence:

- The Device Manager role allows an administrator to discover devices (step 1).
- The Service Manager role allows an administrator to perform device prestaging actions including discovering and assigning device roles (steps 2 and 3).
- The Service Designer roles allows an administrator to create and publish a service definition (step 4).
- The Service Activator (less privileged) role allows an administrator to perform provisioning tasks including creating and managing customers, service orders, and services (steps 5 through 9).

For details about predefined administrator roles, see *Predefined Roles Overview* in the *Junos Space Network Application Platform User Guide*.

Network Operator Tasks—Provisioning Prerequisites

Network operators are usually responsible for performing the prerequisite tasks before the following service designer or service provisioner can perform their tasks:

- Discovering devices
- Launching role discovery
- Assigning N-PE roles

Discovering devices is the process for bringing your network devices under Junos Space management. Network operators who are assigned the Device Manager role can perform this task. See *Device Discovery Overview* in the *Junos Space Network Application Platform User Guide* for more information about discovering devices.

Launching role discovery and assigning N-PE roles are collectively known as prestaging tasks. Prestaging finds the N-PE devices among those already under Junos Space management and assigns appropriate MPLS N-PE roles to these devices and user-to-network interface (UNI) roles to their interfaces. Once these roles are established, the devices are ready for provisioning. Users who are assigned the Service

Manager role can perform device role discovery and role assignment. See *Prestaging Devices Overview* for more information about prestaging devices.

Service Designer Tasks

The service designer is responsible for the creation and management of the service definitions that the service provisioner uses as the basis for creating a service order.

A service definition specifies the attributes that are common among a group of service orders that have similar service requirements. For example, a service definition might specify a port-to-port service, whether the associated VCID should be assigned automatically from a predefined pool or specified by the user, and what range of bandwidths can be assigned in the service order. The service definition also defines which attributes of the service can be edited in the service order.

The Junos Space Connectivity Services Director product provides several standard service definitions which support most needs. If the standard service definitions do not support your needs, then the service designer needs to create new, customized service definitions.

Users who are assigned the Service Designer role can create and manage service definitions.

Service Provisioner Tasks

Service provisioner tasks include the following:

- Creating the customer.
- Creating the service order.
- Deploying the service.
- Performing a configuration audit.
- Performing a functional audit.

A service order is an instance of the service definition that completes the definition for a specific customer's use. The service order always specifies the customer and the endpoints that link the customer sites through the MPLS network. For each endpoint, the service provisioner specifies the N-PE device and the UNI on that device that connects the customer site to the N-PE device. The service order can also specify any additional attributes that are configured in the service definition as editable in the service order. These attributes might include the VCID, MTU for the UNI, MTU for the connection across the network, VLAN-ID, and bandwidth.

Deployment of a service order pushes a service to the network devices. Before deployment completes, a series of pre-validation checks takes place. If the pre-validation checks indicate that the service is valid, the deployment proceeds. If the pre-validation checks indicate an invalid service, the service provisioner must re-create the service order correctly before trying again to deploy it.

After the service is deployed, a functional audit establishes whether the service is up or down. If the functional audit reports that the service is up, the customer can begin using the service.

Once the service is active, the service provisioner can monitor the health of the service by running a functional audit or a configuration audit.

Users assigned the Service Activator role can perform these service provisioning tasks.

RELATED DOCUMENTATION

Discovering Devices section in [Understanding Build Mode in Views Other than Service View of Connectivity Services Director](#) | 181

[Junos Space Layer 2 Services Overview](#) | 56

[Junos Space Layer 3 Services Overview](#) | 66

[Seamless MPLS Support in Junos Space Overview](#) | 72

[Service Attributes Overview](#) | 74

Seamless MPLS Support in Junos Space Overview

MPLS-based Layer 2 services are growing in demand among enterprise and service providers, creating new challenges related to interoperability between Layer 2 and Layer 3 services for service providers who want to provide end-to-end value-added services. Service providers are able to expand service offerings, support multiple Layer 2 services and protocols at the same time, and to expand geographically by stitching different Layer 2 services to one another and to Layer 3 services, moving toward a seamless MPLS environment..

Interconnecting a Layer 2 VPLS network with a Layer 3 network enables the sharing of a service provider's core network infrastructure between IP and Layer 2 services, reducing the cost of providing those services. A Layer 2 MPLS circuit allows service providers to create a Layer 2 circuit service over an existing IP and MPLS backbone.


Service providers do not have to invest in separate Layer 2 equipment to provide Layer 2 services. A service provider can configure a provider edge router to run any Layer 3 protocol in addition to the Layer 2 protocols. Customers who prefer to maintain control over most of the administration of their own networks want Layer 2 circuit connections with their service provider instead of a Layer 3 VPN connection.

Using MPLS pseudowires makes it possible to encapsulate Layer 2 packets and extend Layer 2 services into Layer 3 networks. Junos Space supports the trend toward accomplishing Seamless MPLS with these two features:

- VPLS Access Into Layer 3 Networks
- Pseudowire Access Into a Layer 3 VPN

VPLS Access Into Layer 3 Networks


Integrated Routing and Bridging (IRB) provides simultaneous support for Layer 2 bridging and Layer 3 routing within the same bridge domain, and as well as in the same routing instance. If the IRB interface configured as a Layer 3 interface is being used in a routing instance, that routing instance will specifically declare it as routing-interface rather than regular VPLS interface (which acts like the interface on a specific VPLS Site). This feature requires a normalized VLAN (vlan-id=xxx which is the same as the unit name on which the inet4 address is specified)



Junos Space uses the two peer subinterfaces of the IRB to create the link between an existing VLAN and the Layer 3 network. An extra VPLS node is required to support the IRB interface which allows the rest of the VPLS nodes to be able to access all Layer 3 networks reachable through that interface. Providing the VPLS access into Layer 3 networks enhances basic VPLS services. Because this feature requires a normalized VLAN, it is available only on the Juniper Networks MX 3D Router series.

Pseudowire Access Into Layer 3 VPNs

While technically not a VPLS feature, Junos Space uses pseudowires, also known as pseudowire stitching, to link Layer 2 services together and to Layer 3 services. Pseudowire access into the L3 VPN enhances the standard E-Line LDP and E-Line services. The link into the L3VPN network can be port-based or VLAN-based. At least one node in the peer must be a logical tunnel (LT) interface. The peer must appear in the L3VPN configuration.



In Junos, this Layer 2 access into Layer 3 VPNs is accomplished by using a tunnel PIC to create a peer link between pseudowire and a Layer 3 network interface.

RELATED DOCUMENTATION

[Creating a Service Definition for VPLS Access into Layer 3 Networks | 760](#)

[Creating a Service Order for VPLS Access into Layer 3 Networks | 985](#)

Service Attributes Overview

A service is defined by a set of attributes. Some attributes are common to all service instances created from one service definition, and are therefore set during service definition time. Other attributes are specific to a service instance and must be set in the service order. Some attributes can be set either in the service definition or in the service order; in such cases it is up to the service designer to determine when the attribute will be set.

The Connectivity Services Director user interface groups service attributes as follows:

- **General attributes**—General information about the service, such as whether the service is E-Line, multipoint-to-multipoint E-LAN (full mesh VPLS), or point-to-multipoint E-LAN, what signaling mechanism is used in the network core, whether quality of service (QoS) is enabled on the service, and who the enterprise customer is who uses the service.
- **Connectivity settings**—Information about connectivity among customer sites through the network. For E-Line services in a network with LDP switching in the network core, these settings include the VC ID. For multipoint Ethernet (or E-LAN) services, these settings include the route target and route distinguisher.
- **Advanced settings**—Information about advanced connectivity among customer sites through the network. For multipoint Ethernet (or E-LAN) services, these settings include tunnel services, local switching, fast-reroute-priority, label block size, and connection type.
- **UNI settings**—Information about each customer site, including the N-PE device and interface the site uses to connect to the network, the encapsulation method used (physical and logical), MTU, customer VLAN ID and range, service VLAN ID, bandwidth limiting, and so on.

General Attributes

IN THIS SECTION

- [Service Type | 75](#)
- [Signaling | 75](#)
- [Comments | 75](#)
- [Service Template | 75](#)
- [Interface Type | 75](#)

- [Enabling Additional Features | 76](#)
- [Customer | 76](#)
- [Enable QoS | 76](#)

The following general attributes are defined for each service:

Service Type

The **Service type** attribute specifies a network topology to include in the service definition.

The service type is the first attribute to be determined during service definition. It can be one of the following values:

- E-Line—Virtual circuit between two customer sites in the network core.
- E-LAN (Multipoint-to-multipoint) —Virtual private LAN service (VPLS) among multiple customer sites in the network core to provide full mesh connectivity.
- E-LAN (Point-to-multipoint) —VPLS among multiple customer sites in the network core to provide connectivity between a hub site and multiple spoke sites.
- IP —Supports full mesh and hub-spoke connectivity through different routing protocols such as BGP, OSPF, or static protocols, or a combination of these.

Signaling

The **Signaling** attribute specifies the protocol that controls signaling in the network core. You can select BGP or LDP.

Comments

The **Comments** attribute .

Service Template

The **Service Template** attribute .

Interface Type

The **Interface type** attribute . You can specify one of the following:

- Ethernet
- TDM
- ATM

Enabling Additional Features

In addition to the interface type, depending on the **Service type** topology and **Signaling** you specify, you can enable the following features for a service:

- **Static pseudowire**—For networks that do not support LDP or do not have LDP enabled. You define pseudowires by configuring static values for the inbound and outbound labels of the connection.
- **Enable PW access to L3 VPN networks**
- **Enable L3 Access**
- **Enable Multihoming**
- **Enable PW Extension**
- **Enable PW Resiliency**
- **Decouple Service Status from Port Status**—Isolates events related to an interface in the OpenNMS database. Only traps related to pseudowires are monitored.

Customer

This attribute specifies the enterprise customer who will use the service instance. This attribute is always specified in the service order.

Enable QoS

This attribute specifies whether QoS is enabled on the service to divide traffic into classes and offer various levels of throughput and packet loss when congestion occurs. When you enable QoS in the service definition, the QoS Settings box appears when you configure the service order.

NOTE: When you enable QoS in the service definition, bandwidth settings are also configurable in the service order.

NOTE: A QoS profile that specifies a level-three scheduler is not supported on port-to-port services. Only non-hierarchical port scheduler profiles are supported.

UNI Settings

IN THIS SECTION

- [Ethernet Options | 77](#)
- [Interface | 77](#)

- MTU | 78
- Customer Traffic Type | 78
- Customer VLAN ID | 78
- Service VLAN ID and VLAN ID Range | 78
- Physical Encapsulation | 79
- Logical Encapsulation | 79
- Rate Limiting and Bandwidth | 80
- UNI Settings for TDM Interfaces | 80
- UNI Settings for ATM Interfaces | 81

The following attributes are defined for the service endpoints or customer sites that are connected by the service:

Ethernet Options

This attribute identifies the interface type at the endpoint by defining the level of packet tagging for the UNI. It can have the following values:

- asymmetric tag depth

Allows port-based, 802.1Q and Q-in-Q interfaces for UNIs to coexist in a service.

- port-port

Transfers all data from the UNI to the other end of the LSP trunk.

- dot1q

An 802.1Q interface that tags each packet with a VLAN ID, thus allowing a specific VLAN to traverse the network.

- qinq

A Q-in-Q interface that double tags each frame. The inner tag is added by the service provider. The service provider can use this inner tag to differentiate among services. For example, you can configure VLANs for a customer's intranet with a different inner tag from VLANs used for working with providers or partners.

Interface

Specifies the physical interface on the N-PE device that connects the customer site or CE device to the N-PE device.

MTU

The maximum transmission unit (MTU) represents the largest frame size, in bytes, that passes through the UNI. MTU is configurable.

NOTE: This value is distinct from the MTU assigned to the connectivity in the network core.

Customer Traffic Type

This attribute places restrictions on the traffic that can be transported across the network by the associated service. It can have the following values:

- Transport single VLAN

Restricts the associated service to transporting just one VLAN across the network. You can use this option with 802.1Q and Q-in-Q interface types.

- Transport VLAN range

Allows the associated service to transport a range of VLANs across the network. You can use this option with 802.1Q and Q-in-Q interface types.

- Transport all traffic

Allows the associated service to transport all traffic across the network. You can use this option with Q-in-Q interface types only.

The traffic type attribute is not applicable to port-to-port services. Port-to-port services always transport all traffic.

- Transport VLAN list

Allows the associated service to transport a list of VLANs across the network. You can use this option with dot1q, qinq, and asymmetric tag depth VLAN tagging types.

Customer VLAN ID

Specifies a VLAN ID that is attached to each packet to permit VLANs to be shared across the network.

This attribute can be used only with 802.1Q and Q-in-Q interface types.

Service VLAN ID and VLAN ID Range

The service VLAN ID (VLAN ID) specifies a second level of tagging to segregate groups of VLANs.

The VLAN range specifies a range of VLANs to be transported across the network by associating them with a service VLAN ID.

These options are configurable only for Q-in-Q interfaces.

Physical Encapsulation

Specifies the physical link-layer encapsulation type.

- **flexible-ethernet-services**—Offers the most flexibility, depending on the characteristics of the N-PE device and its line modules.

For Gigabit Ethernet IQ interfaces and Gigabit Ethernet PICs with small form-factor pluggable transceivers (SFPs) only, use flexible Ethernet services encapsulation when you want to configure multiple per-unit Ethernet encapsulations. This encapsulation type allows you to configure any combination of route, TCC, CCC, and VPLS encapsulations on a single physical port. Aggregated Ethernet bundles cannot use this encapsulation type. If you configure flexible Ethernet services encapsulation on the physical interface, VLAN IDs from 1 through 511 are no longer reserved for normal VLANs.

In the Junos Space Connectivity Services Director product, you can use this encapsulation type with 802.1Q interfaces and Q-in-Q interfaces in E-Line services and in multipoint Ethernet services.

- **vlan-ccc**—You can use Ethernet VLAN encapsulation on CCC interfaces. This option restricts the range of available VLAN IDs to 512 through 4094. VLAN IDs 1 through 511 are reserved for internal use.

In the Junos Space Connectivity Services Director product, you can use this encapsulation type with 802.1Q interfaces and Q-in-Q interfaces in E-Line services.

- **extended-vlan-ccc**—Use extended VLAN encapsulation on CCC interfaces with Gigabit Ethernet interfaces that must accept packets carrying 802.1Q values.

In the Junos Space Connectivity Services Director product, you can use this encapsulation type with 802.1Q interfaces and Q-in-Q interfaces in E-Line services.

- **ethernet-vpls**—Use Ethernet VPLS encapsulation on Ethernet interfaces that have VPLS enabled and that must accept packets carrying standard TPID values.

In the Junos Space Connectivity Services Director product, this encapsulation is used only for dedicated port interface types in multipoint Ethernet services.

Logical Encapsulation

Specifies the logical link-layer encapsulation type. Logical encapsulation with 802.1Q interfaces allows you to route multiple services through the same physical interface.

- **vlan-ccc**—Use Ethernet virtual LAN (VLAN) encapsulation on CCC interfaces. When you use this encapsulation type, you can configure the family ccc only.
- **extended-vlan-ccc**—Use extended VLAN encapsulation on CCC interfaces with Gigabit Ethernet interfaces that must accept packets carrying 802.1Q values.
- **vlan-vpls**—Use VLAN VPLS encapsulation on Ethernet interfaces with VLAN tagging and VPLS enabled. Interfaces with VLAN VPLS encapsulation accept packets carrying standard Tag Protocol (TPID) values only.

[Table 7 on page 80](#) defines the logical encapsulation types that are valid for each physical encapsulation type in an E-Line service.

Table 7: Physical and Logical Encapsulation Compatibilities in E-Line Services

Physical Encapsulation	Logical Encapsulation	Valid Interface Types
flexible-ethernet-services	vlan-ccc	802.1Q and Q-in-Q
vlan-ccc	vlan-ccc	802.1Q and Q-in-Q
extended-vlan-ccc	extended-vlan-ccc	802.1Q and Q-in-Q
ethernet-ccc	not applicable	dedicated port

Table 8 on page 80 defines the logical encapsulation types that are valid for each physical encapsulation type in multipoint Ethernet services.

Table 8: Physical and Logical Encapsulation Compatibilities in Multipoint E-LAN Services

Physical Encapsulation	Logical Encapsulation	Valid Interface Types
flexible-ethernet-services	vlan-vpls	802.1Q and Q-in-Q
ethernet-vpls	not applicable	dedicated port

Rate Limiting and Bandwidth

Rate limiting allows you to specify the maximum bandwidth permitted for a service.

The burst rate is automatically calculated as two times the MTU of the UNI.

NOTE: When a service is QoS enabled, you can also configure rate limiting and bandwidth in the service.

UNI Settings for TDM Interfaces

The following TDM options are configurable for TDM interfaces:

- **Physical IF encapsulation**—satop or cesopsn
- **Jitter buffer**
M Series: 1 through 340
- **Idle pattern**—0 through 255
- **Excessive packet loss rate**—1 through 100%
- **Payload size**

M Series: 64 through 1024

UNI Settings for ATM Interfaces

The following ATM options are configurable for ATM interfaces:

- **Physical IF encapsulation**—The type of encapsulation to apply to the interface. Use atm-ccc-cell-relay for ATM cell relay encapsulation. Use atm-ccc-cell-mux for ATM VC for CCC.
- **VPI selection**—The virtual path identifier
- **VCI selection**—This integer uniquely identifies the virtual circuit that the service uses.
- **Cell bundle size**—Cell bundle size can be 1 through 34.

Connectivity Settings

IN THIS SECTION

- [Virtual Private LAN Service Identifier \(VPLS ID\) | 81](#)
- [Auto Discovery | 81](#)
- [Virtual Circuit Identifier \(VCID\) \(E-Line Services Only\) | 81](#)
- [Route Targets and Route Distinguishers | 82](#)
- [Normalized VLAN \(Multipoint Services Only\) | 82](#)
- [MAC Learning | 83](#)

The following attributes are defined for the connectivity among UNI endpoints across the network:

Virtual Private LAN Service Identifier (VPLS ID)

This VPLS ID is available if the signaling is LDP and the Auto Discovery check box is disabled. The VPLS ID can be selected automatically or manually. The VPLS ID identifies the virtual circuit identifier used for the VPLS routing instance.

Auto Discovery

The Auto Discovery check box is available only if the signaling is LDP. If you enable Auto Discovery, the attributes Route target, Route distinguisher, and VPN ID appear and are provisionable.

Virtual Circuit Identifier (VCID) (E-Line Services Only)

This unique identifier can be assigned automatically from a pool of VCIDs or can be manually specified. It uniquely identifies a point-to-point virtual circuit through the network and is provided for all switched E-Line services.

Route Targets and Route Distinguishers

Route targets and route distinguishers are applied to E-Line services in which BGP controls the connections in the network core.

Route targets and route distinguishers are always automatically generated by the Junos Space software for multipoint E-LAN services. Route targets and route distinguishers designate the multipoint connectivity among the participating endpoints of a multipoint service. They identify the members of the virtual LAN.

Normalized VLAN (Multipoint Services Only)

Similar to E-Line services, the UNIs of E-LAN services can be port-to-port, 802.1Q, or Q-in-Q. The type of VLAN mapping—or normalization—is specified in the service definition. VLAN normalization applies only to MX Series devices.

Normalization supports automatic mapping of VLANs and performs operations on VLAN tags to achieve the desired translation. The Connectivity Services Director application supports the following forms of VLAN normalization:

- **Normalize to VLAN all**—The customer VLAN ID is preserved across the network. That is, the broadcast domain includes the interfaces that have the same VLAN ID across the E-LAN service. For double-tagged packets (Q-in-Q interfaces), a pop operation at ingress strips the service VLAN ID from the packet. A corresponding push operation at egress inserts the service VLAN ID known at the local site. Hence, the service VLAN ID at egress does not have to match the service VLAN ID at ingress.

For single-tagged packets (802.1Q interfaces), “Normalize to VLAN All” has no effect, because the packet has no service VLAN ID to pop or push.

- **Normalize to VLAN none**—The customer VLAN ID is not preserved across the network. The broadcast domain includes all VLANs at any site provisioned in the service. For single-tagged packets (802.1Q interfaces), a pop operation at ingress removes the customer VLAN ID from the packet. A corresponding push operation at egress adds a local customer VLAN ID.

For double-tagged packets (Q-in-Q interfaces), both customer VLAN ID and service VLAN ID are popped from the packet at ingress and pushed at egress.

- **Normalize to Dot1q tag**—The VLAN tag is preserved across the network. The broadcast domain includes all VLANs at any site provisioned in the service. For information about how frames are translated to provide the required VLAN tags for interfaces with different tag heights, see the section “VLAN Mapping for E-LAN Services” in *Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services*.
- **Normalize to QinQ tags**—The inner VLAN tag and outer VLAN tag are preserved across the network. The broadcast domain includes all VLANs at any site provisioned in the service. For information about how frames are translated to provide the required VLAN tags for interfaces with different tag heights, see the section “VLAN Mapping for E-LAN Services” in *Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services*.
- **Normalization not required**—For port-to-port services only. Specifies that normalization is not used.

If normalization is not used, then all customer VLAN IDs and all service VLAN IDs must match to be part of the same broadcast domain. Services with dedicated port interfaces cannot use normalization.

Normalization works well with automatically assigned VLAN IDs, because the service provider does not need to specify the VLAN IDs that are popped and pushed. Without normalization, the service provider must specify explicitly the customer VLAN ID and the service VLAN ID.

NOTE: For a description of how the Connectivity Services Director application manipulates VLANs, see *Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services*.

MAC Learning

You can enable MAC learning for a virtual switch, for a bridge domain, for a specific logical interface in a bridge domain, or for a set of bridge domains associated with a Layer 2 trunk port. MAC learning is enabled by default.

When MAC learning is enabled, you can configure the following settings:

Interface MAC Limit

You can specify the maximum number of media access control (MAC) addresses that can be learned by the VPLS routing instance. You can configure the same limit for all interfaces configured for a routing instance. You can also configure a limit for a specific interface. The default is 1024 addresses. The range is 16 through 65,536 MAC addresses. This option is supported for MX-series routers only.

MAC Statistics

You can enable MAC accounting either for a specific bridge domain, or for a set of bridge domains associated with a Layer 2 trunk port. MAC statistics is disabled by default. This option is supported for MX-series routers only.

MAC Table Size

You can modify the size of the MAC address table for the bridge domain, a set of bridge domains associated with a trunk port, or a virtual switch. The default is 5120 MAC addresses.

Advanced Settings

IN THIS SECTION

- Tunnel Services | 84
- Local Switching | 84
- Fast Reroute Priority | 84

- Label Block Size | 84
- Connectivity Type | 85

The following attributes are defined for advanced connectivity among UNI endpoints across the network:

Tunnel Services

You can enable tunnel services to specify that traffic for particular VPLS routing instances be forwarded to specific virtual tunnel (VT) interfaces, allowing you to load-balance VPLS traffic among all the available VT interfaces on the router.

Tunnel services are disabled by default.

Local Switching

In local switching mode, you can terminate multiple Layer 2 circuit pseudowires at a single VPLS mesh group.

Local switching is disabled by default.

NOTE: In a point-to-multipoint topology, you must enable local switching on the hub router and disable local switching on the spokes.

Fast Reroute Priority

Specify the fast reroute priority for a VPLS routing instance. You can configure high, medium, or low fast reroute priority to prioritize specific VPLS routing instances for faster convergence and traffic restoration. Because the router repairs next hops for high-priority VPLS routing instances first, the traffic traversing a VPLS routing instance configured with high fast reroute priority is restored faster than the traffic for VPLS routing instances configured with medium or low fast reroute priority. The default setting is LOW.

Label Block Size

VPLS MPLS packets have a two-label stack. The outer label is used for normal MPLS forwarding in the service provider's network. If BGP is used to establish VPLS, the inner label is allocated by a PE router as part of a label block. One inner label is needed for each remote VPLS site. Four sizes are supported. We recommend using the default size of 8, unless the network design requires a different size for optimal label usage, to allow the router to support a larger number of VPLS instances.

If you allocate a large number of small label blocks to increase efficiency, you also increase the number of routes in the VPLS domain. This has an impact on the control plane overhead.

Changing the configured label block size causes all existing pseudowires to be deleted. For example, if you configure the label block size to be 4 and then change the size to 8, all existing label blocks of size 4 are deleted, which means that all existing pseudowires are deleted. The new label block of size 8 is created, and new pseudowires are established.

Four label block sizes are supported: 2, 4, 8, and 16. Consider the following scenarios:

- 2—Allocate the label blocks in increments of 2. For a VPLS domain that has only two sites with no future expansion plans.
- 4—Allocate the label blocks in increments of 4.
- 8 (default)—Allocate the label blocks in increments of 8.
- 16—Allocate the label blocks in increments of 16. A label block size of 16 enables you to minimize the number of routes in the VPLS domain. Use this setting only if the number of routes is the most important concern.

Connectivity Type

You can configure the VPLS routing instance to take down or maintain its VPLS connections depending on the status of the interfaces configured for the VPLS routing instance. By default, the VPLS connection is taken down whenever a customer-facing interface configured for the VPLS routing instance fails. This behavior is explicitly configured by specifying the `ce` option. You can alternatively specify the `irb` option to ensure that the VPLS connection remain up so long as an integrated routing and bridging (IRB) interface is configured for the VPLS routing instance.

Node Settings

Nodes refer to the devices or network elements that are used in establishing a network connection for a particular protocol. You can define configuration parameters and attributes that are common and apply to several nodes in your topology in a single, one-step task by selecting such nodes or devices and specifying the common definitions. Some of the settings need to be unique for each node, and in such cases, you can specify or modify such properties individually for each node. After you select the nodes that need to be associated with a service definition or order, you can select the interfaces corresponding to each device to define the interface-specific characteristics or capabilities. Node-wise parameters provide a quick, effective mechanism for applying configurations on devices. You can select one or more devices from the list of displayed devices that are previously configured for management by the Connectivity Services Director database. After you select the devices and add them, they are mapped with the service definition. The following attributes can be configured as node-level settings, depending on the type of service order, such as IP or E-LAN:

Static Routes

Routes that are permanent fixtures in the routing and forwarding tables are often configured as static routes. These routes generally do not change, and often include only one or very few paths to the destination. To create a static route in the routing table, you must, at minimum, define the route as static

and associate a next-hop address with it. The static route in the routing table is inserted into the forwarding table when the next-hop address is reachable. All traffic destined for the static route is transmitted to the next-hop address for transit. You can specify options that define additional information about static routes that is included with the route when it is installed in the routing table. All static options are optional. A router uses static routes in the following scenarios:

NOTE: Although you can configure next-hop tables using service templates, you can configure only next-hop addresses in the service order.

When it does not have a route to a destination that has a better (lower) preference value.

When it cannot determine the route to a destination.

When it is forwarding unroutable packets.

For the destination prefix of the static route, you must specify the destination of the route (in route destination-prefix) in one of the following ways:

network/mask-length, where network is the network portion of the IP address and mask-length is the destination prefix length.

default if this is the default route to the destination. This is equivalent to specifying an IP address of 0.0.0.0/0.

NOTE: IPv4 packets with a destination of 0.0.0.0 (the obsoleted limited broadcast address) and IPv6 packets with a destination of 0::0 are discarded by default. To forward traffic destined to these addresses, you can add a static route to 0.0.0.0/32 for IPv4 or 0::0/128 for IPv6.

For the next-hop portion of the static route, you must configure the IPv4, IPv6, or ISO network address of the next hop or the name of the interface on which to configure an independent metric or preference for a static route.

PIM Settings

Protocol Independent Multicast (PIM) emerged as an algorithm to overcome the limitations of dense-mode protocols such as the Distance Vector Multicast Routing Protocol (DVMRP), which was efficient for dense clusters of multicast receivers, but did not scale well for the larger, sparser, groups encountered on the Internet. The Core Based Trees (CBT) Protocol was intended to support sparse mode as well, but CBT, with its all-powerful core approach, made placement of the core critical, and large conference-type applications (many-to-many) resulted in bottlenecks in the core. PIM was designed to avoid the dense-mode scaling issues of DVMRP and the potential performance issues of CBT at the same time. PIM operates in several modes: bidirectional mode, sparse mode, dense mode, and sparse-dense mode. In sparse-dense mode, some multicast groups are configured as dense mode (flood-and-prune, [S,G] state) and others are

configured as sparse mode (explicit join to rendezvous point [RP], [* ,G] state). To join the shared tree, or rendezvous-point tree (RPT) as it is called in PIM sparse mode, the router must do the following: Determine the IP address of the RP for that group. Determining the address can be as simple as static configuration in the router, or as complex as a set of nested protocols.

- Build the shared tree for that group. The router executes an RPF check on the RP address in its routing table, which produces the interface closest to the RP. The router now detects that multicast packets from this RP for this group need to flow into the router on this RPF interface.
- Send a join message out on this interface using the proper multicast protocol (probably PIM sparse mode) to inform the upstream router that it wants to join the shared tree for that group. This message is a (* ,G) join message because S is not known. Only the RP is known, and the RP is not actually the source of the multicast packets. The router receiving the (* ,G) join message adds the interface on which the message was received to its outgoing interface list (OIL) for the group and also performs an RPF check on the RP address. The upstream router then sends a (* ,G) join message out from the RPF interface toward the source, informing the upstream router that it also wants to join the group.

You can specify the following attributes: PIM mode on the interface. The choice of PIM mode is closely tied to controlling how groups are mapped to PIM modes, as follows: bidirectional-sparse—Use if all multicast groups are operating in bidirectional, sparse, or SSM mode. bidirectional-sparse-dense—Use if all multicast groups, except those that are specified in the dense-groups statement, are operating in bidirectional, sparse, or SSM mode. dense—Use if all multicast groups are operating in dense mode. sparse—Use if all multicast groups are operating in sparse mode or SSM mode. sparse-dense—Use if all multicast groups, except those that are specified in the dense-groups statement, are operating in sparse mode or SSM mode

Name of the interface on which PIM must be enabled. Specify the full interface name, including the physical and logical address components.

Configure the routing device as an actual or potential rendezvous point (RP). A routing device can be an RP for more than one group.

Name of the interface on the device that functions as the RP.

Address ranges for the multicast groups for which the routing device is the RP. By default, a routing device running PIM is eligible to be the RP for all IPv4 or IPv6 groups (224.0.0.0/4 or FF70::/12 to FFF0::/12). The following example limits the groups for which this routing device can be the RP.

MVPN Settings

Multiprotocol BGP-based multicast VPNs (also referred to as next-generation Layer 3 VPN multicast) constitute the next evolution after dual multicast VPNs (draft-rosen) and provide a simpler solution for administrators who want to configure multicast over Layer 3 VPNs. For MBGP MVPNs (also referred to as next-generation Layer 3 multicast VPNs), the default mode of operation supports only intersite shortest-path trees (SPTs) for customer PIM (C-PIM) join messages. It does not support rendezvous-point trees (RPTs) for C-PIM join messages. The default mode of operation provides advantages, but it requires either that the customer rendezvous point (C-RP) be located on a PE router or that the Multicast Source

Discovery Protocol (MSDP) be used between the C-RP and a PE router so that the PE router can learn about active sources advertised by other PE routers. If the default mode is not suitable for your environment, you can configure RPT-SPT mode (also known as shared-tree data distribution), as documented in section 13 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt). RPT-SPT mode supports the native PIM model of transmitting (*,G) messages from the receiver to the RP for intersite shared-tree join messages. This means that the type 6 (*,G) routes get transmitted from one PE router to another. In RPT-SPT mode, the shared-tree multicast routes are advertised from an egress PE router to the upstream router connected to the VPN site with the C-RP. The single-forwarder election is performed for the C-RP rather than for the source. The egress PE router takes the upstream hop to advertise the (*,G) and sends the type 6 route toward the upstream PE router. To send the data on the RPT, either inclusive or selective provider tunnels can be used. After the data starts flowing on the RPT, the last-hop router switches to SPT mode, unless you include the spt-threshold infinity statements in the configuration.

You can specify the following parameters:

- Indicate whether the shared-tree data distribution mode or the shortest path tree only (SPT-only) mode of MVPN must be enabled to learn about active multicast sources using multicast VPN source-active routes. the default mode of operation is shortest path tree only (SPT-only) mode. In SPT-only mode, the active multicast sources are learned through multicast VPN source-active routes. This mode of operation is described in section 14 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt).
- Specify the export and import targets specified specifically for sender sites or receiver sites, or can be borrowed from a configured unicast route target. Note that a sender site export route target is always advertised when security association routes are exported. By default, the VPN routing and forwarding (VRF) import and export route targets (configured either using VRF import and export policies or using the vrf-target statement) are used for importing and exporting routes with the MBGP MVPN network layer reachability information (NLRI). You can use the export-target and import-target options to override the default VRF import and export route targets.
- Specify the export target to enable you to override the Layer 3 VPN import and export route targets used for importing and exporting routes for the MBGP MVPN network layer reachability information (NLRI).
- Specify the target value when importing sender and receiver site routes.
- Specify a unicast target community as the import target while importing sender and receiver site routes.
- Specify if you want to enable automatic selection of an export target if a configuration is not provided. An imported automatic discovery route is treated as belonging to both the sender site set and the receiver site set.
- Specify the export and import target community names.
- Specify the provider tunnel name to configure virtual private LAN service (VPLS) flooding of unknown unicast, broadcast, and multicast traffic using point-to-multipoint LSPs. Also configure point-to-multipoint LSPs for MBGP MVPNs.

- Specify the site type of the MBGP MVPN. An MBGP MVPN defines two types of site sets, a sender site set and a receiver.
- Configure the upstream multicast hop (UMH) to denote a router to use the unicast route preference to determine the single forwarder election.

MAC Settings

You can specify the following attributes related to the MAC application of a node:

Enable or disable MAC learning for all logical interfaces in a specified bridge domain, or for a specific logical interface in a bridge domain. Disabling dynamic MAC learning prevents the specified interfaces from learning source MAC addresses. A limit on the number of MAC addresses learned from a specific bridge domain or from a specific logical interface that belongs to a bridge domain. For an access port, the default limit on the maximum number of MAC addresses that can be learned on an access port is 1024. For a trunk port, the default limit on the maximum number of MAC addresses that can be learned on a trunk port is 8192.

Enable or disable packet accounting either for a router or switch as a whole or for a specific VLAN. After you enable packet accounting, the Junos OS maintains packet counters for each MAC address learned. By default, MAC accounting is disabled. Size of the MAC address table for each VLAN. The default table size is 5120 addresses. The minimum you can configure is 16 addresses, and the maximum is 1,048,575 addresses. If the MAC table limit is reached, new addresses can no longer be added to the table. Unused MAC addresses are removed from the MAC address table automatically. This frees space in the table, allowing new entries to be added.

Topology Settings

Automatically assign a route distinguisher to the routing instance. Alternatively, specify the route distinguisher manually by specifying an identifier attached to a route, enabling you to distinguish to which VPN or VPLS the route belongs. Each routing instance must have a unique route distinguisher associated with it. The route distinguisher is used to place bounds around a VPN so that the same IP address prefixes can be used in different VPNs without having them overlap.

RELATED DOCUMENTATION

[Junos Space Layer 2 Services Overview | 56](#)

[Junos Space Layer 3 Services Overview | 66](#)

[Provisioning Process Overview | 68](#)

[Seamless MPLS Support in Junos Space Overview | 72](#)


Service Order States and Service States Overview

Service provisioners create service orders which are requests to provision a service, validate a service, or decommission a service. The service order for provisioning a service defines all the service attributes.

Service Order States

Before a service order can affect a service, it must transition through several states as shown in [Figure 10 on page 90](#).

Figure 10: Service Order States and State Transitions



When the service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment, the service order is in the Draft state (also, formerly, called Requested state).

After the service provisioner has scheduled the service order for deployment, the service order transitions to the Scheduled state. If the service provisioner schedules the service order for immediate deployment, then the service order will be in the Scheduled state only briefly. However, if the service provisioner has scheduled a later deployment, the service order could be in this state for several hours or days.

When a scheduled service order reaches its time for deployment, it transitions to the transitory In Progress state. From this state, the Junos Space software attempts to deploy the service. Successful deployment transitions the service order to the Completed state.

If the Junos Space software cannot deploy the service because of invalid information in the service order itself, the service order enters the Invalid state. The service provisioner must resolve the issues that cause the failure before re-creating the service order and rescheduling it for deployment.

If the device is down or the Junos Space software is unable to push the service configuration to the device, the service order transitions to the Failed Deploy state. A network operator might need to resolve the problem before the service provisioner reschedules the service order.

After you disable a service order to deactivate the configuration settings on devices mapped to the service, you might require the service settings to be reenabled after you have modified the service parameters, either directly on the device or using the Connectivity Services Director application. In such a case, you can use the reactivation functionality to revive and activate the service properties on devices. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deactivated state. By disabling a service, the traffic processing for the traversed packets is impacted.

In certain network topologies, you might require a service-related settings to be disabled for a certain period to perform troubleshooting or modification to the traffic-handling method, and you might want to reactivate a disabled service later when you have completed network maintenance and analysis work. In such a case, it might be beneficial to use the deactivation functionality for a service order. When you disable a service order, the configuration attributes associated with such a service order are deactivated and commented out in the device settings. The deactivated service is propagated to the devices associated with the service order. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deployed or Re-Activated state.

When you cancel a job, the service order may not fail, but changes the service order state to **Scheduled**. When the job state is **In Progress** and until the device responds, the service order state is **Scheduled**. When the job is **Cancelled**, the job state becomes **Cancelled** and the service order state is **Scheduled**. As a result, the service order cannot be deleted or edited. However, you can move the service order state to **Draft** by right-clicking any service order or by clicking **Actions** at the header of the grid and selecting **Cancel Order** option. The **Cancel Order** option is enabled or disabled, depending on the state of the service order. This option is enabled only when the service order state is **Scheduled** and the job state is **Cancelled** while it is disabled for all the other service order states. When the state of the service order is **Draft**, you can modify and deploy or delete the service order.

The Deployed-Active or Active state denotes a service that has been deployed and is in an active state (enabled). The Deployed-Inactive or Inactive state denotes a service that has been deployed and is in a deactivated state (disabled). The Deployment-Pending or Pending state denotes a service for which deployment of the service to a device is pending to be performed.

Service States

A service is created when a service order to provision a service reaches the Completed state.

If a service exists, it is in the Deployed state. If a new service fails to deploy, the service does not exist.

If an attempt to modify a service fails, the service enters the Fail Deploy state. When a service is in the Fail Deploy state, you can attempt to redeploy it, or you can delete it.

The service also has an audit state of Up or Down, depending on whether the service passed or failed functional audit.

If you modify a service order and successfully redeploy the service, the modified service will operate according to the updated configuration.

RELATED DOCUMENTATION

[Publishing a Custom Service Definition | 690](#)

[Unpublishing a Custom Service Definition | 691](#)

[Deactivating a Service | 923](#)

[Reactivating a Service | 925](#)

Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services

To effectively manage Ethernet frames that are transported across bridge domains and VPLS routing instances, frames are processed and, if necessary, translated to provide the required VLAN tags. When the customer sites participating in a VPLS domain send traffic of different tag heights (untagged, single tagged, or dual tagged packets) across a service, Internet service providers (ISPs) need to provide a network environment to transport traffic of different tag heights. The Connectivity Services Director application supports VLAN manipulation on E-LAN services. VLAN manipulation allows transport of traffic with different tag heights between different customer access sites while preserving the customer traffic profiles that are transported over an MPLS core. You can also use VLAN manipulation for the following purposes:

- Specify different normalized values for outer and inner VLAN tags while troubleshooting packet captures to identify wrong inner/ outer VLAN tag configuration issues.
- Simplify provisioning across a BGP/LDP scenario because VLAN tag manipulation is performed on customer facing interfaces only.
- Simplify the process for troubleshooting predetermined tag values.
- Enable end-to-end communication between clients employing different VLAN topologies.
- Provide ISPs the flexibility to enforce their own QoS policies through metro area and core networks because customer traffic classification is not impacted.

NOTE: To support all access types (port-based [untagged], single-tag, and dual-tag) in a VPLS instance, we recommend that normalization is based on a two-tag operation. However, when only port-based or single-tag access is required, normalizing traffic to a single tag might be sufficient.

For Ethernet services and Ethernet services with flexible VLAN tagging (asymmetric tag height), the type of VLAN manipulation applied depends on the type of device sending and receiving packets. MX Series devices can use VLAN mapping or normalization to translate VLANs tags. M Series devices use only VLAN mapping to translate VLAN tags.

VLAN Translation (Normalization) for E-LAN Services

A packet received on a physical port is only accepted for processing if the VLAN tags of the received packet match the VLAN tags associated with one of the logical interfaces configured on the physical port. The VLAN tags of the received packet are translated only if they are different than the normalized VLAN tags. For the translation case, the VLAN identifier tags specify the normalized VLAN.

The VLAN tags of a received packet are compared with the normalized VLAN tags specified with either the **vlan-id** or **vlan-tags** statements. If the VLAN tags of the received packet are different from the normalized VLAN tags, then appropriate VLAN tag operations (such as push-push, pop-pop, pop-swap, swap-swap, swap, and others) are implicitly made to convert the received VLAN tags to the normalized VLAN tags. Then, the source MAC address of a received packet is learned based on the normalized VLAN configuration. For output packets, if the VLAN tags associated with an egress logical interface do not match the normalized VLAN tags within the packet, then appropriate VLAN tag operations (such as push-push, pop-pop, pop-swap, swap-swap, swap, and others) are implicitly made to convert the normalized VLAN tags to the VLAN tags for the egress logical interface. For more information about these operations, see the *Junos OS Routing Protocols Configuration Guide*.

VLAN Mapping for VPLS Services

For Ethernet services and Ethernet services with flexible VLAN tagging (asymmetric tag depth), the Connectivity Services Director application uses the VLAN configuration data that you specified in the service order to apply the appropriate VLAN tags to the input and output VLAN maps for the ingress and egress logical interfaces, respectively. The following steps outline the process of bridging a packet received

over a Layer 2 logical interface when a normalizing VLAN identifier (**vlan-id number** or **vlan-tags** statement) is specified for a bridge domain or VPLS routing instance:

1. When a packet is received on a physical port, it is accepted only if the VLAN identifier of the packet matches the VLAN identifier of one of the logical interfaces configured on that port.
2. The VLAN tags of the received packet are then compared with the normalizing VLAN identifier. If the VLAN tags of the packet are different from the normalizing VLAN identifier, the VLAN tags are rewritten, as described in [Table 9 on page 95](#).
3. If the source MAC address of the received packet is not present in the source MAC table, it is learned based on the normalizing VLAN identifier.
4. The packet is then forwarded toward one or more outbound Layer 2 logical interfaces based on the destination MAC address. A packet with a known unicast destination MAC address is forwarded only to one outbound logical interface. For each outbound Layer 2 logical interface, the normalized VLAN identifier configured for the bridge domain or VPLS routing instance is compared with the VLANs tags that are configured on that logical interface. If the VLAN tags associated with an outbound logical interface do not match the normalizing VLAN identifier that is configured for the bridge domain or VPLS routing instance, the VLAN tags are rewritten, as described in [Table 10 on page 95](#).

[Table 9 on page 95](#) and [Table 10 on page 95](#) show how VLAN tags are applied when traffic is sent to and from the bridge domain, depending on how the VLAN IDs and VLAN tags (inner and outer) are configured for the bridge domain and on how VLAN identifiers are configured for the logical interfaces in a bridge domain or VPLS routing instance. Depending on the configuration of the Ethernet services that you create in Connectivity Services Director, the following rewrite operations are performed on VLAN tags:

- **pop**—Remove the VLAN tag from the top of the VLAN tag stack.
- **pop/pop**—Remove both the outer and inner VLAN tags of the frame.
- **pop/swap**—Remove the outer VLAN tag of the frame and replace the inner VLAN tag of the frame.
- **swap**—Replace the inner VLAN tag of the frame.
- **push**—Add a new VLAN tag to the top of the VLAN stack.
- **push/push**—Push two VLAN tags in front of the frame.
- **swap/push**—Replace the VLAN tag of the frame and add a new VLAN tag to the top of the VLAN stack.
- **swap/swap**—Replace both the outer and inner VLAN tags of the frame.

No operation means that the VLAN tags of the inbound or outbound packet are not translated for the specified output logical interface or input logical interface. **NA** means not applicable.

Table 9: VLAN Tag Rewrite Operations at UNI Ingress for Ethernet Services

VLAN Identifier of Logical Interface	vlan-id none	vlan-id 200	vlan-id all	vlan tags outer 100, inner 300
none	no operation	push 200	NA	push 100, push 300
200	pop 200	no operation	no operation	swap 200 to 300, push 100
1000	pop 1000	swap 1000 to 200,	no operation	swap 1000 to 300, push 100
vlan-tags outer 2000, inner 300	pop 2000, pop 300	pop 2000, swap 300 to 200	pop 200	swap 2000 to 100
vlan-id range 10-100	NA	NA	no operation	NA
vlan-tags outer 200, inner range 10-100	NA	NA	pop 200	NA

Table 10: VLAN Tag Rewrite Operations at UNI Egress for Ethernet Services

VLAN Identifier of Logical Interface	vlan-id none	vlan-id 200	vlan-id all	vlan tags outer 100, inner 300
none	no operation	pop 200	NA	pop 100, pop 300
200	push 200	no operation	no operation	pop 200, swap 300 to 200
1000	push 1000	swap 200 to 1000	no operation	pop 100, swap 300 to 1000
vlan-tags outer 2000, inner 300	push 2000, push 300	swap 200 to 300, push 3000	push 2000	swap 100 to 2000
vlan-id range 10-100	NA	NA	no operation	NA
vlan-tags outer 200, inner range 10-100	NA	NA	push 200	NA

Sample VLAN Configuration on MX Series and M Series PE Routers

MX Series devices can use VLAN mapping or normalization to translate VLANs tags. M Series devices use only VLAN mapping to translate VLAN tags. The following sample configurations show the VLAN and VPLS routing-instance configurations for an MX960 PE interface and M320 PE interface.

MX960 PE Interface Configuration	M320 PE Interface Configuration
<pre>interfaces { ge-0/0/0 { unit 1 { encapsulation vlan-vpls; vlan-tags outer 5 inner } } } ##normalizing the inner and outer tags towards the core with Push/Push operations## family vpls }</pre>	<pre>interfaces { ge-1/1/1 { unit 1 { encapsulation vlan-vpls; vlan-tags outer 22 inner 2; } } } ## Q-in-Q tags configured on the PE interface ## input-vlan-map { swap-swap; ##normalizing the inner and outer tags towards the core by swapping both tags## vlan-id 2; inner-vlan-id 1; } output-vlan-map swap-swap; ## Put the original tags back for the packets towards the VPLS CE ## family vpls }</pre>

RELATED DOCUMENTATION

Creating a Multipoint-to-Multipoint E-LAN Service Order 943
Creating a Point-to-Multipoint E-LAN Service Order 964

VLAN Pool Profiles Overview

A VLAN pool profile specifies the ranges of valid VLAN IDs that are available for use on MX Series devices, on each physical interface. The maximum theoretical pool of VLAN IDs contains 4096 VLAN IDs—IDs 0 through 4095.

VLAN ID 0 and VLAN ID 4095 are never valid VLAN IDs.

The Connectivity Services Director system provides the following predefined VLAN pool profiles:

- **maximum-range**—Any VLAN ID pool created using the maximum-range profile allows any VLAN ID from 1 through 4094. This is the default VLAN profile.
- **vlan-ccc**—Any VLAN ID pool created using the vlan-ccc profile allows any VLAN IDs from 512 through 4094 available for use. VLAN IDs 1 through 511 are reserved for use by Juniper Networks.

For each physical interface that Junos Space recommends as a UNI, the system attempts to determine the best VLAN pool profile. For example, if a UNI has the vlan-ccc encapsulation setting, the rules recommend the vlan-ccc pool profile for that interface. When the correct VLAN pool profiles have been assigned to each UNI, Connectivity Services Director creates a VLAN ID pool for each UNI containing only the allowed VLAN IDs specified in the VLAN pool profile for that UNI.

If the device interface is already running encapsulation before being brought under Junos Space management, the Connectivity Services Director application assigns the appropriate VLAN range.

For details about encapsulation, see the *Junos OS VPNs Configuration Guide*.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

Redundant Pseudowires for Layer 2 Circuits and VPLS

IN THIS SECTION

- [Types of Redundant Pseudowire Configurations | 98](#)
- [Pseudowire Failure Detection | 99](#)

A redundant pseudowire can act as a backup connection between PE routers and CE devices, maintaining Layer 2 circuit and VPLS services after certain types of failures. This feature can help improve the reliability of certain types of networks (metro for example) where a single point of failure can interrupt service for multiple customers. Redundant pseudowires cannot reduce traffic loss to zero. However, they provide a way to gracefully recover from pseudowire failures in such a way that service can be restarted within a known time limit.

When you configure redundant pseudowires to remote PE routers, you configure one to act as the primary pseudowire over which customer traffic is being transmitted and you configure another pseudowire to act as a backup in the event the primary fails. You configure the two pseudowires statically. A separate label is allocated for the primary and backup neighbors.

The following sections provide an overview of redundant pseudowires for Layer 2 circuits and VPLS:

Types of Redundant Pseudowire Configurations

You can configure redundant pseudowires for Layer 2 circuits and VPLS in either of the following manners:

- You can configure a single active pseudowire. The PE router configured as the primary neighbor is given preference and this connection is the one used for customer traffic. For the LDP signaling, labels are exchanged for both incoming and outgoing traffic with the primary neighbor. The LDP label advertisement is accepted from the backup neighbor, but no label advertisement is forwarded to it, leaving the pseudowire in an incomplete state. The pseudowire to the backup neighbor is completed only when the primary neighbor fails. The decision to switch between the two pseudowires is made by the device configured with the redundant pseudowires. The primary remote PE router is unaware of the redundant configuration, ensuring that traffic is always switched using just the active pseudowire.
- Alternatively, you can configure two active pseudowires, one to each of the PE routers. Using this approach, control plane signaling is completed and active pseudowires are established with both the primary and backup neighbors. However, the data plane forwarding is done only over one of the pseudowires (designated as the active pseudowire by the local device). The other pseudowire is on standby. The active pseudowire is preferably established with the primary neighbor and can switch to the backup pseudowire if the primary fails.

The decision to switch between the active and standby pseudowires is controlled by the local device. The remote PE routers are unaware of the redundant connection, and so both remote PE routers send traffic to the local device. The local device only accepts traffic from the active pseudowire and drops the traffic from the standby. In addition, the local device only sends traffic to the active pseudowire. If the active pseudowire fails, traffic is immediately switched to the standby pseudowire.

Pseudowire Failure Detection

When a failure is detected, traffic is switched to the redundant pseudowire, which is then also designated as the active pseudowire. The switch is nonreversible, meaning that once traffic has been switched to the redundant pseudowire, it remains active unless it also fails unless the switch to the redundant pseudowire is never done unless there is a failure in the currently active pseudowire. For example, a primary pseudowire has failed and traffic has been successfully switched to the redundant pseudowire. After a period of time, the cause of the failure of the primary pseudowire has been resolved and it is now possible to reestablish the original connection. However, traffic is not switched back to the original pseudowire unless a failure is detected on the now active pseudowire.

RELATED DOCUMENTATION

Creating an E-Line Service Definition

[Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696](#)

[Creating a Point-to-Multipoint E-LAN Service Definition | 726](#)

VPLS over GRE Overview

Generic routing encapsulation (GRE) is one of the tunneling mechanisms that uses IP as the transport protocol. The tunnels behave as virtual point-to-point links that have two endpoints identified by the tunnel source and tunnel destination addresses at each endpoint.

The primary use of GRE is to carry non-IP packets through an IP network. GRE also carries IP packets such as IP broadcast, IP multicast through an IP cloud. A GRE tunnel has the following characteristics:

- GRE tunnel is stateless, and offers no flow control mechanisms.
- GRE is multiprotocol and can tunnel any OSI Layer 3 protocol.
- GRE enables routing protocols to travel through the tunnel.
- GRE has weak security features.
- GRE provides no reliability or sequencing. Such features are typically handled by upper-layer protocols.
- GRE tunnels carry multicast traffic.

The VPLS over GRE feature allows you to combine flow-based and packet-based services in a single device. You can deploy large-scale VPLS over GRE.

To better understand this configuration, consider the following scenarios:

In the first scenario, pseudowires enable the creation of point-to-point circuits between two endpoints carried over the MPLS network. Ignoring the signaling protocols for this discussion, these connections are just point-to-point connections. Using this approach provides an end-to-end wire between sites. This is beneficial from a traffic processing point of view because the gateways do not need to learn MAC addresses; they simply forward anything they receive to the pseudowire. Deploying this configuration can be difficult when trying to provide connectivity to multiple branch offices.

In the second scenario, VPLS provides a Layer 2 network abstraction. With VPLS, endpoints typically negotiate LSPs and pseudowires with every other endpoint (that is, they are fully meshed). When a node receives an Ethernet frame from one of its LAN interfaces, the source MAC address is learned, if it is not already known, and flooded using every pseudowire connecting to all other branch nodes. However, if the destination has been previously learned, then the frame is sent to the appropriate destination. When an Ethernet frame is received through one of the pseudowires (that is, from the MPLS network), source MAC address learning is performed. The next time a frame is sent to that MAC it does not need to be flooded and the frame is flooded to every single LAN interface in the node, but not over the pseudowires. The network acts as a distributed Layer 2 switch providing any-to-any Ethernet connectivity between the devices connected to the different nodes in the network.

While the second scenario provides significant advantages (any-to-any connectivity, automated provisioning, and simple abstraction), it is more complex. Every PE node has to perform Layer 2 learning and flooding of traffic, which can cause problems when either multiple broadcast/multicast or frames to unknown MAC addresses are used. For example, in a topology with a thousand branch offices, each office that receives a broadcast packet must replicate it 999 times, encapsulate each copy in GRE, and forward the resulting traffic. Additionally, because each node performs Layer 2 learning, the maximum number of MAC addresses that each node can learn is limited, limiting the total number of nodes in the domain.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696](#)

[Creating a Point-to-Multipoint E-LAN Service Definition | 726](#)

Junos Space Network Topology Overview

Network topology is the arrangement of various elements including nodes and links. It is the graphical representation of physical devices and their interconnection. The topology has the following three components:

1. Physical topology
2. Link topology
3. IP connectivity

Each application registers itself to the topology framework so that you can view and change topology on the application layer. To view the network topology, select **Network Management Platform > Network Monitoring > Topology**.

In a network topology, you can:

- Monitor the status and configurations of the discovered devices and their interconnections.
- View source and destination information for the device interconnections that exist within the discovered topologies.
- Select a service and view all the devices associated with the service.
- Discover IS-IS configuration devices.

The network topology helps you to understand and visualize the physical and logical interconnection between the network devices and the services. It also enables you to view the end-to-end network and zoom into the segments of the network for management and troubleshooting.

RELATED DOCUMENTATION

[Creating a Service Order | 876](#)

[Creating an E-Line ATM or TDM Pseudowire Service Order | 877](#)

[Creating an E-Line Service Order | 895](#)

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

Service Recovery Overview

The Service Recovery operation recovers services that are present on devices that Junos Space is not managing. The missing entity can be an entirely new service or the missing component of an existing service.

The Service Recovery operation has two parts. First, you select one or more devices for which services are to be recovered. Service Recovery recovers and identifies the missing services and displays the result. Second, you select a service to be managed, providing any missing information about the recovered service. When you provide missing information for a service, the recovered service is converted to a managed service.

Besides the supported capabilities of recovery of new services and new endpoints for existing services, recovery of CFM profiles attached to services is also supported. Also, the Service Recovery task enables you to recover modifications made to existing endpoints associated with services and recover deleted endpoints for services.

The Service Recovery task is displayed in the Connectivity tree node under Network Services root node of the View pane. Recovery of services is supported only for E-Line, IP, and E-LAN services. The following tasks are available under the Service Recovery section of the Tasks pane:

- **Recover Services**—Enables you to create or modify a service recovery request. You can also initiate the recovery operation for a request that you created. The Create Service Recovery Request wizard is available to create a service recovery request. The Recover Services button enables you to initiate the recovery job. You can also view the recovered status of services.
- **Recover OutOfBand Changes**—Enables you to recover out-of-band changes that are performed on previously deployed service. A network managed by Connectivity Services Director has three repositories of information about the configuration of a network device—the configuration stored on the device itself, the device configuration record maintained by Junos Space, and the Build mode configuration maintained by Connectivity Services Director. When the configuration contained in all three repositories match, the device configuration state is shown as In Sync in Connectivity Services Director. When the repositories do not match, the configuration state is shown as Out of Sync. A common cause for this state is out-of-band configuration changes—that is, configuration changes made to a device outside of Connectivity Services Director.
- **Rejected Services**—Displays the services that were rejected during service recovery process with the reject reason.

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request](#) | 419

Multicast L3VPN Overview

The Junos Space Connectivity Services Director application uses Multiprotocol-BGP (MBGP) Multicast L3VPNs (MVPN) to implement MVPNs because it is simpler. This method does not require a service provider to configure multicast in its provider backbone to connect PE routers.

For the control plane, MBGP MVPN uses the intra-autonomous system (AS) next-generation BGP. The data plane is configured with Protocol Independent Multicast (PIM) sparse mode. Connectivity Services Director maintains PIM state information using the same architecture that is used for unicast VPNs.

The MBGP MVPN method avoids potential control and data plane scaling problems that can occur with the requirement to maintain two routing and forwarding mechanisms, one for VPN unicast and one for VPN multicast.

The Connectivity Services Director application addresses aspects of published standards as follows:

- IP service, as defined by RFC 4364, is supported to enable service providers to implement IP multicast for IP services.
- The architecture defined by RFC 4364 for unicast VPNs is supported to enable service providers to configure BGP for the control plane between PE routers.
- Unicast with extensions for intra-Autonomous System (AS) and inter-AS communication, as defined by RFC 4364, is supported.

For MVPNs, Connectivity Services Director enables you to configure two site sets, a sender site set and a receiver site set. Site sets have the following properties:

- Hosts within a sender site can originate multicast traffic for receivers in a receiver site set.
- Receivers outside the receiver site set should not be able to receive traffic sent from the sender site.
- Hosts within the receiver site set can receive multicast traffic originated from any host in the sender site set.
- Hosts within the receiver site set should not be able to receive multicast traffic originated from any host that is not in the sender site set.

A host can be in both the sender site set and the receiver site set. Therefore, such a host can both originate and receive multicast traffic. For example, the sender site set could be the same as the receiver site set. In this case, all hosts could both originate and receive multicast traffic from one another.

Administrative policies define an MBGP MVPN. The policies define both the sender site set and receiver site set. Customers establish the policies but the policies are implemented by service providers, which use the existing BGP and MPLS VPN infrastructure.

RELATED DOCUMENTATION

[VPLS over GRE Overview | 99](#)[Junos Space Network Topology Overview | 100](#)[Service Recovery Overview | 102](#)[Multi-Chassis Link Aggregation Group Overview](#)[Multi-Chassis Automatic Protection Switching Overview | 104](#)

Multi-Chassis Automatic Protection Switching Overview

Automatic protection switching (APS) is a linear protection scheme designed to protect VLAN-based Ethernet networks.

With APS, a protected domain is configured with two paths: a working path and a protection path. Both working and protection paths can be monitored. Normally, traffic is carried on the working path (that is, the working path is the active path), and the protection path is disabled. If the working path fails, its protection status is marked as degraded (DG) and APS switches the traffic to the protection path, then the protection path becomes the active path.

APS uses two modes of operation: linear 1+1 protection switching architecture and linear 1:1 protection switching architecture. The linear 1+1 protection switching architecture operates with either unidirectional or bidirectional switching. The linear 1:1 protection switching architecture operates with bidirectional switching.

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)

Inverse Multiplexing for ATM Overview

The Inverse multiplexing for ATM (IMA) protocol defines a technique for transporting ATM traffic over a bundle of T1 or E1 interfaces. IMA processes traffic differently from multiplexing. While multiplexing combines multiple signals into a single signal, IMA divides a data stream into multiple concurrent streams that are transmitted at the same time across separate channels (such as T1 or E1 interfaces). The data streams are reconstructed into the original data stream at the far end. IMA speeds up the flow of data across a slower interface, such as a T1 or E1 interface, by load balancing the data stream across multiple T1 or E1 interfaces, which increases the line capacity.

You can deploy IMA on Juniper Networks M7, MX and ACX devices. IMA includes the following operational features:

- **Aggregated device count**—A device count is the number of IMA group interfaces created on a CT1 or CE1 interface. As part of an IMA group, a logical ATM interface is identified by the naming format: “*at-fpc/pic/port*”. The port number is derived from the last port on the MIC plus 1.

For example, for an ACX2000 router with a 16-port built-in T1/E1 TDM MIC, IMA group interface numbering starts with *at-0/0/16*. That interface number is incremented by 1 to *at-0/0/17*, and so on. For an ACX1000 router with an 8-port built-in T1/E1 TDM MIC, IMA group interface numbering starts with *at-0/0/8*. That interface number is incremented by 1 to *at-0/0/9*, and so on.

- **Framing mode**—An emulation mechanism duplicates the essential attributes of a service, such as T1 or E1, over a packet-switched network. On the ACX Series routers, you can configure the built-in channelized T1 and E1 interfaces (CT1 and CE1) to work in either T1 or E1 mode. You can configure these child T1 and E1 interfaces to carry ATM services over the packet-switched network.
- **Built-in channelized interface**—The Juniper Networks devices that support ATM IMA are deployed with one full T1 or E1 interface on the channelized CT1 or CE1 interface. You cannot configure the built-in interface. However, on the built-in interface, you configure the parameters for a child T1 or E1 interface.
- **T1 or E1 interface member of IMA group for IMA link**—Each child T1 or E1 interface of a channelized CT1 or CE1 interface is the physical interface over which the ATM signals are transmitted. To ensure that the IMA link operates correctly, you specify the T1 or E1 interface to be a member of an IMA group.
- **IMA group interface configuration**—To ensure proper operation, you must configure each IMA group interface (*at-fpc/pic/g*) with all ATM properties, which include the logical link-layer encapsulation type and the circuit cross-connect protocol suite. Further, you must dedicate the entire ATM device to the ATM cell relay circuit.

RELATED DOCUMENTATION

[Inverse Multiplexing for ATM Overview | 104](#)


[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Rendezvous Point

The RP router serves as the information exchange point for the other routers. All routers in a PIM domain must provide mapping to an RP router. It is the only router that needs to know the active sources for a domain—the other routers just need to know how to get to the RP. In this way, the RP matches receivers with sources.

The RP router is downstream from the source and forms one end of the SPT. As shown in [Figure 11 on page 106](#), the RP router is upstream from the receiver and thus forms one end of the RPT.

Figure 11: Rendezvous Point as Part of the RPT and SPT



The benefit of using the RP as the information exchange point is that it reduces the amount of state in non-RP routers. No network flooding is required to provide non-RP routers information about active sources.

RELATED DOCUMENTATION

[Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees | 106](#)

[Understanding PIM Sparse Mode | 108](#)

[Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs | 111](#)

[Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs | 113](#)

[Configuring VRF Route Targets for Routing Instances for an MBGP MVPN | 115](#)

Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees

In a shared tree, the root of the distribution tree is a router, not a host, and is located somewhere in the core of the network. In the primary sparse mode multicast routing protocol, Protocol Independent Multicast sparse mode (PIM SM), the core router at the root of the shared tree is the rendezvous point (RP). Packets from the upstream source and join messages from the downstream routers “rendezvous” at this core router.

In the RP model, other routers do not need to know the addresses of the sources for every multicast group. All they need to know is the IP address of the RP router. The RP router discovers the sources for all multicast groups.

The RP model shifts the burden of finding sources of multicast content from each router (the (S,G) notation) to the network (the (*,G) notation knows only the RP). Exactly how the RP finds the unicast IP address of the source varies, but there must be some method to determine the proper source for multicast content for a particular group.

Consider a set of multicast routers without any active multicast traffic for a certain group. When a router learns that an interested receiver for that group is on one of its directly connected subnets, the router attempts to join the distribution tree for that group back to the RP, not to the actual source of the content.

To join the shared tree, or *rendezvous-point tree (RPT)* as it is called in PIM sparse mode, the router must do the following:

- Determine the IP address of the RP for that group. Determining the address can be as simple as static configuration in the router, or as complex as a set of nested protocols.
- Build the shared tree for that group. The router executes an RPF check on the RP address in its routing table, which produces the interface closest to the RP. The router now detects that multicast packets from this RP for this group need to flow into the router on this RPF interface.
- Send a join message out on this interface using the proper multicast protocol (probably PIM sparse mode) to inform the upstream router that it wants to join the shared tree for that group. This message is a (*,G) join message because S is not known. Only the RP is known, and the RP is not actually the source of the multicast packets. The router receiving the (*,G) join message adds the interface on which the message was received to its outgoing interface list (OIL) for the group and also performs an RPF check on the RP address. The upstream router then sends a (*,G) join message out from the RPF interface toward the source, informing the upstream router that it also wants to join the group.

Each upstream router repeats this process, propagating join messages from the RPF interface, building the shared tree as it goes. The process stops when the join message reaches one of the following:

- The RP for the group that is being joined
- A router along the RPT that already has a multicast forwarding state for the group that is being joined

In either case, the branch is created, and packets can flow from the source to the RP and from the RP to the receiver. Note that there is no guarantee that the shared tree (RPT) is the shortest path tree to the source. Most likely it is not. However, there are ways to “migrate” a shared tree to an SPT once the flow of packets begins. In other words, the forwarding state can transition from (*,G) to (S,G). The formation of both types of tree depends heavily on the operation of the RPF check and the RPF table.

RELATED DOCUMENTATION

[Rendezvous Point | 105](#)

[Understanding PIM Sparse Mode | 108](#)

[Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs | 111](#)

[Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs | 113](#)

[Configuring VRF Route Targets for Routing Instances for an MBGP MVPN | 115](#)

Understanding PIM Sparse Mode

A Protocol Independent Multicast (PIM) sparse-mode domain uses reverse-path forwarding (RPF) to create a path from a data source to the receiver requesting the data. When a receiver issues an explicit join request, an RPF check is triggered. A (*,G) PIM join message is sent toward the RP from the receiver's designated router (DR). (By definition, this message is actually called a join/prune message, but for clarity in this description, it is called either join or prune, depending on its context.) The join message is multicast hop by hop upstream to the ALL-PIM-ROUTERS group (224.0.0.13) by means of each router's RPF interface until it reaches the RP. The RP router receives the (*,G) PIM join message and adds the interface on which it was received to the outgoing interface list (OIL) of the rendezvous-point tree (RPT) forwarding state entry. This builds the RPT connecting the receiver with the RP. The RPT remains in effect, even if no active sources generate traffic.

NOTE: State—the (*,G) or (S,G) entries—is the information used for forwarding unicast or multicast packets. S is the source IP address, G is the multicast group address, and * represents any source sending to group G. Routers keep track of the multicast forwarding state for the incoming and outgoing interfaces for each group.

When a source becomes active, the source DR encapsulates multicast data packets into a PIM register message and sends them by means of unicast to the RP router.

If the RP router has interested receivers in the PIM sparse-mode domain, it sends a PIM join message toward the source to build a shortest-path tree (SPT) back to the source. The source sends multicast packets out on the LAN, and the source DR encapsulates the packets in a PIM register message and forwards the message toward the RP router by means of unicast. The RP router receives PIM register messages back from the source, and thus adds a new source to the distribution tree, keeping track of sources in a PIM table. Once an RP router receives packets natively (with S,G), it sends a register stop message to stop receiving the register messages by means of unicast.

In actual application, many receivers with multiple SPTs are involved in a multicast traffic flow. To illustrate the process, we track the multicast traffic from the RP router to one receiver. In such a case, the RP router begins sending multicast packets down the RPT toward the receiver's DR for delivery to the interested receivers. When the receiver's DR receives the first packet from the RPT, the DR sends a PIM join message toward the source DR to start building an SPT back to the source. When the source DR receives the PIM join message from the receiver's DR, it starts sending traffic down all SPTs. When the first multicast packet is received by the receiver's DR, the receiver's DR sends a PIM prune message to the RP router to stop duplicate packets from being sent through the RPT. In turn, the RP router stops sending multicast packets to the receiver's DR, and sends a PIM prune message for this source over the RPT toward the source DR to halt multicast packet delivery to the RP router from that particular source.

If the RP router receives a PIM register message from an active source but has no interested receivers in the PIM sparse-mode domain, it still adds the active source into the PIM table. However, after adding the

active source into the PIM table, the RP router sends a register stop message. The RP router discovers the active source's existence and no longer needs to receive advertisement of the source (which utilizes resources).

NOTE: If the number of PIM join messages exceeds the configured MTU, the messages are fragmented in IPv6 PIM sparse mode. To avoid the fragmentation of PIM join messages, the multicast traffic receives the interface MTU instead of the path MTU.

The major characteristics of PIM sparse mode are as follows:

- Routers with downstream receivers join a PIM sparse-mode tree through an explicit join message.
- PIM sparse-mode RPs are the routers where receivers meet sources.
- Senders announce their existence to one or more RPs, and receivers query RPs to find multicast sessions.
- Once receivers get content from sources through the RP, the last-hop router (the router closest to the receiver) can optionally remove the RP from the shared distribution tree (*,G) if the new source-based tree (S,G) is shorter. Receivers can then get content directly from the source.

The transitional aspect of PIM sparse mode from shared to source-based tree is one of the major features of PIM, because it prevents overloading the RP or surrounding core links.

There are related issues regarding source, RPs, and receivers when sparse mode multicast is used:

- Sources must be able to send to all RPs.
- RPs must all know one another.
- Receivers must send explicit join messages to a known RP.
- Receivers initially need to know only one RP (they later learn about others).
- Receivers can explicitly prune themselves from a tree.
- Receivers that never transition to a source-based tree are effectively running Core Based Trees (CBT).


PIM sparse mode has standard features for all of these issues.

Rendezvous Point

The RP router serves as the information exchange point for the other routers. All routers in a PIM domain must provide mapping to an RP router. It is the only router that needs to know the active sources for a domain—the other routers just need to know how to reach the RP. In this way, the RP matches receivers with sources.

The RP router is downstream from the source and forms one end of the shortest-path tree. As shown in [Figure 11 on page 106](#), the RP router is upstream from the receiver and thus forms one end of the rendezvous-point tree.

Figure 12: Rendezvous Point as Part of the RPT and SPT



The benefit of using the RP as the information exchange point is that it reduces the amount of state in non-RP routers. No network flooding is required to provide non-RP routers information about active sources.

RP Mapping Options

RPs can be learned by one of the following mechanisms:

- Static configuration
- Anycast RP
- Auto-RP
- Bootstrap router

We recommend a static RP mapping with anycast RP and a bootstrap router (BSR) with auto-RP configuration, because static mapping provides all the benefits of a bootstrap router and auto-RP without the complexity of the full BSR and auto-RP mechanisms.

Protocol Independent Multicast (PIM) sparse mode is the most common multicast protocol used on the Internet. PIM sparse mode is the default mode whenever PIM is configured on any interface of the device. However, because PIM must not be configured on the network management interface, you must disable it on that interface.

Each any-source multicast (ASM) group has a shared tree through which receivers learn about new multicast sources and new receivers learn about all multicast sources. The rendezvous point (RP) router is the root of this shared tree and receives the multicast traffic from the source. To receive multicast traffic from the groups served by the RP, the device must determine the IP address of the RP for the source.

You can configure a static rendezvous point (RP) configuration that is similar to static routes. A static configuration has the benefit of operating in PIM version 1 or version 2. When you configure the static RP, the RP address that you select for a particular group must be consistent across all routers in a multicast domain.

One common way for the device to locate RPs is by static configuration of the IP address of the RP. A static configuration is simple and convenient. However, if the statically defined RP router becomes unreachable, there is no automatic failover to another RP router. To remedy this problem, you can use anycast RP.

RELATED DOCUMENTATION

[Rendezvous Point | 105](#)

[Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees | 106](#)

[Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs | 111](#)

[Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs | 113](#)

[Configuring VRF Route Targets for Routing Instances for an MBGP MVPN | 115](#)

Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs

For MBGP MVPNs (also referred to as next-generation Layer 3 multicast VPNs), the default mode of operation supports only intersite shortest-path trees (SPTs) for customer PIM (C-PIM) join messages. It does not support rendezvous-point trees (RPTs) for C-PIM join messages. The default mode of operation provides advantages, but it requires either that the customer rendezvous point (C-RP) be located on a PE router or that the Multicast Source Discovery Protocol (MSDP) be used between the C-RP and a PE router so that the PE router can learn about active sources advertised by other PE routers.

If the default mode is not suitable for your environment, you can configure RPT-SPT mode (also known as *shared-tree data distribution*), as documented in section 13 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt). RPT-SPT mode supports the native PIM model of transmitting (*,G) messages from the receiver to the RP for intersite shared-tree join messages. This means that the type 6 (*,G) routes get transmitted from one PE router to another. In RPT-SPT mode, the shared-tree multicast routes are advertised from an egress PE router to the upstream router connected to the VPN site with the C-RP. The single-forwarder election is performed for the C-RP rather than for the source. The egress PE router takes the upstream hop to advertise the (*,G) and sends the type 6 route toward the upstream PE router. To send the data on the RPT, either inclusive or selective provider tunnels can be used. After the data starts flowing on the RPT, the last-hop router switches to SPT mode, unless you include the **spt-threshold infinity** statements in the configuration.

NOTE: The MVPN single-forwarder election follows the rule documented in section 9.1.1 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt). The single-forwarder election winner is based on the following rules:

- If the active unicast route to the source is through the interface, then this route is used to determine the upstream multicast hop (UMH).
- If the active unicast route to the source is a VPN route, MVPN selects the UMH based on the highest IP address in the route import community for the VPN routes, and the local primary loopback address for local VRF routes.

The switch to SPT mode is performed by PIM and not by MVPN type 5 and type 6 routes. After the last-hop router switches to SPT mode, the SPT (S,G) join messages follow the same rules as the SPT-only default mode.

The advantage of RPT-SPT mode is that it provides a method for PE routers to discover sources in the multicast VPN when the C-RP is located on the customer site instead of on a PE router. Because the shared C-tree is established between VPN sites, there is no need to run MSDP between the C-RP and the PE routers. RPT-SPT mode also enables egress PE routers to switch to receiving data from the PE connected to the source after the source information is learned, instead of receiving data from the RP.

In Junos OS Release 15.1 and later, in RPT-SPT mode, PIM SSG Joins are created on the egress PE even if no directly-connected receivers are present.



CAUTION: When you configure RPT-SPT mode, receivers or sources directly attached to the PE router are not supported. As a workaround, place a CE router between any receiver or source and the PE router.

RELATED DOCUMENTATION

[Rendezvous Point | 105](#)

[Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees | 106](#)

[Understanding PIM Sparse Mode | 108](#)

[Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs | 113](#)

[Configuring VRF Route Targets for Routing Instances for an MBGP MVPN | 115](#)

Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs

For MBGP MVPNs (also referred to as next-generation Layer 3 multicast VPNs), the default mode of operation is shortest path tree only (SPT-only) mode. In SPT-only mode, the active multicast sources are learned through multicast VPN source-active routes. This mode of operation is described in section 14 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt).

In contrast to SPT-only mode, rendezvous point tree (RPT)-SPT mode (also known as shared-tree data distribution) supports the native PIM model of transmitting (*,G) messages from the receiver to the RP for intersite shared-tree join messages.

In SPT-only mode, when a PE router receives a (*, C-G) join message, the router looks for an active source transmitting data to the customer group. If the PE router has a source-active route for the customer group, the router creates a source tree customer multicast route and sends the route to the PE router connected to the VPN site with the source. The source is determined by MVPN's single-forwarder election. When a receiver sends a (*,G) join message in a VPN site, the (*,G) join message only travels as far as the PE router. After the join message is converted to a type 6 multicast route, which is equivalent to a (S,G) join message, the route is installed with the no-advertise community setting.

NOTE: The MVPN single-forwarder election follows the rule documented in section 9.1.1 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt). The single-forwarder election winner is based on the following rules:

- If the active unicast route to the source is through the interface, then this route is used to determine the upstream multicast hop (UMH).
- If the active unicast route to the source is a VPN route, MVPN selects the UMH based on the highest IP address in the route import community for the VPN routes, and the local primary loopback address for local VRF routes.

Single-forwarder election guarantees selection of a unique forwarder for a given customer source (C-S). The upstream PE router might differ for the source tree and the shared tree because the election is based on the customer source and C-RP, respectively. Although the single-forwarder election is sufficient for SPT-only mode, the alternative RPT-SPT mode involves procedures to prevent duplicate traffic from being sent on the shared tree and the source tree. These procedures might require administrator-configured parameters to reduce duplicate traffic and reduce null routes during RPT to SPT switch and the reverse.

In SPT-only mode, when a source is active, PIM creates a register state for the source both on the DR and on the C-RP (or on a PE router that is running Multicast Source Discovery Protocol [MSDP] between itself and the C-RP). After the register states are created, MVPN creates a source-active route. These type 5 source-active routes are installed on all PE routers. When the egress PE router with the (*,G) join message receives the source-active route, it has two routes that it can combine to produce the (S,G) multicast route. The type 6 route informs the PE router that a receiver is interested in group G. The source active route

informs the PE router that a source S is transmitting data to group G. MVPN combines this information to produce a multicast join message and advertises this to the ingress PE router, as determined by the single-forwarder election.

For some service providers, the SPT-only implementation is not ideal because it creates a restriction on C-RP configuration. For a PE router to create customer multicast routes from (*, C-G) join messages, the router must learn about active sources through MVPN type 5 source-active routes. These source-active routes can be originated only by a PE router. This means that a PE router in the MVPN must learn about all PIM register messages sent to the RP, which is possible only in the following cases:

- The C-RP is colocated on one of the PEs in the MVPN.
- MSDP is run between the C-RP and the VRF instance on one of the PE routers in the MVPN.

If this restriction is not acceptable, providers can use RPT-SPT mode instead of the default SPT-only mode. However, because SPT-only mode does not transmit (*,G) routes between VPN sites, SPT-only mode has the following advantages over RPT-SPT mode:

- Simplified operations by exchanging and processing only source-tree customer multicast routes among PE routers
- Simplified operations by eliminating the need for the service provider to suppress MVPN transient duplicates during the switch from RPT to SPT
- Less control plane overhead in the service provider space by limiting the type of customer multicast routes exchanged, which results in more scalable deployments
- More stable traffic patterns in the backbone without the traffic shifts involved in the RPT-SPT mode
- Easier maintenance in the service provider space due to less state information

RELATED DOCUMENTATION

[Rendezvous Point | 105](#)

[Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees | 106](#)

[Understanding PIM Sparse Mode | 108](#)

[Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs | 111](#)

[Configuring VRF Route Targets for Routing Instances for an MBGP MVPN | 115](#)

Configuring VRF Route Targets for Routing Instances for an MBGP MVPN

By default, the VPN routing and forwarding (VRF) import and export route targets (configured either using VRF import and export policies or using the **vrf-target** statement) are used for importing and exporting routes with the MBGP MVPN network layer reachability information (NLRI).

You can use the **export-target** and **import-target** statements to override the default VRF import and export route targets. Export and import targets can also be specified specifically for sender sites or receiver sites, or can be borrowed from a configured unicast route target. Note that a sender site export route target is always advertised when security association routes are exported.

NOTE: When you configure an MBGP MVPN routing instance, you should not configure a target value for an MBGP MVPN specific route target that is identical to a target value for a unicast route target configured in another routing instance.

Specifying route targets in the MBGP MVPN NLRI for sender and receiver sites is useful when there is a mix of sender only, receiver only, and sender and receiver sites. A sender site route target is used for exporting automatic discovery routes by a sender site and for importing automatic discovery routes by a receiver site. A receiver site route target is used for exporting routes by a receiver site and importing routes by a sender site. A sender and receiver site exports and imports routes with both route targets.

A provider edge (PE) router with sites in a specific MBGP MVPN must determine whether a received automatic discovery route is from a sender site or receiver site based on the following:

- If the PE router is configured to be only in a sender site, route targets are imported only from receiver sites. Imported automatic discovery routes must be from a receiver site.
- If the PE router is configured to be only in a receiver site, route targets are imported only from sender sites. Imported automatic discovery routes must be from a sender site.
- If a PE router is configured to be in both sender sites and receiver sites, these guidelines apply:
 - Along with an import route target, you can optionally configure whether the route target is from a receiver or a sender site.
 - If a configuration is not provided, an imported automatic discovery route is treated as belonging to both the sender site set and the receiver site set.

RELATED DOCUMENTATION

[Rendezvous Point | 105](#)

[Understanding Multicast Rendezvous Points, Shared Trees, and Rendezvous-Point Trees | 106](#)

[Understanding PIM Sparse Mode | 108](#)[Configuring Shared-Tree Data Distribution Across Provider Cores for Providers of MBGP MVPNs | 111](#)[Configuring SPT-Only Mode for Multiprotocol BGP-Based Multicast VPNs | 113](#)

Static Pseudowire Provisioning for VPLS Services

A virtual private LAN service (VPLS) domain consists of a set of PE routers that act as a single virtual Ethernet bridge for the customer sites connected to these routers. By configuring static pseudowires for the VPLS domain, network providers do not need to configure the LDP or BGP protocols that are normally used for signaling. Static pseudowires require that you configure a set of in and out labels for each pseudowire configured for the VPLS domain. You still need to configure a VPLS identifier and neighbor identifiers for a static VPLS domain. You can configure both static and dynamic neighbors within the same VPLS routing instance.

The manual configuration of a static pseudowire in MPLS requires configuring many parameters at the two PE sides. We recommend that you configure the parameters on both sides the same to make the pseudowire operational. A mismatch in one or more parameters on either end can cause the pseudowire not to operate correctly. In the case of a dynamic pseudowire, these parameters are negotiated at either end through a signaling session. For static pseudowire, there is no such signaling session and therefore parameters must be pre-selected and configured on both PE ends.

To enable static VPLS on a router, you need either to configure a virtual tunnel interface (requires the router to have a tunnel services PIC) or to configure a label-switching interface (LSI).

To configure an LSI, include the **no-tunnel-services** statement at the **[edit protocols vpls static-vpls]** hierarchy level.

NOTE: This **Enable Static PW Labels** option is available in the Point-to-Multipoint and Multipoint-to-Multipoint service types when the signaling type is LDP and only in the Point-to-Multipoint service type when the signaling type is BGP.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696](#)[Creating a Point-to-Multipoint E-LAN Service Definition | 726](#)[Creating a Service Definition for VPLS Access into Layer 3 Networks | 760](#)

2

PART

Getting Started With Connectivity Services Director

Understanding Connectivity Services Director System Administration and
Preferences | **118**

Understanding Connectivity Services Director System Administration and Preferences

IN THIS CHAPTER

- [Understanding Connectivity Services Director User Administration | 118](#)
- [Understanding the System Tasks Pane | 119](#)
- [Audit Logs Overview | 120](#)
- [Viewing Audit Logs From Connectivity Services Director | 121](#)
- [Managing Jobs | 122](#)
- [Collecting Logs for Troubleshooting | 124](#)
- [Setting Up User and System Preferences | 125](#)

Understanding Connectivity Services Director User Administration

Connectivity Services Director application uses the user administration features of Junos Space Network Management Platform to add, delete, and edit user accounts and roles. For more information on user administration, see *Junos Space Network Application Platform User Guide*.

When you install the Connectivity Services Director application, additional user administration options specific to the application are available in Junos Space. In addition to the Super Administrator role, the following predefined roles are also available to Connectivity Services Director users:

- **Device Manager role**---allows an administrator to discover devices.
- **Service Manager role**--allows an administrator to perform device pre-staging actions including discovering and assigning device roles.
- **Service Designer role**--allows an administrator to create and publish a service definition.
- **Service Activator (less privileged) role**---allows an administrator to perform provisioning tasks including creating and managing customers, service orders, and services.

NOTE: You can create custom roles to grant users different access rights. Access is controlled at the task category level. If you grant a user access to a task category, the user has access to all tasks in that category.

Access to Connectivity Services Director system preferences is controlled by user access rights. For more information, see [“Setting Up User and System Preferences” on page 125](#)

If you try to log in to Connectivity Services Director by using an account that does not have access rights to any Connectivity Services Director task category, you are redirected to Junos Space instead.

RELATED DOCUMENTATION

Connectivity Services Overview 2
Benefits of a Unified User Interface for Routing and Tunnel Services with Connectivity Services Director 14
Connectivity Services Director Overview 15
Understanding the Connectivity Services Director User Interface 16
Understanding the Usage and Layout of Connectivity Services Director Views and Tasks 24
Understanding Task Categories in Connectivity Services Director 26
Logging In to Connectivity Services Director 29
Logging Out of Connectivity Services Director 32

Understanding the System Tasks Pane

The System Tasks pane provides tasks for viewing audit logs of Connectivity Services Director user activities, for managing jobs, and for collecting troubleshooting logs.

To access the System Tasks pane, click **System** in the Connectivity Services Director banner. The tasks are described in [Table 11 on page 119](#).

Table 11: System Tasks

Task	Description
View Audit Logs	View a history of user activities on Connectivity Services Director, including log in, log out, and task initiation and completion.

Table 11: System Tasks (*continued*)

Task	Description
Manage Jobs	View all jobs that are scheduled to run or have been run by Connectivity Services Director. You can cancel jobs that are in progress or scheduled to run in the future.
Collect Jobs for Troubleshooting	Download a zip file containing logs and troubleshooting data from both Connectivity Services Director and Junos Space.

RELATED DOCUMENTATION

[Understanding Connectivity Services Director User Administration | 28](#)

[Audit Logs Overview | 120](#)

Audit Logs Overview

Audit logs provide a record of login history and user-initiated tasks that are performed from the user interface. From the Audit Logs page, you can monitor user login–logout activity over time, track device management tasks, view services that were provisioned on devices, and so forth. Audit logging does not record non-user initiated activities, such as device-driven activities, and is not designed for debugging purposes.

Administrators can sort and filter on audit logs to determine which users performed what actions on what objects at what time. For example, an administrator can use audit log filtering to track the user accounts that were added on a specific date, track configuration changes across a particular type of device, view services that were provisioned on specific devices, or monitor user login–logout activity over time.

Over time, Connectivity Services Director will archive a large volume of log entries. Such log entries might or might not be reviewed, but they must be retained for a period of time.

The audit logs can be saved to a local server (the server that functions as the active node for Connectivity Services Director) or a remote network host or media.

RELATED DOCUMENTATION

[Viewing Audit Logs From Connectivity Services Director | 121](#)

[Collecting Logs for Troubleshooting | 124](#)

Viewing Audit Logs From Connectivity Services Director

Audit logs are generated for login activity and tasks that are initiated from the Connectivity Services Director application. The Audit Logs page displays the logs for all user-initiated activities.

You can do the following on the Audit Logs page:

- Sort, filter, and search the log entries using the standard table manipulation features in Connectivity Services Director.
- Obtain more information about a log entry by double-clicking the entry or by selecting the entry and clicking **Show Details**. The Audit Log Details window is displayed.
- For a user-initiated task that runs as a job, you can obtain more information about the job by clicking the job ID in the Job ID column.

To display the Audit Logs page:

1. Click **System** in the Connectivity Services Director banner.
2. Select **View Audit Logs** from the Tasks pane.

The Audit Logs page is displayed with the fields listed in [Table 12 on page 121](#).

Table 12: Audit Logs Page Fields

Field	Description
User Name	The login ID of the user that initiated the task
User IP	The IP address of the client computer from which the user initiated the task
Task	The name of the task that triggered the audit log
Time	The data and time when the user initiated the task
Result	The execution result of the task that triggered the audit log: <ul style="list-style-type: none"> • Success—Job completed successfully • Failure—Job failed and was terminated • Job Scheduled—Job is scheduled but has not yet started
Description	A description of the audit log
Job ID	The job ID for any task that runs as a job

RELATED DOCUMENTATION

[Audit Logs Overview | 120](#)

[Collecting Logs for Troubleshooting | 124](#)

Managing Jobs

Connectivity Services Director enables you to view and manage jobs. You can view the status of completed jobs and cancel the jobs that are scheduled to execute at a later time or jobs that are in progress.

The Job Management page, accessible as a System task, enables you to view and manage all jobs. In addition, Connectivity Services Director enables you to view special pre-filtered versions of this page from various other tasks, such as View Discovery Status or View Image Deployment Jobs. These pages contain the same fields (although some fields might be hidden) and have the same functionality as the Job Management page, but they list only those jobs relevant to particular tasks.

To display the Job Management page:

1. Click **System** on the Connectivity Services Director banner.
2. Select **Manage Jobs** from the Tasks pane. The Job Management page appears.
3. To view the details of a job, select a row and click **Show Details** or double-click a row.
4. To cancel a scheduled job, select a job that is scheduled for a later time or a job that is in progress and click **Cancel**.

The fields in the Job Management page are described in [Table 13 on page 123](#). To view any hidden column, keep the mouse on any column heading and select the down arrow and then click Columns. Select the check box to display the hidden columns.

NOTE: You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

NOTE: Details of jobs initiated from Connectivity Services Director will be available only from Connectivity Services Director. These jobs will not be listed in the Job Management pane in Junos Space platform and vice-versa.

Table 13: Job Management Page Fields

Field	Description
Job ID	The unique ID assigned to the job
Name	The name of the job
Percent	The percentage of completion of the job
State	<p>The status of the job:</p> <ul style="list-style-type: none"> • Success—Job completed successfully • Failure—Job failed and was terminated • Job Scheduled—Job is scheduled but has not yet started • In progress—Job is has started, but not completed • Cancelled—Job is cancelled
Job Type	The type of the job
Summary	Summary of the job scheduled and executed with status
Scheduled Start Time	The time when the job is scheduled to start
Actual Start Time	The actual time when the job started
End Time	The time when the job was completed
User	The login ID of the user that initiated the task
Recurrence	The recurrent time when the job will be restarted.

RELATED DOCUMENTATION

[Managing Service Configuration Deployment Jobs | 1080](#)
[Deploying Services Configuration to Devices | 1083](#)

Collecting Logs for Troubleshooting

Connectivity Services Director enables you to collect logs and other data from both Connectivity Services Director and Junos Space that can assist in managing and monitoring Connectivity Services Director servers.

Connectivity Services Director collects the logs and troubleshooting data into a compressed file that you can download. This file is named **troubleshoot_yyyy-mm-dd_hh-mm-ss.zip**—for example, **troubleshoot_2012-12-21_11-25-12.zip**. The date and time in the file name is the server Coordinated Universal Time (UTC) date and time.

To retrieve troubleshooting data and log files, follow these steps:

1. Click **System** on the Connectivity Services Director banner.
2. From the Tasks pane, click **Collect Logs for Troubleshooting**. The Collect Logs for Troubleshooting page appears.
3. Click the **Download troubleshooting data and logs from Connectivity Services Director and Junos Space** link.

Connectivity Services Director begins collecting the logs and data. It can take a few minutes for Connectivity Services Director to collect the information and create the zip file.

4. When the standard file download window for your browser opens, save the **troubleshoot_yyyy-mm-dd_hh-mm-ss.zip** file.
5. When you contact the Juniper Technical Assistance Center, describe the problem you encountered and provide the JTAC representative with the **troubleshoot.zip** file.

[Table 14 on page 124](#) lists the files included in the **troubleshoot_yyyy-mm-dd_hh-mm-ss.zip** file.

Table 14: Log Files in the troubleshooting.zip File

Description	Location
Jboss log files	<code>/var/log/jboss/servers/server1</code>
Connectivity Services Director application log files	<code>/var/log/jboss/CSD.log</code>
Connectivity Services Director monitoring log files	<code>/var/log/jboss/CSDMoniotring.log</code>
MSS OS adapter log files	<code>/home/jmp/mssosadpater/var/errorLog/</code>
Daemon log files	<code>/opt/opennms/logs/daemon/</code>
Platform log files	<code>/var/log/platform</code>

Table 14: Log Files in the troubleshooting.zip File (continued)

Description	Location
Access Log Files	/var/log/httpd
Log files for Apache, NMA, Webproxy	/var/log/httpd/
Watchdog log file	/var/log/

RELATED DOCUMENTATION

[Audit Logs Overview | 120](#)
[Viewing Audit Logs From Connectivity Services Director | 121](#)

Setting Up User and System Preferences

IN THIS SECTION

- [Accessing the Preferences page | 126](#)
- [Choosing Server Time or Local Time | 126](#)
- [Specifying Search Preferences | 127](#)
- [Retaining Connectivity Services Director Reports | 127](#)
- [Modifying Services Activation Parameter Settings | 127](#)
- [Specifying Topology Preferences | 134](#)
- [Changing Monitor Mode Settings | 134](#)
- [Changing Alarm Settings | 137](#)
- [Disabling Optical Performance Monitoring | 165](#)
- [Specifying NorthStar Controller Preferences | 166](#)

Depending on your system authority, Preferences page can display either user settings or a combination of user settings and system settings. One or more of these preference tabs appear when you open the Preferences page:

- **User**—All users can choose whether monitors and reports display local time or server time.
- **Search**—Administrators can configure options for search indexing.
- **Monitoring**—Network Administrators can change the polling interval for data collection for Monitor mode monitors and enable or disable the internal processes used for data collection.
- **Fault**—Network Administrators can enable or disable alarms. They can also set the retention period for alarms and the number of events per alarm.
- **Report**—Network Administrators can specify length of time Connectivity Services Director reports are retained.
- **Topology**—Network Administrators can specify the topology server to which the Connectivity Services Director application can establish a connection. Also, you can specify settings for the automatic update and refresh of the topology. In addition, you can define a retention period for the deleted links in Topology.
- **Service Activation**—Network Administrators can modify the configuration settings for services activation-related components or functionalities of the Connectivity Services Director application.
- **Optical**—Network Administrators can enable or disable optical performance monitoring.
- **NorthStar**—Network Administrators can select NorthStar Controller for the management of LSPs.

Based on the Preference settings, LSPs will be deployed either through CSD or through NorthStar Controller using REST APIs.

This topic describes:

Accessing the Preferences page

To open the Preferences page, click  in the Connectivity Services Director banner and select **Preferences**.

The Preferences page opens with User Preferences as the default tab.

Choosing Server Time or Local Time

All users can specify whether Connectivity Services Director displays local time or the server's time in monitors and reports on the User Preferences tab. The default setting is to display local time. To change the setting to display the server's time:

1. In the Preferences page, select **Use Server Time** from the list.
2. Click **OK** to save your changes or click **Cancel** to close Preferences.

Specifying Search Preferences

Connectivity Services Director indexes the device inventory data periodically to enable users to perform efficient searches. You can specify a time interval after which Connectivity Services Director initiates the next indexing on the Search tab. You can also specify to stop indexing while devices are imported into Connectivity Services Director. If you are running short of system memory, selecting this option can help save some memory and speed up the discovery and import of new devices. By default this option is selected and the search index update interval is set to 900 seconds.

Retaining Connectivity Services Director Reports

By default, Connectivity Services Director keeps reports for 30 days. However, Network Administrators can change the retention period from 0 to 365 days. To change the setting, move the slider right or left on the Report tab of Preferences to the new setting. Click **OK** to save the setting.

Modifying Services Activation Parameter Settings

To understand the parameters of the services-activation settings, such as the attributes and functionalities that apply to the management, provisioning, and monitoring of E-Line, IP, RSVP LSP, and E-LAN services, refer to [Table 15 on page 127](#).

Table 15: Parameters in the Services Activation Tab

Fields	Description
Deployment	
Check service version	Select this check box to validate the version of the service being configured.
Deploy configuration to the device	Select this check box to deploy the configuration to the device.
Enable service alarms	Select this check box to enable the service alarms. Enabling the service alarms causes a GUI impact on the Connectivity Services Director application. When you select the check box and deploy the service, the interface goes down, resulting in the failure to update the fault status. When you right-click Service and select View Service Alarms , the latter does not appear in the results.
Save configuration in XML format	Select this check box to save the configuration of the device in XML format.
Show configuration in set format	Select this check box to display the configuration in set format.

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
Use two-phase commit for service provisioning	Select this check box to push the configuration on all the network elements automatically, making either one or all successful.
Use vlan maps for E-Line services	<p>When this check box is selected, normalization of VLAN tags is performed using the input or output VLAN maps.</p> <p>This check box is selected by default.</p> <p>NOTE: Starting from Connectivity Services Director Release 2.1R1 onward, Use vlan maps for flexible tagged services under Setting Up User and System Preferences is renamed to Use vlanmaps for E-Line services.</p>
Use vlan maps for flexible tagged services instead of normalized vlan (VPLS)	<p>When this check box is cleared, normalization of VLAN tags is performed using normalized tags under routing instance.</p> <p>This check box is cleared by default.</p> <p>NOTE: Starting from Connectivity Services Director Release 2.1R1 onward, normalization of VLAN tags is performed using normalized tags under routing instance while setting up user and system preferences.</p>
Allow (Stacked) Vlan-Tagging mode for Physical Interface	<p>When this check box is selected, stacked VLAN tagging for all logical interfaces on the physical interface is enabled for EX Series devices.</p> <p>This check box is cleared by default.</p>
Block deployment on pending notifications	<p>Select this check box to cause a validation to be performed to determine if any of the selected devices have pending out-of-band notification, before deploying a service order. If a pending out-of-band notification exists for a device, deployment is blocked with the following message:</p> <p>Cannot deploy service order, since pending notification exists for device(s): <dev-1>, <dev-2>, <dev-3></p>
Audit	
Enable Functional Audit after deployment	Select this check box to perform the functional audit automatically, after the service is deployed successfully. By default, the functional audit is not checked. Extra time is taken to complete both the functional audit and deployment.

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
Functional Audit Waiting Time after deployment	<p>Specify the initial wait time to auto-schedule a functional audit job after deployment.</p> <p>If the entered value is greater than 30 minutes, it is reset to 30 minutes. If the entered value is less than 1 minute, the wait time is ignored.</p> <p>The range is from 1 minute through 30 minutes.</p>
Perform Functional Audit on Control plane only	Select this check box to make the functional audit ignore the data plane verification and to consider only the control plane.
User Interface	
Allow template modification for service	Select this check box to allow the templates to be changed during the service modification.
Bandwidth Combo Items Count	<p>Specify the bandwidth combo items count.</p> <p>In Create E-Line service order page, if the bandwidth range exceeds the bandwidth combo items count, then the bandwidth input is taken in text field.</p> <p>The default value is 100.</p>
Service Detail Wait Time (sec)	Specify the period of time in seconds as the wait period for retrieving service details during service template modification.
Monitoring	
Perform Monitoring on Failed Functional Audit	Select this check box to perform monitoring if the functional audit fails.
Pseudowire Redundancy Transition TimeDelay	<p>Select this check box to dump the configuration files.</p> <p>Specify the time delay to issue the remote procedure call (RPC) call for redundancy service. Since there is no support for the fault management for redundancy service, it should not update the fault status as down, when the interface goes down as the service will be running with the help of backup device. The RPC is issued to check the status of the service. If the value of this time delay is 2 seconds and the interface goes down, it waits for 2 seconds to check whether the service is up, with the help of the backup device and correspondingly updates the fault status.</p> <p>The default value is 2 seconds.</p>

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
Statistics Aggregation Reporting	Specify the manner in which the aggregated results are returned for a query that polls and retrieves data from devices. Two aggregation values are supported: <ul style="list-style-type: none"> • Total: Sum of the number of packets received in the interval • Average: Average of the total number of packets received in the interval
Logging	
Dump Configuration Files	By default, the configuration files are not dumped into the log directory. This is enabled, if there is a need to provide troubleshooting to Juniper Networks Technical Assistance Center (JTAC).
Dump Deployment Data	Select this check box to write the configlets and error response from the JUNOS devices into the log directory..
Log Directory	Specify the default path of the log directory: <code>/var/tmp/jboss</code>
Prestage Devices	
Pre-stage Wait Time (Sec)	Specify the number of seconds for which the task to trigger a job for prestaging devices must wait after receiving the first notification for prestaging devices. For example, if you specify the prestage wait time as 20 seconds, the prestaging task waits for a period of 20 seconds, after receiving the first notification for prestaging devices, and then initiates the prestaging-devices job.
Pre-stage Idle Time (Sec)	Specify the number of seconds after which the job for prestaging devices is initiated, if no notification is received during the idle period. For example, if you specify the prestage idle time as 10 seconds and if no notification for prestaging devices is received within this period, the job for prestaging devices is triggered immediately after 10 seconds. The prestage idle time value takes precedence over the prestage wait time value.
Loopback Unit	Specify the logical unit of the loopback interface that must be used as the default loopback logical interface for all provisioning tasks that are initiated from Connectivity Services Director. The default logical unit for the loopback interface is 0.
Route Target	

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
BeginIndex	<p>Specify the least value in the preferred range of numbers, among which a certain number is assigned for each BGP service. Route target allows you to distribute VPN routes to only the routers that need them. When a route target value is entered manually, it should be either of the following two formats: Autonomous System number format or IPv4 format. For Autonomous System number format, the pattern is as-number:2-byte-number. For example, target:100:200.</p> <p>Range: The Autonomous System number format number can be in the range from 1 through 65,535.</p> <p>The IPv4 format is ip-address:2-byte-number. For example, target:10.1.1.1:2.</p>
EndIndex	<p>Specify the greatest value in the preferred range of numbers, among which a certain number is assigned for each BGP service. Route target allows you to distribute VPN routes to only the routers that need them. When a route target value is entered manually, it should be either of the following two formats: Autonomous System number format or IPv4 format. For Autonomous System number format, the pattern is as-number:2-byte-number. For example, target:100:200.</p> <p>Range: The Autonomous System number format number can be in the range from 1 through 65,535.</p> <p>The IPv4 format is ip-address:2-byte-number. For example, target:10.1.1.1:2. The EndIndex value should be lesser than the maximum assigned value.</p>
Virtual Circuit ID	
BeginIndex	<p>Specify the least value in the preferred range of numbers, among which a certain number is assigned as the VirtualCircuitID to the new circuit created. This VCID can be manually chosen by the customer or auto-generated by the system. For example, if BeginIndex = 100 and EndIndex = 200, then the VCID would be somewhere between 100 and 200.</p> <p>Minimum: 1</p> <p>The value of BeginIndex should be less than or equal to EndIndex value.</p> <p>The range is from 0 through 200000.</p>

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
EndIndex	<p>Specify the greatest value in the preferred range of numbers, among which a certain number is assigned as the VirtualCircuitID to the new circuit created. This VCID can be manually chosen by the customer or auto-generated by the system. For example, if BeginIndex = 100 and EndIndex = 200, then the VCID would be somewhere between 100 and 200.</p> <p>Maximum: 2147483647.</p> <p>The range is from 0 through 200000.</p>
Performance Monitoring	
DataSetSize	<p>DataSetSize is the size of the performance monitoring data set in days. This field indicates the number of days of performance monitoring data could be stored for display.</p> <p>The default value is 2880.</p>
Enable Performance Monitoring through scripts	<p>Select the check box to collect the performance data through scripts and opennms will store the data in its database. If this check box is not selected, then performance data such as one-way delay, two-way delay, and frame loss are collected through RPC and stored in the application database.</p>
OSS Config Parameters	
Alcatel Primary Server IP	Specify the IP address of the primary server.
Alcatel Primary Server Port	Specify the port number of the primary server.
Backup Server IP	Specify the IP address of the backup server.
Backup Server Port	Specify the port number of the backup server.
HTTP Connection Timeout	Specify the duration of HTTP connection before the time-out elapses.
Maximum API Requests	Specify the maximum number of simultaneous API requests permitted.
OSS Log Directory	Specify the directory path of the OSS log directory.
OSS Log Filename	Specify the OSS log filename.
OSS User Name	Specify the user name for accessing the OSS server.

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
OSS User Password	Specify the hashed password for accessing the OSS server.
Synchronize OSS Inventory daily at given time	Sets the daily time at which the CPP system synchronizes third-party devices, added or deleted from the CPP system, with the OSS server.
Use primary server	If the check box is enabled, the CPP system communicates with the primary OSS server.
Service Decommission	
Device Sync Wait Time	<p>Specify the device synchronization waiting time. This is the maximum wait time to complete the device synchronization. After this time duration, irrespective of the device synchronization status, the resources are released.</p> <p>The default value is 60 seconds.</p> <p>The range is from 30 seconds through 300 seconds.</p>
Wait for Device Sync Before Releasing Resource	Select this check box to wait for the device synchronization before resources are released. To revert the decommissioning to the normal behavior, clear this check box.
Allow IFD Template Deletion	<p>If this option is enabled, the IFD template associated with a service is deleted when,</p> <ul style="list-style-type: none"> the template is deleted, or the endpoint to which template is associated is deleted, or the service is decommissioned. <p>CAUTION: Deleting IFD (physical interface) templates can impact services on the IFL (logical interface) belonging to the IFD.</p>
Service Recovery	
OutofBand Notification	<p>Select either of the following options from the OutofBand Notification Action list to specify the action you want to be performed when an OutOfBand notification is received by Connectivity Services Director:</p> <ul style="list-style-type: none"> Make Device OutOfSync—Causes the device to be made OutOfSync and disables subsequent provisioning on that device until it changes to the In Sync state again Ignore Notification—Causes the notification to be ignored and device will remain InSync

Table 15: Parameters in the Services Activation Tab (*continued*)

Fields	Description
Store OutofBand Notification XML	Select the check box to enable the storage of OutOfBand notification XML in the Connectivity Services Director database. By default, this check box is not selected, which disables the saving of OutofBand notification XML in the Connectivity Services Director database.

Specifying Topology Preferences

From the **Topology** tab of the Preferences page (which you can launch by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences), you can specify the topology server IP and the credentials for enabling the Connectivity Services Director to connect to the topology server.

For Layer 2 topology settings, you can also disable the automatic updates to the topology and, instead, enable the topology updates to be manually triggered by selecting the **Disable Autoupdate of Topology** check box. In the **Deleted Link Retention Period (Days)** field, drag the square over the line to specify the number of days that you might want to retain the deleted link.

For Layer 3 topology settings, you can select or clear the **Use PCEP** check box. Select the **Use PCEP** check box to use the Path Computation Element Protocol (PCEP) for discovery of LSPs. PCEP enables communication between a PCC and the CSD-Topology to learn about the network and LSP path state and communicate with the Path Computation Clients (PCCs). By default, this check box is not selected.

Enter the server IP address in the Topology Server field, and the authentication credentials in the Username and Password fields.

In the **Refresh Topology Interval (days)** field, drag the square over the line to specify the frequency in number of days at which the Layer 3 topology must be refreshed and displayed in the Topology View. By default, the topology is refreshed once every day. Drag the square to the leftmost end of the line to disable the refresh of topology. Drag the square to the rightmost end of the line to enable the refresh of topology once every 365 days or a year, which is the largest frequency you can specify for the refresh setting.

Changing Monitor Mode Settings

IN THIS SECTION

- [Disabling Data Collection for Monitors | 135](#)
- [Changing the Polling Interval | 136](#)
- [Specifying Database History Retention | 137](#)

The Monitoring tab of Preferences has three tabs under it. These are:

- **Monitor Settings**—Enables you to change the default polling interval for data collection for Monitor mode monitors. You can also disable or reen able the internal processes used for data collection on this sub-tab.
- **Client Session History**—Enables you to set the retention period for history records and the frequency that these records are checked for deletion.

This section describes:

Disabling Data Collection for Monitors

Connectivity Services Director internally gathers data for monitors by using a set of data collection processes. You can disable these data collectors if they do not pertain to your installation. For example, if you do not use Virtual Chassis, you can disable the data collection processes used for Virtual Chassis.

The data collection processes are divided into the following categories:

- Equipment
- FM
- Traffic

One data collector can be used by multiple monitors. Likewise, some monitors can be supported by multiple data collectors. These data collectors are enabled by default. To ensure proper data collection, if you enable the equipment data collectors, you must also enable the traffic collectors..

To disable or reen able a data collector:

1. Determine which monitors are used by the data collectors. Use [Table 16 on page 135](#) to determine the relationship between the data collectors and the monitors.

Table 16: Monitor Mapping for Data Collectors

Monitor	Data Collector	Category
Show Interface Statistics	ProvisioningMonitorInterfaceStatsCollector	Equipment
Show Interface Status	ProvisioningMonitorInterfaceStatusCollector	Equipment
Service Traffic, Service Summary, Service Transport	ProvisioningMonitorServiceStatusCollector	Equipment
LSP Statistics	ProvisioningMonitorLSPStatsCollector	Equipment
LDP Statistics	ProvisioningMonitorLDPStatsCollector	Equipment
Service Performance	ProvisioningMonitorY1731PMCollector	Equipment

Table 16: Monitor Mapping for Data Collectors (*continued*)

Monitor	Data Collector	Category
RFC2544 Benchmarking Tests	ProvisioningMonitoringRFC2544Poller	Equipment
Port Status (physical)	EquipmentMonitorDeviceStatusCollector	Equipment
Traffic Trend	PortTrafficMonitorCollector	Traffic
Alarms	FMAAlarmCountCollector	FM
Collection of LSPs and Service Association for Topology View	ProvisioningMonitorLSPToServiceAssociationCollector	Traffic

2. Clear the check box to disable the collector or select to enable the collector.
3. Click **Save** and **Close** to save the configuration and to close the window.

Changing the Polling Interval

The frequency at which data is collected is determined by the polling interval. [Table 17 on page 136](#) shows the default polling intervals used by each data collector.

Table 17: Default Polling Intervals

Collector	Polling Interval
ProvisioningMonitorInterfaceStatsCollector	5 minutes
ProvisioningMonitorInterfaceStatusCollector	10 minutes
ProvisioningMonitorServiceStatusCollector	10 minutes
ProvisioningMonitorLSPStatsCollector	10 minutes
ProvisioningMonitorLDPStatsCollector	5 minutes
ProvisioningMonitorY1731PMCollector	5 minutes
ProvisioningMonitoringRFC2544Poller	5 minutes
EquipmentMonitorDeviceStatusCollector	10 minutes
PortTrafficMonitorCollector	10 minutes

Table 17: Default Polling Intervals *(continued)*

Collector	Polling Interval
ProvisioningMonitorLSPToServiceAssociationCollector	5 minutes

To change the polling interval:

1. Select the polling interval for a data collector in the Monitor Settings table.
2. Type the new interval level in whole minutes. For example, do not specify 1.5 minutes. Recommended intervals are 5, 10, or 20 minutes.
3. Click **OK** and then **Yes** to verify the change to the configuration.

Specifying Database History Retention

To keep the database manageable, the system periodically checks the age of the records and retires those that have past an expiration date. By default, Connectivity Services Director ages database records off at 90 days and runs a database cleanup every 6 hours.

Use the Client Session History sub-tab to change the default values:

1. Select from the lists new values.
 - Age of history records (in days) from 1 to 365 days.
 - Cleanup job frequency (in hours) from 1 through 24 hours.
2. Click **OK** to save the changes.

Changing Alarm Settings

IN THIS SECTION

- [Configuring Global Alarm Notifications | 138](#)
- [Retaining Alarm History | 138](#)
- [Specifying Event History | 138](#)
- [Enabling Alarms | 138](#)
- [Changing the Severity of Individual Alarms | 164](#)
- [Configuring Individual Alarm Notifications | 165](#)

Use the Fault tab to enable individual alarms, set the retention period for alarms, configure alarm notifications, and to specify the number of events to keep for each alarm. The Fault tab has multiple sections, which you can expand and collapse by clicking the arrow next to the section title:

- Global Settings, for configuring Faults settings such as global alarm notifications and alarm data retention.
- Individual Alarms and Threshold Settings, for configuring settings for individual alarms.

This section describes the following tasks that you can perform by using the Fault tab:

Configuring Global Alarm Notifications

You can configure global e-mail notifications to be sent when any alarm with notifications enabled is generated. To configure global e-mail notifications, enter the e-mail addresses to receive global alarm notifications in the Alarm Notifications Destinations field in the Global Settings section. Separate addresses with a comma (.). For information about enabling notification for an alarm, see [“Configuring Individual Alarm Notifications” on page 165](#).

Retaining Alarm History

Use the **No. of days to keep Alarm** field in the Global Settings section to specify the number of days to keep alarm history. The default retention time is 120 days; but you can specify a period of 7 through 1000 days. Specifying a longer retention time consumes more database resources. To change the alarm retention duration, type a new value and click **OK** and **Yes** to confirm the change.

Specifying Event History

Use the **Events/Alarm** field in the Global Settings section to specify the number of event entries that are kept in the alarm history. The default setting for events is 20. To change the setting, type a new value and click **OK** and **Yes** to confirm the change.

Enabling Alarms

Ensure all devices are configured to send traps to Connectivity Services Director. This task is performed for the devices in Deploy mode through Set SNMP Trap Configuration.

Use the Individual Alarms and Threshold Settings section to disable and re-enable individual alarms or all alarms. Alarms appear on both tabs in the section: Alarm Settings and Threshold Settings. Fault alarms are preconfigured and initially enabled. To enable or disable alarms:

1. (Optional) Sort the alarms. By default, the list of alarms is sorted alphabetically within each category. You can also sort by description or alarm severity within a category by clicking a column heading.
2. Review the alarms and either select the check box in the heading to select all of the alarms or select the check box for the individual alarms you want to enable. For a full description of each of the alarms, see [Table 18 on page 139](#).
3. Click **OK** and **Yes** to confirm the alarm change.

Table 18: Alarm Descriptions

Alarm Name	Description	Device Type
<i>BFD</i>		
BfdSessionDetectionTimeAlarm	Generated when the threshold value for detection time is set and the BFD session detection-time adapts to a value greater than the threshold.	ACX, M, MX, and PTX Series routers
BfdSessionTxAlarm	Generated when the threshold value for transmit interval (in microseconds) is exceeded.	ACX, M, MX, and PTX Series routers
<i>BGP</i>		
BgpM2BackwardTransitionAlarm	Generated when the BGP FSM moves from a higher-numbered state to a lower-numbered state.	ACX, M, MX, and PTX Series routers
BgpM2EstablishedAlarm	Generated when the BGP Finite State Machine (FSM) enters the ESTABLISHED state.	ACX, M, MX, and PTX Series routers
<i>Chassis</i>		
FanFailureAlarm	Generated when the specified cooling fan or impeller has failed (is not spinning).	ACX, M, MX, and PTX Series routers
FEBSwitchoverAlarm	Generated when the Forwarding Engine Board (FEB) has switched over.	ACX, M, MX, and PTX Series routers
FRUCheckAlarm	Generated when the device has detected that a field-replaceable unit (FRU), has some operational errors and has gone into check state.	ACX, M, MX, and PTX Series routers
FRUFailedAlarm	Generated when a FRU has failed.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
FRUInsertionAlarm	Generated when the system detects that the specified FRU is inserted into the chassis.	ACX, M, MX, and PTX Series routers
FRUOfflineAlarm	Generated when the specified FRU goes offline.	ACX, M, MX, and PTX Series routers
FRUOnlineAlarm	Generated when the specified FRU goes online.	ACX, M, MX, and PTX Series routers
FRUPowerOffAlarm	Generated when the specified FRU is powered off.	ACX, M, MX, and PTX Series routers
FRUPowerOnAlarm	Generated when the specified FRU is powered on.	ACX, M, MX, and PTX Series routers
FRURemovalAlarm	Generated when the system detects that the specified FRU was removed from the chassis.	ACX, M, MX, and PTX Series routers
HardDiskFailedAlarm	Generated when the hard disk for the specified routing engine has failed.	ACX, M, MX, and PTX Series routers
HardDiskMissingAlarm	Generated when the hard disk in the specified routing engine is missing from the boot device list.	ACX, M, MX, and PTX Series routers
PowerSupplyFailureAlarm	Generated when the specified power supply has failed (bad DC output).	ACX, M, MX, and PTX Series routers
RedundancySwitchOverAlarm	Generated when a graceful Routing Engine switchover (GRES) occurs on a switch with dual Routing Engines or on a Virtual Chassis.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
TemperatureAlarm	Generated when the device has over heated.	ACX, M, MX, and PTX Series routers
<i>Cluster/Modo</i>		
Cluster Sync Failure	Generated when the cluster configuration failed to apply.	ACX, M, MX, and PTX Series routers
<i>Configuration (Configuration)</i>		
CmCfgChangeAlarm	Generated when the jnxCMCfgChgEventTable records a configuration management event.	ACX, M, MX, and PTX Series routers
CMRescueChangeAlarm	Generated when a change is made to the rescue configuration.	ACX, M, MX, and PTX Series routers
<i>Core and controllers (Controllers)</i>		
Device alarm	Generated when the device status changes (up to down or down to up).	ACX, M, MX, and PTX Series routers
<i>CoS</i>		
CoSAlmostOutOfDedicatedQueuesAlarm	Generated when only 10% of CoS queues are available.	ACX, M, MX, and PTX Series routers
CoSOutOfDedicatedQueuesAlarm	Generated when there are no more available dedicated CoS queues.	ACX, M, MX, and PTX Series routers
<i>DHCP</i>		
JdhcpLocalServerDupClientAlarm	Generated when a DHCP client is detected changing interfaces.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
JdhcpLocalServerIfLimitExceededAlarm	Generated when the client limit is reached on an interface.	ACX, M, MX, and PTX Series routers
Jdhcpv6LocalServerLimitExceededAlarm	Generated when the client limit is reached on an interface for DHCPv6.	ACX, M, MX, and PTX Series routers
<i>DOM</i>		
DomAlertSetAlarm	Generated when an interface detects Digital Optical Monitor (DOM) alarm conditions.	ACX, M, MX, and PTX Series routers
<i>General</i>		
Authentication Failure Alarm	Generated when a protocol message is received that is not properly authenticated.	ACX, M, MX, and PTX Series routers
Cold Start Alarm	Generated when a device is re-initializing and its configuration might have changed.	ACX, M, MX, and PTX Series routers
Link Down Alarm	Generated when a link is down. The trap is generated when the ifOperStatus object for a communication link is about to enter the down state from another state other than notPresent. This other state is indicated by the included value of ifOperStatus.	ACX, M, MX, and PTX Series routers
Link Up Alarm	Generated when a link comes up that was previously in the down state. The trap is generated when the ifOperStatus object for a communication link left the down state and transitioned into another state other than notPresent state. This other state is indicated by the included value of ifOperStatus.	ACX, M, MX, and PTX Series routers
Warm Start Alarm	Generated when a device is re-initializing and its configuration has not changed.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
<i>Generic (GenericEvent)</i>		
GenericEventTrapAlarm	Generated by an Op script or event policies. This notification can include one or more attribute-value pairs. The pairs are identified by the jnxEventAvAttribute and jnxEventAvValue objects.	ACX, M, MX, and PTX Series routers
<i>OTN Notification</i>		
FRU: OTN Admin Notification Set	Generated as a notification of an OTM alarm that is set. An alarm is triggered when an optical PIC or field-replaceable unit (FRU) is removed or reinserted, or transitions between in-service and out-of-service states.	PTX Series routers
ODU::OduKptmAlarm	Generated as Optical Channel Payload (OPU) Payload Type Mismatch defect trigger.	PTX Series routers
ODU::OduKTcm	Generated as OC target of evaluation (TOE) security functionality (TSF) defect trigger.	PTX Series routers
ODU::OduKTcm15MinThreshBBETCA	Generated as ODU Background Block Error Threshold crossing defect trigger in the 15-minute interval threshold.	PTX Series routers
ODU::OduKTcm15MinThreshBip8TCA	Generated as ODU Bit interleaved parity for SONET section overhead defect trigger in the 15-minute interval threshold.	PTX Series routers
ODU::OduKTcm15MinThreshESTCA	Generated as ODU errored seconds threshold-crossing defect trigger in the 15-minute interval threshold.	PTX Series routers
ODU::OduKTcm15MinThreshSESTCA	Generated as ODU severely errored seconds threshold-crossing defect trigger in the 15-minute interval threshold.	PTX Series routers
ODU::OduKTcm15MinThreshUASTCA	Generated as ODU unavailable seconds threshold-crossing defect trigger in the 15-minute interval threshold.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
ODU::OdukTcm15MinThreshBBETCA	Generated as ODU Background Block Error Threshold crossing defect trigger in the 15-minute interval threshold.	PTX Series routers
ODU::OdukTcm24HourThreshBip8TCA	Generated as ODU Bit interleaved parity for SONET section overhead defect trigger in the 24-hour or 1-day interval threshold.	PTX Series routers
ODU::OdukTcm24HourThreshESTCA	Generated as ODU errored seconds threshold-crossing defect trigger in the 24-hour or 1-day interval threshold.	PTX Series routers
ODU::OdukTcm24HourThreshSESTCA	Generated as ODU severely errored seconds threshold-crossing defect trigger in the 24-hour or 1-day interval threshold.	PTX Series routers
ODU::OdukTcm24HourThreshUASTCA	Generated as ODU unavailable seconds threshold-crossing defect trigger in the 24-hour or 1-day interval threshold.	PTX Series routers
ODU::OdukTcmAisAlarm	Generated as ODU Alarm Indication Signal defect trigger.	PTX Series routers
ODU::OdukTcmBdiAlarm	Generated as ODU Backward Defect Indication defect trigger.	PTX Series routers
ODU::OdukTcmCSfAlarm	Generated as ODU client signal failure alarm.	PTX Series routers
ODU::OdukTcmDegAlarm	Generated as ODU degradation alarm.	PTX Series routers
ODU::OdukTcmIaeAlarm	Generated as ODU incoming alignment error alarm.	PTX Series routers
ODU::OdukTcmLTCAAlarm	Generated as ODU threshold crossing alert (TCA) alarm.	PTX Series routers
ODU::OdukTcmLckAlarm	Generated as ODU locked defect trigger.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
ODU::OdukTcmOciAlarm	Generated as ODU open connection indication alarm.	PTX Series routers
ODU::OdukTcmSSfAlarm	Generated as ODU server signal failure alarm.	PTX Series routers
ODU::OdukTcmTimAlarm	Generated as ODU trace identifier mismatch alarm.	PTX Series routers
ODU::OtnOdukTcmNoAlarm	Generated as ODU no-alarm when threshold crossing alert occurs.	PTX Series routers
OTN Admin Notification Set	Generated as a notification when OTN alarm is set.	PTX Series routers
OTU::OdukTcmAisAlarm	Generated as OTU alarm indication signal trigger.	PTX Series routers
OTU::15MinThUnCorrectedWordsTCA	Generated as an alarm when OTU uncorrected words in the 15-minute threshold is exceeded.	PTX Series routers
OTU::15MinThreshBBETCA	Generated as an alarm when OTU background block error count in the 15-minute threshold is exceeded.	PTX Series routers
OTU::15MinThreshBip8TCA	Generated as an alarm when OTU bit interleaved parity count in the 15-minute threshold is exceeded.	PTX Series routers
OTU::15MinThreshESTCA	Generated as an alarm when errored seconds count in the 15-minute threshold is exceeded.	PTX Series routers
OTU::15MinThreshSESTCA	Generated as an alarm when severely errored seconds count in the 15-minute threshold is exceeded.	PTX Series routers
OTU::15MinThreshPreFECBERTCA	Generated as an alarm when pre-forward error correction bit error rate count in the 15-minute threshold is exceeded.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
OTU::15MinThreshUASTCA	Generated as an alarm when unavailable seconds count in the 15-minute threshold is exceeded.	PTX Series routers
OTU::24HourThreshBBETCA	Generated as an alarm when OTU background block error count in the 24-hour threshold is exceeded.	PTX Series routers
OTU::24HourThreshBip8TCA	Generated as an alarm when OTU bit interleaved parity count in the 24-hour threshold is exceeded.	PTX Series routers
OTU::24HourThreshESTCA	Generated as an alarm when errored seconds count in the 24-hour threshold is exceeded.	PTX Series routers
OTU::24HourThreshPreFECBERTCA	Generated as an alarm when severely errored seconds count in the 24-hour threshold is exceeded.	PTX Series routers
OTU::24HourThreshSESTCA	Generated as an alarm when pre-forward error correction bit error rate count in the 24-hour threshold is exceeded.	PTX Series routers
OTU::24HourThreshUASTCA	Generated as an alarm when unavailable seconds count in the 24-hour threshold is exceeded.	PTX Series routers
OTU:OtnLofAlarm	Generated as an OTN loss of signal alarm.	PTX Series routers
OTU:OtnLosAlarm	Generated as an OTN loss of frame alarm.	PTX Series routers
OTU:OtnLomAlarm	Generated as an OTN loss of multiframe alarm.	PTX Series routers
OTU:OtnNoAlarm	Generated as an OTN no alarm.	PTX Series routers
OTU:OtuBdiAlarm	Generated as an OTU backward defect indication alarm.	PTX Series routers

Table 18: Alarm Descriptions (continued)

Alarm Name	Description	Device Type
OTU:OtuBiaeAlarm	Generated as an OTU backward error indication alarm.	PTX Series routers
OTU:OtuDegAlarm	Generated as an OTU degraded alarm.	PTX Series routers
OTU:OtuFecExcessiveErrsAlarm	Generated as an OTU excessive errors alarm.	PTX Series routers
OTU:OtuLaeAlarm	Generated as an OTU incoming alignment defect alarm.	PTX Series routers
OTU:OtuSsAlarm	Generated as an OTU server signal alarm.	PTX Series routers
OTU:OtuTimAlarm	Generated as an OTN trail trace identifier mismatch defect alarm.	PTX Series routers
OTU:OtuTsfAlarm	Generated as an OTU TOE security functionality (TSF) alarm.	PTX Series routers
Optical::LOS	Generated as input loss of signal alarm.	PTX Series routers
Optical::WavelengthLockErr	Generated as wavelength lock error alarm.	PTX Series routers
Optical::PowerHighAlarm	Generated as Tx high power alarm.	PTX Series routers
Optical::PowerLowAlarm	Generated as Tx low power alarm.	PTX Series routers
Optical::BiasCurrentHighAlarm	Generated as Bias Current High alarm.	PTX Series routers
Optical::BiasCurrentLowAlarm	Generated as Bias Current Low alarm.	PTX Series routers
Optical::TemperatureHighAlarm	Generated as Temperature High alarm.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
Optical::TemperaturelowAlarm	Generated as Temperature low alarm.	PTX Series routers
Optical::TxPLLLockAlarm	Generated as transmitted phase-locked loop lock alarm.	PTX Series routers
Optical::RxPLLLockAlarm	Generated as received phase-locked loop lock alarm.	PTX Series routers
Optical::AvgPowerAlarm	Generated as average power alarm.	PTX Series routers
Optical::RxLossAvgPowerAlarm	Generated as Rx Loss Avg Power alarm.	PTX Series routers
Optical::LossOfACPowerAlarm	Generated as Loss of AC Power alarm.	PTX Series routers
Optical::TxPowerHighThreshAlert	Generated as transmitted temperature high threshold setting trigger.	PTX Series routers
Optical::TxPowerLowThreshAlert	Generated as transmitted temperature low threshold setting trigger.	PTX Series routers
Optical::RxPowerHighThreshAlert	Generated as received temperature high threshold setting trigger.	PTX Series routers
Optical::RxPowerLowThreshAlert	Generated as received temperature low threshold setting trigger.	PTX Series routers
Optical::ModuleTempHighThreshAlert	Generated as temperature high threshold setting trigger.	PTX Series routers
Optical::ModuleTempLowThreshAlert	Generated as temperature low threshold setting trigger.	PTX Series routers
Optical::24HourTxPowerHighThreshAlert	Generated as transmitted temperature high threshold setting trigger within the 24-hour period.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
Optical::24HourTxPowerLowThreshAlert	Generated as transmitted temperature low threshold setting trigger within the 24-hour period.	PTX Series routers
Optical::24HourRxPowerHighThreshAlert	Generated as received temperature high threshold setting trigger within the 24-hour period.	PTX Series routers
Optical::24HourRxPowerLowThreshAlert	Generated as received temperature low threshold setting trigger within the 24-hour period.	PTX Series routers
Optical::24HourModuleTempHighThreshAlert	Generated as temperature high threshold setting trigger within the 24-hour period.	PTX Series routers
Optical::24HourModuleTempLowThreshAlert	Generated as temperature low threshold setting trigger within the 24-hour period.	PTX Series routers
Optical::RxPowerHighAlarm	Generated as received high power alarm.	PTX Series routers
Optical::RxPowerLowAlarm	Generated as received low power alarm.	PTX Series routers
Optical::TxPowerHighWarning	Generated as Rx high power warning.	PTX Series routers
Optical::TxPowerLowWarning	Generated as Rx high power warning.	PTX Series routers
Optical::RxPowerHighWarning	Generated as Rx high power warning.	PTX Series routers
Optical::RxPowerLowWarning	Generated as Rx high power warning.	PTX Series routers
Optical::ModuleTempHigh	Generated as module temperature high warning.	PTX Series routers
Optical::ModuleTempLowWarning	Generated as module temperature low warning.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
Optical::RxCarrierFreqHigh	Generated as received carrier frequency high warning.	PTX Series routers
Optical::RxCarrierFreqLow	Generated as received carrier frequency low warning.	PTX Series routers
Optical::ChromaticDispHighWarning	Generated as chromatic dispersion high warning.	PTX Series routers
Optical::ChromaticDispLowWarning	Generated as chromatic dispersion low warning.	PTX Series routers
Optical::QLowWarning	Generated as low quality factor warning.	PTX Series routers
Optical::OSNRLowWarning	Generated as low signal-to-noise ratio warning.	PTX Series routers
Optical::CarrierFreqHighAlert	Generated as carrier frequency high threshold setting trigger.	PTX Series routers
Optical::CarrierFreqLowAlert	Generated as carrier frequency low threshold setting trigger.	PTX Series routers
Optical::24HourCarrierFreqHighAlert	Generated as carrier frequency high threshold setting trigger within the 24-hour threshold interval period.	PTX Series routers
Optical::24HourCarrierFreqLowAlert	Generated as carrier frequency low threshold setting trigger within the 24-hour threshold interval period.	PTX Series routers
<i>ILA Notification</i>		
ILA::edfaEabCaliTableErr	Generated when the EDFA in the direction from optical supervisory channel (OSC) A to OSC B (Eab) has a calibration table error.	PTX Series routers
ILA::edfaEabCaseTemperature	Generated when the EDFA case temperature exceeds the configured threshold in the direction from OSC A to OSC B.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
ILA::edfaEabInputLOS	Generated when the input loss of signal (LOS) is detected in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabOOG	Generated when the Out-of-Service Out-of-Group (OOS OOG) condition occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabOOP	Generated when the Out-of-Policy (OOP) condition occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabOutputLOS	Generated when an output LOS condition occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabPump1EOL	Generated when the end-of-life (EoL) state for pump 1 of the EDFA occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabPump2EOL	Generated when the end-of-life (EoL) state for pump 2 of the EDFA occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabPump1Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabPump2Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEabRFL	Generated when the radio frequency loss (RFL) occurs for the EDFA occurs in the direction from OSC A to OSC B.	PTX Series routers
ILA::edfaEbaCaliTableErr	Generated when the EDFA in the direction from optical supervisory channel (OSC) B to OSC A (Eba) has a calibration table error.	PTX Series routers
ILA::edfaEbaCaseTemperature	Generated when the EDFA case temperature exceeds the configured threshold in the direction from OSC B to OSC A.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
ILA::edfaEbaInputLOS	Generated when the input loss of signal (LOS) is detected in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaOOG	Generated when the Out-of-Gain (OOG) condition occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaOOP	Generated when the Out-of-Power (OOP) condition occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaOutputLOS	Generated when an output LOS condition occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaPump1EOL	Generated when the end-of-life (EoL) state for pump 1 of the EDFA occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaPump2EOL	Generated when the end-of-life (EoL) state for pump 2 of the EDFA occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaPump1Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaPump2Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::edfaEbaRFL	Generated when the radio frequency loss (RFL) occurs for the EDFA occurs in the direction from OSC B to OSC A.	PTX Series routers
ILA::ilaBoardTemperatureAbnormal	Generated when the ILA board temperature reaches an abnormal level.	PTX Series routers
ILA::ilaCommunicationAbnormal	Generated when the communication channel between the NMS system and the ILA reaches an abnormal level.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
ILA::ilaACPowerAbnormal	Generated when the ILA AC power reaches an abnormal level.	PTX Series routers
ILA::ilaDCPowerAbnormal	Generated when the ILA DC power reaches an abnormal level.	PTX Series routers
ILA::ilaFan1OnlineAbnormal	Generated when the ILA fan tray controller 1 that is online reaches an abnormal level.	PTX Series routers
ILA::ilaFan1SpeedAbnormal	Generated when the speed of the ILA fan tray controller 1 reaches an abnormal level.	PTX Series routers
ILA::ilaFan2OnlineAbnormal	Generated when the ILA fan tray controller 1 that is online reaches an abnormal level.	PTX Series routers
ILA::ilaFan2SpeedAbnormal	Generated when the speed of the ILA fan tray controller 1 reaches an abnormal level.	PTX Series routers
ILA::ilaFan3OnlineAbnormal	Generated when the ILA fan tray controller 1 that is online reaches an abnormal level.	PTX Series routers
ILA::ilaFan3SpeedAbnormal	Generated when the speed of the ILA fan tray controller 1 reaches an abnormal level.	PTX Series routers
ILA::ilaSoftwareVersionAbnormal	Generated when the ILA software version reaches an abnormal level.	PTX Series routers
ILA::ilaTableErr	Generated when the ILA table error occurs.	PTX Series routers
ILA::oscaAddPowerLOS	Generated when the addition of power LOS condition occurs for the OSC A.	PTX Series routers
ILA::oscaDropPowerLOS	Generated when the dropping of power LOS condition occurs for the OSC A.	PTX Series routers
ILA::oscbAddPowerLOS	Generated when the addition of power LOS condition occurs for the OSC B.	PTX Series routers
ILA::oscbDropPowerLOS	Generated when the dropping of power LOS condition occurs for the OSC B.	PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
<i>IPLC Notification</i>		
jnxlplcFpcAwgAddLosAlarm	Generated as the FPC arrayed waveguide gratings (AWG) add LOS alarm for the IPLC	PTX3000 Packet Transport Routers
jnxlplcFpcExpInLosAlarm	Generated as the FPC input LOS alarm for the express-in mode of the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcOscAddLosAlarm	Generated as the FPC add LOS alarm for the optical supervisory channel (OSC) of the IPLC. The OSC is an in-band channel used to communicate with ILAs and other optical nodes in the line system that are not directly accessible over the DCN. OSC framing logic is implemented in the FPGA.	PTX3000 Packet Transport Routers
jnxlplcFpcOscDrpLosAlarm	Generated as the FPC drop LOS alarm for the OSC of the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcLineInLosAlarm	Generated as the FPC input line-in LOS alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1RefPwAlarm	Generated as the FPC erbium doped fiber amplifier (EDFA) 1 reflect power alarm for the IPLC. EDFA1 is considered as ingress EDFA and EDFA2 is considered as egress EDFA	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1OutPwAlarm	Generated as the FPC EDFA1 output power alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1OutGain	Generated as the FPC EDFA1 output gain alarm for the IPLC	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1PumpEolAlarm	Generated as the FPC EDFA1 pump end-of-life (EoL) alarm for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
jnxlplcFpcEdfa1TempAlarm	Generated as the FPC EDFA1 temperature alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1OutLosAlarm	Generated as the FPC EDFA1 output LOS alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1InLosAlarm	Generated as the FPC EDFA1 input LOS alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2RefPwAlarm	Generated as the FPC erbium doped fiber amplifier (EDFA) 1 reflect power alarm for the IPLC. EDFA1 is considered as ingress EDFA and EDFA2 is considered as egress EDFA	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2OutPwAlarm	Generated as the FPC EDFA2 output power alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2OutGainAlarm	Generated as the FPC EDFA2 output gain alarm for the IPLC	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2PumpEolAlarm	Generated as the FPC EDFA2 pump end-of-life (EoL) alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2TempAlarm	Generated as the FPC EDFA2 temperature alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2OutLosAlarm	Generated as the FPC EDFA2 output LOS alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2InLosAlarm	Generated as the FPC EDFA2 input LOS alarm for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
jnxlplcFpcWssTempAlarm	Generated as the FPC wavelength selective switching (WSS) temperature alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcWssVoltAlarm	Generated as the FPC WSS voltage alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcInterDiagAlarm	Generated as the FPC internal diagnostic alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcFwCnsistAlarm	Generated as the FPC firmware consistency alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcHwFailAlarm	Generated as the FPC hardware failure alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcFwFailAlarm	Generated as the FPC firmware failure alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcOcmFailAlarm	Generated as the FPC optical channel module (OCM) failure alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcWssFailAlarm	Generated as the FPC WSS failure alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa2FailAlarm	Generated as the FPC EDFA2 failure alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcEdfa1FailAlarm	Generated as the FPC EDFA1 alarm for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (continued)

Alarm Name	Description	Device Type
jnxlplcFpcPwrFailAlarm	Generated as the FPC power rail failure alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscTxPowerHigh15minAlert	Generated as an alarm when the OSC transmitted high power exceeds the threshold within the 15-minute interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscTxPowerLow15minAlert	Generated as an alarm when the OSC transmitted low power exceeds the threshold within the 15-minute interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscRxPowerHigh15minAlert	Generated as an alarm when the OSC received high power exceeds the threshold within the 15-minute interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscRxPowerLow15minAlert	Generated as an alarm when the OSC received low power exceeds the threshold within the 15-minute interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscFiberLosHigh15minAlert	Generated as an alarm when the OSC fiber high LOS exceeds the threshold within the 15-minute interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscFiberLosLow15minAlert	Generated as an alarm when the OSC fiber low LOS exceeds the threshold within the 15-minute interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcLineOutVoaHigh15minAlert	Generated as the line-out Variable Optical Attenuator (VOA) high threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcLineOutVoaLow15minAlert	Generated as the line-out Variable Optical Attenuator (VOA) low threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaInputPwHigh15minAlert	Generated as the ingress EDFA input power high threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (continued)

Alarm Name	Description	Device Type
jnxlplcIngressEdfaInputPwLow15minAlert	Generated as the ingress EDFA input power low threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOcmPwHigh15minAlert	Generated as the OCM module power high threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOcmPwLow15minAlert	Generated as the OCM module power low threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscTxPowerHigh24hourAlert	Generated as the OSC transmitted high power threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscTxPowerLow24hourAlert	Generated as the OSC transmitted high power threshold setting trigger within the 15-minute period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscRxPowerHigh24hourAlert	Generated as an alarm when the OSC received high power exceeds the threshold within the 24-hour interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscRxPowerLow24hourAlert	Generated as an alarm when the OSC received low power exceeds the threshold within the 24-hour interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscFiberLosHigh24hourAlert	Generated as an alarm when the OSC fiber high LOS exceeds the threshold within the 24-hour interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOscFiberLosLow24hourAlert	Generated as an alarm when the OSC fiber low LOS exceeds the threshold within the 24-hour interval for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcLineOutVoaHigh24hourAlert	Generated as the line-out Variable Optical Attenuator (VOA) high threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (continued)

Alarm Name	Description	Device Type
jnxlplcLineOutVoaLow24hourAlert	Generated as the line-out Variable Optical Attenuator (VOA) low threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaInputPwHigh24hourAlert	Generated as the ingress EDFA input high power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaInputPwLow24hourAlert	Generated as the ingress EDFA input low power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaOutputPwHigh24hourAlert	Generated as the ingress EDFA output high power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaOutputPwLow24hourAlert	Generated as the ingress EDFA output low power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaSignalPwHigh24hourAlert	Generated as the ingress EDFA signal high power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaSignalPwLow24hourAlert	Generated as the ingress EDFA signal low power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaPumpCurrentHigh24hourAlert	Generated as the ingress EDFA pump current high temperature threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcIngressEdfaPumpCurrentLow24hourAlert	Generated as the ingress EDFA pump current low temperature threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaInputPwHigh24hourAlert	Generated as the egress EDFA input high power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
jnxlplcEgressEdfaInputPwLow24hourAlert	Generated as the egress EDFA input low power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaOutputPwHigh24hourAlert	Generated as the egress EDFA output high power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaOutputPwLow24hourAlert	Generated as the egress EDFA output low power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaSignalPwHigh24hourAlert	Generated as the egress EDFA signal high power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaSignalPwLow24hourAlert	Generated as the egress EDFA signal low power threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaPumpCurrentHigh24hourAlert	Generated as the egress EDFA pump current high temperature threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcEgressEdfaPumpCurrentLow24hourAlert	Generated as the egress EDFA pump current low temperature threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcPowerMonitorAwgAddHigh24hourAlert	Generated as the power monitor AWG add high threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcPowerMonitorAwgAddLow24hourAlert	Generated as the power monitor AWG add low threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcPowerMonitorExpressInHigh24hourAlert	Generated as the power monitor express-in mode high threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
jnxlplcPowerMonitorExpressInLow24hourAlert	Generated as the power monitor express-in mode low threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOcmPwHigh24hourAlert	Generated as the OCM module power high threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcOcmPwLow24hourAlert	Generated as the OCM module power low threshold setting trigger within the 24-hour period for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcSfpLosAlarm	Generated as the FPC SFP loss of signal (LOS) alarm for the IPLC.	PTX3000 Packet Transport Routers
jnxlplcFpcSfpLofAlarm	Generated as the FPC SFP loss of frame (LOF) alarm for the IPLC.	PTX3000 Packet Transport Routers
<i>L2ALD</i>		
L2aldGlobalMacLimitAlarm	Generated when the MAC limit is reached for the entire system. This trap is sent only once, when the limit is reached.	ACX, M, MX, and PTX Series routers
L2aldInterfaceMacLimitAlarm	Generated when the given interface reaches the MAC limit (jnxl2aldInterfaceMacLimit).	ACX, M, MX, and PTX Series routers
L2aldRoutingInstMacLimitAlarm	Generated when the MAC limit is reached for a given routing instance (jnxl2aldRoutingInst).	ACX, M, MX, and PTX Series routers
<i>L2CP</i>		
LacpTimeOutAlarm	Generated when LACP has timed out.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
PortBpduErrorStatusChangeTrapAlarm	Generated when the port's BPDU error state (no-error or detected) changes.	ACX, M, MX, and PTX Series routers
PortLoopProtectStateChangeTrapAlarm	Generated when the port's loop-protect state (no-error or loop-prevented) changes.	ACX, M, MX, and PTX Series routers
PortRootProtectStateChangeTrapAlarm	Generated when the port's root-protect state (no-error or root-prevented) changes.	ACX, M, MX, and PTX Series routers
<i>MAC Forwarding Database (MACFDB)</i>		
MacChangedNotificationAlarm	Generated when MAC addresses of the monitored devices are learned or removed from the forwarding database (FDB).	ACX, M, MX, and PTX Series routers
<i>Misc.</i>		
Counter Measures Alarm	Generated when counter measures are started against a rogue device.	Wireless LAN controller
Device Configuration Saved	Generated when the running configuration of the switch is written to the configuration file.	Wireless LAN controller
Multimedia Call Failure	Generated when a multimedia call fails.	Wireless LAN controller
PoE failure	Generated when Power over Ethernet (PoE) has failed on the indicated port.	ACX, M, MX, and PTX Series routers
<i>Network Service</i>		
LSP Service	Generated when an LSP service is affected.	ACX, M, MX, and PTX Series routers
VPN Service	Generated when an E-LAN service is affected.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
<i>Passive Monitoring (PassiveMonitoring)</i>		
PMonOverloadSetAlarm	Generated when an overload condition is detected on a Passive Monitoring Interface.	ACX, M, MX, and PTX Series routers
<i>Ping</i>		
PingEgressJitterThresholdExceededAlarm	Generated when egress time jitter (jnxPingMaxEgressUs minus jnxPingResultsMinEgressUs) exceeds the configured threshold (jnxPingCtlEgressJitterThreshold) causing the egressJitterThreshold bit to be set.	ACX, M, MX, and PTX Series routers
PingEgressStdDevThresholdExceededAlarm	Generated when the standard deviation of the egress time (jnxPingResultsStddevEgressUs) exceeds the configured threshold (jnxPingCtlEgressTimeThreshold) and causes the egress bit to be set.	ACX, M, MX, and PTX Series routers
PingEgressThresholdExceededAlarm	Generated when the egress time (jnxPingResultsStddevEgressUs) exceeds the configured threshold (jnxPingCtlEgressTimeThreshold) and the egress threshold bit is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers
PingIngressJitterThresholdExceededAlarm	Generated when ingress time jitter (jnxPingResultsMaxIngressUs minus jnxPingResultsMinIngressUs) exceeds the configured threshold (jnxPingCtlIngressJitterThreshold) and the ingressJitterThreshold bit is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers
PingIngressStddevThresholdExceededAlarm	Generated when the standard deviation of the ingress time (jnxPingResultsStdDevIngressUs) exceeds the configured threshold (jnxPingCtlIngressStddevThreshold) and the ingress StdDevThreshold bit is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers

Table 18: Alarm Descriptions (*continued*)

Alarm Name	Description	Device Type
PingIngressThresholdExceededAlarm	Generated when the ingress time jitter (jnxPingResultsIngressUs) exceeds the configured threshold (jnxPingCtlIngressTimeThreshold) and the ingress threshold bit (jnxPingIngressThresholdExceeded) is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers
PingRttJitterThresholdExceededAlarm	Generated when the round trip time jitter (jnxPingResultsMaxRttUs minus jnxPingResultsMinRttUs) exceeds the configured threshold (jnxPingCtlRttJitterThreshold) and the rttJitterThreshold bit is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers
PingRttStdDevThresholdExceededAlarm	Generated when the standard deviation of the round trip time (jnxPingResultsStdDevRttUs) exceeds the configured threshold (jnxPingCtlRTTStdDev) and the rttStdDevThreshold bit is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers
PingRttThresholdExceededAlarm	Generated when the round trip time (jnxPingCtlRttThreshold) exceeds the configured threshold (jnxPingCtlRttThreshold) and the rttThreshold bit is set in jnxPingCtlTrapGeneration.	ACX, M, MX, and PTX Series routers
<i>RMon</i>		
RmonAlarmGetFailureAlarm	Generated when a GET request for an alarm variable returns an error. The specific error is identified by a varbind in jnxRmonAlarmGetFailReason.	ACX, M, MX, and PTX Series routers

Changing the Severity of Individual Alarms

You can change the severity of the alarms to match your corporate procedures and guidelines. For example, at your company a DoS attack might be considered a critical alarm, while Connectivity Services Director has a default severity for DoS attacks as a major alarm. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To change the severity of an alarm:

1. Select the current severity in the **Severity** column. A list of the severity levels appear.
2. Select the new severity level for the alarm.
3. Click **OK** and **Yes** to confirm the change to the severity setting.

To configure alarm notifications, see [“Configuring Individual Alarm Notifications” on page 165](#).

Configuring Individual Alarm Notifications

You can configure e-mail notifications to be sent when an individual alarm is generated. When you enable notification for an alarm, the notifications are sent to the e-mail addresses configured for the alarm and the addresses configured for global alarm notifications. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To configure e-mail notification for an alarm name:

1. Select the check box in the alarm’s Notification column.

If you later want to disable notification for the alarm, clear the check box.

2. Click **Edit Notification** in the Notification column. The Alarm Notification Details window opens.
3. Enter one or more e-mail addresses in the Notification Email Addresses field. Separate addresses with a comma (,).
- You can later edit the addresses to send notifications to different addresses.
4. (Optional) Enter a comment in the Comments field. This comment is included in the e-mail notification message.
5. Click **Save**.

Disabling Optical Performance Monitoring

From the **Optical** tab of the Preference page, you can disable optical performance monitoring by selecting the **Disable Optical Performance Monitoring** check box.

Select the **Disable Optical Performance Monitoring** check box, if you do not intend to store optical parameters.

Specifying NorthStar Controller Preferences

Starting from Release 3.0 onward, you can choose NorthStar Controller to manage LSPs from the Connectivity Services Director user interface. The NorthStar tab in the Preferences page displays the attributes listed in [Table 19 on page 166](#).

Table 19: NorthStar Controller Preferences

Fields	Description
Enable NorthStar LSP Management	Select this check box to manage LSPs through the NorthStar Controller server.
PCEP for Provisioning	Select this check box to enable PCEP as the provisioning type for LSPs.
Provisioning Type	Select either RSVP or Segment Routing as the provisioning type. Default: RSVP
Credentials	Enter the NorthStar server IP , Username , and Password to validate your access to the NorthStar server.

SEE ALSO

[Understanding Connectivity Services Director User Administration](#) | 28

3

PART

Working with the Dashboard

[About the Dashboard](#) | **168**

[Using the Dashboard](#) | **169**

[Dashboard Widget Reference](#) | **171**

About the Dashboard

IN THIS CHAPTER

- [Understanding the Dashboard | 168](#)

Understanding the Dashboard

When you log in to the Connectivity Services Director interface, the first page that is displayed is the Dashboard page. Service Dashboard and Monitoring provide a proactive account of the services and devices health status and working efficiency of devices in a bird's eye, comprehensive, and intuitive format at the network level and service levels. A single pane of glass (SPOG) view helps the operator to view various alarms and quickly identify and isolate issues. The dashboard and monitoring feature aggregates and correlates data from different sources such as SNMP and system event logs. The defined threshold values enable operators to specify monitoring criteria critical for service operations and administration. The performance management view also highlights the top or first three non-confirming devices and provides a historical context with time graph and additional data from the logging system. The Dashboard page contains several monitors or frames.

The Dashboard is a customizable page to view information about the network, and is the default page that opens when you log in. You select monitoring widgets to display on the Dashboard that show various information about the network. The Dashboard is a view. To open a different view, select a view from the Views list in the Connectivity Services Director banner.

RELATED DOCUMENTATION

| [Using Dashboard Widgets | 169](#)

Using the Dashboard

IN THIS CHAPTER

- [Using Dashboard Widgets | 169](#)

Using Dashboard Widgets

The Dashboard is a customizable page for viewing information about the network. You select monitoring widgets to display on the Dashboard that show various information about the network. The Dashboard is the default view that opens when you log in. When a different view is selected, select **Dashboard View** from the Select View list in the Connectivity Services Director banner to open the Dashboard.

To select what appears on the Dashboard:

1. To add a monitor to the Dashboard:
 - a. Select **Add Widgets**. Thumbnails of the available widgets appear.
 - b. To add a widget to the Dashboard, mouse over the widget's thumbnail, then click the **Add** button that appears on the widgets.
 - c. When you are finished adding widgets, click **Done**. The new widgets appear on the Home page.
2. To refresh a widget's data, click the **Refresh** button in its title bar.
3. To see additional information for a widget, click the **Maximize** button in the widget's title bar.
4. To remove a widget from the Dashboard, click the Close button (X) in its title bar.
5. To open online help for a widget, click the Help button (?) in its title bar.
6. To move a widget, click its title bar and drag it to the new location.

RELATED DOCUMENTATION

| [Understanding the Dashboard](#) | 168

Dashboard Widget Reference

IN THIS CHAPTER

- [Device Alarms Widget | 171](#)
- [Service Alarms by Severity Widget | 172](#)
- [Config Deployment Jobs Status Widget | 173](#)
- [Device & Port Utilization Heatmap Widget | 174](#)
- [Port Status - Physical Widget | 178](#)

Device Alarms Widget

The Device Alarms widget displays summary information about alarms generated for the devices present in the network that is managed by Connectivity Services Director. The summarized way in which you can view statistical details enables you to examine the health and operating-efficiency of devices, and the performance of services. It provides a bird's eye, high-level view of parameters that enables effective and simplified troubleshooting and administration. For example, if you find that a particular device has recorded a large number of critical or major alarms, you can then navigate to the Monitoring page or the appropriate device settings page to correct and modify the attributes or diagnose the problems that might be generating the alarms.

Critical, major, and minor alarms are displayed in a pie chart with percentage values of each type of alarm. When you move the mouse over the segments of the pie chart, the total number of alarms of each type are displayed. Mouse over each segment in the pie chart to highlight and display the number of alarms for each severity level.

Alarm severity levels are:

- **Critical (Red)**—A critical condition exists; immediate action is necessary.
- **Major (Orange)**—A major error has occurred; escalate or notify as necessary.
- **Minor (Yellow)**—A minor error has occurred; notify or monitor the condition.
- **Info (Wedgewood Blue)**—An informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

RELATED DOCUMENTATION

[Service Alarms by Severity Widget | 172](#)

[Port Status - Physical Widget | 178](#)

[Config Deployment Jobs Status Widget | 173](#)

[Device & Port Utilization Heatmap Widget | 174](#)

Service Alarms by Severity Widget

The Service Alarms by Severity widget displays comprehensive and cohesive details about the alarms generated by different devices for which services, such as E-Line, IP, LSPs, and E-LAN, are configured. You can view critical, salient information about the configured devices and services in an intuitive, easily-navigable format. The summarized way in which you can view statistical details enables you to examine the health and operating-efficiency of devices, and the performance of services. These alarm details enable effective and simplified troubleshooting and administration. For example, if you find that a particular device has recorded a large number of critical or major alarms for a service, you can then navigate to the design and provisioning pages of the type of service to correct and modify the attributes or diagnose the problems that might be generating the alarms.

Critical, major, and minor alarms are displayed in a pie chart with percentage values of each type of alarm. When you move the mouse over the segments of the pie chart, the total number of alarms of each type are displayed.

Alarm severity levels are:

- Critical (Red)—A critical condition exists; immediate action is necessary.
- Major (Orange)—A major error has occurred; escalate or notify as necessary.
- Minor (Yellow)—A minor error has occurred; notify or monitor the condition.
- Info (Wedgewood Blue)—An informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

RELATED DOCUMENTATION

[Device & Port Utilization Heatmap Widget | 174](#)

[Port Status - Physical Widget | 178](#)

[Device Alarms Widget | 171](#)

[Config Deployment Jobs Status Widget | 173](#)

Config Deployment Jobs Status Widget

IN THIS SECTION

- [Config Deployment Jobs Status Widget Summary | 173](#)
- [Config Deployment Jobs Status Widget Details | 173](#)

The Config Deployment Jobs Status widget provides summary and detailed information about the status of configuration deployment jobs.

This topic describes:

Config Deployment Jobs Status Widget Summary

The Config Deployment Jobs Status widget displays summary information about the status of configuration deployment jobs. The information appears in a table. The vertical axis lists the job statuses. The horizontal axis shows the times when job status data was collected. You can do the following tasks:

- Select a time period to view from the **Deployment Trend** list.
- Click the **Refresh** button to refresh the information displayed.

Config Deployment Jobs Status Widget Details

To open the Config Deployment Jobs Status widget details page, click the **Maximize** button in the widget's title bar. The Config Deployment Jobs Status widget details window displays detailed information about the status of configuration deployment jobs. The page shows the same summary information table as the widget. It also shows a table of detailed configuration job status information. To close the details page, click the **Minimize** button in the title bar.

RELATED DOCUMENTATION

[Device Alarms Widget | 171](#)

[Service Alarms by Severity Widget | 172](#)

[Port Status - Physical Widget | 178](#)

[Device & Port Utilization Heatmap Widget | 174](#)

Device & Port Utilization Heatmap Widget

IN THIS SECTION




- [Using the Global Controls | 174](#)
- [Interacting with the Heat Maps | 175](#)
- [Viewing Active Flows on a Port | 175](#)
- [Flow Analysis Details Window | 176](#)

The Device & Port Utilization Heatmap widget provides a graphical view of device port utilization percentage. The heat map represents each device as a color-coded box. The color coding indicates the overall level of port utilization on a device. Cooler colors (for example, green) indicate lower port utilization, while hotter colors (for example, red) indicate higher port utilization.

You can view the utilization level for each port on a device by clicking on the box representing the device. A heat map is displayed that represents each port on the device as a color-coded box, with the color coding representing the level of port utilization.

Using the Global Controls

Use the controls in the upper right corner to make global changes to how the device and port heat maps are displayed. You can:

- Select the time period over which device utilization and port utilization are shown.
- Display information about the devices or the ports in either graphical heat map or tabular format by clicking either  (graphical) or  (tabular).
- Select how to organize the heat map by clicking the Settings icon (), and then selecting an option from the **Group Devices By** list. Each option creates a different view of the heat map, with device boxes grouped according to your selection.

Interacting with the Heat Maps

You can interact with the device and port heat maps as follows:

- If you have grouped the devices by location, you can drill down into the heat map’s hierarchy by clicking one of the device container names (for example, a site or building). To move back up the hierarchy, click the navigation arrows above the heat map.
- Mouse over a device box to see detailed device-level port utilization information in a pop-up window. In the pop-up window, you can click the **View top 5 ports** link to view the top five ports that use the most bandwidth on the device.
- Click on a device box to display a heat map of the ports on the device. In this port-level heat map, each port is represented by a box that is color-coded to show its level of utilization. To return to the device view, click the navigation arrows above the heat map.
- Mouse over a port box to display information about the port—such as port name, status, speed, and percent utilization—in a pop-up window. For ports on devices that support Cloud Analytics Engine, you can view any existing flow analysis results on flows through the port by clicking **View active flows through this link**. See “[Viewing Active Flows on a Port](#)” on page 175 for more information.
- Slide the circular controls along the bar under the heat map to Filter the devices or ports shown in the heat map by degree of port utilization..

Viewing Active Flows on a Port

For devices that support Cloud Analytics Engine, you can view the results of the most recent flow analysis traces on application flows on the port by mousing over the port and clicking **View active flows through this link**. The Current Active Flows window is displayed.

The Current Active Flows window lists only application flows for which flow analysis traces exist—there might be other active application flows on the port that are not shown. Each flow is uniquely defined by source IP address and TCP/UDP port, destination IP address and TCP/UDP port, and transport protocol. [Table 20 on page 175](#) describes the fields in this window.

Table 20: Fields in the Current Active Flows Window

Field	Description
Source IP Source Port	Source IP address and source TCP/UDP port for the flow. In the case of a flow between two VMS, the IP address is the source VTEP address. If the port is associated with a well-known service, the service name is also shown.

Table 20: Fields in the Current Active Flows Window (*continued*)

Field	Description
Destination IP Destination Port	<p>Destination IP address and destination TCP/UDP port for the flow. In the case of a flow between two VMS, the IP address is the destination VTEP address.</p> <p>If the port is associated with a well-known service, the service name is also shown.</p>
Protocol	Either TCP or UDP.
Bandwidth	<p>Bandwidth used by the flow. This is a count of the number of packets through the port for the flow up to this point in time.</p> <p>For a value to be displayed in this field, flow analysis must have been performed on flow with the Capture Bandwidth option enabled.</p>
Flow Analysis	<p>Click View Results to see the results of the most recent flow analysis trace. The Flow Analysis Details window opens.</p> <p>NOTE: The View Results link is not available for VM to VM flows.</p>


Flow Analysis Details Window

The Flow Analysis Details window provides detailed information about a flow trace.

The Flow Analysis Details window is divided into three sections:

- The flow path diagram—This diagram shows the path taken by a probe through the network. By default, the path shown is the path taken by the probe that experienced the highest per-hop latency in the trace. You can change this diagram to reflect the path taken by a different probe by selecting the probe from the top Latency Trend chart.
- Latency Trend charts—These charts show the change in latency experienced by the probes during the trace. The bars in the top chart are grouped by completed probes, with each bar in a probe group representing the latency experienced by the probe at a hop. By clicking on a probe group, you can change the flow path diagram and the Analysis Results section to reflect the results of that probe. For traces of long duration, the bar chart shows only a portion of the trace results.

The bottom area chart graphs the highest latency experienced by each probe over the entire duration of the trace. You can use the provided controls to focus on a portion of the trace—the portion you choose is reflected in the top bar chart. By default, the focus is on the portion of the trace that had the highest latency. If the trace is ongoing, a rotating circle appears at the end of the plotted area and the chart is periodically refreshed to show new results.

Both charts display a path change icon () when the path a probe takes through the network differs from the path taken by the previous probe.

- **Analysis Results**—This section provides details about the overall trace results and about the selected probe:
 - The Latency table provides overall latency information for the trace: the highest and lowest latency experienced at a single hop and the average latency of all hops.
 - The Latency for Selected Path table shows the latency experienced by the selected probe at each hop.

You can perform the following actions in the Flow Analysis Details window.

General actions:

- For bidirectional traces, you can select the direction for which you want results by clicking one of the arrows at the top of the window (these arrows do not appear for unidirectional traces).
- To stop an active flow analysis, click **Stop Flow Analysis** at the bottom of the window. When you stop an active flow analysis, the results up to the time you stopped the flow analysis are retained and the previously active trace is marked as complete.

On the flow path diagram, you can:


- Reposition the topology diagram by dragging it or reposition devices by dragging them.
- Zoom in or out by clicking the plus or minus signs on the left.
- Mouse over the link connecting two devices to get the connecting port names. The names are displayed in green if the link is up and in red if the link is down.
- Mouse over a device to view details about the device, such as name, connection state, and IP address. The details shown depends on the device type.

If a device in the flow path does not support Cloud Analytics Engine, it is shown in the diagram in light grey color and minimal details, such as IP address, are available.

- Display the traffic statistics for switches by mousing over the device to display the device details and clicking the **Show Traffic Data** link. If you selected the Capture Bandwidth option when you started the flow analysis, the flow bandwidth is also displayed along with the traffic statistics.
- Display the active flows associated with a VM, BMS, or virtualized host by mousing over the device and clicking **Show Active Flows** in the details box.

On the Latency Trend charts, you can:

- Mouse over a bar group in the top bar chart. A pop-up box displays the latency figures for each hop taken by the probe.
- Click a bar group in the top bar chart. The flow path diagram and the Analysis Results change to reflect the information for the probe.
- Mouse over a path change icon in the top bar chart. Information about the old and new paths is displayed.
- Change the span and position of the focus indicator on the bottom area chart:

- To increase or decrease the time span of the focus—in other words, to zoom in or zoom out on a portion of the trace—click on one of the handle controls () and move it in either direction.
- To change the focus to another time period, click on the arrows at either end of the slider bar.

RELATED DOCUMENTATION

[Config Deployment Jobs Status Widget | 173](#)

[Device Alarms Widget | 171](#)

[Service Alarms by Severity Widget | 172](#)

[Port Status - Physical Widget | 178](#)

Port Status - Physical Widget

IN THIS SECTION

- [Port Status - Physical Widget Summary | 178](#)
- [Port Status - Physical Widget Details | 179](#)

The Port Status - Physical widget provides summary and detailed information about the status of physical ports on managed devices.

This topic describes:

Port Status - Physical Widget Summary

The Port Status - Physical widget displays summary information about the status of physical ports on managed devices. It has the following pie charts:

- Admin Status pie chart—Shows the distribution of ports that are administratively up or down and states the total number of ports. Mouse over a chart segment to see more information about it.
- Free vs. Used pie chart—Shows the distribution of ports that are free or used and states the total number of ports. Mouse over a chart segment to see more information about it.

Port Status - Physical Widget Details

The Port Status - Physical widget details window has a table containing detailed information about the status of physical ports on managed devices. See *Port Status Monitor* for descriptions of the table columns.

RELATED DOCUMENTATION

Config Deployment Jobs Status Widget 173
Device Alarms Widget 171
Service Alarms by Severity Widget 172
Device & Port Utilization Heatmap Widget 174

4

PART

Working in Build Mode

About Build Mode | **181**

Discovering Devices | **188**

Creating Custom Device Groups | **194**

Configuring Quick Templates | **202**

Configuring Device Settings | **210**

Configuring Class of Service (CoS) | **228**

Configuring Link Aggregation Groups (LAGs) | **256**

Managing Network Devices | **261**

About Build Mode

IN THIS CHAPTER

- [Understanding Build Mode in Views Other than Service View of Connectivity Services Director | 181](#)
- [Understanding the Build Mode Tasks Pane in Views Other than Service View | 184](#)

Understanding Build Mode in Views Other than Service View of Connectivity Services Director

IN THIS SECTION

- [Discovering Devices | 181](#)
- [Building the Custom View | 182](#)
- [Configuring Devices | 182](#)
- [Managing Devices | 184](#)

In Build mode, you build the network managed by Junos Space Connectivity Services Director. It provides you with the ability to use device discovery to bring devices under Connectivity Services Director management, to customize your view of the devices, to configure devices, and to perform some common device management tasks.

This topic describes:

Discovering Devices

Device discovery finds your network devices and brings them under Connectivity Services Director management. You provide Connectivity Services Director with identifying information about the devices you want Connectivity Services Director to manage—an IP address or hostname, an IP address range, an IP subnetwork, or a CSV file that contains this information. Connectivity Services Director uses the information to probe the devices by using either ping or SNMP get requests. If a device probe is successful,

Connectivity Services Director then attempts to make an SSH connection to the device using the login credentials you supply. If the connection is successful and the device is a supported device, Connectivity Services Director adds the device to its database of managed devices. Connectivity Services Director uses Juniper Network's Device Management Interface (DMI), which is an extension to the NETCONF network configuration protocol, to connect to and configure its managed devices.

You can also discover devices using the device discovery feature provided by the Junos Space Network Management Platform. Devices you discover using Junos Space device discovery are brought under Connectivity Services Director management if they are supported by Connectivity Services Director.

Besides bringing your devices under Connectivity Services Director management, device discovery:

- Reads the device configuration and saves it in the Junos Space configuration database. Connectivity Services Director uses this record of the device configuration to determine what configuration commands it needs to send to a device when you deploy the configuration on the device. For this reason, it is important for the Junos Space configuration record to match, or be in sync with, the device configuration. For more information about how the Junos Space configuration record and device configuration are kept in sync, see ["Understanding Resynchronization of Device Configuration" on page 833](#).
- Imports the device configuration into the Build mode configuration. For more information about importing device configurations, see ["Importing Device Configurations" on page 183](#).

Building the Custom View

When a device is discovered in the physical network mode, it is added to the network tree in the View pane.

The Custom Group View displays only the top level—My Network—until you create one or more custom groups. Custom group is another way of grouping your devices based on your business needs. You can create custom groups and add devices to each custom group. You can manually add devices to a custom group or you can define rules to add devices, that match the rule condition, to the custom group once they are discovered by Connectivity Services Director. You can view the custom groups and devices that are assigned to each group in the Custom Group view.

NOTE: This section does not apply to virtual devices that Connectivity Services Director manages.

Configuring Devices

In Build mode, you can define the configuration of network devices in your Physical network. To support rapid, large-scale deployment of devices, you can define much of your Build mode configuration in a set of profiles. You can reference profiles in other profiles or apply them to multiple objects in your network—devices, ports, radios, logical entities. For example, you can create a class-of-service (CoS) profile

that contains settings that are appropriate for E-Line, IP, and E-LAN services that you can manage, provision, and monitor in Service View of Connectivity Services Director.

In addition to creating configuration profiles, in Build mode you can configure Link Aggregation Groups (LAGs) on routers.

Deploying Device Configurations

After you build your device configurations in Build mode, you need to deploy the configurations on the devices. None of the configurations you create in Build mode affect your devices until the configurations are actually deployed on the devices.

To deploy the configuration on devices, use Deploy mode. When you change a device's configuration in Build mode, the device becomes available in Deploy mode for configuration deployment.

Importing Device Configurations

As part of device discovery, Connectivity Services Director analyzes the configuration of a newly discovered device and automatically imports the configuration into the Build mode configuration for that device.

As it imports the device configuration, Connectivity Services Director automatically creates profiles to match the configuration. It first determines whether any existing profiles match the configuration, and if so, assigns those profiles to the device. It then creates and assigns new profiles as needed. For example, if an access switch has some ports that match the configuration of an existing Port profile, Connectivity Services Director assigns the existing Port profile to those ports. For the other ports, Connectivity Services Director creates as many Port profiles as needed to match the port configurations and assigns them to the ports.

You can manage the profiles that Connectivity Services Director creates as part of device discovery in the same way that you manage user-created profiles—that is, you can modify, delete, or assign them to other devices.

Out-of-Band Configuration Changes

Out-of-band configuration changes are configuration changes made to a device outside of Connectivity Services Director. Examples include changes made by:

- Using the device CLI.
- Using the device Web-based management interface (the J-Web interface or Web View).
- Using the Junos Space Network Management Platform configuration editor.
- Using RingMaster software.
- Restoring or replacing device configuration files.

When an out-of-band change is made, the device configuration no longer matches the Build mode configuration, and the device configuration state changes to out of sync. You cannot deploy configuration on a device that is out of sync. Use the Resynchronize Device Configuration task in Deploy mode to resynchronize the device configuration. For more information about how Connectivity Services Director

resolves out-of-band configuration changes and synchronizes the Build mode configuration with the device configuration, see [“Understanding Resynchronization of Device Configuration” on page 833](#).

TIP: Before you make configuration changes in Build mode, make sure that devices that will be affected are in sync. Resynchronizing the device configuration can result in losing pending Build mode configuration changes for that device.

Managing Devices

In addition to the tasks that allow you to build your network, Build mode provides a number of tasks for day-to-day device management. For example, you can:

- View a device’s hardware component inventory or its installed licenses
- Reboot a device or groups of devices
- Connect to a device’s CLI through SSH or to its web-based management interface
- View the profiles assigned to a device

RELATED DOCUMENTATION

| [Understanding the Build Mode Tasks Pane in Views Other than Service View](#) | 184

Understanding the Build Mode Tasks Pane in Views Other than Service View

The Tasks pane in Build mode contains all the tasks you can do in Build mode. Click a specific task to begin that task.

The tasks listed in the Tasks pane depend on the scope you select in the View pane—that is, what view (Device or Custom Group) you have selected and what object you have selected. Not all tasks are available in all scopes. As you change your selections in the View pane, the contents of the Tasks pane also change.

Build mode tasks are divided into the following categories in the Tasks pane.

Connectivity Services Director enables you to perform the following tasks for devices in your physical network:

- **Device Discovery**—Before your devices can be managed by Connectivity Services Director, you must use device discovery to discover them. As Connectivity Services Director discovers devices, it adds them to your network view in the View pane. [Table 21 on page 185](#) describes the device discovery tasks.
- **Device Management**—After devices have been discovered, you can perform administrative tasks on them, such as viewing a list of the device's physical components, connecting to a device using SSH, or rebooting a device. [Table 22 on page 185](#) describes the device management tasks.
- **Wired**—You can create configuration profiles and quick templates for the different wired devices—ACX Series routers, M Series routers, MX Series routers, and PTX Series routers.
- **Profile and Configuration Management**—Connectivity Services Director provides a set of configuration profiles that you can create to provision multiple devices in your network. [Table 24 on page 187](#) describes the profile and configuration management tasks.
- **Key Tasks**—Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can modify this set of tasks to suit your requirements. This feature is available in Task pane irrespective of your current mode, scope, or view.

For more information about Build mode features, see [“Understanding Build Mode in Views Other than Service View of Connectivity Services Director” on page 181](#).

[Table 21 on page 185](#) through [Table 24 on page 187](#) describe the tasks that you can perform in the physical network category, including the scope in the View pane that you must select to access the task.

Table 21: Device Discovery Tasks

Task	Description	Scope
Discover Devices	Discovers supported routers in the network and brings them under Connectivity Services Director management.	Any
View Discovery Status	Displays the status of device discovery jobs.	Any

Table 22: Device Management Tasks

Task	Description	Scope
Delete Devices	Deletes a device as a managed device from Connectivity Services Director. If you select a scope that contains more than one router, you can choose which devices are deleted.	View: All Object: All

Table 22: Device Management Tasks (*continued*)

Task	Description	Scope
Launch Web View	Launches the Web-based management interface for the selected device in a separate window: the J-Web interface for routers.	View: All Object: Individual device
Manage LAG	Creates and manages Link Aggregation Groups (LAGs).	View: All Object: Individual router
Reboot Devices	Reboots devices. If you select a scope that contains more than one router, you can choose which devices get deleted.	View: All Object: All
Show Current Configuration	Shows the running configuration on a device.	View: All Object: Individual device
SSH to Device	Launches an SSH connection to the selected device.	View: All Object: Individual device
View Inventory	Displays information about all the devices in the currently selected object and all its child objects.	View: All Object: All
View License Information	View the licenses installed on the device and their status.	View: All Object: Individual device
View Physical Inventory	Displays information about the selected device's hardware components.	View: All Object: Individual device

Table 23: Connectivity Tasks

Task	Description	Scope
View Device Connectivity	Displays the connection details of a device with its neighbors in graphical and grid views. If the selected device is connected to more than 60 devices, then the connection details are displayed only in grid view.	View: Device Object: Individual device

Table 24: Profile and Configuration Management Tasks

Task	Description	Device Family	Scope
Manage Quick Templates	Enables you to create and manage quick templates. Quick templates enable you to define your network configuration in the form of templates that you can apply to multiple devices in your network.	ACX Series M Series MX Series PTX Series	All, except wireless devices
View Deployed Templates	Enables you to view the list of quick templates that are deployed.	ACX Series M Series MX Series PTX Series	All, except wireless devices
CoS	Creates and manages CoS profiles. Use CoS profiles to configure class-of-service (CoS) attributes to be applied to interfaces or to user traffic.	ACX Series M Series MX Series PTX Series	Any
Device Common Settings	Creates and manages Device Common Settings profiles. Use Device Common Settings profiles to configure basic system settings, such as users, time and time servers, SNMP, system logging, and so on.	ACX Series M Series MX Series PTX Series	Any

RELATED DOCUMENTATION

[Understanding Build Mode in Views Other than Service View of Connectivity Services Director](#) | 181

Discovering Devices

IN THIS CHAPTER

- [Discovering Devices | 188](#)
- [Troubleshooting Device Discovery Error Messages | 190](#)
- [Viewing the Brownfield Job | 192](#)

Discovering Devices

When you start Connectivity Services Director for the first time, the system does not have any devices. The first step is to build your network. Even with large networks, Connectivity Services Director has made this step relatively easy and straightforward. You will add devices to Connectivity Services Director and the database by using a process called *device discovery*. Once a device is discovered, it shows in the interface and Connectivity Services Director begins to monitor the device.

Connectivity Services Director provides a wizard for device discovery. The following example shows the path for device discovery through the wizard. For an alternate path, you can get a step-by-step instruction from the help system.

In this example, we provide an IP address range, and Connectivity Services Director populates the database with all supported devices within that range.

1. While in the **Build** mode, select **Location View**, **Device View**, or **Custom Group View** from the View selector.
2. To discover physical devices, click **Discover Devices** in the Tasks pane. Each mode has a Tasks Pane that displays the actions you can take while in that mode and that particular network view.
3. (Optional) Type a name for the discovery job. The default name is ND Discovery.
4. Click **Add** in the Device Targets window. You can add a single device IP address, a range of IP addresses, an IP subnet, or a hostname. In this example, we select an IP address range.

5. Provide the initial or the lowest IP address value and the ending or highest IP address value for the range and click **Add**. You can have up to 1024 devices in a range. After you click Add, the address range is listed in the Device Targets window.
6. Click **Next** or click **Discovery Options** to proceed to specify the device credentials and method of discovery.
7. Click **Add** in the Device Credentials window and enter the username and password assigned for administrative access.
8. Select **Ping**, **SNMP**, or both as the method of device discovery. Selecting both is the preferred method if the device is configured for SNMP.

If you select SNMP, the Add SNMP Settings dialog box is displayed. In this example, because we run SNMP version 2, we need to provide the community string. Click **Add** to save the setting.

NOTE: You cannot choose a method for device discovery for virtual Connectivity Services Discovery.

9. Click **Next** or **Schedule Options** to proceed to schedule the time when discovery is run.

NOTE: Scheduling options are not available for virtual Connectivity Services Discovery.

10. Indicate whether to run the device discovery now or set up a schedule to minimize network traffic. In this example, we set the schedule to run during off hours.
11. Click **Review** to review the settings before you exit the wizard.
12. Click **Finish** to complete the discovery setup and to save the settings.
13. Click **View Discovery Status** to view all scheduled and completed jobs. After a job completes, you can click **Show Details** to view further information on any unexpected results.

Troubleshooting Device Discovery Error Messages

While you are discovering devices by using Connectivity Services Director, you might encounter some issues. Connectivity Services Director enables you to detect the errors and provide solutions to the potential errors that you encounter.

Error Message	Solution
Error Messages Displayed During Discovery of Routers	
SSH connection failed. Device might not be reachable.	<p>For routers, Connectivity Services Director connects to port 22 (default port) on the JA2500 Appliance or the Junos Space Virtual Appliance by using SSH. Ensure that you have configured port 22 on the Space appliance through Administration > Applications in the Junos Space Platform page. To do this, select Network Application Platform and click Actions > Modify Application Settings. Change SSH port for device connection field to 22.</p> <p>If port 22 is open on the Junos Space Appliance, and you still get the error, then check if port 22 is open on the switch and if the switch is accepting SSH connections on port 22.</p>
User Authentication failed.	Check the read and write credentials used during device discovery.
Device is not reachable.	If ping is enabled during device discovery, then check whether the switch is reachable using the CLI command ping .

Error Message	Solution
Junos Space is unable to query the device information through SNMP. Check the SNMP settings on the device to verify SNMP is not blocked and the SNMP settings specified in Junos Space match the device SNMP settings.	If the SNMP option is enabled in Connectivity Services Director during device discovery, check and ensure that SNMP is enabled on the switch. Also, check and ensure that the SNMP settings on Connectivity Services Director and Junos Space match with the SNMP settings on the switch.
General Error Messages	
Device Failed to return System information.	This message is displayed if the switch is too busy to respond to operational commands. Try discovering the device again.
Failed to configure device, Check Device state.	Check whether the Edit lock is open on the switch and close it if it is open. The configuration commit fails if the Edit lock is open.
Device has been added, but failed to synchronize. Please try manual re-synchronization. Error while reading config from device: device_name, Detail - Fail while executing following RPC: <get-configuration database=committed><configuration></configuration></get-configuration>	Try to resynchronize the devices manually. For details, see "Resynchronizing Device Configuration" on page 839 .
Error while reading config from device: device-name Failed while executing the following RPC: <get-hardware-inventory/>	<p>Check the hardware details of the switch using the CLI command show chassis hardware detail.</p> <p>If the output displays a message error: command is not valid, then the Junos OS image on the specified switch is corrupted and you need to upgrade to the latest version of Junos OS.</p>

RELATED DOCUMENTATION

Viewing the Brownfield Job | 192

Viewing the Brownfield Job

Starting in Release 2.1R1, Connectivity Services Director initiates the brownfield job immediately after the device discovery. The Brownfield Job window displays the job and the device details. To open the Brownfield Job window double-click the brownfield job name in the Job Management table. The following table describes the information provided in the Brownfield Job page:

Table 25: Brownfield Job Page Fields

Table Column	Description
Job Name	Job name (user-created)
Job Start Time	Job's actual start time
Job End Time	Time when the job ended
Percentage Completed	Percentage of the job that is complete
Job Status	<p>Job status. The possible states are:</p> <ul style="list-style-type: none"> • CANCELLED—The job was cancelled by a user. • FAILURE—The job failed. This state is applied if any of the devices in the job failed. But some of the devices might have completed successfully. View the job details for the status of each device. • INPROGRESS—The job is running. • SCHEDULED—The job is scheduled but has not run yet. • SUCCESS—The job completed successfully. This state is applied if all of the devices in the job completed successfully.
Devices	<p>The devices section lists device details such as device name, IP address of the device, job status of the device, job start and end times and the summary of the brownfield job. For a successful job, the summary column displays the message "Brownfield is Successful". For a job that is skipped, the summary column lists the error or warning message along with a View link. Double-click on the View link to open the Brownfield Errors page, which displays the device profile name along with the error associated with that device.</p>

Release History Table

Release	Description
2.1R1	Starting in Release 2.1R1, Connectivity Services Director initiates the brownfield job immediately after the device discovery.

RELATED DOCUMENTATION

Troubleshooting Device Discovery Error Messages 190
<i>Discovering Devices in a Physical Network</i>

Creating Custom Device Groups

IN THIS CHAPTER

- Understanding Custom Device Groups | 194
- Creating Custom Device Groups | 196

Understanding Custom Device Groups

IN THIS SECTION

- Where Is the Custom Group Function Located in Connectivity Services Director? | 195
- How Do Custom Group Rules Work? | 195
- What Happens When I Edit a Custom Group Rule? | 196
- When Are Rules Executed? | 196

Custom group is way of grouping your devices based on your business needs. You can create custom groups and add devices to each custom group. You can manually add devices to a custom group or you can define rules to add devices, that match the rule condition, to the custom group once they are discovered by Connectivity Services Director. You can view the custom groups and devices that are assigned to each group in the Custom Group view.

A custom group can include devices such as different routing platforms. Creating custom device groups enables the configuration of multiple devices simultaneously—you can create multiple custom groups and directly associate devices at any level. Up to this point, Custom Groups are the same as selecting related items in the view tree. What makes Custom Groups unique is that you can also configure a custom group to automatically add devices after discovery. You indicate the criteria for additional devices by editing rules. Custom groups can then be created in a hierarchy up to eight levels deep. Each layer can contain up to 32 peer containers under a single parent container.

Where Is the Custom Group Function Located in Connectivity Services Director?

Connectivity Services Director has different views that you select to see different aspects of your data. You select one of these views at a time from the Select View option in the Connectivity Services Director banner. The options are Device View, Custom Group View, and Topology View. To create a Custom Group, Connectivity Services Director must be in Custom Group View. Custom Groups are created at the top level of the network—My Network.

Once Custom Groups are created, they appear in all views as options for profile assignment—assigning a profile to a Custom Group assigns that profile to all members of the group.

How Do Custom Group Rules Work?

Adding rules to a Custom group consists of creating a three part rule statement, with a rule basis, an operator, and matching criteria. Possible combinations are shown in [Table 26 on page 195](#).

Table 26: Three Options of a Rule Statement

Rule Basis	Operator	Matching Criteria
Device Type	Equals or Not Equals	Router
Serial Number	Equals or Contains	<i>You provide serial numbers or letters</i>
SKU or Model	Equals or Contains	<i>You provide model numbers or letters</i>
Management IP Address	Equals or Regex	<i>You provide IP address</i>
Device Type	Equals or Not Equals	Router

Table 26: Three Options of a Rule Statement (*continued*)

Rule Basis	Operator	Matching Criteria
Firmware Version	Equals or Contains	<i>You provide a full or partial firmware version for devices</i>

What Happens When I Edit a Custom Group Rule?

When you edit a rule, devices that were added to the group but no longer qualify because of the rule edit are not automatically removed from the group. You must remove those devices manually. If more devices are now qualified to join the group because of your rule edit, the devices are added to the group on the next device notification change to the network.

When Are Rules Executed?

The option **Associate devices based on the rules for the custom groups while saving group information** is enabled by default. If the option is disabled, the rule engine will be activated only when there is some change in the device property. When a device property change occurs, rules are processed and devices are added to the group, if the group has a rule for those actions.

RELATED DOCUMENTATION

| [Creating Custom Device Groups](#) | 196

Creating Custom Device Groups

IN THIS SECTION

- [Creating Custom Groups](#) | 197
- [Creating a Custom Group](#) | 197

From Connectivity Services Director, you can create a custom group, then add devices, such as routers, to the group. Creating custom device groups enables the configuration of multiple devices simultaneously—you can also create multiple custom groups and directly associate devices at any level. What makes Custom Groups unique is that you can also configure a custom group to automatically add

devices after discovery. You indicate the criteria for additional devices with rules. Custom groups can then be created in a hierarchy up to eight levels deep. Each layer can contain up to 32 peer containers under a single parent container.

NOTE: A device can be part of a group at only one level in a hierarchy.

This topic describes:

Creating Custom Groups

To create custom groups:

1. In the top banner, under **Views**, select **Custom Group View**.
2. Click the **Build** icon in the Connectivity Services Director banner.
3. Click **Set Up Custom Group** under Key Tasks in the Tasks pane.

The Set Up Custom Group page opens, displaying a list of currently configured Custom Groups.

4. Configure the custom group, following the directions [“Creating a Custom Group” on page 197](#).
5. Click **Done**.

The new custom group appears in the Groups List.

Creating a Custom Group

Use the Set Up Custom Group page to define a group of devices that you can configure simultaneously.

To add a new custom group:

1. Type a Custom Group Name for the new group and then click **Add**.

The Custom Group tree is displayed with your new group added.

2. Click **Done** now to create the group with no child groups, devices, or rules. The *Message Data Saved Successfully* is displayed. Click **OK**.

For additional configuration, select your new group.

The options **Add Child Group**, **Assign Devices**, and **Add/Edit Rule** appear.

3. To add a child group under the new custom group:

- a. Be sure the correct custom group is selected—this group will become the parent group.
- b. Click **Add Child Group**.

The Add Child Group window opens, displaying a default child group name such as Group-0.

- c. Replace the default child group name.
- d. Click **Add**.

The new child group appears in the Custom Group list tree under the parent group.

TIP: Custom groups can be created in a hierarchy up to eight levels deep. Each layer can contain up to 32 peer containers under a single parent container.

4. To assign devices to a custom group:

- a. Select a custom group, either a parent or child group, and then click **Assign Devices**.

The Assign Devices To Custom Group window opens, displaying a list of discovered network devices, their IP addresses, and their platforms. Platforms include junos-acx, junos-m, junos-mx, and junos-ptx. These are devices that can be added to the group.

- b. Select one or more devices by adding a check mark and then click **Add**.

The devices are listed under the appropriate group in the Custom Groups List.

NOTE: A device can be part of a group at only one level in a hierarchy.

5. To add a rule that will automatically add devices to a parent or child custom group:

- a. Select a custom group, either a parent or child group, that will have devices added to it automatically when a specific rule has been met.
- b. Click **Add/Edit Rule(s)**.

The Add/Edit Rules window opens.

- c. Click **Add Rule**.

A rule statement is displayed with three columns—two columns display the words *Please select...*. The third column is blank.

- d. From the first *Please select...* option in the rule statement, select the basis for the rule. You are indicating that automatic additions to the list will be based on either **Device Type**, **Firmware Version**, **Serial Number**, **SKU/Model**, **Management IP**.
- e. From the second *Please select...* option in the rule statement, select an available operator, either **Equals**, **Not Equals**, **Like**, **Regex**, or **Contains**—the operators presented depend on the basis you selected in the first column. For example, if the basis for the rule is **SKU/Model**, then the only operator options are **Equals** and **Not Equals**.

TIP: The **Equals** operation matches all characters of the matching criteria. The **Like** operation matches the first few characters of the matching criteria.

- f. For the third option in the rule statement, provide a matching criteria. Matching criteria are indicated in the third column of the list shown in [Table 27 on page 199](#).

TIP: Some rules have no third option.

Table 27: Three Options of a Rule Statement

Rule Basis	Operator	Matching Criteria
Device Type	Equals or Not Equals	Router
Serial Number	Equals or Contains	<i>You provide serial numbers or letters</i>
SKU or Model	Equals or Contains	<i>You provide model numbers or letters</i>
Management IP	Equals or Regex TIP: Regex, a regular expression, consists of a sequence of characters that forms a search pattern.	<i>You provide IP address or regular expression</i> TIP: For example, <code>(?<=\.) {2,} (?=[A-Z])</code> is a regular expression.

Table 27: Three Options of a Rule Statement (*continued*)

Rule Basis	Operator	Matching Criteria
Firmware Version	Equals or Contains	<i>You provide a full or partial firmware version for devices.</i>

- g. Click **OK**.

Rules are executed when new devices are discovered. Devices that match the defined rules are added to the group dynamically once discovery is complete.

TIP: If you add more than one rule to a Custom Group, then all rules must be met for a device to join the group.

- The option **Associate devices based on the rules for the custom groups while saving group information** is enabled by default. When a device property change occurs, rules are processed and devices are added to the group, if the group has a rule for those actions. If you disable the option, the rule engine will be activated only when there is some change in the device property.
- Click **Done**.
A status window opens with either the message *Data saved successfully* or with an error message. Click **OK**.
- To edit a rule, select the appropriate custom group and then click **Add/Edit Rule**. When you edit a rule, devices in the group that no longer qualify because of the rule change are not automatically removed from the group. You must remove those devices manually. If more devices are now qualified to join the group because of your rule edit, the devices are added to the group on the next device notification change to the network.

TIP: To delete a device from the group, select the device and then click **Delete**. To delete an entire Custom Group, select the group and then click **Delete**. You are asked to confirm the deletion—click **OK**.

SEE ALSO

Configuring Quick Templates

IN THIS CHAPTER

- Understanding Quick Templates | 202
- Configuring and Managing Quick Templates | 203

Understanding Quick Templates

Quick templates is a way to create a base build for the devices. This feature enables you to use a CLI-based text editor to define your network configuration in the form of a template that you can apply to multiple devices in your network in addition to the profile assignment feature. Because quick templates are driven by Device Management Interface (DMI) schema, you can use them to set all the configuration parameters for any supported device.

Quick templates makes network configuration easier by providing a CLI-based text editor in which you can specify network configuration in a text file in the form of a template. You can apply this template to multiple devices in the network. For example, you can use quick templates to configure routing protocols such as BGP, OSPF, ISIS, or static routes by specifying the device configuration.

You can append or add the system commands or the user-defined commands in the form of the variables. The user-defined commands support variables in the format `$(variable_name)`, which must be populated with data when you apply a template to a device.

The variable name defined for each CLI must be unique. Otherwise, you cannot assign different values to those variables even though they are used in different CLIs. For example, if a variable say `$(description)` is used in two CLIs `set vlans $(name) description $(description)` and `set snmp description $(description)`, you will not be able to define different values to the descriptions. To define different values, you must change the variable name for one of the commands.

The [Table 28 on page 202](#) shows data types supported for the values entered for variables.

Table 28: Variable Data Types

Data Type	Description
Container	Holds other data types.

Table 28: Variable Data Types (continued)

Data Type	Description
String	Contains character strings.
Integer [Number]	Specifies a numeric value without a fractional component.
Boolean	Has two possible values: true and false. True if checked and False if unchecked.
Enumeration	Defines a variable to be a set of predefined constants. The variable is equal to one of the values that have been predefined for it.
Choice	Provides a radio button. Check the radio button to use the configuration option in the template.
String - Key [column in a table]	Identifies the uniqueness of the record in the table. If the table has a key specified , only one record with the given key could exist.

The Save option in the Create Quick Templates page enables you to save and also validate a template. If there are any conflicts in the configuration, you must resolve the conflicting variables in the configuration elements manually, before you deploy the configuration to the devices. Upon successful validation (and after you apply a template to a device), you can deploy the configurations (specified in the templates) to the devices. You can choose to deploy the configuration immediately, or at a later time. Depending upon the approval mode selected for your deployment, you can either deploy the changes directly or you can get an approval from the approver before deploying the changes. For more information about types of approval modes supported for deployments in Connectivity Services Director, see [“Setting Up User and System Preferences” on page 125](#).

RELATED DOCUMENTATION

[Configuring and Managing Quick Templates | 203](#)

Configuring and Managing Quick Templates

IN THIS SECTION

- [Creating a Quick Template | 205](#)
- [Applying Templates to Devices | 206](#)

- [Editing a Quick Template | 207](#)
- [Deleting a Quick Template | 207](#)
- [Cloning a Quick Template | 208](#)
- [Using the Quick Template Details Window | 208](#)
- [Viewing Deployed Quick Templates | 208](#)

You can create and manage custom templates for your device configurations that are deployable through Connectivity Services Director. Unlike other features that support implementation of only some of the device configurations, quick templates enables you to set up all the configuration parameters for any supported device because it is Device Management Interface (DMI) schema-driven.

Each device type is described by a unique data model that contains all the configuration data for that device. The Schema window shows the device family that you select while you create a template and the DMI schema that lists all the possible fields and attributes for a type of device. The latest schema describe the new features associated with recent device releases. After you create a quick template, you can add or delete device configuration details to and from quick templates by loading the configuration data from the schema. You need to apply these templates to devices manually.

If you click the **More tips** link you are guided on the variable and the command syntax usages. It also provides instructions on how to issue sub-commands. When defining your network configuration in quick templates by using a particular command, ensure that you define the sub-commands individually. Stating sub-commands as a single command causes errors. For example, the commands **set snmp location xyz** and **set snmp contact admin@example.com** are valid when defined individually. However, if you combine these commands into the single command **set snmp location xyz contact admin@example.com** schema validation treats the end command, **contact**, as an extra entry and displays an error.

To avoid any conflicts with the profile configurations while creating the template, a warning message **Please don't create any Profile conflict configuration** is displayed to indicate that you must not create a configuration as part of the template if the same configuration is available as part of the profile configuration.

The Templates page in the Quick Templates workspace lists the device templates created, in a tabular view. The [Table 29 on page 204](#) lists the columns in the table along with a description:

Table 29: Quick Templates

Column	Description
Creation Time	Date and time when the template was created.
Template Name	Name of the quick template.

Table 29: Quick Templates (*continued*)

Column	Description
Device Family	Name of the device family for which the template is created. Selecting the option Common indicates that the template is applicable for all the device families.
OS Version	Junos OS version of the device family selected.
Description	Description of the quick template.
Last Updated Time	Date and time when the template was last modified.
Last Updated By	User name of the person who created the template.

This topic describes:

Creating a Quick Template

Quick templates enable you create a template to define configurations for your devices. You can create and deploy quick templates from the Wired workspace.

To create a quick template:

1. Click the **Build** icon in the Connectivity Services Director banner.
2. Select **Wired > Tasks > Manage Quick Templates** in the Tasks pane.

The Manage Quick Template page appears.

3. Click **Create**.

The Create Quick Template page opens.

4. Specify the following details:

- **Name**—Type a name for the quick template. The quick template name is required. The quick template name must be unique and limited to 63 characters.
- **Description**—Type a description for the quick template. The description is optional and limited to 255 characters.
- **Device Family**—From the Device Family list, select an appropriate device family. Selecting the option **Common** in device family creates a generic template, which can be applied to any device family. Therefore, specify only the most common settings such as system, SNMP, or track group settings

that are applicable to all the platforms. If you want to define the settings that are specific to a platform select the appropriate platform from the device family instead of the Common option. For the list of device families supported by Connectivity Services Director, see the latest [Connectivity Services Director Release Notes](#).

NOTE: ACX Series routers are listed when you select the **Common** option from the Device Family list on the Create Quick Template page. If you select the option as **MX** from the Device Family list, only MX Series routers are displayed on the Assign Quick Templates page. To apply quick templates for ACX Series routers, you must select the Common option as the device family type.

- **OS Version**—From the OS Version list, select an appropriate DMI Schema version running on that platform. If you are unable to locate the DMI schema for a device family, you can update the DMI schema version on the Junos Space server. For more information about updating the DMI schema on the Junos Space server, see Junos Space documentation.

The Schema window displays the device family and the OS version selected in this step.

5. Type or paste the Junos commands in the text area provided in the CLI commands section. Alternatively, you can navigate through the configuration option levels (at the left side) in Schema and double-click the configuration option you want to add to the quick template. The selected configuration option is displayed in the CLI Commands text area. The configuration options available here depend on the device family you selected.
6. Optionally, you can modify the configuration in the CLI Commands text area by using the tool bar functionalities such as undo, redo, cut, copy, paste, and find.
7. Click **Save**.

The template you created is displayed in the quick templates table.

Applying Templates to Devices

After you create a template, you can define your device configuration to be managed by using the quick templates, and apply these templates to the multiple devices.

To assign a template to a device:

1. Select the check box against the quick template for which you want to assign the profile.
2. Click **Assign**.

The Assign Quick Template : template names page opens.

3. Choose at least one device to which the profile needs to be assigned.
4. Click **Next**.
5. Choose a device and specify the quick template variables in Configure attributes page and click **Save**.
For example, when you configure a VLAN interface in a quick template, you can specify the variables VLAN and interface names for that template for a selected device.
6. Optionally, you can apply the settings specified here to all the selected devices of a device family by selecting the check box against the option **Apply above settings to all other selected devices**.
7. Click **Next** and then click **Finish**.
8. Review the profile association with the quick template and then click **Finish**.

Editing a Quick Template

You can edit a quick template to modify configurations for your devices.

To edit a quick template:

1. Select the check box against the quick template that you want to modify.
2. Click **Edit**.

The Edit Quick Template : template name page opens.

3. Make the required changes to the quick template and click **Save**.

Deleting a Quick Template

To delete a quick template:

1. Select the check box against the quick template that you want to delete.
2. Click **Delete**.

The Delete Quick Templates window opens.

3. Click **Yes** to delete the quick template; else click **No**.

Cloning a Quick Template

A cloned quick template is a copy of an existing quick template. You can use the quick template as a primary copy to create clone of that template. When you clone a quick template, you create a copy of the entire device configuration, including its settings, and other contents. Cloning a quick template saves time if you are deploying device configuration that are similar to the primary copy, rather than creating a template and defining configurations multiple times.

To create a copy of an existing template:

1. Select the check box against the quick template you want to clone.
2. Click **Clone**.

The cloned template named primary template-clone is shown in the list of templates.

Using the Quick Template Details Window

Use the Quick Template Details window to view the details of the quick template. [Table 30 on page 208](#) describes the fields in this window.

Table 30: Quick Template Details

Field	Description
Name	Displays the name of the quick template.
Description	Provides a description of the quick template.
Device Family	Displays the device family for which quick template is created.
OS Version	Displays the Junos OS version for the selected device family.
CLI Commands	Displays the CLI commands configured for the device family.

Viewing Deployed Quick Templates

You deploy the device configurations defined in a quick template after you have applied the template to a device. The View Deployed Templates option enables an administrator or an operator to view the list of templates that are deployed to the devices.

You can mouse over the template name to view the date and time when the template was created and last modified.

The View Deployed Templates page lists the deployed templates device in a tabular view. The [Table 31 on page 209](#) lists the columns in the table along with a description.

Table 31: View Deployed Template

Column	Description
Template Name	Indicates the name of the template whose configuration is deployed to the system.
Creation Time	Indicates the date and time when the template was created.
Last Updated Time	Indicates the date and time when the template was last modified.
User Name	Indicates the user name of the person who created the template.

Depending upon the type of approval mode configured—Manual Approval or Auto Approval mode— you can either deploy the device configurations defined in the template directly or by pursuing an approval from a configuration approver for the device changes.

To view the list of quick templates that are deployed to a device:

1. Click the Build Mode icon in the Connectivity Services Director banner.
2. Select a device in the View pane.

The View Deployed Templates option appears under Wired>Tasks.

3. Click **View Deployed Templates**.

The Deployed Templates For Device: device name page displays listing the templates applied for that device.

Configuring Device Settings

IN THIS CHAPTER

- [Understanding Device Common Settings Profiles | 210](#)
- [Creating and Managing Device Common Settings | 211](#)
- [Assigning Device Common Settings to Devices | 224](#)

Understanding Device Common Settings Profiles

Connectivity Services Director enables you to configure device-level settings for routers in the Device Common Settings profile. Once you create the profiles, you can assign the profiles to a switch or a controller and you can deploy the profiles using the Deploy mode tasks.

Connectivity Services Director also creates Device Common Settings profiles when it discovers devices. It creates a Device Common Settings profile for each device it discovers, importing the device-level settings from the device into the profile.

While configuring the profiles, you can specify the basic settings, which includes the profile name, device user list, and time settings. Apart from the basic settings, you can optionally specify the management and protocol settings too.

RELATED DOCUMENTATION

[Creating and Managing Device Common Settings | 211](#)

[Assigning Device Common Settings to Devices | 224](#)

Creating and Managing Device Common Settings

IN THIS SECTION

- [Managing Device Common Settings | 211](#)
- [Creating a Device Common Settings Profile | 213](#)
- [Specifying Basic Settings for Device Common Settings | 215](#)
- [Specifying Management Settings for Routing Device Common Settings | 218](#)
- [Specifying Protocol Settings for Routing Device Common Settings | 221](#)
- [Reviewing and Saving a Device Common Settings Configuration | 223](#)
- [What to Do Next | 224](#)

Use the Manage Device Common Settings page to create new device common settings for routing devices and to manage the existing device common settings.

This topic describes:

Managing Device Common Settings

From the Manage Device Common Settings page, you can:

- Create a new Device Common Settings profile by clicking **Add**. For directions, see [“Creating a Device Common Settings Profile” on page 213](#).
- Modify an existing Device Common Settings profile by selecting it and clicking **Edit**.
- Assign a Device Common Settings profile to a device by selecting a profile and clicking **Assign**. For directions, see [“Assigning Device Common Settings to Devices” on page 224](#).
- Modify an existing assignment of a Device Common Settings profile by selecting the profile and clicking **Edit Assignment**.
- View information about a Device Common Settings profile by either double-clicking the profile name or by selecting the profile and clicking **Details**.
- Delete a Device Common Settings profile by selecting a profile and clicking **Delete**.

TIP: You cannot delete common settings profiles that are in use—that is, assigned to devices or used by other profiles. To see the current assignments for a profile, select the profile and click **Details**.

- Clone a Device Common Settings profile by selecting a profile and clicking **Clone**.

Table 32 on page 212 describes the device information available on the Manage Device Common Settings page. This page lists all Device profiles defined for your network, regardless of your current selected scope in the network view.

Table 32: Manage Device Common Settings Settings

Field Name	Action
Profile Name	Name given to the profile when the profile was created.
Family Type	The device family; ACX Series router, M Series router, MX Series router, and PTX Series router.
Description	Description of the Device profile entered when the profile was created.
Assignment State	Displays the assignment state of the profile. A profile can be: <ul style="list-style-type: none"> • Unassigned—When the profile is not assigned to any device • Deployed—When the profile is assigned to a device and is deployed from Deploy mode • Pending Deployment—When the profile is assigned to a device, but not yet deployed in the network. For deployment directions, see <i>Deploying Configuration to Devices</i>.
Assigned to	Displays the number of devices to which the profile assignment is done.
Creation Time	Date and time when the profile was created.
Last Updated Time	Date and time when the profile was last modified.
User Name	The username of the person who created or modified the profile.

TIP: All columns might not be displayed. To show or hide fields listed in the Manage Authorization Profiles table, click the down arrow on the field header, select **Columns**, and select or clear the check box adjacent to the field that you want to show or hide.

Creating a Device Common Settings Profile

In Connectivity Services Director, as an administrator, you can configure Device Common Settings profiles by using the Create Device Profile page for devices. You can view the summary of the configurations before saving the Device profile.

At minimum, you must specify the Device profile and profile name in the workflow. You can include additional configuration such as:

- Device users
- Management services
- Multicast, spanning-tree protocol (STP)
- Domain Name Server
- DHCP servers, DHCP Relay servers, Login Banner, and Global PoE settings for switches


You can create profiles on the basis of the device family and each Device profile is specific to a device family. After you create a Device profile, you assign the profiles to different devices.

NOTE: You can assign only one profile to a device. However, you can assign the same profile to multiple devices.

To create a Device profile:

1. Under Views, select one of these options: **Logical View**, **Device View** or **Custom Group View**.

TIP: Do not select **Dashboard View** or **Topology View**.

2. Click  in the Connectivity Services Director banner.
3. From the Tasks pane, select the type of network, the appropriate functional area, and select the name of the profile that you want to create. For example, to create a QoS profile for a device, click **Wired > Profiles > CoS**. The appropriate Manage Profile page opens.

4. Click **Add** to add a new profile.

If you chose to create a profile for the wired network, Connectivity Services Director opens the Device Family Chooser window.

- a. From the Device Family Chooser, select the device family for which you want to create a profile. The available device families are **Switching (EX)**, **Campus Switching ELS** (Enhanced Layer 2 Software), **Data Center Switching Non-ELS** and **Data Center Switching ELS**.

- b. Click **OK**.

The Create Device Common Settings wizard for the selected device family is displayed. It consists of four sections, Basic Settings, Management Settings, Protocol Settings, and Review.

If you chose to create a profile for the wireless network, Connectivity Services Director opens the Create Device Common Settings for Wireless wizard.

5. Specify the basic settings. Complete the Basic Setting wizard page as described in both the online help and in [“Specifying Basic Settings for Device Common Settings” on page 215](#).
6. When you have completed the basic settings, either click **Next** or click **Management Settings** at the top of the wizard window.
7. Complete the Management Settings described in both the online help and in the section [“Specifying Management Settings for Routing Device Common Settings” on page 218](#).
8. When you have completed the management settings, click **Next**.
9. Complete the protocol settings.
10. When you have completed the protocol settings, either click **Next** or click **Review** at the top of the wizard window.
11. You can either save your profile or make changes to your profile from the Review page. For more information, see [“Reviewing and Saving a Device Common Settings Configuration” on page 223](#).
12. Click **Finish** to save the Device profile configuration.

The system saves the Device profile and displays the Manage Device Common Settings page. Your new or modified Device profile is listed in the table.

Specifying Basic Settings for Device Common Settings

To configure the basic settings for any Device Common Settings profile, enter the settings described in [Table 33 on page 215](#). Mandatory settings are indicated by a red asterisk (*) that appears next to the field label in the user interface.

Table 33: Device Profile Basic Settings

Field	Action
Profile Name	Type a name for the profile.
Description	Type a description of the profile containing up to 256 characters.
Login Banner for EX Series switches, Campus Switching ELS, and Data Center Switching	Enter the banner text—this text is displayed in the banner when you log in to the device.
Country Code for wireless LAN controllers only	<div>Select the country code for the wireless LAN controllers. Country code settings are required on the primary wireless seed controller.</div> <div>TIP: Do not set the country code if you plan to provision the Device profile for active secondary and member nodes that will be part of a cluster.</div>
Device Users	

Table 33: Device Profile Basic Settings (*continued*)

Field	Action
Task: Add a Device User	<p>To add a device user:</p> <ol style="list-style-type: none"> Click Add under Device Users. The Add User window opens. Provide a username and password. Confirm the password. Enter a combination of 6 through 128 alphanumeric characters and special characters. The password is case sensitive and must be a combination of at least two different types of characters or a combination of upper case and lower case letters. TIP: Do not create a user with the name <i>root</i>. Select a role for the user: <ul style="list-style-type: none"> For switches, the role options are: Operator, Read-only, Super-user, or Unauthorized. Operators have clear, network, reset, trace, and view privileges. Super-Users have all privileges. For wireless controllers, the role options are: Framed, Administrative, or NAS-Prompt. Framed users have network user access only. Administrative users have access to the controller, including the enabled (configuration) mode. NAS-Prompt users have administrative access to the controller, excluding enabled mode. Click OK. The user is added to the list of Device Users. <p>TIP: To edit an entry, select a row from the Device Users table and click Edit to modify the information. To delete an entry select a row from the Device Users table and click Delete to delete the user.</p>
Time Settings	
Time settings apply to all platforms. However, the setting for offset applies exclusively to wireless.	
Time Zone	Select a country and time zone from the list. For wireless, you can also change the setting for Offset.

Table 33: Device Profile Basic Settings (*continued*)

Field	Action
Add a Time Server	<p>To add a time server:</p> <ol style="list-style-type: none"> 1. Click Add under Time Server. The Add Time Server window opens. 2. Provide an IP address and, optionally for switches only, mark the corresponding time server as Preferred. TIP: Valid IP addresses are 1.0.0.1 through 255.255.255.254 excluding 127.x.x.x and 224.0.0.0 through 239.255.255.255 3. Click OK. The server is added to the list of Time Servers. TIP: To edit the settings of a time server, select it and then click Edit.

To configure management settings, click **Next** or click **Management Settings** at the top of the wizard window. To skip the management settings and protocol settings, click **Review** at the top of the wizard window.

Specifying Management Settings for Routing Device Common Settings

To configure the management settings for an Routing Device profile:

1. Enter the settings described in [Table 34 on page 219](#). All settings are optional. Default values are applied to the configuration if you skip the management settings configuration.

Table 34: Device Profile Management Settings for Routing

Task	Action
Enable Services	You can enable one or more network protocol services for this Device profile: FTP , TELNET , HTTPS , or HTTP .
Configure PoE	<p>To add Power over Ethernet (PoE) configuration for Routing, enable Configure PoE and provide these settings:</p> <p>NOTE: PoE configuration will be added only to switches that support PoE.</p> <ol style="list-style-type: none"> a. Using the arrows, adjust the Guard Band value from 0 through 19 watts. A guard band reserves a specified amount of power from the PoE power budget for the router or line card in case of a spike in PoE consumption. For routers with multiple PoE line cards, the guard band wattage is set to the specified value on all line cards, unless a line card has been explicitly configured with a different value. b. Select a Management Mode for PoE, either Class or Static: <ul style="list-style-type: none"> • Class Management—In class PoE management mode, the maximum power for an interface is determined by the class of the connected powered device. • Static Management—In the static PoE management mode, you specify the maximum power for each PoE interface. The PoE controller then allocates this amount of power to the interface from its total budget. c. For PoE Global, you can indicate Enable All, Disable All, or None. <p>NOTE: If you deselect Configure PoE, PoE is disabled and the global PoE settings supported by this profile (poe guard-band, poe fpc all guard-band, poe management, poe fpc all management, and poe interface all) are deleted from the switch when the profile is deployed on the switch.</p>

Syslog Settings

Optionally, expand the Syslog Settings and provide the following system logging settings.

Table 34: Device Profile Management Settings for Routing (*continued*)

Task	Action
Enable Device Logging for Switches	<p>To enable device logging for switches:</p> <ol style="list-style-type: none"> Under Enable Device Log, click Add. The Add Log window opens. Select the log type for switching, either Console, File, User, or Host. <ul style="list-style-type: none"> Console logging sends system log messages to the console. File logging sends system log messages to the file you specify in File Name. User logging sends system log messages to the terminal session of the user specified in User Name. You will also need to provide the name of the user. Host logging sends system log messages to the server specified in Host. Host can be either an IP address or host name. Under Services, click Add. The phrase <i>Click to enter value</i> appears in both the Service column and Severity Filter column. Click the phrase <i>Click to enter value</i> in the Service column. A list box replaces the phrase in the Service column. From the Service list, select a logging service: Any, Authorization, Change-log, Conflict-log, Daemon, DFC, External, Firewall, FTP, Interactive-commands, Kernel, NTP, PFE, Security or User. Click the phrase <i>Click to enter value</i> in the Severity Filter column. A list box replaces the phrase in the Severity Filter column. Select an available severity filter from the list, either Alert, Any, Critical, Emergency, Error, Info, None, Notice, or Warning. The filter is added to the list of Severity Filters. The filter is activated when the corresponding service is triggered. Click OK. The log is added to the Enable Device Log list.
Edit Logging Settings	Select a Log Type from the Enable Device Log list and click Edit to change the configuration.

Table 34: Device Profile Management Settings for Routing (*continued*)

Task	Action
Delete Logging Settings	Select a Log Type from the Enable Device Log list and click Delete to remove the server configuration.

To configure protocol settings, either click **Next** or click **Protocol Settings**. To use the default protocol settings, skip to final review by clicking **Review** at the top of the wizard window.

Specifying Protocol Settings for Routing Device Common Settings

To configure the protocol settings for an Routing Device profile, enter the settings described in [Table 35 on page 221](#). All settings are optional.

Table 35: Device Profile Protocol Settings for Routing

Field	Action
Enable Storm Control	
Select this option to enable storm control on a switch.	
Spanning Tree Settings	
Spanning Tree Protocol Settings for switches only	<p>Select one of spanning-tree protocol (STP) settings for switches: STP, RSTP (default), MSTP, or None of these.</p> <ul style="list-style-type: none"> Spanning Tree Protocol—With STP configured, the switches use the IEEE 802.1D 2004 specification, force version 0. This configuration runs a version of RSTP that is compatible with classic, basic STP as defined in the 802.1D 1998 specification. Rapid Spanning Tree Protocol—RSTP provides faster reconvergence time than the original STP both by identifying certain links as point-to-point and by using protocol handshake messages rather than fixed timeouts. VLAN Spanning Tree Protocol (VSTP) and RSTP can be configured concurrently. You can selectively configure up to 253 VLANs by using VSTP; the remaining VLANs will be configured by using RSTP. VSTP and RSTP are the only spanning-tree protocols that can be configured concurrently on a switch. Multiple Spanning Tree Protocol—MSTP enables multiple VLANs to be mapped to the same spanning-tree instance, reducing the number of spanning-tree instances needed to support a large number of VLANs. MSTP provides multiple forwarding paths for data traffic and enables load-balancing. It improves the fault tolerance of the network because a failure in one instance, or forwarding path, does not affect other instances. <p>You can also select the Enable VSTP check box to enable VSTP.</p>

Table 35: Device Profile Protocol Settings for Routing (*continued*)

Field	Action
Multicast Settings	
Enable IGMP	Selecting this option enables Internet Group Management Protocol (IGMP) on all the interfaces for the selected device. Default is disabled. IGMP is a communications protocol used by both hosts and adjacent routers on IP networks to establish multicast group memberships.
Enable IGMP Snooping	Enables IGMP snooping on all VLANs. Default is enabled.
Enable DHCP Relay	
Select this option to display the DHCP Relay settings.	
Add DHCP Relay to Device Profile	<p>To add DHCP Relay to this Device Profile:</p> <ol style="list-style-type: none"> 1. Select Legacy DHCP Relay (default). 2. Add one or more DHCP servers to the Device Common Settings profile: <ol style="list-style-type: none"> a. Click Add under DHCP Servers. The Add Server window opens. b. Type an IP Address. c. Click OK. The server is added to the list of DHCP Servers.

Table 35: Device Profile Protocol Settings for Routing (*continued*)

Field	Action
Add Extended DHCP Relay to a Device Profile	<p>To add Extended DHCP Relay to this Device Profile:</p> <ol style="list-style-type: none"> 1. Select Extended DHCP Relay instead of Legacy DHCP Relay. 2. Add one or more DHCP Server Groups to the Device Common Settings profile: <ol style="list-style-type: none"> a. Click Add under Add DHCP Servers Group. The Add Server Group window opens. b. Provide a name for the server group. c. Optionally, make this an active server group by checking Active Group. d. Add servers to the group by clicking Add under DHCP Servers. The phrase <i>Click to enter value</i> appears in the IP Address column. e. Select <i>Click to enter value</i> and then enter an IP Address. f. Click OK. The server is added to the DHCP server group list. g. Add a relay interface group by clicking Add under Add Relay Interface Group. The Add DHCP Relay Interface window opens. h. Type a DHCP interface group name. i. Select a server group from the Server Group list. j. Click OK. The group is added to the Relay Interface Group list.

Click either **Next** or **Review**, to see the Review page. For review directions, see [“Reviewing and Saving a Device Common Settings Configuration” on page 223](#).

Reviewing and Saving a Device Common Settings Configuration

From this page, you can save or make changes to Device Common Settings:

- To make changes to the settings, click the **Edit** associated with the configuration you want to change.

Alternatively, you can also click appropriate sections of the workflow at the top of the page that corresponds to the configuration you want to change.

When you have completed your modifications, click **Review** to return to this page.

- To save a new profile or to save modified settings to an existing profile, click **Finish**.

The Manage Device Common Settings page is displayed with the new or modified profile listed

What to Do Next

Once the Device Common Settings profile is created, you must assign the profile to the required device by using the Manage Device Profile page and then deploy the Device profile by using the **Deploy** mode. To assign a Device Common Settings profile to a device, see *Security Director Release Notes*.

NOTE: A device can have only one Device profile assigned to it. However, you can assign the same Device profile to multiple devices.

RELATED DOCUMENTATION

[Understanding Device Common Settings Profiles | 210](#)

[Assigning Device Common Settings to Devices | 224](#)

Assigning Device Common Settings to Devices

IN THIS SECTION

- [Assigning Device Common Settings | 225](#)
- [Editing the Assignments of the Device Common Setting | 227](#)

Once a Device Common Settings profile is created or discovered (system-created profile), you must assign it to devices using the steps described in this topic. You can assign a Device profile to a either single device, a series of single devices, or a Custom Group of devices (see [“Creating Custom Device Groups” on page 196](#)).

NOTE: A device can have only one Device Common Settings profile assigned to it.

You must have one or more device profiles created or discovered before you can assign a device profile to a device. When you deploy an assigned device profile, the configuration is pushed onto the device.

This topic describes:

Assigning Device Common Settings

To assign device common settings to either a single device, a series of single devices, or members of a Custom Group:

1. Click **Build** task category in the Connectivity Services Director banner.
2. Select **Device Common Settings** from the Profile and Configuration Management menu in the Tasks pane.

The Manage Device Common Settings page is displayed. The page displays all the device profiles that you configured as well as the system-created profiles detected during device discovery.

3. Select an undeployed profile from the list of profiles and then click **Assign**.

The Assign Device Profile page for the selected device family appears with a wizard consisting of three parts, Device Selection, Profile Assignment, and Review. Device Selection is displayed.

4. Expand the Device Selection object tree and select one or more objects to receive the device profile. You must place a check next to a device to select it—simply highlighting the device does not select it.

NOTE: If Connectivity Services Director fails to read the configuration of one or more devices after device discovery, those devices are not displayed in the Device Selection list. You will not be able to assign profiles to those devices. The Manage Jobs page in System mode displays details of the device discovery jobs. Use the information displayed on this page to take appropriate corrective steps to enable Connectivity Services Director to reread the configuration of the failed device. For more information, see *Discovering Devices in a Physical Network*.

5. Click either **Next** or click **Profile Assignment** from the wizard workflow.

The Profile Assignment page opens, displaying your selections, including their Device (name), Type, Assigned To, and Attributes. The Assigned To column now has the entry DEVICE and the Attributes column has the entry Undefined.

6. Click **Define** in the **Attributes** column in the Assignments table to configure the attributes.

The Configure Attributes window opens, listing all the Layer 3 interfaces available on the device.

- a. Select the Layer 3 interfaces that are required for DHCP relay from the Available list and using the right arrow, move them to the Selected list. You can reorder the interfaces using the UP and DOWN arrows.
- b. Click **Save** to save the interface list and close the Configure Attributes window.

7. You can view the assignment details for the selected device and also remove any assignments:

- To view the assignment details, select the device and click **View Assignments**.

The Profile Details page for selected device appears. Expand the **Device** name to view the details of the assignment. The assignment status displays the status whether the device is deployed or is pending device update, and so on.

- To delete a device common setting assignment for a device, select the device from the Assignments table and click **Remove**.

8. Click **Next** or click **Review** from the wizard workflow to review the assignments. On the Review page, click **Edit** to edit the profile assignment.

9. Click **Finish** once you are done reviewing the profile assignment.

The Create Profile Assignments Job Details window appears with a status report for the profile assignment job—click **OK** to close this window. If you have assigned the profile to a large number of objects, the profile assignment job can take some time to complete. Instead of waiting for the Job Details dialog box to report job completion status, you can close it and check the details of the profile assignment job at a later time using the Manage Job task in System mode.

NOTE: If any assignment fails, the profile assignment job fails and none of the assignments are created. Check the details for the profile assignment job for information about why the assignment failed.

An assigned Device profile has the Assignment State *Pending Deployment* in the Manage Device Common Settings list. Deploy any device profile in this state.

To view the details of a profile, select the profile from the Manage Device Common Settings page and then click **Details**.

Editing the Assignments of the Device Common Setting

Use the Edit Assignments page to change device common setting assignments. To edit an existing assignment:

1. Select a profile from the **Manage Device Common Settings** page and click **Edit Assignment**.

The Edit Assignments page for the selected device appears.

2. Expand the **Devices** cabinet and make the desired change from the **Operation** column of the table.

3. Click **Define** from the **Attributes** column of the table to modify the attributes.

The Configure attributes page is displayed listing all the Layer 3 interfaces available on the device.

- Select the Layer 3 interfaces that are required for DHCP relay from the Available box and using the right arrow, move them to the Selected box.

You can rearrange the order of the interfaces using the up and down arrows.

- Click **Save** after you are done with selecting the interfaces.

4. Click **Apply** once you are done with the changes.

The Manage Device Common Settings page is displayed.

RELATED DOCUMENTATION

[Understanding Device Common Settings Profiles](#) | 210

[Creating and Managing Device Common Settings](#) | 211

Configuring Class of Service (CoS)

IN THIS CHAPTER

- [Understanding Class of Service \(CoS\) Profiles | 228](#)
- [Creating and Managing Wired CoS Profiles | 233](#)

Understanding Class of Service (CoS) Profiles

IN THIS SECTION

- [How Would I Use CoS \(also known as QoS\)? | 229](#)
- [How Does CoS Work? | 230](#)
- [What CoS Parameters Can I Control? | 231](#)
- [What Are the Default CoS Traffic Types? | 231](#)
- [Data Center Switching CoS Configuration | 232](#)
- [How Do I Implement Class of Service? | 232](#)
- [Editing Discovered CoS Profiles | 232](#)

When a network experiences congestion and delay, some packets must be prioritized to avoid random loss of data. Class of service (CoS) (also known as QoS) accomplishes this prioritization by dividing similar types of traffic, such as e-mail, streaming video, voice, large document file transfer, into classes. You then apply different levels of priority, such as those for throughput and packet loss, to each group, and thereby control traffic behavior. For example, when packets must be dropped, you can ensure that packet loss takes place according to your configured rules. CoS also enables you to rewrite the Differentiated Services code point (DSCP), IP precedence, or 802.1p CoS bits of packets exiting a specific interface, thus enabling you to tailor outgoing packets to meet the network requirements of remote peers.

On Data Center Switching devices, CoS can be used to configure Ethernet interfaces to support Fibre Channel over Ethernet (FCoE) traffic.

How Would I Use CoS (also known as QoS)?

On an Ethernet trunk, you can mark frames with a class-of-service (CoS) value. CoS is used to define trunk connections as full-duplex, incoming only, or outgoing only.

Network devices such as routers and switches can be configured to use existing CoS values on incoming packets from other devices (trust mode), or can rewrite the CoS values to something completely different. Layer 2 markings also can extend to the WAN; for example, with a frame relay network. CoS is usually limited to use within an organization's intranet.

With legacy telephone systems, CoS can be used to define the permissions an extension will have on a private branch exchange (PBX) or Centrex. Some users might need extended voicemail message retention or the ability to forward calls to a cell phone, while others have no need to make calls outside the office. Permissions for a group of extensions can be changed by modifying a CoS variable applied to the entire group.

NOTE: CoS configurations can be complicated, so unless it is required, we recommend that you do not alter the default class names or queue number associations.

How Do I Create CoS Groups?

Use 802.1Q tagged VLANs to group users and enable CoS to set priorities supported by downstream devices.

How Is CoS Different From QoS?

CoS operates only on 802.1Q VLAN Ethernet at the data link layer (layer 2), while quality-of-service (QoS) mechanisms operate at the IP network layer (layer 3). 802.1p Layer 2 tagging can be used by QoS to differentiate and shape network traffic.

How Does CoS Work?

CoS is a 3-bit field in an Ethernet frame header when 802.1Q VLAN tagging has been applied. The 3-bit field specifies a priority value between 0 and 7 that can be used by QoS to differentiate and shape network traffic. Different devices use different priority values. When you choose to create a CoS profile, Connectivity Services Director displays the priority based on the device family that you chose. You can modify these or add more priority values

It is helpful to think of forwarding classes as output queues. In effect, the end result of classification is the identification of an output queue for a particular packet. For a classifier to assign an output queue to each packet, it must associate the packet with one of the forwarding classes listed in [Table 36 on page 230](#).

Table 36: 3-Bit CoS Field in Ethernet Header with VLAN Tagging

CoS Value	Priority Applied
0	Best-effort is a backward compatibility feature.
1	Assured-forwarding offers a high-level of assurance that the packets are delivered as long as the packet flow from the client stays within a certain Service profile that you define.
2	<p>Multicast assured-forwarding offers a high level of assurance that the multicast packets are delivered as long as the packet flow from the customer stays within a certain Service profile that you define. The software accepts excess traffic, but it applies a tail drop profile to determine if the excess packets are dropped and not forwarded. Up to two drop probabilities (low and high) are defined for this service class.</p> <p>Multicast expedited-forwarding delivers assured bandwidth, low loss, low delay, and low delay variation (jitter) end-to-end for multicast packets in this service class. The software accepts excess traffic in this class, but in contrast to the multicast assured forwarding class, out-of-profile multicast expedited-forwarding class packets can be forwarded out of sequence or dropped.</p> <p>Multicast best-effort does not apply any special CoS handling to the multicast packets. These packets are usually dropped under congested network conditions.</p>
3	
4	
5	Expedited-forwarding delivers assured bandwidth, low loss, low delay, and low delay variation (jitter) end-to-end for packets in this service class.
6	
7	Network-connect

Note: The forwarding classes multicast expedited-forwarding, multicast assured-forwarding, and multicast best-effort are applicable to ACX, M, MX, PTX Series routers.

Differentiated Services indicate how a packet is forwarded. Because the three bits used in Layer 2 simple priority tagging provide minimal direction in managing traffic, the protocol Differentiated Services (DS or DiffServ) was developed to enhance traffic differentiation.

What CoS Parameters Can I Control?

You can use CoS profiles to group a set of class of service (CoS) parameters and apply it to one or more interfaces. You can configure the following parameters within a CoS profile:

- **Classifiers**—Packet classification refers to the examination of an incoming packet. This function associates the packet with a particular CoS servicing level.
- **Scheduler maps**—Schedulers define the properties of output queues. These properties include the amount of interface bandwidth assigned to the queue, the size of the memory buffer allocated for storing packets, the priority of the queue, and the drop profiles associated with the queue. You associate the schedulers with forwarding classes by means of scheduler maps. You can then associate each scheduler map with an interface, thereby configuring the queues, packet schedulers, and tail drop processes that operate according to this mapping.
- **Rewrite values**—A rewrite rule modifies the appropriate CoS bits in an outgoing packet. Modification of CoS bits enables the next downstream device to classify the packet into the appropriate service group. Rewriting or marking outbound packets is useful when the device is at the border of a network and must alter the CoS values to meet the policies of the targeted peer.
- **Traffic-control profile**—Traffic-control profiles enable traffic limitation of a certain class to a specified bandwidth and burst size. Packets exceeding the limits can be discarded, or can be assigned to a different forwarding class, a different loss priority, or both.

What Are the Default CoS Traffic Types?

On EX Series switches, the system provides you with these four predefined traffic types—Data, Voice, Video, and Network Control—with these default traffic configuration and shaping details:

- **Data**—Forwarding queue 0 (nd_best-effort), Buffer size 50%, Bandwidth reserved 30%
- **Voice**—Forwarding queue 5 (nd_expedited-forwarding), Buffer size 20%, Bandwidth reserved 0%
- **Video**—Forwarding queue 4 (nd_video-forwarding), Buffer size 20%, Bandwidth reserved 70%
- **Network Control**—Forwarding queue 7 (nd_network-control), Buffer size 10%, Bandwidth reserved 0%

For Campus Switching ELS, the system provides you with these four predefined traffic types—Data, Voice, Video, and Network Control—with these default traffic configuration and shaping details:

- Data—Forwarding queue 0 (nd_best-effort), Buffer size 50%, Bandwidth reserved 30%
- Voice—Forwarding queue 1 (nd_expedited-forwarding), Buffer size 20%, Bandwidth reserved 0%
- Video—Forwarding queue 2 (nd_video-forwarding), Buffer size 20%, Bandwidth reserved 70%
- Network Control—Forwarding queue 3 (nd_network-control), Buffer size 10%, Bandwidth reserved 0%

For Campus Switching ELS with *Hierarchical Port Scheduling* (Juniper Networks EX4600 Ethernet switches), Connectivity Services Director provides you with predefined forwarding classes—nd_cs_best-effort, nd_cs_video-forwarding, nd_cs_expedited-forwarding, and nd_cs_network-control. These forwarding classes are grouped under two priority groups—data_video_pg and voice_control_pg.

On data center switches, the system provides you with forwarding classes—nd_dc_best-effort, nd_dc_network-control, nd_dc_fcoe, nd_dc_no-loss, and nd_dc_mcast. These forwarding classes are grouped under three priority groups—data_control_pg, fcoe_noloss_pg, and multicast_pg.

For both Campus Switching ELS with *Hierarchical Port Scheduling* and Data Center Switching, you can modify and customize each of these priority groups and forwarding classes. For more details, see [“Creating and Managing Wired CoS Profiles” on page 233](#).

Data Center Switching CoS Configuration

For data center switching devices, these additional CoS features are available:

- Hierarchical Port Scheduling (ETS)—Hierarchical port scheduling (Enhanced Transmission Selection, or ETS) is a two-tier process that provides better port bandwidth utilization and greater flexibility to allocate resources to queues and to groups of queues.
- Priority-based flow control (PFC)—A link-level flow control mechanism.

How Do I Implement Class of Service?

CoS can be implemented from the MSS CLI, from Connectivity Services Director. RingMaster configures unicast traffic but does not configure multicast traffic. For directions to implement CoS from Connectivity Services Director, see [“Creating and Managing Wired CoS Profiles” on page 233](#).

Editing Discovered CoS Profiles

Duplicate scheduler configuration is deployed to the device when you edit a CoS profile that are automatically created by Connectivity Services Director as part of device discovery or out-of-band changes. In CoS configuration, a single classifier can be associated to multiple ports regardless of the other CoS configuration. When Connectivity Services Director discovers a device with such configuration it will create multiple profiles, based on the difference in other CoS configurations, and mapped to same classifier configuration. If you modify classifier settings in such a CoS profile that is created automatically by Connectivity Services Director, Connectivity Services Director cannot modify the configuration because

it is mapped to multiple profiles. Whenever you modify such a CoS profile that is created automatically, Connectivity Services Director will create new classifier settings configuration on the device and map the same to it, without affecting the existing classifier settings. Newly created classifier settings will have a name generated based on the profile name. Even if only one profile is mapped to the classifier settings, Connectivity Services Director creates new classifier settings and the old settings are orphaned.

NOTE: This behavior is applicable to both hierarchical and non hierarchical profiles, and is applicable for congestion notification profile name, traffic control profile name, scheduler map name, classifier name and rewrite rule settings.

RELATED DOCUMENTATION

| [Creating and Managing Wired CoS Profiles | 233](#)

Creating and Managing Wired CoS Profiles

IN THIS SECTION

- [Managing Wired CoS Profiles | 234](#)
- [Using the Default CoS Profiles for Routers | 235](#)
- [Using the Default CoS Profiles for Campus Switching ELS with Hierarchical Port Scheduling | 235](#)
- [Using the Default CoS Profiles for Data Center Switching | 235](#)
- [Creating a Wired CoS Profile | 236](#)
- [Specifying Settings for a Routing, Switching, and Campus Switching ELS CoS Profile | 237](#)
- [Specifying Settings for a Campus Switching ELS CoS Profile with Hierarchical Port Scheduling \(ETS\) | 241](#)
- [Specifying Settings for a Data Center Switching CoS Profile | 246](#)
- [What to Do Next | 255](#)

CoS profiles enable the grouping of class-of-service (CoS) parameters and apply them to one or more interfaces. Connectivity Services Director provides you with predefined traffic types for each CoS profile that you create. These traffic types represent the most common types of traffic for the device type. Each

of these templates has preconfigured values for all CoS parameters based on the typical application requirements. You can change the preconfigured values of these parameters to suit your requirements.

This topic describes:

Managing Wired CoS Profiles

From the Manage CoS Profiles page, you can:

- Create a new CoS profile by clicking **Add**. For details, see [“Creating a Wired CoS Profile” on page 236](#).
- Modify an existing CoS profile by selecting it and clicking **Edit**.
- View information about a profile by selecting the profile and clicking **Details**.
- Delete a CoS profile by selecting a profile and clicking **Delete**.

TIP: You cannot delete profiles that are in use—that is, assigned to objects or used by other profiles. To see the current assignments for a profile, select the profile and click **Details**.

- Clone an existing CoS profile by selecting it and clicking **Clone**.

[Table 37 on page 234](#) describes the information provided about wired CoS profiles on the Manage CoS Profiles page. This page lists all CoS profiles defined for your network, regardless of the scope you selected in the network view.

Table 37: Managing Wired CoS Profile Fields

Field	Description
Profile Name	Name given to the profile when the profile was created.
Family Type	The device family on which the profile was created: ACX Series routers, M Series routers, MX Series routers, PTX Series routers.
Description	<p>Description of the profile that was entered when the profile was created. If the profile was created by using the CLI and then discovered by Connectivity Services Director, the description is <i>Profile created as part of device discovery</i>.</p> <p>TIP: To display the entire description, you might need to resize the Description column by clicking the column border in the heading and dragging it.</p>
Creation Time	Date and time when the profile was created.
Update Time	Date and time when the profile was last modified.

Table 37: Managing Wired CoS Profile Fields (*continued*)

Field	Description
User Name	The username of the user who created or modified the profile.

TIP: All columns might not be displayed. To show or hide fields listed in the Manage Authorization Profiles table, click the down arrow on the field header, select **Columns**, and select or clear the check box adjacent to the field that you want to show or hide.

Using the Default CoS Profiles for Routers

When you install Connectivity Services Director, a default CoS profile (juniper_CoS_template) is added to the Manage CoS Profiles page for routers and EX Series switches, and another with the same name is added for Campus Switching ELS. Default CoS profiles have most basic settings preconfigured. For example, the forwarding classes in the default CoS profile have already been assigned with default scheduler values. However, you can use the Edit CoS Profile page to optimize your communication with the network by customizing the bandwidth and buffer size assigned to each of the forwarding classes in the default CoS profile.

Using the Default CoS Profiles for Campus Switching ELS with Hierarchical Port Scheduling

When you install Connectivity Services Director, juniper_CS_Hier_Ethernet_CoS is the default CoS profiles that is installed for Campus Switching ELS with Hierarchical Port Scheduling.

To see the settings configured for a default profile, select it on the Manage CoS Profiles page, then click **Details**.

Using the Default CoS Profiles for Data Center Switching

When you install Connectivity Services Director, the following default CoS profiles are installed for Data Center Switching:

- juniper_DC_NonHier_Ethernet_CoS
- juniper_DC_Hier_Ethernet_CoS
- juniper_DC_NonHier_CoS
- juniper_DC_Hier_CoS
- juniper_DC_Hier_FCoE_CoS


To see the settings configured for a default profile, select it on the Manage CoS Profiles page, then click **Details**.

Creating a Wired CoS Profile

In Connectivity Services Director, you can create a CoS profile to group a set of Class of Service parameters and apply it to one or more network sessions.

For a CoS profile, you must specify the profile name. You can use defaults for the other values.

To create a wired CoS profile:

1. Click  **Build** in the Connectivity Services Director banner.
2. Under Select View, select one of the following: **Device View** or **Custom Group View**.

TIP: Do not select **Dashboard View** or **Topology View**.

3. From the Tasks pane, expand **Wired**, expand **Profiles**, and then select **CoS**.
4. Click **Add** to add a new profile.
Connectivity Services Director opens the Device Family Chooser window.
5. From the Device Family Chooser, select the wired device family for which you want to create a profile.
The available device families are **Switching (EX)**, **Campus Switching ELS>Non-Hierarchical Port Scheduling**, **Campus Switching ELS>Hierarchical Port Scheduling**, and **Data Center Switching**.
6. Click OK.
7. Complete the appropriate settings using the steps mentioned in [“Specifying Settings for a Routing, Switching, and Campus Switching ELS CoS Profile” on page 237](#), [“Specifying Settings for a Campus Switching ELS CoS Profile with Hierarchical Port Scheduling \(ETS\)” on page 241](#), or [“Specifying Settings for a Data Center Switching CoS Profile” on page 246](#).

Specifying Settings for a Routing, Switching, and Campus Switching ELS CoS Profile

Create a CoS profile for switching by providing a profile name and, optionally, changing any default settings for Traffic Configuration and Shaping.

1. Enter the CoS switching settings described in [Table 38 on page 237](#). Required settings are indicated by a red asterisk (*) that appears next to the field label in the user interface.

Table 38: CoS Profile Settings for Routers, EX and Campus Switching ELS

Field	Action
Profile Name	Type the name of the profile. You can use up to 64 characters for profiles created for wired devices. Profile name must not contain special characters or spaces. Note that profiles that are automatically created by Connectivity Services Director as part of device discovery or out-of-band changes may contain the underscore (_) character.
Description	Type a description of the profile.

2. Connectivity Services Director includes four predefined traffic types, Data, Voice, Video, and Network Control. You can either modify those traffic types or you can create your own traffic type. Modify and customize any listed traffic type by selecting the traffic type from the list and clicking **Edit**, then changing any of the settings described in [Table 39 on page 237](#).
3. To create your own traffic type, click **Add** and then configure the settings described in [Table 39 on page 237](#).

Table 39: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS

Field	Description
Traffic Type	If you are editing a Connectivity Services Director default traffic type, this field cannot be changed. If you are adding a traffic type, indicate the type of traffic—this can be any value, such as a server name or something to do with your business.

Table 39: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Forwarding Name	<p>If you are editing a Connectivity Services Director default traffic type, this field cannot be changed. If you are adding a traffic type, you can use one of the predefined forwarding classes for your switch or you can create your own forwarding class. These forwarding classes are always provided: nd_best-effort, nd_network-control, nd_video-forwarding, and nd_expedited-forwarding. To create your own forwarding class, type a name instead of selecting an option.</p> <p>Most switches support the four predefined forwarding classes listed above. The exception is the EX4300 switch, which has eight default forwarding classes, including the standard four classes, plus multicast-network-connect, multicast-assured-forwarding, multicast-expedited-forwarding, and multicast-network-connect.</p>
Forwarding Queue	<p>Existing forwarding classes already have associated queues that cannot be altered. If you defined a new forwarding class by specifying your own Forwarding Name, then select an internal queue number to which forwarding classes are assigned. Most switches support queues 0 - 10. The exception is the EX4300 switch, which supports queues 0 - 11.</p> <p>By default, if a packet is not classified, it is assigned to the class associated with queue 0. You can assign more than one forwarding class to a queue number.</p>
Scheduler Map <p>A note in the Scheduler Map section indicates how much buffer size and bandwidth you have available to configure. For example, the message “You have been left with 0 percent buffer size and 0 percent bandwidth.” means that you have no available buffer or bandwidth, and you must reconfigure existing traffic types to free some bandwidth before configuring additional traffic types.</p>	
Low Priority	Enable Low Priority if you want the queue to receive low priority.

Table 39: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Strict High Priority	<p>Enable Strict High Priority if you want the queue to receive preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue.</p> <p>A strict-high priority queue receives preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue. Queues are scheduled according to the queue number, starting with the highest queue, 7, with decreasing priority down through queue 0. Traffic in higher-numbered queues is always scheduled prior to traffic in lower-numbered queues. In other words, in case of two high-priority queues, the queue with the higher queue number is processed first.</p> <p>NOTE: You can modify this field in the Traffic Configuration and Shaping table or from the Traffic Configuration and Shaping window.</p>
Buffer Size (%)	<p>Buffer Size (%) is the size of the memory buffer allocated for storing packets. Use the slider to specify the scheduler Buffer Size percentage.</p> <p>NOTE: You can modify this value by double-clicking this field in the Traffic Configuration and Shaping table or by sliding the bar in the Traffic Configuration and Shaping window.</p>
Bandwidth Reserved (%)	<p>Bandwidth Reserved (%) is the amount of interface bandwidth assigned to the queue. Move the slider to specify the Bandwidth Reserved percentage. Defaults are:</p> <ul style="list-style-type: none"> • Data: 30% • Voice: Strict High • Video: 70% • Network control: 0% <p>If Strict-High is enabled for this traffic type, you cannot reserve bandwidth.</p> <p>NOTE: This field displays the value based on either your input or on the transmit-rate parameter from the switch, if that parameter is configured. While specifying transmit-rate on the EX Series switch, if you choose to specify the value as an exact rate, Connectivity Services Director converts this value and displays it as a percentage in the Bandwidth Reserved (%) field. You can modify this percentage value from the CoS Profile page.</p>
Shaping Rate	<p>Move the Shaping Rate slider to throttle the rate of packet transmission by setting a maximum bandwidth (rate in bits per second) or a maximum percentage of bandwidth for a queue or a forwarding class.</p>

Table 39: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Traffic Classification	
Behavior aggregate classification classifies packets. The DSCP or DSCP IPv6 precedence bits of the IP header convey the behavior aggregate class information. The information might also be found in the IEEE 802.1ad, or IEEE 802.1p CoS bits.	
Classifier Type	<p>Select a classifier type—DSCP, DSCP-IPv6, INET-precedence, or IEEE-802.1—and associate the corresponding code-point aliases to loss priorities.</p> <p>NOTE: You can specify code-point—loss priority associations for one or more classifier types.</p> <ul style="list-style-type: none"> • DSCP—Differentiated services code point, a field in IPv4 headers, is used to classify traffic. • DSCP-IPv6—Differentiated services code point, a field in IPv6 headers, is used to classify traffic. • INET precedence—Field that indicates class of service rewrite rules are used to classify traffic. • IEEE-802.1—IEEE 802.1ad, or IEEE 802.1p CoS bits are used to classify traffic.
Classifier Code Points	
Code Points	<p>The code points list includes all available and unselected code points for the selected classifier type.</p> <p>Specify one or more code-point aliases or bit sets to associate with a forwarding class by moving the value to one of the two lists, Loss Priority Low or Loss Priority High.</p>
Loss Priority Low	Indicate that packets have low loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority Medium-Low	Indicate that packets have medium-low loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority Medium-High	Indicate that packets have medium-high loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.

Table 39: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (*continued*)

Field	Description
Loss Priority High	Indicate that packets have high loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.

4. Click **OK** to close the Add Traffic and Classification window and save your configuration.

Your changes are added to this CoS profile.

NOTE: If all bandwidth has already been reserved, your changes are not made. Reduce the bandwidth reserved from another Traffic Type, then repeat the configuration.

5. To configure rewrite rules for a forwarding queue, click **Configure Rewrite Rules** at the bottom of the screen. The Configure Rewrite Rules window appears. Specify rewrite rule settings as described below to alter CoS values in outgoing packets on the outbound interfaces of an edge switch:
 - a. Select the forwarding class for which you want to create or modify rewrite rules. Connectivity Services Director lists all the forwarding classes that you have used for configuring traffic in the Traffic Configuration and Shaping section.
 - b. For each classifier's loss priority, select a code-point alias for each loss-priority type—Low, Medium-Low, Medium-High, and High.
 6. Click **OK** to save the rewrite rules and close the Configure Rewrite Rules window.
- The system saves the rewrite rules and returns to the **Create CoS Profile** page.

7. Click **Done**.

After you create a CoS profile for switching devices, associate the CoS profile with a Port profile. For directions, see *Creating and Managing Port Profiles*.

Specifying Settings for a Campus Switching ELS CoS Profile with Hierarchical Port Scheduling (ETS)

You can create a CoS profile for Campus Switching ELS with Hierarchical Post Scheduling by specifying the profile settings and the traffic configuration and shaping details. Hierarchical port scheduling is a two-tier process that provides better port bandwidth utilization and greater flexibility to allocate resources

to queues and to groups of queues. Hierarchical scheduling includes the Junos OS implementation of enhanced transmission selection (ETS, described in IEEE 802.1Qaz).

When you open the Create CoS Profile page, Connectivity Services Director displays two predefined priority groups—data_video_pg and voice_control_pg—with default forwarding classes grouped under each of them. You can modify these priority groups or forwarding classes according to your network requirements.

To specify the settings for the CoS profile:

1. Enter the settings described in [Table 40 on page 242](#). Required settings are indicated by a red asterisk (*) that appears next to the field label in the user interface.

Table 40: CoS Profile Basic Settings for Campus Switching ELS CoS Profile with Hierarchical Port Scheduling (ETS)

Field	Action
Profile Name	Type the name of the profile. You can use up to 64 characters for profiles created for wired devices. Profile name must not contain special characters or spaces. Note that profiles that are automatically created by Connectivity Services Director as part of device discovery or out-of-band changes may contain the underscore (_) character.
Description	Type the description of the profile.

2. Specify settings in the Priority Group and Traffic Settings section.

The table lists priority groups and the forwarding classes they contain in an expandable list. Priority groups refer to forwarding class sets in the device. You can perform these tasks on priority groups and forwarding classes:

- To add a new priority group, click **Add Priority Group**. The Add Priority Group and Traffic Control Profile Window opens. Enter the settings as described in [Table 41 on page 243](#).

Table 41: Add Priority Group and Traffic Control Profile Window

Field	Description
Priority Group Name	Enter a name for the priority group.
Traffic Control Profile Settings	
Transmit Rate (%)	Select a transmit rate percentage for the priority group.
Shaping Rate (%)	Select a shaping rate percentage for the priority group.

- To edit a priority group or forwarding class's properties, click the field that you want to edit in the table. The properties that can be edited are described in [Table 42 on page 243](#).

Table 42: Priority Group and Traffic Settings Table Properties

Field	Description
No Loss	Select to make the forwarding class lossless. Not applicable to priority groups.
Strict High	Select to cause the forwarding class to receive preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue. Not applicable to priority groups.
Transmit Rate (%)	Select the percentage of interface bandwidth assigned to the forwarding class or priority group. If you have enabled Strict-High , you cannot reserve bandwidth for this traffic type.
Shaping Rate (%)	Select a shaping rate percentage for the forwarding class or priority group.
Buffer Size (%)	Select the percentage of the memory buffer allocated for storing packets for the forwarding class. Not applicable to priority groups.

- To edit a forwarding class's properties, click its name. The Edit Traffic Classification and Shaping for priority group window opens. Enter the settings as described in [Table 43 on page 243](#).

Table 43: Edit and Add Traffic Classification and Shaping for Priority Group Window

Field	Description
Forwarding Class Name	Select or specify a name for the forwarding class.

Table 43: Edit and Add Traffic Classification and Shaping for Priority Group Window (*continued*)

Field	Description
Forwarding Class Queue	Specify the internal queue numbers to which forwarding classes are assigned.
No Loss	Select to make the forwarding class lossless.
Scheduler Map	
Strict High	Select if you want the queue to receive preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue.
Transmit Rate	Select the percentage of interface bandwidth assigned to the forwarding class. If you have enabled Strict-High , you cannot reserve bandwidth for this traffic type.
Shaping Rate	Select a shaping rate percentage for the forwarding class.
Buffer Size (%)	Select the percentage of the memory buffer allocated for storing packets for the forwarding class.
Traffic Classification	
Classifier Type	Select the classifier type that maps packets to a forwarding class and a loss priority.
Code Points	Specify one or more code-points for associating with a forwarding class.
Loss Priority Low	Indicates that packets have low loss priority. Select code points from the Code Points table and use the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority Medium High	Indicates that packets have medium high loss priority. Select code points from the Code Points table and use the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority High	Indicates that packets have high loss priority. Select code points from the Code Points table and use the LEFT and RIGHT arrows to move them into the appropriate loss priority table.

- To add a forwarding class to a priority group, click the **Add Forwarding Class** link at the end of the priority group's list of forwarding classes. The Add Traffic Classification and Shaping for priority group window opens. Enter the settings as described in [Table 43 on page 243](#).
- To remove a priority group or forwarding class, click the **X** at the end of its table row.

- Specify priority-based flow control (PFC) settings in the PFC Settings section. Enter the settings as described in [Table 44 on page 245](#).

Table 44: PFC Settings for Campus Switching ELS CoS Profile with Hierarchical Port Scheduling (ETS)

Field	Description
Input Cable Length (meter)	Enter the length of the cable attached to the input interface, in meters.
Input	
Add	Click to add an input congestion notification profile (CNP). A new entry appears in the table.
Remove	Click to remove the selected input CNP.
IEEE Code Point	Select the IEEE code point for the input CNP.
Maximum Receive Size (bytes)	Enter the maximum receive unit (MRU) on an interface for traffic that matches the PFC priority, in bytes.
Output	
Add	Click to add an output CNP. A new entry appears in the table.
Remove	Click to remove the selected output CNP.
IEEE Code Point	Select the IEEE code point for the output CNP.
Queue List	Select output queues on which to enable flow control (PFC pause).

- Specify rewrite rule settings in the Rewrite Rule Settings section. Enter the settings as described in [Table 45 on page 245](#).

Table 45: Rewrite Rule Settings for Campus Switching ELS CoS Profile with Hierarchical Port Scheduling (ETS)

Field	Description
Forwarding Name	The name of the forwarding class.
Queue	The number corresponding to the forwarding queue. You cannot modify this field.
Rewrite Type	Select a rewrite-rules mapping for the traffic that passes through the various queues on the interface.

Table 45: Rewrite Rule Settings for Campus Switching ELS CoS Profile with Hierarchical Port Scheduling (ETS) (continued)

Field	Description
Egress Code Point - Loss Priority Low	Specify a code-point for association with a forwarding class for loss priority low.
Egress Code Point - Loss Priority Medium High	Specify a code-point for association with a forwarding class for loss priority medium high.
Egress Code Point - Loss Priority High	Specify a code-point for association with a forwarding class for loss priority high.

5. Click **Done** to save the changes to the profile.

Specifying Settings for a Data Center Switching CoS Profile

You can create a CoS profile by specifying the profile settings and the traffic configuration and shaping details.

To specify the settings for the CoS profile:

1. Enter the settings described in [Table 46 on page 246](#). Required settings are indicated by a red asterisk (*) that appears next to the field label in the user interface.

Table 46: CoS Profile Basic Settings for Data Center Switching

Field	Action
Profile Name	Type the name of the profile. You can use up to 64 characters for profiles created for wired devices. Profile name must not contain special characters or spaces. Note that profiles that are automatically created by Connectivity Services Director as part of device discovery or out-of-band changes may contain the underscore (_) character.
Description	Type the description of the profile.

2. In the Traffic Classification and Shaping Settings section, select one of these options:
 - **Hierarchical Port Scheduling (ETS)**—Hierarchical port scheduling (Enhanced Transmission Selection, or ETS) is a two-tier process that provides better port bandwidth utilization and greater flexibility to allocate resources to queues and to groups of queues (for QFX and QFabric devices).

- **Non Hierarchical Port Scheduling**—Non-hierarchical scheduling is a one-tier process that provides port bandwidth utilization and allocates resources to queues (for EX4500 and EX4550 transit switches).
3. If you selected Hierarchical Port Scheduling (ETS), specify settings in the Priority Group and Traffic Settings section.

The table lists priority groups and the forwarding classes they contain in an expandable list. Priority groups refer to forwarding class sets in the device. You can perform these tasks on priority groups and forwarding classes:

- To add a new priority group, click **Add Priority Group**. The Add Priority Group and Traffic Control Profile Window opens. Enter the settings as described in [Table 47 on page 247](#).

Table 47: Add Priority Group and Traffic Control Profile Window

Field	Description
Priority Group Name	Enter a name for the priority group.
Traffic Control Profile Settings	
Transmit Rate (%)	Select a transmit rate percentage for the priority group.
Shaping Rate (%)	Select a shaping rate percentage for the priority group.

- To edit a priority group or forwarding class's properties, click the field that you want to edit in the table. The properties that can be edited are described in [Table 48 on page 247](#).

Table 48: Priority Group and Traffic Settings Table Properties

Field	Description
No Loss	Select to make the forwarding class lossless. Not applicable to priority groups.
Strict High	Select to cause the forwarding class to receive preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue. Not applicable to priority groups.
Transmit Rate (%)	Select the percentage of interface bandwidth assigned to the forwarding class or priority group. If you have enabled Strict-High , you cannot reserve bandwidth for this traffic type.
Shaping Rate (%)	Select a shaping rate percentage for the forwarding class or priority group.
Buffer Size (%)	Select the percentage of the memory buffer allocated for storing packets for the forwarding class. Not applicable to priority groups.

- To edit a forwarding class's properties, click its name. The Edit Traffic Classification and Shaping for priority group window opens. Enter the settings as described in [Table 49 on page 248](#).

Table 49: Edit and Add Traffic Classification and Shaping for Priority Group Window

Field	Description
Forwarding Class Name	Select or specify a name for the forwarding class.
Forwarding Class Queue	Specify the internal queue numbers to which forwarding classes are assigned.
No Loss	Select to make the forwarding class lossless.
Scheduler Map	
Strict High	Select if you want the queue to receive preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue.
Transmit Rate	Select the percentage of interface bandwidth assigned to the forwarding class. If you have enabled Strict-High , you cannot reserve bandwidth for this traffic type.
Shaping Rate	Select a shaping rate percentage for the forwarding class.
Buffer Size (%)	Select the percentage of the memory buffer allocated for storing packets for the forwarding class.
Traffic Classification	
Classifier Type	Select the classifier type that maps packets to a forwarding class and a loss priority.
Code Points	Specify one or more code-points for associating with a forwarding class.
Loss Priority Low	Indicates that packets have low loss priority. Select code points from the Code Points table and use the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority Medium High	Indicates that packets have medium high loss priority. Select code points from the Code Points table and use the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority High	Indicates that packets have high loss priority. Select code points from the Code Points table and use the LEFT and RIGHT arrows to move them into the appropriate loss priority table.

- To add a forwarding class to a priority group, click the **Add Forwarding Class** link at the end of the priority group's list of forwarding classes. The Add Traffic Classification and Shaping for priority group window opens. Enter the settings as described in [Table 49 on page 248](#).
 - To remove a priority group or forwarding class, click the **X** at the end of its table row.
4. If you selected Non Hierarchical Port Scheduling, specify settings in the Traffic Configuration and Shaping table.

The table lists forwarding classes. You can perform these tasks on forwarding classes:

- To add traffic configuration and shaping details for different types of traffic, click **Add** in the Traffic Configuration and Shaping box. The Add Traffic Classification and Shaping window opens.
- To modify the details of an existing traffic configuration, select the traffic configuration from the list and click **Edit**. The Edit Traffic Classification and Shaping window opens.

NOTE: You can modify some of the details in the Traffic Configuration and Shaping table without having to open the Edit Traffic Classification and Shaping window—by clicking on the field that you want to modify.

- To delete a traffic configuration entry, select the traffic configuration from the list and click **Remove**.

The system deletes the selected traffic configuration entry.

To create your own traffic type, click **Add** and then configure the settings described in [Table 50 on page 249](#).

Table 50: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS

Field	Description
Traffic Type	If you are editing a Connectivity Services Director default traffic type, this field cannot be changed. If you are adding a traffic type, indicate the type of traffic—this can be any value, such as a server name or something to do with your business.

Table 50: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Forwarding Name	<p>If you are editing a Connectivity Services Director default traffic type, this field cannot be changed. If you are adding a traffic type, you can use one of the predefined forwarding classes for your switch or you can create your own forwarding class. These forwarding classes are always provided: nd_best-effort, nd_network-control, nd_video-forwarding, and nd_expedited-forwarding. To create your own forwarding class, type a name instead of selecting an option.</p> <p>Most switches support the four predefined forwarding classes listed above. The exception is the EX4300 switch, which has eight default forwarding classes, including the standard four classes, plus multicast-network-connect, multicast-assured-forwarding, multicast-expedited-forwarding, and multicast-network-connect.</p>
Forwarding Queue	<p>Existing forwarding classes already have associated queues that cannot be altered. If you defined a new forwarding class by specifying your own Forwarding Name, then select an internal queue number to which forwarding classes are assigned. Most switches support queues 0 - 10. The exception is the EX4300 switch, which supports queues 0 - 11.</p> <p>By default, if a packet is not classified, it is assigned to the class associated with queue 0. You can assign more than one forwarding class to a queue number.</p>
Scheduler Map <p>A note in the Scheduler Map section indicates how much buffer size and bandwidth you have available to configure. For example, the message “You have been left with 0 percent buffer size and 0 percent bandwidth.” means that you have no available buffer or bandwidth, and you must reconfigure existing traffic types to free some bandwidth before configuring additional traffic types.</p>	
Low Priority	Enable Low Priority if you want the queue to receive low priority.

Table 50: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Strict High Priority	<p>Enable Strict High Priority if you want the queue to receive preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue.</p> <p>A strict-high priority queue receives preferential treatment over a low-priority queue. Unlimited bandwidth is assigned to a strict-high priority queue. Queues are scheduled according to the queue number, starting with the highest queue, 7, with decreasing priority down through queue 0. Traffic in higher-numbered queues is always scheduled prior to traffic in lower-numbered queues. In other words, in case of two high-priority queues, the queue with the higher queue number is processed first.</p> <p>NOTE: You can modify this field in the Traffic Configuration and Shaping table or from the Traffic Configuration and Shaping window.</p>
Buffer Size (%)	<p>Buffer Size (%) is the size of the memory buffer allocated for storing packets. Use the slider to specify the scheduler Buffer Size percentage.</p> <p>NOTE: You can modify this value by double-clicking this field in the Traffic Configuration and Shaping table or by sliding the bar in the Traffic Configuration and Shaping window.</p>
Bandwidth Reserved (%)	<p>Bandwidth Reserved (%) is the amount of interface bandwidth assigned to the queue. Move the slider to specify the Bandwidth Reserved percentage. Defaults are:</p> <ul style="list-style-type: none"> • Data: 30% • Voice: Strict High • Video: 70% • Network control: 0% <p>If Strict-High is enabled for this traffic type, you cannot reserve bandwidth.</p> <p>NOTE: This field displays the value based on either your input or on the transmit-rate parameter from the switch, if that parameter is configured. While specifying transmit-rate on the EX Series switch, if you choose to specify the value as an exact rate, Connectivity Services Director converts this value and displays it as a percentage in the Bandwidth Reserved (%) field. You can modify this percentage value from the CoS Profile page.</p>
Shaping Rate	<p>Move the Shaping Rate slider to throttle the rate of packet transmission by setting a maximum bandwidth (rate in bits per second) or a maximum percentage of bandwidth for a queue or a forwarding class.</p>

Table 50: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Traffic Classification Behavior aggregate classification classifies packets. The DSCP or DSCP IPv6 precedence bits of the IP header convey the behavior aggregate class information. The information might also be found in the IEEE 802.1ad, or IEEE 802.1p CoS bits.	
Classifier Type	Select a classifier type— DSCP , DSCP-IPv6 , INET-precedence , or IEEE-802.1 —and associate the corresponding code-point aliases to loss priorities. NOTE: You can specify code-point—loss priority associations for one or more classifier types. <ul style="list-style-type: none"> • DSCP—Differentiated services code point, a field in IPv4 headers, is used to classify traffic. • DSCP-IPv6—Differentiated services code point, a field in IPv6 headers, is used to classify traffic. • INET precedence—Field that indicates class of service rewrite rules are used to classify traffic. • IEEE-802.1—IEEE 802.1ad, or IEEE 802.1p CoS bits are used to classify traffic.
Classifier Code Points	
Code Points	The code points list includes all available and unselected code points for the selected classifier type. Specify one or more code-point aliases or bit sets to associate with a forwarding class by moving the value to one of the two lists, Loss Priority Low or Loss Priority High.
Loss Priority Low	Indicate that packets have low loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority Medium-Low	Indicate that packets have medium-low loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.
Loss Priority Medium-High	Indicate that packets have medium-high loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.

Table 50: Traffic Configuration and Shaping for EX Switching and Campus Switching ELS (continued)

Field	Description
Loss Priority High	Indicate that packets have high loss priority by selecting code-point aliases from the Code Points table and using the LEFT and RIGHT arrows to move them into the appropriate loss priority table.

5. If you selected Hierarchical Port Scheduling (ETS), specify priority-based flow control (PFC) settings in the PFC Settings section. Enter the settings as described in [Table 51 on page 253](#).

Table 51: PFC Settings for Data Center Switching Hierarchical Port Scheduling (ETS) CoS Profile

Field	Description
Input Cable Length (meter)	Enter the length of the cable attached to the input interface, in meters.
Input	
Add	Click to add an input congestion notification profile (CNP). A new entry appears in the table.
Remove	Click to remove the selected input CNP.
IEEE Code Point	Select the IEEE code point for the input CNP.
Maximum Receive Size (bytes)	Enter the maximum receive unit (MRU) on an interface for traffic that matches the PFC priority, in bytes.
Output	
Add	Click to add an output CNP. A new entry appears in the table.
Remove	Click to remove the selected output CNP.
IEEE Code Point	Select the IEEE code point for the output CNP.
Queue List	Select output queues on which to enable flow control (PFC pause).

6. If you selected Non-Hierarchical Port Scheduling, specify priority-based flow control (PFC) settings in the PFC Settings section. Enter the settings as described in [Table 52 on page 254](#).

Table 52: PFC Settings for Data Center Switching Non-Hierarchical Port Scheduling CoS Profile

Field	Description
Input	
Add	Click to add an input congestion notification profile (CNP). A new entry appears in the table.
Remove	Click to remove the selected input CNP.

7. If you selected Hierarchical Port Scheduling (ETS), specify rewrite rule settings in the Rewrite Rule Settings section as described in [Table 53 on page 254](#).

Table 53: Rewrite Rule Settings for Data Center Switching CoS Profile

Field	Description
Forwarding Name	The name of the forwarding class.
Queue	The number corresponding to the forwarding queue. You cannot modify this field.
Rewrite Type	Select a rewrite-rules mapping for the traffic that passes through the various queues on the interface.
Egress Code Point - Loss Priority Low	Specify a code-point for association with a forwarding class for loss priority low.
Egress Code Point - Loss Priority Medium High	Specify a code-point for association with a forwarding class for loss priority medium high.
Egress Code Point - Loss Priority High	Specify a code-point for association with a forwarding class for loss priority high.

8. If you selected Non-Hierarchical Port Scheduling, click **Configure Rewrite Rules** at the bottom of the screen to configure rewrite rules for a forwarding queue. The Configure Rewrite Rules window appears. Specify rewrite rule settings as described below to alter CoS values in outgoing packets on the outbound interfaces of an edge switch:
- Select the forwarding class for which you want to create or modify rewrite rules. Connectivity Services Director lists all the forwarding classes that you have used for configuring traffic in the Traffic Configuration and Shaping section.

- b. For each classifier's loss priority, select a code-point alias for each loss-priority type—Low, Medium-Low, Medium-High, and High.

9. Click **Done** to save the changes to the profile.

What to Do Next

After you have created a CoS profile for switching devices, you can associate the CoS profile to a Port profile.

RELATED DOCUMENTATION

| [Understanding Class of Service \(CoS\) Profiles](#) | 228

Configuring Link Aggregation Groups (LAGs)

IN THIS CHAPTER

- [Understanding Link Aggregation | 256](#)
- [Managing and Creating a Link Aggregation Group | 256](#)

Understanding Link Aggregation

You can combine multiple physical Ethernet ports to form a logical point-to-point link, known as a link aggregation group (LAG) or bundle. A LAG provides more bandwidth than a single Ethernet link can provide. Additionally, link aggregation provides network redundancy by load-balancing traffic across all available links. If one of the links fails, the system automatically load-balances traffic across all remaining links. In a Virtual Chassis, LAGs can be used to load-balance network traffic between member routers.

The maximum number of interfaces that can be grouped into a LAG and the maximum number of LAGs supported on a router varies according to the router model and the version of and the version of Juniper Networks Junos operating system (Junos OS) that is running on that router.

RELATED DOCUMENTATION

| [Managing and Creating a Link Aggregation Group | 256](#)

Managing and Creating a Link Aggregation Group

IN THIS SECTION

- [Link Aggregation Group Options | 257](#)
- [Creating a Link Aggregation Group | 259](#)
- [What To Do Next | 260](#)

IEEE 802.3ad link aggregation enables you to group Ethernet interfaces to form a single link layer interface, also known as a link aggregation group (LAG) or bundle.

Aggregating multiple links between physical interfaces creates a single logical point-to-point trunk link or a LAG. Link Aggregation Control Protocol (LACP), a component of IEEE 802.3ad, provides additional functionality for LAGs.

LACP ensures that both ends of the Ethernet link are functional and are members of the aggregation group before the link is added to the LAG. If you use LACP, make sure that LACP is enabled at both the local and remote ends of the link. When LACP is configured, it detects misconfigurations on the local end or the remote end of the link. Thus, LACP can help to prevent communication failure. When LACP is not enabled, a local LAG might attempt to transmit packets to a remote single interface, which causes the communication to fail. However, when LACP is enabled, a local LAG cannot transmit packets unless a LAG with LACP is also configured on the remote end of the link.

The maximum number of interfaces that can be grouped into a LAG and the maximum number of LAGs supported on a router varies according to the router model and the version of Juniper Networks Junos operating system (Junos OS) that is running on that router. Be aware of the maximum number of interfaces per LAG and the maximum number of LAGs that are supported on your routers by referring to your device specific documentation before implementing LAG in your network.

NOTE: You only see the Manage Lag option under Device Management when a qualified router is selected in the View Pane.

When creating LAGs, follow these guidelines:

- You must configure the LAG on both sides of the link.
- You must set the interfaces on either side of the link to the same speed.
- You can configure and apply firewall filters on a LAG.

NOTE: You only see the Manage Lag option under Device Management when a qualified router is selected in the View Pane.

This topic includes:

Link Aggregation Group Options

From the Manage LAG page, you can:

- Create a new Link Aggregation by clicking **Create**. The Create Link Aggregation window opens—for directions, see [“Creating a Link Aggregation Group” on page 259](#).

- Modify an existing Link Aggregation by selecting it and clicking **Edit**. The Modify Link Aggregation window opens. You can modify all the fields in the Modify Link Aggregation window, except the Interface Name field.
- Delete a Link Aggregation Group by selecting it and clicking **Delete**.

Table 54 on page 258 describes the information provided about the link aggregation configurations on the LACP (Link Aggregation Control Protocol) Configuration page. This page lists all link aggregation groups defined on the selected device.

Table 54: LACP (Link Aggregation Control Protocol) Configuration Fields

Field	Description
Logical Interface Name	Name given to the aggregated interface when the LAG was created.
Member Interfaces	Names of individual member interfaces.
LACP Mode	<p>Mode in which LACP packets are exchanged between the interfaces.</p> <p>The possible modes are:</p> <ul style="list-style-type: none"> • Active—Indicates that the interface initiates transmission of LACP packets • Passive—Indicates that the interface responds only to LACP packets.
Description	<p>The description for the LAG.</p> <p>TIP: If you cannot view the entire description, you can resize the Description column by clicking the column border in the heading and dragging it.</p>
Deployment State	<p>The deployment state of the link aggregation. Deployment state can be:</p> <ul style="list-style-type: none"> • Pending Deployment—Indicates that the LAG is not yet deployed on the device. • Deployed—Indicates that the LAG is deployed on the device. • Pending Removal—Indicates that the LAG is deleted.
Creation Time	Date and time when this profile was created.
Update Time	Date and time when this profile was last modified.
User Name	The username of the user who created or modified the profile.

TIP: All columns might not be displayed. To show or hide fields in the LACP (Link Aggregation Control Protocol) Configuration table, click the DOWN arrow on the field header, select **Columns**, and select or clear the check box adjacent to the field that you want to show or hide.

Creating a Link Aggregation Group

You can create one or more LAGs for your device in Device view. The number of interfaces that can be grouped into a LAG and the total number of LAGs supported on a router varies according to router model.

To create a link aggregation group:

1. In the View pane, select a router for link aggregation.

NOTE: The Manage LAG task is only available when a qualified router is selected in the View pane.

2. Click the **Build** icon in the Connectivity Services Director banner.

3. Select **Wired > Manage LAG** in the Tasks pane.

The Manage LAG page opens.

4. Click **Create**.

The Create Link Aggregation window opens.

5. Use the up and down arrows to select an AE Name for the aggregation interface. The interface name begins with *ae* followed by an interface number.

6. Select the mode in which LACP packets are to be exchanged between interfaces, either **Active** or **Passive**.

- **Active**—Indicates that the interface initiates transmission of LACP packets
- **Passive**—Indicates that the interface responds only to LACP packets.

7. Enter a description for the link aggregation.

8. Configure up to eight available interfaces on the LAG. Select one or more interfaces from the Available list and then click the RIGHT arrow to move them to the Selected list.

NOTE: The Available interfaces list displays only those interfaces that are not part of any link aggregation.

9. If the device is capable of using MC-LAGs, an MC-LAGs section also appears in the Create Link Aggregation window. For information about MC-LAG configuration, see *MC-LAG Settings*.

10. Click **OK** to save the link aggregation configuration.

A message confirms that the link aggregation is created successfully and ready to be deployed to a device. If the configuration contains an error, the message instead indicates the error.

11. Click **OK** to close the information message.

The LAG appears in the Manage LAG list.

What To Do Next

The configuration changes that you make in the Build mode are not deployed to devices automatically. After you create a link aggregation group, you must manually deploy the changes to the routers in Deploy mode. For details, see *Deploying Configuration to Devices*.

TIP: Even though link aggregation configuration is not contained within a profile, you can view the link aggregation groups assigned to a router by using the View Assigned Profiles task in Build mode.

RELATED DOCUMENTATION

| [Understanding Link Aggregation](#) | 256

Managing Network Devices

IN THIS CHAPTER

- Viewing the Device Inventory Page in Device View of Connectivity Services Director | 262
- Viewing the Physical Inventory of Devices | 264
- Viewing Licenses With Connectivity Services Director | 265
- Viewing a Device's Current Configuration from Connectivity Services Director | 267
- Accessing a Device's CLI from Connectivity Services Director | 267
- Accessing a Device's Web-Based Interface from Connectivity Services Director | 268
- Deleting Devices | 270
- Rebooting Devices | 270

Viewing the Device Inventory Page in Device View of Connectivity Services Director

The Device Inventory page lists devices managed by Connectivity Services Director and provides basic information about the devices, such as IP address and current operating status. The Device Inventory page is available in Build and Deploy mode and is the default landing page for Build mode.

The scope you have selected in the View pane and the network view that you have selected from the View selector determines which devices are listed in the Device Inventory page. For example:

- If you are in the Device View and select My Network, all devices managed by Connectivity Services Director are listed.

The Device Inventory page provides three pie charts that summarize the status of the devices in your selected scope:

- Devices by Family—Indicates the proportion of devices in each device family.
- Connection State—Shows the proportion of devices that are up or down. In this chart, Virtual Chassis count as one device.
- Configuration State—Shows the proportion of devices in each configuration state. See the Config State entry in [Table 55 on page 262](#) for definitions of the configuration states.

Mouse over a pie segment to view the actual number of devices and the percentage represented by that pie segment.

[Table 55 on page 262](#) describes the fields in the Device Inventory table.

Table 55: Fields in the Device Inventory Table

Field	Description
Hostname	Configured name of the device or IP address if no hostname is configured.
IP Address	IP Address of the device.
Serial Number	Serial number of device chassis.
Platform	Model number of the device.
OS Version	Operating system version running on the device.
Device Family	Device family of the device, such as JUNOS for MX Series routers.

Table 55: Fields in the Device Inventory Table (*continued*)

Field	Description
Device Type	Type of the device: <ul style="list-style-type: none"> ROUTER—ACX Series routers, M Series routers, MX Series routers, and PTX Series routers
Connection State	Connection status of the device in Connectivity Services Director: <ul style="list-style-type: none"> UP—Device is connected to Connectivity Services Director. DOWN—Device is not connected to Connectivity Services Director. N/A—Access point state is unavailable to Connectivity Services Director.
Config State	Displays the configuration status of the device: <ul style="list-style-type: none"> In Sync—The configuration on the device is in sync with the Connectivity Services Director configuration for the device. Out Of Sync—The configuration on the device does not match the Connectivity Services Director configuration for the device. This state is usually the result of the device configuration being altered outside of Connectivity Services Director. You cannot deploy configuration on a device from Connectivity Services Director when the device is Out Of Sync. To resolve this state, use the Resynchronize Device Configuration task in Deploy mode. Sync failed—An attempt to resynchronize an Out Of Sync device failed. Synchronizing—The device configuration is in the process of being resynchronized. N/A—The device is down or is an access point.
Manageability State	Displays if the device is directly manageable or not. <p>This is a hidden field. To display the Manageability State field, click any column, click the down arrow to expand the list, select Columns from the list, and then enable Manageability State.</p>

NOTE: Juniper Networks devices require a license to activate the feature. To understand more about Connectivity Services Director Licenses, see, [Licenses for Network Management](#). Please refer to the Licensing Guide for general information about License Management.

RELATED DOCUMENTATION

[Viewing the Physical Inventory of Devices](#) | 264

Viewing the Physical Inventory of Devices

You can view the physical inventory of all the devices in your network in the Device Physical Inventory page. The Device Physical Inventory page displays information about the slots that are available for a device and provides information about power supplies, chassis cards, fans, part numbers, and so on. Connectivity Services Director displays hardware inventory by device name, based on data retrieved both from the device during discovery and resynchronizing operations, and from the data stored in the hardware catalog. For each managed device, the physical inventory page provides descriptions for field replaceable units (FRUs), part numbers, model numbers, and the pluggable locations from which empty slots are determined.

To view the Device Physical Inventory page, while in the Build mode, select a router from the View pane and select **Device Management > Physical Inventory** from the Tasks pane.

The physical inventory page displays the model number, part number, serial number, and description for the following, depending on the device that you selected:

- For standalone routers, the page displays details of the switch, the chassis, the Flexible PIC Concentrator (FPC), the PIC slot, the PIC installed in the PIC slot, the power supply, the fan tray, and the routing engine.

You can view the following details from the Device Physical Inventory page as described in [Table 56 on page 264](#).

Table 56: Fields in the Device Physical Inventory Table

Field	Description
Item	Name of the device and the components that are part of the device. By default, Connectivity Services Director displays the device and components in an expanded tree structure. You can click a device or component to collapse or expand the sub-components.
Model Number	Model number of the FRU hardware component.
Part Number	Part number of the router chassis component.
Serial Number	The hardware serial number of the device.
Description	The description about the component.

NOTE: Juniper Networks devices require a license to activate the feature. To understand more about Connectivity Director Licenses, see, [Licenses for Network Management](#). Please refer to the Licensing Guide for general information about License Management. Please refer to the product Data Sheets for further details, or contact your Juniper Account Team or Juniper Partner.

RELATED DOCUMENTATION

- [Viewing the Device Inventory Page in Device View of Connectivity Services Director | 262](#)
- [Viewing Licenses With Connectivity Services Director | 265](#)
- [Viewing a Device's Current Configuration from Connectivity Services Director | 267](#)

Viewing Licenses With Connectivity Services Director

Juniper Networks devices require a license to operate some features. You can view the licenses for devices connected to Connectivity Services Director.

To view the license for a Juniper Networks device on your network:

1. Select the **Build** icon in the Connectivity Services Director banner.
2. In the View pane, select a device.
3. In the Tasks pane, select **View License Information**.

The Licenses page for that object is displayed with the fields listed in [Table 57 on page 265](#).

Table 57: Viewing Licenses with Connectivity Services Director

Field	Description
Feature Name	Name of the licensed SKU or feature. It can be used to look up the license with Juniper Networks. Not all devices support this.
License Count	Number of times an item has been licensed. This value can have contributions from more than one licensed SKU or feature. Alternatively, it can be 1, no matter how many times it has been licensed.

Table 57: Viewing Licenses with Connectivity Services Director (*continued*)

Field	Description
Used Count	Number of times the feature is used. For some types of licenses, the license count will be 1, no matter how many times it is used. For capacity-based licensable items, if infringement is supported, the license count can exceed the given count, which has a corresponding effect on the need count.
Need Count	Number of times the feature is used without a license. Not all devices can provide this information.
Given Count	Number of instances of the feature that are provided by default.

NOTE: If a device does not have a license, a blank page is displayed with the message, **No license is installed on this device**. If you are sure the device has a license, try resynchronizing the device before displaying the license again.

NOTE: If you apply a new license to an existing device, you must resynchronize the device before the new license is seen in Connectivity Services Director. For directions, see [“Resynchronizing Device Configuration” on page 839](#).

RELATED DOCUMENTATION

[Viewing the Device Inventory Page in Device View of Connectivity Services Director | 262](#)

[Viewing the Physical Inventory of Devices | 264](#)

[Viewing a Device's Current Configuration from Connectivity Services Director | 267](#)

Viewing a Device's Current Configuration from Connectivity Services Director

You can view a device's current configuration from Connectivity Services Director. This is a convenient way to view device configurations without leaving Connectivity Services Director.

To view a device's current configuration:

1. Click **Build** or **Deploy** in the Connectivity Services Director banner.
2. Select the device in the View pane.
3. Select **Device Management > Show Current Configuration** in the Tasks pane.
4. The device's current configuration displays in the main window.

RELATED DOCUMENTATION

[Viewing the Device Inventory Page in Device View of Connectivity Services Director | 262](#)

[Viewing the Physical Inventory of Devices | 264](#)

[Viewing Licenses With Connectivity Services Director | 265](#)

Accessing a Device's CLI from Connectivity Services Director

Connectivity Services Director enables you to connect to the CLI for devices in your network, using SSH.

This topic describes the steps to connect to a router by using SSH (Secure Shell). SSH is a cryptographic network protocol used for remote shell services or command execution. SSH is one of the many access services that are supported on the Juniper Networks devices. All Juniper Network devices have SSH enabled by default.

To connect to a device by using SSH:

1. Do one of the following:
 - In the View pane, select the device to which you want to connect.
 - In the Topology View, locate the device to which you want to connect.
2. Do one of the following:

- With the device selected in the View pane, select **Build** mode and select **Tasks > Device Management > SSH to Device**.
- While in the Topology View, select the device to which you want to launch the SSH connection and click **Device Management > SSH To Device**.

The SSH to Device dialog box appears.

3. Enter the username and password to connect to the selected device and click **Connect**.

NOTE: Ensure that you have removed Pop-Up blockers, if any, before you click Connect.

The SSH console to the router or controller opens in a separate browser tab or window depending on your browser settings. Refer to the [MX Series documentation](#) for more information about using the CLI for MX Series routers.

NOTE: Any configuration changes you make to a device, using the CLI qualify as out-of-band changes in Connectivity Services Director. Out-of-band configuration changes can cause the configuration state of a managed device to become out of sync, which indicates that the device configuration no longer matches the Build mode configuration for the device. Use the Resynchronize Device Configuration task in Deploy mode to resynchronize the device configuration.

RELATED DOCUMENTATION

| [Accessing a Device's Web-Based Interface from Connectivity Services Director](#) | 268

Accessing a Device's Web-Based Interface from Connectivity Services Director

Connectivity Services Director enables you to connect to the routers in your network, using the device Web-based interface.

This topic describes the steps to connect to a router by using the J-Web interface or to a controller by using Web View. The J-Web interface is a graphical user interface, using which you can monitor, configure,

troubleshoot, and manage routers. Web View is a web-based management application that enables you to perform common configuration and management tasks on devices.

You can connect and configure a device by using the J-Web interface or Web View only if the device is configured to accept HTTP or HTTPS as a management service. You can configure HTTP or HTTPS as a management service using the Device Common Settings profile.

To connect to a device using the J-Web interface or Web View:

1. Do one of the following:
 - In the View pane, select the device to which you want to connect.
 - In the Topology view, locate the device to which you want to connect.
2. Do one of the following:
 - While selecting the device in the View pane, select Build mode and select **Tasks** pane > **Device Management** > **Launch Web View**.
 - While in the Topology View, select the device for which you want to launch the Web connection and click **Device Management** > **Launch Web View**.

The Web View or J-Web Login page appears.

3. Enter the username and password to connect to the selected router and click **Login**.

If the credentials that you entered are valid, the system displays the J-Web or Web View home page for the selected device.

NOTE: Any configuration changes you make to a device using the Web interface qualify as out-of-band changes in Connectivity Services Director. Out-of-band configuration changes can cause the configuration state of a managed device to become out of sync, which indicates that the device configuration no longer matches the Build mode configuration for the device. Use the Resynchronize Device Configuration task in Deploy mode to resynchronize the device configuration.

RELATED DOCUMENTATION

| [Accessing a Device's CLI from Connectivity Services Director](#) | 267

Deleting Devices

You can delete devices that are no longer used from Connectivity Services Director. Deleting a device removes all device configuration and device inventory information from the Junos Space database. Once a device is deleted from the database, all the profiles associations, device configurations, and inventory information of the deleted device are also deleted. However, the system maintains the audit logs and monitoring data for the device even after the device is deleted.

Use the Delete Devices page to delete devices from Connectivity Services Director. While in Build mode, click **Delete Devices** from the **Tasks > Device Management** menu. The Delete Devices page appears.

The Delete Devices page displays the devices contextually depending on your selection in the View pane. For example, if you select a particular switch family in Device View and click Delete Devices, only switches that belong to that switch family are displayed.

To delete devices, complete the following tasks:

1. Select the check box adjacent to the devices that you want to delete.
2. Click **Done**.

Connectivity Services Director prompts you to confirm the deletion. Click **Yes** to confirm the deletion or **No** to go back and make changes to the selection.

RELATED DOCUMENTATION

| [Rebooting Devices](#) | 270

Rebooting Devices

Use the Reboot Devices task to immediately reboot the selected device. This task is available in all scopes when in Build mode. To reboot one or more devices immediately:

1. Select the scope in the View pane that contains the devices you want to reboot.
2. Select Reboot Devices from the Tasks pane.
3. Expand the tree on the page as needed to locate the available devices.

4. Select the check box for one or more devices.
5. Click **Done** to start the reboot or click **Cancel** to return to the Device Inventory page.

The rebooting process triggers a Cold Start Alarm that can be seen in Fault mode.

RELATED DOCUMENTATION

| [Deleting Devices](#) | 270

5

PART

Building a Topology View of the Network

Downloading and Installing CSD-Topology | **273**

Configuring Topology Acquisition and Connectivity Between the CSD-Topology and Path Computation Clients | **305**

Accessing the Topology View of CSD-Topology | **315**

Downloading and Installing CSD-Topology

IN THIS CHAPTER

- CSD-Topology Installation and Configuration Overview | 273
- Installation Prerequisites | 274
- Installing the CSD-Topology Software Using the RPM Bundle | 275
- Minimum Hardware and Software Requirements for Junos VM on VMWare | 276
- Installing the JunosVM for CSD-Topology | 276
- Connecting an x86 Server to the Network | 296
- Interactive Method of Installing the RPM Image and CSD-Topology Software from a USB or DVD Drive | 301

CSD-Topology Installation and Configuration Overview

Install Juniper Networks CSD-Topology by downloading and installing the CSD-Topology RPM bundle.

For the RPM bundle installation, we recommend that you install CentOS 6.6 or 6.7 with the minimal ISO. If you are using a different version of Linux, contact JTAC to determine whether your Linux version is supported.

After you successfully install the CSD-Topology software on an x86 server, you must establish a connection between the CSD-Topology and the network by configuring Path Computation Element Protocol (PCEP) on each PE router to configure the router as a Path Computation Client (PCC). A PCC supports the configurations related to the Path Computation Element (PCE) and communicates with the CSD-Topology (PCE), which by default is configured to accept a PCEP connection from any source address. After you have established communication between the CSD-Topology and the PCCs, you can configure topology acquisition using BGP-LS. For BGP-LS topology acquisition, you must configure both the CSD-Topology and the PCC routers.

NOTE:

We recommend that you use BGP-LS instead of IGP adjacency for topology acquisition for the following reasons:

- The OSPF and IS-IS databases have lifetime timers, which means that if the OSPF or IS-IS neighbor is down, the corresponding database is not removed immediately. CSD-Topology is, therefore, not able to determine whether the topology is valid.
- Using BGP-LS minimizes the risk of making the JunosVM a transit router between AS areas if the GRE metric is not properly configured.
- Typically, CSD-Topology is located in a Network Operations Center (NOC) Data Center, multihops away from the backbone and MPLS TE routers. This is easily accommodated by BGP-LS, but more difficult for IGP protocols because they would have to employ a tunneling mechanism such as GRE to establish adjacency.

RELATED DOCUMENTATION

| [Connecting an x86 Server to the Network](#) | 296

Installation Prerequisites

Before you install CSD-Topology, ensure your system meets the following requirements:

- Recommended minimum hardware requirements:
 - 32 GB RAM
 - 500 GB HDD
- CSD-Topology supports the CentOS 6.x versions only. CentOS 7 is not supported.

RELATED DOCUMENTATION

| [Connecting an x86 Server to the Network](#) | 296

Installing the CSD-Topology Software Using the RPM Bundle

We recommend that you install CentOS 6.6 or 6.7 with the minimal ISO. CentOS can be downloaded from http://mirror.centos.org/centos/6/isos/x86_64. If you are using a different version of Linux, contact JTAC to determine whether your Linux version is supported.

For the hardware requirements that must be met for installing the CSD-Topology software or virtual machine (VM), see “[Installation Prerequisites](#)” on page 274.

1. Access the Junos Space Connectivity Services Director software download page:

```
https://www.juniper.net/support/downloads/?p=spacecsd
```

2. Select the Software tab.
3. From the Version drop-down menu, select **2.0**.
4. From under the Application Package heading, download CSD-Topology.
5. Install the RPM bundle.

```
[root@hostname~]# rpm -ivh
CSD-Topology-Bundle-2.1.0-20160703_202104_67972_345.x86_64.rpm
[root@hostname~]# cd /opt/csd/csd_topology_bundle/
[root@hostname csd_topology_bundle]# ./install.sh
```

During the installation, you may need to respond to prompts about configuring bridge interfaces. The existing eth0 bridge will need to be migrated to external0 bridge, and the existing eth1 bridge to mgmt0 bridge. If the system Ethernet interface name is not already **eth0**, you must manually create the bridge interface.

The installation process prompts you to enter different credentials to use such as credentials for the Cassandra server. Specifically, the user credentials that are used to access the GUI are also used to validate API users.

You must ensure that the security settings (such as iptables and SELinux) allow the required services and that the underlying networking settings (such as IP addresses and interfaces) are correctly configured. In the context of Connectivity Services Director, access to the following ports is necessary:

- Access to port 8443
- Outbound SSH connections to perform the CLI data collection
- Inbound PCEP connections (TCP port 4189) for networks using PCEP

RELATED DOCUMENTATION

| [Installation Prerequisites](#) | 274

Minimum Hardware and Software Requirements for Junos VM on VMWare

[Table 58 on page 276](#) lists the hardware requirements.

Table 58: Minimum Hardware Requirements for VMware

Description	Value
Number of cores	Minimum of 2
Memory	2 GB
Storage	Local or NAS

[Table 59 on page 276](#) lists the software requirements.

Table 59: Software Requirements for VMware

Description	Value
Hypervisor	ESXi 5.5 Update 2
Management Client	vSphere 5.5 or vCenter Server

RELATED DOCUMENTATION

| [Installing the JunosVM for CSD-Topology](#) | 276

Installing the JunosVM for CSD-Topology

IN THIS SECTION

- [Setting Up the Datastore](#) | 278
- [Creating VRR VMs](#) | 280

- Configuring the JunosVM | 289
- Configuring the CSD-Topology Server with the JunosVM IP Address | 291
- Verifying the Connectivity Between the CSD-Topology Server and JunosVM | 291
- Verifying That the CSD-Topology Services Are Running | 292
- Stopping Firewall on the CSD-Topology Server | 292
- Configuring Peer Routers and Topology Acquisition on the JunosVM | 293
- Specifying the Topology Details in the Connectivity Services Director GUI | 295

The CSD-Topology runs Junos in a virtual machine (JunosVM) that uses routing protocols to communicate with the network and dynamically learn the network topology. To provide real-time updates of the network topology, the JunosVM, which is based on a virtual route reflector (VRR), establishes a BGP-link state (LS) peering session with one or more routers from the existing MPLS TE backbone network.

The VRR feature allows you to implement route reflector capability using a general purpose virtual machine that can be run on a 64-bit Intel-based blade server or appliance. Because a route reflector works in the control plane, it can run in a virtualized environment. A virtual route reflector on an Intel-based blade server or appliance works the same as a route reflector on a router, providing a scalable alternative to full mesh internal BGP peering. For more information regarding VRR, see [Understanding Virtual Route Reflector](#)

VRR supports different physical PCI devices such as E1000 and VRRNET3. The procedure in this section is specific to E1000 and VRRNET3 devices.

The JunosVM (VRR) software image is located at <https://www.juniper.net/support/downloads/?p=vrr#sw>.

The IP address of the JunosVM is configurable in the northstar.cfg file. The name of the property is ntad_host and it defaults to 172.16.16.2. In the sample configuration scenario described in this topic, an IP address is assigned to the Ethernet interface, eth1, of the CSD-Topology VM, and an IP address is assigned to the management Ethernet interface, em0, of the JunosVM.

NOTE: The configuration discussed in this section assumes that the JunosVM can be reached at the 172.16.16.2 address. If a different address is used for the connection between the JunosVM and CSD-Topology VM, you must update the `/opt/csd-topology/data/northstar.cfg` file (the property name is ntad_host=172.16.16.2) to point to the correct address where the JunosVM can be reached.

The interfaces, eth0 and eth2, of the CSD-Topology VM must be connected to the management Ethernet interfaces, em1 and em2, respectively, of the JunosVM or the Hypervisor. The connection between eth0 and em1 is the router-facing link, whereas the connection between eth2 and em2 is the management link.


NOTE: The procedure for installing the JunosVM for CSD-Topology has been validated only for Junos OS Release 14.2R6.

To install VRR with vSphere for E1000 and VRRNET3 adapters and configure the JunosVM (VRR VM) for CSD-Topology, perform these tasks:



Setting Up the Datastore

To upload VRR to the ESXi datastore:

1. Download the VRR software package for VMware from the [VRR page](#).
2. Launch the vSphere Web Client for your ESXi server and log in to the server.
3. Click the **Summary** tab, select the datastore under Storage, right-click, and select **Browse Datastore**.



4. In the Datastore Browser, click the **Upload** button, select **Upload File**, and upload the **jinstall64-vrr*.vmdk** files for the package contents




Creating VRR VMs


To create a JunosVM or VRR VM:

1. In the left navigation pane, select the ESXi server. In the Getting Started tab, click **Create a new virtual machine**.


The Create New Virtual Machine wizard appears.




2. In the Configuration pane, select the **Custom** button and click **Next**.




3. In the Name and Location pane, specify the name of the VM and click **Next**. For example, **CSD-Topology_JunosVM** for the JunosVM.




4. In the Storage pane, select appropriate datastore (for example, **datastore1**) for the destination storage of the VM and click **Next**.




5. In the Virtual Machine Version pane, select the **Virtual Machine Version: 8** button and click **Next**.




6. In the Guest Operating System pane, select the **Other** button, select **Other (64-bit)** from the list, and click **Next**.




7. In the CPUs pane, select 2 for the number of cores per virtual socket and click **Next**.




8. In the Memory pane, select 2 GB from the Memory Size list for the VM and click **Next**.




9. In the Network pane, select **3** from the list, assign the proper vswitch to the E1000 adapters, and click **Next**.




10. In the SCSI Controller pane, select the **LSI Logic SAS** button (default option is LSI Logic Parallel) and click **Next**.




11. In the Select a Disk pane, select the **Use an existing virtual disk** button and click **Next**.




12. In the Select Existing Disk pane, click **Browse** to select the appropriate **jinstall64-vmx*** file from the datastore and click **Next**.



13. In the Advanced Options pane, click **Next** to accept the default options.



14. In the Ready to Complete pane, click **Finish**.



Configuring the JunosVM

To configure the JunosVM:

1. Enter the following commands from the Junos OS CLI interface. Replace the variables with actual values to suit your network needs

```

set system host-name csd_topology_junosvm
set system root-authentication encrypted-password xxxx
set system login announcement "This JunOS VM is running in non-persistent
mode.\nIf you make any change on this JunOS VM,\nPlease make sure you save to
the Host using net_setup.py utility, otherwise the config will be lost if this
VM is restarted.\n\n"

set system processes routing force-32-bit
set interfaces em0 unit 0 family inet address Management IP address on JunosVM
set interfaces em2 unit 0 family inet address Management IP address on JunosVM
set interfaces lo0 unit 0 family inet filter input protect-re
set interfaces lo0 unit 0 family mpls
set routing-options static route 0.0.0.0/0 next-hop next-hop-address
set routing-options autonomous-system 36000
set protocols topology-export
set protocols mpls traffic-engineering database import igp-topology
set protocols mpls traffic-engineering database import policy TE
set protocols bgp group csdtopology type internal
set protocols bgp group csdtopology description "csdtopology BGP-TE Pering"
set protocols bgp group csdtopology local-address JunosVM management IP address
set protocols bgp group csdtopology family traffic-engineering unicast
set protocols bgp group csdtopology allow 0.0.0.0/0
set protocols isis traffic-engineering igp-topology
set policy-options prefix-list internal-net csdtopology server IP address
set policy-options policy-statement TE term 1 from family traffic-engineering
set policy-options policy-statement TE term 1 then accept
set policy-options policy-statement TE from family traffic-engineering
set policy-options policy-statement TE then accept
set firewall interface-set mgmt-intf em0.0
set firewall filter protect-re term mgmt-intf from interface-set mgmt-intf
set firewall filter protect-re term mgmt-intf then accept
set firewall filter protect-re term internal-net from prefix-list internal-net
set firewall filter protect-re term internal-net then accept
set firewall filter protect-re term ssh from protocol tcp
set firewall filter protect-re term ssh from port ssh
set firewall filter protect-re term ssh then accept
set firewall filter protect-re term bgp from protocol tcp
set firewall filter protect-re term bgp from port bgp
set firewall filter protect-re term bgp then accept
set firewall filter protect-re term ntp from protocol udp

```

```

set firewall filter protect-re term ntp from port ntp
set firewall filter protect-re term ntp then accept
set firewall filter protect-re term ospf from protocol ospf
set firewall filter protect-re term ospf then accept
set firewall filter protect-re term icmp from protocol icmp
set firewall filter protect-re term icmp then accept
set firewall filter protect-re term traceroute from protocol udp
set firewall filter protect-re term traceroute from port 33200-33600
set firewall filter protect-re term traceroute then accept
set firewall filter protect-re term default-discard then syslog
set firewall filter protect-re term default-discard then discard

```

Configuring the CSD-Topology Server with the JunosVM IP Address

To associate the CSD-Topology VM with JunosVM:

1. Establish an SSH session with the server running the CSD-Topology software.
2. Edit **northstar.cfg** file as follows:

```
modify /opt/csd-topology/data/northstar.cfg ntad_host=Management IP address of the JunosVM
```

where **ntad_host** is the name of the topology discovery process running on the JunosVM. In this example, the management IP address of the JunosVM is 172.16.16.2.

3. Restart the JunosVM services.

```
sservice csd_topology restart all
```

Verifying the Connectivity Between the CSD-Topology Server and JunosVM

To verify the connectivity between the CSD-Topology server and JunosVM:

1. Establish a session with the server running the CSD-Topology software.
2. Run the **netstat** command to verify that connectivity is established between the CSD-Topology server and JunosVM.

```
[root@csd-topo ~]# netstat -an | grep 450
tcp        0      0 172.16.16.1:35178    172.16.16.2:450
ESTABLISHED
```

Verifying That the CSD-Topology Services Are Running

To verify that the CSD-Topology services are running correctly:

1. Access CSD-Topology server VM.
2. Run the **csd_topology status** command.

```
[root@csd-topo ~]# csd_topology status
infra:cassandra          RUNNING    pid 1881, uptime 4 days, 21:12:20
infra:ha_agent           RUNNING    pid 1880, uptime 4 days, 21:12:20
infra:haproxy            RUNNING    pid 1877, uptime 4 days, 21:12:20
infra:nodejs             RUNNING    pid 2558, uptime 4 days, 21:10:47
infra:rabbitmq           RUNNING    pid 1879, uptime 4 days, 21:12:20
infra:zookeeper          RUNNING    pid 1878, uptime 4 days, 21:12:20
listener1:listener1_00   RUNNING    pid 1876, uptime 4 days, 21:12:20
northstar:mladapter      RUNNING    pid 2707, uptime 4 days, 21:10:04
northstar:npat           RUNNING    pid 2661, uptime 4 days, 21:10:15
northstar:npat_ro        RUNNING    pid 2658, uptime 4 days, 21:10:15
northstar:pceserver      RUNNING    pid 2586, uptime 4 days, 21:10:36
northstar:pcserver       RUNNING    pid 2620, uptime 4 days, 21:10:25
northstar:toposerver     RUNNING    pid 2659, uptime 4 days, 21:10:15
```

Stopping Firewall on the CSD-Topology Server

You can optionally stop firewall services. To stop firewall services on the CSD-Topology server:

1. Access CSD-Topology server VM.
2. Stop firewall services on the CSD-Topology server.

```
[root@csd_topo csd_topology_bundle]# service iptables stop
```

Configuring Peer Routers and Topology Acquisition on the JunosVM

To configure the peer route settings on the JunosVM for BGP peering:

1. Configure a policy.

```
[edit policy-options]
user@PE1# set policy-statement TE term 1 from family traffic-engineering
user@PE1# set policy-statement TE term 1 then accept
```

2. Configure BGP-link state (LS) distribution on the CSD-Topology for topology acquisition

- a. Specify the autonomous system (AS) number for the node (BGP peer).

```
[edit routing-options]
user@csd_topology_junosvm# set autonomous-system AS_number
```

- b. Specify the BGP group name and type for the node.

```
[edit protocols bgp]
user@csd_topology_junosvm# set group group_1 type internal
```

- c. Specify a description for the BGP group for the node.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set description "CSD-Topology BGP-TE Peering"
```

- d. Specify the address of the local end of a BGP session.

This is the IP address for the JunosVM external IP address which is used to accept incoming connections to the JunosVM peer and to establish connections to the remote peer.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set local-address <junosVM IP address>
```

- e. Enable the traffic engineering features for the BGP routing protocol.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set family traffic-engineering unicast
```

- f. Specify the IP address for the neighbor router that connects with the CSD-Topology.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set neighbor <router loopback IP address>
```

NOTE: You can specify the router loopback address if it is reachable by the BGP peer on the other end. But for loopback to be reachable, usually some IGP has to be enabled between the CSD-Topology JunosVM and the peer on the other end.

3. Import the routes into the traffic-engineering database.

```
[edit protocols mpls traffic-engineering database]
user@PE1# set import policy TE
```

4. Configure a BGP group by specifying the IP address of the router that peers with the CSD-Topology as the local address (typically the loopback address) and the JunosVM external IP address as the neighbor.

```
[edit routing-options]
user@PE1# set autonomous-system AS Number

[edit protocols bgp group csd-topology]
user@PE1# set type internal
user@PE1# set description "CSD-Topology BGP-TE Peering"
user@PE1# set local-address <router-IP-address>
user@PE1# set family traffic-engineering unicast
user@PE1# set export TE
user@PE1# set neighbor <JunosVM IP-address>
```

Specifying the Topology Details in the Connectivity Services Director GUI

To specify the topology preferences on the Connectivity Services Director server:

1. From the Junos Space user interface, click the **System** icon on the Connectivity Services Director banner.

The options that you can configure in System mode are displayed in a drop-down menu.

2. Select **Preferences** from the drop-down menu to open the Preferences page.

The Preferences page opens with User Preferences as the default tab.

3. Click the **Topology** tab to configure the CSD-Topology preference settings.

The settings that you can configure on the Topology tab are displayed.

4. In the L3 Topology Settings section, do the following:

- a. Select the **Use PCEP** check box to use the Path Computation Element Protocol (PCEP) for discovery of LSPs. PCEP enables communication between a PCC and the CSD-Topology to learn about the network and LSP path state and communicate with the Path Computation Clients (PCCs). If you select the **Use PCEP** check box, the LSP data is collected by using PCEP.

By default, this check box is not selected. If you do not enable this option to use PCEP for discovery of LSPs, Connectivity Services Director discovers the LSPs by parsing the configuration statements and operational command outputs of the devices that it manages.

- b. In the Topology Server field, specify the topology server IP address, which is the IP address of the system on which the CSD-Topology application is running.
- c. In the UserName and Password fields, specify the username and password of the user to allow the Connectivity Services Director to connect to the topology server.
- d. Click **Validate** beside the Password field, which triggers a task to examine and verify the entered credentials for connecting to the CSD-Topology server. A dialog box is displayed to indicate whether the specified credentials are valid or not.
- e. Click **OK** to close the dialog box. If the login credentials for communicating with the CSD-Topology are invalid, correct the username and password values and revalidate them.

5. Click **OK** to save the settings.

You are prompted to confirm the changes you made to topology preferences.

6. Click **Yes** to confirm.

The Preferences page is closed. A dialog box is displayed to confirm the successful saving of topology preferences. Click **OK** to close the dialog box.

RELATED DOCUMENTATION

| [Connecting an x86 Server to the Network](#) | 296

Connecting an x86 Server to the Network

For minimum hardware requirements, see [“Installation Prerequisites” on page 274](#).

To establish basic TCP connectivity to the network, you must connect your x86 64-bit network appliance (running the CSD-Topology software) directly to a switch or router.

Before configuring the x86 server to connect to the network, download and install the RPM bundle as described in [“Installing the CSD-Topology Software Using the RPM Bundle” on page 275](#).

After installing the RPM bundle, the following default settings apply:

- Host machine:
 - User=**root**
 - Password=**csdtopology**
 - IP addresses:
 - external0=**dhcp**
 - host mgmt0=**172.16.17.1/24**
 - host management:internal network=**172.16.16.1/24**

NOTE: The Path Computation Server (PCS) runs native on the host machine, and the host address is the PCS.

- JunosVM:
 - User=**csdtopology**
 - Password=**csdtopology**
 - Root Password=**csdtopology**
 - IP addresses:
 - em0=**172.16.16.2/24**
 - em1=**none**
 - em2=**172.16.17.2/24**

NOTE:

The following default values are also configured for the JunosVM configuration:


- JunosVM internal IP address: 172.16.16.2
- JunosVM internal netmask: 255.255.255.0

NOTE: The JunosVM internal IP and netmask should not be changed.

NOTE: For network security, by default, JunosVM SSH and telnet access is restricted and available only from the host server (PCS server) using the 172.16.16.2 IP address. To remove this restriction, you can manually remove the firewall filter on the JunosVM lo0 (loopback) configuration.

Figure 13 on page 298 shows the default interfaces and preconfigured addresses on the x86 appliance.

Figure 13: Interfaces and Addresses Preconfigured on the x86 Appliance



To establish basic connectivity between the x86 network appliance and a switch or router:

1. Power on the x86 network appliance.
2. Use one of the following options to access the x86 console:

- Use a serial cable to connect to the serial console.

You can use an SSH client (hypertem, minicom, or securecr) to connect to the serial console.

NOTE: To set up the serial port connection, refer to your hardware manual.

NOTE: The serial port setting should be **9600-8-N-1** with hardware control enabled.

- If your network appliance has two or more Ethernet ports, use an Ethernet cable to connect to the x86 appliance management interface.
 - a. Connect an Ethernet cable from a laptop computer to 1-Gigabit Ethernet port 1 on the x86 appliance.
 - b. Configure the IP address on your laptop to 172.16.17.10/24.
 - c. Using an SSH client, connect to the x86 appliance at IP address 172.16.17.1.
3. On the network appliance, connect a 1-Gigabit Ethernet or 10-Gigabit Ethernet port to the LAN switch or router that you will use to access the network.

NOTE: The Ethernet interface on the switch or router must be configured in **access/untagged** mode.

4. From prompt, log in to the x86 system with the username **root** and password **password**.
5. To configure the required network settings, access the Main Menu:

```
[root@csd-topo ~]# /opt/csd-topology/utils/net_setup.py
```

The Main Menu, shown in [Figure 14 on page 300](#), displays the options that you can select to configure the host and JunosVM settings, verify network settings, perform maintenance and troubleshooting, and collect trace and log files.

Figure 14: CSD-Topology Main Menu

```

Main Menu:
.....
A.) Host configuration
B.) JunosVM configuration
.....
C.) Check Network Setting
.....
D.) Maintenance & Troubleshooting
.....
E.) HA Setting
.....
F.) Collect Trace/Log
.....
X.) Exit
.....

Please select a letter to execute.

```

NOTE: To establish connectivity between the x86 network appliance and a switch or router, the host IP and JunosVM IP addresses (including netmask and default gateway) must be from the same subnet.

- a. To create the host configuration:

NOTE: You must provide settings for the host external IP address, host external netmask, and host default gateway. All other host settings are optional.

1. Type **A** at the prompt and press Enter to update the host configuration.
The current CSD-Topology host configuration settings are displayed.
2. For each host setting you want to configure, enter the number that corresponds to the specific host parameter (host external IP address, host external netmask, host management IP address, host default gateway, and so forth), and enter the appropriate value.
3. After you configure the required host settings, type **B** to apply the host settings.

- b. To create the JunosVM configuration:

NOTE: You must provide settings for the JunosVM external IP address, JunosVM external netmask, JunosVM default gateway, and BGP AS number. All other JunosVM settings are optional.

1. Type **B** at the prompt and press Enter to update the CSD-Topology JunosVM configuration.
The current JunosVM configuration settings are displayed.
 2. For each JunosVM setting you want to configure, enter the number that corresponds to the specific JunosVM parameter (JunosVM external IP address, JunosVM external netmask, JunosVM management IP address, JunosVM default gateway, and BGP AS number), and enter the appropriate value.
 3. After configuring the required JunosVM settings, type **C** to apply the JunosVM settings.
6. Verify the host and JunosVM configurations and deploy.
- a. Type **C** at the prompt and press Enter to view all current host configuration and JunosVM configuration settings.
 - b. To apply all updated host and JunosVM configuration settings to the CSD-Topology, type **Y** and press Enter.

RELATED DOCUMENTATION

[Configuring Connectivity for BGP-LS Topology Acquisition | 308](#)

[Configuring Connectivity for OSPF Topology Acquisition | 311](#)

[Configuring Connectivity for IS-IS Topology Acquisition | 313](#)

Interactive Method of Installing the RPM Image and CSD-Topology Software from a USB or DVD Drive

You can install the CSD-Topology RPM image on any x86 64-bit network appliance.

Before configuring the x86 server to connect to the network, download and install the RPM bundle as described in [“Installing the CSD-Topology Software Using the RPM Bundle” on page 275](#).

If you have a keyboard and monitor as part of your system, the interactive installation method is preferred. To install the ISO image on the x86 network appliance from a USB drive using the interactive method:

1. Power on the x86 network appliance.

The CSD-Topology login prompt is displayed after you power on the appliance.

2. Enter the following command to launch the interactive user interface:

```
[root@csd-topo ~]# /csd-topology/csd_topology_2.0.0_interactive_install.md
```

3. Plug in the USB or DVD drive with the RPM image of the CSD-Topology package to the x86 appliance.
4. When the “Welcome to CSD-Topology(SCL 6.6R2.0)” screen is displayed, select the appropriate Boot option (the default is **Boot from Local HDD**), and press Enter to start the CSD-Topology installation.

The CentOS 6 logo screen is displayed.

5. Click **Next**.
6. Select your preferred language for the installation process, and click **Next**.
7. Choose your preferred storage type, and click **Next**.
8. Indicate your time zone, and click **Next**.
9. Enter and confirm the root password, and click **Next**.
10. Select a partitioning option, and click **Next**.

NOTE: Because CSD-Topology is installed in /opt/, be sure to allocate sufficient space for /opt.

11. Indicate your preferences regarding boot loader (two screens), and click **Next** after completing each screen.

12. Select **Core** installation, and click **Next**.
13. The CentOS 6 logo screen is displayed, showing installation progress. When the installation completes, the screen shows that all packages are completed.
14. Two errors are displayed because the password has not yet been initialized and the license key has not yet been added:
 - The state of all CSD-Topology processes shows as STOPPED.
 - The state of the PCServer process shows as FATAL.
15. To resolve the license error, copy the npatpw license file to /opt/pcs/db/sys.

NOTE: Be sure the owner of the file is pcs.

16. To resolve the password error, access the Main Menu:

```
[root@csd-topo ~]# /opt/csd-topology/utils/net_setup.py
```

From the Main Menu shown in [Figure 15 on page 303](#), select **D** for Maintenance & Troubleshooting.

Figure 15: CSD-Topology Controller Main Menu

```
Main Menu:
.....
A.) Host configuration
B.) JunosVM configuration
.....
C.) Check Network Setting
.....
D.) Maintenance & Troubleshooting
.....
E.) HA Setting
.....
F.) Collect Trace/Log
.....
X.) Exit
.....

Please select a letter to execute.
```


Select **9** to Initialize all credentials.

The state of all processes should now show as **RUNNING**.

Disconnect the USB flash drive or DVD drive that is connected to the x86 network appliance.

17. Power on the x86 network appliance.

The system requires a few minutes to power on. Then the CSD-Topology login prompt is displayed.

18. From the CSD-Topology login prompt, enter user **root** and the root password you selected during the installation to log in to the CSD-Topology CLI.

19. Run each of the following commands to verify that the JunosVM and Path Computation Server (PCS) processes are running and that key directories were successfully installed:

- a. As root user, run the **service csdtology status** command to verify that JunosVM is running. This command tells you the status of all processes, the disk space being used, network configuration check results, and JunosVM check results.
- b. After your license is set, run the **ps -ef | grep PCS** command to verify that the PCS is running on specific ports.

RELATED DOCUMENTATION

[Installation Prerequisites | 274](#)

[Installing the CSD-Topology Software Using the RPM Bundle | 275](#)

Configuring Topology Acquisition and Connectivity Between the CSD-Topology and Path Computation Clients

IN THIS CHAPTER

- [Configuring PCEP on a PE Router \(from CLI\) | 305](#)
- [Configuring Connectivity for BGP-LS Topology Acquisition | 308](#)
- [Configuring Connectivity for OSPF Topology Acquisition | 311](#)
- [Configuring Connectivity for IS-IS Topology Acquisition | 313](#)

Configuring PCEP on a PE Router (from CLI)

A Path Computation Client (PCC) supports the configurations related to the Path Computation Element (PCE) and communicates with the CSD-Topology, which by default is configured to accept a Path Computation Element Protocol (PCEP) connection from any source address. However, you must configure PCEP on each PE router to configure the router as a PCC and establish a connection between the PCC and the CSD-Topology. A PCC initiates path computation requests, which are then executed by the CSD-Topology.

The following requirements apply for each PCC in the network that the CSD-Topology can access:

- The corresponding JSDN package (with PCEP support) is installed on the router.

NOTE: You must boot the PCC router with the Junos OS 14.2X1.1 image, and then boot the router a second time with the JSDN image. After the router boots up a second time, the router (functioning as a PCC) is able to support the configurations related to the PCE and communicate with the CSD-Topology.

NOTE: For a PCEP connection, the PCC can connect to the CSD-Topology using an in-band or out-of-band management network, provided that IP connectivity is established between the Path Computation Server (PCS) and the specified PCEP local address. In some cases, an additional static route might be required from the CSD-Topology to reach the PCC, if the IP address is unreachable from the CSD-Topology default gateway.

To configure a PE router as a PCC:

1. Enable external control of LSPs from the PCC router to the CSD-Topology.

```
[edit protocols]
user@PE1# set mpls lsp-external-controller pccd
```

2. Specify the loopback address of the PCC router as the local address, for example:

```
[edit protocols]
user@PE1# set pcep pce csdtopology local-address 10.0.0.101
```

NOTE: As a best practice, the router ID is usually the loopback address, but is not necessarily configured this way.

3. Specify the CSD-Topology (**csdtopology**) as the PCE that the PCC connects to, and specify the CSD-Topology host external IP address as the destination address.

```
[edit protocols]
user@PE1# set pcep pce csdtopology destination-ipv4-address 10.99.99.1
```

4. Configure the destination port for the PCC router that connects to the CSD-Topology (PCE server) using the TCP-based PCEP.

```
[edit protocols]
user@PE1# set pcep pce csdtopology destination-port 4189
```

5. Configure the PCE type.

```
[edit protocols]
user@PE1# set pcep pce csdtopology pce-type active
user@PE1# set pcep pce csdtopology pce-type stateful
```

6. Enable LSP provisioning.

```
[edit protocols]
user@PE1# set pcep pce csdtopology lsp-provisioning
```

7. To verify that PCEP has been configured on the router, open a telnet session to access the router, and run the following commands:

```
user@PE1> show configuration protocols mpls
```

Sample output:

```
lsp-external-controller pccd;
```

```
user@PE1> show configuration protocols pcep
```

Sample output:

```
pce csdtopology {
  local-address 10.0.0.101;
  destination-ipv4-address 10.99.99.1;
  destination-port 4189;
  pce-type active-stateful;
  lsp-provisioning;
}
```

RELATED DOCUMENTATION

[Configuring Connectivity for BGP-LS Topology Acquisition | 308](#)

[Configuring Connectivity for OSPF Topology Acquisition | 311](#)

[Configuring Connectivity for IS-IS Topology Acquisition | 313](#)

Configuring Connectivity for BGP-LS Topology Acquisition

IN THIS SECTION

- [Configuring BGP-LS Topology Acquisition on the CSD-Topology | 309](#)
- [Configuring Topology Acquisition on the PCC Routers | 310](#)

After you have successfully established a connection between the CSD-Topology and the network, you can configure topology acquisition using Border Gateway Protocol Link State (BGP-LS). For BGP-LS topology acquisition, you must configure both the CSD-Topology and the PCC routers.

NOTE:

We recommend that you use BGP-LS instead of IGP adjacency for the following reasons:

- The OSPF and IS-IS databases have a lifetime timer, and if the OSPF or IS-IS neighbor is down, the OSPF or IS-IS database is not removed immediately, and the CSD-Topology will not be able to determine whether the topology is valid or not.
- Using BGP-LS minimizes the risk of making the JunosVM a transit router between AS areas if the GRE metric is not properly configured.
- Typically, the CSD-Topology is located in a NOC Data Center and multihops away from the backbone routers and MPLS TE routers.

NOTE: If BGP-LS is used, JunosVM is configured to automatically accept any I-BGP session from, in this example, 0.0.0.0/0. However, you must verify that JunosVM is correctly configured and that it has IP reachability to the peering router.

Before you begin, complete the following tasks:

- Verify IP connectivity between a switch (or router) and the x86 appliance on which CSD-Topology software is installed.
- Make sure that PCEP is configured on each PE router in the network topology.

To configure BGP-LS topology acquisition, see:

Configuring BGP-LS Topology Acquisition on the CSD-Topology

To configure BGP-LS on the CSD-Topology for topology acquisition, perform the following configuration steps from the CSD-Topology JunosVM:

1. Initiate an SSH or telnet session to the JunosVM external IP or management IP address.
2. Specify the autonomous system (AS) number for the node (BGP peer).

```
[edit routing-options]
user@csd_topology_junosvm# set autonomous-system AS_number
```

3. Specify the BGP group name and type for the node.

```
[edit protocols bgp]
user@csd_topology_junosvm# set group group_1 type internal
```

4. Specify a description for the BGP group for the node.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set description "csd-topology BGP-TE Peering"
```

5. Specify the address of the local end of a BGP session.

This is the IP address for the JunosVM external IP address which is used to accept incoming connections to the JunosVM peer and to establish connections to the remote peer.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set local-address <junosVM IP address>
```

6. Enable the traffic engineering features for the BGP routing protocol.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set family traffic-engineering unicast
```

7. Specify the IP address for the neighbor router that connects with the CSD-Topology.

```
[edit protocols bgp group group_1]
user@csd_topology_junosvm# set neighbor <router loopback IP address>
```

NOTE: You can specify the router loopback address if it is reachable by the BGP peer on the other end. But for loopback to be reachable, usually some IGP has to be enabled between the CSD-Topology JunosVM and the peer on the other end.

Configuring Topology Acquisition on the PCC Routers

To enable the CSD-Topology to discover the network, you must add the following configuration on each router that peers with the CSD-Topology. The CSD-Topology JunosVM must peer with at least one router from each area (autonomous system).

To configure topology acquisition, initiate a telnet session to each PCC router and add the following configuration:

1. Configure a policy.

```
[edit policy-options]
user@PE1# set policy-statement TE term 1 from family traffic-engineering
user@PE1# set policy-statement TE term 1 then accept
```

NOTE: This configuration is appropriate for both OSPF and IS-IS.

2. Import the routes into the traffic-engineering database.

```
[edit protocols mpls traffic-engineering database]
user@PE1# set import policy TE
```

3. Configure a BGP group by specifying the IP address of the router that peers with the CSD-Topology as the local address (typically the loopback address) and the JunosVM external IP address as the neighbor.

```
[edit routing-options]
user@PE1# set autonomous-system AS Number

[edit protocols bgp group bgp group1]
user@PE1# set type internal
user@PE1# set description "CSD-Topology BGP-TE Peering"
user@PE1# set local-address <router-IP-address>
```

```

user@PE1# set family traffic-engineering unicast
user@PE1# set export TE
user@PE1# set neighbor <JunosVM IP-address>

```

SEE ALSO

[Configuring PCEP on a PE Router \(from CLI\) | 305](#)

[Configuring Connectivity for OSPF Topology Acquisition | 311](#)

[Configuring Connectivity for IS-IS Topology Acquisition | 313](#)

Configuring Connectivity for OSPF Topology Acquisition

IN THIS SECTION

- [Configuring OSPF on the CSD-Topology | 311](#)
- [Configuring OSPF Over GRE on the CSD-Topology | 312](#)

If BGP-LS is not being used, one of the IGP protocols must be configured on the CSD-Topology. To enable OSPF on CSD-Topology, before you begin, verify IP connectivity between a switch (or router) and the x86 appliance on which CSD-Topology software is installed.

To configure OSPF topology acquisition, see:

Configuring OSPF on the CSD-Topology

To configure OSPF on the CSD-Topology:

1. Configure the policy.

```

[edit policy-options]
user@csd_topology_junosvm# set policy-statement TE term 1 from family traffic-engineering
user@csd_topology_junosvm# set policy-statement TE term 1 then accept

```

2. Populate the traffic engineering database.


```
[edit]
user@csd_topology_junosvm# set protocols mpls traffic-engineering database import policy TE
```

3. Configure OSPF.

```
[edit]
user@csd_topology_junosvm# set protocols ospf area area interface interface interface-type p2p
```

Configuring OSPF Over GRE on the CSD-Topology

Once you have configured OSPF on the CSD-Topology, you can take the following additional steps to configure OSPF over GRE:

1. Initiate an SSH or telnet session using the IP address for the CSD-Topology JunosVM external IP address.
2. Configure the tunnel.

```
[edit interfaces]
user@csd_topology_junosvm# set gre unit 0 tunnel source local-physical-ip
user@csd_topology_junosvm# set gre unit 0 tunnel destination destination
user@csd_topology_junosvm# set gre unit 0 family inet address tunnel-ip-addr
user@csd_topology_junosvm# set gre unit 0 family iso
user@csd_topology_junosvm# set gre unit 0 family mpls
```

3. Enable OSPF traffic engineering on the JunosVM and add the GRE interface to the OSPF configuration.

```
[edit protocols ospf]
user@csd_topology_junosvm# set traffic-engineering
user@csd_topology_junosvm# set area area interface gre.0 interface-type p2p
user@csd_topology_junosvm# set area area interface gre.0 metric 65530
```

SEE ALSO

[Configuring PCEP on a PE Router \(from CLI\) | 305](#)

[Configuring Connectivity for BGP-LS Topology Acquisition | 308](#)

[Configuring Connectivity for IS-IS Topology Acquisition | 313](#)

Configuring Connectivity for IS-IS Topology Acquisition

IN THIS SECTION

- [Configuring IS-IS on the CSD-Topology | 313](#)
- [Configuring IS-IS Over GRE on the CSD-Topology | 314](#)

If BGP-LS is not being used, you must configure one of the IGP protocols on the CSD-Topology. To enable IS-IS on the CSD-Topology, before you begin, complete the following tasks:

1. Verify IP connectivity between a switch (or router) and the x86 appliance on which CSD-Topology software is installed.
2. Configure interfaces on the JunosVM for IS-IS routing, for example:

```
[edit]
user@csd_topology_junosvm# set interfaces em0 unit 0 family inet address 172.16.16.2/24
user@csd_topology_junosvm# set interfaces em1 unit 0 family inet address 192.168.179.117/25
user@csd_topology_junosvm# set interfaces em0 unit 0 family inet address 172.16.16.2/24
user@csd_topology_junosvm# set interfaces em2 unit 0 family mpls
user@csd_topology_junosvm# set interfaces lo0 unit 0 family inet address 88.88.88.88/32 primary
user@csd_topology_junosvm# set routing-options static route 0.0.0.0/0 next-hop 192.168.179.126
user@csd_topology_junosvm# set routing-options autonomous-system 1001
```

To configure IS-IS topology acquisition, see:

Configuring IS-IS on the CSD-Topology

To configure IS-IS topology acquisition and enable IS-IS routing, perform the following steps on the CSD-Topology JunosVM:

1. Configure the policy.

```
[edit policy-options]
user@csd_topology_junosvm# set policy-statement TE term 1 from family traffic-engineering
user@csd_topology_junosvm# set policy-statement TE term 1 then accept
```

2. Populate the traffic engineering database.

```
[edit protocols]
user@csd_topology_junosvm# set mpls traffic-engineering database import policy TE
```

3. Configure IS-IS.

```
[edit protocols]
user@csd_topology_junosvm# set isis interface interface level level metric metric
user@csd_topology_junosvm# set isis interface interface point-to-point
```

Configuring IS-IS Over GRE on the CSD-Topology

Once you have configured IS-IS on the CSD-Topology, you can take the following additional steps to configure IS-IS over GRE:

1. Initiate an SSH or telnet session using the IP address for the CSD-Topology JunosVM external IP address.
2. Configure the tunnel.

```
[edit interfaces]
user@csd_topology_junosvm# set gre unit 0 tunnel source local-physical-ip
user@csd_topology_junosvm# set gre unit 0 tunnel destination destination
user@csd_topology_junosvm# set gre unit 0 family inet address tunnel-ip-addr
user@csd_topology_junosvm# set gre unit 0 family iso
user@csd_topology_junosvm# set gre unit 0 family mpls
```

3. Add the GRE interface to the IS-IS configuration.

```
[edit protocols isis]
user@csd_topology_junosvm# set interface gre.0 level level metric 65530
user@csd_topology_junosvm# set interface gre.0 point-to-point
```

SEE ALSO

[Configuring PCEP on a PE Router \(from CLI\) | 305](#)

[Configuring Connectivity for BGP-LS Topology Acquisition | 308](#)

[Configuring Connectivity for OSPF Topology Acquisition | 311](#)

Accessing the Topology View of CSD-Topology

IN THIS CHAPTER

- Understanding the Network Topology in Connectivity Services Director | 316
- Monitoring the Topology of Network Elements Managed by CSD-Topology Overview | 317
- Specifying Topology Preferences | 318
- CSD-Topology Topology Map Window Overview | 320
- Working with the Graphical Image in the Topology View Window | 322
- Expanding and Collapsing Groups by Using the Topology Map Grouping Shortcut Menu | 325
- Filtering Links, LSPs, and Services by Using the Topology Map Node Shortcut Menu | 326
- Removing the Highlighted LSPs by Using the Topology Map LSPs Shortcut Menu | 327
- Viewing the Service Path by Using the Topology Map Service Shortcut Menu | 328
- Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View | 330
- Segregating the Displayed Devices by Searching the Entire Topology View | 331
- Resynchronizing the Topology View | 332
- Viewing Device Details of a CSD-Topology for Examining Traffic Transmission | 333
- Viewing LSP Details of a CSD-Topology for Analyzing Network Changes | 335
- Viewing Link Details of a CSD-Topology for Determining the Operational Status | 338
- Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters | 339
- Viewing Topology Map Group Details in a Pop-Up Dialog Box | 342
- Viewing Topology Map Device Details in a Pop-Up Dialog Box | 344
- Viewing Topology Map Link Details in a Pop-Up Dialog Box | 346
- Viewing Topology Map LSP Details in a Pop-Up Dialog Box | 348
- Viewing Topology Map Service Details in a Pop-Up Dialog Box | 350
- Enabling the Collection of LSP and Service Association Details | 352
- Using Custom Grouping for Devices in a CSD Topology | 352
- Viewing Generated Alarms for Services in the Topology View | 353
- Viewing the Optical Link Details for Examining the Performance of Optical Links | 354

Understanding the Network Topology in Connectivity Services Director

Junos Space Connectivity Services Director provides features for monitoring and managing Juniper Networks ACX Series routers, M Series routers, MX Series routers, and PTX Series routers. Connectivity between devices and their association with their location provide the foundation for rendering topology in a complete manner.

As a network administrator, you must have a clear understanding of the various networking devices in your network, their physical locations, and how these devices are interconnected in your network. The network topology represents the interconnection between various devices in your network, which are managed by Connectivity Services Director, based on their connectivity and association to their physical surroundings. The network topology provides a visual insight into the network, which is useful for debugging, troubleshooting, planning, and executing administrative actions.

Before you access the topological view of your network, you must:

- Discover the devices managed by Connectivity Services Director in your network. For details about discovering devices, see [“Discovering Devices” on page 188](#).

NOTE: You must specify the SNMP parameters during device discovery to have all the devices discovered and managed by Connectivity Services Director available in Topology View.

NOTE: Ensure that you have enabled the LLDP, STP, or RSTP protocols on the devices as Connectivity Services Director uses these protocols to determine the connectivity of devices with their neighbors in the network. LLDP and RSTP protocols are enabled by default on all MX Series routers.

Network topology enables you to view all the discovered devices in your network, where the devices are located along with their physical interconnection with other devices in your network. Topology also provides visualization around physical connectivity between various discovered interconnected devices. Multiple links displayed between nodes use line bending to avoid hidden trunks in the topology.

You can use the Topology View to zoom in or zoom out of a site to a group of devices and a group of devices to a site. In the Topology View, you can also double-click a site or a zone to view the devices in a site. You can also see the connectivity between a device and its immediate neighbors, alarms details, and so on.

Network topology also provides visualization around physical connectivity between various discovered interconnected devices. You can move the topology map by holding down the left mouse button, dragging the mouse to another point, and letting go of the mouse.

RELATED DOCUMENTATION

[Monitoring the Topology of Network Elements Managed by CSD-Topology Overview | 317](#)

[Specifying Topology Preferences | 134](#)

[CSD-Topology Topology Map Window Overview | 320](#)

[Working with the Graphical Image in the Topology View Window | 322](#)

Monitoring the Topology of Network Elements Managed by CSD-Topology Overview

Connectivity Services Director enables you to monitor the network elements, such as devices and links, that are configured, administered, and maintained using CSD-Topology. The CSD-Topology enables granular configuration and control of IP and MPLS flows in large service provider and enterprise networks. By establishing a connection between the CSD-Topology, which is a topology server from the perspective of Connectivity Services Director, and the server on which Connectivity Services Director is running, a topological network view or map is presented that enables you to visualize label-switched paths (LSPs), links, and services for monitoring and debugging network faults and traffic outages in IP and MPLS networks. Fault, configuration, accounting, performance, and security (FCAPS) is an explicit model that is used to achieve the operational objectives of network management. Connectivity Services Director offers an effective management system for a complete FCAPS functionality.

To compute optimal paths through the network, the CSD-Topology requires a consolidated view of the network topology. The Topology View of the network includes the nodes, links, and their attributes (metric, link utilization bandwidth, and so forth) that form the network topology. Therefore, any router CLI configuration changes to interior gateway protocol (IGP) metric, Resource Reservation Protocol (RSVP) bandwidth, Priority/Hold values, and so forth are instantly available from the Topology View of Connectivity Services Director.

Without the need to traverse to the CSD-Topology GUI, you can use the Topology View from within the Connectivity Services Director GUI to obtain a global and expansive view of the network state for monitoring, management, and proactive planning. In the CSD-Topology, a Path Computation Client (PCC) is a client application that requests the Path Computation Element (PCE) to perform path computations for the PCC's external label-switched paths (LSPs). The Path Computation Element Protocol (PCEP) enables communication between a PCC and the CSD-Topology to learn about the network and LSP path state and communicate with the PCCs. By providing a view of the global network state and bandwidth demand in the network, the CSD-Topology is able to compute optimal paths and provide the attributes that the PCC uses to resignal the LSPs.

You can also sort and classify the devices, LSPs, or services of interest and applicability for your network environment to diagnose the traffic-handling capacity, performance, and operating efficiency of the paths through which packets traverse through the circuit managed by the CSD-Topology.

You can also view the optical links configured on the optical interfaces of devices, such as PTX Series routers, on the topology map. You can sort and filter the optical links to be displayed on the topology map for easier and optimal monitoring. Only PTX3000 routers are currently supported for display on the topology map, which can contain integrated photonic line cards (IPLCs) that work in conjunction with optical inline amplifiers (optical ILAs).

RELATED DOCUMENTATION

[Specifying Topology Preferences | 134](#)

[CSD-Topology Topology Map Window Overview | 320](#)

[Working with the Graphical Image in the Topology View Window | 322](#)

Specifying Topology Preferences

You must first configure the communication and authentication settings between the CSD-Topology system and the Connectivity Services Director server by using the Preferences page before you can view the topology, which is a pictorial representation of the baseline network that shows the sites, nodes, interconnecting links, label-switched paths (LSPs) configured over pseudowire links, and services. The settings that you specify on the Preferences page establish the connection between the system on which the Connectivity Services Director application is running and the CSD-Topology server. The CSD-Topology server runs on a virtual machine (CSD-Topology VM), which works in conjunction with Junos OS running on another virtual machine (JunosVM), to use routing protocols to communicate with the network and dynamically learn the network topology. You must configure the Connectivity Services Director application with the IP address of the CSD-Topology server and the login credentials to access the CSD-Topology system. If you do not configure the connection between the CSD-Topology and Connectivity Services Director servers when you navigate to the Topology View, a message is displayed stating that you must first set up the connection before you can view the topology map that shows the interconnections among devices.

To specify topology preferences on the Connectivity Services Director server:

1. From the Junos Space user interface, click the **System** icon on the Connectivity Services Director banner.

The options that you can configure in System mode are displayed on a drop-down menu.

2. Select **Preferences** from the drop-down menu to open the Preferences page.

The Preferences page opens with User Preferences as the default tab.

3. Click the **Topology** tab to configure topology preference settings.

The settings that you can configure on the Topology tab are displayed.

4. In the L2 Topology Settings section, do the following:

- a. In the Deleted Link Retention Period (Days) field, drag the slider to the right or left to specify a retention period for the deleted links in the Topology View.

By default, the deleted links are retained for one day. Drag the slider to the leftmost end of the line to specify the period for which deleted links must be preserved as one day. Drag the slider to the rightmost end of the line to specify the period for which deleted links must be preserved as 365 days or a year, which is the longest duration for which deleted links are preserved.

- b. Select the **Disable Autoupdate of Topology** check box to disable the automatic updates to the topology and, instead, enable the topology updates to be manually triggered by the user.

By default, automatic updates to the topology are disabled.

5. In the L3 Topology Settings section, do the following:

- a. Select the **Use PCEP** check box to use the Path Computation Element Protocol (PCEP) for discovery of LSPs. PCEP enables communication between a PCC and the CSD-Topology to learn about the network and LSP path state and communicate with the Path Computation Clients (PCCs). By default, this check box is not selected.

If you do not enable this option to use PCEP for discovery of LSPs, Connectivity Services Director discovers the LSPs by parsing the configuration statements and operational command outputs of the devices that it manages.

- b. In the Topology Server field, specify the topology server IP address, which is the IP address of the system on which the CSD-Topology application is running.

- c. In the UserName and Password fields, specify the username and password of the user to allow the Connectivity Services Director to connect to the topology server.

- d. Click **Validate** beside the Password field, which triggers a task to examine and verify the entered credentials for connecting to the CSD-Topology server.

A dialog box is displayed to indicate whether the specified credentials are valid or not.

- e. Click **OK** to close the dialog box. If the login credentials for communicating with the CSD-Topology are invalid, correct the username and password values and revalidate them.

- f. In the Refresh Topology Interval (Days) field, drag the slider right or left to specify the frequency in number of days at which the Layer 3 topology must be refreshed and displayed in the Topology View.

By default, the topology is refreshed once every day. Drag the slider to the leftmost end of the line to disable the refresh of the topology. Drag the slider to the rightmost end of the line to enable the refresh of topology once every 365 days or a year, which is the largest frequency you can specify for the refresh setting.

6. Click **OK** to save the settings.

You are prompted to confirm the changes you made to topology preferences.

7. Click **Yes** to confirm.

The Preferences page is closed. A dialog box is displayed to confirm the successful saving of topology preferences. Click **OK** to close the dialog box.

RELATED DOCUMENTATION

[Monitoring the Topology of Network Elements Managed by CSD-Topology Overview | 317](#)

[CSD-Topology Topology Map Window Overview | 320](#)

[Working with the Graphical Image in the Topology View Window | 322](#)

CSD-Topology Topology Map Window Overview

As a network administrator, you must have a clear understanding of the various networking devices in your network, their physical locations, and how these devices are interconnected in your network. Connectivity between devices and their association with their locations provide the foundation for rendering topology in a complete manner. Connectivity Services Director enables you to monitor the devices that are managed by the CSD-Topology, besides offering a centralized view of the connectivity. The CSD-Topology topology map represents the interconnection between various devices in your network, which are managed by Junos Space Connectivity Services Director, based on their connectivity to and association with their physical surroundings. This information is useful for debugging, troubleshooting, planning, and executing administrative actions.

Before you can view the topology map, which is a pictorial representation of the baseline network that shows the sites, nodes, interconnecting links, label-switched paths (LSPs) configured over pseudowire links, and services, you must establish the connection between the system on which the Connectivity Services Director application is running and the CSD-Topology server. After you select **Topology View** from the View selector in Build mode, the topology (map) window is the main work area for any live network or network model you load into the system. Multiple links displayed between nodes use *line bending* to avoid hidden trunks in the topology. The topology map enables expandable and collapsible views, which

is useful when several nodes or devices are present in groups. Line bending refers to multiple parallel connector lines among devices displayed as curves to avoid overlapping between the lines.

On the topology map, devices or nodes are present in an ungrouped manner or are grouped based on the configured custom groups or sites. Sites represent a geographical region, such as a zone or a general area, within which devices are located. Different devices in a site are interconnected by links and LSPs. Services are configured on the different devices in a site. You can view the interconnection among sites, devices, links, LSPs, and services on the topology map.

NOTE: LSP names that are not unique in the network are not displayed on the topology map.

NOTE: You cannot view node locations by their geographic coordinates on the world map using latitude and longitude or automatic layouts on the Connectivity Services Director GUI.

The topology window displays important link and node properties. Links are color coded according to utilization. Alternatively, you can view links by other properties such as trunk type, protocols, coloring, status, and area. Nodes are color coded by symbols, icons, or vendor types.

Path information can be displayed in the topology window. The path function displays detailed path information between any two nodes found in the network based on factors such as the routing method used, reserved and actual bandwidth allocation, link distance, or oversubscription.

The topology window contains the following main components:

Filter dialog box (a funnel symbol)—For sorting and changing the settings of the Topology View

Search (magnifying glass icon)—For specifying the search criteria for filtering and viewing relevant data

Plus sign—For zooming in to the topology map for a detailed view of the elements on the map

Minus sign—For zooming out of the topology map for a high-level view of the entire map

Pictorial representation of the network on the upper portion of the page—For displaying the network

The upper portion of the right pane, which shows the topology map, is the middle portion of the topology window. In this area, you can double-click the zones that are displayed to expand and display the devices contained in that zone. The pop-up menu is accessed by right-clicking in the center pane that shows the topology map. Right-click a node, link, or group on the map to display a pop-up menu for that element.

Tables on the lower portion of the page—For viewing detailed information about devices, links, LSPs, and services configured for the network topology

Downward arrow at the bottom of the page—For hiding the table that displays information about devices, links, and LSPs, and for displaying the topology map in the entire canvas

Zoom in and zoom out—For zooming in and out by using the mouse scroll wheel for a detailed or high-level representation of the topology map

Moving the map—For dragging the map around by holding down the left mouse button

RELATED DOCUMENTATION

[Monitoring the Topology of Network Elements Managed by CSD-Topology Overview | 317](#)

[Specifying Topology Preferences | 134](#)

[Working with the Graphical Image in the Topology View Window | 322](#)

Working with the Graphical Image in the Topology View Window

In the Topology View of Build mode, the topology (map) window shown is the main work area for any live network or network model you load into the system. Multiple links displayed between nodes use line bending to avoid hidden trunks in the topology. The topology incorporates node aggregation collapsible views. You can also view node locations by their geographic coordinates on the world map using latitude and longitude or automatic layouts in the Topology View of Build mode.

The Topology View window displays important link and node properties, and also the devices contained in sites. Links interconnecting the devices are color coded according to utilization. Alternatively, you can view links by other properties such as trunk type, protocols, coloring, status, and area. Nodes are color-coded by symbols, icons, or vendor types.

Path information can be displayed in the Topology View window. The path function displays detailed path information between any two nodes found in the network based on factors such as routing method used, reserved and actual bandwidth allocation, link distance, or oversubscription.

The Topology View is a graphical representation of the baseline network.

- When the cursor is positioned over a network element in the Topology View, a description of the network element is displayed above each device.
- Double-click an element icon to collapse the devices or network elements and view the entire site or zone as an icon.
- Right-click an element to view more options for that element.
- Hold the left mouse button to drag the map around.
- Use the mouse scroll wheel to zoom in and out of the map.

Right-clicking on the map area displays a pop-up menu for more functions. You can move the map by holding down the left mouse button and dragging. You can zoom in and out by using the mouse scroll wheel.

In the Topology View, zones or sites are displayed as circular discs with devices when they are expanded or as small group symbols when they are collapsed. Devices or nodes are displayed within the appropriate zones as squares with the device icons. Links are displayed as gray solid connector lines. LSPs are displayed as color-coded solid connector lines. Services that are configured on nodes are displayed as dotted connector lines.

NOTE: LSP names that are not unique in the network are not displayed in the Topology View.

There are several ways to select nodes and links in the Topology View.

- Press Ctrl-click or Shift-click nodes and links.
- Right-click a node and use the Select options.
- Right-click a link and use the Select options.
- Click the plus sign to zoom in and the minus sign to zoom out of the Topology View.

When moving nodes on the map area, you are changing the graphical coordinates rather than the geographical coordinates. Graphical coordinates are the positions of the nodes in the Topology View window. Geographical coordinates are positions of the nodes according to actual physical locations (for example, latitude and longitude).

You can perform the following tasks with the View Topology page:

- [Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View on page 330](#)
- [Viewing Device Details of a CSD-Topology for Examining Traffic Transmission on page 333](#)
- [Viewing LSP Details of a CSD-Topology for Analyzing Network Changes on page 335](#)
- [Viewing Link Details of a CSD-Topology for Determining the Operational Status on page 338](#)
- [Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters on page 339](#)

The Map Preferences settings are saved to each client.

NOTE:

In the CSD-Topology database, the topology information that gets saved for each network includes the following:

NOTE: By default, the graphcoordaux file is automatically saved when closing a network to avoid losing auxiliary changes made to the map, such as map legend settings. Clear this check box to disable this feature.

group file—Groupings of network devices are saved in the **group** file

graphcoord file—Graphical coordinates of network devices are saved in the **graphcoord** file

graphcoordaux file—Stores the following map settings data:

Legends—Node and link color settings, link utilization color bar settings, and line styles.

Labels—Which node or link labels are turned on and labeling preferences for the bottom bar

Background Image—Background images to use

Country Maps—Country maps to use

Groups—Which groups are collapsed and which groups are expanded

RELATED DOCUMENTATION

[Monitoring the Topology of Network Elements Managed by CSD-Topology Overview | 317](#)

[Specifying Topology Preferences | 134](#)

[CSD-Topology Topology Map Window Overview | 320](#)

Expanding and Collapsing Groups by Using the Topology Map Grouping Shortcut Menu

In the Topology View displayed in Build mode on the Connectivity Services Director GUI, you can collapse any groups, thereby displaying them as small group symbols, which enables you to obtain a high-level view of large network deployments with several devices and links. You can also expand any collapsed group in the topology to display and view details of the network elements.

To expand or collapse groups displayed in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Right-click a zone or a group on the upper portion of the topology window and select either of the following options from the shortcut menu:

Collapse Groups—Collapses any groups, displaying them as small group symbols with their contents hidden

Expand Groups—Expands any collapsed group in the topology. The groups are displayed as discs and the contents are visible.

RELATED DOCUMENTATION

[Filtering Links, LSPs, and Services by Using the Topology Map Node Shortcut Menu | 326](#)

[Removing the Highlighted LSPs by Using the Topology Map LSPs Shortcut Menu | 327](#)

[Viewing the Service Path by Using the Topology Map Service Shortcut Menu | 328](#)

Filtering Links, LSPs, and Services by Using the Topology Map Node Shortcut Menu

In a network topology that contains a large number of links configured among devices or nodes, it might be necessary to hide some of the links to avoid a cluttered view of multiple connector lines and display only the links that are of relevance for your network administration tasks. Also, you might need to filter LSPs and services for a particular device or node to selectively display only the LSPs and services configured for that device or node. You can obtain such a restricted set of necessary links, LSPs, and services by using the shortcut menu for each device or node.

To obtain a filtered display of LSPs, links, and services for a particular node in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Select the **Devices** tab on the lower portion of the page.

The configured device details are displayed in a table.

4. Select the check boxes beside the devices that you want to view on the topology map.

The selected devices in the corresponding zones or custom groups are displayed on the topology map.

5. Mouse over a node icon or set of nodes and right-click to display a menu.

When you mouse over a device or a node, the name of the device or node is displayed as a tooltip.

The following options are available on the shortcut menu when you right-click each device or node:

Select Device—Highlights the device to indicate that it has been selected among other nodes displayed in the Topology View

Show Links—Displays the current route and the defined routes (for example, primary and backup) of the given tunnel in the Topology View. If multiple tunnels are selected, their primary paths are highlighted in the Topology View, and the tunnel currently selected in the path window is highlighted with a different color.

Hide Links—Removes the connector lines that are displayed to signify the links from the selected or source device to destination pairs of all tunnels on the topology map

Filters > Filter LSPs—Displays the LSPs that match the filter criteria that you specified for LSPs, such as whether LSPs that are up or down must be displayed, and whether delegated LSPs, CSD-Topology-initiated or PCEP-initiated LSPs, or router-initiated or PCC-initiated LSPs must be displayed.

Filters > Filter Services—Displays the services that match the filter criteria that you specified for services, such as whether E-Line, IP, or E-LAN services must be displayed

RELATED DOCUMENTATION

[Expanding and Collapsing Groups by Using the Topology Map Grouping Shortcut Menu | 325](#)

[Removing the Highlighted LSPs by Using the Topology Map LSPs Shortcut Menu | 327](#)

[Viewing the Service Path by Using the Topology Map Service Shortcut Menu | 328](#)

Removing the Highlighted LSPs by Using the Topology Map LSPs Shortcut Menu

You can remove the highlighted LSPs from being displayed in the Topology View in network scenarios in which several LSPs are configured for a service to prevent the topology map from being cluttered with a large set of connector lines. You might require to specifically focus on some of the LSPs that you want to troubleshoot and diagnose for faults and traffic disruptions.

NOTE: In the Topology View displayed in Build mode on the Connectivity Services Director GUI, mouse over an LSP and right-click to display a menu. When you mouse over an LSP, the name of the link is displayed as a tooltip.

To remove the highlighted LSPs from display in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.
2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Select the **LSPs** tab on the lower portion of the page.

The configured LSP details are displayed in a table.

4. Select the check boxes beside the LSPs that you want to view on the topology map.

The selected LSPs are displayed as different color-coded lines on the map.

5. Mouse over an LSP and right-click to display a menu.

When you mouse over an LSP, the name of the link is displayed as a tooltip. The following option is available on the shortcut menu when you right-click each LSP:

Remove LSP Highlight > LSPName—Removes the selected LSPs displayed on the shortcut menu from being highlighted in the Topology View. This option is useful when a service is configured with multiple LSPs and you do not want the LSPs to be highlighted and shown.

RELATED DOCUMENTATION

[Expanding and Collapsing Groups by Using the Topology Map Grouping Shortcut Menu | 325](#)

[Filtering Links, LSPs, and Services by Using the Topology Map Node Shortcut Menu | 326](#)

[Viewing the Service Path by Using the Topology Map Service Shortcut Menu | 328](#)

Viewing the Service Path by Using the Topology Map Service Shortcut Menu

A service path is a connector that displays the LSP configured for a particular service on a device in the Topology View. Because of a large number of services that might be configured among devices in a topology, it is required to distinguish only the LSPs or service paths that connect from one device to another device. In such a case, you can select a service displayed in the Topology View and choose to hide or show the service path for analysis purposes.

NOTE: In the Topology View displayed in Build mode on the Connectivity Services Director GUI, mouse over a service and right-click to display a menu. When you mouse over a service, the name of the service is displayed as a tooltip.

To hide or display a service path associated with a device in the Topology View:

1. Select **Topology View** from the Views list in the Connectivity Services Director application.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

2. Select the **Service** tab on the lower portion of the page.

The service details are displayed in a table.

3. Select the check box beside a service configured for devices in the topology.

The service paths that traverse the different devices on which the selected service is configured are displayed as highlighted lines in the Topology View.

4. Right-click a service path and select one of the following options available on the shortcut menu:

Hide Service Path—Removes the LSPs highlighted in the Topology View.

Retrieve Service Path—Retrieves an LSP associated with the service path.

NOTE: Starting from Connectivity Services Director Release 2.0R4, you can also select **Retrieve Service Path** to retrieve an LSP associated with a service path.

Show Service Path—Displays the LSPs associated with the service.

Release History Table

Release	Description
2.0R4	Starting from Connectivity Services Director Release 2.0R4, you can also select Retrieve Service Path to retrieve an LSP associated with a service path.

RELATED DOCUMENTATION

[Expanding and Collapsing Groups by Using the Topology Map Grouping Shortcut Menu | 325](#)

[Filtering Links, LSPs, and Services by Using the Topology Map Node Shortcut Menu | 326](#)

[Removing the Highlighted LSPs by Using the Topology Map LSPs Shortcut Menu | 327](#)

Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View

In network environments that contain several thousands of devices, it might be helpful to sort and segregate the devices and their associated LSPs and links, based on certain filter conditions. You can specify the criteria that must be matched for the network elements shown in the Topology View. For example, you can specify that only devices that are up or only LSPs for devices on which IP services are defined must be displayed.

To specify the filter criteria for segregating the displayed elements in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Click the **Filter** icon (the funnel symbol) at the top-left corner of the Topology View window.

The Filter dialog box is displayed.

4. On the Devices tab, mouse over the tab to view the drop-down menu and do the following:

- Select **Show All**, **Up**, or **Down** from the Device Status list to display the devices that are in any state, in the up state, or in the down state respectively.
- Select the **Show Unmanaged Devices** check box to display the unmanaged devices that are present in the links in the topology. Alternatively, clear this check box to view only the managed devices in the topology.
- Select **Custom Group**, **OSPF Area**, or **AS Number** from the Group by list to group the devices in the topology based on the configured custom groups, OSPF area, or autonomous system (AS) number respectively.

5. On the Links tab, mouse over the tab to view the drop-down menu and do the following:

- Select the **Show All Links** check box to display all the links originating from each node in the topology.
- Select the **Show Optical Links** check box to display only the optical links originating from each node in the topology.
- Select **Up** or **Down** from the Operational Status list to display links that are either active or disabled.

6. Click **Filter** to save the filter criteria.

The dialog box is closed and you are returned to the Topology View.

RELATED DOCUMENTATION

[Viewing Device Details of a CSD-Topology for Examining Traffic Transmission | 333](#)

[Viewing LSP Details of a CSD-Topology for Analyzing Network Changes | 335](#)

[Viewing Link Details of a CSD-Topology for Determining the Operational Status | 338](#)

[Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters | 339](#)

Segregating the Displayed Devices by Searching the Entire Topology View

In the Topology View displayed in Build mode on the Connectivity Services Director GUI, you can enter the strings or terms that you want to use as search labels to search for any node, link, or group and filter the display. The Search box is displayed on the top-right corner of the Topology View. You can search based on only one term or criterion at a time. You can search for nodes or devices on the topology map based on router ID, hostname, management IP address, and serial number of the device. In certain network deployments, you might require a certain set of devices that match a particular subnet to be viewed for obtaining a subset of the entire topology that is of interest and relevance to you. In such cases, you can specify the IP address of the device as the search term to view only the appropriate device that matches the search term.

To specify a search criterion for classifying the displayed devices in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. Click the **Search** icon (magnifying glass symbol) and enter the search term in the text field that is displayed.

The Search box is displayed on the top-right corner of the Topology View. A drop-down list prompts you to select a term that matches the characters you enter in the search field. The node that matches the search term is highlighted in the Topology View.

You can search based on only one criterion at a time. You can search for nodes or devices in the Topology View based on the router ID, hostname, management IP address, and serial number of the device. Delete the search term that you entered to remove the term from the search criterion.

RELATED DOCUMENTATION

[Resynchronizing the Topology View](#) | 332

Resynchronizing the Topology View

You can resynchronize the topology map displayed on the Connectivity Services Director GUI, which enables the latest links information, label-switched path (LSP) details, and device states to be retrieved from the CSD-Topology application and shown in the Topology View. This resynchronization capability enables you to view the most recent synchronization of paths signaled across routed network elements. It is essential to view the latest topology information in a network that has changing traffic conditions and transmission states to be able to modify the link and LSP settings according to the deployment needs. The resynchronization functionality enables you to obtain the up-to-date topology states.

To create a job to resynchronize the topology map:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. Click the **Resynch the Topology** icon (5 o'clock symbol) to create a job to resynchronize the topology map.

A job is triggered and a pop-up dialog box displays the job ID.

4. Click **OK** to close the pop-up dialog box.

You can navigate to the Job Management page to view the status of the resynchronization job (which you can launch by clicking the **System** button on the Connectivity Services Director banner and selecting **Manage Jobs** from the Tasks pane).

RELATED DOCUMENTATION

| [Configuring PCEP on a PE Router \(from CLI\)](#) | 305

Viewing Device Details of a CSD-Topology for Examining Traffic Transmission

You can view the details of all of the devices or nodes in a Topology View that are managed by the CSD-Topology. Node addresses for the Node A and Node Z elements define the endpoint nodes for the tunnel. Devices that are discovered as part of the topology acquisition by the CSD-Topology and are not managed devices in the Connectivity Services Director database are displayed in gray. Devices that are discovered by the CSD-Topology using BGP and MPLS and are managed devices in the Connectivity Services Director database are displayed in blue.

NOTE: Because of the way in which the link-state database (LSDB) interior gateway protocols (IGPs) represent LAN connections (in order to improve scaling), multiple entries for the same hostname might be displayed on the Devices tab of the Topology View. Similarly, multiple entries for the same hostname might be displayed on the Devices tab because of the manner in which OSPF and ISIS associate with broadcast interfaces. The pseudonodes are represented in a distinct way on the GUI. When the IGP (OSPF or ISIS) builds neighboring relationships on broadcast media (such as Ethernet), the IGP represents this deployment as a hub-and-spoke topology with all nodes in the same broadcast domain having a point-to-point connection with a pseudonode. In such instances, the traffic engineering database includes a pseudonode on each interface that is configured with the interface-type LAN (the default). If such pseudonodes are not added, the topology displays a full-mesh of point-to-point connections between all nodes in the same LAN segment (this case occurs if you manually configure the interface type as point-to-multipoint [P2MP], and manually add each neighbor). The GUI represents these pseudonodes in a way that enables you to easily see that these are not real nodes (it can represent the pseudonode as a different entity, such as a special node or a LAN segment).

To view details of devices or nodes in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.
2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Select the **Devices** tab on the lower portion of the page.

For columns in the table that contain an empty text field displayed at the top of the table on each tab, you can enter the search criterion that you want to use for that particular column or parameter to sort and classify the display of values in the table. For parameters that you can enable or disable, you can select or clear the check boxes respectively. The page is refreshed to display the devices that match the specified criterion. The search criteria that you have entered are displayed above the first row of the table. You can click Clear All displayed beside each of the search terms to remove the previously defined search terms.

- Name—Hostname of the device. Click in the first cell in this column to enter the hostname as the criterion for filtering and displaying the devices in the table.
- Management Address—Management IP address of the node. Click in the first cell in this column to enter the management IP address as the criterion for filtering and displaying the devices in the table.
- Serial Number—Hardware serial number of the device
- Software Version—Junos OS software version and release number running on the device
- Platform—Platform type of the device, such as MX240 or MX480
- Platform Series—Device family to which the device belongs, such as MX Series for an MX240 router

RELATED DOCUMENTATION

[Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View | 330](#)

[Viewing LSP Details of a CSD-Topology for Analyzing Network Changes | 335](#)

[Viewing Link Details of a CSD-Topology for Determining the Operational Status | 338](#)

[Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters | 339](#)

Viewing LSP Details of a CSD-Topology for Analyzing Network Changes

You can view the details of all the label-switched paths (LSPs) configured for devices in the Topology View that are managed by the CSD-Topology. For MPLS-enabled networks, after you configure an LSP, you should also configure a standby or secondary LSP to provide an alternate route in the event the primary route fails. The tunnel ID, from node, to node, and IP address of a secondary or standby tunnel must be identical to those of the primary tunnel.

When you expand a zone or a group in the Topology View, and select an LSP on the map, the LSP is highlighted. Different highlighting colors are used to distinguish the LSPs on the map.

To view details of LSPs in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. Select the **LSPs** tab on the lower portion of the page.

NOTE: LSP names that are not unique in the network are not displayed in the Topology View.

For columns in the table that contain an empty text field displayed at the top of the table on each tab, you can enter the search criterion that you want to use for that particular column or parameter to sort and classify the display of values in the table. For parameters that you can enable or disable, you can select or clear the check boxes respectively. The page is refreshed to display the devices that match the specified criterion. The search criteria that you have entered are displayed above the first row of the table. You can click Clear All displayed beside each of the search terms to remove the previously defined search terms.

- Name—Name of the LSP. Click in the first cell in the Name column to enter the name of the LSP that you want to use as the filter for viewing the LSPs.
- Start Node Router ID—Node ID of the LSP head end. A router ID is used to uniquely identify the router within a BGP autonomous system (AS). The router ID is the IP address of the loopback interface.
- Start Node Hostname—Hostname of the router at the LSP head end
- End Node Router ID—Node ID of the LSP tail end
- End Node Hostname—Hostname of the router at the LSP tail end

- End A IP—IP address of the LSP head end. Click in the first cell in the End A IP column to enter the IP address of the head end that you want to use as the filter for viewing the LSPs.
- End B IP— IP address of the LSP tail end. Click in the first cell in the End B IP column to enter the IP address of the tail end that you want to use as the filter for viewing the LSPs.
- Operational Status—Whether the LSP is active (up) or inactive (down). Click in the first cell in the Operational Status column to select the status from the drop-down menu that you want to use as the filter for viewing the LSPs.
- Path Type—Whether the path is a primary path (explicit or dynamic) or a secondary path (explicit or dynamic)
- Control Type—Whether the LSP is router controlled or PCC initiated, CSD-Topology initiated or PCEP initiated, or CSD-Topology managed or delegated LSP. Click in the first cell in the Control Type column to specify the type of LSP from the drop-down menu that you want to use as the filter for viewing the LSPs.
- Metric—LSP tunnel metric
- Setup Priority—Setup priority supported by RSVP for the tunnel traffic

NOTE: You must assign priorities according to network policies to prevent resource poaching and LSP thrashing. The hold priority values should be lower than or equal to the setup priority value.

- Holding Priority—Hold priority supported by RSVP for the tunnel traffic

NOTE: The default is priority 07 and hold 07, which is the standard MPLS LSP definition in Junos OS. Setup priority determines whether a new LSP that preempts an existing LSP can be established. For preemption to occur, the setup priority of the new LSP must be higher than the setup priority of the existing LSP. In addition, the act of preempting the existing LSP must provide sufficient bandwidth to support the new LSP. Therefore, preemption occurs only if the new LSP can be set up successfully. You can configure each LSP with a setup priority and hold priority to provide a preemption strategy whereby a new LSP can claim resources from an existing LSP. Each LSP can claim resources from an existing LSP. Priority levels range from 0 (highest priority) through 7 (lowest priority). If traffic engineering admission control determines that there are insufficient resources available to accept a request to set up a new LSP, the setup priority is evaluated against the hold priority of the existing LSPs (per standard Junos OS behavior). An LSP with a hold priority lower than the setup priority of the new LSP can be preempted. The existing LSP is terminated to make resources available for the new LSP.

- **Current Bandwidth**—Bandwidth that is specified for the tunnel traffic (bandwidth applies for each direction)

4. Mouse over an LSP and click the LSP to display a menu.

When you mouse over an LSP, the name of the LSP is displayed on a pop-up menu. The following fields are displayed in the pop-up dialog box when you mouse over the LSP:

- **Name**—Name of the LSP. The names of all the LSPs that are configured for the particular link are displayed.
- **View Details**—Detailed information about the selected LSP.

RELATED DOCUMENTATION

[Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View | 330](#)

[Viewing Device Details of a CSD-Topology for Examining Traffic Transmission | 333](#)

[Viewing Link Details of a CSD-Topology for Determining the Operational Status | 338](#)

[Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters | 339](#)

Viewing Link Details of a CSD-Topology for Determining the Operational Status

It is necessary to determine the operational status of links configured among devices in a topology to examine and troubleshoot data traffic loss and packet-forwarding problems. You can view the details of all the links configured for devices in the Topology View that are managed by the CSD-Topology. For explicit routing, from the Map view, click the links or nodes to define an alternate route between the source (Node A) and destination (Node Z) nodes to provide a path that is diverse from the path specified in the primary tunnel. When you schedule a maintenance event on nodes or links, the CSD-Topology routes delegated label-switched paths (LSPs) around those nodes and links that are scheduled for maintenance. After the completion of the maintenance event, delegated LSPs are reverted to optimal paths.

To view details of links in the Topology View:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Select the **Links** tab on the lower portion of the page.

For columns in the table that contain an empty text field displayed at the top of the table on each tab, you can enter the search criterion that you want to use for that particular column or parameter to sort and classify the display of values in the table. For parameters that you can enable or disable, you can select or clear the check boxes respectively. The page is refreshed to display the devices that match the specified criterion. The search criteria that you have entered are displayed above the first row of the table. You can click Clear All displayed beside each of the search terms to remove the previously defined search terms.

- Link Name—Name of the configured link
- End A RouterId—Router ID of the starting node of the link. The router ID is used to uniquely identify a router and is the IP address of the loopback interface.
- End B RouterId—Router ID of the ending node of the link
- Endpoint A Hostname—Hostname of the router at the starting node of the link. Click in the first cell in the Endpoint A IP column to enter the IP address of the LSP head end that you want to use as the filter for viewing the links.

- End B Hostname—Hostname of the router at the ending node of the link. Click in the first cell in the Endpoint A IP column to enter the IP address of the LSP tail end that you want to use as the filter for viewing the links.
- End A Interface Name—Name of the interface on the router at the starting point of the link
- End B Interface Name—Name of the interface on the router at the ending point of the link
- End A Interface Address—IP address of the interface on the router at the starting point of the link
- End B Interface Address—IP address of the interface on the router at the ending point of the link
- Link Type—Whether the link is an IP link or an optical link
- Operational Status—Whether the link is active (up) or inactive (down). Click in the first cell in the Operational Status column to open the drop-down menu and select the type of operational status that you want as the filter for viewing for the links.

RELATED DOCUMENTATION

[Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View | 330](#)

[Viewing Device Details of a CSD-Topology for Examining Traffic Transmission | 333](#)

[Viewing LSP Details of a CSD-Topology for Analyzing Network Changes | 335](#)

[Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters | 339](#)

Viewing Service Details of a CSD-Topology for Monitoring and Troubleshooting Service Parameters

You can view the consolidated and cumulative information pertaining to a service to examine and diagnose the deployment and fault statuses for debugging and corrective action. The overall information pertaining to the service that you can obtain from the Topology View enables you to navigate to the appropriate device or service settings page and modify the configuration parameters appropriately.

You can view the details of all the services configured for devices on a topology map that are managed by the CSD-Topology. This information display of service attributes is especially helpful if devices that are managed by the CSD-Topology are also added to the Connectivity Services Director database for administration and monitoring. You can view the topology map based on the services and other filter conditions, such as their deployment states, functional audit statuses, or customer name. E-Line, E-LAN, and IP services defined on devices can be viewed.

To view details of services on a topology map:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Select the **Services** tab on the lower portion of the page.

For columns in the table that contain an empty text field displayed at the top of the table on each tab, you can enter the search criterion that you want to use for that particular column or parameter to sort and classify the display of values in the table. For parameters that you can enable or disable, you can select or clear the check boxes respectively. The page is refreshed to display the devices that match the specified criterion. The search criteria that you have entered are displayed above the first row of the table. You can click Clear All displayed beside each of the search terms to remove the previously defined search terms.

- Name—Name of the service configured for a device. Click in the first cell in the Name column to enter the service name that you want to use as the filter for viewing the services.
- Service Type—Type of service, such as E-Line, IP, or E-LAN. Click in the first cell in the Service Type column to select the type of service from the displayed drop-down menu that you want to use as the filter for viewing the services.
- Customer Name—Name of the customer associated with the service. Click in the first cell in the Customer Name column to enter the customer name that you want to use as the filter for viewing the services.
- Topology Type—Design of the network, such as a point-to-point topology, point-to-multipoint or hub-and-spoke format, and multipoint-to-multipoint or full-mesh format. Click in the first cell in the Topology Type column to select the type of topology from the displayed drop-down menu that you want to use as the filter for viewing the services. The following options are displayed on the drop-down menu:
 - POINT2POINT—Point-to-point topology type
 - POINT2MULTIPOINT—Point-to-multipoint topology type
 - MULTIPOINT2MULTIPOINT—Multipoint-to-multipoint topology type for E-LAN services
 - FULLMESH—Full-mesh topology type for IP services
 - HUBSPOKE1INTF—Hub-and-spoke topology type with one interface
 - HUBSPOKE2INTF—Hub-and-spoke topology type with two interfaces
- Deployment State—Status of deployment, such as whether the deployment is successful, failed, or pending. Click in the first cell in the Deployment State column to select the deployment status from

the displayed drop-down menu that you want to use as the filter for viewing the services. The following values are displayed on the drop-down menu:

- Deployed—The service is deployed and is in an active state (enabled) or inactive state (disabled).
- Deployment-Pending—The service has not yet been deployed.
- Failed Deploy—Attempt to modify the service failed.
- Fault Status—Fault management status of the service, such as whether a service fault is active on a device (red bell icon) or the service fault that was generated for the device has been cleared (green bell icon)
- FA Status—Whether the link is active (up) or inactive (down). Click in the first cell under the FA Status column to select the functional audit status from the displayed drop-down menu that you want to use as the filter for viewing the services. The following values are displayed on the drop-down menu:
 - Pending—Functional audit operation is pending to be performed for the service.
 - Failed—Functional audit operation has failed for the service.
 - Up—Functional audit completed successfully for the service.
- Last Updated Date—Date and time that the information for the service was last modified

RELATED DOCUMENTATION

[Filtering Devices, LSPs, and Services for Sorting and Segregating the Topology View | 330](#)

[Viewing Device Details of a CSD-Topology for Examining Traffic Transmission | 333](#)

[Viewing LSP Details of a CSD-Topology for Analyzing Network Changes | 335](#)

[Viewing Link Details of a CSD-Topology for Determining the Operational Status | 338](#)

Viewing Topology Map Group Details in a Pop-Up Dialog Box

In the Topology View of Build mode, the upper portion of the page, which shows the topology map, is the main display area. In this area, you can double-click the zones that are displayed to expand and display the devices contained in that zone. Mouse over a node, link, or group on the map to display a pop-up menu for that element. Mouse over a group to view the group information. When you mouse over a group, the name of the group is displayed on a pop-up menu.

In a large network that comprises devices or nodes situated in several groups, which denote the geographical locations or zones, it might be essential to view the details of a particular group that is of relevance for your network management needs. In such cases, apart from viewing the number of devices that are associated with a group, you can also view information on the alarms generated for these devices. For example, you might want to modify the grouping of devices by transferring devices to a different group or zone for better load-balancing of traffic or optimizing packet flows. Also, if you find that a particular group has recorded a large number of critical or major alarms, you can then navigate to the Alarm Detail widget in Monitor mode or the appropriate device settings page to correct and modify the attributes or diagnose the problems that might be generating the alarms.

NOTE: Right-clicking the map area displays a pop-up menu for more functions. You can move the map by holding down and dragging the left mouse button. You can zoom in and out by using the mouse scroll wheel. Double-click an element icon to collapse the devices or network elements and view the entire site or zone as an icon.

To view group details in a pop-up dialog box:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. In the graphical representation of the topology displayed, select the group for which you want to view the device details by double-clicking the group.

The group is expanded and the devices contained in the group are displayed within a circle.

Devices that are discovered as part of the topology acquisition by the CSD-Topology and are not managed devices in the Connectivity Services Director database are displayed in gray. Devices that

are discovered by the CSD-Topology using BGP and MPLS and are managed devices in the Connectivity Services Director database are displayed in blue.

4. Mouse over the group for which you want to view the configuration settings.

The group pop-up menu is displayed with the number of devices contained in the group.

5. Click the **View Details** link from the pop-up menu.

The Group Details pop-up dialog box is displayed, which displays the name of the group and the number of devices contained in the group. Also, the Fault Details field displays four colored circles—red, orange, yellow, and blue—to signify the four alarm severity levels as follows:

- Critical (red)—A critical condition exists for a device in the zone; immediate action is necessary.
- Major (orange)—A major error has occurred for a device in the zone; escalate or notify as necessary.
- Minor (yellow)—A minor error has occurred for a device in the zone; notify or monitor the condition.
- Info (blue)—An informational message has been generated for a device in the zone; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

6. Click the **Close** icon at the top-right corner of the pop-up dialog box to return to the topology map.

RELATED DOCUMENTATION

[Viewing Topology Map Device Details in a Pop-Up Dialog Box | 344](#)

[Viewing Topology Map Link Details in a Pop-Up Dialog Box | 346](#)

[Viewing Topology Map LSP Details in a Pop-Up Dialog Box | 348](#)

[Viewing Topology Map Service Details in a Pop-Up Dialog Box | 350](#)

Viewing Topology Map Device Details in a Pop-Up Dialog Box

In the Topology View of Build mode, the upper portion of the page shows the topology map, which is the main display area. In this area, you can double-click the zones that are displayed to expand and display the devices contained in that zone. The pop-up menu is accessed by double-clicking the group in the center pane that shows the topology map. Mouse over a device on the map to display a pop-up menu for that device.

In a geographically diverse network with several groups or zones, after you expand and view a particular group, you can also view the salient configuration details of devices contained in that group. Both the devices that are managed by Connectivity Services Director and the devices that are not managed by Connectivity Services Director, but have been only acquired as part of the CSD-Topology topology acquisition, are displayed in the expanded groups on the topology map. You can view important, high-level device details such as the Junos OS release that is running on a particular device for determining any Junos OS image upgrade as necessary and the device status. If you identify the status of the device to be down, you can then view the device configuration settings and take any corrective action.

NOTE: Right-clicking the map area displays a pop-up menu for more functions. You can move the map by holding down and dragging the left mouse button. You can zoom in and out by using the mouse scroll wheel. Double-click an element icon to collapse the devices or network elements and view the entire site or zone as an icon.

Devices that are discovered as part of the topology acquisition by the CSD-Topology and are not managed devices in the Connectivity Services Director database are displayed in gray. Devices that are discovered by the CSD-Topology using BGP and MPLS and are managed devices in the Connectivity Services Director database are displayed in blue.

Mouse over a node icon or set of nodes and double-click to display a menu. When you mouse over a device or a node, the name of the device is displayed on a pop-up menu. The following fields are displayed in the pop-up dialog box when you mouse over the device or node:

- Host Name—Hostname of the selected device or node
- IP Address—IP address of the selected device or node
- Device Status—Status of the selected device or node, such as Up or Down
- View Details—Detailed information about the selected device or node. Click the link in **View Details** to open a pop-up dialog box that displays these details.

When you select a particular device by expanding a group or zone and clicking the device, the device icon is highlighted and displayed.

To view device details in a pop-up dialog box:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. In the graphical representation of the topology displayed on the right pane, select the group for which you want to view the device details by double-clicking the group.

The group is expanded and the devices contained in the group are displayed within a circle.

4. Mouse over the device or node for which you want to view the configuration settings.

The device pop-up menu is displayed.

5. Click the **View Details** link from the pop-up menu.

The Device Details dialog box is displayed on the right pane, which contains the following fields:

- Host Name—Hostname of the device or node
- Serial Number—Serial number of the chassis component. The serial number of the backplane is also the serial number of the router chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.
- OS Version—Operating system firmware version running on the device or node
- Device Family—Device family of the device or node, such as JUNOS for MX Series routers

6. Click the **Close** icon at the top-right corner of the pop-up dialog box to return to the topology map.

RELATED DOCUMENTATION

[Viewing Topology Map Group Details in a Pop-Up Dialog Box | 342](#)

[Viewing Topology Map Link Details in a Pop-Up Dialog Box | 346](#)

[Viewing Topology Map LSP Details in a Pop-Up Dialog Box | 348](#)

[Viewing Topology Map Service Details in a Pop-Up Dialog Box | 350](#)

Viewing Topology Map Link Details in a Pop-Up Dialog Box

In the Topology View of Build mode, the upper portion of the page shows the topology map, which is the main display area. In this area, you can click or right-click the connecting lines, which represent the links that transmit traffic between devices, to view the link details. The pop-up menu is accessed by double-clicking in the center pane that shows the topology map. Mouse over a link on the map to display a pop-up menu for that link.

For a specific zone and a set of devices in that zone, you can view the links connecting the devices. You can view the link details, such as the node identifier and the node IP address of the head end or originating router and the tail end or the destination router. These link details are useful for diagnosing and troubleshooting any link problems that cause traffic drops or loss in transmission of packets.

NOTE: Right-clicking the map area displays a pop-up menu for more functions. You can move the map by holding down and dragging the left mouse button. You can zoom in and out by using the mouse scroll wheel. Double-click an element icon to collapse the devices or network elements and view the entire site or zone as an icon.

To view link details in a pop-up dialog box:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. In the graphical representation of the topology displayed on the page, select the link by clicking the link or right-clicking the link for which you want to view details.

The link is highlighted and displayed as a colored line.

4. Mouse over a link and click the link to display a menu.

When you mouse over a link, the name of the link is displayed on a pop-up menu. The following fields are displayed in the pop-up dialog box when you mouse over the link:

- Operational Status—Status of the link, such as Up or Down
- View Details—Detailed information about the selected link. Click the link in **View Details** to open a pop-up dialog box that displays these details.

5. Click the **View Details** link from the pop-up menu.

The Link Details pop-up dialog box is displayed on the right pane. The link details are displayed in a table as follows:

- End A Device—Node ID of the LSP head end
- End B Device—Node ID of the LSP tail end
- End A IP—IP address of the LSP head end
- End B IP—IP address of the LSP tail end
- Operational Status—Whether the link is active (up) or inactive (down)

6. Click the **Close** icon at the top-right corner of the pop-up dialog box to return to the topology map.

RELATED DOCUMENTATION

[Viewing Topology Map Group Details in a Pop-Up Dialog Box | 342](#)

[Viewing Topology Map Device Details in a Pop-Up Dialog Box | 344](#)

[Viewing Topology Map LSP Details in a Pop-Up Dialog Box | 348](#)

[Viewing Topology Map Service Details in a Pop-Up Dialog Box | 350](#)

Viewing Topology Map LSP Details in a Pop-Up Dialog Box

In the Topology View of Build mode, the upper portion of the page shows the topology map, which is the main display area. In this area, you can click or right-click the connecting lines, which represent the label-switched paths (LSPs) configured over pseudowire links, that transmit traffic between devices, to view the LSP details. Mouse over an LSP on the map to display a pop-up menu for that LSP.

For a specific zone and a set of devices in that zone, you can view the links and LSPs connecting the devices. When you view the LSP details, the link details are also displayed. You can determine the path type of the LSP—primary or backup. You can then decide whether you want to automatically configure a tunnel to have its secondary or standby paths diverse from its primary path. You can also design two different tunnels to have diverse primary paths, and set the primary and backup paths to perform explicit routing or dynamic routing. You can also verify the type of LSP—CSD-Topology managed (Delegated) LSP, path computation element protocol (PCEP) initiated LSP, or path computation client (PCC) or router initiated LSP—and change the type of delegation to be performed for the LSP.

NOTE: Right-clicking the map area displays a pop-up menu for more functions. You can move the map by holding down and dragging the left mouse button. You can zoom in and out by using the mouse scroll wheel. Double-click an element icon to collapse the devices or network elements and view the entire site or zone as an icon.

Mouse over an LSP and click the link to display a menu. When you mouse over an LSP, the name of the LSP is displayed on a pop-up menu. The following fields are displayed in the pop-up dialog box when you mouse over the LSP:

- **Name**—Name of the configured LSP. The names of all LSPs configured for a particular link are displayed.
- **View Details**—Detailed information about the selected LSP. Click the link in **View Details** to open a pop-up dialog box that displays these details.

To view LSP details in a pop-up dialog box:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. Select the **LSPs** tab on the lower portion of the page.

The configured LSP details are displayed in a table.

4. Select the check boxes beside the LSPs that you want to view on the topology map.

The selected LSPs are displayed as different color-coded lines on the map.

5. In the graphical representation of the topology displayed on the upper portion of the page, select the LSP by clicking the LSP or right-clicking the LSP for which you want to view details.

The LSP is highlighted and displayed as a colored line.

6. Click the **View Details** link from the pop-up menu.

The LSP Details and Link Details pop-up dialog boxes are displayed on the right pane.

The LSP details are displayed in a table as follows:

- Name—Name of the configured LSP on the specific link
- Status—Whether the LSP is active (up) or inactive (down)
- Path Type—Whether the path is a primary path (explicit or dynamic) or a secondary path (explicit or dynamic)
- Control Type—Whether the LSP is router-controlled or PCC-initiated, CSD-Topology-initiated or PCEP-initiated, or CSD-Topology managed or delegated LSP

The link details are displayed in a table as follows:

- End A Device—Node ID of the LSP head end
- End B Device—Node ID of the LSP tail end
- End A IP—IP address of the LSP head end
- End B IP—IP address of the LSP tail end
- Operational Status—Specifies whether the link is active (up) or inactive (down)

7. Click the **Close** icon at the top-right corner of the pop-up dialog box to return to the topology map.

RELATED DOCUMENTATION

[Viewing Topology Map Group Details in a Pop-Up Dialog Box | 342](#)

[Viewing Topology Map Device Details in a Pop-Up Dialog Box | 344](#)

[Viewing Topology Map Link Details in a Pop-Up Dialog Box | 346](#)

[Viewing Topology Map Service Details in a Pop-Up Dialog Box | 350](#)

Viewing Topology Map Service Details in a Pop-Up Dialog Box

In the Topology View of Build mode, the upper portion of the page shows the topology map, which is the main display area. In this area, you can click or right-click the dotted connecting links, which represent the services configured across devices, to view the service details. The pop-up menu is accessed by double-clicking a group in the center pane that shows the topology map. Mouse over a service on the map to display a pop-up menu for that service.

The topology map enables you to obtain a comprehensive view of services configured on devices in the entire network. Because you can narrow down to a specific service that is of relevance to you in the topology map, you can easily view important configuration specifications of a service, such as the type of service, the customer with which the service is associated, whether the service is successfully deployed or is pending deployment, and whether the service is in the requested, scheduled, or pending status. Such salient service-specific details enable you to obtain a comprehensive view of the health of services, and navigate to the Service View in Deploy mode to modify the service settings for debugging and corrective action.

NOTE: Right-clicking the map area displays a pop-up menu for more functions. You can move the map by holding down and dragging the left mouse button. You can zoom in and out by using the mouse scroll wheel. Double-click an element icon to collapse the devices or network elements and view the entire site or zone as an icon.

Mouse over the dotted lines that denote the services configured across different endpoints on the topology map and click the service to display a menu. The following fields are displayed in the pop-up dialog box when you mouse over the service:

- Name—Name of the configured service
- Customer Name—Name of the customer for which the service is configured
- Service Type—Type of the configured service, such as E-LINE Martini, IP, or E-LAN
- Service State—State of the service, such as whether the service is deployed or not
- Service Status—Status of the service, such as whether the service is in requested, scheduled, or pending status
- View Details—Detailed information about the selected service. Click the link in **View Details** to open a pop-up dialog box that displays these details.

To view service details in a pop-up dialog box:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed.

3. Select the **Services** tab on the lower portion of the page.

The configured service details are displayed in a table.

4. Select the check box beside the services that you want to view on the topology map.

The selected services are displayed as different dotted color-coded lines on the map.

5. In the graphical representation of the topology displayed on the upper portion of the page, select the service by clicking the dotted lines or right-clicking the dotted lines for which you want to view details.

The service is highlighted and displayed as a colored dotted line.

6. Click the **View Details** link from the shortcut menu.

The Service Details pop-up dialog box is displayed on the right pane.

The service details are displayed in a table as follows:

- Customer Name—Name of the customer for which the service is configured
- Service Type—Type of the configured service, such as ELINE Martini, L3VPN, or VPLS
- Service State—State of the service, such as whether the service is deployed or not
- Service Status—Status of the service, such as whether the service is in requested, scheduled, or pending status

7. Click the **Close** icon at the top-right corner of the pop-up dialog box to return to the topology map.

RELATED DOCUMENTATION

[Viewing Topology Map Group Details in a Pop-Up Dialog Box | 342](#)

[Viewing Topology Map Device Details in a Pop-Up Dialog Box | 344](#)

[Viewing Topology Map Link Details in a Pop-Up Dialog Box | 346](#)

[Viewing Topology Map LSP Details in a Pop-Up Dialog Box | 348](#)

Enabling the Collection of LSP and Service Association Details

From the **Monitoring** tab of the Preferences page (which you can launch by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences), you can enable the collection of LSPs configured on the links of the PCC devices in a topology and also to enable retrieval of service association details with the LSPs. When you enable this functionality, the details are obtained from the devices at periodic polling intervals.

To specify the monitoring setting for Topology:

1. From the Junos Space user interface, click the **System** icon in the Connectivity Services Director banner.

The options that you can configure in System mode are displayed in a drop-down menu.

2. Select **Preferences** from the drop-down menu to open the Preferences page.

The Preferences page opens with User Preferences as the default tab.

3. Click the **Monitoring** tab to configure the frequency at which the association between LSPs and services must be retrieved for the topology.

The settings that you can configure on the Monitoring tab are displayed.

4. Select the **ProvisioningMonitorLSPToServiceAssociationCollector** check box to enable the collection of LSPs configured on the links of the PCC devices in a topology and also to enable retrieval of service association details with the LSPs.

When you select this check box, the details are obtained from the devices at periodic polling intervals. By default, the polling interval is 5 minutes.

RELATED DOCUMENTATION

[Configuring PCEP on a PE Router \(from CLI\) | 305](#)

Using Custom Grouping for Devices in a CSD Topology

You can use the custom grouping methodology in Connectivity Services Director to cluster the devices that the CSD-Topology provisions PCEP for establishing LSPs between the PCC routers. Custom group is way of grouping your devices based on your business needs. You can create custom groups and add devices to each custom group. You can manually add devices to a custom group or you can define rules to add devices, that match the rule condition, to the custom group once they are discovered by Connectivity

Services Director. You can view the custom groups and devices that are assigned to each group in the Custom Group view.

Using the custom groups feature, you can control how the group is displayed on the topology map—as a single group entity or as individual member nodes. When you expand a group on the topology map by double-clicking the group icon, all the member nodes are listed in a circle with interconnecting links and are displayed on the map. When you collapse a group on the topology map by double-clicking the circle that contains the member nodes, only the group is displayed and represented by a single icon on the map.

RELATED DOCUMENTATION

| [Configuring PCEP on a PE Router \(from CLI\) | 305](#)

Viewing Generated Alarms for Services in the Topology View

Apart from displaying a graphical representation of the nodes and interconnecting links in a network deployment, the Topology View also displays the alarms of each severity level generated for services configured on nodes in the network topology at the top-left corner of the View Topology page. Information is displayed about the alarms generated by different devices for which services, such as E-Line, IP, LSPs, and E-LAN, are configured. The summarized way in which you can view alarm details enables you to examine the health and operating-efficiency of devices, and the performance of services. These alarm details enable effective and simplified troubleshooting and administration.

For example, if you find that a particular device has recorded a large number of critical or major alarms for a service, you can then navigate to the design and provisioning pages of the type of service to correct and modify the attributes or diagnose the problems that might be generating the alarms. You can then clear the appropriate alarm from the Alarm Detail monitor in Fault mode of Service View after examining the alarm and associated events, and taking any corrective action needed to resolve the alarm condition on the corresponding device.

NOTE: Only service-level alarms are displayed; alarms generated for LSPs configured on the links connecting the nodes are not shown.

RELATED DOCUMENTATION

| [Configuring PCEP on a PE Router \(from CLI\) | 305](#)

Viewing the Optical Link Details for Examining the Performance of Optical Links

In the Topology View of Build mode, in addition to the Layer 3 links configured for services (such as Layer 3 VPNs), you can view the optical links or connections that are configured on optical interfaces of devices such as PTX Series Packet Transport Routers. You can sort and filter the optical links for viewing only the links of interest for your network. You can easily identify the type of links—Layer 3 or optical—by using the Type field on the Links tab displayed on the lower portion of the View Topology page.

Selecting a particular optical link on the Links tab highlights the link with a color-coded connector line in the Topology View. Also, the optical inline amplifiers (optical ILAs) that are installed on the PTX3000 routers are displayed on the topology map when you select an optical link that connects two optical ILAs. The optical ILAs are not plotted on the topology map unless you select an optical link on the Links tab.

To view optical links on a topology map:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Topology View**.

The topology map of the sites or zones and the devices configured in each zone using the CSD-Topology is displayed on the upper portion of the page. A table with details of devices, services, links, and LSPs is displayed on the lower portion of the page.

3. Select the **Links** tab on the lower portion of the page.

The link details are displayed in a table.

4. Select the check box next to the link for which the value in the Type column is displayed as Optical.

The selected optical link is displayed as a color-coded line on the topology map. Also, the optical ILAs on PTX3000 routers that are present on either sides of the selected optical links are displayed on the topology map.

5. (Optional) Mouse over an optical ILA and click **View Details** from the pop-up menu to open a pop-up dialog box that displays detailed information about the optical ILA.

6. (Optional) Mouse over an optical link and click **View Details** from the pop-up menu to open a pop-up dialog box that displays detailed information about the optical link.

7. (Optional) Click the **Filter** icon at the top right of the topology map, and select the **Show Optical Links** check box from the Links drop-down menu.

Only the optical connections, and any optical ILAs between which the links exist, on the topology map are filtered and displayed in the topology window.

RELATED DOCUMENTATION

[Enabling the Collection of LSP and Service Association Details | 352](#)

[Using Custom Grouping for Devices in a CSD Topology | 352](#)

[Viewing Generated Alarms for Services in the Topology View | 353](#)



Prestaging

Prestaging Devices Overview | **357**

Prestaging: Managing Devices and Device Roles | **384**

Prestaging: Managing IP Addresses | **403**

Device Configuration Prerequisites to Prestaging Examples | **411**

Prestaging Services | **418**

Prestaging Devices Overview

IN THIS CHAPTER

- [Prestaging Devices Process Overview | 358](#)
- [Prestaging Workflow in Connectivity Services Director | 361](#)
- [Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)
- [Discovering and Assigning All N-PE Devices | 366](#)
- [Discovering and Assigning N-PE Devices with Exceptions | 367](#)
- [Prestaging ATM and TDM Pseudowire Devices | 370](#)
- [Discovering and Assigning Provider Role or LSP Role for Devices with Exceptions | 375](#)
- [Discovering and Assigning All Provider or LSP Devices | 377](#)
- [Prestaging Rules | 380](#)

Prestaging Devices Process Overview

After Junos Space has discovered the devices, a two- or three-stage process to prestage devices is performed automatically in the backend by the Connectivity Services Director application. The following events occur in a sequential manner for preparing the devices to be compatible and qualified for configuration of services:

1. Discover roles. In this stage, the Junos Space software searches the database for N-PE devices that have not yet been assigned.

2. Examine the results of the role discovery and make any exceptions to the system recommendations. Specifically, you might:

- Exclude specified devices from N-PE role assignment.

You might need to exclude a device that you know is not a PE device. For example, Provider (P) devices that have loopback addresses pass the rules for N-PE role assignment. For devices that you know are not PE devices, you can edit the configuration out-of-band, and then run role discovery again.

- Select a different loopback address for a device.
- Exclude interfaces from UNI assignment.

3. Confirm the assignments.

When device assignments are confirmed internally by the Connectivity Services Director application, those devices are removed from the list of recommendations. If, initially, you exclude devices from assignment, you can return to the list of recommendations later and make further assignments.

When you add more devices to your network, the role discovery operation runs again. Running role discovery again overwrites any devices remaining in the role discovery results list of recommended assignments, but has no effect on devices with confirmed assignments.

- The Prestage Devices screen shows a device inventory of N-PE routers that Connectivity Services Director has discovered in its database that have not yet been assigned. You can perform the following operations from the Prestage Devices screen:

- Select multiple devices to assign roles—The most common and recommended prestaging workflow is to select all devices in the Assign Roles screen and assign them all. See [“Discovering and Assigning All N-PE Devices” on page 366](#) for step-by-step instructions for assigning all Junos Space recommendations.
- Select a single device to assign a role—You must select a single device to change the the UNI assignments on that device. For step-by-step instructions on changing UNI assignments, see [“Excluding Interfaces from UNI Role Assignments” on page 392](#).

You can also exclude a single device using this screen.

- Exclude specified devices from the N-PE role. See [“Discovering and Assigning N-PE Devices with Exceptions” on page 367](#) for step-by-step instructions.
- The Manage Interface Roles screen is an inventory of UNI-qualified interfaces for a specific discovered device. You can view a separate Manage Interface Roles screen for each discovered N-PE device. You can also exclude multiple interfaces from qualification as UNIs. For step-by-step instructions on excluding interfaces from the list of qualified UNIs, see [“Excluding Interfaces from UNI Role Assignments” on page 392](#).

NOTE: The UNI role is assigned to an interface by a notification from the managed device that is sent to the Connectivity Services Director application, even when you unassign the UNI role from the interface using the Prestage Devices workspace. For example, if you unassign the UNI role on an interface of a managed device, that interface is available for provisioning services on devices, when you attempt to create a service order. For the same interface, if you configure encapsulation on it directly from the device and navigate to the Prestaging workspace in Connectivity Services Director after a few minutes, the interface status indicates that UNI role is configured on it. This behavior occurs because the UNI role is assigned to the interface by a device notification.

NOTE: After a device is prestaged in Connectivity Services Director, the prestaging job is not initiated on the same device again. When a device notification is received by the application, Connectivity Services Director synchronizes the prestaging database on the UI interfaces. If a mismatch is detected in the UNI status of the interface in Connectivity Services Director database and the UNI status of the interface on the device (caused by the application being down or network accessibility problems), the synchronization of the UNI interface might not occur. In such a case, the synchronization operation occurs when a configuration- commit on the device is done the next time. To manually resolve this discrepancy in the UNI status of the interface, you can unassign the UNI role of the interface, which causes prestaging to perform a synchronization.

The E-LAN service needs to be enabled in a network device, to make the static pseudowire functionality active in the device. You can activate the static pseudowire functionality by configuring the network device through the CLI window. You need to enter the CLI configuration mode of a network element and run the command

```
set protocols vpls static-vpls no-tunnel-services
```

```
commit
```

If the device is not configured through CLI, a warning message appears in the application server log, that is the **JBOSS Log**:

<Device name> should be configured with static VPLS no tunnel service rule.

To discover the roles of the various network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

To remove the role of the network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
5. Click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

The device is removed from the list of network elements displayed on the Devices Chart page.

To resynchronize the role of the network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
5. Click **Manage Device Roles** and from the drop-down list, select **Re-sync Role Capability** resynchronize the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, request is submitted to retrieve the latest role of the network element or device.

The role is re-synced with the same device now.

RELATED DOCUMENTATION

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning All N-PE Devices | 366](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

[Prestaging Rules | 380](#)

Prestaging Workflow in Connectivity Services Director

Prestaging of devices using the Connectivity Service Director comprises the process of discovering capabilities of devices in the network. Certain classifications are made, depending on the result of the device prestaging process. Service provisioning is made possible on the device based on the discovered capabilities and classification. The devices that do not confirm to an expected configuration are not made available for selection, when you attempt to provision services. These capability discoveries of devices are prone to errors on certain occasions. A second level of control for the user to classify the device above the prestaging classification is implemented in Connectivity Services Director. This additional level of segregation and selection enables you to choose to override the capabilities discovered by the prestaging workflow. The information discovered by the prestaging workflow serves as a tip for you to modify the device-capability classification accordingly. Design enhancements have been made to automate this process using the automated prestaging mechanism, where the devices are prestaged automatically when concerned events occur on the device, in the Junos Space Platform database, or the deployment of the Connectivity Services Director application. Using this effective and streamlined automated prestaging methodology, the devices are always prestaged with latest configuration when you attempt to configure services on them.

In Connectivity Services Director, the devices are always prestaged services are configured on them to enable the latest configuration to be synchronized between the device and the application. Auto-discovering the devices, based on changes occurring on the device and Junos Space Platform is highly efficient and user-friendly.

Auto-Discovery and Auto Prestaging of Devices

The process of automatically synchronizing device configuration and service capability discovery, based on the configuration setting changes made on the device and using the Junos Space Platform software application, is called device automatic prestaging. The auto prestaging mechanism is triggered based on events occurring on the device and the Junos Space Platform software. Certain events that occur on the devices are identified as conditions for triggering the auto prestaging workflow. The following are some of the events that impact the capability of the device to enable Network Services to function:

- Device addition and deletion using the Junos Space Platform GUI
- Interface status alternating between up and down
- Loopback address change
- Interface addition and deletion
- Service type-related configuration (in scenarios when additional configuration such as BGP or LDP changes are made, which updates the service capability (L2, L3) of the device)
- Management IP address or hostname change
- Changes to the interface family
- Changes in the interface encapsulation type

Parallel Prestaging Jobs

Because auto prestaging is an automated process triggered by the change events from the device and platform, there can be multiple parallel prestaging jobs from a single device and from multiple devices. These jobs update the corresponding device information on completion. Service creation and deployment is not impacted by the prestaging jobs and picks up the available configuration at the given point of time. With the introduction of auto device prestaging feature, the scenario is different because auto-prestaging is mostly per-device, and therefore, it is essential to have parallel prestaging jobs running for different devices.

Auto Prestaging Jobs When a Manual Prestaging Job is Running

Manual prestaging process prestages the entire device inventory and auto assigns device roles to them. Therefore, having a per-device auto prestaging job running in parallel might be redundant for the functionality because the concerned device could most likely be taken care of by the manual prestaging job. However, possibilities arise in which the concerned device is prestaged before the new event and the latest configuration is not synced. To avoid such race condition, the auto prestaging job has to run after the manual job completes. For this sequencing of the types of prestaging jobs, auto prestaging event request is stored in a memory queue against a particular device ID and is run by the scheduler after the manual prestaging job completes.

Manual Prestaging Jobs When an Auto Prestaging Job is Running.

Manual prestaging jobs are queued if there are auto prestaging jobs currently running. The manual prestaging job for a particular device is discarded if an auto prestaging job is already in progress.

Multiple Auto Prestaging Jobs for a Device

In cases where there are multiple events generated for a single device the event are queued for execution, a validation is performed to determine if there are current jobs in execution for the particular device and queue the request in which case. There can only be one prestaging request per device in queue at any point in time.

Scenarios With a Clustered Environment

There are possibilities of race conditions in a clustered Junos Space appliance environment where there can be parallel prestaging jobs queued up for the same type of devices as the jobs because the queue context is local to each instance in the cluster. These scenarios are prevented by using a cluster-level context for the queues is present.

Types of Prestaging

Because of scenarios where the manual and auto prestaging has to be identified specifically, the support for distinguishing both the types needs to be added. Instead of the handling of the auto prestaging and manual prestaging jobs by a single job API in which the job data does not contain any information regarding the nature of the job being manual or auto prestaging, the distinction is achieved by comparing the device ID against null from the database job data and by running two separate jobs, one for manual prestaging and the other for auto prestaging.

Prestaging takes the devices already under Junos Space management and prepares them for service activation. The prestaging process discovers network provider edge (N-PE) devices in the Junos Space database and assigns roles to those devices and their interfaces. In Connectivity Services Director, device discovery and prestaging done automatically whenever a device is added or updated.

RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

Prerequisites for Prestaging Devices in Connectivity Services Director

Before you can perform prestaging on your network devices, each device must meet specific configuration requirements, and must be brought under Junos Space management through device discovery.

The following configuration requirements must be met before beginning the provisioning process. Otherwise, service deployment fails:

- MPLS must run on each N-PE device and on each P device.
- LDP signaling must be established between N-PE devices that participate in the same E-Line (LDP) service.
- MPBGP must run on each N-PE device that participates in a Layer 2 multipoint or Layer 3 full mesh service.
- To run Layer 2, Layer 3, or E-LAN services on an N-PE device, ensure that an autonomous system (AS) number is configured on the device.

Before you can prestage devices, you must perform device discovery to import all Juniper Networks devices on your network that Junos Space can manage. The Connectivity Services Director prestaging workspace works on devices that have already been discovered and imported into the Junos Space database, but have not yet been prestaged.

The E-LAN service needs to be enabled in a network device, to make the static pseudowire functionality active in the device. You can activate the static pseudowire functionality by configuring the network device through the CLI window. You need to enter the CLI configuration mode of a network element and run the command

```
set protocols vpls static-vpls no-tunnel-services
```

```
commit
```

If the device is not configured through CLI, a warning message appears in the application server log, that is the **JBOSS Log**:

<Device name> should be configured with static VPLS no tunnel service rule.

To discover the roles of the various network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

4. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

To remove the role of the network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
5. Click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

The device is removed from the list of network elements displayed on the Devices Chart page.

To resynchronize the role of the network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
5. Click **Manage Device Roles** and from the drop-down list, select **Re-sync Role Capability** to resynchronize the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, request is submitted to retrieve the latest role of the network element or device.

The role is re-synced with the same device now.

RELATED DOCUMENTATION

[Prestaging Workflow in Connectivity Services Director | 361](#)

[Prestaging Devices Process Overview | 358](#)

Discovering and Assigning All N-PE Devices

Prestaging all Connectivity Services Director assignment recommendations is a powerful yet simple way to prepare your devices for provisioning. This procedure provides the prestaging steps that accept all system recommendations. To prestage devices and make exceptions to the system recommendations, see [“Discovering and Assigning N-PE Devices with Exceptions” on page 367](#).

Before discovering and assigning N-PE devices, you must have already run device discovery. See the “Discovering Devices” section in the *Junos Space Network Application Platform User Guide*.

Prestaging has two parts:

1. [Discovering Device Roles | 366](#)
2. [Assigning Device Roles | 367](#)

Discovering Device Roles

To discover the roles of devices found during element discovery:

To discover the roles of the various network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. View the values displayed under the Roles column of the discovered devices.
5. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

NOTE: You cannot discover a device as a PE device if no user-to-network interfaces (UNIs) are available in the device.

The Connectivity Services Director application throws the following error message:

```
2012-06-08 10:17:23,446 ERROR [PreStageDeviceManagerBean]
(PreStageDeviceManagerBean#savePreStageDeviceList Thread-6894
(group:HornetQ-client-global-threads-1332782448):) No ge/fe/at/t1 interfaces in this PE device:
junos-mx480-space; it can only be used for virtual routers
```

Assigning Device Roles

If you need to exclude devices from role assignment, or you need to exclude interfaces from the list of interfaces that can be used as UNIs, use the procedures documented in [“Discovering and Assigning N-PE Devices with Exceptions” on page 367](#).

To discover the roles of the various network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. View the values displayed under the Roles column of the discovered devices.
5. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

The **Job Management** page shows the progress and status of the role assignment job. See *Viewing Jobs* in the *Junos Space Network Application Platform User Guide* for details.

While the job is ongoing, you cannot make additional assignments from the **Assign Roles** page. The Assign NPE Role action is dimmed to indicate you cannot select it.

RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

[Prestaging Rules | 380](#)

Discovering and Assigning N-PE Devices with Exceptions

Preparing network devices for service activation is usually a simple process which directs the Connectivity Services Director application to prepare your devices automatically. When you prestage devices, the Connectivity Services Director application scans the database for devices that have already been discovered but have no MPLS role assigned, and recommends a role for each device it finds, based on the device

configuration data and a set of predefined rules. You can then display those devices and their recommended settings for:

- MPLS role for the device (PE only)
- Loopback interface
- UNI interfaces

The Connectivity Services Director application allows you to exclude specific recommended devices from being assigned the N-PE role and to exclude interfaces from use as UNIs during service provisioning. You can also change the loopback address of a PE device..

For step-by-step instructions on how to prepare devices for network activation using all the recommendations for N-PE role assignment and UNI assignment that the Connectivity Services Director application makes, see [“Discovering and Assigning All N-PE Devices” on page 366](#). These topics describe how to prestage devices with exceptions:

- [Including Interfaces in UNI Role Assignments | 368](#)
- [Committing Your Prestaging Choices | 369](#)

Including Interfaces in UNI Role Assignments

To include interfaces from the list of interfaces that the prestaging rules determined were suitable for use as UNIs:

1. Click the Junos Space icon in the Connectivity Services Director banner from the Connectivity Services Director GUI. The Junos Space Network Management Platform page is displayed.
2. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices > Manage Device Roles**.

The results of the most recent role discovery operation appear, including any changes you have subsequently made to your prestaging data.

Repeat Step 2 through Step 7 for each device for which you want to include some recommended UNI selections:

3. In the **Devices Chart** page, select the device for which you want to manage UNIs.
4. Select a device and click **Manage Interface Roles**.

The **Manage Interface Roles** window shows all the device interfaces for the selected device and indicates those that the Connectivity Services Director application recommends for use as UNIs.

5. In the **Manage Interface Roles** window, select the check box under the UNI column that you want to assign to the device.

To assign more than one UNI, use the multiple selection capability.

6. Click **OK** to submit the selection and return to the Devices Chart page.

SEE ALSO

| [Excluding Devices from N-PE Role Assignment](#) | 391

Committing Your Prestaging Choices

This procedure provides instructions for assigning the N-PE role to selected devices and committing all device prestaging information to the database.

Before performing these steps, you must complete the following tasks:

- Discover devices that have not yet been assigned an MPLS role.
- Exclude from the list of discovered devices those devices that you do not want to assign the N-PE role to.
- On each device, exclude the interfaces you do not want used as UNIs.

To commit your prestaging choices to the database:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Manage Device Roles > Assign Roles**.
4. Examine the list of devices to be sure these are the devices you want to assign the N-PE role.
5. Select all devices.
6. Click **Manage Device Roles** and select **Discover Roles**. A job is submitted to obtain the roles of the devices.
7. To view the assignment status, in the Job Management screen, click the job ID of the assignment job.

The **Job Management** page shows the progress and status of the role assignment job.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

While the job is ongoing, you cannot make additional assignments from the **Assign Roles** page. The Assign NPE Role action is dimmed to indicate you cannot select it.

NOTE: If you modify the configuration of a device after the device is prestaged, remove the device from prestaged status and then Discover Roles and prestage the device again.

RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning All N-PE Devices | 366](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

[Prestaging Rules | 380](#)

Prestaging ATM and TDM Pseudowire Devices

Junos Space supports ATM and TDM pseudowires in IP/MPLS networks on M Series Multiservice Edge Routers with Circuit Emulation Service (CES) Physical Interface Cards (PICs). The ATM and TDM pseudowires run over an LSP connection.

Static pseudowires are designed for networks that do not support LDP or do not have LDP enabled. You define pseudowires by configuring static values for the inbound and outbound labels of the connection. For details on configuring pseudowire connections in Junos OS, see the [Junos OS VPNs Configuration Guide](#), the [Layer 2 VPN Configuration Example](#), and [Configuring Layer 2 Circuit and Layer 2 VPN Pseudowires](#).

Prerequisites for M Series Routers

One of the following CES PICs is required:

- 4-Port ChOC3/STM1 CES PIC
- 12-Port T1/E1 CES PIC

Prerequisites for the BX Series Gateway

The BX Series devices have a fixed configuration with 3 Gigabit Ethernet (GE) interfaces and 16 T1/E1 ports that can be used by ATM/TDM pseudowire services. The correct level of firmware is required. Refer to the release notes that correspond to the release of Junos Space that you are running for the correct level information.

RFCs Supported

RFC 4553, *Structure-Agnostic Time Division Multiplexing (TDM) over Packet (SAToP)*

Before discovering and assigning N-PE devices, you must have already have run device discovery. See the “Discovering Devices” section in the *Junos Space Network Application Platform User Guide*.

When you run the discovery process for ATM and TDM devices, they need to be discovered as N-PE devices. In addition, the BX Series devices require an additional device role defined as a cell site router (CSR). This figure shows the discovered devices.

Name	Physic...	Logical...	OS Ver...	Device...	Platform	Schem...	IP Add...	Connec...	Manag...	AIS In...
access-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
access-hd-bgm	View	View	3.0.0	tcaos	C-2030	3.0.0	10.216...	up	Out Of Sync	---
access1-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
access2-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
access3-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
access4-bt750	View	View	3.0.0	tcaos	B-6010	3.0.0	10.216...	up	Out Of Sync	---
access5-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
access6-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
access7-bt750	View	View	3.0.0	tcaos	B-7510	3.0.0	10.216...	up	Out Of Sync	---
junos-m10-1-space	View	View	12.2R1.8	junos	M10I	12.1R3.5	10.216...	up	In Sync	---
junos-m10-2-space	View	View	12.2R1.8	junos	M10I	12.1R3.5	10.216...	up	In Sync	---

After you discover the devices, use Connectivity Services Director Prestaging feature to bring the PE and CSR devices into Network Services together with their UNI interfaces. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Manage Device Roles**.

Prestage Devices > Manage Device Roles

0 Items Selected Actions


Name	Management Address	Loopback Address
<input type="checkbox"/> vjx-junos-mx80-2-space	10.213.52.119	40.1.255.9
<input type="checkbox"/> vjx-junos-mx80-1-space	10.213.53.57	40.1.255.1
<input type="checkbox"/> vjx-junos-mx480-space	10.213.50.234	40.1.255.3
<input type="checkbox"/> vjx-junos-mx240-space	10.213.51.206	40.1.255.8
<input type="checkbox"/> vjx-junos-m10-2-space	10.213.51.130	40.1.255.4
<input type="checkbox"/> vjx-junos-m10-1-space	10.213.53.151	40.1.255.10
<input type="checkbox"/> vjx-embassy-mx80-space	10.213.51.177	40.1.255.7
<input type="checkbox"/> vjx-acx4-space	10.213.52.148	40.1.255.2
<input type="checkbox"/> vjx-acx3-space	10.213.53.203	40.1.255.11
<input type="checkbox"/> vjx-acx2-space	10.213.53.68	40.1.255.6
<input type="checkbox"/> vjx-acx1-space	10.213.50.227	40.1.255.5
<input type="checkbox"/> junos-space5	10.216.114.123	30.1.2.11
<input type="checkbox"/> junos-space3	10.216.114.121	30.1.2.9
<input type="checkbox"/> junos-space2	10.216.114.120	30.1.2.8
<input type="checkbox"/> junos-space1	10.216.114.119	30.1.2.7
<input type="checkbox"/> junos-mx80-2-space	10.216.114.105	30.1.2.3
<input type="checkbox"/> junos-mx80-1-space	10.216.114.104	30.1.2.5
<input type="checkbox"/> junos-mx480-space	10.216.114.100	30.1.2.6
<input type="checkbox"/> junos-mx240-space	10.216.114.101	30.1.2.1

Page 1 of 1 | Displaying 1 - 21 of 21 | Show 30 items

Double-click a listed device. In this example; you can see that an MPLS role and an additional device role as a CSR are assigned.



Double-click another listed device. In this example, the details window shows the channelized ATM and T1 interfaces.



RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning All N-PE Devices | 366](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

Discovering and Assigning Provider Role or LSP Role for Devices with Exceptions

Preparing network devices for service activation is usually a simple process which directs the Connectivity Services Director application to prepare your devices automatically. When you prestage devices, the Connectivity Services Director application scans the database for devices that have already been discovered but have no MPLS role assigned, and recommends a role for each device it finds, based on the device configuration data and a set of predefined rules. You can then display those devices and their recommended settings for:

- MPLS role for the device (PE only)
- Loopback interface
- UNI interfaces

The Connectivity Services Director application allows you to exclude specific recommended devices from being assigned the P or LSP role and to exclude interfaces from use as UNIs during service provisioning. You can also change the loopback address of an LSP device..

For step-by-step instructions on how to prepare devices for network activation using all the recommendations for P or LSP role assignment and UNI assignment that the Connectivity Services Director application makes, see [“Discovering and Assigning All N-PE Devices” on page 366](#). These topics describe how to prestage devices with exceptions:

- [Including Interfaces in UNI Role Assignments | 375](#)
- [Committing Your Prestaging Choices | 376](#)

Including Interfaces in UNI Role Assignments

To include interfaces from the list of interfaces that the prestaging rules determined were suitable for use as UNIs:

1. Click the Junos Space icon in the Connectivity Services Director banner from the Connectivity Services Director GUI. The Junos Space Network Management Platform page is displayed.
2. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices > Manage Device Roles**.

The results of the most recent role discovery operation appear, including any changes you have subsequently made to your prestaging data.

Repeat Step 2 through Step 7 for each device for which you want to include some recommended UNI selections:

3. Select a device and click **Manage Interface Roles**.

The **Manage Interface Roles** window shows all the device interfaces for the selected device and indicates those that the Connectivity Services Director application recommends for use as UNIs.

4. In the **Manage Interface Roles** window, select the check box under the UNI column that you want to assign to the device.

To assign more than one UNI, use the multiple selection capability.

5. Click **OK** to submit the selection and return to the Devices Chart page.

SEE ALSO

| [Excluding Devices from N-PE Role Assignment](#) | 391

Committing Your Prestaging Choices

This procedure provides instructions for assigning the P or LSP role to selected devices and committing all device prestaging information to the database.

Before performing these steps, you must complete the following tasks:

- Discover devices that have not yet been assigned an MPLS role.
- Exclude from the list of discovered devices those devices that you do not want to assign the P or LSP role to.
- On each device, exclude the interfaces you do not want used as UNIs.

To commit your prestaging choices to the database:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Manage Device Roles > Assign Roles**.
4. Examine the list of devices to be sure these are the devices you want to assign the P or LSP role.
5. Select all devices.

6. Click **Manage Device Roles** and select **Discover Roles**. A job is submitted to obtain the roles of the devices.
7. To view the assignment status, in the Job Management screen, click the job ID of the assignment job.

The **Job Management** page shows the progress and status of the role assignment job.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

While the job is ongoing, you cannot make additional assignments from the **Assign Roles** page. The Assign NPE Role action is dimmed to indicate you cannot select it.

NOTE: If you modify the configuration of a device after the device is prestaged, remove the device from prestaged status and then Discover Roles and prestage the device again.

RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning All N-PE Devices | 366](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

[Prestaging Rules | 380](#)

Discovering and Assigning All Provider or LSP Devices

Prestaging all Connectivity Services Director assignment recommendations is a powerful yet simple way to prepare your tunneling or label-switched path (LSP) devices for provisioning. This procedure provides the prestaging steps that accept all system recommendations. To prestage LSP or tunneling devices and make exceptions to the system recommendations, see [“Discovering and Assigning Provider Role or LSP Role for Devices with Exceptions” on page 375](#).

Before discovering and assigning provider (P) or LSP devices, you must have already run device discovery. See the “Discovering Devices” section in the *Junos Space Network Application Platform User Guide*.

Prestaging has two parts:

1. [Discovering LSP Device Roles | 378](#)
2. [Assigning Provider Device Roles | 378](#)

Discovering LSP Device Roles

To discover the roles of LSP devices found during element discovery:

To discover the roles of the various network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. View the values displayed under the Roles column of the discovered devices.
5. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

NOTE: You cannot discover a device as a PE device if no user-to-network interfaces (UNIs) are available in the device.

The Connectivity Services Director application throws the following error message:

```
2012-06-08 10:17:23,446 ERROR [PreStageDeviceManagerBean]
(PreStageDeviceManagerBean#savePreStageDeviceList Thread-6894
(group:HornetQ-client-global-threads-1332782448):) No ge/fe/at/t1 interfaces in this PE device:
junos-mx480-space; it can only be used for virtual routers
```

Assigning Provider Device Roles

If you need to exclude devices from role assignment, or you need to exclude interfaces from the list of interfaces that can be used as UNIs, use the procedures documented in [“Discovering and Assigning Provider Role or LSP Role for Devices with Exceptions” on page 375](#).

To discover the roles of the various network elements configured:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. View the values displayed under the Roles column of the discovered devices.
5. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

The **Job Management** page shows the progress and status of the role assignment job. See *Viewing Jobs* in the *Junos Space Network Application Platform User Guide* for details.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

While the job is ongoing, you cannot make additional assignments from the **Assign Roles** page. The Assign LSP Role action is dimmed to indicate you cannot select it.

RELATED DOCUMENTATION

[Prestaging Devices Process Overview | 358](#)

[Prerequisites for Prestaging Devices in Connectivity Services Director | 364](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

[Prestaging ATM and TDM Pseudowire Devices | 370](#)

[Prestaging Rules | 380](#)

Prestaging Rules

Prestaging rules are predefined. These rules contain criteria for classifying the MPLS role of each device, in addition to recommending which physical interfaces should be UNI interfaces. For each recommended UNI interface, the system recommends its primary loopback address and its VLAN pool profile.

Correctly assigning MPLS roles to devices is critical for provisioning the correct MPLS behavior. Each MPLS role has a different behavior. For example, N-PE is the only role allowed to terminate MPLS sessions..

The rules used by the Junos Space software to determine the recommended role assignment are described for devices, UNIs, and VLAN pool profiles in the following sections:

N-PE Device Classification Rules

The system recommends the N-PE role for devices that satisfy the following criteria:

- The comment field in the device configuration identifies the device as an N-PE device.
- The device role is set to N-PE unless EBGp is enabled for the device. Specifically, the device role is set to N-PE unless the device configuration has **configuration/protocols/bgp/group/type** set to external. If EBGp is enabled, the device role is set to P.
- The device is assigned a loopback address. A device that has no loopback address cannot function as an N-PE device.
- LDP is enabled on the loopback interface for the device. LDP must be enabled on the loopback interface if the device is to be assigned the PE MPLS role. (Required E-Line services).
- L2 VPN signaling for BGP is enabled. Specifically, the rule checks whether the device configuration has **configuration/protocols/bgp/family/l2vpn/signaling** or **configuration/protocols/bgp/group/l2vpn/signaling** set. (Required for Layer 2 Ethernet services.)
- inet-vpn unicast for BGP is enabled. Specifically, the rule checks whether the device configuration has **configuration/protocols/bgp/family/inet-vpn/unicast** set. (Required for IP services.)

UNI Classification Rules

Before an interface on an N-PE device can be provisioned as a UNI, it must satisfy the following criteria:

- The interface must be Gigabit Ethernet (ge), 10-Gigabit Ethernet (xe), Aggregated Ethernet (ae), or Fast Ethernet (fe) type.

Fast Ethernet (fe) interfaces are supported for the Ethernet service configurations (on M Series devices with Junos OS Release 10.2R1.6).

- Checks for Gigabit Ethernet (ge) interfaces within an Aggregated Ethernet (ae) interface. Excludes Gigabit Ethernet interfaces that are configured within an Aggregated Ethernet interface from UNI assignment.

- Checks for bridge family on logical interfaces. Excludes interfaces from UNI assignment if interface configuration on the device has **/interface/unit/family/bridge** set.
- Checks for the following configurations on a device interface. An interface is excluded from UNI assignment when *all* of the following configurations are present and the logical interface is Unit 0:
 - An IP address is defined on the physical interface. The interface configuration on the device has **interface/unit/name/./family/inet/address/name** set. For example:

```

interfaces {
  ge-0/1/0 {
    unit 0 {
      family inet {
        address 10.10.30.52;
      }
    }
  }
}

```

- MPLS is enabled on the physical port. The interface configuration on the device has **interface/unit/name/./family/mpls** set. For example:

```

interfaces {
  ge-0/1/0 {
    unit 0 {
      family mpls;
    }
  }
}

```

- OSPF is running on the logical interface. The interface configuration on the device has **configuration/protocols/ospf/area/interface** set. For example:

```

interfaces {
  ge-5/0/0 {
    unit 0 {
      family inet {
        address 10.10.34/30;
      }
      family mpls;
    }
  }
}

```

```

protocols {
  ospf {
    traffic-engineering;
    area 0.0.0.0. {
      interface ge-5/0/0.0;
    }
  }
}

```

- MPLS is running on the physical interface. The interface configuration on the device has **configuration/protocols/mpls/interface** set. For example:

```

interfaces {
  ge-5/0/0 {
    unit 0 {
      family inet {
        address 10.10.34/30;
      }
      family mpls;
    }
  }
}
protocols {
  mpls {
    interface ge-5/0/0.0;
  }
}

```

VLAN Pool Profile Classification Rules

The Junos Space software assigns VLAN pool ranges to the UNIs, depending on the configured encapsulation.

Auto Discovery Only

The Junos Space software enables the router to process only the autodiscovery network layer reachability information (NLRI) update messages for LDP-based VPLS update messages.

RELATED DOCUMENTATION

Deleting UNIs 388
Discovering Device Roles 390
Excluding Devices from N-PE Role Assignment 391
Excluding Interfaces from UNI Role Assignments 392
Unassigning N-PE Devices 393
Viewing N-PE Devices 394
Viewing Prestaging Statistics 395
Viewing Prestaging Rules 397

Prestaging: Managing Devices and Device Roles

IN THIS CHAPTER

- [Discovering Tunnel Devices | 384](#)
- [Adding a UNI | 386](#)
- [Unassigning Device Roles | 387](#)
- [Deleting UNIs | 388](#)
- [Discovering Device Roles | 390](#)
- [Excluding Devices from N-PE Role Assignment | 391](#)
- [Excluding Interfaces from UNI Role Assignments | 392](#)
- [Unassigning N-PE Devices | 393](#)
- [Viewing N-PE Devices | 394](#)
- [Viewing Prestaging Statistics | 395](#)
- [Viewing Prestaging Rules | 397](#)
- [Managing Prestage Device Jobs | 398](#)
- [Specifying the Wait and Idle Times for Prestaging Devices | 401](#)

Discovering Tunnel Devices

When you start Connectivity Services Director for the first time, the system does not have any devices. The first step is to build your network. Even with large networks, Connectivity Services Director has made this step relatively easy and straightforward. You will add devices to Connectivity Services Director and the database by using a process called *device discovery*. Once a device is discovered, it shows in the interface and Connectivity Services Director begins to monitor the device.

Connectivity Services Director provides a wizard for device discovery. The following example shows the path for device discovery through the wizard. For an alternate path, you can get a step-by-step instruction from the help system.

Before you discover tunneling devices:

- Ensure that the devices that you want to discover are configured for MPLS with the required interface in the Junos OS configuration hierarchy [edit protocols mpls]. See the *Junos Software MPLS Configuration Guide*.

In this example, we provide an IP address range, and Connectivity Services Director populates the database with all supported devices within that range.

1. While in the **Build** mode, select **Device View** or **Custom Group View** from the View selector.
2. To discover physical devices, click **Discover Devices** in the Tasks pane. Each mode has a Tasks Pane that displays the actions you can take while in that mode and that particular network view.
3. (Optional) Type a name for the discovery job. The default name is ND Discovery.
4. Click **Add** in the Device Targets window. You can add a single device IP address, a range of IP addresses, an IP subnet, or a hostname. In this example, we select an IP address range.
5. Provide the initial or the lowest IP address value and the ending or highest IP address value for the range and click **Add**. You can have up to 1024 devices in a range. After you click Add, the address range is listed in the Device Targets window.
6. Click **Next** or click **Discovery Options** to proceed to specify the device credentials and method of discovery.
7. Click **Add** in the Device Credentials window and enter the username and password assigned for administrative access.
8. Select **Ping**, **SNMP**, or both as the method of device discovery. Selecting both is the preferred method if the device is configured for SNMP.

If you select SNMP, the Add SNMP Settings dialog box is displayed. In this example, because we run SNMP version 2, we need to provide the community string. Click **Add** to save the setting.

NOTE: You cannot choose a method for device discovery for virtual network discovery.

9. Click **Next** or **Schedule Options** to proceed to schedule the time when discovery is run.

NOTE: Scheduling options are not available for virtual network discovery.

10. Indicate whether to run the device discovery now or set up a schedule to minimize network traffic. In this example, we set the schedule to run during off hours.
11. Click **Review** to review the settings before you exit the wizard.
12. Click **Finish** to complete the discovery setup and to save the settings.
13. Click **View Discovery Status** to view all scheduled and completed jobs. After a job completes, you can click **Show Details** to view further information on any unexpected results.

RELATED DOCUMENTATION

[Viewing LSP Service Orders in a Table | 1813](#)

[Deactivating an LSP Service | 1814](#)

[Reactivating an LSP Service | 1816](#)

Adding a UNI

To add a UNI to the list of UNIs that can be assigned to a service on a specific device:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.
5. Click **Manage Interface Roles** to assign UNI interfaces to the specified device.
6. The **Manage Interface Roles** window appears, displaying all interfaces on the device that have not been assigned.

7. Select the check box under the UNI column to specify the interface you want to make available for assignment as a UNI. To select multiple interfaces, use the multiple selection feature.
8. Click **OK** to submit the configuration changes. You are returned to the Devices Chart page.

RELATED DOCUMENTATION

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Unassigning Device Roles

If you need to exclude devices from role assignment, or you need to exclude interfaces from the list of interfaces that can be used as UNIs, use the procedures documented in [“Discovering and Assigning N-PE Devices with Exceptions” on page 367](#).

To unassign all discovered roles and interfaces:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.

5. Click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

The device is removed from the list of network elements displayed on the Devices Chart page.

6. To view the assignment status, in the **Job Management** window from the Junos Space Platform UI, click the job ID of the assignment job.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Deleting UNIs

After performing the initial assignment of N-PE devices and UNIs, you can still exclude additional interfaces from the list of UNIs so long as those UNIs are not assigned to services.

To remove an interface from consideration as a UNI:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.
5. Click **Manage Interface Roles**.

The **Manage Interface Roles** window appears, showing all interfaces assigned the UNI role.

6. Select the interface you no longer want to have the UNI role. To unassign multiple interfaces, use the multiple selection feature.

NOTE: The UNI role is assigned to an interface by a notification from the managed device that is sent to the Connectivity Services Director application, even when you unassign the UNI role from the interface using the Prestage Devices workspace. For example, if you unassign the UNI role on an interface of a managed device, that interface is available for provisioning services on devices, when you attempt to create a service order. For the same interface, if you configure encapsulation on it directly from the device and navigate to the Prestaging workspace in Connectivity Services Director after a few minutes, the interface status indicates that UNI role is configured on it. This behavior occurs because the UNI role is assigned to the interface by a device notification.

7. Click **OK** to submit the selection. You are returned to the Devices Chart page.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Discovering Device Roles

To discover the roles of devices found during element discovery:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.
5. Click **Manage Device Roles** and from the drop-down list, select **Discover Role** to retrieve the role capability of a network element. A job is created to obtain the latest role of the network element or device.

Device role discovery is now complete. To assign device and interface roles, follow the steps in the next section, "[Discovering and Assigning All N-PE Devices](#)" on page 366.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Excluding Devices from N-PE Role Assignment

The rules-driven process that the Connectivity Services Director application uses to discover device roles recommends the correct roles in most cases. To exclude a device from N-PE role assignment:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.
5. Click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

The device is removed from the list of network elements displayed on the Device Statistics page.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Excluding Interfaces from UNI Role Assignments

To exclude interfaces from the list of interfaces that the prestaging rules determined were suitable for use as UNIs:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.
5. Click **Manage Interface Roles**.

The **Manage Interface Roles** window appears, showing all interfaces assigned the UNI role.

6. Deselect the check box under the UNI Role column for the interface you no longer want to have the UNI role. To unassign multiple interfaces, use the multiple selection feature.
7. Click **OK** to submit the selection. You are returned to the Device Statistics page.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Unassigning N-PE Devices

To unassign an N-PE device so that it can no longer be assigned to a service:

NOTE: Before you can unassign an N-PE device, it must not be assigned to any deployed service.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.
4. In the **Devices Chart** window, select the device on which you want to add an interface to the list of potential UNIs.
5. Click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

The device is removed from the list of network elements displayed on the Devices Chart page.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Viewing N-PE Devices | 394](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Viewing N-PE Devices

You can view network devices that have been assigned the N-PE role or provider (P) role.

The following topic provides a procedure for viewing N-PE devices:

- [Viewing N-PE Devices in a Table | 394](#)

Viewing N-PE Devices in a Table

To view N-PE devices in a table:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

The **Devices Chart** page displays the following information about all N-PE devices on your network:

- Name—The assigned device name.
 - Roles—The role assigned to the device.
 - Management address—The IP address to which the Junos Space fabric connects to the device.
 - Loopback address—The IP address type used by a device to send a packet to itself.
4. To view more device details and UNI information, double-click the table row for the device. Alternatively, select a service, and click **Device Details** at the top of the table. The **NPE Details** window appears. The detailed view lists all UNIs discovered on the device with the applied VLAN pool profile and includes the following device information:
 - Name—The name assigned to the device
 - Version—Operating system firmware version running on the device. For example, 13.1X49D29.1.
 - Platform—Device model number or the platform type of the discovered device. For example, MX480.
 -
 - Loopback address—The IP address type used by a device to send a packet to itself.
 - Connection status—up or down.
 - Service capability—N-PE device role: L2 or L3.

The following tabs are displayed:

- **UNI**—All assigned user-to-network interfaces (UNIs) on the device with the applied VLAN pool profile. “0” in the Encapsulation field means that no encapsulation has been applied and the UNI is available for allocation.
- **NNI**—All the assigned network-to-network interfaces (NNIs) on the device. Also, the encapsulation types defined for the NNI interfaces are shown.
- **Admin Groups**—Names of the administrative groups configured for the interfaces on the device. Administrative groups, also known as link coloring or resource class, are manually assigned attributes that describe the “color” of links, such that links with the same color conceptually belong to the same class. You can use administrative groups to implement a variety of policy-based LSP setups. Administrative groups are meaningful only when constrained-path LSP computation is enabled.
- **Path**—The path name, IP address, and type are shown.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing Prestaging Statistics | 395](#)

[Viewing Prestaging Rules | 397](#)

Viewing Prestaging Statistics

The landing page for the Prestage Devices workspace contains charts and graphs that provide information about available capacity on discovered N-PE devices. You can determine which devices have UNIs available, or which devices have plenty of available capacity for routing services.

The following topics describe viewing statistics in the Prestage Devices workspace landing page:

- [Viewing the Prestaged Device Details | 396](#)
- [Viewing Services for Devices and Device Roles in a Graphical Form | 396](#)

Viewing the Prestaged Device Details

To view the details of the prestaged devices:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

The **Prestage Devices** page in the lower part of the right pane displays the following information about all N-PE devices on your network:

- Name—The assigned device name.
 - Roles—The role assigned to the device.
 - Service Capability—Indicates whether the device is capable of supporting Layer 2, Layer 3, or MPLS services.
 - Management address—The IP address to which the Junos Space fabric connects to the device.
 - Loopback address—The IP address type used by a device to send a packet to itself.
4. Enter a criterion in the Search box and press Enter to sort and filter the devices that match the search condition.

Viewing Services for Devices and Device Roles in a Graphical Form

To view the number of services provisioned on each N-PE device and the number of devices with different roles in your network:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

The **Device Statistics** page in the upper part of the right pane displays two pie charts. One of the pie charts represents the different types of services configured on devices in your network. You can remove or restore a category (segment) from the pie chart by clicking that segment in the chart. A color-code is used to denote different portions of the pie chart for the service types. Mouse over each portion of the pie to view the number of services corresponding to the percentage of each service type. The

color-coding legends reference the service types, such as E-LINE Martini, E-LINE Kompella, IP, E-LAN, and E-Line services.

The other pie chart displays the roles of devices, such as network provider edge (N-PE) and provider (P) roles. A color-code is used to denote different portions of the pie chart for the device roles. Mouse over each portion of the pie to view the number of devices corresponding to the percentage of each device role. The color-coding legends reference the device roles, such as N-PE or P.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

Viewing Prestaging Rules

Prestaging rules contain criteria for classifying the MPLS role of each device and recommending which physical interfaces should be UNI interfaces. For each recommended UNI interface, the system recommends its primary loopback address.

These prestaging rules are predefined and cannot be configured. They are neither selectable nor configurable. However, you can modify the results of the rules before committing the recommended assignments to the database.

The following topic shows how to view prestaging rules. You can view a summary of all prestaging rules, see a summary, or view details of a specific prestaging rule.

- [Viewing Prestaging Rules in a Table | 397](#)

Viewing Prestaging Rules in a Table

To view prestaging rules in a tabular format:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Rules**.

The **Rules** window appears.

The **Rules** window lists all the prestaging rules by type, along with the name and a brief description of each rule.

- Name—The name of the prestaging rule.
- Rule Type—The category of the rule, such as an NNI rule or a UNI rule.
- Description—Textual description that illustrates the purpose and functionality of the rule.
- Loopback address—The IP address type used by a device to send a packet to itself.

RELATED DOCUMENTATION

[Adding a UNI | 386](#)

[Unassigning Device Roles | 387](#)

[Deleting UNIs | 388](#)

[Discovering Device Roles | 390](#)

[Excluding Devices from N-PE Role Assignment | 391](#)

[Excluding Interfaces from UNI Role Assignments | 392](#)

[Unassigning N-PE Devices | 393](#)

[Viewing N-PE Devices | 394](#)

Managing Prestage Device Jobs

Connectivity Services Director enables you to view and manage device prestaging jobs. You can view the status of completed prestaging jobs and cancel the prestaging jobs that are scheduled to execute at a later time or jobs that are in progress.

After Junos Space has discovered the devices, a two- or three-stage process to prestage devices is performed automatically in the backend by the Connectivity Services Director application. Prestaging is the process of preparing the devices to be compatible and qualified for configuration of services, by discovering the

roles of devices and assigning network-provider edge (N-PE) roles as necessary. Because auto prestaging is an automated process triggered by the change events from the device and platform, there can be multiple parallel prestaging jobs from a single device and from multiple devices. These jobs update the corresponding device information on completion.

Manual prestaging process prestages the entire device inventory and automatically assign device roles to them. Therefore, having a per-device auto prestaging job running in parallel might be redundant for the functionality because the concerned device could most likely be taken care by the manual prestaging job.

The Prestage Device Jobs page shows the progress and status of the role assignment job. Although you can view details about the status of all the jobs initiated in the Connectivity Services Director application from the Prestage Device Jobs page accessible as a System task, you can use the Prestage Device Jobs page in Build mode of Service view to obtain a filtered display of only the prestaging jobs for easy analysis and debugging.

To display the Prestage Device Jobs page:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Prestage Devices > View Prestage Jobs**. The **Prestage Device Jobs** window appears.
4. To view the details of a job, select a row and click **Show Details** or double-click a row.
5. To cancel a scheduled job, select a job that is scheduled for a later time or a job that is in progress and click **Cancel**.

The fields in the Prestaging Device Jobs page are described in [Table 60 on page 400](#). To view any hidden column, keep the mouse on any column heading and select the down arrow and then click Columns. Select the check box to display the hidden columns.

NOTE: Details of jobs initiated from Connectivity Services Director will be available only from Connectivity Services Director. These jobs will not be listed in the Prestage Device Jobs pane in Junos Space platform and vice-versa.

Table 60: Prestage Device Jobs Page Fields

Field	Description
Job ID	The unique ID assigned to the job
Name	The name of the job
Percent	The percentage of completion of the job
State	<p>The status of the job:</p> <ul style="list-style-type: none"> • Success—Job completed successfully • Failure—Job failed and was terminated • Job Scheduled—Job is scheduled but has not yet started • In progress—Job is has started, but not completed • Cancelled—Job is cancelled
Job Type	The type of the job
Summary	Summary of the job scheduled and executed with status
Scheduled Start Time	The time when the job is scheduled to start
Actual Start Time	The actual time when the job started
End Time	The time when the job was completed
User	The login ID of the user that initiated the task
Recurrence	The recurrent time when the job will be restarted.

RELATED DOCUMENTATION

[Managing Service Configuration Deployment Jobs | 1080](#)
[Deploying Services Configuration to Devices | 1083](#)

Specifying the Wait and Idle Times for Prestaging Devices

After Junos Space has discovered the devices, a two- or three-stage process to prestage devices is performed automatically in the backend by the Connectivity Services Director application. Prestaging takes the devices already under Junos Space management and prepares them for service activation by assigning roles to those devices and their interfaces..

To specify the wait and idle times to be used for triggering jobs for prestaging devices:

1. From the Junos Space user interface, click the **System** icon on the Connectivity Services Director banner.

The options that you can configure in System mode are displayed in a drop-down menu.

2. Select **Preferences** from the drop-down menu to open the Preferences page.

The Preferences page opens with User Preferences as the default tab.

3. Click the **Services Activation** tab to configure the services activation-related settings.

The settings that you can configure on the Services Activation tab are displayed.

4. Click the right arrow beside the **Prestage Device** section to expand it.

The parameters that you can configure for prestaging devices are displayed.

5. In the **Pre-stage Wait Time (Sec)** field, specify the number of seconds for which the task to trigger a job for prestaging devices must wait after receiving the first notification for prestaging devices. For example, if you specify the prestage wait time as 20 seconds, the prestaging task waits for a period of 20 seconds, after receiving the first notification for prestaging devices, and then initiates the prestaging-devices job.

6. In the **Pre-stage Idle Time (Sec)** field, specify the number of seconds after which the job for prestaging devices is initiated, if no notification is received during the idle period. For example, if you specify the prestage idle time as 10 seconds and if no notification for prestaging devices is received within this period, the job for prestaging devices is triggered immediately after 10 seconds. The prestage idle time value takes precedence over the prestage wait time value.

7. Click **OK** to save the settings. You are prompted to confirm the changes you made to services-activation preferences.

8. Click **Yes** to confirm. The Preferences page is closed. A dialog box is displayed to confirm the successful saving of the preferences. Click **OK** to close the dialog box.

RELATED DOCUMENTATION

Modifying the Application Settings of Connectivity Services Director | **1161**

Prestaging: Managing IP Addresses

IN THIS CHAPTER

- Creating an IP Address Pool | 404
- Managing Resources | 406
- Specifying IPv4 Addressing Assignment in IP Service Definitions | 409

Creating an IP Address Pool

You, the Service Designer, can create consistent IP address pools for Layer 3 VPNs by selecting **Prestage Devices > Resources > Add IP Address Pools** from the Network Services > Connectivity task pane in Build mode of Service View. The IP addresses assigned to each PE/CE link need to allow routing across the customer's entire Layer 3 VPN, as long as the PE/CE addresses are not exposed outside of that VPN. If the PE/CE link addresses are accessible from outside the customer's VPN, then those IP addresses may also need to be globally unique across the internet, instead of just within the customer's VPN.

When you create an IP address pool, it appears in the **Prestage Devices > Resources** inventory page. See ["Creating an IP Address Pool" on page 404](#)

NOTE: Preferably, create all IPv4 address pools at the beginning of the prestaging process (see ["Prestaging Devices Overview" on page 55](#)), before you run Role Discovery (see ["Discovering and Assigning All N-PE Devices" on page 366](#)), so that any IPv4 IP addresses found on devices during the role discovery process can be marked as already allocated in the corresponding IPv4 IP address pools.

To create an IPv4 IP address pool:

1. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Manage Resources**. The Resource Utilization Status page is displayed. The status of various resources such as VLAN, virtual circuit, route target, route distinguisher, and IP address pool are displayed in a tabular format. You can create a customized IP pool based on your network deployment needs.
2. Under the Allocated column, click the link in the displayed number to open the Resource Allocated Details dialog box. If the resource pool is an IP address pool, the IP addresses allocated from the selected resource pool are displayed in a table. Similarly, for other resources such as VLAN or virtual circuit, information regarding the element or device to which the resource is allocated is displayed.
3. Click **Add** at the top of the table of displayed resources. The **Add IP Address Pool** dialog box appears.
4. In the **Pool Type** drop-down list box, select the IP pool type as either **Global** or **Customer**.
 - A **Global** IP address pool pertains to the service provider. There can be more than one global IPv4 address pool. However, each global pool must have its own unique name and its set of IPv4 addresses must not overlap with those of any other global pool. You can allocate addresses from global pools across multiple Layer 3 VPNs across multiple customers.
 - A **Customer** IP address pool pertains to an existing customer. These pools are associated with the corresponding customer. You can associate more than one customer IPv4 pool with each customer. However, each customer pool must have its own set of IPv4 addresses which must not overlap with

those of any other pool belonging to the same customer. You can allocate addresses from customer pools across multiple Layer 3 VPNs for a particular customer.

5. In the **Pool Name** field, enter a unique name.

An IP address pool name can be no more than 50 characters.

6. In the **IP Address Pool** field, enter an IPv4 IP address pool.

Any IPv4 address pool in Junos Space maps directly onto the Classless Interdomain Routing (CIDR) notation for IPv4 network addresses. The CIDR network address, 192.168.1.0/24 is a contiguous block of 256 individual IPv4 addresses: 192.168.1.0/32 through 192.168.1.255/32, inclusive. The network address 10.0.99.20/30 is a contiguous block of 4 individual IPv4 addresses: 10.0.99.20/32 through 10.0.99.23/32, inclusive. As a consequence, any Junos Space IPv4 address pool directly maps to (and is identified by) its CIDR network address. The Junos Space IPv4 address pool, 192.168.1.0/24, contains all of the addresses from 192.168.1.0/32 to 192.168.1.255/32, while the IPv4 address pool, 10.0.99.20/30 contains all of the addresses from 10.0.99.20/32 to 10.0.99.23/32.

7. In the **Subnet (/)** field, enter the destination IP prefix length or the subnet mask. The subnet mask indicates the number of bits used for the network portion of the address (for example, 10.10.20.0/24).
8. If you are creating a **Customer** IP address pool, the **Associate with customer** drop-down list box appears. Select an existing customer name. To create a customer, see [“Adding a New Customer” on page 795](#).
9. Click **Create**.

Junos Space saves the IP address pool information in the database. The IP address pool appears in the **Resources** inventory page. The **Pool Type** column differentiates global from customer IP address pools.

NOTE: You need to create IP address pools only if the operation of your network requires it. Alternatively, you can use the global IP pools provided by the Connectivity Services Director application for IP services.

NOTE: When you delete an IP address pool, you must ensure that such a pool is not being currently utilized or allocated to a managed element. Otherwise, you cannot delete such an allocated IP address pool.

Managing Resources

You can use the Manage Resource page to view existing IP address pools created for global use or for specific customers. Besides the IP address pool information, the status of various other resources such as VLAN IDs, virtual circuit IDs, route distinguisher, and route targets that are created for utilization in services is also displayed. You can also view the details of allocated or utilized resources, such as the VLAN ID allocated to the corresponding interface and the logical unit association with a particular interface on a device. For more information about creating an IPv4 IP address pool, see [“Creating an IP Address Pool” on page 404](#).

Viewing Resources

Starting in Connectivity Services Director Release 2.1R1, you can view and manage a particular pool of resources by selecting an option from the **Pool Type** list. The **Manage Resource** page displays the list of resource pools that can be configured. You can filter the resources displayed on this page by device name, interfaces on the device, and a customer associated with the device.

Viewing Detailed Resources Information

To view and manage detailed information about resources:

1. In the Connectivity Services Director application, select **Service View** from the Views list.
2. From the Tasks pane, select **Prestage Devices > Manage Resource**.
The Manage Resource page is displayed.
3. Fill in the fields in the Manage Resource page as indicated in [Table 61 on page 407](#).

Table 61: Resource Pool Landing Page Details

Detail	Description
Pool Type	<p>Select one of the following options from the list to view and manage a particular pool of resources:</p> <ul style="list-style-type: none"> • Global Pool—to manage pools of IPv4 addresses related to the service provider. • Unit Pool—to manage units for interfaces in a resource pool. • VLAN Pool—to manage pools of IPv4 address for a VLAN. • Customer IP Pool—to manage pools of IPv4 addresses applicable to a particular customer. <p>NOTE: Starting in Connectivity Services Director Release 2.1R1, the Pool Type list is available in the Manage Resource page.</p>
Device Name	<p>Select a device from the list to view resource types specific to interfaces on that device.</p> <p>NOTE: This field is available only if you select Unit Pool or VLAN Pool from the Pool Type list.</p>
Interface Name	<p>Choose an interface of the selected device from the list.</p> <p>NOTE: This field is available only if you select Unit Pool or VLAN Pool from the Pool Type list.</p>
Customer	<p>Click Select to view the list of customers. The Choose Customer window is displayed.</p> <p>To choose a customer, select the check box next to the customer and click OK.</p>
Filter	Click Filter to execute the search.
Add	Click Add to add a new IPv4 address pool.
Delete	Click Delete to delete an existing IPv4 address pool.
Pool Name	This column displays the names of IPv4 address pools.
Description	This column displays the user-defined description of the resource pool.
Allocated	This column displays the number of resources allocated from the pool.

Release History Table

Release	Description
2.1R1	Starting in Connectivity Services Director Release 2.1R1, the Pool Type list is available in the Manage Resource page.

RELATED DOCUMENTATION

Creating an IP Address Pool 404
Specifying IPv4 Addressing Assignment in IP Service Definitions 409

Specifying IPv4 Addressing Assignment in IP Service Definitions

You, the Service Designer, can specify the IPv4 IP address settings to use for PE/CE link when provisioning IP service definitions.

When configuring Layer 3 VPNs, it is necessary to assign consistent IP addresses to the logical interfaces on both sides of each PE/CE link. The IP addresses assigned to each PE/CE link need to allow routing across the customer's entire Layer 3 VPN, and only need to be unique within the confines of the customer's VPN, as long as the PE/CE addresses are not exposed outside of that VPN. If the PE/CE link addresses are accessible from outside of the customer's VPN, then those IP addresses may also need to be globally unique across the Internet, instead of just within the customer's VPN.

The Connectivity Services Director application automatically assigns IPv4 addresses to both sides of each PE/CE link, as well as keeps track of which IPv4 addresses are already in use. It ensures the correct assignment of IP addresses and prevents the reuse of IP addresses.

To specify auto-assigning of the PE/CE link addresses from IPv4 pools, you select the **Auto Pick** option, the **IP pool type**—**global** or **customer**, and the number of contiguous IPv4 addresses—**size of the IPV4 address block** that is allocated for each PE/CE link. Which particular global or customer IPv4 address pool to use is chosen during service provisioning when filling out the IP Service Order.

For auto-assignment scenarios, the service designer can always select the **Allow editing in Service Order** option at the right of each service definition setting to allow the corresponding IPv4 pool setting to be overridden later when filling out the IP Service Order.

To specify manual assignment of PE/CE link addresses, the designer simply selects the manual-assignment option.

To specify IP address settings in an IP service definition:

1. In the **IP Address Settings** area **PE Interface IP Address** check boxes, select one of the following:
 - **Auto Pick**—Specifies whether PE/CE link addresses are automatically assigned from an IPv4 IP address pool.
 - **Select Manually**—Specifies whether the service designer manually assigns PE/CE link addresses from the same IPv4 IP address pool.
2. In the **IP Pool Types** drop-down list box, select one of the following:
 - **Global**—Pools of IPv4 addresses pertaining to the Service Provider. There can be more than one global IPv4 address pool. However, each global pool must have its own unique name and its set of IPv4 addresses must not overlap with those of any other global pool. You can allocate addresses from global pools across multiple Layer 3 VPN across multiple customers.
 - **Customer**—Pools of IPv4 addresses pertaining to a particular customer. These pools are associated with the corresponding customer. There can be more than one customer IPv4 pool associated with each customer. However, each customer pool must have its own set of IPv4 addresses which must

not overlap with those of any other pool belonging to the same customer. Addresses from customer pools can be allocated across multiple Layer 3 VPNs for a particular customer.

3. In the **IP Address Block Size** field, enter the size of the IPv4 IP address block allocated for each PE/CE link.
4. Select the **Editable in service order** check box on the right of each IP address setting to overwrite the corresponding IPv4 IP address pool setting when creating the service order.
5. Click another Layer 3 VPN Settings link to continue specifying settings or click **Finish**.

If you click **Finish**, the custom IP service definition appears on the **Manage Service Definitions** inventory page.

RELATED DOCUMENTATION

[Creating an IP Address Pool | 404](#)

[Managing Resources | 406](#)

Device Configuration Prerequisites to Prestaging Examples

IN THIS CHAPTER

- [Example: Base Configuration for N-PE Device in a Multipoint Service | 411](#)
- [Example: Base Configuration for N-PE Device in an E-Line \(LDP\) Service | 413](#)
- [Example: Base Configuration for a P Router | 415](#)

Example: Base Configuration for N-PE Device in a Multipoint Service

An N-PE device to be used in a multipoint service must have the following entities configured before you assign the N-PE role to the device:

- Gigabit Ethernet interfaces to the network core
- Loopback interface
- Routing options
- MPLS protocol
- BGP protocol
- OSPF protocol
- LDP protocol

The N-PE device in this configuration example has just one interface to the network core. In a more complex network in which the N-PE device connects to more than one P device, you need to configure multiple interfaces.

```
interfaces {
  ge-0/0/0 {
    unit 0 {
      family inet {
        address 10.1.22.2/30;
      }
    }
  }
}
```

```

        }
        family mpls;
    }
}

}

lo0 {
    unit 0 {
        family inet {
            address 192.168.1.30/32;
        }
    }
}

}
routing-options {
    autonomous-system 65410;
}
protocols {
    mpls {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
    bgp {
        group CA-Peer {
            type internal;
            local-address 192.168.1.30;
            family l2vpn {
                signaling;
            }
            neighbor 192.168.1.40;
            neighbor 192.168.1.10;
            neighbor 192.168.1.20;
            neighbor 192.168.1.50;
            neighbor 192.168.1.60;
        }
    }
    ospf {
        traffic-engineering;
        area 0.0.0.0 {
            interface lo0.0 {
                passive;
            }
            interface ge-0/0/0.0;

```

```

    }
    ldp {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
}

```

RELATED DOCUMENTATION

[Example: Base Configuration for N-PE Device in an E-Line \(LDP\) Service | 413](#)

[Example: Base Configuration for a P Router | 415](#)

Example: Base Configuration for N-PE Device in an E-Line (LDP) Service

An N-PE device to be used in an E-Line service must have the following entities configured before you assign the N-PE role to the device:

- Gigabit Ethernet interfaces to the network core
- Loopback interface
- MPLS protocol
- OSPF protocol
- LDP protocol

The N-PE device in this configuration example has just one interface to the network core. In a more complex network in which the N-PE device connects to more than one P device, you need to configure multiple interfaces.

```

interfaces {
    ge-0/0/0 {
        unit 0 {
            family inet {
                address 10.1.18.2/30;
            }
            family mpls;
        }
    }
}

```

```

    }
    lo0 {
        unit 0 {
            family inet {
                address 192.168.1.20/32;
            }
        }
    }
}

protocols {
    mpls {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
    ospf {
        traffic-engineering;
        area 0.0.0.0 {
            interface lo0.0 {
                passive;
            }
            interface ge-0/0/0.0;
        }
    }
    ldp {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
}

```

NOTE: If the N-PE router will also be used in multipoint services, do not use this base configuration. Instead, use the base configuration for multipoint services.

RELATED DOCUMENTATION

[Example: Base Configuration for N-PE Device in a Multipoint Service | 411](#)

[Example: Base Configuration for a P Router | 415](#)


Example: Base Configuration for a P Router

P routers in your MPLS network must have the following entities configured before these devices are prestaged:

- A Gigabit Ethernet interface to each router in the network
- Loopback interface
- MPLS protocol
- OSPF protocol
- LDP protocol

Figure 16 on page 415 shows a simple network with one P router connecting five N-PE routers.

Figure 16: Connectivity in a Simple Network



The following example shows a P router configuration for the simple network shown in Figure 16 on page 415.

```
interfaces {
    ge-0/0/2 {
        unit 0 {
            family inet {
                address 10.1.14.1/30;
            }
            family mpls;
        }
    }
}
```



```

ge-0/0/3 {
  unit 0 {
    family inet {
      address 10.1.15.2/30;
    }
    family mpls;
  }
}
ge-5/0/0 {
  unit 0 {
    family inet {
      address 10.1.17.1/30;
    }
    family mpls;
  }
}
ge-5/0/1 {
  unit 0 {
    family inet {
      address 10.1.18.1/30;
    }
    family mpls;
  }
}
lo0 {
  unit 0 {
    family inet {
      address 192.168.1.1/32;
    }
  }
}

}

}
protocols {
  mpls {
    interface ge-0/0/2.0;
    interface ge-0/0/3.0;
    interface ge-5/0/0.0;
    interface ge-5/0/1.0;
    interface lo0.0;
  }
  ospf {
    traffic-engineering;
  }
}

```

```
    area 0.0.0.0 {  
        interface ge-0/0/2.0;  
        interface ge-0/0/3.0;  
        interface ge-5/0/0.0;  
        interface ge-5/0/1.0;  
        interface lo0.0 {  
            passive;  
        }  
    }  
}  
ldp {  
    interface ge-0/0/2.0;  
    interface ge-0/0/3.0;  
    interface ge-5/0/0.0;  
    interface ge-5/0/1.0;  
}  
}
```

RELATED DOCUMENTATION

[Example: Base Configuration for N-PE Device in a Multipoint Service | 411](#)

[Example: Base Configuration for N-PE Device in an E-Line \(LDP\) Service | 413](#)

Prestaging Services

IN THIS CHAPTER

- [Creating and Handling a Service Recovery Request | 419](#)
- [Selecting a Service Definition in the Wizard for Creating a Service Recovery Request | 421](#)
- [Specifying Devices and Filters in the Wizard for Creating a Service Recovery Request | 423](#)
- [Reviewing the Configured Settings in the Wizard for Creating a Service Recovery Request | 426](#)
- [Viewing Service Recovery Report | 428](#)
- [Performing a Service Recovery on a Defined Service | 429](#)
- [Processing of Device Change Notifications Overview | 431](#)
- [Handling of Out-of-Band Notifications for Service Recovery | 434](#)
- [Viewing Service Recovery Instance Details | 434](#)
- [Managing Out-of-Band Notifications for Recovered Services | 439](#)
- [Viewing Details of an Out-of-Band Notification for Recovered Services | 441](#)
- [Viewing Services Rejected During a Service Recovery | 443](#)
- [Viewing Service Recovery Jobs | 445](#)
- [Performing a Configuration Audit for Recovered Services | 447](#)
- [Viewing Configuration Audit Results of Recovered Services | 449](#)
- [Recovering Modifications and Deletions Performed for Existing Endpoints | 452](#)
- [REST API Changes in Connectivity Services Director for Service Recovery | 457](#)
- [Sample XPath Notifications Received on Devices for Deleted Endpoints | 457](#)
- [Sample XPath Notifications Received on Devices for a Modified E-LAN Service | 461](#)
- [Sample XPath Notifications Received on Devices for a Created E-LAN Service | 467](#)
- [Sample XPath Notifications Received on Devices for a Created IP Service | 471](#)
- [Sample XPath Notifications Received on Devices for a Created E-Line Service | 473](#)
- [Sample XPath Notifications Received on Devices for CFM Profiles Associated with an E-Line Service | 475](#)
- [Sample XPath Notifications Received on Devices for CoS Profiles Associated with an E-Line Service | 477](#)

Creating and Handling a Service Recovery Request

The Service Recovery feature functions within the pre-staging operation of the Network Activate application. Service Recovery has two parts.

First, Service Recovery parses each device's configuration searching for service configurations and existing Network Activate service elements (E-Line services, Layer 2 circuits, routing instances, firewalls, policy options, routing options, and OAM interface branches of Junos Space configurations that are being processed).

Second, Service Recovery stitches the service elements by identifying related service attributes across devices, such as VCIDs for Martini services and route targets for Kompella (L2VPN) services, to form Network Activate services.

NOTE: When you attempt to recover E-LAN and IP services using the Service Recovery feature, you must not select any service templates that are attached with such services for recovery. The basic configuration of services is recovered in such a scenario. This is an expected behavior with performing a service recovery for E-LAN and IP services. For E-Line services, you can recover QoS templates that are attached with such services.

A wizard is available to create a Service Recovery request in an intuitive and easily-navigable format. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create Service Recovery Request page. Alternatively, you can proceed to the corresponding setting-related pages by clicking the Back and Next buttons at any point in the wizard during the creation of the Service Recovery request.

To perform Service Recovery, in the Network Services > Connectivity task pane, select **Service Recovery > Recover Services**. Initially, Service Recovery generates the following Alert message, which describes the process you are about to start and recommends saving previously recovered services.

To create a service recovery request:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. From the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. From the Network Services > Connectivity Tasks pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services.

NOTE: The Latest Recovery Job field at the top of the page displays the job ID and job status in blue hyperlink. Click the hyperlink in the job ID and status to open the Job Details dialog box. The job ID, start and end times of the job, percentage of completion, and status of the job are displayed. Click Close to close the job dialog box.

5. The **Create Service Recovery Request** wizard contains two pages— **Select Service Recovery Options** and **Review**.

In the **Select Service Definition** page of the wizard, you can select one or more service types: E-Line, E-LAN, and IP.

The **Select Service Definition** table on the of the **Select Service Recovery Options** page of the wizard also presents a table that lists the names of all services of the selected **Service Type**.

The **Select Devices** and **Filter Criteria** sections of the **Select Service Recovery Options** page of the wizard displays the devices and filters, with the devices listed in the **Name** column. You can specify a **VCID Range** and **Route target range** to complete the definition of the service recovery profile search.

The following topics describe the different pages of the Create Service Recovery Request wizard:

- [Selecting a Service Definition in the Wizard for Creating a Service Recovery Request on page 421](#)
- [Specifying Devices and Filters in the Wizard for Creating a Service Recovery Request on page 423](#)
- [Reviewing the Configured Settings in the Wizard for Creating a Service Recovery Request on page 426](#)

RELATED DOCUMENTATION

[Viewing Service Recovery Report | 428](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Selecting a Service Definition in the Wizard for Creating a Service Recovery Request

On the first page of the wizard to create a service recovery request, you can select the service type, which causes the page to be populated with the services that match the selected service type. For example, if you want to recover E-Line services, you can select this service type to view the relevant services of this type. You can also select multiple service types, based on your network needs. You can select a service definition for which you want to create a service recovery request.

To select a service type and definition in the service recovery request creation wizard:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. From the Network Services > Connectivity Tasks pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services.

NOTE: The Latest Recovery Job field at the top of the page displays the job ID and job status in blue hyperlink. Click the hyperlink in the job ID and status to open the Job Details dialog box. The job ID, start and end times of the job, percentage of completion, and status of the job are displayed. Click Close to close the job dialog box.

5. Click the **New** icon above the table of listed service names and service definitions.

The Select Service Recovery Options page of the Create Service Recovery Request wizard is displayed.

6. In the Select Service Definition table of the Select Service Recovery Options page, fill in the fields as described in the following table.

Field	Action
Add	<p>Click the Add button to open the Choose Service Definition page. The Choose Service Definition inventory page displays only those published service definitions designed to work with the type of services you need.</p> <p>Select the check boxes beside the types of service definitions for which you want to create a service recovery request. The search utility that is present in the Choose Service Definition dialog box that is displayed when you click Select beside the Service Definition field enables you to search by Name, Created by, and Signaling columns; the search utility is not supported for other columns in the dialog box.</p> <p>Click OK to add the selected definitions to the service recovery request. The dialog box closes and you are returned to the Select Service Definition table that lists the service definitions you selected.</p>
Delete	Select the check boxes beside the service definitions you want to remove from the service recovery request, and click the Delete button to remove the service definitions from the table.
Name	<p>Select the check boxes for the service definitions whose services you want to recover.</p> <p>All the published service definitions based on service type selected are listed.</p>

7. Proceed to [“Specifying Devices and Filters in the Wizard for Creating a Service Recovery Request” on page 423.](#)

RELATED DOCUMENTATION

[Viewing Service Recovery Report | 428](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Specifying Devices and Filters in the Wizard for Creating a Service Recovery Request

After you select a service definition to create a service recovery request, you can specify the devices and filters to associate with the service recovery request. The **Rule Parameters** page of the wizard displays the devices and filters, with the devices listed in the **Name** column. You can specify a **VCID Range** and **RouteTarget Range** to complete the definition of the service recovery profile search.

To specify the rule parameters in the service recovery request creation wizard:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. From the Network Services > Connectivity Tasks pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services.

5. Click the **New** icon above the table of listed service orders and service definitions.

The Select Service Recovery Options page of the Create Service Recovery Request wizard is displayed.

6. In the **Select Devices** and **Filter Criteria** sections of the wizard page, specify the devices and filters for the service recovery operation.

7. Fill in the fields as described in the following table.

Field	Action
Select Devices	
Devices	Select the check boxes beside the devices whose services you want to recover. The hostnames, IP addresses, managed states, OS versions, and roles of the devices are displayed in a table.

Field	Action
Add	<p>Click the Add button to open a dialog box to select the N-PE device you want to associate with the service recovery request. From the Choose Endpoints dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices. The search box that is present in the Choose Endpoints dialog box enables search across all the columns displayed in the dialog box.</p> <p>Click OK to add the devices to the service recovery request. The dialog box closes and you are returned to the Select Devices table that lists the endpoints that you selected.</p>
Delete	<p>Select the check boxes beside the devices you want to remove from the service recovery request, and click the Delete button to remove the devices from the table.</p>
Filter Criteria	
Recover Templates	<p>Select this check box to recover service templates during the service recovery operation for the associated devices.</p>
Recover Deleted EndPoints	<p>Select this check box to recover the deleted endpoints during the service recovery operation.</p>
Recover Modified EndPoints	<p>Select this check box to recover the modified endpoints during the service recovery operation.</p>
VCID Range	<p>This field is displayed if you have selected an E-Line service definition.</p> <p>Specify the VCID range within which services are to be recovered.</p> <p>Range: 1 through 2147483647</p> <p>NOTE: The VCID Range parameter enables you to change the VCID range for services that had been configured previously outside of the context of Junos Space.</p>
Route Target Range	<p>This field is displayed for all the service types.</p> <p>Specify the route target range within which services are to be recovered. You can express the range in Autonomous System number format or IPv4 format:</p> <ul style="list-style-type: none"> AS number format—Autonomous system (AS) number format: <l2vpn-id:as-number:2-byte-number>. For example, 100:200. The AS number can be in the range from 1 through 65,535. IPv4 format—<l2vpn-id:ip-address:2-byte-number>. For example, l2vpn-id:10.1.1.1:2. Make sure that this value is lower than the value specified as the maximum route target allowed. <p>NOTE: The Route target parameter enables you to change the route target range for services that had been configured previously outside of the context of Junos Space.</p>

Field	Action
VPLS ID Range	<p>This field is displayed if you have selected an E-LAN service definition.</p> <p>Specify the VPLS ID range within which the services are to be recovered.</p> <p>Range: 1 through 2147483647</p>
Hub-Route Target Range	<p>This field is displayed if you have you have selected an E-LAN or IP service definition.</p> <p>Specify the Hub-Route target range within which services are to be recovered. You can express the range in Autonomous System number format or IPv4 format:</p> <ul style="list-style-type: none"> AS number format—Autonomous system (AS) number format: <l2vpn-id:as-number:2-byte-number>. For example, 100:200. The AS number can be in the range from 1 through 65,535. IPv4 format—<l2vpn-id:ip-address:2-byte-number>. For example, l2vpn-id:10.1.1.1:2. Make sure that this value is lower than the value specified as the maximum route target allowed.
Spoke-Route Target Range	<p>This field is displayed if you have selected an E-LAN or IP service definition.</p> <p>Specify the Spoke-Route target range within which services are to be recovered. You can express the range in Autonomous System number format or IPv4 format:</p> <ul style="list-style-type: none"> AS number format—Autonomous system (AS) number format: <l2vpn-id:as-number:2-byte-number>. For example, 100:200. The AS number can be in the range from 1 through 65,535. IPv4 format—<l2vpn-id:ip-address:2-byte-number>. For example, l2vpn-id:10.1.1.1:2. Make sure that this value is lower than the value specified as the maximum route target allowed.

8. When you complete defining the Service Recovery Profile, proceed to [“Reviewing the Configured Settings in the Wizard for Creating a Service Recovery Request” on page 426.](#)

Alternatively, click **Done** to trigger the service recovery operation.

The Connectivity Services Director application fetches the latest device configuration. It then processes the device configuration to derive the configuration of selected service types. A message is displayed to denote that the service recovery request is being saved in the database.

NOTE:

- In case of an IP service with pseudowire attached, you have to first recover the IP service, and then the E-Line service.

When the service recovery operation completes, the **Service Recovery Report** window appears. The service recovery report for each service is displayed in different tabs.

RELATED DOCUMENTATION

[Viewing Service Recovery Report | 428](#)[Performing a Service Recovery on a Defined Service | 429](#)

Reviewing the Configured Settings in the Wizard for Creating a Service Recovery Request

The Review page of the service recovery job creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

After you click **Start** on the Review page of the service recovery request creation wizard, the Service Recovery Request job starts. After the job is completed, all the configuration parameters for all the devices are retrieved, but only those configurations that match the filter are processed and are populated in the Service Recovery page. Also, when a service recovery request job starts, the action denotes that only a discovery is initiated of all the possible services that can be recovered from the device. They are not yet stored in the Connectivity Services Director application database. Their status is initially marked as Partial as shown on the Service Recovery page.

To examine the configured service recovery request settings in the service recovery request creation wizard:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. From the Network Services > Connectivity Tasks pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services.

5. Click the **New** icon above the table of listed service definitions.

The Select Service Recovery Options page of the Create Service Recovery Request wizard is displayed.

6. Click the **Review** button at the top of the wizard page to examine the configured settings. Alternatively, click **Next** after you specify the rule parameters.
7. You can examine and modify the created service recovery request parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
8. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
9. Click **Finish** to save the service recovery request.
10. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes. The Service Recovery page appears.
11. When you complete defining the service recovery profile, click **Done** To submit the service recovery request.

The Connectivity Services Director application fetches the latest device configuration. It then processes the device configuration to derive the configuration of selected service types. A message is displayed to denote that the service recovery request is being saved in the database.

NOTE:

- In case of an IP service with pseudowire attached, you have to first recover the IP service, and then the E-Line service.

When the service recovery operation completes, the **Service Recovery Report** window appears. The service recovery report for each service is displayed in different tabs.

RELATED DOCUMENTATION

[Viewing Service Recovery Report | 428](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Viewing Service Recovery Report

When the service recovery operation completes, the **Service Recovery** window appears.

The **Service Recovery** window displays the recovered services according to service type. The service recovery report for all services is displayed in a table.

To view the service recovery report:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > Recover Services**.

The Service Recovery window is displayed.

The following fields are displayed in the window:

Column	Description
Recovered Services —Lists the recovered service instances for the different services.	
Service Name	Name of the recovered service instance.
Service Definition	Name of the service definition attached to a service.
Service Type	One of the following: <ul style="list-style-type: none"> • E-Line • E-LAN • IP
Status	Partial or Recovered
Customer	Customer for which the service is created
Comments	Comments to describe the service.

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Performing a Service Recovery on a Defined Service

You can perform a service recovery operation on a service instance that you have previously configured in the Service Recovery page, instead of running the recovery job during the process of creation of the recovery request. In certain situations, you might require a set of service instances to be defined separately, before you want to run the recovery task on all such services. In such cases, you can perform the recovery, independent of the recovery job creation, at a future time.

Partially recovered services are available on the Recover Service landing page, from which you can select one or more services and click on Recover button. After you click the Recover button, a pop-up dialog box is displayed, in which you need to provide the necessary attributes such as the customer for which the service is created and a meaningful description of the service. Once the user clicks on Start the Service Recovery Request job starts. After the job is completed, all the configurations for all the devices will be retrieved, but only those configurations that match the filter are processed and populated in Service Recovery page.

An important point to note here is that the recover action only discovers all the possible services that can be recovered from the device. They are not yet stored in the Connectivity Services Director application database. Their status will be initially marked as Partial as shown in grid.

To trigger a service recovery request on a previously configured service instance:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. From the Network Services > Connectivity Tasks pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services with the Recovered Services tab selected.

NOTE: The Latest Recovery Job field at the top of the page displays the job ID and job status in blue. Click the the job ID and status to open the Job Details dialog box. The job ID, start and end times of the job, percentage of completion, and status of the job are displayed. Click Close to close the job dialog box.

5. Select the check box next to the service for which you want to perform the recovery operation again.
6. Click the **Manage** button above the table of listed service instances.
The Manage Recovery of a Service dialog box is displayed.
7. Select a customer from the Customer list to be associated with the service recovery job.
8. Enter a meaningful, easily-identifiable description in the Comments box.
9. For IP services, select a hub of a full-mesh or a hub-and-spoke IP service from the **Select Hub** list.
10. Click **Manage** to initiate the recovery job. Alternatively, click **Cancel** to discard the job.

If you click **Manage**, a dialog box is displayed stating that a service recovery job has been initiated. Click the link in the job ID to view the job details. Click **OK** to close the dialog box.

You can view the details of the recovered service from the Service Recovery page.

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

[Viewing Service Recovery Report | 428](#)

Processing of Device Change Notifications Overview

IN THIS SECTION

- [XPaths of Relevance to Connectivity Services Director | 432](#)
- [Processing of XPath Notifications for Out-of-Band Configuration Changes | 432](#)

All the device change notifications are processed by the following EJB:

`net.juniper.jmp.cm.notification.inventory.device.cmp.CMDeviceChangeNotificationMDB`

The method `handleDeviceChange()` is called passing a result of type `DeviceChangeDiffResult`, which provides the following parts of information:

- Device ID—The ID of the device in the notification
- Notification Meta Data—The type of update—whether the configuration has been modified out-of-band or using Connectivity Services Director.
- DiffResults—A map containing the changed configuration from different configuration parameters on the CLI. The map contains the following keys:
 - Configuration
 - hardware-inventory
 - interface-inventory
 - software-inventory
 - license-inventory
 - system-information
 - logical-interface-inventory
 - configuration-version
- Device ID—The ID of the device in the notification
- Changed XPath List—The changed XPath list can be retrieved by querying `getChangedXPathList()` on result object.

For Service Recovery, Connectivity Services Director examines notifications that will match following criteria:

- Type of update is `OutOfBand`.

- DiffResults for “configuration” is not empty.
- Changed XPath list is from the interested XPath list for services supported in Connectivity Services Director. For the Connectivity Services Director application, an interested XPath list is maintained. If the changed XPath list contains any XPath from the interested XPath list, the configuration difference is processed.

XPaths of Relevance to Connectivity Services Director

All the XPathS are not processed for service recovery. Instead, an interested or relevant XPath list is maintained for Connectivity Services Director. If the changed XPath list contains any of the following XPath attributes, the configuration differential-set is processed to determine the impacted service because of an update to service settings.

```
/configuration/routing-instances/instance
/configuration/firewall/family/vpls
/configuration/firewall/family/ccc
/configuration/firewall/policer/
/configuration/interfaces/interface
/configuration/interfaces/interface/unit
/configuration/policy-options/
/configuration/protocol/l2circuit
/configuration/protocol/local-switching
```

Processing of XPath Notifications for Out-of-Band Configuration Changes

A network managed by Connectivity Services Director has three repositories of information about the configuration of a network device—the configuration stored on the device itself, the device configuration record maintained by Junos Space, and the Build mode configuration maintained by Connectivity Services Director. When the configuration contained in all three repositories match, the device configuration state is shown as In Sync in Connectivity Services Director. When the repositories do not match, the configuration state is shown as Out of Sync. A common cause for this state is out-of-band configuration changes—that is, configuration changes made to a device outside of Connectivity Services Director.

When a device state is Out of Sync, you cannot deploy configuration changes on the device in Deploy mode. Use the Resynchronize Device Configuration task to resynchronize the three configuration repositories and change the device configuration state back to In Sync.

This section describes the different scenarios for out-of-band configuration change on the device and the approach to determine the service impacted by the change. Any XPath change list and configuration differences can belong to any of the following categories:

- Change to the existing endpoint on the service
- Missing or new endpoint on the service
- Endpoint for the new service
- Deleted endpoint for the existing service

The following list of attributes is used to identify neighbor service elements:

When serviceType is ServiceTypesEnum.ELINEMARTINI

```
vcID  
lsName  
lsEndName/LsEndIf:  
deviceID
```

When serviceType is ServiceTypesEnum.ELINEKOMPELLA

```
routeTarget
```

When serviceType is ServiceTypesEnum.VPLS

```
vplsID  
routeTarget  
hubRouteTarget  
spokeRouteTarget
```

When serviceType is ServiceTypesEnum.L3VPN

```
routeTarget  
hubRouteTarget  
spokeRouteTarget
```

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request](#) | 419

Handling of Out-of-Band Notifications for Service Recovery

After a device goes into the Out Of Sync state, a notification is displayed in the status bar at the bottom of the Connectivity Services Director GUI with the count of devices currently out of sync due to out-of-band notifications. The action to be taken when an out-of-band notification is received for the device can be defined using the Preferences page (which you can launch by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

The Service Activation tab of the Preferences page contains the following check box in the Deployments section for service recovery:

- **Block deployment on pending notifications**—Select this check box to cause a validation to be performed to determine if any of the selected devices have pending out-of-band notification, before deploying a service order. If a pending out-of-band notification exists for a device, deployment is blocked with the following message:

Cannot deploy service order, since pending notification exists for device(s) : <dev-1>, <dev-2>, <dev-3>

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request](#) | 419

Viewing Service Recovery Instance Details

The **Service Recovery** window displays the recovered services according to service type. The service recovery report for each service is displayed in a table. You can view the individual and fine-grained details of the services recovered by double-clicking the name of a service instance from the table displayed in the Service Recovery window.

To view the details of a service recovery instance:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** Tasks pane, select **Service Recovery > Recover Services**. The Service Recovery window is displayed.

The **Details** button enables you to view information about a service selected in the **Recovered Services** tab of the Service Recovery window.

5. Double-click a service instance in the **Service Recovery** window to open the **View Service Details** window. This window contains several sections or panels that provide details about the recovered services.

The **View Service Details** window displays information about a service selected in the **Recovered Services** tab of the Service Recovery window. You can view detailed, in-depth information about a selected service.

The Service Details window is divided into three sections—Basic Details, Advanced Details, and Endpoint Details. The service tree contains the service name as the root node. The device node is the child of the service node and it contains the provisioned UNIs as the child nodes. The details panel in the Endpoint Details table displays configuration parameters and their corresponding values for the service in the tree and based on the service type.

Under the Basic Details section, the general details about the node details are shown. Also, the device configuration parameters are displayed. Under the Advanced Details section, which you can open or close by clicking the View Less or View More toggle links, the advanced connectivity settings between sites in the service provider network are shown, such as route distinguisher and VRF route label details. Under the Endpoint Details table, the configuration parameters of the UNI are displayed. The right pane displays the details corresponding to the node or element you selected on the left pane.

Basic Details

This section is applicable for all types of services and displays the following details.

- Name—Name of the selected service
- Customer—Name of the customer associated with the service.
- Service Definition—Name of the service definition that is used to create the service.
- Service Type—Selected service type, such as E-Line, IP, or E-LAN.
- Comments—User-defined description of the recovered service.
- Signalling—Type of signaling, namely, BGP or LDP.
- Order Type—Type of the service order, which is indicated as Recovery to signify a recovered service.

- Status—Status of the recovered service, such as Partial or Recovered.
- Recovered By—Name of the user that performed the service recovery operation.

Advanced Details

This section displays the advanced, fine-grained connectivity settings between sites, such as the configured route distinguisher, VRF route label. The parameters displayed under this section are similar to the advanced parameters displayed in the wizard for service order creation.

Column	Description
Advanced Details	
VCID	Virtual channel identifier number This field is displayed for E-Line services only.
Service Order Type	Type of the service order, such as Ethernet, E-LAN, or IP.
MTU (Bytes)	Maximum transmission unit number This field is displayed for E-Line and E-LAN services.
MTU (Factor)	The factor by which the MTU value that you specify for the service is multiplied.
Route Target	Route target of the recovered service.
Route Distinguisher	Route distinguisher of the recovered service.
VLAN Normalization	Type of normalization for VLAN IDs, such as Q-in-Q or dot1q.
Customer Traffic Type	Type of restrictions placed on the traffic that can be transported across the network by the associated service, such as whether the associated service is restricted to transporting just one VLAN across the network, transporting a VLAN range, or VLAN list.
Unmanaged IP	If the Unmanaged IP field includes a valid IP address, the selected service is valid but the other end is an unmanaged device. If the field displays Unmanaged IP , the IP address of the unmanaged device is unknown. You must provide the IP address. NOTE: If Service Recovery finds an endpoint attached to a recovered service for a device that was not selected for Service Recovery, the endpoint is reported as an Unmanaged IP. The endpoint is recovered and attached to the service when Service Recovery is executed on the particular device. This field is displayed for E-Line services only.

Column	Description
Unmanaged Interface	<p>If one endpoint is an unmanaged device, the interface information is unknown. You must provide the interface for the endpoint.</p> <p>This field is displayed for E-Line services only.</p>
VPLS ID	<p>VPLS ID of the recovered service</p> <p>This field is displayed for E-LAN services only.</p>
L2VPN ID	<p>Layer 2 VPN ID of the recovered service</p> <p>This field is displayed for E-LAN services only.</p>
Hub Route Target	<p>Route target of the hub.</p> <p>This field is displayed only for E-LAN and IP services.</p>
Spoke Route Target	<p>Route target of the spoke.</p> <p>This field is displayed for E-LAN and IP services only.</p>
VRF Table	<p>When this check box is selected, the VPN facilitates VRF table lookup, based on MPLS labels.</p> <p>This field is displayed for IP services only.</p>
Routing Protocol	<p>Provider edge (PE) and customer edge (CE) routing protocol configured for the service.</p> <p>This field is displayed for IP services only.</p>
Hub	<p>Hub device for the hub-and-spoke IP service.</p> <p>This field is displayed for IP services only. This is applicable for hub-and-spoke IP service only.</p>
Auto Discovery	<p>Denotes whether auto discovery is enabled, which indicates that route target, route distinguisher, and VPN ID are provisionable. This field is applicable only if signaling is LDP.</p>
Normalized Vlan ID	<p>The VLAN to push at the relevant end points. This should be the same VLAN specified as the VLAN ID.</p>
Revert Time	<p>Revert time for redundant Layer 2 circuits and VPLS pseudowires. This field is applicable only if signaling is LDP.</p>
Switch Over Delay	<p>Delay to wait before the backup pseudowire takes over.</p>

Column	Description
Dot1QVLANTag	Tag number of the dot1q VLAN.
AS Override	Indicates whether the service provisioner can override the AS number or not.
Export Direct Routes	Indicates whether the functionality to export direct routes to remote sites is enabled.
VRF Table Label	Indicates whether mapping of the inner label of a packet to a specific VRF, thereby allowing the examination of the encapsulated IP header, is enabled.

Endpoint Details

A tabular view is displayed of the configured device and UNI Details that are part for the service. Each row in the table displays the basic, salient parameters, such as Device Name, Interface Name, Unit ID, Encapsulation and Description. You can use the paging controls to navigate across multiple pages of endpoints as necessary. A minimum of 20 endpoints per page are displayed.

The following fields are displayed in the End Points table:

- End Point—Name of the device configured as the source or origin (A) endpoint and the destination or target (Z) endpoint. This field is displayed for E-Line services. Click the plus sign beside the device name for E-Line services to expand the device-related parameters and view the detailed settings.
 - Device Name—Name of the device for which the service is created. Click the plus sign beside the device name for E-LAN and IP services to expand the device-related parameters and view the detailed settings.
 - Interface—Name of the physical interface associated with the service
 - Tagging—Type of packet tagging for the interface, such as Ethernet, dot1Q, or Q-in-Q
 - UnitId—Logical unit identifier of the interface
 - VlanId—VLAN identifier of the interface
 - Role—Indicates whether the node is a hub or a spoke
 - Template—Name of the service template that is used to create the service order
 - CoS Profiles—Name of the COS profile associated with the service
6. View the information of a recovered service in the **Basic Details** and **Advanced Details** panel. Click **Close** to close the View Service Details window and return to the Service Recovery window.

The **Service Recovery** window displays the status of all the recovered services. It also indicates the configuration that are converted to service orders. You can view the status of a recovered service in its corresponding tab. The **Service Recovery** window displays one of the following status indications:

- Managed—The service is now managed successfully

- Failed—Service Recovery did not convert the service to a service order
- Partial—The service cannot be managed yet

NOTE: You can access the **Recovered Service Status** window whenever you want to attempt to recover additional services.

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Managing Out-of-Band Notifications for Recovered Services

The service recovery module contains a landing page for out of band device change notifications where all the device change notifications are listed. You can perform the following actions with the Service Recovery—Recover Out of Band Changes page:

- View the out-of-band notifications for recovered services and detailed information for each notification.
- Accept an out-of-band notification
- Delete an existing out-of-band notification
- Ignore an out-of-band notification

The **Service Recovery Report** window displays the recovered services according to service type. The service recovery report for each service is displayed in a table. You can view the individual and fine-grained details of the services recovered by double-clicking the name of a service instance from the table displayed in the Service Recovery window.

To view and manage out-of-band notifications for a service recovery instance:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > Manage Out of Band Changes**.

The Manage Out of Band Changes window is displayed.

The following fields are displayed in this window:

- Device Name—Name of the device to which the notification belongs
 - State—Indicates whether the notification is processed or not. One of the following states is displayed:
 - Ignored—Notification is ignored and device changes to InSync again.
 - Failed—Processing failed and services was not recovered. The device remains in the OutOfSync state.
 - Pending—Notifications are not processed. The device continues to remain OutOfSync. Notifications for successfully recovered services are removed from grid and device are brought to InSync state.
 - Notification XML— A **View** link shows the configuration difference for all the out of band notifications received for that device. Each time a notification is received, it is merged with earlier out-of-band notifications received. A single copy of each notification is maintained per device. Click **View** to view the configuration differences in XML format.
 - Create Timestamp—Date and time at which the record was created. The record will be created when the first out-of-band notification is received for the device.
 - Update Timestamp—Date and time at which the most recent out-of-band notification is received for the device
5. Select the check box beside a device for which an out-of-band notification is displayed, and click **Accept** above the table to navigate to the Create Service Recovery Request wizard with the devices and service definitions preselected on the landing page. The out-of-band notification is accepted and removed from the table of out-of-band entries.

You can select a notification and click **Accept** to recover endpoints. The following two options are available for recovering endpoints:

- When Connectivity Services Director is able to determine the service to which the endpoint belongs— Here, the service type and service definition in use are identified. In that case, the service is recovered only for the selected endpoint. You can select multiple endpoints and say recover service and all the selected endpoints will recovered.
- When Connectivity Services Director is unable to determine the service to which the endpoint belongs—Here, the service type and service definition are not identified, and therefore, the existing service recovery flow is invoked. Only devices are preselected and you must select the appropriate

service definition. If the recovery of the service fails, the operator can use existing option of force-deploy from Connectivity Services Director to make the service on device in-sync with the service in Connectivity Services Director and then discard the notification on out-of-band changes landing page to make device In Sync again.

6. Select the check box beside a device for which an out-of-band notification is displayed, and click **Ignore** above the table to ignore the notification.

The notification is discarded and device is marked as In-Sync. The notification is not removed from the table.

7. Select the check box beside a device for which an out-of-band notification is displayed, and click **Delete** above the table to delete the record from the table.

Only processed or discarded records are enabled to be deleted.

8. Select the check box beside a device for which an out-of-band notification is displayed, and click **Details** above the table to open a pop-up dialog box that displays the type of update performed on the device that caused the out-of-band notification.

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Viewing Details of an Out-of-Band Notification for Recovered Services

On the Manage Out of Band Changes page, the **Details** button displays granular and comprehensive information for a selected service recovery notification.

The Manage Out of Band Changes page displays the devices for which the configuration settings have been modified outside of the Connectivity Services Director application. The configuration state of a device is shown as In Sync when the configuration information in all three repositories match (settings made using the devices CLI, Connectivity Services Director in Build mode, or Junos Space Network Management Platform). If there is a conflict between the configuration information in one or more of the repositories, the device configuration state is Out of Sync. An Out of Sync state is usually the result of out-of-band configuration changes—that is, configuration changes made to a device using a management tool other than Connectivity Services Director.

To view detailed information that pertains to an out-of-band notification of a service recovery instance:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > Manage Out of Band Changes**.

The Manage Out of Band Changes window is displayed.

5. Select the check box beside a device for which an out-of-band notification is displayed, and click **Details** above the table.

The Details pop-up dialog box appears that contains the following fields:

- Service Name—The configuration difference received in the device change notification will be processed to see if we are able to determine the name of service. If name of service can be determined it will displayed.
- Service Type—The type of service (E-Line, E-LAN, or IP)
- Service Definition—The definition associated with service
- Customer—The customer associated with service
- Type of update—Indicates the type of modification performed as follows:
 - CREATE—Missing endpoint added to the service
 - MODIFY—Existing endpoint modified for the service

- DELETE—Endpoint deleted for the service
6. Click **OK** to close the Details dialog box.
You are returned to the Out of band Changes page.

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Viewing Services Rejected During a Service Recovery

You can view the services that were rejected during the service recovery operation. The reason for the failure of the service recovery operation is also displayed, which enables you to analyze and resolve the problem and perform a service recovery task again.

To view services that are rejected during a service recovery operation:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services with the Recovered Services tab selected.

5. Select the **Rejected Endpoints** tab. The Service Recovery—Rejected Services window is displayed.

The following fields are displayed in a table:

- Service Name—Name of the rejected service
- Configuration XML—Click **View** to open a dialog box that displays the configuration differences in XML format for the corresponding device on which out-of-band changes have been made. Close the dialog box after viewing the out-of-band configuration changes. Configuration changes are shown only when the device configuration differs from the Junos Space configuration record—that is, when the device configuration state in Junos Space is not In Sync.

NOTE: The Junos XML API is an XML representation of Junos configuration statements and operational mode. It defines an XML equivalent for all statements in the Junos configuration hierarchy and many of the commands that you issue in CLI operational mode. Each operational mode command with a Junos XML counterpart maps to a request tag element and, if necessary, a response tag element.

- Service Type—Type of the rejected service, such as E-Line, IP, or E-LAN
 - Device Name—Name of the device for which the service was rejected
 - Interface—Name of the interface on the device for which the service was rejected
 - Unit—Logical unit number of the interface associated with the device
 - Rejected Reason—Cause for the service recovery operation to reject the service
6. For each device displayed under the Devices column, you can view detailed information regarding the services for which out-of-band notification was generated.

From the Manage Out of Band Changes page, select the check box beside a device for which an out-of-band notification is displayed, and click **Details** above the table to open a pop-up dialog box that displays the following fields:

- Service Name—The configuration difference received in the device change notification will be processed to see if we are able to determine the name of service. If name of service can be determined it will be displayed.
- Service Definition—Name of the definition associated with the service
- Customer—Name of the customer associated with the service
- Type of update—Indicates the type of modification performed as follows:
 - CREATE—Missing endpoint added to the service
 - MODIFY—Existing endpoint modified for the service
 - DELETE—Endpoint deleted for the service

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

[Performing a Service Recovery on a Defined Service | 429](#)

Viewing Service Recovery Jobs

You can perform a service recovery operation on a service instance that you have previously configured in the Service Recovery page, instead of running the recovery job during the process of creation of the recovery request. In certain situations, you might require a set of service instances to be defined separately, before you want to run the recovery task on all such services. In such cases, you can perform the recovery, independent of the recovery job creation, at a future time.

The Service Recovery Jobs page shows the progress and status of the service recovery job. Although you can view details about the status of all the jobs initiated in the Connectivity Services Director application from the Jobs page accessible as a System task, you can use the Service Recovery Jobs page in Build mode of Service view to obtain a filtered display of only the service recovery jobs for easy analysis and debugging.

To the service recovery jobs:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > View Service Recovery Jobs**.

The **Service Recovery Jobs** window appears.

5. To view the details of a job, select a row and click **Show Details** or double-click a row.

6. To cancel a scheduled job, select a job that is scheduled for a later time or a job that is in progress and click **Cancel**.

The fields in the Prestaging Device Jobs page are described in [Table 60 on page 400](#). To view any hidden column, keep the mouse on any column heading and select the down arrow and then click Columns. Select the check box to display the hidden columns.

NOTE: Details of jobs initiated from Connectivity Services Director will be available only from Connectivity Services Director. These jobs will not be listed in the Jobs pane in Junos Space platform and vice-versa.

Table 62: Service Recovery Jobs Page Fields

Field	Description
Job ID	The unique ID assigned to the job
Name	The name of the job
Percent	The percentage of completion of the job
State	The status of the job: <ul style="list-style-type: none"> • Success—Job completed successfully • Failure—Job failed and was terminated • Job Scheduled—Job is scheduled but has not yet started • In progress—Job is has started, but not completed • Cancelled—Job is cancelled
Job Type	The type of the job
Summary	Summary of the job scheduled and executed with status
Scheduled Start Time	The time when the job is scheduled to start
Actual Start Time	The actual time when the job started
End Time	The time when the job was completed
User	The login ID of the user that initiated the task
Recurrence	The recurrent time when the job will be restarted.

RELATED DOCUMENTATION

[Managing Service Configuration Deployment Jobs | 1080](#)

[Deploying Services Configuration to Devices | 1083](#)

Performing a Configuration Audit for Recovered Services

A configuration audit can help you determine whether the service configuration on the device has been changed out of band. To this end, you can compare the results of a configuration audit with the service configuration in the Junos Space database. The following example shows a sample comparison.

To perform a configuration audit:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services with the Recovered Services tab selected.

5. Select a recovered service, and click the **Audit** button at the top of the table of listed services and select **Configuration Audit > Run Configuration Audit**.

6. In the **Schedule Configuration Audit** window, either:

- Select **Audit Now**, then click **OK**.

An informational dialog appears, stating that the configuration audit job is successfully triggered with the job ID, and an **OK** button.

- Select **Audit Later**, enter a date and time, then click **OK**.

7. To monitor the progress of an audit after selecting **Audit Now**, click the Job ID in the **Audit Information** window. The **Job Management** page shows information about the configuration audit job.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

The **State** field indicates whether the service passed or failed the audit. If the service failed the audit, then the **Summary** field provides information about the failure.

To monitor the progress of an audit after selecting **Audit Later**, after the scheduled time of the audit:

- a. On the Junos Space Network Management Platform user interface, select **Jobs**.
- b. In the **Job Types** chart, select the **Configuration Audit** segment of the pie chart.
- c. Select the configuration audit of interest from the list on the **Job Management** page.
Summary information about the audit appears in the quick look panel.
- d. In the filter bar, select the table view icon to see additional information about the job. If the service failed the audit, information about the failure appears in the **Summary** field.

8. In the **Audit Information** window, click the job ID of the configuration audit.

The **Job Management** window appears and shows a filtered view of the job inventory, showing only the configuration audit job.

NOTE: If a resynchronization between a device and the Junos Space database is ongoing when the configuration audit job starts, the configuration audit job suspends until the resynchronization job finishes. If the resynchronization job fails to complete, the audit could be suspended indefinitely. To allow the audit to proceed, go to the **Job Management** workspace and cancel the resynchronization job, as described in *Canceling a Job*.

9. In the **Status** column, check the status of the audit to determine whether it succeeded or failed.

Check the **Summary** column, which contains useful service information such as the VC ID and endpoint information. For some failed deployments, this column also contains information about why the deployment failed.

NOTE: When a configuration audit is performed, the XPATH attributes that are present in the service configuration are used. Only the addition, modification, or deletion of the XPATH attributes is detected, and the creation of a new attribute (child XPATH) on a device is not determined. The audit operation disregards such attributes and does not identify them. This behavior is expected and occurs because Junos Space Platform software audits only the settings present a user template. If the template has a container, Junos Space Platform only audits to determine whether the device is configured with this container. If a user wants to audit any container child, the user needs add it into the template. This scenario is similar to an out-of-band configuration change on the device, which Junos Space Platform can determine only if the system of record (SOR) mode is set for the Junos Space Network Management Platform application.

RELATED DOCUMENTATION

[Performing a Functional Audit | 1145](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Troubleshooting the Endpoints of Services | 1168](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Viewing Configuration Audit Results of Recovered Services

After performing a configuration audit of a recovered service, check the detailed results of the audit:

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in Service View of the Connectivity Services Director banner.

The functionalities that you can configure in Build mode are displayed on the Tasks pane.

3. In the View pane, select the **Network Services > Connectivity** node without expanding the tree and selecting a type of service.

The tasks that are applicable for the different connectivity services are displayed on the Tasks pane.

4. In the **Network Services > Connectivity** task pane, select **Service Recovery > View Recovered Services**.

The Service Recovery page is displayed with a list of recovered services with the Recovered Services tab selected.

5. Select a recovered service, and click the **Audit** button at the top of the table of listed services and select **Configuration Audit > View Audit Results**.

The configuration audit results are displayed if an audit operation was previously performed on the selected service.

Examine the audit results for missing configuration information, and keep the window open for later comparison with the service configuration in the Junos Space database.

You can validate policies for the hub and spoke (1 interface).

NOTE: In the Service Configuration tab of the Configuration Audit dialog box, you can observe several lines with the **delete** statement in the service settings. These **delete** statements indicate the policy attributes that are deleted from the corresponding service on a device. Whenever a service is created or modified, the policy options are always deleted from the device to prevent the previously existing policies from interfering with the service. The presence of the **delete** statements is an expected behavior and does not indicate any incorrect service configuration.

6. To view the service configuration in the Junos Space database, in Deploy mode, from the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Service Deployment page is displayed on the bottom part of the right pane. Select a service from the **Manage Service Deployment** page, then in the **Actions** menu, select **View Service Configuration**.

A new window opens and shows the service configuration.

If a CFM is configured in E-Line service or E-LAN service, the configuration audit result displays the CFM configuration details.

7. Compare the contents of the Service Configuration with those of the **Configuration Audit Results** window for each device in turn. If you see discrepancies, then it is likely that the service configuration was modified out-of-band. If so, you might need to synchronize the device with the Junos Space database.

For step-by-step instructions about synchronizing devices, see *Resynchronizing Managed Devices with the Network* for details.

After the audit job is completed, you can view the output of the operation in the Configuration Audit Results window that is displayed on the right pane. The left pane displays a tree of devices associated with

the specified service. You can select a **Service-name > Interface-name Device-name** in the left pane of the window. The attribute definitions and parameters defined in the service are displayed in the right pane. The right pane contains three tabs— Service Configuration, Template Configuration, and Audit Results. The Service Configuration tab displays the settings specified for the service on the device in CLI format. This tab displays the elements or components specified for a service template in the form of configuration stanzas and hierarchy levels. This display is similar to the **show** command that you can use at a certain **[edit]** hierarchy level to view the defined settings. The Template Configuration tab displays the service attributes and options defined in the service template, if any, that is associated with the service. The Audit Results tab displays the status of the audit job that was run, such as whether the job succeeded or failed. You can also view the service definition and associated template details under the Service Config and Template Config tabs in Junos OS XML API format, instead of the CLI format.

Click the **Show XML Config** button at the top-right corner of the window to view the audit results in XML API format. Alternatively, click the **Show Set** button to view the audit results in the manner in which they are displayed in the Junos OS CLI interface. The **Show XML/Set** button is a toggle button.

The Junos OS command-line interface (CLI) and the Junos OS infrastructure communicate using XML. When you issue an operational mode command in the CLI, the CLI converts the command into XML format for processing. After processing, Junos OS returns the output in the form of an XML document, which the CLI converts back into a readable format for display. Remote client applications also use XML-based data encoding for operational and configuration requests on devices running Junos OS. The Junos XML API is an XML representation of Junos configuration statements and operational mode commands. It defines an XML equivalent for all statements in the Junos configuration hierarchy and many of the commands that you issue in CLI operational mode. Each operational mode command with a Junos XML counterpart maps to a request tag element and, if necessary, a response tag element.

Click **Reload Result** at the top-right corner of the window to refresh and display the results of the audit. When you click this button, only the output of the audit operation is displayed afresh and the audit job is not run again. You can refresh the results only for completed audit instances. When you select **Service-name** in the left pane of the window, service status information is displayed in the right pane. Click **Run Configuration Audit** after selecting the services you need to run the audit job again.

Configuration audit can be run for multiple services from Build mode of Service View of the Connectivity Services Director GUI. From the Manage Network Services page, select the check boxes beside multiple services, click the **Audit** button at the top of the table of configured services, and select **Run Configuration Audit** from the drop-down menu.

We recommend that you configure a script as a local script for effective and optimal debugging and analysis of the configuration settings contained in the script. The main advantage of a local script is that you need not download the script to a device (because a connection is established with the device by the GUI application and the script is run) and you need not remove the script from a device after you decommission a service.

RELATED DOCUMENTATION

[Viewing Functional Audit Results | 1180](#)

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

Recovering Modifications and Deletions Performed for Existing Endpoints

Until Connectivity Services Director Release 1.0R2, the service recovery operation did not support the recovery of updated configurations made on existing endpoints associated with services. The only supported operations were recovery of new services and new endpoints for existing services, and recovery of connectivity fault management (CFM) profiles.

Starting with Release 2.0R1, the following recovery operations are supported in addition:

- Recovering modifications to existing endpoints
- Recovering endpoint deletions for a service

Also, recovery of the swap of hubs and spokes for hub-and-spoke IP and E-LAN services are supported. In addition, recovery of changes in configuration of backup endpoints for point-to-point A and Z endpoints is supported.

Recovery of templates, recovery for devices with different Junos OS versions running on them, and recovery of class of service (CoS) profiles are not supported.

Recovering Parameters for E-Line Services

Table 63 on page 452 describes the fields or parameters that are supported for recovery during a service recovery operation and the corresponding XPath notifications for those configuration parameters. This table also denotes the service operation that is supported, such as creation, edit, or deletion of a service

Table 63: Mapping of Parameters, XPaths, and Supported Operations for E-Line Services

Field	XPath	Supported Operation
Interface MTU	configuration/interfaces/interface/mtu	Modify service
Interface bandwidth	/configuration/firewall/policer/if-exceeding/bandwidth-limit	Modify service

Table 63: Mapping of Parameters, XPath, and Supported Operations for E-Line Services (*continued*)

Field	XPath	Supported Operation
Starting C-VLAN ID in a range	/configuration/interfaces/unit/vlan-tags/inner-range	Modify service
Ending C-VLAN ID in a range	/configuration/interfaces/unit/vlan-tags/inner-range	Modify service
C-VLAN ID	/configuration/interfaces/unit/vlan-tags/inner (Q-in-Q)	Modify service
V-LAN ID	/configuration/interfaces/unit/vlan-tags/outer (Q-in-Q) /configuration/interfaces/unit/vlan-id (Dot1Q)	Modify service
Outer TPID	/configuration/interfaces/interface/unit/input-vlan-map/tag-protocol-id /configuration/interfaces/interface/unit/output-vlan-map/tag-protocol-id	Create, modify, and delete service
Inner TPID	/configuration/interfaces/interface/unit/input-vlan-map/inner-tag-protocol-id /configuration/interfaces/interface/unit/output-vlan-map/inner-tag-protocol-id	Create, modify, and delete service
Endpoint LSP association	/configuration/protocols/l2circuit/neighbor/interface/community /configuration/policy-options/policy-statement/term/then/install-next-hop/lsp	Create, modify, and delete service
Interface description	/configuration/interfaces/interface/unit/description	Create, modify, and delete service
Changing, disabling, and enabling CFM profile	Not supported	Not applicable

Recovering Parameters for IP Services

Table 64 on page 454 describes the fields or parameters that are supported for recovery during a service recovery operation and the corresponding XPath notifications for those configuration parameters. This table also denotes the service operation that is supported, such as creation, edit, or deletion of a service

Table 64: Mapping of Parameters, XPath, and Supported Operations for IP Services

Field	XPath	Supported Operation
Interface MTU	configuration/interfaces/interface/mtu	Modify service
Interface bandwidth	/configuration/firewall/policer/if-exceeding/bandwidth-limit	Modify service
Starting C-VLAN ID in a range	/configuration/interfaces/unit/vlan-tags/inner-range	Modify service
Ending C-VLAN ID in a range	/configuration/interfaces/unit/vlan-tags/inner-range	Modify service
C-VLAN ID	/configuration/interfaces/unit/vlan-tags/inner (Q-in-Q)	Modify service
V-LAN ID	/configuration/interfaces/unit/vlan-tags/outer (Q-in-Q) /configuration/interfaces/unit/vlan-id (dot1Q)	Modify service
Outer TPID	Gets prefixed to VLAN tags, for example: <vlan-tags> <outer>0x88a8.51</outer> <inner-range>0x9100.56-65</inner-range> </vlan-tags>	Create, modify, and delete service
Inner TPID	<vlan-tags> <outer>0x88a8.51</outer> <inner-range>0x9100.56-65</inner-range> </vlan-tags>	Create, modify, and delete service
MAC table size	Not supported	Not applicable
Interface MAC limit	Not supported	Not applicable
Mesh group name change	Not supported	Not applicable
Interface description	/configuration/interfaces/interface/unit/description	Create, modify, and delete service

Table 64: Mapping of Parameters, XPath, and Supported Operations for IP Services (continued)

Field	XPath	Supported Operation
PW extension (BGP and LDP)	<p>Addition of point-to-point spoke and update of neighbor in hub are supported</p> <p>/configuration/instances/instance/instance/protocols/vp/meshgroup/vpid</p> <p>/configuration/instances/instance/instance/protocols/vp/meshgroup/neighbor</p>	Create and delete service
PW resiliency (LDP)	<p>Addition of a backup hub and update of neighbor details in point-to-point spoke and E-LAN LDP spoke are supported</p> <p>Update of neighbor to primary hub is not supported</p> <p>/configuration/instances/instance/protocols/vp/neighbor/backupneighbor/name</p> <p>for LDP spoke</p> <p>/configuration/protocols/2circuit/neighbor/interface/backupneighbor/name</p> <p>for point-to-point spoke</p>	Create and delete service
Changing, disabling, and enabling CFM profile	Not supported	Not applicable

Recovering Parameters for E-LAN Services

Table 65 on page 455 describes the fields or parameters that are supported for recovery during a service recovery operation and the corresponding XPath notifications for those configuration parameters. This table also denotes the service operation that is supported, such as creation, edit, or deletion of a service

Table 65: Mapping of Parameters, XPath, and Supported Operations for E-LAN Services

Field	XPath	Supported Operation
Interface MTU	configuration/interfaces/interface/mtu	Modify service
Interface bandwidth	/configuration/field/policies/forcingbandwidthlimit	Modify service
Tagging	Not supported	Not applicable
Starting C-VLAN ID in a range	/configuration/interfaces/unit/Vlan-tag/inner-range	Modify service
Ending C-VLAN ID in a range	/configuration/interfaces/unit/Vlan-tag/inner-range	Modify service

Table 65: Mapping of Parameters, XPath, and Supported Operations for E-LAN Services (*continued*)

Field	XPath	Supported Operation
C-VLAN ID	/configuration/interfaces/unit/vlan-tags/inner (Q-in-Q)	Modify service
V-LAN ID	/configuration/interfaces/unit/vlan-tags/outer (Q-in-Q) /configuration/interfaces/unit/vlan-id (dot1Q)	Modify service
IP address	/configuration/interfaces/unit/vlan-id/address	Modify service
Neighbor IP address	/configuration/interfaces/unit/vlan-id/neighbor	Modify service
Peer AS	/configuration/interfaces/unit/vlan-id/peer-as	Create and modify service
AS override	/configuration/interfaces/unit/vlan-id/as-override	Create, modify, and delete service
Interface description	/configuration/interfaces/interface/unit/description	Create, modify, and delete service
Static routes (destination prefix, next hop)	Not supported	Not applicable
Enable or disable of MVPN and MC-LAG (addition of MVPN capability to an existing L3VPN)	Not supported	Not applicable
PE-CE Settings, OSPF Domain ID, version	Not supported	Not applicable
Stitching into an E-Line service	Both services must be recovered individually according to the current behavior	Not applicable
Route distinguisher (full-mesh OSPF_	Not supported	Not applicable

Recovering Endpoint Deletions from a Service

The following scenarios are supported when recovering endpoint deletion from a service:

- Recovery of a deleted endpoint for multipoint-to-multipoint E-LAN and full-mesh IP services
- Recovery of a deleted spoke for point-to-multipoint E-LAN and hub-and-spoke IP services

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

REST API Changes in Connectivity Services Director for Service Recovery

In Connectivity Services Director, all these three REST APIs for creating a service request report are being merged into one REST API as follows:

```
POST method
@Path("/startServiceRecovery")
@Consumes({ "application/x-www-form-urlencoded", "application/json" })
public Response startServiceRecovery_V2(ServiceRecoveryProfileBean
svcRecProfileBean, List<DeviceBean> deviceList, (List<ServiceDefinitionBean> sdList,
@Context
HttpServletRequest request);
```

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request | 419](#)

Sample XPath Notifications Received on Devices for Deleted Endpoints

For endpoints that are removed from a service, such as an E-LAN service, the changed XPath list contains the following values for removed endpoint, which includes the routing instance along with its logical unit of the interface, firewall, and policy, that are deleted from the device.

The following are the changed XPath attributes:

```
/configuration/routing-instances/instance/protocols/vpls/mac-table-size/limit,
/configuration/firewall/family/vpls/filter/term/name,
/configuration/firewall/policer/if-exceeding/bandwidth-limit,
/configuration/firewall/policer/if-exceeding/burst-size-limit
/configuration/interfaces/interface/unit/name
/configuration/routing-instances/instance/interface/name
/configuration/routing-instances/instance/instance-type
/configuration/firewall/policer/name
```

```

/configuration/routing-instances/instance/protocols/vpls/site/interface/name
/configuration/routing-instances/instance/protocols/vpls/site/site-preference
/configuration/interfaces/interface/unit/vlan-id
/configuration/interfaces/interface/unit/family/vpls/filter/input/filter-name
/configuration/routing-instances/instance/route-distinguisher/rd-type
/configuration/routing-instances/instance/name
/configuration/interfaces/interface/unit/encapsulation
/configuration/routing-instances/instance/vrf-export
/configuration/routing-instances/instance/protocols/vpls/no-mac-learning
/configuration/firewall/policer/then/discard
/configuration/routing-instances/instance/protocols/vpls/site/site-identifier
/configuration/routing-instances/instance/protocols/vpls/interface-mac-limit/limit

/configuration/firewall/family/vpls/filter/name
/configuration/routing-instances/instance/protocols/vpls/no-tunnel-services
/configuration/firewall/family/vpls/filter/interface-specific
/configuration/firewall/family/vpls/filter/term/then/policer
/configuration/firewall/family/vpls/filter/term/then/accept
/configuration/routing-instances/instance/protocols/vpls/site/name
/configuration/routing-instances/instance/vrf-import

```

The following is the differential configuration set for the XPath attributes:

```

<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
  <configuration op="U">
    <interfaces op="U">
      <interface op="U">
        <name>ge-0/1/7</name>
        <flexible-vlan-tagging/>
        <mtu>1522</mtu>
        <encapsulation>flexible-ethernet-services</encapsulation>
        <unit op="D">
          <name op="D">29</name>
          <encapsulation op="D">vlan-vpls</encapsulation>
          <vlan-id op="D">34</vlan-id>
          <family op="D">
            <vpls op="D">
              <filter op="D">
                <input op="D">
                  <filter-name op="D">filter_in_ge-0/1/7_29</filter-name>
                </input>
              </filter>
            </vpls>
          </family>
        </unit>
      </interface>
    </interfaces>
  </configuration>
</rpc-reply>

```

```

        </filter>
    </vpls>
</family>
</unit>
</interface>
</interfaces>
<firewall op="U">
    <family op="U">
        <vpls op="U">
            <filter op="D">
                <name op="D">filter_in_ge-0/1/7_29</name>
                <interface-specific op="D"/>
                <term op="D">
                    <name op="D">1</name>
                    <then op="D">
                        <policer op="D">policer_in_ge-0/1/7_29</policer>
                        <accept op="D"/>
                    </then>
                </term>
            </filter>
            <filter op="D">
                <name op="D">filter_in_ge-0/1/8_102</name>
                <interface-specific op="D"/>
                <term op="D">
                    <name op="D">1</name>
                    <then op="D">
                        <policer op="D">policer_in_ge-0/1/8_102</policer>
                        <accept op="D"/>
                    </then>
                </term>
            </filter>
        </vpls>
    </family>
    <policer op="D">
        <name op="D">policer_in_ge-0/1/7_29</name>
        <if-exceeding op="D">
            <bandwidth-limit op="D">10m</bandwidth-limit>
            <burst-size-limit op="D">15220</burst-size-limit>
        </if-exceeding>
        <then op="D">
            <discard op="D"/>
        </then>
    </policer>
</policer op="D">

```

```

<name op="D">policer_in_ge-0/1/8_102</name>
<if-exceeding op="D">
  <bandwidth-limit op="D">10m</bandwidth-limit>
  <burst-size-limit op="D">15220</burst-size-limit>
</if-exceeding>
<then op="D">
  <discard op="D"/>
</then>
</policer>
</firewall>
<routing-instances op="U">
  <instance op="D">
    <name op="D">VplsBgpPW</name>
    <instance-type op="D">vpls</instance-type>
    <interface op="D">
      <name op="D">ge-0/1/7.29</name>
    </interface>
    <route-distinguisher op="D">
      <rd-type op="D">36000:23</rd-type>
    </route-distinguisher>
    <vrf-import op="D">VplsBgpPW-import</vrf-import>
    <vrf-export op="D">VplsBgpPW-export</vrf-export>
    <protocols op="D">
      <vpls op="D">
        <mac-table-size op="D">
          <limit op="D">5120</limit>
        </mac-table-size>
        <interface-mac-limit op="D">
          <limit op="D">1024</limit>
        </interface-mac-limit>
        <no-mac-learning op="D"/>
        <no-tunnel-services op="D"/>
        <site op="D">
          <name op="D">Site_2</name>
          <site-identifier op="D">2</site-identifier>
          <site-preference op="D">primary</site-preference>
          <interface op="D">
            <name op="D">ge-0/1/7.29</name>
          </interface>
        </site>
      </vpls>
    </protocols>
  </instance>
</routing-instances>

```

```
</configuration>
</rpc-reply>
```

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request](#) | 419

Sample XPath Notifications Received on Devices for a Modified E-LAN Service

While developing configlets, XPath and Regular Expressions would be used intensively. It would be desirable to let the user define frequently used XPath and Regular expressions in such a way that they can be referred when required. User can define these templates from the XPath and Regex task group in the CLI Configlets workspace of the Junos Space Platform GUI. For an E-LAN service that is modified using the Connectivity Services Director application, the XPath attributes corresponding to the modified configuration settings and parameters are sent to the associated devices of the service for the revised configuration elements to be applied on the devices. This topic illustrates the differential configuration, which is the delta or the change-set of the configuration that you are about to deploy on the devices, and the XPath attributes associated with the delta configuration for a modified E-LAN service:

The following is the changed XPath attribute for a routing instance of a modified E-LAN service:

```
/configuration/routing-instances/instance/route-distinguisher/rd-type
```

The following is the differential configuration set for the XPath attribute for a routing instance of a modified E-LAN service:

```
<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
<configuration op="U">
<routing-instances op="U">
  <instance op="U">
    <name>VplsBasicSO</name>
    <instance-type>vpls</instance-type>
    <interface>
      <name>ge-0/1/4.69</name>
```

```

</interface>
<route-distinguisher op="U">
  <rd-type op="U">36001:7</rd-type>
</route-distinguisher>
<vrf-target>
  <community>target:36000:6</community>
</vrf-target>
<protocols>
  <vpls>
    <mac-table-size>
      <limit>5120</limit>
    </mac-table-size>
    <interface-mac-limit>
      <limit>1024</limit>
    </interface-mac-limit>
    <no-tunnel-services/>
    <site>
      <name>Site_1</name>
      <site-identifier>1</site-identifier>
      <site-preference>primary</site-preference>
      <interface>
        <name>ge-0/1/4.69</name>
      </interface>
    </site>
  </vpls>
</protocols>
</instance>
</routing-instances>
</configuration>
</rpc-reply>

```

For the **policy- statement** statement at the **[edit policy-options]** hierarchy level, the correct XPath Notification is not received if changes happen only to the policy-statement. The notification does not contain the changed XPath and configuration difference. Therefore, it is not possible to determine the instance of service impacted due to the change (when only localized to **policy-options->policy-statement**). Full service recovery is recommended in such cases.

The following is the changed XPath attribute for physical interfaces:

```
/configuration/interfaces/interface
```

The following is the configuration difference for the XPath attribute of physical interfaces:

```
<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
  <configuration op="U">
    <system>
      <services/>
    </system>
    <chassis/>
    <interfaces op="U">
      <interface op="U">
        <name>ge-0/0/5</name>
        <flexible-vlan-tagging/>
        <mtu op="U">1520</mtu>
        <encapsulation>flexible-ethernet-services</encapsulation>
        <unit>
          <name>29</name>
          <encapsulation>vlan-vpls</encapsulation>
          <vlan-tags>
            <outer>34</outer>
          </vlan-tags>
          <family>
            <vpls>
              <filter>
                <input>
                  <filter-name>filter_in_ge-0/0/5_29</filter-name>
                </input>
              </filter>
            </vpls>
          </family>
        </unit>
      </interface>
    </interfaces>
  </configuration>
</rpc-reply>
```

The following is the changed XPath attribute for the logical unit of an interface:

```
/configuration/interfaces/interface/unit/vlan-tags/outer
```


The following is the configuration difference for the XPath attribute of logical unit of an interface:

```
<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
  <configuration op="U">
    <system>
      <services/>
    </system>
    <chassis/>
    <interfaces op="U">
      <interface op="U">
        <name>ge-0/0/5</name>
        <flexible-vlan-tagging/>
        <mtu>1522</mtu>
        <encapsulation>flexible-ethernet-services</encapsulation>
        <unit op="U">
          <name>29</name>
          <encapsulation>vlan-vpls</encapsulation>
          <vlan-tags op="U">
            <outer op="U">34</outer>
          </vlan-tags>
          <family>
            <vpls>
              <filter>
                <input>
                  <filter-name>filter_in_ge-0/0/5_29</filter-name>
                </input>
              </filter>
            </vpls>
          </family>
        </unit>
      </interface>
    </interfaces>
  </configuration>
</rpc-reply>
```

The following are the changed XPath attributes for a firewall filter at the **[edit firewall family vpls]** hierarchy level:

```
/configuration/firewall/family/vpls/filter/term/then/discard,
/configuration/firewall/family/vpls/filter/term/name
```

The following is the configuration difference for the XPath attribute of a firewall filter in an E-LAN family:

```
<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
  <configuration op="U">
    <system>
      <services/>
    </system>
    <chassis/>
    <interfaces op="U">
      <interface op="U">
        <name>ge-0/0/5</name>
        <flexible-vlan-tagging/>
        <mtu op="U">1520</mtu>
        <encapsulation>flexible-ethernet-services</encapsulation>
        <unit>
          <name>29</name>
          <encapsulation>vlan-vpls</encapsulation>
          <vlan-tags>
            <outer>34</outer>
          </vlan-tags>
          <family>
            <vpls>
              <filter>
                <input>
                  <filter-name>filter_in_ge-0/0/5_29</filter-name>
                </input>
              </filter>
            </vpls>
          </family>
        </unit>
      </interface>
    </interfaces>
  </configuration>
</rpc-reply>
```

The following are the changed XPath attributes for the **policer** statement at the **[edit firewall]** hierarchy level:

```
/configuration/firewall/policer/if-exceeding/bandwidth-percent
/configuration/firewall/policer/if-exceeding/bandwidth-limit
```

The following is the configuration difference for the XPath attribute of a firewall policer:

```
<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
  <configuration op="U">
    <system>
      <services/>
    </system>
    <chassis/>
    <interfaces op="U">
      <interface op="U">
        <name>ge-0/0/5</name>
        <flexible-vlan-tagging/>
        <mtu op="U">1520</mtu>
        <encapsulation>flexible-ethernet-services</encapsulation>
        <unit>
          <name>29</name>
          <encapsulation>vlan-vpls</encapsulation>
          <vlan-tags>
            <outer>34</outer>
          </vlan-tags>
          <family>
            <vpls>
              <filter>
                <input>
                  <filter-name>filter_in_ge-0/0/5_29</filter-name>
                </input>
              </filter>
            </vpls>
          </family>
        </unit>
      </interface>
    </interfaces>
  </configuration>
</rpc-reply>
```

The service instance cannot be determined if the changes to policer occur and in such cases ,you need to determine the type of service and also identify whether the change is to existing service or a new service. You can select a service instance and the operation type (such as create or modify) to recover service for that endpoint. Using changed XPath and applying the differential configuration to the changed XPath, you can determine the type of change and the name of the changed configuration parameter.

RELATED DOCUMENTATION

| [Creating and Handling a Service Recovery Request](#) | 419

Sample XPath Notifications Received on Devices for a Created E-LAN Service

This topic illustrates the differential configuration, which is the delta or the change-set of the configuration that you are about to deploy on the devices, and the XPath attributes associated with the delta configuration for a newly created E-LAN service:

The following are the configuration stanzas and device settings for a newly created E-LAN service at the different hierarchy levels of the CLI interface:

```
[edit interfaces ge-0/1/7]
unit 29 {
  encapsulation vlan-vpls;
  vlan-id 34;
  family vpls {
    filter {
      input filter_in_ge-0/1/7_29;
    }
  }
}
```

```
[edit firewall family vpls]
filter filter_in_ge-0/1/8_102 { ... }
filter filter_in_ge-0/1/7_29 {
  interface-specific;
  term 1 {
    then {
      policer policer_in_ge-0/1/7_29;
      accept;
    }
  }
}
```

```
[edit firewall]
policer policer_in_ge-0/1/8_102 { ... }
policer policer_in_ge-0/1/7_29 {
```

```

if-exceeding {
    bandwidth-limit 10m;
    burst-size-limit 1g;
}
then discard;
}

```

```

[edit routing-instances]
VplsBgpPW {
    instance-type vpls;
    interface ge-0/1/7.29;
    route-distinguisher 36000:23;
    vrf-import VplsBgpPW-import;
    vrf-export VplsBgpPW-export;
    protocols {
        vpls {
            mac-table-size {
                5120;
            }
            interface-mac-limit {
                1024;
            }
            no-mac-learning;
            no-tunnel-services;
            site Site_2 {
                site-identifier 2;
                site-preference primary;
                interface ge-0/1/7.29;
            }
        }
    }
}

```

The following are the changed XPath attributes for a newly created E-LAN service:

```

/configuration/routing-instances/instance/protocols/vpls/mac-table-size/limit
/configuration/firewall/family/vpls/filter/term/name
/configuration/firewall/policer/if-exceeding/burst-size-limit
/configuration/interfaces/interface/unit/name
/configuration/routing-instances/instance/interface/name
/configuration/routing-instances/instance/instance-type
/configuration/firewall/policer/name
/configuration/routing-instances/instance/protocols/vpls/site/interface/name

```

```

/configuration/routing-instances/instance/protocols/vpls/site/site-preference
/configuration/interfaces/interface/unit/vlan-id
/configuration/interfaces/interface/unit/family/vpls/filter/input/filter-name
/configuration/routing-instances/instance/route-distinguisher/rd-type
/configuration/routing-instances/instance/name
/configuration/interfaces/interface/unit/encapsulation
/configuration/routing-instances/instance/vrf-export
/configuration/routing-instances/instance/protocols/vpls/no-mac-learning
/configuration/firewall/policer/then/discard
/configuration/routing-instances/instance/protocols/vpls/site/site-identifier
/configuration/routing-instances/instance/protocols/vpls/interface-mac-limit/limit
/configuration/firewall/family/vpls/filter/name
/configuration/routing-instances/instance/protocols/vpls/no-tunnel-services
/configuration/firewall/family/vpls/filter/interface-specific
/configuration/firewall/family/vpls/filter/term/then/policer
/configuration/firewall/family/vpls/filter/term/then/accept
/configuration/routing-instances/instance/protocols/vpls/site/name
/configuration/routing-instances/instance/vrf-import

```

The following is the differential configuration set for the XPath attributes of a newly created E-LAN service:

```

<?xml version="1.0" encoding="UTF-8"?>
<rpc-reply op="U">
  <configuration op="U">
    <interfaces op="U">
      <interface op="U">
        <name>ge-0/1/7</name>
        <flexible-vlan-tagging/>
        <mtu>1522</mtu>
        <encapsulation>flexible-ethernet-services</encapsulation>
        <unit op="C">
          <name op="C">29</name>
          <encapsulation op="C">vlan-vpls</encapsulation>
          <vlan-id op="C">34</vlan-id>
          <family op="C">
            <vpls op="C">
              <filter op="C">
                <input op="C">
                  <filter-name op="C">filter_in_ge-0/1/7_29</filter-name>
                </input>
              </filter>
            </vpls>
          </family>
        </unit>
      </interface>
    </interfaces>
  </configuration>
</rpc-reply>

```

```

        </family>
    </unit>
</interface>
</interfaces>
<firewall op="U">
    <family op="U">
        <vpls op="U">
            <filter op="C">
                <name op="C">filter_in_ge-0/1/7_29</name>
                <interface-specific op="C"/>
                <term op="C">
                    <name op="C">1</name>
                    <then op="C">
                        <policer op="C">policer_in_ge-0/1/7_29</policer>
                        <accept op="C"/>
                    </then>
                </term>
            </filter>
        </vpls>
    </family>
    <policer op="C">
        <name op="C">policer_in_ge-0/1/7_29</name>
        <if-exceeding op="C">
            <bandwidth-limit op="C">10m</bandwidth-limit>
            <burst-size-limit op="C">1g</burst-size-limit>
        </if-exceeding>
        <then op="C">
            <discard op="C"/>
        </then>
    </policer>
</firewall>
<routing-instances op="U">
    <instance op="C">
        <name op="C">VplsBgpPW</name>
        <instance-type op="C">vpls</instance-type>
        <interface op="C">
            <name op="C">ge-0/1/7.29</name>
        </interface>
        <route-distinguisher op="C">
            <rd-type op="C">36000:23</rd-type>
        </route-distinguisher>
        <vrf-import op="C">VplsBgpPW-import</vrf-import>
        <vrf-export op="C">VplsBgpPW-export</vrf-export>
        <protocols op="C">

```

```

    <vpls op="C">
      <mac-table-size op="C">
        <limit op="C">5120</limit>
      </mac-table-size>
      <interface-mac-limit op="C">
        <limit op="C">1024</limit>
      </interface-mac-limit>
      <no-mac-learning op="C"/>
      <no-tunnel-services op="C"/>
      <site op="C">
        <name op="C">Site_2</name>
        <site-identifier op="C">2</site-identifier>
        <site-preference op="C">primary</site-preference>
        <interface op="C">
          <name op="C">ge-0/1/7.29</name>
        </interface>
      </site>
    </vpls>
  </protocols>
</instance>
</routing-instances>
</configuration>
</rpc-reply>

```

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request](#) | 419

Sample XPath Notifications Received on Devices for a Created IP Service

This topic illustrates the differential configuration, which is the delta or the change-set of the configuration that you are about to deploy on the devices, and the XPath attributes associated with the delta configuration for a newly created IP service:

The following is the changed XPath attribute for routing instances of a newly created IP service:

```
/configuration/routing-instances/instance/route-distinguisher/rd-type
```


For the **policy- statement** statement at the **[edit policy-options]** hierarchy level, the correct XPath Notification is not received if changes happen only to the policy-statement. The notification does not contain the changed XPath and configuration difference. Therefore, it is not possible to determine the instance of service impacted due to the change (when only localized to **policy-options->policy-statement**). Full service recovery is recommended in such cases.

The following is the changed XPath attribute for physical interfaces:

```
/configuration/interfaces/interface/mtu
```

The following is the changed XPath attribute for the logical unit of interfaces:

```
/configuration/interfaces/interface/unit/description
```

The following are the changed XPath attributes for the **policer** statement at the **[edit firewall]** hierarchy level:

```
/configuration/firewall/policer/if-exceeding/bandwidth-percent  
/configuration/firewall/policer/if-exceeding/bandwidth-limit
```

The service instance cannot be determined if the changes to policer occur and in such cases ,you need to determine the type of service and also identify whether the change is to existing service or a new service. You can select a service instance and the operation type (such as create or modify) to recover service for that endpoint. Using changed XPath and applying the differential configuration to the changed XPath, you can determine the type of change and the name of the changed configuration parameter.

RELATED DOCUMENTATION

| [Creating and Handling a Service Recovery Request](#) | 419

Sample XPath Notifications Received on Devices for a Created E-Line Service

This topic illustrates the differential configuration, which is the delta or the change-set of the configuration that you are about to deploy on the devices, and the XPath attributes associated with the delta configuration for a newly created E-Line service. The following two scenarios need to be handled for E-Line services. Accordingly, the mechanism to identify impacted services is implemented.

- A or Z endpoint of the existing service
- A pseudowire extension for E-LAN or E-LAN services

The following is the changed XPath attribute for Layer 2 circuit of a newly created E-Line service:

```
/configuration/protocols/l2circuit/neighbor/interface/description
```

The following is the configuration difference corresponding to the XPath attribute for Layer 2 circuit:

```
<protocols op="U">
  <l2circuit op="U">
    <neighbor op="U">
      <name>128.220.3.158</name>
      <interface>
        <name>ge-0/1/5.560</name>
        <virtual-circuit-id>1</virtual-circuit-id>
        <mtu>1522</mtu>
      </interface>
      <interface>
        <name>ge-0/1/5.512</name>
        <virtual-circuit-id>2</virtual-circuit-id>
        <mtu>1522</mtu>
      </interface>
      <interface op="U">
        <name>ge-0/0/3.0</name>
        <virtual-circuit-id>221</virtual-circuit-id>
        <description op="U">TestP2P2</description>
        <community>R2-to-R1</community>
        <mtu>1522</mtu>
      </interface>
    </neighbor>
  </l2circuit>
</protocols>
```

For the **policy- statement** statement at the **[edit policy-options]** hierarchy level, the correct XPath Notification is not received if changes happen only to the policy-statement. The notification does not contain the changed XPath and configuration difference. Therefore, it is not possible to determine the instance of service impacted due to the change (when only localized to **policy-options->policy-statement**). Full service recovery is recommended in such cases.

The following is the changed XPath attribute for physical interfaces:

```
/configuration/interfaces/interface/mtu
```

The following is the changed XPath attribute for the logical unit of interfaces:

```
/configuration/interfaces/interface/unit/description
```

The following are the changed XPath attributes for the **policer** statement at the **[edit firewall]** hierarchy level:

```
/configuration/firewall/policer/if-exceeding/bandwidth-percent  
/configuration/firewall/policer/if-exceeding/bandwidth-limit
```

The following are the changed XPath attributes for the **filter** statement at the **[edit firewall family family-name filter filter-name term term-name]** hierarchy level

```
/configuration/firewall/filter
```

The service instance cannot be determined if the changes to policer occur and in such cases ,you need to determine the type of service and also identify whether the change is to existing service or a new service. You can select a service instance and the operation type (such as create or modify) to recover service for that endpoint. Using changed XPath and applying the differential configuration to the changed XPath, you can determine the type of change and the name of the changed configuration parameter.

RELATED DOCUMENTATION

| [Creating and Handling a Service Recovery Request](#) | 419

Sample XPath Notifications Received on Devices for CFM Profiles Associated with an E-Line Service

This topic illustrates the differential configuration, which is the delta or the change-set of the configuration that you are about to deploy on the devices, and the XPath attributes associated with the delta configuration for CFM profiles associated with an E-Line service:

The following is the changed XPath attribute for CFM profiles of an E-Line service:

```
/configuration/protocols/oam/ethernet/connectivity-fault-management/maintenance-domain/
maintenance-association/continuity-check/loss-threshold
```

The following is the configuration difference corresponding to the XPath attribute for CFM profiles associated with an E-Line service:

```
<protocols op="U">
  <oam op="U">
    <ethernet op="U">
      <connectivity-fault-management op="U">
        <maintenance-domain op="U">
          <name>Default-Domain</name>
          <level>1</level>
          <maintenance-association>
            <name>PW_1001_P2P-CFM992015-12-30-05</name>
            <continuity-check>
              <interval>1s</interval>
              <loss-threshold>3</loss-threshold>
              <hold-interval>10</hold-interval>
            </continuity-check>
            <mep>
              <name>1</name>
              <interface>
                <interface-name>ge-0/0/5.1</interface-name>
              </interface>
              <direction>up</direction>
              <auto-discovery/>
              <lowest-priority-defect>all-defects</lowest-priority-defect>
            </mep>
          </maintenance-association>
          <maintenance-association>
            <name>PW_101_P2P-Asym-CFM2015-12-30-05</name>
            <continuity-check>
```

```

        <interval>1s</interval>
        <loss-threshold>3</loss-threshold>
        <hold-interval>10</hold-interval>
    </continuity-check>
    <mep>
        <name>3</name>
        <interface>
            <interface-name>ge-0/0/4.0</interface-name>
        </interface>
        <direction>up</direction>
        <auto-discovery/>
        <lowest-priority-defect>all-defects</lowest-priority-defect>
    </mep>
</maintenance-association>
<maintenance-association op="U">
    <name>PW_221_P2PService1</name>
    <continuity-check op="U">
        <interval>1s</interval>
        <loss-threshold op="U">5</loss-threshold>
        <hold-interval>10</hold-interval>
    </continuity-check>
    <mep>
        <name>1</name>
        <interface>
            <interface-name>ge-0/0/2.0</interface-name>
        </interface>
        <direction>up</direction>
        <auto-discovery/>
        <lowest-priority-defect>all-defects</lowest-priority-defect>
    </mep>
</maintenance-association>
</maintenance-domain>
</connectivity-fault-management>
</ethernet>
</oam>
</protocols>

```

RELATED DOCUMENTATION

Creating and Handling a Service Recovery Request | 419

Sample XPath Notifications Received on Devices for CoS Profiles Associated with an E-Line Service

This topic illustrates the differential configuration, which is the delta or the change-set of the configuration that you are about to deploy on the devices, and the XPath attributes associated with the delta configuration for CoS profiles associated with an E-Line service:

The following is the changed XPath attribute for CoS profiles of an E-Line service:

```
/configuration/class-of-service/interfaces/interface/shaping-rate/rate
```

The following is the configuration difference corresponding to the XPath attribute for CoS profiles associated with an E-Line service:

```
<class-of-service op="U">
  <interfaces op="U">
    <interface op="U">
      <name>ge-0/0/3</name>
      <scheduler-map>nd_schedulerMap</scheduler-map>
      <unit>
        <name>513</name>
        <classifiers>
          <dscp>
            <name>dscp_nd_classifer</name>
          </dscp>
        </classifiers>
      </unit>
      <shaping-rate op="C">
        <rate op="C">160001</rate>
      </shaping-rate>
    </interface>
  </interfaces>
</class-of-service>
```

RELATED DOCUMENTATION

[Creating and Handling a Service Recovery Request](#) | 419

7

PART

Service Design: Working with Service Definitions

Service Design: Predefined Service Definitions | **479**

Service Design: Managing E-Line Service Definitions | **645**

Service Design: Managing E-LAN Service Definitions | **696**

Service Design: Managing IP Service Definitions | **765**

Service Design: Predefined Service Definitions

IN THIS CHAPTER

- [Predefined Service Definitions | 479](#)
- [Predefined E-Line Service Definitions | 548](#)
- [Predefined Multipoint-to-Multipoint Ethernet Service Definitions | 592](#)
- [Predefined Point-to-Multipoint Ethernet Service Definitions | 625](#)
- [Predefined Full Mesh IP Service Definitions | 642](#)
- [Predefined Hub-and-Spoke IP Service Definitions | 643](#)

Predefined Service Definitions

Connectivity Services Director provides predefined service definitions that a service provisioner can use when creating a service order.

If none of the predefined service definitions is appropriate for your needs, you can create a service definition as described in *Creating an E-Line Service Definition*, “[Creating a Point-to-Multipoint E-LAN Service Definition](#)” on page 726, or “[Creating a Service Definition for VPLS Access into Layer 3 Networks](#)” on page 760.

The Junos Space Connectivity Services Director product provides predefined service definitions for E-Line services and for E-LAN services. The following sections describe these service definitions:


- [E-Line Predefined Service Definitions on page 479](#)
- [Multipoint-to-Multipoint Predefined Service Definitions on page 511](#)
- [Point-to-Multipoint Service Definitions on page 544](#)

E-Line Predefined Service Definitions

The Ethernet Activator software provides predefined service definitions for E-Line services that use LDP switching in the network core. These services are sometimes known as E-Line Martini services.

[Figure 17 on page 480](#) shows an example of such a service.

Figure 17: E-Line Service



Information specific to each service instance, such as the device name, endpoint name, and customer VLAN ID, is provided in the service order. Attributes that can apply across many service instances are typically defined in the service definition. These attributes include:

- Ethernet option (dot1.q, port-port, qinq, asymmetric tag depth)
- Traffic type (single vlan, vlan range, all traffic, Transport vlan List)
- Physical interface encapsulation
- Logical interface encapsulation
- Rate limit range

[Table 66 on page 480](#) lists each of the standard E-Line service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 66: Standard Service Definitions

Standard Service Definition Name	Service Attributes
"ELine-Dot1q-SingleVLAN" on page 482	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
"ELine-Dot1q-SingleVLAN-CCC" on page 485	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 66: Standard Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELine-Dot1q-SingleVLAN-Ext-CCC” on page 488	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Extended-vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-PortBased” on page 491	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • Port-based UNI • Ethernet-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-AllVLAN” on page 494	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-AllVLAN-CCC” on page 497	<ul style="list-style-type: none"> • E-Line service for J series, M Series, and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-AllVLAN-Ext-CCC” on page 500	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Extended-vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 66: Standard Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELine-QinQ-VLANRange” on page 503	<ul style="list-style-type: none"> • E-Line service for MX Series devices only • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • Customer traffic is range of VLANs • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-VLANRange-CCC” on page 506	<ul style="list-style-type: none"> • E-Line service for MX Series devices only • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • Customer traffic is range of VLANs • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-VLANRange-Ext-CCC” on page 509	<ul style="list-style-type: none"> • E-Line service for MX Series devices only • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • Customer traffic is range of VLANs • Extended-vlan-ccc physical encapsulation • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

ELine-Dot1q-SingleVLAN**IN THIS SECTION**

- [Configuration on Endpoint A | 483](#)
- [Configuration on Endpoint Z | 484](#)

This service definition provides a base for creating E-Line services that transport a single VLAN across an LDP network core using 802.1Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "Dot1q Eline Martini ";
        encapsulation vlan-ccc;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
}

family ccc {
    filter filter_in_ge-0/1/1_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/1_1;
                accept;
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40
        interface ge-0/1/1.1 {
            virtual-circuit-id 786;
            no-control-word;
        }
    }
}

```

```

        mtu 1522;
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "Dot1q Eline Martini ";
        encapsulation vlan-ccc;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
}

family ccc {
    filter filter_in_ge-0/1/1_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/1_1;
                accept;
            }
        }
    }
}

```

```

    }

    protocols {
        l2circuit {
            neighbor 192.168.1.30 {
                interface ge-0/1/1.1 {
                    virtual-circuit-id 786;
                    no-control-word;
                    mtu 1522;
                }
            }
        }
    }
}

```

ELine-Dot1q-SingleVLAN-CCC

IN THIS SECTION

- [Configuration on Endpoint A | 485](#)
- [Configuration on Endpoint Z | 487](#)

This service definition provides a base for creating E-Line services that transport a single VLAN across an LDP network core using 802.1Q endpoint interface types and vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 513 {
        description VLANCCC-SR;
        encapsulation vlan-ccc;
    }
}

```

```

        vlan-id 513;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_513;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_513 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_513 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_513;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.513 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation vlan-ccc;
  unit 513 {
    description VLANCCC-SR;
    encapsulation vlan-ccc;
    vlan-id 513;
    family ccc {
      filter {
        input filter_in_ge-0/1/1_513;
      }
    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_513 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_513 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_513;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.30 {

```



```

        interface ge-0/1/1.513 {
            virtual-circuit-id 786;
            no-control-word;
            mtu 1522;
        }
    }
}

```

ELine-Dot1q-SingleVLAN-Ext-CCC

IN THIS SECTION

- Configuration on Endpoint A | 488
- Configuration on Endpoint Z | 490

This service definition provides a base for creating E-Line services that transport a single VLAN across an LDP network core using 802.1Q endpoint interface types and extended-vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Extended-SR;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

```

```

    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_1 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_1 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_1;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.40 {
      interface ge-0/1/1.1 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Extended-SR;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.1 {

```

```

        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
    }
}
}
}

```

ELine-PortBased

IN THIS SECTION

- Configuration on Endpoint A | 491
- Configuration on Endpoint Z | 492

This service definition provides a base for creating E-Line services that transport all traffic across an LDP network core using an entire port at each endpoint using ethernet-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps to 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    encapsulation ethernet-ccc;
    unit 0 {
        family ccc {
            filter {
                input filter_in_ge-0/1/1;
            }
        }
    }
}

firewall {

```

```

    policer policer_in_ge-0/1/1 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 6250000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.0 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    encapsulation ethernet-ccc;
    unit 0 {
        family ccc {
            filter {

```

```

        input filter_in_ge-0/1/1;
    }
}
}

firewall {
    policer policer_in_ge-0/1/1 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 6250000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.0 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}
}

```

ELine-QinQ-AllVLAN**IN THIS SECTION**

- Configuration on Endpoint A | 494
- Configuration on Endpoint Z | 495

This service definition provides a base for creating E-Line services that transport all customer traffic across an LDP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation flexible-ethernet-services;
  unit 1 {
    description "AllVlanTransport";
    encapsulation vlan-ccc;
    vlan-tags outer 1;
    family ccc {
      filter {
        input filter_in_ge-0/1/1_1;
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.40 {
      interface ge-0/1/1.1 {
        virtual-circuit-id 786;
        no-control-word;
      }
    }
  }
}
```

```

        mtu 1522;
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "AllVlanTransport";
        encapsulation vlan-ccc;
        vlan-tags outer 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

```



```

    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.1 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

*ELine-QinQ-AllVLAN-CCC***IN THIS SECTION**

- Configuration on Endpoint A | 497
- Configuration on Endpoint Z | 498

This service definition provides a base for creating E-Line services that transport all customer traffic across an LDP network core using Q-in-Q endpoint interface types and vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 515 {
        description QinQ-ALLVLAN;
        encapsulation vlan-ccc;
        vlan-tags outer 515;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_515;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_515 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}

```

```

        then discard;
    }

    family ccc {
        filter filter_in_ge-0/1/1_515 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_515;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.515 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 515 {
        description QinQ-ALLVLAN;
        encapsulation vlan-ccc;
        vlan-tags outer 515;
        family ccc {
            filter {

```

```

        input filter_in_ge-0/1/1_515;
    }
}

firewall {
    policer policer_in_ge-0/1/1_515 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_515 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_515;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.515 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

*ELine-QinQ-AllVLAN-Ext-CCC***IN THIS SECTION**

- Configuration on Endpoint A | 500
- Configuration on Endpoint Z | 501

This service definition provides a base for creating E-Line services that transport all customer traffic across an LDP network core using Q-in-Q endpoint interface types and extended-vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Ext-AllVLAN;
        vlan-tags outer 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}
```

```

        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.1 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Ext-AllVLAN;
        vlan-tags outer 1;
        family ccc {

```

```

        filter {
            input filter_in_ge-0/1/1_1;
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.1 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

ELine-QinQ-VLANRange**IN THIS SECTION**

- Configuration on Endpoint A | 503
- Configuration on Endpoint Z | 504

This service definition provides a base for creating E-Line services that transport a range of VLANs across an LDP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 2 {
        description "QinQ Eline Martini";
        encapsulation vlan-ccc;
        vlan-tags outer 2 inner-range 100-110;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_2;
            }
        }
    }
}
```

```
firewall {
    policer policer_in_ge-0/1/1_2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}
```



```

    }

family ccc {
    filter filter_in_ge-0/1/1_2 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/1_2;
                accept;
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.2 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 2 {
        description "QinQ Eline Martini";
        encapsulation vlan-ccc;
        vlan-tags outer 2 inner-range 100-110;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_2;
            }
        }
    }
}

```

```

}

firewall {
    policer policer_in_ge-0/1/1_2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }

    family ccc {
        filter filter_in_ge-0/1/1_2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_2;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        interface ge-0/1/1.2 {
            virtual-circuit-id 786;
            no-control-word;
            mtu 1522;
        }
    }
}

```

*ELine-QinQ-VLANRange-CCC***IN THIS SECTION**

- Configuration on Endpoint A | 506
- Configuration on Endpoint Z | 507

This service definition provides a base for creating E-Line services that transport a range of VLANs across an LDP network core using Q-in-Q endpoint interface types and vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation vlan-ccc;
  unit 514 {
    description VLANRANGE-SR;
    encapsulation vlan-ccc;
    vlan-tags outer 514 inner-range 600-610;
    family ccc {
      filter {
        input filter_in_ge-0/1/1_514;
      }
    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_514 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
  }
}

```

```

        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_514 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_514;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.514 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 514 {
        description VLANRANGE-SR;
        encapsulation vlan-ccc;
        vlan-tags outer 514 inner-range 600-610;
        family ccc {
            filter {

```

```

        input filter_in_ge-0/1/1_514;
    }
}
}

firewall {
    policer policer_in_ge-0/1/1_514 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_514 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_514;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.514 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

ELine-QinQ-VLANRange-Ext-CCC**IN THIS SECTION**

- Configuration on Endpoint A | 509
- Configuration on Endpoint Z | 510

This service definition provides a base for creating E-Line services that transport a range of VLANs across an LDP network core using Q-in-Q endpoint interface types and extended-vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation extended-vlan-ccc;
  unit 2 {
    description Ext-VLANRange;
    vlan-tags outer 2 inner-range 100-110;
    family ccc {
      filter {
        input filter_in_ge-0/1/1_2;
      }
    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_2 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
  }
}
```

```

    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_2 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_2;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.30 {
      interface ge-0/1/1.2 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation extended-vlan-ccc;
  unit 2 {
    description Ext-VLANRange;
    vlan-tags outer 2 inner-range 100-110;
    family ccc {
      filter {
        input filter_in_ge-0/1/1_2;

```

```

    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_2 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_2 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_2;
          accept;
        }
      }
    }
  }
}


protocols {
  l2circuit {
    neighbor 192.168.1.30 {
      interface ge-0/1/1.2 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

Multipoint-to-Multipoint Predefined Service Definitions

The Ethernet Activator software provides predefined service definitions for E-LAN services that use BGP switching in the network core. This section covers multipoint-to-multipoint (or full mesh) service definitions. [Figure 18 on page 512](#) shows an example of such a service.

Figure 18: Multipoint—to—Multipoint Service



Information specific to each service instance, such as the device name, endpoint name, and customer VLAN ID, is provided in the service order. Attributes that can apply across many service instances are typically defined in the service definition. These attributes include:

- Ethernet option (dot1.q, port-port, qinq, asymmetric tag depth)
- Traffic type (single vlan, vlan range, all traffic, transport vlan list)
- VLAN normalization
- Physical interface encapsulation
- Logical interface encapsulation
- Rate limit range

[Table 67 on page 513](#) lists each of the standard E-LAN service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 67: Standard Service Definitions

Standard Service Definition Name	Service Attributes
“ELAN-BGP-Dot1q-Normalized-VLAN-None” on page 514	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are not preserved • 802.1Q endpoint interface types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-Dot1Q-SingleVLAN” on page 519	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series or MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-PortBased” on page 523	<ul style="list-style-type: none"> • Multipoint Ethernet service for M series and MX Series devices • Gigabit Ethernet interfaces • Port-based UNIs • Transports all customer traffic • E-LAN as physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-QinQ-AllVLAN” on page 528	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 67: Standard Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELAN-BGP-QinQ-AllVLAN-Normalized-All” on page 532	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-QinQ-AllVLAN-Normalized-None” on page 537	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • VLAN IDs not preserved • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-QinQ-Range-Normalized-VLAN” on page 541	<ul style="list-style-type: none"> • Multipoint Ethernet service for MX Series devices only • Gigabit Ethernet interfaces • Customer VLAN IDs preserved • Q-in-Q endpoint interface types • Transports specified VLAN range • Flexible Ethernet services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

ELAN-BGP-Dot1q-Normalized-VLAN-None**IN THIS SECTION**

- [Configuration on Endpoint A | 515](#)
- [Configuration on Endpoint B | 516](#)
- [Configuration on Endpoint Z | 517](#)

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport traffic from a single VLAN on an endpoint across a BGP network core using 802.1Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. VLAN IDs are not preserved across the network—traffic passes from the single VLAN on an endpoint to any VLANs in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```
ge-0/0/1 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/1_1;
                    accept;
                }
            }
        }
    }
}
```

```

    }
  }
}
routing-instances {
  BestCustomer_ELAN-BGP-Dot1q-Normalized-VLAN-SR {
    instance-type vpls;
    interface ge-0/0/1.1;
    route-distinguisher 65410:1;
    vrf-target target:65410:0;
    protocols {
      vpls {
        no-tunnel-services;
        site Site_2 {
          site-identifier 2;
          site-preference primary;
          interface ge-0/0/1.1;
        }
      }
    }
  }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/0/1 {
  flexible-vlan-tagging;
  encapsulation flexible-ethernet-services;
  unit 1 {
    encapsulation vlan-vpls;
    vlan-id 1;
    family vpls {
      filter {
        input filter_in_ge-0/0/1_1;
      }
    }
  }
}

firewall {
  policer policer_in_ge-0/0/1_1 {
    if-exceeding {

```

```

        bandwidth-limit 100m;
        burst-size-limit 62500000;
    }
    then discard;
}
family vpls {
    filter filter_in_ge-0/0/1_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/1_1;
                accept;
            }
        }
    }
}
}
routing-instances {
    BestCustomer_ELAN-BGP-Dot1q-Normalized-VLAN-SR {
        instance-type vpls;
        interface ge-0/0/1.1;
        route-distinguisher 65410:0;
        vrf-target target:65410:0;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/0/1.1;
                }
            }
        }
    }
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

SJC:

```

ge-0/0/1 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/1_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-Dot1q-Normalized-VLAN-SR {
        instance-type vpls;
        interface ge-0/0/1.1;
        vlan-id none;
        route-distinguisher 65410:2;
        vrf-target target:65410:0;
        protocols {
            vpls {
                no-tunnel-services;
            }
        }
    }
}

```

```

        site Site_3 {
            site-identifier 3;
            site-preference primary;
            interface ge-0/0/1.1;
        }
    }
}

```

ELAN-BGP-Dot1Q-SingleVLAN

IN THIS SECTION

- Configuration on Endpoint A | 519
- Configuration on Endpoint B | 521
- Configuration on Endpoint Z | 522

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport traffic on a single VLAN across a BGP network core using 802.1Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. No VLAN mapping is performed—the VLAN ID must be the same on all endpoints. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```

ge-0/0/2 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/2_1;
            }
        }
    }
}

```



```

    }
  }
}

firewall {
  policer policer_in_ge-0/0/2_1 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }

  filter filter_in_ge-0/0/2_1 {
    interface-specific;
    term 1 {
      then {
        policer policer_in_ge-0/0/2_1;
        accept;
      }
    }
  }
}

routing-instances {
  BestCustomer_ELAN-BGP-Dot1Q-SingleVLAN-SR {
    instance-type vpls;
    interface ge-0/0/2.1;
    route-distinguisher 65410:4;
    vrf-target target:65410:1;
    protocols {
      vpls {
        no-tunnel-services;
        site Site_2 {
          site-identifier 2;
          site-preference primary;
          interface ge-0/0/2.1;
        }
      }
    }
  }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/0/2 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/2_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/2_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    filter filter_in_ge-0/0/2_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/2_1;
                accept;
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-Dot1Q-SingleVLAN-SR {
        instance-type vpls;
        interface ge-0/0/2.1;
        route-distinguisher 65410:3;
        vrf-target target:65410:1;
    }
}

```

```

protocols {
    vpls {
        no-tunnel-services;
        site Site_1 {
            site-identifier 1;
            site-preference primary;
            interface ge-0/0/2.1;
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/2 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/2_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/2_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/2_1 {
            interface-specific;
            term 1 {

```


The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```

ge-0/1/3 {
    mtu 1522;
    encapsulation ethernet-vpls;
    unit 0 {
        family vpls {
            filter {
                input filter_in_ge-0/1/3;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/3 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 15220;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/3 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/3;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    ELAN_BGP_PortBased_10_100M {
        instance-type vpls;
        interface ge-0/1/3.0;
        route-distinguisher 65410:3;
    }
}

```

```

vrf-target target:65410:1;
protocols {
    vpls {
        no-tunnel-services;
        site Site_2 {
            site-identifier 2;
            site-preference primary;
            interface ge-0/1/3.0;
        }
    }
}
}
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/1/3 {
    mtu 1522;
    encapsulation ethernet-vpls;
    unit 0 {
        family vpls {
            filter {
                input filter_in_ge-0/1/3;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/3 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 15220;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/3 {
            interface-specific;
        }
    }
}

```



```

    }

}

firewall {
    policer policer_in_ge-0/2/2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 15220;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/2/2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/2/2;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    ELAN_BGP_PortBased_10_100M {
        instance-type vpls;
        interface ge-0/2/2.0;
        route-distinguisher 65410:4;
        vrf-target target:65410:1;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/2/2.0;
                }
            }
        }
    }
}

```


ELAN-BGP-QinQ-AllVLAN

IN THIS SECTION

- Configuration on Endpoint A | 528
- Configuration on Endpoint B | 529
- Configuration on Endpoint Z | 531

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. No VLAN mapping is performed—customer VLAN IDs and service provider VLAN IDs must match on each endpoint that is to send or receive traffic. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```
ge-0/1/1 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}
```

```

    }
    then discard;
  }
  family vpls {
    filter filter_in_ge-0/1/1_1 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_1;
          accept;
        }
      }
    }
  }
}
routing-instances {
  BestCustomer_ELAN-BGP-QinQ-AllVLAN-SR {
    instance-type vpls;
    interface ge-0/1/1.1;
    route-distinguisher 65410:13;
    vrf-target target:65410:4;
    protocols {
      vpls {
        no-tunnel-services;
        site Site_2 {
          site-identifier 2;
          site-preference primary;
          interface ge-0/1/1.1;
        }
      }
    }
  }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/1/1 {
  flexible-vlan-tagging;
  encapsulation flexible-ethernet-services;
  unit 1 {

```

```

        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-SR {
        instance-type vpls;
        interface ge-0/1/1.1;
        route-distinguisher 65410:12;
        vrf-target target:65410:4;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/1/1.1;
                }
            }
        }
    }
}

```

```

    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/5 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/5_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/5_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/5_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/5_1;
                    accept;
                }
            }
        }
    }
}

```

```

}
routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-SR {
        instance-type vpls;
        interface ge-0/0/5.1;
        route-distinguisher 65410:14;
        vrf-target target:65410:4;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/5.1;
                }
            }
        }
    }
}

```

ELAN-BGP-QinQ-AllVLAN-Normalized-All

IN THIS SECTION

- [Configuration on Endpoint A | 533](#)
- [Configuration on Endpoint B | 534](#)
- [Configuration on Endpoint Z | 535](#)

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Customer VLAN IDs are preserved across the network—traffic passes only among matching customer VLAN IDs. However, traffic can pass among any service provider VLAN ID in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```

ge-0/1/0 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/0_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/0_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/0_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/0_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-All-SR {
        instance-type vpls;
        interface ge-0/1/0.1;
        route-distinguisher 65410:10;
        vrf-target target:65410:3;
    }
}

```

```

protocols {
    vpls {
        no-tunnel-services;
        site Site_2 {
            site-identifier 2;
            site-preference primary;
            interface ge-0/1/0.1;
        }
    }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/1/0 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/0_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/0_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/0_1 {
            interface-specific;
            term 1 {

```



```

    }
    firewall {
        policer policer_in_ge-0/0/4_1 {
            if-exceeding {
                bandwidth-limit 100m;
                burst-size-limit 62500000;
            }
            then discard;
        }
        family vpls {
            filter filter_in_ge-0/0/4_1 {
                interface-specific;
                term 1 {
                    then {
                        policer policer_in_ge-0/0/4_1;
                        accept;
                    }
                }
            }
        }
    }
}
routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-All-SR {
        instance-type vpls;
        interface ge-0/0/4.1;
        vlan-id all;
        route-distinguisher 65410:11;
        vrf-target target:65410:3;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/4.1;
                }
            }
        }
    }
}

```

ELAN-BGP-QinQ-AllVLAN-Normalized-None**IN THIS SECTION**

- Configuration on Endpoint A | 537
- Configuration on Endpoint B | 538
- Configuration on Endpoint Z | 540

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. VLAN IDs are not preserved across the network—traffic passes between any customer VLAN or service provider VLAN in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```
ge-0/0/3 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/3_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/3_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}
```

```

        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/3_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/3_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-SR {
        instance-type vpls;
        interface ge-0/0/3.1;
        route-distinguisher 65410:7;
        vrf-target target:65410:2;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_2 {
                    site-identifier 2;
                    site-preference primary;
                    interface ge-0/0/3.1;
                }
            }
        }
    }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/0/3 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
    }
}

```

```

        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/3_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/3_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/3_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/3_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-SR {
        instance-type vpls;
        interface ge-0/0/3.1;
        route-distinguisher 65410:6;
        vrf-target target:65410:2;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/0/3.1;
                }
            }
        }
    }
}

```

```

    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/3 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/3_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/3_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/3_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/3_1;
                    accept;
                }
            }
        }
    }
}
}

```

```

routing-instances {
  BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-SR {
    instance-type vpls;
    interface ge-0/0/3.1;
    vlan-id none;
    route-distinguisher 65410:8;
    vrf-target target:65410:2;
    protocols {
      vpls {
        no-tunnel-services;
        site Site_3 {
          site-identifier 3;
          site-preference primary;
          interface ge-0/0/3.1;
        }
      }
    }
  }
}

```

ELAN-BGP-QinQ-Range-Normalized-VLAN

IN THIS SECTION

- [Configuration on Endpoint A | 542](#)
- [Configuration on Endpoint Z | 543](#)

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport traffic from a range of VLANs on an endpoint across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Services built from this service definition must use MX Series devices on the provider edge. Customer VLAN IDs are preserved across the network—traffic passes among like customer VLAN IDs on any service provider VLAN in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data for a service with only two endpoints, SJC and SFO.

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device SJC):

```

ge-0/0/6 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 2 {
        encapsulation vlan-vpls;
        vlan-tags outer 2 inner-range 1500-2000;
        family vpls {
            filter {
                input filter_in_ge-0/0/6_2;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/6_2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/6_2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/6_2;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-Range-Normalized-VLAN-SR1 {
        instance-type vpls;
        vlan-id all;
        interface ge-0/0/6.2;
    }
}

```

```

vlan-id all;
route-distinguisher 65410:19;
vrf-target target:65410:6;
protocols {
    vpls {
        no-tunnel-services;
        site Site_2 {
            site-identifier 2;
            site-preference primary;
            interface ge-0/0/6.2;
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SFO):

```

ge-0/0/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1 inner-range 1500-2000;
        family vpls {
            filter {
                input filter_in_ge-0/0/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
}

```



```

    }
    family vpls {
        filter filter_in_ge-0/0/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/1_1;
                    accept;
                }
            }
        }
    }
}


routing-instances {
    BestCustomer_ELAN-BGP-QinQ-Range-Normalized-VLAN-SR1 {
        instance-type vpls;
        vlan-id all;
        interface ge-0/0/1.1;
        route-distinguisher 65410:18;
        vrf-target target:65410:6;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/0/1.1;
                }
            }
        }
    }
}

```

Point-to-Multipoint Service Definitions

The Ethernet Activator software provides predefined service definitions for E-LAN services that use BGP switching in the network core. This section covers point-to-multipoint (or hub and spoke) service definitions. [Figure 19 on page 545](#) shows an example of such a service.

Figure 19: Point-to-Multipoint Service



Information specific to each service instance, such as the device name, endpoint name, customer VLAN ID, and whether a specific endpoint is a hub or a spoke is provided in the service order. Attributes that can apply across many service instances are typically defined in the service definition. These attributes include:

- Ethernet option (dot1.q, port-port, qinq, asymmetric tag depth)
- Traffic type (single vlan, vlan range, all traffic, transport vlan list)
- VLAN normalization
- Physical interface encapsulation
- Logical interface encapsulation
- Rate limit range

[Table 68 on page 546](#) lists each of the standard E-LAN service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 68: Standard Service Definitions

Standard Service Definition Name	Service Attributes
“ELAN-Hub-Spoke-QinQ-AllVLAN” on page 546	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are not preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-Hub-Spoke-QinQ-AllVLAN-No” on page 547	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series or MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

ELAN-Hub-Spoke-QinQ-AllVLAN

IN THIS SECTION

- [Configuration on Endpoint A | 547](#)
- [Configuration on Endpoint B | 547](#)
- [Configuration on Endpoint Z | 547](#)

This service definition provides a base for creating point-to-multipoint Ethernet services that transport all traffic on an endpoint across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Customer VLAN IDs are preserved across the network—traffic passes among like customer VLAN IDs on any service provider VLAN in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 19 on page 545](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

ELAN-Hub-Spoke-QinQ-AllVLAN-No**IN THIS SECTION**

- [Configuration on Endpoint A | 547](#)
- [Configuration on Endpoint B | 547](#)
- [Configuration on Endpoint Z | 547](#)

This service definition provides a base for creating point-to-multipoint Ethernet services that transport all traffic on an endpoint across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. VLAN IDs are not preserved across the network—traffic passes from the single VLAN on an endpoint to any VLANs in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 19 on page 545](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A(device IND):

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

RELATED DOCUMENTATION

[Creating an E-Line Service Definition](#)

[Creating a Multipoint-to-Multipoint E-LAN Service Definition](#) | 696

Predefined E-Line Service Definitions


The Connectivity Services Director application provides predefined service definitions that a service provisioner can choose from when creating a service order. This section provides information about predefined service definitions used for creating E-Line services. For information about predefined service definitions used to create other types of service, see the following topics:

- [Predefined Multipoint-to-Multipoint Ethernet Service Definitions on page 592](#)
- [Predefined Point-to-Multipoint Ethernet Service Definitions on page 625](#)
- [Predefined Full Mesh IP Service Definitions on page 642](#)
- [Predefined Hub-and-Spoke IP Service Definitions on page 643](#)

If none of the predefined E-Line service definitions described here is appropriate for your needs, you can create a service definition as described in *Creating an E-Line Service Definition*,

The Connectivity Services Director application provides predefined service definitions for E-Line services that use LDP switching or BGP in the network core. The LDP based services are sometimes known as E-Line Martini services, and the BGP based services are sometimes known as E-Line Kompella services. [Figure 17 on page 480](#) shows an example of such a service.

Figure 20: E-Line Service



Information specific to each service instance, such as the device name, endpoint name, and customer VLAN ID, is provided in the service order. Attributes that can apply across many service instances are typically defined in the service definition. These attributes include:

- Ethernet option (dot1.q, port-port, qinq, asymmetric tag depth)
- Traffic type (single VLAN, VLAN range, all traffic, VLAN list)
- Physical interface encapsulation
- Logical interface encapsulation
- Rate limit range

Table 66 on page 480 lists each of the standard E-Line service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 69: Standard E-Line Service Definitions

Standard Service Definition Name	Service Attributes
"ELine-Dot1q-SingleVLAN" on page 482	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
"ELine-Dot1q-SingleVLAN-CCC" on page 485	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
"ELine-Dot1q-SingleVLAN-Ext-CCC" on page 488	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Extended-vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
"ELine-PortBased" on page 491	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • Port-based UNI • Ethernet-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 69: Standard E-Line Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELine-QinQ-AllVLAN” on page 494	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-AllVLAN-CCC” on page 497	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-AllVLAN-Ext-CCC” on page 500	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series routers • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Extended-vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-VLANRange” on page 503	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • Customer traffic is range of VLANs • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-QinQ-VLANRange-CCC” on page 506	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • Customer traffic is range of VLANs • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 69: Standard E-Line Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELine-QinQ-VLANRange-Ext-CCC” on page 509	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • Customer traffic is range of VLANs • Extended-vlan-ccc physical encapsulation • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
TDM Interface	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • T1 interfaces • satop physical encapsulation
Static TDM pseudowire	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • T1 interfaces • satop physical encapsulation • Static pseudowire
ATM pseudowire	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • ATM/T1 interfaces • atm-cc-cell-relay physical encapsulation
ATM-AAL5 pseudowire	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • ATM/T1 interfaces • atm-ccc-vc-mux/aal5 physical encapsulation
Static ATM pseudowire	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • ATM/T1 interfaces • atm-ccc-cell-relay/atm physical encapsulation • Static pseudowire
Static ATM-AAL5 pseudowire	<ul style="list-style-type: none"> • E-Line service for MX Series routers only • ATM/T1 interfaces • atm-ccc-vc-mux / aal5 physical encapsulation • Static pseudowire

Table 69: Standard E-Line Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELine-BGP-QinQ-AllVLAN” on page 588	<ul style="list-style-type: none"> • Ethernet service for M Series, MX Series, and ACX Series routers • Gigabit Ethernet interface • Q-in-Q endpoint interface type • Transport all traffic • Flexible-ethernet-services physical encapsulation type • Rate limit from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-BGP-Dot1q-SingleVLAN” on page 585	<ul style="list-style-type: none"> • Ethernet service for M Series, MX Series, and ACX Series routers • Gigabit Ethernet interface • 802.1Q endpoint interface types • Single VLAN traffic • Flexible-ethernet-services physical encapsulation type • Rate limit from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELine-BGP-Port-Based” on page 582	<ul style="list-style-type: none"> • Ethernet service for M Series, MX Series, and ACX routers • Gigabit Ethernet interface • Port-based UNIs • Ethernet-ccc physical encapsulation type • Rate limit from 10 Mbps to 100 Mbps with 10 Mbps increment

ELine-Dot1q-SingleVLAN Service Definition

IN THIS SECTION

- [Configuration on Endpoint A | 553](#)
- [Configuration on Endpoint Z | 554](#)

This service definition provides a base for creating E-Line services that transport a single VLAN across an LDP or BGP network core using 802.1Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "Dot1q Eline Martini ";
        encapsulation vlan-ccc;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
}

family ccc {
    filter filter_in_ge-0/1/1_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/1_1;
                accept;
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40
        interface ge-0/1/1.1 {
            virtual-circuit-id 786;
            no-control-word;
        }
    }
}

```

```

        mtu 1522;
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "Dot1q Eline Martini ";
        encapsulation vlan-ccc;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
}

family ccc {
    filter filter_in_ge-0/1/1_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/1_1;
                accept;
            }
        }
    }
}

```

```

    }

protocols {
  l2circuit {
    neighbor 192.168.1.30 {
      interface ge-0/1/1.1 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

ELine-Dot1q-SingleVLAN-CCC Service Definition

IN THIS SECTION

- [Configuration on Endpoint A | 555](#)
- [Configuration on Endpoint Z | 557](#)

This service definition provides a base for creating E-Line services that transport a single VLAN across an LDP or BGP network core using 802.1Q endpoint interface types and vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation vlan-ccc;
  unit 513 {
    description VLANCCC-SR;
  }
}

```

```

        encapsulation vlan-ccc;
        vlan-id 513;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_513;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_513 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_513 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_513;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.513 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 513 {
        description VLANCCC-SR;
        encapsulation vlan-ccc;
        vlan-id 513;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_513;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_513 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_513 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_513;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {

```

```

        interface ge-0/1/1.513 {
            virtual-circuit-id 786;
            no-control-word;
            mtu 1522;
        }
    }
}

```

ELine-Dot1q-SingleVLAN-Ext-CCC Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 558
- Configuration on Endpoint Z | 560

This service definition provides a base for creating E-Line services that transport a single VLAN across an LDP or BGP network core using 802.1Q endpoint interface types and extended-vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Extended-SR;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

```

```

    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_1 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_1 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_1;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.40 {
      interface ge-0/1/1.1 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```


Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Extended-SR;
        vlan-id 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.1 {

```

```

        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
    }
}
}

```

ELine-PortBased Service Definition

IN THIS SECTION

- [Configuration on Endpoint A | 561](#)
- [Configuration on Endpoint Z | 562](#)

This service definition provides a base for creating E-Line services that transport all traffic across an LDP or BGP network core using an entire port at each endpoint using ethernet-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps to 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    encapsulation ethernet-ccc;
    unit 0 {
        family ccc {
            filter {
                input filter_in_ge-0/1/1;
            }
        }
    }
}

```

```

firewall {
    policer policer_in_ge-0/1/1 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 6250000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.0 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    encapsulation ethernet-ccc;
    unit 0 {
        family ccc {

```

```

        filter {
            input filter_in_ge-0/1/1;
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 6250000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.0 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

ELine-QinQ-AllVLAN Service Definition

IN THIS SECTION

- [Configuration on Endpoint A | 564](#)
- [Configuration on Endpoint Z | 565](#)

This service definition provides a base for creating E-Line services that transport all customer traffic across an LDP or BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "AllVlanTransport";
        encapsulation vlan-ccc;
        vlan-tags outer 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.1 {
                virtual-circuit-id 786;
            }
        }
    }
}
```

```

        no-control-word;
        mtu 1522;
    }
}

}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        description "AllVlanTransport";
        encapsulation vlan-ccc;
        vlan-tags outer 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

```

```

    }
  }
}

firewall {
  policer policer_in_ge-0/1/1_1 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_1 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_1;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.30 {
      interface ge-0/1/1.1 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

ELine-QinQ-AllVLAN-CCC Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 567
- Configuration on Endpoint Z | 568

This service definition provides a base for creating E-Line services that transport all customer traffic across an LDP or BGP network core using Q-in-Q endpoint interface types and vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 515 {
        description QinQ-ALLVLAN;
        encapsulation vlan-ccc;
        vlan-tags outer 515;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_515;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_515 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}
```



```

    }
    then discard;
  }

  family ccc {
    filter filter_in_ge-0/1/1_515 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_515;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.40 {
      interface ge-0/1/1.515 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation vlan-ccc;
  unit 515 {
    description QinQ-ALLVLAN;
    encapsulation vlan-ccc;
    vlan-tags outer 515;
    family ccc {

```

```

        filter {
            input filter_in_ge-0/1/1_515;
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_515 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_515 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_515;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.515 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

ELine-QinQ-AllVLAN-Ext-CCC Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 570
- Configuration on Endpoint Z | 571

This service definition provides a base for creating E-Line services that transport all customer traffic across an LDP or BGP network core using Q-in-Q endpoint interface types and extended-vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Ext-AllVLAN;
        vlan-tags outer 1;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}
```

```

        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.40 {
            interface ge-0/1/1.1 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 1 {
        description Ext-AllVLAN;
        vlan-tags outer 1;
    }
}

```

```

        family ccc {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.1 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

ELine-QinQ-VLANRange Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 573
- Configuration on Endpoint Z | 574

This service definition provides a base for creating E-Line services that transport a range of VLANs across an LDP or BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 2 {
        description "QinQ Eline Martini";
        encapsulation vlan-ccc;
        vlan-tags outer 2 inner-range 100-110;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_2;
            }
        }
    }
}
```

```
firewall {
    policer policer_in_ge-0/1/1_2 {
        if-exceeding {
            bandwidth-limit 100m;
```

```

        burst-size-limit 62500000;
    }

    family ccc {
        filter filter_in_ge-0/1/1_2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_2;
                    accept;
                }
            }
        }
    }

    protocols {
        l2circuit {
            neighbor 192.168.1.40 {
                interface ge-0/1/1.2 {
                    virtual-circuit-id 786;
                    no-control-word;
                    mtu 1522;
                }
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 2 {
        description "QinQ Eline Martini";
        encapsulation vlan-ccc;
        vlan-tags outer 2 inner-range 100-110;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_2;
            }
        }
    }
}

```

```

    }
}

firewall {
    policer policer_in_ge-0/1/1_2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }

    family ccc {
        filter filter_in_ge-0/1/1_2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_2;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        interface ge-0/1/1.2 {
            virtual-circuit-id 786;
            no-control-word;
            mtu 1522;
        }
    }
}
}

```


ELine-QinQ-VLANRange-CCC Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 576
- Configuration on Endpoint Z | 577

This service definition provides a base for creating E-Line services that transport a range of VLANs across an LDP or BGP network core using Q-in-Q endpoint interface types and vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation vlan-ccc;
    unit 514 {
        description VLANRANGE-SR;
        encapsulation vlan-ccc;
        vlan-tags outer 514 inner-range 600-610;
        family ccc {
            filter {
                input filter_in_ge-0/1/1_514;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_514 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
    }
}

```

```

    }
    then discard;
  }
  family ccc {
    filter filter_in_ge-0/1/1_514 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/1_514;
          accept;
        }
      }
    }
  }
}

protocols {
  l2circuit {
    neighbor 192.168.1.40 {
      interface ge-0/1/1.514 {
        virtual-circuit-id 786;
        no-control-word;
        mtu 1522;
      }
    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation vlan-ccc;
  unit 514 {
    description VLANRANGE-SR;
    encapsulation vlan-ccc;
    vlan-tags outer 514 inner-range 600-610;
    family ccc {

```

```

        filter {
            input filter_in_ge-0/1/1_514;
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_514 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family ccc {
        filter filter_in_ge-0/1/1_514 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_514;
                    accept;
                }
            }
        }
    }
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.514 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}

```

ELine-QinQ-VLANRange-Ext-CCC Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 579
- Configuration on Endpoint Z | 580

This service definition provides a base for creating E-Line services that transport a range of VLANs across an LDP or BGP network core using Q-in-Q endpoint interface types and extended-vlan-ccc as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```
ge-0/1/1 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation extended-vlan-ccc;
  unit 2 {
    description Ext-VLANRange;
    vlan-tags outer 2 inner-range 100-110;
    family ccc {
      filter {
        input filter_in_ge-0/1/1_2;
      }
    }
  }
}
```

```
firewall {
  policer policer_in_ge-0/1/1_2 {
    if-exceeding {
      bandwidth-limit 100m;
    }
  }
}
```

```

        burst-size-limit 62500000;
    }
    then discard;
}
family ccc {
    filter filter_in_ge-0/1/1_2 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/1_2;
                accept;
            }
        }
    }
}
}

protocols {
    l2circuit {
        neighbor 192.168.1.30 {
            interface ge-0/1/1.2 {
                virtual-circuit-id 786;
                no-control-word;
                mtu 1522;
            }
        }
    }
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

ge-0/1/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation extended-vlan-ccc;
    unit 2 {
        description Ext-VLANRange;
        vlan-tags outer 2 inner-range 100-110;
        family ccc {
            filter {

```


ELine-BGP-Port-Based

IN THIS SECTION

- Configuration on Endpoint A | 582
- Configuration on Endpoint Z | 583

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

routing-instances{
  instance-type l2vpn;
  interface ge-1/0/7.0;
  route-distinguisher 69:27;
  vrf-target target:69:49165;
  protocols {
    l2vpn {
      encapsulation-type ethernet-vlan;
      no-control-word;
      site L2VPN_Site_1 {
        site-identifier 1;
        mtu 1522;
        interface ge-1/0/7.0 {
          remote-site-id 2;
          description P2P-BGP-PortBased;
        }
      }
    }
  }
}

ge-1/0/7 {
  mtu 1522;
  encapsulation ethernet-ccc;
  unit 0 {
    family ccc {

```

```

        filter {
            input filter_in_ge-1/0/7;
        }
    }
}

firewall{

    family ccc {

        filter filter_in_ge-1/0/7 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-1/0/7;
                    accept;
                }
            }
        }
    }

    policer policer_in_ge-1/0/7 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 15220;
        }
        then discard;
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

routing-instances{
    instance-type l2vpn;
    interface ge-1/0/8.0;
    route-distinguisher 69:27;
    vrf-target target:69:49165;
    protocols {
        l2vpn {
            encapsulation-type ethernet-vlan;

```



```

        no-control-word;
        site L2VPN_Site_2 {
            site-identifier 2;
            mtu 1522;
            interface ge-1/0/8.0 {
                remote-site-id 1;
                description P2P-BGP-PortBased;
            }
        }
    }
}

ge-1/0/8 {
    mtu 1522;
    encapsulation ethernet-ccc;
    unit 0 {
        family ccc {
            filter {
                input filter_in_ge-1/0/8;
            }
        }
    }
}

firewall{

    family ccc {

        filter filter_in_ge-1/0/8 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-1/0/8;
                    accept;
                }
            }
        }
    }

    policer policer_in_ge-1/0/8 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 15220;
        }
    }
}

```

```

    then discard;
  }
}

```

Eline-BGP-Dot1q-SingleVLAN

IN THIS SECTION

- Configuration on Endpoint A | 585
- Configuration on Endpoint Z | 587

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

routing-instances {
  instance-type l2vpn;
  interface ge-0/0/2.823;
  route-distinguisher 69:26;
  vrf-target target:69:49164;
  protocols {
    l2vpn {
      encapsulation-type ethernet-vlan;
      no-control-word;
      site L2VPN_Site_1 {
        site-identifier 1;
        interface ge-0/0/2.823 {
          remote-site-id 2;
        }
      }
    }
  }
}

ge-0/0/2 {

```

```

enable;
flexible-vlan-tagging;
mtu 1522;
encapsulation flexible-ethernet-services;
unit 823 {
    description "ELINE-BGP-Dot1Q";
    encapsulation vlan-ccc;
    vlan-id 823;
    family ccc {
        filter {
            input filter_in_ge-0/0/2_823;
        }
    }
}

firewall{

    family ccc {

        filter filter_in_ge-0/0/2_823 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/2_823;
                    accept;
                }
            }
        }

        policer policer_in_ge-0/0/2_823 {
            if-exceeding {
                bandwidth-limit 10m;
                burst-size-limit 15220;
            }
            then discard;
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

routing-instances {
    instance-type l2vpn;
    interface ge-0/0/3.823;
    route-distinguisher 69:26;
    vrf-target target:69:49164;
    protocols {
        l2vpn {
            encapsulation-type ethernet-vlan;
            no-control-word;
            site L2VPN_Site_2 {
                site-identifier 2;
                interface ge-0/0/3.823 {
                    remote-site-id 1;
                }
            }
        }
    }
}

ge-0/0/3 {
    enable;
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 823 {
        description "ELine-BGP-Dot1Q";
        encapsulation vlan-ccc;
        vlan-id 823;
        family ccc {
            filter {
                input filter_in_ge-0/0/3_823;
            }
        }
    }
}

firewall{

    family ccc {

```

```

    filter filter_in_ge-0/0/3_823 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/3_823;
                accept;
            }
        }
    }
}
policer policer_in_ge-0/0/3_823 {
    if-exceeding {
        bandwidth-limit 10m;
        burst-size-limit 15220;
    }
    then discard;
}
}

```

Eline-BGP-QinQ-AllVLAN

IN THIS SECTION

- [Configuration on Endpoint A | 588](#)
- [Configuration on Endpoint Z | 590](#)

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 17 on page 480](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A:

```

routing-instances {
    instance-type l2vpn;
    interface ge-0/0/1.981;
    route-distinguisher 69:15;
    vrf-target target:69:49160;
}

```

```

protocols {
    l2vpn {
        encapsulation-type ethernet-vlan;
        no-control-word;
        site L2VPN_Site_1 {
            site-identifier 1;
            mtu 1522;
            interface ge-0/0/1.981 {
                remote-site-id 2;
                description P2P-BGP-QnQAllVlan;
            }
        }
    }
}

ge-0/0/3 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 981 {
        description "No description available for selected UNI interface.";
        encapsulation vlan-ccc;
        vlan-tags outer 981;
        family ccc {
            filter {
                input filter_in_ge-0/0/3_981;
            }
        }
    }
}

firewall{

    family ccc {

        filter filter_in_ge-0/0/3_981;{
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/3_981;
                    accept;
                }
            }
        }
    }
}

```

```

    }
  }
}
policer policer_in_ge-0/0/3_981;{
  if-exceeding {
    bandwidth-limit 10m;
    burst-size-limit 15220;
  }
  then discard;
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z:

```

routing-instances {
  instance-type l2vpn;
  interface ge-0/0/5.981;
  route-distinguisher 69:15;
  vrf-target target:69:49160;
  protocols {
    l2vpn {
      encapsulation-type ethernet-vlan;
      no-control-word;
      site L2VPN_Site_2 {
        site-identifier 2;
        mtu 1522;
        interface ge-0/0/5.981 {
          remote-site-id 1;
          description P2P-BGP-QnQAllVlan;
        }
      }
    }
  }
}

ge-0/0/5 {
  flexible-vlan-tagging;
  mtu 1522;
  encapsulation flexible-ethernet-services;
}

```

```

unit 981 {
    description "No description available for selected UNI interface.";
    encapsulation vlan-ccc;
    vlan-tags outer 981;
    family ccc {
        filter {
            input filter_in_ge-0/0/5.981
        }
    }
}

firewall{

    family ccc {

        filter filter_in_ge-0/0/5.981 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/5.981
                    accept;
                }
            }
        }
    }

    policer policer_in_ge-0/0/5.981 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 15220;
        }
        then discard;
    }
}

```

RELATED DOCUMENTATION

[Choosing a Predefined Service Definition or Creating a New Service Definition | 645](#)

Creating an E-Line Service Definition

[Predefined Multipoint-to-Multipoint Ethernet Service Definitions | 592](#)

[Predefined Point-to-Multipoint Ethernet Service Definitions | 625](#)

Predefined Multipoint-to-Multipoint Ethernet Service Definitions


The Connectivity Services Director application provides predefined service definitions that a service provisioner can choose from when creating a service order. This section provides information about predefined service definitions used for creating multipoint-to-multipoint Ethernet services. For information about predefined service definitions used to create E-Line service definitions or point-to-multipoint service definitions, see the following topics:

- [Predefined E-Line Service Definitions on page 548](#)
- [Predefined Point-to-Multipoint Ethernet Service Definitions on page 625](#)

If none of the multipoint-to-multipoint predefined service definitions described here is appropriate for your needs, you can create a service definition as described in [“Creating a Multipoint-to-Multipoint E-LAN Service Definition” on page 696](#).

The Connectivity Services Director application provides predefined service definitions for E-LAN services that use BGP switching in the network core. These services are sometimes known as E-LAN services. This section covers multipoint-to-multipoint (or full mesh) service definitions. [Figure 18 on page 512](#) shows an example of such a service.

Figure 21: Multipoint-to-Multipoint Service



Information specific to each service instance, such as the device name, endpoint name, and customer VLAN ID, is provided in the service order. Attributes that can apply across many service instances are typically defined in the service definition. These attributes include:

- Ethernet option (dot1.q, port-port, qinq, asymmetric tag depth)
- Traffic type (single VLAN, VLAN range, all traffic, VLAN list)

- VLAN normalization
- Physical interface encapsulation
- Logical interface encapsulation
- Rate limit range

Table 67 on page 513 lists each of the standard E-LAN service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 70: Standard Multipoint-to-Multipoint Service Definitions

Standard Service Definition Name	Service Attributes
“ELAN-BGP-Dot1q-Normalized-VLAN-None” on page 514	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are not preserved • 802.1Q endpoint interface types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-Dot1Q-SingleVLAN” on page 519	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series or MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint interface types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-PortBased” on page 523	<ul style="list-style-type: none"> • Multipoint Ethernet service for M series and MX Series devices • Gigabit Ethernet interfaces • Port-based UNIs • Transports all customer traffic • Ethernet VPLS as physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 70: Standard Multipoint-to-Multipoint Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
“ELAN-BGP-QinQ-AllVLAN” on page 528	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-QinQ-AllVLAN-Normalized-All” on page 532	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-QinQ-AllVLAN-Normalized-None” on page 537	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint interface types • VLAN IDs not preserved • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-BGP-QinQ-Range-Normalized-VLAN” on page 541	<ul style="list-style-type: none"> • Multipoint Ethernet service for MX Series devices only • Gigabit Ethernet interfaces • Customer VLAN IDs preserved • Q-in-Q endpoint interface types • Transports specified VLAN range • Flexible Ethernet services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

ELAN-BGP-Dot1q-Normalized-VLAN-None Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 595
- Configuration on Endpoint B | 596
- Configuration on Endpoint Z | 598

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport traffic from a single VLAN on an endpoint across a BGP network core using 802.1Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. VLAN IDs are not preserved across the network—traffic passes from the single VLAN on an endpoint to any VLANs in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```
ge-0/0/1 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
        }
    }
}
```

```

        burst-size-limit 62500000;
    }
    then discard;
}
family vpls {
    filter filter_in_ge-0/0/1_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/1_1;
                accept;
            }
        }
    }
}
}
}
routing-instances {
    BestCustomer_ELAN-BGP-Dot1q-Normalized-VLAN-SR {
        instance-type vpls;
        vlan-id none;
        interface ge-0/0/1.1;
        route-distinguisher 65410:1;
        vrf-target target:65410:0;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_2 {
                    site-identifier 2;
                    site-preference primary;
                    interface ge-0/0/1.1;
                }
            }
        }
    }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/0/1 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {

```

```

        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/1_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-Dot1q-Normalized-VLAN-SR {
        instance-type vpls;
        vlan-id none;
        interface ge-0/0/1.1;
        route-distinguisher 65410:0;
        vrf-target target:65410:0;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/0/1.1;
                }
            }
        }
    }
}

```

```

    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/1 {
  flexible-vlan-tagging;
  encapsulation flexible-ethernet-services;
  unit 1 {
    encapsulation vlan-vpls;
    vlan-id 1;
    family vpls {
      filter {
        input filter_in_ge-0/0/1_1;
      }
    }
  }
}

firewall {
  policer policer_in_ge-0/0/1_1 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 62500000;
    }
    then discard;
  }
  family vpls {
    filter filter_in_ge-0/0/1_1 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/0/1_1;
          accept;
        }
      }
    }
  }
}

```

```

    }
}
routing-instances {
    BestCustomer_ELAN-BGP-Dot1q-Normalized-VLAN-SR {
        instance-type vpls;
        vlan-id none;
        interface ge-0/0/1.1;
        vlan-id none;
        route-distinguisher 65410:2;
        vrf-target target:65410:0;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/1.1;
                }
            }
        }
    }
}

```

ELAN-BGP-Dot1Q-SingleVLAN Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 600
- Configuration on Endpoint B | 601
- Configuration on Endpoint Z | 602

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport traffic on a single VLAN across a BGP network core using 802.1Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. No VLAN mapping is performed—the VLAN ID must be the same on all endpoints. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```

ge-0/0/2 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/2_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/2_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }

    filter filter_in_ge-0/0/2_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/2_1;
                accept;
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-Dot1Q-SingleVLAN-SR {
        instance-type vpls;
        interface ge-0/0/2.1;
        route-distinguisher 65410:4;
        vrf-target target:65410:1;
    }
}

```

```

protocols {
    vpls {
        no-tunnel-services;
        site Site_2 {
            site-identifier 2;
            site-preference primary;
            interface ge-0/0/2.1;
        }
    }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/0/2 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/2_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/2_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    filter filter_in_ge-0/0/2_1 {
        interface-specific;
        term 1 {
            then {

```

```

        policer policer_in_ge-0/0/2_1;
        accept;
    }
}
}
}
}

routing-instances {
    BestCustomer_ELAN-BGP-Dot1Q-SingleVLAN-SR {
        instance-type vpls;
        interface ge-0/0/2.1;
        route-distinguisher 65410:3;
        vrf-target target:65410:1;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/0/2.1;
                }
            }
        }
    }
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/2 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-id 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/2_1;
            }
        }
    }
}

```

```

    }

    firewall {
        policer policer_in_ge-0/0/2_1 {
            if-exceeding {
                bandwidth-limit 100m;
                burst-size-limit 62500000;
            }
            then discard;
        }
        family vpls {
            filter filter_in_ge-0/0/2_1 {
                interface-specific;
                term 1 {
                    then {
                        policer policer_in_ge-0/0/2_1;
                        accept;
                    }
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-Dot1Q-SingleVLAN-SR {
        instance-type vpls;
        interface ge-0/0/2.1;
        route-distinguisher 65410:5;
        vrf-target target:65410:1;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/2.1;
                }
            }
        }
    }
}

```

ELAN-BGP-PortBased Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 604
- Configuration on Endpoint B | 605
- Configuration on Endpoint Z | 607

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic on an entire port across a BGP network core using ethernet-vpls as the physical encapsulation type. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```
ge-0/1/3 {
    mtu 1522;
    encapsulation ethernet-vpls;
    unit 0 {
        family vpls {
            filter {
                input filter_in_ge-0/1/3;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/3 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 15220;
        }
        then discard;
    }
}
```

```

family vpls {
    filter filter_in_ge-0/1/3 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/3;
                accept;
            }
        }
    }
}

routing-instances {
    ELAN_BGP_PortBased_10_100M {
        instance-type vpls;
        interface ge-0/1/3.0;
        route-distinguisher 65410:3;
        vrf-target target:65410:1;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_2 {
                    site-identifier 2;
                    site-preference primary;
                    interface ge-0/1/3.0;
                }
            }
        }
    }
}

```

```

    }
  }
}

firewall {
  policer policer_in_ge-0/1/3 {
    if-exceeding {
      bandwidth-limit 100m;
      burst-size-limit 15220;
    }
    then discard;
  }
  family vpls {
    filter filter_in_ge-0/1/3 {
      interface-specific;
      term 1 {
        then {
          policer policer_in_ge-0/1/3;
          accept;
        }
      }
    }
  }
}

routing-instances {
  ELAN_BGP_PortBased_10_100M {
    instance-type vpls;
    interface ge-0/1/3.0;
    route-distinguisher 65410:2;
    vrf-target target:65410:1;
    protocols {
      vpls {
        no-tunnel-services;
        site Site_1 {
          site-identifier 1;
          site-preference primary;
          interface ge-0/1/3.0;
        }
      }
    }
  }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/2/2 {
    mtu 1522;
    encapsulation ethernet-vpls;
    unit 0 {
        family vpls {
            filter {
                input filter_in_ge-0/2/2;
            }
        }
    }
}

}

firewall {
    policer policer_in_ge-0/2/2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 15220;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/2/2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/2/2;
                    accept;
                }
            }
        }
    }
}

}

routing-instances {
    ELAN_BGP_PortBased_10_100M {
        instance-type vpls;
        interface ge-0/2/2.0;
        route-distinguisher 65410:4;
        vrf-target target:65410:1;
    }
}

```



```

protocols {
  vpls {
    no-tunnel-services;
    site Site_3 {
      site-identifier 3;
      site-preference primary;
      interface ge-0/2/2.0;
    }
  }
}

```

ELAN-BGP-QinQ-AllVLAN Service Definition

IN THIS SECTION

- [Configuration on Endpoint A | 608](#)
- [Configuration on Endpoint B | 610](#)
- [Configuration on Endpoint Z | 611](#)

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. No VLAN mapping is performed—customer VLAN IDs and service provider VLAN IDs must match on each endpoint that is to send or receive traffic. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```

ge-0/1/1 {
  flexible-vlan-tagging;
  encapsulation flexible-ethernet-services;
  unit 1 {

```

```

        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-SR {
        instance-type vpls;
        interface ge-0/1/1.1;
        route-distinguisher 65410:13;
        vrf-target target:65410:4;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_2 {
                    site-identifier 2;
                    site-preference primary;
                    interface ge-0/1/1.1;
                }
            }
        }
    }
}

```

```

    }
  }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/1/1 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/1_1;
                    accept;
                }
            }
        }
    }
}

```

```

}
routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-SR {
        instance-type vpls;
        interface ge-0/1/1.1;
        route-distinguisher 65410:12;
        vrf-target target:65410:4;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/1/1.1;
                }
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/5 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/5_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/5_1 {
        if-exceeding {
            bandwidth-limit 100m;

```

```

        burst-size-limit 62500000;
    }
    then discard;
}
family vpls {
    filter filter_in_ge-0/0/5_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/5_1;
                accept;
            }
        }
    }
}
}
routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-SR {
        instance-type vpls;
        interface ge-0/0/5.1;
        route-distinguisher 65410:14;
        vrf-target target:65410:4;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/5.1;
                }
            }
        }
    }
}
}

```

ELAN-BGP-QinQ-AllVLAN-Normalized-All Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 613
- Configuration on Endpoint B | 614
- Configuration on Endpoint Z | 616

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Customer VLAN IDs are preserved across the network—traffic passes only among matching customer VLAN IDs. However, traffic can pass among any service provider VLAN ID in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```
ge-0/1/0 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/0_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/0_1 {
        if-exceeding {
            bandwidth-limit 100m;
        }
    }
}
```

```

        burst-size-limit 62500000;
    }
    then discard;
}
family vpls {
    filter filter_in_ge-0/1/0_1 {
        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/1/0_1;
                accept;
            }
        }
    }
}
}
routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-All-SR {
        instance-type vpls;
        vlan-id all;
        interface ge-0/1/0.1;
        route-distinguisher 65410:10;
        vrf-target target:65410:3;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_2 {
                    site-identifier 2;
                    site-preference primary;
                    interface ge-0/1/0.1;
                }
            }
        }
    }
}
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/1/0 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
}

```

```

    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/1/0_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/1/0_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/1/0_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/1/0_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-All-SR {
        instance-type vpls;
        vlan-id all;
        interface ge-0/1/0.1;
        route-distinguisher 65410:9;
        vrf-target target:65410:3;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                }
            }
        }
    }
}

```



```

        interface ge-0/1/0.1;
    }
}
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/4 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/4_1;
            }
        }
    }
}
firewall {
    policer policer_in_ge-0/0/4_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/4_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/4_1;
                    accept;
                }
            }
        }
    }
}
}

```

```

}
routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-All-SR {
        instance-type vpls;
        vlan-id all;
        interface ge-0/0/4.1;
        vlan-id all;
        route-distinguisher 65410:11;
        vrf-target target:65410:3;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/4.1;
                }
            }
        }
    }
}

```

ELAN-BGP-QinQ-AllVLAN-Normalized-None Service Definition

IN THIS SECTION

- Configuration on Endpoint A | 618
- Configuration on Endpoint B | 619
- Configuration on Endpoint Z | 620

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport all traffic across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. VLAN IDs are not preserved across the network—traffic passes between any customer VLAN or service provider VLAN in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 18 on page 512](#):

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device IND):

```

ge-0/0/3 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/3_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/3_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/3_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/3_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-SR {
        instance-type vpls;
        vlan-id none;
        interface ge-0/0/3.1;
        route-distinguisher 65410:7;
    }
}

```

```

vrf-target target:65410:2;
protocols {
    vpls {
        no-tunnel-services;
        site Site_2 {
            site-identifier 2;
            site-preference primary;
            interface ge-0/0/3.1;
        }
    }
}
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device BLR):

```

ge-0/0/3 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {
                input filter_in_ge-0/0/3_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/3_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/3_1 {

```

```

        interface-specific;
        term 1 {
            then {
                policer policer_in_ge-0/0/3_1;
                accept;
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-SR {
        instance-type vpls;
        vlan-id none;
        interface ge-0/0/3.1;
        route-distinguisher 65410:6;
        vrf-target target:65410:2;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_1 {
                    site-identifier 1;
                    site-preference primary;
                    interface ge-0/0/3.1;
                }
            }
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SJC):

```

ge-0/0/3 {
    flexible-vlan-tagging;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1;
        family vpls {
            filter {

```

```

        input filter_in_ge-0/0/3_1;
    }
}
}
}

firewall {
    policer policer_in_ge-0/0/3_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/3_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/3_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-AllVLAN-Normalized-SR {
        instance-type vpls;
        vlan-id none;
        interface ge-0/0/3.1;
        vlan-id none;
        route-distinguisher 65410:8;
        vrf-target target:65410:2;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_3 {
                    site-identifier 3;
                    site-preference primary;
                    interface ge-0/0/3.1;
                }
            }
        }
    }
}

```

```
}
}
```

ELAN-BGP-QinQ-Range-Normalized-VLAN Service Definition

IN THIS SECTION

- [Configuration on Endpoint A | 622](#)
- [Configuration on Endpoint Z | 624](#)

This service definition provides a base for creating multipoint-to-multipoint Ethernet services that transport traffic from a range of VLANs on an endpoint across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. Services built from this service definition must use MX Series devices on the provider edge. Customer VLAN IDs are preserved across the network—traffic passes among like customer VLAN IDs on any service provider VLAN in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data for a service with only two endpoints, SJC and SFO.

Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device SJC):

```
ge-0/0/6 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 2 {
        encapsulation vlan-vpls;
        vlan-tags outer 2 inner-range 1500-2000;
        family vpls {
            filter {
                input filter_in_ge-0/0/6_2;
            }
        }
    }
}
```

```

firewall {
    policer policer_in_ge-0/0/6_2 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/6_2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/6_2;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-Range-Normalized-VLAN-SR1 {
        instance-type vpls;
        vlan-id all;
        interface ge-0/0/6.2;
        vlan-id all;
        route-distinguisher 65410:19;
        vrf-target target:65410:6;
        protocols {
            vpls {
                no-tunnel-services;
                site Site_2 {
                    site-identifier 2;
                    site-preference primary;
                    interface ge-0/0/6.2;
                }
            }
        }
    }
}

```


Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device SFO):

```

ge-0/0/1 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 1 {
        encapsulation vlan-vpls;
        vlan-tags outer 1 inner-range 1500-2000;
        family vpls {
            filter {
                input filter_in_ge-0/0/1_1;
            }
        }
    }
}

firewall {
    policer policer_in_ge-0/0/1_1 {
        if-exceeding {
            bandwidth-limit 100m;
            burst-size-limit 62500000;
        }
        then discard;
    }
    family vpls {
        filter filter_in_ge-0/0/1_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/1_1;
                    accept;
                }
            }
        }
    }
}

routing-instances {
    BestCustomer_ELAN-BGP-QinQ-Range-Normalized-VLAN-SR1 {
        instance-type vpls;
        vlan-id all;
        interface ge-0/0/1.1;
    }
}

```

```

route-distinguisher 65410:18;
vrf-target target:65410:6;
protocols {
    vpls {
        no-tunnel-services;
        site Site_1 {
            site-identifier 1;
            site-preference primary;
            interface ge-0/0/1.1;
        }
    }
}

```

RELATED DOCUMENTATION

[Predefined Service Definitions | 479](#)

[Predefined E-Line Service Definitions | 548](#)

[Predefined Point-to-Multipoint Ethernet Service Definitions | 625](#)

[Predefined Full Mesh IP Service Definitions | 642](#)

[Predefined Hub-and-Spoke IP Service Definitions | 643](#)

Predefined Point-to-Multipoint Ethernet Service Definitions

The Connectivity Services Director application provides predefined service definitions that a service provisioner can choose from when creating a service order. This section provides information about predefined service definitions used for creating point-to-multipoint services. For information about predefined service definitions used to create E-Line service definitions or multipoint-to-multipoint service definitions, see the following topics:

- [Predefined E-Line Service Definitions on page 548](#)
- [Predefined Multipoint-to-Multipoint Ethernet Service Definitions on page 592](#)

If none of the point-to-multipoint predefined service definitions described here is appropriate for your needs, you can create a service definition as described in [“Creating a Point-to-Multipoint E-LAN Service Definition” on page 726](#).

The Connectivity Services Director application provides predefined service definitions for E-LAN services that use BGP switching in the network core. These services are sometimes known as E-LAN services. This section covers point-to-multipoint (or hub-and-spoke) service definitions.

Information specific to each service instance, such as the device name, endpoint name, customer VLAN ID, and whether a specific endpoint is a hub or a spoke is provided in the service order. Attributes that can apply across many service instances are typically defined in the service definition. These attributes include:

- Ethernet option (dot1.q, qinq)
- Traffic type (single VLAN, VLAN range, all traffic, VLAN list)
- VLAN normalization
- Physical interface encapsulation
- Logical interface encapsulation
- Rate limit range

[Table 71 on page 626](#) lists each of the standard E-LAN service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 71: Standard Point-to-Multipoint Service Definitions

Standard Service Definition Name	Service Attributes
“ELAN-Hub-Spoke-QinQ-AllVLAN” on page 546	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series or MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
“ELAN-Hub-Spoke-QinQ-AllVLAN-No” on page 547	<ul style="list-style-type: none"> • Multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are not preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

ELAN-Hub-Spoke-QinQ-AllVLAN-Normalized-All Service Definition


IN THIS SECTION

- Configuration on Endpoint A | 628
- Configuration on Endpoint B | 630
- Configuration on Endpoint Z | 632

This service definition provides a base for creating point-to-multipoint Ethernet services that transport all traffic on an endpoint across a BGP network core using Q-in-Q endpoint interface types and flexible-ethernet-services as the physical encapsulation type. VLAN IDs are not preserved across the network—traffic passes from the single VLAN on an endpoint to any VLANs in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps.

The following sections show the configuration data on each endpoint when you use this service definition to create the service shown in [Figure 19 on page 545](#)—a point-to-multipoint service with one hub and two spokes.

Figure 22: Point-to-Multipoint Service with One Hub



Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device SFO). This device is configured as the service hub.

```

interfaces {
  ge-0/0/2 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 4 {
      encapsulation vlan-vpls;
      vlan-tags outer 4;
      family vpls {
        filter {
          input filter_in_ge-0/0/2_4;
        }
      }
    }
  }
}

policy-options {
  policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-hm-export {
    term 1 {
      then {
        community add
        export-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8;
        accept;
      }
    }
    term 2 {
      then reject;
    }
  }
  policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-hm-import {
    term 1 {
      from {
        protocol bgp;
        community [
          import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:9
          import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8 ];
      }
      then accept;
    }
    term 2 {
      then reject;
    }
  }
}

```

```

    }
}
community export-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8
members target:65410:8;
community import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8
members target:65410:8;
community import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:9
members target:65410:9;
}
firewall {
    family vpls {
        filter filter_in_ge-0/0/2_4 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/2_4;
                    accept;
                }
            }
        }
    }
}
policer policer_in_ge-0/0/2_4 {
    if-exceeding {
        bandwidth-limit 10m;
        burst-size-limit 15220;
    }
    then discard;
}
}
routing-instances {
    ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All {
        instance-type vpls;
        vlan-id all;
        interface ge-0/0/2.4;
        route-distinguisher 65410:15;
        vrf-import ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-hm-import;
        vrf-export ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-hm-export;
        protocols {
            vpls {
                mac-table-size {
                    5120;
                }
                interface-mac-limit {
                    1024;
                }
            }
        }
    }
}

```

```

    }
    no-tunnel-services;
    site Site_2 {
        site-identifier 2;
        site-preference primary;
        interface ge-0/0/2.4;
    }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device SJC). This device is a service spoke.

```

interfaces {
    ge-0/0/4 {
        flexible-vlan-tagging;
        mtu 1522;
        encapsulation flexible-ethernet-services;
        unit 4 {
            encapsulation vlan-vpls;
            vlan-tags outer 4;
            family vpls {
                filter {
                    input filter_in_ge-0/0/4_4;
                }
            }
        }
    }
}

policy-options {
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-export {
        term 1 {
            then {
                community add
                export-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:9;
                accept;
            }
        }
        term 2 {
            then reject;
        }
    }
}

```

```

    }
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-import {
        term 1 {
            from {
                protocol bgp;
                community
import-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8;
            }
            then accept;
        }
        term 2 {
            then reject;
        }
    }

    community export-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:9 members
target:65410:9;
    community import-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8 members
target:65410:8;
}

firewall {
    family vpls {
        filter filter_in_ge-0/0/4_4 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/4_4;
                    accept;
                }
            }
        }
    }

    policer policer_in_ge-0/0/4_4 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 15220;
        }
        then discard;
    }
}

routing-instances {
    ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All {
        instance-type vpls;
    }
}

```



```

vlan-id all;
interface ge-0/0/4.4;
route-distinguisher 65410:16;
vrf-import ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-import;
vrf-export ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-export;
protocols {
    vpls {
        mac-table-size {
            5120;
        }
        interface-mac-limit {
            1024;
        }
        no-tunnel-services;
        site Site_3 {
            site-identifier 3;
            site-preference primary;
            interface ge-0/0/4.4;
        }
    }
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device Beijing). Thus device is a service spoke.

```

interfaces{
    ge-5/0/2 {
        unit 2 {
            encapsulation vlan-vpls;
            vlan-tags outer 2;
            family vpls {
                filter {
                    input filter_in_ge-5/0/2_2;
                }
            }
        }
    }
}

policy-options {
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-export {
        term 1 {
            then {

```

```

        community add
export-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:9;
        accept;
    }
}
term 2 {
    then reject;
}
}
policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-import {
    term 1 {
        from {
            protocol bgp;
            community
import-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8;
        }
        then accept;
    }
    term 2 {
        then reject;
    }
}
community export-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:9 members
target:65410:9;
community import-comm-ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-65410:8 members
target:65410:8;
}
firewall {
    family vpls {
        filter filter_in_ge-5/0/2_2 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-5/0/2_2;
                    accept;
                }
            }
        }
    }
}
policer policer_in_ge-5/0/2_2 {
    if-exceeding {
        bandwidth-limit 10m;
        burst-size-limit 15220;
    }
}

```

```

        then discard;
    }
}

ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All {
    instance-type vpls;
    vlan-id all;
    interface ge-5/0/2.2;
    route-distinguisher 65410:14;
    vrf-import ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-import;
    vrf-export ELAN_Hub_Spoke_QinQ_AllVLAN_Normalized_All-export;
    protocols {
        vpls {
            mac-table-size {
                5120;
            }
            interface-mac-limit {
                1024;
            }
            no-tunnel-services;
            site Site_1 {
                site-identifier 1;
                site-preference primary;
                interface ge-5/0/2.2;
            }
        }
    }
}

```

ELAN-Hub-Spoke-QinQ-AllVLAN Service Definition

IN THIS SECTION


- Configuration on Endpoint A | 635
- Configuration on Endpoint B | 638
- Configuration on Endpoint Z | 640

This service definition provides a base for creating point-to-multipoint Ethernet services that transport all traffic on an endpoint across a BGP network core using Q-in-Q endpoint interface types and

flexible-ethernet-services as the physical encapsulation type. Customer VLAN IDs are preserved across the network—traffic passes among like customer VLAN IDs on any service provider VLAN in the broadcast domain. Service provisioners can limit the bandwidth of services built from this service definition to specific values from 10 Mbps through 100 Mbps. [Figure 23 on page 635](#) shows a point-to-multipoint service with two hubs.

The following sections show the configuration data on endpoints A, B, and Z when you use this service definition to create the service shown in [Figure 23 on page 635](#)—a point-to-multipoint service with two service hubs and two spokes. The configuration for endpoint Y is not described.

Figure 23: Point-to-Multipoint Service with Two Hubs



Configuration on Endpoint A

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint A (device SFO). This device is configured as a service hub.

```
interfaces {
  ge-0/0/2 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services;
    unit 3 {
      encapsulation vlan-vpls;
      vlan-tags outer 3;
      family vpls {
        filter {
          input filter_in_ge-0/0/2_3;
        }
      }
    }
  }
}
```

```

    }
}

policy-options {
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN-hm-export {
        term 1 {
            then {
                community add export-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4;

                accept;
            }
        }
        term 2 {
            then reject;
        }
    }
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN-hm-import {
        term 1 {
            from {
                protocol bgp;
                community [ import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:5
import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 ];
            }
            then accept;
        }
        term 2 {
            then reject;
        }
    }

    community export-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 members
target:65410:4;
    community import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 members
target:65410:4;
    community import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:5 members
target:65410:5;
}

firewall {
    family vpls {
        filter filter_in_ge-0/0/2_3 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/2_3;

```

```

        accept;
    }
}

policer policer_in_ge-0/0/2_3 {
    if-exceeding {
        bandwidth-limit 10m;
        burst-size-limit 15220;
    }
    then discard;
}

ELAN_Hub_Spoke_QinQ_AllVLAN {
    instance-type vpls;
    interface ge-0/0/2.3;
    route-distinguisher 65410:9;
    vrf-import ELAN_Hub_Spoke_QinQ_AllVLAN-hm-import;
    vrf-export ELAN_Hub_Spoke_QinQ_AllVLAN-hm-export;
    protocols {
        vpls {
            mac-table-size {
                5120;
            }
            interface-mac-limit {
                1024;
            }
            no-tunnel-services;
            site Site_2 {
                site-identifier 2;
                site-preference primary;
                interface ge-0/0/2.3;
            }
        }
    }
}

```

Configuration on Endpoint B

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint B (device SJC). This device is configured as a service hub.

```

interfaces {
  ge-0/0/4 {
    flexible-vlan-tagging;
    mtu 1522;
    encapsulation flexible-ethernet-services
    unit 3 {
      encapsulation vlan-vpls;
      vlan-tags outer 3;
      family vpls {
        filter {
          input filter_in_ge-0/0/4_3;
        }
      }
    }
  }
}
policy-options {
  policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN-hm-export {
    term 1 {
      then {
        community add export-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4;

        accept;
      }
    }
    term 2 {
      then reject;
    }
  }
  policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN-hm-import {
    term 1 {
      from {
        protocol bgp;
        community [ import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:5
import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 ];
      }
      then accept;
    }
    term 2 {
      then reject;
    }
  }
}

```

```

        community export-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 members
target:65410:4;
        community import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 members
target:65410:4;
        community import-comm-hm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:5 members
target:65410:5;

}

firewall {
    family vpls {
        filter filter_in_ge-0/0/4_3 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-0/0/4_3;
                    accept;
                }
            }
        }
    }
    policer policer_in_ge-0/0/4_3 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 15220;
        }
        then discard;
    }
}

ELAN_Hub_Spoke_QinQ_AllVLAN {
    instance-type vpls;
    interface ge-0/0/4.3;
    route-distinguisher 65410:10;
    vrf-import ELAN_Hub_Spoke_QinQ_AllVLAN-hm-import;
    vrf-export ELAN_Hub_Spoke_QinQ_AllVLAN-hm-export;
    protocols {
        vpls {
            mac-table-size {
                5120;
            }
            interface-mac-limit {
                1024;
            }
        }
        no-tunnel-services;
        site Site_3 {

```



```

        site-identifier 3;
        site-preference primary;
        interface ge-0/0/4.3;
    }
}
}
}

```

Configuration on Endpoint Z

The following statements show the interface configuration, the filter configuration, and connectivity configuration on endpoint Z (device Beijing). This device is configured as a service spoke.

```

interfaces {
    ge-5/0/2 {
        flexible-vlan-tagging;
        mtu 1522;
        encapsulation flexible-ethernet-services;
        unit 1 {
            encapsulation vlan-vpls;
            vlan-tags outer 1;
            family vpls {
                filter {
                    input filter_in_ge-5/0/2_1;
                }
            }
        }
    }
}

policy-options {
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN-export {
        term 1 {
            then {
                community add export-comm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:5;
                accept;
            }
        }
        term 2 {
            then reject;
        }
    }
    policy-statement ELAN_Hub_Spoke_QinQ_AllVLAN-import {

```

```

    term 1 {
        from {
            protocol bgp;
            community import-comm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4;
        }
        then accept;
    }
    term 2 {
        then reject;
    }
}

community export-comm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:5 members
target:65410:5;
community import-comm-ELAN_Hub_Spoke_QinQ_AllVLAN-65410:4 members
target:65410:4;
}

firewall {
    family vpls {
        filter filter_in_ge-5/0/2_1 {
            interface-specific;
            term 1 {
                then {
                    policer policer_in_ge-5/0/2_1;
                    accept;
                }
            }
        }
    }
    policer policer_in_ge-5/0/2_1 {
        if-exceeding {
            bandwidth-limit 10m;
            burst-size-limit 15220;
        }
        then discard;
    }
}

routing-instances {
    ELAN_Hub_Spoke_QinQ_AllVLAN {
        instance-type vpls;
        interface ge-5/0/2.1;
        route-distinguisher 65410:8;
        vrf-import ELAN_Hub_Spoke_QinQ_AllVLAN-import;
        vrf-export ELAN_Hub_Spoke_QinQ_AllVLAN-export;
        protocols {
            vpls {

```

```

        mac-table-size {
            5120;
        }
        interface-mac-limit {
            1024;
        }
        no-tunnel-services;
        site Site_1 {
            site-identifier 1;
            site-preference primary;
            interface ge-5/0/2.1;
        }
    }
}

```

RELATED DOCUMENTATION

[Creating a Point-to-Multipoint E-LAN Service Definition | 726](#)

[Predefined E-Line Service Definitions | 548](#)

[Predefined Multipoint-to-Multipoint Ethernet Service Definitions | 592](#)

Predefined Full Mesh IP Service Definitions

The Connectivity Services Director application section provides information about predefined service definitions used for creating IP full mesh services.

If neither of the predefined service definitions described here is appropriate for your needs, you can create a service definition as described in [“Creating a Full-Mesh IP Service Definition” on page 765](#).

The Connectivity Services Director application provides predefined service definitions for IP services that use the BGP or OSPF protocols.

Information specific to each service instance, such as the device name, endpoint name, VLAN ID, Interface IP, Peer AS (BGP), and whether you want to allow a service provisioner to create static routes on the service, is provided in the service order.

[Table 72 on page 643](#) lists each of the standard VPLS service definitions. Each standard service definition is then described in detail in the sections that follow.

Table 72: Standard Full-Mesh IP Service Definitions

Standard Service Definition Name	Predefined Service Attributes
L3VPN-OSPF-STATIC L3 VPN (Full Mesh)	<ul style="list-style-type: none"> • VLAN ID selection: Auto pick • Route target: Auto pick • Route distinguisher: Auto pick • Allowed Routing Protocols <ul style="list-style-type: none"> • OSPF/Static Route • BGP/Static Route • BGP/OSPF/Static Route
L3VPN-BGP-STATIC L3 VPN (Full Mesh)	<ul style="list-style-type: none"> • VLAN ID selection : Auto pick • Route target: Auto pick • Route distinguisher: Auto pick • Allowed Routing Protocols <ul style="list-style-type: none"> • OSPF/Static Route • BGP/Static Route • BGP/OSPF/Static Route

RELATED DOCUMENTATION

[Creating a Full-Mesh IP Service Definition | 765](#)

[Predefined Service Definitions | 479](#)

[Predefined E-Line Service Definitions | 548](#)

[Predefined Multipoint-to-Multipoint Ethernet Service Definitions | 592](#)

[Predefined Point-to-Multipoint Ethernet Service Definitions | 625](#)

[Predefined Hub-and Spoke IP Service Definitions | 643](#)

Predefined Hub-and Spoke IP Service Definitions

The Connectivity Services Director application provides predefined service definitions that use BGP or OSPF routing protocols that you, the service provisioner, can use to create a service order. You must have a Service Designer user role to use IP hub-and-spoke service definitions.

You view predefined and custom service definitions in the **Service Design >Manage Service Definitions** inventory page. You can view service definition details or attributes in the **Manage Service Definitions** inventory page by clicking the service definition.

You can also view service instance details by selecting **Service Provisioning > Deploy Services > Manage Service Orders** in Deploy mode of Service View.

[Table 73 on page 644](#) describes the predefined or standard hub-and-spoke (one interface) service definitions and their preconfigured service attributes. You can not reconfigure attributes in these predefined services. However, if you need custom attributes, create a new hub-and-spoke service definition to use, as described in the *Creating a IP Hub-and-Spoke Service Definition* topic.

Table 73: Standard Hub-and-Spoke Service Definitions

Standard Service Definition Name	Description	Predefined Service Attributes
L3VPN-OSPF-Static (Hub-Spoke-1-Interface)	L3VPN Hub and Spoke 1 interface with OSPF/Static as PE-CE routing protocol	<ul style="list-style-type: none"> • VLAN ID selection: Auto pick This attribute is editable in the service order. • Route target: Auto pick • Pick VLAN within this range: N/A • Route target: Auto pick • Route distinguisher: Auto pick This attribute is editable in the service order. The VRF table label option is selected. • Allowed Routing Protocols: OSPF/Static Route
L3VPN-BGP-Static (Hub-Spoke-1-Interface)	L3VPN Hub and Spoke 1 interface with BGP/Static as PE-CE routing protocol	<ul style="list-style-type: none"> • VLAN ID selection: Auto pick This attribute is editable in the service order. • Route target: Auto pick • Pick VLAN within this range: N/A • Route target: Auto pick • Route distinguisher: Auto pick This attribute is editable in the service order. The VRF table label option is selected. • Allowed Routing Protocols: BGP/Static Route

RELATED DOCUMENTATION

[Viewing Service Definitions | 692](#)

[Creating a Hub-and-Spoke \(One Interface\) IP Service Definition | 776](#)

[Creating a Full-Mesh IP Service Definition | 765](#)

Service Design: Managing E-Line Service Definitions

IN THIS CHAPTER

- [Choosing a Predefined Service Definition or Creating a New Service Definition | 645](#)
- [Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)
- [Monitoring Performance Management Statistics | 682](#)
- [Modifying a Custom Service Definition | 688](#)
- [Publishing a Custom Service Definition | 690](#)
- [Unpublishing a Custom Service Definition | 691](#)
- [Deleting a Customized Service Definition | 691](#)
- [Viewing Service Definitions | 692](#)

Choosing a Predefined Service Definition or Creating a New Service Definition

IN THIS SECTION

- [Choosing a Predefined Service Definition | 646](#)
- [Creating an E-Line Service Definition | 652](#)

The Connectivity Services Director software provides a set of predefined service definitions for E-Line services, multipoint-to-multipoint E-LAN (full mesh) services, and point-to-multipoint E-LAN (hub and spoke) services. These service definitions are capable of providing the basis for most of the service orders your organization will need to create. In case these predefined service definitions are not adequate for all your needs, however, the Connectivity Services Director software enables you to create service definitions of your own.

The following topics review the predefined service definitions and provide instructions on creating your own.

Choosing a Predefined Service Definition

[Table 74 on page 646](#) lists the predefined service definitions that Junos Space provides for E-Line services that use LDP in the network core. [Table 75 on page 649](#) lists the predefined service definitions for multipoint-to-multipoint (full mesh) services. [Table 72 on page 643](#) lists the predefined service definitions for point-to-multipoint (hub and spoke) services.

Table 74: Standard E-Line Service Definitions

Standard Service Definition Name	Service Attributes
ELine-Dot1q-SingleVLAN	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint circuit types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-Dot1q-SingleVLAN-CCC	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint circuit types • Customer traffic is single VLAN • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-Dot1q-SingleVLAN-Ext-CCC	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint circuit types • Customer traffic is single VLAN • Extended-vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-PortBased	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint circuit types • Port-based UNI • Rate limiting default 10 Mbps

Table 74: Standard E-Line Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
ELine-QinQ-AllVLAN	<ul style="list-style-type: none"> • E-Line service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-QinQ-AllVLAN-CCC	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • All customer traffic • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-QinQ-AllVLAN-Ext-CCC	<ul style="list-style-type: none"> • E-Line service for J Series, M Series, and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • All customer traffic • Extended-vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-QinQ-VLANRange	<ul style="list-style-type: none"> • E-Line service for MX Series devices only • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • Customer traffic is range of VLANs • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELine-QinQ-VLANRange-CCC	<ul style="list-style-type: none"> • E-Line service for MX Series devices only • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • Customer traffic is range of VLANs • Vlan-ccc physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 74: Standard E-Line Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
ELine-QinQ-VLANRange-Ext-CCC	<ul style="list-style-type: none"> • E-Line service for MX Series devices only • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • Customer traffic is range of VLANs • Extended-vlan-ccc physical encapsulation • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
Eline-BGP-QinQ-AllVLAN	<ul style="list-style-type: none"> • Ethernet service for M/MX/ACX device family • Gigabit Ethernet interface • Q-in-Q endpoint interface type • Transport all traffic • Flexible-ethernet-services physical encapsulation type • Rate limit from 10 Mbps to 100 Mbps with 10 Mbps increment
Eline-BGP-Dot1q-SingleVLAN	<ul style="list-style-type: none"> • Ethernet service for M/MX/ACX device family • Gigabit Ethernet interface • 802.1Q endpoint interface types • Single VLAN traffic • Flexible-ethernet-services physical encapsulation type • Rate limit from 10 Mbps to 100 Mbps with 10 Mbps increment
Eline-BGP-PortBased	<ul style="list-style-type: none"> • Ethernet service for M/MX/ACX device family • Gigabit Ethernet interface • Port-based UNIs • Ethernet-ccc physical encapsulation type • Rate limit from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 75: Standard Multipoint-to-Multipoint Service Definitions

Standard Service Definition Name	Service Attributes
ELAN-BGP-Dot1q-Normalized-VLAN-None	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs not preserved • 802.1Q endpoint circuit types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELAN-BGP-Dot1Q-SingleVLAN	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • 802.1Q endpoint circuit types • Customer traffic is single VLAN • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELAN-BGP-PortBased	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M series and MX Series devices • Gigabit Ethernet interfaces • Port-based UNIs • Transports all customer traffic • Ethernet VPLS as physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELAN-BGP-QinQ-AllVLAN	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 75: Standard Multipoint-to-Multipoint Service Definitions (*continued*)

Standard Service Definition Name	Service Attributes
ELAN-BGP-QinQ-AllVLAN-Normalized-All	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs preserved • Q-in-Q endpoint circuit types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELAN-BGP-QinQ-AllVLAN-Normalized-None-10-100M	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Q-in-Q endpoint circuit types • VLAN IDs not preserved • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELAN-BGP-QinQ-Range-Normalized-VLAN	<ul style="list-style-type: none"> • Multipoint-to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs preserved • Q-in-Q endpoint circuit types • Transports specified VLAN range • Flexible Ethernet services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Table 76: Standard Point-to-Multipoint Service Definitions

Standard Service Definition Name	Service Attributes
ELAN-Hub-Spoke-QinQ-AllVLAN	<ul style="list-style-type: none"> • Point to-multipoint Ethernet service for M Series and MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are not preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment
ELAN-Hub-Spoke-QinQ-AllVLAN-No	<ul style="list-style-type: none"> • Point-to-multipoint Ethernet service for M Series or MX Series devices • Gigabit Ethernet interfaces • Customer VLAN IDs are preserved • Q-in-Q endpoint interface types • All customer traffic • Flexible-ethernet-services physical encapsulation type • Rate limiting from 10 Mbps to 100 Mbps with 10 Mbps increment

Many of the service attributes can be edited in the service order, which allows the flexibility for creating most of the service orders you will need from these predefined service definitions.

To view the contents of a predefined service definition, follow these steps:

1. in the Network Services > Connectivity view pane, select **Service Design > Manage Service Definitions**.

The **Manage Service Definitions** page appears and shows all the service definitions present on your system.

2. Double click the predefined service definition you want to review.

Details of the service definition replace the **Manage Service Definitions** page.

TIP: If predefined and customized service definitions both exist on your system, you can easily find the predefined ones in the service definition inventory page.

3. When you are done reviewing the service definition, click **Back** to return to the **Manage Service Definitions** page.

For detailed descriptions of each of the predefined service definitions and their service attributes, see [“Predefined Service Definitions” on page 479](#)

Creating an E-Line Service Definition

Use this procedure to create a definition for an E-Line service. The standard service definitions that came with your initial software installation are designed to be appropriate for most requirements. You can also create a customized service definition—for example, to set different bandwidth limits on the service than those offered in the standard service definitions.

After the new service definition is complete and published, network operators or service provisioners can use the completed service definition as a base for creating and then activating E-Line services on the network.

The windows appear in the order stated. You can, however, perform these steps in any order by accessing them through the task list in the right panel. If the panel is not visible, click the snap tool on the right side of the main display area.

To create an E-Line service definition, complete these tasks, in the order shown:

1. [Specifying General Information | 652](#)
2. [Specifying UNI Settings | 656](#)
3. [Specifying Connectivity Information When Signaling Is LDP | 669](#)
4. [Specifying Connectivity Information When Signaling Is BGP | 672](#)
5. [Reviewing the Configured Settings | 674](#)

Specifying General Information

A wizard is available to create a service order in an intuitive and easily-navigable format. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create a Service Definition page. Alternatively, you can proceed to the corresponding setting-related pages by clicking the **Back** and **Next** buttons at any point in the wizard during the creation of the service definition.

To specify the general information for an E-Line service definition:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. in the Network Services > Connectivity view pane, select **Service Design > Manage Service Definitions**.
 - Select **E-Line** to create an E-Line service definition.
 - Select **E-LAN** to create an E-LAN service definition.
 - Select **IP** to create an IP service definition.

The **Manage Service Definitions** page displays an inventory of all available E-Line service definitions.

4. Click the **New** icon at the top of the lower half of the page that displays previously created service orders, and click **E-Line** from the Select Service Type dialog box appears. The **General** settings window appears.
5. Fill in the fields in the **General** window.

Field	Action
Service Definition Name	Enter a name for the service definition.
Service Type	By default, the service type is E-Line .
Signaling	<p>Select a signaling type:</p> <ul style="list-style-type: none"> • BGP • LDP <p>You cannot edit the Signaling type in the service order.</p> <p>NOTE: If the signaling type is BGP, the Static Pseudowire and the Enable PW Access to L3 VPN Network check boxes are not available. You cannot edit the Signaling type in the service order.</p>
Description (Optional)	<p>Enter a brief description or other comment that you want to appear in the Service Definition table.</p> <p>Range: 0 through 200 characters. Spaces and special characters are allowed.</p>
Enable QoS	<p>When you enable QoS in the service definition, you can specify a QoS profile in the service order to classify traffic into defined service groups to provide the special treatment of traffic across the network service. For example, voice traffic can be sent across certain links, and data traffic can use other links.</p>
Pseudowire Type	<p>Select the interface type:</p> <ul style="list-style-type: none"> • Ethernet • TDM • ATM

Field	Action
Instance Type	<p>Select an instance type to specify the type of routing instance for the E-Lan service:</p> <ul style="list-style-type: none"> • l2vpn • evpn-vpws
Static Pseudowire	<p>To enable static pseudowire, select the Static Pseudowire check box. This check box is disabled if the signaling type is BGP.</p>
Enable PW Access to L3 VPN Network	<p>To enable the pseudowire access to L3 VPN network, select the Enable PW Access to L3 VPN Network check box. This check box is disabled if the signaling type is BGP, or if you have selected the interface type as TDM/ATM.</p> <p>If you select this check box, the Enable Multi Segment Pseudowire check box is disabled.</p>
Enable Multihoming	<p>Select this check box to pair any two N-PE devices, for providing redundant connectivity.</p> <p>When you select this check box, a Multihoming Mode list appears based on the instance type. If you select evpn-vpws instance type, you can select either single-active or all-active as the multihoming mode.</p>
Enable Multi Segment Pseudowire	<p>Select this check box to enable multi-segment pseudowire.</p> <p>If you select this check box, the Enable PW Access to L3 VPN Network check box is disabled.</p> <p>A multi-segment pseudowire (MS-PW) is a static or dynamically configured set of two or more contiguous pseudowire segments that behave and function as a single E-Line pseudowire. Each end of an MS-PW, by definition, terminates on a T-PE.</p> <p>NOTE: The number of pseudowire segments that you can stitch is limited to two.</p> <p>For more information on E-Line pseudowire stitching, see “Stitching Two E-Line Pseudowires” on page 920.</p>

Field	Action
Enable PW Resiliency	To enable the pseudowire resiliency, select the Enable PW Resiliency check box. For more information on pseudowire redundancy, see “Redundant Pseudowires for Layer 2 Circuits and VPLS” on page 98.
Decouple Service Status From Port Status	<p>By default, all the events are saved in the OpenNMS database. To isolate the events related to an interface in the OpenNMS, select the Decouple Service Status From Port Status check box.</p> <p>NOTE: When you select this check box, only the pseudowire traps are monitored, and not the interface-related traps (such as jnxVpnIfUp or jnxVpnIfDown).</p>
Service Template	<p>(Optional) To include a service template for the service, click the Add icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click OK. You are returned to the General Settings page.</p> <p>The selected service template appears in the Default Service Template field.</p> <p>You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.</p> <p>NOTE: You cannot add or delete a service template while creating a service order.</p> <p>The remaining service templates on the Service Template list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.</p> <p>In the View Service Definition Details window, the value for the default service template in the Default Service Template column is <i>True</i>.</p> <p>For instructions on creating a service template, see <i>Creating a Service Template</i>.</p>

6. Click **Next** to save the information. You can proceed to [“Specifying UNI Settings” on page 656.](#)

Specifying UNI Settings

In this step, you provide the UNI service attributes for this service definition. The attributes you set depend on whether you are setting attributes for a port, an 802.1Q interface, a Q-in-Q interface, or a flexible VLAN tagging:

- [Specifying UNI Settings for Port-to-Port Services | 656](#)
- [Specifying UNI Settings for Services with 802.1Q Interface Types | 658](#)
- [Specifying UNI Settings for Services with Q-in-Q Interface Types | 661](#)
- [UNI Settings for Services with Flexible VLAN Tagging \(Asymmetric Interface Types\) | 665](#)

Specifying UNI Settings for Port-to-Port Services

To set UNI attributes for a port-to-port service, complete the following procedure.

1. Enter information in the UNI Settings window.
2. Fill in the fields in the **UNI Settings** window according to the following table.

Field	Action
Traffic Treatment Settings	
Ethernet Option	<p>Select port from the list.</p> <p>The Ethernet option you choose determines the other options you can select and specify on the page.</p>
Customer Traffic Type	This option is disabled. For port-to-port services, all traffic is always transported.
VLAN ID Selection	In port-to-port services, all traffic and all VLANs on one port are transported to all other ports.
VLAN Normalization	For port-to-port services, VLAN normalization is disabled.
Editable in Service Order	Select this check box to allow the service provisioner to override the MTU setting.
Interface Settings	
Physical Interface	Select ethernet-vpls , the only valid physical interface encapsulation method allowed for port-to-port services.
Logical Interface	You cannot change this field because it is not relevant to port-to-port services.
MTU Settings	

Field	Action
Default MTU (Bytes)	<p>You can specify an MTU value in this field. The default value for MTU is 1522 bytes.</p> <p>To see the permitted range for the MTU value, select the Editable in Service Order check box. The MTU range is 1522 through 9192.</p>
MTU Range (Bytes)	<p>If you select the check box Editable in Service Order, you can specify a value range for MTU (in bytes). The permitted range for MTU is 1522 through 9192.</p> <p>NOTE: Ultimately, the system establishes the MTU by multiplying the value you specify in the Default MTU (Bytes) field by the value you specify for MTU Factor.</p>

Calculation of Burst-Size

Calculate Burst Size	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based <p>If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902.</p> <p>The default value for MTU Factor is 10.</p> Line Rate Based <p>If you select the option Line Rate Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds.</p> <p>The default value for Burst Period is 1.</p> <p>NOTE: The Calculate Burst Size list is enabled only when you select the Enable rate limiting check box.</p>
-----------------------------	--

Bandwidth Settings

Enable Rate Limiting (check box)	If you select this check box, you can override the MTU setting.
Default Bandwidth (Mbps)	<p>Specify the default bandwidth value, in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>To override the default bandwidth value, select the Editable in Service Order check box.</p> <p>Specify the minimum bandwidth value in Kbps:</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Field	Action
Max Bandwidth (Mbps)	Specify the maximum bandwidth value, in Mbps. Default: 100 Mbps Range: 1 Mbps through 100,000 Mbps

The following table lists the **Max Bandwidth (Mbps)** for the M Series, MX Series, and ACX Series Routers:

Table 77: Maximum Bandwidth for M Series, MX Series, and ACX Series Routers

M Series IQ2E PIC		M Series IQ2 PIC		MX Series 3D PIC		MX Series Non-3D PIC		ACX 2000	
GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)
32,000 Mbps or 32 Gbps	32,000 Mbps or 32 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	100,000 Mbps or 100 Gbps	100,000 Mbps or 100 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps
Increment (Kbps)		Specify a value in the range that is made available to the service provisioner.							

3. Click **Next** to proceed to specify the connectivity settings.

Specifying UNI Settings for Services with 802.1Q Interface Types

To set UNI attributes for a 802.1Q service, complete the following procedure.

1. To set UNI attributes for 802.1Q interfaces:
2. Fill in the fields in the **UNI Settings** window according to the following table:

Field	Action
Traffic Treatment Settings	
Ethernet Option	Select dot1q from the list. The window expands to include options specific to dot1q interfaces.

Field	Action
Customer Traffic Type	<p>Specify the customer traffic type.</p> <ul style="list-style-type: none"> • Select Transport Single VLAN to transport traffic for a specific VLAN across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify the Outer Tag protocol ID. • Select Transport VLAN List to limit traffic across the network to a specific list of VLANs. If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition. The VLAN List can consist of a single VLAN-ID or a combination of single VLAN-ID and VLAN-ID range separated by commas. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>
VLAN ID Selection	<p>Indicate how the VLAN ID is selected during service order creation.</p> <ul style="list-style-type: none"> • Select manually—Allows the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. NOTE: Make sure to check Editable in Service Order if you want the service provisioner to be able to override this setting. Specify the VLAN ID range in VLAN range for manual input. • Auto pick—This option is normally used when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. NOTE: Make sure to check Editable in Service Order if you want the service provisioner to be able to override this setting. <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.

Field	Action
VLAN range for auto-pick	Specify the VLAN ID pool. Range: 1 through 4094
VLAN range for manual input	Specify the VLAN ID range. Range: 1 through 4094
Outer Tag protocol ID	<p>Select the outer tag protocol ID if the Customer Traffic Type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPIDs) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You cannot specify the Inner Tag protocol ID if the Customer Traffic Type is Transport Single VLAN or Transport Vlan List.</p>
Editable in service order	Select this check box to allow the service provisioner to override the MTU setting.
Interface Settings	
Physical Interface	Select the default physical encapsulation scheme to be used by service orders based on this service definition. We recommend you select flexible-ethernet-services .

Field	Action
Logical Interface	Constrained by your selection in the Physical Interface box. If you selected the recommended physical encapsulation mode of flexible-ethernet-services, then your only option is to select vlan-vpls for the logical encapsulation method.
MTU Settings	
Default MTU (Bytes)	<p>You can specify an MTU value in this field. The default value for MTU is 1522.</p> <p>To see the permitted range for the MTU value, select the Editable in Service Order check box. The MTU range is 1522 through 9192.</p>
MTU Range (Bytes)	<p>If you select the check box Editable in Service Order, you can specify a value range for MTU (in bytes). The permitted range for MTU is 1522 through 9192.</p> <p>NOTE: Ultimately, the system establishes the MTU by multiplying the value you specify in the Default MTU (Bytes) field by the value you specify for MTU Factor.</p>
Calculation of Burst-Size	
Calculate Burst Size	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> • MTU Based <p>If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902.</p> <p>The default value for MTU Factor is 10.</p> • Line Rate Based <p>If you select the option Line Rate Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds.</p> <p>The default value for Burst Period is 1.</p> <p>NOTE: The Calculate Burst Size list is enabled only when you select the Enable rate limiting check box.</p>

3. Click **Next** to continue with connectivity settings.

Specifying UNI Settings for Services with Q-in-Q Interface Types

To set UNI attributes for a Q-in-Q service, complete the following procedure.

1. To set UNI attributes for Q-in-Q interfaces:

2. Fill in the fields in the **UNI Settings** window according to the following table:

Field	Action
Traffic Treatment Settings	
Ethernet Option	<p>Select qinq from the list.</p> <p>The window expands to include options specific to Q-in-Q interfaces.</p>
Customer Traffic Type	<p>Specify the customer traffic type:</p> <ul style="list-style-type: none"> • Transport All Traffic—Transports the traffic from all VLANs across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID. • Transport Single VLAN—Transports traffic for a specific VLAN across the network. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID. • Select Transport VLAN List to limit traffic across the network to a specific list of VLANs. You need to specify only the Outer Tag protocol ID. <p>If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition. The VLAN List can consist of a single VLAN-ID or a combination of single VLAN-ID and VLAN-ID range separated by commas.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN ID selection	<p>Indicate how the VLAN ID is selected during service order creation.</p> <ul style="list-style-type: none"> • Select manually—Allows the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. <p>NOTE: Make sure to check Editable in Service Order if you want the service provisioner to be able to override this setting. Specify the VLAN ID range in VLAN range for manual input.</p> <ul style="list-style-type: none"> • Auto pick—This option is normally used when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to check Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick:	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag protocol ID	<p>Select the outer tag protocol ID if the Customer Traffic Type is Transport single VLAN, Transport VLAN List, or Transport all Traffic:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPIDs) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You can specify the Inner Tag protocol ID only if the Customer Traffic Type is Transport single VLAN.</p>
Editable in Service Order	Select this check box to allow the service provisioner to override the MTU setting.
Interface Settings	
Physical Interface	Select the default physical encapsulation scheme to be used by service orders based on this service definition. We recommend you select flexible-ethernet-services .
Logical Interface	Constrained by your selection in the Physical Interface box. If you selected the recommended physical encapsulation mode of flexible-ethernet-services, then your only option is to select vlan-vpls for the logical encapsulation method.
MTU Settings	

Field	Action
Default MTU (Bytes)	<p>You can specify an MTU value in this field. The default value for MTU is 1522.</p> <p>To see the permitted range for the MTU value, select the Editable in Service Order check box. The MTU range is 1522 through 9192.</p>
MTU Range (Bytes)	<p>If you select the check box Editable in Service Order, you can specify a value range for MTU (in bytes). The permitted range for MTU is 1522 through 9192.</p> <p>NOTE: Ultimately, the system establishes the MTU by multiplying the value you specify in the Default MTU (Bytes) field by the value you specify for MTU Factor.</p>

Calculation of Burst-Size

Calculate Burst Size	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based <p>If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902.</p> <p>The default value for MTU Factor is 10.</p> Line Rate Based <p>If you select the option Line Rate Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds.</p> <p>The default value for Burst Period is 1.</p> <p>NOTE: The Calculate Burst Size list is enabled only when you select the Enable rate limiting check box.</p>
-----------------------------	--

- Click **Next** to continue with connectivity settings.

UNI Settings for Services with Flexible VLAN Tagging (Asymmetric Interface Types)

You can specify the Ethernet option **asymmetric tag depth** to create a service that includes any combination of port-based interfaces, 802.1Q interfaces, and Q-in-Q interfaces.

- Enter information in the UNI Settings window.
- Specify the UNI Settings for asymmetric tag depth according to the following table:

Field	Action
Traffic Treatment Settings	
Ethernet Option	Select asymmetric tag depth from the list.

Field	Action
Customer Traffic Type	<p>Select the customer traffic type:</p> <ul style="list-style-type: none"> • Transport All Traffic—Transports the traffic from all VLANs across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID and Inner Tag protocol ID. • Transport Single VLAN—Transports traffic for a specific VLAN across the network. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID. • Select Transport VLAN List to limit traffic across the network to a specific list of VLANs. You need to specify the Outer Tag protocol ID. <p>If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition.</p> <p>The VLAN List can consist of a single VLAN-ID or a combination of single VLAN-ID and VLAN-ID range separated by commas.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN ID selection	<p>Indicate how the VLAN ID is selected during service order creation.</p> <ul style="list-style-type: none"> ● Select manually—Allows the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to check Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> ● Auto pick—This option is normally used when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to check Editable in Service Order if you want the service provisioner to be able to override this setting. Specify the VLAN ID pool in VLAN range for auto-pick.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> ● If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. ● If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick:	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag protocol ID	<p>Select the outer tag protocol ID if the Customer Traffic Type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPIDs) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You cannot specify the Inner Tag protocol ID if the Customer Traffic Type is Transport all traffic.</p>
Editable in Service Order	To allow the service provisioner to override the MTU setting, select the check box for those options.
Interface Settings	
Physical Interface	Select the default physical encapsulation scheme to be used by service orders based on this service definition. We recommend you select flexible-ethernet-services .
Logical Interface	Constrained by your selection in the Physical Interface box. If you selected the recommended physical encapsulation mode of flexible-ethernet-services, then your only option is to select vlan-vpls for the logical encapsulation method.
MTU Settings	

Field	Action
Default MTU (Bytes)	<p>You can specify an MTU value in this field. The default value for MTU is 1522.</p> <p>To see the permitted range for the MTU value, select the Editable in Service Order check box. The MTU range is 1522 through 9192.</p>
MTU Range (Bytes)	<p>If you select the check box Editable in Service Order, you can specify a value range for MTU (in bytes). The permitted range for MTU is 1522 through 9192.</p> <p>NOTE: Ultimately, the system establishes the MTU by multiplying the value you specify in the Default MTU (Bytes) field by the value you specify for MTU Factor.</p>
Calculation of Burst-Size	
Calculate Burst Size	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based <p>If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902.</p> <p>The default value for MTU Factor is 10.</p> Line Rate Based <p>If you select the option Line Rate Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds.</p> <p>The default value for Burst Period is 1.</p> <p>NOTE: The Calculate Burst Size list is enabled only when you select the Enable rate limiting check box.</p>

3. Click **Next** to continue with specifying the connectivity settings.

Specifying Connectivity Information When Signaling Is LDP

The fields displayed in the **Connectivity** window depend on the **Signaling type** (LDP or BGP) that you selected in the **General** settings window.

To specify connectivity between sites across the network when signaling is LDP:

1. Fill in the fields in the **Connectivity** window.

Field	Action
VC ID selection	<p>The VC ID selection is available only if the Signaling type is LDP.</p> <p>In the VC ID selection box, specify how you want the VC ID to be chosen during service order creation:</p> <ul style="list-style-type: none"> • To allow the service provisioner to enter the VC ID, choose Select manually. • To cause the Junos Space software to assign a VC ID automatically from the VC ID pool, select Auto pick. <p>To allow the service provisioner to override the setting in the VC ID box, select Editable in Service Order.</p>
Default MTU	<p>In the Default MTU box, specify the MTU across the service provider network.</p> <p>To allow the service provisioner to override the MTU setting, select Editable in Service Order. In the MTU range, enter the highest and lowest MTU that the service provisioner can enter.</p>
Revert time (sec)	<p>This field is available if you selected the Enable PW Resiliency check box and if the Signaling is LDP in the General settings.</p> <p>Revert time (sec)—Revert time for redundant Layer 2 circuits and VPLS pseudowires.</p> <p>Default: 5 seconds</p> <p>Range: 0 through 65,535 seconds</p>
Switch Over Delay (sec)	<p>This field is available if you selected the Enable PW Resiliency check box and if the Signaling is LDP, in the General settings.</p> <p>Switch Over Delay (sec)—Delay to wait before the backup pseudowire takes over.</p> <p>Default: 0 second</p> <p>Range: 0 through 180 seconds</p>
VLAN Normalization	<p>The options available in the VLAN normalization drop-down list are based on the value set for the Ethernet interface.</p>
Outgoing label selection	<p>This field is available if you selected the Static pseudowire check box in the General settings. By default, the outgoing label selection is limited to manual.</p>

The following table presents the available **VLAN normalization** options:

Ethernet Option	Customer Traffic Type	VLAN Normalization
port	N/A	Normalization not required Normalization to Dot1q tag Normalization to QinQ tags
dot1q	Transport Single VLAN	Swap Normalize to None Normalization to Dot1q tag Normalization to QinQ tags
	Transport VLAN Range	Normalization not required
	Transport VLAN List	Normalization not required
qinq	Transport All Traffic	Swap Normalize to None Normalization to Dot1q tag Normalization to QinQ tags
	Transport Single VLAN	Swap Normalize to None Normalization to Dot1q tag Normalization to QinQ tags
	Transport VLAN Range	Normalization not required
	Transport VLAN List	Normalization not required
asymmetric tag depth	(Identical to qinq)	(Identical to qinq)

2. Click **Finish** to complete the service definition.

Specifying Connectivity Information When Signaling Is BGP

To specify connectivity between sites across the network when signaling is BGP, fill in the fields in the Connectivity window:

1. When the signaling type is BGP, fill in the fields in the **Connectivity** window.
 - **Route Distinguisher**—Identifier attached to a route, enabling you to distinguish to which VPN the route belongs. Each routing instance must have a unique route distinguisher associated with it.
Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295
 - **Route Target**—Allows you to distribute VPN routes to only the routers that need them.
Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295
 - **Default MTU (Bytes)**—The default MTU established by the system.
 - **MTU range (Bytes)**—Specify the range, in bytes, for the MTU.
 - **VLAN normalization**—The options available in the **VLAN normalization** field are based on the value set for the Ethernet interface. The following table presents the options.

Ethernet Option	Customer Traffic Type	VLAN Normalization
port	N/A	Normalization not required Normalization to Dot1q tag Normalization to QinQ tags
dot1q	Transport Single VLAN	Swap Normalize to None Normalization to Dot1q tag Normalization to QinQ tags
	Transport VLAN Range	Normalization not required
	Transport VLAN List	Normalization not required
qinq	Transport All Traffic	Swap Normalize to None Normalization to Dot1q tag Normalization to QinQ tags
	Transport Single VLAN	Swap Normalize to None Normalization to Dot1q tag Normalization to QinQ tags
	Transport VLAN Range	Normalization not required
	Transport VLAN List	Normalization not required
asymmetric tag depth	(Identical to qinq)	(Identical to qinq)

NOTE: For a description of how the Connectivity Services Director software manipulates VLANs, see [“Understanding VLAN Manipulation \(Normalization and VLAN Mapping\) on Ethernet Services”](#) on page 92.

2. Click **Review** to analyze and verify the configured attributes for the service definition.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine and modify the configured service definition settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

When the service definition is successfully created, you are returned to the Manage Service Definitions window.

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)

[Creating an E-Line Service Definition](#)

[Publishing a Custom Service Definition | 690](#)

[Unpublishing a Custom Service Definition | 691](#)

[Deleting a Customized Service Definition | 691](#)

[Viewing Service Definitions | 692](#)

Creating an E-Line ATM or TDM Pseudowire Service Definition

This procedure provides the steps to create a definition for an E-Line ATM or TDM service. The standard service definitions that came with your initial software installation are designed to be appropriate for most requirements. You can also create a customized service definition—for example, to set different bandwidth limits on the service than those offered in the standard service definitions.

After the new service definition is complete and published, network operators or service provisioners can use the completed service definition as a base for creating and then activating E-Line ATM or TDM services on the network.

The windows appear in the order shown. You can, however, perform these steps in any order by accessing them through the task list in the right panel. If the panel is not visible, click the snap tool on the right side of the main display area.

To create an E-Line service definition, complete these tasks, in the order shown:

1. [Specifying General Information for the ATM or TDM Service | 675](#)
2. [Specifying UNI Settings for ATM and TDM Service Definitions | 678](#)
3. [Specifying UNI Settings for ATM Interfaces | 678](#)
4. [Specifying UNI Settings for TDM Interfaces | 678](#)
5. [Specifying Connectivity Information for an ATM or a TDM Service | 679](#)
6. [Reviewing the Configured Settings | 681](#)

Specifying General Information for the ATM or TDM Service

1. In the Build mode of the Network Services > Connectivity task pane, select **Service Design > Manage Service Definitions > New > E-Line Service Definition**.

The first **Create E-Line Service Definition** window appears.

2. In the **Name** box, type a name for the service definition.
3. Select the signaling type:
 - LDP
 - BGP

NOTE: If the signaling type is BGP, the **Static pseudowire**, **Enable PW Resiliency**, **Enable Multi Segment Pseudowire** and the **Enable PW access to L3 VPN network** check boxes are not available.

4. (Optional) In the **Description** box, type a brief description or other comment that you want to appear in the Service Definition table.
5. (Optional) For an ATM or TDM service, only l2vpn instance type is available if the signaling type is BGP. The instance type field is not available for LDP signaling type.
6. The Enable Multihoming check box is optional and is not available if the signaling type is LDP.
7. (Optional) To include a service template for the service, click the **Add** icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click **OK**. You are returned to the General Settings page.

The selected service template appears in the **Default Service Template** field.

You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.

NOTE: You cannot add or delete a service template while creating a service order.

The remaining service templates on the **Service Template** list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.

In the View Service Definition Details window, the value for the default service template in the Default Service Template column is *True*.

For instructions on creating a service template, see *Creating a Service Template*.

8. Select the interface type. If you select TDM or ATM as the interface type, the **Enable PW access to L3 VPN network** check box is unavailable.
9. Select the **Enable Multi Segment Pseudowire** check box to enable multi-segment pseudowire. This check box is available for LDP signaling only

A multi-segment pseudowire is a static or dynamically configured set of two or more contiguous pseudowire segments that behave and function as a single E-Line pseudowire. Each end of a multi-segment pseudowire, by definition, terminates on a T-PE.

NOTE: The number of pseudowire segments that you can stitch is limited to two.

For more information on E-Line pseudowire stitching, see [“Stitching Two E-Line Pseudowires” on page 920](#).

10. Select the **Static pseudowire** check box to indicate whether the E-Line service definition is a static pseudowire.
11. To enable the pseudowire resiliency, select the **Enable PW Resiliency** check box. For more information on pseudowire redundancy, see [“Redundant Pseudowires for Layer 2 Circuits and VPLS” on page 98](#).
12. By default, all the events are saved in the OpenNMS database. To isolate the events related to an interface in the OpenNMS, select the **Decouple Service Status From Port Status** check box.

NOTE: When you select this check box, only the pseudowire traps are monitored, and not the interface-related traps (such as jnxVpnIfUp or jnxVpnIfDown).

13. Click **Next** to continue to the **Connectivity Settings** window.

Specifying UNI Settings for ATM and TDM Service Definitions

In this step, you provide the UNI service attributes for this service definition. The attributes you set depend on whether you are setting attributes for an ATM or for a TDM interface.

Specifying UNI Settings for ATM Interfaces

To specify the UNI settings for ATM interfaces:

1. Fill in the fields as indicated in the table.

Field	Action
Physical Interface Encapsulation	Select the type of encapsulation to apply to the interface. Use atm-ccc-cell-relay for ATM cell relay encapsulation. Use atm-ccc-cell-mux for ATM VC for CCC.
Autopick VPI	Select the virtual path identifier (VPI). The combination of the VPI and VCID defines the next destination for a cell in the ATM network.
Autopick VCI	Select the virtual channel identifier (VCID)—This integer uniquely identifies the virtual circuit that the service uses. The VCID can be either set automatically by the Junos Space software, or the service provisioner can set it manually in the service order. The service definition can force the system to pick the VCID, force the service provisioner to pick the VCID, or allow the service provisioner to override the settings in the service definition. We recommend allocating the VCID automatically; however, service providers with their own systems for allocating VCIDs may choose the manual setting. In the previous example, by default, the system picks a VCID from its pool automatically, but allows the service provisioner to override this value in the service order. Clear the check box to override the service definition setting. The form expands to include an additional field for entering the VCID manually.
Cell bundle size	The range for the cell bundle size can be 1 through 34.

2. Click **Next** to go to the **Connectivity Settings** window.

Specifying UNI Settings for TDM Interfaces

To specify the UNI settings for TDM interfaces:

1. Select the type of **Physical Interface Encapsulation**.

- SAToP—Structure-Agnostic time-division multiplexing (TDM) over Packet (SAToP), as defined in RFC 4553, Structure-Agnostic TDM over Packet (SAToP) is used for pseudowire encapsulation for TDM bits (T1, E1). The encapsulation disregards any structure imposed on the T1 and E1 streams, in particular the structure imposed by standard TDM framing. SAToP is used over packet-switched networks, where the provider edge (PE) routers do not need to interpret TDM data or participate in the TDM signaling.
- CESoPSN—Circuit Emulation Service over Packet-Switched Network (CESoPSN) bundle represents an IP circuit emulation flow. With CESoPSN bundles, you can group multiple DS0s on one IP circuit, and you can have more than one circuit emulation IP flow created from a single physical interface. For example, some DS0 channels from a T1 interface can go in an IP flow to destination A, and other DS0 channels from that same T1 interface can go to destination B.

NOTE: The **Physical Interface Encapsulation** is not editable in service order.

2. Fill in the SAToP and CESoPSN fields as indicated in the table.

SAToP Field	Value Range	Default Value
Jitter buffer	M Series: 1 through 340	5
		There is no default value for the jitter buffer on BX7000 Gateway devices. You must specify a value.
Idle pattern	0 through 255	255
Excessive packet loss rate	1 through 100%	20%
Payload size	M Series: 64 through 1024	192
NOTE: If the Physical Interface Encapsulation type is CESoPSN, the Payload size is unavailable.		NOTE: For M Series, the value you specify must be a multiple of 32.

3. Click **Next** to go to the **Connectivity Settings** window.

Specifying Connectivity Information for an ATM or a TDM Service

In this step, you specify the attributes that define the connectivity between remote sites across the service provider network. A sample window follows.

1. Provide the following information to create connectivity between sites across the network:

Field	Action
VC ID selection	<p>This box is available only if the Signaling is LDP.</p> <p>Specify how you want the VC ID chosen during service order creation:</p> <ul style="list-style-type: none"> • To allow the service provisioner to type the VC ID, choose Select manually. • To cause the Junos Space software to assign a VC ID automatically from the VC ID pool, select Auto pick. <p>To allow the service provisioner to override the setting in the VC ID box, select Editable in Service Order.</p>
Enable Multihoming	<p>This check box is available only if the signaling type is BGP.</p>
Default MTU (Bytes)	<p>Specify the MTU across the service provider network.</p> <p>To allow the service provisioner to override the MTU setting, select Editable in Service Order.</p>
MTU range (Bytes)	<p>Specify the highest and lowest MTU that the service provisioner can type.</p> <p>Range: 1522 bytes through 9192 bytes</p>
Revert time (sec)	<p>This box is available only if the Signaling is LDP.</p> <p>Revert time for redundant Layer 2 circuits and VPLS pseudowires.</p> <p>Default: 5 seconds</p> <p>Range: 0 through 65,535 seconds</p>
Switch Over Delay (sec)	<p>This box is available only if the Signaling type is LDP.</p> <p>Specify the delay to wait before the backup pseudowire takes over.</p> <p>Default: 0 second</p> <p>Range: 0 through 180 seconds</p>
Route Distinguisher	<p>This box is available only if the Signaling type is BGP.</p> <p>Specify an identifier attached to a route, enabling you to distinguish to which VPN the route belongs. Each routing instance must have a unique route distinguisher associated with it.</p> <p>Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295</p>

Field	Action
Route Target	<p>This box is available only if the Signaling is BGP.</p> <p>Allows you to distribute VPN routes to only the routers that need them.</p> <p>Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295</p>
Outgoing label selection	<p>This field is available only if you have selected the Static pseudowire check box in the General settings. By default, the outgoing label selection is limited to manual.</p>

2. Click **Review** to examine the settings configured for the E-Line ATM/TDM service definition.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine and modify the configured service definition settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

When the service definition is successfully created, you are returned to the Manage Service Definitions window.

RELATED DOCUMENTATION

[Choosing a Predefined Service Definition or Creating a New Service Definition | 645](#)

Creating an E-Line Service Definition

[Publishing a Custom Service Definition | 690](#)

[Unpublishing a Custom Service Definition | 691](#)

[Deleting a Customized Service Definition | 691](#)

[Viewing Service Definitions | 692](#)

Monitoring Performance Management Statistics

IN THIS SECTION

- [Monitoring Statistics for an E-Line Service | 683](#)
- [Monitoring Statistics for an E-LAN Service | 685](#)

The following topics show how to monitor the performance statistics for E-Line and E-LAN services:

You can employ the ITU-T Y.1731 standard-compliant Ethernet loss measurement (ETH-LM), Ethernet synthetic loss measurement (ETH-SLM), and Ethernet delay measurement (ETH-DM) capabilities to analyze and examine the operating efficiency and performance status. These performance monitoring functionalities can be run for E-Line and E-LAN services. You can start and stop the collection of performance monitoring (PM) statistics on the services that you want to monitor. The retrieval and computation of statistical details is performed using SNMP MIBs.

A predefined event script, Y1731_PM.slax, is available on the Scripts page of the Junos Space Platform GUI, which displays all the scripts imported into the Junos Space Platform database (accessible by selecting **Network management platform > Images and scripts > Scripts**). This script needs to be downloaded on devices. Whenever you trigger the PM mechanism from the Connectivity Services Director GUI, an event is initiated, which in turn causes the SLAX script to be run. The event continues to run the script until the event is stopped. The event runs the script at intervals of 5 minutes. The monitoring framework is used to consolidate and display the retrieved counters and values.

NOTE: Although you can start or stop the collection of PM statistics without a predefined event script made available on the corresponding devices by selecting **OAM > Y1731 > Start** or **Stop** from the Tasks pane in Monitor mode of Service view (no error is displayed and the start or stop of Y1731 PM statistics collection is successful), you must ensure that the event script is present on the devices before you trigger the mechanism for collection of Y1731 PM statistics. Otherwise, although the operation does not display an error in the GUI, no backend processing occurs.

Monitoring Statistics for an E-Line Service

You can start a performance monitoring operation on a service to diagnose the working efficiency and operating quality from the Monitor mode in Service View of Connectivity Services Director.

To monitor the statistics for the E-Line service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders. Select the E-Line service order for which you want to monitor performance statistics.

Alternatively, click the plus sign (+) beside E-LAN Services to view the E-LAN service orders. Select the E-LAN service order for which you want to monitor performance statistics.

5. From the tasks pane, select **OAM > Y1731 > Start**. The **Monitor Performance Statistics** window is displayed.

NOTE: If a CFM profile is not associated with the service, an informational message is displayed stating that an OAM or CFM profile must be mapped with the service.

NOTE: The **Start** action is enabled only if the CFM is enabled in the selected E-Line service. Always perform a functional audit before monitoring the statistics. The **Start** action is disabled if the functional audit status of a service is Down.

NOTE: You can **Start** and **Stop** the PM Statistics collection functionality on multiple pairs of devices at a time. But, you cannot **Start** the PM Statistics collection functionality on pairs in the reverse order simultaneously.

For example, if Device A and Device B are the Source Devices and Device C and Device D are the Destination Devices, you can start the PM statistics functionality between the following multiple pairs of devices:

- Device A and Device C
- Device A and Device D
- Device B and Device C
- Device B and Device D

But you cannot start PM Statistics functionality between the following multiple pairs of devices simultaneously.

- Device C and Device A
- Device D and Device A
- Device C and Device B
- Device D and Device B

6. Fill in the fields as indicated in the table.

Field	Action
Source Device	Select a local device from the list.
Destination Device	Select a remote device from the list.
Request Count	Specify the number of frames to be sent to a specific peer MEP. Range: 1 through 65,535 frames Default: 10 frames
Delay (seconds)	Specify the wait interval for the frame transfer. Range: 1 through 255 seconds Default: 1 second

Field	Action
Frame Priority (802.1p)	<p>Select the dot1p (IEEE 802.1p or packet classification layer 2 headers) priority of continuity-check and link-trace packet.</p> <p>Range: 0 through 7</p> <p>Default: 0</p>
Monitor Statistics	<p>Select one of the following check boxes:</p> <ul style="list-style-type: none"> • Two-Way delay • One-Way delay • Loss

7. Click **OK**.

NOTE: When you stop PM statistical collection, a popup dialog box is displayed, prompting you to confirm whether you want to stop PM statistical collection. Click **OK** to confirm the action. Click **Cancel** to discard the changes.

To terminate the performance monitoring task, select **OAM > Y1731 > Stop** from the tasks pane for the selected service.

If you are upgrading from the older version of Services Activation Director to Connectivity Services Director 1.0, you must stop any performance monitoring and restart the collection of Y1731 PM statistics on the endpoints. A seamless migration of Y1731 PM statistics from Services Activation Director is not supported because the mechanism used to retrieve and store the PM statistical details is different between Services Activation Director and Connectivity Services Director. While utility MIBs (OpenNMS for SNMP trap collection and correlation) and remote procedure calls (RPC) are used in Services Activation Director, only utility MIBs are used in Connectivity Services Director to collect the data. Also, event scripts are different between the two applications, which causes the object ID to be changed.

Monitoring Statistics for an E-LAN Service

You can start a performance monitoring operation on a service to diagnose the working efficiency and operating quality from the Monitor mode in Service View of Connectivity Services Director.

To monitor the statistics for the E-LAN Service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders. Select the E-Line service order for which you want to monitor performance statistics.

Alternatively, click the plus sign (+) beside E-LAN Services to view the E-LAN service orders. Select the E-LAN service order for which you want to monitor performance statistics.

5. From the tasks pane, select **OAM > Y1731 > Start**. The **Monitor Performance Statistics** window is displayed.

NOTE: The **OAM > Y1731 > Start** action is enabled only if the CFM is enabled in the selected E-LAN service. Always perform a functional audit before monitoring the statistics. The **OAM > Y1731 > Start** action is disabled if the functional audit status of a service is Down.

NOTE: You can **Start** and **Stop** the PM Statistics collection functionality on multiple pairs of devices at a time. But, you cannot **Start** the PM Statistics collection functionality on pairs in the reverse order simultaneously.

For example, if Device A and Device B are the Source Devices and Device C and Device D are the Destination Devices, you can start the PM statistics functionality between the following multiple pairs of devices:

- Device A and Device C
- Device A and Device D
- Device B and Device C
- Device B and Device D

But you cannot start PM Statistics functionality between the following multiple pairs of devices simultaneously.

- Device C and Device A
- Device D and Device A
- Device C and Device B
- Device D and Device B

6. Fill in the fields as indicated in the table.

Field	Action
Source Device	Select a local device from the list.
Destination Device	Select a remote device from the list.
Request Count	Specify the number of frames to be sent to a specific peer MEP. Range: 1 through 65,535 frames Default: 10 frames
Delay (seconds)	Specify the wait interval for the frame transfer. Range: 1 through 255 seconds Default: 1 second

Field	Action
Frame Priority (802.1p)	Select the 802.1p priority of continuity-check and link-trace packet. Range: 0 through 7 Default: 0
Monitor Statistics	Select Two-Way delay.

7. Click **OK**.

To terminate the performance monitoring task, select **OAM > Y1731 > Stop** from the tasks pane for the selected service.

If you are upgrading from the older version of Services Activation Director to Connectivity Services Director 1.0, you must stop any performance monitoring and restart the collection of Y1731 PM statistics on the endpoints. A seamless migration of Y1731 PM statistics from Services Activation Director is not supported because the mechanism used to retrieve and store the PM statistical details is different between Services Activation Director and Connectivity Services Director. While utility MIBs (OpenNMS for SNMP trap collection and correlation) and remote procedure calls (RPC) are used in Services Activation Director, only utility MIBs are used in Connectivity Services Director to collect the data. Also, event scripts are different between the two applications, which causes the object ID to be changed.

RELATED DOCUMENTATION

[Performance Management Overview | 1192](#)

[Viewing Performance Management Statistics | 1198](#)

[Service Troubleshooting Overview | 1204](#)

[Performing a Configuration Audit | 1156](#)

Modifying a Custom Service Definition

You can modify a customized service definition only when it is in the unpublished state. Predefined service definitions are by default in the published state and cannot be modified.

NOTE: Templates associated with the service definition can be added or deleted while modifying a service definition. You can delete a template associated with a service definition when there is no service or service order associated with the service definition.

To modify a service definition:

1. In the Connectivity Services Director application, select **Service View** from the Views selector.
2. Click the **Build** tab on the Task Categories banner.
3. From the Service View pane, select **Network Services > Connectivity**.
4. From the Tasks pane, select **Service Design > Manage Service Definitions**.
5. In the Manage Service Definitions page, select the customized service definition you want to modify.
6. Click the **Edit** button.

The Edit Service Definition wizard for the selected service type is displayed

7. Modify the settings, as necessary, using the wizard, and save your changes by clicking **Done**.

The **Manage Service Definitions** page reappears. The selected service definition is now modified with the redefined settings.

RELATED DOCUMENTATION

[Choosing a Predefined Service Definition or Creating a New Service Definition | 645](#)

[Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)

[Creating an E-Line Service Definition](#)

[Unpublishing a Custom Service Definition | 691](#)

[Deleting a Customized Service Definition | 691](#)

[Viewing Service Definitions | 692](#)

Publishing a Custom Service Definition

You can use service definition in a service order only when it is in the published state. A customized service definition, by default, is in the unpublished state when created. You must publish the customized service definition before it can be used to create a service request.

NOTE: By default, predefined service definitions are in the published state.

To publish a service definition:

1. In the Connectivity Services Director application, select **Service View** from the Views selector.
2. Click the **Build** tab on the Task Categories banner.
3. From the Service View pane, select **Network Services > Connectivity**.
4. From the Tasks pane, select **Service Design > Manage Service Definitions**.
5. In the Manage Service Definitions page, select the unpublished customized service definition you want to publish.
6. Click **Publish**.

The Information window is displayed.

7. Click **Yes** in the Information window to publish the service definition.

The **Manage Service Definitions** page reappears. The selected customized service definition is now in the published state.

RELATED DOCUMENTATION

[Choosing a Predefined Service Definition or Creating a New Service Definition | 645](#)

[Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)

[Creating an E-Line Service Definition](#)

[Unpublishing a Custom Service Definition | 691](#)

[Deleting a Customized Service Definition | 691](#)

[Viewing Service Definitions | 692](#)

Unpublishing a Custom Service Definition

You can unpublish a customized service definition to make it unavailable. A service definition can be unpublished even if there are service orders (pending or active) associated with it. However, an unpublished service definition cannot be deleted or modified if it has services associated with it.

You can use the **Unpublish** feature when you want to delete or add templates to a service definition.

To unpublish a service definition:

1. In the Connectivity Services Director application, select **Service View** from the Views selector.
2. Click the **Build** tab on the Task Categories banner.
3. From the Service View pane, select **Network Services > Connectivity**.
4. From the Tasks pane, select **Service Design > Manage Service Definitions**.
5. In the Manage Service Definitions page, select the customized service definition you want to unpublish.
6. Click **Unpublish**.

The Information window is displayed.

7. Click **Yes** in the Information window to unpublish the service definition.

The Manage Service Definition page reappears. The selected customized service definition is now in the unpublished state.

RELATED DOCUMENTATION

| [Publishing a Custom Service Definition](#) | 690

Deleting a Customized Service Definition

You can delete a customized service definition only when it is in the unpublished state. You cannot delete an unpublished service definition if it has services or service orders associated with it.

NOTE: You cannot delete a predefined service definition.

To delete a customized service definition:

1. In the Connectivity Services Director application, select **Service View** from the Views selector.
2. Click the **Build** tab on the Task Categories banner.
3. From the Service View pane, select **Network Services > Connectivity**.
4. From the Tasks pane, select **Service Design > Manage Service Definitions**.
5. In the Manage Service Definitions page, select the customized service definition you want to delete.

NOTE: You must unpublish the service definition before you can delete it. To unpublish a service definition, see [“Unpublishing a Custom Service Definition” on page 691](#).

6. Click **Delete**.

The Information window is displayed.

7. Click **Yes** in the Information window to confirm deletion.

The Manage Service Definition page refreshes with the selected service definition removed.

RELATED DOCUMENTATION

[Unpublishing a Custom Service Definition](#) | 691

Viewing Service Definitions

The Manage Service Definitions inventory page allows you, the Service Designer, to view the status of service definitions and list of service definitions that you have created to include in service orders.

Service definitions are listed by name.

Select **Service Design > Manage Service Definitions** to view and perform actions on service definitions. From the Manage Service Definitions inventory page, you can publish, unpublish, and delete service definitions.

- [Tabular View | 693](#)
- [Searching for Service Definitions | 694](#)
- [Viewing Service Definition Details | 694](#)
- [Performing Actions on Service Definitions | 694](#)

Tabular View

In tabular view, service definition information appears in table rows and columns.

[Table 78 on page 693](#) describes the information presented in the table.

Table 78: Service Definition Table Fields

Column	Meaning
Name	The unique name assigned to the service definition.
State	One of the following values: <ul style="list-style-type: none"> ● Published—The service definition is available for use by service provisioners. ● Unpublished—The service definition is not yet available for use by service provisioners.
Service Type	One of the following: <ul style="list-style-type: none"> ● E-Line pseudowire (LDP) ● E-Line pseudowire (BGP) ● E-LAN (MultiPoint-to-MultiPoint) ● E-LAN (Point-to-MultiPoint) ● IP (Full Mesh) ● IP (Hub-Spoke 1 Interface)
Signaling	One of the following values: <ul style="list-style-type: none"> ● BGP ● LDP
Pseudowire	Type of pseudowire configured for the service.
Description	A brief comment or easily-identifiable description specified for the service definition.

Table 78: Service Definition Table Fields (*continued*)

Column	Meaning
Use Count	Number of service orders with which this service definition has been associated.
Created By	The screen name of the user who created the service definition.
Created Date	The date and Pacific Daylight Time (PDT) time when you created the service definition.
Service Templates	Names of the service templates with which the service definition is associated. The Default Service Template column indicates whether the attached template is the default template.

Searching for Service Definitions

To search for a specific service definition, start typing its name in the Search field. The service definition name(s) starting with the letters you type are listed in the Search drop-down list box.

If you create tags to categorize service definitions, start typing the tag name in the Search field. Service definitions with the tag you type appears.

Viewing Service Definition Details

To view service definition detailed information, double-click the service definition row.

The Service Definition Details page displays a summary of the service definition settings: General, Connectivity, and UNI settings.

Performing Actions on Service Definitions

From the Manage Service Definitions inventory page you can perform the following actions:

- **Publish Service Definition**—See [“Publishing a Custom Service Definition” on page 690](#).
- **Unpublish Service Definition**—See [“Unpublishing a Custom Service Definition” on page 691](#).

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)

[Creating an E-Line Service Definition](#)

[Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696](#)

Creating a Point-to-Multipoint E-LAN Service Definition | 726

Creating a Full-Mesh IP Service Definition | 765

Creating a Hub-and-Spoke (One Interface) IP Service Definition | 776

Service Design: Managing E-LAN Service Definitions

IN THIS CHAPTER

- [Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696](#)
- [Creating a Point-to-Multipoint E-LAN Service Definition | 726](#)
- [Creating a Service Definition for VPLS Access into Layer 3 Networks | 760](#)

Creating a Multipoint-to-Multipoint E-LAN Service Definition

IN THIS SECTION

- [Specifying General Information for Multipoint-to-Multipoint E-LAN Service Definitions | 697](#)
- [Specifying Advanced Settings | 701](#)
- [Specifying Site Settings for Multipoint-to-Multipoint E-LAN Service Definitions | 705](#)
- [UNI or Site Settings for Port-to-Port Interfaces in E-LAN Services | 705](#)
- [UNI or Site Settings for 802.1Q Interfaces in E-LAN Services | 708](#)
- [UNI or Site Settings for Q-in-Q Interfaces in E-LAN Services | 713](#)
- [UNI Settings for Services with Flexible VLAN Tagging \(Asymmetric Interface Types\) | 719](#)
- [Reviewing the Configured Settings | 725](#)

This procedure provides the steps to create a definition for a multipoint-to-multipoint E-LAN service.

The standard service definitions that came with your initial software installation are designed to be appropriate for most requirements. You can also create a customized service definition—for example, to set different bandwidth limits on the service than those offered in the standard service definitions.

When the new service definition is complete and published, network operators or service provisioners can use the completed service definition as a base for creating and then activating multipoint-to-multipoint Ethernet services on the network.

The windows appear in the order stated. You can, however, perform these steps in any order by accessing them through the task list in the right panel. If the panel is not visible, click the snap tool on the right side of the main display area.

To create a multipoint-to-multipoint Ethernet service definition, complete these tasks, in the order shown. As you finish a section and click **Next**, the attributes from the current window are saved and the next window in the sequence appears.

Specifying General Information for Multipoint-to-Multipoint E-LAN Service Definitions

To specify the general information for a multipoint-to-multipoint service definition, in the Network Services > Connectivity view pane, select **Service Design > Manage Service Definitions > New > E-LAN Service Definition**.

The **General** window appears.

To specify the general information for a multipoint-to-multipoint service definition:

1. Fill in the fields on the **General** window.

Field	Action
Service Definition Name	Type a name for the service definition.
Service Type	Select (E-LAN) Multipoint-to-Multipoint
Instance Type	<p>Select an instance type to choose the type of routing instance for the MultiPoint-to-MultiPoint E-LAN service:</p> <ul style="list-style-type: none"> • vpls • evpn • virtual-switch <p>NOTE: Virtual-switch supports only dot1q as the encapsulation type.</p> <p>Normalization not required is the only available vlan normalization type.</p>
Protocol	<p>Select the protocol type:</p> <ul style="list-style-type: none"> • vpls • evpn • evpn e-tree <p>NOTE: Different protocols are available based on the instance type you select.</p>

Field	Action
Signaling Protocol	<p>Select a signaling type:</p> <ul style="list-style-type: none"> • BGP— If BGP signaling is selected, the following fields are available in the Connectivity section of the General Settings page: <ul style="list-style-type: none"> • Auto-pick Route Target • Auto-pick Route Distinguisher • LDP—If LDP signaling is selected, the following fields are available in the Connectivity section of the General Settings page: <ul style="list-style-type: none"> • Enable BGP-based Auto Discovery • Auto-pick Route Target, if Auto Discovery is enabled • Auto-pick Route Distinguisher , if Auto Discovery is enabled • Auto-pick VPLS ID, if Auto Discovery is disabled • Auto-pick VPN ID, if Auto Discovery is enabled <p>NOTE: You cannot edit the Signaling type in the service order.</p>
Description (Optional)	<p>Type a brief description or other comment that you want to appear in the Service Definition table.</p> <p>Range: 0 through 200 characters. Space and special characters are allowed.</p>
Enable QoS	<p>When you enable QoS in the service definition, you can specify a QoS profile in the service order to classify traffic into defined service groups to provide the special treatment of traffic across the network service. For example, voice traffic can be sent across certain links, and data traffic can use other links.</p>
Enable L3 Access	<p>Select this check box to create the link into Layer 3. If this check box is selected, the available Ethernet option in the Site Settings window are:</p> <ul style="list-style-type: none"> • dot1q • qinq
Enable Static PW Labels	<p>Select this check box to enable a pseudowire connection by configuring static values.</p> <p>NOTE: The Enable Static PW Labels check box is enabled only when the signaling type is LDP.</p>

Field	Action
Service Template	<p>(Optional) To include a service template for the service, click the Add icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click OK. You are returned to the General Settings page.</p> <p>The selected service template appears in the Default Service Template field.</p> <p>You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.</p> <p>NOTE: You cannot add or delete a service template while creating a service order.</p> <p>The remaining service templates on the Service Template list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.</p> <p>In the View Service Definition Details window, the value for the default service template in the Default Service Template column is <i>True</i>.</p> <p>For instructions on creating a service template, see <i>Creating a Service Template</i>.</p>

BGP Connectivity Settings—This section is displayed if you select the signaling type as BGP.

Auto-pick Route Target	<p>Select this check box to enable route target to be configured automatically. Clear the check box if you want the route target to be manually configured. By default, manual configuration of route target is enabled.</p> <p>To override this setting in the service order, select the Editable in Service Order check box.</p>
Auto-pick Route Distinguisher	<p>Define a route distinguisher option:</p> <ul style="list-style-type: none"> • Select the check box to enable the service provider to specify the route distinguisher. • Select the check box to enable the route distinguisher to be selected automatically. <p>To override this setting in the service order, select the Editable in Service Order check box.</p>
Enable Multihoming	<p>(Optional) Select this check box to pair any two N-PE devices, for providing redundant connectivity.</p> <p>When you select this check box, a Multihoming Mode list appears, if you select evpn or evpn e-tree as the protocol type. You can select either single-active or all-active as the multihoming mode.</p>

LDP Connectivity Settings—This section is displayed if you select the signaling type as LDP.

Field	Action
Enable BGP-based Auto Discovery	<p>The Auto Discovery check box is available only if the signaling type is LDP.</p> <p>NOTE: If the Enable Static PW Labels check box in the General window is selected for LDP signaling, then the Auto Discovery check box is disabled.</p> <p>The Auto Discovery check box is not available when the signaling type is BGP.</p> <p>On disabling the auto discovery specify the VPLS ID.</p>
Auto-pick VPLS ID or VPN ID	<p>This field is available only if the signaling type is LDP and auto discovery is disabled.</p> <p>Identifies the virtual circuit identifier used for the VPLS routing instance and the VPN ID associated with the router.</p> <p>Select this check box to enable the VPLS ID and VPN ID to be configured automatically. Clear the check box if you want these attributes to be manually configured. By default, manual configuration is enabled.</p>
Auto-pick Route Target	<p>Select this check box to enable route target to be configured automatically. Clear the check box if you want the route target to be manually configured. By default, manual configuration of route target is enabled.</p>
Auto-pick Route Distinguisher	<p>Define a route distinguisher option:</p> <ul style="list-style-type: none"> • Select the check box to enable the service provider to specify the route distinguisher. • Select the check box to enable the route distinguisher to be selected automatically. <p>To override this setting in the service order, select the Editable in Service Order check box.</p>
MAC Settings	
MAC learning	To enable MAC learning , select the check box.
Interface MAC limit	<p>Maximum number of MAC addresses learned from an interface.</p> <p>Range: 1 through 131071 MAC addresses per interface</p>
MAC statistics	To enable MAC statistic , select the check box.
MAC Table Size	<p>Modify the size of the MAC address table for the bridge domain.</p> <p>Range: 16 through 1048575</p> <p>To allow the service provisioner to override the MAC settings, select Editable in Service Order.</p>

2. Click **Next** to save the information and continue with UNI or site settings.

Specifying Advanced Settings

In this step, you can specify the parameters that define advanced connectivity between sites across the service provider network. These settings can be configured in the **Advanced** settings section of the General Settings page of the Create E-LAN Service Definition wizard.

To specify advanced settings:

1. Fill in the fields as indicated in the table.

Advanced Settings—This section enables you to specify the parameters that define advanced connectivity between sites across the service provider network

Include	<p>Select the Include check box for each advanced setting that you want to include in the service definition.</p> <p>NOTE: If you select any advanced parameters for a service definition, you must also select the Include check box for the Disable tunnel services parameter, and select or clear the Disable tunnel services check box.</p> <p>For MX Series devices, if you deploy an E-LAN service without selecting the Include check box for Disable tunnel services parameter, the E-LAN service is down. As a work around, you can push the configuration to each PE device for the service by running the following command:</p> <pre>root@test_device# set chassis fpc 0 pic 1 tunnel-services bandwidth 1g</pre>
Disable Tunnel Services	<p>Enable or disable tunnel-services to specify that traffic for particular VPLS routing instances be forwarded to specific virtual tunnel (VT) interfaces.</p> <ul style="list-style-type: none"> • To enable tunnel-services, clear the Disable Tunnel Services check box. • To disable tunnel-services, select the Disable Tunnel Services check box (default).
Disable Local Switching	<p>Enable or disable local switching. In local switching mode, you can terminate multiple Layer 2 circuit pseudowires at a single VPLS mesh group:</p> <ul style="list-style-type: none"> • To enable local switching across the network, clear the Disable Local Switching check box. • To disable local switching across the network, select the Disable Local Switching check box (default).
Fast Reroute-Priority	<p>In this drop-down list, specify the reroute priority for a VPLS routing instance:</p> <ul style="list-style-type: none"> • HIGH—Set the fast reroute priority for a VPLS routing instance to high. During a fast reroute event, the router repairs next hops for high-priority VPLS routing instances first. • MEDIUM—Set the fast reroute priority for a VPLS routing instance to medium. During a fast reroute event, the router repairs next hops for medium-priority VPLS instances after high-priority VPLS routing instances but before low-priority VPLS routing instances. • LOW—Set the fast reroute priority for a VPLS routing instance to low, which is the default. During a fast reroute event, the router repairs next hops for low-priority VPLS routing instances last.

Label Block Size	<p>Configure the label block size for VPLS labels by using one of the following values.</p> <ul style="list-style-type: none"> • 2—Allocate the label blocks in increments of 2. Use this setting for a VPLS domain that has only two sites with no future expansion plans. • 4—Allocate the label blocks in increments of 4. • 8 —Allocate the label blocks in increments of 8. This is the default. • 16—Allocate the label blocks in increments of 16. A label block size of 16 enables you to minimize the number of routes in the VPLS domain. Use this setting only if the number of routes is the primary concern. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery check box is enabled.</p>
Connectivity type	<p>Select a connection-type to specify when a VPLS connection is taken down, depending on whether the interface for the VPLS routing instance is customer-facing or integrated routing and bridging (IRB):</p> <ul style="list-style-type: none"> • ce—Require that for the VPLS connection to be up, the customer-facing interface for the VPLS routing instance must also be up. If the customer-facing interface fails, the VPLS connection is taken down. This is the default. • irb—Allow a VPLS connection to remain up so long as an IRB interface is configured for the VPLS routing instance. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery is enabled.</p>
Editable in Service Order	<p>By default, each advanced setting that you include in the service definition can be edited in the service order. To prevent the service provisioner from overriding an advanced setting in the service order, clear the Editable in Service Order check box.</p>

2. Click **Next** to define the UNI or site parameters. Alternatively, click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.
3. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.
4. After you complete reviewing the settings, click **Finish** to complete the service definition creation.

Specifying Site Settings for Multipoint-to-Multipoint E-LAN Service Definitions

In this step, you provide the UNI attributes for this service definition. The attributes you set depend on the type of interface you are using in this E-LAN service definition. The following interface types are supported:

- ports
- 802.1Q interfaces
- Q-in-Q interfaces
- asymmetric interface

UNI or Site Settings for Port-to-Port Interfaces in E-LAN Services

The **Site Settings** window provides four expanding or collapsing panels: Traffic Treatment, Interface Settings, MTU Settings, and Bandwidth Settings.

To specify the UNI Settings for Port-to-Port interfaces:

1. Fill in the fields on the **Site Settings** window.

Field	Action
PE-CE Interface Settings- Ethernet Encapsulation	
VLAN Tagging	<p>Select port-port from the list.</p> <p>The VLAN tagging option you choose determines the other options you can select and specify on the page.</p>
Editable in Service Order	To allow the service provisioner to override the VLAN tagging or Ethernet option attribute, select the check box.
Physical Interface Encapsulation	Select ethernet-vpls , the only valid physical interface encapsulation method allowed for port-to-port services.
Logical Interface Encapsulation	You cannot select a choice in this field because it is not relevant to port-to-port services.
Traffic Type	This drop-down is disabled for port-to-port services. For port-to-port services, all traffic is always transported.

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to VLAN all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalize to VLAN none—To preserve no VLAN IDs across the network. • Normalized to Dot1q tag—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalized to QinQ tags—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>
Auto Pick VLAN ID	This check box is disabled because in port-to-port services, all traffic and all VLANs on one port are transported to all other ports.
Editable in Service Order	To allow the service provisioner to override the VLAN ID setting, select the check box. This check box is not applicable for port-to-port services.
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes.
MTU Range for manual-config(Bytes)	<p>Specify the low and high values to define the MTU range that you want to define.</p> <p>The default range is 1522 through 9192 bytes.</p>
PE-CE Interface Rate-Limiting Settings	

Field	Action
Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when CoS profiles are associated.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Bandwidth – Burst Size Settings	

Field	Action
Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>

The following table lists the **Max Bandwidth (Mbps)** for the M Series, MX Series, and ACX Series Routers:

Table 79: Maximum Bandwidth for M Series, MX Series, and ACX Series Routers

M Series IQ2E PIC		M Series IQ2 PIC		MX Series 3D PIC		MX Series Non-3D PIC		ACX 2000	
GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)
32,000 Mbps or 32 Gbps	32,000 Mbps or 32 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	100,000 Mbps or 100 Gbps	100,000 Mbps or 100 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

UNI or Site Settings for 802.1Q Interfaces in E-LAN Services

To specify the UNI Settings for 802.1Q interfaces:

1. Fill in the fields on the **Site Settings** window.

Field	Action
PE-CE UNI Settings- Ethernet Encapsulation	
VLAN Tagging	<p>Select dot1q from the list.</p> <p>The Ethernet option you choose determines the other options you can select and specify on the page.</p>
Physical Interface Encapsulation	Select the default physical encapsulation scheme to be used by service orders based on this service definition. We recommend you select flexible-ethernet-services .
Logical Interface Encapsulation	Constrained by your selection in the Physical interface encapsulation box. If you selected the recommended physical encapsulation mode of flexible-ethernet-services, then your only option is to select vlan-vpls for the logical encapsulation method.
Traffic Type	<p>Select Transport single vlan to transport the traffic for a specific VLAN across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify the Outer Tag protocol ID.</p> <p>Select Transport vlan range to limit the traffic across the network to a specific range of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID range when creating a service order based on this service definition.</p> <p>Select Transport vlan list to limit the traffic across the network to a specific list of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to VLAN all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalized VLAN none—To preserve no VLAN IDs across the network. • Normalized to Dot1q—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalized to QinQ—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>

Field	Action
Auto Pick VLAN ID	<p>Indicate how the VLAN ID is determined. By default, this check box is disabled.</p> <ul style="list-style-type: none"> • Clear this check box to allow the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> • Select this check box when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag Protocol ID	<p>Select the outer tag protocol ID if the Customer traffic type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPID) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p>
Editable in Service Order	To allow the service provisioner to override the outer tag protocol ID setting, select the check box for those options.
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes. To allow the service provisioner to override the MTU setting, select the Editable in Service Order check box.
MTU range for manual-config	<p>In the MTU range fields, type the lowest and highest values for MTU for each UNI.</p> <p>NOTE: To allow the service provisioner to override the MTU setting, select Editable in Service Order and, in the MTU range fields, type the highest and lowest MTU values.</p>

PE-CE Interface Rate-Limiting Settings

Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Field	Action
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Bandwidth – Burst Size Settings

Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>
------------------------------	---

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

UNI or Site Settings for Q-in-Q Interfaces in E-LAN Services

To specify the site or UNI settings for q-in-q interfaces:

1. Fill in the fields on the **Site Settings** window.

Field	Action
PE-CE Interface Settings- Ethernet Encapsulation	
VLAN Tagging	<p>Select qinq from the list.</p> <p>The window expands to include options specific to Q-in-Q interfaces.</p>
Physical Interface Encapsulation	Select the default physical encapsulation scheme to be used by service orders based on this service definition. We recommend you select flexible-ethernet-services .
Logical Interface Encapsulation	Constrained by your selection in the Physical Interface encapsulation box. If you selected the recommended physical encapsulation mode of flexible-ethernet-services, then your only option is to select vlan-vpls for the logical encapsulation method.
Traffic Type	<p>Transport all traffic Transports the traffic from all VLANs across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID.</p> <p>Transport single vlan Transports traffic for a specific VLAN across the network. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>Transport vlan range Limits the traffic across the network to a specific range of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID range when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID.</p> <p>Transport vlan list Limits the traffic across the network to a specific list of VLANs. If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> ● Normalize to VLAN all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> ● Normalized VLAN none—To preserve no VLAN IDs across the network. ● Normalized to Dot1q—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network ● Normalized to QinQ—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. ● Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>

Field	Action
Auto Pick VLAN ID	<p>Indicate how the VLAN ID is determined. By default, this check box is disabled.</p> <ul style="list-style-type: none"> • Clear this check box to allow the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> • Select this check box when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick:	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag Protocol ID	<p>Select the outer tag protocol ID if the Customer traffic type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPID) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag Protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You cannot specify the Inner Tag protocol ID if the Customer traffic type is Transport single VLAN.</p>
Editable in Service Order	To allow the service provisioner to override the outer and inner tag protocol IDs, select the check boxes for those options.
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes. To allow the service provisioner to override the MTU setting, select the Editable in Service Order check box.
MTU range for manual-config	<p>In the MTU range fields, type the lowest and highest values for MTU for each UNI.</p> <p>NOTE: To allow the service provisioner to override the MTU setting, select Editable in Service Order and, in the MTU range fields, type the highest and lowest MTU values.</p>

PE-CE Interface Rate-Limiting Settings

Field	Action
Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Bandwidth – Burst Size Settings	

Field	Action
Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

UNI Settings for Services with Flexible VLAN Tagging (Asymmetric Interface Types)

You can specify the Ethernet option **asymmetric tag depth** to create a service that includes any combination of port-based interfaces, 802.1Q interfaces, and Q-in-Q interfaces.

To specify the UNI Settings for q-in-q interfaces:

- Fill in the fields on the **Site Settings** window.

Field	Action
PE-CE Interface Settings- Ethernet Encapsulation	
VLAN Tagging	Select asymmetric tag depth from the list.
Physical Interface Encapsulation	<p>Select the default physical encapsulation scheme to be used by service orders based on this service definition. We recommend you select flexible-ethernet-services.</p> <p>For multipoint-to-multipoint services with Q-in-Q interfaces, the only option is flexible-ethernet-services</p>

Field	Action
Logical Interface Encapsulation	Constrained by your selection in the Physical interface encapsulation box. If you selected the recommended physical encapsulation mode of flexible-ethernet-services, then your only option is to select vlan-vpls for the logical encapsulation method.
Traffic Type	<p>Transport all traffic Transports the traffic from all VLANs across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID.</p> <p>Transport single vlan Transports traffic for a specific VLAN across the network. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>Transport vlan range Limits the traffic across the network to a specific range of VLANs. You need to specify only the Outer Tag protocol ID.</p> <p>Transport vlan list limits the traffic across the network to a specific list of VLANs. If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID range when creating a service order based on this service definition.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to VLAN all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalize to VLAN none—To preserve no VLAN IDs across the network. • Normalize to Dot1q tag—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalize to QinQ tags—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>

Field	Action
Auto Pick VLAN ID	<p>Indicate how the VLAN ID is determined. By default, this check box is disabled.</p> <ul style="list-style-type: none"> • Clear this check box to allow the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> • Select this check box when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick:	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag Protocol ID	<p>Select the outer tag protocol ID if the Customer traffic type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPID) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag Protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You cannot specify the Inner Tag protocol ID if the Customer traffic type is Transport all traffic.</p>
Editable in Service Order	To allow the service provisioner to override the outer and inner tag protocol IDs, select the check boxes for those options.
MTU range for manual-config	<p>In the MTU range fields, type the lowest and highest values for MTU that the service provisioner can type, for each UNI</p> <p>NOTE: To allow the service provisioner to override the MTU setting, select Editable in Service Order and, in the MTU range fields, type the highest and lowest MTU values that the service provisioner can type.</p>
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes. To allow the service provisioner to override the MTU setting, select the Editable in Service Order check box.
PE-CE Interface Rate-Limiting Settings	

Field	Action
Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Bandwidth – Burst Size Settings

Field	Action
Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine and modify the configured service definition settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

RELATED DOCUMENTATION

[Creating a Service Definition for VPLS Access into Layer 3 Networks](#) | 760

Creating a Point-to-Multipoint E-LAN Service Definition

IN THIS SECTION

- [Specifying General Information for Point-to-Multipoint E-LAN Service Definitions](#) | 727
- [Specifying Advanced Settings](#) | 734
- [Specifying UNI or Site Settings for Point-to-Multipoint E-LAN Service Definitions](#) | 737
- [UNI or Site Settings for Port-to-Port Interfaces in E-LAN Services](#) | 737
- [UNI or Site Settings for 802.1Q Interfaces in E-LAN Services](#) | 740
- [UNI or Site Settings for Q-in-Q Interfaces in E-LAN Services](#) | 747
- [UNI or Site Settings for Services with Flexible VLAN Tagging \(Asymmetric Interface Types\)](#) | 753
- [Reviewing the Configured Settings](#) | 759

This procedure provides the steps to create a definition for a point-to-multipoint Ethernet service. Point-to-multipoint services are also known as hub and spoke services.

The standard service definitions that came with your initial software installation are designed to be appropriate for most requirements. You can also create a customized service definition—for example, to set different bandwidth limits on the service than those offered in the standard service definitions.

When the new service definition is complete and published, network operators or service provisioners can use the completed service definition as a base for creating and then activating point-to-multipoint Ethernet services on the network.

The windows appear in the order stated. You can, however, perform these steps in any order by accessing them through the task list in the right panel. If the panel is not visible, click the snap tool on the right side of the main display area.

Specifying General Information for Point-to-Multipoint E-LAN Service Definitions

in the Network Services > Connectivity view pane, select **Service Design > Manage Service Definitions > New > E-LAN Service Definition**. The **General** settings window appears.

To specify the general information for a point-to-multipoint service definition:

1. Fill in the fields on the **General** page of the wizard that enables you to create a service definition.

Field	Action
Service Definition Name	Type a name for the service definition.
Service Type	Select (E-LAN) Point-to-Multipoint)

Field	Action
Signaling Protocol	<p>Select a signaling type:</p> <ul style="list-style-type: none"> • BGP— If BGP signaling is selected, the following fields are available in the Connectivity section of the General Settings page: <ul style="list-style-type: none"> • Route target • Route distinguisher • VLAN normalization • MAC Settings • VCID, if Enable PW Extension is enabled • LDP—If LDP signaling is selected, the following fields are available in the Connectivity section of the General Settings page: <ul style="list-style-type: none"> • Enable BGP-based Auto Discovery • Auto-pick Route target, if Auto Discovery is enabled • Auto-pick Route distinguisher, if Auto Discovery is enabled • Auto-pick VPLS ID, if Auto Discovery is disabled • Auto-pick VPN ID, if Auto Discovery is enabled • VLAN normalization • Mac Security Settings <p>NOTE: You cannot edit the Signaling type in the service order.</p>
Description (Optional)	<p>Type a brief description or other comment that you want to appear in the Service Definition table.</p> <p>Range: 0 through 200 characters. Space and special characters are allowed.</p>
Instance Type	<p>Select an instance type to choose the type of routing instance for the Point-to-MultiPoint E-LAN service:</p> <ul style="list-style-type: none"> • vpls • evpn • virtual-switch
Protocol	<p>Different protocols are available based on the instance type you select:</p> <ul style="list-style-type: none"> • vpls • evpn • evpn e-tree

Field	Action
Enable QoS	When you enable QoS in the service definition, you can specify a QoS profile in the service order to classify traffic into defined service groups to provide the special treatment of traffic across the network service. For example, voice traffic can be sent across certain links, and data traffic can use other links.
Enable L3 Access	<p>Select this check box to create the link into Layer 3. If this check box is selected, the available Ethernet option in the Site Settings window are:</p> <ul style="list-style-type: none"> • dot1q • qinq
Enable PW Extension	Select this check box to enable pseudowire extension. You cannot edit this check box in the service order.
Enable PW Resiliency	<p>Select this check box to enable resiliency. You cannot edit this field in the service order.</p> <p>If the Signaling type is BGP, you need to select the Enable PW Extension check box to enable the Enable PW Resiliency check box.</p> <p>For more information of pseudowire redundancy, see “Redundant Pseudowires for Layer 2 Circuits and VPLS” on page 98.</p>
Enable Static PW Labels	<p>Select this check box to enable a pseudowire connection by configuring static values.</p> <p>NOTE: The Enable Static PW Labels check box is enabled for both signaling types: LDP and BGP.</p> <p>When the signaling type is BGP, selection of this check box enables the Enable PW Resiliency check box and automatically selects the Enable PW Extension check box.</p>

Field	Action
Service Template	<p>(Optional) To include a service template for the service, click the Add icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click OK. You are returned to the General Settings page.</p> <p>The selected service template appears in the Default Service Template field.</p> <p>You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.</p> <p>NOTE: You cannot add or delete a service template while creating a service order.</p> <p>The remaining service templates on the Service Template list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.</p> <p>In the View Service Definition Details window, the value for the default service template in the Default Service Template column is <i>True</i>.</p> <p>For instructions on creating a service template, see <i>Creating a Service Template</i>.</p>

BGP Connectivity Settings—This section is displayed if you select the signaling type as BGP.

Auto-pick Route Target	<p>Select this check box to enable route target to be configured automatically. Clear the check box if you want the route target to be manually configured. By default, manual configuration of route target is enabled.</p> <p>To override this setting in the service order, select the Editable in Service Order check box.</p>
Auto-pick Route Distinguisher	<p>Define a route distinguisher option:</p> <ul style="list-style-type: none"> • Select the check box to enable the service provider to specify the route distinguisher. • Select the check box to enable the route distinguisher to be selected automatically. <p>To override this setting in the service order, select the Editable in Service Order check box.</p>
Enable Multihoming	<p>Select this check box to pair any two N-PE devices, for providing redundant connectivity. When you select this check box, a Multihoming Mode list appears, if you select evpn or evpn-etree as the protocol type.</p> <p>You can select either single-active or all-active as the multihoming mode.</p>

LDP Connectivity Settings—This section is displayed if you select the signaling type as LDP.

Field	Action
Enable BGP-based Auto Discovery	<p>You cannot enable or disable the Auto Discovery check box if you have enabled the Enable PW Extension or the Enable PW Resiliency check boxes.</p> <p>This check box is available only if the signaling type is LDP.</p> <p>NOTE: If the Enable Static PW Labels check box in the General window is checked for the LDP signaling, then the Auto Discovery check box is disabled in the Connectivity Settings page.</p> <p>The Auto Discovery check box is not available in the Connectivity Settings page when the signaling type is BGP.</p> <p>On enabling the auto discovery, the following fields are available:</p> <ul style="list-style-type: none"> • Route target • Route distinguisher • VPN ID <p>On disabling the auto discovery specify the VPLS ID.</p>
Auto-pick VPLS ID or VPN ID	<p>This field is available only if the signaling type is LDP and auto discovery is disabled.</p> <p>Identifies the virtual circuit identifier used for the VPLS routing instance and the VPN ID associated with the router.</p> <p>Select this check box to enable the VPLS ID and VPN ID to be configured automatically. Clear the check box if you want these attributes to be manually configured. By default, manual configuration is enabled.</p>
Auto-pick Route Target	<p>Select this check box to enable route target to be configured automatically. Clear the check box if you want the route target to be manually configured. By default, manual configuration of route target is enabled.</p>
Auto-pick Route Distinguisher	<p>Define a route distinguisher option:</p> <ul style="list-style-type: none"> • Select the check box to enable the service provider to specify the route distinguisher. • Select the check box to enable the route distinguisher to be selected automatically. <p>To override this setting in the service order, select the Editable in Service Order check box.</p>
MAC Settings	
MAC learning	<p>To enable MAC learning, select the check box.</p>
Interface MAC limit	<p>Maximum number of MAC addresses learned from an interface.</p> <p>Range: 1 through 131071 MAC addresses per interface</p>

Field	Action
MAC statistics	To enable MAC statistic , select the check box.
MAC Table Size	<p>Modify the size of the MAC address table for the bridge domain.</p> <p>Range: 16 through 1048575</p> <p>To allow the service provisioner to override the MAC settings, select Editable in Service Order.</p>
Enable L3 Access	<p>Select this check box to create the link into Layer 3. If you enable the Layer 3 access, the available Ethernet option in the Site Settings are:</p> <ul style="list-style-type: none"> • port-port • dot1q • qinq • asymmetric tag depth
Enable PW Extension	Select this check box to enable pseudowire extension. You cannot edit this check box in the service order.
Enable PW Resiliency	<p>Select this check box to enable resiliency. You cannot edit this field in the service order.</p> <p>If the Signaling type is BGP, you need to select the Enable PW Extension check box to enable the Enable PW Resiliency check box.</p> <p>For more information of pseudowire redundancy, see "Redundant Pseudowires for Layer 2 Circuits and VPLS" on page 98.</p>
Enable Static PW Labels	<p>Select this check box to enable a pseudowire connection by configuring static values.</p> <p>NOTE: The Enable Static PW Labels check box is enabled for both signaling types: LDP and BGP.</p> <p>When the signaling type is BGP, selection of this check box enables the Enable PW Resiliency check box and automatically selects the Enable PW Extension check box.</p>

Field	Action
Service Template Definition	<p>(Optional) To include a service template for the service, click the Add icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click OK. You are returned to the General Settings page.</p> <p>The selected service template appears in the Default Service Template field.</p> <p>You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.</p> <p>NOTE: You cannot add or delete a service template while creating a service order.</p> <p>The remaining service templates on the Service Template list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.</p> <p>In the View Service Definition Details window, the value for the default service template in the Default Service Template column is <i>True</i>.</p> <p>For instructions on creating a service template, see <i>Creating a Service Template</i>.</p>

2. Click **Next** to save the information. Continue with [“Specifying Advanced Settings” on page 734](#).

Specifying Advanced Settings

In this step, you can specify the parameters that define advanced connectivity between sites across the service provider network. These settings can be configured in the **Advanced** settings section of the General Settings page of the Create E-LAN Service Definition wizard.

1. Fill in the fields as indicated in the table.

Advanced Settings—This section enables you to specify the parameters that define advanced connectivity between sites across the service provider network

Include	<p>Select the Include check box for each advanced setting that you want to include in the service definition.</p> <p>NOTE: If you select any advanced parameters for a service definition, you must also select the Include check box for the Disable tunnel services parameter, and select or clear the Disable tunnel services check box.</p> <p>For MX Series devices, if you deploy an E-LAN service without selecting the Include check box for Disable tunnel services parameter, the E-LAN service is down. As a work around, you can push the configuration to each PE device for the service by running the following command:</p> <pre>root@test_device# set chassis fpc 0 pic 1 tunnel-services bandwidth 1g</pre>
Disable Tunnel Services	<p>Enable or disable tunnel-services to specify that traffic for particular VPLS routing instances be forwarded to specific virtual tunnel (VT) interfaces.</p> <ul style="list-style-type: none"> • To enable tunnel-services, clear the Disable Tunnel Services check box. • To disable tunnel-services, select the Disable Tunnel Services check box (default).
Disable Local Switching	<p>Enable or disable local switching. In local switching mode, you can terminate multiple Layer 2 circuit pseudowires at a single VPLS mesh group:</p> <ul style="list-style-type: none"> • To enable local switching across the network, clear the Disable Local Switching check box. • To disable local switching across the network, select the Disable Local Switching check box (default).
Fast Reroute-Priority	<p>In this drop-down list, specify the reroute priority for a VPLS routing instance:</p> <ul style="list-style-type: none"> • HIGH—Set the fast reroute priority for a VPLS routing instance to high. During a fast reroute event, the router repairs next hops for high-priority VPLS routing instances first. • MEDIUM—Set the fast reroute priority for a VPLS routing instance to medium. During a fast reroute event, the router repairs next hops for medium-priority VPLS instances after high-priority VPLS routing instances but before low-priority VPLS routing instances. • LOW—Set the fast reroute priority for a VPLS routing instance to low, which is the default. During a fast reroute event, the router repairs next hops for low-priority VPLS routing instances last.

Label Block Size	<p>Configure the label block size for VPLS labels by using one of the following values.</p> <ul style="list-style-type: none"> ● 2—Allocate the label blocks in increments of 2. Use this setting for a VPLS domain that has only two sites with no future expansion plans. ● 4—Allocate the label blocks in increments of 4. ● 8 —Allocate the label blocks in increments of 8. This is the default. ● 16—Allocate the label blocks in increments of 16. A label block size of 16 enables you to minimize the number of routes in the VPLS domain. Use this setting only if the number of routes is the primary concern. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery check box is enabled.</p>
Connectivity type	<p>Select a connection-type to specify when a VPLS connection is taken down, depending on whether the interface for the VPLS routing instance is customer-facing or integrated routing and bridging (IRB):</p> <ul style="list-style-type: none"> ● ce—Require that for the VPLS connection to be up, the customer-facing interface for the VPLS routing instance must also be up. If the customer-facing interface fails, the VPLS connection is taken down. This is the default. ● irb—Allow a VPLS connection to remain up so long as an IRB interface is configured for the VPLS routing instance. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery is enabled.</p>
Editable in Service Order	<p>By default, each advanced setting that you include in the service definition can be edited in the service order. To prevent the service provisioner from overriding an advanced setting in the service order, clear the Editable in Service Order check box.</p>

2. Click **Next** to define the UNI or site parameters. Alternatively, click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.
3. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.
4. After you complete reviewing the settings, click **Finish** to complete the service definition creation.

Specifying UNI or Site Settings for Point-to-Multipoint E-LAN Service Definitions

In this step, you provide the UNI attributes for this service definition. The attributes you set depend on the type of interface you are using in this E-LAN service definition. The following interface types are supported:

- ports
- 802.1Q interfaces
- Q-in-Q interfaces
- asymmetric interface

UNI or Site Settings for Port-to-Port Interfaces in E-LAN Services

The **Site Settings** window provides four expanding or collapsing panels: Traffic Treatment, Interface Settings, MTU Settings, and Bandwidth Settings.

To specify the UNI Settings for Port-to-Port interfaces:

1. Fill in the fields on the **Site Settings** window.

Field	Action
PE-CE Interface Settings- Ethernet Encapsulation	
VLAN Tagging	<p>Select port-port from the list.</p> <p>The VLAN tagging option you choose determines the other options you can select and specify on the page.</p>
Editable in Service Order	To allow the service provisioner to override the VLAN tagging or Ethernet option attribute, select the check box.
LDP PW Extension Settings	
<p>NOTE: The LDP PW Extension Settings is available only if you have selected the Enable PW Extension check box in the General tab.</p>	
Physical Interface Encapsulation	In the Physical Interface Encapsulation box, select ethernet-ccc , which is the only valid physical interface encapsulation method for port-to-port services.
Logical Interface Encapsulation	You can not select a choice in this field because it is not relevant to port-to-port services.

Field	Action
Traffic Type	This drop-down is disabled for port-to-port services. For port-to-port services, all traffic is always transported.
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to vlan all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalize to vlan none—To preserve no VLAN IDs across the network. • Normalize to Dot1q tag—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalize to QinQ tags—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>
Auto Pick VLAN ID	This check box is disabled because in port-to-port services, all traffic and all VLANs on one port are transported to all other ports.
Editable in Service Order	To allow the service provisioner to override the VLAN ID setting, select the check box. This check box is not applicable for port-to-port services.
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes.
MTU Range for manual-config(Bytes)	<p>Specify the low and high values to define the MTU range that you want to define.</p> <p>The default range is 1522 through 9192 bytes.</p>

Field	Action
-------	--------

PE-CE Interface Rate-Limiting Settings

Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Bandwidth – Burst Size Settings

Field	Action
Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>

The following table lists the **Max Bandwidth (Mbps)** for the M Series, MX Series, and ACX Series Routers:

Table 80: Maximum Bandwidth for M Series, MX Series, and ACX Series Routers

M Series IQ2E PIC		M Series IQ2 PIC		MX Series 3D PIC		MX Series Non-3D PIC		ACX 2000	
GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)
32,000 Mbps or 32 Gbps	32,000 Mbps or 32 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	100,000 Mbps or 100 Gbps	100,000 Mbps or 100 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

UNI or Site Settings for 802.1Q Interfaces in E-LAN Services

To specify the UNI Settings for 802.1Q interfaces:

1. Fill in the fields on the **Site Settings** window.

Field	Action
-------	--------

PE-CE UNI Settings- Ethernet Encapsulation

VLAN Tagging	<p>Select dot1q from the list.</p> <p>The Ethernet option you choose determines the other options you can select and specify on the page.</p>
Physical Interface Encapsulation	<p>In the Physical Interface Encapsulation box, select the default physical encapsulation scheme to be used by service orders based on this service definition. For point-to-multipoint services with 802.1Q interfaces, the only option is flexible-ethernet-services.</p>
Logical Interface Encapsulation	<p>The Logical Interface Encapsulation field is constrained by your selection in the Physical Interface Encapsulation field. For the physical encapsulation mode of flexible-ethernet-services, your only option is to select vlan-vpls for the logical encapsulation method.</p>

LDP PW Extension Settings

NOTE: The **LDP PW Extension Settings** is available only if you have selected the **Enable PW Extension** check box in the General tab.

Physical Interface Encapsulation	<p>In the Physical Interface Encapsulation box, select one of the following options:</p> <ul style="list-style-type: none"> • vlan-ccc • extended-vlan-ccc • flexible-ethernet-services
Logical Interface Encapsulation	<p>The Logical Interface Encapsulation field is constrained by your selection in the Physical Interface Encapsulation field.</p> <p>For the physical encapsulation mode of vlan-ccc or flexible-ethernet-services, your only option is to select vlan-ccc for the logical encapsulation method.</p> <p>For the physical encapsulation mode of extended-vlan-ccc, your only option is to select extended-vlan-ccc for the logical encapsulation method.</p>

Field	Action
Traffic Type	<p>Select Transport single vlan to transport the traffic for a specific VLAN across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify the Outer Tag protocol ID.</p> <p>Select Transport vlan range to limit the traffic across the network to a specific range of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID range when creating a service order based on this service definition.</p> <p>Select Transport vlan list to limit the traffic across the network to a specific list of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to vlan all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalize to vlan none—To preserve no VLAN IDs across the network. • Normalize to Dot1q tag—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalize to QinQ tags—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>

Field	Action
Auto Pick VLAN ID	<p>Indicate how the VLAN ID is determined. By default, this check box is disabled.</p> <ul style="list-style-type: none"> • Clear this check box to allow the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> • Select this check box when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag Protocol ID	<p>Select the outer tag protocol ID if the Customer traffic type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPID) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Editable in Service Order	To allow the service provisioner to override the outer tag protocol ID setting, select the check box for those options.
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes. To allow the service provisioner to override the MTU setting, select the Editable in Service Order check box.
MTU range for manual-config	<p>In the MTU range fields, type the lowest and highest values for MTU for each UNI.</p> <p>NOTE: To allow the service provisioner to override the MTU setting, select Editable in Service Order and, in the MTU range fields, type the highest and lowest MTU values.</p>
PE-CE Interface Rate-Limiting Settings	
Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>

Field	Action
Min Bandwidth (Kbps)	Specify the minimum bandwidth value in Kbps. Default: 1000 Kbps Range: 64 Kbps through 100,000 Kbps
Max Bandwidth (Mbps)	Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708 Default: 100 Mbps Range: 1 Mbps through 100,000 Mbps
Increment (Kbps)	Specify a value that defines which values in the range is made available to the service provisioner. Default: 1000 Kbps Range: 64 Kbps through 100,000 Kbps

Bandwidth – Burst Size Settings

Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>
------------------------------	---

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

UNI or Site Settings for Q-in-Q Interfaces in E-LAN Services

To specify the UNI Settings for q-in-q interfaces:

1. Fill in the fields on the **Site Settings** window.

Field	Action
-------	--------

PE-CE Interface Settings- Ethernet Encapsulation

VLAN Tagging	<p>Select qinq from the list.</p> <p>The window expands to include options specific to Q-in-Q interfaces</p>
Physical Interface Encapsulation	<p>In the Physical Interface Encapsulation box, select the default physical encapsulation scheme to be used by service orders based on this service definition. For point-to-multipoint services with 802.1Q interfaces, the only option is flexible-ethernet-services.</p>
Logical Interface Encapsulation	<p>The Logical Interface Encapsulation field is constrained by your selection in the Physical Interface Encapsulation field. For the physical encapsulation mode of flexible-ethernet-services, your only option is to select vlan-vpls for the logical encapsulation method.</p>

LDP PW Extension Settings

NOTE: The **LDP PW Extension Settings** is available only if you have selected the **Enable PW Extension** check box in the General tab.

Physical Interface Encapsulation	<p>In the Physical Interface Encapsulation box, select one of the following options:</p> <ul style="list-style-type: none"> • vlan-ccc • extended-vlan-ccc • flexible-ethernet-services
Logical Interface Encapsulation	<p>The Logical Interface Encapsulation field is constrained by your selection in the Physical Interface Encapsulation field.</p> <p>For the physical encapsulation mode of vlan-ccc or flexible-ethernet-services, your only option is to select vlan-ccc for the logical encapsulation method.</p> <p>For the physical encapsulation mode of extended-vlan-ccc, your only option is to select extended-vlan-ccc for the logical encapsulation method.</p>

Field	Action
Traffic Type	<p>Transport all traffic Transports the traffic from all VLANs across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID.</p> <p>Transport single vlan Transports traffic for a specific VLAN across the network. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>Transport vlan range Limits the traffic across the network to a specific range of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID range when creating a service order based on this service definition. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>Transport vlan list Limits the traffic across the network to a specific list of VLANs.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition. You need to specify only the Outer Tag Protocol ID.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to vlan all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalize to vlan none—To preserve no VLAN IDs across the network. • Normalize to Dot1q tag—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalize to QinQ tags—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>

Field	Action
Auto Pick VLAN ID	<p>Indicate how the VLAN ID is determined. By default, this check box is disabled.</p> <ul style="list-style-type: none"> • Clear this check box to allow the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> • Select this check box when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick:	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag Protocol ID	<p>Select the outer tag protocol ID if the Customer traffic type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPID) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag Protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You cannot specify the Inner Tag protocol ID if the Customer traffic type is Transport single VLAN.</p>
Editable in Service Order	To allow the service provisioner to override the outer and inner tag protocol IDs, select the check boxes for those options.
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes. To allow the service provisioner to override the MTU setting, select the Editable in Service Order check box.
MTU range for manual-config	<p>In the MTU range fields, type the lowest and highest values for MTU for each UNI.</p> <p>NOTE: To allow the service provisioner to override the MTU setting, select Editable in Service Order and, in the MTU range fields, type the highest and lowest MTU values.</p>

PE-CE Interface Rate-Limiting Settings

Field	Action
Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Bandwidth – Burst Size Settings

Field	Action
Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

UNI or Site Settings for Services with Flexible VLAN Tagging (Asymmetric Interface Types)

You can specify the Ethernet option **asymmetric tag depth** to create a service that includes any combination of port-based interfaces, 802.1Q interfaces, and Q-in-Q interfaces.

To specify the UNI Settings for q-in-q interfaces:

- Fill in the fields on the **Site Settings** window.

Field	Action
PE-CE Interface Settings- Ethernet Encapsulation	
VLAN Tagging	Select asymmetric tag depth from the list.
Physical Interface Encapsulation	In the Physical Interface Encapsulation box, select the default physical encapsulation scheme to be used by service orders based on this service definition. For point-to-multipoint services with 802.1Q interfaces, the only option is flexible-ethernet-services .

Field	Action
Logical Interface Encapsulation	The Logical Interface Encapsulation field is constrained by your selection in the Physical Interface Encapsulation field. For the physical encapsulation mode of flexible-ethernet-services, your only option is to select vlan-vpls for the logical encapsulation method.

LDP PW Extension Settings

NOTE: The **LDP PW Extension Settings** is available only if you have selected the **Enable PW Extension** check box in the General tab.

Physical Interface Encapsulation	<p>In the Physical Interface Encapsulation box, select one of the following options:</p> <ul style="list-style-type: none"> • vlan-ccc • extended-vlan-ccc • flexible-ethernet-services
Logical Interface Encapsulation	<p>The Logical Interface Encapsulation field is constrained by your selection in the Physical Interface Encapsulation field.</p> <p>For the physical encapsulation mode of vlan-ccc or flexible-ethernet-services, your only option is to select vlan-ccc for the logical encapsulation method.</p> <p>For the physical encapsulation mode of extended-vlan-ccc, your only option is to select extended-vlan-ccc for the logical encapsulation method.</p>
Traffic Type	<p>Transport all traffic Transports the traffic from all VLANs across the network. When you select this option, the service provisioner is prompted for the VLAN-ID when creating a service order based on this service definition. You need to specify only the Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>Transport single vlan Transports traffic for a specific VLAN across the network. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>Transport vlan range Limits the traffic across the network to a specific range of VLANs. You need to specify both Outer Tag protocol ID and Inner Tag protocol ID.</p> <p>If you select this option, the service provisioner is prompted for the VLAN-ID range when creating a service order based on this service definition.</p> <p>Transport vlan list Limits the traffic across the network to a specific list of VLANs. If you select this option, the service provisioner is prompted for the VLAN-ID list when creating a service order based on this service definition. You need to specify only the Outer Tag Protocol ID.</p> <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p>

Field	Action
VLAN Normalization	<p>Select a value:</p> <ul style="list-style-type: none"> • Normalize to vlan all—To preserve customer VLAN IDs (and customer QoS priorities) across the network. <p>NOTE: For services that transport a range of VLANs, you must select VLAN Normalization to all. You cannot transport a range of VLANs without normalization.</p> <ul style="list-style-type: none"> • Normalize to vlan none—To preserve no VLAN IDs across the network. • Normalize to Dot1q tag—To transport only single-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network • Normalize to QinQ tags—To transport only double-tagged frames across the network core. All port, dot1q , and Q-in-Q traffic is transported across the network. • Normalization not required—To specify no normalization for port-to-port services <p>NOTE: Starting with Release 1.0R2, when you newly install Connectivity Services Director, if you select the option to not require normalization in a service definition, the auto-pick option for VLAN IDs and the option to edit the auto-pick behavior in service order are disabled in the service definition. When you create a service order by associating with that service definition, you need to manually enter the VLAN IDs for the interfaces and cannot use the auto-pick functionality. This same behavior also applies to default service templates in which if you select the normalization-not-required functionality, the auto-pick option for VLAN IDs is disabled.</p> <p>For more information about VLAN normalization, see “Junos Space Layer 2 Services Overview” on page 56.</p> <p>For information about VLAN manipulation, see “Understanding VLAN Manipulation (Normalization and VLAN Mapping) on Ethernet Services” on page 92.</p>

Field	Action
Auto Pick VLAN ID	<p>Indicate how the VLAN ID is determined. By default, this check box is disabled.</p> <ul style="list-style-type: none"> • Clear this check box to allow the service provider to specify the VLAN ID. This option is normally used when no VLAN normalization is applied. Specify the VLAN ID range in VLAN range for manual input. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <ul style="list-style-type: none"> • Select this check box when VLAN normalization is applied. Specify the VLAN ID pool in VLAN range for auto-pick. <p>NOTE: Make sure to select Editable in Service Order if you want the service provisioner to be able to override this setting.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick:	<p>Specify the VLAN ID pool.</p> <p>Range: 1 through 4094</p>
VLAN range for manual input	<p>Specify the VLAN ID range.</p> <p>Range: 1 through 4094</p>

Field	Action
Outer Tag Protocol ID	<p>Select the outer tag protocol ID if the Customer traffic type is Transport single VLAN:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: For an interface, you must configure a physical port with the possible Tag Protocol Identifiers (TPID) either manually or through a template. Otherwise, the service creation fails for all TPIDs except 0x8100. To configure the TPIDs manually, use the following commands:</p> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x9100</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x88a8</pre> <pre>set interfaces ae0 aggregated-ether-options ethernet-switch-profile tag-protocol-id 0x8100</pre>
Inner Tag Protocol ID	<p>Select the inner tag protocol ID:</p> <ul style="list-style-type: none"> • 0x88a8 • 0x8100 • 0x9100 <p>NOTE: You cannot specify the Inner Tag protocol ID if the Customer traffic type is Transport all traffic.</p>
Editable in Service Order	To allow the service provisioner to override the outer and inner tag protocol IDs, select the check boxes for those options.
MTU range for manual-config	<p>In the MTU range fields, type the lowest and highest values for MTU that the service provisioner can type, for each UNI</p> <p>NOTE: To allow the service provisioner to override the MTU setting, select Editable in Service Order and, in the MTU range fields, type the highest and lowest MTU values that the service provisioner can type.</p>
Default Interface MTU (Bytes)	The default MTU value is 1522 bytes. To allow the service provisioner to override the MTU setting, select the Editable in Service Order check box.
PE-CE Interface Rate-Limiting Settings	

Field	Action
Enable Interface Rate Limiting	<p>To enable a service provisioner to limit the available bandwidth, select this check box, and type a default bandwidth limit.</p> <p>NOTE: Bandwidth settings are available in the service definition when Manage CoS Profiles page is configured with CoS profiles.</p>
Default bandwidth (Mbps)	<p>Specify the default bandwidth value in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Min Bandwidth (Kbps)	<p>Specify the minimum bandwidth value in Kbps.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value in Mbps. For more information on maximum bandwidth see Table 79 on page 708</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>
Increment (Kbps)	<p>Specify a value that defines which values in the range is made available to the service provisioner.</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>

Bandwidth – Burst Size Settings

Field	Action
Burst Size Calculator	<p>Select the preferred option for calculating the burst size:</p> <ul style="list-style-type: none"> MTU Based If you select the option MTU Based, you can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. Burst Period Based If you select the option Burst Period Based, you can specify a value for Burst Period in the range 1 through 7450 milliseconds. The default value for Burst Period is 1. <p>NOTE: The Burst Size Calculator list is enabled only when you select the Enable Interface Rate Limiting check box.</p>

- Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine and modify the configured service definition settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Definition | 696](#)

[Creating a Service Definition for VPLS Access into Layer 3 Networks | 760](#)

Creating a Service Definition for VPLS Access into Layer 3 Networks

You can configure an Integrated Routing and Bridging (IRB) interface to provide access from VPLS Layer 2 networks and services into Layer 3 networks. If the IRB interface configured as a Layer 3 interface is being used in a routing instance, that routing instance will specifically declare it as routing-interface rather than a regular VPLS interface (which acts like the interface on a specific VPLS site). This feature requires a normalized VLAN (vlan-id=xxx which is the same as the unit name on which the inet4 address is specified)

Junos Space uses the two peer subinterfaces of the IRB to create the link between an existing VLAN and the Layer 3 network. An extra VPLS node is required to support the IRB interface which allows the rest of the VPLS nodes to be able to access all Layer 3 networks reachable through that interface. Providing the VPLS access into Layer 3 networks enhances basic VPLS services. Because this feature requires a normalized VLAN, it is available only on the Juniper Networks MX 3D Router series.

Prerequisites for VPLS Access into Layer 3 Networks

- The PE device with the IRB must be a Juniper Networks MX 3D Series Router to accommodate the normalized VLAN requirement.
- In addition to the PE device used for the IRB, 2 or more PEs must exist on the VPLS network for a minimum of 3 PE devices.

- A VLAN must already exist to configure this feature.

To begin the configuration of the IRB interface, in the **Network Services > Connectivity** task pane, select **Service Design > Manage Service Definitions > Create E-LAN Service Definition**.

Field	Action
Service Definition Name	Provide a name for the E-LAN service definition you want to create.
Service Type	<p>Select the type of service from the menu list. To create the VPLS into Layer 3 service, use either of the following service type:</p> <ul style="list-style-type: none"> • (E-LAN) Multipoint-to-Multipoint • (E-LAN) Point-to-Multipoint
Description	Provide any comments or a description that will help explain the purpose of this definition.
Instance Type	<p>Select an instance type to choose the type of routing instance for the E-LAN service:</p> <ul style="list-style-type: none"> • vpls • evpn • virtual-switch
Protocol	<p>Different protocols are available based on the instance type you select:</p> <ul style="list-style-type: none"> • vpls • evpn • evpn e-tree
Enable L3 Access	Select the check box to create the link into Layer 3.
Enable Multihoming	<p>Select this check box to pair any two N-PE devices, for providing redundant connectivity. When you select this check box, a Multihoming Mode list appears if you select evpn or evpn e-tree as the protocol type.</p> <p>You can select either single-active or all-active as the multihoming mode.</p>
Route target	The Route target field is prepopulated with the Auto pick option.
Route distinguisher	The Route distinguisher field is prepopulated with the Auto pick option.
MAC Settings	
MAC learning	MAC learning is on by default for E-LAN service definitions.
Interface MAC limit	The default value for Interface MAC limit is 1024. If you are using a different value, enter that value.

Field	Action
MAC table size	The table size is predetermined to correspond to the default MAC limit. If you are using a value other than the default, specify that value.

1. Click **Next** to display the next screen, **Site Settings**, and continue creating the service definition.

Specifying Site or UNI Settings

Site Settings Field	Action
PE-CE Interface Settings – Ethernet Encapsulation	
VLAN Tagging	Indicate the Ethernet option to use for this E-LAN service definition. Choices are qinq , dot1q , or asymmetric tag depth .
Customer VLANs	The only option for E-LAN service definitions is Transport single VLAN .
VLAN normalization	All E-LAN service definitions require VLAN normalization.
Auto Pick VLAN ID	The only option for E-LAN service definitions is Select manually .
Physical Interface Encapsulation	The only option for E-LAN service definitions is flexible-ethernet-services
Logical Interface Encapsulation	The only option for E-LAN service definitions is vlan-vpls .
Default MTU (Bytes)	This field is populated with the default MTU value of 1522. If you are not using the default value, enter the MTU value in bytes.
MTU range (Bytes)	If you are specifying a custom MTU value, indicate the range of values in bytes.

1. Click **Finish** to see the service definition inventory list.
2. Click on the unpublished service definition you just created.
3. Right-click on the selected service definition to choose publishing options.
4. Select the service definition and click **Publish** to save and publish the definition.
5. The next step is to create the service order. In the **Network Services > Connectivity** task pane, select **Service Provisioning**.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Definition](#) | 696

[Creating a Point-to-Multipoint E-LAN Service Definition](#) | 726

Service Design: Managing IP Service Definitions

IN THIS CHAPTER

- [Creating a Full-Mesh IP Service Definition | 765](#)
- [Creating a Hub-and-Spoke \(One Interface\) IP Service Definition | 776](#)
- [Creating a Service Definition for E-Line Pseudowire Access into a Layer 3 VPN | 788](#)
- [Creating a Multicast VPN Service Definition | 791](#)

Creating a Full-Mesh IP Service Definition

You can create a customized service definition—for example, to set a different VLAN ID range on the service than those offered in the standard service definitions. Network operators or service provisioners can use the service definition as a base for creating and then activating full-mesh ethernet services on the network.

You can use the tab panel at the top, or the **Back** and **Next** buttons to switch between the wizard pages.

You can create a Full-Mesh IP Service Definition, by following the steps given in the procedure.

Creating a full mesh IP service definition consists of the following steps:

1. [Specifying General Settings Information | 765](#)
2. [Specifying Site or UNI Settings | 769](#)
3. [Reviewing the Configured Settings | 775](#)

Specifying General Settings Information

In the **Service View** pane, select **Network Services > Connectivity > IP Services**. In the **Tasks** pane, select **Service Design > Manage Service Definitions**.

1. In the **Manage Service Definitions** pane, click **New**.

The **Create IP Service Definition** wizard appears.

2. To specify the general settings or service attributes for a full mesh service definition, fill in the fields on the General page as indicated in [Table 81 on page 766](#).

Table 81: IP Service Definition - General Settings

Field	Action
Service Definition Name	Type a unique name that identifies the full mesh IP definition. Range: 3 through 50 characters.
Service Type	Select IP (Full Mesh) .
Instance Type	Select one of the following instance types: <ul style="list-style-type: none"> • vrf—To advertise routes from the CE router to the PE router and vice versa. • default—To add an IP Transit Service to the PE-CE router configuration. • virtual router—To divide a router into multiple independent virtual routers where each router has its own routing table. <p>The Connectivity Settings sections appear only if the instance type is vrf.</p> <p>NOTE: Starting from Connectivity Services Director Release 2.0R4 onward, default instance type and virtual router instance type are also added to full-mesh IP services.</p>
Description (Optional)	Type a comment that identifies or describes the definition. Range: 1 through 200 characters.
Enable Distinct Instance Name	Select this check box to specify different routing instance name for each device selected in an IP Service. NOTE: Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a full-mesh IP service definition.
Decouple Service Status From Port Status	Select this check box to isolate the events related to an interface in the OpenNMS. NOTE: When you select this check box, only the MPLS traps are monitored, and not the interface-related traps (such as jnxVpnIfUp or jnxVpnIfDown). By default, all the events are saved in the OpenNMS database.
Connectivity Settings	

Table 81: IP Service Definition - General Settings (*continued*)

Field	Action
Policy Based Route Target	<p>Select this check box to create a policy-based vrf instance.</p> <p>Deselect this check box to create a community-based vrf instance.</p> <p>Route Leak is supported when Policy Based Route Target check box is selected.</p> <p>For more information on creating policies for an IP service, see “Creating Policies for an IP Service” on page 1057.</p>
Auto-pick Route Target	<p>Select a route target option:</p> <ul style="list-style-type: none"> • Select the Auto-pick Route Target check box and the Policy Based Route Target check box to auto generate route target policies. • Select the Auto-pick Route Target check box and deselect the Policy Based Route Target check box to auto generate a community. No policy will be used. • When you clear this check box and select the Policy Based Route Target check box: <ul style="list-style-type: none"> • You can create a route target policy and associate it with import and export policy. • The route target policy will be auto generated. <p>Note that, you cannot manually select or modify policy during the modification of service.</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
Enable Auto Export Routes	<p>Select this check box in the Create IP Service Definition wizard to enable internal and external route leak as part of route target policy creation.</p> <p>NOTE: Starting from Release 2.0R4 onward, Connectivity Services Director supports internal and external route leak as part of route target policy creation while creating a full-mesh IP service definition.</p>
Import Internal Routes	<p>Select this check box in the Create IP Definition wizard to enable internal route leak feature as part of route target policy creation.</p> <p>Import Internal Route field is available only if Policy Based Route Target check box is selected.</p>
Import External Route	<p>Select this check box in the Create IP Definition wizard to enable external route leak feature as part of route target policy creation.</p> <p>Import External Route field is available only if Policy Based Route Target check box is selected.</p>

Table 81: IP Service Definition - General Settings (*continued*)

Field	Action
Auto-pick Route Distinguisher	<p>Select a route distinguisher option:</p> <ul style="list-style-type: none"> • Deselect the check box to enable the service provider to specify the route distinguisher. • Select the check box to enable the route distinguisher to be selected automatically. <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
VRF Table label	<p>Select this check box to configure a separate label for each VRF to provide double lookup and egress filtering.</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
Export Direct Routes	Select this check box to export direct routes.
Enable MVPN	Select the check box to enable multicast virtual private network (MVPN).
Service Template	<p>(Optional) To include a service template for the service, click the Add icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click OK. You are returned to the General Settings page.</p> <p>The selected service template appears in the Default Service Template field.</p> <p>You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.</p> <p>NOTE: Starting with Connectivity Services Director Release 2.1, you can add or delete a service template while creating a service order.</p> <p>The remaining service templates on the Service Template list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.</p> <p>In the View Service Definition Details window, the value for the default service template in the Default Service Template column is <i>True</i>.</p> <p>For instructions on creating a service template, see <i>Creating a Service Template</i>.</p> <p>NOTE: To provision an IP service for QinQ UNI type, you can create a service template with service variables as <i>interface name</i> and <i>unit name</i>.</p>

3. Click **Next** to save the General page information. Continue with [“Specifying Site or UNI Settings” on page 769](#).

Specifying Site or UNI Settings

To provide the site or UNI service attributes for this service definition:

1. Fill in the fields on the Site Settings page as indicated in [Table 82 on page 769](#).

Table 82: IP Service Definition - PE-CE UNI Settings

Field	Action
PE-CE UNI Settings	
MTU Settings	
Interface MTU (Bytes)	<p>You can specify an MTU value in this field. The default value for MTU is 1522 bytes.</p> <p>To see the permitted range for the MTU value, select the Editable in Service Order check box. The MTU range is 1522 through 9192.</p>
MTU Range (Bytes)	<p>If you select the check box Editable in Service Order, you can specify a value range for MTU (in bytes). The permitted range for MTU is 1522 through 9192.</p> <p>NOTE: Ultimately, the system establishes the MTU by multiplying the value you specify in the Default MTU (Bytes) field by the value you specify for MTU Factor.</p>
Bandwidth Settings	
Enable QoS	<p>When you enable QoS in the service definition, you can specify a QoS profile in the service order to classify traffic into defined service groups to provide the special treatment of traffic across the network service. For example, voice traffic can be sent across certain links, and data traffic can use other links.</p> <p>If you enable the inclusion of QoS profile settings for the service in the service template or service definition, the list of CoS profiles that you defined using the Manage CoS Profiles page (by selecting CoS under Profile and Configuration Management in the Tasks pane) are displayed. Select the CoS profile you want to associate with the service from the drop-down list.</p>

Table 82: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
Enable rate limiting (check box)	Select the check box to enable rate-limiting of traffic. Clear the check box to disable rate-limiting.
Bandwidth (Mbps)	Specify the default bandwidth value, in Mbps. Default: 10 Mbps Range: 1 Mbps through 100,000 Mbps
Min Bandwidth (Kbps)	To override the default bandwidth value, select the Editable in Service Order check box. Specify the minimum bandwidth value in Kbps: Default: 1000 Kbps Range: 64 Kbps through 100,000 Kbps
Max Bandwidth (Mbps)	Specify the maximum bandwidth value, in Mbps. Default: 100 Mbps Range: 1 Mbps through 100,000 Mbps

The following table lists the **Max Bandwidth (Mbps)** for the M Series, MX Series, and ACX Series Routers:

Table 83: Maximum Bandwidth for M Series, MX Series, and ACX Series Routers

M Series IQ2E PIC		M Series IQ2 PIC		MX Series 3D PIC		MX Series Non-3D PIC		ACX 2000	
GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)
32,000 Mbps or 32 Gbps	32,000 Mbps or 32 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	100,000 Mbps or 100 Gbps	100,000 Mbps or 100 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps
Increment (Kbps)					Specify a value in the range that is made available to the service provisioner.				

Table 82: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
Burst Size	<p>You can choose one of the following as the Burst Size:</p> <ul style="list-style-type: none"> • MTU Based (default) • Line Rate Based <p>Burst Size is the number of bytes that can pass unrestricted through a policed interface when a burst of traffic pushes the average transmit rate or receive rate above the configured bandwidth limit.</p> <p>NOTE: This field is enabled only when you select the Enable Rate Limiting check box.</p>
MTU Factor	<p>You can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10.</p> <p>The value you configure for MTU Factor should not exceed one tenth of the value you configured for burst size.</p> <p>NOTE: This field is enabled only when you select MTU Based as the Burst Size.</p>
Burst Period	<p>Specify a value for Burst Period in the range 10 through 1000. The default value for Burst Period is 10.</p> <p>NOTE: This field is enabled only when you select Line Rate Based as the Burst Size.</p>
PE-CE Interface Encapsulation Settings	

Table 82: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
Auto-pick VLAN ID	<p>Specify how the VLAN ID is determined:</p> <ul style="list-style-type: none"> • To allow the service provider to specify the VLAN ID, clear this check box. Specify the range in VLAN ID Range for Manual Config. • To allow the VLAN ID to be selected automatically from the VLAN ID pool, select Auto-pick VLAN ID check box. This option is used typically when VLAN normalization is applied. Specify the range in VLAN ID Range for Auto-pick. <p>NOTE: Select the Editable in Service Order check box, if you want to override VLAN ID selection setting in the service order.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the Auto-pick VLAN ID option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN ID Range for Auto-Pick field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the Auto-pick VLAN ID option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN ID range for Manual Config field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick	<p>Specify the range.</p> <p>Range: 1 through 4094.</p>

Table 82: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
VLAN ID Range for Manual Config	<p>Specify the range.</p> <p>Range: 1 through 4094.</p> <p>NOTE: This parameter reserves a range of VLANs for provisioning Layer 3 VPNs. These VLANs are not used to transport data from one end of a connection to the other.</p>
PE-CE Routing	
Routing Protocols	<p>Select one of the following options to allow each PE router to distribute VPN-related routes to and from connected CE routers:</p> <ul style="list-style-type: none"> • BGP/Static Route • OSPF/Static Route • BGP/OSPF/Static Route <p>NOTE: Starting in Connectivity Services Director Release 2.1R1, you can also select the BGP/OSPF/Static option from the routing protocol list to configure both BGP and OSPF protocols while creating a full-mesh IP service definition.</p>
PE-CE Interface Address Settings	
Pool-based assignment	<p>Indicate the method to be used for assigning IP addresses to PE and CE interfaces. The address-assignment pool feature supports subscriber management and DHCP management functionality by enabling you to create centralized IPv4 address pools independently of the client applications that use the pools.</p> <p>Select the check box to enable allocation of PE-CE IP addresses from IP address pools. By default, this check box is deselected. Clear the check box to disable the address-assignment pools functionality.</p>

Table 82: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
IP Pool Type	<p>Select an IP pool type option:</p> <ul style="list-style-type: none"> • Global—A Global IP address pool pertains to the service provider. There can be more than one global IPv4 address pool. However, each global pool must have its own unique name and its set of IPv4 addresses must not overlap with those of any other global pool. You can allocate addresses from global pools across multiple Layer 3 VPNs across multiple customers. The IP addresses allocated to services are unique across customers. • Customer—A Customer IP address pool pertains to an existing customer. These pools are associated with the corresponding customer. You can associate more than one customer IPv4 pool with each customer. However, each customer pool must have its own set of IPv4 addresses which must not overlap with those of any other pool belonging to the same customer. You can allocate addresses from customer pools across multiple Layer 3 VPNs for a particular customer. The IP addresses allocated to services are unique within specified customer services. <p>For more information on creation an IP pool, see <i>Creating an IP Address Pool</i>.</p>
Auto-pick PE Interface IP Address	<p>Select an option:</p> <ul style="list-style-type: none"> • Clear the check box to enable the service provider to specify the IP address of a provider edge (PE) interface. • Select the check box to cause the IP address of a provider edge (PE) interface to be selected automatically. <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
IP Address Block Size	<p>Specify the size of the IPv4 IP addressee block allocated for each provider edge (PE) or customer edge (CE) link.</p> <p>Range: 1 through 32</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>

2. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine and modify the configured service definition settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Done** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

Release History Table

Release	Description
2.1R1	Starting in Connectivity Services Director Release 2.1R1, you can also select the BGP/OSPF/Static option from the routing protocol list to configure both BGP and OSPF protocols while creating a full-mesh IP service definition.
2.0R4	Starting from Connectivity Services Director Release 2.0R4 onward, default instance type and virtual router instance type are also added to full-mesh IP services.
2.0R4	Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a full-mesh IP service definition.
2.0R4	Starting from Release 2.0R4 onward, Connectivity Services Director supports internal and external route leak as part of route target policy creation while creating a full-mesh IP service definition.

RELATED DOCUMENTATION

[Creating a Hub-and-Spoke \(One Interface\) IP Service Definition | 776](#)

[Creating a Service Definition for E-Line Pseudowire Access into a Layer 3 VPN | 788](#)

[Creating a Multicast VPN Service Definition | 791](#)

Creating a Hub-and-Spoke (One Interface) IP Service Definition

You can create a one-interface hub-and-spoke BGP/Static or OSPF/Static IP service definition, for the Connectivity Services Director application, using predefined service definitions.

In the **Service View** pane, click **Network Services > Connectivity > IP Services**. In the **Tasks** pane, click **Service Design > Manage Service Definitions**.

To create a new service definition, click **New** In the **Manage Service Definitions** pane. You can also choose a predefined service definition from the **Manage Service Definitions** pane.

In a one-interface hub-and-spoke topology, there is only one interface using a combination of static routes, BGP, and OSPF routes between CE hub and PE hub routers. You can use a one-interface hub-and-spoke IP service definition to configure a service to advertise a default route from a hub to the spokes.

For more information about predefined one-interface hub-and-spoke BGP/Static or OSPF/Static IP service definitions, see [“Predefined Hub-and Spoke IP Service Definitions” on page 643](#). You can, however create

a customized service definition—for example, to set different bandwidth limits on the service than those offered in the standard service definitions.

You must have a Service Designer user role to create IP hub-and-spoke service definitions. When you create and publish a new service definition, network operators or service provisioners with a Service Activator role can use the completed service definition as a base for creating and then activating hub-and-spoke Ethernet services on the network.

Creating a hub-and-spoke (one interface) IP service definition consists of the following steps:

1. [Specifying General Information | 777](#)
2. [Specifying UNI or Site Settings | 780](#)
3. [Reviewing the Configured Settings | 787](#)

Specifying General Information

To specify general information for a hub-and-spoke service definition:

1. Fill in the fields on the General page as indicated in [Table 84 on page 777](#).

Table 84: IP Service Definition - General Settings

Field	Action
Service Definition Name	Type a unique name that identifies the hub-and-spoke IP definition. Range: 3 through 50 characters.
Service Type	Select IP (Hub-Spoke 1 Interface) .
Instance Type	Select one of the following instance types: <ul style="list-style-type: none"> • vrf—To advertise routes from the CE router to the PE router and vice versa. • default—To add an IP Transit Service to the PE-CE router configuration. • virtual router—To divide a router into multiple independent virtual routers where each router has its own routing table. <p>The Connectivity Settings sections appear only if the instance type is vrf.</p> <p>NOTE: Starting from Connectivity Services Director Release 2.0R4 onward, default instance type and virtual router instance type are also added to hub-and-spoke IP services.</p>
Description (Optional)	Type a comment that identifies or describes the definition. Range: 1 through 200 characters.

Table 84: IP Service Definition - General Settings (*continued*)

Field	Action
Enable Distinct Instance Name	<p>Select this check box to specify different routing instance name for each device selected in an IP service.</p> <p>NOTE: Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a hub-and-spoke IP service definition.</p>
Decouple Service Status From Port Status	<p>Select this check box to isolate the events related to an interface in the OpenNMS.</p> <p>NOTE: When you select this check box, only the MPLS traps are monitored, and not the interface-related traps (such as jnxVpnIfUp or jnxVpnIfDown).</p> <p>By default, all the events are saved in the OpenNMS database.</p>
Connectivity Settings	
Policy Based Route Target	<p>Select this check box to create a policy-based vrf instance.</p> <p>Deselect this check box to create a community-based vrf instance.</p> <p>Route Leak is supported when Policy Based Route Target check box is selected.</p> <p>For more information on creating policies for an IP service, see “Creating Policies for an IP Service” on page 1057.</p>
Auto-pick Route Target	<p>Select a route target option:</p> <ul style="list-style-type: none"> • Select the Auto-pick Route Target check box and the Policy Based Route Target check box to auto generate route target policies. • Select the Auto-pick Route Target check box and deselect the Policy Based Route Target check box to auto generate a community. No policy will be used. • When you clear this check box and select the Policy Based Route Target check box: <ul style="list-style-type: none"> • You can create a route target policy and associate it with import and export policy. • The route target policy will be auto generated. <p>Note that, you cannot manually select or modify policy during the modification of service.</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>

Table 84: IP Service Definition - General Settings (*continued*)

Field	Action
Enable Auto Export Routes	<p>Select this check box in the Create IP Service Definition wizard to enable internal and external route leak as part of route target policy creation.</p> <p>NOTE: Starting from Release 2.0R4 onward, Connectivity Services Director supports internal and external route leak as part of route target policy creation while creating a hub-and-spoke IP service definition.</p>
Import Internal Routes	<p>Select this check box in the Create IP Definition wizard to enable internal route leak feature as part of route target policy creation.</p> <p>Import Internal Route field is available only if Policy Based Route Target check box is selected.</p>
Import External Route	<p>Select this check box in the Create IP Definition wizard to enable external route leak feature as part of route target policy creation.</p> <p>Import External Route field is available only if Policy Based Route Target check box is selected.</p>
Auto-pick Route Distinguisher	<p>Select a route distinguisher option:</p> <ul style="list-style-type: none"> • Deselect the check box to enable the service provider to specify the route distinguisher. • Select the check box to enable the route distinguisher to be selected automatically. <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
VRF Table Label	<p>Select this check box to configure a separate label for each VRF to provide double lookup and egress filtering.</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
Export Direct Routes	Select this check box to export direct routes.
Enable MVPN	Select this check box to enable MVPN settings in IP service orders to be based on this service definition.

Table 84: IP Service Definition - General Settings (*continued*)

Field	Action
Service Template	<p>(Optional) To include a service template for the service, click the Add icon or plus sign (+) to select a service template from the Service Template list. The list of available service templates is displayed. Select the check box beside the template you want and click OK. You are returned to the General Settings page.</p> <p>The selected service template appears in the Default Service Template field.</p> <p>You can select one or more service templates as the default service template. By default, the default service templates are attached to the endpoints.</p> <p>NOTE: Starting with Connectivity Services Director Release 2.1, you can add or delete a service template while creating a service order.</p> <p>The remaining service templates on the Service Template list are termed as optional service templates. You can attach the optional service templates to the endpoints on a need basis.</p> <p>In the View Service Definition Details window, the value for the default service template in the Default Service Template column is <i>True</i>.</p> <p>For instructions on creating a service template, see <i>Creating a Service Template</i>.</p> <p>NOTE: To provision an IP service for QinQ UNI type, you can create a service template with service variables as <i>interface name</i> and <i>unit name</i>.</p>

2. Click **Next** to save the General information.

The **Site Settings-Create IP Service Definition** page appears.

Specifying UNI or Site Settings

To specify UNI interface settings for the service definition:

1. Fill in the fields on the Site Settings page as indicated in the table as indicated in [Table 85 on page 780](#).

Table 85: IP Service Definition - PE-CE UNI Settings

Field	Action
PE-CE UNI Settings	
MTU Settings	

Table 85: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
Interface MTU (Bytes)	<p>You can specify an MTU value in this field. The default value for MTU is 1522 bytes.</p> <p>To see the permitted range for the MTU value, select the Editable in Service Order check box. The MTU range is 1522 through 9192.</p>
MTU Range (Bytes)	<p>If you select the check box Editable in Service Order, you can specify a value range for MTU (in bytes). The permitted range for MTU is 1522 through 9192.</p> <p>NOTE: Ultimately, the system establishes the MTU by multiplying the value you specify in the Default MTU (Bytes) field by the value you specify for MTU Factor.</p>
Bandwidth Settings	
Enable QoS	<p>When you enable QoS in the service definition, you must specify a QoS profile in the service order to classify traffic into defined service groups to provide the special treatment of traffic across the network service. For example, voice traffic can be sent across certain links, and data traffic can use other links.</p> <p>If you enable the inclusion of QoS profile settings for the service in the service template or service definition, the list of CoS profiles that you defined using the Manage CoS Profiles page (by selecting CoS under Profile and Configuration Management in the Tasks pane) are displayed. Select the CoS profile you want to associate with the service from the drop-down list.</p>
Enable rate limiting (check box)	Select the check box to enable rate-limiting of traffic. Clear the check box to disable rate-limiting.
Bandwidth (Mbps)	<p>Specify the default bandwidth value, in Mbps.</p> <p>Default: 10 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>

Table 85: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
Min Bandwidth (Kbps)	<p>To override the default bandwidth value, select the Editable in Service Order check box.</p> <p>Specify the minimum bandwidth value in Kbps:</p> <p>Default: 1000 Kbps</p> <p>Range: 64 Kbps through 100,000 Kbps</p>
Max Bandwidth (Mbps)	<p>Specify the maximum bandwidth value, in Mbps.</p> <p>Default: 100 Mbps</p> <p>Range: 1 Mbps through 100,000 Mbps</p>

The following table lists the **Max Bandwidth (Mbps)** for the M Series, MX Series, and ACX Series Routers:

Table 86: Maximum Bandwidth for M Series, MX Series, and ACX Series Routers

M Series IQ2E PIC		M Series IQ2 PIC		MX Series 3D PIC		MX Series Non-3D PIC		ACX 2000	
GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)	GE Port (1G)	XE Port (10G)
32,000 Mbps or 32 Gbps	32,000 Mbps or 32 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	100,000 Mbps or 100 Gbps	100,000 Mbps or 100 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps	50,000 Kbps or 50 Gbps

Burst Size	<p>You can choose one of the following as the Burst Size:</p> <ul style="list-style-type: none"> • MTU Based (default) • Line Rate Based <p>Burst Size is the number of bytes that can pass unrestricted through a policed interface when a burst of traffic pushes the average transmit rate or receive rate above the configured bandwidth limit.</p> <p>NOTE: This field is enabled only when you select the Enable Rate Limiting check box.</p>
-------------------	--

Table 85: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
MTU Factor	<p>You can specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10.</p> <p>The value you configure for MTU Factor should not exceed one tenth of the value you configured for burst size.</p> <p>NOTE: This field is enabled only when you select MTU Based as the Burst Size.</p>
Burst Period	<p>Specify a value for Burst Period in the range 10 through 1000. The default value for Burst Period is 10.</p> <p>NOTE: This field is enabled only when you select Line Rate Based as the Burst Size.</p>
Increment (Kbps)	Specify a value in the range that is made available to the service provisioner.
PE-CE Interface Encapsulation Settings	

Table 85: IP Service Definition - PE-CE UNI Settings (continued)

Field	Action
Auto-pick VLAN ID	<p>Specify how the VLAN ID is determined:</p> <ul style="list-style-type: none"> • To allow the service provider to specify the VLAN ID, clear the check box. Specify the range in VLAN ID Range for Manual Config.. • To allow the VLAN ID to be selected automatically from the VLAN ID pool, select Auto-pick VLAN ID check box. This option is used typically when VLAN normalization is applied. Specify the range in VLAN ID Range for Auto-pick <p>NOTE: Select the Editable in Service Order check box, if you want to override VLAN ID selection setting in the service order.</p> <p>NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:</p> <ul style="list-style-type: none"> • If you create a service order with the Auto-pick VLAN ID option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN ID Range for Manual Config field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range. • If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
VLAN range for auto-pick	<p>Specify the range.</p> <p>Range: 1 through 4094.</p>

Table 85: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
VLAN ID Range for Manual Config	<p>Specify the range.</p> <p>Range: 1 through 4094.</p> <p>NOTE: This parameter reserves a range of VLANs for provisioning Layer 3 VPNs. These VLANs are not used to transport data from one end of a connection to the other.</p>
PE-CE Routing	
Routing Protocols	<p>Select one of the following options to allow each PE router to distribute VPN-related routes to and from connected CE routers:</p> <ul style="list-style-type: none"> • BGP/Static Route • OSPF/Static Route • BGP/OSPF/Static Route <p>NOTE: Starting from Connectivity Services Director Release 2.1R1, you can also select the BGP/OSPF/Static option from the routing protocol list to configure both BGP and OSPF protocols while creating a hub-and-spoke IP service definition.</p>
PE-CE Interface Address Settings	
Pool-based assignment	<p>Indicate the method to be used for assigning IP addresses to PE and CE interfaces. The address-assignment pool feature supports subscriber management and DHCP management functionality by enabling you to create centralized IPv4 address pools independently of the client applications that use the pools.</p> <p>Select the check box to enable allocation of PE-CE IP addresses from IP address pools. By default, this check box is deselected. Clear the check box to disable the address-assignment pools functionality.</p>

Table 85: IP Service Definition - PE-CE UNI Settings (*continued*)

Field	Action
IP Pool Type	<p>Select an IP pool type option:</p> <ul style="list-style-type: none"> • Global—A Global IP address pool pertains to the service provider. There can be more than one global IPv4 address pool. However, each global pool must have its own unique name and its set of IPv4 addresses must not overlap with those of any other global pool. You can allocate addresses from global pools across multiple Layer 3 VPNs across multiple customers. The IP addresses allocated to services are unique across customers. • Customer—A Customer IP address pool pertains to an existing customer. These pools are associated with the corresponding customer. You can associate more than one customer IPv4 pool with each customer. However, each customer pool must have its own set of IPv4 addresses which must not overlap with those of any other pool belonging to the same customer. You can allocate addresses from customer pools across multiple Layer 3 VPNs for a particular customer. The IP addresses allocated to services are unique within specified customer services. <p>For more information on creation an IP pool, see “Creating an IP Address Pool” on page 404.</p>
Auto-pick PE Interface IP Address	<p>Select an option:</p> <ul style="list-style-type: none"> • Clear the check box to enable the service provider to specify the IP address of a provider edge (PE) interface. • Select the check box to cause the IP address of a provider edge (PE) interface to be selected automatically. <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>
IP Address Block Size	<p>Specify the size of the IPv4 IP addressee block allocated for each provider edge (PE) or customer edge (CE) link.</p> <p>Range: 1 through 32</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box.</p>

2. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

After you complete reviewing the settings, click **Finish** to complete the service definition creation.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine and modify the configured service definition settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Done** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

Release History Table

Release	Description
2.1R1	Starting from Connectivity Services Director Release 2.1R1, you can also select the BGP/OSPF/Static option from the routing protocol list to configure both BGP and OSPF protocols while creating a hub-and-spoke IP service definition.
2.0R4	Starting from Connectivity Services Director Release 2.0R4 onward, default instance type and virtual router instance type are also added to hub-and-spoke IP services.
2.0R4	Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a hub-and-spoke IP service definition.
2.0R4	Starting from Release 2.0R4 onward, Connectivity Services Director supports internal and external route leak as part of route target policy creation while creating a hub-and-spoke IP service definition.

RELATED DOCUMENTATION

[Creating a Full-Mesh IP Service Definition | 765](#)

[Creating a Service Definition for E-Line Pseudowire Access into a Layer 3 VPN | 788](#)

[Creating a Multicast VPN Service Definition | 791](#)

Creating a Service Definition for E-Line Pseudowire Access into a Layer 3 VPN

Creating a pseudowire between two terminating PE devices allows you to encapsulate traffic from the Layer 2 VPN into a Layer 3 VPN, thereby providing access to Layer-3 services. Also known as *pseudowire stitching*, the benefit of this feature is that devices running older technologies will continue to function when networks are upgraded and Layer-3 technologies are in play.

To use this feature, the following prerequisites must be met:

- An existing Layer 3 VPN must be used as the target VPN.
- A device with an LT interface must be used to create the pseudowire.

To create the pseudowire, in the Network Services > Connectivity view pane, select **Service Design > New > E-Line Service Definition**.

1. Define the general settings for the service definition.

Field	Action
Name	Provide a name for the service definition.
Service type	The service type is E-Line pseudowire
Comments	Enter any comments that will help describe the service definition and its purpose.
Interface type	Specify the type of interface as Ethernet. Also check the box to enable pseudowire access into the Layer 3 VPN network.

2. Click **Next** to display the **Connectivity** window.

Field	Action
VC ID selection	Choose from Auto pick or Select Manually for VC ID assignment.
Default MTU (Bytes)	Indicate the MTU size or use the default that appears in the field.

3. Click **Next** to display the **Site Settings** window.
4. Define the UNI settings for the service definition. This definition can be created as a port-to-port or 802.1q link. This procedure shows the port-to-port Ethernet settings.

Site Settings Field	Action
Traffic Treatment Settings	
Ethernet option	Indicate the Ethernet option to use for this E-Line service definition. Choices are port-port or dot1q .
Customer traffic type	This field can be left blank.
VLAN ID selection	This field can be left blank.
Interface Settings	

Site Settings Field	Action
Physical IF encapsulation	The interface encapsulation for the port-to-port link must be specified as ethernet-ccc .
Logical IF encapsulation	This field is not used.
MTU Settings	
Default MTU (Bytes)	This field is populated with the default MTU value of 1522. If you are not using the default value, enter the MTU value in bytes.
MTU range (Bytes)	If you are specifying a custom MTU value, indicate the range of values in bytes.

If you are creating an 802.1q link, use the following settings:

5. Click **Finish** and then create the service order.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

RELATED DOCUMENTATION

[Creating a Full-Mesh IP Service Definition | 765](#)

[Creating a Hub-and-Spoke \(One Interface\) IP Service Definition | 776](#)

[Creating a Multicast VPN Service Definition | 791](#)

Creating a Multicast VPN Service Definition

This topic describes how the Connectivity Services Director application enables you to create an L3VPN service definition preliminary to creating a Multicast VPN (MVPN) service order.

Refer to the topic [“Creating a Full-Mesh IP Service Definition” on page 765](#).

NOTE: Multicast VPN services are supported on LN2600 and MX devices only.

To create a L3VPN Service definition upon which to base a MVPN service order, in the Network Services > Connectivity view pane, select **Service Design > Manage Service Definitions > New > L3VPN Service Definition**.

1. Specify values for the parameters in the **General** and **Site Settings** windows as described in the following tables.

In the **General** settings window, add information in the relevant fields as described in the following table:

Field	Description
Service Definition Name	Type a name for this service definition.
Service type	Select L3VPN (Full Mesh)
Description	Type comments to describe the service definition.
Service Template	None
Enable MVPN	Select this check box to enable MVPN settings in L3VPN service orders to be based on this service definition.
Decouple Service Status from Port Status	Do not select this check box.

2. Click **Next**.

3. In the **Site Settings** window, add information in the relevant fields as described in the following table:

Field	Description
Ethernet	Select this check box.

Field	Description
Auto-pick VLAN ID	Select this check box.
VLAN range for auto-pick	N/A
VLAN range for manual input	N/A
Auto-pick Route Target	A site within a VPN that a PE router services and to which the PE router will distribute routes.
Auto-pick Router Distinguisher	<p>An identifier attached to a route that distinguishes the VPN to which the route belongs. Each routing instance must have a unique route distinguisher associated with it.</p> <p>Select Auto pick. JUNOS Space selects the route distinguisher automatically.</p>
VRF Table label	<p>A VRF table label distinguishes one VRF instance from another and enables double lookup and egress filtering.</p> <p>Select this check box.</p>
Export Direct Routes	Select this check box.
Allowed Routing Protocols	Select BGP/Static Route
PE Interface IP Address	<p>The IP address of the interface on the PE device.</p> <p>Select Auto pick.</p>
IP Pool Type	<p>Global—A Global IP address pertains to the service provider. There can be more than one global IPv4 address pool. However, each global pool must have its own unique name and its set of IPv4 addresses must not overlap with those of any other global pool. You can allocate addresses from global pools across multiple Layer 3 VPNs across multiple customers.</p> <p>Customer—A Customer IP address pool pertains to an existing customer. These pools are associated with the corresponding customer. You can associate more than one customer IPv4 pool with each customer. However, each customer pool must have its own set of IPv4 addresses which must not overlap with those of any other pool belonging to the same customer. You can allocate addresses from customer pools across multiple Layer 3 VPNs for a particular customer.</p>
IP Address Block Size	<p>The size of the IPv4 addresses block allocated for each PE/CE link.</p> <p>Range: 28–32</p>

4. Click **Review** to examine the settings and modify any attributes as required.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

5. Click **Finish**.

RELATED DOCUMENTATION

[Creating a Full-Mesh IP Service Definition | 765](#)

[Creating a Hub-and-Spoke \(One Interface\) IP Service Definition | 776](#)

[Creating a Service Definition for E-Line Pseudowire Access into a Layer 3 VPN | 788](#)

8

PART

Service Provisioning: Working with Customers

Service Provisioning: Managing Customers | 795

Service Provisioning: Managing Customers

IN THIS CHAPTER

- Adding a New Customer | 795
- Deleting Customers | 796
- Modifying an Existing Customer | 797
- Viewing Customer Details | 798

Adding a New Customer

New customers must be identified to the system before you can provision and activate a service order for them.

To add a customer to the database:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Customer > Manage Customers**. The View Customers window is displayed.
4. Click the **Add** icon above the table of listed customers. The Add Customer dialog box is displayed.
5. On the **Create Customer** dialog box, provide the information requested for the customer, similar to the following example.

Fill out the fields in the form.

The **Name** and **Account number** fields are required. All other fields are optional.

6. Click **Create**.

The **View Customers** page shows the new customer.

RELATED DOCUMENTATION

[Deleting Customers | 796](#)

[Modifying an Existing Customer | 797](#)

[Viewing Customer Details | 798](#)

Deleting Customers

You cannot delete a customer from the database if an active service exists for that customer. You must decommission all such services before you can delete the customer.

To delete a customer from the database:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Customer > Manage Customers**. The View Customers window is displayed.
4. Select the customer you need to delete by clicking the row of the corresponding customer.
5. Click the **Delete** above the list of displayed customers.

If the **Delete** option is dimmed, it indicates that you have not selected a customer that must be cleared for the operation to succeed.

After successfully selecting the **Delete** action, a pop-up window appears requesting confirmation.

6. Click **Delete**.

The **View Customers** page no longer lists the deleted customer.

RELATED DOCUMENTATION

[Adding a New Customer | 795](#)

[Modifying an Existing Customer | 797](#)

[Viewing Customer Details | 798](#)

Modifying an Existing Customer

To edit the information about an existing customer:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Customer > Manage Customers**. The View Customers window is displayed, which shows the customers already added to the system.
4. Select the customer you need to modify by clicking the row of the corresponding customer.
5. Click the **Edit** icon above the table of displayed customers.
6. Make the required changes to the customer information.
7. Click **Modify**.

The **View Customers** page shows the modified information.

RELATED DOCUMENTATION

[Adding a New Customer | 795](#)

[Deleting Customers | 796](#)

[Viewing Customer Details | 798](#)

Viewing Customer Details

To view your customers:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Customer > Manage Customers**. The View Customers window is displayed, which shows the customers already added to the system.
4. Click the plus sign (+) next to the Customers tree in the Service View pane and select the customer for which you need to view detailed, extensive information.
5. From the View Customers page, click the **Details** icon above the table of displayed customers.

Alternatively, for details about a specific customer, double-click the listed customer.

The **Details** window displays the customer name, account number, contact name, contact e-mail address, and contact information in the upper half of the page. The lower half of the page displays the **Services Provisioned for Customer** pane. This pane contains three tabs: E-Line, E-LAN, and IP. The following fields are displayed in a table under each tab, depending on the type of service associated with a customer.

Field	Description
Name	Name of the service order assigned during service creation or edit.
Service Type	One of the following: <ul style="list-style-type: none"> • E-Line (LDP) • E-LAN—Either a multipoint-to-multipoint service or a point-to-multipoint service
Customer	Name of the enterprise customer who placed an order for the service.

Field	Description
Order State	<p>Status of the service order:</p> <ul style="list-style-type: none"> • Completed—Service order has been successfully deployed. • Deploy failed—Device is down or the Connectivity Services Director application was unable to push the service configuration to a device configured for the service. • In-progress—Connectivity Services Director application is in the process of deploying the service. • Requested—Service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment. • Scheduled—Service provisioner has scheduled the service order for deployment. • Invalid—Service order contains invalid data.
FA Status	Status of functional audit of the service.
Fault Status	Fault management status of the service.
PM Status	Performance management status of the service.
Definition	Name of the service definition upon which the service order is based.
Activation Date	Date and time at which the service order was last activated.
Last Modified Time	Date and time at which the profile was last updated.
Image Name	Name of the image file to pictorially depict the customer.
Domain ID	Unique domain identifier associated with the customer.

- To restrict the display of customers, enter a search criterion of one or more characters in the Search bar and press Enter. All customer names that match the search criterion are shown in the main display area.

RELATED DOCUMENTATION

[Adding a New Customer | 795](#)

[Deleting Customers | 796](#)

[Modifying an Existing Customer | 797](#)

[Adding a New Customer | 795](#)

9

PART

Working in Deploy Mode

About Deploy Mode | **801**

Deploying and Managing Device Configurations | **808**

Deploying and Managing Software Images | **851**

About Deploy Mode

IN THIS CHAPTER

- [Understanding Deploy Mode in Views Other than Service View of Connectivity Services Director | 801](#)
- [Understanding the Deploy Mode Tasks Pane in Views Other than Service View | 805](#)

Understanding Deploy Mode in Views Other than Service View of Connectivity Services Director

IN THIS SECTION

- [Deploying Configuration Changes | 801](#)
- [Managing Software Images | 803](#)
- [Managing Devices | 803](#)
- [Managing Device Configuration Files | 804](#)
- [Managing Baseline Configuration | 804](#)

The Deploy mode enables you to deploy configuration changes and software upgrades to devices and perform several device management and configuration file management tasks.

This topic describes:

Deploying Configuration Changes

When you make configuration changes in Build mode, the changes are not deployed to devices automatically. You must manually deploy the changes to devices in Deploy mode. Every time you make configuration changes in Build mode that affect a device, the device is automatically added to the list of devices with pending changes. Configuration changes are deployed to devices at the device level. When you deploy configuration changes to a device, all pending configuration changes for that device are deployed.

You can deploy the device configurations in the following two ways:

- **Auto Approval**—In this mode, the device configuration changes are approved automatically by the system and do not require explicit (manual) approval by a configuration approver before they can be deployed. This is the default approval mode.
- **Manual Approval**—In this mode, the device configuration changes are required to be explicitly approved by a configuration approver before the changes can be deployed to the device.

NOTE: Manual approval is not supported in Connectivity Services Director.

For more information about enabling these modes, see [“Setting Up User and System Preferences” on page 125](#).

An operator performs device configurations and creates a change request for that configuration and submits it for approval to an approver. The approvers are notified by e-mail whenever a change request is created. If a configuration or a change to it is approved by an approver, then the operator is able to deploy it. If a configuration is rejected then the operator must make the necessary changes, resubmit the change request, and procure an approval before the configuration can be deployed. For more information, see [“Approving Change Requests” on page 825](#)

NOTE: You can specify any number of approvers. If you specify more than one approver while configuring the Manual Approval mode, once an approver accepts or rejects the proposed change, the change request is not listed for the other approvers and they cannot approve or reject the same change request.

You can do the following configuration deployment tasks on devices that have pending changes:

- Run configuration deployment jobs immediately or schedule them for future times.
- Approve the change requests for pending configurations, if you have selected the Manual Approval mode.
- Preview pending configuration changes before deploying the changes.
- Validate that the pending changes are compatible with the device’s configuration.
- Manage configuration deployment jobs.

Configuration changes are validated for each device both in Connectivity Services Director and on the device. If any part of a configuration change for a device fails validation, no configuration changes are deployed to the device. You can see the results of each validation phase separately.

Connectivity Services Director will not deploy configuration to a device with a configuration that is out of sync (meaning that the device’s configuration differs from Connectivity Services Director’s version of

that device's configuration), or to a device that has uncommitted changes to its candidate configuration. Deployment to such devices will fail.

When you schedule a deployment job, that job and any profiles and devices assigned to that job are locked within Connectivity Services Director. You cannot edit the job or any of its assigned profiles until the job runs or gets cancelled. This locking feature prevents you from deploying unintended configuration changes that could result from editing profiles and devices that are already scheduled to deploy. To change any properties of a scheduled job, cancel the job and create a new scheduled job with the desired properties. You cannot edit the profile assignments of a device that has scheduled pending configuration changes.

Managing Software Images

Connectivity Services Director can manage software images on the nodes it manages. You can do the following software image management tasks:

- Deploy a software image stored in an image repository on the Connectivity Services Director server to multiple devices with a single job.
- Track the status of software image management jobs.
- Stage and install software images as separate tasks.
- Schedule staging and installation to happen at independent future times.
- Perform several software image upgrade options, such as rebooting devices automatically after the upgrade finishes.

NOTE: Using nonstop software upgrade (NSSU) to upgrade EX Series switches is supported in Connectivity Services Director.

Managing Devices

In Deploy mode you can perform several device management tasks, including:

- View the device inventory.
- Show a device's current configuration.
- Resynchronize the device configuration maintained in Build mode with the configuration on the device. For more information about resynchronization of device configuration, see [“Understanding Resynchronization of Device Configuration” on page 833](#)

Managing Device Configuration Files

You can back up device configuration files to the Connectivity Services Director server. You can perform several actions on backed up configuration files, such as restoring configuration files to devices, and viewing and comparing configuration files.

Managing Baseline Configuration

You can baseline device configuration and the OS version to the Connectivity Services Director server. You can perform several actions on baseline configuration files, such as restoring configuration files to devices, and viewing and comparing configuration files.

RELATED DOCUMENTATION

| [Understanding the Deploy Mode Tasks Pane in Views Other than Service View](#) | 805

Understanding the Deploy Mode Tasks Pane in Views Other than Service View

The Tasks pane in Deploy mode lists the available tasks. All Deploy mode tasks are always available, regardless of the scope selected in the View pane.

Deploy mode tasks are divided into the following categories:

- **Configuration Deployment**—These tasks enable you to deploy configuration changes to devices and manage configuration deployment jobs. [Table 87 on page 805](#) describes the configuration deployment tasks.
- **Image Management**—These tasks enable you to manage software images on devices. [Table 88 on page 806](#) describes the image management tasks.
- **Device Management**—These tasks enable you to view the device inventory, resynchronize the configuration of out-of-sync devices, manage the administrative state of ports, manage QFabric node groups, and convert QSFP+ port configuration. [Table 89 on page 806](#) describes the device management tasks.
- **Device Configuration File Management**—These tasks enable you manage configuration files on managed devices. [Table 90 on page 806](#) describes the device configuration file management tasks.
- **Baseline Management**—These tasks enable you manage baseline configuration of devices. [Table 91 on page 806](#) describes the baseline management tasks.
- **Key Tasks**—Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can modify this set of tasks to suit your requirements. This feature is available in Task pane irrespective of your current mode, scope, or view.

[Table 87 on page 805](#) through [Table 90 on page 806](#) describe the tasks in each task category.

Table 87: Configuration Deployment Tasks

Task	Description
Deploy Configuration Changes	Deploys pending configuration changes to devices.
Approve Change Requests	Enables a configuration approver to approve or reject a change request, which has been submitted for approval by an operator.
Set SNMP Trap Configuration	Enables SNMP traps on Connectivity Services Devices so that Connectivity Services Director can collect and manage event and error information from these devices.

Table 87: Configuration Deployment Tasks (continued)

Task	Description
View Deployment Jobs	Manages configuration deployment jobs.

Table 88: Image Management Tasks

Task	Description
Manage Image Repository	Manages the software images repository on the server.
Deploy Images to Devices	Deploys software images from the repository to devices.
View Image Deployment Jobs	Manages software image deployment jobs.

Table 89: Device Management Tasks

Task	Description
Resynchronize Device Configuration	Resynchronizes the device configuration maintained in Build mode with the running configuration on the devices.
Show Current Configuration	Shows the selected device's current configuration.
View Inventory	Displays the device inventory of the selected node.

Table 90: Device Configuration File Management Tasks

Task	Description
Manage Device Configuration Files	Manages backup device configuration files.
View Configuration File Mgmt Jobs	Manages device configuration file management jobs.

Table 91: Baseline Management Tasks

Task	Description
Manage Baseline	Manages baseline configuration files.
View Baseline Mgmt Jobs	Manages baseline configuration file management jobs.

RELATED DOCUMENTATION

Understanding Deploy Mode in Views Other than Service View of Connectivity Services Director | **801**

Deploying and Managing Device Configurations

IN THIS CHAPTER

- [Deploying Configuration to Devices | 808](#)
- [Managing Configuration Deployment Jobs | 821](#)
- [Deploy Configuration Window | 824](#)
- [Approving Change Requests | 825](#)
- [Enabling SNMP Categories and Setting Trap Destinations | 827](#)
- [Understanding Resynchronization of Device Configuration | 833](#)
- [Resynchronizing Device Configuration | 839](#)
- [Managing Device Configuration Files | 844](#)
- [Enabling or Disabling Network Ports on Routers | 849](#)

Deploying Configuration to Devices

IN THIS SECTION

- [Selecting Configuration Deployment Options | 809](#)
- [Using the Change Request Details Page | 813](#)
- [Creating a Change Request | 814](#)
- [Validating Configuration | 814](#)
- [Discarding the Pending Configurations | 815](#)
- [Viewing Pending Configuration Changes | 815](#)
- [Using the Pending Changes Window | 815](#)
- [Using the Configuration or Pending Configuration Window | 816](#)
- [Using the Deploy Configuration Errors/Warnings Window | 817](#)
- [Using the Configuration Validation Window | 817](#)
- [Deploying Configuration Changes to Devices Immediately | 817](#)
- [Scheduling Configuration Deployment | 817](#)

- [Specifying Configuration Deployment Scheduling Options | 818](#)
- [Editing Change Requests | 819](#)
- [Deleting Change Request | 820](#)
- [Resubmitting a Change Request | 820](#)
- [Performing a Rollback | 821](#)

When you make configuration changes in Build mode, the changes are not deployed to devices automatically. You must manually deploy the changes to devices in Deploy mode.

To start deploying configuration changes:

1. Click **Deploy** in the Connectivity Services Director banner.
2. Select a node in the View pane that contains the devices to which you want to deploy.
3. In the Tasks pane, select **Configuration Deployment > Deploy Configuration Changes**.

Depending upon the type of approval mode you select different windows are displayed.

If you select the Auto Approval mode, the Devices with Pending Changes page opens in the main window, listing the devices within the selected node that have pending configuration changes.

If you select the Manual Approval mode, the following two sections open in the main window:

- **Devices with recent configuration changes**—This section lists the devices with pending changes (along with the details of the change) performed by the user currently logged into the system.
- **Change Requests**—This section lists the change requests created by the user currently logged into the system.

This topic describes:

Selecting Configuration Deployment Options

Based on the approval mode, you can choose to deploy the device configuration changes in the following ways:

- When you select the auto approval mode, the page Devices with Pending Changes open. From the Devices with Pending Changes page, you can:

- Deploy configuration changes immediately by selecting one or more devices and clicking Deploy Now. For more information, see [“Deploying Configuration Changes to Devices Immediately” on page 817](#).
- Schedule configuration deployment by selecting one or more devices and clicking Schedule Deploy. For more information, see [“Scheduling Configuration Deployment” on page 817](#).
- View configuration changes that are pending on a device by clicking View in the Configuration Changes column. For more information, see [“Viewing Pending Configuration Changes” on page 815](#).
- Validate that the pending changes for a device are compatible with the device’s configuration by selecting up to ten devices and clicking Validate Pending Configuration Changes. For more information, see [“Validating Configuration” on page 814](#).
- Discard the pending configuration changes. For more information, see [“Discarding the Pending Configurations” on page 815](#).

[Table 92 on page 810](#) describes the information provided in the table on the Devices with Pending Changes page. Only the subset of devices within the selected object that have pending configuration changes are listed in the table.

Table 92: Devices with Pending Changes Page

Table Column	Description
Check box	Select to perform an action on the device in that row
Name	Device name
IP Address	Device IP address
Model	Device Model
OS Version	Operating system version running on device
Connection State	<p>State of the connection to the device:</p> <ul style="list-style-type: none"> • Up—Connectivity Services Director can communicate with the device. • Down—Connectivity Services Director cannot communicate with the device. You cannot deploy configuration to devices that are down.

Table 92: Devices with Pending Changes Page (*continued*)

Table Column	Description
Configuration State	<p>Indicates whether the device's configuration is in sync with Connectivity Services Director's version:</p> <ul style="list-style-type: none"> • In Sync—The configuration on the device is in sync with the Connectivity Services Director configuration for the device. • Out Of Sync—The configuration on the device does not match the Connectivity Services Director configuration for the device. This state is usually the result of the device configuration being altered outside of Connectivity Services Director. You cannot deploy configuration on a device when the device is Out Of Sync. To resolve this state, use the Resynchronize Device Configuration task in Deploy mode. • Synchronizing—The device configuration is in the process of being resynchronized. • Sync failed—An attempt to resynchronize an Out Of Sync device failed.
Configuration Changes	Click to view pending configuration changes for a device. The Pending Changes window opens.

If you select the Manual Approval mode, the windows Devices with recent configuration changes and Change Requests opens.

From the Devices with recent configuration changes window, you can:

- Create a device configuration change request approval and submit it for approval. Upon submission, all device changes made by an operator are validated and all the approvers are notified of the details of the proposed change request by e-mail. For more information, see [“Creating a Change Request” on page 814](#).
- View configuration changes that are pending on a device by clicking View in the Configuration Changes column. For more information, see [“Viewing Pending Configuration Changes” on page 815](#).
- Validate that the pending changes for a device are compatible with the device's configuration . For more information, see [“Validating Configuration” on page 814](#).
- Discard the pending configuration changes. For more information, see [“Discarding the Pending Configurations” on page 815](#).

NOTE: You cannot delete a device from the Devices with Pending Changes list. To remove a device from the list, you must undo the Build mode configuration changes that placed the device on the list.

[Table 93 on page 812](#) describes the information provided in the table on the Devices with recent configuration changes page.

Table 93: Devices with recent configuration changes

Table Column	Description
Name	Indicates the name of the device and profile node. Below each device node, a profile node is listed.
Change Type	Indicates the type of the configuration change done to the device.
Associations Added	Lists the ports that are added to that profile.
Associations Deleted	Lists the ports that are deleted from that profile.
Configuration	Click to view pending configuration changes for a device. The Pending Changes window opens.
Deployment State	Indicates the deployment state of a change request.

From the Change Requests window, you can:

- Deploy configuration changes immediately by selecting one or more devices and clicking Deploy Now. For more information, see [“Deploying Configuration Changes to Devices Immediately” on page 817](#).
- Schedule configuration deployment by selecting one or more devices and clicking Schedule Deploy. For more information, see [“Scheduling Configuration Deployment” on page 817](#).
- Resubmit for the change request for approval after making the necessary modifications. For more information, see [“Resubmitting a Change Request” on page 820](#).
- Edit or delete the change requests by selecting one or more change requests and clicking Edit or Delete respectively. For more information, see [“Editing Change Requests” on page 819](#) and [“Deleting Change Request” on page 820](#).
- Roll back the device configuration that is already deployed. For more information, see [“Performing a Rollback” on page 821](#).
- View the details of the change request created. For more information, see [“Using the Change Request Details Page” on page 813](#)

[Table 94 on page 812](#) describes the information provided in the table on the change requests submitted for the devices for which configuration changes are sought.

Table 94: Change Requests

Table Column	Description
Check Box	Select to perform an action on the device in that row.

Table 94: Change Requests (*continued*)

Table Column	Description
Change Request No	Indicates the change request number of the change request that is waiting to be deployed.
Title	Indicates the title name of the change request.
Created On	Indicates the change request creation date.
Approver	Indicates the username of the configuration approver.
Last Action On	Indicates the date on which the change request status is changed.
Approval Status	Indicates whether a change request is approved or rejected by the approver.
Deployment Status	Indicates whether a change request is deployed after the approval.
History Icon	Records the audit trail details of a change request, such as operation performed on a change request during a given period of time, username of the approver or operator, and so on.

Using the Change Request Details Page

Use the Change Request Details window to view the details of the change request before you either approve or reject a change request. This window provides you the details such as change request number, title, username of the user who created the change request, change request creation date and so on. A Devices table is also displayed showing the deployment status. [Table 95 on page 813](#) describes the fields in this table.

Table 95: Change Request Details

Column	Description
Name	Indicates the name of the device and profile node. Below each device node, a profile node is listed.
Change Type	Indicates the type of the configuration change done to the device.
Associations Added	Lists the ports that are added to that profile.
Associations Deleted	Lists the ports that are deleted from that profile.

Table 95: Change Request Details *(continued)*

Configuration	Click to view pending configuration changes for a device. The Pending Changes window opens.
Deployment Status	Indicates the deployment state of a change request.

Creating a Change Request

To create a change request for device configurations approval:

1. Click **Create Change Request** in the Devices with recent configuration changes page.

The Create Change Request page opens.

2. Enter the change request number.

You can either enter a number or retain the autogenerated number in this field.

3. Enter an appropriate title name for the change request.

4. Optionally, you can enter comments for the device configuration changes.

5. Click **Submit**.


The Create Change Request page opens, listing the change request details such as change request number, title, and comment, along with the change request submission job details. A Devices table is also displayed showing the validation status of the device and configuration generated for that device.

6. Click **Close**.

A new change request entry with the status Pending Approval is added to the Change Request section.

Validating Configuration

When you deploy configuration changes to a device, validation checks are performed to validate that the pending changes are compatible with the device. You can also perform this validation without deploying.



NOTE: You can also verify the configuration from the Build mode by clicking **Tasks > Domain Management > Validate Pending Configuration**.

To validate that the pending changes for devices are compatible with the device configuration:

1. For Auto Approval mode, select up to ten devices in the Devices with Pending Changes page.

NOTE: For Manual Approval mode, you cannot choose the devices for which validation needs to be done. All the configuration changes for all the devices are validated.

2. Click **Validate Pending Configuration Changes**.

The Configuration Validation window opens. See [“Using the Configuration Validation Window” on page 817](#) for a description of the window.

Discarding the Pending Configurations

Use the Discard Local Configuration Changes Results window to discard all the pending configurations that were made on a device. Once you discard the local configuration changes on a device, the configuration state of the device changes to In Sync or Out of Sync based on the system of record (SOR) mode set for the Junos Space Network Management Platform. If the SOR mode is set to Network as system of record (NSOR), then the configuration state changes to In Sync and if the SOR mode is set to Junos Space as system of record (SSOR), then the configuration state changes to Out of Sync.

To discard the configuration changes:

1. For Auto Approval mode, select the devices for which you want to discard the pending configuration and click **Discard Pending Configuration**.

The Discard Local Configuration Changes Results window opens displaying the status of the discard pending configuration job.

2. Click **Close** to close the Discard Local Configuration Changes Results window.

Viewing Pending Configuration Changes

To view pending configuration changes for a device, click **View** in the Pending Changes column.

The Pending Changes window opens. See [“Using the Pending Changes Window” on page 815](#) for a description of the window.

Using the Pending Changes Window

Use the Pending Changes window to view the pending Connectivity Services Director changes for a device. [Table 96 on page 816](#) describes the fields in this window.

Table 96: Pending Changes Window

Field	Description
Name	Lists each selected device. Expand a device by Clicking its plus sign to see its pending changes. Each pending change to a profile or other configuration object for the device is listed.
State	<p>Describes the nature of the pending change to the configuration object. These are the possible states:</p> <ul style="list-style-type: none"> • Added—The profile or configuration object was added to this device. • Removed—The profile or configuration object was removed from the device • Updated—The profile or configuration object was updated.
Configuration	<p>Click View to view the pending configuration changes for a device. The Pending Configuration window opens. See “Using the Configuration or Pending Configuration Window” on page 816 for information about the window.</p> <p>NOTE: The device configuration state must be In Sync for you to view the pending configuration changes.</p>
Close	Click to close the window.

Using the Configuration or Pending Configuration Window

Use the Pending Configuration window to view the configuration changes that will be deployed to a device when a job runs. Use the Configuration window to see changes that were deployed to a device when a completed job ran. The configuration changes are shown in these formats:

- Select the **XML View** tab to view the configuration changes in XML format. This view shows the XML-formatted configuration that will be deployed to the device’s Device Management Interface (DMI), which is used to remotely manage devices.
- Select the **CLI View** tab to view the configuration changes in CLI format. This view shows the Junos configuration statements that will be deployed to the device.

In both views, the content is color-coded for easier reading:

- Black text indicates configuration that is already active on the device, and will not be changed if you deploy.
- Green text indicates configuration that will be added if you deploy.
- Red text indicates configuration that will be removed if you deploy.

Using the Deploy Configuration Errors/Warnings Window

Use the Deploy Configuration Errors/Warnings window to view the results of deploying configuration to a device. The Errors/Warnings in validating the device configuration pane shows the results of configuration validation by Connectivity Services Director. The Errors/Warnings in Updating Device configuration pane shows the results of configuration validation on the device.

Using the Configuration Validation Window

Use the Configuration Validation window to validate that the pending changes for a device are compatible with the device's configuration. [Table 97 on page 817](#) describes this window.

Table 97: Configuration Validation Window

Table Column	Description
Object name	Lists the devices you selected for validation. Click the arrow next to a device to expand it. If there are no errors or warnings, one item labeled No Validation warnings appears. If the device has errors or warnings, they appear under the device. The device contains a list of the profiles that caused errors or warnings. Expand a profile name to see the of errors and warnings it caused.
Errors/Warnings	Describes the error or warning.

Deploying Configuration Changes to Devices Immediately

To deploy configuration changes to devices immediately:

1. Select the device or devices in the Devices with Pending Changes page.
2. Click **Deploy Now**.

The Deploy Options window opens.

3. In the Deploy Options window, enter a job name in the Deployment Job Name field, then click **OK**.

The configuration deployment job runs. The Deploy Configuration window opens and shows the results of the deployment job. For a description of fields in this window, see *Deploy Configuration Window*.

Scheduling Configuration Deployment

To schedule configuration deployment to devices:

1. Select the device or devices in the Devices with Pending Changes page.

- 2. Click **Schedule Deploy**.
The Deploy Options window opens.
- 3. Use the Deploy Options window to schedule the configuration deployment. See [“Specifying Configuration Deployment Scheduling Options” on page 818](#) for a description of the window.

Specifying Configuration Deployment Scheduling Options

Use the Deploy Options window to schedule configuration deployment jobs. [Table 98 on page 818](#) describes the actions for the fields in this window.

Table 98: Deploy Options Window

Field	Action
Deployment Job Name	Enter a job name.
Date and Time	Enter the job's start date and time.
OK	Click to accept changes and exit the window.
Cancel	Click to cancel changes and exit the window.

Editing Change Requests

You can edit a change request to change the profile that was added to a device or delete some of the profile associations. After editing a change request, you can resubmit the change request for approval. While editing a change request, if you try to delete all the profile associations in a given change request, the system prompts a message that a change request should have at least one valid association. Deleting all the associations in a change request makes it invalid. Hence, you cannot delete all the associations in a given change request. However, you can delete a change request itself to delete all the associations for that change request.

NOTE: You are unable to delete a change request or an association of a change request if an association is in pending removal state.

You are unable to edit a change request that is in Cancelled, Deployed, Rollback Success, or Rollback Failed state.

To change a profile or delete the profile associations of a change request:

1. Select the change request in the Change Requests pending action page to edit.

2. Click **Edit**.

The Edit Change Request window opens.

3. Click the call out symbol to change the profile and choose the new profile that you want to assign.. the change request.

4. To delete a profile association, click **Delete**

5. Click **Save**.

The Edit Change Request window opens, listing the change request details such as change request number, title, and comment, along with the change request submission job details. A Devices table is also displayed showing the validation status of the device and configuration generated for that device.

6. Click **Close**.

Deleting Change Request

Sometimes you might need to delete a change request from the change request list. A change request is assigned with profile associations. If you delete a change request, all the associations of that change request are also deleted.

To delete a change request:

1. Select the change request or change requests in the Change Requests pending action window.
2. Click **Delete**.

The Delete Change Request window opens, displaying the message: **Are you sure you want to delete Change Request?**.

3. Click **Yes** to delete the change request; else click **No**.

If you clicked **Yes**, the message: **Change Request deleted successfully** appears.

4. Click **OK**.

Resubmitting a Change Request

You can resubmit only those change requests that are in Pending Approval, Pending Deployment, Deploy Failed, and Create Failed state. You are unable to resubmit change requests in Deployed, Cancelled, Rollback Success, or Rollback Failure state.

In certain situations, a device can go out of sync while a user is creating a change request for that device. The change request is created, but the configuration changes for that change request are not generated. You can select the change request and resubmit it after the device is in sync again, which generates the configuration for this change request. You can resubmit change requests only for devices that have pending configuration changes.

To resubmit a change request:

1. Select the change request in the Change Requests pending action window to edit.
2. Click **Resubmit**.

A warning message pops up indicating if you want to resubmit the change request.

3. Click **Yes**.

The Resubmit Change Request window opens, listing the change request details such as change request number, title, and comment, along with the change request submission job details. A Devices table is also displayed showing the validation status of the device and configuration generated for that device.

4. Click **Close**.

Performing a Rollback

In case of any misconfigurations, you can choose to roll back a configuration that has already been deployed to the device. The following conditions apply for a rollback operation:

- The maximum number of change requests that you can roll back is the rollback limit specified in Preferences.
- Change requests are rolled back in reverse chronological order; the later change requests are rolled back first. If there are any conflicting change requests, roll back is not supported. For example, assume that a user assigns port profile P1 to ge-0/0/1 and creates a change request CR1 and deploys the profile. After this, if the user edits P1, creates another change request CR2 and deploys and removes P1 from the port by assigning some other port profile and deploys device changes or configurations as part of CR3. If the user now tries to roll back CR1, an error message about the conflicting change requests CR2 and CR3 is shown. To roll back CR1, the user must roll back CR3, then CR2, and then CR1.

RELATED DOCUMENTATION

| [Managing Configuration Deployment Jobs](#) | 821

Managing Configuration Deployment Jobs

IN THIS SECTION

- [Selecting Configuration Deployment Job Options](#) | 822
- [Viewing Configuration Deployment Job Details](#) | 823
- [Canceling Configuration Deployment Jobs](#) | 823

When you deploy configuration changes or schedule a configuration deployment, a configuration deployment job is created.

To start managing configuration deployment jobs:

1. Click **Deploy** in the Connectivity Services Director banner.
2. In the Tasks pane, select **Device Management > View Deployment Jobs**.

The Deploy Configuration page opens in the main window. The table on that page lists configuration deployment jobs.

This topic describes:

Selecting Configuration Deployment Job Options

From the Deploy Configuration page, you can:

- View the details of a configuration deployment job by clicking Show Details. See [“Viewing Configuration Deployment Job Details” on page 823](#) for more information.
- Cancel a scheduled configuration deployment job by clicking Cancel Job. See [“Canceling Configuration Deployment Jobs” on page 823](#) for more information.

[Table 99 on page 822](#) describes the information provided on the Deploy Configuration page

Table 99: Deploy Configuration Table Description

Table Column	Description
Check box	Select to perform an action on the job in that row.
Job Id	An identifier assigned to the job.
Job Name	Job name (user-created).
Percent	Percentage of the job that is complete.
Status	<p>Job status. The possible states are:</p> <ul style="list-style-type: none"> • CANCELLED—The job was cancelled by a user. • FAILURE—The job failed. This state is applied if any of the devices in the job failed. But some of the devices might have completed successfully. View the job details for the status of each device. • INPROGRESS—The job is running. • SCHEDULED—The job is scheduled but has not run yet. • SUCCESS—The job completed successfully. This state is applied if all of the devices in the job completed successfully.
Summary	Job summary.

Table 99: Deploy Configuration Table Description (*continued*)

Table Column	Description
Scheduled Start Time	Job's scheduled start time
Actual Start Time	Time when the job started.
End Time	Time when the job ended
User	User who created the job
Recurrence	This field is not used for configuration deployment jobs.

Viewing Configuration Deployment Job Details

To view the details of a configuration deployment job:

1. Select the job in the table.
2. Click **Show Details**. The Deploy Configuration window opens. See *Deploy Configuration Window* for a description of the window.

Canceling Configuration Deployment Jobs

To cancel a configuration deployment job:

1. Select the job in the table.
2. Click **Cancel Job**.
3. Click **Yes** in the confirmation window that opens.

SEE ALSO

[Deploying Configuration to Devices | 808](#)
[Managing Device Configuration Files | 844](#)

Deploy Configuration Window

The Deploy Configuration window shows the results of a completed deployment job or information about a scheduled job. See [Table 100 on page 824](#) for a description of the fields in this window.

Table 100: Deploy Configuration Window

Field	Description
Job Name	Job name.
Job Start Time	Time when job started or will start.
Job End Time	Time when job ended.
Percentage Completed	Percentage of the job that is complete.
Number of Devices	Number of devices in the deployment job.
Deployed Devices table	
Name	Device name.
IP Address	Device IP address.
Deployment Status	Status of configuration deployment on device: <ul style="list-style-type: none"> • Scheduled—Job is scheduled for future deployment. • In Progress—Deployment is in progress. • Success—Deployment completed successfully. • Failed—Deployment failed.
Configuration	Click View to see the configuration changes that were deployed to the device. For a scheduled job, this column does not contain a link. See “Deploying Services Configuration to Devices” on page 1083 for information about viewing pending configuration changes for a device.
Result Details	Click View to see the results of configuration deployment for the device.
Close	Click to close the window.

RELATED DOCUMENTATION

Approving Change Requests

NOTE: This option is available only for the users who are assigned a Configuration Approver role.

When you select the Approve Change Request option, the page Change request(s) pending approval and the page approved/declined change request(s) open in the top and bottom panels respectively.

The [Table 101 on page 825](#) shows details of the change requests that are pending for approval by the approver.

Table 101: Change request(s) pending approval

Table Column	Description
Change Request No	Indicates the change request number that was either approved or rejected by the approver.
Title	Indicates the title of the change request.
Created By	Indicates the operator name who created the change request and submitted it for approval.
Created On	Indicates the date on which the change request was created.
Age	Indicates the age of the change request, time since the change request was created.
Deployment Status	Indicates the deployment state of the change request.
History Icon	Records the audit trail details of a change request, such as operation performed on a change request during a given period of time, username of the operator, and so on.

The [Table 102 on page 826](#) shows the change requests that were approved or rejected by the currently logged in approver. The approver can also provide comments

Table 102: approved/declined change request(s)

Table Column	Description
Change Request No	Indicates the change request number that was either approved or rejected by the approver.
Title	Indicates the title of the change request.
Created By	Indicates the operator name who created the change request and submitted it for approval.
Created On	Indicates the date on which the change request was created.
Age	Indicates the age of the change request, time since the change request was created.
Approval Status	Indicates the approval state of the change request.
Deployment Status	Indicates the deployment state of the change request.
History Icon	Records the audit trail details of a change request, such as operation performed on a change request during a given period of time, username of the approver, and so on.

To approve or reject the change requests submitted by an operator:

1. Select **Approve Change Requests** under Configuration Deployment.
2. Select the check box against the change request and click on a change request in the change request(s) pending approval page.
The Change Request Details page opens.
3. Review details of the profile and its associations.
4. Click on the **View** link.
The Pending Configuration device name page opens.
5. Click **Close**.
6. Click **Approve** or **Reject** to approve or reject the device configuration changes respectively.

The Change Request Details page opens.

7. Type your comments and click **Approve** to approve; else click **Reject**.

After the successful approval, you can deploy the device configurations immediately or schedule the deployment for a later period.

RELATED DOCUMENTATION

[Managing Configuration Deployment Jobs | 821](#)

[Deploying Configuration to Devices | 808](#)

Enabling SNMP Categories and Setting Trap Destinations

IN THIS SECTION

- [Viewing Eligible Devices for Trap Forwarding | 828](#)
- [Enabling Trap Forwarding | 829](#)
- [Deploying SNMP Trap Configurations | 829](#)

SNMP traps must be enabled on network devices for Connectivity Services Director to collect and manage event and error information from these devices.

Connectivity Services Director organizes switch and controller traps by categories. These categories must be enabled and deployed in order to forward trap information to Connectivity Services Director.

NOTE: Connectivity Services Director uses protocol port 10162 for receiving traps from devices. This port must be open on the devices.

This topic describes:

Viewing Eligible Devices for Trap Forwarding

Traps are enabled on the Devices page in Deploy mode. To locate this page:

1. Select **Deploy** in the Connectivity Services Director banner.
2. Select **Set SNMP Trap Configuration** in the Tasks pane. The Devices page opens. For a description of fields in the Devices page, view [Table 103 on page 828](#).

Table 103: Device Page Fields

Field	Description
Name	Either the hostname or the IP address of the device.
IP Address	Device IP address.
Model	Device model number.
OS Version	Version and release level of the operating system running on the device.
Connection State	<p>State of connection to the device. Valid states are:</p> <ul style="list-style-type: none"> • Up—Connectivity Services Director is in communication with the device. • Down—Connectivity Services Director cannot communicate with the device. You cannot enable traps on devices that are in this state.
Configuration State	<p>Either the device's configuration is in sync or out-of-sync with Connectivity Services Director's version:</p> <ul style="list-style-type: none"> • IN_SYNC—The configuration is in-sync with the database. • OUT_OF_SYNC—The configuration is out-of-sync with the database.

Enabling Trap Forwarding

Select **Set SNMP Trap Configuration** in Deploy mode to enable your network devices to pass SNMP traps and events to Connectivity Services Director. Connectivity Services Director creates a target group called *networkdirector_trap_group* using target port 10162. The Community name is *public* and the access is *read-write-notify*.

Before enabling trap forwarding, complete device discovery for all the devices and ensure they are in the up state. Down devices cannot be enabled for trap forwarding.

Selecting Set SNMP Trap Configuration displays the Devices page which contains a table of all discovered switches and controllers in the network. To enable SNMP traps on switches and controllers:

1. Either select individual check boxes for devices, or select the check box next to the Name heading to select all devices. These devices must be up and in the same device family.
2. Click **Deploy Trap Configuration**. The Deploy Options window opens.
3. Fill in a new deployment job name or accept the default name of Deploy SNMP Targets.
4. Either select check boxes for individual traps, or select the check box next to the Trap Name heading to select all traps. These traps are discussed further in [“Deploying SNMP Trap Configurations” on page 829](#).

TIP: To clear an existing configuration, do not select any of the check boxes.

5. Click **Ok**. The Deploy Configuration window opens, which shows the status of deploying the configuration change.
6. Review the outcome of the deployment.

After enabling the traps, enable the alarms and establish the alarm retention period. These tasks are located in Preferences in the Connectivity Services Director banner.

Deploying SNMP Trap Configurations

The Deploy Options for trap forwarding enable you to select individual traps or all traps for the selected device family.

The device family determines which traps are displayed in the Deploy Options window. The following tables map the trap to one or more MIBs being used.

- EX Series switches traps and related MIBs are shown in [Table 104 on page 830](#).
- Controllers traps and related MIBs are shown in [Table 105 on page 830](#).

Table 104: EX Series Switches Traps

Trap	MIB
Chassis	jnxExMibRoot.mib
Link	snmpTraps.mib
Configuration	jnxCfgMgmt.mib
Authentication	jnxJsAuth.mib
Remote operations	jnxPing.mib
Routing	jnx-ipv6.mib
Startup	snmpTraps.mib
Rmon-alarm	jnxRmon.mib
Vrrp-events	rfc2787a.mib
Services	jnxServices.mib
Sonet-alarms	jnx-sonetaps.mib
Otn-alarms	jnxMIbs.mib

Table 105: Controllers Traps

Trap	MIB
LinkDown	snmpTraps.mib
LlinkUp	snmpTraps.mib
Authentication	snmpTraps.mib
DeviceFail	trpzTrapsV2.mib
DeviceOkay	trpzTrapsV2.mib

Table 105: Controllers Traps (continued)

Trap	MIB
PoEFail	trpzTrapsV2.mib
MobilityDomainJoin	trpzTrapsV2.mib
MobilityDomainTimeout	trpzTrapsV2.mib
RFDetectAdhocUser	trpzTrapsV2.mib
ClientAuthenticationFailure	trpzTrapsV2.mib
ClientAuthorizationFailure	trpzTrapsV2.mib
ClientAssociationFailure	trpzTrapsV2.mib
ClientDeAssociation	trpzTrapsV2.mib
ClientRoaming	trpzTrapsV2.mib
AutoTuneRadioPowerChange	trpzTrapsV2.mib
AutoTuneRadioChannelChange	trpzTrapsV2.mib
CounterMeasureStart	trpzTrapsV2.mib
CounterMeasureStop	trpzTrapsV2.mib
ClientDot1xFailure	trpzTrapsV2.mib
RFDetectDoS	trpzTrapsV2.mib
RFDetectDoSPort	trpzTrapsV2.mib
ClientIpAddrChange	trpzTrapsV2.mib
ClientAssociationSuccess	trpzTrapsV2.mib
ClientAuthenticationSuccess	trpzTrapsV2.mib
ClientDeAuthentication	trpzTrapsV2.mib
RFDetectBlacklisted	trpzTrapsV2.mib

Table 105: Controllers Traps (continued)

Trap	MIB
RFDetectAdhocUserDisappear	trpzTrapsV2.mib
ApRejectLicenseExceeded	trpzTrapsV2.mib
ClientDynAuthorChangeSuccess	trpzTrapsV2.mib
ClientDynAuthorChangeFailure	trpzTrapsV2.mib
ClientDisconnect	trpzTrapsV2.mib
MobilityDomainFailOver	trpzTrapsV2.mib
MobilityDomainFailBack	trpzTrapsV2.mib
RFDetectRogueDeviceDisappear	trpzTrapsV2.mib
RFDetectSuspectDeviceDisappear	trpzTrapsV2.mib
RFDetectedClientViaRogueWiredAP	trpzTrapsV2.mib
RFDetectedClassificationChange	trpzTrapsV2.mib
ConfigurationSaved	trpzTrapsV2.mib
APNonOperStatus	trpzTrapsV2.mib
MichaelMICFailure	trpzTrapsV2.mib
ApManagerChange	trpzTrapsV2.mib
ClientCleared	trpzTrapsV2.mib
MobilityDomainResiliencyStatus	trpzTrapsV2.mib
ApOperRadioStatus	trpzTrapsV2.mib
ClientAuthorizationSuccess	trpzTrapsV2.mib
RFDetectRogueDevice	trpzTrapsV2.mib
RFDetectSuspectDevice	trpzTrapsV2.mib

Table 105: Controllers Traps (continued)

Trap	MIB
ClusterFailure	trpzTrapsV2.mib
MultimediaCallFailure	trpzTrapsV2.mib
ApTunnelLimitExceeded	trpzTrapsV2.mib
WsTunnelLimitExceeded	trpzTrapsV2.mib
RFNoiseSource	trpzTrapsV2.mib
M2UConvNotPossibleTrap	trpzTrapsV2.mib
M2UConvAvailabilityRestored	trpzTrapsV2.mib

SEE ALSO

[Deploying Configuration to Devices | 808](#)

[Managing Configuration Deployment Jobs | 821](#)

Understanding Resynchronization of Device Configuration

IN THIS SECTION

- [The Resynchronize Device Configuration Task | 834](#)
- [How Resynchronization Works in NSOR Mode | 835](#)
- [How Resynchronization Works in SSOR Mode | 837](#)
- [How Connectivity Services Director Resynchronizes the Build Mode Configuration | 839](#)

In a network managed by Connectivity Services Director, three separate repositories about device configuration are maintained:

- The configuration information on the devices themselves. Each device maintains its own configuration record.
- The configuration information maintained by the Junos Space Network Management Platform. When a device is discovered, either by Junos Space or Connectivity Services Director, Junos Space stores a record of the configuration on that device.

Connectivity Services Director uses the configuration record maintained by Junos Space to determine what configuration commands need to be sent to the device when you deploy configuration on the device in Deploy mode.

- The configuration information maintained by Connectivity Services Director in Build mode. This information takes the form of the profiles assigned to the device, plus the additional configuration, such as LAG and access point configuration, that you can do under device management.

In Connectivity Services Director, the configuration state of a device is shown as In Sync when the configuration information in all three repositories match. If there is a conflict between the configuration information in one or more of the repositories, Connectivity Services Director shows the device configuration state as Out of Sync.

An Out of Sync state is usually the result of out-of-band configuration changes—that is, configuration changes made to a device using a management tool other than Connectivity Services Director. Examples of such changes include changes made by:

- Using the device CLI.
- Using the device Web-based management interface (the J-Web interface or Web View).
- Using the Junos Space Network Management Platform configuration editor.
- Using RingMaster software.
- Restoring or replacing device configuration files.

You cannot deploy configuration on a device when the device configuration state is Out of Sync.

This topic describes how Connectivity Services Director enables you to resynchronize the device configuration state. It covers:

The Resynchronize Device Configuration Task

Connectivity Services Director provides a task in Deploy mode that enables you to resynchronize the repositories of configuration information. When an out-of-band configuration change is made, you can use this task to resynchronize both the Junos Space configuration record and the Build mode configuration with the configuration on the device.

How Connectivity Services Director performs resynchronization depends on the system of record (SOR) mode set for the Junos Space Network Management Platform. There are two possible modes:

- Network as system of record (NSOR). This is the default mode.
- Junos Space as system of record (SSOR).

You set the mode in Junos Space under Administration > Applications > Network Management Platform > Modify Application Settings.

How Resynchronization Works in NSOR Mode

In NSOR mode, the network device is considered the system of record for device configuration, which means the configuration maintained by the device takes precedence over the configuration maintained by Junos Space and Connectivity Services Director. Thus when you perform a resynchronization, the Junos Space configuration record and the Connectivity Services Director Build mode configuration are updated to match the device configuration.

When an out-of-band change is made on a managed device when Junos Space is in NSOR mode:

1. Junos Space detects that a configuration change has occurred on the device and informs Connectivity Services Director about the change.
2. Both Junos Space and Connectivity Services Director set the device configuration state to Out of Sync.
3. Junos Space and Connectivity Services Director automatically resynchronizes its configuration record to match the device configuration and sets the device configuration state to In Sync when the synchronization completes. Connectivity Services Director performs auto-synchronization when it is operating in the Network as System Of Record (NSOR) mode. The auto-resynchronization parameters are defined in the Preferences page. These parameters enables auto-resynchronization after the interval specified in this page. For more information see, *Setting Up User and System Preferences*.
4. When the device out-of-band changes does not conflict with Connectivity Services Director, Connectivity Services Director automatically resynchronizes the network changes and retains the local changes in Connectivity Services Directory. The configuration state of the device and the profile associated with that device remains unaffected. For example, if you modify the MTU value of the port ge-0/0/1 in Connectivity Services Director and another user modifies the MTU value of port ge-0/0/2 on the same device, Connectivity Services Director automatically resynchronizes the changes on ge-0/0/2 into Connectivity Services Director and retains the local changes on ge-0/0/1. The profile corresponding to ge-0/0/1 continues to remain in Pending Deployment state and the profile corresponding to port ge-0/0/2 is in Deployed state.
5. When the device out-of-band changes conflict with the changes made in Connectivity Services Director, Connectivity Services Director does not automatically resynchronize the device changes into Connectivity

Services Director. The device is marked as Out Of Sync, and you must manually resynchronize the changes by using the Resynchronize Configuration task. After this, the local changes are discarded and are replaced by the latest network configuration. For example, if you modify MTU of ge-0/0/1 from Connectivity Services Director and another user modifies MTU of the same port on the device, Connectivity Services Director does not automatically synchronize and marks this device as Out Of Sync.

6. When a profile associated with a device is either added or removed from that device while another user tries to change the attributes corresponding to that profile, Connectivity Services Director does not automatically synchronize the device and marks the device as Out Of Sync, and you must manually resynchronize the changes by using the Resynchronize Configuration task.

7. When you make local changes to profiles, the changes are merged with the new profiles if there is no conflicting configuration. If there are conflicting changes, Connectivity Services Director receives an Out Of Sync message from Junos Space and you need to manually choose the appropriate profile value.

When you do not make any local changes on a profile, the device association with the profile is deleted and a new device association is created. However, when a profile has local changes, the device association of the profile is not deleted.

8. If the configuration change does not affect configuration that you can perform in Build mode (for example, routing configuration), Connectivity Services Director also sets the device configuration state to In Sync after the Junos Space resynchronization completes. All three configuration repositories are now in sync.

If the configuration change affects configuration that you can perform in Build mode, Connectivity Services Director does not set the device configuration state to In Sync. Instead, it continues to show the device configuration state as Out of Sync because the Build mode configuration does not match the device configuration.

9. To resolve the Out of Sync state in Connectivity Services Director, use the Resynchronize Device Configuration task in Deploy mode. Connectivity Services Director updates the Build mode configuration to match the out-of-band changes.

10. Connectivity Services Director sets the device configuration state to In Sync.

NOTE: Automatic resynchronization, as described in Step 3 above, is a default setting for the Junos Space Network Management Platform. If automatic resynchronization is disabled, you must manually resynchronize the Junos Space configuration with the device configuration. You can do so in two ways:

- Use the Resynchronize with Network action in Junos Space. The Junos Space configuration is synchronized with the device configuration. However, the Build mode configuration is not synchronized, so the device state in Connectivity Services Director remains Out of Sync. You must use the Resynchronize Device Configuration task in Deploy mode to resynchronize the Build mode configuration.
- Use the Resynchronize Device Configuration task in Deploy mode. In this case, Connectivity Services Director resynchronizes both the Junos Space configuration and the Build mode configuration with the device configuration.

How Resynchronization Works in SSOR Mode

When Junos Space is in SSOR mode, Junos Space is considered the system of record for device configuration. In this mode, when an out-of-band configuration change occurs on a device, you can choose whether to accept the change or to overwrite the change with the configuration maintained by Junos Space.

When an out-of-band change is made on a managed device when Junos Space is in SSOR mode:

1. Junos Space detects that a configuration change has occurred on the device and informs Connectivity Services Director about the change.
2. Junos Space sets the device configuration state as Device Changed, and Connectivity Services Director sets the device configuration state to Out of Sync.

Connectivity Services Director sets the device configuration state to Out of Sync even if the configuration change does not affect configuration you can perform in Build mode. This allows you to resolve the Device Changed configuration state for Junos Space from Connectivity Services Director.

3. In Connectivity Services Director, use the Resynchronize Device Configuration task to accept or reject the out-of-band changes:
 - If you accept the out-of-band changes, both the Junos Space configuration record and the Connectivity Services Director Build mode configuration are resynchronized to reflect the out-of-band configuration changes.

- If you reject the out-of-band changes, the configuration on the device is overwritten by the configuration record maintained by Junos Space. The Connectivity Services Director Build mode configuration remains unchanged.

4. Both Junos Space and Connectivity Services Director set the device configuration state to In Sync.

The above process differs somewhat when out-of-band configuration changes are made through the Junos Space configuration editor. In this case:

1. Junos Space sets the device configuration state as Space Changed after the configuration change is saved.

At this point, the changes have been made only in the Junos Space configuration record and the changes have not yet been deployed to the device. Connectivity Services Director shows the device configuration state as In Sync.

NOTE: Because the device configuration state is In Sync in Connectivity Services Director, you can deploy configuration on the device from Connectivity Services Director at this point. If you do so, the Connectivity Services Director changes are deployed on the device, but the Junos Space changes are not. The device state in Junos Space remains Space Changed.

2. When the changes are deployed to the device from Junos Space, Junos Space changes the device state to In Sync, while Connectivity Services Director changes the device state to Out of Sync.
3. In Connectivity Services Director, use the Resynchronize Device Configuration task to resolve the Out of Sync state. In this case, because the Junos Space configuration record and the device configuration are in sync, you cannot reject the changes. When you resynchronize the device in Connectivity Services Director, the Build mode configuration is updated to reflect the configuration changes.
4. Connectivity Services Director sets the device configuration state to In Sync.

If you use Junos Space instead of Connectivity Services Director to resolve out-of-band configuration changes in SSOR mode, note the following:

- If you reject an out-of-band change, the device state becomes In Sync in both Connectivity Services Director and Junos Space.
- If you accept an out-of-band change that does not affect the Build mode configuration, the device state becomes In Sync in both Connectivity Services Director and Junos Space.
- If you accept an out-of-band change that affects the Build mode configuration, the device state becomes In Sync in Junos Space but remains Out Of Sync in Connectivity Services Director. You must use the Resynchronize Device Configuration task to resolve the Out of Sync state.

NOTE: When Junos Space is in SSOR mode, we recommend that you do not make out-of-band changes to the cluster configuration on the secondary seeds and member controllers of a mobility domain, such as disabling the cluster on these devices. Use Connectivity Services Director to modify the cluster configuration on these devices.

How Connectivity Services Director Resynchronizes the Build Mode Configuration

When you use the Resynchronize Device Configuration task to resynchronize the Build mode configuration to the device configuration, Connectivity Services Director launches a resynchronization job. This job deletes all profile assignments configured for the device. The profiles themselves are not deleted—just the assignments of the profiles to the device are deleted. It then reimports the device configuration, as if the device were a newly discovered device. It reassigns existing profiles and creates new profiles as necessary. Profiles that were originally assigned to the device will be reassigned to the device if the profiles were unaffected by the out-of-band changes. All profiles assigned to the device are in a deployed state at the end of the process. Any profile that is not reassigned to the device and is not assigned to any other device will be in a unassigned state.

RELATED DOCUMENTATION

| [Resynchronizing Device Configuration](#) | 839

Resynchronizing Device Configuration

IN THIS SECTION

- [The Resynchronize Device Configuration List of Devices](#) | 840
- [Resynchronizing Devices When Junos Space Is in NSOR Mode](#) | 842
- [Resynchronizing Devices When Junos Space Is in SSOR Mode](#) | 842
- [Resynchronizing Devices in Manual Approval Mode](#) | 843
- [Viewing the Network Changes](#) | 843
- [Viewing Resynchronization Job Status](#) | 844

A network managed by Connectivity Services Director has three repositories of information about the configuration of a network device—the configuration stored on the device itself, the device configuration record maintained by Junos Space, and the Build mode configuration maintained by Connectivity Services Director.

When the configuration contained in all three repositories match, the device configuration state is shown as In Sync in Connectivity Services Director. When the repositories do not match, the configuration state is shown as Out of Sync. A common cause for this state is out-of-band configuration changes—that is, configuration changes made to a device outside of Connectivity Services Director.

When a device state is Out of Sync, you cannot deploy configuration changes on the device in Deploy mode. Use the Resynchronize Device Configuration task to resynchronize the three configuration repositories and change the device configuration state back to In Sync.

How the Resynchronize Device Configuration task performs the resynchronization depends on the system of record (SOR) mode setting for the Junos Space Network Management Platform:

- When Junos Space is in network as system of record (NSOR) mode, the device is considered the system of record for configuration. When you resynchronize a device when Junos Space is in NSOR mode, both the Junos Space configuration record and the Connectivity Services Director Build mode configuration are updated to reflect the device configuration—in other words, the out-of-band configuration changes are incorporated into both the Junos Space and the Connectivity Services Director configuration repositories.
- When Junos Space is in Junos Space as system of record (SSOR) mode, you can choose whether accept or reject the out-of-band changes reflected in the device configuration. If you accept the changes, both the Junos Space configuration record and the Connectivity Services Director Build mode configuration are updated to reflect the device configuration. If you reject the changes, the out-of-band changes are rolled back on the device so that the device configuration matches the Junos Space configuration record and the Connectivity Services Director Build mode configuration.

For more information about out-of-band configuration changes, Junos Space SOR modes, and how Connectivity Services Director resynchronizes device configuration, see *Understanding Resynchronization of Device Configuration*.

This topic covers:

The Resynchronize Device Configuration List of Devices

The Resynchronize Device Configuration page displays a list of all devices in the selected scope whose configuration was successfully imported during device discovery and whose configuration state is now Out Of Sync. You can select devices from this list and resynchronize them.

[Table 106 on page 841](#) describes the fields in the list of devices.

Table 106: Resynchronize Device Configuration Fields

Field	Description
Name	Device hostname or device IP address.
IP address	IP address of device.
Model	Model number of the device.
OS Version	Operating system version currently running on the device.
Connection State	<p>Connection state:</p> <ul style="list-style-type: none"> • UP—Connectivity Services Director is connected to the device • DOWN—Connectivity Services Director cannot connect to the device
Configuration State	<p>Shows the configuration state of the device:</p> <ul style="list-style-type: none"> • Out Of Sync—The device configuration is out of sync with either the Connectivity Services Director Build mode configuration or the Junos Space configuration record or both. • Resynchronizing—The device configuration is in the process of being resynchronized. • Sync Failed—The resynchronization attempt failed. <p>If the resynchronization is successful, the device is removed from the table.</p>
Local Changes	<p>Specifies whether configuration changes have been made in Build mode and are pending deployment on the device.</p> <ul style="list-style-type: none"> • None—There are no configuration changes pending deployment. • View—There are configuration changes that are pending deployment. Click View to view the changes. These changes will be lost if you resynchronize the Build mode configuration to match the device configuration. <p>NOTE: The Pending Changes window that appears when you click View allows you to see what profiles have been added, modified, or changed. However, because the device is not in sync, you cannot view the specific changes in CLI or XML format.</p>
Network Changes	<p>Indicates whether you can view the out-of-band changes:</p> <ul style="list-style-type: none"> • None—The out-of-band changes are not available for viewing. You cannot view out-of-band changes in NSOR mode. In SSOR mode, you cannot view the out-of-band changes if they are already resolved in Junos Space—that is, the device configuration state in Junos Space is In Sync. • View—You can view the out-of-band changes made on the device. Click View to view the changes presented in XML format.

Resynchronizing Devices When Junos Space Is in NSOR Mode

To resynchronize devices when the Junos Space Network Application Platform is in NSOR mode:

1. On the Resynchronization Device Configuration page, select the device or devices that you want to resynchronize.
2. (Optional) View any pending changes to a device's configuration in Connectivity Services Director by clicking **View** in the Local Changes column. These pending changes are deleted when you resynchronize the device.
3. Click **Resynchronize Configuration**.

The Resynchronize Device Configuration Results window appears. This window will be updated with status of the resynchronization when the resynchronization completes.

Resynchronizing Devices When Junos Space Is in SSOR Mode

To resynchronize devices when the Junos Space Network Management Platform is in SSOR mode:

1. On the Resynchronization Device Configuration page, select the device or devices that you want to resynchronize.
2. (Optional) View any pending changes to a device's configuration in Connectivity Services Director by clicking **View** in the Local Changes column. These pending changes are deleted if you accept the out-of-band changes when you resynchronize the device.
3. (Optional) View the out-of-band configuration changes by selecting **View** in the Network Changes column. If you accept the out-of-band changes when you resynchronize the device, these changes will be reflected in the Build mode configuration. If you reject the out-of-band changes when you resynchronize the devices, these changes will be deleted from the device. For more information about viewing the out-of-band changes, see ["Viewing the Network Changes" on page 843](#).

NOTE: Out-of-band changes that were made with the Junos Space configuration editor or that were already accepted in Junos Space are not shown. Such changes also cannot be rejected.

4. Click **Resynchronize Configuration**.
5. In the Confirm dialog box:

- Click **Accept device changes** if you want to accept the out-of-band changes.
- Click **Reject device changes** if you want to reject the out-of-band changes and have the configuration that existed on the device before the out-of-band changes were made be reinstated.

click **Submit**.

The Resynchronize Device Configuration Results window appears. This window will be updated with status of the resynchronization when the resynchronization completes.

NOTE: Device changes made by the Junos Space configuration editor or device changes that have been accepted in Junos Space cannot be rejected. Even if you select Reject device changes, these changes will not be rejected and instead will be incorporated into the Build mode configuration.

Resynchronizing Devices in Manual Approval Mode

When out-of-band changes exist, device resynchronization merges the changes done by using the CLI with the local changes provided that there are no conflicts. If there are conflicting changes, the changes made using the CLI take precedence over the local changes. Therefore, configuration changes that are part of a change request might be lost. The configuration change requests that are lost are marked as Cancelled against the corresponding device. When device resynchronization is initiated for a device, a message is displayed that lists the change requests that will be lost because of conflicting CLI and local changes. All other changes remain unaffected.

Viewing the Network Changes

The Network Changes window shows the out-of-band configuration changes made to a device when Junos Space is in SSOR mode.

Not all out-of-band configuration changes are shown in this window. Configuration changes are shown only when the device configuration differs from the Junos Space configuration record—that is, when the device configuration state in Junos Space is not In Sync. For example, if the out-of-band changes were deployed from the Junos Space configuration editor or if the out-of-band changes were already accepted in Junos Space, the configuration changes will not appear in this window.

The configuration changes are shown in XML format. If there have been multiple out-of-band changes—that is, there has been more than one configuration commit, or save, on the device—the changes are grouped by each commit.

The following information is provided for each configuration commit:

- `junos:commit-seconds`—Specifies the time when the configuration was committed as the number of seconds since midnight on 1 January 1970.
- `junos:commit-localtime`—Specifies the time when the configuration was committed as the date and time in the device's local time zone.
- `xmlns:junos`—Specifies the URL for the DTD that defines the XML namespace for the tag elements.
- `junos:commit-user`—Specifies the username of the user who requested the commit operation.

Viewing Resynchronization Job Status

The Resynchronize Device Configuration Results window appears after you start a resynchronization job. This window is automatically updated with the resynchronization status for each device when the job completes.

You can also view the status of the resynchronization jobs using the Manage Jobs task in System mode. The following jobs are associated with resynchronization:

- **Resynch Network Elements**—This job runs in NSOR mode and resynchronizes the Junos Space configuration record with the device configuration.
- **Resolve OOB Changes**—This job runs in SSOR mode and resolves the out-of-band changes for Junos Space—either accepting the changes and updating the Junos Space configuration or rejecting the changes and rolling back the changes on the device.
- **Resynchronize devices**—This job runs in both NSOR and SSOR mode and resynchronizes the Build mode configuration with the device configuration.

SEE ALSO

[Understanding Resynchronization of Device Configuration](#) | 833

Managing Device Configuration Files

You can back up device configuration files to the Connectivity Services Director server. You can perform several actions on backed up configuration files, such as restoring configuration files to devices, and viewing and comparing configuration files.

To start managing device configuration files:

1. Click **Deploy** in the Connectivity Services Director banner.

2. In the Tasks pane, select **Device Configuration Files > Manage Device Configuration Files**.

The Manage Device Configuration page opens in the main window. The table lists the devices that have configuration files backed up.

This topic describes:

- [Selecting Device Configuration File Management Options | 845](#)
- [Backing Up Device Configuration Files | 846](#)
- [Restoring Device Configuration Files | 846](#)
- [Viewing Device Configuration Files | 847](#)
- [Comparing Device Configuration Files | 847](#)
- [Deleting Device Configuration Files | 848](#)
- [Managing Device Configuration File Management Jobs | 848](#)

Selecting Device Configuration File Management Options

From the Manage Device Configuration page, you can:

- Back up device configuration files by clicking Backup. See [“Backing Up Device Configuration Files” on page 846](#) for more information.
- Restore backup device configuration files to devices by selecting devices and clicking Restore. See [“Restoring Device Configuration Files” on page 846](#) for more information.
- View backed up configuration files by selecting a device and clicking View Configuration File. See [“Viewing Device Configuration Files” on page 847](#) for more information.
- Compare backed up device configuration files by selecting devices and clicking Compare Config Files. See [“Comparing Device Configuration Files” on page 847](#) for more information.
- Delete backup device configuration files by selecting devices and clicking Delete. See [“Deleting Device Configuration Files” on page 848](#) for more information.

[Table 107 on page 845](#) describes the information provided in the Manage Device Configuration table.

Table 107: Manage Device Configuration Table

Table Column	Description
Device Name	Device name.
Config File Version	Version number of the backup configuration file.
First Backup on	Date when the oldest version of the backup configuration file was created.

Table 107: Manage Device Configuration Table (*continued*)

Table Column	Description
Most Recent Backup on	Date when the configuration file was backed up most recently.

Backing Up Device Configuration Files

To back up device configuration files:

1. Click **Backup**.

The Backup Devices Configuration page opens in the main window.

2. Select the devices to back up from the device tree.

3. To back up configuration files immediately, click **Backup Now**.

The backup job runs. When it finishes, the Manage Device Configuration table shows updated information for the devices you backed up.

4. To schedule the backup to run later, click **Schedule Backup**.

The Schedule Backup window opens.

- a. Select the **Schedule at a later time** check box.

- b. Specify when the backup will run using the **Date and Time** fields.

- c. Optionally, configure the backup job to repeat by selecting the **Repeat** check box, then specifying the backup schedule using the provided fields.

Optionally, you can specify when repeated backups will stop by selecting the **End Time** check box, then specifying the last date on which the repeated backup job will run using the **Date and Time** fields.

- d. Click **Schedule Backup**.

Restoring Device Configuration Files

You can restore a backed up configuration file to the device from which it was backed up.



CAUTION: Restoring a configuration file to a device is considered an out-of-band configuration change, which can cause some unexpected results. For more information, see [“Out-of-Band Configuration Changes” on page 183](#).

To restore backed up configuration files to devices:

1. Select the devices to restore from the Manage Device Configuration list.

2. Click **Restore**.

The Restore Device Configuration File(s) window opens.

3. To restore a configuration file that is older than the most recent version, click in the **Latest Version** cell and select the version to restore.

4. Click **Restore**.

Viewing Device Configuration Files

To view the backed up configuration files for a device:

1. Select the device from the Manage Device Configuration list.

2. Click **View Configuration File**.

The Device Configuration Summary window opens, displaying the most recently backed up configuration file.

3. To view an older stored configuration file version, select a version number from the **Config File Version** list.

Comparing Device Configuration Files

To compare backed up device configuration files:

1. Select the configuration files to compare from the Manage Device Configuration list.

2. Click **Compare Configuration Files**.

The Compare Configuration Files window opens.

3. Select a source device from the **Source Device** list and a configuration file version from the **Config File Version** list.
4. Select a target device from the **Target Device** list and a configuration file version from the **Config File Version** list.
5. The configuration file versions you selected are displayed in the window. The file name and version appears at the top of each file. The differences between the configuration files are color-coded. The color-coding legend appears at the top of the window.

Deleting Device Configuration Files

When you delete a device's backed up configuration, all of the configuration file versions for the device are deleted.

To delete device configuration files:

1. Select the configuration files to delete from the Manage Device Configuration list.
2. Click **Delete**.

The Delete Device Configuration File(s) window opens.

3. Verify that the correct devices are listed, then click **Delete**.

Managing Device Configuration File Management Jobs

Each time you back up or restore device configuration files, a device configuration file management job is created.

To manage device configuration file management jobs:

1. Click **Deploy** in the Connectivity Services Director banner.
2. In the Tasks pane, select **Device Configuration Files > View Configuration File Mgmt Jobs**.

The Device Configuration Jobs page opens in the main window, listing the device configuration file management jobs.

Managing these jobs is similar to managing other types of jobs using the System mode. The advantage of accessing the jobs this way is that the jobs list show only configuration file management jobs. See [“Managing Jobs” on page 122](#) for more information.

SEE ALSO

[Managing Configuration Deployment Jobs | 821](#)

[Deploying Configuration to Devices | 808](#)

Enabling or Disabling Network Ports on Routers

Network ports connect Routers to the network and carry network traffic. You can enable or disable network ports of Routers that are part of your network. When you enable or disable a port, the administrative status of the port changes to UP or DOWN respectively. When you disable a port, the system marks that port as administratively down, without removing the port configurations.

You can enable or disable one or more ports at a time using the Manage Port Admin State page. The status of the port is indicated by the Admin State and the Link State fields. The administrative status of a port is indicated by the Admin State field.

To enable or disable a network interface:

1. Do one of the following:

- In the topology view, locate the device for which you want to enable or disable ports and click **Device Management > Manage Port Admin State** from the Tasks pane.
- While in the Deploy mode, select the device for which you want to enable or disable ports in the View pane and click **Device Management > Manage Port Admin State** from the Tasks pane.

The Manage Port Admin State page appears displaying all the physical ports available on the selected device and the current status of each port. This page also displays the port mode of each interface, if any. Port mode can be access, tagged-access, or trunk mode.

2. Do one of the following:

- Select the check box adjacent to the ports that you want to enable and click **Change Admin State UP**.
- Select the check box adjacent to the interfaces that you want to disable and click **Change Admin State DOWN**.

3. Click **Done**. Connectivity Services Director changes the administrative status of the ports and displays a confirmation message confirming the changes.

RELATED DOCUMENTATION

[Deploying Configuration to Devices | 808](#)

Deploying and Managing Software Images

IN THIS CHAPTER

- [Managing Software Images | 851](#)
- [Deploying Software Images | 854](#)
- [Managing Software Image Deployment Jobs | 858](#)

Managing Software Images

This topic describes how to manage software images for managed devices.

To start managing software images:

1. Click **Deploy** in the Connectivity Services Director banner.
2. In the Tasks pane, select **Image Management > Manage Image Repository**.

The Device Image Repository page opens in the main window. The table lists the software images in the repository.

3. In the Tasks pane, select **Device Configuration File Management > Manage Device Configuration**.

The Manage Device Configuration page opens in the main window. The table lists the devices that have configuration files backed up software images in the repository.

This topic describes:

- [Selecting Software Image Management Options | 852](#)
- [Adding Software Images to the Repository | 852](#)
- [Using the Device Image Upload Window | 853](#)
- [Viewing Software Image Details | 853](#)
- [Using the Device Image Summary Window | 853](#)
- [Deleting Software Images | 854](#)

Selecting Software Image Management Options

From the Device Image Repository page, you can:

- Add a software image to the repository by clicking Add.
- View details about a software image by selecting it and clicking Details.
- Delete software images from the repository by selecting them and clicking Delete.

[Table 108 on page 852](#) describes the information provided in the Device Image Repository table.

Table 108: Device Image Repository Table

Table Column	Description
Check box	Select to perform an action on the software image in that row.
Name	Software image name.
Version	Software version.
Series	Device series that uses the software image.
Uploaded By	User who uploaded the software image.
Created On	Time when the software image was uploaded to the server.
Size(MB)	Size of the software image in megabytes.

Adding Software Images to the Repository

Software images are stored in a repository on the Connectivity Services Director server.

To add a software image to the repository:

1. Click **Add**.
The Device Image Upload window opens.
2. Use the Device Image Upload window to upload a device software image. See [“Using the Device Image Upload Window” on page 853](#) for a description of the window.

Using the Device Image Upload Window

To use the Device Image Upload window to add a software image to the repository:

- 1. Click **Browse** and browse to the software image file.
- 2. Click **Upload** to add the file to the repository.

Viewing Software Image Details

To view details about a software image:

- 1. Select the software image file in the table.
- 2. Click **Details**.

The Device Image Summary window opens. See [“Using the Device Image Summary Window” on page 853](#) for information about this window.

Using the Device Image Summary Window

Use the Device Image Summary window to view detailed information about a software image. [Table 109 on page 853](#) describes the fields in this window.

Table 109: Device Image Summary Window

Field	Description
Name	Software image filename.
Version	Software version (release number).
Series	Device series on which the software is supported.
Supported Platforms	Platforms on which the software is supported.
Uploaded By	User who uploaded the image to the server.
Created On	Date and time when the software image was uploaded.
Size (MB)	Size of the software image file, in megabytes.
OK	Click to close the window.

Deleting Software Images

To delete software image files:

1. Select the check box in the rows of the software image files that you want to delete.
2. Click **Delete**.

SEE ALSO

[Managing Software Image Deployment Jobs | 858](#)

[Deploying Software Images | 854](#)

Deploying Software Images

This topic describes how to deploy software images to managed devices. You must upload software images to the Connectivity Services Director server before you can deploy them to devices. See [“Managing Software Images” on page 851](#) for more information.

To start deploying software images:

1. Click **Deploy** in the Connectivity Services Director banner.
2. Select a node in the View pane that contains the devices to which you want to deploy software images.
3. In the Tasks pane, select **Image Management > Deploy Images to Devices**.

The Select Devices page of the Deploy Images to Devices wizard opens in the main window.

This topic describes:

- [Specifying Software Deployment Job Options | 855](#)
- [Selecting Software Images To Deploy | 855](#)
- [Selecting Options for Software Deployment | 856](#)
- [Summary of Software Deployment | 858](#)

Specifying Software Deployment Job Options

To specify software deployment job options in the Select Devices page:

1. In the Job name field, enter a job name.
2. From the Device and deployment options list, select an option:
 - Select **Staging only (Download image to the device)** to download the software image to the device but not install it.
 - Select **Upgrade only (Install previously staged image on device)** to upgrade the device to a software image that was previously staged on the device.
 - Select **Staging and Upgrade (Download and Install image on device)** to download the software image and install it on the device.

Devices are not automatically rebooted after upgrade to make the device begin running the new software version. You can select the option to reboot the device automatically after the upgrade in a later wizard page.

3. Click **Next** to continue to the next page.

The Select Images page opens. Select a software image as described in [“Selecting Software Images To Deploy” on page 855](#).

Selecting Software Images To Deploy

The Select Images page includes a table listing each device group and device that you selected for deployment. See [Table 110 on page 856](#) for a description of the table columns.

If you selected the Upgrade only (Install previously staged image on device) option, only devices that contain a previously staged software image appear in the table. You cannot select a different image to install on these devices.

To select the software images to deploy, perform the following steps on the table row for each device group or individual device that you want to upgrade:

1. In the Proposed Image Version/Profile column, click **Select Image/Profile**.


The Select Image/Profile list is displayed.

2. From the Select Image/Profile list, select a software image.

TIP: To clear this field, select **Select Image/Profile** from the list.

3. After you finish selecting software images, click **Next** to continue to the next page.

The Select Options page opens.



TIP: A pop-up message notifies you if you do not select a software image for all the listed devices. This is just for your information. No action will be taken on devices for which you do not select a software image. In effect, this removes those devices from the job.

Select options for software deployment as described in [“Selecting Options for Software Deployment” on page 856](#).

Table 110: Select images for devices Table

Table Column	Description
Device Family	Device family to which the device belongs. Devices are grouped by family. To display the devices within a device family, click the arrow next to the device family name.
Count	Number of devices contained within a device family.
IP Address	Device's IP address.
Device Name	Device's name.
State	Device's state: <ul style="list-style-type: none"> • UP—Connectivity Services Director can communicate with the device. • DOWN—Connectivity Services Director cannot communicate with the device.
Running Image Version	Software version the device is running.
Proposed Image Version/Profile	Software version that will be installed on the device when the job runs successfully.

Selecting Options for Software Deployment

The options that you can configure in the Select Options page are described in [Table 111 on page 857](#). The options that are available depend on the job flow you chose in the Select Images page.

After you finish selecting options, click **Next** to continue to the next page. The Summary page opens. Review the job summary as described in [“Summary of Software Deployment” on page 858](#).

Table 111: Image Management Job Options

Option	Action
Select Options	
All Device Types	
Delete any existing image before download	Select to delete any existing software images on devices before downloading the new software image.
Reboot device after successful installation	<p>Select to reboot the device after the software image is installed. A reboot is required to begin running the new software version on the device.</p> <p>NOTE: This option may get disabled based on your details that you specify in the remaining fields. This indicates that for the options that you specified, the system will automatically reboot the device as per the requirement during or after the image upgrade.</p>
Wired Devices	
Check compatibility with current configuration	Select to validate the software package or bundle against the current configuration as a prerequisite to adding the software package or bundle.
ISSU/NSSU	<p>Select if you want to perform a Nonstop software upgrade (NSSU) or lin-service software upgrade (ISSU).</p> <p>ISSU enables you to upgrade between two different Junos OS releases with minimal disruption on the control plane and with minimal disruption of traffic.</p> <p>NSSU enables you to upgrade the software running on an MX Series router with redundant Routing Engines or on most MX Series Virtual Chassis configuration by using a single command and with minimal disruption to network traffic</p>
Archive data (Snapshot)	Select to take an archive snapshot of the files currently used to run the switch and copy them to an external USB storage device connected to the switch.
Copy to alternate slice	<p>Select to copy the new Junos OS image into the alternate root partition. This ensures that the resilient dual-root partitions feature operates correctly.</p> <p>This option is available only if you select Reboot device after successful installation.</p>
Select Schedule	
Stage now	Select Stage now to start staging software images to devices as soon as the job runs.
Stage later time	Select Stage later time to schedule the staging for a later time.

Table 111: Image Management Job Options *(continued)*

Option	Action
Staging Schedule	If you selected Stage later time, enter the date and time for staging to start.
Upgrade now	Select Upgrade now to start upgrading software images on devices as soon as staging finishes.
Upgrade later time	Select Upgrade later time to schedule the software upgrade for a later time.
Deployment Schedule	<p>If you selected Upgrade later time, enter the date and time for upgrade to start.</p> <p>If you scheduled staging, you must schedule the upgrade for at least 10 minutes after staging, to ensure that staging completes before upgrade starts.</p>

Summary of Software Deployment

On the Summary page, review the selections you made for the job. To change selections, click **Edit** in the area that you want to change. You can also click the boxes in the process flowchart above the wizard page to navigate between pages. When you are done making selections, click **Finish** on the Summary page to save the job, and run it if you configured the job to run immediately.

RELATED DOCUMENTATION

[Managing Software Image Deployment Jobs | 858](#)

[Managing Software Images | 851](#)

Managing Software Image Deployment Jobs

This topic describes how to manage software image jobs. A software image job is created each time you deploy software images to devices or schedule a software image deployment. You can check the status of jobs, see job details, and cancel scheduled jobs.

To start managing software image jobs:

1. Click **Deploy** in the Connectivity Services Director banner.
2. In the Tasks pane, select **Image Management > View Image Deployment Jobs**.

The Image Deployment Jobs page opens in the main window.

This topic describes:

- [Selecting Software Image Management Options | 859](#)
- [Viewing Software Image Job Details | 860](#)
- [Using the Device Image Staging Window | 860](#)
- [Canceling Software Image Jobs | 861](#)

Selecting Software Image Management Options

From the Image Deployment Jobs page, you can:

- Show deployment job details by selecting a job and clicking Show Details. See [“Viewing Software Image Job Details” on page 860](#) for more information.
- Cancel a pending job by selecting the job and clicking Cancel Job. See [“Canceling Software Image Jobs” on page 861](#) for more information.

[Table 112 on page 859](#) describes the information provided in the of the Image Deployment Jobs table.

Table 112: Image Deployment Jobs Table

Table Column	Description
Job Id	An identifier assigned to the job.
Check box	Select to perform an action on the job in that row.
Job Name	Job name.
Percent	Percentage of the job that is complete.
Status	<p>Job status. The possible states are:</p> <ul style="list-style-type: none"> ● CANCELLED—The job was cancelled by a user. ● SCHEDULED—The job is scheduled but has not run yet. ● INPROGRESS—The job is running. ● SUCCESS—The job completed successfully. This state is applied if all of the devices in the job completed successfully. ● FAILURE—The job failed. This state is applied if any of the devices in the job failed. But some of the devices might have completed successfully. View the job details for the status of each device.
Summary	Job summary.
Scheduled Start Time	Job’s scheduled start time.

Table 112: Image Deployment Jobs Table (*continued*)

Table Column	Description
Actual Start Time	Time when the job started.
End Time	Time when the job ended.
User	User who created the job.
Recurrence	This field is not used for software image management jobs.

Viewing Software Image Job Details

To view the details of a software image job:

1. Select the job in the table.
2. Click **Show Details**.

The Device Image Staging window opens. See [“Using the Device Image Staging Window” on page 860](#) for a description of the window.

Using the Device Image Staging Window

Use the Device Image Staging window to view information about software image jobs. [Table 113 on page 860](#) describes this window.

Table 113: Device Image Staging Window Description

Field	Description
Job Name	Job name.
Start Time	Job's scheduled start time.
End Time	Time when the job ended.
% Complete	Percentage of the job that is complete.

Table 113: Device Image Staging Window Description (*continued*)

Field	Description
Status	<p>Job status. The possible statuses are:</p> <ul style="list-style-type: none"> • CANCELLED—The job was cancelled by a user. • SCHEDULED—The job is scheduled but has not run yet. • INPROGRESS—The job is running. • SUCCESS—The job completed successfully. • FAILURE—The job failed.
Host Name	Host name of device.
Status	<p>Device status. The possible statuses are:</p> <ul style="list-style-type: none"> • INPROGRESS—The job is running. • SUCCESS—The job completed successfully. • FAILURE—The job failed.
% Complete	Percentage of the job that is complete on the device.
Start Time	Time when the job started on the device.
End Time	Time when the job ended on the device.
Description	Description of the job on the device. Can include error messages for failed devices.
Close	Click to close the window.

Canceling Software Image Jobs

To cancel a software image job:

1. Select the job in the table.
2. Click **Cancel**.

SEE ALSO

[Deploying Software Images | 854](#)

[Managing Software Images | 851](#)

10

PART

Service Provisioning: Working with Service Orders

Service Provisioning: Viewing the Configured Services and Service Orders | **863**

Service Provisioning: Managing E-Line Service Orders | **876**

Service Provisioning: Managing E-LAN Service Orders | **943**

Service Provisioning: Managing IP Service Orders | **993**

Service Provisioning: Performing RFC 2544 Benchmark Testing | **1060**

Service Provisioning: Viewing the Configured Services and Service Orders

IN THIS CHAPTER

- [Viewing Service Orders | 863](#)
- [Viewing Service Order and Service Details | 865](#)
- [Viewing Services | 869](#)
- [Viewing the Configured E-Line, IP, and E-LAN Services | 871](#)
- [Viewing the Configuration Details of VPN Services | 874](#)

Viewing Service Orders

The following topic describes how you can view service orders.

- [Viewing Service Orders in a Table | 863](#)

Viewing Service Orders in a Table

To view and determine the status of service orders in a tabular form:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the Network Services > Connectivity tree and select the type of service.
4. In the Network Services > Connectivity view pane, select **Service Provisioning > Deploy Services**.
The Manage Service Deployment page is displayed in the lower half of the window.

Manage Service Orders							
Deploy Now Schedule Deploy View Pending Configuration Action Modify							
<input type="checkbox"/>	Name	Customer	State	Service Type	Signaling	Latest Job	Created Date
<input type="checkbox"/>	VPLS_LDP_451_audit_2015-09...	test	Completed	VPLS	LDP	622651	September 3, 20...
<input type="checkbox"/>	VPLS_LDP_451	test	Completed	VPLS	LDP	622647 ALL	September 3, 20... super

Page 1 of 1

Displaying 1 - 2 of 2 | Show 3 items

A table of service orders on the system appears in the main display area. The following fields are displayed on this page:

- Name—Unique name assigned to the service.
- Customer—Name of the customer for which the service is provided.
- State:
 - Completed—Service order has been successfully deployed.
 - Failed—Device is down or the Connectivity Services Director application was unable to push the service configuration to a device configured for the service.
 - In-progress—Connectivity Services Director application is in the process of deploying the service.
 - Invalid—Service order contains invalid data.
 - Requested—Service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
 - Scheduled—Service provisioner has scheduled the service order for deployment.
- Service Type:
 - E-Line pseudowire (LDP)
 - E-Line pseudowire (BGP)
 - E-LAN (MultiPoint-to-MultiPoint)
 - E-LAN (Point-to-MultiPoint)
 - IP (Full Mesh)
 - IP (Hub-Spoke 1 Interface)
- Latest Job—Unique identifier assigned by the system for a deployment job. Click the link in the job ID to open the CSD Deployment Jobs. The table on that page lists configuration deployment jobs.
- Signaling Type:
 - BGP
 - LDP

- **Created By**—The screen name of the user who created the service order
- **Created Date**—The date and when you created the service order.

From this page, you can create a service order, modify the properties of the service order, conduct a functional or configuration audit, deploy or deactivate the service order, and view alarms associated with a particular service order for debugging and corrective action.

5. To view details of a specific service order, double-click the table row that summarizes the service order.

RELATED DOCUMENTATION

[Viewing Service Order and Service Details | 865](#)

[Modifying a Saved Service Order | 1184](#)

[Viewing Services | 869](#)

Viewing Service Order and Service Details

In your network environment, it might be necessary to quickly view the list of deployed services for different protocols that you have defined, such as IP or E-Line, and obtain a high-level, comprehensive view of the different parameters defined for a service order. Based on the currently defined service attributes, you can modify them accordingly to suit your deployment needs. The service orders associated with customers that are shown also enable you to view the customer information and update the user-related details for a service order. The details for the service selected are displayed in a popup window such as the general settings, PE devices, UNI settings, the mapped service definition, and the corresponding service customer details. All the values shown in the details view are read-only fields.

You can launch the Service Detail window in two ways— by double-clicking a service order from the Manage Services page in Deploy Mode of Service View, and by selecting a service from the View pane and selecting Manage Services > View Details from the task pane in Deploy Mode of Service View to display detailed information for deployed services.

To view the consolidated details of a service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Select **IP Services** to manage IP service orders.
 - Select **E-Line Services** to manage E-Line service orders.
 - Select **E-LAN Services** to create and manage E-LAN service orders.

Alternatively, you can drill-down the tree of each of the services, such as E-LAN or IP services, to view the previously configured service orders and modify their attributes.

5. From the task pane, which is the middle pane in the window, select **Manage Services > View Details**. The Service Details window is displayed. The service details are grouped into various sections and only the applicable attributes are displayed for the selected service, based on the service type.

Alternatively, select **Deploy Services** from the task pane, and from the Manage Network Services window, select a service. The corresponding service order details are displayed in the Manage Service Orders window at the bottom of the right pane. Double-click a service order to view the service order details.

The Service Details window is divided into three sections—Basic Details, Advanced Details, and Endpoint Details. The service tree contains the service name as the root node. The device node is the child of the service node and it contains the provisioned UNIs as the child nodes. The details panel in the Endpoint Details table displays configuration parameters and their corresponding values for the service in the tree and based on the service type.

Under the Basic Details section, the general details about the node details are shown. Also, the device configuration parameters are displayed. Under the Advanced Details section, which you can open or close by clicking the View Less or View More toggle links, the advanced connectivity settings between sites in the service provider network are shown, such as route distinguisher and VRF route label details. Under the Endpoint Details table, the configuration parameters of the UNI are displayed. The right pane displays the details corresponding to the node or element you selected on the left pane.

Under the Device Details section, the service details displayed on the right pane are organized under the following sections:

Basic Details

This section is applicable for all types of services and displays the following details.

- Name—Name of the selected service
- Customer—Name of the customer associated with the service.
- Service Definition—Name of the service definition that is used to create the service.
- Service Order—Unique identifier assigned by the system to denote the service order.

- Service Type—Selected service type, such as E-Line, IP, or E-LAN
- State—State of the selected service. Possible values are:

NOTE: These states apply only for a service and not a service order

- Active—Denotes a service that has been deployed and is in an active state (enabled).
 - Inactive—Denotes a service that has been deployed and is in a deactivated state (disabled).
 - Pending—Denotes a service for which deployment of the service to a device is pending to be performed.
 - Deploy—An attempt to modify the service failed.
- State—State of the selected service order. Possible values are:

NOTE: These states apply only for a service order and not a service.

- Completed—Service order has been successfully deployed.
 - Deploy failed—Device is down or the Connectivity Services Director application was unable to push the service configuration to a device configured for the service.
 - In-progress—Connectivity Services Director application is in the process of deploying the service.
 - Requested—Service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
 - Scheduled—Service provisioner has scheduled the service order for deployment.
 - Invalid—Service order contains invalid data.
 - Validated—When all the information in the service order is successfully validated, the service order transitions to the Validated state.
- Last Updated Date—Date and time at which the service was last modified.
 - Functional Audit Status—Status of the functional audit for the selected service
 - Configuration Audit Status—Status of the configuration audit for the selected service
 - Fault Status—Fault status of the audit performed for the selected service
 - SLA Status—SLA status of the audit performed for the selected service.

Advanced Details

This section displays the advanced, fine-grained connectivity settings between sites, such as the configured route distinguisher, VRF route label. The parameters displayed under this section are similar to the advanced parameters displayed in the wizard for service order creation.

Endpoint Details

A tabular view is displayed of the configured device and UNI Details that are part for the service. Each row in the table displays the basic, salient parameters, such as Device Name, Interface Name, Unit ID, Encapsulation and Description. You can use the paging controls to navigate across multiple pages of endpoints as necessary. A minimum of 20 endpoints per page are displayed.

The following fields are displayed in the End Points table:

- **End Point**—Name of the device configured as the source or origin (A) endpoint and the destination or target (Z) endpoint. This field is displayed for E-Line services. Click the plus sign beside the device name for E-Line services to expand the device-related parameters and view the detailed settings.
- **Device Name**—Name of the device for which the service is created. Click the plus sign beside the device name for E-LAN and IP services to expand the device-related parameters and view the detailed settings.
- **Interface**—Name of the physical interface associated with the service.
- **Tagging**—Type of packet tagging for the interface, such as Ethernet, dot1Q, or Q-in-Q.
- **UnitId**—Logical unit identifier of the interface.
- **VlanId**—VLAN identifier of the interface.
- **Is Hub**—Indicates whether the node is a hub or a spoke.
- **Template**—Name of the service template that is used to create the service order.
- **CoS Profiles**—Name of the COS profile associated with the service.

Device Details

Click the plus sign beside the device name shown under the Endpoint (for E-Line services) or Device Name (for E-LAN or IP services) row of the table. The configured parameters on the device for the service are expanded and displayed after selecting a device in the navigation tree. The parameters to be shown are based on the service type. The parameters displayed under this section are similar to the node parameters and UNI parameters displayed in the wizard for service order creation, such as route distinguisher, MVPN status of the service (shown only for MVPN-enabled L3VPN services), and MC-LAG status of the service (shown only for the MCLAG-enabled L3VPN services).

RELATED DOCUMENTATION

[Viewing Service Orders | 863](#)

[Modifying a Saved Service Order | 1184](#)

[Viewing Services | 869](#)

Viewing Services

The following topic describes how to view services:

- [Viewing Services in a Table | 869](#)

Viewing Services in a Table

To view the services inventory in a table:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Connectivity Services Director user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**.

In the top half of the window on the right pane, the Manage Network Services page presents information on existing services in a table.

The **Manage Network Services** page provides the following information about each service:

[Table 114 on page 869](#) describes the fields in the service orders table.

Table 114: Fields in the Services Table

Field	Description
Name	Name of the service order assigned during service creation or edit.

Table 114: Fields in the Services Table (*continued*)

Field	Description
Service Type	One of the following: <ul style="list-style-type: none"> • E-Line pseudowire (LDP) • E-Line pseudowire (BGP) • E-LAN (MultiPoint-to-MultiPoint) • E-LAN (Point-to-MultiPoint) • IP (Full Mesh) • IP (Hub-Spoke 1 Interface)
Customer	Name of the enterprise customer who placed an order for the service.
Deployment State	State of the service: <ul style="list-style-type: none"> • Active—Denotes a service that has been deployed and is in an active state (enabled). • Inactive—Denotes a service that has been deployed and is in a deactivated state (disabled). • Pending—Denotes a service for which deployment of the service to a device is pending to be performed. • Failed—An attempt to modify the service failed.
FA Status	Status of functional audit of the service.
Fault Status	Fault management status of the service.
PM Status	Performance management status of the service.
Definition	Name of the service definition upon which the service order is based.
Activation Date	Date and time at which the service order was last activated.
Last Modified Time	Date and time at which the profile was last updated.

6. To restrict the display of services, enter a search criterion of one or more characters in the search bar and press Enter. All services that match the search criterion are shown in the main display area.
7. To view details of a specific service, double-click the table row that summarizes the service.

For an E-LAN service (point-to-multipoint or multipoint-to-multipoint), a table of service details appears.

8. Select the check box beside a service to launch the Manage Service Orders page in the lower half of the pane. The service orders associated with the selected service are displayed. You can perform different actions, such as validating or discarding configuration.

SEE ALSO

[Viewing Service Orders | 863](#)

[Viewing Service Order and Service Details | 865](#)

RELATED DOCUMENTATION

[Understanding Service Validation | 1142](#)

[Managing Jobs | 122](#)

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

[Validating the Pending Configuration of a Service Order | 1096](#)

[Viewing the Configuration of a Pending Service Order | 1098](#)

Viewing the Configured E-Line, IP, and E-LAN Services

To view the services inventory in a table:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Build** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.

- Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. With the Connectivity item selected in the View pane, from the **Network Services > Connectivity** task pane, select **Service Provisioning > View Services**.

The View Network Services page is divided into two panes. The top pane provides a pictorial representation of the types of services, statuses of services, and audit-related information.

In the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

In the View pane, if you do not expand the Network Services tree, and select the Network Services node in the View pane, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number of services corresponding to the percentage of service types. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information.

The View Network Services page provides the following information about each service in the bottom pane:

[Table 114 on page 869](#) describes the fields in the View Network Services table.

Table 115: Fields in the Services Table

Field	Description
Name	Name of the service order assigned during service creation or edit.

Table 115: Fields in the Services Table (*continued*)

Field	Description
Service Type	One of the following: <ul style="list-style-type: none"> • E-Line pseudowire (LDP) • E-Line pseudowire (BGP) • E-LAN (MultiPoint-to-MultiPoint) • E-LAN (Point-to-MultiPoint) • IP (Full Mesh) • IP (Hub-Spoke 1 Interface)
Customer	Name of the enterprise customer who placed an order for the service.
Deployment State	State of the service: <ul style="list-style-type: none"> • Active—Denotes a service that has been deployed and is in an active state (enabled). • Inactive—Denotes a service that has been deployed and is in a deactivated state (disabled). • Pending—Denotes a service for which deployment of the service to a device is pending to be performed. • Failed—An attempt to modify the service failed.
FA Status	Status of functional audit of the service.
Fault Status	Fault management status of the service.
PM Status	Performance management status of the service.
Definition	Name of the service definition upon which the service order is based.
Activation Date	Date and time at which the service order was last activated.
Last Modified Time	Date and time at which the profile was last updated.

- To restrict the display of services, enter a search criterion of one or more characters in the search bar and press Enter. All services that match the search criterion are shown in the main display area.
- To view details of a specific service, double-click the table row that summarizes the service.
For an E-LAN service (point-to-multipoint or multipoint-to-multipoint), a table of service details appears.

RELATED DOCUMENTATION

[Viewing Service Orders | 863](#)

[Viewing Service Order and Service Details | 865](#)

Viewing the Configuration Details of VPN Services

You can view the configuration of an E-Line, IP, or E-LAN service, which enables you to see the parameters and attributes configured for a service on the associated devices in the form of configuration statements and commands that are displayed in the Junos OS CLI interface. You can use these settings to examine the existing service configuration and modify it as necessary to correct any traffic-handling problems or system discrepancies.

To view the configuration of services:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Network Services page is displayed on the top part of the right pane.
5. Select the check box next to a service for which you want to view the configuration details.
6. Click the **View Configuration** option. The Service Configuration View dialog box is displayed. The configuration is displayed in the CLI interface structure and in the form of configuration stanzas.

The left pane displays a tree of devices associated with the specified service. You can select a Service-name > Device-name in the left pane of the window to view the configuration parameters of the corresponding device on the right pane. The right pane contains two tabs— Service Configuration and Template Configuration. The Service Configuration tab displays the settings specified for the service on the device in CLI format. This tab displays the elements or components specified for a service template in the form of configuration stanzas and hierarchy levels. This display is similar to the show command that you can use at a certain [edit] hierarchy level to view the defined settings. The Template

Configuration tab displays the service attributes and options defined in the service template, if any, that is associated with the service.

7. Click **OK** to close the dialog box after you complete viewing the configuration attributes and settings.

RELATED DOCUMENTATION

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

[Validating the Pending Configuration of a Service Order | 1096](#)

Service Provisioning: Managing E-Line Service Orders

IN THIS CHAPTER

- [Creating a Service Order | 876](#)
- [Creating an E-Line ATM or TDM Pseudowire Service Order | 877](#)
- [Creating an E-Line Multisegment Pseudowire Service Order | 886](#)
- [Creating an E-Line Service Order | 895](#)
- [Creating a Bulk-Provisioning Service Order for Pseudowire Services | 909](#)
- [Creating an Inverse Multiplexing for ATM Service Order | 912](#)
- [Provisioning a Single-Ended E-Line Service | 916](#)
- [Selecting Specific LSPs for Connectivity Services | 918](#)
- [Stitching Two E-Line Pseudowires | 920](#)
- [Using Print Page | 922](#)
- [Deactivating a Service | 923](#)
- [Reactivating a Service | 925](#)
- [Force-Deploying a Service | 927](#)
- [Recovering a Service Definition through Force Upload | 930](#)
- [Decommissioning a Service | 931](#)
- [Viewing Alarms for a Service | 934](#)
- [Inline Editing of E-LAN and IP Service Orders | 935](#)
- [Interconnecting an IP Service with an E-LAN Service | 939](#)
- [Changing the Logical Loopback Interface for Provisioning | 941](#)

Creating a Service Order

A service order is an instance of the service definition that completes the definition for a specific customer's use. The service order always specifies the customer and the endpoints that link the customer sites through the MPLS network. For each endpoint, the service provisioner specifies the N-PE device and the UNI on that device that connects the customer site to the N-PE device. The service order can also specify any additional attributes that are configured in the service definition as editable in the service order. These

attributes might include the VCID, MTU for the UNI, MTU for the connection across the network, VLAN-ID, rate limiting bandwidth, and so forth.

RELATED DOCUMENTATION

[Creating an E-Line Service Order | 895](#)

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

Creating an E-Line ATM or TDM Pseudowire Service Order

To create an E-Line service order, complete the following tasks in order:

1. [Selecting the Service Definition | 877](#)
2. [Entering General/Connectivity Settings Information | 879](#)
3. [Specifying Endpoint Information | 881](#)
4. [Specifying Template Settings | 884](#)
5. [Reviewing the Configured Settings | 885](#)
6. [Deploying the New Service | 886](#)

Selecting the Service Definition

To select a service definition on which to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Connectivity Services Director user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. From the Tasks pane, select **Service Provisioning > Manage Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

From the **Manage Network Services** page, select **New > E-Line Service Order**.

The **Create E-Line Service Order** page displays an inventory of all available E-Line service definitions.

The **General/Connectivity Settings** panel appears initially in the right panel, as shown in the example.

NOTE: In the service order creation wizard for E-Line services, the search function has been enhanced to enable you to easily sort and filter the parameters that are of interest and relevance for the services you want to configure. The Choose Customer dialog box that is displayed when you click **Select** beside the Customer field contains the Search box, which enables you to perform a search on all of the columns. The search utility that is present in the Choose Service Definition dialog box that is displayed when you click **Select** beside the Service Definition field enables you to search by Name, Created by, and Signaling columns; search utility is not supported for other columns in the dialog box. The search box that is present in the Choose Endpoints dialog box when you click **Select** beside the PE Device and UNI Interface fields enables search across all the columns displayed in the dialog box. For any string-based search (which shows strings that match any part of the text you enter in the search box), only the Name, Platform, and OS Version columns are supported. For exact string-based search (which shows strings that exactly match the text you enter in the search box), the IPAddress, State, and Manage State columns are supported.

5. From the Service Definition field, click **Select** to choose the service definition you want to base your service order on. The Choose Service Definition inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

6. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.
7. Click **View** to open a popup dialog box that displays the details of the selected service definition. The service definition properties, such as the name, signaling type (LDP or BGP), service type (Ethernet, ATM, or TDM), are displayed. The interface-specific attributes, such as rate-limiting details, encapsulation, and VLAN tags, are also displayed in the dialog box. Close the dialog box to return to the service order creation wizard.

If a template is attached to the service definition on which the service order is based, you can invoke the template editor from the Template page of the wizard.

Entering General/Connectivity Settings Information

The **General Settings** panel is displayed on the right side of the service order window.

To configure general settings in the **General Settings/Connectivity Settings** panel, provide the following information:

1. In the **Name** box, enter a unique name for the service.

The service order name can consist of only letters, numbers, and underscores.

NOTE: The name you specify for a service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, “bgp” or “vpls”, as the name of a service order.

2. In the **Customer** box, select the customer requesting the service.

If the customer is not in the list, you must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

3. In the **Description** box, enter a description of the service. This description appears in information windows about the request or service instance created from the request.

4. In the **Connectivity Settings** box, specify the MTU for the connection across the network.

The service definition can constrain the MTU to a specific value or allow the service provisioner to override it in the service order. In this example, the service definition sets the MTU, but allows the service provisioner to change the value.

When you advance to the next step in creating your service order, your new connectivity settings appear under the Connectivity image in the main graphic and new general information is added to the text above the cloud. If you have incomplete or invalid information in the **General/Connectivity Settings** panel, a warning icon appears next to the cloud image.

5. Specify the virtual path identifier (VPI). This field is available only if you have selected an ATM E-Line service definition.

The combination of the VPI and VCID defines the next destination for a cell in the ATM network.

Range: 0 through 255

6. Specify the virtual channel identifier (VCI). This field is available only if you have selected an ATM E-Line service definition.

Range: 0 through 65535

7. Enter the virtual circuit identifier (VCID). This integer uniquely identifies the virtual circuit that the service uses.

The VCID can be set either automatically by the Junos Space software, or the service provisioner can set it manually in the service order. The service definition can force the system to pick the VCID, force the service provisioner to pick the VCID, or allow the service provisioner to override the settings in the service definition.

We recommend allocating the VCID automatically; however, service providers with their own systems for allocating VCIDs can choose the manual setting.

By default, the system picks a VCID from its pool automatically, but allows the service provisioner to override this value in the service order. The form expands to include an additional field for typing the VCID manually.

This field is displayed only if the selected definition's signaling type is **LDP**. You cannot edit this field if you have not selected the **Editable in Service Order** in the service definition.

8. Select the **MC APS** check box to add the **run show aps extensive** command.

NOTE: This check box is available only in an LDP-based E-Line service order with PW Resiliency enabled. The **Interface type** must be ATM/TDM.

For more information on MC-APS, see [“Multi-Chassis Automatic Protection Switching Overview” on page 104](#).

9. Enter the **Route Distinguisher** value.

Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295

This field is displayed only if the selected definition's signaling type is **BGP**. You cannot edit this field if you have not selected the **Editable in Service Order** in the service definition.

10. Specify the **Route Target**.

1. Clear the **Auto pick Route Target** check box.

2. Enter the **Route Target** value.

Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295

This field is displayed only if the selected definition's signaling type is **BGP**. You cannot edit this field if you have not selected the **Editable in Service Order** in the service definition.

11. Provide endpoint information for the first endpoint: click the **Endpoint A** graphic element or click **Next**.

The **Endpoint Settings** form appears in the right panel.

Specifying Endpoint Information

On M Series, MX Series, and ACX routers:

- The ATM interfaces always appear as an AT interface.
- The TDM interfaces with SAToP encapsulation always appear as a T1 interface; TDM interfaces with CESoPSN encapsulation always appear as a DS interfaces.

To configure the endpoint settings:

1. In the **PE Device** box, select the N-PE device you want to use for the first endpoint. From the Choose Endpoints dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices. The lower part of the dialog box refreshes to display the interfaces associated with the selected device. Select the check boxes next to the interfaces you want to associate with the service order.

NOTE: In the Choose Endpoints dialog box, you can sort and segregate the devices and their corresponding interfaces based on the roles of the devices to easily and quickly view only the devices of interest. Click the down arrow on the **Filter Role** menu, and select **P2E** to view only the provider edge devices, **P** to view only the provider devices, and **L2E** to view only Layer 2 Ethernet devices.

If you are unsure about which PE device to choose, go to the Prestaging Devices workspace landing page, which shows capacity information about UNIs on PE devices. You must pick a device that has available UNIs.

This step is required for all service orders.

2. In the **UNI interface** box, select a UNI. The list includes all UNIs available on the selected device.

You can enter the description of the UNI interface in the **UNI description** field.

If you have selected the **Enable Multi Segment Pseudowire** check box in the service definition, the **UNI interface** of the second endpoint lists the interworking (iw) interfaces only.

For more information on E-Line pseudowire stitching, see [“Stitching Two E-Line Pseudowires” on page 920](#).

This step is required for all service orders.

You cannot change the type of **Physical IF encapsulation**. This value is set in the service definition.

Based on the type of **Physical IF encapsulation**, the corresponding fields are displayed. For example, if the **Physical IF encapsulation** is CESoPSN, the following fields are displayed:

- **Jitter buffer**

- **Idle pattern**
- **Excessive packet loss rate**

NOTE: These fields are editable if you have selected the **Editable in Service Order** check box in the service definition.

3. Specify the stitching unit.

Default: 0

Range: 0 through 255

NOTE: This field is displayed only in the second endpoint. You must have selected the **Enable Multi Segment Pseudowire** check box in the service definition.

4. If the **Physical IF encapsulation** type is CESoPSN, specify the **Packetization Latency**. Packetization latency is the time required to create packets.

Range: 1000 through 8000 microseconds

NOTE: Based on the number of time slots, the default Packetization Latency value is as follows:

- If the number of time slots is equal to 1, the default value is either 5000 microseconds or 8000 microseconds.
- If the number of time slots is 2, 3, or 4, the default value is 4000 microseconds.
- If the number of time slots is greater than 4, the default value is 1000 microseconds.

5. In the **LSP tunnel name** box, select the LSP tunnel you want to use for this device.

You must supply an LSP tunnel name for the interface on BX devices. If one is not defined, you must first use the Transport Activate application to create an LSP on the BX7000 Gateway.

On the M Series router, the LSP tunnel is chosen automatically.

This field is displayed only if the selected definition's signaling type is **LDP**.

6. Specify the cell bundle size. The value of the cell bundle size can be from 1 through 34.

7. If you have selected **Transport VLAN List** as the customer traffic type in the selected service definition, you must specify either a single value or a range of values that are separated by commas.
8. If you have enabled the **Enable PW Resiliency** check box in the selected service definition, fill in the following fields in the Backup settings and Resiliency settings:

- **Enable**
- **PE device**
- **UNI interface**
- **MTU (Bytes)**
- **LSP tunnel name**
- **Revert time (sec)**
- **Switch Over Delay (sec)**

For more information of pseudowire redundancy, see [“Redundant Pseudowires for Layer 2 Circuits and VPLS” on page 98](#).

9. If you selected the **Static pseudowire** check box in the selected service definition, you need to specify the **Outgoing label** for the static pseudowire.

Range: 1000000 through 1048575

In case of multi-segment pseudowire, you have to specify a new outgoing label for the second segment. The outgoing label for the second segment is not prepopulated from the first segment.

NOTE: You must manually compare the encapsulation, TDM bit rate, and control word of the router with the remote peer router and ensure that these parameters match; otherwise the static pseudowire might not work.

10. Select the **Enable send-oam config** check box to enable the **send-oam** command. You can select or clear this check box even in the Modify Service page.
11. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order that you have created is listed in the Manage Service Orders page.

Specifying Template Settings

The Template Settings page of the service order creation and modification wizards enables you to associate service templates with an E-Line, E-LAN, and IP service order. You can apply only the templates that are previously configured in a service definition with the corresponding service order. The Template Settings page is available in the service order wizard only if the service definition that you selected to apply to the service order contains a service template. Otherwise, the Template Settings page is not displayed in the service order wizard. You can perform template operations for all endpoints in a service order.

If you defined a service template as the default service template, it is attached to the endpoint by default. You have the flexibility to create and provision a dynamic attribute in a service template. You can mark an attribute of a service template as dynamic, and you can obtain the values for these dynamic attributes from a specific device. To create a dynamic attribute, you must first mark an attribute of a service template as dynamic and then specify the device XPath for the dynamic attribute.

The Template Settings page is displayed before the Review page, which is the final step of the service order wizard.

In the Service Settings page, from the Select Service Definition field of the service order creation wizard, you can double-click a service definition name displayed in the table to view the details of the definition in a popup dialog box. You can use this information to determine if the service definition is appropriate for your deployment needs. To filter and sort the display of service templates, enter the name of the template as a match criterion in the Search box and click the Search icon. The page refreshes to display only the template names that match with the search term. You can use the paging controls to navigate across multiple pages of templates as necessary.

All the tasks that you can perform with service templates are presented in the Template Settings page. The page is divided into three panes. The top half of the page displays a table of selected endpoints. All the endpoints or UNIs that you selected in the preceding pages of the service order wizard are displayed in this table. You can configure the template pertaining to only one endpoint at a point in time. If the selected endpoints (in previous pages of the wizard) contained a manually-entered unit number, that number is displayed in the table of selected endpoints. Otherwise, the Auto-pick label is displayed.

The lower half of the page is divided into two panes. The left pane displays the template selection table for the endpoint you selected. All the templates associated with the service definition are displayed. You can add and delete templates using the template selection table. The right pane displays all the parameters that you can modify for a selected service template. All such editable parameters are displayed in a consolidated form of a configuration page. This pane is displayed after you select a template. If any configuration parameter in template is set as a service-specific value, such attributes are not displayed in this pane.

To associate a service template with a service order:

1. Click **Add** to include a service template for the endpoint. A dialog box is displayed with the list of service templates associated with the service definition that is used to create the service order. The templates selected in this dialog box are displayed in the Template Selection table for the specified endpoint. Such templates are considered to be attached to that endpoint.

If you specified a template as a default template during the service definition creation, the template is displayed by default in the template selection table. You can associate non-default templates with the service order by clicking the **Add** button.

2. Click the link in the template name to open the Template Details dialog box. The template settings are displayed in the popup dialog box. For the selected template, the Configuration Page is displayed in the lower-right pane of the Template Settings page.
3. Modify any template-specific service components as necessary.
4. Click **Save** to submit the changes.
5. Select a template from the Template Selection table, and click Delete to remove the template from being associated with the service order for a particular endpoint.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.

3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

Deploying the New Service

To deploy the new service:

1. Perform one of the following actions from the Deploy mode of the Service View of Connectivity Services Director:
 - To deploy the service immediately, select **Deploy now**, then click **OK**.
 - To deploy the service later, select **Schedule deployment**, select a date and time, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.
2. To monitor the progress and status of the deployment, use the Jobs workspace.

RELATED DOCUMENTATION

[Creating a Service Order | 876](#)

[Creating an E-Line Service Order | 895](#)

[Creating a Bulk-Provisioning Service Order for Pseudowire Services | 909](#)

[Creating an Inverse Multiplexing for ATM Service Order | 912](#)

[Provisioning a Single-Ended E-Line Service | 916](#)

[Selecting Specific LSPs for Connectivity Services | 918](#)

Creating an E-Line Multisegment Pseudowire Service Order

To create an E-Line service order for a multisegment pseudowire (MS-PW), complete the following tasks in order:

1. [Selecting the Service Definition | 887](#)
2. [Entering General/Connectivity Settings Information | 888](#)
3. [Specifying Endpoint A Information | 890](#)
4. [Specifying Endpoint Z Information | 892](#)

5. [Specifying Stitching Endpoint\(s\) Settings | 893](#)
6. [Reviewing the Configured Settings | 894](#)

Selecting the Service Definition

To select a service definition on which to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Connectivity Services Director user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionality that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. From the Tasks pane, select **Service Provisioning > Manage Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

From the **Manage Network Services** page, select **New > E-Line Service Order**.

The **Create E-Line Service Order** page displays an inventory of all available E-Line service definitions.

The **General/Connectivity Settings** panel appears initially in the right panel.

NOTE: In the service order creation wizard for E-Line services, the search function has been enhanced to enable you to easily sort and filter the parameters that are of interest and relevance for the services you want to configure. The Choose Customer dialog box that is displayed when you click Select beside the Customer field contains the Search box, which enables you to perform a search on all of the columns. The search utility that is present in the Choose Service Definition dialog box that is displayed when you click Select beside the Service Definition field enables you to search by Name, Created by, and Signaling columns; search utility is not supported for other columns in the dialog box. The search box that is present in the Choose Endpoints dialog box when you click Select beside the PE Device and UNI Interface fields enables search across all the columns displayed in the dialog box. For any string-based search (which shows strings that match any part of the text you enter in the search box), only the Name, Platform, and OS Version columns are supported. For exact string-based search (which shows strings that exactly match the text you enter in the search box), the IPAddress, State, and Manage State columns are supported.

5. From the Service Definition field, click **Select** to choose the service definition you want to base your service order on. The Choose Service Definition inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

6. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.
7. Click **View** to open a popup dialog box that displays the details of the selected service definition. The service definition properties, such as the name, signaling type (LDP or BGP), service type (Ethernet, ATM, or TDM), are displayed. The interface-specific attributes, such as rate-limiting details, encapsulation, and VLAN tags, are also displayed in the dialog box. Close the dialog box to return to the service order creation wizard.

If a template is attached to the service definition on which the service order is based, you can invoke the template editor from the Template page of the wizard.

Entering General/Connectivity Settings Information

The **General Settings** panel is displayed on the right side of the service order window.

To configure general settings in the **General Settings/Connectivity Settings** panel, provide the following information:

1. In the **Name** box, enter a unique name for the service.

The service order name can consist of only letters, numbers, and underscores.

NOTE: The name you specify for a service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, “bgp” or “vpls”, as the name of a service order.

2. (Optional) In the **Comments** box, enter a description of the service. This description appears in information windows about the request or service instance created from the request.
3. In the **Customer** box, select the customer requesting the service.

If the customer is not in the list, you must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

4. (Optional) Select the **LSP Association** check box to associate an existing LSP.

NOTE: The Enable LSP Association check box is not available on the General Settings page if the signaling type is LDP.

Select the **Create LSP** check box to import an existing LSP service definition and also select an LSP name pattern.

NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.

For information about creating an LSP name pattern, see [“Creating a Name Pattern for LSPs in the Service Order” on page 1794](#).

5. In the **Connectivity Settings** box, specify the MTU for the connection across the network.

The service definition can constrain the MTU to a specific value or allow the service provisioner to override it in the service order. In this example, the service definition sets the MTU, but allows the service provisioner to change the value.

When you advance to the next step in creating your service order, your new connectivity settings appear under the Connectivity image in the main graphic and new general information is added to the text above the cloud. If you have incomplete or invalid information in the **General/Connectivity Settings** panel, a warning icon appears next to the cloud image.

6. Enter the virtual circuit identifier (VCID). This integer uniquely identifies the virtual circuit that the service uses.

The VCID can be set either automatically by the Junos Space software by selecting **Auto Pick VC ID**, or the service provisioner can set it manually in the service order. The service definition can force the system to pick the VCID, force the service provisioner to pick the VCID, or allow the service provisioner to override the settings in the service definition.

We recommend allocating the VCID automatically; however, service providers with their own systems for allocating VCIDs can choose the manual setting.

By default, the system picks a VCID from its pool automatically, but allows the service provisioner to override this value in the service order. The form expands to include an additional field for typing the VCID manually.

This field is displayed only if the selected definition's signaling type is **LDP**. You cannot edit this field if you have not selected the **Editable in Service Order** in the service definition.

7. Select a CFM profile that you want to associate with the E-line MS-PW. The CFM profile is propagated to a single endpoint when multiple interfaces are selected for a given device (the last interface overrides the other configurations).
8. Provide endpoint information for the first endpoint: click the **Endpoint A Setting** graphic element or click **Next**.

The **Endpoint A Settings** form appears in the right panel.

Specifying Endpoint A Information

To configure endpoint A settings:

1. In the **Endpoint A** box, click **Select** to choose the N-PE device you want to use as Endpoint A. From the Choose Endpoints dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices. The lower part of the dialog box refreshes to display the interfaces associated with the selected device. Select the check boxes next to the interfaces you want to associate with the service order.

NOTE: In the Choose Endpoints dialog box, you can sort and segregate the devices and their corresponding interfaces based on the roles of the devices to easily and quickly view only the devices of interest. Click the down arrow on the **Filter Role** menu, and select **P2E** to view only the provider edge devices, **P** to view only the provider devices, and **L2E** to view only Layer 2 Ethernet devices.

If you are unsure about which PE device to choose, go to the Prestaging Devices workspace landing page, which shows capacity information about UNIs on PE devices. You must pick a device that has available UNIs.

This step is required for all service orders.

Based on the device selected, the rest of the fields such as **UNI Interface**, **Physical IF encapsulation**, **Logical IF encapsulation**, and **Traffic Type** on the Endpoint A Settings page are automatically populated.

2. If you have selected **Enable PW Resiliency** in the selected service definition, select a backup by clicking **Backup Settings A**. Provide required information for the **LSP Name**, **Revert time (sec)**, and **Switch Over Delay (sec)** fields.
3. Based on the type of **Physical IF encapsulation**, the corresponding fields are displayed. For example, if the **Physical IF encapsulation** is **vlan-ccc**, the following fields are displayed. Enter the required information.

NOTE: You cannot change the type of **Physical IF encapsulation** and the **Logical IF encapsulation**. These values are set in the service definition.

- **Unit ID**—Enter the logical unit identifier of the service.
- **VLAN ID**—Enter the VLAN identifier of the service.
- **LSP Name**—Select the LSP tunnel you want to use for this device. This field is displayed only if the selected definition's signaling type is **LDP**.
- **COS Profile**—Enter the name of the COS profile that you want to associate with the service.

NOTE: These fields are editable if you have selected the **Editable in Service Order** check box in the service definition.

4. Provide endpoint information for the second endpoint: click the **Endpoint Z Setting** graphic element or click **Next**.

The **Endpoint Z Settings** form appears in the right panel.

Specifying Endpoint Z Information

To configure endpoint Z settings:

1. In the **Endpoint Z** box, click **Select** to choose the N-PE device you want to use as Endpoint Z. From the Choose Endpoints dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices. The lower part of the dialog box refreshes to display the interfaces associated with the selected device. Select the check boxes next to the interfaces you want to associate with the service order.

NOTE: In the Choose Endpoints dialog box, you can sort and segregate the devices and their corresponding interfaces based on the roles of the devices to easily and quickly view only the devices of interest. Click the down arrow on the **Filter Role** menu, and select **P2E** to view only the provider edge devices, **P** to view only the provider devices, and **L2E** to view only Layer 2 Ethernet devices.

If you are unsure about which PE device to choose, go to the Prestaging Devices workspace landing page, which shows capacity information about UNIs on PE devices. You must pick a device that has available UNIs.

This step is required for all service orders.

Based on the device selected, the rest of the fields such as **UNI Interface**, **Physical IF encapsulation**, **Logical IF encapsulation**, and **Traffic Type** on the Endpoint A Settings page are automatically populated.

2. If you have selected **Enable PW Resiliency** in the selected service definition, select a backup by clicking **Backup Settings Z**. Provide required information for the **LSP Name**, **Revert time (sec)**, and **Switch Over Delay (sec)** fields.
3. Based on the type of **Physical IF encapsulation**, the corresponding fields are displayed. For example, if the **Physical IF encapsulation** is **vlan-ccc**, the following fields are displayed. Enter the required information.

NOTE: You cannot change the type of **Physical IF encapsulation** and the **Logical IF encapsulation**. These values are set in the service definition.

- **Unit ID**—Enter the logical unit identifier of the service.
- **VLAN ID**—Enter the VLAN identifier of the service.

- **LSP Name**—Select the LSP tunnel you want to use for this device. This field is displayed only if the selected definition's signaling type is **LDP**.
- **COS Profile**—Enter the name of the COS profile that you want to associate with the service.

NOTE: These fields are editable if you have selected the **Editable in Service Order** check box in the service definition.

4. In the service definition, if the following conditions are set, the next tab is **Stitching Endpoint(s) Setting**. Click **Stitching Endpoint(s) Setting** graphic element or click **Next** to stitch the MS-PW.
 - Signalling type is **BGP**,
 - **Enable Multi Segment Pseudowire** is selected, and
 - **Enable Auto Discovery for MS-PW** is not selected.
- In all other cases, the next tab is **Review**. Click **Review** graphic element or click **Next** to review your service order.

Specifying Stitching Endpoint(s) Settings

You can use the **Stitching Endpoint(s) Settings** tab to add segments between endpoint A and endpoint Z.

NOTE:

- This tab is only applicable for FEC 128.
- You can add a maximum 254 segments in one MS-PW.

To stitch the endpoints of the MS-PW:

1. The UNI Settings section displays the UNI settings that has been set in the service definition. You can update the UNI settings if you choose to do so.
2. The table displayed on the lower part of the page lists the devices that you have selected as endpoints A and Z. Endpoint A is displayed under **Source Device > Primary**. Endpoint B is displayed under **Destination Device > Device Name**. In the service definition, if the signalling type is **LDP** and **Enable PW Resiliency** option is selected, the backup device details that you provided for endpoint A is populated under **Source Device > Backup**. The backup device details that you provided for endpoint Z is populated in the last entry of the grid's destination device backup.

You can now select the segments that you want to configure between endpoint A and endpoint Z. To select segments:

1. In the row that displays the first primary device, click **Device Name** under **Destination Device**.

A pop-up screen appears displaying a list of devices that you can select.

2. Select a device that you want to add as a segment.

The selected device appears under **Destination Device > Device Name**. It will also appear under **Source Device > Primary**. So effectively this segment connects endpoint A to endpoint Z.

3. Select an interface for the segment by clicking **Interface** and selecting an interface from the pop-up screen that appears.

The selected interface appears under **Destination Device > Interface**.

NOTE: The segment can only have an It or iw interface.

4. (Optional) Select a backup for the segment by clicking **Destination Device - Backup > Device Name**.

A pop-up screen appears displaying a list of devices that you can select. Select a device that you want to add as a segment backup.

5. Enter values for **Unit** and **Peer Unit** for the segment under **Destination Device > Unit** and **Destination Device > Peer Unit** respectively.

NOTE: You have to configure the unit and peer unit only for segments, and not for the endpoints.

3. Click **Review** graphic element or click **Next** to review your service order.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

To review you service order:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Done** to save the service definition or service order.

A pop-up screen appears with the following options:

- **Save and Validate**—Click **Save and Validate** to save and validate the service order. If there are any errors during validation process, they are displayed on the screen. You can fix the errors and validate the service order again.
 - **Save and Deploy**—Click **Save and Deploy** to save and deploy the service order. If there are any errors during validation process, they are displayed on the screen. You can fix the errors and deploy the service order again.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

RELATED DOCUMENTATION

[Using Print Page | 922](#)

[Creating a Multisegment Pseudowire Service Definition | 682](#)

Creating an E-Line Service Order

To create an E-Line service order, complete the following tasks in order:

1. [Selecting the Service Type | 896](#)
2. [Entering General Settings Information | 897](#)
3. [Specifying the Connectivity | 898](#)
4. [Specifying QoS Settings | 900](#)
5. [Specifying CFM Settings | 901](#)
6. [Specifying Endpoint Information | 901](#)

7. [Specifying Template Settings | 906](#)
8. [Reviewing the Configured Settings | 907](#)
9. [Specifying Connectivity and Endpoint Information for Managing VLANs | 908](#)
10. [Deploying and Monitoring the Progress of the New Service | 908](#)

Selecting the Service Type

A wizard is available to create a service order in an intuitive and easily-navigable format. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create a Service Order page. Alternatively, you can proceed to the corresponding setting-related pages by clicking the **Back** and **Next** buttons at any point in the wizard during the creation of the service order.

To select the service type as E-Line to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. From the Tasks pane, select **Service Provisioning > Manage Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

5. From the **Manage Network Services** page, click the **New** icon at the top of the lower half of the page that displays previously created service orders. The Select Service Type dialog box appears.
6. Select **E-Line** to create an E-Line service order.

The General/Connectivity Settings panel appears initially in the right panel, as shown in the example.

NOTE: In the service order creation wizard for E-Line services, the search function has been enhanced to enable you to easily sort and filter the parameters that are of interest and relevance for the services you want to configure. The Choose Customer dialog box that is displayed when you click Select beside the Customer field contains the Search box, which enables you to perform a search on all of the columns. The search utility that is present in the Choose Service Definition dialog box that is displayed when you click Select beside the Service Definition field enables you to search by Name, Created by, and Signaling columns; search utility is not supported for other columns in the dialog box. The search box that is present in the Choose Endpoints dialog box when you click Select beside the PE Device and UNI Interface fields enables search across all the columns displayed in the dialog box. For any string-based search (which shows strings that match any part of the text you enter in the search box), only the Name, Platform, and OS Version columns are supported. For exact string-based search (which shows strings that exactly match the text you enter in the search box), the IPAddress, State, and Manage State columns are supported.

Entering General Settings Information

To enter general parameters related to a service order in the **General Settings** box of the General/Connectivity Settings page of the wizard:

1. In the **Name** field, enter a unique name for the service.

The service order name can consist of only letters, numbers, and underscores.

NOTE: The name you specify for an E-Line service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, "bgp" or "vpls", as the name of a service order.

2. From the Service Definition field, click **Select** to choose the service definition you want to base your service order on. The Choose Service Definition inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

3. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.

4. Click **View** to open a popup dialog box that displays the details of the selected service definition. The service definition properties, such as the name, signaling type (LDP or BGP), service type (Ethernet pseudowire, ATM, or TDM), are displayed. The interface-specific attributes, such as rate-limiting details, encapsulation, and VLAN tags, are also displayed in the dialog box. Close the dialog box to return to the service order creation wizard.

If a template is attached to the service definition on which the service order is based, you can invoke the template editor from the Template page of the wizard.

5. (Optional) Select the **Enable LSP Association** check box to create or associate LSPs.

Select the **Create LSP** check box to import an existing LSP service definition and also select an LSP name pattern.

NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.

For information about creating an LSP name pattern, see [“Creating a Name Pattern for LSPs in the Service Order” on page 1794](#).

Select the **Associate LSP** check box to associate an existing LSP.

NOTE: The Enable LSP Association check box is not available on the General Settings page if the signaling type is LDP.

6. In the **Customer** field, select the customer requesting the service.

If the customer is not in the list, you must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

7. In the **Description** field, enter a description of the service that you want to appear in the request or in a service instance created from the request.

This description is displayed in the Manage Service Order page.

8. Configure connectivity settings. See [“Specifying the Connectivity” on page 898](#).

Specifying the Connectivity

In the **Connectivity Settings** box of the General/Connectivity Settings page of the wizard, specify VCID and MTU information.

1. Specify the VCID. This is an integer that uniquely identifies the virtual circuit that the service will use.

The VCID can be either set automatically by the Junos Space software, or it can be set manually by the service provisioner in the service order. The service definition can force the system to pick the VCID, force the service provisioner to pick the VCID, or allow the service provisioner to override the settings in the service definition.

This field is displayed only if the selected definition's signaling type is **LDP**. You cannot edit this field if you have not selected **Editable in Service Order** in the service definition.

We recommend allocating the VCID automatically; however, service providers with their own systems for allocating VCIDs can choose the manual setting.

In the previous example, by default, the system picks a VCID from its pool automatically, but allows the service provisioner to override this value in the service order. Clear the check box to override the service definition setting. The form expands to include an additional field for entering the VCID manually.

2. Specify the MTU for the connection across the network.

The service definition can constrain the MTU to a specific value or allow the service provisioner to override it in the service order. In this example, the service definition sets the MTU, but allows the service provisioner to change the value.

When you advance to the next step in creating your service order, your new connectivity settings appear under the Connectivity image in the main graphic and new general information is added to the text above the cloud. If you have incomplete or invalid information in the General/Connectivity Settings panel, a warning icon appears next to the cloud image.

3. Select the **Enable MC LAG** check box if you want the following configuration to be pushed to the selected endpoint.

```
set protocols l2circuit neighbor x.x.x.x interface interface name
pseudowire-status-tlv
```

NOTE: This check box is available only for an LDP-based E-Line service order with PW Resilency enabled. The **Interface type** must be Ethernet.

4. Specify the **Route Distinguisher** value.

Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295

This field is displayed only if the selected definition's signaling type is **BGP**. You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

5. To specify the **Route Target**, clear the **Auto pick Route Target** check box.

Range: 1.1.1.1:1 through 255.255.255.254:65535, or 1:1 through 65535:4294967295

This field is displayed only if the selected definition's signaling type is **BGP**. You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

6. The **VLAN normalization** displays the information based on the option you have selected in the service definition.

7. If **VLAN normalization** is *Normalize to Dot1q tag*, specify the **VLAN Tag to stack**.

Default: 1

Range: 1 through 4094

8. If **VLAN normalization** is *Normalize to QinQ tags*, specify the **Normalize – Outer VLAN Tag** and **Normalize – Inner VLAN Tag** fields.

Default: 1

Range: 1 through 4094

9. To provide endpoint information for the first endpoint, click the **Endpoint A** button or click **Next**.

The Endpoint Settings form appears.

10. If you have enabled QoS, configure QoS settings. See [“Specifying QoS Settings” on page 900](#).

If QoS is not enabled, configure endpoint settings. See [“Specifying Endpoint Information” on page 901](#).

Specifying QoS Settings

NOTE: You can specify QoS parameters for an E-Line service only in the service definition. This section explains the QoS attributes that can be defined or modified in a service definition. These settings cannot be modified in the service order.

If QoS is enabled on the service definition, configure the QoS Settings of the General/Connectivity Settings panel.

1. In the **CoS profile** field, select a profile from the list.

The **CoS profile** list displays the CoS profiles that are currently configured in the Manage CoS Profiles page of the Connectivity Services Director application.

A CoS profile classifies traffic into defined service groups to provide the special treatment of traffic across the network service.

2. Configure endpoint information. See [“Specifying Endpoint Information” on page 901](#).

Specifying CFM Settings

By default, CFM is enabled on the service definition. Enter the following information in the CFM Settings of the General Settings panel:

1. In the **CFM Profile** field, select a profile from the list.

NOTE: For CFM Settings, if you specify a CFM profile (for example, a CFM action profile with remote MEP), first you must ensure that the profile is attached to the same device upon which you intend to deploy the E-Line service order. If the profile is not previously attached (using the CFM Insight application), it is not on the device to support the service order.

To remove a previously associated CFM definition or CFM profile from a service definition, click the **Detach** button next to the CFM Profile field to remove the association. To associate a new CFM profile, you must dissociate the existing CFM profile and attach a fresh CFM profile. Detaching an CFM profile is enabled when you modify a service or service order.

NOTE: For Juniper Networks PTX3000 Packet Transport Routers, if you attach a CFM Definition to the service order, the CFM session operates for MEPs in either the Up or Down direction when the service is deployed.

2. Click **CFM Details** beside the CFM Profile field to view the profile configuration details in a dialog box.
3. Configure endpoint information. See [“Specifying Endpoint Information” on page 901](#).

Specifying Endpoint Information

If a service template is attached to the service definition, a link to that template is listed in the Template page of the creation of service order wizard. The service templates settings are same for both the endpoints. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

Some of the fields differ from one interface type to another and also differ depending on permissions assigned in the service definition.

To specify endpoint information:

1. In the **PE device** field, select the N-PE device you want to use for the first endpoint.

If you are unsure about which PE device to choose, go to the Prestaging Devices workspace landing page, which shows capacity information about UNIs on PE devices. You must pick a device that has available UNIs.

This step is required for all service orders.

You can configure the primary endpoint device as an unmanaged device. With the primary endpoint as an unmanaged device, the following combinations of primary and backup endpoints are supported:

- Primary (endpoint Z) as an unmanaged device and no backup (endpoint Z) device.
- Primary (endpoint Z) as an unmanaged device and backup (endpoint Z) as a managed device.

The following combinations are not supported:

- Primary (endpoint Z) as an unmanaged device and backup (endpoint Z) as an unmanaged device.
- Primary (endpoint Z) as a managed device and backup (endpoint Z) as an unmanaged device.

You cannot configure the backup endpoint Z as an unmanaged device using Connectivity Services Director. P2P Resiliency cannot be configured if any one of the endpoints is unmanaged. A validation is performed for the supported combinations of endpoints.

NOTE: If this endpoint is a third-party device, select **Unmanaged device** from the **PE Device** field list. You need to specify only the **IP Address** and **Unmanaged Interface**. For more information, see *Provisioning a Single-Ended Point-to-Point Service*.

2. In the UNI interface field, select a UNI.

The list includes all UNIs available on the selected device.

This step is mandatory for all service orders.

If you have selected the **Enable Multi Segment Pseudowire** check box in the service definition, the **UNI interface** of the second endpoint lists the interworking (iw) interfaces only.

For more information on E-Line pseudowire stitching, see [“Stitching Two E-Line Pseudowires” on page 920](#).

You can enter the description of the UNI interface in the **UNI description** field.

3. (Optional) If you have selected the **Enable Multihoming** check box in the service definition, the **Backup Settings** box is displayed. You must select the **PE device** and **UNI Interface**.

The **Multihoming mode** is based on the mode selected in the service definition.

4. Specify the stitching unit.

Default: 0

Range: 0 through 255

NOTE: This field is displayed only in the second endpoint. You must have selected the **Enable Multi Segment Pseudowire** check box in the service definition.

5. In the **Traffic type** field, designate whether you want the service to transport all traffic, a single VLAN, a range of VLANs, or a list of VLANs.

Although this field is present for all service orders, the value is predetermined for some types of interfaces. For example, a port-to-port interface always transports all traffic. Moreover, for interface types that do support multiple traffic types, you can select this value only if the service definition allows you to do so.

If you are allowed to select this field, depending on the interface type, you can choose from the following values:

- Transport single vlan
- Transport vlan range
- Transport all traffic
- Transport vlan list

NOTE: The **Physical IF encapsulation** and **Logical IF encapsulation** fields are not selectable. These values are set in the service definition.

The **Vlan Range for manual input** field displays the VLAN range that is specified in the service definition.

If the **Ethernet option** is *do1q* or *qinq*, and the **VLAN selection** is *Transport single vlan* type, the **Vlan Range for manual input** range is used for validation of manually entered VLAN.

If the **Ethernet option** is *qinq*, and the **VLAN selection** is *Transport vlan range* type, the **Vlan Range for manual input** range is used for validation of manually entered outer VLAN.

If the **Ethernet option** is *do1q*, and the **VLAN selection** is *Transport vlan range* type, the **Vlan Range for manual input** range is used for validation of manually entered customer's VLAN start and VLAN end.

If the **Ethernet option** is *do1q*, and the **VLAN selection** is *Transport vlan range* type, the **Vlan Range for manual input** range is used for validation of manually entered customer's VLAN start and VLAN end.

6. In the **C-VLAN ID** field (or **VLAN ID** field), enter the customer's VLAN ID.

This field is mandatory for service orders that transport a single customer VLAN. The ID is provided by the customer.

7. In the **C-Vlan Start** and **C-Vlan End** fields, specify the beginning and end of the range of customer VLANs that you want the service to transport.

This field is mandatory for all services that transport a specific range of customer VLANs. These VLAN IDs are provided by the customer.

8. Select the **Auto pick VLAN ID** check box to have the system choose a service VLAN ID automatically.

This field is present only for interface types that provide double tagging; that is, only for Q-in-Q endpoint interface types. If this field is not set, then you must enter a service VLAN ID manually.

9. In the **VLAN ID** field, specify the service VLAN ID that you want be used to provide the outer tag for the service.

This field is present only for interface types that provide double tagging, and only if the **Auto pick VLAN ID** check box is not selected.

10. Specify whether the **Autopick UNIT ID** can be selected automatically or manually.

- To assign the **UNIT ID** automatically, select the **Autopick UNIT ID** check box.
- To assign the **UNIT ID** manually, clear the **Autopick UNIT ID** check box.

The window expands to include the **UNIT ID** field. In the **UNIT ID** field, type a value.

Range: 1 through 1073741823

NOTE: You can edit this field only if you have selected the **Editable in Service Order** check box for the **VLAN ID selection** in the service definition.

11. In the **MTU (Bytes)** field, specify the maximum transmission unit size for the UNI.

This field is present in all service orders. However, you can set this field only if the service definition allows you to do so.

12. If you selected the **Static pseudowire** check box in the selected service definition, you need to specify the **Outgoing label** for the static pseudowire.

Range: 1000000 through 1048575

In case of multi-segment pseudowire, you have to specify a new outgoing label for the second segment. The outgoing label for the second segment is not prepopulated from the first segment.

NOTE: You must manually compare the encapsulation, TDM bit rate, and control word of the router with the remote peer router and ensure that these parameters match; otherwise the static pseudowire might not work.

13. In the **Bandwidth (Mbps)** field, select a value from the list to limit the bandwidth of the service you are creating.

This field is present only if bandwidth limiting is allowed by the service definition, and is configurable in the service order only if the service definition allows you to do so.

When you click another graphic element in the main graphic area, the selected device name and interface name appear beneath the endpoint image in the main graphic.

14. If you have enabled the **Enable PW access to L3 VPN network** check box in the selected service definition, fill in the following fields in PW Stitching:

- **L3 routing instance name**—Specify the name of the Layer 3 routing instance.
- **Autopick interface IP**—If this field is enabled, specify **IP block size** and **IP address pool**; otherwise specify the **Interface IP address**.
- **Autopick peer unit**—To select the logical system unit number automatically, select the check box; otherwise specify the **Peer unit name**.

NOTE: These fields are available only if you have selected an LT interface in the **UNI interface**.

15. If you have enabled the **Enable PW Resiliency** check box in the selected service definition, fill in the following fields in the Backup settings and Resiliency settings:

- **Enable**
- **PE device**
- **UNI interface**
- **MTU (Bytes)**
- **LSP tunnel name**
- **Revert time (sec)**
- **Switch Over Delay (sec)**

For more information of pseudowire redundancy, see [“Redundant Pseudowires for Layer 2 Circuits and VPLS” on page 98](#).

16. Select the **Enable send-CFM config** check box to enable the **send-CFM** command. You can enable or disable this check box even in the Modify Service page.
17. To provide endpoint information for the second endpoint, click the **Endpoint Z** button (or click **Next**).
The Endpoint Settings form appears in the right panel for the second endpoint. Complete this form as for the first endpoint (repeat Step 1 through Step 18).
18. Click **Next** to proceed to the last step of the wizard, which is to examine the specified service attributes and submit the changes. Alternatively, click **Back** to navigate to the previous step of the wizard.

Specifying Template Settings

The Template Settings page of the service order creation and modification wizards enables you to associate service templates with an E-Line, E-LAN, and IP service order. You can apply only the templates that are previously configured in a service definition with the corresponding service order. The Template Settings page is available in the service order wizard only if the service definition that you selected to apply to the service order contains a service template. Otherwise, the Template Settings page is not displayed in the service order wizard. You can perform template operations for all endpoints in a service order.

If you defined a service template as the default service template, it is attached to the endpoint by default. You have the flexibility to create and provision a dynamic attribute in a service template. You can mark an attribute of a service template as dynamic, and you can obtain the values for these dynamic attributes from a specific device. To create a dynamic attribute, you must first mark an attribute of a service template as dynamic and then specify the device XPath for the dynamic attribute.

The Template Settings page is displayed before the Review page, which is the final step of the service order wizard.

In the Service Settings page of the Select Service Definition field of the service order creation wizard, you can double-click a service definition name displayed in the table to view the details of the definition in a popup dialog box. You can use this information to determine if the service definition is appropriate for your deployment needs. To filter and sort the display of service templates, enter the name of the template as a match criterion in the Search box and click the Search icon. The page refreshes to display only the template names that match with the search term. You can use the paging controls to navigate across multiple pages of templates as necessary.

All the tasks that you can perform with service templates are presented in the Template Settings page. The page is divided into three panes. The top half of the page displays a table of selected endpoints. All the endpoints or UNIs that you selected in the preceding pages of the service order wizard are displayed in this table. You can configure the template pertaining to only one endpoint at a point in time. If the selected endpoints (in previous pages of the wizard) contained a manually-entered unit number, that number is displayed in the table of selected endpoints. Otherwise, the Auto-pick label is displayed.

The lower half of the page is divided into two panes. The left pane displays the template selection table for the endpoint you selected. All the templates associated with the service definition are displayed. You can add and delete templates using the template selection table. The right pane displays all the parameters that you can modify for a selected service template. All such editable parameters are displayed in a consolidated form of a configuration page. This pane is displayed after you select a template. If any configuration parameter in template is set as a service-specific value, such attributes are not displayed in this pane.

To associate a service template with a service order:

1. Click **Add** to include a service template for the endpoint. A dialog box is displayed with the list of service templates associated with the service definition that is used to create the service order. The templates selected in this dialog box are displayed in the Template Selection table for the specified endpoint. Such templates are considered to be attached to that endpoint.

If you specified a template as a default template during the service definition creation, the template is displayed by default in the template selection table. You can associate non-default templates with the service order by clicking the **Add** button.

2. Click the link in the template name to open the Template Details dialog box. The template settings are displayed in the popup dialog box. For the selected template, the Configuration Page is displayed in the lower-right pane of the Template Settings page.
3. Modify any template-specific service components as necessary.
4. Click **Save** to submit the changes.
5. Select a template from the Template Selection table, and click Delete to remove the template from being associated with the service order for a particular endpoint.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

Specifying Connectivity and Endpoint Information for Managing VLANs

The Connectivity Services Director application provides greater flexibility for provisioning VLANs for E-Line service orders by extending the VLAN normalization options.

You can create logical interfaces that define both the **Outer-VLAN-tag-to-stack** protocol ID and **Inner-VLAN-tag-to-stack** protocol ID. The following illustration shows the **General/Connectivity** window. The **Connectivity Settings** panel displays the **Outer-VLAN-tag-to-stack** and **Inner-VLAN-tag-to-stack** parameters.

Connectivity Services Director now enables you to manually select a value for the **Outer VLAN tag to stack** and **Inner VLAN tag to stack** parameters for a service that specifies the **qinq Ethernet option**.

The following illustration displays the service order **Connectivity Settings** based upon a service definition that set the **VLAN normalization parameter** to **Normalize to Dot1q tag**.

For service orders that are based on service definitions that set the **Ethernet option** to **dot1q** or **qinq**, the **Unit ID** parameter appears in the **Logical IF Settings** panel in the service order **Endpoint Settings** window.

Deploying and Monitoring the Progress of the New Service

To deploy the new service:

1. Perform one of the following actions in the Deploy mode of the Service View of Connectivity Services Director:

- To deploy the service immediately, select **Deploy now**, then click **OK**.
- To deploy the service later, select **Schedule deployment**, select a date and time, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.

2. To monitor the progress and status of the deployment, use the Jobs workspace.

RELATED DOCUMENTATION

[Creating a Service Order | 876](#)

[Creating an E-Line ATM or TDM Pseudowire Service Order | 877](#)

[Creating a Bulk-Provisioning Service Order for Pseudowire Services | 909](#)

[Creating an Inverse Multiplexing for ATM Service Order | 912](#)

[Provisioning a Single-Ended E-Line Service | 916](#)

[Selecting Specific LSPs for Connectivity Services | 918](#)

Creating a Bulk-Provisioning Service Order for Pseudowire Services

Bulk provisioning allows for devices with similar configurations to be deployed as a group. The groups can be defined based on some characteristic common to all of the devices in a group, such as their functional role. Mobile backhaul deployments, for example, can run into hundreds of thousands of devices. These devices are commonly grouped according to their functional rules such as Cell Site Devices, Pre-aggregation or Hub-site devices, Aggregation Devices, Edge Routers and so on. To use this feature, tags must be defined and created so that groups can be selected. This feature is intended to simplify deployments of large groups of devices.

Prerequisites

- Existing E-Line pseudowire service definitions that will be used for the bulk-provisioning service order.
- Tags - You must have defined tags in the Prestaging workspace that you intend to use for groups of devices for which you will be creating the bulk service order. If you do not have tags already created, you can select **Prestage Devices > Manage Device Roles** and either select existing tags to apply to devices or create new tags.

To begin the bulk provisioning process, in the Network Activate task pane, select **Prestage Devices > Manage Device Roles** and choose a service definition from the list. Click on the tag view of the inventory list.

1. Select the tag you want to use from the left **Tag** panel.
2. Select the devices you want to include in the tagged group.
3. Click, **Apply Tag**.
4. In the Network Activate task pane, select **Service Design > Manage Service Definitions**. The Manage Services Definitions page displays a list of service definitions.
5. Right-click on the E-Line service definition, and select **Create Bulk E-Line Service Order**.

The Create Bulk E-Line Service Order window appears.

6. In the Bulk E-Line provisioning window, define the settings for the service order.

Field	Action
Name	Provide a name for the bulk service order
Customer	Select the customer name from the list of defined customers.
VLAN normalization	<p>The options available in the VLAN normalization are based on the value set for the Ethernet interface.</p> <p>For information on VLAN normalization, see “Creating an E-Line Service Definition” on page 652.</p>
Bandwidth	Specify the bandwidth for the endpoints
MTU (Bytes)	Specify the MTU size in bytes.
Service tag	Select the service tag from the defined list. This tag will be applied to the services you create.
Description	Provide a description for the service tag.

Field	Action
-------	--------

Defining the Endpoint Settings

To define the endpoint settings, you will define both the A endpoint and the Z endpoint.

As an example of how you can use the bulk provisioning and how the endpoints work, if you want to establish a hub-spoke pseudowire between an Aggregation PE and a set of CSR devices, you can tag all the CSRs with a certain tag in the **Manage Device Roles** page. You can then select the PE device on the A end and the tag that you have already created for all the CSR devices on the Z end. If the endpoint is a tag then you can provide a wild-card interface (for example, ge-0/*/*) that matches all the devices under that tag.

Define the A End Settings

PE Device/Tag	Select the device or tag from the defined list.
UNI interface	Select the UNI interface from the list
VLAN ID	VLANs are created as part of this process. Enter the beginning VLAN ID that you want to use for creating the new service orders.
VLAN ID increment	Indicate how the VLAN IDs will be assigned for each of the new services. The number of VLANs created depends on the number of new services you are creating. One service order will be created for each device in the tag group.
UNIT ID	Specify the unit ID. Range: 1 through 1073741823
UNIT ID increment	Indicate how the unit IDs are assigned for each of the new services. The number of units created depends on the number of new services you are creating. One service order will be created for each device in the tag group.

Define the Z End Settings

PE Device/Tag	Select the device or tag from the defined list.
UNI interface	Select the UNI interface from the list
VLAN ID	Enter the VLAN ID from the list of existing VLANs. VLAN range cannot be used for this feature.
VLAN ID increment	Indicate how the VLAN ID
UNIT ID	Specify the unit ID. Range: 1 through 1073741823

Field	Action
UNIT ID increment	Indicate how the unit IDs are assigned for each of the new services. The number of units created depends on the number of new services you are creating. One service order will be created for each device in the tag group.

- When required information has been entered, click **Create**.

The service order that you have created is graphically represented in the topology. To view the service order that you have created in the topology, select **Platform > Network Monitoring > Topology > Service > NA service order name**. Select the service order to view its parameters.

- From the **Deploy Service** window, select the deployment method you wish to use.

RELATED DOCUMENTATION

| [Creating an E-Line ATM or TDM Pseudowire Service Definition](#) | 675

Creating an Inverse Multiplexing for ATM Service Order

Before you can create a service order that implements Inverse Multiplexing for ATM (IMA), you must preconfigure a T1 or E1 IMA Group interface (at-fpc/pic/g) on the devices upon which you want to deploy the service, before you prestage the devices in the Junos Space Connectivity Services Director application.

To create an inverse multiplexing for ATM service order:

A wizard is available to create a service order in an intuitive and easily-navigable format. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create a Service Order page. Alternatively, you can proceed to the corresponding setting-related pages by clicking the **Back** and **Next** buttons at any point in the wizard during the creation of the service order.

With the Service View selected and in the Deploy mode of Connectivity Services Director, from the Network Services > Connectivity task pane, select **Service Provisioning** > **Deploy Services**.

The Manage Network Services page is displayed in the upper part of the right pane.

Click the **New** icon at the top of the lower half of the page that displays previously created service orders. The Select Service Type dialog box appears. Do one the following

- Select **E-Line** to create an E-Line service order.
 - Select **E-LAN** to create an E-LAN service order.
 - Select **IP** to create an IP service order.
 - Select **Bulk E-Line** to create a bulk E-Line service order.
1. Select **E-Line** to create an E-Line service order. The **Create E-Line Service Order** window appears.
 2. Select the service definition upon which you want to create the service order. Click **Next** to move to the next page of the wizard. The left panel displays a representation of the connection you are configuring. The right panel displays the **General/Connectivity Settings**.
 3. Fill in the fields in the **General/Connectivity** panel.

NOTE: In the service order creation wizard for E-Line services, the search function has been enhanced to enable you to easily sort and filter the parameters that are of interest and relevance for the services you want to configure. The Choose Customer dialog box that is displayed when you click Select beside the Customer field contains the Search box, which enables you to perform a search on all of the columns. The search utility that is present in the Choose Service Definition dialog box that is displayed when you click Select beside the Service Definition field enables you to search by Name, Created by, and Signaling columns; search utility is not supported for other columns in the dialog box. The search box that is present in the Choose Endpoints dialog box when you click Select beside the PE Device and UNI Interface fields enables search across all the columns displayed in the dialog box. For any string-based search (which shows strings that match any part of the text you enter in the search box), only the Name, Platform, and OS Version columns are supported. For exact string-based search (which shows strings that exactly match the text you enter in the search box), the IPAddress, State, and Manage State columns are supported.

4. Click **Next**. The **Endpoint Settings** panel for Endpoint A appears.
5. Fill in the Endpoint A settings. Ensure that you select a device on which a T1 or E1 IMA Group interface was preconfigured.
6. Click **Next**. The **Endpoint Settings** panel for Endpoint Z appears.
7. Fill in the Endpoint Z settings. Ensure that you select a device on which a T1 or E1 IMA Group interface was preconfigured.
8. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.
9. After you complete reviewing the settings, click **Finish** to complete the service order creation.
10. To deploy or deactivate the service order on devices, click the **Deploy** icon in the Service View of the Connectivity Services Director banner, and from the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services > Manage Service Orders > *service order name***. Select the service order to view its configuration parameters, decommission the settings applied to devices, or deploy the service order to devices.
11. Select the deployment option you want from the top of the page that lists the created service orders:

- **Deploy now**
- **Schedule deploy** (Specify the date and time.)

The Connectivity Services Director application displays the **Job Details** window, which includes a **Job Details ID** number.

12. in the Network Services > Connectivity view pane, select **Service Provisioning > Deploy Services**.

13. In the **Manage Network Services** window, you can view the status of the service.

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Definition | 675](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Provisioning a Single-Ended E-Line Service

You can create a point-to-point link between the end points of a managed device and an unmanaged device. An unmanaged device is a third-party device. In cases where interoperability with a third-party device is necessary, Junos Space allows you to define the link between a Juniper Networks managed device and the third-party device. You need to specify the IP address and the end point interface name of the unmanaged device. The Junos Space does not validate the information of an unmanaged device. You cannot configure an unmanaged device. The Junos Space pushes the configuration only to managed devices.

You can configure the primary endpoint device as an unmanaged device. With the primary endpoint as an unmanaged device, the following combinations of primary and backup endpoints are supported:

- Primary (endpoint Z) as an unmanaged device and no backup (endpoint Z) device.
- Primary (endpoint Z) as an unmanaged device and backup (endpoint Z) as a managed device.

The following combinations are not supported:

- Primary (endpoint Z) as an unmanaged device and backup (endpoint Z) as an unmanaged device.
- Primary (endpoint Z) as a managed device and backup (endpoint Z) as an unmanaged device.

You cannot configure the backup endpoint Z as an unmanaged device using Connectivity Services Director. P2P Resiliency cannot be configured if any one of the endpoints is unmanaged. A validation is performed for the supported combinations of endpoints.

To create a point-to-point link to an end point that is not managed by Junos Space, in the Network Services > Connectivity view pane, select **Service Provisioning** > **Manage Service Orders** > **New** > **E-Line**. The **Manage Service Orders** page displays an inventory of all available E-Line service definitions.

1. Select the service definition upon which you want to base your service order from the Service Definition field.
2. Specify the general/connectivity settings. For details on creating an E-Line service order, see [“Creating an E-Line Service Order” on page 895](#)
3. Click **Next** to specify the endpoint settings.
 - If this end point is N-PE device, select a device from the **PE Device**. Configure the endpoint settings as mentioned in [“Creating an E-Line Service Order” on page 895](#)
 - If this endpoint is a third-party device, select **Unmanaged device** from the **PE Device**.

Fill in the fields as indicated in the table:

Field	Actions
PE Device	Since the endpoint is a third-party device, select Unmanaged device from the list.
Loopback IP Address	Specify the loopback IP address of the third-party device. Range: 1.0.0.1 through 223.255.255.254, excluding 127.x.x.x
Unmanaged Interface	Specify the end point interface name of the unmanaged device, which is the third-party device.

4. Click **Next** to specify another endpoint settings.

NOTE: Both the endpoints cannot be a third-party device.

5. To finish creating the service order, click **Finish**.

NOTE: The functional audit is performed only on the Juniper Networks devices (managed devices). To perform a successful functional audit of an unmanaged device, configure the following attributes of an unmanaged device:

- Neighbor IP
- Virtual circuit ID
- Unit ID
- Encapsulation
- Filter
- Policer

RELATED DOCUMENTATION

Creating an E-Line Service Order | 895

Selecting Specific LSPs for Connectivity Services

IN THIS SECTION

- [Associating an LSP with an E-Line Service | 918](#)
- [Viewing LSP Details in a Service Order | 919](#)
- [Viewing LSP Details in a Service | 919](#)
- [Viewing LSP Configuration Details | 920](#)

This feature allows you to associate a policy with an E-Line service. This in turn attaches the pseudowire to an LSP, which satisfies the conditions of the policy. The configuration for the service order includes the LSP name as the Next hop name. The following topics provide information on attaching an LSP and viewing its details:

Associating an LSP with an E-Line Service

To associate an LSP with an E-Line service:

1. Create an E-Line service order.
 - a. From Deploy mode of Service View, In the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**, and from the **Manage Network Services** page, select **New > E-Line**.

The **Manage Network Services** page displays an inventory of all available E-Line services. For each selected service, you can view the associated service orders from the **Manage Service Orders** page in the lower part of the right pane.
 - b. Select the service definition you want to base your service order on, and click **Next**. The **General/Connectivity Settings** window is displayed.
 - c. Specify the general/connectivity settings.
 - d. Click **Next**. The **Endpoint Settings** window is displayed. You can now attach an LSP tunnel to a service order. To provision the specific LSP, select an LSP tunnel from the **LSP tunnel**.

NOTE: The **LSP tunnel** is not a mandatory field. The service order is created even if you do not specify the LSP tunnel name.

- e. Click **Next** to configure another endpoint. To provision the specific LSP, select an LSP tunnel from the **LSP tunnel**
- f. To create an E-Line service order, click **Finish**.

For more information on creating an E-Line service order, see [“Creating an E-Line Service Order” on page 895](#)

2. Deploy the E-Line service order.

The LSP is now associated with the E-Line service order.

Viewing LSP Details in a Service Order

From the Deploy mode of Service View, In the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Network Services page is displayed in the top part of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom part of the right pane, which displays all of the service orders associated with a service.

To view the details of an E-Line service order, double-click an E-Line service order in the **Manage Service Orders** inventory page. If an LSP is associated with an E-Line service order, the **Endpoint Details** window includes the following information:

- LSP tunnel name—Name of the LSP tunnel attached to the E-Line service order.
- Community name—Name of the community. A community is a group of destinations that share a common property.
- Community member—One or more community members.

Viewing LSP Details in a Service

From the Deploy mode of Service View, In the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Network Services page is displayed in the top part of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom part of the right pane, which displays all of the service orders associated with a service.

To view the details of an E-Line service, double-click an E-Line service in the **Manage Network Services** inventory page.

If an LSP is associated with an E-Line service order, the **Endpoint Details** of an E-Line service includes the information on the LSP.

NOTE: You cannot modify the LSP tunnel in a service.

Viewing LSP Configuration Details

In the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Network Services page is displayed in the top part of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom part of the right pane, which displays all of the service orders associated with a service.

From the Manage Network Services page, select a service and click the **View Service Configuration** button at the top of the table of listed services.

If an LSP selection is provisioned, you can view the LSP selection configuration in the **Service Configuration** window.

RELATED DOCUMENTATION

| [Creating an E-Line Service Order](#) | 895

Stitching Two E-Line Pseudowires

A multi-segment pseudowire (MS-PW) is a static or dynamically configured set of two or more contiguous pseudowire segments that behave and function as a single E-Line pseudowire. Each end of an MS-PW, by definition, terminates on a T-PE.

Pseudowires are deployed in large networks. Such networks typically encompass hundreds or thousands of aggregation devices at the edge, each of which would be a provider edge (PE). These networks can be partitioned into separate metro and core pseudowire domains, with multi-segment pseudowires connecting endpoints across the various domains. You can stitch two E-Line pseudowires.

To stitch two E-Line pseudowires:

1. Create an E-Line service definition.

In the General tab, you must select the **Enable Multi Segment Pseudowire** check box to enable multi-segment pseudowire.

For more information on creating an E-Line service definition, see *Creating an E-Line Service Definition*.

2. Create an E-Line service order.

The fields displayed in the E-Line service order are based on the E-Line service definition that you created in Step 1. In the second endpoint settings page, select an interworking (iw) interface and specify the stitching unit.

For more information on creating an E-Line service order, see [“Creating an E-Line Service Order” on page 895](#).

3. Deploy the E-Line service order.

- a. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top part of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom part of the right pane, which displays all of the service orders associated with a service.

- b. In the Manage Service Orders page, select the E-Line service order you created in Step 2.
- c. Select the **Deploy now** option button at the top of the page and click **OK**.

The service order is deployed.

4. In the Manage Services inventory page, select the check box next to the E-Line service that you created and select **Actions > Stitch PW Segment**. The Stitch PW Segment inventory page is displayed.

The Stitch PW Segment inventory page lists only the E-Line service definitions with the **Enable Multi Segment Pseudowire** check box enabled. This inventory page must also list the E-Line service definition you created in Step 1.

5. In Build mode of Service View, from the Manage Service Definitions page, select an E-Line service definition and click **Next**.

6. Specify the General Setting, Connectivity Settings, and Endpoints details. For more information on these fields, see [“Creating an E-Line Service Order” on page 895](#).

NOTE: The fields of the first endpoint are auto-filled. Notice that the second endpoint fields of the service order you created in Step 2 and the first endpoint fields of this service order are same.

7. Deploy the stitched service order.

- a. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top part of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom part of the right pane, which displays all of the service orders associated with a service.

- b. In the Manage Service Orders page, select the E-Line service order you created in Step 6.
- c. Select the **Deploy now** option button at the top of the page and click **Ok**.

The service order is deployed.

The two E-Line pseudowires are stitched.

The Manage Services lists both services. The E-Line Service Details window displays the **Stitch PW Segment** details.

NOTE: The number of pseudowire segments that you can stitch is limited to two.

You can perform a functional audit to the first service only. You can view the details of the stitched pseudowire in the Functional Audit Results window.

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Order | 877](#)

[Creating an E-Line Service Order | 895](#)

Using Print Page

Use the Print Page to print all functionalities associated with the Service View Tasks in the Monitor mode. This is applicable for E-Line, E-LAN, and IP services. You can download the data from the selected functionalities of the Service View Task pane in a .pdf or .csv format.

To download the data from any of the selected functionalities associated with the Service View Task pane:

1. From the View selector, select **Service View**.

The functionalities that you can configure in this view are displayed on the View pane.

2. Click the **Monitor** mode icon in the Service View on the Connectivity Services Director banner.

The workspaces that are applicable to this mode are displayed on the Tasks pane.

3. From the **Service View** pane, select the types of services for which you want to print the data.

The types of services are displayed on the middle pane of the main display area.

4. From the Tasks pane, which is displayed on the right, select **Print Page**.

The print window page appears on the Tasks pane.

- Click **Download PDF** to download the data from the selected Service View pane in the .pdf format
- Click **Download CSV** to download the data from the selected Service View pane in the .csv format.

The data from the Service View pane gets downloaded with the default file name.

NOTE: If you want to change the file name, select **Custom File Name** check box and enter the required name in the **Name** field.

RELATED DOCUMENTATION

[Clearing Interface Statistics | 1292](#)

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

[Viewing Interface Status Details | 1297](#)

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

[Routing Table Overview | 1308](#)

Deactivating a Service

This procedure disables a service for a particular protocol that you have previously created on the network. By disabling a service, the traffic processing for the traversed packets is impacted. In certain network topologies, you might require a service-related settings to be disabled for a certain period to perform troubleshooting or modification to the traffic-handling method, and you might want to reactivate a disabled service later when you have completed network maintenance and analysis work. In such a case, it might be beneficial to use the deactivation functionality for a service. When you disable a service, the configuration attributes associated with such a service are deactivated and commented out in the device settings. The

deactivated service is propagated to the devices associated with the service order. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deployed or Re-Activated state.

NOTE: To modify a service order, it must not be in the Deactivated state.

To deactivate a service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Orders page, with the table of service orders.

TIP: In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

6. From the Manage Network Services page, select the check box next to the service you want to deactivate.
7. Click the down arrow on the **Action** menu, above the table of listed services, and select **Deactivate** to disable the selected service. A dialog box is displayed prompting you to confirm your action.
8. Do one of the following in the Confirmation dialog box:
 - To deactivate the service immediately, select Deactivate now, and click Yes. If you click Yes, a pending change request is created for each selected service. Alternatively, if you click No, the deactivate operation is discarded.
 - To deactivate the service at a later time, select Deactivate later, and select a date and time for deployment, then click OK. The time field specifies the time kept by the server, but in the time zone of the client. After scheduling the service order for deactivation, the provisioning software begins validating the service order.
9. Use the Jobs workspace to monitor the outcome of the deployment.

RELATED DOCUMENTATION

[Reactivating a Service | 925](#)

[Force-Deploying a Service | 927](#)

[Decommissioning a Service | 931](#)

Reactivating a Service

After you disable a service to deactivate the configuration settings on devices mapped to the service, you might require the service settings to be reenabled after you have modified the service parameters, either directly on the device or using the Connectivity Services Director application. In such a case, you can use the reactivation functionality to revive and activate the service properties on devices. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deactivated state.

To reactivate a service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP Ethernet service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Orders page, with the table of service orders.

TIP: In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

6. From the Manage Network Services page, select the check box next to the service you want to reactivate.
7. Click the down arrow on the Action menu, above the table of listed service orders, and select Reactivate to reenab the selected service order. A dialog box is displayed prompting you to confirm your action.
8. Do one of the following in the Confirmation dialog box:
 - To reactivate the service immediately, select Reactivate now, and click Yes. If you click Yes, the selected service is activated immediately. Alternatively, if you click No, the deactivate operation is discarded.
 - To reactivate the service at a later time, select Reactivate later, and select a date and time for reactivating, then click OK. The time field specifies the time kept by the server, but in the time zone of the client.
9. Use the Jobs workspace to monitor the outcome of the deployment.

RELATED DOCUMENTATION

[Deactivating a Service | 923](#)

[Force-Deploying a Service | 927](#)

[Decommissioning a Service | 931](#)

Force-Deploying a Service

When a service fails a configuration audit because configuration changes on a PE device do not match the configuration required for the service, you can force-deploy the service to push the configuration to the device.

Force deployment pushes the same configuration to the device that was pushed during the deployment of the service, thus allowing the operator to recover from a state in which the configuration on the device was lost or changed out-of-band.

The validation before generating the configuration for a force-deployed service order will be performed against the current configuration on the device and the configuration is not pushed if the validation fails. If the forced deployment is unable to push the configuration again, then you might need to manually configure the device.

This procedure forces deployment of a service on the network.

You cannot force-deploy an invalid service order.

To schedule a service for forced deployment:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Orders page, with the table of service orders.
6. From the Manage Network Services page, select the check box next to the service you want to forcibly deploy.

TIP: In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

The top pane displays information about the services that have been previously created, such as the name of the service, the functional audit status, the performance management status, and the status of the service. You can modify the properties of the service, conduct a functional or configuration audit, force-deploy or deactivate the service, and view alarms associated with a particular service order for debugging and corrective action. Services can be in one of the following service states:

- **Completed**—The service order has been successfully deployed.
- **Scheduled for deployment**—The service provisioner has scheduled the service order for deployment.
- **Deployment Failed**—An attempted service deployment was not successfully completed or failed an audit.
- **In Progress**—The Connectivity Services Director application is in the process of deploying the service.
- **Requested**—The service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
- **Invalid**—The service order is not valid.

7. Open the **Actions** menu and click **Force Deploy Service**.

The **Schedule Force Deployment** window appears.

8. To deploy the service immediately, select **Force deploy now**, and click **OK**.

To deploy the service at a later time, select **Force deploy later**, select a date and time for deployment, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.

After scheduling the service order for deployment, the provisioning software begins validating the service order.

- 9. Use the Jobs workspace to monitor the outcome of the forced deployment.

RELATED DOCUMENTATION

Deactivating a Service 923
Reactivating a Service 925
Decommissioning a Service 931

Recovering a Service Definition through Force Upload

You can use the force-upload feature to overwrite the service definitions that were recovered using the service recovery feature and do not contain the changes made through CLI configuration or through templates. You do this by creating a service definition containing templates that matches the configuration, and uploading it to the Connectivity Services Director application.

NOTE: You use service recovery to manage a service on the device. You can only upload data which is part of the service definition. The **Force Upload** feature is used to upload templates associated with the service definition.

NOTE: You can use templates to recover changes made through the CLI configuration. You use the **Force Upload** feature to upload a template for one or more endpoints associated with the service.

In Connectivity Services Director Release 2.0 and earlier, you cannot recover changes made to service definitions through CLI configuration or through templates.

To perform the force-upload action:

1. In the Connectivity Services Director Application, select **Service View** from the Views list.
The workspaces applicable to the services are displayed.
2. Click the **Deploy** tab in the Task Categories banner.
The features that you can configure in this mode are displayed in the Tasks pane.
3. From the Service View pane, click **Network Services**.
The tasks you can perform are displayed in the **Tasks** pane.
4. From the Tasks pane, select **Key Tasks > Manage Services**.
The **Manage Network Services** page is displayed.
5. Select the service you want to force-upload by selecting the check box next to the service.
6. Click the **Action** tab and select **Force Upload** from the list of actions.
The **Force Upload** page is displayed.

7. From the **Service Details** table in the force upload page:

- a. Click the arrow in the **Device Name** column of the table. From the list that appears, choose the device by selecting the check box next to it.

The device is added to the **Device Name** column.

NOTE: You can add more than one device at a time.

- b. Click the arrow in the **Interfaces** column of the table. From the list that appears, you can select more than one interface associated with the device.

The interface is added to the **Interfaces** column.

NOTE: Selection of devices and interfaces is optional. If you select a device or an interface, the template associated with the selected device or selected interface is uploaded.

If you select a device, all interfaces associated with that device are uploaded. If you select a device and an interface, the interface associated with that device is uploaded.

8. Click **Ok** to confirm force-upload.

The service definition is uploaded on the selected device and interface.

RELATED DOCUMENTATION

[Deactivating a Service | 923](#)

[Reactivating a Service | 925](#)

[Decommissioning a Service | 931](#)

Decommissioning a Service

You can decommission a service that a customer no longer needs.

You cannot decommission a service if a service order requesting action on that service is in the Requested, Scheduled, In Progress, or Invalid state. The Y.1731 monitoring functionality must be in the disabled state (by selecting OAM > Y1731 > Start from the task pane after selecting the specified service in the View pane in Monitor mode of Service View) for the service to be decommissioned.

To decommission a service:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
5. From the Manage Network Services page, select the check box next to the service you want to decommission.

TIP: In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

The top pane displays information about the services that have been previously created, such as the name of the service, the functional audit status, the performance management status, and the status of the service. You can modify the properties of the service, conduct a functional or configuration audit, force-deploy or deactivate the service, and view alarms associated with a particular service order for debugging and corrective action. Services can be in one of the following service states:

- **Completed**—The service order has been successfully deployed.
- **Scheduled for deployment**—The service provisioner has scheduled the service order for deployment.

- **Deployment Failed**—An attempted service deployment was not successfully completed or failed an audit.
 - **In Progress**—The Connectivity Services Director application is in the process of deploying the service.
 - **Requested**—The service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
 - **Invalid**—The service order is not valid.
6. Open the **Actions** menu and click **Decommission Service**. Alternatively, select **Decommission** by drilling down the Manage Services tree in the task pane.

The **Schedule Decommission** window appears.

7. Do one of the following:

- To decommission the service immediately, select **Decommission now**, and click **OK**.

In the **Order Information** window, click the job ID of the decommission job.

The **Job Management** page appears and shows a filtered view of the job inventory, showing only the decommission job. See *Viewing Jobs* in the *Junos Space Network Application Platform User Guide* for details.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

- To deploy the service at a later time, select **Decommission later**, select a date and time to perform the operation, then click **OK**.

If you decommission a service and the device confirms the deletion, the resources associated with the service are immediately released and are available for reuse without waiting for the device synchronization. If you want the synchronization to happen before the resources are released, you need to configure the decommissioning settings.

To configure the service decommissioning settings:

1. Select **Network Management Platform > Administration > Applications**. The Applications page displays the list of applications.
2. Right-click the Connectivity Services Director row and select **Modify Applications Settings**. The Modify Connectivity Services Director Settings page displays the list of parameters that can be modified.
3. Select **ServiceDecommission**.

4. Specify values for the parameters in the Service Decommission page as described in the following tables.

Field	Action
Wait for Device Sync Before Releasing Resource	Select this check box to wait for the device synchronization before resources are released. To revert the decommissioning to the normal behavior clear this check box.
Device sync wait time	Specify the device synchronization waiting time. This is the maximum wait time to complete the device synchronization. After this time duration, irrespective of the device synchronization status, the resources are released. Default: 60 seconds Range: 30 seconds to 300 seconds

5. Click **Modify**.

The service decommissioning settings are configured.

RELATED DOCUMENTATION

[Viewing Service Order and Service Details | 865](#)

Viewing Alarms for a Service

Activity on a network device consists of a series of events. A software component on the network device, called an entity, is responsible for running the Simple Network Management Protocol (SNMP) to log and monitor these events. You can view the details of alarms and events generated for a particular service order to examine and diagnose the problems that are generating the alarms. These alarms provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity

To view alarm and event details for a service:

1. Select Service View from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Build** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
5. From the task pane, select Service Provisioning > Deploy Services. The table of services is displayed.
6. Select the check box next to the service for which you want to view alarm details.
7. Click the **View Alarms** button, above the table of listed services.
The Alarm Detail dialog box is displayed.
8. Click **Close** after you finish evaluating the information to return to the Manage Network Services page.

RELATED DOCUMENTATION

| [Alarm Detail Monitor \(Service View\)](#) | 1331

Inline Editing of E-LAN and IP Service Orders

The Manage Service Order windows that enable the provisioning of IP and E-LAN services utilize grids as a navigation element to add sites and interfaces to a VPN. In addition, grids are also used to select individual elements and configure any details that might be required for such element to be part of the VPN. For example, a typical E-LAN configuration workflow involves the following steps:

Entering general service parameters that apply to all nodes in the VPN, such as the name of the service, signaling protocol used, route distinguishers, and route targets

Selecting the set of nodes that participate in the VPN instance. Per-node parameters can be configured by going through one node at a time, or through a bulk edit operation by selecting and editing multiple nodes simultaneously.

Choosing the the set of interfaces on each node that connect to the customer devices and configure the interface-specific characteristic of each interface. Similar to the node settings, users can perform bulk edits to modify multiple interfaces at a time.

In your network environment, the E-LAN and IP services, owing to their multipoint nature, involve multiple devices and interfaces, which causes the configuration to require many steps, and becomes cumbersome and complicated. To simplify and optimize the configuration of multipoint services by allowing users to configure devices and interfaces in a grid so that the operator can easily view and modify the most important parameters of the service, the inline edit mechanism is implemented. Inline modification signifies the ability to perform changes to previously defined settings in an easy and quick manner.

Embedded editing is enabled, which causes the grids showing the devices and interfaces to become modifiable directly without the need to perform the process of highlighting, editing, and saving the changes every time you want to edit a particular parameter. The page that displays the configured settings presents as a form in which the fields or cells of the table are editable.

Because the inline edit functionality enables you to directly edit the grids, only the salient and most important parameters for each service in the grids are displayed.

For parameters that you can enable or disable, you can select or clear the check boxes.

For parameters that require a value to be specified, an auto drop-down list is displayed that enables you to select a value from the list of available or configured values.

Advanced parameters can be continued to be edited by selecting the rows and clicking Edit. A popup dialog box is displayed with the list of all parameters supported for editing. You can perform inline edits by double-clicking in the cell or the field under a particular column in the table of displayed settings. The field becomes editable when you double-click within the cell.

For an E-LAN service order, the following node settings can be modified using the inline edit method:

Service loopback, Hub, Mac learning, Mac Interface limit, Mac statistics

Parameter	Editable	Dependencies
Node	Yes	None
Status	No	None
Platform	No	None
Service loopback	Not available	None
Hub	Yes	Only available for hub-spoke topologies
Mac learning	Yes	None
Mac Interface limit	Yes	None
Mac statistics	Yes	None

For an E-LAN service order, the following site settings can be modified using the inline edit method:

Node, Interface, Autopick Unit, Unit ID, VLAN tagging, Autopick VLAN ID, Outer VLAN ID, Inner VLAN ID, Rate Limit, Interface Description

Parameter	Editable	Dependencies
Node	Yes	None
Interface	Yes	The Node name has to be configured
Status	No	None
Autopick Unit	Yes	None
Unit ID	Yes	Only enabled when autopick unit ID is not checked
VLAN tagging	Yes	None. This is a combo box with 3 options (Disabled, Dot1Q and QinQ)
Autopick VLAN ID	Yes	Enabled when VLAN tagging is set to Dot1Q or QinQ
Outer VLAN ID	Yes	Enabled when VLAN tagging is set to Dot1Q or QinQ and autopick VLAN ID is not checked
Inner VLAN ID	Yes	Only available for QinQ VLAN tagging
Rate Limit	Yes	None
Interface Description	Yes	None

For an IP service order, the following node settings can be modified using the inline edit method:

Node, Hub, Stitching point

Parameter	Editable	Dependencies
Node	Yes	None
Hub	Yes	Only editable for Hub-and-spoke topologies
Stitching point	Yes	When hub is selected, stitching point must be disabled

For an IP service order, the following site settings can be modified using the inline edit method:

Node, Interface, Autopick Unit, Unit ID, VLAN tagging, Autopick VLAN ID, Outer VLAN ID, Inner VLAN ID, Auto pick IP, IP Address, Subnet

Parameter	Editable	Dependencies
Node	Yes	None
Interface	Yes	The Node name has to be configured

Status	No	None
Autopick Unit	Yes	None
Unit ID	Yes	Only enabled when autopick unit ID is not checked
VLAN tagging	Yes	Only enabled when the interface selected is not a loopback (lo0). For loopback interfaces the VLAN tagging should be set to disabled. For other ethernet-based interfaces, this should be a combo box with 3 options (Disabled, Dot1Q and QinQ)
Autopick VLAN ID	Yes	Enabled when VLAN tagging is set to Dot1Q or QinQ
Outer VLAN ID	Yes	Enabled when VLAN tagging is set to Dot1Q or QinQ and autopick VLAN ID is not checked
Inner VLAN ID	Yes	Only available for QinQ VLAN tagging
Auto pick IP	Yes	None
IP Address	Yes	If autopick is enabled this should be a combo box showing the available pools. If autopick is disabled, this should be an input text box allowing users to enter the IP
Subnet	Yes	None, when autopick is enabled this sets the block size. Then autopick is disabled it sets up the subnet size

RELATED DOCUMENTATION

[Modifying an E-Line Service | 1102](#)

[Modifying a Multipoint-to-Multipoint Ethernet Service | 1104](#)

[Modifying a Point-to-Multipoint Ethernet Service | 1111](#)

[Modifying a Hub-and-Spoke IP Service Order | 1120](#)

[Modifying a Full Mesh IP Service | 1137](#)

Interconnecting an IP Service with an E-LAN Service

You can stitch or interconnect an IP service with an E-LAN service. You must enable the stitching functionality to perform this interconnection. If the stitching capability is enabled, when you select the interfaces for the endpoints added to a service, only the integrated routing and bridging (IRB) physical and logical interfaces are available for selection. If you select a physical IRB interface, a new logical interface is created with the logical unit identifier of the interface you specify. If you select a logical IRB interface, the existing logical interface is used to create the service.

You can stitch or interconnect an IP service with an E-LAN service during the creation or modification of an IP service order. Follow the steps outlined in for performing the tasks in the Service Settings and Node Settings pages of the wizard. To enable the stitching of an IP service with an E-LAN service, you can select the Stitch check box for a device associated with the service order on the Site Settings page of the IP service order creation or modification wizard.

Before you begin:

- Ensure that you have already created an IP service.
- Complete the configuration of settings on the Service Settings and Node Settings pages of the service order creation or modification wizard.

To interconnect an IP service with an E-LAN service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the Tasks pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the Manage Network Services page, select **New > IP Service**.

The **Create IP Service Order** window appears and shows a filtered inventory view of only those published service definitions designed to work with multipoint Ethernet services. You can select the service definition based on the signaling type.

See [“Creating a Full Mesh IP Service Order” on page 995](#) and [“Creating a Hub-and-Spoke IP Service Order” on page 1019](#) for detailed information about the settings that you can configure on the Service Settings and Node Settings pages of the wizard.

7. After you complete the configuration of settings on the Service Settings and Node Settings pages of the service order creation or modification wizard, click **Site Settings** at the top of the wizard page.

The Site Settings page is displayed.

8. Select the check box beside the device for which you want to enable the stitching of E-LAN and IP services.

The device that you select is available for stitching.

9. Select the **Stitch** check box to enable the interconnection of the IP service with an E-LAN service.

10. Click inside the Interface Name field to select an IRB interface. A popup dialog box is displayed with the list of all configured IRB interfaces. If the stitching capability is enabled, when you select the interfaces for the endpoints added to a service, only the IRB physical and logical interfaces are available for selection.

11. Select a physical or logical IRB interface that you want to use to stitch the IP service with an E-LAN service.

The selected interface is used for interconnection of the services.

12. (Optional) If you select a physical IRB interface, you can specify the logical unit of the interface in the UNIT ID field.

The specified logical IRB interface is used for stitching the services.

13. For service orders associated with a service definition that contains a service template, click **Next** to modify the template settings.

14. Click **Review** to examine and modify the settings as necessary.

15. Click **Finish** when you have completed examining the settings to confirm the creation of the service order.
16. You can proceed to enable the stitching functionality for the same IRB interface with the E-LAN service. See [“Interconnecting an E-LAN Service with an IP Service” on page 990](#) for detailed information about enabling the stitching functionality for the E-LAN service.

RELATED DOCUMENTATION

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

[Interconnecting an E-LAN Service with an IP Service | 990](#)

Changing the Logical Loopback Interface for Provisioning

The loopback interface supports many different network and operational functions and is an *always-up* interface. This means that the loopback interface ensures that the device is reachable, even if some of the physical interfaces are down or removed, or an IP address has changed. In most cases, you always define a loopback interface.

Junos OS follows the IP convention of identifying the loopback interface as lo0.

Junos OS requires that the loopback interface always be configured with a /32 network mask, thus avoiding any unnecessary allocation of address space.

Typically, the VRF or virtual-router routing instance IP address is drawn from among the IP addresses associated with interfaces configured for that routing instance. If none of the interfaces associated with a VRF or virtual-router routing instance is configured with an IP address, you need to explicitly configure a logical loopback interface with an IP address. This interface must then be associated with the routing instance.

You change the logical unit of the loopback interface to be a logical unit other than unit 0 to be used as the default loopback logical interface for all provisioning tasks that are initiated from Connectivity Services Director

NOTE: Although Junos OS allows you to assign multiple loopback addresses to the same loopback unit, the Junos Space software recognizes only the first address assigned to the loopback unit. Therefore, when you change the loopback address of an N-PE device, it must be to that of a different loopback unit.

To change the logical unit of the loopback interface:

1. From the Junos Space user interface, click the **System** icon on the Connectivity Services Director banner.

The options that you can configure in System mode are displayed in a drop-down menu.

2. Select **Preferences** from the drop-down menu to open the Preferences page.

The Preferences page opens with User Preferences as the default tab.

3. Click the **Services Activation** tab to configure the services activation-related settings.

The settings that you can configure on the Services Activation tab are displayed.

4. Click the right arrow beside the **Prestage Device** section to expand it.

The parameters that you can configure for prestaging devices are displayed.

5. In the Loopback Unit field, specify the logical unit of the loopback interface that must be used as the default loopback logical interface for all provisioning tasks that are initiated from Connectivity Services Director. The default logical unit for the loopback interface is 0.

6. Click **OK** to save the settings. You are prompted to confirm the changes you made to services-activation preferences.

7. Click **Yes** to confirm. The Preferences page is closed. A dialog box is displayed to confirm the successful saving of the preferences. Click **OK** to close the dialog box.

RELATED DOCUMENTATION

Modifying the Application Settings of Connectivity Services Director | 1161

Service Provisioning: Managing E-LAN Service Orders

IN THIS CHAPTER

- [Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)
- [Creating a Point-to-Multipoint E-LAN Service Order | 964](#)
- [Creating a Service Order for VPLS Access into Layer 3 Networks | 985](#)
- [Creating an E-LAN Service Order with CFM | 987](#)
- [Interconnecting an E-LAN Service with an IP Service | 990](#)

Creating a Multipoint-to-Multipoint E-LAN Service Order

The Connectivity Services Director application implements multipoint-to-multipoint Ethernet services as E-LAN services.

To create a multipoint-to-multipoint Ethernet service order, complete these tasks in order:

1. [Selecting the Service Definition | 943](#)
2. [Entering Service Parameters Information | 945](#)
3. [Specifying CFM Settings | 952](#)
4. [Selecting N-PE Devices | 952](#)
5. [Specifying Node Settings | 953](#)
6. [Modifying Site Settings | 957](#)
7. [Specifying QoS Settings | 960](#)
8. [Specifying Template Settings | 960](#)
9. [Reviewing the Configured Settings | 962](#)
10. [Deploying the New Service | 963](#)

Selecting the Service Definition

To select a service definition on which to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Connectivity Services Director user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the Tasks pane, select **Service Provisioning > Manage Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the Manage Network Services page, select **New > E-LAN Service**.

The **Create E-LAN Service Order** window appears and shows a filtered inventory view of only those published service definitions designed to work with multipoint Ethernet services. You can select the service definition based on the signaling type.

The **Service Settings** page appears.

7. From the Service Definition field, click **Select** to choose the service definition you want to base your service order on. The Choose Service Definition inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

8. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.
9. Click **View** to open a popup dialog box that displays the details of the selected service definition. The service definition properties, such as the name, signaling type (LDP or BGP), service type (Ethernet, ATM, or TDM), are displayed. The interface-specific attributes, such as rate-limiting details, encapsulation,

and VLAN tags, are also displayed in the dialog box. Close the dialog box to return to the service order creation wizard.

10. (Optional) Select the **Enable LSP Association** check box to create or associate LSPs.

Select the **Create LSP** check box to import an existing LSP service definition and also select an LSP name pattern.

NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.

For information about creating an LSP name pattern, see [“Creating a Name Pattern for LSPs in the Service Order” on page 1794](#).

Select the **Associate LSP** check box to associate an existing LSP.

Entering Service Parameters Information

This part of the create multipoint Ethernet service order procedure sets general information about the service order in the **Service Settings** page of the Create E-LAN Service Order wizard:

A wizard is available to create a service order in an intuitive and easily-navigable format. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create a Service Order page. Alternatively, you can proceed to the corresponding setting-related pages by clicking the **Back** and **Next** buttons at any point in the wizard during the creation of the service order.

In the General Settings section of the Service Settings page, enter general settings or service parameters information by doing the following tasks:

1. In the **Name** field, type a unique name for the multipoint service.

The service order name can consist of only letters, numbers, and underscores.

NOTE: The name you specify for an E-LAN service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, “bgp” or “vpls”, as the name of a service order.

2. In the **Customer** field, select the customer requesting the service. To speed your search, type the first few letters of the customer name and then select from the list.

If the customer is not in the list, you must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

3. In the **Comments** field, provide a description of the service. This description appears in information windows about the request or service instance created from the request.

The **Customer traffic type** parameter is not selectable. Its value is set in the service definition.

QoS settings are added to a service order, depending on the configuration attributes that are defined in the service templates associated with it.

In the VPLS Settings section of the Service Settings page, enter the connectivity information by doing the following tasks:

The **Signaling** cannot be changed in the service order.

The **Instance type** and **Protocol** parameters are not selectable. Their values are set in the service definition.

The following check boxes are displayed based on the service definition you have selected:

- Enable PW Extension
- Enable PW Resiliency
- Allow access to L3 network
- Enable Multihoming

You cannot change these check boxes in the service order.

1. Specify whether the route distinguisher can be selected automatically or manually.

NOTE: You cannot edit the route distinguisher if you have not selected the **Editable in Service Order** check box in the service definition.

- To assign the route distinguisher automatically, select the **Autopick Route Distinguisher** check box.
- To assign the route distinguisher manually, clear the **Autopick Route Distinguisher** check box.

If you choose to assign the route distinguisher manually, the window expands to include the **Route distinguisher** field. In the **Route distinguisher** field, type a value. Junos Space accepts either of the following two formats:

- *prefix-number: assigned-number*

Where *prefix-number* can be any numeric value from 1 through 65,535, and *assigned-number* can be any numeric value from 0 through 2,147,483,647

- *IPV4-address: assigned-number*

Where *IPV4-address* can be any valid IPv4 address, and *assigned-number* can be any numeric value from 0 through 65,535

NOTE: The **Route distinguisher** field is available in either of the following cases:

- The **Signaling** type is BGP
- The **Signaling** type is LDP and **Auto Discovery** is enabled

2. Specify whether the route target can be selected automatically or manually.

NOTE: You cannot edit the route target if you have not selected the **Editable in Service Order** check box in the service definition.

- To assign the route target automatically, select the **Autopick Route target** check box.
- To assign the route target manually, clear the **Autopick Route target** check box.

If you choose to assign the route target manually, the window expands to include the **Route Target** field. In the **Route Target** field, type a value. Junos Space accepts either of the following two formats:

- *prefix-number:assigned-number*

Where *prefix-number* can be any numeric value from 1 through 65,535, and *assigned-number* can be any numeric value from 0 through 2,147,483,647

- *IPv4-address:assigned-number*

Where *IPv4-address* can be any valid IPv4 address, and *assigned-number* can be any numeric value from 0 through 65,535

NOTE: The **Route Target** field is available in either of the following cases:

- The **Signaling** type is BGP
- The **Signaling** type is LDP and **Auto Discovery** is enabled

3. In the **Revert time (sec)** field, specify the revert time for redundant Layer 2 circuits and VPLS pseudowires.

Default: 5 seconds

Range: 0 through 65,535 seconds

This field is available only if you have enabled the **Enable PW Resiliency** check box in the selected service definition.

4. In the **Switch Over Delay (sec)** field, specify the time to wait before the backup pseudowire takes over.

Default: 0 seconds

Range: 0 through 180 seconds

This field is available only if you have enabled the **Enable PW Resiliency** check box in the selected service definition.

5. If **Autopick VPLS ID** is disabled, specify the **VPLS ID**.

Range: 1 through 2147483647

NOTE: If the signaling type is LDP and if auto discovery is enabled, **Autopick VPLS ID** appears dimmed. This field is not editable in the service order.

If the signaling type is BGP, **Autopick VPLS ID** is not available.

6. If **Autopick VPN ID** is enabled, specify the **VPN ID**.

Range: 1 through 65535

NOTE: If the signaling type is LDP and if auto discovery is enabled, **Autopick VPN ID** appears dimmed. This field is not editable in the service order.

If the signaling type is BGP, **Autopick VPN ID** is not available.

7. Select the **Autopick Hub Route Target** and **Autopick Spoke Route Target** check boxes if you want the Route target chosen automatically by the Network Activate software.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

To manually assign a Route target:

1. Clear the **Autopick Hub Route Target** and **Autopick Spoke Route Target** check boxes to activate the **Hub Route Target** and **Spoke Route Target** fields respectively.
2. In the **Route Target** field, enter a value.

When you manually enter route target, Junos Space accepts either of the following two formats:

- *<prefix-number>: <assigned-number>*

Where *<prefix-number>* can be any numeric value from 1 to 65535, inclusive. The *<assigned-number>* can be any numeric value from 0 to 2,147,483,647, inclusive.

- *<IPV4-address>: <assigned-number>*

Where *<IPV4-address>* can be any valid IPV4 address (in W.X.Y.Z "dot" notation), and *<assigned-number>* can be any numeric value from 0 to 65535, inclusive.

In the Site Settings section of the Service Settings page, enter the endpoint or device settings information by doing the following tasks:

1. Select a value for **Ethernet option**.

- **Port**
- **Dot1Q**

Specifying the **Dot1Q** Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN List to the service order.

- **QinQ**

Specifying the **QinQ** Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN List to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).

2. In the **Bandwidth** field, select a value from the list to limit the bandwidth of the service you are creating.

This field is present only if bandwidth limiting is allowed by the service definition, and is configurable in the service order only if the service definition allows it.

3. In the **MTU** field, type the maximum transmission unit size for the UNI.

This field is present in all service orders. However, you can set this field only if the service definition allows it.

The **Auto-pick VLAN range constraint** field is displayed and validates the VLAN range specified in the service definition.

4. Specify the Logical interface settings:

NOTE: The **Autopick Interface Unit ID** field is not available if you have selected the **Ethernet option** as Port.

- Specify whether the **Autopick Interface Unit ID** can be selected automatically or manually.
 - To assign the **Unit** automatically, select the **Autopick Interface Unit ID** check box.
 - To assign the **Unit** manually, clear the **Autopick Interface Unit ID** check box.

The window expands to include the **Unit** field. In the **Unit** field, type a value.

Range: 1 through 1073741823

NOTE: You can edit this field only if you have selected the **Editable in Service Order** check box for the **VLAN ID selection** in the service definition.

- Specify whether the **Autopick VLAN ID** can be selected automatically or manually.
 - To assign the **VLAN ID** automatically, select the **Autopick VLAN ID** check box.
 - To assign the **VLAN ID** manually, clear the **Autopick VLAN ID** check box.

The window expands to include the **VLAN ID** field. In the **VLAN ID** field, type a value.

5. Select the preferred option for calculating the burst size:

- **MTU Based**

If you select the option **MTU Based**, you can specify a value for **MTU Factor** in the range 1 through 1087902.

The default value for **MTU Factor** is 10.

- **Line Rate Based**

If you select the option **Line Rate Based**, you can specify a value for **Burst Period** in the range 1 through 7450 milliseconds.

The default value for **Burst Period** is 1.

6. In the **Customer VLAN Range Start** and **Customer VLAN Range End** fields, type the first and last VLAN ID of the range of customer VLANs to be transported over the network.

These fields are present only for services with UNIs that have Q-in-Q interface types and allow a range of VLANs to be transported.

7. In the **Normalize - VLAN ID Tag** field, type a value for the customer VLAN.

This field is present only for services that specify Normalize to Dot1q tags.

8. In the **Normalize - Inner VLAN Tag (for QinQ)** field, type a value to provide a default inner VLAN tag for the UNI endpoints.

This field is present only for services that specify Normalize to QinQ tags.

9. In the **Normalize - Outer VLAN Tag** field, type a value to provide an outer VLAN tag that matches the Outer VLAN tag of at least one of the UNI endpoints.

This field is present only for services that specify Normalize to QinQ tags.

10. Click **Next** to proceed to the subsequent step of the wizard, which is to define the node or endpoint parameters.

Specifying CFM Settings

To enable CFM on the service definition, type information in the CFM Settings of the Service Settings page of the wizard.

1. In the **CFM Profile** field, select a profile from the list.

NOTE: For CFM Settings, if you specify a CFM profile (for example, a CFM action profile with remote MEP), first you must ensure that the profile is attached to the same device upon which you intend to deploy the E-Line service order. If the profile is not previously attached (using the CFM Insight application), it will not be present on the device to support the service order.

To remove a previously associated CFM definition or CFM profile from a service definition, click the **Detach** button next to the CFM Profile field to remove the association. To associate a new CFM profile, you must dissociate the existing CFM profile and attach a fresh CFM profile. Detaching an CFM profile is enabled when you modify a service or service order.

NOTE: For Juniper Networks PTX3000 Packet Transport Routers and Junos Space Release 13.1P1, if you attach a CFM Definition to the service order, the CFM session will operate for MEPs in either the Up or Down direction when the service is deployed.

2. Click **CFM Details** beside the CFM Profile field to view the profile configuration details in a dialog box.
3. Continue with specifying the endpoint information.

Selecting N-PE Devices

This part of the create multipoint Ethernet service order procedure selects the N-PE devices. The selection is made from the **Node Settings** page of the Create E-LAN Service Order wizard.

If there is a service template attached to the service definition, there is a link to that template at the bottom of the **Node Settings** section of the window. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

NOTE: The inline grid of the **Node Settings** page shows only assigned NPE devices that have an AS number configured. If you do not see the device you are looking for, use the CLI on the device to check for and assign an AS number.

1. From the drop down, select the interface that you want to associate with the service.
2. Click **OK**.

The **Node Settings** window appears.

3. Continue with modifying or entering the node parameters.

Specifying Node Settings

This part of the create multipoint Ethernet service order procedure sets the attributes that are usually common for all endpoints in the service.

NOTE: If you are using a definition with multiple templates, you can set different attributes for the endpoints.

In any case, the values that you type depend on the service definition on which the service order is based. Follow the steps in one of the following tasks, depending on whether or not the service provides flexible VLAN tagging. To create a service with flexible VLAN tagging, the service definition that you selected for the service order must include the Ethernet option **asymmetric tag depth** in the UNI settings step.

- [Setting Attributes for Nodes or Devices on a Service | 953](#)
- [Setting Attributes for Nodes or Devices on a Service with Flexible VLAN Tagging | 956](#)

Setting Attributes for Nodes or Devices on a Service

If these attributes are not the same on all endpoints, you can set them to be the same for now and then make changes later, or you can choose to skip this step and apply the attribute values one at a time later, or use a definition with multiple templates.

This procedure sets the attributes listed in the Node Settings page of the of the Create E-LAN Service Order wizard. The attributes shown depend on the interface type and the signaling type.

The Node Settings page displays configuration attributes for the device selected in the table of all added nodes. If multiple devices are selected, data is displayed beneath the table for the last selected device. If you do not select a device, the service definition details for nodes are displayed.

To set attributes common to most endpoints:

1. Fill in the following fields under the MAC Settings section

Field	Action
MAC Settings	
MAC learning	To enable MAC learning , select the check box.
Interface MAC limit	Maximum number of MAC addresses learned from an interface. Range: 1 through 131071 MAC addresses per interface
MAC statistics	To enable MAC statistic , select the check box.
MAC Table Size	Modify the size of the MAC address table for the bridge domain. Range: 16 through 1048575 To allow the service provisioner to override the MAC settings, select Editable in Service Order .

2. If **Multihoming** check box is selected in the service definition, a **Multi-Homing Settings** section, with **MH Role** and **Peer Node** tabs, is available.

To define primary and backup PE devices, select **primary** and **backup**, respectively, from the MH Role tab.

You can select peer nodes for the chosen devices from the list.

3. Fill in the following fields under the Topology Settings section.
 - a. In the Topology field, the type of network connection or circuit is displayed as E-LAN (MultiPoint-to-MultiPoint) or E-LAN (Point-to-MultiPoint), based on the type of service definition selected. In this case, the topology is shown as multipoint-to-multipoint.
 - b. Define a route distinguisher option from the **Auto Pick Route Distinguisher** check box and **Route Distinguisher** field:
 - Select the check box to enable the service provider to specify the route distinguisher.
 - Select the check box to enable the route distinguisher to be selected automatically.

4. Fill in the following fields under the Advanced Settings section.

Advanced Settings—This section enables you to specify the parameters that define advanced connectivity between sites across the service provider network. Configuring advanced settings is optional. You can click on the Advanced link to view the default values for Advanced Settings. If the advanced settings can be edited in the service order, you can override the default values. If you do not click the Advanced link, the default advanced settings are applied to the service order.

Include	<p>Select the Include check box for each advanced setting that you want to include in the service definition.</p> <p>NOTE: If you select any advanced parameters for a service definition, you must also select the Include check box for the Disable tunnel services parameter, and select or clear the Disable tunnel services check box.</p> <p>For MX Series devices, if you deploy an E-LAN service without selecting the Include check box for Disable tunnel services parameter, the E-LAN service is down. As a work around, you can push the configuration to each PE device for the service by running the following command:</p> <pre>root@test_device# set chassis fpc 0 pic 1 tunnel-services bandwidth 1g</pre>
Disable Tunnel Services	<p>Enable or disable tunnel-services to specify that traffic for particular VPLS routing instances be forwarded to specific virtual tunnel (VT) interfaces.</p> <ul style="list-style-type: none"> • To enable tunnel-services, clear the Disable Tunnel Services check box. • To disable tunnel-services, select the Disable Tunnel Services check box (default).
Disable Local Switching	<p>Enable or disable local switching. In local switching mode, you can terminate multiple Layer 2 circuit pseudowires at a single VPLS mesh group:</p> <ul style="list-style-type: none"> • To enable local switching across the network, clear the Disable Local Switching check box. • To disable local switching across the network, select the Disable Local Switching check box (default).
Fast Reroute-Priority	<p>In this drop-down list, specify the reroute priority for a VPLS routing instance:</p> <ul style="list-style-type: none"> • HIGH—Set the fast reroute priority for a VPLS routing instance to high. During a fast reroute event, the router repairs next hops for high-priority VPLS routing instances first. • MEDIUM—Set the fast reroute priority for a VPLS routing instance to medium. During a fast reroute event, the router repairs next hops for medium-priority VPLS instances after high-priority VPLS routing instances but before low-priority VPLS routing instances. • LOW—Set the fast reroute priority for a VPLS routing instance to low, which is the default. During a fast reroute event, the router repairs next hops for low-priority VPLS routing instances last.

Label Block Size	<p>Configure the label block size for VPLS labels by using one of the following values.</p> <ul style="list-style-type: none"> • 2—Allocate the label blocks in increments of 2. Use this setting for a VPLS domain that has only two sites with no future expansion plans. • 4—Allocate the label blocks in increments of 4. • 8 —Allocate the label blocks in increments of 8. This is the default. • 16—Allocate the label blocks in increments of 16. A label block size of 16 enables you to minimize the number of routes in the VPLS domain. Use this setting only if the number of routes is the primary concern. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery check box is enabled.</p>
Connectivity type	<p>Select a connection-type to specify when a VPLS connection is taken down, depending on whether the interface for the VPLS routing instance is customer-facing or integrated routing and bridging (IRB):</p> <ul style="list-style-type: none"> • ce—Require that for the VPLS connection to be up, the customer-facing interface for the VPLS routing instance must also be up. If the customer-facing interface fails, the VPLS connection is taken down. This is the default. • irb—Allow a VPLS connection to remain up so long as an IRB interface is configured for the VPLS routing instance. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery is enabled.</p>

5. Click **Next**.

The **Site Settings** page of the Create E-LAN Service Order wizard appears.

6. Continue with specifying the UNI or interface settings.

Setting Attributes for Nodes or Devices on a Service with Flexible VLAN Tagging

A service with flexible VLAN tagging can include port-based, 802.1Q, and Q-in-Q interfaces.

If these attributes are not the same on all endpoints, you can set them to be the same for now and then make changes later, or you can choose to skip this step and apply the attribute values one at a time later, or you can use a definition with multiple templates.

If there is a service template attached to the service definition, there is a link to that template at the bottom of the **Node Settings** page of the wizard. For instructions on working with service templates in service orders.

This procedure sets the attributes listed in the Node Settings page of the of the Create E-LAN Service Order wizard. The attributes shown depend on the signaling type and interface type. The following example

shows the endpoints settings box for a multipoint-to-multipoint service with flexible VLAN tagging that transports a single VLAN and specifies Normalize to Dot1Q tag.

Modifying Site Settings

This part of the create multipoint Ethernet service order procedure sets the attributes for each interface of an endpoint or a device in the service. Selection is made using the **Site Settings** page of the wizard that enables you to create an E-LAN service order.

This window shows one interface for each device that you selected from the inline grid of the Node Settings page, as described in [“Selecting N-PE Devices” on page 952](#).

The Site Settings page enables you to select a device to add interfaces for that device. You can select multiple interfaces for the device. If the Enable L3 Access check box is enabled, the UNI lists available integrated routing and bridging (IRB) interfaces for the selected device. If the device role is a P2P spoke, you can select one UNI and it is required for such devices. If Ethernet Option is set as port-to-port, the UNI can be added only once as an endpoint for the device.

The interface shown in the **UNI Interface** field is automatically selected by the Connectivity Services Director application, which chooses the UNI that has the highest available capacity among interfaces that are in the Up state. To calculate the available capacity of the interface, the system subtracts the bandwidth reserved for each service deployed on that interface from the total capacity of the interface.

For each endpoint, the **Site Settings** page shows the following value for each UNI attribute:

- For port-to-port services, the displayed values are Bandwidth and MTU.
- For 802.1Q UNIs, the displayed attributes are Bandwidth, Autopick VLAN ID, VLAN ID, and MTU.
- For Q-in-Q UNIs, the displayed attributes include Bandwidth, AutoPick VLAN ID, and VLAN ID. For a service with Q-in-Q UNIs that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.

For each endpoint on a service with flexible VLAN tagging, the Endpoint Settings window shows the following value for each UNI attribute:

- For a service with flexible VLAN tagging that transports a single VLAN and specifies Normalize to Dot1q tags, the displayed attributes include Ethernet Option, Bandwidth, AutoPick VLAN ID, Inner VLAN ID, and MTU. For a service with flexible VLAN tagging that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.
- For a service with flexible VLAN tagging that transports a single VLAN and specifies Normalized to QinQ tags, the displayed attributes include Bandwidth, AutoPick VLAN ID, and VLAN ID. For a service with flexible VLAN tagging that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.

- For a service with flexible VLAN tagging that transports a VLAN range, the displayed attributes include Bandwidth, AutoPick VLAN ID, and VLAN ID. For a service with flexible VLAN tagging that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.

The values shown are initially the values you set earlier on the Service Settings page of the creation of E-LAN service order wizard, as described in [“Specifying Node Settings” on page 953](#).

To add a UNI and specify its settings:

1. Click the **Add** icon at the top of the Site Settings grid. The endpoints are displayed in the inline grid.
2. Select the check box next to the endpoint or device from which you want to add a UNI to the service order.
3. Click **OK** to save the settings. You are returned to the Site Settings page.
4. For a service with flexible VLAN tagging, set the interface type in the Ethernet Option column for each endpoint in the service.
5. To select a different UNI on a device, from the **User-to-Network Interfaces** section, click the UNI name you want to change and choose another interface from the list.
6. Select the **Enable CFM** check box beside a particular interface of a device in the service order creation and modification wizards to enable connectivity fault management (CFM) on the interface. Based on your network needs, you can create a point-to-multipoint and a multipoint-to- multipoint E-LAN service with service-level CFM enabled. The CFM profile is propagated to a single endpoint when multiple interfaces are selected for a given device (the last interface overrides the other configurations). When you select the **Enable CFM** check box for an interface of a particular device, you cannot enable CFM on other interfaces of the same device. The CFM configuration is pushed only on the selected interface. When you delete the interface with CFM enabled, the CFM configuration on the particular device is also removed. When you attempt to delete an interface with CFM enabled, you are prompted to confirm the deletion.
7. In the **Customer VLAN Range Start** and **Customer VLAN Range End** fields, type the first and last VLAN ID of the range of customer VLANs to be transported over the network.

These fields are present only for services with UNIs that have Q-in-Q interface types and allow a range of VLANs to be transported.

8. Select a value for **Ethernet option**.
 - Port
 - Dot1Q

Specifying the **Dot1Q** Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN List to the service order.

- **QinQ**

Specifying the **QinQ** Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN List to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).

9. To enter the description for an UNI interface, click the corresponding **Description** cell.

10. To change the bandwidth on an endpoint, click the bandwidth value for the endpoint and select another value from the list.

11. The **AutoPick Interface Unit ID** and the **Unit ID** columns appear, if you have not selected the **Ethernet option** as port-to-port.

- To change an automatically selected service UNIT ID to manual selection, clear the **AutoPick Interface Unit ID** check box, and type a service UNIT ID value in the **Unit ID** field.
- To change from manual selection to automatic selection, select the **AutoPick Interface Unit ID** check box.
- To change the value of a manually selected service Unit ID, type a new value in the **Unit ID** field.

NOTE: The unit ID value that you have specified in the Enter Order Information page is displayed in the **Unit ID** field.

12. For Q-in-Q interface endpoints, you can change how the service VLAN ID is selected:

- To change an automatically selected service VLAN ID to manual selection, clear the **AutoPick VLAN ID** check box, and type an VLAN ID value in the **VLAN ID** field.
- To change from manual selection to automatic selection, select the **AutoPick VLAN ID** check box.
- To change the value of a manually selected service VLAN ID, type a new value in the **VLAN ID** field.

13. For Q-in-Q interface endpoints with customer VLAN ranges specified, you can also change the range limits for an endpoint.

14. For 802.1Q interface endpoints, you can change the customer VLAN ID.

15. To change the MTU for the UNI, click the value in the **MTU** field and type a new value.

16. To add a UNI on a selected device, click **Add** to open the Choose Endpoints dialog box and then select the interface you want from the UNI interface list.

17. If the interface you selected in the previous step is already configured (duplicate) you must either type a different value in the **VLAN ID** field manually, or check the **Autopick VLAN ID** field.
18. To delete a UNI from a device, select the interface and click **Delete** in the table that displays the UNIs.
If the deleted UNI is the only UNI selected from the device, then the device is deleted from the service configuration.
19. When you have finished modifying the endpoint settings, click **Review** to examine and modify the settings.
20. For service orders associated with a service definition that contains a service template, click **Next** to modify the template settings.
21. Click **Finish** when you have completed examining the settings to confirm the creation of the service order.
22. You can proceed with deploying the service.

Specifying QoS Settings

CoS profiles enable the grouping of class-of-service (CoS) parameters and apply them to one or more interfaces. Connectivity Services Director provides you with predefined traffic types for each CoS profile that you create. These traffic types represent the most common types of traffic for the device type. Each of these templates has preconfigured values for all CoS parameters based on the typical application requirements. You can change the preconfigured values of these parameters to suit your requirements. To display the CoS Profiles page, in Build mode, select CoS under Profile and Configuration Management in the Tasks pane. The Manage CoS Profiles page appears.

If QoS is enabled on the service definition, configure the QoS Settings of the Site Settings panel of the service order creation wizard.

1. In the **QoS profile** field, select a profile from the list.

The **QoS profile** list displays the QoS profiles that are currently configured in the Manage CoS Profiles page of the Connectivity Services Director application.

A QoS profile classifies traffic into defined service groups to provide the special treatment of traffic across the network service.

Specifying Template Settings

The Template Settings page of the service order creation and modification wizards enables you to associate service templates with an E-Line, E-LAN, and IP service order. You can apply only the templates that are

previously configured in a service definition with the corresponding service order. The Template Settings page is available in the service order wizard only if the service definition that you selected to apply to the service order contains a service template. Otherwise, the Template Settings page is not displayed in the service order wizard. You can perform template operations for all endpoints in a service order.

If you defined a service template as the default service template, it is attached to the endpoint by default. You have the flexibility to create and provision a dynamic attribute in a service template. You can mark an attribute of a service template as dynamic, and you can obtain the values for these dynamic attributes from a specific device. To create a dynamic attribute, you must first mark an attribute of a service template as dynamic and then specify the device XPath for the dynamic attribute.

The Template Settings page is displayed before the Review page, which is the final step of the service order wizard.

In the Service Settings page of the Select Service Definition field of the service order creation wizard, you can double-click a service definition name displayed in the table to view the details of the definition in a popup dialog box. You can use this information to determine if the service definition is appropriate for your deployment needs. To filter and sort the display of service templates, enter the name of the template as a match criterion in the Search box and click the Search icon. The page refreshes to display only the template names that match with the search term. You can use the paging controls to navigate across multiple pages of templates as necessary.

All the tasks that you can perform with service templates are presented in the Template Settings page. The page is divided into three panes. The top half of the page displays a table of selected endpoints. All the endpoints or UNIs that you selected in the preceding pages of the service order wizard are displayed in this table. You can configure the template pertaining to only one endpoint at a point in time. If the selected endpoints (in previous pages of the wizard) contained a manually-entered unit number, that number is displayed in the table of selected endpoints. Otherwise, the Auto-pick label is displayed.

The lower half of the page is divided into two panes. The left pane displays the template selection table for the endpoint you selected. All the templates associated with the service definition are displayed. You can add and delete templates using the template selection table. The right pane displays all the parameters that you can modify for a selected service template. All such editable parameters are displayed in a consolidated form of a configuration page. This pane is displayed after you select a template. If any configuration parameter in template is set as a service-specific value, such attributes are not displayed in this pane.

To associate a service template with a service order:

1. Click **Add** to include a service template for the endpoint. A dialog box is displayed with the list of service templates associated with the service definition that is used to create the service order. The templates selected in this dialog box are displayed in the Template Selection table for the specified endpoint. Such templates are considered to be attached to that endpoint.

If you specified a template as a default template during the service definition creation, the template is displayed by default in the template selection table. You can associate non-default templates with the service order by clicking the **Add** button.

2. Click the link in the template name to open the Template Details dialog box. The template settings are displayed in the popup dialog box. For the selected template, the Configuration Page is displayed in the lower-right pane of the Template Settings page.
3. Modify any template-specific service components as necessary.
4. Click **Save** to submit the changes.
5. Select a template from the Template Selection table, and click **Delete** to remove the template from being associated with the service order for a particular endpoint.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

NOTE: On the Review page, in the Service Templates section, the names of the service templates with which the service definition is associated are displayed. The Default Service Template column indicates whether the attached template is the default template.

To examine the configured service settings:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

Deploying the New Service

This part of the create multipoint Ethernet service order procedure deploys the service.

To deploy the service from the **Manage Deploy Services** window:

1. Perform one of the following actions in the Deploy mode of the Service View of Connectivity Services Director:
 - To deploy the service immediately, select **Deploy now**, then click **OK**.
 - To deploy the service later, select **Schedule deployment**, select a date and time, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.

2. To monitor the status of the deployment, use the Jobs workspace.

The service order is now complete.

The **Manage Service Orders** page shows the service order you just added.

RELATED DOCUMENTATION

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

[Creating a Service Order for VPLS Access into Layer 3 Networks | 985](#)

Creating a Point-to-Multipoint E-LAN Service Order

IN THIS SECTION

- [Selecting the Service Definition | 964](#)
- [Entering Service Parameters Information | 966](#)
- [Specifying CFM Settings | 971](#)
- [Selecting N-PE Devices | 972](#)
- [Specifying Node Settings | 973](#)
- [Modifying Site Settings | 978](#)
- [Specifying QoS Settings | 982](#)
- [Specifying Template Settings | 982](#)
- [Reviewing the Configured Settings | 983](#)
- [Deploying the New Service | 984](#)

The Connectivity Services Director application implements point-to-multipoint Ethernet services as E-LAN services. These services are also referred to as hub-and-spoke services.

To create a point-to-multipoint Ethernet service order, complete the following tasks in order:

Selecting the Service Definition

To select a service definition on which to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP Ethernet service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the Tasks pane, select **Service Provisioning > Manage Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the **Manage Network Services** page, select **New > E-LAN Service**.

The **Create E-LAN Service Order** window appears and shows a filtered inventory view of only those published service definitions designed to work with point-to-multipoint Ethernet services. You can select the service definition based on the signaling type.

The **Service Settings** page appears.

7. From the Service Definition field, click **Select** to choose the service definition you want to base your service order on. The Choose Service Definition inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

8. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.
9. Click **View** to open a popup dialog box that displays the details of the selected service definition. The service definition properties, such as the name, signaling type (LDP or BGP), service type (Ethernet, ATM, or TDM), are displayed. The interface-specific attributes, such as rate-limiting details, encapsulation, and VLAN tags, are also displayed in the dialog box. Close the dialog box to return to the service order creation wizard.

If a template is attached to the service definition on which the service order is based, you can invoke the template editor from the Template page of the wizard.

10. (Optional) Select the **Enable LSP Association** check box to create or associate LSPs.

Select the **Create LSP** check box to import an existing LSP service definition and also select an LSP name pattern.

NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.

For information about creating an LSP name pattern, see [“Creating a Name Pattern for LSPs in the Service Order” on page 1794](#).

Select the **Associate LSP** check box to associate an existing LSP.

Entering Service Parameters Information

This part of the create point-to-multipoint Ethernet service order procedure sets general information about the service order in the **Service Settings** page of the Create E-LAN Service Order wizard:

A wizard is available to create a service order in an intuitive and easily-navigable format. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create a Service Order page. Alternatively, you can proceed to the corresponding setting-related pages by clicking the **Back** and **Next** buttons at any point in the wizard during the creation of the service order.

In the General Settings section of the Service Parameters page, enter general settings or service parameters information by doing the following tasks:

1. In the **Name** field, type a unique name for the multipoint service.

The service order name can consist of only letters, numbers, and underscores.

NOTE: The name you specify for an E-LAN service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, “bgp” or “vpls”, as the name of a service order.

2. In the **Customer** field, select the customer requesting the service. To speed your search, type the first few letters of the customer name and then select from the list.

If the customer is not in the list, you must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

3. In the **Comments** field, provide a description of the service. This description appears in information windows about the request or service instance created from the request.

The **Customer traffic type** parameter is not selectable. Its value is set in the service definition.

QoS settings are added to a service order, depending on the configuration attributes that are defined in the service templates associated with it.

4. The **Instance type** and **Protocol** parameters are not selectable. Their values are set in the service definition.

In the VPLS Settings section of the Service Settings page, enter the connectivity information by doing the following tasks:

The **Signaling** cannot be changed in the service order.

The following check boxes are displayed based on the service definition you have selected:

- Enable PW Extension
- Enable PW Resiliency
- Allow L3 access
- Allow Multihoming

You cannot change these check boxes in the service order.

1. Specify whether the route distinguisher can be selected automatically or manually.

NOTE: You cannot edit the route distinguisher if you have not selected the **Editable in Service Order** check box in the service definition.

- To assign the route distinguisher automatically, select the **Autopick Route Distinguisher** check box.
- To assign the route distinguisher manually, clear the **Autopick Route Distinguisher** check box.

If you choose to assign the route distinguisher manually, the window expands to include the **Route distinguisher** field. In the **Route distinguisher** field, type a value. Junos Space accepts either of the following two formats:

- *prefix-number: assigned-number*

Where *prefix-number* can be any numeric value from 1 through 65,535, and *assigned-number* can be any numeric value from 0 through 2,147,483,647

- *IPv4-address: assigned-number*

Where *IPv4-address* can be any valid IPv4 address, and *assigned-number* can be any numeric value from 0 through 65,535

NOTE: The **Route distinguisher** field is available in either of the following cases:

- The **Signaling** type is BGP
- The **Signaling** type is LDP and **Auto Discovery** is enabled

2. Specify whether the route target can be selected automatically or manually.

NOTE: You cannot edit the route target if you have not selected the **Editable in Service Order** check box in the service definition.

- To assign the route target automatically, select the **Autopick Route target** check box.
- To assign the route target manually, clear the **Autopick Route target** check box.

If you choose to assign the route target manually, the window expands to include the **Route Target** field. In the **Route Target** field, type a value. Junos Space accepts either of the following two formats:

- *prefix-number:assigned-number*

Where *prefix-number* can be any numeric value from 1 through 65,535, and *assigned-number* can be any numeric value from 0 through 2,147,483,647

- *IPV4-address:assigned-number*

Where *IPV4-address* can be any valid IPv4 address, and *assigned-number* can be any numeric value from 0 through 65,535

NOTE: The **Route Target** field is available in either of the following cases:

- The **Signaling** type is BGP
- The **Signaling** type is LDP and **Auto Discovery** is enabled

3. In the **Revert time (sec)** field, specify the revert time for redundant Layer 2 circuits and VPLS pseudowires.

Default: 5 seconds

Range: 0 through 65,535 seconds

This field is available only if you have enabled the **Enable PW Resiliency** check box in the selected service definition.

4. In the **Switch Over Delay (sec)** field, specify the time to wait before the backup pseudowire takes over.

Default: 0 seconds

Range: 0 through 180 seconds

This field is available only if you have enabled the **Enable PW Resiliency** check box in the selected service definition.

5. If **Autopick VPLS ID** is disabled, specify the **VPLS ID**.

Range: 1 through 2147483647

NOTE: If the signaling type is LDP and if auto discovery is enabled, **Autopick VPLS ID** appears dimmed. This field is not editable in the service order.

If the signaling type is BGP, **Autopick VPLS ID** is not available.

6. If **Autopick VPN ID** is enabled, specify the **VPN ID**.

Range: 1 through 65535

NOTE: If the signaling type is LDP and if auto discovery is enabled, **Autopick VPN ID** appears dimmed. This field is not editable in the service order.

If the signaling type is BGP, **Autopick VPN ID** is not available.

7. Select the **Autopick Hub Route Target** and **Autopick Spoke Route Target** check boxes if you want the Route target chosen automatically by the Network Activate software.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

To manually assign a Route target:

1. Clear the **Autopick Hub Route Target** and **Autopick Spoke Route Target** check boxes to activate the **Hub Route Target** and **Spoke Route Target** fields respectively.
2. In the **Route Target** field, enter a value.

When you manually enter route target, Junos Space accepts either of the following two formats:

- *<prefix-number>: <assigned-number>*

Where *<prefix-number>* can be any numeric value from 1 to 65535, inclusive. The *<assigned-number>* can be any numeric value from 0 to 2,147,483,647, inclusive.

- *<IPV4-address>: <assigned-number>*

Where *<IPV4-address>* can be any valid IPV4 address (in W.X.Y.Z "dot" notation), and *<assigned-number>* can be any numeric value from 0 to 65535, inclusive.

In the Site Settings page, enter the endpoint or device settings information by doing the following tasks:

1. Select a value for **Ethernet option**.

- **Port**
- **Dot1Q**

Specifying the **Dot1Q** Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN list to the service order.

- **QinQ**

Specifying the **QinQ** Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN list to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).

2. In the **Bandwidth** field, select a value from the list to limit the bandwidth of the service you are creating.

This field is present only if bandwidth limiting is allowed by the service definition, and is configurable in the service order only if the service definition allows it.

3. In the **MTU** field, type the maximum transmission unit size for the UNI.

This field is present in all service orders. However, you can set this field only if the service definition allows it.

The **Auto-pick VLAN range constraint** field is displayed and validates the VLAN range specified in the service definition.

4. Specify the Logical interface settings:

NOTE: The **Autopick Interface Unit ID** field is not available if you have selected the **Ethernet option** as Port.

- Specify whether the **Autopick Interface Unit ID** can be selected automatically or manually.
 - To assign the **Unit** automatically, select the **Autopick Interface Unit ID** check box.
 - To assign the **Unit** manually, clear the **Autopick Interface Unit ID** check box.

The window expands to include the **Unit** field. In the **Unit** field, type a value.

Range: 1 through 1073741823

NOTE: You can edit this field only if you have selected the **Editable in Service Order** check box for the **VLAN ID selection** in the service definition.

- Specify whether the **Autopick VLAN ID** can be selected automatically or manually.
 - To assign the **VLAN ID** automatically, select the **Autopick VLAN ID** check box.
 - To assign the **VLAN ID** manually, clear the **Autopick VLAN ID** check box.

The window expands to include the **VLAN ID** field. In the **VLAN ID** field, type a value.

5. Select the preferred option for calculating the burst size:

- **MTU Based**

If you select the option **MTU Based**, you can specify a value for **MTU Factor** in the range 1 through 1087902.

The default value for **MTU Factor** is 10.

- **Line Rate Based**

If you select the option **Line Rate Based**, you can specify a value for **Burst Period** in the range 1 through 7450 milliseconds.

The default value for **Burst Period** is 1.

6. In the **Customer VLAN Range Start** and **Customer VLAN Range End** fields, type the first and last VLAN ID of the range of customer VLANs to be transported over the network.

These fields are present only for services with UNIs that have Q-in-Q interface types and allow a range of VLANs to be transported.

7. In the **Normalize - VLAN ID Tag** field, type a value for the customer VLAN.

This field is present only for services that specify Normalize to Dot1q tags.

8. In the Inner **Normalize - Inner VLAN Tag (for QinQ)** field, type a value to provide a default inner VLAN tag for the UNI endpoints.

This field is present only for services that specify Normalize to QinQ tags.

9. In the **Normalize - Outer VLAN Tag** field, type a value to provide an outer VLAN tag that matches the Outer VLAN tag of at least one of the UNI endpoints.

This field is present only for services that specify Normalize to QinQ tags.

10. Click **Next** to proceed to the next step of the wizard, which is to define the node or endpoint parameters.

Specifying CFM Settings

To enable CFM on the service order, type information in the CFM Settings of the Service Parameters page of the wizard.

1. In the **CFM Profile** field, select a profile from the list.

NOTE: For CFM Settings, if you specify a CFM profile (for example, a CFM action profile with remote MEP), , first you must ensure that the profile is attached to the same device upon which you intend to deploy the E-LAN service order. If the profile is not previously attached (using the CFM Insight application), it will not be present on the device to support the service order.

To remove a previously associated CFM definition or CFM profile from a service definition, click the **Detach** button next to the CFM Profile field to remove the association. To associate a new CFM profile, you must dissociate the existing CFM profile and attach a fresh CFM profile. Detaching an CFM profile is enabled when you modify a service or service order.

NOTE: For Juniper Networks PTX3000 Packet Transport Routers and Junos Space Release 13.1P1, if you attach a CFM Definition to the service order, the CFM session will operate for MEPs in either the Up or Down direction when the service is deployed.

2. Click **CFM Details** beside the CFM Profile field to view the profile configuration details in a dialog box.
3. Continue with specifying the endpoint information.

Selecting N-PE Devices

This part of the create point-to-multipoint Ethernet service order procedure selects the N-PE devices. The selection is made from the **Node Settings** page of the Create E-LAN Service Order wizard.

If there is a service template attached to the service definition, there is a link to that template at the bottom of the **Node Settings** section of the window. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

NOTE: The inline grid of the **Node Settings** page shows only assigned N-PE devices that have an AS number configured. If you do not see the device you are looking for, use the CLI on the device to check for and assign an AS number.

To select endpoint N-PE devices:

1. In the **Node Settings** page, click the **Add** icon at the top of the Node Settings grid. From the dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices.
2. From the drop down, select the interface that you want to associate with the service.
3. Click **OK**.

The **Node Settings** window appears.

4. Continue with modifying or entering the node parameters.

Specifying Node Settings

This part of the create point-to-multipoint Ethernet service order procedure sets the attributes that are usually common for all endpoints in the service.

NOTE: If you are using a definition with multiple templates, you can set different attributes for the endpoints.

In any case, the values that you type depend on the service definition on which the service order is based. Follow the steps in one of the following tasks, depending on whether or not the service provides flexible VLAN tagging. To create a service with flexible VLAN tagging, the service definition that you selected for the service order must include the Ethernet option **asymmetric tag depth** in the UNI settings step.

- [Setting Attributes for Nodes or Devices on a Service | 973](#)
- [Setting Attributes for Nodes or Devices on a Service with Flexible VLAN Tagging | 978](#)

Setting Attributes for Nodes or Devices on a Service

If these attributes are not the same on all endpoints, you can set them to be the same for now and then make changes later, or you can choose to skip this step and apply the attribute values one at a time later, or use a definition with multiple templates.

This procedure sets the attributes listed in the Node Settings page of the of the Create E-LAN Service Order wizard. The attributes shown depend on the interface type and the signaling type.

The Node Settings page displays configuration attributes for the device selected in the table of all added nodes. If multiple devices are selected, data is displayed beneath the table for the last selected device. If you do not select a device, the service definition details for nodes are displayed.

To set attributes common to most endpoints:

1. Fill in the following fields under the MAC Settings section

Field	Action
MAC Settings	
MAC learning	To enable MAC learning , select the check box.
Interface MAC limit	Maximum number of MAC addresses learned from an interface. Range: 1 through 131071 MAC addresses per interface
MAC statistics	To enable MAC statistic , select the check box.
MAC Table Size	Modify the size of the MAC address table for the bridge domain. Range: 16 through 1048575 To allow the service provisioner to override the MAC settings, select Editable in Service Order .

2. If **Multihoming** check box is selected in the service definition, a **Multi-Homing Settings** section, with **MH Role** and **Peer Node** tabs, is available.

To define primary and backup PE devices, select **primary** and **backup**, respectively, from the MH Role tab.

You can select peer nodes for the chosen devices from the list.

3. Fill in the following fields under the Advanced Settings and Spoke Settings sections.

Advanced Settings—This section enables you to specify the parameters that define advanced connectivity between sites across the service provider network. Configuring advanced settings is optional. You can click on the Advanced link to view the default values for Advanced Settings. If the advanced settings can be edited in the service order, you can override the default values. If you do not click the Advanced link, the default advanced settings are applied to the service order.

Include	<p>Select the Include check box for each advanced setting that you want to include in the service definition.</p> <p>NOTE: If you select any advanced parameters for a service definition, you must also select the Include check box for the Disable tunnel services parameter, and select or clear the Disable tunnel services check box.</p> <p>For MX Series devices, if you deploy an E-LAN service without selecting the Include check box for Disable tunnel services parameter, the E-LAN service is down. As a work around, you can push the configuration to each PE device for the service by running the following command:</p> <pre>root@test_device# set chassis fpc 0 pic 1 tunnel-services bandwidth 1g</pre>
Disable Tunnel Services	<p>Enable or disable tunnel-services to specify that traffic for particular VPLS routing instances be forwarded to specific virtual tunnel (VT) interfaces.</p> <ul style="list-style-type: none"> • To enable tunnel-services, clear the Disable Tunnel Services check box. • To disable tunnel-services, select the Disable Tunnel Services check box (default).
Disable Local Switching	<p>Enable or disable local switching. In local switching mode, you can terminate multiple Layer 2 circuit pseudowires at a single VPLS mesh group:</p> <ul style="list-style-type: none"> • To enable local switching across the network, clear the Disable Local Switching check box. • To disable local switching across the network, select the Disable Local Switching check box (default).
Fast Reroute-Priority	<p>In this drop-down list, specify the reroute priority for a VPLS routing instance:</p> <ul style="list-style-type: none"> • HIGH—Set the fast reroute priority for a VPLS routing instance to high. During a fast reroute event, the router repairs next hops for high-priority VPLS routing instances first. • MEDIUM—Set the fast reroute priority for a VPLS routing instance to medium. During a fast reroute event, the router repairs next hops for medium-priority VPLS instances after high-priority VPLS routing instances but before low-priority VPLS routing instances. • LOW—Set the fast reroute priority for a VPLS routing instance to low, which is the default. During a fast reroute event, the router repairs next hops for low-priority VPLS routing instances last.

Label Block Size	<p>Configure the label block size for VPLS labels by using one of the following values.</p> <ul style="list-style-type: none"> • 2—Allocate the label blocks in increments of 2. Use this setting for a VPLS domain that has only two sites with no future expansion plans. • 4—Allocate the label blocks in increments of 4. • 8 —Allocate the label blocks in increments of 8. This is the default. • 16—Allocate the label blocks in increments of 16. A label block size of 16 enables you to minimize the number of routes in the VPLS domain. Use this setting only if the number of routes is the primary concern. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery check box is enabled.</p>
Connectivity type	<p>Select a connection-type to specify when a VPLS connection is taken down, depending on whether the interface for the VPLS routing instance is customer-facing or integrated routing and bridging (IRB):</p> <ul style="list-style-type: none"> • ce—Require that for the VPLS connection to be up, the customer-facing interface for the VPLS routing instance must also be up. If the customer-facing interface fails, the VPLS connection is taken down. This is the default. • irb—Allow a VPLS connection to remain up so long as an IRB interface is configured for the VPLS routing instance. <p>NOTE: This field is unavailable if the Signaling type is LDP and the Auto discovery is enabled.</p>

Spoke Settings - Disable Standby—By default, if you configure the Neighbour Hub and Backup Neighbour, CSD pushes the standby configuration for the Backup Neighbour to the device.

Enable this option if you do not want to push the standby configuration of the Backup neighbor to the device.

4. Fill in the following fields under the Spoke Settings section.

For spoke devices you can update the **Neighbor Hub** details only if:

- The **Signaling** type is LDP and the **Auto discovery** check box is disabled
- The **Signaling** type is BGP and the **Enable PW Extension** check box is enabled
- **Enable P2P-Spoke**—If selected, the spoke acts as a stitched E-Line pseudowire. This check box is available only if you have enabled the **Enable PW Extension** in the selected service definition. If you have added more than one UNI interface for a spoke device, you cannot select this check box.
- **NeighborHub**—Select the neighbor hub device from the list. If the **Signaling** type is BGP, enable the **Enable P2P-Spoke** check box to select the neighbor hub.

- **Backup neighbor**—Select the backup neighbor hub device from the list. This field is available if the **Enable PW Resiliency** check box is enabled in the selected service definition. If the **Signaling** type is BGP, enable the **Enable P2P-Spoke** check box to select the backup neighbor.

NOTE: You cannot select the same device for **NeighborHub** and **Backup neighbor**.

- **PW-Hub Connectivity name**— If the **Signaling** type is BGP and if you have enabled the **Enable P2P-Spoke** check box, select or type the mesh group name from other pseudowire spoke.

Range: 1 through 32 characters

If the **Signaling** type is LDP, the pseudowire-hub connectivity name is auto generated.

- **Autopick VC ID**

- For an E-Lan Spoke VPLS-ID is always **Autopick VPLS ID** and is same as the service **VPLS ID**.
- For a p2p spoke, you can either select **Autopick VC ID** or manually enter a VC ID.

- **VC ID**—If the **Signaling** type is BGP and if you have enabled **Enable P2P-Spoke**, specify the VC ID.

You can also modify the VCID field in the Modify Service Order window.

Range: 1 through 2147483647

If the **Signaling** type is LDP, the **VPLS ID** of the routing instance is used.

5. Fill in the following fields under the Mesh Settings section.

NOTE:

- Mesh settings are not applicable for a hub. They are only applicable for E-LAN spoke and p2p-spoke.
- E-LAN spoke is only available when Service Type is E-LAN (Point-MultiPoint), Signalling Protocol is LDP, and Auto-Discovery is False.

For an E-LAN spoke, you can configure only the mesh group name. For a p2p spoke, you can configure the mesh group name and VCID.

- **Name**—Select the mesh group name or enter a new name for the mesh group.
 - **E-LAN Spoke**—Select the mesh group name from the list of available mesh group names.
 - **p2p Spoke**—You can either select mesh group name from the list of available mesh group names, or, you can provide your own mesh group name.
- **Autopick VCID**
 - For E-LAN Spoke, the VPLS ID is always Autopick VPLS ID, and it is same as the service VPLS ID.

- For P2P Spoke, you can auto-pick the VCID by selecting **Autopick VCID** or manually enter a VCID.
- **VCID**—For E-LAN spoke, by default, the VPLS ID is taken as the VCID. For p2p spoke, you can manually enter a VCID, or select **Autopick VCID** so that CSD selects any available VCID from the resource pool.

6. Click **Next**.

The **Site Settings** page of the Create E-LAN Service Order wizard appears.

7. Continue with specifying the UNI or interface settings.

Setting Attributes for Nodes or Devices on a Service with Flexible VLAN Tagging

A service with flexible VLAN tagging can include port-based, 802.1Q, and Q-in-Q interfaces.

If these attributes are not the same on all endpoints, you can set them to be the same for now and then make changes later, or you can choose to skip this step and apply the attribute values one at a time later, or you can use a definition with multiple templates.

If there is a service template attached to the service definition, there is a link to that template at the bottom of the **Node Settings** page of the wizard. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

This procedure sets the attributes listed in the Node Settings page of the of the Create E-LAN Service Order wizard. The attributes shown depend on the signaling type and interface type. The following example shows the endpoints settings box for a point-to-multipoint service with flexible VLAN tagging that transports a single VLAN and specifies Normalize to Dot1Q tag.

Modifying Site Settings

This part of the create point-to-multipoint Ethernet service order procedure sets the attributes for each interface of an endpoint or a device in the service. Selection is made using the **Site Settings** page of the wizard that enables you to create an E-LAN service order.

This window shows one interface for each device that you selected from the inline grid of the Node Settings page, as described in [“Selecting N-PE Devices” on page 952](#).

The Site Settings page enables you to select a device to add interfaces for that device. You can select multiple interfaces for the device. If the Enable L3 Access check box is enabled, the UNI lists available integrated routing and bridging (IRB) interfaces for the selected device. If the device role is a P2P spoke, you can select one UNI and it is required for such devices. If Ethernet Option is set as port-to-port, the UNI can be added only once as an endpoint for the device.

The interface shown in the **UNI Interface** field is automatically selected by the Connectivity Services Director application, which chooses the UNI that has the highest available capacity among interfaces that

are in the Up state. To calculate the available capacity of the interface, the system subtracts the bandwidth reserved for each service deployed on that interface from the total capacity of the interface.

For each endpoint, the **Site Settings** page shows the following value for each UNI attribute:

- For port-to-port services, the displayed values are Bandwidth and MTU.
- For 802.1Q UNIs, the displayed attributes are Bandwidth, Autopick VLAN ID, VLAN ID, and MTU.
- For Q-in-Q UNIs, the displayed attributes include Bandwidth, AutoPick VLAN ID, and VLAN ID. For a service with Q-in-Q UNIs that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.

For each endpoint on a service with flexible VLAN tagging, the Endpoint Settings window shows the following value for each UNI attribute:

- For a service with flexible VLAN tagging that transports a single VLAN and specifies Normalize to Dot1q tags, the displayed attributes include Ethernet Option, Bandwidth, AutoPick VLAN ID, Inner VLAN ID, and MTU. For a service with flexible VLAN tagging that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.
- For a service with flexible VLAN tagging that transports a single VLAN and specifies Normalized to QinQ tags, the displayed attributes include Bandwidth, AutoPick VLAN ID, and VLAN ID. For a service with flexible VLAN tagging that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.
- For a service with flexible VLAN tagging that transports a VLAN range, the displayed attributes include Bandwidth, AutoPick VLAN ID, and VLAN ID. For a service with flexible VLAN tagging that specifies a customer VLAN range, the displayed attributes also include C-VLAN ID Start and C VLAN End.

The values shown are initially the values you set earlier on the Service Settings page of the creation of E-LAN service order wizard, as described in [“Specifying Node Settings” on page 953](#).

To add a UNI and specify its settings:

1. Click the **Add** icon at the top of the Site Settings grid. The endpoints are displayed in the inline grid.
2. Select the check box next to the endpoint or device from which you want to add a UNI to the service order. After you select the check box, the view refreshes to display the configured interfaces for that corresponding device in the lower part of the dialog box
3. Select the check boxes next to the interfaces to add to the service order.
4. Click the **Add** icon to save the settings.. You are returned to the Site Settings page.
5. For a service with flexible VLAN tagging, set the interface type in the Ethernet Option column for each endpoint in the service.

6. To select a different UNI on a device, from the **User-to-Network Interfaces** section, click the UNI name you want to change and choose another interface from the list.

7. Select the **Enable CFM** check box beside a particular interface of a device in the service order creation and modification wizards to enable connectivity fault management (CFM) on the interface. Based on your network needs, you can create a point-to-multipoint and a multipoint-to-multipoint E-LAN service with service-level CFM enabled. The CFM profile is propagated to a single endpoint when multiple interfaces are selected for a given device (the last interface overrides the other configurations). When you select the **Enable CFM** check box for an interface of a particular device, you cannot enable CFM on other interfaces of the same device. The CFM configuration is pushed only on the selected interface.

When you delete the interface with CFM enabled, the CFM configuration on the particular device is also removed. When you attempt to delete an interface with CFM enabled, you are prompted to confirm the deletion.

8. In the **Customer VLAN Range Start** and **Customer VLAN Range End** fields, type the first and last VLAN ID of the range of customer VLANs to be transported over the network.

These fields are present only for services with UNIs that have Q-in-Q interface types and allow a range of VLANs to be transported.

9. Select a value for **Ethernet option**.

- **Port**

- **Dot1Q**

Specifying the **Dot1Q** Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN list to the service order.

- **QinQ**

Specifying the **QinQ** Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN list to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).

10. To enter the description for an UNI interface, click the corresponding **Description** cell.

11. To change the bandwidth on an endpoint, click the bandwidth value for the endpoint and select another value from the list.

12. The **AutoPick Interface Unit ID** and the **Unit ID** columns appear, if you have not selected the **Ethernet option** as port-to-port.

- To change an automatically selected service UNIT ID to manual selection, clear the **AutoPick Interface Unit ID** check box, and type a service UNIT ID value in the **Unit ID** field.

- To change from manual selection to automatic selection, select the **AutoPick Interface Unit ID** check box.
- To change the value of a manually selected service Unit ID, type a new value in the **Unit ID** field.

NOTE: The unit ID value that you have specified in the Enter Order Information page is displayed in the **Unit ID** field.

13. For Q-in-Q interface endpoints, you can change how the service VLAN ID is selected:

- To change an automatically selected service VLAN ID to manual selection, clear the **AutoPick VLAN ID** check box, and type an VLAN ID value in the **VLAN ID** field.
- To change from manual selection to automatic selection, select the **AutoPick VLAN ID** check box.
- To change the value of a manually selected service VLAN ID, type a new value in the **VLAN ID** field.

14. For Q-in-Q interface endpoints with customer VLAN ranges specified, you can also change the range limits for an endpoint.

15. For 802.1Q interface endpoints, you can change the customer VLAN ID.

16. To change the MTU for the UNI, click the value in the **MTU** field and type a new value.

17. To add a UNI on a selected device, click **Add** to open the Choose Endpoints dialog box and then select the interface you want from the UNI interface list.

18. If the interface you selected in the previous step is already configured (duplicate) you must either type a different value in the **VLAN ID** field manually, or check the **Autopick VLAN ID** field.

19. To delete a UNI from a device, select the interface and click **Delete** in the table that displays the UNIs.

If the deleted UNI is the only UNI selected from the device, then the device is deleted from the service configuration.

20. When you have finished modifying the endpoint settings, click **Review** to examine and modify the settings.

21. Click **Finish** when you have completed examining the settings to confirm the creation of the service order.

22. You can proceed with deploying the service.

Specifying QoS Settings

CoS profiles enable the grouping of class-of-service (CoS) parameters and apply them to one or more interfaces. Connectivity Services Director provides you with predefined traffic types for each CoS profile that you create. These traffic types represent the most common types of traffic for the device type. Each of these templates has preconfigured values for all CoS parameters based on the typical application requirements. You can change the preconfigured values of these parameters to suit your requirements. To display the CoS Profiles page, in Build mode, select CoS under Profile and Configuration Management in the Tasks pane. The Manage CoS Profiles page appears.

If QoS is enabled on the service definition, configure the QoS Settings of the Site Settings panel of the service order creation wizard.

1. In the **QoS profile** field, select a profile from the list.

The **QoS profile** list displays the QoS profiles that are currently configured in the Manage CoS Profiles page of the Connectivity Services Director application.

A QoS profile classifies traffic into defined service groups to provide the special treatment of traffic across the network service.

Specifying Template Settings

The Template Settings page of the service order creation and modification wizards enables you to associate service templates with an E-Line, E-LAN, and IP service order. You can apply only the templates that are previously configured in a service definition with the corresponding service order. The Template Settings page is available in the service order wizard only if the service definition that you selected to apply to the service order contains a service template. Otherwise, the Template Settings page is not displayed in the service order wizard. You can perform template operations for all endpoints in a service order.

If you defined a service template as the default service template, it is attached to the endpoint by default. You have the flexibility to create and provision a dynamic attribute in a service template. You can mark an attribute of a service template as dynamic, and you can obtain the values for these dynamic attributes from a specific device. To create a dynamic attribute, you must first mark an attribute of a service template as dynamic and then specify the device XPath for the dynamic attribute.

The Template Settings page is displayed before the Review page, which is the final step of the service order wizard.

In the Service Settings page of the Select Service Definition field of the service order creation wizard, you can double-click a service definition name displayed in the table to view the details of the definition in a popup dialog box. You can use this information to determine if the service definition is appropriate for your deployment needs. To filter and sort the display of service templates, enter the name of the template as a match criterion in the Search box and click the Search icon. The page refreshes to display only the

template names that match with the search term. You can use the paging controls to navigate across multiple pages of templates as necessary.

All the tasks that you can perform with service templates are presented in the Template Settings page. The page is divided into three panes. The top half of the page displays a table of selected endpoints. All the endpoints or UNIs that you selected in the preceding pages of the service order wizard are displayed in this table. You can configure the template pertaining to only one endpoint at a point in time. If the selected endpoints (in previous pages of the wizard) contained a manually-entered unit number, that number is displayed in the table of selected endpoints. Otherwise, the Auto-pick label is displayed.

The lower half of the page is divided into two panes. The left pane displays the template selection table for the endpoint you selected. All the templates associated with the service definition are displayed. You can add and delete templates using the template selection table. The right pane displays all the parameters that you can modify for a selected service template. All such editable parameters are displayed in a consolidated form of a configuration page. This pane is displayed after you select a template. If any configuration parameter in template is set as a service-specific value, such attributes are not displayed in this pane.

To associate a service template with a service order:

1. Click **Add** to include a service template for the endpoint. A dialog box is displayed with the list of service templates associated with the service definition that is used to create the service order. The templates selected in this dialog box are displayed in the Template Selection table for the specified endpoint. Such templates are considered to be attached to that endpoint.

If you specified a template as a default template during the service definition creation, the template is displayed by default in the template selection table. You can associate non-default templates with the service order by clicking the **Add** button.

2. Click the link in the template name to open the Template Details dialog box. The template settings are displayed in the popup dialog box. For the selected template, the Configuration Page is displayed in the lower-right pane of the Template Settings page.
3. Modify any template-specific service components as necessary.
4. Click **Save** to submit the changes.
5. Select a template from the Template Selection table, and click Delete to remove the template from being associated with the service order for a particular endpoint.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in preceding steps or pages

of the wizard. This page provides a comprehensive, single-page view of all the service elements configured in the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

To review the configured service settings in the wizard:

1. Click **Review** to view the defined parameters. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify.
2. Click **Edit** next to the section that contains the parameter you want to modify. You are navigated to the corresponding page of the wizard in which the parameter settings are defined.
3. Click **Finish** to save the service definition or service order.
4. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

The service order inventory window appears.

Deploying the New Service

This part of the create point-to-multipoint Ethernet service order procedure deploys the service.

To deploy the service from the **Manage Deploy Services** window:

1. Perform one of the following actions in the Deploy mode of the Service View of Connectivity Services Director:
 - To deploy the service immediately, select **Deploy now**, then click **OK**.
 - To deploy the service later, select **Schedule deployment**, select a date and time, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.

2. To monitor the status of the deployment, use the Jobs workspace.

The service order is now complete.

The **Manage Service Orders** page shows the service order you just added.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Service Order for VPLS Access into Layer 3 Networks | 985](#)

Creating a Service Order for VPLS Access into Layer 3 Networks

To select a service definition on which to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to network and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the Tasks pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the **Manage Network Services** page, select **New > E-LAN Service Order**.

The **Create E-LAN Service Order** window appears and shows a filtered inventory view of only those published service definitions designed to work with multipoint Ethernet services.

7. From the **Service Parameters** page, select the service definition you want to base your service order
8. Specify the **General Settings**.

Field	Action
Name	<p>Enter a unique name for the E-LAN multipoint service.</p> <p>The service order name can consist of only letters, numbers, and underscores.</p> <p>NOTE: The name you specify for an E-LAN service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, "bgp" or "vpls", as the name of a service order.</p>

Field	Action
Customer	<p>Select the customer requesting the service. To speed your search, enter the first few letters of the customer name and then select from the list.</p> <p>If the customer is not in the list, you must add the customer to the database before proceeding. See “Adding a New Customer” on page 795.</p>
Comments	<p>Enter a description of the service. This description appears in the information screens about the request or service instance created from the request.</p> <p>The Customer traffic type field is not selectable. Its value is set in the service definition.</p> <p>The Autopick Route Target field cannot be changed. Route targets are always selected automatically.</p>
Enable LSP Association	<p>(Optional) Select this check box to create or associate LSPs.</p> <p>Select the Create LSP check box to import an existing LSP service definition and also select an LSP name pattern.</p> <p>NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.</p> <p>For information about creating an LSP name pattern, see “Creating a Name Pattern for LSPs in the Service Order” on page 1794.</p> <p>Select the Associate LSP check box to associate an existing LSP.</p>
Autopick route target	<p>Check the box if you are allowing the system to choose the VPLS routing instance.</p> <p>NOTE: The Autopick route target is not editable in service order. By default, the check box is always selected.</p>
Allow access to L3 network	<p>Check this box to create the access path into the Layer 3 network.</p> <p>Required for E-LAN service orders with access into Layer 3 networks.</p> <p>NOTE: The Allow access to L3 network is not editable in service order. By default, the check box is always selected.</p>

9. Continue with the **Node Settings** page.

Node Settings

Field	Action
Bandwidth	Specify the bandwidth or use the default that appears in the field.

Field	Action
MTU (Bytes)	Specify the MTU value or use the default that appears in the field.
VLAN ID	Specify the VLAN ID associated with the IRB subinterface that will provide the link into the Layer 3 network. This must be a VLAN that already exists.
VLAN Tag to stack	The E-LAN service definition requires a normalized VLAN. Indicate the VLAN to push at the relevant end points. This should be the same VLAN specified as the VLAN ID.

10. Click **Next** to display the device list where you will select the the interfaces for the endpoint devices.
11. Select the devices you will use for this Layer 3 access.
12. The E-LAN service order requires three interface: One IRB interface for the tunnel and two endpoints to ping end-to-end. Add your three interfaces using the **Site Settings** page.
13. Select the IRB interface and click **Finish**. The service order is saved.

RELATED DOCUMENTATION

| [Creating a Point-to-Multipoint E-LAN Service Order](#) | 964

Creating an E-LAN Service Order with CFM

Ethernet interfaces support the IEEE 802.1ag standard for Operation, Administration, and Management (OAM). The IEEE 802.1ag specification provides for Ethernet connectivity fault management (CFM). CFM monitors Ethernet networks that might comprise one or more service instances for network-compromising connectivity faults.

The major features of CFM are:

- Fault monitoring using the continuity check protocol. This is a neighbor discovery and health check protocol that discovers and maintains adjacencies at the VLAN or link level.
- Path discovery and fault verification using the linktrace protocol. Similar to IP traceroute, this protocol maps the path taken to a destination MAC address through one or more bridged networks between the source and destination.

- Fault isolation using the loopback protocol. Similar to IP ping, this protocol works with the continuity check protocol during troubleshooting.

CFM partitions the service network into various administrative domains. For example, operators, providers, and customers might be part of different administrative domains.

Each administrative domain is mapped into one maintenance domain providing enough information to perform its own management, thus avoiding security breaches and making end-to-end monitoring possible. Each maintenance domain is associated with a maintenance domain level from 0 through 7. Level allocation is based on the network hierarchy, where outermost domains are assigned a higher level than the innermost domains.

Customer end points have the highest maintenance domain level. In a CFM maintenance domain, each service instance is called a maintenance association. A *maintenance association* can be thought as a full mesh of maintenance endpoints (MEPs) having similar characteristics. MEPs are active CFM entities generating and responding to CFM protocol messages.

There is also a maintenance intermediate point (MIP), which is a CFM entity similar to the MEP, but more passive (MIPs only respond to CFM messages).

MEPs can be *up MEPs* or *down MEPs*. A link can connect a MEP at level 5 to a MEP at level 7. The interface at level 5 is an up MEP (because the other end of the link is at MEP level 7), and the interface at level 7 is a down MEP (because the other end of the link is at MEP level 5).

In a Metro Ethernet network, CFM is commonly used at two levels:

- By the service provider to check the connectivity among its provider edge (PE) routers
- By the customer to check the connectivity among its customer edge (CE) routers

NOTE: The configured customer CFM level must be greater than service provider CFM level.

In many Metro Ethernet networks, CFM is used to monitor connectivity over a VPLS and bridge network.

The CFM profile is propagated to a single endpoint when multiple interfaces are selected for a given device (the last interface overrides the other configurations). When you enable CFM for an interface of a particular device, you cannot enable CFM on other interfaces of the same device. The CFM configuration is pushed only on the selected interface. When you delete the interface with CFM enabled, the CFM configuration on the particular device is also removed. When you attempt to delete an interface with CFM enabled, you are prompted to confirm the deletion.

To create an E-LAN service order with CFM enabled:

1. Select **Service View** from the View Selector. The workspaces that are applicable to network and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the Tasks pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the **Manage Network Services** page, select **New > E-LAN Service Order**.

The **Create E-LAN Service Order** window appears and shows a filtered inventory view of only those published service orders designed to work with multipoint Ethernet services.

See [“Creating a Multipoint-to-Multipoint E-LAN Service Order” on page 943](#) and [“Creating a Point-to-Multipoint E-LAN Service Order” on page 964](#) for detailed information about the settings that you can configure on the Service Settings and Node Settings pages of the wizard.

7. After you complete the configuration of settings on the Service Settings and Node Settings pages of the service order creation or modification wizard, click **Site Settings** at the top of the wizard page.

The Site Settings page is displayed.

8. Select the **Enable CFM** check box beside a particular interface of a device in the service order creation and modification wizards to enable connectivity fault management (CFM) on the interface. Based on your network needs, you can create a point-to-multipoint and a multipoint-to-multipoint E-LAN service with service-level CFM enabled. The CFM profile is propagated to a single endpoint when multiple interfaces are selected for a given device (the last interface overrides the other configurations). When you select the **Enable CFM** check box for an interface of a particular device, you cannot enable CFM on other interfaces of the same device. The CFM configuration is pushed only on the selected interface.

When you delete the interface with CFM enabled, the CFM configuration on the particular device is also removed. When you attempt to delete an interface with CFM enabled, you are prompted to confirm the deletion.

9. For service orders associated with a service definition that contains a service template, click **Next** to modify the template settings.
10. Click **Review** to examine and modify the settings as necessary.
11. Click **Finish** when you have completed examining the settings to confirm the creation of the service order.

RELATED DOCUMENTATION

| [Creating a Point-to-Multipoint E-LAN Service Order](#) | 964

Interconnecting an E-LAN Service with an IP Service

You can stitch or interconnect an E-LAN service with an IP service. You must enable the stitching functionality to perform this interconnection. If the stitching capability is enabled, when you select the interfaces for the endpoints added to a service, only the integrated routing and bridging (IRB) physical and logical interfaces are available for selection. If you select a physical IRB interface, a new logical interface is created with the logical unit identifier of the interface you specify. If you select a logical IRB interface, the existing logical interface is used to create the service.

You can stitch or interconnect an E-LAN service with an IP service during the creation or modification of an E-LAN service order. Follow the steps outlined in for performing the tasks in the Service Settings and Node Settings pages of the wizard. To enable the stitching of an E-LAN service with an IP service, you can select the Stitch check box for a device associated with the service order on the Site Settings page of the E-LAN service order creation or modification wizard.

- Ensure that you have already created an E-LAN service.
- Complete the configuration of settings on the Service Settings and Node Settings pages of the service order creation or modification wizard.

To interconnect an E-LAN service with an IP service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

- Expand the **IP Services** tree to select an IP service.
- Expand the **E-Line Services** tree to select an E-Line service.
- Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the Tasks pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the Manage Network Services page, select **New > E-LAN Service**.

The **Create E-LAN Service Order** window appears and shows a filtered inventory view of only those published service definitions designed to work with multipoint Ethernet services. You can select the service definition based on the signaling type.

See [“Creating a Multipoint-to-Multipoint E-LAN Service Order” on page 943](#) and [“Creating a Point-to-Multipoint E-LAN Service Order” on page 964](#) for detailed information about the settings that you can configure on the Service Settings and Node Settings pages of the wizard.

7. After you complete the configuration of settings on the Service Settings and Node Settings pages of the service order creation or modification wizard, click **Site Settings** at the top of the wizard page.

The Site Settings page is displayed.

8. Select the check box beside the device for which you want to enable the stitching of E-LAN and IP services.

The device that you select is available for stitching.

9. Select the **Stitch** check box to enable the interconnection of the E-LAN service with an IP service.

10. Click inside the Interface Name field to select an IRB interface. A popup dialog box is displayed with the list of all configured IRB interfaces. If the stitching capability is enabled, when you select the interfaces for the endpoints added to a service, only the IRB physical and logical interfaces are available for selection.

11. Select a physical or logical IRB interface that you want to use to stitch the E-LAN service with an IP service.

The selected interface is used for interconnection of the services.

12. (Optional) If you select a physical IRB interface, you can specify the logical unit of the interface in the UNIT ID field.

The specified logical IRB interface is used for stitching the services.

13. For service orders associated with a service definition that contains a service template, click **Next** to modify the template settings.
14. Click **Review** to examine and modify the settings as necessary.
15. Click **Finish** when you have completed examining the settings to confirm the creation of the service order.
16. You can proceed to enable the stitching functionality for the same IRB interface with the IP service. See [“Interconnecting an IP Service with an E-LAN Service” on page 939](#) for detailed information about enabling the stitching functionality for the IP service.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

[Interconnecting an IP Service with an E-LAN Service | 939](#)

Service Provisioning: Managing IP Service Orders

IN THIS CHAPTER

- [Stitching a Pseudowire to an IP Service | 993](#)
- [Creating a Full Mesh IP Service Order | 995](#)
- [Creating a Hub-and-Spoke IP Service Order | 1019](#)
- [Selecting a Published IP Service Definition for a Service Order | 1044](#)
- [Entering IP Service Order Information | 1045](#)
- [Selecting Endpoint PE Devices or Nodes | 1048](#)
- [Creating a Service Order Based on a Service Definition with a Template | 1049](#)
- [Deploying an IP Service Order | 1051](#)
- [Creating a Multicast VPN Service Order | 1053](#)
- [Creating Policies for an IP Service | 1057](#)

Stitching a Pseudowire to an IP Service

You can terminate an E-Line pseudowire service into an existing Layer 3 VPN, thereby providing access to Layer 3 services. The benefit of the pseudowire stitching feature is that devices running on Layer 2 technology continue to function when networks are upgraded and Layer 3 technologies are used. In order to stitch Layer 2 services to one another and to Layer 3 services, Junos Space utilizes tunnel PICs to peer up a pseudowire and a Layer 3 VPN.

To stitch a pseudowire to an IP service:

1. Create an E-Line service definition.

In the General page of the Create E-Line Service Definition wizard, select the **Enable PW access to IP network** check box to enable pseudowire access to the Layer 3 VPN network.

For more information on creating an E-Line service definition, see *Creating an E-Line Service Definition*.

2. Create an IP service definition.

For information about creating a full mesh IP service definition, see [“Creating a Full-Mesh IP Service Definition” on page 765](#). For information about creating a hub-and-spoke service definition, see [“Creating a Hub-and-Spoke \(One Interface\) IP Service Definition” on page 776](#).

3. Create and deploy an IP service order.

For information about creating a full mesh IP service order, see [“Creating a Full Mesh IP Service Order” on page 995](#). For information about creating a hub-and-spoke service order, see [“Creating a Hub-and-Spoke IP Service Order” on page 1019](#).

4. In Deploy mode of Service View, from the Manage Network Services inventory page, select an IP service that you created and select **Extend PW Service** from the Actions menu

The Extend PW Service inventory page lists the E-Line service definitions that are enabled for Layer 3 access. This inventory page must also list the E-Line service definition you created in Step 1.

5. Select the E-Line service definition and click **Next**.

6. Create an E-Line service order.

The stitched end of the E-Line service is prepopulated with IP service details.

The fields displayed in the E-Line service order are based on the E-Line service definition selected in Step 5. For example, in the E-Line service definition, when pseudowire resiliency is enabled, then the **Revert time (sec)** and the **Switch Over Delay (sec)** fields are available in the service order.

You can select any one of the devices from the **PE device** field. Only the devices with logical tunnel interfaces are listed. These devices are associated with the IP service.

Specify the following information in the PW Stitching box:

- **L3 routing instance name**—Name of the Layer 3 routing instance

NOTE: This field is prepopulated for a stitched end of the E-Line service.

- **Autopick interface IP**—If enabled, specify **IP block size** and **IP address pool**; otherwise specify the **Interface IP address**.
- **Autopick peer unit**—To peer logical system unit number, select the check box; otherwise specify the **Peer unit name**.

For more information on creating an E-Line service order, see [“Creating an E-Line Service Order” on page 895](#).

The IP Service Details window now displays the **PW Extension** details.

When you perform a functional audit for an IP service with pseudowire termination, by default the functional audit is applicable only to the IP service. To perform a functional audit for the pseudowires, select the **Include all extensions** check box in the Schedule Functional Audit window.

NOTE: For pseudowires, the functional audit is launched as a separate job.

Similarly, to perform a Force Deploy for the pseudowires, select the **Include all extensions** check box in the Schedule Force Deployment window.

You can view the details of the stitched pseudowire in the Functional Audit Results window.

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Order | 877](#)

[Creating an E-Line Service Order | 895](#)

Creating a Full Mesh IP Service Order

You can use Connectivity Services Director application to implement IP services.

Creating an IP full mesh Ethernet service order consists of the following tasks:

1. [Selecting the Service Definition | 996](#)
2. [Configuring Service Parameters Information | 997](#)
3. [Selecting N-PE Devices or Nodes | 1002](#)
4. [Setting Attributes for Endpoints or Nodes | 1003](#)
5. [Adding and Deleting UNI Interfaces | 1009](#)
6. [Setting Attributes for UNIs or Sites | 1009](#)
7. [Specifying QoS Settings | 1016](#)
8. [Specifying Template Settings | 1017](#)
9. [Reviewing the Configured Settings | 1018](#)
10. [Deploying the New Service | 1018](#)

Selecting the Service Definition

To select a service definition to base the new service order on:

1. From the Connectivity Services Director application, select **Service View** from the Views list.

The workspaces that are applicable to routing and tunnel services are displayed.

2. From the Junos Space user interface, click the **Deploy** tab in the Task Categories banner. The features that you can configure in this mode are displayed in the task pane.

3. From the Service View pane, click the plus sign (+) to expand the tree and select the type of service.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

- Expand the **IP Services** tree to select an IP service.
- Expand the **E-Line Services** tree to select an E-Line service.
- Expand the **E-LAN Services** tree to select an E-LAN service.

5. Select **IP Services** and from the Tasks pane, select **Service Provisioning > Manage Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. From the Manage Network Services page, select **New > IP Service Order**.

The Service Settings page in the Create IP Service Order wizard is displayed.

7. From the **Service Definition** field, click **Select** to choose the service definition you want to base your service order on.

The **Choose Service Definition** inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

8. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.

9. (Optional) Select the **Enable LSP Association** check box to create or associate LSPs.

Select the **Create LSP** check box to import an existing LSP service definition and also select an LSP name pattern.

NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.

For information about creating an LSP name pattern, see [“Creating a Name Pattern for LSPs in the Service Order” on page 1794](#).

Select the **Associate LSP** check box to associate an existing LSP.

Configuring Service Parameters Information

IN THIS SECTION

- [Specifying General Settings | 997](#)
- [Specifying PE-CE Settings Information | 1001](#)

In this topic you configure general settings, VPN settings that can be applied to all end points, and routing protocol settings for the provider edge (PE) and customer edge (CE) devices.

Specifying General Settings

To specify general information for an IP Service Order:

1. Fill in the fields on the Service Settings page as indicated in [Table 116 on page 998](#).

Table 116: IP Service Order - Service Settings

Field	Description
General Settings	
Name	<p>Type a unique name for the service. The service order name can consist of only letters, numbers, and underscores.</p> <p>NOTE: The name you specify for an IP Service Order becomes the routing-instance name in the device configuration when you deploy the service.</p>
Comments	Type a description of the service.
Customer	<p>Click Select to select name of the enterprise customer that requests for a service.</p> <p>Click Clear to clear the current selection.</p>
Service Definition	<ul style="list-style-type: none"> Click Select to choose a service definition from the Choose Service Definition pop-up. <p>The Service Order is created based on the service definition you choose.</p> <p>Select the check box beside the service definition that you want to associate with the service order, and click OK.</p> <ul style="list-style-type: none"> Click View to view details of the service definition you selected. <p>The type of Service Definition you choose determines the fields that are available in the Connectivity Settings section, VPN Settings section, and the PE-CE Settings section of the Settings Page of the IP Service Order wizard.</p>
Instance Type	The type of Service Definition you choose will determine the Instance Type displayed in the field.
Enable Distinct Instance Name	<p>Select this check box to specify a distinct instance name for each device.</p> <p>NOTE: Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a full-mesh IP service order.</p>
Connectivity Settings	
Policy Based Route Target	<p>Select this check box to create a policy-based vrf instance.</p> <p>Clear this check box to create a community-based vrf instance.</p> <p>For more information on creating policies for an IP service, see “Creating Policies for an IP Service” on page 1057.</p>

Table 116: IP Service Order - Service Settings (*continued*)

Field	Description
Auto Pick Route Target	<p>Clear this check box, to enable the Route Target field.</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box in the create Layer 3 full-mesh service definition wizard.</p>
Route Target	<p>Specify the route target range in any of the following formats:</p> <ul style="list-style-type: none"> AS Number format: <ul style="list-style-type: none"> AS Number Range: 1 through 4294967295 IPv4 address format: <ul style="list-style-type: none"> If AS Number or IP is less than or equal to 65535, range is 0 through 65535. If AS Number or IP is greater than 65535, range is 0 through 4294967295. <p>NOTE: You must clear the Auto Pick Route Target check box to enable this field.</p> <p>NOTE: Starting from Release 2.1R1 onward, Connectivity Services Director supports a mix of both 2-byte and 4-byte AS numbers while creating a full-mesh IP service order.</p>
Auto Pick Hub Route Target	<p>Select this check box to automatically generate a Hub Route Target.</p> <p>Clear this check box to manually enter a Hub Route Target.</p> <p>NOTE: The Auto Pick Hub Route Target check box is visible if the selected Instance Type is vrf.</p> <p>You can edit this field if you select the Editable in Service Order check box in the Create Layer 3 Hub-and-Spoke Service Definition wizard.</p>
Hub Route Target	<p>Specify the hub route target range in any of the following formats:</p> <ul style="list-style-type: none"> prefix-number:assigned-number Prefix-number can be any numeric value from 1 through 65535. Assigned-number can be any numeric value from 0 through 2147483647. IPV4-address:assigned-number IPV4-address can be any valid IPv4 address, and assigned-number can be any numeric value from 0 through 65635. <p>NOTE: To manually enter the Hub Route Target, clear the Auto Pick Hub Route Target check box.</p>

Table 116: IP Service Order - Service Settings (*continued*)

Field	Description
Auto Pick Spoke Route Target	<p>Select this check box to automatically generate a Spoke Route Target.</p> <p>Clear the Auto Pick Spoke Route Target check box to manually enter a Spoke Route Target.</p> <p>NOTE: The Auto Pick Spoke Route Target check box is visible only if Instance Type selected is vrf.</p> <p>You can edit this field if you select the Editable in Service Order check box in the Create Layer 3 Hub-and-Spoke Service Definition wizard.</p>
Spoke Route Target	<p>Specify the spoke route target range in any of the following formats:</p> <ul style="list-style-type: none"> • prefix-number:assigned-number Prefix-number can be any numeric value from 1 through 65535. Assigned-number can be any numeric value from 0 through 2147483647. • IPV4-address:assigned-number IPV4-address can be any valid IPv4 address, and assigned-number can be any numeric value from 0 through 65635.
VPN Settings	
VRF Table Label	<p>Select this check box while creating a service definition to configure a separate label for each VRF to provide double lookup and egress filtering.</p> <p>This check box is visible only if the selected Instance Type is vrf.</p>
Export Direct Routes	Select this check box in the Create Layer 3 Full Mesh Service Definition wizard to export direct routes.
Enable Auto Export Routes	You can select this check box in the Create IP Service Definition wizard to enable internal and external route leak as part of route target creation.
Import Internal Routes	Select this check box in the Create IP Service Definition wizard to enable the internal route leak feature as part of route target policy creation.
Import External Routes	Select this check box in the Create IP Service Definition wizard to enable the external route leak feature as part of route target policy creation.
Enable MVPN	<p>Select this check box to enable multicast VPN (MPVN) settings.</p> <p>If you select this check box, the Enable MC-LAG check box is disabled.</p>

Table 116: IP Service Order - Service Settings (*continued*)

Field	Description
Default UNI Settings	
MTU Factor	<p>Specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10.</p> <p>The value you configure for MTU Factor should not exceed one tenth of the value you configured for burst size.</p> <p>NOTE: This field is enabled only if you select MTU Based as the Burst Size.</p>
Burst Period	<p>Specify a value for Burst Period in the range 10 through 1000. The default value for Burst Period is 10.</p> <p>NOTE: This field is enabled only when you select Line Rate Based as the Burst Size.</p>

Specifying PE-CE Settings Information

You configure VPN attributes that are usually common for all the endpoints in the service. Depending on the service definition on which the service order is based, the values that you provide vary.

If you do not expect these attributes to be the same on all endpoints, you can set them to be the same for now and then make changes later, or you can skip this step and apply the attribute values one at a time later.

Fill in the PE-CE Settings as indicated in [Table 117 on page 1001](#):

Table 117: Layer 3 VPN Service Order - PE-CE Settings

Field	Description
PE-CE Settings	
Routing Protocol	The routing protocol in use is displayed.
AS Override	<p>Select this check box to allow a service provisioner to override the AS number.</p> <p>This check box is available if you select BGP as the routing protocol while creating the service definition.</p>
Maximum Prefixes	<p>Range: 1 through 4294967295</p> <p>This feature limits the number of unique destinations in a routing instance.</p>

Table 117: Layer 3 VPN Service Order - PE-CE Settings (*continued*)

Field	Description
OSPF Domain ID	<ul style="list-style-type: none"> • ID Range Prefix: 1 through 65535 • ID Range Postfix: 0 through 4294967295 <p>This check box is available only if you select OSPF as the routing protocol while creating the service definition.</p>
OSPF Version	<p>Choose an OSPF version from the OSPF Version list:</p> <ul style="list-style-type: none"> • Ver 2 • Ver 3 <p>Junos OS supports OSPF version 2 (OSPFv2) and OSPF version 3 (OSPFv3).</p> <p>This check box is available only if OSPF is selected as the routing protocol while creating the service definition.</p>

Click **Next**

The **Node Settings** page appears.

Selecting N-PE Devices or Nodes

In this topic you select the N-PE devices that you want to host the service endpoints.

To select endpoint N-PE devices:

1. Click **Add** in the **Node Settings** page of the **Create IP Service Order** wizard to add a device.

A new row is added to the existing table.

NOTE: You can create a new policy by clicking **Create Policy**.

This option is available if you select **Policy Based Route Target** check box and clear the **Auto Pick Route Target** check box.

For more information on creating a policy, see [“Creating Policies for an IP Service” on page 1057](#)

2. Click the arrow in the name field.
3. From the list, select a device you want to add to the service.

You can select more than one device.

4. Click **OK**.

The device is added to the table.

NOTE: You can modify the device settings by selecting the check box next to the device and clicking **Edit**.

Click **Ok** to save your changes.

Continue with modifying or entering the node parameters.

Setting Attributes for Endpoints or Nodes

For instructions on working with service templates in service orders, see *Creating a Service Order Based on a Service Definition with a Template*.

You set attributes for each endpoint in the service from the **Node Settings** page.

For each endpoint, the **Node Settings** page shows the value for each UNI attribute.

You can enter topology settings, create static routes on the service, and enter MVPN/PIM settings in the Node Settings page. To specify these settings for a CE device on the Node Settings page:

1. Select the device and click **Edit**.

The Node Settings window appears.

2. Fill in the fields to configure or change topology settings as indicated in [Table 118 on page 1003](#):

Table 118: IP Service Order - Topology Settings

Field	Description
Topology	<p>The type of network circuit in use is displayed in this field:</p> <ul style="list-style-type: none"> • Full Mesh • Hub-and-spoke
Is Stitching Point	<p>Clear this check box.</p> <p>If you select the Enable MC- LAG check box in the General Settings window, the Is Stitching Point check box is available for each endpoint. If you select the Is Stitching Point check box, all the parameters of that endpoint are disabled.</p>

Table 118: IP Service Order - Topology Settings (*continued*)

Field	Description
Is Hub	<p>Select this check box to enable the node to function as a hub.</p> <p>Clear this check box if you want the device to function as a spoke.</p> <p>NOTE: This field is not applicable for full-mesh IP services.</p>
Import RT Policy	<p>Select a policy from the list.</p> <p>Policies associated with other devices and policies created as part of the service are listed. You can select more than one policy.</p> <p>You have the option to:</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>NOTE: You can also add or delete a policy while modifying the service.</p>
Export RT Policy	<p>Select a policy from the list</p> <p>Policies associated with other devices and policies created as part of the service are listed. You can select more than one policy.</p> <p>You have the option to:</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>NOTE: You can also add or delete a policy while modifying the service.</p>
Auto pick Route Distinguisher	<p>Select this check box to assign the Route Distinguisher automatically.</p> <p>This field is enabled if you have selected the Editable in Service Order check box in the service definition.</p>

Table 118: IP Service Order - Topology Settings (*continued*)

Field	Description
Route Distinguisher	<p>Enter a valid Route Distinguisher range:</p> <ul style="list-style-type: none"> • as-number:id—Range: 1 through 65535 • ip-address:id—Range: <ul style="list-style-type: none"> • ip address: any unique unicast address • id: 1 through 65535 <p>Each routing instance must have a unique route distinguisher (RD) associated with it. The RD is used to place bounds around a VPN so that the same IP address prefixes can be used in different VPNs without any overlap.</p> <p>This field is available only if you have selected full-mesh as the service type while creating the service definition.</p>
Auto pick Hub Route Distinguisher	<p>Select this check box to assign the Hub Route Distinguisher automatically.</p> <p>This field is enabled if you selected the Editable in Service Order check box in the service definition.</p>
Hub Route Distinguisher	<p>Enter a valid Hub Route Distinguisher range:</p> <ul style="list-style-type: none"> • as-number:id—Range: 1 through 65535 • ip-address:id—Range: <ul style="list-style-type: none"> • ip address: any unique unicast address • id: 1 through 65535 <p>This field is available only if you selected hub-and-spoke as the service type while creating the service definition.</p>
Auto pick Spoke Route Distinguisher	<p>Select this check box to assign the Spoke Route Distinguisher automatically.</p> <p>This field is enabled only if you selected the Editable in Service Order check box in the service definition.</p>
Spoke Route Distinguisher	<p>Enter a valid Spoke Route Distinguisher range:</p> <ul style="list-style-type: none"> • as-number:id—Range: 1 through 65535 • ip-address:id—Range: <ul style="list-style-type: none"> • ip address: any globally unique unicast address • id: 1 through 65535 <p>This field is available only if you selected hub-and-spoke as the service type while creating the service definition.</p>

3. Fill in the fields to create static routes on the service as indicated in [Table 119 on page 1006](#):

Table 119: IP Service Order - Static Routes

Field	Action
Destination Prefix	<p>Enter the endpoint for the static route in this field.</p> <ul style="list-style-type: none"> • IP address–Destination IP address that the router uses to identify packets. • Network mask–Network mask for associated IP subnet. Netmask value: 0-32
Option Type	<p>Choose an option type from the Option Type list:</p> <ul style="list-style-type: none"> • next-hop • next-table • community <p>NOTE: Starting from Connectivity Services Director Release 2.1R1 onward, you can also configure static routes by adding next table and community as option types while creating a full-mesh IP service order.</p>
Hop Address	<p>Enter a valid IP address in this field. You can have multiple hop for every destination prefix.</p> <p>This field is available only if you choose next-hop as the Option Type.</p>
Route Table Name	<p>Choose one of the following options as the route table name:</p> <ul style="list-style-type: none"> • inet.0 • inet.3 <p>This field is available only if you choose next-table as the Option Type.</p>
Member	<p>Choose one of the following values as the member type:</p> <ul style="list-style-type: none"> • no-export • no-advertise • no-export-subconfed <p>This field is available only if you choose community as the Option Type.</p>
Add	<p>Click Add to add a static route to the Static Route Table.</p> <p>A new row is added to the table.</p>
Delete	<p>Select the row you want to delete and click Delete to remove the static route from the Static Route Table.</p>
Attribute	<p>The Attribute column displays the Option Type you select</p>

Table 119: IP Service Order - Static Routes (continued)

Field	Action
Attribute Value	The Attribute Value column displays the corresponding value for every Option Type you select.

4. Specify the MVPN and PIM Settings as indicated in [Table 120 on page 1007](#):

NOTE: The MVPN and PIM Settings sections are displayed only if you select the **Enable MVPN** check box in the Service Settings page of the **Create IP Service Order** wizard.

Table 120: IP Service Order - MVPN and PIM Settings

Field	Description
PIM Settings	
PIM Mode	Choose the PIM Mode from the drop down list. Only sparse mode is currently supported.
MVPN Settings	
MVPN Mode	Choose one of the following MVPN modes from the MVPN Mode list: <ul style="list-style-type: none"> • rpt-spt • spt-only
Site Type	Choose one of the following MBGP MVPN site types from the list: <ul style="list-style-type: none"> • sender • receiver
Provider Tunnel Name	Specify the provider tunnel name to configure virtual private LAN service (VPLS) flooding of unknown unicast, broadcast, and multicast traffic using point-to-multipoint LSPs in this field. You can also configure point-to-multipoint LSPs for MBGP MVPNs.
Upstream Multicast Hop	Select this check box to configure the upstream multicast hop (UMH).

Table 120: IP Service Order - MVPN and PIM Settings (*continued*)

Field	Description
Import Target	<p>Specify the import targets for sender and receiver sites in this field.</p> <p>Select the Sender radio button to import targets for sender sites, select the Receiver radio button to import targets for receiver sites.</p>
Import Unicast Target	<p>Specify the import targets specifically for sender sites or receiver sites in this field. You can also borrow import targets from a configured unicast route target.</p> <p>NOTE: A sender site export route target is always advertised when security association routes are exported. By default, the VPN routing and forwarding (VRF) import and export route targets (configured either using VRF import and export policies or using the vrf-target statement) are used for importing and exporting routes with the MBGP MVPN network layer reachability information (NLRI).</p>
Export Unicast Target	<p>Select this check box to specify the export target to enable you to override the Layer 3 VPN export route targets used for importing and exporting routes for the MBGP MVPN network layer reachability information (NLRI).</p>
Auto pick Export Target	<p>Select this check box to enable automatic selection of an export target if a configuration is not provided.</p>
Target Community	<p>Specify the target community value to be used when exporting sender and receiver site routes in this field.</p> <p>You can specify this value manually if you clear the Autopick Export Target check box.</p>

Click **Ok** to accept all configured values.

Click **Cancel** to reject all configured values.

- Click **Next** when you have finished configuring node settings.

The Site Settings page is displayed.

Adding and Deleting UNI Interfaces

In the Site Settings page, you can add or delete UNI interfaces on the PE devices that participate in a service.

To add a UNI interface on a selected device:

1. Click **Add** to add a new row to the table.
2. From the newly added row, click the arrow in the **Device Name** field.

A list of interfaces is displayed.

3. Select the check boxes beside the UNIs that you want to associate with the service order and click **Ok**. You can select more than one UNI.

The table now displays the UNI interfaces configured on the selected device.

To delete a UNI Interface from a selected device, select the check box next to the interface that you want to delete, and click the **Delete** button above the table.

NOTE: If the deleted UNI is the only UNI selected from the device, then the device is deleted from the service configuration.

Setting Attributes for UNIs or Sites

If there is a service template attached to the service definition, there is a link to that template at the bottom of the Site Settings section of the screen. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

This part of the create Ethernet service order procedure sets the attributes for each endpoint in the service. Selection is made using the Site Settings page.

The interface shown in the UNI Interface field is automatically selected by the Connectivity Services Director application, which chooses the UNI that has the highest available capacity among interfaces that are in the Up state. To calculate the available capacity of the interface, the system subtracts the bandwidth reserved for each service deployed on that interface from the total capacity of the interface.

For each endpoint, the Site Settings page shows the value for each UNI attribute.

To modify the values of a UNI interface:

1. To modify the device settings, select the device by clicking the check box next to it.

The row is highlighted in blue.

2. You can edit details in the row based on [Table 121 on page 1010](#):

Table 121: IP Service Order - Modify or alter UNI Interface

Field	Description
Device Name	Displays the name of the device associated with the UNI.
Interface Name	<p>Displays the selected interface name.</p> <p>To add a new interface:</p> <ol style="list-style-type: none"> Click the arrow in the Interface Name field. To select the interface, select the check box that corresponds to the interface. Click Ok. <p>The interface name is displayed and the corresponding fields are updated.</p>
Interface Status	<p>Displays the interface's status.</p> <ul style="list-style-type: none"> A Green Up arrow indicates devices that are up and running. A Red Down arrow indicates devices that are down.
Unit Autopick	<p>Select this check box to assign the Unit ID automatically.</p> <p>Clear this check box to assign the Unit ID manually.</p>
Unit ID	<p>Enter a value in this field.</p> <p>Range: 1 through 1073741823</p> <p>This field is available only if you clear the Unit Autopick checkbox.</p>
VLAN Tagging	<p>Select one of the following options from the list:</p> <ul style="list-style-type: none"> Port Dot1Q QinQ(All) QinQ(Single) <p>Specifying the Dot1Q Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN list to the service order.</p> <p>Specifying the QinQ Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN list to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).</p>

Table 121: IP Service Order - Modify or alter UNI Interface (*continued*)

Field	Description
VLAN Autopick	Select this check box to assign the VLAN Outer ID automatically. Clear this check box to assign the VLAN Outer ID manually.
VLAN Outer	Enter a value in this field. This field is available if you clear the Unit Autopick check box.
VLAN Inner	Enter a value in this field. This field is available if you choose Dot1Q or QinQ(All) as the VLAN Tagging value.
IP Autopick	Select this check box to assign the IP address automatically. Clear this check box to assign the IP address manually. You cannot edit this check box if you have not selected the Editable in Service Order check box in the service definition.
IP Address	You can enter an IP address in this field if you have cleared the IP Autopick check box. You can choose an IP address from the list if you have selected the IP Autopick check box.
IP Subnet	Enter a valid IP subnet in this field.

To configure or edit Site Settings:

1. Select the interface that you want to edit by clicking the check box next to it.

The selected row is highlighted in blue.

2. You can edit the interface details by following [Table 122 on page 1011](#):

Table 122: IP Service Order - Configure Site Settings

Field	Action
Site Settings	
Interface	The name of the interface you choose is displayed in this field.
Description	Type a description that describes the UNI Interface. Range: 0 to 128 characters.

Table 122: IP Service Order - Configure Site Settings (*continued*)

Field	Action
UNI Settings	
Encapsulation	<p>Choose an encapsulation value from the Encapsulation list:</p> <ul style="list-style-type: none"> • Port • Dot1Q • QinQ(Single) • QinQ(All) <p>If you choose Port as the encapsulation value, no field in the UNI settings section is enabled.</p> <p>If you choose Dot1Q as the encapsulation value, Auto pick Interface Unit and Auto pick VLAN ID check boxes are enabled.</p> <p>If you choose QinQ(Single) or QinQ(All) as the encapsulation value, Customer VLAN Type and Outer TP ID fields are enabled.</p>
Auto pick Interface Unit	<p>Select this check box to automatically assign the Unit ID.</p> <p>Clear this check box to manually enter the Unit ID.</p>
Unit ID	<p>Enter a unit ID in this field.</p> <p>Range - 1 through 16385</p> <p>This field becomes available when you clear the Auto pick Interface Unit check box.</p>
Auto pick VLAN ID	<p>Select this check box to assign the VLAN ID automatically.</p> <p>Clear this check box to manually enter the VLAN ID.</p>
VLAN ID	<p>Enter a VLAN ID in this field.</p> <p>Range - 1 through 4094</p> <p>This field is available when you clear the Auto pick VLAN ID check box.</p>
Customer VLAN Type	<p>Choose a customer VLAN type from the Customer VLAN Type drop down box:</p> <ul style="list-style-type: none"> • Transport All Traffic—Transports traffic from all VLANs across the network • Transport Single VLAN—Transports traffic for a specific VLAN across the network. <p>This field is available only when the encapsulation value you select is QinQ(Single) or QinQ(All)</p>

Table 122: IP Service Order - Configure Site Settings (*continued*)

Field	Action
Customer VLAN ID	<p>Enter a Customer VLAN ID in this field.</p> <p>Range - 1 through 4094</p> <p>This field is available only when you select Transport Single VLAN as the Customer VLAN type.</p>
Outer TP ID	<p>Choose a value form the Outer TP ID list:</p> <ul style="list-style-type: none"> • empty (default) • 0x8100 • 0x88a8 • 0x9100
Inner TP ID	<p>Choose a value form the Inner TP ID list:</p> <ul style="list-style-type: none"> • empty (default) • 0x8100 • 0x88a8 • 0x9100 <p>This field is available when you select Transport Single VLAN as the customer VLAN type.</p>
IP Settings	
Autopick Interface IP	<p>Select this check box to choose an interface IP from IP Address Pool drop down list.</p> <p>Clear this check box to manually enter an interface IP in the Interface IP Address field.</p>
IP Pool Type	<p>Displays the IP Pool Type you have selected.</p> <ul style="list-style-type: none"> • Global • Customer • None
Interface IP Address	<p>Enter an interface IP address.</p> <p>This field is available only when you clear the Autopick Interface IP check box.</p>
IP Address Pool	<p>Choose an interface IP address from the IP Address Pool drop down list.</p> <p>This field is available only if you select the Autopick Interface IP check box.</p>

Table 122: IP Service Order - Configure Site Settings (*continued*)

Field	Action
IP Block size	<p>Enter a valid IP address block size value in this field.</p> <p>Range - 1 through 32</p> <p>NOTE: Starting from Connectivity Services Director Release 2.1R1 onward, you can configure an IP block size using a wider range from 1 through 32 while creating a full-mesh IP service order.</p>
PE-CE Settings	
Routing Protocol	<p>Select a protocol from the list:</p> <ul style="list-style-type: none"> • BGP • OSPF • Static
OSPF Area ID	<p>Enter an OSPF area id.</p> <p>Valid IP Range - 0.0.0.0 through 255.255.255.255</p> <p>This field is available only if OSPF is selected as the routing protocol in the service definition.</p>
OSPF Version	<p>Enter an OSPF version number.</p> <ul style="list-style-type: none"> • Ver 2 • Ver 3 <p>This field is available only if OSPF is selected as the routing protocol in the service definition.</p>
Group Name	<p>Enter a group name.</p> <p>Range - 0 to 255 characters</p> <p>This field is available only if BGP is selected as the routing protocol in the service definition.</p>
Local Address	This field is available if BGP is selected as the routing protocol in the service definition.
Autopick Neighbour IP	<p>Select this field if you want to automatically generate a Neighbour IP. You can edit this field if you select Editable in Service Order check box.</p> <p>This field is available only if BGP is selected as the routing protocol in the service definition.</p>

Table 122: IP Service Order - Configure Site Settings (*continued*)

Field	Action
Neighbour IP	<p>Enter a valid IP address in this field.</p> <p>Range - 1.0.0.1 through 223.225.225.254, excluding 127.x.x.x</p> <p>This field is available if BGP is selected as the routing protocol in the service definition.</p>
Peer AS	<p>Enter a Peer AS range in this field.</p> <p>Range - 1 through 4294967295</p> <p>This field is available if BGP is selected as the routing protocol in the service definition.</p>
Import Policy	<p>Select the policy from the list.</p> <p>Policies associated with other devices and policies created as part of the service is listed. You can select more than one policy from the list.</p> <p>You also have the option to:</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>You can also add or delete a policy while modifying the service.</p>
Export Policy	<p>Select the policy from the list.</p> <p>Policies associated with other devices and policies created as part of the service is listed. You can select more than one policy from the list.</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>You can add or delete a policy while modifying the service.</p>
PIM Settings	
Add	Click Add to add a new row in the PIM Settings table.
Delete	Click Delete to delete a row from the PIM Settings table.
Rendezvous Point (device)	Click the arrow in this field to select a device from the drop down list.
Group Address	<p>Enter a group IP address.</p> <p>Range - 224.0.1.0 through 239.255.255.255</p>

Table 122: IP Service Order - Configure Site Settings (*continued*)

Field	Action
Update or Cancel	<p>Click Update to update the Rendezvous Point (device) and Group Address to the PIM Settings table.</p> <p>Click Cancel to cancel any updates.</p>

- Click **Ok** after you enter the site settings details in the **Site Settings** window.

The site settings page is displayed.

- Click **Next**.

The **Review** page is displayed.

You can examine and modify the created service order parameters. Alternatively, you can click the corresponding buttons at the top of the wizard page to navigate to the specific pages.

- Click **Done**. The **Confirmation** dialogue box appears.

You can choose one of the following options:

- **Save & Validate**
- **Save & Deploy**

- Click **Ok** to confirm the deployment option.

Specifying QoS Settings

CoS profiles enable the grouping of class-of-service (CoS) parameters and apply them to one or more interfaces. Connectivity Services Director provides you with predefined traffic types for each CoS profile that you create. These traffic types represent the most common types of traffic for the device type. Each of these templates has preconfigured values for all CoS parameters based on the typical application requirements. You can change the preconfigured values of these parameters to suit your requirements. To display the CoS Profiles page, in Build mode, select CoS under Profile and Configuration Management in the Tasks pane. The Manage CoS Profiles page appears.

If QoS is enabled on the service definition, configure the QoS Settings of the Site Settings panel of the service order creation wizard.

1. In the **QoS profile** field, select a profile from the list.

The **QoS profile** list displays the QoS profiles that are currently configured in the Manage CoS Profiles page of the Connectivity Services Director application.

A QoS profile classifies traffic into defined service groups to provide the special treatment of traffic across the network service.

Specifying Template Settings

The Template Settings page of the service order creation and modification wizards enables you to associate service templates with an E-Line, E-LAN, and IP service order. You can apply only the templates that are previously configured in a service definition with the corresponding service order. The Template Settings page is available in the service order wizard only if the service definition that you selected to apply to the service order contains a service template. Otherwise, the Template Settings page is not displayed in the service order wizard. You can perform template operations for all endpoints in a service order.

If you defined a service template as the default service template, it is attached to the endpoint by default. You have the flexibility to create and provision a dynamic attribute in a service template. You can mark an attribute of a service template as dynamic, and you can obtain the values for these dynamic attributes from a specific device. To create a dynamic attribute, you must first mark an attribute of a service template as dynamic and then specify the device XPath for the dynamic attribute.

The Template Settings page is displayed before the Review page, which is the final step of the service order wizard.

In the Service Settings page of the Select Service Definition field of the service order creation wizard, you can double-click a service definition name displayed in the table to view the details of the definition in a popup dialog box. You can use this information to determine if the service definition is appropriate for your deployment needs. To filter and sort the display of service templates, enter the name of the template as a match criterion in the Search box and click the Search icon. The page refreshes to display only the template names that match with the search term. You can use the paging controls to navigate across multiple pages of templates as necessary.

All the tasks that you can perform with service templates are presented in the Template Settings page. The page is divided into three panes. The top half of the page displays a table of selected endpoints. All the endpoints or UNIs that you selected in the preceding pages of the service order wizard are displayed in this table. You can configure the template pertaining to only one endpoint at a point in time. If the selected endpoints (in previous pages of the wizard) contained a manually-entered unit number, that number is displayed in the table of selected endpoints. Otherwise, the Auto-pick label is displayed.

The lower half of the page is divided into two panes. The left pane displays the template selection table for the endpoint you selected. All the templates associated with the service definition are displayed. You can add and delete templates using the template selection table. The right pane displays all the parameters that you can modify for a selected service template. All such editable parameters are displayed in a

consolidated form of a configuration page. This pane is displayed after you select a template. If any configuration parameter in template is set as a service-specific value, such attributes are not displayed in this pane.

To associate a service template with a service order:

1. Click **Add** to include a service template for the endpoint. A dialog box is displayed with the list of service templates associated with the service definition that is used to create the service order. The templates selected in this dialog box are displayed in the Template Selection table for the specified endpoint. Such templates are considered to be attached to that endpoint.

If you specified a template as a default template during the service definition creation, the template is displayed by default in the template selection table. You can associate non-default templates with the service order by clicking the **Add** button.

2. Click the link in the template name to open the Template Details dialog box. The template settings are displayed in the popup dialog box. For the selected template, the Configuration Page is displayed in the lower-right pane of the Template Settings page.
3. Modify any template-specific service components as necessary.
4. Click **Save** to submit the changes.
5. Select a template from the Template Selection table, and click Delete to remove the template from being associated with the service order for a particular endpoint.

Reviewing the Configured Settings

You can examine and modify the created service order parameters in the **Review** page of the **Create IP Service Order** wizard.

If you want to modify a particular section in the review page, click the **Edit** button corresponding to that section.

Click **Done** to save the service order. The **Confirmation** dialogue box appears.

Deploying the New Service

From the **Confirmation** dialogue box that appears, you can choose one of the following options to deploy the service:

- Choose **Save & Validate** to validate the service.
- Choose **Save & Deploy** to deploy the service immediately.

The service order is now complete.

Release History Table

Release	Description
2.1R1	Starting from Release 2.1R1 onward, Connectivity Services Director supports a mix of both 2-byte and 4-byte AS numbers while creating a full-mesh IP service order.
2.1R1	Starting from Connectivity Services Director Release 2.1R1 onward, you can also configure static routes by adding next table and community as option types while creating a full-mesh IP service order.
2.1R1	Starting from Connectivity Services Director Release 2.1R1 onward, you can configure an IP block size using a wider range from 1 through 32 while creating a full-mesh IP service order.
2.0R4	Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a full-mesh IP service order.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

Creating a Hub-and-Spoke IP Service Order

Connectivity Services Director can configure and deploy IP hub-and-spoke service orders. Creating a hub-and-spoke IP service order involves the following tasks:

1. [Selecting the Service Definition | 1020](#)
2. [Configuring Service Parameters Information | 1021](#)
3. [Selecting N-PE Devices or Nodes | 1026](#)
4. [Setting Attributes for Endpoints or Nodes | 1027](#)
5. [Adding and Deleting UNI Interfaces | 1033](#)
6. [Setting Attributes for UNIs or Sites | 1034](#)
7. [Specifying QoS Settings | 1041](#)

8. [Specifying Template Settings | 1042](#)
9. [Reviewing the Configured Settings | 1043](#)
10. [Deploying the New Service | 1043](#)

Selecting the Service Definition

To select a service definition on which to base the new service order:

1. From the Connectivity Services Director application, select **Service View** from the Views list.
The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** tab in the Task Categories banner. The features that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. Select the **IP Services** and from the Tasks pane, select **Service Provisioning > Manage Services**.
The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.
6. From the **Manage Network Services** page, select **New > IP Service Order**.
The Service Settings page in the Create IP Service Order wizard is displayed.
7. From the Service Definition field, click **Select** to choose the service definition you want to base your service order on. The Choose Service Definition inventory page displays a view of only those published service definitions designed to work with the type of services you need.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.
8. Select the check box beside the service definition that you want to associate with the service order, and click **OK**.

Configuring Service Parameters Information

IN THIS SECTION

- [Specifying General Settings | 1021](#)
- [Specifying PE-CE Settings Information | 1025](#)

In this topic you configure general settings, VPN settings that can be applied to all end points, and routing protocol settings for the provider edge (PE) and customer edge (CE) devices.

Specifying General Settings

To specify general information for an IP service order:

1. Fill in the fields on the Service Settings page as indicated in [Table 116 on page 998](#).

Table 123: IP Service Order - Service Settings

Field	Description
General Settings	
Name	<p>Type a unique name for the service. The service order name can consist of only letters, numbers, and underscores.</p> <p>NOTE: The name you specify for an IP Service Order becomes the routing-instance name in the device configuration when you deploy the service.</p>
Comments	Type a description of the service.
Customer	<p>Click Select to select name of the enterprise customer that requests for a service.</p> <p>Click Clear to clear the current selection.</p>
Service Definition	<ul style="list-style-type: none"> • Click Select to choose a service definition from the Choose Service Definition pop-up. <p>The Service Order is created based on the service definition you choose.</p> <p>Select the check box beside the service definition that you want to associate with the service order, and click OK.</p> <ul style="list-style-type: none"> • Click View to view details of the service definition you selected. <p>The type of Service Definition you choose determines the fields that are available in the Connectivity Settings section, VPN Settings section, and the PE-CE Settings section of the Settings Page of the IP Service Order wizard.</p>
Enable LSP Association	<p>(Optional) Select this check box to create or associate LSPs.</p> <p>Select the Create LSP check box to import an existing LSP service definition and also select an LSP name pattern.</p> <p>NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.</p> <p>For information about creating an LSP name pattern, see “Creating a Name Pattern for LSPs in the Service Order” on page 1794.</p> <p>Select the Associate LSP check box to associate an existing LSP.</p>
Instance Type	The type of Service Definition you choose will determine the Instance Type displayed in the field.

Table 123: IP Service Order - Service Settings (*continued*)

Field	Description
Enable Distinct Instance Name	<p>Select this check box to specify a distinct instance name for each device.</p> <p>NOTE: Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a hub-and-spoke IP service order.</p>
Connectivity Settings	
Policy Based Route Target	<p>Select this check box to create a policy-based vrf instance.</p> <p>Clear this check box to create a community-based vrf instance.</p> <p>For more information on creating policies for an IP service, see “Creating Policies for an IP Service” on page 1057.</p>
Auto Pick Route Target	<p>Clear this check box, to enable the Route Target field.</p> <p>To override this setting in the service order, you can select the Editable in Service Order check box in the create Layer 3 full-mesh service definition wizard.</p>
Route Target	<p>Specify the route target range in any of the following formats:</p> <ul style="list-style-type: none"> AS Number format: <ul style="list-style-type: none"> AS Number Range: 1 through 4294967295 IPv4 address format: <ul style="list-style-type: none"> If AS Number or IP is less than or equal to 65535, range is 0 through 65535. If AS Number or IP is greater than 65535, range is 0 through 4294967295. <p>NOTE: You must clear the Auto Pick Route Target check box to enable this field.</p> <p>NOTE: Starting from Release 2.1R1 onward, Connectivity Services Director supports a mix of both 2-byte and 4-byte AS numbers while creating a hub-and-spoke IP service order.</p>
Auto Pick Hub Route Target	<p>Select this check box to automatically generate a Hub Route Target.</p> <p>Clear this check box to manually enter a Hub Route Target.</p> <p>NOTE: The Auto Pick Hub Route Target check box is visible if the selected Instance Type is vrf.</p> <p>You can edit this field if you select the Editable in Service Order check box in the Create Layer 3 Hub-and-Spoke Service Definition wizard.</p>

Table 123: IP Service Order - Service Settings (*continued*)

Field	Description
Hub Route Target	<p>Specify the hub route target range in any of the following formats:</p> <ul style="list-style-type: none"> • prefix-number:assigned-number Prefix-number can be any numeric value from 1 through 65535. Assigned-number can be any numeric value from 0 through 2147483647. • IPV4-address:assigned-number IPV4-address can be any valid IPv4 address, and assigned-number can be any numeric value from 0 through 65635. <p>NOTE: To manually enter the Hub Route Target, clear the Auto Pick Hub Route Target check box.</p>
Auto Pick Spoke Route Target	<p>Select this check box to automatically generate a Spoke Route Target.</p> <p>Clear the Auto Pick Spoke Route Target check box to manually enter a Spoke Route Target.</p> <p>NOTE: The Auto Pick Spoke Route Target check box is visible only if Instance Type selected is vrf.</p> <p>You can edit this field if you select the Editable in Service Order check box in the Create Layer 3 Hub-and-Spoke Service Definition wizard.</p>
Spoke Route Target	<p>Specify the spoke route target range in any of the following formats:</p> <ul style="list-style-type: none"> • prefix-number:assigned-number Prefix-number can be any numeric value from 1 through 65535. Assigned-number can be any numeric value from 0 through 2147483647. • IPV4-address:assigned-number IPV4-address can be any valid IPv4 address, and assigned-number can be any numeric value from 0 through 65635.
VPN Settings	
VRF Table Label	<p>Select this check box while creating a service definition to configure a separate label for each VRF to provide double lookup and egress filtering.</p> <p>This check box is visible only if the selected Instance Type is vrf.</p>
Export Direct Routes	Select this check box in the Create Layer 3 Full Mesh Service Definition wizard to export direct routes.
Enable Auto Export Routes	You can select this check box in the Create IP Service Definition wizard to enable internal and external route leak as part of route target creation.

Table 123: IP Service Order - Service Settings (*continued*)

Field	Description
Import Internal Routes	Select this check box in the Create IP Service Definition wizard to enable the internal route leak feature as part of route target policy creation.
Import External Routes	Select this check box in the Create IP Service Definition wizard to enable the external route leak feature as part of route target policy creation.
Enable MVPN	Select this check box to enable multicast VPN (MPVN) settings. If you select this check box, the Enable MC-LAG check box is disabled.
Default UNI Settings	
MTU Factor	Specify a value for MTU Factor in the range 1 through 1087902. The default value for MTU Factor is 10. The value you configure for MTU Factor should not exceed one tenth of the value you configured for burst size. NOTE: This field is enabled only if you select MTU Based as the Burst Size .
Burst Period	Specify a value for Burst Period in the range 10 through 1000. The default value for Burst Period is 10. NOTE: This field is enabled only when you select Line Rate Based as the Burst Size .

Specifying PE-CE Settings Information

You configure VPN attributes that are usually common for all the endpoints in the service. Depending on the service definition on which the service order is based, the values that you provide vary.

If you do not expect these attributes to be the same on all endpoints, you can set them to be the same for now and then make changes later, or you can skip this step and apply the attribute values one at a time later.

Fill in the PE-CE Settings as indicated in [Table 124 on page 1025](#):

Table 124: IP Service Order - PE-CE Settings

Field	Description
PE-CE Settings	
Routing Protocol	The routing protocol in use is displayed.

Table 124: IP Service Order - PE-CE Settings (*continued*)

Field	Description
AS Override	<p>Select this check box to allow a service provisioner to override the AS number.</p> <p>This check box is available if you select BGP as the routing protocol while creating the service definition.</p>
Maximum Prefixes	<p>Range: 1 through 4294967295</p> <p>This feature limits the number of unique destinations in a routing instance.</p>
OSPF Domain ID	<ul style="list-style-type: none"> • ID Range Prefix: 1 through 65535 • ID Range Postfix: 0 through 4294967295 <p>This check box is available only if you select OSPF as the routing protocol while creating the service definition.</p>
OSPF Version	<p>Choose an OSPF version from the OSPF Version list:</p> <ul style="list-style-type: none"> • Ver 2 • Ver 3 <p>Junos OS supports OSPF version 2 (OSPFv2) and OSPF version 3 (OSPFv3).</p> <p>This check box is available only if OSPF is selected as the routing protocol while creating the service definition.</p>

Click **Next**

The **Node Settings** page appears.

Selecting N-PE Devices or Nodes

In this topic you select the N-PE devices that you want to host the service endpoints.

To select endpoint N-PE devices:

1. Click **Add** in the **Node Settings** page of the **Create IP Service Order** wizard to add a device.

A new row is added to the existing table.

NOTE: You can create a new policy by clicking **Create Policy**.

This option is available if you select **Policy Based Route Target** check box and clear the **Auto Pick Route Target** check box.

For more information on creating a policy, see [“Creating Policies for an IP Service” on page 1057](#)

2. Click the arrow in the name field.
3. From the list, select a device you want to add to the service.

You can select more than one device.

4. Click **OK**.

The device is added to the table.

NOTE: You can modify the device settings by selecting the check box next to the device and clicking **Edit**.

Click **Ok** to save your changes.

Continue with modifying or entering the node parameters.

Setting Attributes for Endpoints or Nodes

If a service template is attached to the service definition, there is a link to that template at the bottom of the Endpoint Settings section of the window. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

You set attributes for each endpoint in the service from the **Node Settings** page.

For each endpoint, the **Node Settings** window shows the value for each UNI attribute.

You can enter topology settings, create static routes on the service, and enter MVPN/PIM settings in the Node Settings page. To specify these settings for a CE device on the Node Settings page:

1. Select the device and click **Edit**.

The Node Settings window appears.

2. Fill in the fields to configure or change topology settings as indicated in [Table 125 on page 1028](#):

Table 125: IP Service Order - Topology Settings

Field	Description
Topology	<p>The type of network circuit in use is displayed in this field:</p> <ul style="list-style-type: none"> • Full Mesh • Hub-and-spoke
Is Stitching Point	<p>Clear this check box.</p> <p>If you select the Enable MC- LAG check box in the General Settings window, the Is Stitching Point check box is available for each endpoint. If you select the Is Stitching Point check box, all the parameters of that endpoint are disabled.</p>
Is Hub	<p>Select this check box to enable the node to function as a hub.</p> <p>Clear this check box if you want the device to function as a spoke.</p> <p>NOTE: This field is not applicable for full-mesh IP services.</p>
Import RT Policy	<p>Select a policy from the list.</p> <p>Policies associated with other devices and policies created as part of the service is listed. You can select more than one policy.</p> <p>You have the option to:</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>NOTE: You can also add or delete a policy while modifying the service.</p>

Table 125: IP Service Order - Topology Settings (*continued*)

Field	Description
Export RT Policy	<p>Select a policy from the list</p> <p>Policies associated with other devices and policies created as part of the service is listed. You can select more than one policy.</p> <p>You have the option to:</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>NOTE: You can also add or delete a policy while modifying the service.</p>
Auto pick Route Distinguisher	<p>Select this check box to assign the Route Distinguisher automatically.</p> <p>This field is enabled if you have selected the Editable in Service Order check box in the service definition.</p>
Route Distinguisher	<p>Enter a valid Route Distinguisher range:</p> <ul style="list-style-type: none"> • as-number:id—Range: 1 through 65535 • ip-address:id—Range: <ul style="list-style-type: none"> • ip address: any unique unicast address • id: 1 through 65535 <p>Each routing instance must have a unique route distinguisher (RD) associated with it. The RD is used to place bounds around a VPN so that the same IP address prefixes can be used in different VPNs without any overlap.</p> <p>This field is available only if you have selected full-mesh as the service type while creating the service definition.</p>
Auto pick Hub Route Distinguisher	<p>Select this check box to assign the Hub Route Distinguisher automatically.</p> <p>This field is enabled if you selected the Editable in Service Order check box in the service definition.</p>

Table 125: IP Service Order - Topology Settings (*continued*)

Field	Description
Hub Route Distinguisher	<p>Enter a valid Hub Route Distinguisher range:</p> <ul style="list-style-type: none"> • as-number:id—Range: 1 through 65535 • ip-address:id—Range: <ul style="list-style-type: none"> • ip address: any unique unicast address • id: 1 through 65535 <p>This field is available only if you selected hub-and-spoke as the service type while creating the service definition.</p>
Auto pick Spoke Route Distinguisher	<p>Select this check box to assign the Spoke Route Distinguisher automatically.</p> <p>This field is enabled only if you selected the Editable in Service Order check box in the service definition.</p>
Spoke Route Distinguisher	<p>Enter a valid Spoke Route Distinguisher range:</p> <ul style="list-style-type: none"> • as-number:id—Range: 1 through 65535 • ip-address:id—Range: <ul style="list-style-type: none"> • ip address: any globally unique unicast address • id: 1 through 65535 <p>This field is available only if you selected hub-and-spoke as the service type while creating the service definition.</p>

3. Fill in the fields to create static routes on the service as indicated in [Table 119 on page 1006](#):

Table 126: IP Service Order - Static Routes

Field	Action
Destination Prefix	<p>Enter the endpoint for the static route in this field.</p> <ul style="list-style-type: none"> • IP address—Destination IP address that the router uses to identify packets. • Network mask—Network mask for associated IP subnet. <p>Netmask value: 0-32</p>

Table 126: IP Service Order - Static Routes (continued)

Field	Action
Option Type	<p>Choose an option type from the Option Type list:</p> <ul style="list-style-type: none"> • next-hop • next-table • community <p>NOTE: Starting from Connectivity Services Director Release 2.1R1 onward, you can also configure static routes by adding next table and community as option types while creating a hub-and-spoke IP service order.</p>
Hop Address	<p>Enter a valid IP address in this field. You can have multiple hop for every destination prefix.</p> <p>This field is available only if you choose next-hop as the Option Type.</p>
Route Table Name	<p>Choose one of the following options as the route table name:</p> <ul style="list-style-type: none"> • inet.0 • inet.3 <p>This field is available only if you choose next-table as the Option Type.</p>
Member	<p>Choose one of the following values as the member type:</p> <ul style="list-style-type: none"> • no-export • no-advertise • no-export-subconfed <p>This field is available only if you choose community as the Option Type.</p>
Add	<p>Click Add to a static route to the Static Route Table.</p> <p>A new row is added to the table.</p>
Delete	<p>Select the row you want to delete and click Delete to remove the static route from the Static Route Table.</p>
Attribute	<p>The Attribute column displays the Option Type you select</p>
Attribute Value	<p>The Attribute Value column displays the corresponding value for every Option Type you select.</p>

4. Specify the MVPN and PIM Settings as indicated in [Table 127 on page 1032](#):

NOTE: The MVPN and PIM Settings sections are displayed only if you select the **Enable MVPN** check box in the Service Settings page of the **Create IP Service Order** wizard.

Table 127: IP Service Order - MVPN and PIM Settings

Field	Description
PIM Settings	
PIM Mode	<p>Choose the PIM Mode from the list.</p> <p>Only sparse mode is currently supported.</p>
MVPN Settings	
MVPN Mode	<p>Choose one of the following MVPN mode from the MVPN Mode list:</p> <ul style="list-style-type: none"> • rpt-spt • spt-only
Site Type	<p>Choose one of the following MBGP MVPN site type from the list:</p> <ul style="list-style-type: none"> • sender • receiver
Provider Tunnel Name	<p>Specify the provider tunnel name to configure virtual private LAN service (VPLS) flooding of unknown unicast, broadcast, and multicast traffic using point-to- multipoint LSPs in this field. You can also configure point-to-multipoint LSPs for MBGP MVPNs.</p>
Upstream Multicast Hop	<p>Select this check box to configure the upstream multicast hop (UMH).</p>
Import Target	<p>Specify the import targets for sender and receiver sites in this field.</p> <p>Select the Sender radio button to import targets for sender sites, select the Receiver radio button to import targets for receiver sites.</p>

Table 127: IP Service Order - MVPN and PIM Settings (*continued*)

Field	Description
Import Unicast Target	<p>Specify the import targets specifically for sender sites or receiver sites in this field. You can also borrow import targets from a configured unicast route target.</p> <p>NOTE: A sender site export route target is always advertised when security association routes are exported. By default, the VPN routing and forwarding (VRF) import and export route targets (configured either using VRF import and export policies or using the vrf-target statement) are used for importing and exporting routes with the MBGP MVPN network layer reachability information (NLRI).</p>
Export Unicast Target	Select this check box to specify the export target to enable you to override the IP export route targets used for importing and exporting routes for the MBGP MVPN network layer reachability information (NLRI).
Auto pick Export Target	Select this check box to enable automatic selection of an export target if a configuration is not provided.
Target Community	<p>Specify the target community value to be used when exporting sender and receiver site routes in this field.</p> <p>You can specify this value manually if you clear the Autopick Export Target check box.</p>

Click **Ok** to accept all configured values.

Click **Cancel** to reject all configured values.

- Click **Next** when you have finished configuring node settings.

The Site Settings page is displayed.

Adding and Deleting UNI Interfaces

In the Site Settings page, you can add or delete UNI interfaces on the PE devices that participate in a service.

To add a UNI interface on a selected device:

1. Click **Add** to add a new row to the table
2. From the newly added row, click the arrow in the **Device Name** field.

A list of UNI devices is displayed.

3. Select the check boxes beside the UNIs that you want to associate with the service order and click **Ok**.
You can select more than one UNI.

The table now displays the UNI interfaces configured on the selected device.

To delete a UNI Interface from a selected device, select the check box next to the interface you want to delete, and click the **Delete** button above the table.

NOTE: If the deleted UNI is the only UNI selected from the device, then the device is deleted from the service configuration.

Setting Attributes for UNIs or Sites

If there is a service template attached to the service definition, there is a link to that template at the bottom of the Site Settings section of the screen. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

This part of the create Ethernet service order procedure sets the attributes for each UNI or interface in the service. Selection is made using the Site Settings screen.

The interface shown in the UNI Interface field is automatically selected by the Connectivity Services Director application, which chooses the UNI that has the highest available capacity among interfaces that are in the Up state. To calculate the available capacity of the interface, the system subtracts the bandwidth reserved for each service deployed on that interface from the total capacity of the interface.

For each endpoint, the Site Settings page shows the value for each UNI attribute.

To modify the values of a UNI interface:

1. To modify the device settings, select the device by clicking the check box next to it.

The row is highlighted in blue.

2. You can alter details in the row based on [Table 128 on page 1035](#):

Table 128: IP Service Order - Modify or alter UNI Interface

Field	Description
Device Name	Displays the name of the device associated with the UNI.
Interface Name	<p>Displays the selected interface name.</p> <p>To add a new interface:</p> <ol style="list-style-type: none"> Click the arrow in the Interface Name field. To select the interface, select the check box that corresponds to the interface. Click Ok. <p>The interface name is displayed and the corresponding fields are updated.</p>
Interface Status	<p>Displays the interface's status.</p> <ul style="list-style-type: none"> A Green Up arrow indicates devices that are up and running. A Red Down arrow indicates devices that are down.
Unit Autopick	<p>Select this check box to assign the Unit ID automatically.</p> <p>Clear this check box to assign the Unit ID manually.</p>
Unit ID	<p>Enter a value in this field.</p> <p>Range: 1 through 1073741823</p> <p>This field is available only if you clear the Unit Autopick checkbox.</p>
VLAN Tagging	<p>Select one of the following options from the list:</p> <ul style="list-style-type: none"> Port Dot1Q QinQ(All) QinQ(Single) <p>Specifying the Dot1Q Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN list to the service order.</p> <p>Specifying the QinQ Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN list to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).</p>

Table 128: IP Service Order - Modify or alter UNI Interface (*continued*)

Field	Description
VLAN Autopick	<p>Select this check box to assign the VLAN Outer ID automatically.</p> <p>Clear this check box to assign the VLAN Outer ID manually.</p>
VLAN Outer	<p>Enter a value in this field.</p> <p>This field is available if you clear the Unit Autopick check box.</p>
VLAN Inner	<p>Enter a value in this field.</p> <p>This field is available if you choose Dot1Q or QinQ(All) as the VLAN Tagging value.</p>
IP Autopick	<p>Select this check box to assign the IP address automatically.</p> <p>Clear this check box to assign the IP address manually.</p> <p>You cannot edit this check box if you have not selected the Editable in Service Order check box in the service definition.</p>
IP Address	<p>You can enter an IP address in this field if you have cleared the IP Autopick check box.</p> <p>You can choose an IP address from the list if you have selected the IP Autopick check box.</p>
IP Subnet	Enter a valid IP subnet in this field.

To configure or edit Site Settings:

1. Select the interface that you want to edit by clicking the check box next to it.
The selected row is highlighted in blue.
2. You can edit the interface details by following [Table 129 on page 1036](#):

Table 129: IP Service Order - Configure Site Settings

Field	Action
Site Settings	
Interface	The name of the interface you choose is displayed in this field.
Description	<p>Type a description that describes the UNI Interface.</p> <p>Range: 0 to 128 characters.</p>

Table 129: IP Service Order - Configure Site Settings (*continued*)

Field	Action
UNI Settings	
Encapsulation	<p>Choose an encapsulation value from the Encapsulation list:</p> <ul style="list-style-type: none"> • Port • Dot1Q • QinQ(Single) • QinQ(All) <p>If you choose Port as the encapsulation value, no field in the UNI settings section is enabled.</p> <p>If you choose Dot1Q as the encapsulation value, Auto pick Interface Unit and Auto pick VLAN ID check boxes are enabled.</p> <p>If you choose QinQ(Single) or QinQ(All) as the encapsulation value, Customer VLAN Type and Outer TP ID fields are enabled.</p>
Auto pick Interface Unit	<p>Select this check box to automatically assign the Unit ID.</p> <p>Clear this check box to manually enter the Unit ID.</p>
Unit ID	<p>Enter a unit ID in this field.</p> <p>Range - 1 through 16385</p> <p>This field becomes available when you clear the Auto pick Interface Unit check box.</p>
Auto pick VLAN ID	<p>Select this check box to assign the VLAN ID automatically.</p> <p>Clear this check box to manually enter the VLAN ID.</p>
VLAN ID	<p>Enter a VLAN ID in this field.</p> <p>Range - 1 through 4094</p> <p>This field becomes available when you clear the Auto pick VLAN ID check box.</p>
Customer VLAN Type	<p>Choose a customer VLAN type from the Customer VLAN Type drop down box:</p> <ul style="list-style-type: none"> • Transport All Traffic—Transports traffic from all VLANs across the network • Transport Single VLAN—Transports traffic for a specific VLAN across the network. <p>This field is available only when the encapsulation value you selected is QinQ(Single) or QinQ(All)</p>

Table 129: IP Service Order - Configure Site Settings (*continued*)

Field	Action
Customer VLAN ID	<p>Enter a Customer VLAN ID in this field.</p> <p>Range - 1 through 4094</p> <p>This field is available only when you select Transport Single VLAN as the Customer VLAN type.</p>
Outer TP ID	<p>Choose a value form the Outer TP ID list:</p> <ul style="list-style-type: none"> • empty (default) • 0x8100 • 0x88a8 • 0x9100
Inner TP ID	<p>Choose a value form the Inner TP ID list:</p> <ul style="list-style-type: none"> • empty (default) • 0x8100 • 0x88a8 • 0x9100 <p>This field is available when you select Transport Single VLAN as the customer VLAN type.</p>
IP Settings	
Autopick Interface IP	<p>Select this check box to choose an interface IP from IP Address Pool drop down list.</p> <p>Clear this check box to manually enter an interface IP in the Interface IP Address field.</p>
IP Pool Type	<p>Displays the IP Pool Type you have selected.</p> <ul style="list-style-type: none"> • Global • Customer • None
Interface IP Address	<p>Enter an interface IP address.</p> <p>This field is available only when you clear the Autopick Interface IP check box.</p>
IP Address Pool	<p>Choose an interface IP address from the IP Address Pool list.</p> <p>This field is available only if you select the Autopick Interface IP check box.</p>

Table 129: IP Service Order - Configure Site Settings (*continued*)

Field	Action
IP Block size	<p>Enter a valid IP address block size value in this field.</p> <p>Range - 1 through 32</p> <p>NOTE: Starting from Connectivity Services Director Release 2.1R1 onward, you can configure an IP block size using a wider range from 1 through 32 while creating a hub-and-spoke IP service order.</p>
PE-CE Settings	
Routing Protocol	<p>Select a protocol from the list:</p> <ul style="list-style-type: none"> • BGP • OSPF • Static
OSPF Area ID	<p>Enter an OSPF area id.</p> <p>Valid IP Range - 0.0.0.0 through 255.255.255.255</p> <p>This field is available only if OSPF is selected as the routing protocol in the service definition.</p>
OSPF Version	<p>Enter an OSPF version number.</p> <ul style="list-style-type: none"> • Ver 2 • Ver 3 <p>This field is available only if OSPF is selected as the routing protocol in the service definition.</p>
Group Name	<p>Enter a group name.</p> <p>Range - 0 to 255 characters</p> <p>This field is available only if BGP is selected as the routing protocol in the service definition.</p>
Local Address	This field is available if BGP is selected as the routing protocol in the service definition.
Autopick Neighbour IP	<p>Select this field if you want to automatically generate a Neighbour IP. You can edit this field if you select Editable in Service Order check box.</p> <p>This field is available only if BGP is selected as the routing protocol in the service definition.</p>

Table 129: IP Service Order - Configure Site Settings (*continued*)

Field	Action
Neighbour IP	<p>Enter a valid IP address in this field.</p> <p>Range - 1.0.0.1 through 223.225.225.254, excluding 127.x.x.x</p> <p>This field is available if BGP is selected as the routing protocol in the service definition.</p>
Peer AS	<p>Enter a Peer AS range in this field.</p> <p>Range - 1 through 4294967295</p> <p>This field is available if BGP is selected as the routing protocol in the service definition.</p>
Import Policy	<p>Select the policy from the list.</p> <p>Policies associated with other devices and policies created as part of the service is listed. You can select more than one policy from the list.</p> <p>You also have the option to:</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>You can also add or delete a policy while modifying the service.</p>
Export Policy	<p>Select the policy from the list.</p> <p>Policies associated with other devices and policies created as part of the service is listed. You can select more than one policy from the list.</p> <ul style="list-style-type: none"> • Select a policy from the list. • Clear the current selection by clicking Clear. <p>You can add or delete a policy while modifying the service.</p>
PIM Settings	
Add	Click Add to add a new row in the PIM Settings table.
Delete	Click Delete to delete a row from the PIM Settings table.
Rendezvous Point (device)	Click the arrow in this field to select a device from the drop down list.
Group Address	<p>Enter a group IP address.</p> <p>Range - 224.0.1.0 through 239.255.255.255</p>

Table 129: IP Service Order - Configure Site Settings (*continued*)

Field	Action
Update or Cancel	<p>Click Update to update the Rendezvous Point (device) and Group Address to the PIM Settings table.</p> <p>Click Cancel to cancel any updates.</p>

- Click **Ok** after you enter the site settings details in the **Site Settings** window.

Alternatively, click **Cancel** if you do not want to make any change.

The site settings page is displayed.

- Click **Next**.

The **Review** page is displayed.

You can examine and modify the created service order parameters. Alternatively, you can click the corresponding buttons at the top of the wizard page to navigate to the specific pages.

- Click **Done**. The **Confirmation** dialogue box appears.

You can choose one of the following options:

- **Save & Validate**
- **Save & Deploy**

- Click **Ok** to confirm the deployment option.

Specifying QoS Settings

CoS profiles enable the grouping of class-of-service (CoS) parameters and apply them to one or more interfaces. Connectivity Services Director provides you with predefined traffic types for each CoS profile that you create. These traffic types represent the most common types of traffic for the device type. Each of these templates has preconfigured values for all CoS parameters based on the typical application requirements. You can change the preconfigured values of these parameters to suit your requirements. To display the CoS Profiles page, in Build mode, select CoS under Profile and Configuration Management in the Tasks pane. The Manage CoS Profiles page appears.

If QoS is enabled on the service definition, configure the QoS Settings of the Site Settings panel of the service order creation wizard.

1. In the **QoS profile** field, select a profile from the list.

The **QoS profile** list displays the QoS profiles that are currently configured in the Manage CoS Profiles page of the Connectivity Services Director application.

A QoS profile classifies traffic into defined service groups to provide the special treatment of traffic across the network service.

Specifying Template Settings

The Template Settings page of the service order creation and modification wizards enables you to associate service templates with an E-Line, E-LAN, and IP service order. You can apply only the templates that are previously configured in a service definition with the corresponding service order. The Template Settings page is available in the service order wizard only if the service definition that you selected to apply to the service order contains a service template. Otherwise, the Template Settings page is not displayed in the service order wizard. You can perform template operations for all endpoints in a service order.

If you defined a service template as the default service template, it is attached to the endpoint by default. You have the flexibility to create and provision a dynamic attribute in a service template. You can mark an attribute of a service template as dynamic, and you can obtain the values for these dynamic attributes from a specific device. To create a dynamic attribute, you must first mark an attribute of a service template as dynamic and then specify the device XPath for the dynamic attribute.

The Template Settings page is displayed before the Review page, which is the final step of the service order wizard.

In the Service Settings page of the Select Service Definition field of the service order creation wizard, you can double-click a service definition name displayed in the table to view the details of the definition in a popup dialog box. You can use this information to determine if the service definition is appropriate for your deployment needs. To filter and sort the display of service templates, enter the name of the template as a match criterion in the Search box and click the Search icon. The page refreshes to display only the template names that match with the search term. You can use the paging controls to navigate across multiple pages of templates as necessary.

All the tasks that you can perform with service templates are presented in the Template Settings page. The page is divided into three panes. The top half of the page displays a table of selected endpoints. All the endpoints or UNIs that you selected in the preceding pages of the service order wizard are displayed in this table. You can configure the template pertaining to only one endpoint at a point in time. If the selected endpoints (in previous pages of the wizard) contained a manually-entered unit number, that number is displayed in the table of selected endpoints. Otherwise, the Auto-pick label is displayed.

The lower half of the page is divided into two panes. The left pane displays the template selection table for the endpoint you selected. All the templates associated with the service definition are displayed. You can add and delete templates using the template selection table. The right pane displays all the parameters that you can modify for a selected service template. All such editable parameters are displayed in a

consolidated form of a configuration page. This pane is displayed after you select a template. If any configuration parameter in template is set as a service-specific value, such attributes are not displayed in this pane.

To associate a service template with a service order:

1. Click **Add** to include a service template for the endpoint. The templates selected in this dialog box are displayed in the Template Selection table for the specified endpoint. Such templates are considered to be attached to that endpoint.

When you click **Add**, a dialog box is displayed with the list of service templates associated with the service definition that is used to create the service order. If you specified a template as a default template during the service definition creation, the template is displayed by default in the template selection table. You can associate non-default templates with the service order by clicking the **Add** button.

2. Click the link in the template name to open the Template Details dialog box. The template settings are displayed in the popup dialog box. For the selected template, the Configuration Page is displayed in the lower-right pane of the Template Settings page.
3. Modify any template-specific service components as necessary.
4. Click **Save** to submit the changes.
5. Select a template from the Template Selection table, and click Delete to remove the template from being associated with the service order for a particular endpoint.

Reviewing the Configured Settings

You can examine and modify the created service order parameters in the **Review** page of the **Create IP Service Order** wizard.

If you want to modify a particular section in the review page, click the **Edit** button corresponding to that section.

Click **Done** to save the service order. The **Confirmation** dialogue box appears.

Deploying the New Service

From the **Confirmation** dialogue box that appears, you can choose one of the following options to deploy the service:

- Choose **Save & Validate** to validate the service.
- Choose **Save & Deploy** to deploy the service immediately.

The service order is now complete.

Release History Table

Release	Description
2.1R1	Starting from Release 2.1R1 onward, Connectivity Services Director supports a mix of both 2-byte and 4-byte AS numbers while creating a hub-and-spoke IP service order.
2.1R1	Starting from Connectivity Services Director Release 2.1R1 onward, you can also configure static routes by adding next table and community as option types while creating a hub-and-spoke IP service order.
2.1R1	Starting from Connectivity Services Director Release 2.1R1 onward, you can configure an IP block size using a wider range from 1 through 32 while creating a hub-and-spoke IP service order.
2.0R4	Starting from Connectivity Services Director 2.0R4 onward, you can specify a distinct routing instance name for each device when you deploy a service on multiple devices while creating a hub-and-spoke IP service order.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

Selecting a Published IP Service Definition for a Service Order

To select a service definition on which to base the new service order:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.

- Expand the **IP Services** tree to select an IP service.
- Expand the **E-Line Services** tree to select an E-Line service.
- Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the Tasks pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. In the **Manage Network Services** page, select **New > IP Service Order**.

The **Choose Service Definition** inventory page, which opens when you click **Select** from the Service Definition Name field of the Service Settings page of the service order creation wizard, displays a view of only those published service definitions designed to work with IP services you need.

7. Select the service definition you want to base your service order on, then click **Next** to display the **Service Parameters** window.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

Entering IP Service Order Information

You, the Service Activator must set settings for an IP service order, including general settings, VPN settings that are applied to all end points, and routing protocol settings for the PE and CE devices.

1. [Setting General Settings | 1045](#)
2. [Entering VPN and Connectivity Settings Information | 1046](#)
3. [Entering PE-CE Settings | 1047](#)

Setting General Settings

Before You Begin

- You must add the customer to the database that requested the service order before proceeding. See [“Adding a New Customer” on page 795](#).

You must specify the following general information about the service order in the General Settings section of the Service Parameters page:

1. In the **Name** field, enter a unique name for the IP service.

The service order name can consist of only letters, numbers, and underscores. It must be no longer than 50 characters.

NOTE: The name you specify for an IP service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, “bgp” or “ospf”, as the name of a service order.

2. In the **Customer** drop-down , select the customer who requested the service.

If the customer is not in the list, you must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

3. In the **Comments** field, enter a description of the service no longer than 200 characters. This description appears in information screens about the request or service instance created from the request.

You cannot change the **Route Target** field. Route targets are always selected automatically.

Entering VPN and Connectivity Settings Information

You must set VPN attributes that are usually common for all the endpoints in the service. The values that you enter vary, depending on the service definition on which the service order is based.

If these attributes will not be the same on all endpoints, you can set them to be the same for now and then make changes later, or you can choose to skip this step and apply the attribute values one at a time later.

To set attributes common to most endpoints on a service:

1. The **Autopick VLAN ID** option is automatically selected for Network Activate to automatically chose the VLAN ID. Deselect the check box if you want to manually assigned the VLAN ID.

The **VLAN ID** text box appears.

2. If you deselected the **Autopick VLAN ID** option, enter a value in the **VLAN ID** field.

3. The **Autopick Route Target** option is selected, and you cannot deselect it. Network Activate automatically selects the route target.

4. The **Autopick Route Distinguisher** option is selected, and you cannot deselect it.
5. The **Autopick Interface IP Address** option is selected, and you cannot deselect it. Network Activate automatically selects the interface IP address.
6. The **VRF Table label** option is selected, and you cannot deselect it. Network Activate automatically selects the interface IP address.

Entering PE-CE Settings

In the **PE-CE Settings** section of the Service Parameters page, depending on the PE-CE routing protocol—OSPF/Static Route or BGP/Static Route—do one of the following:

- If **BGP/Static Route routing protocol** is specified in the service definition:
 - a. The **AS override** option is selected to allow a service provisioner to override the AS number. Clear the **AS override** check box to prevent a service provisioner from overriding the AS number.
 - b. Enter a value for the maximum number of prefixes accepted by a PE router from a CE router.
- If **OSPF/Static Route routing protocol** is specified in the service definition, in the **OSPF domain ID** field, enter a IP address.

You can enter from 1.0.0.1 to 223.255.255.254. excluding 127.x.x.x.

1. Click **Next**.

The **Node Settings** page appears.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

Selecting Endpoint PE Devices or Nodes

NOTE: The **Choose Endpoints** window, which you can open by clicking **Add** above the Nodes table on the Node Parameters page of the Create L3VPN Service Order wizard, shows only assigned NPE devices that have an AS number configured. If you do not see the device you are looking for, use the CLI on the device to check for and assign an AS number.

N-PE devices that are L2VPN-only will not appear.

To select endpoint N-PE devices:

1. In the **Node Parameters** page, click **Add** in the Service Nodes table. From the Choose Endpoints dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices.

NOTE: In the Choose Endpoints dialog box, you can sort and segregate the devices and their corresponding interfaces based on the roles of the devices to easily and quickly view only the devices of interest. Click the down arrow on the **Filter Role** menu, and select **P2E** to view only the provider edge devices, **P** to view only the provider devices, and **L2E** to view only Layer 2 Ethernet devices.

2. Based on the devices you select in the top half of the dialog box, the interfaces that are present in the selected device are displayed in the lower half of the dialog box. Select the check boxes next to the interfaces that you want to associate with the service.

3. Click **OK**.

The **Node Parameters** window appears.

4. Continue with modifying or entering the node parameters.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

Creating a Service Order Based on a Service Definition with a Template

Creating a service order using a service definition with service templates attached to it facilitates endpoint configuration.

By means of a template, a number of service attributes identified by the service definition designer can be not only applied as a group to one or more endpoints in a service order, but also, in some cases, edited. Some attributes can only be set by service provisioners. For this reason, service definition designers can make these values editable by the service provisioner during service order creation.

A service definition can have multiple templates attached to it. If you use a definition with more than one template, you are not obliged to apply the same settings to all endpoints. You can create a service order in which each endpoint is configured using a different template. In other words, each endpoint can use a subset of templates defined in the service definition, and there, template choice is per service order.

From a service provisioner's perspective, the service template takes the form of a collection of flexible service attributes accessible through a link in the service order.

This topic describes how to work with a service template from within a service order, that is, while creating the service order.

These instructions assume that the service order is based on a service definition that has at least one template attached to it. The instructions apply to a definition with multiple templates, because the procedure for a definition with a single template is simpler.

To see if a definition has any templates before you begin creating a service order, view the details of the definition on the Service Settings page of the **Select Service Definition** field of **Create Service Order**. The presence or absence of an attached Service Template is indicated below **Name** and **Type**.

To configure a service order based on a service definition with multiple templates:

1. To start creating a service order, follow the instructions in the topic listed below that is relevant to your service order type :
 - [Creating an E-Line Service Order on page 895](#)
 - [Creating a Multipoint-to-Multipoint E-LAN Service Order on page 943](#)
 - [Creating a Point-to-Multipoint E-LAN Service Order on page 964](#)
 - [Creating a Full Mesh IP Service Order on page 995](#)
 - [Creating a Hub-and-Spoke IP Service Order on page 1019](#)
2. At the **Node Parameters** page, with an endpoint selected, make the appropriate selection or enter the appropriate data (guidelines for this are in ["Creating an E-Line Service Order" on page 895](#)).

3. (Optional for a service definition containing multiple templates). Examine all the attributes in all the templates to determine whether to apply all templates to all endpoints. You can delete templates and add templates back at will.

4. To display and, if necessary, edit the attributes a page contains, select the page in the panel on the left.

On the right, underneath the name of the page, appear the attributes on the selected page of the template.

Usually the names of the attributes are ambiguous (for example, “description,”), therefore you must mouse over the field next to the name to see its context in the DMI schema hierarchy.

5. For each page in each applicable template, make the appropriate changes in the field on the right.

6. (Optional) If you determine that one of the templates contained in the definition is superfluous, select it in the panel on the left.

The name of the first page of the template appears at the top of the panel on the right.

7. Click the red “X” icon near the top of the panel on the left.

The template disappears.

NOTE: If you delete a template by mistake, you can add it again. Click the green “+” icon.

The Add Template window appears, displaying a list of all the templates previously deleted from the current endpoint’s group of flexible service attributes.

Select the templates you want to add, and click **Add Template**.

The Flexible Service Attributes window reappears, displaying the newly added templates

8. When you have finished configuring the current endpoint’s group of flexible service attributes, click **OK**.

The Endpoint Settings page reappears.

9. (Optional) Repeat the preceding steps for other endpoints.

To verify your work:

1. In Deploy mode, select a service from the Service View pane, and navigate to **Service Provisioning > Deploy Services** in the task pane, select the service you deployed, and select **View Service Configuration Change** from the **Actions** drawer.

The **Service Configuration** window opens.

2. Select the appropriate device from the panel on the left.

If a template was deployed to the device, the **Template Configuration** tab appears to the right of the **Service Configuration** tab.

3. Click the **Template Configuration** tab to display the configlet that was deployed as a result of the template.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

[Entering IP Service Order Information | 1045](#)

[Selecting Endpoint PE Devices or Nodes | 1048](#)

Deploying an IP Service Order

You must deploy a service for it to run on devices in the network.

To deploy the service, make selections from the **Manage Service Orders** window.

1. Select **Service View** from the View Selector. The workspaces that are applicable to network and tunnel services are displayed.
2. From the Connectivity Services Director user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select a E-Line service.

- Expand the **E-LAN Services** tree to select a E-LAN service.
5. From the Tasks pane, select **Service Provisioning > Deploy Services**.
 The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.
 6. Select the check box next to an IP service in the Manage Network Services page. The corresponding service orders for the selected service are displayed in the Manage Service Orders page in the lower half of the main display area.
 7. Select the check box next to the IP service order you want to deploy.
 8. Perform one of these actions from Deploy mode in the Service View of Connectivity Services Director :
 - To deploy the service immediately, select **Deploy now** and then click **OK**.
 - To deploy the service later, select **Schedule deployment**, select a date and time, and then click **OK**.
 The time field specifies the time kept by the server, but in the time zone of the client.
 - To validate the service, click **Validate**.
 9. Use the Deploy Configuration page to view the job and monitor the status of the service deployment.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service | 993](#)

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

[Entering IP Service Order Information | 1045](#)

[Selecting Endpoint PE Devices or Nodes | 1048](#)

[Creating a Service Order Based on a Service Definition with a Template | 1049](#)

Creating a Multicast VPN Service Order

This topic describes how to use the Connectivity Services Director application to create a Multicast VPN (MVPN) service order.

NOTE: Multicast VPN services are supported on LN2600 and MX devices only.

1. Select **Service View** from the View Selector. The workspaces that are applicable to network and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP Ethernet service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the Tasks pane, select **Service Provisioning > Deploy Services**.

The Manage Network Services page is displayed in the top half of the right pane, which displays all of the configured services. The Manage Service Orders page is displayed in the bottom half of the right pane, which displays all of the service orders corresponding to a service.

6. To select a service definition on which to base the new service order, from the Network Services page, select **New > IP Service Order**.
7. In the **Service Parameters** window, from the **Select Service Definition** field, select the service definition upon which you want to base your service order.
8. In the **Service Parameters** window, enter the service attributes-related information in the relevant fields as described in the following table:

Field	Description
Service Definition	The service definition upon which this service order is based.
Name	Type a name for the service order.

Field	Description
Customer	Enter the customer for which you are creating the service order.
Comments	Enter comments to describe the service order (optional).
Enable LSP Association	<p>(Optional) Select this check box to create or associate LSPs.</p> <p>Select the Create LSP check box to import an existing LSP service definition and also select an LSP name pattern.</p> <p>NOTE: You can also create an LSP name pattern of your preference, instead of using an existing pre-defined pattern.</p> <p>For information about creating an LSP name pattern, see “Creating a Name Pattern for LSPs in the Service Order” on page 1794.</p> <p>Alternatively, you can select the Associate LSP check box to associate an existing LSP with a pattern provided for the service you create.</p> <p>You must enter the LSP Regex value in the Node Settings page to associate LSPs with a pattern.</p>
MVPN	If selected, this check box indicates that the service order is intended to function in a Multicast VPN. This check box is selected if it was selected in the service definition upon which this service order is based.
VPN Settings	The VPN settings listed in this panel correspond to the settings selected in the service definition upon which this service order is based.
Autopick VLAN ID	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Autopick Hub Route Target	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Autopick Spoke Route Target	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Autopick Hub Route Distinguisher	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Autopick Spoke Route Distinguisher	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Autopick Interface IP Address	This check box is selected automatically if it was selected in the service definition upon which this service order is based.

Field	Description
VRF Table Label	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Export Direct Routes	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
PE-CE Settings	
Routing Protocol	OSPF/Static Route–This routing protocol corresponds to the protocol selected in the service definition upon which this service order is based.
OSPF domain ID	This field is optional. Range: 1.0.0.1 to 223.255.255.254 (excluding 127.x.x.x)

9. Click **Next**.

10. Select the device for which you want to implement the service order.

11. Click **Next**.

12. In the **Site Settings** window, enter information as described in the following table:

Field	Description
Choose Endpoints	
Device	Add the devices for which you intend to implement this service order.
UNI Interface	Select the interface on each device for which you intend to implement this service order.
UNI Description	Enter the description for the selected UNI interface . The Description field is displayed in Modify Service Order, View Service Order Details, Modify Service, and View Service windows. You can edit this field while modifying an IP service order or service. Range: 0 through 128 characters
Set loopback	Select this check box to create a loopback interface for the service order. NOTE: If you provision a loopback interface for an IP service, an operator is able to identify a VRF routing instance. Thereafter, an operator can manually ping a remote CE router from a local PE router.

Field	Description
Encapsulation	VLAN This field displays the value specified in the service definition upon which you are basing this service order.
UNI interface	Select the interface on the device for which you intend to implement this service order.
Autopick interface IP	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
IP pool type	Global This field displays the value specified in the service definition upon which this service order is based.
IP address pool	Select the IP address pool from the list.
IP block size	This field displays the value specified in the service definition upon which this service order is based.
Autopick VLAN ID	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Routing protocol	BGP This field displays the value specified in the service definition upon which this service order is based.
Autopick neighbor IP	This check box is selected automatically if it was selected in the service definition upon which this service order is based.
Peer AS	The peer autonomous system number. Select a Peer AS from the list.

13. Click **Review**.

14. Click **Finish** to complete the creation of the service order.

RELATED DOCUMENTATION

Stitching a Pseudowire to an IP Service 993
Creating a Full Mesh IP Service Order 995
Creating a Hub-and-Spoke IP Service Order 1019
Selecting a Published IP Service Definition for a Service Order 1044
Entering IP Service Order Information 1045
Selecting Endpoint PE Devices or Nodes 1048
Creating a Service Order Based on a Service Definition with a Template 1049

Creating Policies for an IP Service

Starting from Connectivity Services Director Release 2.0R4 onward, you can create route target policies or protocol policies. These policies can be associated with provider edge protocols and customer edge protocols, and route target. In releases earlier than Connectivity Services Director Release 2.0R4, the Connectivity Services Director application automatically generates route target policies. You can create these policies on the Node Settings page of the Create IP Service Order wizard.

To create a route target policy, you must select the **Policy Based Route Target** check box in the Create IP Service Definition wizard. If you have cleared the **Policy Based Route Target** check box, the Connectivity Services Director application does not generate the policy.

If you have selected the **Policy Based Route Target** check box, you have an option to create a policy on the Node Settings page of the Create IP Service Order wizard. If you have not defined a policy in the Create IP Service Order wizard, the Connectivity Services Director application automatically generates the necessary policy.

Creating PE-CE protocol policies is optional.

1. On the Node Settings page of the Create IP Service Order wizard, click **Create Policy**.

The Policy Settings window appears.

2. Fill in the following fields in the Policy Settings window:

Field	Description
Device Name	This drop down menu lists the devices that are part of the IP service. Select a device that you want to apply the policy.
Option Settings	

Field	Description
Option Type	<p>Select an option type:</p> <ul style="list-style-type: none"> • Community Specify the following attributes: <ul style="list-style-type: none"> • Community name—Specify the name of the community. Range: 0 through 255 characters • Member—Specify the member value in AS-number or IP address:ID format AS Number Range: 1 through 65535 IP address Range: Globally unique unicast address. • As-path Specify the following attributes: <ul style="list-style-type: none"> • AS-path name—Specify the name of the AS path. Range: 0 through 255 characters • Path—Specify the path. Range: Regular expressions • prefix-list Specify the following attributes: <ul style="list-style-type: none"> • Prefix List Name—Specify the name of the prefix list. Range: 0 through 255 characters • Prefix Address—Specify the prefix address. IP address Range: Globally unique address with subnet mask.
Add	Click Add to validate option attribute values. The attribute is listed in the table.
Delete	Select an attribute from the table and click Delete to delete an option attribute row.
Policy Settings	
Policy Name	<p>Specify the name of the policy.</p> <p>Range: 0 through 255 characters</p>
Name	<p>Specify the name of the policy term.</p> <p>Range: 0 through 255 characters</p>
Clause	<p>Select one of the following clause:</p> <ul style="list-style-type: none"> • From • Then

Field	Description
Attribute selection	<p>If the Clause type is From select one of the following attributes:</p> <ul style="list-style-type: none"> • route filter • community • protocol • family • as-path • prefix-list • prefix-list-filter <p>If the Clause type is Then, select one of the following attributes:</p> <ul style="list-style-type: none"> • community • local-preference • accept • reject
Add	Click Add to validate policy setting values. The attribute is listed in the table.
Delete	Select an attribute from the table and click Delete to delete a policy term.

3. Click **Save**.

The policy is created.

Release History Table

Release	Description
2.0R4	Starting from Connectivity Services Director Release 2.0R4 onward, you can create route target policies or protocol policies.

RELATED DOCUMENTATION

Service Provisioning: Performing RFC 2544 Benchmark Testing

IN THIS CHAPTER

- [RFC 2544 Testing Overview | 1060](#)
- [Creating an RFC 2544 Test Profile for Services | 1063](#)
- [Creating an RFC 2544 Test Profile for Devices | 1070](#)
- [Deploying RFC 2544 Tests | 1076](#)
- [Viewing RFC 2544 Test Results | 1076](#)

RFC 2544 Testing Overview

IN THIS SECTION

- [Supported Devices for RFC2544 | 1061](#)
- [Performing an RFC 2544 test for a Service | 1062](#)
- [Performing an RFC 2544 Test Between Devices | 1062](#)

The RFC 2544 test methodology defines specific set of tests that operator can use to measure and report the performance characteristics of network devices and services. These tests measure throughput, latency, frame loss rate, and bursty frames. The test methodology enables you to define various parameters such as different frame sizes to be examined, the test time for each test iteration, and the frame format (UDP-over-IP).

The RFC 2544 methodology can be used to measure various parameters based on SLA agreements and certify it. By providing performance availability, transmission delay, link burstability and service integrity measurements, a carrier can certify that the working parameters of the delivered ethernet circuit comply with the contract.

An RFC2544-based benchmarking test is performed by transmitting test packets from a device that functions as the generator or the initiator (which is also called the originator). These packets are sent to a device that functions as a reflector, which receives and returns the packets to the initiator.

The following are some of RFC 2544 benchmarking tests methodology types that you can use to test, measure, and report performance characteristics of network devices.

- **Throughput**—The throughput test calculates the maximum rate at which none of the offered frames are dropped by the device/system under test (DUT/SUT). This measurement translates the obtained rate into the available bandwidth of the service.
- **Latency**—The latency test (for store-and-forward devices) refers to the time interval that begins when the last bit of the input frame reaches the input port and ends when the first bit of the output frame is seen on the output port. It is the time taken by a bit to go through the network and back. Latency variability can be a problem. With protocols like VoIP, a variable or long latency can cause degradation in voice quality.
- **Frame Loss**—The frame loss test calculates the percentage of frames that should have been forwarded by a network device under steady state (constant) loads, that were not forwarded due to lack of resources. This measurement can be used for reporting the performance of a network device in an overloaded state, as it can be a useful indication of how a device would perform under pathological network conditions such as broadcast storms.
- **Burst**—The burstability or back-to-back test refers to the fixed length of frames that are presented at a rate such that there is the minimum legal separation for a given medium between frames (maximum rate) over a short to medium period of time, starting from an idle state. The test result provides the number of frames in the longest burst that the device or network under test will handle without the loss of any frames.

Supported Devices for RFC2544

The following devices support RFC 2544:

- ACX Series Universal Access Routers
- MX Series 5G Universal Routing Platforms

Performing an RFC 2544 test for a Service

Use the following steps to perform an RFC test on a service and view the results:

1. Create an RFC 2544 test profile—For step-by-step instructions on creating an RFC 2544 test profile, see [“Creating an RFC 2544 Test Profile for Services” on page 1063](#).
2. Start RFC 2544 test—To start an RFC 2544 test, select the test profile in the **RFC2544** tab, and select **OAM > RFC2544 Test > Start Test** in the **Tasks** pane on the right side.

The **Test Status** in the **RFC2544** displays the status of the tests.

3. Stop RFC 2544 test—To stop an RFC 2544 test, select the test profile in the **RFC2544** tab, and select **OAM > RFC2544 Test > Stop Test** in the **Tasks** pane on the right side.

The Test Status appears as Stopped in the RFC2544 tab. The test results are available for the iteration till the test was stopped.

4. View the test results—For more information on viewing test results, see [“Viewing RFC 2544 Test Results” on page 1076](#).

Performing an RFC 2544 Test Between Devices

Use the following steps to perform an RFC test between devices and view the test results:

1. Create an RFC 2544 test profile—See [“Creating an RFC 2544 Test Profile for Devices” on page 1070](#) for step-by-step instructions on creating an RFC 2544 test profile.
2. Modify an RFC 2544 test profile—To modify an RFC 2544 test, go to the **OAM-RFC2544-Test > Manage Tests** page, select the test you want to modify, and click **Actions > Modify**. The **Modify Test** page appears displaying the parameters of the test. See [“Creating an RFC 2544 Test Profile for Devices” on page 1070](#) for details about the parameters of an RFC 2544 test.

NOTE: After you modify an RFC 2544 test, you have to validate and deploy it again for the modified configuration to be deployed to the device.

3. Deploy an RFC 2544 test—See [“Deploying RFC 2544 Tests” on page 1076](#) for step-by-step instructions on deploying an RFC 2544 test.
4. Start RFC2544 test—To start an RFC 2544 test, go to the **OAM-RFC2544-Test > Manage Tests** page, select the test you want to run, and click **Actions > Start Test**.

5. Stop RC2544 test—To stop an RFC 2544 test, go to the **OAM-RFC2544-Test > Manage Tests** page, select the test you want to stop, and click **Actions > Stop Test**. The RFC Test Status appears as Stopped in the Manage Test page. The test results are available for the iteration till the test was stopped.
6. View the test results— To view the results of an RFC 2544 test, go to the **OAM-RFC2544-Test > Manage Tests** page, select the test for which you want to view the results, and click **Actions > View Test Result**. For more information on viewing test results, see [“Viewing RFC 2544 Test Results” on page 1076](#).

RELATED DOCUMENTATION

[Creating an RFC 2544 Test Profile for Services | 1063](#)

[Creating an RFC 2544 Test Profile for Devices | 1070](#)

[Deploying RFC 2544 Tests | 1076](#)


[Viewing RFC 2544 Test Results | 1076](#)


Creating an RFC 2544 Test Profile for Services

You must create a test profile (parameters for the RFC 2544-based benchmarking test), which specifies the type of test and the manner in which it must be performed, and associate the test profile with a test name.

Before you begin to create an RFC test for a service, ensure that:

- You have created an E-LINE or IP service on which you want to perform the RFC test.

-  **NOTE:** You can perform RFC tests on E-LINE and IP services only.

-  **NOTE:** You must configure unit 0 for E-line service and interface IP for IP services to run an RFC 2544 test. You can configure unit 0 for E-line service and interface IP for IP services by using device or service templates. You can delete these service templates after the test is completed. For more information, see [Configuring RFC 2544-Based Benchmarking Tests on MX Series Routers](#).

•

NOTE: You cannot perform an RFC test on an E-LAN service as it cannot be provisioned on ACX 2k devices, it can only be provisioned on ACX 5k devices. The initiator PE device can only be an ACX 2k device. ACX 5k devices cannot serve as the initiator, only as the reflector. Therefore, you will not be able to perform the RFC 2544 test on an E-LAN service. You can, however, run an RFC 2544 test at device-level. For more information on this, see [“Creating an RFC 2544 Test Profile for Devices” on page 1070](#). You can also refer [Example: Configuring Benchmarking Tests to Measure SLA Parameters for E-LAN Services on an MX104 Router Using VPLS](#) to understand how to configure benchmarking tests for E-LAN services using VPLS.

- The functional audit status (FA Status) is Up for the service that you want to perform an RFC test.

To create an RFC 2544 test profile:

1. Log into Junos Space application and select **Connectivity Services Director** in the Applications pane on the left.

The Connectivity Services Director dashboard is displayed.

2. On the Connectivity Services Director banner, click **Views** and select **Service View**.

The Service View page is displayed.

3. From the Service View pane on the left, select an E-LINE or IP service on which you want perform an RFC test.

The details of the service is loaded in the View Service Details pane.

4. On the Connectivity Services Director banner, click **Monitor** in Task Categories.

The Service Summary tab is loaded.

5. Select the **RFC2544** tab.

The RFC2544 tab is loaded.

6. On the Tasks pane on the right side of the page, select **OAM > RFC2544 Test > Create Test**.

The Create RFC Test Profile page is displayed.

7. Complete the configuration of the RFC test according to the guidelines provided in [Table 130 on page 1065](#).

8. Click **Save**.

The test profile is created, saved, and deployed. The details of the test profile is displayed on the Create RFC Test Profile page in view-only mode.

9. Click **OK** to close the Create RFC Test Profile page.

The newly created RFC 2544 test profile appears in the **RFC2544** tab.

For more information on running the RFC test and viewing the results, see [“RFC 2544 Testing Overview” on page 1060](#).

[Table 130 on page 1065](#) describes the fields in the Create Test page.

Table 130: Fields on the Create Test Page

Field	Description
General Settings	
Name	Enter a unique string of alphanumeric characters, dashes, and underscores. Colons, and periods are not allowed, and the maximum length is 10 characters.
Description	Enter a description for the RFC 2544 test; maximum length is 250 characters.
RFC Test Profile	<p>Select the test performance metric for the test profile. You can measure the throughput, latency, frame loss, and back-to-back of a service.</p> <p>NOTE: You can choose one performance metric for each test profile. If you want to test more than one performance metric, you must create one test profile for each performance metric.</p> <p>For example, if you want to measure the throughput and latency for a service, then you must create one test profile to measure throughput and another test profile to measure latency.</p>
Bandwidth	Enter a numerical value for the bandwidth (in Kbps) that needs to be tested. The maximum value is 1000000.
Packet Size	Select the packet size(s) for the test. You can select multiple packet sizes for a test; the maximum number of packet sizes you can select is 10.
Step Percent	<p>Enter a numerical value for the frame loss ratio. The maximum value is 100.</p> <p>NOTE: Step percent information is only applicable if you select Frame Loss as the RFC test profile.</p>
Initiator Settings	

Table 130: Fields on the Create Test Page (*continued*)

Field	Description
Provider Edge (PE) Device	<p>PE device lists all the devices on which the service is running. Select the device that you want to act as the initiator for the RFC 2544 test.</p> <p>NOTE: The initiator PE device can only be an ACX device.</p>
Family	<p>Select the address type family for the benchmarking test.</p> <p>NOTE: This field is auto-populated based on the types of service you have selected.</p>
Test Interface	<p>Select the logical interface on which the service (that you want to run an RFC test on) is running. This parameter is required only if you selected the ccc family.</p> <p>NOTE: By default, only the interfaces on which the service is running is listed.</p>
Source IPv4 Address	Enter the source IPv4 address of the initiator. This parameter is required only if you have selected IPv4 family inet.
Source MAC Address	Enter the source MAC address of the initiator. The MAC address is only applicable for the ccc family.
Source UDP Port	Enter the UDP port of the source to be used in the UDP header for the generated frames.
Destination IPv4 Address	Enter the destination IPv4 address of the reflector. This parameter is required only if you have selected IPv4 family inet.
Destination MAC Address	Enter the destination MAC address of the reflector. The MAC address is only applicable for the ccc family.
Destination UDP Port	Enter the UDP port of the destination to be used in the UDP header for the generated frames.
Direction	Select the direction of the interface on which the test must be run. This parameter is valid only for the ccc family. To enable the test to be run in the egress direction of the interface (network-to-network interface (NNI)), use the egress option. To enable the test to be run in the ingress direction of the interface (user-to-network interface (UNI)), use the ingress option.
DSCP Code Points	Specify the value of the Differentiated Services (DiffServ) field within the IP header of host-generated RPM packets. The DiffServ code point (DSCP) bits value must be set to a valid 6-bit pattern.

Table 130: Fields on the Create Test Page (*continued*)

Field	Description
Forwarding Class	<p>Forwarding classes (FCs) allow you to group packets for transmission and to assign packets to output queues. The forwarding class and the loss priority define the per-hop behavior (PHB in DiffServ) of a packet.</p> <ul style="list-style-type: none"> assured-forwarding—Provides a group of values you can define and includes four subclasses—AF1, AF2, AF3, and AF4—each with three drop probabilities (low, medium, and high). best-effort—Provides no service profile. For the BE forwarding class, loss priority is typically not carried in a class-of-service (CoS) value, and random early detection (RED) drop profiles are more aggressive. expedited-forwarding—Provides a low-loss, low-latency, low-jitter, assured-bandwidth, end-to-end service. network-control—This class is typically high priority because it supports protocol control.
Inner VLAN ID	For dynamic VLAN interfaces, enter the VLAN ID to rewrite for the inner tag of the final packet.
Skip ARP Iteration	<p>Select this option to disable the Address Resolution Protocol (ARP) test iteration for IPv4 or inet services during a benchmarking test. This parameter is valid only for an inet family. An ARP test iteration is a three-second iteration that is run for all inet tests. The results of this iteration are disregarded in the test result calculations. The ARP test iteration is executed by sending test frames to all the devices on the path to the destination for 3 seconds. This is to ensure that all devices add ARP entries in the cache of the corresponding devices.</p> <p>This parameter is not applicable for the ccc family.</p>
Test Iteration Duration	Enter the duration of each iteration in seconds, with a value from 10 seconds to 1,728,000 seconds.
Reflector Settings	
PE Device	PE device lists all the devices on which the service is running. Select the device that you want to act as the reflector for the RFC 2544 test.
Family	Select the address type family for the benchmarking test.
Test Interface	<p>Select the logical interface on which the service (that you want to RFC test) is running.</p> <p>NOTE: By default, only the interfaces on which the service is running is listed.</p>

Table 130: Fields on the Create Test Page (*continued*)

Source IPv4 Address	Enter the source IPv4 address of the reflector. This parameter is required only if you selected IPv4 family inet.
Source MAC Address	Enter the source MAC address of the reflector. The MAC address is only applicable for the ccc family.
Source UDP Port	Enter the UDP port of the source to be used in the UDP header for the generated frames.
Destination IPv4 Address	Enter the destination IPv4 address of the reflector. This parameter is required only if you have selected IPv4 family inet.
Destination MAC Address	Enter the destination MAC address of the reflector. The MAC address is only applicable for the ccc family.
Destination UDP Port	Enter the UDP port of the destination to be used in the UDP header for the generated frames.
Direction	Select the direction of the interface on which the test must be run. This parameter is valid only for the ccc family. To enable the test to be run in the egress direction of the interface (network-to-network interface (NNI)), use the egress option. To enable the test to be run in the ingress direction of the interface (user-to-network interface (UNI)), use the ingress option.
DSCP Code Points	Specify the value of the Differentiated Services (DiffServ) field within the IP header of host-generated RPM packets. The DiffServ code point (DSCP) bits value must be set to a valid 6-bit pattern.
Forwarding Class	<p>Forwarding classes (FCs) allow you to group packets for transmission and to assign packets to output queues. The forwarding class and the loss priority define the per-hop behavior (PHB in DiffServ) of a packet.</p> <ul style="list-style-type: none"> assured-forwarding—Provides a group of values you can define and includes four subclasses—AF1, AF2, AF3, and AF4—each with three drop probabilities (low, medium, and high). best-effort—Provides no service profile. For the BE forwarding class, loss priority is typically not carried in a class-of-service (CoS) value, and random early detection (RED) drop profiles are more aggressive. expedited-forwarding—Provides a low-loss, low-latency, low-jitter, assured-bandwidth, end-to-end service. network-control—This class is typically high priority because it supports protocol control.

Table 130: Fields on the Create Test Page (*continued*)

Halt on Prefix Down	By default, the RFC 2544-based benchmarking test ignores a prefix-down event (when the prefix associated with the test goes down) and continues to run. If you select this option, a prefix that moves to the down state causes the corresponding tests to be stopped. The show command output for the test displays that the test was terminated due to the prefix going down.
Inner VLAN ID	For dynamic VLAN interfaces, enter the VLAN ID to rewrite for the inner tag of the final packet.
Outer VLAN ID	<p>The Outer VLAN ID field is disabled unless you provide a value for the Inner VLAN ID.</p> <p>Enter the outer VLAN ID for the test frames. Range: 0 through 4094 This parameter is valid only for family ccc mode.</p>
Skip ARP Iteration	<p>Select this option to disable the Address Resolution Protocol (ARP) test iteration for IPv4 or inet services during a benchmarking test. This parameter is valid only for an inet family. An ARP test iteration is a 3-second iteration that is run for all inet tests. The results of this iteration are disregarded in the test result calculations. The ARP test iteration is performed by sending test frames for 3 seconds to ensure that all devices on the path to destination add ARP entries in the cache of the corresponding devices.</p> <p>This parameter is not applicable for the ccc family.</p>
Test Iteration Duration	Enter the duration of each iteration in seconds, with a value from 10 seconds to 1,728,000 seconds.

RELATED DOCUMENTATION

[RFC 2544 Testing Overview | 1060](#)
[Viewing RFC 2544 Test Results | 1076](#)

Creating an RFC 2544 Test Profile for Devices

You must create a test profile (parameters for the RFC 2544-based benchmarking test), which specifies the type of test and the manner in which it must be performed, and associate the test profile with a test name. The test name that you configure contains details, such as the address family and the test mode, for the test. You can associate the same test profile with multiple test names.

RFC 2544 test profile configuration is done in two parts:

- **Configure General Settings**—Use the **General Settings** pane to define the tests (throughput, latency, back-to-back, and frame loss) that you want to be part of the RFC 2544 test.
- **Configure Test Settings**—Use the **Test Settings** pane to define the initiator and reflector device settings for the RFC 2544 test.

To create an RFC 2544 test profile:

1. Log into Junos Space application and click on **Junos SPACE** in the Connectivity Services Director banner.
2. From the **Applications** pane on the left, select **Services Activation Director**.

The Services Activation Director dashboard is displayed.

3. From the pane on the left, click **OAM-RFC2544-Test > Manage Test Configuration > Create RFC2544 Test**.

The General Settings pane displays fields required for configuring an RFC 2544 test.

4. Complete the configuration for General Settings according to the guidelines provided in [Table 131 on page 1071](#).

5. Click **Next** after you have completed configuring General Settings.

The Test Settings pane displays fields required for configuring the test devices.

6. Complete the configuration for Test Settings according to the guidelines provided in [Table 132 on page 1073](#).

7. Click **Finish**.

The Deployment Options page appears providing various deployment options.

8.
 - Select **Save only** and **Validate** options to validate the test profile against the device and save in the database.
 - Select **Deploy Now** option deploy the test profile to the device.

- Select **Schedule Deployment** option to deploy the test profile at a scheduled date and time; enter the date and time at which the test profile needs to be deployed to the device.

9. Click **OK** to save/deploy the test profile.

The Job Details page appears displaying the job ID that has been created to validate and save/deploy the test profile. You can double-click on the job ID to view the details of the job.

10. Click **OK** to close the Job Details page.

The newly created RFC 2544 test profile appears in the Manage Service Orders page. Double-click on the it to view the details of the test profile.

If you have just saved the new test profile, it is listed in the **Manage Test Configuration** page. Once you deploy the test profile, it is listed in **Manage Test** page. For more information on deploying an RFC 2544 test, see [“Deploying RFC 2544 Tests” on page 1076](#).

For more information on running the RFC 2544 and viewing the results, see [“RFC 2544 Testing Overview” on page 1060](#).

[Table 131 on page 1071](#) describes the fields in the General Settings pane.

Table 131: Fields on the General Settings Pane

Field	Description
Name	Enter a unique string of alphanumeric characters, dashes, and underscores. Colons, and periods are not allowed, and the maximum length is 50 characters.
Comments	Enter a description for the RFC 2544 test; maximum length is 250 characters.
Throughput	<p>Select Throughput to add it as test parameter in the RFC 2544 test. When you select a test parameter, the other test parameters are disabled.</p> <p>NOTE: You can choose only one performance metric for each test profile. If you want to test more an than one performance metric, you must create one test profile for each performance metric.</p> <p>For example, if you want to measure the throughput and latency for a device, then you must create two test profiles—one test profile to measure throughput and another to measure latency.</p>
Bandwidth	Enter a numerical value for the bandwidth for which throughput needs to be tested. The maximum value is 1000000.
Packet Size	Select the packet size(s) for the throughput test. You can select multiple packet sizes for the test; the maximum number of packet sizes you can select is 10.

Table 131: Fields on the General Settings Pane (*continued*)

Field	Description
Frame Loss	<p>Select Frame Loss to add it as test parameter in the RFC 2544 test. When you select a test parameter, the other test parameters are disabled.</p> <p>NOTE: You can choose only one performance metric for each test profile. If you want to test more an than one performance metric, you must create one test profile for each performance metric.</p> <p>For example, if you want to measure the throughput and latency for a device, then you must create two test profiles—one test profile to measure throughput and another to measure latency.</p>
Bandwidth	Enter a numerical value for the bandwidth for which frame loss needs to be tested. The maximum value is 1000000.
Packet Size	Select the packet size(s) for the frame loss test. You can select multiple packet sizes for the test; the maximum number of packet sizes you can select is 10.
Step Percent	Enter the numerical value for the frame loss ratio. The maximum value is 100.
Latency	<p>Select Latency to add it as test parameter in the RFC 2544 test. When you select a test parameter, the other test parameters are disabled.</p> <p>NOTE: You can choose only one performance metric for each test profile. If you want to test more an than one performance metric, you must create one test profile for each performance metric.</p> <p>For example, if you want to measure the throughput and latency for a device, then you must create two test profiles—one test profile to measure throughput and another to measure latency.</p>
Bandwidth	Enter a numerical value for the bandwidth for which latency needs to be tested. The maximum value is 1000000.
Packet Size	Select the packet size(s) for the latency test. You can select multiple packet sizes for the test; the maximum number of packet sizes you can select is 10.

Table 131: Fields on the General Settings Pane (*continued*)

Field	Description
Back-to-Back	<p>Select Back-to-Back to add it as test parameter in the RFC 2544 test. When you select a test parameter, the other test parameters are disabled.</p> <p>NOTE: You can choose only one performance metric for each test profile. If you want to test more an than one performance metric, you must create one test profile for each performance metric.</p> <p>For example, if you want to measure the throughput and latency for a device, then you must create two test profiles—one test profile to measure throughput and another to measure latency.</p>
Bandwidth	Enter a numerical value for the bandwidth for which back-to-back (or burst) needs to be tested. The maximum value is 1000000.
Packet Size	Select the packet size(s) for the back-to-back test. You can select multiple packet sizes for the test; the maximum number of packet sizes you can select is 10.

[Table 132 on page 1073](#) describes the fields in the Test Settings pane.

Table 132: Fields in the Test Settings Pane

Field	Description
Initiator	
Device Name	Select the device that you want to be the initiator or reflector for the RFC 2544 test.
Family	Select the address type family for the benchmarking test. The inet option indicates that the test is run on an IPv4 service.
Test Interface	<p>Specify the logical interface on which the RFC 2544-based benchmarking test is run.</p> <p>NOTE: You can only select the test interface for the reflector device. This field is disabled for the initiator device.</p>
Source IPv4 Address	Enter the source IPv4 address of the initiator. This parameter is required only if you selected IPv4 family inet.
Source MAC Address	Enter the source MAC address of the initiator. The MAC address is only applicable for the ccc family.
Source UDP Port	Enter the UDP port of the source to be used in the UDP header for the generated frames.

Table 132: Fields in the Test Settings Pane (*continued*)

Field	Description
Destination IPv4 Address	Enter the destination IPv4 address of the reflector. This parameter is required only if you have selected IPv4 family inet.
Destination MAC Address	Enter the destination MAC address of the reflector. The MAC address is only applicable for the ccc family.
Destination UDP Port	Enter the UDP port of the destination to be used in the UDP header for the generated frames.
Direction	Select the direction of the interface on which the test must be run. This parameter is valid only for the ccc family. To enable the test to be run in the egress direction of the interface (network-to-network interface (NNI)), use the egress option. To enable the test to be run in the ingress direction of the interface (user-to-network interface (UNI)), use the ingress option.
DSCP Code Points	Specify the value of the Differentiated Services (DiffServ) field within the IP header of host-generated RPM packets. The DiffServ code point (DSCP) bits value must be set to a valid 6-bit pattern.
Forwarding Class	<p>Forwarding classes (FCs) allow you to group packets for transmission and to assign packets to output queues. The forwarding class and the loss priority define the per-hop behavior (PHB in DiffServ) of a packet.</p> <ul style="list-style-type: none"> assured-forwarding—Provides a group of values you can define and includes four subclasses—AF1, AF2, AF3, and AF4—each with three drop probabilities (low, medium, and high). best-effort—Provides no service profile. For the BE forwarding class, loss priority is typically not carried in a class-of-service (CoS) value, and random early detection (RED) drop profiles are more aggressive. expedited-forwarding—Provides a low-loss, low-latency, low-jitter, assured-bandwidth, end-to-end service. network-control—This class is typically high priority because it supports protocol control.
Halt on prefix down	By default, the RFC 2544-based benchmarking test ignores a prefix-down event (when the prefix associated with the test goes down) and continues to run. If you select this option, a prefix that moves to the down state causes the corresponding tests to be stopped. The show command output for the test displays that the test was terminated due to the prefix going down.
Inner VLAN ID	For dynamic VLAN interfaces, enter the VLAN ID to rewrite for the inner tag of the final packet.

Table 132: Fields in the Test Settings Pane (*continued*)

Field	Description
Mode	<p>initiate-and-terminate—Causes the test frames to be initiated at the router and the reflected back frames to be terminated. This mode requires a reflector to be configured at the peer end of the network to return back the generated frames. For initiator device, the initiate-and-terminate mode is selected by default.</p> <p>reflect—Causes the received test frames to be reflected back on the configured service (for example, inet, ccc). For reflector device, the reflect mode is selected by default.</p>
Outer VLAN ID	<p>The Outer VLAN ID field is disabled unless you provide a value for the Inner VLAN ID.</p> <p>Enter the outer VLAN ID for the test frames. Range: 0 through 4094 This parameter is valid only for family ccc mode.</p>
Skip ARP Iteration	<p>Select this option to disable the Address Resolution Protocol (ARP) test iteration for IPv4 or inet services during a benchmarking test. This parameter is valid only for an inet family. An ARP test iteration is a three-second iteration that is run for all inet tests. The results of this iteration are disregarded in the test result calculations. The ARP test iteration is executed by sending test frames to all the devices on the path to the destination for 3 seconds. This is to ensure that all devices add ARP entries in the cache of the corresponding devices.</p> <p>This parameter is not applicable for the ccc family.</p>
Test Iteration Duration	Enter the duration of each iteration in seconds, with a value from 10 seconds to 1,728,000 seconds.
Reflect eType	Specify the EtherType to be used for reflection of the test frames. EtherType is a two-octet field in an Ethernet frame that defines the protocol in the frame payload. This statement is valid only if you configure the test mode to be a reflector. If you do not configure this statement, all EtherTypes are reflected.
Reflect Mode	<p>Select the reflection mode for the benchmarking test.</p> <ul style="list-style-type: none"> • mac-swap—Swaps the source and destination MAC addresses in the test frame. This is the default behavior. • no-mac-swap—Does not swap the source and destination MAC addresses in the test frame. The frame is returned to the originator without any modification to the MAC addresses. • mac-rewrite—(ACX Series routers only) Enable rewriting of the MAC address on the reflected frames. The MAC addresses specified in the Source MAC Address and Destination MAC Address options are used.

RELATED DOCUMENTATION

[RFC 2544 Testing Overview | 1060](#)[Deploying RFC 2544 Tests | 1076](#)[Viewing RFC 2544 Test Results | 1076](#)

Deploying RFC 2544 Tests

After you create an RFC 2544 test, you must deploy the configuration to the test devices.

To deploy an RFC 2544 test:

1. Go to **OAM-RFC2544-Test > Manage Test Configuration**.

The Manage Test Configuration page appears displaying a list of the validated (**Order Status is Validated**) but un-deployed RFC 2544 tests.

2. To deploy an RFC 2544 test, select it and click **Actions > Deploy Service Order**.

The Schedule Service Order Deployment page appears providing deployment options.

- Select **Deploy Now** option to deploy the RFC 2544 test to the device immediately.
- Select **Deploy Later** if you want to schedule the deployment for a later date and time. Enter the deployment date and time in the **Date and time** field and select the time zone for the deployment.

3. Click **OK**.

If you have chosen **Deploy Now**, a Job Details page appears indicating that a job has been created to deploy the RFC 2544 to the device. You can click on the job ID link to view the details and status of the job in the **Job Management** page.

RELATED DOCUMENTATION

[RFC 2544 Testing Overview | 1060](#)[Creating an RFC 2544 Test Profile for Devices | 1070](#)

Viewing RFC 2544 Test Results

After the test run is completed, you can view the results as follows:

- To view the test results of an RFC 2544 test in CSD, select the test profile in the ServicePerformance-RFC2544 tab. The test results are displayed in the bottom pane.

The test results are based on the test parameter or metric that you chose while creating the test profile.

- If you have created a test profile to measure throughput, the following tabs appear:
 - Throughput Chart—Displays a chart that shows the throughput achieved for various frame lengths. Hover over various frame lengths on the chart to view details such as theoretical rate, transmitted (TX) packets, received packets (RX) packets, TX bytes, RX bytes, bandwidth, and iteration count. You can view more information on the test results in the Throughput Test Result tab.
 - Throughput Test Result—Displays the throughput results for different packet sizes and bandwidths.
 - Throughput Summary—Displays the test profile and test configuration.
- If you have created a test profile to measure frame loss, the following tabs appear:
 - Frameloss Chart—Displays a chart that shows the frame loss percentage for various frame lengths. Hover over various frame lengths on the chart to view details such as theoretical rate, TX packets, RX packets, TX bytes, RX bytes, bandwidth, and iteration count. You can view more information on the test results in the Frameloss Test Result tab.
 - Frameloss Test Result—Displays the frame loss results for different packet sizes and bandwidths.
 - Frameloss Summary—Displays the test profile and test configuration.
- If you have created a test profile to measure latency, the following tabs appear:
 - Latency Chart—Displays a chart that shows the latency for various frame lengths. Hover over various frame lengths on the chart to view details such as elapsed time, TX packets, RX packets, packets-per-second (PPS), measured bandwidth, and iteration count. You can view more information on the test results in the Latency Test Result tab.
 - Latency Test Result—Displays the latency results for different packet sizes and bandwidths.
 - Latency Summary—Displays the test profile and test configuration.
- If you have created a test profile to measure bursty frames, the following tabs appear:
 - Back Back Frame Chart—Displays a chart that shows the throughput achieved for various frame lengths. Hover over various frame lengths on the chart to view details such as elapsed time, TX packets, RX packets, TX bytes, RX bytes, bandwidth, and iteration count. You can view more information on the test results in the Back Back Frame Test Result tab.
 - Back Back Frame Test Result—Displays the back-to-back frame results for different packet sizes and bandwidths.
 - Back Back Frame Summary—Displays the test profile and test configuration.

RELATED DOCUMENTATION

RFC 2544 Testing Overview 1060
Creating an RFC 2544 Test Profile for Devices 1070

11

PART

Service Provisioning: Working with Services Deployment

Service Provisioning: Managing Deployed Services | **1080**

Service Provisioning: Managing Deployed Services

IN THIS CHAPTER

- [Managing Service Configuration Deployment Jobs | 1080](#)
- [Deploying Services Configuration to Devices | 1083](#)
- [Deploy Configuration Window | 1090](#)
- [Deleting a Partial Configuration of an LSP Service Order | 1091](#)
- [Deleting a Service Order | 1092](#)
- [Deploying a Service | 1094](#)
- [Validating the Pending Configuration of a Service Order | 1096](#)
- [Viewing the Configuration of a Pending Service Order | 1098](#)
- [Viewing Decommissioned E-Line, E-LAN, and IP Service Orders | 1100](#)
- [Modifying an E-Line Service | 1102](#)
- [Modifying a Multipoint-to-Multipoint Ethernet Service | 1104](#)
- [Modifying a Point-to-Multipoint Ethernet Service | 1111](#)
- [Modifying a Hub-and-Spoke IP Service Order | 1120](#)
- [Modifying a Full Mesh IP Service | 1137](#)
- [Understanding Service Validation | 1142](#)
- [Highlighting of Endpoints in the IP, RSVP LSP, and E-LAN Service Modification Wizards | 1143](#)

Managing Service Configuration Deployment Jobs

IN THIS SECTION

- [Selecting Service Configuration Deployment Job Options | 1081](#)
- [Viewing Service Configuration Deployment Job Details | 1082](#)
- [Canceling Service Configuration Deployment Jobs | 1082](#)

When you Deployment Jobs changes or schedule a configuration deployment, a service configuration deployment job is created.

To start managing configuration deployment jobs:

1. Click **Deploy** in the Connectivity Services Director banner.
2. In the Tasks pane, select **View Deployment Jobs**.

The CSD Deployment Jobs page opens in the bottom part of the main window. The table on that page lists configuration deployment jobs.

This topic describes:

Selecting Service Configuration Deployment Job Options

From the Deployment Jobs page, you can:

- View the details of a service configuration deployment job by clicking Show Details. See [“Viewing Configuration Deployment Job Details” on page 823](#) for more information.
- Cancel a scheduled service configuration deployment job by clicking Cancel Job. See [“Canceling Configuration Deployment Jobs” on page 823](#) for more information.

[Table 99 on page 822](#) describes the information provided on the Deployment Jobs page

Table 133: Deployment Jobs Table Description

Table Column	Description
Check box	Select to perform an action on the job in that row.
Job Id	An identifier assigned to the job.
Job Name	Job name (user-created).
Percent	Percentage of the job that is complete.

Table 133: Deployment Jobs Table Description (*continued*)

Table Column	Description
Status	<p>Job status. The possible states are:</p> <ul style="list-style-type: none"> • CANCELLED—The job was cancelled by a user. • FAILURE—The job failed. This state is applied if any of the devices in the job failed. But some of the devices might have completed successfully. View the job details for the status of each device. • INPROGRESS—The job is running. • SCHEDULED—The job is scheduled but has not run yet. • SUCCESS—The job completed successfully. This state is applied if all of the devices in the job completed successfully.
Summary	Job summary.
Scheduled Start Time	Job's scheduled start time
Actual Start Time	Time when the job started.
End Time	Time when the job ended
User	User who created the job
Recurrence	This field is not used for configuration deployment jobs.

Viewing Service Configuration Deployment Job Details

To view the details of a configuration deployment job:

1. Select the job in the table.
2. Click **Show Details**. The Deployment Jobs window opens. See *Deploy Configuration Window* for a description of the window.

Canceling Service Configuration Deployment Jobs

To cancel a configuration deployment job:

1. Select the job in the table.
2. Click **Cancel Job**.

3. Click **Yes** in the confirmation window that opens.

Deploying Services Configuration to Devices

IN THIS SECTION

- [Selecting Configuration Deployment Options | 1085](#)
- [Validating Configuration | 1085](#)
- [Deleting the Partial Service Configurations | 1087](#)
- [Discarding the Pending Configurations | 1088](#)
- [Deploying Configuration Changes to Devices Immediately | 1089](#)
- [Scheduling Configuration Deployment | 1089](#)
- [Specifying Configuration Deployment Scheduling Options | 1090](#)

When you make configuration changes in Build mode, the changes are not deployed to devices automatically. You must manually deploy the changes to devices in Deploy mode.

To start deploying configuration changes:

1. From the View selector, select **Service View**. The workspaces that are applicable to this view are displayed.
2. Click **Deploy** in the Connectivity Services Director banner.
3. Click the plus sign (+) beside Connectivity to expand the tree in the View pane and view the list of service types.
4. Select the type of service, such as E-Line, L2VPN, or E-LAN, for which you want to deploy the service order.
5. In the Tasks pane, select **Service Provisioning > Deploy Services**. The Manage Service Deployment window is displayed in the bottom part of the right pane.

TIP: From Build mode of Service View, in the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

The following fields are displayed in this window:

- Name—Unique name assigned to the service.
- Customer—Name of the customer for which the service is provided.
- State—Status of the service order. Service orders can be one of the following states:
 - Completed—The service order has been successfully deployed.
 - Scheduled for deployment—The service provisioner has scheduled the service order for deployment.
 - Deployment Failed—An attempted service deployment was not successfully completed or failed an audit.
 - In Progress—The Connectivity Services Director application is in the process of deploying the service.

- Requested—The service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
- Invalid—The service order is not valid.
- Signaling—Type of signaling, namely, BGP or LDP.
- Created By—Name of the user that created the service order.
- Created Date—Date and time at which the service order was created.

This topic describes:

Selecting Configuration Deployment Options

Based on the approval mode, you can choose to deploy the device configuration changes in the following ways:

- When you select the auto approval mode, the page *Devices with Pending Changes* open. From the *Devices with Pending Changes* page, you can:
 - Deploy configuration changes immediately by selecting one or more devices and clicking *Deploy Now*. For more information, see [“Deploying Configuration Changes to Devices Immediately” on page 817](#).
 - Schedule configuration deployment by selecting one or more devices and clicking *Schedule Deploy*. For more information, see [“Scheduling Configuration Deployment” on page 817](#).
 - View configuration changes that are pending on a device by clicking *View* in the *Configuration Changes* column.
 - Validate that the pending changes for a device are compatible with the device’s configuration by selecting up to ten devices and clicking *Validate Pending Configuration Changes*. For more information, see [“Validating Configuration” on page 814](#).
 - Discard the pending configuration changes. For more information, see [“Discarding the Pending Configurations” on page 1088](#).

Validating Configuration

When you deploy configuration changes to a device, validation checks are performed to validate that the pending changes are compatible with the device. You can also perform this validation without deploying.

NOTE: You can also verify the configuration from the Build mode by clicking **Tasks > Domain Management > Validate Pending Configuration**.

To view the configuration of such service orders:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Service Deployment page is displayed on the right pane.

TIP: From Build mode of Service View, in the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

4. Select a service order that is in either of the following states:

- Requested
- Invalid
- Scheduled
- Failed deployment

NOTE: The **Order State** column displays the state of the service order.

5. Right-click the service order and select the **View Pending Order Configuration**. The **Pending Order Configuration** window is displayed. The configuration is displayed in xml format.

NOTE: The **View Pending Order Configuration** appears to be dimmed if the service order state is Completed.

6. Select a device to view the configuration details. You can also view the template configuration if a template is attached to the service order.

Deleting the Partial Service Configurations

A failed service order of type Provisioning can leave parts of the service configuration on the devices.

To remove the partial configuration of services that are present on the associated devices of the service order:

1. From the View selector, select **Service View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that are applicable to this lifecycle mode are displayed.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Orders page, with the table of service orders.
6. From the Manage Service Orders page, select the services for which you want to delete the partial configuration and click **Delete Partial Configuration** from the Actions menu.

A dialog box is displayed, prompting you to specify whether you want to delete the partial service configuration immediately or schedule the partial deletion for a future specified time.
7. To delete the pending changes of the service immediately, select **Partial Delete Now**, and click **OK**. To discard the pending changes of the service at a later time, select **Partial Delete Later**, select a date and time for deletion, then click **OK**. The time field specifies the time kept by the server, but in the time zone of the client. After scheduling the service order for deployment, the provisioning software begins validating the service order.

You are returned to the Manage Service Orders page.

Discarding the Pending Configurations

Use the Discard Local Configuration Changes Results window to discard all the pending service configurations that were made on a device. Once you discard the local configuration changes on a device, the configuration state of the device changes to In Sync or Out of Sync based on the system of record (SOR) mode set for the Junos Space Network Management Platform. If the SOR mode is set to Network as system of record (NSOR), then the configuration state changes to In Sync and if the SOR mode is set to Junos Space as system of record (SSOR), then the configuration state changes to Out of Sync.

To discard the configuration changes:

1. From the View selector, select **Service View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that are applicable to this lifecycle mode are displayed.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
6. From the Manage Service Deployment page, select the services for which you want to discard the pending configuration and click **Discard Pending Configuration** from the Actions menu.
7. You are prompted to confirm whether you want to discard the service order, which causes the associated service to be deleted along with it. Click **OK** to confirm the deletion.
8. Click **OK** to close the dialog box that displays the job ID. The Manage Service Orders page appears.

Deploying Configuration Changes to Devices Immediately

To deploy configuration changes to devices immediately:

1. Select the check box next to the service you want to deploy from the Manage Service Deployment page.
2. Click **Deploy Now**.

The Deploy Options window opens.

3. In the Deploy Options window, enter a job name in the Deployment Job Name field, then click **OK**.

The configuration deployment job runs. The Deploy Configuration window opens and shows the results of the deployment job.

Scheduling Configuration Deployment

To schedule configuration deployment to devices:

1. Select the check box next to the service you want to deploy from the Manage Service Deployment page.
2. Click **Schedule Deploy**.

The Deploy Options window opens.

3. Use the Deploy Options window to schedule the configuration deployment. See [“Specifying Configuration Deployment Scheduling Options” on page 818](#) for a description of the window.

Specifying Configuration Deployment Scheduling Options

Use the Deploy Options window to schedule configuration deployment jobs. [Table 98 on page 818](#) describes the actions for the fields in this window.

Table 134: Deploy Options Window

Field	Action
Deployment Job Name	Enter a job name.
Date and Time	Enter the job's start date and time.
OK	Click to accept changes and exit the window.
Cancel	Click to cancel changes and exit the window.

Deploy Configuration Window

The Deploy Configuration window shows the results of a completed deployment job or information about a scheduled job. See [Table 100 on page 824](#) for a description of the fields in this window.

Table 135: Deploy Configuration Window

Field	Description
Job Name	Job name.
Job Start Time	Time when job started or will start.
Job End Time	Time when job ended.
Percentage Completed	Percentage of the job that is complete.
Number of Devices	Number of devices in the deployment job.
Deployed Devices table	
Name	Device name.
IP Address	Device IP address.

Table 135: Deploy Configuration Window (*continued*)

Field	Description
Deployment Status	<p>Status of configuration deployment on device:</p> <ul style="list-style-type: none"> • Scheduled—Job is scheduled for future deployment. • In Progress—Deployment is in progress. • Success—Deployment completed successfully. • Failed—Deployment failed.
Configuration	<p>Click View to see the configuration changes that were deployed to the device.</p> <p>For a scheduled job, this column does not contain a link. See “Deploying Services Configuration to Devices” on page 1083 for information about viewing pending configuration changes for a device.</p>
Result Details	Click View to see the results of configuration deployment for the device.
Close	Click to close the window.

RELATED DOCUMENTATION

[Deploying Configuration to Devices | 808](#)

[Managing Configuration Deployment Jobs | 821](#)

Deleting a Partial Configuration of an LSP Service Order

A failed service order of type Provisioning can leave parts of the service configuration on the devices. To remove this partial configuration:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.

- Expand the **IP Services** tree to select an IP Ethernet service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
 6. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services > service order name**.
 7. In the **Manage Service Deployment** page, select the failed service order for which you want to delete the partial configuration.
 8. Open the **Actions** menu and select **Delete Partial Configuration**.
 9. In the confirmation screen, select **Delete**.

RELATED DOCUMENTATION

[Managing Service Configuration Deployment Jobs | 1080](#)

[Deploying Services Configuration to Devices | 1083](#)

[Deploy Configuration Window | 824](#)

[Managing Jobs | 122](#)

Deleting a Service Order

You can delete a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state.

To delete a service order from the database:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

3. From the **Network Services** task pane, select **Connectivity** or **Tunnel**.
4. In the **Tasks** task pane, select **Decommissioned Service Orders**.
5. In the **Decommissioned Service Orders** page, select the service order to be deleted from the Connectivity Services Director application database.
6. Click **Delete**.

The **Manage Service Deployment** page reappears with the deleted service orders removed.

To delete a service order from a service, which is not decommissioned:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services** task pane, select a service in **Connectivity** or **Tunnel**.
4. In the **Tasks** task pane, select **Service Provisioning > Manage Services**.
5. In the **Manage Network Service** page, select a service from which the service order must be deleted.
6. In the **Manage Service Order** page, select the service order.
7. Click **Actions** menu, and select **Discard pending Configuration**.

The selected service order along with the associated service is deleted.

RELATED DOCUMENTATION

[Creating an E-Line Service Order | 895](#)

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

Deploying a Service

This procedure schedules a service for deployment on the network. Use this procedure to perform the following tasks:

- Deploy a new service.
- Deploy a modified service.
- Redeploy a service order that failed deployment.

You cannot deploy an invalid service order.

To schedule a service for deployment:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Service Deployment page is displayed on the right pane.

TIP: From Build mode of Service View, in the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

4. In the **Manage Service Deployment** page, select the service order that you want to deploy.

5. Click the **Deploy Service Order** button at the top of the page.

The **Deploy Service** window appears.

6. To deploy the service immediately, select **Deploy now**, and click **OK**.

To deploy the service at a later time, select **Schedule Deploy**, and select a date and time for deployment, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.

After scheduling the service order for deployment, the provisioning software begins validating the service order.

7. Use the Jobs workspace to monitor the outcome of the deployment.

RELATED DOCUMENTATION

[Validating the Pending Configuration of a Service Order | 1096](#)

[Viewing the Configuration of a Pending Service Order | 1098](#)

Validating the Pending Configuration of a Service Order

This procedure validates a service order but does not push the configuration to the device. Use this procedure to perform the following tasks:

- Validate a service request in the REQUESTED state.
- Validate a service request in the INVALID state after making necessary configuration changes on one or more PE devices associated with the service order.

When you create a service order, it is automatically validated in Connectivity Services Director. However, if subsequent changes to service configuration attributes and settings have occurred for the devices or endpoints to which they are associated, you can use the functionality to validate pending service order configuration. You can validate the configuration of a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state

To schedule a service order for validation, follow these steps:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select a IP t service.
 - Expand the **E-Line Services** tree to select an E-Line service.

- Expand the **E-LAN Services** tree to select an E-LAN service.
5. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
 6. From the Manage Service Deployment page, select the service order you want to validate and save.
 7. Open the **Actions** menu and click **Validate Pending Configuration**.
The **Schedule Service Request Validation** window appears.
 8. You can validate a service now or at some future time:
 - To validate the service immediately, select **Validate now**, and click **OK**.
 - To validate the service at a later time, select **Validate later**, select a date and time for deployment, and then click **OK**.

NOTE: When specifying a time to validate the service, the time field specifies the time kept by the server, but in the time zone of the client.

After scheduling the service order for validation, the provisioning software begins validating the service order.

9. You can use the **Job Management** window to view details about the service validation.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

RELATED DOCUMENTATION

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

Viewing the Configuration of a Pending Service Order

You can view the configuration of a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state.

To view the configuration of such service orders:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Service Deployment page is displayed on the bottom part of the right pane.

TIP: From Build mode of Service View, in the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

4. Select a service order that is in either of the following states:

- Requested
- Invalid
- Scheduled
- Failed deployment

NOTE: The **Order State** column displays the state of the service order.

5. Select the service order for which you want to view the configuration details.

6. Open the **Actions** menu and select the **View Pending Order Configuration** option. The **Pending Order Configuration** window is displayed. The configuration is displayed in xml format.

NOTE: The **View Pending Order Configuration** appears to be dimmed if the service order state is Completed.

7. Select a device to view the configuration details. You can also view the template configuration if a template is attached to the service order.

Based on the application's settings, the configuration is displayed in xml format or in set format. To view the configuration in set format:

1. Select **Platform > Administration > Applications > Connectivity Services Director**.
2. Right-click the Connectivity Services Director application and select **Modify Application Settings**. The Modify Connectivity Services Director Settings window is displayed.
3. Select the **show configuration in set format** check box.

RELATED DOCUMENTATION

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

[Validating the Pending Configuration of a Service Order | 1096](#)

Viewing Decommissioned E-Line, E-LAN, and IP Service Orders

In certain situations, you might decommission a service that a customer no longer needs. You cannot decommission a service if a service order requesting action on that service is in the Requested, Scheduled, In Progress, or Invalid state. You can view the decommissioned service orders in a separate page to determine whether you want to delete it completely.

To view and determine the status of decommissioned service orders in a tabular form:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Connectivity Services Director user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the Network Services tree, and select the Connectivity node.
4. In the Network Services > Connectivity view pane, select **Service Provisioning > Decommissioned Service Orders**.

The Decommissioned Service Orders page is displayed on the right pane.

A table of service orders on the system appears in the main display area. The following fields are displayed on this page:

- Name—Unique name assigned to the service.
- Customer—Name of the customer for which the service is provided.
- State:
 - Completed—Service order has been successfully deployed.
 - Deploy failed—Device is down or the Connectivity Services Director application was unable to push the service configuration to a device configured for the service.
 - In-progress—Connectivity Services Director application is in the process of deploying the service.
 - Invalid—Service order contains invalid data.
 - Requested—Service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
 - Scheduled—Service provisioner has scheduled the service order for deployment.
- Service Type:
 - E-Line pseudowire (LDP)
 - E-Line pseudowire (BGP)
 - E-LAN (MultiPoint-to-MultiPoint)
 - E-LAN (Point-to-MultiPoint)
 - IP (Full Mesh)
 - IP (Hub-Spoke 1 Interface)

- Latest Job—Unique identifier assigned by the system for a deployment job. Click the link in the job ID to open the CSD Deployment Jobs. The table on that page lists configuration deployment jobs.
- Signaling Type:
 - BGP
 - LDP
- Created By—The screen name of the user who created the service order
- Created Date—The date and when you created the service order.

From this page, you can delete a decommissioned service order and view the details of a service order.

5. Select the check box beside a decommissioned service order that you want to delete, and click **Delete** above the table of listed service orders.

You are prompted to confirm the deletion. Click **OK** to confirm the deletion. The deleted service order is removed from the list of decommissioned service orders.

6. To view details of a specific service order, double-click the table row that summarizes the service order.

Modifying an E-Line Service

You can modify the following entities of an E-Line service:

- MTU across the network
- Rate limiting bandwidth of an endpoint
- MTU of an endpoint

After modifying a service, the configuration audit and functional audit information is cleared and the functional audit status is set to pending.

To modify the attributes of a service:

NOTE: When you modify a service or a service order, the read-only fields in the different pages of the wizard for service or service order modification are grayed out to indicate that you cannot modify those attributes.

1. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service you want to modify.
3. Click the **Modify** icon at the top of the page.

A graphical image of the service appears, showing device images that represent the service endpoints. The General Settings box contains a unique name for the service order that will request the change.
4. In the **Name** field, change the name of the modification service order, if desired.
5. Change the MTU setting, as required.
6. If you have configured the CFM, the **General/Connectivity Settings** panel provides an option to disable the CFM service. You can select the **Disable CFM** check box to disable the CFM service, if desired.

If you have not configured the CFM, the **General/Connectivity Settings** panel provides an option to enable the CFM service. You can select the CFM definition from the **OAM Profile** list, if desired.
7. Click **Next**.

The service order endpoint settings information for endpoint A appears in the right panel.
8. Change the bandwidth or MTU setting as required.
9. Change the **Revert time (sec)** and **Switch Over Delay (sec)** as required.
10. Select or clear the **Enable send-oam config** check box.
11. Click **Next** and make any required changes to endpoint Z.
12. Click **Modify**.

The Connectivity Services Director application modifies the service.

13. Use the **System > Manage Jobs > Job Management** workspace to check for successful completion of the action.

NOTE: Alternatively, to display the Job Management page, access the Jobs workspace from the Junos Space Network Management Platform UI, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

[Creating an E-Line Service Order | 895](#)

Modifying a Multipoint-to-Multipoint Ethernet Service

For a multipoint-to-multipoint service, you can change the bandwidth or MTU of a specific UNI, add or delete a UNI, change C-VLAN range values, and change advanced settings for a device endpoint or add a new device endpoint.

You cannot change the interface of an existing UNI. Neither can you change the service VLAN ID.

To perform the equivalent of changing the interface on an existing UNI, add a new UNI with the desired interface, and then delete the old UNI.

After modifying a service, the configuration audit and functional audit information is cleared and the functional audit status is set to pending.

Modifying a service creates a new service order based on the attribute settings of the existing service.

NOTE: When you modify a service or a service order, the read-only fields in the different pages of the wizard for service or service order modification are grayed out to indicate that you cannot modify those attributes.

The following topics provide instructions for modifying a multipoint-to-multipoint (full mesh) Ethernet service:

- [Adding an Endpoint | 1105](#)
- [Adding a UNI Interface | 1106](#)
- [Deleting a UNI Interface and Deleting an Endpoint | 1108](#)
- [Changing the Endpoint Bandwidth | 1109](#)
- [Changing Advanced Settings for an Endpoint | 1110](#)

Adding an Endpoint

To add an endpoint to a multipoint-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning** > **Manage Services**.
2. In the **Manage Services** page, select the service to which you want to add an endpoint.
3. Click **Modify** at the top of the table of listed service orders.

Current service settings appear in the main display area. The **General Information** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.
5. If you have configured the CFM, the **Service Parameters** panel provides an option to disable the CFM service. You can select the **Disable CFM** check box to disable the CFM service, if desired.

If you have not configured the CFM, the **Service Parameters** panel provides an option to enable the CFM service. You can select the CFM definition from the **OAM Profile** list, if desired.
6. Click the **Node Settings** button to view the endpoints or devices that are associated with the service.
7. In the **Service Nodes** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

8. Select the devices on which you want to add new endpoints, then click **OK**. You are returned to the Node Settings page of the Manage Service Orders wizard.

To filter and sort the display of objects, enter the name of the object as a match criterion in the Search box and click the Search icon. The page refreshes to display only the object names that match with the search term. You can use the paging controls to navigate across multiple pages of objects as necessary.

Based on the devices you select in the top half of the dialog box, the interfaces that are present in the selected device are displayed in the lower half of the dialog box. Select the check boxes next to the interfaces that you want to associate with the service.

The service modification window shows the added devices with system recommended choices for UNI. To select a different UNI, see [“Adding a UNI Interface” on page 1106](#). To select a different bandwidth than the applied default, see [“Changing the Endpoint Bandwidth” on page 1109](#).

9. Click **Finish** to complete the modification of the service order and save the settings.
10. In Deploy mode of the Service View of the Connectivity Services Director, select one of the following from the Manage Services page:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
11. Click **OK**.
12. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Adding a UNI Interface

To add a UNI on a device that is already part of a multipoint-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service to which you want to add a UNI.
3. Click **Modify** at the top of the table of listed service orders.

Current service settings appear in the main display area. The **Service Parameters** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.
5. Click the **Site/Endpoint Settings** button to view the interfaces on endpoints or devices that are associated with the service.
6. In the **User-to-Network Interfaces** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

7. Select the devices on which you want to add new interfaces. The window refreshes to display all the user-to-network (UNI) or ingress interfaces for the selected device in the lower part of the window as a tabular grid. Select the interfaces that you want to assign to the service order, and then click **OK**.

To filter and sort the display of objects, enter the name of the object as a match criterion in the Search box and click the Search icon. The page refreshes to display only the object names that match with the search term. You can use the paging controls to navigate across multiple pages of objects as necessary.

You are returned to the Node Settings page of the Manage Service Orders wizard.

The service modification window shows the added devices with system recommended choices for UNI. To select a different bandwidth than the applied default, see [“Changing the Endpoint Bandwidth” on page 1109](#).

8. If the interface you selected in the previous step is already configured (duplicate) you must either manually enter a different value in the service VLAN ID fields, or check the **Autopick VLAN ID** field.
9. Select an interface from the UNI Interface column.
10. Click **Finish** to complete the modification of the service order and save the settings.
11. In Deploy mode of the Service View of the Connectivity Services Director, select one of the following from the Manage Services page:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
12. Click **OK**.
13. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, and select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Deleting a UNI Interface and Deleting an Endpoint

To delete a UNI from a multipoint-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.

2. In the **Manage Services** page, select the service from which you want to delete a UNI.

3. Click **Modify** at the top of the table of listed service orders.

Current service settings appear in the main display area. The **Service Parameters** page contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.

5. Click the **Site/Endpoint Settings** button to view the interfaces on endpoints or devices that are associated with the service.

6. In the **User-to-Network Interfaces** table, select the interfaces that you want to remove from being assigned to the service order, and click **Delete** at the top of the table.

The selected UNI is removed from the table. If the deleted UNI was the only UNI selected on that device, then the device is deleted from the Endpoint Settings table.

7. Click **Finish** to save the modified service order.

8. In Deploy mode of the Service View of the Connectivity Services Director, select one of the following from the Manage Services page:

- Schedule the change for immediate deployment.
- Schedule the change for later deployment.

9. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Jobs workspace of the Junos Space Platform UI, select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Changing the Endpoint Bandwidth

To change the rate limit or bandwidth for an endpoint of a multipoint-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service on which you want to change the bandwidth of an endpoint.
3. Click **Modify** at the top of the table of listed service orders.

Current service settings appear in the main display area. The **Service Parameters** page of the wizard contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.
5. Click the **Site/Endpoint Settings** button to navigate to the corresponding page of the wizard. Click on the **Bandwidth** entry for the UNI on which you want to change the bandwidth.
6. From the list of valid bandwidth settings, select the setting you want, then click **Finish**.
7. In Deploy mode of the Service View of Connectivity Services Director, select one of the following:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
8. Click **OK**.
9. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Changing Advanced Settings for an Endpoint

To change advanced settings for an endpoint of a multipoint-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service on which you want to change one or more advanced settings for an endpoint.
3. Click **Modify** at the top of the table of listed service orders.

Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modified service order, if desired.
5. In the **Endpoint Settings** page of the wizard, find the device endpoint you want to modify, and click **Advanced** for that table row.

The **Advanced Setting** window displays the security and advanced settings that you can configure for a device.

See the *Service Attributes Overview* for more information about configuring MAC security settings and advanced settings.

6. In the **MAC Security Settings** box, make selections for MAC learning and MAC statistics and enter values for Interface MAC limit, MAC table size, and MAC table aging time.
7. Enable or disable tunnel services by selecting or clearing the **disable-tunnel-service** check box.
8. Enable or disable local switching by selecting or clearing the **disable-local-switching** check box.
9. In the **Fast reroute priority** field, specify the reroute priority for a VPLS routing instance.
10. In the **Label block size** field, specify the label block size for VPLS labels.

11. In the **Connectivity type** field, select a connection-type to specify when a VPLS connection is taken down, depending on whether or not the interface for the VPLS routing instance is customer-facing or integrated routing and bridging (IRB)
12. Click **OK** to save all your changes in the Advanced Setting window.
13. Click **Finish**.
14. In Deploy mode of the Service View, select one of the following:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
15. Click **OK**.
16. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

RELATED DOCUMENTATION

[Creating a Full Mesh IP Service Order | 995](#)

[Creating a Hub-and-Spoke IP Service Order | 1019](#)

Modifying a Point-to-Multipoint Ethernet Service

For a point-to-multipoint service, you can add a spoke or a hub, change the role of a device from hub to spoke or spoke to hub, change the bandwidth or MTU of a specific UNI, or add or delete a UNI.

You cannot change the interface of an existing UNI or the service VLAN ID.

To perform the equivalent of changing the interface on an existing UNI, add a new UNI with the desired interface, and then delete the old UNI.

After modifying a service, the configuration audit and functional audit information is cleared and the functional audit status is set to pending.

Modifying a service creates a new service order based on the attribute settings of the existing service.

The following topics provide instructions for modifying a multipoint Ethernet (E-LAN) service:

NOTE: When you modify a service or a service order, the read-only fields in the different pages of the wizard for service or service order modification are grayed out to indicate that you cannot modify those attributes.

- [Adding a Spoke | 1112](#)
- [Adding a Hub | 1113](#)
- [Changing a Spoke to a Hub | 1114](#)
- [Changing a Hub to a Spoke | 1115](#)
- [Adding a UNI Interface | 1116](#)
- [Deleting a UNI Interface or Deleting an Endpoint | 1117](#)
- [Changing the Endpoint Bandwidth | 1118](#)
- [Changing Advanced Settings for an Endpoint | 1119](#)

Adding a Spoke

To add an endpoint configured as a spoke to a multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the point-to-multipoint service to which you want to add a spoke.
3. Click the **Modify** icon at the top of the table of previously created service orders.
Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.
4. In the service **Order name** field, change the name of the modification service order, if desired.
5. If you have configured the CFM, the **General Settings** panel provides an option to disable the CFM service. You can select the **Disable CFM** check box to disable the CFM service, if desired.

If you have not configured the CFM, the **General Settings** panel provides an option to enable the CFM service. You can select the CFM definition from the **OAM Profile** list, if desired.

6. Click the **Node Settings** button to view the endpoints or devices that are associated with the service.

7. In the **Service Nodes** table, click **Add**.

The **Choose Endpoints** dialog box shows available N-PE devices that are not part of the service.

The dialog box is divided into two halves. The top half of the dialog box displays the devices that you can associate with the service. Based on the devices you select in the top half of the dialog box, the interfaces that are present in the selected device are displayed in the lower half of the dialog box. Select the check boxes next to the interfaces that you want to associate with the service.

8. In the **Endpoint Settings** table, check **Spoke** for the device you just added.

9. Click **Finish** to complete the modification of the service order and save the settings.

10. In Deploy mode of the Service View of Connectivity Services Director, select one of the following from the Manage Services page:

- Schedule the change for immediate deployment.
- Schedule the change for later deployment.

Adding a Hub

To add an endpoint to a multipoint Ethernet service:

1. In the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.

2. In the **Manage Services** page, select the service to which you want to add a hub.

3. Click the **Modify** icon at the top of the table of previously created service orders.

Current service settings appear in the main display area. The **General Information** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.

5. Click the **Node Settings** button to view the endpoints or devices that are associated with the service.

6. In the **Service Nodes** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

The dialog box is divided into two halves. The top half of the dialog box displays the devices that you can associate with the service. Based on the devices you select in the top half of the dialog box, the

interfaces that are present in the selected device are displayed in the lower half of the dialog box. Select the check boxes next to the interfaces that you want to associate with the service.

7. In the **Endpoint Settings** table, check **Spoke** for the device you just added.
8. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Changing a Spoke to a Hub

To change a spoke to a hub in a point-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the point-to-multipoint service for which you want to change a spoke to a hub.
3. Click the **Modify** icon at the top of the table of previously created service orders.
Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.
4. In the service **Order name** field, change the name of the modification service order, if desired.
5. In the **Device** column of the **Endpoint Settings** table, find the spoke endpoint you want to change to a hub and select the **Hub** check box.
6. Click **Finish** to save the modified service order properties.
7. In Deploy mode of the Service View of Connectivity Services Director, select one of the following:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
8. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Changing a Hub to a Spoke

NOTE: You cannot change the only hub of a point-to-multipoint service to a spoke. You will receive an error message when you try to save such a service configuration.

To change a hub to a spoke in a point-to-multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the point-to-multipoint service for which you want to change a hub to a spoke.
3. Click the **Modify** icon at the top of the table of previously created service orders.
Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.
4. In the service **Order name** field, change the name of the modification service order, if desired.
5. In the **Device** column of the **Endpoint Settings** table, find the spoke endpoint you want to change to a hub and clear the **Hub** check box.
6. Click **Finish** to save the modified service order properties.
7. In Deploy mode of the Service View of Connectivity Services Director, select one of the following:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
8. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Adding a UNI Interface

To add a UNI on a device that is already part of a multipoint Ethernet service:

1. in the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service to which you want to add a UNI.
3. Click the **Modify Service** icon at the top of the page of previously defined service orders.
Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.
4. In the service **Order name** field, change the name of the modification service order, if desired.
5. Click the **Site/Endpoint Settings** button to view the interfaces on endpoints or devices that are associated with the service.
6. In the **User-to-Network Interfaces** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

7. Select the devices on which you want to add new interfaces. The window refreshes to display all the user-to-network (UNI) or ingress interfaces for the selected device in the lower part of the window as a tabular grid. Select the interfaces that you want to assign to the service order, and then click **OK**.

To filter and sort the display of objects, enter the name of the object as a match criterion in the Search box and click the Search icon. The page refreshes to display only the object names that match with the search term. You can use the paging controls to navigate across multiple pages of objects as necessary.

You are returned to the Node Settings page of the Manage Service Orders wizard.

The service modification window shows the added devices with system recommended choices for UNI.

8. If the interface you selected in the previous step is already configured (duplicate) you must either enter a different value in the service **VLAN ID** field manually, or check the **Autopick VLAN ID** field.

9. Click **Modify**.

10. In the **Deployment Options** window, select one of the following:

- Save the change without scheduling it.
- Schedule the change for immediate deployment.
- Schedule the change for later deployment.

11. Click **OK**.

12. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Deleting a UNI Interface or Deleting an Endpoint

NOTE: You cannot delete the last endpoint on the only hub device in the service. You will receive an error message when you try to save such a service configuration.

To delete a UNI from a multipoint Ethernet service:

1. In the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.

2. In the **Manage Services** page, select the service from which you want to delete a UNI.

3. Click the **Delete** icon at the top of the page.

Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.

5. Click the **Site/Endpoint Settings** button to view the interfaces on endpoints or devices that are associated with the service.

6. In the **User-to-Network Interfaces** table, select the interfaces that you want to remove from being assigned to the service order, and click **Delete** at the top of the table.

The selected UNI is removed from the table. If the deleted UNI was the only UNI selected on that device, then the device is deleted from the Endpoint Settings table.

7. Click **Finish** to save the modified service order.
8. In Deploy mode of the Service View of Connectivity Services Director, select one of the following from the Manage Services page:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
9. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Changing the Endpoint Bandwidth

To change the rate limit or bandwidth for an endpoint of a multipoint Ethernet service:

1. In the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service on which you want to change the bandwidth of an endpoint.
3. Open the **Actions** menu and select **Modify Service**.

Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.
5. Click the **Site/Endpoint Settings** button to navigate to the corresponding page of the wizard. Click on the **Bandwidth** entry for the UNI on which you want to change the bandwidth.

6. From the list of valid bandwidth settings, select the setting you want, then click **Modify**.
7. In Deploy mode of the Service View of Connectivity Services Director, select one of the following:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.

Changing Advanced Settings for an Endpoint

To change advanced settings for an endpoint of a point-to-multipoint Ethernet service:

1. In the Network Services > Connectivity view pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service on which you want to change one or more advanced settings for an endpoint.
3. Click the **Modify** icon at the top of the page.

Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modified service order, if desired.
5. In the **Action** column of the **Endpoint Settings** table, find the device endpoint you want to modify, and click **Advanced** for that table row.

The **Advanced Setting** window displays the security and advanced settings that you can configure for a device.

6. In the **MAC Settings** box, make selections for MAC learning and MAC statistics and enter values for Interface MAC limit, MAC table size, and MAC table aging time.
7. Enable or disable tunnel services by selecting or clearing the **disable-tunnel-service** check box.
8. Enable or disable local switching by selecting or clearing the **disable-local-switching** check box.
9. In the **Fast reroute priority** field, specify the reroute priority for a VPLS routing instance.
10. In the **Label block size** field, specify the label block size for VPLS labels.
11. In the **Connectivity type** field, select a connection-type to specify when a VPLS connection is taken down, depending on whether the interface for the VPLS routing instance is customer-facing or integrated routing and bridging (IRB)

12. Click **OK** to save all your changes in the **Advanced Setting** window.
13. In Deploy mode of the Service View in the Connectivity Services Director GUI, select one of the following:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
14. Click **OK**.
15. Use the **System > Manage Jobs > Job Management** workspace to monitor the progress and status of the deployment.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

RELATED DOCUMENTATION

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

[Creating an E-Line Service Order | 895](#)

Modifying a Hub-and-Spoke IP Service Order

You can modify and deploy previously configured IP hub-and-spoke service orders. Modifying a service order involves the following tasks:

NOTE: When you modify a service or a service order, the read-only fields in the different pages of the wizard for service or service order modification are grayed out to indicate that you cannot modify those attributes.

1. [Viewing the Service Definition | 1121](#)
2. [Configuring Service Parameters Information | 1122](#)

3. [Selecting N-PE Devices or Nodes | 1128](#)
4. [Setting Attributes for Endpoints or Nodes | 1129](#)
5. [Adding and Deleting UNI Interfaces | 1132](#)
6. [Setting Attributes for UNIs or Sites | 1133](#)
7. [Deploying the New Service | 1136](#)

Viewing the Service Definition

To view the service definition on which the service order is based:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
5. Select IP Services to manage IP Ethernet service orders.
6. You can modify a service order or a deployed service in either of the following ways:

From the Manage Network Services page, do the following:

- a. Select the check box beside the service that you want to modify.
- b. Click **Edit** at the top of the table of the listed services.

The Edit Service Order wizard is displayed. You can navigate to the various pages of the wizard by clicking the buttons at the top of the page or the navigation buttons at the bottom of the page.

From the Manage Service Deployment page, do the following:

- a. From the Manage Service Deployment page, select the check box beside the service you want to modify.
- b. Click **Edit** at the top of the table of the listed services.

The Review page or step of the Edit Service Order wizard is displayed. You can click **Edit** beside the sections in the page for which you want to update the configuration parameters. The settings that you can configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Edit Service Order page. Alternatively,

you can proceed to the corresponding setting-related pages by clicking the Back and Next buttons at any point in the wizard.

7. From the Service Definition field, click **View** to open a popup dialog box that displays the details of the selected service definition. The service definition properties, such as the name, signaling type (LDP or BGP), service type (Ethernet, ATM, or TDM), are displayed. The interface-specific attributes, such as rate-limiting details, encapsulation, and VLAN tags, are also displayed in the dialog box. Close the dialog box to return to the service order modification wizard.

Based on the fields or parameters that you defined in the service definition to be enabled for modification in the service order, the corresponding fields are available for editing. The fields that are disabled for modification in the service order can only be edited in the service definition.

Configuring Service Parameters Information

IN THIS SECTION

- [Specifying General Settings | 1122](#)
- [Specifying PE-CE Settings Information | 1127](#)

In this topic you configure general settings, VPN settings that can be applied to all end points, and routing protocol settings for the provider edge (PE) and customer edge (CE) devices.

Specifying General Settings

You configure general information about the service order in the General Settings box of the Enter Order Information window.

If a service template is attached to the service definition, there is a link to that template at the bottom of the Endpoint Settings section of the window. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

You must add the customer to the database before proceeding. See [“Adding a New Customer” on page 795](#).

To enter general settings information:

1. In the **Name** field, type a unique name for the full mesh service.

The service order name can consist of only letters, numbers, and underscores.

NOTE: The name you specify for an IP service order becomes the routing-instance name in the device configuration when you deploy the service. Consequently, you cannot use any Juniper Networks keywords, for example, “bgp” or “ospf”, as the name of a service order.

2. In the **Customer** field, select the customer who is requesting the service.

3. In the **Comments** field, type a description of the service.

This description appears in information windows about the request or service instance created from the request.

To enter connectivity settings information:

1. Specify whether the **Autopick Route Target** can be selected automatically or manually.

- To assign the **Route Target** automatically, select the **Auto Pick Route target** check box.
- To assign the **Route Target**, clear the **Auto Pick Route Target** check box.

The window expands to include the **Route Target** field. In the **Route Target** field, type a value.

NOTE: For Hub-and-Spoke service order, clear the **Auto Pick Hub Route Target** and **Autopick Spoke Route Target** check boxes to activate the **Hub Route Target** and **Spoke Route Target** fields, respectively.

When you manually type a route target, Junos Space accepts either of the following two formats:

- *prefix-number:assigned-number*

Where *prefix-number* can be any numeric value from 1 through 65,535. The *assigned-number* can be any numeric value from 0 through 2,147,483,647.

- *IPV4-address:assigned-number*

Where *IPV4-address* can be any valid IPv4 address, and *assigned-number* can be any numeric value from 0 through 65,535.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

2. Specify whether the **Auto Pick Route Distinguisher** can be selected automatically or manually.

- To assign the **Route Distinguisher** automatically, select the **Auto Pick Route Distinguisher** check box.
- To assign the **Route Distinguisher** manually, clear the **Auto Pick Route Distinguisher** check box.

The window expands to include the **Route Distinguisher** field. In the **Route Distinguisher** field, type a value.

When you manually type route distinguishers, Junos Space accepts either of the following two formats:

- *prefix-number: assigned-number*

Where *prefix-number* can be any numeric value from 1 through 65,535. The *assigned-number* can be any numeric value from 0 through 2,147,483,647.

- *IPV4-address: assigned-number*

Where *IPV4-address* can be any valid IPv4 address, and *assigned-number* can be any numeric value from 0 through 65,535.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

3. Select the **Autopick Hub Route Target** and **Autopick Spoke Route Target** check boxes if you want the Route target chosen automatically by the Connectivity Services Director application.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

To manually assign a Route target:

1. Clear the **Autopick Hub Route Target** and **Autopick Spoke Route Target** check boxes to activate the **Hub Route Target** and **Spoke Route Target** fields respectively.
2. In the **Route Target** field, enter a value.

When you manually enter route target, Junos Space accepts either of the following two formats:

- *<prefix-number>: <assigned-number>*

Where *<prefix-number>* can be any numeric value from 1 to 65535, inclusive. The *<assigned-number>* can be any numeric value from 0 to 2,147,483,647, inclusive.

- *<IPV4-address>: <assigned-number>*

Where *<IPV4-address>* can be any valid IPV4 address (in W.X.Y.Z "dot" notation), and *<assigned-number>* can be any numeric value from 0 to 65535, inclusive.

4.

5. Select the **Autopick Hub Route Distinguisher** and the **Autopick Spoke Route Distinguisher** check boxes if you want the Route distinguisher chosen automatically by the Connectivity Services Director application.

To manually assign a Route distinguisher:

1. Clear the **Autopick Hub Route Distinguisher** and the **Autopick Spoke Route Distinguisher** check boxes to activate the **Hub Route distinguisher** and **Spoke Route distinguisher** fields respectively.
2. In the **Route distinguisher** field, enter a value.

When you manually enter route distinguishers, Junos Space accepts either of the following two formats:

- *<prefix-number>*: *<assigned-number>*

Where *<prefix-number>* can be any numeric value from 1 to 65535, inclusive. The *<assigned-number>* can be any numeric value from 0 to 2,147,483,647, inclusive.

- *<IPV4-address>*: *<assigned-number>*

Where *<IPV4-address>* can be any valid IPV4 address (in W.X.Y.Z "dot" notation), and *<assigned-number>* can be any numeric value from 0 to 65535, inclusive.

To enter VPN settings details:

1. To configure a separate label for each VRF to provide double lookup and egress filtering, select the **VRF Table label** check box.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

The **Export Direct Routes** check box is not editable in the service order.

2. Select the **Enable MVPN** check box to enable multicast virtual private network (MVPN).

To enter default UNI settings information:

1. Select a value for **Ethernet Option**:

- **Port**
- **Dot1Q**

Specifying the **Dot1Q** Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN list to the service order.

- **QinQ**

Specifying the **QinQ** Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN list to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).

2. Select or clear the **Autopick Interface IP** check box.

- To specify the **Interface IP address**, clear the **Autopick interface IP** check box.
- To specify the **IP Address Pool** and **IP Block Size** field values in the Site Settings page of the service order creation wizard, select the **Autopick interface IP** check box.

If you have selected the **Enable MC- LAG** check box in the Service Settings section, the maximum and minimum values for **IP block size** are 29 and 28, respectively.

NOTE: You cannot edit the **Autopick Interface IP** check box if you have not selected the **Editable in Service Order** check box in the service definition.

NOTE: The fields specified in the Default UNI Settings section are based on the **Ethernet Option** type. The Logical IF Settings box is not available if you have selected the **Ethernet Option** as *Port*.

3. Specify whether the **Autopick Interface Unit** can be selected automatically or manually.

- To assign the **Unit ID** automatically, select the **Autopick Interface Unit** check box.
- To assign the **Unit ID** manually, clear the **Autopick Interface Unit** check box.

The window expands to include the **Unit ID** field. In the **Unit ID** field, type a value.

Range: 1 through 1073741823

NOTE: You can edit this field only if you have selected the **Editable in Service Order** check box for the **VLAN ID selection** in the service definition.

4. Specify whether the **Autopick VLAN ID** can be selected automatically or manually.

- To assign the **VLAN ID** automatically, select the **Autopick VLAN ID** check box.
- To assign the **VLAN ID** manually, clear the **Autopick VLAN ID** check box.

The window expands to include the **VLAN ID** field. In the **VLAN ID** field, type a value.

NOTE: You cannot edit this field if you have not selected the **Editable in Service Order** check box in the service definition.

Specifying PE-CE Settings Information

You configure VPN attributes that are usually common for all the endpoints in the service. The values that you provide vary, depending on the service definition on which the service order is based.

If you do not expect these attributes to be the same on all endpoints, you can set them to be the same for now and then make changes later, or you can skip this step and apply the attribute values one at a time later.

In the **PE-CE Settings** section of the Service Parameters page, depending on the PE-CE routing protocol—OSPF/Static Route or BGP/Static Route—do one of the following:

- If **BGP/Static Route routing protocol** is specified in the service definition:
 - a. The **AS override** option is selected to allow a service provisioner to override the AS number. Clear the **AS override** check box to prevent a service provisioner from overriding the AS number.
 - b. Enter a value for the maximum number of prefixes accepted by a PE router from a CE router.
- If **OSPF/Static Route routing protocol** is specified in the service definition, in the **OSPF domain ID** field, enter a IP address.

You can enter from 1.0.0.1 to 223.255.255.254. excluding 127.x.x.x.

1. Click **Next**.

The **Node Parameters** page appears.

Selecting N-PE Devices or Nodes

In this topic you select the N-PE devices that you want to host the service endpoints. The selection is made from the **Select Endpoint PE Devices** window.

NOTE: The **Choose Endpoints** window, which you can view by clicking the **Add** icon on the Node Parameters page, shows only assigned N-PE devices that have an AS number configured. If you do not see the device you are looking for, use the CLI on the device to check for and assign an AS number.

N-PE devices that have L2VPN only do not appear.

To select endpoint N-PE devices:

1. In the **Node Parameters** page, click **Add** in the Service Nodes table. From the Choose Endpoints dialog box that appears, select the devices that you want to participate in the service. Use the multiple selection feature to select one or more devices.

NOTE: In the Choose Endpoints dialog box, you can sort and segregate the devices and their corresponding interfaces based on the roles of the devices to easily and quickly view only the devices of interest. Click the down arrow on the **Filter Role** menu, and select **P2E** to view only the provider edge devices, **P** to view only the provider devices, and **L2E** to view only Layer 2 Ethernet devices.

2. Click **OK**.

The **Node Parameters** window appears.

3. Continue with modifying or entering the node parameters.

Setting Attributes for Endpoints or Nodes

If a service template is attached to the service definition, there is a link to that template at the bottom of the Endpoint Settings section of the window. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

You set attributes for each endpoint in the service from the Endpoint Settings window.

The interface shown in the UNI Interface field is automatically selected by the Connectivity Services Director application, which chooses the UNI that has the highest available capacity among interfaces that are in the Up state. To calculate the available capacity of the interface, the system subtracts the bandwidth reserved for each service deployed on that interface from the total capacity of the interface.

For each endpoint, the Endpoint Settings window shows the value for each UNI attribute.

As a service provider, you can create static routes on the service. To specify static routes for a CE device on the Node Parameters page:

1. Click the **Add** icon above the Static Routes table. A new row is added to the table and highlighted in yellow to denote that you can enter the destination prefix and next-hop address.
2. In the Destination Prefix field, enter the endpoint for the static route.
3. In the Next-Hop field, enter the IP address of the next-hop. You can enter a dotted decimal notation, between 1.0.0.1 and 223.255.255.254 except 127.x.x.x.
4. Insert as many static routes as you require. To delete an existing route, select the check box beside the route, and click **Delete** above the listed routes.

The MVPN and PIM Settings sections are displayed only if you selected the **Enable MVPN** check box in the Service Parameters page of the creation of service order wizard. To specify PIM settings for the service order:

1. From the **PIM Mode** list, specify the mode of PIM. Only PIM sparse mode is currently supported.

NOTE: A Protocol Independent Multicast (PIM) sparse-mode domain uses reverse-path forwarding (RPF) to create a path from a data source to the receiver requesting the data. When a receiver issues an explicit join request, an RPF check is triggered. A (*,G) PIM join message is sent toward the RP from the receiver's designated router (DR). (By definition, this message is actually called a join/prune message, but for clarity in this description, it is called either join or prune, depending on its context.) The join message is multicast hop by hop upstream to the ALL-PIM-ROUTERS group (224.0.0.13) by means of each router's RPF interface until it reaches the RP. The RP router receives the (*,G) PIM join message and adds the interface on which it was received to the outgoing interface list (OIL) of the rendezvous-point tree (RPT) forwarding state entry. This builds the RPT connecting the receiver with the RP. The RPT remains in effect, even if no active sources generate traffic.

2. From the **Interface** list, select the interface to be used for PIM. When you modify a UNI from the list of interfaces on the Site Settings page, the GUI does not automatically delete the UNI from the Endpoint list. However, the newly added UNIs are added to the **Interface** list for the selected device or node.

To specify rendezvous point (RP) settings:

1. Click the **Add** icon above the table of RP addresses. The Add Rendezvous Point Address dialog box is displayed.
2. In the Rendezvous Point (device) field, configure the routing device as an actual or potential rendezvous point (RP). A routing device can be an RP for more than one group.
3. In the Interface field, specify the name of the interface on which PIM must be enabled. Specify the full interface name, including the physical and logical address components. UNIs for the selected device include lo0 if the selected device is enabled with loopback.
4. In the Group Address field, configure the address ranges of the multicast groups for which this routing device can be a rendezvous point (RP). By default, the routing device is eligible to be the RP for all IPv4 or IPv6 groups (224.0.0.0/4 or FF70::/12 to FFF0::/12).
5. Click **OK** to add the RP addresses to the table on the Node Parameters page.
6. To modify an added RP address, select the check box beside the row and click **Edit**. The dialog box is displayed to enable you modify the settings.
7. To delete an added RP address, select the check box beside the row and click **Delete**. The selected RP address is removed from the table.

To define MVPN settings for the service order:

1. From the **MVPN mode** list, indicate whether the shared-tree data distribution mode (**RPT-SPT**) or the shortest path tree only (**SPT-only**) mode of MVPN must be enabled to learn about active multicast sources using multicast VPN source-active routes. the default mode of operation is shortest path tree only (SPT-only) mode. In SPT-only mode, the active multicast sources are learned through multicast VPN source-active routes. This mode of operation is described in section 14 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt). If the default mode is not suitable for your environment, you can configure RPT-SPT mode (also known as shared-tree data distribution), as documented in section 13 of the BGP-MVPN draft (draft-ietf-l3vpn-2547bis-mcast-bgp-00.txt). RPT-SPT mode supports the native PIM model of transmitting (*,G) messages from the receiver to the RP for intersite shared-tree join messages. This means that the type 6 (*,G) routes get transmitted from one PE router to another. In RPT-SPT mode, the shared-tree multicast routes are advertised from an egress PE router to the upstream router connected to the VPN site with the C-RP
2. In the Provider Tunnel Name field, specify the provider tunnel name to configure virtual private LAN service (VPLS) flooding of unknown unicast, broadcast, and multicast traffic using point-to- multipoint LSPs. Also configure point-to-multipoint LSPs for MBGP MVPNs.
3. From the **Site Type** list, specify the site type of the MBGP MVPN. An MBGP MVPN defines two types of site sets, a sender site set and a receiver.
4. Select the **Upstream Multicast Hop** check box to configure the upstream multicast hop (UMH) to denote a router to use the unicast route preference to determine the single forwarder election.
5. In the **Import Unicast Target** field, specify the import targets specifically for sender sites or receiver sites, or can be borrowed from a configured unicast route target. Note that a sender site export route target is always advertised when security association routes are exported. By default, the VPN routing and forwarding (VRF) import and export route targets (configured either using VRF import and export policies or using the **vrf-target** statement) are used for importing and exporting routes with the MBGP MVPN network layer reachability information (NLRI). You can use the **export-target** and **import-target** options to override the default VRF import and export route targets. Select the **Sender** radio button to import unicast targets for sender sites, select the **Receiver** radio button to import unicast targets for receiver sites, or select **None** to disable the import of unicast targets.
6. In the **Import Target** field, specify the import targets for sender and receiver sites. Select the **Sender** radio button to import targets for sender sites, select the **Receiver** radio button to import targets for receiver sites.
7. Select the **Export Unicast Target** check box to specify the export target to enable you to override the Layer 3 VPN export route targets used for importing and exporting routes for the MBGP MVPN network layer reachability information (NLRI).

8. In the Target Community field, specify the target community value to be used when exporting sender and receiver site routes. You can specify this value manually if you deselect the **Autopick Export Target** check box.
9. Select the **Autopick Export Target** check box to specify that you want to enable automatic selection of an export target if a configuration is not provided. An imported automatic discovery route is treated as belonging to both the sender site set and the receiver site set.

If you have selected the **Enable MC- LAG** check box in the General Settings window, the **Is Stitching Point** check box is available for each endpoint. If you select this check box, all the parameters of that endpoint are disabled.

To configure or change the topology settings on the Node Parameters page:

1. The type of network circuit is displayed in the Topology field as full-mesh or hub-and-spoke.
2. Make sure the **Is Stitching Point** check box is not selected.
3. To add the loopback interface for an IP service, select the **Add Loopback** check box.

NOTE: If you provision a loopback interface for an IP service, an operator is able to identify a VRF routing instance. Thereafter, an operator can manually ping a remote CE router from a local PE router.

4. Select the **Is Hub** check box to enable the node to function as a hub. Deselect the check box if you want the device to function as a spoke. This field is not applicable for full-mesh IP services.
5. When you have finished configuring the endpoint settings, click **Next**.

The Site Settings page of the Create IP Service Order wizard appears.

Adding and Deleting UNI Interfaces

You can add or delete UNI interfaces on the PE devices that participate in a service:

To add a UNI interface on a selected device:

1. Select the **Add** icon in above the table of listed UNI interfaces, and from the **Choose Endpoints** window, select the device from which you want to retrieve the UNI interface to associate with the service order. The window refreshes to display all the UNI interfaces configured on the selected device.
2. Select the check boxes beside the UNIs that you want to associate.

3. Click **Add** to close the window. You are returned to the Site Settings page, and the selected UNIs are displayed in the table.
4. If the interface you selected in the previous step is already configured (duplicate) either type a different value in the VLAN ID field manually, or check the **Autopick VLAN ID** field.

To delete a UNI interface from a selected device:

- Select the check box adjacent to the interface you want to delete, and click the **Delete** icon above the list of displayed interfaces.

If the deleted UNI is the only UNI selected from the device, then the device is deleted from the service configuration.

You can set or modify attributes for a UNI endpoint.

To modify a UNI interface for a selected device:

1. Select the row for the UNI endpoint that you want to modify.
The **UNI Settings** dialog box appears.
2. Modify the **UNI Settings** fields.
3. Either apply the attributes you already specified or add values that you did not configure for different attributes of a UNI.
4. When you have finished modifying the endpoint settings, click **OK**.

The **Site Settings** page appears.

Setting Attributes for UNIs or Sites

If there is a service template attached to the service definition, there is a link to that template at the bottom of the Site Settings section of the screen. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

This part of the create Ethernet service order procedure sets the attributes for each UNI or interface in the service. Selection is made using the Site Settings screen.

The interface shown in the UNI Interface field is automatically selected by the Connectivity Services Director application, which chooses the UNI that has the highest available capacity among interfaces that are in the Up state. To calculate the available capacity of the interface, the system subtracts the bandwidth reserved for each service deployed on that interface from the total capacity of the interface.

For each endpoint, the Site Settings page shows the value for each UNI attribute.

To configure or change the site or UNI settings:

1. Select a value for **Encapsulation**.

- **Port**
- **Dot1Q**

Specifying the **Dot1Q** Ethernet option enables you to apply a Unit ID, a single VLAN ID, a VLAN Range, or a VLAN list to the service order.

- **QinQ**

Specifying the **QinQ** Ethernet option enables you to apply a single VLAN, a VLAN Range, or a VLAN list to the service order. For an IP service deployed on a dual tagged interface, the inner tag determines the VPN routing and forwarding instance(VRF).

- **Flexible UNI**

Specifying the **Flexible UNI** Ethernet option enables you to apply different values for the Unit ID and vlan-tags.

NOTE: Prior to release 13.1P6.1, Network Activate set the unit and vlan-id parameters to the same value.

To create a service order that specifies the Flexible UNI Ethernet option, you must complete two preliminary tasks. First you must create a service template in which you specify both outer and inner vlan tags. Then you must create a service definition that associates the service template with the service definition.

2. To select a different UNI on a device, click the **UNI interface** and choose another interface from the list.
3. In the **UNI Description**, you can enter the description for the selected **UNI interface**. The **Description** field is displayed in Modify Service Order, View Service Order Details, Modify Service, and View Service windows. You can edit this field while modifying a IP service order or service.

Range: 0 through 128 characters

4. Specifying the encapsulation settings for a particular UNI:

NOTE: The fields specified in the Encapsulation Settings box are based on the **Encapsulation** type. The Encapsulation Settings box is not available if you have selected the **Encapsulation** as *Port*.

- If you have selected the **Encapsulation** as *Dot1Q*, or, *QinQ*, or *Flexible UNI*, specify whether the **Autopick Interface Unit** can be selected automatically or manually.
 - To assign the **Unit ID** automatically, select the **Autopick Interface Unit** check box.
 - To assign the **Unit ID** manually, clear the **Autopick Interface Unit** check box.

The window expands to include the **Unit ID** field. In the **Unit ID** field, type a value.

Range: 1 through 1073741823

NOTE: The unit ID value that you have specified in the Enter Order Information page is displayed in the **Unit ID** field.

- If you have selected the **Encapsulation** as *Dot1Q*, or, *QinQ*, or *Flexible UNI*, specify whether the **Autopick VLAN ID** can be selected automatically or manually.
 - To assign the **VLAN ID** automatically, select the **Autopick VLAN ID** check box.
 - To assign the **VLAN ID** manually, clear the **Autopick VLAN ID** check box.

The window expands to include the **VLAN ID** field. In the **VLAN ID** field, type a value.

NOTE: The unit ID value that you have specified in the Enter Order Information page is displayed in the **UNIT ID** field.

- If you have selected the **Encapsulation** as *QinQ*, select the **Customer VLAN Type**.

If the **Customer VLAN type** is *Transport all traffic*, select the **Outer TP ID**.

If the **Customer VLAN type** is *Transport single vlan*, select the **Customer VLAN**, **Inner TP ID**, and **Outer TP ID**.

NOTE: You can optionally specify **Inner TP ID** and **Outer TP ID**.

5. In the IP section of the Site Settings page, clear the **Autopick Interface IP** check box to specify the **Interface IP address**.

Select the **Autopick Interface IP** check box to specify the **IP Address Pool** and **IP Block Size**.

NOTE: You cannot edit the **Autopick Interface IP** check box if you have not selected the **Editable in Service Order** check box in the service definition.

6. In the Routing Protocol section of the Site Settings page, select the **Protocol** type.

If the **Protocol** type is **BGP**, specify the following information:

- **Neighbor IP address**

NOTE: You need to clear the **Autopick neighbor IP** check box to specify the **Neighbor IP address**.

- **Peer AS**

If the **Protocol** type is **OSPF**, specify the following information:

- **OSPF area ID**--Specify any valid IPV4 address in W.X.Y.Z "dot" notation.

Range: 0.0.0.0 through 225.255.255.255

- **OSPF version**--Select the OSPF version from the list.

7. When you have finished configuring the endpoint settings, click **Review** to examine the defined settings. You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages pertain to the settings you want to modify. Click **Back** to return to the previous page of the wizard; else click **Cancel** to discard the changes.

Deploying the New Service

To deploy the service:

1. From the **Manage Deploy Services** window in Deploy mode of Service View of Connectivity Services Director, perform one of these actions:

- To deploy the service immediately, select **Deploy now** and then click **OK**.
- To deploy the service later, select **Schedule deployment**, select a date and time, and then click **OK**.
The time field specifies the time kept by the server, but in the time zone of the client.
- To validate the service, click **Validate**.

2. Navigate to the Deployment Configuration Changes window to view the status of the deploy job.

The service order is now complete.

RELATED DOCUMENTATION

[Stitching a Pseudowire to an IP Service](#) | 993

[Creating a Full Mesh IP Service Order | 995](#)

[Selecting a Published IP Service Definition for a Service Order | 1044](#)

Modifying a Full Mesh IP Service

IN THIS SECTION

- [Adding an Endpoint | 1138](#)
- [Adding a UNI Interface | 1139](#)
- [Deleting a UNI Interface and Deleting an Endpoint | 1141](#)

For a full mesh IP service, you can add a new device endpoint, add or delete a UNI, change routing protocol parameters, remove or add static routes, change IP addresses, swap between BGP and static routing protocols (if service definition specifies BGP and Static), swap between OSPF and static routing protocols (if service definition specifies OSPF and Static).

NOTE: You cannot change the interface of an existing UNI. To perform the equivalent of changing the interface on an existing UNI, add a new UNI with the desired interface, and then delete the old UNI.

After modifying a service, the configuration audit and functional audit information is cleared and the functional audit status is set to pending.

If there is a service template attached to the service definition, there is a link to that template at the bottom of the **Endpoint Settings** section of the window. For instructions on working with service templates in service orders, see [“Creating a Service Order Based on a Service Definition with a Template” on page 1049](#).

Modifying a service creates a new service order based on the attribute settings of the existing service.

NOTE: When you modify a service or a service order, the read-only fields in the different pages of the wizard for service or service order modification are grayed out to indicate that you cannot modify those attributes.

Adding an Endpoint

To add an endpoint to a multipoint-to-multipoint Ethernet service:

1. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service to which you want to add an endpoint.
3. Click the **Modify** icon at the top of the page that displays the previously created service orders.

The **Modify Service** page appears.

Current service settings appear in the main display area. The **General Information** box contains a unique name for the service order that will request the change.

4. In the **Order name** field, change the name of the modification service order, if desired.
5. Click the **Node Settings** button to view the endpoints or devices that are associated with the service.
6. In the **Service Nodes** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

7. Select the devices and the interfaces corresponding to the selected devices on which you want to add new endpoints, then click **OK**. You are returned to the Node Settings page of the Manage Service Orders wizard.

To filter and sort the display of objects, enter the name of the object as a match criterion in the Search box and click the Search icon. The page refreshes to display only the object names that match with the search term. You can use the paging controls to navigate across multiple pages of objects as necessary.

The service modification window shows the added devices with system recommended choices for UNI.

8. Select the devices on which you want to add new endpoints, and then click **Next**.

The service modification window shows the added devices with system recommended choices for UNI. To select a different UNI, see [“Adding a UNI Interface” on page 1139](#).

9. Click **Finish** to save the modified service order. You are returned to the Manage Service Orders page.

10. In Deploy mode of the Service View of Connectivity Services Director, select one of the following:

- Deploy now to deploy modified service immediately when you click, OK
- Schedule deployment to specify a date and time to deploy the modified service later. The default time is the current date and time when you select the option.

11. Click **OK**.

The service modification deployment job ID is assigned.

12. Click the Job ID.

You see the service modification deployment job details in the **System > Manage Jobs > Job Management** page. The **Job Management** page presents the job information by job ID, Name, Percent complete, State, Job Type, Summary, Scheduled Start, Username, and Recurrence. The State column indicates whether the modified service deployment is successful.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Adding a UNI Interface

To add a UNI on a device that is already part of a multipoint-to-multipoint Ethernet service:

1. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service to which you want to add a UNI.
3. Click the **Modify** icon at the top of the page that displays the previously created service orders.

Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.

4. In the service **Order name** field, change the name of the modification service order, if desired.
5. Click the **Site/Endpoint Settings** button to view the interfaces on endpoints or devices that are associated with the service.
6. In the **User-to-Network Interfaces** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

7. Select the devices on which you want to add new interfaces. The window refreshes to display all the user-to-network (UNI) or ingress interfaces for the selected device in the lower part of the window as a tabular grid. Select the interfaces that you want to assign to the service order, and then click **OK**.

To filter and sort the display of objects, enter the name of the object as a match criterion in the Search box and click the Search icon. The page refreshes to display only the object names that match with the search term. You can use the paging controls to navigate across multiple pages of objects as necessary.

Based on the devices you select in the top half of the dialog box, the interfaces that are present in the selected device are displayed in the lower half of the dialog box. Select the check boxes next to the interfaces that you want to associate with the service.

You are returned to the Node Settings page of the Manage Service Orders wizard.

8. The **Interface IP** field displays the interface IP address.
9. The **Autopick VLAN ID** check box is selected by default to allow Network Activate to select a VLAN ID. If you deselect the **Autopick VLAN ID** check box, you must either enter a different value in the service **VLAN ID** field manually.
10. Select a routing protocol from the drop-down list box.
11. Click **Modify**.

12. Click **Modify**.

You can now deploy the modified service.

13. In the **Deployment Options** dialog box, select one of the following:

- Save only and Validate to save the service modification and validate it.
- Deploy now to deploy modified service immediately when you click, OK
- Schedule deployment to specify a date and time to deploy the modified service later. The default time is the current date and time when you select the option.

14. Click **OK**.

The service modification deployment Job ID link appears.

15. Click the Job ID.

You see the service modification deployment job details in the **System > Manage Jobs > Job Management** page. The **Job Management** page presents the job information by job ID, Name, Percent complete, State, Job Type, Summary, Scheduled Start, Username, and Recurrence. The State column indicates whether the modified service deployment is successful.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

Deleting a UNI Interface and Deleting an Endpoint

To delete a UNI from a multipoint-to-multipoint Ethernet service:

1. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Services**.
2. In the **Manage Services** page, select the service from which you want to delete a UNI.
3. Click the **Modify** icon at the top of the page that displays the previously created service orders.
Current service settings appear in the main display area. The **General Settings** box contains a unique name for the service order that will request the change.
4. In the service **Order name** field, change the name of the modification service order, if desired.
5. Click the **Site/Endpoint Settings** button to view the interfaces on endpoints or devices that are associated with the service.
6. In the **User-to-Network Interfaces** table, click **Add**.

The **Choose Endpoints** window shows available N-PE devices that are not part of the service.

7. Select the devices on which you want to add new interfaces. The window refreshes to display all the user-to-network (UNI) or ingress interfaces for the selected device in the lower part of the window as a tabular grid. Select the interfaces that you want to assign to the service order, and then click **OK**.

To filter and sort the display of objects, enter the name of the object as a match criterion in the Search box and click the Search icon. The page refreshes to display only the object names that match with the search term. You can use the paging controls to navigate across multiple pages of objects as necessary.

Based on the devices you select in the top half of the dialog box, the interfaces that are present in the selected device are displayed in the lower half of the dialog box. Select the check boxes next to the interfaces that you want to associate with the service.

You are returned to the Node Settings page of the Manage Service Orders wizard.

The service modification window shows the added devices with system recommended choices for UNI.

8. Click **Finish** to complete the modification of the service order and save the settings.
9. In Deploy mode of the Service View of the Connectivity Services Director, select one of the following from the Manage Services page:
 - Schedule the change for immediate deployment.
 - Schedule the change for later deployment.
10. You see the service modification deployment job details in the **System > Jobs > Job Management** page. The **Job Management** page presents the job information by job ID, Name, Percent Complete, State, Job Type, Summary, Scheduled Start, Username, and Recurrence. The State column indicates whether the modified service deployment is successful.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

RELATED DOCUMENTATION

[Modifying a Multipoint-to-Multipoint Ethernet Service | 1104](#)

[Modifying a Point-to-Multipoint Ethernet Service | 1111](#)

[Modifying a Hub-and-Spoke IP Service Order | 1120](#)

Understanding Service Validation

You can use a functional audit and a configuration audit to monitor the health of a service for any of the following reasons:

- You have just deployed a service and want to verify that it works before your customer starts to use it.
- You want to perform periodic verification that a service is functioning correctly.
- A customer has reported that a service is not functioning correctly and you need to find out what the problem is and fix it.

The following sections provide instructions for functional audit and configuration audit:

- [Performing a Functional Audit on page 1145](#)

- [Performing a Configuration Audit on page 1156](#)

RELATED DOCUMENTATION

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

Highlighting of Endpoints in the IP, RSVP LSP, and E-LAN Service Modification Wizards

In the Edit E-LAN Service and Edit IP Service wizards that you use to modify the corresponding service types, the Node Settings and Site Settings pages that display the endpoints and interfaces associated with a service are enhanced to provide an easily-identifiable color-coding format for quickly understanding the changes made to these pages of the wizards. A new row that you add to these pages is displayed in blue. An existing row that is deleted from these pages is displayed in red. An existing row that you update on these pages is shaded in gray. Similarly, the Node Parameters page of the Edit RSVP LSP Service wizard uses this color-coding format to denote added, modified, and deleted nodes.

For the modified and deleted endpoints or nodes that are highlighted in gray and red, respectively, you can select the check boxes beside such rows and click **Revert** to cancel the changes and deletions made to these nodes. You can click Revert only for the modified and deleted nodes, which restores the nodes in the states in which they were present in the service before you changed or deleted them.

12

PART

Auditing Services and Viewing Audit Results

[Service Provisioning: Auditing Services](#) | **1145**

[Troubleshooting Devices and Services](#) | **1192**

Service Provisioning: Auditing Services

IN THIS CHAPTER

- Performing a Functional Audit | 1145
- Performing a Configuration Audit | 1156
- Troubleshooting N-PE Devices Before Provisioning a Service | 1158
- Modifying the Application Settings of Connectivity Services Director | 1161
- Troubleshooting the Endpoints of Services | 1168
- Basic Requirements of Operational Scripts | 1174
- Viewing Configuration Audit Results | 1177
- Viewing Functional Audit Results | 1180
- Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184
- Modifying a Saved Service Order | 1184
- Viewing Service-Level Alarms | 1189

Performing a Functional Audit

A functional audit determines whether a deployed service instance is functioning. It checks the control plane to ensure connectivity among endpoints and that the UNIs are functioning correctly. It also checks the data plane to verify packet transmission between each valid pair of endpoints in the service.

The functional audit provides both a CLI verification and a troubleshooting feature that allows you to check the status of interfaces, LDP sessions, neighbor links, and endpoints of E-Line services. The **Functional Audit Results** window displays information about the service statistics for the link you are monitoring. When you click **Troubleshoot** button in the Functional Audit Results window, the **Troubleshooting** page displays status of the interfaces, LDP sessions, neighbor links, and endpoints.

Performing the Functional Audit

To perform a functional audit:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. In the **Network Services > Connectivity** task pane, select **Audit Results > Functional Audit**. Alternatively, you can select a service order, click the **Audit** button at the top of the table of listed service orders from the Manage Network Services page and select **Run Functional Audit**.
5. In the **Schedule Functional Audit** dialog box, do one of the following:
 - a. Select **Audit Now**, then click **OK**.

The **Job Details** dialog box appears for you to click the Job ID link to see the functional results. The **Job Management** page displays the functional audit details by job ID, name, percentage complete, state, job type, summary, scheduled start time, user, and recurrence.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

- b. Select **Audit Later**, enter a date and time, then click **OK**.

To monitor the progress of an audit after selecting **Audit Later**, after the scheduled time of the audit:

- a. On the Junos Space Network Management Platform user interface, select **Jobs**.
 - b. On the **Jobs** statistics page, select the **Functional Audit** segment of the Job Types pie chart.

The **Job Management** page appears filtered by functional audit jobs.
 - c. Select the functional audit job that you want.

Summary information about the audit appears in the quick look panel.

- d. In the filter bar, select the table view icon to see additional information about the job. If the service failed the audit, information about the failure appears in the **Summary** field.

NOTE: Functional audit can be run for multiple services from Build mode of Service View of the Connectivity Services Director GUI. From the Manage Network Services page, select the check boxes beside multiple services, and click the **Audit/Results** button at the top of the table of configured services. When the **Audit/Results** button is clicked, the Schedule Functional Audit window is displayed, which enables you to perform the audit immediately or schedule it to be run at a later time. You can view detailed, ingrained information about the output of the functional audit that you performed for a service from the Functional Audit Results window. Select the **Service-name > Interface-name Device-name > Remote Interface - Remote Device** in the left pane of the window. The control plane and data plane statuses are displayed by running service-specific commands in the right pane of the window. Click **Rerun Functional Audit** at the top-right corner of the window to perform the audit again. If the Status field displays as Completed, an audit can be run again; else, if the Status field displays as Ongoing, it denotes that an audit is currently in progress, you must wait for the running instance to be completed to perform a functional evaluation again.

Click **Reload Result** at the top-right corner of the window to refresh the results of the audit and display the updated information. You can refresh the results only for completed audit instances. When you select Service-name in the left pane of the window, service status information is displayed in the right pane. The Service Status window displays details such as the operational status of the service, the device name, the topology used in the service are displayed in a tabular format. The number of UNI interfaces and PE devices that are up and down is also shown. When you select **Service-name > Interface-name Device-name > Remote Interface - Remote Device** in the left pane of the window, endpoint status information is shown in the right pane. The Endpoint Status window displays details of the device name, the topology used in service, remote UNIs status, and device status of the selected service.

The Service Status field corresponding to the service for which polled data is not available is displayed as NA. The Service Status field represents the overall status of a service. To calculate the overall service status, a polling mechanism is used to retrieve data from devices by Connectivity Services Director. Because the overall status of a service involves multiple devices, it is possible to calculate and update service statuses, based on an event from one of the devices because the status of all endpoints of a service needs to be determined to compute the overall service status. It is an expensive operation to send requests to all endpoints, based on an event from a single device. As a result, a polling method is used to obtain the overall status of the device. Because the polled data represents a snapshot at a point in time, a delay occurs in updating the status of a service. Also, while polling, if service information from one of the devices is not available, the service is marked as down.

6. To view additional details about the functional audit, including results from checking the control plane and the data plane, see [“Viewing Functional Audit Results” on page 1180](#).

CLI Verification

The CLI verification feature of a functional audit works by running commands that perform verification and reporting relevant information.

The following table shows the commands that are used for each service type.

Service Type/ Device Type	XML Commands		CLI Commands	
	Control Plane	Data Plane	Control Plane	Data Plane
ELINE Martini/ M Series and MX Series	<pre><get-l2ckt-connection-information> <neighbor>neighborIP</neighbor> <interface>interfaceName </interface> </get-l2-ckt-connection-information></pre>	<pre><request-ping-l2circuit-virtual-circuit> <neighbor>neighborIP</neighbor> <virtual-circuit-id>VCID</virtual-circuit-id> </request-ping-l2circuit-virtual-circuit></pre>	<pre>show l2circuit connections neighbor neighborIP interface interfaceName show ppp interface mlppp group1 members</pre>	<pre>ping mpls l2circuit virtual-circuit VCID neighbor neighborIP</pre>
	Where: <i>neighborIP</i> = Address of remote neighbor VC ID = Virtual Circuit ID <i>interfaceName</i> = Name of interface			
BX Series	Not supported.	<pre><get-l2circuit-information> <l2circuit-name> name<l2circuit-name> <brief/> </get-l2circuit-information></pre>	Not supported.	<pre>show l2circuit nam brief</pre>
	Where: Name = name of the l2 circuit ID			

Service Type/ Device Type	XML Commands		CLI Commands	
	Control Plane	Data Plane	Control Plane	Data Plane
VPLS/ M Series	<pre><get-vpls-connection-information> <instance> routing_instance_name </instance> <local-site> local-siteID </local-site> <remote-site> remote-siteID </remote-site> </get-vpls-connection-information></pre>	<pre><request-ping-vpls-instance> <instance-name> routing_instance_name </instance-name> <destination-mac> destMacValue </destination-mac> <source-ip> sourceIp </source-ip> <learning-vlan-id> learning-vlan-id </learning-vlan-id> </request-ping-vpls-instance></pre>	<pre>show vpls connections instance routing_instance_name local-site local-siteID remote-site remote-siteID</pre>	<pre>ping vpls instance routing_instance_name destination-mac destMacValue source-ip sourceIpValue learning-vlan-id learningVlanID</pre>
	<p>Where:</p> <p><i>routing_instance_name</i> = Routing instance name</p> <p><i>destMacValue</i> = Destination MAC address</p> <p><i>sourceIp</i> = Source IP address</p> <p><i>local-SiteID</i> = Name or ID of VPLS local site</p> <p><i>remote-SiteID</i> = ID of VPLS remote site</p> <p><i>learning-vlan-id</i> = Learning VLAN identifier</p>			
L3VPN/ Junos	<pre><get-route-information> <table> bgp.l3vpn.0</table> <rd-prefix>destinationRDprefix</rd-prefix> </get-route-information></pre>	<pre><ping><routing-instance> routingInstanceValue </routing-instance> <count>5 </count></pre>	<pre>show route table bgp.l3vpn.0 rd-prefix destinationRDprefix</pre>	<pre>ping routing-instance routingInstanceValue count</pre>
	<p>Where:</p> <p><i>routingInstanceValue</i> = Routing instance name</p> <p><i>destinationRDprefix</i> = Route Distinguisher: remote UNI IP address</p> <p><i>destinationUniInterfaceIP</i> = Destination UNI IP address</p>			

For the data plane, the Junos Space software places a static MAC address in the forwarding table of the remote endpoint, which it uses to verify correct packet transfer.

NOTE: Data plane validation of an E-LAN service works for MX Series devices running Junos Release 9.4 or later. If the service under audit contains an M Series device or an N-PE device running Junos Release 9.2 or 9.3, the functional audit does not complete successfully and generates a message stating that functional audit is not supported on that platform.

The following table shows the commands for E-LAN service type:

Service Type	Device Family	XML Commands	CLI Commands	Category
--------------	---------------	--------------	--------------	----------

VPLS	M Series	<get-vpls-connection-information> <instance> <i>instanceValue</i> </instance> </get-vpls-connection-information>	show vpls connection instance <i>instanceValue</i>	Route
		<get-mpls-lsp-information> <ingress/> </get-mpls-lsp-information>	show mpls lsp ingress	MPLS
		<get-mpls-lsp-information> <egress/> </get-mpls-lsp-information>	show mpls lsp egress	MPLS
		<get-mpls-static-lsp-information> <ingress/> </get-mpls-static-lsp-information>	show mpls static-lsp ingress	MPLS
		<get-rsvp-session-information> </get-rsvp-session-information>	show rsvp session	Route
		<get-route-information> <table>inet.3</table> </get-route-information>	show route table inet.3	Route
		<get-interface-information> <terse/><interface-name> <i>interfaceValue</i> </interface-name> </get-interface-information>	show interface <i>interfaceValue</i> terse	UNI
		<get-interface-information> <statistics/> <interface-name> <i>interfaceValue</i> </interface-name> </get-interface-information>	show interface <i>interfaceValue</i> statistics	UNI
		<get-route-information> <table> <i>instanceValue</i> </table> <protocol> <i>bgp</i> </protocol> </get-route-information>	show route protocol bgp table <i>instanceValue</i> .l2vpn.0	Route
		Where: <i>instanceValue</i> = Name of the service <i>neighborIP</i> = Address of the remote neighbor <i>interfaceValue</i> = Name of the interface		

The following table shows the commands for IP service type:

Service Type	Device Family	XML Commands	CLI Commands	Category
--------------	---------------	--------------	--------------	----------

L3VPN	M Series	<get-mpls-lsp-information> <ingress/> </get-mpls-lsp-information>	show mpls lsp ingress	MPLS
		<get-mpls-lsp-information> <egress/> </get-mpls-lsp-information>	show mpls lsp egress	MPLS
		<get-interface-information> <terse/> <interface-name>instancevalue</interface-name> </get-interface-information>	show interfaces instancevalue.initvalue terse	Route
		<get-forwarding-table-information> <vpn>instance </vpn> </get-forwarding-table-information>	show route forwarding-table vpn instance	Route
		<get-rsvp-session-information> </get-rsvp-session-information>	show rsvp session	Route
		<get-interface-information> <statistics/> <interface-name>instance</interface-name> </get-interface-information>	show interfaces instance statistics	UNI
		<get-mpls-static-lsp-information> <ingress/> </get-mpls-static-lsp-information>	show mpls static-lsp	MPLS
		<get-ospf-neighbor-information> </get-ospf-neighbor-information>	show ospf neighbor	Route
		<get-route-information> <table>bgp.l3vpn.0 </table> <rd-prefix>destinationRDprefix</rd-prefix> </get-route-information>	show route table bgp.l3vpn.0	Route
		<get-lacp-interface-information> <interface-name> lagInterface </interface-name> </get-lacp-interface-information>	show lacp interfaces	UNI
		<get-mc-ae-interface-information> </get-mc-ae-interface-information>	show interfaces mc-ae	UNI

	<pre><get-vrrp-interface-information> <interface-name> Interface </interface-name> </get-vrrp-interface-information></pre>	Show vrrp <i>interfaceName</i>	UNI
	<pre><get-bridge-instance-information> <bridge-domain-name> domainName </bridge-domain-name> </get-bridge-instance-information></pre>	Show bridge domain <i>domainName</i>	UNI
	<p>Where:</p> <p><i>instanceValue</i>= Name of the service</p> <p><i>neighborIP</i>= Address of the remote neighbor</p> <p><i>interfaceValue</i>= Name of the interface</p>		

RELATED DOCUMENTATION

[Performing a Configuration Audit | 1156](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Troubleshooting the Endpoints of Services | 1168](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Performing a Configuration Audit

A configuration audit can help you determine whether the service configuration on the device has been changed out of band. To this end, you can compare the results of a configuration audit with the service configuration in the Junos Space database. The following example shows a sample comparison.

To perform a configuration audit:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. In the **Network Services > Connectivity** task pane, select **Audit Results > Configuration Audit**, and from the Configuration Audit page that is launched, click the **Run Configuration Audit** button. Alternatively, you can select a service order, and click the **Audit** button at the top of the table of listed services from the Manage Network Services page and select **Run Configuration Audit**.
5. In the **Schedule Configuration Audit** window, either:
 - Select **Audit Now**, then click **OK**.
An informational dialog appears, stating that the configuration audit job is successfully triggered with the job ID, and an **OK** button.
 - Select **Audit Later**, enter a date and time, then click **OK**.
6. To monitor the progress of an audit after selecting **Audit Now**, click the Job ID in the **Audit Information** window. The **Job Management** page shows information about the configuration audit job.

NOTE: Alternatively, to display the Job Management page, click the **System** icon on the Connectivity Services Director banner, and select **Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

The **State** field indicates whether the service passed or failed the audit. If the service failed the audit, then the **Summary** field provides information about the failure.

To monitor the progress of an audit after selecting **Audit Later**, after the scheduled time of the audit:

- a. On the Junos Space Network Management Platform user interface, select **Jobs**.
 - b. In the **Job Types** chart, select the **Configuration Audit** segment of the pie chart.
 - c. Select the configuration audit of interest from the list on the **Job Management** page.
Summary information about the audit appears in the quick look panel.
 - d. In the filter bar, select the table view icon to see additional information about the job. If the service failed the audit, information about the failure appears in the **Summary** field.
7. In the **Audit Information** window, click the job ID of the configuration audit.

The **Job Management** window appears and shows a filtered view of the job inventory, showing only the configuration audit job.

NOTE: If a resynchronization between a device and the Junos Space database is ongoing when the configuration audit job starts, the configuration audit job suspends until the resynchronization job finishes. If the resynchronization job fails to complete, the audit could be suspended indefinitely. To allow the audit to proceed, go to the **Job Management** workspace and cancel the resynchronization job, as described in *Canceling a Job*.

8. In the **Status** column, check the status of the audit to determine whether it succeeded or failed.

Check the **Summary** column, which contains useful service information such as the VC ID and endpoint information. For some failed deployments, this column also contains information about why the deployment failed.

NOTE: When a configuration audit is performed, the XPATH attributes that are present in the service configuration are used. Only the addition, modification, or deletion of the XPATH attributes is detected, and the creation of a new attribute (child XPATH) on a device is not determined. The audit operation disregards such attributes and does not identify them. This behavior is expected and occurs because Junos Space Platform software audits only the settings present in a user template. If the template has a container, Junos Space Platform only audits to determine whether the device is configured with this container. If a user wants to audit any container child, the user needs to add it into the template. This scenario is similar to an out-of-band configuration change on the device, which Junos Space Platform can determine only if the system of record (SOR) mode is set for the Junos Space Network Management Platform application.

RELATED DOCUMENTATION

[Performing a Functional Audit | 1145](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Troubleshooting the Endpoints of Services | 1168](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Troubleshooting N-PE Devices Before Provisioning a Service

You can use the **Troubleshoot** option to check PE router configurations before you deploy a new service or troubleshoot PE router configurations if you are unable to deploy a new service.

To check the configuration on a PE router, follow these steps:

1. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Manage Device Roles**

The **Manage Device Roles** page appears displaying all devices on the network that are assigned the N-PE role

2. Select the device that you want to troubleshoot.

3. In the **Actions** menu, select **Troubleshoot**.

The **Troubleshoot Device** window appears. The table here describes the show commands that you can run to check the configuration on a N-PE device.

Table 136: Commands Available in the Troubleshoot Device Window

Command	Description	Fields Displayed
show mpls lsp ingress	Display whether ingress LSP is up and running.	<ul style="list-style-type: none"> • Device name • LSP State • Destination Address
show mpls lsp egress	Display whether egress LSP is up and running.	<ul style="list-style-type: none"> • Device name • LSP State • Destination Address

Table 136: Commands Available in the Troubleshoot Device Window (*continued*)

show bgp summary	Display summary information about BGP and its neighbors to determine if routes are received from peers in the autonomous system (AS). When a BGP session is established, the peers exchange update messages.	<ul style="list-style-type: none"> • Peer Address • Peer State
show ospf neighbor	Display information about OSPF neighbors.	<ul style="list-style-type: none"> • Interface Name • Neighbor Address • OSPF Neighbor State
show bgp neighbor	Display information about all BGP peers.	<ul style="list-style-type: none"> • Peer Address • Peer State • Local AS
show ldp interface	Display standard status information about all LDP-enabled interfaces for all routing instances.	<ul style="list-style-type: none"> • Interface Name • LDP Neighbor Count
show ldp neighbor	Display standard information about LDP neighbors for all routing instances.	<ul style="list-style-type: none"> • Interface Name • Neighbor Address • Remaining Time—remaining hold time before the neighbor expires, in seconds.
show rsvp session	Display information about Resource Reservation Protocol (RSVP) sessions.	<ul style="list-style-type: none"> • Name • LSP State • Destination Address <p>For complete information about the fields displayed for the show rsvp session command, see the <i>Junos Software Routing Protocols and Policies Command Reference</i>.</p>
show rsvp interface	Display the status of Resource Reservation Protocol (RSVP)-enabled interfaces and packet statistics.	<ul style="list-style-type: none"> • Interface Name • RSVP Status • Static Bandwidth • Available Bandwidth • Total Reserved Bandwidth

Table 136: Commands Available in the Troubleshoot Device Window *(continued)*

show isis adjacency	Display information about intermediate System-to-Intermediate System (*IS-IS) neighbors.	<ul style="list-style-type: none">• Interface Name• Adjacency State• System Name <p>For complete information about the fields displayed for the show isis adjacency command, see the <i>Junos Software Routing Protocols and Policies Command Reference</i>.</p>
---------------------	--	--

4. Select on any show command to view device-specific configuration information.


NOTE: For additional information about a PE device configuration, you can explicitly run a show command with the extensive option, for example, **show mpls lsp extensive**.

RELATED DOCUMENTATION

Performing a Functional Audit 1145
Performing a Configuration Audit 1156
Modifying the Application Settings of Connectivity Services Director 1161
Troubleshooting the Endpoints of Services 1168
Viewing Configuration Audit Results 1177
Viewing Functional Audit Results 1180
Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service 1184

Modifying the Application Settings of Connectivity Services Director

To modify the configuration settings of services activation-related capabilities of Connectivity Services Director, perform the following steps:

1. To open the Preferences page, click  in the Connectivity Services Director banner and select **Preferences** from the list.

The Preferences page appears, with **User Preferences** as the default tab.

2. Click the **Services Activation** tab.
3. Click any parameter, or specify a different value for parameters that accept values, to modify it.

NOTE: You cannot modify the application settings if another user is currently modifying them.

4. Click **OK** to save the changes that you made in the **Connectivity Services Director** application or click **Cancel** to retain the original settings.

Also, you can modify the configuration settings for the Connectivity Services Director application using the Junos Space Platform GUI.

To modify the configuration settings of Connectivity Services Director using the Junos Space Platform GUI, perform the following steps:

1. From the **Network Management Platform** task pane, select **Administration** > **Applications**.

The **Applications** page that appears displays a list of the applications in the Network Management platform.

2. Right-click **Network Activate** and select **Modify Applications Settings**.

The **Modify Application Settings** page that appears displays a list of the parameters that can be modified.

3. Click any parameter to modify it.

NOTE: You cannot modify the application settings if another user is currently modifying them.

4. Click **Modify** to save the changes that you made in the **Connectivity Services Director** application or click **Cancel** to retain the original settings.

To understand the parameters of the Connectivity Services Director application settings, refer to [Table 15 on page 127](#).

Table 137: Parameters in Connectivity Services Director Application Settings

Fields	Description
Deployment	
Check service version	Select this check box to validate the version of the service being configured.
Deploy configuration to the device	Select this check box to deploy the configuration to the device.
Enable service alarms	Select this check box to enable the service alarms. Enabling the service alarms causes a GUI impact on the Connectivity Services Director application. When you select the check box and deploy the service, the interface goes down, resulting in the failure to update the fault status. When you right-click Service and select View Service Alarms , the latter does not appear in the results.
Save configuration in XML format	Select this check box to save the configuration of the device in XML format.
Show configuration in set format	Select this check box to display the configuration in set format.
Use two-phase commit for service provisioning	Select this check box to push the configuration on all the network elements automatically, making either one or all successful.
Use vlan maps for E-Line services	<p>When this check box is selected, normalization of VLAN tags is performed using the input or output VLAN maps.</p> <p>This check box is selected by default.</p> <p>NOTE: Starting in Connectivity Services Director Release 2.1R1, Use vlan maps for flexible tagged services under Modifying the Application Settings of Connectivity Services Director is renamed to Use vlan maps for E-Line services.</p>

Table 137: Parameters in Connectivity Services Director Application Settings (*continued*)

Fields	Description
Use vlan maps for flexible tagged services instead of normalized vlan (VPLS)	<p>When this check box is cleared, normalization of VLAN tags is performed using normalized tags under routing instance.</p> <p>This check box is cleared by default.</p> <p>NOTE: Starting in Connectivity Services Director Release 2.1R1, normalization of VLAN tags is performed using normalized tags under routing instance while modifying the application settings.</p>
Audit	
Enable Functional Audit after deployment	Select this check box to perform the functional audit automatically, after the service is deployed successfully. By default, the functional audit is not checked. Extra time is taken to complete both the functional audit and deployment.
Functional Audit Waiting Time after deployment	<p>Specify the initial wait time to auto-schedule a functional audit job after deployment.</p> <p>If the entered value is greater than 30 minutes, it is reset to 30 minutes. If the entered value is less than 1 minute, the wait time is ignored.</p> <p>The range is from 1 minute through 30 minutes.</p>
Perform Functional Audit on Control plane only	Select this check box to make the functional audit ignore the data plane verification and to consider only the control plane.
User Interface	
Allow template modification for service	Select this check box to allow the templates to be changed during the service modification.
Bandwidth Combo Items Count	<p>Specify the bandwidth combo items count.</p> <p>In Create IP service order page, if the bandwidth range exceeds the bandwidth combo items count, then the bandwidth input is taken in text field.</p> <p>The default value is 100.</p>
Service Detail Wait Time (sec)	Specify the period of time in seconds as the wait period for retrieving service details during service template modification.
Monitoring	
Perform Monitoring on Failed Functional Audit	Select this check box to perform monitoring if the functional audit fails.

Table 137: Parameters in Connectivity Services Director Application Settings (*continued*)

Fields	Description
Pseudowire Redundancy Transition TimeDelay	<p>Select this check box to dump the configuration files.</p> <p>Specify the time delay to issue the remote procedure call (RPC) call for redundancy service. Since there is no support for the fault management for redundancy service, it should not update the fault status as down, when the interface goes down as the service will be running with the help of backup device. The RPC is issued to check the status of the service. If the value of this time delay is 2 seconds and the interface goes down, it waits for 2 seconds to check whether the service is up, with the help of the backup device and correspondingly updates the fault status.</p> <p>The default value is 2 seconds.</p>
Statistics Aggregation Reporting	<p>Specify the manner in which the aggregated results are returned for a query that polls and retrieves data from devices. Two aggregation values are supported:</p> <ul style="list-style-type: none"> • Total: Sum of the number of packets received in the interval • Average: Average of the total number of packets received in the interval
Logging	
Dump Configuration Files	By default, the configuration files are not dumped into the log directory. This is enabled, if there is a need to provide troubleshooting to Juniper Networks Technical Assistance Center (JTAC).
Dump Deployment Data	Select this check box to write the configlets and error response from the JUNOS devices into the log directory..
Log Directory	Specify the default path of the log directory: <code>/var/tmp/jboss</code>
Prestage Devices	
Pre-stage Wait Time (Sec)	Specify the number of seconds for which the task to trigger a job for prestaging devices must wait after receiving the first notification for prestaging devices. For example, if you specify the prestage wait time as 20 seconds, the prestaging task waits for a period of 20 seconds, after receiving the first notification for prestaging devices, and then initiates the prestaging-devices job.
Pre-stage Idle Time (Sec)	Specify the number of seconds after which the job for prestaging devices is initiated, if no notification is received during the idle period. For example, if you specify the prestage idle time as 10 seconds and if no notification for prestaging devices is received within this period, the job for prestaging devices is triggered immediately after 10 seconds. The prestage idle time value takes precedence over the prestage wait time value.

Table 137: Parameters in Connectivity Services Director Application Settings (*continued*)

Fields	Description
Loopback Unit	Specify the logical unit of the loopback interface that must be used as the default loopback logical interface for all provisioning tasks that are initiated from Connectivity Services Director. The default logical unit for the loopback interface is 0.
Route Target	
BeginIndex	<p>Specify the least value in the preferred range of numbers, among which a certain number is assigned for each BGP service. Route target allows you to distribute VPN routes to only the routers that need them. When a route target value is entered manually, it should be either of the following two formats: Autonomous System number format or IPv4 format. For Autonomous System number format, the pattern is as-number:2-byte-number. For example, target:100:200.</p> <p>Range: The Autonomous System number format number can be in the range from 1 through 65,535.</p> <p>The IPv4 format is ip-address:2-byte-number. For example, target:10.1.1.1:2.</p>
EndIndex	<p>Specify the greatest value in the preferred range of numbers, among which a certain number is assigned for each BGP service. Route target allows you to distribute VPN routes to only the routers that need them. When a route target value is entered manually, it should be either of the following two formats: Autonomous System number format or IPv4 format. For Autonomous System number format, the pattern is as-number:2-byte-number. For example, target:100:200.</p> <p>Range: The Autonomous System number format number can be in the range from 1 through 65,535.</p> <p>The IPv4 format is ip-address:2-byte-number. For example, target:10.1.1.1:2. The EndIndex value should be lesser than the maximum assigned value.</p>
Virtual Circuit ID	
BeginIndex	<p>Specify the least value in the preferred range of numbers, among which a certain number is assigned as the VirtualCircuitID to the new circuit created. This VCID can be manually chosen by the customer or auto-generated by the system. For example, if BeginIndex = 100 and EndIndex = 200, then the VCID would be somewhere between 100 and 200.</p> <p>Minimum: 1</p> <p>The value of BeginIndex should be less than or equal to EndIndex value.</p> <p>The range is from 0 through 200000.</p>

Table 137: Parameters in Connectivity Services Director Application Settings (*continued*)

Fields	Description
EndIndex	<p>Specify the greatest value in the preferred range of numbers, among which a certain number is assigned as the VirtualCircuitID to the new circuit created. This VCID can be manually chosen by the customer or auto-generated by the system. For example, if BeginIndex = 100 and EndIndex = 200, then the VCID would be somewhere between 100 and 200.</p> <p>Maximum: 2147483647.</p> <p>The range is from 0 through 200000.</p>
Performance Monitoring	
DataSetSize	<p>DataSetSize is the size of the performance monitoring data set in days. This field indicates the number of days of performance monitoring data could be stored for display.</p> <p>The default value is 2880.</p>
Enable Performance Monitoring through scripts	Select the check box to collect the performance data through scripts and opennms will store the data in its database. If this check box is not selected, then performance data such as one-way delay, two-way delay, and frame loss are collected through RPC and stored in the application database.
OSS Config Parameters	
Alcatel Primary Server IP	Specify the IP address of the primary server.
Alcatel Primary Server Port	Specify the port number of the primary server.
Backup Server IP	Specify the IP address of the backup server.
Backup Server Port	Specify the port number of the backup server.
HTTP Connection Timeout	Specify the duration of HTTP connection before the time-out elapses.
Maximum API Requests	Specify the maximum number of simultaneous API requests permitted.
OSS Log Directory	Specify the directory path of the OSS log directory.
OSS Log Filename	Specify the OSS log filename.
OSS User Name	Specify the user name for accessing the OSS server.

Table 137: Parameters in Connectivity Services Director Application Settings (*continued*)

Fields	Description
OSS User Password	Specify the hashed password for accessing the OSS server.
Synchronize OSS Inventory daily at given time	Sets the daily time at which the CPP system synchronizes third-party devices, added or deleted from the CPP system, with the OSS server.
Use primary server	If the check box is enabled, the CPP system communicates with the primary OSS server.
Service Decommission	
Service Recovery	
OutofBand Notification	<p>Select either of the following options from the OutofBand Notification Action list to specify the action you want to be performed when an OutOfBand notification is received by Connectivity Services Director:</p> <ul style="list-style-type: none"> • Make Device OutOfSync—Causes the device to be made OutOfSync and disables subsequent provisioning on that device until it changes to the In Sync state again • Ignore Notification—Causes the notification to be ignored and device will remain InSync
Store OutofBand Notification XML	Select the check box to enable the storage of OutOfBand notification XML in the Connectivity Services Director database. By default, this check box is not selected, which disables the saving of OutofBand notification XML in the Connectivity Services Director database.
Device Sync Wait Time	<p>Specify the device synchronization waiting time. This is the maximum wait time to complete the device synchronization. After this time duration, irrespective of the device synchronization status, the resources are released.</p> <p>The default value is 60 seconds.</p> <p>The range is from 30 seconds through 300 seconds.</p>
Reports (accessible from the Modify Connectivity Services Director Settings page in the Administration workspace of the Junos Space Platform GUI)	
Retention period for generated Reports days	Move the slider right or left to specify the time period for which the generated reports must be retained in the Connectivity Services Director database. By default, Connectivity Services Director keeps reports for 30 days. However, Network Administrators can change the retention period from 0 to 365 days.

Table 137: Parameters in Connectivity Services Director Application Settings (*continued*)

Fields	Description
Search (accessible from the Modify Connectivity Services Director Settings page in the Administration workspace of the Junos Space Platform GUI)	
Index auto update interval in seconds	Specify a time interval after which Connectivity Services Director initiates the next indexing on the Search tab. By default this option is selected and the search index update interval is set to 900 seconds. Connectivity Services Director indexes the device inventory data periodically to enable users to perform efficient searches.
Pause indexing during device import	Select this check box to stop indexing while devices are imported into Connectivity Services Director. If you are running short of system memory, selecting this option can help save some memory and speed up the discovery and import of new devices.
Topology (accessible from the Modify Connectivity Services Director Settings page in the Administration workspace of the Junos Space Platform GUI)	
Retention period for Deleted Link days	Move the slider right or left to specify a retention period for the deleted links in Topology. You can also disable the retention of deleted links by moving the slider to the extreme left to denote Never. You can define a maximum of 365 days for deleted links to be maintained in Topology View.

Release History Table

Release	Description
2.1R1	Starting in Connectivity Services Director Release 2.1R1, Use vlan maps for flexible tagged services under Modifying the Application Settings of Connectivity Services Director is renamed to Use vlan maps for E-Line services .
2.1R1	Starting in Connectivity Services Director Release 2.1R1, normalization of VLAN tags is performed using normalized tags under routing instance while modifying the application settings.

Troubleshooting the Endpoints of Services

IN THIS SECTION

- [Troubleshooting Services Using Operational Scripts | 1171](#)

Junos OS operation (op) scripts automate network and device management and troubleshooting. Op scripts can perform any function available through the remote procedure calls (RPCs) supported by either the Junos XML management protocol or the Junos Extensible Markup Language (XML) API. Op scripts can be executed manually in the CLI or upon user login, or they can be called from another script. They are executed by the Junos OS management (mgd) process.

Op scripts enable you to do the following things:

- Create custom operational mode commands
- Execute a series of operational mode commands
- Customize the output of operational mode commands
- Shorten troubleshooting time by gathering operational information and iteratively narrowing down the cause of a network problem
- Perform controlled configuration changes
- Monitor the overall status of a device by creating a general operation script that periodically checks network warning parameters, such as high CPU usage.

Op scripts are based on the Junos XML management protocol, and the Junos XML API. Op scripts can be written in either the Extensible Stylesheet Language Transformations (XSLT) or Stylesheet Language Alternative Syntax (SLAX) scripting language. Op scripts use XPath to locate the operational objects to be inspected and XSLT constructs to specify the actions to perform on the located operational objects. The actions can change the output or execute additional commands based on the output.

The troubleshooting feature provides an easy and unique way to troubleshoot the services. You do not have to manually login to a device to check the status of services in the Connectivity Services Director application, but you can do the same using the functionality of operational scripts. You do have the flexibility of writing your own scripts to view the results.

Only Juniper Networks devices are supported by this functionality and this is not applicable to the third-party devices.

The operational scripts can either be created or imported to the platform from the local machine before you start troubleshooting the services or you can run the scripts that are of local type directly from the Functional Audit Result window by clicking the **Troubleshoot** button. For op scripts that are not of local type, the op scripts must be imported and staged on to the device using the Junos Space Network Management Platform application before you can run the scripts from within the Connectivity Services Director application for debugging and diagnosing the service endpoints or devices. Currently, you cannot directly add the scripts to the Connectivity Services Director GUI interface. Scripts with execution type as "Local" (@isLocal=true annotation in the SLAX script) are also listed in troubleshooting window. The listing is sorted and filtered based on the context specified for each service.

BEST PRACTICE: We recommend that you configure a script as a local script for effective and optimal debugging and analysis of the configuration settings contained in the script. The main advantage of a local script is that you need not download the script to a device (because a connection is established with the device by the GUI application and the script is run) and you need not remove the script from a device after you decommission a service.

The following table lists the context in which the OP scripts are written for different types of services:

Table 138: OP Scripts Contexts for Different Service Types

Service Type	Context
E-Line LDP	<p>@CONTEXT = "/device/configuration/protocols/l2circuit/neighbor/interface"</p> <p>Example :</p> <p>/device[name="deviceName"]/configuration/protocols/l2circuit/neighbor[name="neighbor IP"]/interface[name="interfaceName.unitID"]</p>
IP	<p>/*@CONTEXT = "/device/configuration/routing-instances/instance/vrf/interface" */</p> <p>Example : /device[name="device name"]/configuration/routing-instances/instance[name="Service name"]/instance-type[instance-type="vrf"]/interface[name="interfaceName.unitID"]</p>
E-LAN	<p>/* @CONTEXT = "/device/configuration/routing-instances/instance/vpls/interface" */</p> <p>Example : /device[name="device name"]/configuration/routing-instances/instance[name="Service name"]/instance-type[instance-type="vpls"]/interface[name="interfaceName.unitID"]</p>
E-Line (Local switching)	<p>/* @CONTEXT =</p> <p>"/device/configuration/protocols/l2circuit/local-switching/interface/end-interface" */</p> <p>Example</p> <p>/device[name="MS01"]/configuration/protocols/l2circuit/local-switching/interface[name="ge1/0/01801"]/end-interface[name="ge1/2/21801"]</p>
E-Line BGP	<p>/* @CONTEXT = "/device/configuration/routing-instances/instance/bgp/interface" */</p> <p>Example : /device[name="device name"]/configuration/routing-instances/instance[name="Service name"]/instance-type[instance-type="bgp"]/interface[name="interfaceName.unitID"]</p>

Table 138: OP Scripts Contexts for Different Service Types (continued)

Service Type	Context
Common context for all services	/* @CONTEXT = "/device/configuration/interface/" */ Example: /device[name="device name"]/configuration/ interface[name="interfaceName.unitID"] Example commands:

When you select a single service and from the Network Services > Connectivity task pane, select **Audit Results > Functional Audit** to schedule and perform a functional audit operation, the Functional Audit Results window is displayed after the operation of the selected service is validated. If you have previously run a functional audit already run, the result of the previous audit is displayed. To perform a troubleshooting of the selected service, you must click the **Troubleshoot** button. The troubleshooting task runs as a separate event in Connectivity Services Director.

Troubleshooting Services Using Operational Scripts

The operational scripts or the OP scripts are written to view the statistics of a service in the Connectivity Services Director application. All the commands in the OP scripts are user-defined. To view the contexts for writing OP scripts for different service types, refer [Table 138 on page 1170](#).

To execute the OP scripts and view the status of any service:

1. From the **Network Management Platform** task pane, select **Images and Scripts > Scripts**.

The **Scripts** page that appears displays a list of the existing scripts.

2. From the list of the scripts available in the SLAX format, right-click a script and click **Stage Scripts on Devices** to push the script onto a device.

The **Stage Scripts on Device(s)** page that appears displays a list of the devices associated with the script that you selected.

3. Select the **Select Device Manually** option and select any number of devices to which you want to push the script.

NOTE: The **Enable Scripts on Devices** check box is selected by default.

4. Click **Stage** to stage the script on all the devices that you selected.

The **Stage Scripts Information** dialog box confirms the successful staging of scripts onto the selected devices along with the **Job ID**.

5. Click **Job ID** to view the status of the job on the **Job Management** page.

You are redirected to the **Scripts** page.

6. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
7. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
8. In the Network Services > Connectivity view pane, select **Audit Results > Functional Audit**. Alternatively, you can select a service order, click the **Audit** button at the top of the table of listed service orders from the Manage Network Services page and select **Run Functional Audit**.
9. In the Schedule Functional Audit dialog box, select **Audit Now**, then click **OK**. After the audit is run, the Functional Audit Results window is displayed.
10. From the Functional Audit Results window that displays a list of the devices associated with the service you selected, select the check box next to the device for which you want to diagnose and examine the associated service.
11. Click **Troubleshoot** to perform troubleshooting and analysis of the service for which functional audit is performed.
12. Select the check box next to a service that you want to analyze and monitor for its working and efficiency. The Execute OP Scripts page is displayed.
13. Select an OP script on the **Execute OP Scripts** page.
14. Click the **Value** column to enter any additional parameter for the selected OP script, besides the ones coded in the script.

NOTE: The selection of parameters is entirely dependent on the OP scripts. If the OP scripts support parameters, then all the parameters are listed and you need to enter the values. Parameters can be optional, on the basis of the OP scripts.

15. Click **Execute** to execute the selected OP scripts with the newly added parameters, if any.

A dialog box confirms the execution of the OP scripts along with the **Job ID**.

16. Click **OK**.

You are redirected to the **Execute OP Scripts** page.

17. Click **View Last Result** to view the previous OP scripts execution results.

The **Execute OP Scripts Job Status** dialog box is displayed with the results of the troubleshooting operation.

NOTE: This is an optional step.

Troubleshooting E-Line Services

From the **Execute OP Scripts Job Status** dialog box, you can check status of the interfaces, LDP sessions, neighbor links, and endpoints of an E-Line service. To select the status you want to check, click on the device from the device list on the left, and select the show command from the **Command** list. This figure shows the routing table for the selected device in the E-Line service.

Troubleshooting E-LAN Services

From the **Execute OP Scripts Job Status** dialog box, you can check status of the interfaces, LDP sessions, neighbor links, connection instances, and endpoints of an E-LAN service. To select the status you want to check, click on the device from the device list on the left, and select the show command from the **Command** list.

Troubleshooting IP Services

From the **Execute OP Scripts Job Status** dialog box, you can check status of the interfaces, LDP sessions, neighbor links, and endpoints of an IP service. To select the status you want to check, click on the device from the device list on the left, and select the show command from the **Command** list.

RELATED DOCUMENTATION

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Basic Requirements of Operational Scripts

For operational (op) scripts, the context is a required argument because a context is transmitted to the script, when the script is run from troubleshooting operation. The format of the argument to be pushed to the script is as follows:

```
var $arguments = {
  <argument> {
    <name> "CONTEXT";
    <description> "The CONTEXT.";
  }
}
var $CONTEXT;
```

The context has parameters based on the service type, which needs to be parsed to use the parameters.

The following is an example of an E-Line LDP service context:

Context: /device[name="deviceName"]/configuration/protocols/l2circuit/neighbor[name="neighbor IP"]/interface[name="interfaceName.unitID"]

The code in op script to parse the context is as follows:

```
var $tempContext = str:replace(str:replace($CONTEXT, "/device[name=\"", ""),
"\"]/configuration/protocols/l2circuit/neighbor[name=\"", "|");
var $finalContext = str:replace(str:replace($tempContext, "\"]/interface[name=\"",
"|"), "\"\]", "");
var $variables = jcs:split( "\\|", $finalContext );
var $deviceName = $variables[1];
var $neighborIp = $variables[2];
var $interfaceName = $variables[3];
```

The following is an example of an E-Line BGP service context:

Context: /device[name="device name"]/configuration/routing-instances/instance[name="Service name" and instance-type="l2vpn"]/bgp/interface[name="interfaceName.unitID"]

The code in op script to parse the context is as follows:

```

var $tempContext1 = str:replace(str:replace($CONTEXT, "/device[name=\"", ""),
"\"]/configuration/routing-instances/instance[name=\"", "|");
var $tempContext2 = str:replace($tempContext1, "\" and instance-type=\"l2vpn\"",
"");
var $finalContext = str:replace(str:replace($tempContext2, "/bgp/interface[name=\"",
"|"), "\"]", "");
var $variables = jcs:split( "\\|", $finalContext );
var $deviceName = $variables[1];
var $instanceName = $variables[2];
var $interfaceName = $variables[3];

```

The following is an example of an E-Line E-LAN service context:

Context: /device[name="device name"]/configuration/routing-instances/instance[name="Service name" and instance-type="vpls"]/vpls/interface[name="interfaceName.unitID"]

The code in op script to parse the context is as follows:

```

var $tempContext1 = str:replace(str:replace($CONTEXT, "/device[name=\"", ""),
"\"]/configuration/routing-instances/instance[name=\"", "|");
var $tempContext2 = str:replace($tempContext1, "\" and instance-type=\"vpls\"",
"");
var $finalContext = str:replace(str:replace($tempContext2, "/vpls/interface[name=\"",
"|"), "\"]", "");
var $variables = jcs:split( "\\|", $finalContext );
var $deviceName = $variables[1];
var $instanceName = $variables[2];
var $interfaceName = $variables[3];

```

The following is an example of an E-Line IP service context:

Context: /device[name="device name"]/configuration/routing-instances/instance[name="Service name" and instance-type="vrf"]/vrf/interface[name="interfaceName.unitID"]

The code in op script to parse the context:

```

var $tempContext1 = str:replace(str:replace($CONTEXT, "/device[name=\"", ""),
"\"]/configuration/routing-instances/instance[name=\"", "|");
var $tempContext2 = str:replace($tempContext1, "\" and instance-type=\"vrf\"",
"");

var $finalContext = str:replace(str:replace($tempContext2, "/vrf/interface[name=\"",
"|"), "\"]", "");
var $variables = jcs:split( "\\|", $finalContext );

```



```
var $deviceName = $variables[1];
var $instanceName = $variables[2];
var $interfaceName = $variables[3];
```

Predefined Scripts for Troubleshooting

Predefined troubleshooting scripts are included by default, during the installation of Connectivity Services Director. The following are the script names for each service and the commands supported for them.

E-Line LDP Service

P2PLDPPredefinedScript.slax is the predefined script that is uploaded.

The following are the supported commands:

- get-l2ckt-connection-information
- get-interface-information
- get-ldp-session-information
- get-ldp-neighbor-information

E-Line BGP Service

P2PBGPPredefinedScript.slax is the predefined script that is uploaded.

The following are the supported commands:

- get-l2vpn-connection-information
- get-interface-information
- get-bgp-summary-information
- get-interface-statistics

E-LAN Service

VPLSPredefinedScript.slax is the predefined script that is uploaded.

The following are the supported commands:

- get-vpls-connection-information
- get-interface-information
- get-interface-statistics

IP Service

L3VPNPredefinedScript.slax is the predefined script that is uploaded.

The following are the supported commands:

- get-vrrp-connection-information
- get-interface-information
- get-interface-statistics

RSVP LSP Service

RSVPLSPPredefinedScript.slax is the predefined script that is uploaded.

The following are the supported commands:

- get-mpls-connection-information
- get-mpls-lsp-information

RELATED DOCUMENTATION

| [Troubleshooting the Endpoints of Services](#) | **1168**

Viewing Configuration Audit Results

After performing a configuration audit, check the detailed results of the audit:

1. a. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
- b. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
- c. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP Ethernet service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
- d. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Audit/Results > Configuration Audit**.

The configuration audit results are displayed if an audit operation was previously performed on the selected service.

Examine the audit results for missing configuration information, and keep the window open for later comparison with the service configuration in the Junos Space database.

You can validate policies for the hub and spoke (1 interface).

NOTE: In the Service Configuration tab of the Configuration Audit dialog box, you can observe several lines with the **delete** statement in the service settings. These **delete** statements indicate the policy attributes that are deleted from the corresponding service on a device. Whenever a service is created or modified, the policy options are always deleted from the device to prevent the previously existing policies from interfering with the service. The presence of the **delete** statements is an expected behavior and does not indicate any incorrect service configuration.

2. To view the service configuration in the Junos Space database, in Deploy mode, from the **Network Services > Connectivity** task pane, select **Service Provisioning > Deploy Services**. The Manage Service Deployment page is displayed on the bottom part of the right pane. Select a service from the **Manage Service Deployment** page, then in the **Actions** menu, select **View Service Configuration**.

A new window opens and shows the service configuration.

If a CFM is configured in E-Line service or E-LAN service, the configuration audit result displays the CFM configuration details.

3. Compare the contents of the Service Configuration with those of the **Configuration Audit Results** window for each device in turn. If you see discrepancies, then it is likely that the service configuration

was modified out-of-band. If so, you might need to synchronize the device with the Junos Space database.

For step-by-step instructions about synchronizing devices, see *Resynchronizing Managed Devices with the Network* for details.

After the audit job is completed, you can view the output of the operation in the Configuration Audit Results window that is displayed on the right pane. The left pane displays a tree of devices associated with the specified service. You can select a **Service-name > Interface-name Device-name** in the left pane of the window. The attribute definitions and parameters defined in the service are displayed in the right pane. The right pane contains three tabs— Service Configuration, Template Configuration, and Audit Results. The Service Configuration tab displays the settings specified for the service on the device in CLI format. This tab displays the elements or components specified for a service template in the form of configuration stanzas and hierarchy levels. This display is similar to the **show** command that you can use at a certain **[edit]** hierarchy level to view the defined settings. The Template Configuration tab displays the service attributes and options defined in the service template, if any, that is associated with the service. The Audit Results tab displays the status of the audit job that was run, such as whether the job succeeded or failed. You can also view the service definition and associated template details under the Service Config and Template Config tabs in Junos OS XML API format, instead of the CLI format.

Click the **Show XML Config** button at the top-right corner of the window to view the audit results in XML API format. Alternatively, click the **Show Set** button to view the audit results in the manner in which they are displayed in the Junos OS CLI interface. The **Show XML/Set** button is a toggle button.

The Junos OS command-line interface (CLI) and the Junos OS infrastructure communicate using XML. When you issue an operational mode command in the CLI, the CLI converts the command into XML format for processing. After processing, Junos OS returns the output in the form of an XML document, which the CLI converts back into a readable format for display. Remote client applications also use XML-based data encoding for operational and configuration requests on devices running Junos OS. The Junos XML API is an XML representation of Junos configuration statements and operational mode commands. It defines an XML equivalent for all statements in the Junos configuration hierarchy and many of the commands that you issue in CLI operational mode. Each operational mode command with a Junos XML counterpart maps to a request tag element and, if necessary, a response tag element.

Click **Reload Result** at the top-right corner of the window to refresh and display the results of the audit. When you click this button, only the output of the audit operation is displayed afresh and the audit job is not run again. You can refresh the results only for completed audit instances. When you select **Service-name** in the left pane of the window, service status information is displayed in the right pane. Click **Run Configuration Audit** after selecting the services you need to run the audit job again.

Configuration audit can be run for multiple services from Build mode of Service View of the Connectivity Services Director GUI. From the Manage Network Services page, select the check boxes beside multiple services, click the **Audit** button at the top of the table of configured services, and select **Run Configuration Audit** from the drop-down menu.

We recommend that you configure a script as a local script for effective and optimal debugging and analysis of the configuration settings contained in the script. The main advantage of a local script is that you need not download the script to a device (because a connection is established with the device by the GUI application and the script is run) and you need not remove the script from a device after you decommission a service.

RELATED DOCUMENTATION

[Viewing Functional Audit Results | 1180](#)

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

Viewing Functional Audit Results

To view the results of a functional audit of a service, follow this procedure:

After performing a functional audit on a service (see [“Performing a Functional Audit” on page 1145](#)), look at the functional audit results:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Audit/Results > Functional Audit**.

The **Functional Audit Result** window appears, displaying Service Status in the right panel.

If a CFM is configured in an E-Line service or E-LAN service, the functional audit results includes the result of both E-Line and E-LAN services.

A green up-arrow in the Service Status header bar indicates that the service has passed the functional audit in both the control plane and the data plane. A red down-arrow indicates that the service failed either or both the control plane validation and the data plane validation.





Depending on the type of service, the left panel lists

- The name of the service
- Each endpoint in the service

Icons representing the endpoint indicate its role in the service and its up or down state.

[Table 139 on page 1181](#) describes these icons for a point-to-multipoint service.



Table 139: Point-to-Multipoint Service Endpoint Icons

Icon	Meaning
	Hub in a point-to-multipoint service. Endpoint state is up.
	Hub in a point-to-multipoint service. Endpoint state is down.
	Spoke in a point-to-multipoint service. Endpoint state is up.
	Spoke in a point-to-multipoint service. Endpoint state is down.

- Interface name
 - A numeric value indicating the subinterface name: the VLAN-ID for an 802.1Q interface, the service VLAN-ID for a Q-in-Q interface, or 0 for a dedicated port.
 - Device name
5. To show all endpoints in the service, in the left panel header, select **All**. To display only the endpoints indicating failed validation, select **Failed**. Failed is dimmed if the functional audit returned no validation errors.
 6. To view details for an individual interface or endpoint, select it in the left panel. The header bar on the right panel changes to End Point or Interface Status, and details for the selected item are displayed below.
 7. Expand each device to show the link from that device to the other N-PE device in the service.

An icon next to each link indicates whether the functional audit commands reported correct functioning of the control plane and data plane. [Table 140 on page 1181](#) describes these icons.

Table 140: Functional Audit Success Status Icons

Icon	Meaning
	Control plane and data plane function correctly.
	Errors were reported in the functioning of either the control plane or the data plane.







8. In the left panel, select a link.

The panel to the right shows the validation results for the control plane validation and data plane validation for the selected link. Icons indicate the success or failure of each set of tests.

The panel to the right shows the validation results for the control plane validation and data plane validation for the selected link. Icons indicate the success or failure of each of these sets of tests.

[Table 141 on page 1182](#) describes icons and the textual information provided in the box beside the icon.

Table 141: Multipoint-to-Multipoint Service Control Plane and Data Plane Validation Icons



Icon	Meaning	Explanation
	Control plane up	The text box shows the name of the remote N-PE device and confirms that the data plane is operational.
	Control plane down	The text box shows the name of the configured remote N-PE device and, in the Command status field, explains why the test failed.
	Control plane status unknown	The text box indicates the name of the configured remote N-PE device and, in the Result field, an explanation as to why the functional audit operation was unable to test the control plane—for example, configuration was missing on the device.
	Data plane up	The text box indicates the number of packets transmitted and received, and confirms that no data packets were lost during the audit.
	Data plane down	The text box indicates that data packets were lost during the audit.
	Data plane status unknown	The functional audit was unable to complete the data plane test. The Result field in the text box indicates the reason—for example, the platform does not support data plane testing, or the connection to the remote N-PE device is down.

The control plane and data plane validation checks must both show operational status for the link to be considered operational.

9. To troubleshoot a service, click the **Troubleshoot** button. To select the status you want to check, click the device from the device list on the left, and select the show command from the **Command** list.

An icon next to each command indicates whether the command execution is successful or failed. [Table 142 on page 1183](#) describes these icons.

Table 142: Command Status Icons

Icon	Meaning
	Command execution is successful and the command status is up.
	<ul style="list-style-type: none">• Command execution is failed, or,• In case of multiple rows, one of the status value is down

NOTE:

- Data plane information between two endpoints in an E-LAN service is provided only for MX Series devices. This information is not provided for M Series devices.
- Junos OS Release 9.3 and Junos OS Release 9.4 do not support data plane validation. The Functional Audit Results screens do not display data plane validation information if any device in the service is running one of these Junos OS releases.

RELATED DOCUMENTATION

[Viewing Configuration Audit Results | 1177](#)

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service

To view functional audit results for an Inverse Multiplexing for ATM Service:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Services**.
4. In the **Manage Services** screen, select the service for which you want to view the functional audit results.
5. Right-click the service, or click the **Audit/Results** menu, and select **View Functional Audit Results**.
6. In the **Functional Audit Results** window, click the **Troubleshoot** button.

In the **Troubleshooting** tab, when you select a **show interfaces** command for a UNI interface that is configured as an IMA Group Link, the command displays details for the IMA group interface.

RELATED DOCUMENTATION

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

Modifying a Saved Service Order


Before a service order can affect a service, it must transition through the following states:

- **Requested**—When the service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment, the service order is in the Requested state.
- **Scheduled**—After the service provisioner has scheduled the service order for deployment, the service order transitions to the Scheduled state.

- **In Progress**—When a scheduled service order reaches its time for deployment, it transitions to the transitory In Progress state. From this state, the Junos Space software attempts to deploy the service.
- **Validated**—When all the information in the service order is successfully validated, the service order transitions to the Validated state.
- **Completed**—Successful deployment transitions the service order to the Completed state.
- **Invalid**—If the Junos Space software cannot deploy the service because of invalid information in the service order itself, the service order enters the Invalid state. The service provisioner must resolve the issues that cause the failure before re-creating the service order and rescheduling it for deployment.
- **Failed Deploy**—If the device is down or the Junos Space software is unable to push the service configuration to the device, the service order transitions to the Failed Deploy state.
- **Deactivated**—When you disable a service order, the configuration attributes associated with such a service order are deactivated and commented out in the device settings. By disabling a service, the traffic processing for the traversed packets is impacted. In certain network topologies, you might require a service-related settings to be disabled for a certain period to perform troubleshooting or modification to the traffic-handling method, and you might want to reactivate a disabled service later when you have completed network maintenance and analysis work. In such a case, it might be beneficial to use the deactivation functionality for a service order. The deactivated service is propagated to the devices associated with the service order. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deployed or Re-Activated state.
- **Reactivated**—After you disable a service order to deactivate the configuration settings on devices mapped to the service, you might require the service settings to be reenabled after you have modified the service parameters, either directly on the device or using the Connectivity Services Director application. In such a case, you can use the reactivation functionality to revive and activate the service properties on devices. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deactivated state.

[Figure 24 on page 1186](#) illustrates the service order states.

Figure 24: Service Order States



To view the state of a service order, in Deploy mode, select **Network Services > Connectivity** from the View pane and drill down to the type of service for which you want to modify a service order, and select **Service Provisioning > Deploy Services** from the task pane. The Manage Service Deployment inventory page lists the service orders and their state.

The Junos Space Connectivity Services Director application provides the flexibility to modify an existing service order. You can modify a service order when the order state is Requested, Validated, or Invalid. You cannot modify a service order when the order state is Scheduled, Completed, or Failed Deploy.

To modify a service order:

1. In Deploy mode, select **Network Services > Connectivity** from the View pane and drill down to the type of service for which you want to modify a service order, and select **Service Provisioning > Deploy Services** from the task pane.
2. From the Manage Service Deployment page, select an existing service order, and then click **Modify**.

The Modify Service Order window appears.

NOTE: The modify option is unavailable if the service order is in Scheduled, or Completed, or Failed Deployed state.

3. Modify the fields as needed.

NOTE: When you modify a service or a service order, the read-only fields in the different pages of the wizard for service or service order modification are grayed out to indicate that you cannot modify those attributes.

The following table lists the fields that you can modify in an E-Line service order, E-LAN service order, and IP service order.

E-Line Service Order	E-LAN Service Order	LIP Service Order
Name	Name	Name
Customer	Customer	Customer
Comments	Comments	Comments
VLAN ID	VLAN ID	VLAN ID
VCID	Inner VLAN ID	Route Target
CFM	VLAN Tag to stack	Hub Route Target
PE device	PE device	Spoke Route Target
UNI interface	UNI interface	UNI Interface
UNI description	UNI description	Route Distinguisher
MTU (Bytes)	MTU	Hub Route Distinguisher
Bandwidth	Bandwidth	Spoke Route Distinguisher
RSVP LSP name	Enable P2P-Spoke	Autopick Interface IP Address
PW backup settings	Ethernet Option in case of Asymmetric	VRF Table label
VPI	Neighbor Hub	Export Direct Routes
VCI	Backup NeighborHub	AS override
Outgoing label	Hub	Hub
-	Customer VLAN Range Start	Maximum prefixes

E-Line Service Order	E-LAN Service Order	LIP Service Order
-	Customer VLAN Range End	IP address pool NOTE: While modifying an IP service order, you must select the IP address pool.
-	MAC learning	Peer AS
-	Interface MAC limit	-
-	MAC statistics	-
-	MAC table size	-
-	Disable tunnel services	-
-	Disable local switching	-
-	Fast reroute priority	-
-	Label block size	-
-	Connectivity type	-

NOTE: You can also change a local switching service order to a normal E-Line service order.

4. Click **Save**.

The service order is modified. You can now deploy the service order with modified parameters to the device.

RELATED DOCUMENTATION

[Creating an E-Line ATM or TDM Pseudowire Service Order | 877](#)

[Creating an E-Line Service Order | 895](#)

[Creating a Multipoint-to-Multipoint E-LAN Service Order | 943](#)

[Creating a Point-to-Multipoint E-LAN Service Order | 964](#)

Viewing Service-Level Alarms

The Junos Space Network Application Platform has integrated a third party tool, OpenNMS, to provide network monitoring capabilities. The OpenNMS network management application platform provides solutions for enterprises and carriers. OpenNMS is installed as part of Platform, which exposes some of OpenNMS' functionality through the Network Monitoring workspace. The default performance management configuration of OpenNMS for Space supports generic counters, CPU, memory, temperature, and Mobility counters. For information on this default configuration, see the subset of the OpenNMS documentation included in this Junos Space Network Application Platform User Guide.



CAUTION: Although additional OpenNMS functionality can be accessed by customizing its XML files, editing these files can affect the functionality of the Network Monitoring workspace. Juniper Networks does not support changes to OpenNMS.

When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director. Connectivity Services Director correlates traps, describing a condition, into an alarm. SNMP also plays another role in Connectivity Services Director. Enabling devices for SNMP with the appropriate read-only V1/V2/V3 credentials, can speed up device discovery.

To access the alarms page for a particular service:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
3. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **IP Services** tree to select an IP service.
 - Expand the **E-Line Services** tree to select an E-Line service.
 - Expand the **E-LAN Services** tree to select an E-LAN service.
4. From the task pane, select **Service Provisioning > Deploy Services**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.

5. From the Manage Network Services page, select the check box next to the service for which you want to view alarms.

TIP: In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

The top pane displays information about the services that have been previously created, such as the name of the service, the functional audit status, the performance management status, and the status of the service. You can modify the properties of the service, conduct a functional or configuration audit, force-deploy or deactivate the service, and view alarms associated with a particular service order for debugging and corrective action. Services can be in one of the following service states:

- Completed—The service order has been successfully deployed.
 - Scheduled for deployment—The service provisioner has scheduled the service order for deployment.
 - Deployment Failed—An attempted service deployment was not successfully completed or failed an audit.
 - In Progress—The Connectivity Services Director application is in the process of deploying the service.
 - Requested—The service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
 - Invalid—The service order is not valid.
6. Click the **View Alarms** button. You are navigated to the Alarms page in Fault mode. See [“Alarm Detail Monitor \(Service View\)” on page 1331](#) for more information.

RELATED DOCUMENTATION

[Managing Jobs | 122](#)

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

[Validating the Pending Configuration of a Service Order | 1096](#)

[Viewing the Configuration of a Pending Service Order | 1098](#)

[SNMP MIBs and Traps Reference](#)

[Junos Space Network Monitoring Reference](#)

Troubleshooting Devices and Services

IN THIS CHAPTER

- [Performance Management Overview | 1192](#)
- [Monitoring Performance Management Statistics | 1194](#)
- [Viewing Performance Management Statistics | 1198](#)
- [Service Troubleshooting Overview | 1204](#)

Performance Management Overview

In performance management (PM), the Connectivity Services Director application provides an option to measure the frame delay, frame loss, frame delay variation, and service availability. These measurements are achieved in either of the following ways:

- Triggering a one-way delay
- Triggering a two-way delay
- Loss

The performance measurement is useful for generating periodic service level agreement conformance reports from the deployed network and for studying traffic patterns in the network over a period of time.

Monitoring Performance Statistics

The PM statistics can be collected in the following two ways:

1. On-Demand Mode
2. Proactive Mode

NOTE: The Connectivity Services Director application supports only the on-demand mode.

On-Demand Mode

In on-demand mode, you can trigger the measurements. You can also collect loss measurement (ETH-LM) and delay measurements (ETH-DM).

Loss Measurement

The frame loss is calculated by collecting the counter values applicable for ingress and egress service frames. The counters maintain a count of transmitted and received data frames between a pair of MEPs. The loss measurement statistics are retrieved as the output of the **monitor ethernet loss-measurement** command and are also stored at the initiator. The frame counts are stored at both the initiator and the receiver MEPs for later retrieval.

The on-demand loss measurement statistics is collected for E-Line service only. There are two linear charts: Near-End-CIR and Far-End-CIR. For each interval, the graph plots three values: Average case, best case, and worst case frame loss.

Delay Measurement

To start an ethernet frame delay measurement session, the router initiates an exchange of frames carrying one-way or two-way frame delay measurement protocol data units (PDUs) between the local and remote MEPs. Ethernet frame delay measurement statistics are measured and stored at only one of the MEPs.

For one-way ethernet frame delay measurement, only the receiver MEP (on the remote system) collects statistics. For two-way Ethernet frame delay measurement, only the initiator MEP (on the local system) collects statistics.

The on-demand delay measurement statistics are collected for E-Line and E-LAN services. Either the one-way or two-way delay measurements statistics are collected for the services at a given point of time. For each interval, the graph plots three value: Average delay, best case delay and worst case delay.

Proactive Mode

In this mode SLA measurements are triggered by an iterator application. The proactive performance monitoring is supported only on VPWS and E-LAN.

Performance Management of Test Traffic

The Connectivity Services Director application enables you to create Threshold Crossing Alert (TCA) Profiles to apply service level agreement (SLA) parameters to test traffic as defined by the following standards:

- L2 Ethernet OAM/ ITU-T Y.1731
- RFC2544

Specifically, the parameters are:

- Bandwidth Utilization
- Delay

- Delay Variation—Jitter
- Frame Loss
- Throughput

See [Creating a TCA Profile](#).

RELATED DOCUMENTATION

[Monitoring Performance Management Statistics | 1194](#)

[Viewing Performance Management Statistics | 1198](#)

[Service Troubleshooting Overview | 1204](#)

[Performing a Configuration Audit | 1156](#)

Monitoring Performance Management Statistics

IN THIS SECTION

- [Monitoring Statistics for an E-Line Service | 1195](#)
- [Monitoring Statistics for an E-LAN Service | 1197](#)

The following topics show how to monitor the performance statistics for E-Line and E-LAN services:

You can employ the ITU-T Y.1731 standard-compliant Ethernet loss measurement (ETH-LM), Ethernet synthetic loss measurement (ETH-SLM), and Ethernet delay measurement (ETH-DM) capabilities to analyze and examine the operating efficiency and performance status. These performance monitoring functionalities can be run for E-Line and E-LAN services. You can start and stop the collection of performance monitoring (PM) statistics on the services that you want to monitor. The retrieval and computation of statistical details is performed using SNMP MIBs.

A predefined event script, `Y1731_PM.slax`, is available on the Scripts page of the Junos Space Platform GUI, which displays all the scripts imported into the Junos Space Platform database (accessible by selecting **Network management platform > Images and scripts > Scripts**). This script needs to be downloaded on devices. Whenever you trigger the PM mechanism from the Connectivity Services Director GUI, an event is initiated, which in turn causes the SLAX script to be run. The event continues to run the script until the event is stopped. The event runs the script at intervals of 5 minutes. The monitoring framework is used to consolidate and display the retrieved counters and values. You can start the PM collection utility only

on one pair of devices at a time. You cannot start the PM collection functionality on multiple pairs of devices simultaneously.

NOTE: Although you can start or stop the collection of PM statistics without a predefined event script made available on the corresponding devices by selecting OAM > Y1731 > Start or Stop from the Tasks pane in Monitor mode of Service view (no error is displayed and the start or stop of Y1731 PM statistics collection is successful), you must ensure that the event script is present on the devices before you trigger the mechanism for collection of Y1731 PM statistics. Otherwise, although the operation does not display an error in the GUI, no backend processing occurs.

Monitoring Statistics for an E-Line Service

You can start a performance monitoring operation on a service to diagnose the working efficiency and operating quality from the Monitor mode in Service View of Connectivity Services Director.

To monitor the statistics for the E-Line service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders. Select the E-Line service order for which you want to monitor performance statistics.

Alternatively, click the plus sign (+) beside E-LAN Services to view the E-LAN service orders. Select the E-LAN service order for which you want to monitor performance statistics.

5. From the tasks pane, select **OAM > Y1731 > Start**. The **Monitor Performance Statistics** window is displayed.

NOTE: If a CFM profile is not associated with the service, an informational message is displayed stating that an OAM or CFM profile must be mapped with the service.

NOTE: The **Start** action is enabled only if the CFM is enabled in the selected E-Line service. Always perform a functional audit before monitoring the statistics. The **Start** action is disabled if the functional audit status of a service is Down.

6. Fill in the fields as indicated in the table.

Field	Action
Source Device	Select a local device from the list.
Destination Device	Select a remote device from the list.
Request Count	Specify the number of frames to be sent to a specific peer MEP. Range: 1 through 65,535 frames Default: 10 frames
Delay (seconds)	Specify the wait interval for the frame transfer. Range: 1 through 255 seconds Default: 1 second
Frame Priority (802.1p)	Select the dot1p (IEEE 802.1p or packet classification layer 2 headers) priority of continuity-check and link-trace packet. Range: 0 through 7 Default: 0
Monitor Statistics	Select one of the following check boxes: <ul style="list-style-type: none"> • Two-Way delay • One-Way delay • Loss

7. Click **OK**.

NOTE: When you stop PM statistical collection, a popup dialog box is displayed, prompting you to confirm whether you want to stop PM statistical collection. Click **OK** to confirm the action. Click **Cancel** to discard the changes.

To terminate the performance monitoring task, select **OAM > Y1731 > Stop** from the tasks pane for the selected service.

Monitoring Statistics for an E-LAN Service

You can start a performance monitoring operation on a service to diagnose the working efficiency and operating quality from the Monitor mode in Service View of Connectivity Services Director.

To monitor the statistics for the E-LAN Service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders. Select the E-Line service order for which you want to monitor performance statistics.

Alternatively, click the plus sign (+) beside E-LAN Services to view the E-LAN service orders. Select the E-LAN service order for which you want to monitor performance statistics.

5. From the tasks pane, select **OAM > Y1731 > Start**. The **Monitor Performance Statistics** window is displayed.

NOTE: The **OAM > Y1731 > Start** action is enabled only if the CFM is enabled in the selected E-LAN service. Always perform a functional audit before monitoring the statistics. The **OAM > Y1731 > Start** action is disabled if the functional audit status of a service is Down.

6. Fill in the fields as indicated in the table.

Field	Action
Source Device	Select a local device from the list.
Destination Device	Select a remote device from the list.
Request Count	Specify the number of frames to be sent to a specific peer MEP. Range: 1 through 65,535 frames Default: 10 frames

Field	Action
Delay (seconds)	Specify the wait interval for the frame transfer. Range: 1 through 255 seconds Default: 1 second
Frame Priority (802.1p)	Select the 802.1p priority of continuity-check and link-trace packet. Range: 0 through 7 Default: 0
Monitor Statistics	Select Two-Way delay.

7. Click **OK**.

To terminate the performance monitoring task, select **OAM > Y1731 > Stop** from the tasks pane for the selected service.

RELATED DOCUMENTATION

[Performance Management Overview | 1192](#)

[Viewing Performance Management Statistics | 1198](#)

[Service Troubleshooting Overview | 1204](#)

[Performing a Configuration Audit | 1156](#)

Viewing Performance Management Statistics

IN THIS SECTION

● [Viewing Y.1731 Performance Monitoring Statistics for E-Line Services | 1199](#)

● [Viewing Y.1731 Performance Monitoring Statistics for E-LAN Services | 1201](#)

You can employ the ITU-T Y.1731 standard-compliant Ethernet loss measurement (ETH-LM), Ethernet synthetic loss measurement (ETH-SLM), and Ethernet delay measurement (ETH-DM) capabilities to analyze

and examine the operating efficiency and performance status. These performance monitoring functionalities can be run for E-Line and E-LAN services. You can start and stop the collection of Y1731 performance monitoring (PM) statistics on the services that you want to monitor. The retrieval and computation of statistical details is performed using SNMP MIBs.

A predefined event script , PM.slax, is available, which needs to be downloaded on devices. Whenever you trigger the PM mechanism from the Connectivity Services Director GUI, an event is initiated, which in turn causes the SLAX script to be run. The event continues to run the script until the event is stopped. The event runs the script at intervals of 5 minutes. The monitoring framework is used to consolidate and display the retrieved counters and values. You can start the PM collection utility only on one pair of devices at a time. You cannot start the PM collection functionality on multiple pairs of devices simultaneously.

The following topics show how to view the performance statistics for E-Line and E-LAN services:

Viewing Y.1731 Performance Monitoring Statistics for E-Line Services

The Y.1731 monitoring functionality is not enabled by default. You must explicitly start the PM collection mechanism by selecting **OAM > Y1731 > Start** from the task pane after selecting the specified service in the View pane. The graphical representation of the retrieved statistical details for the service is displayed, based on data availability. The data collected is retained after you stop the PM collection utility for future reference and correlation.

NOTE: The refresh of values and statuses of the parameters displayed in the graphs and tables of different monitors depends on the polling interval configured under the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button in the Connectivity Services Director banner and selecting Preferences).

To view the statistics for the E-Line service:

1. Select Service View from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders. Select the E-Line service order for which you want to monitor performance statistics.

Alternatively, click the plus sign (+) beside E-LAN Services to view the E-LAN service orders. Select the E-LAN service order for which you want to monitor performance statistics.

5. Select the **OAM > Y1731** tab.
6. View and analyze the respective graph.

The following monitors are displayed:

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is applicable for E-Line and E-LAN services. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its own corresponding column to denote that it is not applicable. Click Refresh at the top of the monitor to update and display the contents of the table.

From the Time Interval drop-down box, select 1 Hour, 8 Hours, 1 Day, 1 Week, 1 Month, 3 Months, 6 Months, 1 Year, or Custom to specify the duration for which the data polled from devices needs to be displayed. If you select the Custom option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the Time From (Start time in the 24-hour time format of collection of data), and Time To (End time in the 24-hour time format of collection of data). Click OK to save the settings. Else, click Cancel to discard the configuration.

Loss Measurement

The Loss Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents the frame loss ratio. Near-end frame loss refers to the count of frame loss associated with ingress data frames. Far-end frame loss refers to the count of frame loss associated with egress data frames. The lines represent the best case frame loss or the lowest frame loss, the worst case frame loss or the highest frame loss, and the average frame loss or the median of the highest and lowest frame losses. The frame loss is calculated by collecting the counter values applicable for ingress and egress service frames. The counters maintain a count of transmitted and received data frames between a pair of MEPs. The loss measurement statistics are retrieved as the output of the monitor ethernet loss-measurement command and are also stored at the initiator. The frame counts are stored at both the initiator and the receiver MEPs for later retrieval. The on-demand loss measurement statistics is collected for E-Line service only. There are two linear charts: Near-End-CIR and Far-End-CIR. For each interval, the graph plots three values: Average case, best case, and worst case frame loss. From the Loss End drop-down list, select **Near-end (CIR)** to display frame loss statistics associated with ingress data frames or **Far-end (CIR)** to display frame loss statistics associated with egress data frames. Mouse over the legends to view the lines corresponding to best-case, average, and worst-case frame loss statistics.

Delay Measurement

The Delay Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents frame delay in microseconds. The legends reference average one-way delay, best-case one-way delay, and worst-case one way delay for one-way delay measurement. The green line denotes the lowest one-way frame delay for the statistics displayed,

the orange line denotes the highest one-way frame delay for the statistics displayed, and the blue line denotes the average one-way frame delay for the statistics displayed. The legends reference average two-way delay, best-case two-way delay, and worst-case two-way delay for two-way delay measurement. The green line denotes the lowest two-way frame delay for the statistics displayed, the orange line denotes the highest two-way frame delay for the statistics displayed, and the blue line denotes the average two-way frame delay for the statistics displayed. From the Delay End drop-down box, select **1-Way** or **2-Way** to display the one-way or two-way frame delay measurement protocols respectively.

Delay Variation

The Delay Variation graph displays the difference between the consecutive frame delay values. The x-axis represents the time and the y-axis represents delay variation in microseconds. The line denotes the average one-way delay variation or the average one-way “frame jitter” for the statistics displayed for one-way frame delay measurement. The line denotes the average two-way delay variation or the average two-way “frame jitter” for the statistics displayed for two-way delay measurement.

The Loss Measurement monitor displays two real-time linear plots: Near End (CIR) and Far End (CIR). The three parameters in each graph plot are average case, best case, and worst case of frame-loss.

The graph is plotted in real-time. By default, the total time duration is ten minutes. If the duration of statistics collection exceeds ten minutes, the graph scrolls and shows the data of latest ten minutes.

SEE ALSO

[Performance Management Overview | 1192](#)

[Monitoring Performance Management Statistics | 1194](#)

[Viewing Performance Management Statistics | 1198](#)

[Service Troubleshooting Overview | 1204](#)

[Performing a Configuration Audit | 1156](#)

Viewing Y.1731 Performance Monitoring Statistics for E-LAN Services

The Y.1731 monitoring functionality is not enabled by default. You must explicitly start the PM collection mechanism by selecting **OAM > Y1731 > Start** from the task pane after selecting the specified service in the View pane. The graphical representation of the retrieved statistical details for the service is displayed, based on data availability. The data collected is retained after you stop the PM collection utility for future reference and correlation.

NOTE: The refresh of values and statuses of the parameters displayed in the graphs and tables of different monitors depends on the polling interval configured under the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button in the Connectivity Services Director banner and selecting Preferences).

To view the statistics for the E-LAN service:

1. Select Service View from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders. Select the E-Line service order for which you want to monitor performance statistics.

Alternatively, click the plus sign (+) beside E-LAN Services to view the E-LAN service orders. Select the E-LAN service order for which you want to monitor performance statistics.

5. Select the **OAM > Y1731** tab.

View and analyze the graphs.

The following monitors are displayed:

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is applicable for E-Line and E-LAN services. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its own corresponding column to denote that it is not applicable. Click Refresh at the top of the monitor to update and display the contents of the table.

From the Time Interval drop-down box, select 1 Hour, 8 Hours, 1 Day, 1 Week, 1 Month, 3 Months, 6 Months, 1 Year, or Custom to specify the duration for which the data polled from devices needs to be displayed. If you select the Custom option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the Time From (Start time in the 24-hour time format of collection of data), and Time To (End time in the 24-hour time format of collection of data). Click OK to save the settings. Else, click Cancel to discard the configuration.

Loss Measurement

The Loss Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents the frame loss ratio. Near-end frame loss refers to the count of frame loss associated with ingress data frames. Far-end frame loss refers to the count of frame loss associated with egress data frames. The lines represent the best case frame loss or the lowest frame loss, the worst case frame loss or the highest frame loss, and the average frame loss or the median of the highest and lowest frame losses. The frame loss is calculated by collecting the counter values applicable for ingress and egress service frames. The counters maintain a count of transmitted and received data frames between a pair of MEPs. The loss measurement statistics are retrieved as the output of the monitor ethernet loss-measurement command and are also stored at the initiator. The frame counts are stored at both the initiator and the receiver MEPs for later retrieval. The on-demand loss measurement statistics is collected for E-Line service only. There are two linear charts: Near-End-CIR and Far-End-CIR. For each interval, the graph plots three values: Average case, best case, and worst case frame loss. From the Loss End drop-down list, select **Near-end (CIR)** to display frame loss statistics associated with ingress data frames or **Far-end (CIR)** to display frame loss statistics associated with egress data frames. Mouse over the legends to view the lines corresponding to best-case, average, and worst-case frame loss statistics.

Delay Measurement

The Delay Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents frame delay in microseconds. The legends reference average one-way delay, best-case one-way delay, and worst-case one way delay for one-way delay measurement. The green line denotes the lowest one-way frame delay for the statistics displayed, the orange line denotes the highest one-way frame delay for the statistics displayed, and the blue line denotes the average one-way frame delay for the statistics displayed. The legends reference average two-way delay, best-case two-way delay, and worst-case two-way delay for two-way delay measurement. The green line denotes the lowest two-way frame delay for the statistics displayed, the orange line denotes the highest two-way frame delay for the statistics displayed, and the blue line denotes the average two-way frame delay for the statistics displayed. From the Delay End drop-down box, select **1-Way** or **2-Way** to display the one-way or two-way frame delay measurement protocols respectively.

Delay Variation

The Delay Variation graph displays the difference between the consecutive frame delay values. The x-axis represents the time and the y-axis represents delay variation in microseconds. The line denotes the average one-way delay variation or the average one-way “frame jitter” for the statistics displayed for one-way frame delay measurement. The line denotes the average two-way delay variation or the average two-way “frame jitter” for the statistics displayed for two-way delay measurement.

The Loss Measurement monitor displays two real-time linear plots: Near End (CIR) and Far End (CIR). The three parameters in each graph plot are average case, best case, and worst case of frame-loss.

The graph is plotted in real-time. By default, the total time duration is ten minutes. If the duration of statistics collection exceeds ten minutes, the graph scrolls and shows the data of latest ten minutes.

SEE ALSO

Performance Management Overview 1192
Monitoring Performance Management Statistics 1194
Viewing Performance Management Statistics 1198
Service Troubleshooting Overview 1204
Performing a Configuration Audit 1156

RELATED DOCUMENTATION

Performance Management Overview 1192
Viewing Performance Management Statistics 1198
Service Troubleshooting Overview 1204
Performing a Configuration Audit 1156

Service Troubleshooting Overview

Common reasons for the failure of a service are that a PE device configured for that service is down, or that device has had its service configuration changed so that it no longer matches the service configuration in the Junos Space database.

The primary tools in Junos Space for troubleshooting service problems are:

- Functional audit
- Configuration audit
- Job Management

If the functional audit shows the service to be running, the next step is to perform a configuration audit to see whether the service configuration has been changed out of band, and is no longer consistent with the service configuration in the Junos Space database.

You can view the results of both configuration and functional audits from the **Manage Services** page. You can also view the service configuration from the **Manage Services** page.

In the **Job Management** page, use the **Summary** column to obtain information about failed deployments and failed audits. For deployments in general, the **Summary** column contains useful service information such as the VC ID and endpoint information. For some failed deployments, this column also contains information about why the deployment failed. The following is an example of a failed deployment in the **Job Management** page.

RELATED DOCUMENTATION

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Troubleshooting the Endpoints of Services | 1168](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

13

PART

Working in Monitor Mode

[About Monitor Mode | 1207](#)

[Monitoring Traffic | 1213](#)

[Monitoring Devices | 1234](#)

[General Monitoring | 1237](#)

[Monitor Reference | 1241](#)

[Detecting and Examining the Health and Performance of Services | 1251](#)

About Monitor Mode

IN THIS CHAPTER

- [Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director | 1207](#)
- [Understanding the Monitor Mode Tasks Pane in Views Other than Service View | 1211](#)

Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director

IN THIS SECTION

- [Scope and Monitor Tab Availability | 1208](#)
- [Monitors and Tasks | 1208](#)
- [Scope and Data Aggregation | 1208](#)
- [How Connectivity Services Director Collects and Displays Monitoring Data | 1209](#)
- [How Connectivity Services Director Displays and Stores Trend Data | 1209](#)
- [More About the Monitor Tabs | 1210](#)

Monitor mode in Connectivity Services Director provides you visibility into your network status and performance. Connectivity Services Director monitors its managed devices and maintains the information it collects from the devices in a database. Monitor mode displays this information in easy-to-understand graphs and in tables that you can sort and filter, allowing you to quickly visualize the state of your network, spot trends developing over time, and find important details.

Monitor mode divides monitoring activity using the Traffic tab, which provides information about traffic on routers and interfaces.

You can access the Traffic tab on the Monitor mode landing page. An additional tab, the Summary tab, is available that provides a high-level dashboard for the scope selected in the View pane. The monitoring information displayed in the Summary tab also appears on other tabs.

This topic describes:

Scope and Monitor Tab Availability

Your current scope—that is, your view and node selection in the View pane—affects which Monitor tabs are available. For example, if you select a router, the RF tab is not available.

The shading of the tabs indicate whether a tab is selected, available, or not available:

- The currently selected tab has dark text on a light background.
- Tabs that are available but not selected have dark text on a dark background.
- Tabs that are not available for your current scope have light text on a light background.

When you enter Monitor mode from another mode, the Summary tab is selected for all scopes. If you have selected a tab and then change scope, the tab remains selected if it is supported in the new scope. If it is not supported in the new scope, Connectivity Services Director selects a default tab for that scope.

Monitors and Tasks

When you click a Monitor tab, the landing page for that tab is displayed, which contains a set of monitors. These monitors enable you to see at a glance important information about the aspect of your network being monitored. For example, the monitors in the Traffic tab present high-level information about the traffic or packets flow in the selected scope.

Detailed information is also available from many monitors when you click the Details icon on the monitor. If the Details icon is not visible in the title bar of a monitor, mouse over the monitor to make it visible. For example, if you click the Details icon from the Current Sessions By Type monitor, you can view detailed information about the current sessions.

In addition to monitors, each tab provides a set of tasks available from the Tasks pane. These tasks enable you to perform additional monitoring functions. Some tasks enable you to view more specialized monitoring data; others enable you to perform an operation, such as pinging a host. For a complete list of tasks available in Monitor mode, see [“Understanding the Monitor Mode Tasks Pane in Views Other than Service View” on page 1211](#).

The scope you select affects which monitors are displayed and which tasks are available.

Scope and Data Aggregation

Connectivity Services Director enables you to more than monitor individual devices. It provides a broader network view by aggregating data from devices and making that data available for viewing at higher scopes within the network.

Not all data is aggregated at higher scopes. For example, it does not make sense to provide power supply status at any higher scope than the device itself. Whenever monitors are available at a scope higher than the device scope, however, the data presented is aggregated data from all devices contained in that scope.

How Connectivity Services Director Collects and Displays Monitoring Data

Connectivity Services Director collects monitoring data from all its managed devices at regular intervals known as polling intervals. These polling intervals can vary according to the type of data being collected. Connectivity Services Director sets default polling intervals for each type of data—you can, however, change these polling intervals in Preferences.

The polling intervals are aligned to clock time. For example, if the polling interval is set to 5 minutes, then within every hour, Connectivity Services Director collects data at :00, :05, :10, :15, and so on. If the polling interval is set to 15 minutes, Connectivity Services Director collects data within every hour at :00, :15, :30, and :45.

Connectivity Services Director uses the Juniper Networks Device Management Interface (DMI) to the managed devices to collect the data. If you have a Junos Space fabric, Connectivity Services Director balances the load of polling the managed devices across the nodes in the fabric.

When you display a monitor, the current data is from the last polling interval. Displaying or refreshing a monitor does not trigger Connectivity Services Director to collect data. However, Connectivity Services Director automatically refreshes monitors with new data after a polling interval completes. Each monitor displays the time that the data was last refreshed.

The detail windows for monitors are not automatically refreshed after a polling period completes. You must manually refresh them to obtain new polling data.

How Connectivity Services Director Displays and Stores Trend Data

In addition to displaying current data, Connectivity Services Director also displays historical data in trend graphs so that you can view trends in network performance over time.

When you display a trend graph, you can select the time period over which the data is displayed—usually 1 hour, 8 hours, 1 day, 1 week, 1 month, 3 months, 6 months, or 1 year. These predefined periods are always relative to the current time and date—that is, if you select a week, the data is from the last 7 days. You can also define a custom time period, which enables you to display data for a period between specific dates and times.

For a trend graph displaying a predefined period of 1 hour, the number of data points depends on the configured polling interval. For periods greater than an hour, the number of data points displayed depends on the time period selected and how Connectivity Services Director consolidates data over time.

To allow storing of monitoring data for a long period of time, Connectivity Services Director consolidates older data. Consolidation involves deriving a single value from a set of shorter term values, generally by

averaging the shorter term values, and then using that value as a data point in a longer term data set. After the shorter term data is consolidated into longer term data, it is discarded to save storage space. For example, if a value is polled every 5 minutes, the set of 12 values is consolidated into a single value after an hour has passed. That value then becomes one of the 24 data points that makes up the data set for a day. Similarly, after a day has passed, data is consolidated into one data point that represents that day; after a month has passed, data is consolidated into a one data point that represents that month. Data is not kept for more than a year.

For all trend graphs, Connectivity Services Director will not display data until it has more than two data points to display. This means that after you discover a device, trend data will not appear until three polling periods have passed.

More About the Monitor Tabs

IN THIS SECTION

- [The Summary Tab | 1210](#)
- [The Traffic Tab | 1210](#)

The following sections provide more information about each tab in Monitor mode.

The Summary Tab

The Summary tab is displayed whenever you enter Monitor mode. It serves as a high-level dashboard for the current selected scope in the View pane.

The monitors displayed in the Summary tab can belong to any of the Monitor categories. Each scope has a predefined set of monitors that are displayed.

When you select an individual device in the View pane, the Summary tab itself displays an arrow that indicates whether the device is up (green up arrow) or down (red down arrow).

For the My Network scope, you can customize what monitors appear on Summary tab, giving you the ability to view at a glance those aspects of network health and performance that are most important to you.

The Traffic Tab

The Traffic tab provides information for analyzing traffic on routers. The four monitors provide an aggregated view of all network traffic on a device, such as proportion of current proportion of multicast, unicast, broadcast traffic or the trend in packet errors. Tasks provide more detailed looks at traffic, such as traffic statistics for individual ports or the degree in which a port's bandwidth is being used.

Understanding the Monitor Mode Tasks Pane in Views Other than Service View

The Tasks pane in Monitor mode displays a list of tasks that are available for the currently selected Monitor tab. These tasks provide monitoring functions in addition to the monitors available under each tab.

The tasks listed in the Tasks pane vary according to the selected tab—that is, Summary or Traffic—and the scope you have selected in the View pane. For example, the L3 VLAN Statistics task is available only when you select the Traffic tab and a router or a device in the View pane.

For each Monitor mode tab, the following tables list each task and provide a short description of the task:

- [Table 143 on page 1211](#): Summary Tab Tasks
- [Table 144 on page 1212](#): Traffic Tab Tasks
- Key Tasks—Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can modify this set of tasks to suit your requirements. This feature is available in Task pane irrespective of your current mode, scope, or view.

Table 143: Summary Tab Tasks

Task	Description
Compare Device Statistics	Compares statistics from multiple devices in real time.
Ping To a Host	From the selected device, pings the host you specify and returns the results.
Port Utilization	Displays port utilization trend information for the devices in the selected scope. You can view overall port utilization for the selected device or can view individual port utilization.
Select Monitors to display	Selects the monitors that are displayed in the Summary tab
Show ARP Table	Shows Address Resolution Protocol (ARP) table information for a device.
Show Routing Instances	Show the routing instances configured on an MX Series router.
Traceroute To a Host	From the selected device, traces the route to the host you specify and returns the results.

Table 144: Traffic Tab Tasks

Task	Description
Compare Device Statistics	Compares statistics from multiple devices in real time.
L3 VLAN Statistics	Displays packet in and out statistics for Layer 3 VLANs on the selected device.
Ping To a Host	From the selected device, pings the host you specify and returns the results.
Port Statistics	Displays packet and error statistics for all ports on the selected device.
Port Utilization	Displays port utilization trend information for the devices in the selected scope. You can view overall port utilization for the selected device or can view individual port utilization.
Show ARP Table	Shows Address Resolution Protocol (ARP) table information for a device.
Show Routing Instances	Show the routing instances configured on an MX Series router.
Traceroute To a Host	From the selected device, traces the route to the host you specify and returns the results.

RELATED DOCUMENTATION

Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director | 1207

Monitoring Traffic

IN THIS CHAPTER

- [Monitoring Traffic on Devices | 1213](#)
- [Monitoring Port Traffic Statistics | 1214](#)
- [Monitoring Traffic on Layer 3 VLANs | 1216](#)
- [Monitoring Port Utilization | 1218](#)
- [Monitoring Routing Instances | 1222](#)
- [Viewing Congestion Events | 1232](#)

Monitoring Traffic on Devices

The monitors on the Traffic tab provide information about the traffic traversing routers and virtual MX Series (vMX) routers.

To monitor traffic on a device:

1. Click **Monitor** in the Connectivity Services Director banner.
2. Select the device in the View pane that contains the traffic you want to monitor.
3. Select the **Traffic** tab to open the traffic monitors.
4. To get help for a monitor, click the Help button in its title bar.

The available monitors include:

- [“Unicast vs Broadcast/Multicast Monitor” on page 1249](#): shows the distribution of unicast, broadcast, and multicast traffic entering and leaving the device.
- [“Unicast vs Broadcast/Multicast Trend Monitor” on page 1249](#): shows trend data about the distribution of unicast, broadcast, and multicast traffic entering and leaving the device.

- “[Traffic Trend Monitor](#)” on page 1248: shows trend data about the amount of traffic entering and leaving the device.
- “[Error Trend Monitor](#)” on page 1241: shows trend data about the amount of errors on the device.

Monitoring Port Traffic Statistics

IN THIS SECTION

- [Procedure for Monitoring Port Traffic Statistics](#) | 1214
- [Port on Device Window](#) | 1214
- [Port Traffic Stats Window](#) | 1215

This topic describes how to monitor port traffic statistics on a device. You can monitor port traffic statistics for a router, virtual router, or a security device.

This topic describes:

Procedure for Monitoring Port Traffic Statistics

1. Click **Monitor** in the Connectivity Services Director banner.
2. Select a node in the View pane that contains the port traffic you want to monitor.
3. Select the **Traffic** tab.
4. In the Tasks pane, select **View > Port Statistics**.

The Port Traffic Stats window opens. For information about this window, click the Help button in the title bar of the window or see “[Port Traffic Stats Window](#)” on page 1215.

Port on Device Window

Port on Device window displays the details of all the ports on devices that are configured for network traffic analysis. [Table 145 on page 1215](#) describes the fields that are displayed in the Port on Device window.

Table 145: Port on Device table field descriptions

Field Name	Description
Port Name	Identification of the port.
Admin State	The administrative state of the port: enabled (UP) or disabled (DOWN).
Operational State	The operational status—link up (UP) or link down (DOWN).
Max Bandwidth	The actual bandwidth available on the port, in megabits (Mb).
Negotiated Bandwidth	The negotiated bandwidth based on the speed that is configured or auto-negotiated for the interface.

To view more details about the traffic on any port, select the port and click View Traffic. The Traffic on Port window opens.

Port Traffic Stats Window

The Port Traffic Stats window displays information about the port traffic on the node you selected in the View pane. It contains the following elements:

- Port Traffic Trend graph—This line graph shows trends in the data and error rates on the port selected in the ports table below it. The horizontal axis shows the times when samples were taken. The vertical axis shows the data rate on the left side (in packets per second) and the error rate on the right side (in errors per second).

To display traffic for a different port, select the port from the table below the graph. To change the time period over which to display the traffic trends, select a time period from the list in the upper right corner.

NOTE: After a device is discovered, trend data does not appear immediately—it appears only after three polling periods have elapsed.

To highlight a line on the graph, mouse over the line legend. To remove or restore a line, click the line legend. To see numeric values, mouse over where a data line intersects with a dotted vertical grid line.

- Ports table (on the lower left side of the window)—This table provides information about the ports as described in [Table 146 on page 1216](#). Selecting a port from this table updates the Port Traffic Trend graph to display traffic information about the selected port.
- Counter selection table (on the lower right side of the window)—This table enables you to select which counters to display on the Port Traffic Trend graph. It includes separate tabs for packet counters and

error counters. Select the check box in the Show column of each counter that you want to display on the graph. The Per/Sec column shows the rate per second of that row's counter.

Table 146: Port Traffic Window

Table Column	Description
Serial Num	Serial number of the device to which the port belongs.
Port Name	Port name.
Port Usage Type	Port mode—either ACCESS or UPLINK.
MAC Addresses	Port MAC address.
Link Type	Full duplex, half duplex, or unspecified.
In Packets/Sec.(Current)	Current rate of inbound packets.
Out Packets/Sec.(Current)	Current rate of outbound packets.

Monitoring Traffic on Layer 3 VLANs

IN THIS SECTION

- [Procedure for Monitoring Layer 3 VLAN Traffic Statistics | 1216](#)
- [L3 VLAN Traffic Stats Window | 1217](#)

This topic describes how to monitor Layer 3 VLAN traffic statistics on a device. You can monitor Layer 3 VLAN statistics for a router, virtual router, or a security device.

This topic describes:

Procedure for Monitoring Layer 3 VLAN Traffic Statistics

1. Click **Monitor** in the Connectivity Services Director banner.
2. Select a node in the View pane that contains the Layer 3 VLAN traffic you want to monitor.

3. Select the **Traffic** tab.
4. In the Tasks pane, select **View > L3 VLAN Statistics**.

The L3 VLAN Traffic Stats window opens. For information about this window, click the Help button in the title bar of the window or see [“L3 VLAN Traffic Stats Window” on page 1217](#).

L3 VLAN Traffic Stats Window

The L3 VLAN Traffic Stats window displays information about the Layer 3 VLAN traffic on the node you selected in the View pane. It contains two panes:

- **VLAN Traffic line graph**—This graph shows the data transmission rate on the Layer 3 VLAN selected in the table beneath the graph. The horizontal axis shows the times when samples were taken. The vertical axis shows the data rate, in bytes per second.

To show a Layer 3 VLAN on the VLAN Traffic line graph, select the Layer 3 VLAN from the table beneath the graph. To highlight a line on the graph, mouse over the line legend. To remove or restore a line, click the line legend. To see numeric values, mouse over a data point.

- **Layer 3 VLAN traffic statistics table**—This table provides information about the Layer 3 VLANs as described in [Table 147 on page 1217](#). Selecting a Layer 3 VLAN from this table updates the VLAN Traffic graph to display the traffic information for the selected Layer 3 VLAN.

Table 147: Layer 3 VLAN Traffic Statistics Table

Table Column	Description
L3 Interface	Layer 3 interface assigned to the VLAN.
SerialNo	The serial number of the device containing the Layer 3 VLAN.
VLAN Name	VLAN name.
VLAN ID	VLAN ID.
Description	VLAN description.
In Packet	Number of packets entering the VLAN.
Out Packet	Number of packets leaving the VLAN.

Monitoring Port Utilization

IN THIS SECTION

- [How to Access the Port Utilization Task | 1218](#)
- [Port Utilization Details Window | 1219](#)
- [Utilization for Device Window | 1219](#)
- [Utilization for IP Fabric Window | 1220](#)

Connectivity Services Director provides information about port utilization in either one of two places, depending on the node you select in the View pane:

- **Port Utilization monitor**—This monitor, available in the Summary tab, provides a bar chart that shows the aggregate utilization of the ports on a device or devices over a period of time that you select. For more information about using the Port Utilization monitor, see *Port Utilization Monitor*.
- **Port Utilization task**—This task, available from **View > Port Utilization** in the Tasks pane of the Summary or Traffic tabs, provides a bar chart similar to the Port Utilization monitor bar chart. Unlike the Port Utilization monitor, it also enables you to obtain information on individual port utilization over time when you have selected an individual device or Layer 3 Fabric in the View pane.

This topic describes the Port Utilization task. It describes:

How to Access the Port Utilization Task

1. Click **Monitor** in the Connectivity Services Director banner.
2. Select a node in the View pane that contains the ports whose utilization you want to monitor.
3. Select the **Summary** or **Traffic** tab.
4. In the Tasks pane, select **View > Port Utilization**.

If you have selected a node that contains more than one device, the Port Utilization Details window opens. For information about this window, see [“Port Utilization Details Window” on page 1219](#).

If you have selected an individual device, the Utilization for Device window opens. For information about this window, see [“Utilization for Device Window” on page 1219](#).

If you have selected a Layer 3 Fabric, the Utilization for IP Fabric window opens. For information about this window, see [“Utilization for IP Fabric Window” on page 1220](#).

Port Utilization Details Window

This window provides a bar chart showing the aggregate port utilization trend for the devices within the selected scope.

Each bar in the bar chart represents the overall port utilization for all the devices at a polling interval. The vertical axis shows the number of ports polled. The horizontal axis shows the time when each poll was taken.

Each bar is divided into the following colored sections to indicate the distribution of port utilization at the polling interval:

- Green indicates ports that operated at less than 50% of negotiated speed.
- Orange indicates ports that operated at between 50% and 80% of negotiated speed.
- Red indicates ports that operated at more than 80% of negotiated speed.

You can perform the following actions on the bar chart:

- Change the time period over which to display the trend data by selecting a time period from the list in the upper right corner.
- Remove or restore a utilization category (bar color) by clicking its legend.
- Display a numeric value by mousing over a bar.

Utilization for Device Window

The Utilization for Device window shows the port utilization trend for individual devices and ports. It is available when you select a individual device in the View pane.

The Utilization for Device window provides two views of port utilization:

- **Device**—This view provides a trend chart of overall port use on the device over time.
- **Port**—This view provides a heat map of all the ports on the device, enabling you to view the utilization of individual ports. You can choose a port from the heat map to view a utilization trend chart for that particular port.

The Device view is the default view. Click **Port** to change to the Port view.

Device View

The Device view provides a bar chart that shows the trend of overall port use on the device. Each bar represents the overall port utilization at a polling interval. The vertical axis shows the number of ports polled. The horizontal axis shows the time when each poll was taken.

Each bar is divided into the following colored sections to indicate the distribution of port utilization at the polling interval:

- Green indicates ports that operated at less than 50% of negotiated speed.
- Orange indicates ports that operated at between 50% and 80% of negotiated speed.
- Red indicates ports that operated at more than 80% of negotiated speed.

You can perform the following actions in Device view:

- Change the time period over which to display the trend data by selecting a time period from the list in the upper right corner.
- Remove or restore a utilization category (bar color) by clicking its legend.
- Display a numeric value by mousing over a bar.

Port View

The Port view provides utilization heat maps of the ports on the device—one heat map for access ports and another for uplink ports. In the heat maps, each port on the device is represented by a box that is color-coded to indicate the level of port utilization. Cooler colors (for example, green) indicate lower port utilization, while hotter colors (for example, red) indicate higher port utilization.

Click a port box to display a utilization trend chart for that individual port.

You can perform the following actions in the Port view:

- On a heat map:
 - Mouse over a port box to see more information about the port such as the port utilization percent, port type, MAC address of the port, duplex mode, device serial number, admin status and operational status of the port, negotiated speed, and the last flap time.
 - Change the time period over which the port utilization percentage is derived.
 - Click a port box to display the utilization trend chart for that port.
 - Use the percentage slider under the port heat map to display only those ports for which utilization falls within a certain percentage range.
- On the port utilization trend chart:
 - Change the time period over which to display the trend data.
 - Display the percentage utilization and polling time by mousing over a data point.

Utilization for IP Fabric Window

The Utilization for IP Fabric window provides information about port utilization for the devices and ports within a Layer 3 Fabric. It is available when you select a Layer 3 Fabric in the View pane.

The top part of the Utilization for IP Fabric window displays a heat map of the devices in the Layer 3 Fabric. Each device in the Layer 3 Fabric shown as either a spine or leaf device and is color-coded to show the overall port utilization on the device.

You can interact with this fabric-level heat map as follows:

- Mouse over a box representing a device. Information about that device is displayed, such as IP address, model, overall port utilization, and a list of the five ports with the highest utilization.
- Click a box representing a device. The information in the remainder of the window is changed to reflect the port utilization of the device.

You can select two different views of the port utilization on the device:

- **Device**—This view provides a trend chart of overall port use on the device over time.
- **Port**—This view provides a heat map of all the ports on the device, enabling you to view the utilization of individual ports. You can choose a port from the heat map to view a utilization trend chart for that particular port.

The Device view is the default view. Click **Port** to change to the Port view.

Device View

The Device view provides a bar chart that shows the trend of overall port use on the selected device. Each bar represents the overall port utilization at a polling interval. The vertical axis shows the number of ports polled. The horizontal axis shows the time when each poll was taken.

Each bar is divided into the following colored sections to indicate the distribution of port utilization at the polling interval:

- Green indicates ports that operated at less than 50% of negotiated speed.
- Orange indicates ports that operated at between 50% and 80% of negotiated speed.
- Red indicates ports that operated at more than 80% of negotiated speed.

You can perform the following actions on the bar chart:

- Change the time period over which to display the trend data by selecting a time period from the list in the upper right corner.
- Remove or restore a utilization category (bar color) by clicking its legend.
- Display a numeric value by mousing over a bar.

Port View

The Port view provides utilization heat maps of the ports on the device—one heat map for access ports and another for uplink ports. In the heat maps, each port on the device is represented by a box that is color-coded to indicate the level of port utilization. Cooler colors (for example, green) indicate lower port utilization, while hotter colors (for example, red) indicate higher port utilization.

You can perform the following actions on the device heat map:

- Mouse over a port box to see more information about the port, such as the port utilization percent, port type, MAC address of the port, duplex mode, device serial number, admin status and operational status of the port, negotiated speed, and the last flap time.
- Change the time period over which the port utilization percentage is derived.
- Use the percentage slider under the port heat map to display only those ports whose percent utilization falls within a certain range.
- Click a port box to display the utilization trend chart for that port.

The port utilization trend chart shows the utilization trend for the selected port. You can:

- Change the time period over which to display the trend data.
- Display the percentage utilization and polling time by mousing over a data point.

Monitoring Routing Instances

IN THIS SECTION

- [Procedure for Monitoring Routing Instances | 1223](#)
- [Show Routing Instances Window | 1223](#)
- [Show Interfaces Window | 1224](#)
- [Show Bridge Domains Window | 1225](#)
- [Show Connections | 1226](#)
- [Show Routing Tables | 1229](#)
- [Show MAC Table | 1231](#)

This topic describes how to monitor VPN routing instances on MX Series routers by using Connectivity Services Director. Using Connectivity Services Director, you can determine which interfaces and bridge domains belong to the routing instances and view traffic statistics for those interfaces and bridge domains. You can also display connection information for Layer 2 VPN and virtual private LAN service (VPLS) routing instances.

Connectivity Services Director can be used to monitor the following types of Layer 2 routing instances:

- Default routing instance
- Ethernet VPN (EVPN)
- Layer 2 VPN
- VPLS
- Virtual switch

Connectivity Services Director can be used to monitor the following types of Layer 3 routing instances:

- Layer 3 VPN

This topic describes:

Procedure for Monitoring Routing Instances

Use the options in the Show Routing Instances window to monitor routing instances.

1. Click **Monitor** in the Connectivity Services Director banner.
2. Select an MX Series router in the View pane that contains the port traffic you want to monitor.
3. In the Tasks pane, select **Tasks > Show Routing Instances**.

The Show Routing Instances window opens. For information about this window, click the Help button in the title bar of the window or see [“Show Routing Instances Window” on page 1223](#).

Show Routing Instances Window

The Show Routing Instances window lists the routing instances configured on a selected device. Use this window to display the interfaces or bridge domains belonging to a routing instance and obtain traffic statistics for the interfaces. You can also display information about the VPLS and Layer 2 VPN connections. [Table 148 on page 1223](#) describes the fields in this window.

Table 148: Fields in the Show Routing Instances Window

Field	Description
Routing Instance Name	Name of the routing instance.
	The default routing instance is named default-switch.

Table 148: Fields in the Show Routing Instances Window (*continued*)

Field	Description
Type	<p>Identifies the routing instance type:</p> <ul style="list-style-type: none"> • EVPN • L2VPN • L3VPN • Virtual Switch <p>The default routing instance is of this type.</p> <ul style="list-style-type: none"> • VPLS • VRF (L3VPN)
Details	<p>Provides the following information (if configured for the routing instance):</p> <ul style="list-style-type: none"> • Route Distinguisher—Used to identify all routes that are part of the VPN. The route distinguisher makes IP addresses globally unique, so that the same IP address prefixes can be used for different VPNs. • Target—Extended BGP community used to match routes for import and export.
Interfaces	<p>Displays the number of interfaces belonging to the routing instance. Click the number to open the Show Interfaces window, described in “Show Interfaces Window” on page 1224.</p>
Bridge Domains	<p>Displays the number of bridge domains belonging to the routing instance. Click the number to open the Show Bridged Domains window, described in “Show Bridge Domains Window” on page 1225.</p>
Actions	<ul style="list-style-type: none"> • Click Show Connections to display information about Layer 2 VPN and VPLS connections. The information described in “Show Connections” on page 1226 is displayed. This link is available only for Layer 2 VPN and VPLS routing instances. • Click Show MAC Table to display the MAC table for the selected routing instance. For details, see “Show MAC Table” on page 1231. • Click Show Routing Table to view the routing table information for the selected routing instance. For details, see “Show Routing Tables” on page 1229.

Show Interfaces Window

The Show Interfaces window lists the logical interfaces configured on the routing instance and provides the information about the interfaces as described in [Table 149 on page 1225](#).

Table 149: Show Interfaces Information

Field	Description
Interface Name	The interface name.
Port Mode	Indicates one of two modes—access or trunk: <ul style="list-style-type: none"> • Access—The interface can be in a single VLAN only. • Trunk—The interface can be in multiple VLANs and accept tagged packets from multiple devices.
Interface State	Indicates whether the interface is up or down.
STP State	Indicates whether the interface is in a discarding (blocked) or in forwarding (unblocked) state. (Not shown for interfaces belonging to Layer 2 VPN and Layer 3 VPN routing instances.)
Local IP Address	Local IP address. (Shown only for interfaces belonging to Layer 2 VPN and Layer 3 VPN routing instances.)
Remote IP Address	Remote IP address. (Shown only for interfaces belonging to Layer 2 VPN and Layer 3 VPN routing instances.)
Actions	<ul style="list-style-type: none"> • Click View Statistics to display traffic statistics for the interface. The Show Interface Statistics window opens, which charts the number of input and output packets and the number of input and output bytes. • Click Show MAC Table to display the MAC table for the interface. For more details, see “Show MAC Table” on page 1231.

Show Bridge Domains Window

The Show Bridge Domains window lists the bridge domains configured on the routing instance. To display information about the VLAN IDs and interfaces configured on a bridge domain, select the bridge domain. [Table 150 on page 1225](#) describes the information provided in the Show Bridge Domains window.

Table 150: Show Bridge Domains Information

Field	Description
Bridge Domains	The bridge domain name.
Actions	Click Show MAC Table to display the MAC table for the selected bridge domain. For details, see “Show MAC Table” on page 1231 .
VLAN ID	The VLAN ID or IDs assigned to the bridge domain.

Table 150: Show Bridge Domains Information (*continued*)

Field	Description
Interface Name	The name of a logical interface assigned to the VLAN ID.
Port Mode	Indicates one of two modes—access or trunk: <ul style="list-style-type: none"> • Access—The interface can be in a single VLAN only. • Trunk—The interface can be in multiple VLANs and accept tagged packets from multiple devices.
Interface State	Indicates whether the interface is up or down.
STP State	Indicates whether the interface is in a discarding (blocked) or in forwarding (unblocked) state.
Actions	<ul style="list-style-type: none"> • Click View Statistics to display traffic statistics for the interface. The Show Interface Statistics window opens, which charts the number of input and output packets and the number of input and output bytes. • Click Show MAC Table to display the MAC table for the interface. For details, see “Show MAC Table” on page 1231.

Show Connections

The Show Connections window provides information about the VPN connections for Layer 2 VPN and VPLS routing instances as described in [Table 151 on page 1226](#).

Table 151: Show Connections Information

Field	Description
Local Site Name	Name of the local site.
Local Site ID	Identifier for the local site.
Local Interface Name	Name of the local interface.
Interface Status	Indicates whether the local interface is up or down.
Remote Site ID	Identifier for the remote site.
Remote IP	IP address of the remote provider edge device (PE device).

Table 151: Show Connections Information (*continued*)

Field	Description
Connection Status	

Table 151: Show Connections Information (*continued*)

Field	Description
	<p>Status of the connection:</p> <ul style="list-style-type: none"> • EI—The local VPN interface is configured with an encapsulation that is not supported. • EM—The encapsulation type received on this connection from the neighbor does not match the local connection interface encapsulation type. • VC-Dn—The virtual circuit is currently down. • CM—The two routers do not agree on a control word, which causes a control word mismatch. • CN—The virtual circuit is not provisioned properly. • OR—The label associated with the virtual circuit is out of range. • OL—No advertisement has been received for this virtual circuit from the neighbor. There is no outgoing label available for use by this virtual circuit. • LD—All of the CE-facing interfaces to the local site are down. Therefore, the connection to the local site is signaled as down to the other PE routers. No pseudowires can be established. • RD—All the interfaces to the remote neighbor are down. Therefore, the remote site has been signaled as down to the other PE routers. No pseudowires can be established. • LN—The local site has lost path selection to the remote site and therefore no pseudowires can be established from this local site. • RN—The remote site has lost path selection to a local site or to a remote site and therefore no pseudowires are established to this remote site. • XX—The connection is down for an unknown reason. This is a programming error. • MM—The MTUs for the local site and the remote site do not match. • BK—The router is using a backup connection. • PF—Profile parse failure. • RS—The remote site is in a standby state. • NC—The interface encapsulation is not configured as an appropriate CCC (circuit cross-connect), TCC (translational cross-connect), Layer 2 VPN, or VPLS encapsulation. • WE—The encapsulation configured for the interface does not match with the encapsulation configured for the associated connection within the routing instance. • NP—The router detects that interface hardware is not present. The hardware might be offline, a PIC might not be of the compatible type, or the interface might be configured in a different routing instance. • ->—Only the outbound connection is up. • <-—Only the inbound connection is up. • Up—The connection is operational. • Dn—The connection is down. • CF—The router cannot find enough bandwidth to the remote router to satisfy the connection bandwidth requirement.

Table 151: Show Connections Information (*continued*)

Field	Description
	<ul style="list-style-type: none"> • SC—The local site identifier is the same as the remote site identifier. No pseudowire can be established between these two sites. You must configure different values for the local and remote site identifiers. • LM—The local site identifier is not the minimum designated, which means it is not of the lowest value. There is another local site with a lower value for site identifier. Pseudowires are not being established to this local site and the associated local site identifier is not being used to distribute Layer 2 VPN or VPLS label blocks. However, this is not an error state. Traffic continues to be forwarded to the PE router interfaces connected to the local sites when the local sites are in this state. • RM—The remote site identifier is not the minimum designated, which means it is not the lowest. There is another remote site connected to the same PE router which has lower site identifier. The PE router cannot establish a pseudowire to this remote site and the associated remote site identifier cannot be used to distribute VPLS label blocks. However, this is not an error state. Traffic continues to be forwarded to the PE router interface connected to this remote site when the remote site is in this state. • IL—The incoming packets for the connection have no MPLS label. • MI—The configured mesh group identifier is in use by another system in the network. • ST—The router has switched to a standby connection. • PB—Profile is busy. • SN—The neighbor is static.
Time Last Up	The time when the connection was last in the Up condition.

Show Routing Tables

The Routing Tables window enables you view the routing table information for the selected virtual routing instance. For L3VPN and EVP services, you can determine which LSPs or tunnels are being used by looking at the routing tables.

- **Routing Tables**—The Routing Tables table shows the routing tables associated with the virtual instance and the number of active routes in each table. Click on a routing table to display the actual contents of the routing table.
- **Details**—The Details table shows the contents of the selected routing table. [Table 152 on page 1229](#) displays the fields that are displayed in the Details table.

Table 152: Show Routing Table Field Descriptions

Name	Description
Routing Instance	Name of the routing instance.

Table 152: Show Routing Table Field Descriptions (*continued*)

Name	Description
Number of Destinations	Number of destinations for which there are routes in the routing table.
Active Routes	Number of routes that are active.
Hidden Routes	Number of routes that are not used because of routing policy.
Hold-down Routes	Number of routes that are in the hold-down state before being declared inactive.
Total Routes	Total number of routes.
Destination Prefix	<p>Route destination (for example:10.0.0.1/24). Sometimes the route information is presented in another format, such as:</p> <ul style="list-style-type: none"> • MPLS-label (for example, 80001). • interface-name (for example, ge-1/0/2). • neighbor-address:control-word-status:encapsulation type:vc-id :source (Layer 2 circuit only. For example, 10.1.1.195:NoCtrlWord:1:1:Local/96): <ul style="list-style-type: none"> • neighbor-address—Address of the neighbor. • control-word-status—Whether the use of the control word has been negotiated for this virtual circuit: NoCtrlWord or CtrlWord. • encapsulation type—Type of encapsulation, represented by a number: (1) Frame Relay DLCI, (2) ATM AAL5 VCC transport, (3) ATM transparent cell transport, (4) Ethernet, (5) VLAN Ethernet, (6) HDLC, (7) PPP, (8) ATM VCC cell transport, (10) ATM VPC cell transport. • vc-id—Virtual circuit identifier. • source—Source of the advertisement: Local or Remote.
State	State of the route.
Protocol	Name of the protocol from which the route was learned. For example, OSPF , RSVP , and Static .
Protocol Preference	Preferred protocol for this routing instance. Junos OS uses this preference to choose which routes become active in the routing table.
Age	Displays how long since the route was learned.
Metric	Cost value of the indicated route. For routes within an AS, the cost is determined by the IGP and the individual protocol metrics. For external routes, destinations, or routing domains, the cost is determined by a preference value.

Table 152: Show Routing Table Field Descriptions (*continued*)

Name	Description
BGP Local Preference	A metric used by BGP sessions to indicate the degree of preference for an external route. The route with the highest local preference value is preferred.
Route Learned From	Interface from which the route was received.
AS Path	<p>AS path through which the route was learned. The letters at the end of the AS path indicate the path origin, providing an indication of the state of the route at the point at which the AS path originated:</p> <ul style="list-style-type: none"> • I—IGP • E—EGP • ?—Incomplete; typically, the AS path was aggregated.
Validation State	<p>(BGP-learned routes) Validation status of the route:</p> <ul style="list-style-type: none"> • Invalid—Indicates that the prefix is found, but either the corresponding AS received from the EBGp peer is not the AS that appears in the database, or the prefix length in the BGP update message is longer than the maximum length permitted in the database. • Unknown—Indicates that the prefix is not among the prefixes or prefix ranges in the database. • Valid—Indicates that the prefix and autonomous system pair are found in the database.
Next Hop Type	<p>Next hop to the destination. An angle bracket (>) indicates that the route is the selected route.</p> <p>If the destination is Discard, traffic is dropped.</p>
Local Interface	The local interface used to reach the next hop.
Address	IP address of the interface.
Via Interface	Interface used to reach the next hop. If there is more than one interface available to the next hop, the interface that is actually used is followed by the word Selected.
MPLS Label	MPLS label and operation occurring at the next hop. The operation can be pop (where a label is removed from the top of the stack), push (where another label is added to the label stack), or swap (where a label is replaced by another label).

Show MAC Table

The Show MAC table window displays the MAC table for the selected routing instance.

[Table 153 on page 1232](#) describes the fields that are displayed in the Show MAC Table window.

Table 153: Show MAC Table fields

Field Name	Description
Routing Instance	Name of the routing instance.
Type	<p>Identifies the routing instance type:</p> <ul style="list-style-type: none"> • EVPN • L2VPN • L3VPN • Virtual Switch <p>The default routing instance is of this type.</p> <ul style="list-style-type: none"> • VPLS • VRF (L3VPN)
Bridge Domain	Name of the bridging domain.
VLAN ID	VLAN ID of the routing instance or bridge domain in which the MAC address was learned.
MAC Address	MAC address or addresses learned on a logical interface.
MAC Flags	<p>Status of MAC address learning properties for each interface:</p> <ul style="list-style-type: none"> • S—Static MAC address is configured. • D—Dynamic MAC address is configured. • L—Locally learned MAC address is configured. • C—Control MAC address is configured. • SE—MAC accounting is enabled. • NM—Non-configured MAC. • R—Remote PE MAC address is configured.
Logical Interface	Name of the logical interface.

Viewing Congestion Events

This topic describes how to view congestion events on a device. A congestion event occurs when congestion on a device port exceeds the configured threshold.

You can view congestion events only for devices that support Cloud Analytics Engine and that have the high-frequency traffic statistics feature enabled in Connectivity Services Director.

To view congestion events on a device, you must first do the following:

- Configure the Data Learning Engine (DLE) settings under **Preferences > Monitoring > Data Learning Engine Settings**. The DLE is a component of Cloud Analytics Engine.
- Enable high-frequency traffic statistics on the device and optionally configure thresholds.

To view congestion events on a device:

1. In the View pane, select a device on which the high-frequency traffic statistics feature is enabled.
2. Click **Monitor** in the Connectivity Services Director banner to open Monitor mode.
3. In the Tasks pane, select **Tasks > View Congestion Events**. The View Congestion Events window opens.

The View Congestion Events window lists congestion events that occurred on the device during the time span of 1 minute. The table column headings are the seconds within the selected minute. Each row represents a device interface. Each cell represents the activity on that interface during that second. When congestion events occurred during that second, a bubble appears in the cell. The size of the bubble indicates how many congestion events occurred during that second. The color of the bubble indicates the severity of the congestion during that second: cooler colors indicate lower severity, and hotter colors indicate higher severity.

You can perform these actions in the View Congestion Events window :

- Use the Select Hour and Select Minute lists to select the minute in which to display congestion events and then click **Submit**.
- Mouse over a port name to change the bubbles in its row into the number of congestion events that occurred during each second.
- Click a bubble to open a bar chart that shows detailed information about the congestion events that occurred during that second.

Monitoring Devices

IN THIS CHAPTER

- [Comparing Device Statistics | 1234](#)
- [Showing ARP Table Information | 1235](#)

Comparing Device Statistics

IN THIS SECTION

- [Procedure for Comparing Device Statistics | 1234](#)
- [Compare Interfaces Window | 1235](#)

This topic describes how to compare statistics from multiple network devices and interfaces in real time. You select which devices, interfaces, and counters to compare, and how often to poll for new statistics.

This topic describes:

Procedure for Comparing Device Statistics

1. Click **Monitor** in the Connectivity Services Director banner.

You can compare device statistics in any tab in Monitor mode.

2. In the Tasks pane, select **Tasks > Compare Device Statistics**.

The Compare Interfaces window opens. For information about this window, click the Help button in the title bar of the window or see [“Compare Interfaces Window” on page 1235](#).

Compare Interfaces Window

The Compare Interfaces window enables you to compare statistics from multiple device interfaces in real time. The search scope is the entire managed network, regardless of which node is selected in the View pane.

To compare device statistics:

1. Select the devices to compare from the device tree in the Select Devices section.

2. Select a device in the Selected Devices section to select which of its interfaces to compare.
The Select Interfaces section lists the device's interfaces. You can select up to two interfaces per device.
3. Select an Interface in the Select Interfaces section to select which of its counters to compare.
The Select Counters section lists the interface's counters.
4. Select the counters to compare in the Select Counters section.
5. Repeat the process of selecting devices, interfaces, and counters to compare until you are finished selecting what to compare.
6. Select how often the data will be refreshed from the **Data Collection Frequency** list.
7. Click the **Compare** button to start comparing information.
A page opens containing a line graph for each counter you selected. Each graph displays all the interfaces for which its counter is selected.
8. To pause data collection, click the **Pause** button. To resume data collection, click the **Resume** button.
9. To change data collection settings, click the **Back** button.

Showing ARP Table Information

IN THIS SECTION

- [Procedure for Showing ARP Table Information | 1236](#)
- [Show ARP Table Information Window | 1236](#)

This topic describes how to show Address Resolution Protocol (ARP) table information for a device. ARP table information is collected from the selected device when this task runs. You can search for ARP table records.

Procedure for Showing ARP Table Information

To show ARP table information for a device:

- 1. Click **Monitor** in the Connectivity Services Director banner.
- 2. Select the device in the View pane that you want to monitor.
- 3. Select **Tasks > Show ARP Table** in the Task pane.

The Show ARP Table Information window opens. For information about this window, click the Help button in the title bar of the window or see [Table 154 on page 1236](#). You can click the Refresh button below the table to refresh the data from the device.

Show ARP Table Information Window

The Show ARP Table Information Window shows information from the selected device’s ARP table.

Table 154: Show ARP Table Information Window

Control or Column	Description
Search controls	Search for ARP table records. Enter search text in the text box. The table of ARP records displays only matching records. Click the X button to clear the search and display all records.
MAC Address	MAC address.
IP Address	IP address.
Interface Name	Interface name.
Expiring in (sec)	Number of seconds until the record expires from the ARP table.

General Monitoring

IN THIS CHAPTER

- [Selecting Monitors To Display on the Summary Tab | 1237](#)
- [Changing Monitor Polling Interval and Data Collection | 1238](#)
- [Pinging Host Devices | 1238](#)
- [Troubleshooting Network Connections Using Traceroute | 1240](#)

Selecting Monitors To Display on the Summary Tab

When you select the My Network node in the View pane, the Summary tab in Monitor mode enables you to select which monitors to display. If you select more than four monitors, a scroll bar appears to allow you to scroll to the additional monitors.

To select monitors to display on the Summary tab:

1. Click **Monitor** in the Connectivity Services Director banner.
2. Select the **My Network** node in the View pane (the top node in the tree).
3. To select which monitors to display on the Summary tab:

- a. Click **Select Monitors to Display** in the Tasks pane.

The Select Monitors window opens. The monitors that are already selected to display are listed in the Selected list. The other available monitors are listed in the Available list.

- b. To move a monitor from one list to the other list, click the monitor name, and then click the right or left arrow button, as appropriate.

- c. To change the order in which the selected monitors appear in the tab, select a monitor name and move it in the list using the up and down arrow buttons. The arrow buttons at the top and bottom of the stack of buttons move the selected monitor to the top or bottom of the list, respectively.
 - d. Click **Save** to save your changes, or click **Cancel** to cancel your changes.
4. To get information about a monitor, click the Help button in its title bar.

RELATED DOCUMENTATION

[Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director](#) | 1207

Changing Monitor Polling Interval and Data Collection

Network Administrators can change the default polling interval for monitors. The default polling period varies by monitor category. You can change these values in Preferences, found in the Connectivity Services Director banner. You can also enable or disable the data collection processes used by monitors in Preferences.

Pinging Host Devices

Use the Ping Host task in Monitor mode to determine whether an MX Series host can be reached over the network from the device selected in the network tree. Entering a hostname or an address creates a periodic ping task that sends a series of Internet Control Message Protocol (ICMP) echo (ping) requests to the specified host. The output of the task displays in the Response Console.

The Ping from Device to a Host task is available only for ACX Series routers, M Series routers, MX Series routers, and PTX Series routers in your network.

1. Select either IP or HostName in the Remote Host Details box.
2. Type the IP address or hostname for the device that you want to reach.
3. Click **Ping** to use the default settings and start the requests or select the plus (+) symbol to use the Advanced Search Criteria. The fields in Advanced Search Criteria are described in [Table 155 on page 1239](#).

Table 155: Ping Host Advanced Search Criteria Field Descriptions

Field	Description	Default
Count	Indicates the number of ping requests to send. Valid values are 1 through 24.	3
Type of Service	Sets the type-of-service (ToS) field in the IP header of the ping packets. The range of values is 0 through 255. If the routing platform does not support ToS, the field is ignored.	0
Time To Live	Indicates the time-to-live hop count for the ping request packet. Valid values are 0 through 255.	32
Wait Interval	Indicates the amount of time in seconds between ping requests. Valid values are 0 through 24; a 0 value sends the request immediately.	0
Packet Size	Indicates the size of the ping request packet in bytes. The routing platform adds 8 bytes of ICMP header to this size before sending the request packet.	56
Interface	Sends the ping requests on the interface you specify. If you do not specify this option, ping requests are sent on all interfaces.	All
Source	Uses the source address that you specify in the ping request packet.	None

RELATED DOCUMENTATION

[Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director](#) | 1207

Troubleshooting Network Connections Using Traceroute

Traceroute is a diagnostic tool that enables you to display the route that a packet takes to reach the destination and measure transit delays of packets across an Internet Protocol (IP) network. You can use traceroute to troubleshoot and identify points of failure in your switching network. In traceroute, the source device sends three Internet Control Message Protocol (ICMP) echo request packets to the destination device. This is done sequentially till the source receives an ICMP echo reply message from the destination device. The time-to-live (TTL) value is used in determining the number of intermediate devices that the packets traverse before reaching the destination device.

You can use traceroute for ACX, M, MX, and PTX Series routers.

To start a traceroute from the selected device to another device in your network:

1. Select either IP or HostName in the Remote Host Details box.
2. Type the IP address or hostname for the device to which you want to start a traceroute.
3. Click **Trace** to use the default settings and start the traceroute or select the plus (+) symbol to use the Advanced Options. The fields in Advanced Options are described in [Table 156 on page 1240](#).

Table 156: Traceroute Advanced Options Field Descriptions

Field	Description	Default
Interface	Sends the Internet Control Message Protocol (ICMP) echo request packets on the interface you specify. If you do not specify this option, ICMP packets are sent on all interfaces.	Select a value from the list.
Time To Live	Indicates the time-to-live hop count for the ICMP echo request packets. Default value is 30. Valid values are 1 through 255.	30
Wait Interval	Indicates the amount of time in seconds between echo requests. Default value is 5. Valid values are 1 through 24.	5
Type of Service	Sets the type-of-service (ToS) field in the IP header of the echo packets. The range of values is 0 through 255. If the routing platform does not support ToS, the field is ignored.	0

RELATED DOCUMENTATION

[Understanding Monitor Mode in Views Other than Service View of Connectivity Services Director](#) | 1207

Monitor Reference

IN THIS CHAPTER

- [Error Trend Monitor | 1241](#)
- [Equipment Status Summary Monitor | 1243](#)
- [Equipment Summary By Type Monitor | 1244](#)
- [Port Status Monitor | 1245](#)
- [Port Utilization Monitor | 1247](#)
- [Status Monitor for Routers | 1247](#)
- [Traffic Trend Monitor | 1248](#)
- [Unicast vs Broadcast/Multicast Monitor | 1249](#)
- [Unicast vs Broadcast/Multicast Trend Monitor | 1249](#)

Error Trend Monitor

IN THIS SECTION

- [Error Trend | 1241](#)
- [Error Trend Details | 1242](#)

The Error Trend monitor displays inbound and outbound error trends on the node you selected in the View pane. This monitor is available in the Traffic tab.

This topic describes:

Error Trend

A line graph shows the rate inbound and outbound errors over time. The horizontal axis shows the times when samples were taken. The vertical axis shows errors per second.

NOTE: After a device is discovered, trend data does not appear immediately—it appears only after three polling periods have elapsed.

You can perform the following actions on the line graph:

- Change the time period over which to display the traffic trends by selecting a time period from the list in the upper right corner.
- Highlight a line in the graph by mousing over the line's legend.
- Remove or restore a line by clicking its legend.
- Display a numeric value by mousing over a data point.

Error Trend Details

The Error Trend details window displays detailed information about errors on the node you selected in the View pane. It contains the following elements:

- A line graph shows the rate of errors over time. The horizontal axis shows the times when samples were taken. The vertical axis shows errors.

NOTE: After a device is discovered, trend data does not appear immediately—it appears only after three polling periods have elapsed.

You can perform the following actions on the line graph:

- Change the time period over which to display the traffic trends by selecting a time period from the list in the upper right corner.
- Highlight a line in the graph by mousing over the line's legend.
- Remove or restore a line by clicking its legend.
- Display a numeric value by mousing over a data point.
- Error Trend Details table—Shows detailed information about the data gathered at each sample. For information about this table, see [Table 157 on page 1243](#)
- Error Trend Additional Details table—Shows additional error trend details and enables you to display them on the graph. For information about this table, see [Table 158 on page 1243](#).

Table 157: Error Trend Details Table

Column	Description
Time	Time when a data sample was taken from devices.
Errors In	Number of inbound errors reported in the sample.
Errors Out	Number of outbound errors reported in the sample.
CRC Errors In	Number of inbound cyclic redundancy check (CRC) errors reported in the sample.
CRC Errors Out	Number of outbound CRC errors reported in the sample.

Table 158: Error Trend Additional Details Table

Column	Description
Series Name	Name of the data series.
Series Value	Value of the data series.
Show	Select the check box to display the series on the graph. Clear the check box to remove the series from the graph.

Equipment Status Summary Monitor

The Equipment Status Summary monitor provides status highlights for the routers in the current scope. Both the summary and details show up to five available fields. [Table 159 on page 1243](#) describes the fields in this monitor.

Table 159: Equipment Status Summary Fields

Field	Function	Default View
Device	Indicates the type of device.	Summary Details
Up	Indicates how many of the devices are up.	Summary Details
Down	Indicates how many of the devices are down.	Summary Details

Table 159: Equipment Status Summary Fields (*continued*)

Field	Function	Default View
Unknown	Indicates if the controller cannot identify the device.	Summary Details
Disabled	Indicates if the device is disabled.	Summary Details

Equipment Summary By Type Monitor

The Equipment Summary By Type monitor provides summary and detailed information about the type and number of devices in the scope selected in the View pane. This monitor is available on the Summary tab in Monitor mode.

Equipment Summary By Type

The summary view of the Equipment Summary By Type monitor shows the distribution of device types in the selected scope. Routers in a Virtual Chassis are counted separately from standalone routers.

Mouse over a segment of the pie chart to see the actual number of devices of that type. Click the details icon to open the Equipment Summary By Type Detail View window.

Equipment Summary By Type Details

The Equipment Summary By Type Detail View window provides details about the distribution of device types in the selected scope. Each table row represents a device type. Device types are defined by the combination of a device family, platform, and operating system version (for some device types). See [Table 160 on page 1244](#) for a description of the table columns.

Table 160: Equipment Summary By Type Detail View

Table Column	Description
Device Family	Device family.
Platform	Device platform.
OS Version	Operating system version running on the device.
Device Type	Device type.

Table 160: Equipment Summary By Type Detail View *(continued)*

Table Column	Description
Count	Number of devices of this platform in the selected scope.

Port Status Monitor

IN THIS SECTION

- [Port Status Summary | 1245](#)
- [Port Status Details | 1245](#)

The Port Status monitor provides summary and detailed information about the status of the physical network interfaces for the selected node in the View pane.

If the selected node represents an individual device, the monitor displays data specific to the ports on the device. If the selected node contains multiple devices, the monitor displays data aggregated from all the ports on all the devices.

This topic describes:

Port Status Summary

The summary view of the Port Status monitor displays two pie charts:

- Admin Status—Of the interfaces on the selected node, shows the proportion of interfaces that are administratively enabled and that are administratively disabled.
- Free vs Used—Of the network interfaces that are administratively enabled, shows the proportion of interfaces that are in use (operationally up) and that are not in use (operationally down).





Mouse over a pie segment to view the actual number of ports. Click the details icon to open the Port Status Details window.

Port Status Details

The Port Status Details table provides details about the physical network interfaces for the selected node, as shown in [Table 161 on page 1246](#).

NOTE: You must have a transceiver installed in an SFP, SFP+, or XFP port for information about the port to appear.

Table 161: Port Status Details Table

Field	Description
Port Name	The name of the physical interface.
MAC Address	<p>For standalone devices, the first five groups of hexadecimal digits are determined when the device is manufactured. The device then assigns a unique MAC address to each interface by assigning a unique identifier as the last group of hexadecimal digits.</p> <p>For Virtual Chassis members, the first four groups of hexadecimal digits are determined when the switch is manufactured. The fifth group of hexadecimal digits reflects the role of the member in the chassis, such as primary or linecard.</p>
Serial Number	The hardware serial number of the device.
Host Name	The hostname of the device.
Description	A text description of the physical interface.
Current Negotiated Speed (Mbps)	The actual operating speed of the port, in megabits per second (Mbps). Depending on the results of autonegotiation, this speed might be less than the maximum speed supported by the port as indicated by port type.
Configured Speed	The speed configured for the port. If the speed is configured to be determined by autonegotiation, the configured speed is shown as Auto.
Duplex Mode	The duplex mode: full (full-duplex), half (half-duplex), or auto (autonegotiation).
Port Type	The port type (for example, 1 Gigabit Ethernet or 10 Gigabit Ethernet interface).
Admin Status	Indicates the administrative state of the port as  UP or  DOWN.
Operational Status	Indicates the operational status of the port as  UP or  DOWN.
Last Flap Time	Date and time at which the advertised link became unavailable, and then, available again.

Port Utilization Monitor

The Port Utilization Monitor displays a bar chart with information about the port traffic utilization on the node selected in the View pane. Each bar in the chart represents the port traffic utilization data gathered at a polling interval. The vertical axis shows the number of ports polled. The horizontal axis shows the time when each poll was taken. The data shown in the graph is aggregated from all the ports contained in the node selected in the View pane.

Each bar is divided into the following colored sections to indicate the distribution of port traffic utilization at the polling interval:

- Green indicates ports that operated at less than 50% of negotiated speed.
- Orange indicates ports that operated at between 50% and 80% of negotiated speed.
- Red indicates ports that operated at more than 80% of negotiated speed.

You can perform the following actions on the bar chart:

- Change the time period over which to display the data by selecting a time period from the list in the upper right corner.
- Remove or restore a utilization category (bar color) by clicking its legend.
- Display a numeric value by mousing over a bar.

Status Monitor for Routers

This monitor provides key information about the status for a standalone switch or a router when the device is selected in any of the views. This monitor is on the Equipment tab in Monitor mode.

[Table 162 on page 1247](#) describes the fields in this monitor.

Table 162: Status Monitor Fields

Field	Function
Serial Number	Indicates the hardware serial number of the device.
IP Address	Indicates the IP address of the device.
Uptime	Indicates the amount of time since the last boot of the unit in days, hours, minutes, and seconds.
Status	Indicates whether the device is up or down.

Table 162: Status Monitor Fields (*continued*)

Field	Function
Used MAC Addresses	Indicates the number of MAC addresses in use on the device.
Used VLANs	Indicates the number of VLAN memberships for this device.
Last Configured Time	Indicates the date and time when the device was last configured.
Temperature (°C)	Indicates the ambient temperature (in degrees Celsius).
Junos Version	Indicates the version and release level of Junos OS running on the device.

Traffic Trend Monitor

The Traffic Trend monitor displays inbound and outbound traffic trends on the node you selected in the View pane. This monitor is available in the Traffic tab. A line graph shows the rate of each type of traffic over time. The horizontal axis shows the times when samples were taken. The vertical axis shows the data rate, in packets per second.

NOTE: After a device is discovered, trend data does not appear immediately—it appears only after three polling periods have elapsed.

You can perform the following actions on the line graph:

- Change the time period over which to display the traffic trends by selecting a time period from the list in the upper right corner.
- Highlight a line in the graph by mousing over the line's legend.
- Remove or restore a line by clicking its legend.
- Display a numeric value by mousing over a data point.

Unicast vs Broadcast/Multicast Monitor

The Unicast vs Broadcast/Multicast monitor displays a pie chart of the current distribution of unicast, broadcast, and multicast traffic types on the node you selected in the View pane. This monitor is available in the Traffic tab.

The traffic is divided into these categories:

- Unicast inbound
- Unicast outbound
- Broadcast inbound
- Broadcast outbound
- Multicast inbound
- Multicast outbound

Mouse over a pie segment to view the actual number of packets.

Unicast vs Broadcast/Multicast Trend Monitor

The Unicast vs Broadcast/Multicast Trend monitor displays trends in the data rates of unicast, broadcast, and multicast traffic on the node you selected in the View pane. This monitor is available on the Traffic tab. A line graph shows the rate of each type of traffic over time. The horizontal axis shows the times when samples were taken. The vertical axis shows the data rate, in packets per second.

NOTE: After a device is discovered, trend data does not appear immediately—it appears only after three polling periods have elapsed.

The traffic is divided into these categories:

- Unicast inbound
- Unicast outbound
- Broadcast inbound
- Broadcast outbound
- Multicast inbound
- Multicast outbound

You can perform the following actions on the line graph:

- Change the time period over which to display the traffic trends by selecting a time period from the list in the upper right corner.
- Highlight a line in the graph by mousing over the line's legend.
- Remove or restore a line by clicking its legend.
- Display a numeric value by mousing over a data point.

Detecting and Examining the Health and Performance of Services

IN THIS CHAPTER

- [Service Monitoring Capabilities in Connectivity Services Director | 1252](#)
- [Computation of Statistics Polled from Devices for Display in Widgets on Monitoring Pages | 1253](#)
- [Configuring the Aggregation Method for Viewing Monitoring Details | 1255](#)
- [Viewing the Service Monitoring Summary Page for a Consolidated Listing of Services | 1257](#)
- [Monitoring the Service Summary Details of E-Line Services for Optimal Debugging | 1259](#)
- [Monitoring the Service Summary Details of E-LAN Services for Optimal Debugging | 1262](#)
- [Monitoring the Service Summary Details of IP Services for Optimal Debugging | 1265](#)
- [Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)
- [Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters | 1271](#)
- [Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)
- [Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)
- [Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | 1279](#)
- [Monitoring the Service Transport Details of IP Services for Easy Analysis | 1282](#)
- [Viewing Y.1731 Performance Monitoring Statistics for E-Line Services | 1286](#)
- [Viewing Y.1731 Performance Monitoring Statistics for E-LAN Services | 1289](#)
- [Clearing Interface Statistics | 1292](#)
- [Viewing MAC Table Details | 1294](#)
- [Viewing Interface Statistics | 1295](#)
- [Viewing Interface Status Details | 1297](#)
- [MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)
- [Using MPLS Ping | 1300](#)
- [Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)
- [Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)
- [Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)
- [Routing Table Overview | 1308](#)
- [Viewing Routing Table Details | 1309](#)

Service Monitoring Capabilities in Connectivity Services Director

In a network environment, a network administrator, operator, or a supervisor must be able to quickly and easily monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services to be able to take corrective action and restoration measures in case of device alarms, overload conditions, or traffic drops. Using the Monitor mode of the Connectivity Services Director application, you can monitor the managed services on devices, and collect and store the information from the devices in the Connectivity Services Director application database. The monitors or widgets are displayed to enable you to track, diagnose, and rectify discrepancies associated with services configured on devices. The information is displayed in easy-to-understand graphs and in tables that you can sort and filter, allowing you to quickly visualize the state of your network, spot trends developing over time, and find important details.. For example, you might observe that an IP service is reported as down from the summarized information presented for that service on the monitoring page. This high-level view enables you to navigate to the settings for that service and fine-tune to function properly.

The following tabs are displayed when you click the Monitor icon in the Service View of the Connectivity Services Director banner.

- **ServiceSummary**—Displays the consolidated and cumulative status of a service. This tab is applicable for E-Line, IP, E-LAN, EVPN, and EVPN-VPWS services. The Connections monitor show the status of the connection or link (up or down) between peer devices. In the table displayed for this monitor, the row represents the source device and the column denotes the destination device. The Traffic Summary monitor represents the total Egress (Packets out) traffic passing through all the UNI or CE interfaces that are part of the cumulative services. The Current Active Alarms monitor shows any active alarm that has not yet been cleared
- **ServiceTransport**—Displays the transport or packet statistics for data against time between the source and destination devices that you select, and based on the LSP that is used by the endpoint. The source device is the row selected in the Connection Matrix widget on the Service Transport tab. The destination device is chosen from the Traffic Statistics widget on the Service Transport tab. By default, no destination devices are selected. Service transport statistical values are displayed for E-Line, E-LAN, and IP services.
- **ServiceTraffic**—Displays the end-to-end traffic matrix that signifies the traffic between peer devices. You can view statistical counters and metrics for input packets, input bytes, output packets, and output bytes. The Interface Statistics monitor shows traffic data on all the user-to-network interfaces (UNI) or site interfaces that are part of the service. These values are on-demand statistical values and the data is retrieved from the device directly without being cached (polling at periodic intervals and displaying a snapshot). This tab is supported for E-Line, E-LAN, and IP services. The data is available only if queues are enabled on the interface.
- **ServicePerformance**—Displays frame delay, frame loss, frame delay variation, and service availability. These measurements are achieved by triggering a one-way delay, two-way delay, or loss The performance measurement is useful for generating periodic service-level agreement conformance reports from the deployed network and for studying traffic patterns in the network over a period of time. In proactive

mode, SLA measurements are triggered by an iterator application. An iterator is designed to periodically transmit SLA measurement packets in form of ITU-Y.1731-compliant frames for two-way delay measurement or loss measurement for each of the connections registered to it. Iterators make sure that measurement cycles do not occur at the same time for the same connection to avoid CPU overload. The iterator profiles are configured on remote MEP for measurement of Ethernet frame delay measurement (ETH-DM), Ethernet frame loss measurement (ETH-LM), and statistical frame loss (SFL).

- **LSP Summary**—Displays a comprehensive and cohesive view about the configured LSP service. The status of the LSP and the status of connections between the ingress router and egress routers in an LSP are displayed. The LSP status details are shown for the ingress router. You can also view the ingress, egress, and transit LSP information, such as the primary and secondary states.

NOTE: Configuring iterator profile is not supported by Connectivity Service Director.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

RELATED DOCUMENTATION

[Configuring the Aggregation Method for Viewing Monitoring Details](#) | 1255

Computation of Statistics Polled from Devices for Display in Widgets on Monitoring Pages

To interpret the statistical details and counters displayed in the charts and tables of the monitoring pages and in the tabular layouts, it is essential to understand the manner in which the metrics and values are retrieved from the devices and displayed in the GUI pages. In the charts, the time intervals are shown along the x-axis and data points or values of a particular attribute are shown along the y-axis. On the y-axis, the counter value displayed is the differential value between two polling intervals or the aggregated interval. For example, for the input packets of an interface, [Table 163 on page 1254](#) describes the mapping between polled and counter values.

Table 163: Mapping Between Polled Values and Counter Values Displayed in the GUI

Polling value from devices	456789	456800	456825	456840	456840
Counter value shown on the charts and tables	-	11	25	15	0

If the number of data points available between two intervals is more than one, the data is aggregated. The aggregation is based on the Connectivity Services Director application settings that you configure as preferences. One of the following types of statistical metrics can be viewed:

- **Total**—Sum of the number of packets in a specific time period
- **Average**—Average of the total number of packets in a specific time period

For example, for the input packets for an interface, the values described in [Table 164 on page 1254](#) illustrate the manner in which the differential values of counters are calculated for different time periods, based on the polling intervals that are used to retrieve details from the devices.

Table 164: Computation of Counters Using Polling Intervals

Polling Time	Start	10:30	10:45	11:00	11:15	11:30	11:45
Polling Counter Value	525	550	555	575	590	625	640
Packets Per Interval	-	25	5	20	15	35	15
Time Interval	-	10:45		11:15		11:45	
Counter Value (Average)	-	15		18		25	
Counter Value (Total)	-	50		45		50	

The number of actual data points varies between the minimum and maximum number of values, based on polling period and data availability. For the time values shown on the graph, the end time indicated is the time at which the last polling or retrieval of data occurred on the device. The interval between two data points is computed by using the total duration for which statistics is displayed by subtracting the period from the end time. The start time displayed is based on the number of intervals calculated by clocking backward from the end time.

RELATED DOCUMENTATION

Configuring the Aggregation Method for Viewing Monitoring Details

On the pages in Monitor mode of the Connectivity Services Director GUI that display statistical information and counters for traffic flow and packets across peer devices for various services and device configuration settings, you can select the aggregation or cumulative method that must be used for computing and displaying statistics. You can also modify the application settings to display the aggregation of traffic.

The following two aggregation values are supported:

- **Total**—Sum of the number of packets received in the interval
- **Average**—Average of the total number of packets received in the interval

You can set the aggregation method from the Junos Space Platform GUI or the Connectivity Services Director GUI.

To configure the aggregation method from the Junos Space Platform GUI:

1. From the Network Management Platform task pane, select **Administration > Applications**.

The Applications page that appears displays a list of the applications in the Network Management platform.

2. Right-click Connectivity Services Director and select **Modify Applications Settings**.

The Modify Application Settings page that appears displays a list of the parameters that can be modified.

3. Click the **Monitoring** button to specify the settings.

NOTE: You cannot modify the application settings if another user is currently modifying them.

4. Select the **Perform Monitoring on failed Functional Audit** check box if you want the monitoring functionality to be enabled for services for which functional audit failed. Otherwise, monitoring data is displayed in the widgets in Monitor mode of Service View only on services for which functional audit succeeded.
5. In the Pseudowire Redundancy Transition TimeDelay field, specify the number of minutes after which a remote procedure call (RPC) must be sent from Connectivity Services Director to the device on which redundant pseudowires are configured for monitoring data to be collected.

By default, an RPC call is initiated every 2 minutes.

6. From the Statistics Aggregation Reporting list, select **Total** or **Average**.

The value of the aggregation method determines the manner in which the aggregated results are returned for a query that polls and retrieves data from devices.

7. Click **Modify** to save the changes that you made in the Connectivity Services Director application. Alternatively, click **Cancel** to retain the original settings.

The aggregation method setting is modified.

To configure the aggregation method from the Connectivity Services Director GUI:

1. To open the Preferences page, click the down arrow next to the **System** button on the Connectivity Services Director banner and select Preferences.

The Preferences page opens with User Preferences as the default tab.

2. Click the **Service Activation** tab.

The settings that you can configure for services activation are displayed.

3. From the Statistics Aggregation Reporting list, select **Total** or **Average**.

The aggregation method that you specified is used for computation of values on the monitoring pages.

4. Click **OK** to save the changes. Alternatively, click **Cancel** to discard the changes.

The aggregation method setting is saved.

NOTE: For the charts and tables displayed in Monitor mode of Service View, you can specify the polling interval and enable or disable the following collectors:

- ProvisioningMonitorInterfaceStatusCollector—Defines the polling interval for monitoring the interface status
- ProvisioningMonitorInterfaceStatsCollector—Defines the polling interval for monitoring the interface statistics
- ProvisioningMonitorServiceStatusCollector—Defines the polling interval for monitoring the service status
- ProvisioningMonitorLDPStatsCollector—Defines the polling interval for monitoring the LDP statistics
- ProvisioningMonitorY1731PMCollector—Defines the polling interval for monitoring the performance management or Y.1731 statistics
- ProvisioningMonitorLSPStatsCollector—Defines the polling interval for monitoring the LSP statistics

RELATED DOCUMENTATION

[Service Monitoring Capabilities in Connectivity Services Director | 1252](#)[Configuring the Aggregation Method for Viewing Monitoring Details | 1255](#)

Viewing the Service Monitoring Summary Page for a Consolidated Listing of Services

The Service Monitoring Summary page displays a consolidated view of all of the service instances for a particular service type. The customer associated with the service, type of service, service definition upon which the service order is based, the traffic rate in bits per second, and the traffic trend are displayed.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Monitoring Summary page:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Deploy** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

- Expand the **IP Services** tree to select an IP Ethernet service.
- Expand the **E-Line Services** tree to select an E-Line service.
- Expand the **E-LAN Services** tree to select an E-LAN service.

The Service Monitoring Summary page is displayed, if you do not select a particular service from the Service View pane and select the E-Line Services, IP Services, or E-LAN Services term in the Service View pane.

5. Click the **ServiceSummary** tab.

The Service Monitoring Summary page is displayed.

The following fields are displayed on this page:

- Name—Name of the configured service. Select the corresponding service from the Network Services > Connectivity tree on the View pane to navigate to the Service Summary page.
- Customer—Name of the customer associated with the service.
- Type—Service type, such as E-Line, IP, or E-LAN.
- Service Definition—Name of the service definition that is used to create the service.
- Status—Whether the status is up or down. NA indicates that the status is not available for the corresponding service.
- UNIs up/down—Number of user-to-network (ingress) interfaces that are in the up and down states.
- Traffic (bps) max/min/avg—Maximum, minimum, and average rates of traffic handled by the service in bits per second (bps).
- Traffic Trend (bps)—Line graph that signifies the rate of egress packets (packets that are sent out from an interface) in bps.

6. Select the service name from the Network Services > Connectivity tree on the View pane to view detailed information about the corresponding service.

The Service Summary page for the corresponding service is displayed.

You can view the consolidated and cumulative status or different types of services on the following tabs:

- ServiceSummary tab for E-Line services—Displays the consolidated service status for E-Line services
- ServiceSummary tab for E-LAN services—Displays the consolidated service status for E-LAN services
- ServiceSummary tab for IP services—Displays the consolidated service status for IP services

RELATED DOCUMENTATION

[Monitoring the Service Summary Details of E-Line Services for Optimal Debugging | 1259](#)

[Monitoring the Service Summary Details of E-LAN Services for Optimal Debugging | 1262](#)

[Monitoring the Service Summary Details of IP Services for Optimal Debugging | 1265](#)

Monitoring the Service Summary Details of E-Line Services for Optimal Debugging

IN THIS SECTION

- [Service Status | 1260](#)
- [Connections | 1261](#)
- [Traffic Summary | 1261](#)
- [Section | ?](#)

You can view the Service Summary page of a particular service to display the consolidated and cumulative status of a service. The overall information pertaining to the service that you can obtain from the different widgets displayed on this page enables you to navigate to the appropriate device or service settings page and modify the configuration parameters appropriately. You can view the connection between the different endpoints and also examine the statistics on the packets and bytes traversing through the endpoints. Using the Service Summary page, you can also select the source device for which you want to view the transport metrics and the traffic statistics on the other pages displayed in Monitor mode for the specific service. This page enables you to obtain an effective graphical view in the form of tables of statistics and charts to view the health and performance of devices and services in your network, which enables you to analyze and troubleshoot the parameters that are causing traffic-handling errors.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Summary page for E-Line services:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Monitor** icon in the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.
5. Expand the **E-Line Services** tree to select an E-Line service.
6. From the main display area, click the **ServiceSummary** tab. The Service Summary page is displayed.

NOTE: The Service Monitoring Summary page is displayed, if you do not select a particular service from the Service View pane and select the E-Line Services term in the Service View pane. The Summary page displays a consolidated view of all of the service instances for a particular service type. The customer associated with the service, type of service, service definition upon which the service order is based, the traffic rate in bits per second, and the traffic trend are displayed. Select the corresponding service from the Network Services > Connectivity tree on the View pane to navigate to the Service Summary page.

Service Status

This widget displays the cumulative, consolidated status of services, such as E-Line. The following fields are displayed in a tabular form in this widget:

- Name—Name of the service.
- Type—Protocol configured for the service, such as ELINE, E-LAN, or IP
- Status—Whether the service is up or down.
- PEs (Up/Down)—Number of provider edge devices that are in the up and down states
- UNIs (Up/Down)—Number of user-to-network (ingress) interfaces that are in the up and down states
- OSPF Neighbors—Number of OSPF neighbors
- BGP Neighbors—Number of BGP neighbors
- Local Switch—Whether the local switching mode to terminate multiple Layer 2 circuit pseudowires is configured.
- Y1731 Status—Whether the connectivity fault management (CFM) profile is configured for the service and whether Y1731 performance monitoring (PM) statistics collection, such as one-way delay measurement and variation, two-way delay measurement and variation, or loss measurement are configured.

Click **Refresh** at the top of the monitor to update and display the contents of the table.

The Service Status monitor is also applicable for an E-Line service with any one endpoint as an unmanaged device. For an E-Line service, with unmanaged devices, the overall service status, PEs up/down, UNIs up/down, that are based on polling of only managed devices are displayed.

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its own corresponding column to denote that it is not applicable. Click **Refresh** at the top of the monitor to update and display the contents of the table.

One of the following values is displayed on the columns that denote the adjacent and destination devices or endpoints:

- PR—Peer Device or Primary-Backup Pair. No Connection such as A/A or Z/Z.
- PBK—Peer Backup. No Connection.
- OL—No advertisement has been received for this virtual circuit from the neighbor. There is no outgoing label available for use by this virtual circuit.
- NA—Not available.

Mouse over the cells in the table to display the description of the connection statuses, such as PR, PBK or NA.

With an E-Line service that contains an unmanaged endpoint, the Connections matrix represents the status from managed to unmanaged devices, based on the managed device polling. The connection status from unmanaged to managed is always displayed as NA.

Traffic Summary

This widget displays the total number of egress packets (packets that are sent out) or traffic passing through all the UNI or customer-edge (CE) interfaces associated with the particular service. This monitor is applicable for E-Line services. The date and time at which the page was last updated is shown. A line graph is displayed with time on the horizontal axis and the number of output packets on the vertical axis.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

For an E-Line service with one endpoint as an unmanaged device, the Traffic Summary monitor represents the total egress traffic trend of only the managed devices. Unmanaged device traffic is not monitored.

RELATED DOCUMENTATION

[Viewing the Service Monitoring Summary Page for a Consolidated Listing of Services | 1257](#)

[Monitoring the Service Summary Details of E-LAN Services for Optimal Debugging | 1262](#)

[Monitoring the Service Summary Details of IP Services for Optimal Debugging | 1265](#)

Monitoring the Service Summary Details of E-LAN Services for Optimal Debugging

IN THIS SECTION

- [Service Status | 1263](#)
- [Connections | 1264](#)
- [Traffic Summary | 1264](#)

You can view the Service Summary page of a particular service to display the consolidated and cumulative status of a service. The overall information pertaining to the service that you can obtain from the different widgets displayed on this page enables you to navigate to the appropriate device or service settings page and modify the configuration parameters appropriately. You can view the connection between the different endpoints and also examine the statistics on the packets and bytes traversing through the endpoints. Using the Service Summary page, you can also select the source device for which you want to view the transport metrics and the traffic statistics on the other pages displayed in Monitor mode for the specific service. This page enables you to obtain an effective graphical view in the form of tables of statistics and charts to view the health and performance of devices and services in your network, which enables you to analyze and troubleshoot the parameters that are causing traffic-handling errors.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Summary page for E-LAN services:

1. Select **Service View** from the View Selector.
The workspaces that are applicable to routing and tunneling services are displayed on the View pane.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.
The functionalities that you can configure in this mode are displayed on the task pane.
3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
The Network Services tree is expanded and displayed on the View pane.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
The Connectivity tree is expanded and displayed on the View pane.
5. Expand the **E-LAN Services** tree to select an E-LAN service.
6. Click the **ServiceSummary** tab. The Service Summary page is displayed.

NOTE: The Service Monitoring Summary page is displayed, if you do not select a particular service from the Service View pane and select the E-LAN Services term in the Service View pane. The Summary page displays a consolidated view of all of the service instances for a particular service type. The customer associated with the service, type of service, service definition upon which the service order is based, the traffic rate in bits per second, and the traffic trend are displayed. Select the corresponding service from the Network Services > Connectivity tree on the View pane to navigate to the Service Summary page.

The following widgets or widgets are displayed under this tab for E-LAN services. These statistical counters and metrics enable you to view an agglomerative, cohesive snapshot of the service configured on a device.

Service Status

This widget displays the cumulative, consolidated status of services, such as E-LAN. The following fields are displayed in a tabular form in this widget:

- Name—Name of the service.
- Type—Protocol configured for the service, such as E-Line, E-LAN, or IP.

- **Status**—Whether the service is up or down. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down.
- **PEs (Up/Down)**—Number of provider edge devices that are in the up and down states
- **UNIs (Up/Down)**—Number of user-to-network (ingress) interfaces that are in the up and down states
- **Local Switch**—Whether the local switching mode to terminate multiple Layer 2 circuit pseudowires is configured
- **Y1731 Status**—Whether the connectivity fault management (CFM) profile is configured for the service and whether performance monitoring (PM) statistics collection, such as one-way delay measurement and variation, two-way delay measurement and variation, or loss measurement are configured.

Click **Refresh** at the top of the monitor to update and display the contents of the table.

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is applicable for E-LAN services.

One of the following values is displayed on the columns that denote the adjacent and destination devices or endpoints:

- **PR**—Peer Device. Primary-Backup Pair. No Connection such as A/A or Z/Z.
- **PBK**—Peer Backup. No Connection.
- **OL**—No advertisement has been received for this virtual circuit from the neighbor. There is no outgoing label available for use by this virtual circuit.
- **NA**—Not available.

Mouse over the cells in the table to display the description of the connection statuses, such as PR, PBK or NA.

For the device for which the connection status is displayed, a hyphen (-) is displayed under its own corresponding column to denote that it is not applicable. Click **Refresh** at the top of the monitor to update and display the contents of the table.

Traffic Summary

This widget displays the total number of egress packets (packets that are sent out) or traffic passing through all the UNI or customer-edge (CE) interfaces associated with the particular service. This monitor is valid for E-LAN services. The date and time at which the page was last updated is shown. A line graph is displayed with time on the horizontal axis and the number of output packets on the vertical axis.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Viewing the Service Monitoring Summary Page for a Consolidated Listing of Services | 1257](#)

[Monitoring the Service Summary Details of E-Line Services for Optimal Debugging | 1259](#)

[Monitoring the Service Summary Details of IP Services for Optimal Debugging | 1265](#)

Monitoring the Service Summary Details of IP Services for Optimal Debugging

IN THIS SECTION

- [Service Status | 1267](#)
- [VPN Routes | 1267](#)
- [VPN Traffic Trend | 1267](#)

You can view the Service Summary page of a particular service to display the consolidated and cumulative status of a service. The overall information pertaining to the service that you can obtain from the different widgets displayed on this page enables you to navigate to the appropriate device or service settings page and modify the configuration parameters appropriately. You can view the connection between the different endpoints and also examine the statistics on the packets and bytes traversing through the endpoints. Using the Service Summary page, you can also select the source device for which you want to view the transport metrics and the traffic statistics on the other pages displayed in Monitor mode for the specific service. This page enables you to obtain an effective graphical view in the form of tables of statistics and charts to view the health and performance of devices and services in your network, which enables you to analyze and troubleshoot the parameters that are causing traffic-handling errors.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Summary page for IP services:

1. Select **Service View** from the View Selector.
The workspaces that are applicable to routing and tunneling services are displayed on the View pane.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.
The functionalities that you can configure in this mode are displayed on the task pane.
3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
The Network Services tree is expanded and displayed on the View pane.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
The Connectivity tree is expanded and displayed on the View pane.
5. Expand the **IP Services** tree to select an IP service.
6. Click the **ServiceSummary** tab.
The Service Summary page is displayed.

NOTE: The Service Monitoring Summary page is displayed, if you do not select a particular service from the Service View pane and select the IP Services term in the Service View pane. The Summary page displays a consolidated view of all of the service instances for a particular service type. The customer associated with the service, type of service, service definition upon which the service order is based, the traffic rate in bits per second, and the traffic trend are displayed. Select the corresponding service from the Network Services > Connectivity tree on the View pane to navigate to the Service Summary page.

Service Status

This widget displays the operational status of IP services. The following fields are displayed in a tabular form in this widget:

- Name—Name of the service
- Type—Protocol configured for the service
- Status—Whether the service is up or down.

Click **Refresh** at the top of the monitor to update and display the contents of the table.

VPN Routes

This monitor shows the status of routers between peer devices in a VPN connection. The following fields are displayed in a tabular form:

- Node—Name of the device configured in a VPN tunnel
- Direct—Number of direct routes in the VPN tunnel for the specified node or device that are up and down
- Local—Number of local routes in the VPN tunnel for the specified node or device that are up and down
- Static—Number of static routes in the VPN tunnel for the specified node or device that are up and down
- BGP—Number of BGP routes in the VPN tunnel for the specified node or device that are up and down (BGP routing information includes the complete route to each destination)
- OSPF—Number of OSPF routes in the VPN tunnel for the specified node or device that are up and down (OSPF routes IP packets based solely on the destination IP address contained in the IP packet header)
- Destination Count—Number of destinations for which there are routes in the routing table.
- Total Route Count—Number of routes in the routing table and total number of routes in the following states:
 - active (routes that are active)
 - holddown (routes that are in the pending state before being declared inactive)
 - hidden (routes that are not used because of a routing policy)
- Active Route Count—Number of VPN routes that are active

Click **Refresh** at the top of the monitor to update and display the contents of the table.

VPN Traffic Trend

This widget displays the total number of egress packets (packets that are sent out) or traffic passing through all the UNI or customer-edge (CE) interfaces associated with the particular service. The date and time at

which the page was last updated is shown. A line graph is displayed with time on the horizontal axis and the number of output bytes on the vertical axis.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Viewing the Service Monitoring Summary Page for a Consolidated Listing of Services | 1257](#)

[Monitoring the Service Summary Details of E-Line Services for Optimal Debugging | 1259](#)

[Monitoring the Service Summary Details of E-LAN Services for Optimal Debugging | 1262](#)

Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters

You can view the Service Traffic page of a specific service to examine and diagnose the transmission details of packets and the metrics on forwarded or received packets. The interface statistical counters display the number of packets and bytes sent and received from interfaces that are associated with the devices of the service. A pictorial representation of the links in an E-Line service topology is also shown. You can also view a bar chart of the class-of-service (CoS) queue information for physical interfaces. For rate-limited interfaces hosted on Modular Interface Cards (MICs), Modular Port Concentrators (MPCs), or Enhanced Queuing DPCs, rate-limit packet-drop operations occur before packets are queued for transmission scheduling. For such interfaces, the statistics for queued traffic do not include the packets that have already been dropped due to rate limiting, and consequently the displayed statistics for queued traffic are the same as the displayed statistics for transmitted traffic.

For rate-limited interfaces hosted on other types of hardware, rate-limit packet-drop operations occur after packets are queued for transmission scheduling. For these other interface types, the statistics for queued traffic include the packets that are later dropped due to rate limiting, and consequently the displayed statistics for queued traffic equals the sum of the statistics for transmitted and rate-limited traffic.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Traffic page for E-Line services:

1. Select **Service View** from the View Selector.
The workspaces that are applicable to routing and tunneling services are displayed on the View pane.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.
The functionalities that you can configure in this mode are displayed on the task pane.
3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
The Network Services tree is expanded and displayed on the View pane.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
The Connectivity tree is expanded and displayed on the View pane.
5. Expand the **E-Line Services** tree to select an E-Line service.
6. Click the **ServiceTraffic** tab.
The Service Traffic page is displayed.

The following widgets are displayed on the Service Traffic tab.

- [Traffic Graph on page 1269](#)
- [Pseudowire Traffic on page 1270](#)
- [Interface Traffic Statistics/Endpoint Users on page 1270](#)

Traffic Graph

The Traffic Graph monitor displays the number of packets transmitted between the peer devices. A table is shown with the row representing the source device and the columns denoting the devices or network elements in the path up to the destination device. It is applicable for E-Line services. From the Statistics Type drop-down list, select Packets or Bytes to display metrics corresponding to the selected parameter.

The Traffic Graph monitor for E-Line services is displayed in a pictorial form, with the primary origin or A endpoint, backup origin or A endpoint, primary destination or Z endpoint, and backup destination or Z endpoints shown as circles. Color-coded legends reference the lines that are shown in the graph. The lines correspond to the traffic traversing from the A primary endpoint to the Z primary endpoints, from the A primary endpoint to the Z backup endpoint, and from the Z primary and Z backup endpoints to the A primary endpoint. The arrows indicate the direction of traffic flows. Red lines denote the Layer 2 Ethernet pseudowire traffic between the endpoints to have been dropped or the connection to be down. Green lines denote the pseudowire traffic to be transmitted successfully or the connection to be up. A gray line denotes that connection state is not available, and NA indicates that the statistic is not available. Solid lines denote the connections between primary pseudowires, while dotted lines denote the connections between secondary pseudowires. The numbers that are shown on the connection lines signify the metrics or count corresponding to the type of parameter you selected, such as output packets or output bytes.

On the Service Traffic page, the Traffic Graph monitor is also supported for an E-Line service with one endpoint as unmanaged device.

For an E-Line service with resiliency, for the redundant pseudowires configured to remote PE routers from the A primary or source endpoint, the traffic statistics for the primary pseudowire over which customer traffic is being transmitted and the backup pseudowire are displayed along the connection lines.

Pseudowire Traffic

This monitor is displayed for E-Line services. A line chart is displayed with time on the horizontal axis and the number of output packets or output bytes on the vertical axis. From the Statistics Type drop-down box at the top of the monitor, select Input Packets or Input Bytes to display the number of packets or bytes traversing in the ingress direction (received traffic). Alternatively, select Output Packets/Second or Output Bytes/Second to display metrics corresponding to the transmitted or egress packets or bytes. From the Select Primary Endpoint list, select the primary endpoint or device for which you want to view the traffic details traversing through the pseudowire in the output direction.

From the Time Interval drop-down box, select 1 Hour, 8 Hours, 1 Day, 1 Week, 1 Month, 3 Months, 6 Months, 1 Year, or Custom to specify the duration for which the data polled from devices needs to be displayed. If you select the Custom option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the Time From (Start time in the 24-hour time format of collection of data), and Time To (End time in the 24-hour time format of collection of data). Click OK to save the settings. Else, click Cancel to discard the configuration.

Interface Traffic Statistics/Endpoint Users

This monitor is displayed for E-Line services. In this monitor, the interface statistics denote the traffic data on all the UNI or site interfaces associated with the service. These values are on-demand statistical values and the data is retrieved from the device directly without being cached (polling at periodic intervals and displaying a snapshot). It is supported for E-Line, E-LAN, and IP services. The following fields are displayed in a table:

- Device Name—Name of the device
- Interface—Name of the interface
- Packets In—Number of packets received on the interface
- Packets Out—Number of packets sent from the interface
- Bytes In—Number of bytes received on the interface
- Bytes Out—Number of bytes sent from the interface

From the Automatic Refresh list, select **Disabled**, **Every 30 Seconds**, **Every 45 Seconds**, or **Every 1 Minute** to specify the frequency at which the statistics in the table must be updated and displayed. When you disable the auto-refresh capability, the page is not refreshed periodically by itself; instead you can click the **Refresh** icon to update the table contents for viewing.

For an E-Line service with one endpoint as unmanaged device, the Interface statistics monitor displays only the managed devices in the list and the corresponding monitored data. Unmanaged devices or its data are not displayed.

RELATED DOCUMENTATION

[Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters | 1271](#)

[Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)

[Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)

[Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | 1279](#)

[Monitoring the Service Transport Details of IP Services for Easy Analysis | 1282](#)

Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters

You can view the Service Traffic page of a specific service to examine and diagnose the transmission details of packets and the metrics on forwarded or received packets. The interface statistical counters display the number of packets and bytes sent and received from interfaces that are associated with the devices of the service. A pictorial representation of the links in an E-Line service topology is also shown. You can also view a bar chart of the class-of-service (CoS) queue information for physical interfaces. For rate-limited interfaces hosted on Modular Interface Cards (MICs), Modular Port Concentrators (MPCs), or Enhanced Queuing DPCs, rate-limit packet-drop operations occur before packets are queued for transmission scheduling. For such interfaces, the statistics for queued traffic do not include the packets that have already been dropped due to rate limiting, and consequently the displayed statistics for queued traffic are the same as the displayed statistics for transmitted traffic.

For rate-limited interfaces hosted on other types of hardware, rate-limit packet-drop operations occur after packets are queued for transmission scheduling. For these other interface types, the statistics for queued traffic include the packets that are later dropped due to rate limiting, and consequently the displayed statistics for queued traffic equals the sum of the statistics for transmitted and rate-limited traffic.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Traffic page for E-LAN services:

1. Select **Service View** from the View Selector.
The workspaces that are applicable to routing and tunneling services are displayed on the View pane.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.
The functionalities that you can configure in this mode are displayed on the task pane.
3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
The Network Services tree is expanded and displayed on the View pane.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
The Connectivity tree is expanded and displayed on the View pane.
5. Expand the **E-LAN Services** tree to select an E-LAN service.
6. Click the **ServiceTraffic** tab.
The Service Traffic page is displayed.

The following widgets are displayed on the Service Traffic tab.

- [Traffic Graph on page 1269](#)
- [Interface Traffic Statistics/Endpoint Users on page 1270](#)
- [Traffic Pattern on page 1273](#)

Traffic Matrix

The Traffic Matrix monitor displays the number of packets transmitted between the peer devices. A table is shown with the row representing the source device and the columns denoting the devices or network elements in the path up to the destination device. It is applicable for E-LAN services. From the Statistics Type drop-down list, select Unicast Bytes, Multicast Bytes, Broadcast Bytes, or Flooded Bytes to display metrics corresponding to the selected parameter.

Interface Statistics

This monitor is displayed for E-LAN services. In this monitor, the interface statistics denote the traffic data on all the UNI or site interfaces associated with the service. These values are on-demand statistical values and the data is retrieved from the device directly without being cached (polling at periodic intervals and displaying a snapshot). It is supported for E-Line, E-LAN, and IP services. The following fields are displayed in a table:

- Device Name—Name of the device
- Interface—Name of the interface
- Packets In—Number of packets received on the interface
- Packets Out—Number of packets sent from the interface
- Bytes In—Number of bytes received on the interface
- Bytes Out—Number of bytes sent from the interface

From the Automatic Refresh list, select **Disabled**, **Every 30 Seconds**, **Every 45 Seconds**, or **Every 1 Minute** to specify the frequency at which the statistics in the table must be updated and displayed. When you disable the auto-refresh capability, the page is not refreshed periodically by itself; instead you can click the **Refresh** icon to update the table contents for viewing.

Traffic Pattern

This monitor is displayed for E-LAN services. A chord graphic displays the relationship among a set of entities. The association in the form of chords for traffic traversing through devices on which the service is assigned is shown.

RELATED DOCUMENTATION

[Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)

[Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)

[Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)

Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters

You can view the Service Traffic page of a specific service to examine and diagnose the transmission details of packets and the metrics on forwarded or received packets. The interface statistical counters display the number of packets and bytes sent and received from interfaces that are associated with the devices of the service. A pictorial representation of the links in an E-Line service topology is also shown. You can also view a bar chart of the class-of-service (CoS) queue information for physical interfaces. For rate-limited interfaces hosted on Modular Interface Cards (MICs), Modular Port Concentrators (MPCs), or Enhanced Queuing DPCs, rate-limit packet-drop operations occur before packets are queued for transmission scheduling. For such interfaces, the statistics for queued traffic do not include the packets that have already been dropped due to rate limiting, and consequently the displayed statistics for queued traffic are the same as the displayed statistics for transmitted traffic.

For rate-limited interfaces hosted on other types of hardware, rate-limit packet-drop operations occur after packets are queued for transmission scheduling. For these other interface types, the statistics for queued traffic include the packets that are later dropped due to rate limiting, and consequently the displayed statistics for queued traffic equals the sum of the statistics for transmitted and rate-limited traffic.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Traffic page for an IP service:

1. Select **Service View** from the View Selector.
The workspaces that are applicable to routing and tunneling services are displayed on the View pane.
2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.
The functionalities that you can configure in this mode are displayed on the task pane.
3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

The Connectivity tree is expanded and displayed on the View pane.

5. Expand the **IP Services** tree to select an IP service.

6. Click the **ServiceTraffic** tab.

The Service Traffic page is displayed.

The following widgets are displayed on the Service Traffic tab.

- [Interface Traffic Statistics/Endpoint Users on page 1270](#)
- [VPN Traffic Trend on page 1275](#)

Interface Statistics

This monitor is displayed for IP services. In this monitor, the interface statistics denote the traffic data on all the UNI or site interfaces associated with the service. These values are on-demand statistical values and the data is retrieved from the device directly without being cached (polling at periodic intervals and displaying a snapshot). It is supported for IP services. The following fields are displayed in a table:

- Device Name—Name of the device
- Interface—Name of the interface
- Packets In—Number of packets received on the interface
- Packets Out—Number of packets sent from the interface
- Bytes In—Number of bytes received on the interface
- Bytes Out—Number of bytes sent from the interface

From the Automatic Refresh list, select **Disabled**, **Every 30 Seconds**, **Every 45 Seconds**, or **Every 1 Minute** to specify the frequency at which the statistics in the table must be updated and displayed. When you disable the auto-refresh capability, the page is not refreshed periodically by itself; instead you can click the **Refresh** icon to update the table contents for viewing.

VPN Traffic Trend

This monitor is displayed for IP services. A line chart is displayed with time on the horizontal axis and the number of output packets on the vertical axis.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

- [Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)
- [Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters | 1271](#)
- [Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)
- [Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | 1279](#)
- [Monitoring the Service Transport Details of IP Services for Easy Analysis | 1282](#)

Monitoring the Service Transport Details of E-Line Services for Easy Analysis

IN THIS SECTION

- [Connections | 1277](#)
- [LSP Information | 1278](#)
- [LSP Traffic | 1279](#)

You can view the Service Transport page of a particular service to obtain detailed and granular information on the high-level statistics that are displayed on the Service Summary page. The VPN routes learned by a provider edge (PE) device from all other PE devices are displayed. The PE routers in the provider's core network are the only routers that are configured to support VPNs and hence are the only routers to have information about the VPNs. From the point of view of VPN functionality, the provider (P) routers in the core—those P routers that are not directly connected to CE routers—are merely routers along the tunnel between the ingress and egress PE routers. The accounting information about configured and active label-switched paths (LSPs) is also displayed. Statistics are not available for LSPs on the egress routing device, because the penultimate routing device in the LSP sets the label to 0. Also, as the packet arrives at the egress routing device, the hardware removes its MPLS header and the packet reverts to being an IPv4 packet. Therefore, it is counted as an IPv4 packet, not an MPLS packet.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Transport page for an E-Line service:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

The Connectivity tree is expanded and displayed on the View pane.

5. Expand the **E-Line Services** tree to select an E-Line service.

6. Click the **ServiceTransport** tab.

The Service Transport page is displayed.

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is applicable for E-Line services. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its own corresponding column to denote that it is not applicable.

LSP Information

For a destination address that contains LSP names, the corresponding LSP details, such as the name, state, and bandwidth of the LSP, are displayed in this monitor. The details displayed in this monitor depend on the device selected in the Connections Matrix widget. The following fields are displayed:

- Name— Name of the LSP
- State— State of the LSP handled by this RSVP session: Up, Dn (down), or Restart
- Bandwidth—Specifies the bandwidth in bits per second for the LSP.
- Primary State— State of the LSP that is a primary path: Up, Down, or Restart
- Secondary State— State of the LSP that is a secondary path: Up, Down, or Restart
- Received RRO—(Ingress LSP) Received record route. A series of hops, each with an address followed by a flag. (In most cases, the received record route is the same as the computed explicit route. If Received RRO is different from Computed ERO, there is a topology change in the network, and the route is taking a detour.) The following flags identify the protection capability and status of the downstream node:
 - 0x01—Local protection available. The link downstream from this node is protected by a local repair mechanism. This flag can be set only if the Local protection flag was set in the SESSION_ATTRIBUTE object of the corresponding Path message.
 - 0x02—Local protection in use. A local repair mechanism is in use to maintain this tunnel (usually because of an outage of the link it was routed over previously).
 - 0x03—Combination of 0x01 and 0x02.
 - 0x04—Bandwidth protection. The downstream routing device has a backup path providing the same bandwidth guarantee as the protected LSP for the protected section.
 - 0x08—Node protection. The downstream routing device has a backup path providing protection against link and node failure on the corresponding path section. If the downstream routing device can set up only a link-protection backup path, the Local protection available bit is set but the Node protection bit is cleared.
 - 0x09—Detour is established. Combination of 0x01 and 0x08.
 - 0x10—Preemption pending. The preempting node sets this flag if a pending preemption is in progress for the traffic engine LSP. This flag indicates to the ingress legacy edge router (LER) of this LSP that it should be rerouted.
 - 0xb—Detour is in use. Combination of 0x01, 0x02, and 0x08.
- Total Packets—Total number of packets and Total number of bytes transmitted over the LSP. This counter is reset to zero whenever the LSP path is optimized (for example, during an automatic bandwidth allocation).
- Total Bytes—Total number of bytes transmitted over the LSP. This counter is reset to zero whenever the LSP path is optimized (for example, during an automatic bandwidth allocation).

LSP Traffic

This widget displays a line chart with the bytes per second (bps) or rate on the y-axis and time on the x-axis to denote the LSP bandwidth utilization in bps.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)

[Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)

[Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)

[Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | 1279](#)

[Monitoring the Service Transport Details of IP Services for Easy Analysis | 1282](#)

Monitoring the Service Transport Details of E-LAN Services for Easy Analysis

IN THIS SECTION

- [Connections | 1280](#)
- [LSP Information | 1281](#)
- [LSP Traffic | 1281](#)

You can view the Service Transport page of a particular service to obtain detailed and granular information on the high-level statistics that are displayed on the Service Summary page. The VPN routes learned by a provider edge (PE) device from all other PE devices are displayed. The PE routers in the provider's core network are the only routers that are configured to support VPNs and hence are the only routers to have information about the VPNs. From the point of view of VPN functionality, the provider (P) routers in the core—those P routers that are not directly connected to CE routers—are merely routers along the tunnel between the ingress and egress PE routers. The accounting information about configured and active

label-switched paths (LSPs) is also displayed. Statistics are not available for LSPs on the egress routing device, because the penultimate routing device in the LSP sets the label to 0. Also, as the packet arrives at the egress routing device, the hardware removes its MPLS header and the packet reverts to being an IPv4 packet. Therefore, it is counted as an IPv4 packet, not an MPLS packet.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Transport page for an E-LAN service:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

The Connectivity tree is expanded and displayed on the View pane.

5. Expand the **E-LAN Services** tree to select an E-LAN service.

6. Click the **ServiceTransport** tab. The Service Transport page is displayed.

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is applicable for E-Line and E-LAN services. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its own corresponding column to denote that it is not applicable.

LSP Information

For a destination address that contains LSP names, the corresponding LSP details, such as the name, state, and bandwidth of the LSP, are displayed in this monitor. The details displayed in this monitor depend on the device selected in the Connection Matrix widget. The following fields are displayed:

- Name— Name of the LSP
- State— State of the LSP handled by this RSVP session: Up, Dn (down), or Restart
- Bandwidth—Specifies the bandwidth in bits per second for the LSP.
- Primary State— State of the LSP that is a primary path: Up, Down, or Restart
- Secondary State— State of the LSP that is a secondary path: Up, Down, or Restart
- Received RRO—(Ingress LSP) Received record route. A series of hops, each with an address followed by a flag. (In most cases, the received record route is the same as the computed explicit route. If Received RRO is different from Computed ERO, there is a topology change in the network, and the route is taking a detour.) The following flags identify the protection capability and status of the downstream node:
 - 0x01—Local protection available. The link downstream from this node is protected by a local repair mechanism. This flag can be set only if the Local protection flag was set in the SESSION_ATTRIBUTE object of the corresponding Path message.
 - 0x02—Local protection in use. A local repair mechanism is in use to maintain this tunnel (usually because of an outage of the link it was routed over previously).
 - 0x03—Combination of 0x01 and 0x02.
 - 0x04—Bandwidth protection. The downstream routing device has a backup path providing the same bandwidth guarantee as the protected LSP for the protected section.
 - 0x08—Node protection. The downstream routing device has a backup path providing protection against link and node failure on the corresponding path section. If the downstream routing device can set up only a link-protection backup path, the Local protection available bit is set but the Node protection bit is cleared.
 - 0x09—Detour is established. Combination of 0x01 and 0x08.
 - 0x10—Preemption pending. The preempting node sets this flag if a pending preemption is in progress for the traffic engine LSP. This flag indicates to the ingress legacy edge router (LER) of this LSP that it should be rerouted.
 - 0xb—Detour is in use. Combination of 0x01, 0x02, and 0x08.

LSP Traffic

This widget displays a line chart with the bytes per second (bps) or rate on the y-axis and time on the x-axis to denote the LSP bandwidth utilization in bps.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)

[Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters | 1271](#)

[Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)

[Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)

[Monitoring the Service Transport Details of IP Services for Easy Analysis | 1282](#)

Monitoring the Service Transport Details of IP Services for Easy Analysis

You can view the Service Transport page of a particular service to obtain detailed and granular information on the high-level statistics that are displayed on the Service Summary page. The VPN routes learned by a provider edge (PE) device from all other PE devices are displayed. The PE routers in the provider's core network are the only routers that are configured to support VPNs and hence are the only routers to have information about the VPNs. From the point of view of VPN functionality, the provider (P) routers in the core—those P routers that are not directly connected to CE routers—are merely routers along the tunnel between the ingress and egress PE routers. The accounting information about configured and active label-switched paths (LSPs) is also displayed. Statistics are not available for LSPs on the egress routing device, because the penultimate routing device in the LSP sets the label to 0. Also, as the packet arrives at the egress routing device, the hardware removes its MPLS header and the packet reverts to being an IPv4 packet. Therefore, it is counted as an IPv4 packet, not an MPLS packet.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the Service Transport page for an IP service:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside Connectivity to view services based on protocols.

The Connectivity tree is expanded and displayed on the View pane.

5. Expand the **IP Services** tree to select an IP service.

6. Click the **ServiceTransport** tab.

The Service Transport page is displayed.

This widget provides details on Summary Monitors, which are shown in Service Summary Tab under Monitor functionality of "Service View".

- [Transport Statistics on page 1283](#)
- [VPN Routes on page 1267](#)
- [Label/LSP Information on page 1284](#)
- [LSP Traffic on page 1279](#)

Transport Statistics

The Transport Statistics monitor shows the statistical counts for the selected data against time between the source device and the specified peer or destination device, and the LSP being used by the endpoint. The source device is the row selected in the Connection Matrix widget. The destination device is based on the device that you chose in the Traffic Statistics widget. By default, destination devices are empty. This monitor is valid for E-Line services. A line graph is displayed with time on the horizontal axis and the type of statistical parameter on the vertical axis. In the Peer Device list, all Devices from the Connection Matrix except the source device are available for selection. In the Statistics Type list, you can select Ingress Packets or Ingress Bytes. Color-coded legends are used to indicate tunnel and device traffic. The purple

line denotes tunnel traffic and the brown line signifies the device (service) traffic. Because the LSP does not provide any metric if it is down, there might be variations in the data point for the LSP and device.

VPN Routes

This widget displays information about the path through which the packets traverse in LSPs in a VPN tunnel. Select a node for which you want to view the VPN routing information from the Select Node list at the top of the monitor. Alternatively, enter the name of the node for which you want to view the VPN routing details as the match criterion in the Search box and click the Search icon. The page refreshes to display the nodes that match with the search criterion. Click **Refresh** to update the contents of the table.

- **Destination**— Destination (egress routing device) of the session
- **Next Hop**— Address of the next-hop (downstream) routing device or client, interface used to reach this neighbor, and number of packets sent to the downstream routing
- **LSP/Label**— Name of the LSP. For LDP signaling, NA is shown.

Label/LSP Information

Label Information

For a destination address that you select in the VPN Routes monitor that contain LDP-established LSPs, the corresponding label details for active and backup LSPs are displayed in this monitor. The following fields are displayed:

- **Protocol**—LDP is the mechanism used to establish LSPs
- **Next-hop**—Network layer address of the directly reachable neighboring system.
- **via**—Interface used to reach the next hop. If there is more than one interface available to the next hop, the name of the interface that is actually used is followed by the word **Selected**. This field can also contain the following information:
 - **Weight**—Value used to distinguish primary, secondary, and fast reroute backup routes. Weight information is available when MPLS label-switched path (LSP) link protection, node-link protection, or fast reroute is enabled, or when the standby state is enabled for secondary paths. A lower weight value is preferred. Among routes with the same weight value, load balancing is possible.
 - **Balance**—Balance coefficient indicating how traffic of unequal cost is distributed among next hops when a routing device is performing unequal-cost load balancing. This information is available when you enable BGP multipath load balancing.
- **Label Operation**—MPLS label and operation occurring at this routing device. The operation can be pop (where a label is removed from the top of the stack), push (where another label is added to the label stack), or swap (where a label is replaced by another label).

- **Label TTL Action**—State of the TTL propagation attribute, such as prop-ttl (propagate the TTL value), prop-ttl (top) (propagate the TTL value of the outermost or top label), no-prop-ttl (do not propagate the TTL value), or no-prop-ttl (top) (do not transmit the TTL value of the top label)
- **Load Balance label**—Whether the load-balancing capability based on labels is enabled.

LSP Information

For a destination address that you select in the VPN Routes monitor that contain LSP names, the corresponding LSP details, such as the name, state, and bandwidth of the LSP, are displayed in this monitor. The details displayed in this monitor depend on the device selected in the Connection Matrix widget. The following fields are displayed:

- **Name**— Name of the LSP
- **State**— State of the LSP handled by this RSVP session: Up, Dn (down), or Restart
- **Bandwidth**—Specifies the bandwidth in bits per second for the LSP.
- **Primary State**— State of the LSP that is a primary path: Up, Down, or Restart
- **Secondary State**— State of the LSP that is a secondary path: Up, Down, or Restart
- **Received RRO**—(Ingress LSP) Received record route. A series of hops, each with an address followed by a flag. (In most cases, the received record route is the same as the computed explicit route. If Received RRO is different from Computed ERO, there is a topology change in the network, and the route is taking a detour.) The following flags identify the protection capability and status of the downstream node:
 - **0x01**—Local protection available. The link downstream from this node is protected by a local repair mechanism. This flag can be set only if the Local protection flag was set in the SESSION_ATTRIBUTE object of the corresponding Path message.
 - **0x02**—Local protection in use. A local repair mechanism is in use to maintain this tunnel (usually because of an outage of the link it was routed over previously).
 - **0x03**—Combination of 0x01 and 0x02.
 - **0x04**—Bandwidth protection. The downstream routing device has a backup path providing the same bandwidth guarantee as the protected LSP for the protected section.
 - **0x08**—Node protection. The downstream routing device has a backup path providing protection against link and node failure on the corresponding path section. If the downstream routing device can set up only a link-protection backup path, the Local protection available bit is set but the Node protection bit is cleared.
 - **0x09**—Detour is established. Combination of 0x01 and 0x08.
 - **0x10**—Preemption pending. The preempting node sets this flag if a pending preemption is in progress for the traffic engine LSP. This flag indicates to the ingress legacy edge router (LER) of this LSP that it should be rerouted.
 - **0xb**—Detour is in use. Combination of 0x01, 0x02, and 0x08.

- **Total Packets**—Total number of packets and Total number of bytes transmitted over the LSP. This counter is reset to zero whenever the LSP path is optimized (for example, during an automatic bandwidth allocation).
- **Total Bytes**—Total number of bytes transmitted over the LSP. This counter is reset to zero whenever the LSP path is optimized (for example, during an automatic bandwidth allocation).

LSP Traffic

This widget displays a line chart with the bytes per second (bps) or rate on the y-axis and time on the x-axis to denote the LSP bandwidth utilization in bps.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

- [Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)
- [Monitoring the Service Traffic Statistics of E-LAN Services for Correlating Device Counters | 1271](#)
- [Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)
- [Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)
- [Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | 1279](#)

Viewing Y.1731 Performance Monitoring Statistics for E-Line Services

IN THIS SECTION

- [Connections | 1287](#)
- [Loss Measurement | 1288](#)
- [Delay Measurement | 1288](#)
- [Delay Variation | 1289](#)

The Y.1731 monitoring functionality is not enabled by default. You must explicitly start the PM collection mechanism by selecting **OAM > Y1731 > Start** from the Tasks pane after selecting the specified service on the View pane. The graphical representation of the retrieved statistical details for the service is displayed, based on data availability. The data collected is retained after you stop the PM collection utility for future reference and correlation.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the performance monitoring statistics for the E-Line service:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside E-Line Services to view the E-Line service orders.

5. Select the E-Line service order for which you want to monitor performance statistics.

The E-Line Services tree is expanded and displayed on the View pane.

6. Select the **Y1731** tab.

The Service Performance page is displayed.

NOTE: You can view performance management statistics only after you start the collection of Y1731 performance monitoring (PM) statistics by selecting **OAM > Y1731 > Start** from the Tasks pane.

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is

applicable for E-Line and E-LAN services. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its own corresponding column to denote that it is not applicable. Click **Refresh** at the top of the monitor to update and display the contents of the table.

From the Time Interval drop-down box, select **1 Hour, 8 Hours, 1 Day, 1 Week, 1 Month, 3 Months, 6 Months, 1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

Loss Measurement

The Loss Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents the frame loss ratio. Near-end frame loss refers to the count of frame loss associated with ingress data frames. Far-end frame loss refers to the count of frame loss associated with egress data frames. The lines represent the best case frame loss or the lowest frame loss, the worst case frame loss or the highest frame loss, and the average frame loss or the median of the highest and lowest frame losses. The frame loss is calculated by collecting the counter values applicable for ingress and egress service frames. The counters maintain a count of transmitted and received data frames between a pair of MEPs. The loss measurement statistics are retrieved as the output of the monitor ethernet loss-measurement command and are also stored at the initiator. The frame counts are stored at both the initiator and the receiver MEPs for later retrieval. The on-demand loss measurement statistics is collected for E-Line service only. There are two linear charts: Near-End-CIR and Far-End-CIR. For each interval, the graph plots three values: Average case, best case, and worst case frame loss. From the Loss End drop-down list, select **Near-end (CIR)** to display frame loss statistics associated with ingress data frames or **Far-end (CIR)** to display frame loss statistics associated with egress data frames. Mouse over the legends to view the lines corresponding to best-case, average, and worst-case frame loss statistics.

Delay Measurement

The Delay Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents frame delay in microseconds. The legends reference average one-way delay, best-case one-way delay, and worst-case one way delay for one-way delay measurement. The green line denotes the lowest one-way frame delay for the statistics displayed, the orange line denotes the highest one-way frame delay for the statistics displayed, and the blue line denotes the average one-way frame delay for the statistics displayed. The legends reference average two-way delay, best-case two-way delay, and worst-case two-way delay for two-way delay measurement. The green line denotes the lowest two-way frame delay for the statistics displayed, the orange line denotes the highest two-way frame delay for the statistics displayed, and the blue line denotes the average two-way

frame delay for the statistics displayed. From the Delay End drop-down box, select **1-Way** or **2-Way** to display the one-way or two-way frame delay measurement protocols respectively.

Delay Variation

The Delay Variation graph displays the difference between the consecutive frame delay values. The x-axis represents the time and the y-axis represents delay variation in microseconds. The line denotes the average one-way delay variation or the average one-way “frame jitter” for the statistics displayed for one-way frame delay measurement. The line denotes the average two-way delay variation or the average two-way “frame jitter” for the statistics displayed for two-way delay measurement.

By default, the total time duration is ten minutes. If the duration of statistics collection exceeds ten minutes, the graph scrolls and shows the data of latest ten minutes.

RELATED DOCUMENTATION

[Performance Management Overview | 1192](#)

[Monitoring Performance Management Statistics | 1194](#)

[Viewing Performance Management Statistics | 1198](#)

[Service Troubleshooting Overview | 1204](#)

[Performing a Configuration Audit | 1156](#)

Viewing Y.1731 Performance Monitoring Statistics for E-LAN Services

IN THIS SECTION

- [Connections | 1290](#)
- [Loss Measurement | 1291](#)
- [Delay Measurement | 1291](#)
- [Delay Variation | 1292](#)

The Y.1731 monitoring functionality is not enabled by default. You must explicitly start the PM collection mechanism by selecting **OAM > Y1731 > Start** from the Tasks pane after selecting the specified service on the View pane. The graphical representation of the retrieved statistical details for the service is displayed,

based on data availability. The data collected is retained after you stop the PM collection utility for future reference and correlation.

NOTE: The values and statuses of the parameters displayed in the graphs and tables of different widgets are refreshed, based on the polling interval configured on the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button on the Connectivity Services Director banner and selecting Preferences).

To view the performance monitoring statistics for the E-LAN service:

1. Select **Service View** from the View Selector.

The workspaces that are applicable to routing and tunneling services are displayed on the View pane.

2. From the Junos Space user interface, click the **Monitor** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed on the task pane.

3. From the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The Network Services tree is expanded and displayed on the View pane.

4. Click the plus sign (+) beside E-LAN Services to view the E-LAN service orders.

The E-LAN Services tree is expanded and displayed on the View pane.

5. Select the E-LAN service order for which you want to monitor performance statistics.

6. Select the **Y1731** tab.

The Service Performance page is displayed.

NOTE: You can view performance management statistics only after you start the collection of Y1731 performance monitoring (PM) statistics by selecting **OAM > Y1731 > Start** from the Tasks pane.

Connections

This monitor shows the status of connections between peer devices. In the tabular view, the row represents the source device and the columns denote the neighboring and destination devices. This monitor is applicable for E-Line and E-LAN services. A green up-arrow in the indicates that the adjoining device in the network path to the destination device is operationally up. A red down-arrow indicates that the device is down. For the device for which the connection status is displayed, a value of NA is displayed under its

own corresponding column to denote that it is not applicable. Click **Refresh** at the top of the monitor to update and display the contents of the table.

From the Time Interval drop-down box, select **1 Hour**, **8 Hours**, **1 Day**, **1 Week**, **1 Month**, **3 Months**, **6 Months**, **1 Year**, or **Custom** to specify the duration for which the data polled from devices needs to be displayed. If you select the **Custom** option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the **Time From** (Start time in the 24-hour time format of collection of data), and **Time To** (End time in the 24-hour time format of collection of data). Click **OK** to save the settings. Else, click **Cancel** to discard the configuration.

Loss Measurement

The Loss Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents the frame loss ratio. Near-end frame loss refers to the count of frame loss associated with ingress data frames. Far-end frame loss refers to the count of frame loss associated with egress data frames. The lines represent the best case frame loss or the lowest frame loss, the worst case frame loss or the highest frame loss, and the average frame loss or the median of the highest and lowest frame losses. The frame loss is calculated by collecting the counter values applicable for ingress and egress service frames. The counters maintain a count of transmitted and received data frames between a pair of MEPs. The loss measurement statistics are retrieved as the output of the monitor ethernet loss-measurement command and are also stored at the initiator. The frame counts are stored at both the initiator and the receiver MEPs for later retrieval. The on-demand loss measurement statistics is collected for E-Line service only. There are two linear charts: Near-End-CIR and Far-End-CIR. For each interval, the graph plots three values: Average case, best case, and worst case frame loss. From the Loss End drop-down list, select **Near-end (CIR)** to display frame loss statistics associated with ingress data frames or **Far-end (CIR)** to display frame loss statistics associated with egress data frames. Mouse over the legends to view the lines corresponding to best-case, average, and worst-case frame loss statistics.

Delay Measurement

The Delay Measurement graph displays a real-time linear plot of delay value with respect to the time. The x-axis represents the time and the y-axis represents frame delay in microseconds. The legends reference average one-way delay, best-case one-way delay, and worst-case one way delay for one-way delay measurement. The green line denotes the lowest one-way frame delay for the statistics displayed, the orange line denotes the highest one-way frame delay for the statistics displayed, and the blue line denotes the average one-way frame delay for the statistics displayed. The legends reference average two-way delay, best-case two-way delay, and worst-case two-way delay for two-way delay measurement. The green line denotes the lowest two-way frame delay for the statistics displayed, the orange line denotes the highest two-way frame delay for the statistics displayed, and the blue line denotes the average two-way frame delay for the statistics displayed. From the Delay End drop-down box, select **1-Way** or **2-Way** to display the one-way or two-way frame delay measurement protocols respectively.

Delay Variation

The Delay Variation graph displays the difference between the consecutive frame delay values. The x-axis represents the time and the y-axis represents delay variation in microseconds. The line denotes the average one-way delay variation or the average one-way “frame jitter” for the statistics displayed for one-way frame delay measurement. The line denotes the average two-way delay variation or the average two-way “frame jitter” for the statistics displayed for two-way delay measurement.

RELATED DOCUMENTATION

[Performance Management Overview | 1192](#)

[Monitoring Performance Management Statistics | 1194](#)

[Viewing Performance Management Statistics | 1198](#)

[Service Troubleshooting Overview | 1204](#)

[Performing a Configuration Audit | 1156](#)

Clearing Interface Statistics

By resetting interface statistics, you ensure that previous input and output errors and packet statistics do not interfere with the current efforts to diagnose a problem. After a graceful Routing Engine switchover, we recommend that you use the functionality to clear interface statistics to reset the cumulative values for local statistics on the new primary Routing Engine. Sometimes, you might require a baseline for interface statistics to be set for computation and reporting purposes. In such cases, before you set the baseline, you might need to clear or restart the accumulated statistics. The system implements the baseline by reading and storing the statistics at the time the baseline is set and then subtracting this baseline whenever baseline-relative statistics are retrieved

To clear interface statistics:

1. From the View selector, select **Service View**.

The functionalities that you can configure in this view are displayed on the View pane on the View pane.

2. Click the **Monitor** mode icon in the Service View on the Connectivity Services Director banner.

The workspaces that are applicable to this mode are displayed on the Tasks pane.

3. From the Service View pane, select the type of service for which you want to clear interface statistics.

The statistics for the service type are displayed on the middle pane of the main display area.

4. From the Tasks pane, which is displayed on the right, select **Tasks > Clear Interface Statistics**.

The Clear Interface Statistics option is displayed on the Tasks pane for E-Line, E-LAN, and IP services to delete all the interface statistics associated with the selected service.

A dialog box appears, prompting you to confirm the deletion. The names of the devices and respective interfaces configured on the devices are shown. In this dialog box, you can also choose to delete the interface statistics on the devices.

NOTE: You can clear interface statistics on managed endpoints only. For an E-Line service with unmanaged endpoints, only managed endpoints are shown in the endpoints table and corresponding statistics. To clear the statistics of unmanaged endpoints, you must clear the statistics using the Junos CLI on the corresponding devices.

5. Select the **Clear statistics from Devices** check box to clear the statistics from the devices. This operation is equivalent to the **clear interface statistics** command that you can run from the Junos OS CLI. If you select the **Clear statistics from Devices** check box, the statistics are cleared on the device for all the interfaces in the service, in addition to being removed from the Connectivity Services director database. If you do not select this check box, the interface statistics are reset only in the application database and not on the device.
6. Click **OK** to confirm; alternatively, click **Cancel** to discard this operation.

The interface statistics are cleared.

RELATED DOCUMENTATION

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

[Viewing Interface Status Details | 1297](#)

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

[Routing Table Overview | 1308](#)

Viewing MAC Table Details

The router learns unicast media access control (MAC) addresses to avoid flooding the packets to all the ports in a bridge domain. The router creates a source MAC entry in its source and destination MAC tables for each MAC address learned from packets received on ports that belong to the bridge domain. If the bridge domain receives a control protocol data unit (PDU) which does not have a corresponding protocol configured, then the control PDU is considered as an unknown multicast data packet and the packets are flooded across all the ports that are part of the same bridge domain. If the bridge domain has the protocol corresponding to the PDU configured, then the control PDU is considered as a control packet and is processed by the routing engine.

MAC table aging ensures that a device tracks only active nodes on the network and that it is able to flush out network nodes that are no longer available. To manage MAC entries more efficiently, you can configure an entry's aging time, which is the maximum time that an entry can remain in the MAC address table before it is deleted because it has reached its maximum age.

To view the learned MAC address information for a device associated with a particular service:

1. From the View selector, select **Service View**.

The functionalities that you can configure in this view are displayed on the View pane.

2. Click the **Monitor** mode icon in the Service View of the Connectivity Services Director banner.

The workspaces that are applicable to this mode are displayed on the Tasks pane.

3. From the Service View pane, select the type of service for which you want to view interface statistics.

The service statistical details are displayed in the middle pane.

4. From the Tasks pane, which is displayed on the right, select **Tasks > Show MAC Table**.

The MAC Table dialog box is displayed. The name of the service is displayed in the Service Name field.

5. From the Devices drop-down list, select the device for which you want to view the MAC table statistical details.

The following information is displayed in the lower pane of the dialog box in a tabular grid.

- MAC address—MAC address or addresses learned on a logical interface.
- Interface—Name of the logical interface
- Packets—Number of processed packets corresponding to the MAC address
- Bytes—Number of processed bytes corresponding to the MAC address
- Expiring—Aging time after which the MAC address expires and is not retained in the MAC table

6. Click **Close** after you complete viewing the details.

You are returned to the main or home page in Monitor Mode of Service View, which is the Service Summary tab.

Viewing Interface Statistics

Packets that need to be forwarded to the adjacent network element or a neighboring device along a routing path might be dropped by a router owing to several factors. Some of the causes for such a loss of traffic or a block in transmission of data packets include overloaded system conditions, profiles and policies that restrict the bandwidth or priority of traffic, network outages, or disruption with physical cable faults. You can use a number of **show** commands to determine and analyze the statistical counters and metrics related to any traffic loss and take an appropriate corrective measure. The fields displayed in the View Interface Statistics dialog box help in diagnosing and debugging network performance and traffic-handling efficiency problems.

To view interface statistical details:

1. From the View selector, select **Service View**.

The functionalities that you can configure in this view are displayed on the View pane.

2. Click the **Monitor** mode icon in the Service View of the Connectivity Services Director banner.

The workspaces that are applicable to this mode are displayed on the Tasks pane.

3. From the Service View pane, select the type of service for which you want to view interface statistics.

The service statistical details are displayed in the middle pane.

4. From the Tasks pane, which is displayed on the right, select **Tasks > Show Interface Statistics**.

The End Point Details dialog box is displayed for the selected service.

NOTE: The Interface Traffic Statistics dialog box displays only the managed endpoints of the E-Line service. Unmanaged device endpoints are not shown in the grid, and therefore the charts are also not applicable for unmanaged endpoints of the E-Line service.

A graphical view and a tabular view of interface statistics are displayed. You can view the interface statuses, such as errors and the operational conditions of the interfaces, that enables you in analyzing, troubleshooting, and rectifying problems with dropped packets or untransmitted bytes. Some of the causes for such a loss of traffic or a block in transmission of data packets include overloaded system conditions, profiles and policies that restrict the bandwidth or priority of traffic, network outages, or disruption with physical cable faults. This operation is equivalent to the `show interface statistics` command that you can run from the Junos OS CLI interface. You can search for specific devices or interfaces by entering a search item and clicking the Search icon. A line graph is displayed with the input packets and errors, and output packets and errors shown on the vertical axis and the time shown on the horizontal axis. The following color-coded legends reference the line graphs:

- Packets In (Orange)—Number of packets received on the interface
- Packets Out (Green)—Number of packets sent from the interface
- Errors In (Blue)—Number of inbound errors received on the interface
- Errors Out (Purple)—Number of outbound errors transmitted from the interface

The Interface Details table displays all the UNI parts of the service. Also, the physical interface for the logical interface participating in the service is displayed.

- Device Name—Name of the device
- Interface—Name of the interface
- Interface Type—Whether the interface is physical or logical
- Encapsulation—Physical or logical encapsulation configured on the interface.
- Operational Status—Operational status of the physical interface: Up, Down.
- Admin Status—Administrative state of the interface: Enabled or Disabled.
- MAC Address—MAC address of the physical interface.
- Input Packets—Number of packets received on the interface.
- Output Packets—Number of packets sent from the interface.
- Last Poll Time—Date and time at which the statistical detail was obtained by polling and retrieving from the device for the specified interface.

The Packet Counter tab on the right side of the page displays the following fields in a table. It is applicable for physical interfaces only. The values displayed are in rates of packets per second.

- Input Unicasts—Number of input unicast packets for the physical interface
- Output Unicasts—Number of output unicast packets for the physical interface
- Input Multicast—Number of input multicast packets for the physical interface
- Output Multicast—Number of output multicast packets for the physical interface
- Input Broadcast—Number of input broadcast packets for the physical interface
- Output Broadcast—Number of output broadcast packets for the physical interface

The Error Counter tab on the right side of the page displays the following fields in a table. It is available for physical interfaces only. The values displayed are in rates of packets per second.

- Input Errors—Number of errors packets received on the physical interface
- Output Drops—Number of outgoing packets that are dropped by the physical interface
- Input Framing Errors—Number of packets with framing errors that are received on the physical interface
- Input Drops—Number of incoming packets that are dropped by the physical interface

- Input Discards—Number of incoming packets discarded by the physical interface
- Output Errors—Number of error packets sent out from the physical interface

RELATED DOCUMENTATION

[Clearing Interface Statistics | 1292](#)

[Viewing Interface Status Details | 1297](#)

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

[Routing Table Overview | 1308](#)

Viewing Interface Status Details

You can use the monitoring functionality to view interface status or to monitor interface bandwidth utilization and traffic statistics on the device. When you view the interface status for a particular service, all the interfaces configured on the different devices associated the service are retrieved and displayed. The operational status of the interface, the encapsulation type configured for the interface, and the VLAN ID specified for the interface enable you to determine whether any changes are needed to the interface settings to correct discrepancies with services and traffic forwarding.

To view interface status details:

1. From the View selector, select **Service View**.
The functionalities that you can configure in this view are displayed on the View pane.
2. Click the **Monitor** mode icon in the Service View of the Connectivity Services Director banner.
The workspaces that are applicable to this mode are displayed on the Tasks pane.
3. From the Service View pane, select the type of service for which you want to view interface status information.
The service statistical details are displayed in the middle pane.
4. From the Tasks pane, which is displayed on the right, select **Tasks > Show Interface Status**.
A graphical view and a tabular view of interface configuration details are displayed.

TIP: You can also open the Interface Traffic Status dialog box by selecting **Troubleshoot > Service Audit** from the Tasks pane for a specific service.

NOTE: Viewing interface information is valid on an E-Line service with unmanaged endpoints. However, the task results are shown only for the managed endpoint. Unmanaged endpoints are not listed in the table.

This operation is equivalent to the **show interface** command that you can run from the Junos OS CLI interface. The following interface information is displayed in a tabular form:

- Device Name—Name of the Device
- Interface—Name of the UNI interface
- Interface Status—Operational status of the interface: Up, Down
- Physical Encapsulation—Physical encapsulation configured on the Interface
- Logical Encapsulation—Logical encapsulation configured on the interface; else it is not applicable
- Vlan Id—VLAN ID of the logical unit number of the interface; else it is not applicable
- Inner Vlan Id—Inner VLAN or customer VLAN tag of the interface; else it is not applicable
- Port Mode—Operating mode for an interface can be one of the following:
 - access—In this mode, the interface can be in a single VLAN only. Access interfaces typically connect to single network devices such as PCs, printers, IP telephones, and IP cameras.
 - tagged-access—In this mode, the interface can accept tagged packets from one access device. Tagged-access interfaces typically connect to servers running Virtual machines using VEPA technology.
 - trunk—In this mode, the interface can be in multiple VLANs and accept tagged packets from multiple devices. Trunk interfaces typically connect to other switches and to routers on the LAN.
 - NA—Not applicable

RELATED DOCUMENTATION

[Clearing Interface Statistics | 1292](#)

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

MPLS Connectivity Verification and Troubleshooting Methods

You can use the MPLS ping application to examine the network reachability and identify any broken links for diagnostic purposes. Before using the ping MPLS feature, make sure that the receiving interface on the VPN or LSP remote endpoint has MPLS enabled, and that the loopback interface on the outbound node is configured as 127.0.0.1. The source address for MPLS probes must be a valid address on the device. When you use the ping MPLS feature from a J Series device operating as the inbound (ingress) node at the entry point of an LSP or VPN, the router sends probe packets into the LSP or VPN. Based on how the LSP or VPN outbound (egress) node at the remote endpoint of the connection replies to the probes, you can determine the connectivity of the LSP or VPN. Each probe is an echo request sent to the LSP or VPN exit point as an MPLS packet with a UDP payload. If the outbound node receives the echo request, it checks the contents of the probe and returns a value in the UDP payload of the response packet. If the device receives the response packet, it reports a successful ping response. Responses that take longer than 2 seconds are identified as failed probes.

In IP networks, the ping and traceroute commands enable you to verify network connectivity and find broken links or loops. In MPLS-enabled networks, you can use the **ping** command to determine whether IP connectivity exists to a destination even when the ping packets must traverse multiple LSPs. You can use the **traceroute** command to determine the labels that data packets use when traversing LSPs to the destination. In an MPLS-enabled network, however, you cannot use these IP commands to determine MPLS connectivity to a destination. You can use the MPLS ping and trace features to detect data plane failures in LSPs. Specific **mpls ping** and **trace mpls** commands enable you to target different types of MPLS applications and network topologies. The various **ping mpls** and **trace mpls** commands send UDP packets, known as MPLS echo requests, to the egress LSR of MPLS packets in a given FEC. Each echo request is forwarded along the same data path as the MPLS packets in that FEC. The echo request packets use a destination address in the 127.0.0.0/8 range and port 3503. The default address is 127.0.0.1. This address range prevents IP from forwarding the packet, so that the echo request must follow the MPLS data path. This behavior is different from that of the IP **ping** and **traceroute** commands, which send ICMP packets to the actual destination. Each MPLS echo request packet contains information about the FEC stack that is being validated. LSRs that receive an MPLS echo request respond with MPLS echo reply packets. (Even when MPLS is not enabled on that router, echo reply packets are sent by routers that receive an echo request packet. This situation is a transient condition when the router is receiving labeled packets. A return code in the echo replies indicates to the sending router that no label mapping exists on the receiving router.)

The **ping mpls** commands perform a basic connectivity check. When the echo request exits the tunnel at the egress LSR, the LSR sends the packet to the control plane. The egress router validates the FEC stack to determine whether that LSR is the actual egress for the FEC. The egress router sends an echo reply packet back to the source address of the echo request packet. The egress router can send the packet back

by means of either the IP path or the MPLS path. The **trace mpls** commands isolate faults in the LSP. For these commands, successive echo request packets are sent along the path. The first packet has a TTL of one; the TTL value is incremented by one for each successive packet. The first packet therefore reaches only the next hop on the path; the second packet reaches the next router after that. Echo request packets are sent until either an echo reply is received from the egress router for the FEC or a TTL of 32 is reached.

When a TTL expires on an LSR, that LSR sends an echo reply packet back to the source. For transit routers, the echo reply indicates that downstream mapping exists for the FEC, meaning that the packet would have been forwarded if the TTL had not expired. The egress router sends an echo reply packet verifying that it is the egress. Although you cannot send IPv6 UDP packets for MPLS ping, you can use the **ping mpls l3vpn** command with an IPv6 prefix to investigate IPv6 VPNs.

For IP services, the **ping mpls l3vpn** command is used to examine the operability of a MPLS Layer 3 VPN connection. For VPLS routing instances, the **ping vpls instance** command is used to examine the reachability of a VPLS instance. The **ping vpls instance** command uses a difference command structure and operates in a different fashion than the **ping mpls** command used for VPNs and Layer 2 circuits. For E-Line services, the pseudowire ping mechanism is used to verify the network accessibility and identify any problems in the link.

RELATED DOCUMENTATION

[Clearing Interface Statistics | 1292](#)

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

[Viewing Interface Status Details | 1297](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

[Routing Table Overview | 1308](#)

Using MPLS Ping

Use the MPLS ping functionality to diagnose the state of label-switched paths (LSPs), Layer 2 and Layer 3 virtual private networks (VPNs), and Layer 2 circuits. You can ping an MPLS endpoint using various options. You can send variations of ICMP echo request packets to the specified MPLS endpoint.

When you use the ping MPLS task from a Junos OS operating as the inbound (ingress) node at the entry point of an LSP or VPN, the routing platform sends probe packets into the LSP or VPN. Based on how the

LSP or VPN outbound (egress) node at the remote endpoint of the connection replies to the probes, you can determine the connectivity of the LSP or VPN.

Each probe is an echo request sent to the LSP or VPN exit point as an MPLS packet with a UDP payload. If the outbound node receives the echo request, it checks the contents of the probe and returns a value in the UDP payload of the response packet. If the Junos OS receives the response packet, it reports a successful ping response.

Responses that take longer than 2 seconds are identified as failed probes.

[Table 165 on page 1301](#) lists the ping MPLS tasks, summarizes their functions, and identifies corresponding CLI **show** commands you can enter in the CLI interface of a device.

Table 165: Ping MPLS Tasks Summary and the Corresponding CLI show Commands

Ping MPLS Task	Corresponding CLI Command	Function	Additional Information
Ping RSVP-signaled LSP	ping mpls rsvp	Checks the operability of an LSP that has been set up by the Resource Reservation Protocol (RSVP). The Junos OS pings a particular LSP using the configured LSP name.	When an RSVP-signaled LSP has several paths, the Junos OS sends the ping requests on the path that is currently active.
Ping LDP-signaled LSP	ping mpls ldp	Checks the operability of an LSP that has been set up by the Label Distribution Protocol (LDP). The Junos OS pings a particular LSP using the forwarding equivalence class (FEC) prefix and length.	When an LDP-signaled LSP has several gateways, the Junos OS sends the ping requests through the first gateway. Ping requests sent to LDP-signaled LSPs use only the primary routing instance.
Ping LSP to Layer 3 VPN prefix	ping mpls l3vpn	Checks the operability of the connections related to a Layer 3 VPN. The Junos OS tests whether a prefix is present in a provider edge (PE) router's VPN routing and forwarding (VRF) table, by means of a Layer 3 VPN destination prefix.	The Junos OS does not test the connection between a PE router and a customer edge (CE) router.

Table 165: Ping MPLS Tasks Summary and the Corresponding CLI show Commands (*continued*)

Ping MPLS Task	Corresponding CLI Command	Function	Additional Information
Ping LSP for a Layer 2 VPN connection by interface	ping mpls l2vpn interface	Checks the operability of the connections related to a Layer 2 VPN. The Junos OS directs outgoing request probes out the specified interface.	For information about interface names, see the CLI Explorer .
Ping LSP for a Layer 2 VPN connection by instance	ping mpls l2vpn instance	Checks the operability of the connections related to a Layer 2 VPN. The Junos OS pings on a combination of the Layer 2 VPN routing instance name, the local site identifier, and the remote site identifier, to test the integrity of the Layer 2 VPN circuit (specified by the identifiers) between the inbound and outbound PE routers.	
Ping LSP to a Layer 2 circuit remote site by interface	ping mpls l2circuit interface	Checks the operability of the Layer 2 circuit connections. The Junos OS directs outgoing request probes out the specified interface.	
Ping LSP to a Layer 2 circuit remote site by VCI	ping mpls l2circuit virtual-circuit	Checks the operability of the Layer 2 circuit connections. The Junos OS pings on a combination of the IPv4 prefix and the virtual circuit identifier on the outbound PE router, testing the integrity of the Layer 2 circuit between the inbound and outbound PE routers.	
Ping end point of LSP	ping mpls lsp-end-point	Checks the operability of an LSP endpoint. The Junos OS pings an LSP endpoint using either an LDP FEC prefix or an RSVP LSP endpoint address.	

RELATED DOCUMENTATION

Clearing Interface Statistics	1292
Viewing MAC Table Details	1294
Viewing Interface Statistics	1295
Viewing Interface Status Details	1297
MPLS Connectivity Verification and Troubleshooting Methods	1299
Monitoring Network Reachability by Using the MPLS Ping Capability	1304
Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability	1306
Routing Table Overview	1308

Pinging VPNs, VPLS, and Layer 2 Circuits

For testing purposes, you can ping Layer 2 VPNs, Layer 3 VPNs, and Layer 2 circuits by using the **ping mpls** command. The **ping mpls** command helps to verify that a VPN or circuit has been enabled and tests the integrity of the VPN or Layer 2 circuit connection between the PE routers. It does not test the connection between a PE router and a CE router. To ping a VPLS routing instance, you issue a **ping vpls instance** command.

You issue the **ping mpls** command from the ingress PE router of the VPN or Layer 2 circuit to the egress PE router of the same VPN or Layer 2 circuit. When you execute the **ping mpls** command, echo requests are sent as MPLS packets.

The payload is a User Datagram Protocol (UDP) packet forwarded to the address **127.0.0.1**. The contents of this packet are defined in RFC 4379, *Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures*. The label and interface information for building and sending this information as an MPLS packet is the same as for standard VPN traffic, but the time-to-live (TTL) of the innermost label is set to 1.

When the echo request arrives at the egress PE router, the contents of the packet are checked, and then a reply that contains the correct return is sent by means of UDP. The PE router sending the echo request waits to receive an echo reply after a timeout of 2 seconds (you cannot configure this value).

You must configure MPLS at the **[edit protocols mpls]** hierarchy level on the egress PE router (the router receiving the MPLS echo packets) to be able to ping the VPN or Layer 2 circuit. You must also configure the address **127.0.0.1/32** on the egress PE router's **lo0** interface. If this is not configured, the egress PE router does not have this forwarding entry and therefore simply drops the incoming MPLS pings.

The **ping mpls** command has the following limitations:

- You cannot ping an IPv6 destination prefix.
- You cannot ping a VPN or Layer 2 circuit from a router that is attempting a graceful restart.
- You cannot ping a VPN or Layer 2 circuit from a logical system.

You can also determine whether an LSP linking two PE routers in a VPN is up by pinging the end point address of the LSP. The command you use to ping an MPLS LSP end point is **ping mpls lsp-end-point address**. This command tells you what type of LSP (RSVP or LDP) terminates at the address specified and whether that LSP is up or down.

RELATED DOCUMENTATION

[Clearing Interface Statistics | 1292](#)

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

[Viewing Interface Status Details | 1297](#)

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

[Routing Table Overview | 1308](#)

Monitoring Network Reachability by Using the MPLS Ping Capability

In IP networks, you can use the **ping** and **traceroute** commands to verify network connectivity and find broken links or loops. In an MPLS-enabled network, you can use the **mpls ping** and **trace mpls** commands to detect plane failures in different types of MPLS applications and network topologies.

To perform an MPLS ping operation:

1. From the View selector, select **Service View**.
The functionalities that you can configure in this view are displayed on the View pane in the GUI window.
2. Click the **Monitor** mode icon in the Service View on the Connectivity Services Director banner.
The workspaces that are applicable to this mode are displayed in the GUI window.
3. On the Service View pane, on the left, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Connectivity to view services based on protocols.
 - Expand the **E-Line Services** tree to select an E-Line service.

- Expand the **E-LAN Services** tree to select an E-LAN service.

5. From the Tasks pane, select **MPLS Ping**.

The MPLS Ping Service Type - Service Name window appears.

NOTE: A warning message is displayed in the window stating that the MPLS echo request to the device might be timed out if the response is delayed from the device.

NOTE: MPLS ping is supported only from managed endpoints to unmanaged endpoints. Therefore, unmanaged endpoints are not listed in the Source column.

For a BGP-based E-Line service, with one endpoint as an unmanaged device, the MPLS ping utility is not supported because the remote site ID of the unmanaged device is not available as part of the service configuration. The remote site ID is required for MPLS ping from a managed to an unmanaged endpoint.

6. In the Endpoint Device section, do the following:

The source device sends an MPLS echo request packet to the specified IP or IPv6 address or, alternatively, sends MPLS echo packets to the egress node in a point-to-multipoint LSP. The MPLS echo request packets and echo reply packets created by this command use the LDP IPv4 LSP sub-TLV described in RFC 4379—Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures (February 2006).

- From the Source Device list, select the source device, whose IP address is to be used as the packet source address.
- From the Destination Device list, select the target endpoint, whose IP address is used as the target IP address for MPLS ping packets or echo requests.

7. On the Advance Options list, do the following:

- In the Ping count (packets) field, enter the number of packets to send to the destination address, in the range 0–4294967295. The default value is 5 and 0 (zero) means ping forever.
- In the Ping size (bytes) field, specify the number of bytes comprising the MPLS packet, including the header, in the range 0–64000. The default value is 100 bytes.
- In the Forwarding Class field, specify the value of the forwarding class for the MPLS ping packets.
- In the Sweep field, configure the payload size, which enables you to vary the sizes of the echo packets being sent. This capability is useful for determining the minimum sizes of the MTUs configured on the nodes along the path to the destination address. This reduces packet fragmentation,

which contributes to performance problems. The default is not to sweep; all packets are of the same size.

e. From the Reply Mode field, select the reply mode for the echo request packet:

- **IP-UDP**—Specifies that the echo request packet is an IPv4 UDP packet
- **Application Level Control Channel**—Specifies that the echo request packet is replied using the application-level control channel connection.

8. From the Format list, select **XML** to display the result or the response of the MPLS ping operation in XML format. Alternatively, select **ASCII** to display the output in the format in which it is displayed on the CLI. The Junos XML API is an XML representation of Junos configuration statements and operational mode commands. Junos XML configuration tag elements are the contents to which the Junos XML protocol operations apply. Junos XML operational tag elements are equivalent in function to operational mode commands on the CLI, which administrators use to retrieve status information for a device.

9. Click **Ping** to start the ping operation and to send the MPLS echo requests from the source to the destination device.

The results of the ping operation are displayed in the Response Console pane at the bottom of the MPLS Ping Service Type - Service Name window.

RELATED DOCUMENTATION

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability

In IP networks, you can use the **ping** and **traceroute** commands to verify network connectivity and find broken links or loops. In an MPLS-enabled network, you can use the **mpls ping** and **trace mpls** commands to detect plane failures in different types of MPLS applications and network topologies.

1. From the View selector, select Service View.

The functionalities that you can configure in this view are displayed on the View pane.

2. Click the **Monitor** mode icon in the Service View of the Connectivity Services Director banner.

The workspaces that are applicable to this mode are displayed on the Tasks pane.

3. Click the plus sign (+) beside Connectivity to view services based on protocols.
4. Expand the **IP Services** tree to select an IP service.
5. From the Tasks pane, select **MPLS Ping**.

The MPLS Ping Service Type - Service Name window appears.

6. In the Endpoint Device section, do the following:

The source device sends an MPLS echo request packet to the specified IP or IPv6 address or, alternatively, sends MPLS echo packets to the egress node in a point-to-multipoint LSP. The MPLS echo request packets and echo reply packets created by this command use the LDP IPv4 LSP sub-TLV described in RFC 4379—Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures (February 2006).

- a. From the Source Device list, select the source device, whose IP address is to be used as the packet source address.
- b. From the Destination Device list, select the target endpoint, whose IP address is used as the target IP address for MPLS ping packets or echo requests.

7. On the Advance Options list, do the following:

- a. In the Ping count (packets) field, enter the number of packets to send to the destination address, in the range 0–4294967295. The default value is 5 and 0 (zero) means ping forever.
- b. In the Ping size (bytes) field, specify the number of bytes comprising the MPLS packet, including the header, in the range 0–64000. The default value is 100 bytes.
- c. In the Forwarding Class field, specify the value of the forwarding class for the MPLS ping packets.
- d. In the Sweep field, configure the payload size, which enables you to vary the sizes of the echo packets being sent. This capability is useful for determining the minimum sizes of the MTUs configured on the nodes along the path to the destination address. This reduces packet fragmentation, which contributes to performance problems. The default is not to sweep; all packets are of the same size.
- e. From the Reply Mode field, select the reply mode for the echo request packet:
 - **IP-UDP**—Specifies that the echo request packet is an IPv4 UDP packet
 - **Application Level Control Channel**—Specifies that the echo request packet is replied using the application-level control channel connection.

8. From the Format list, select **XML** to display the result or the response of the MPLS ping operation in XML format. Alternatively, select **ASCII** to display the output in the format in which it is displayed on the CLI. The Junos XML API is an XML representation of Junos configuration statements and operational mode commands. Junos XML configuration tag elements are the contents to which the Junos XML protocol operations apply. Junos XML operational tag elements are equivalent in function to operational mode commands on the CLI, which administrators use to retrieve status information for a device.
9. Click **Ping** to start the ping operation and to send the MPLS echo requests from the source to the destination device.

The results of the ping operation are displayed in the Response Console pane at the bottom of the MPLS Ping Service Type - Service Name window.

RELATED DOCUMENTATION

[Clearing Interface Statistics | 1292](#)

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

[Viewing Interface Status Details | 1297](#)

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

Routing Table Overview

Typically, routers are attached to multiple networks and are responsible for directing traffic across these networks. Each router maintains a routing table, which is a list of known networks and directions on how to reach them. While processing an incoming packet on a security device, the router performs a routing table lookup to find the appropriate interface that leads to the destination address.

Each entry in a routing table—called a *route entry* or *route*—is identified by the destination network to which traffic can be forwarded. The destination network, in the form of an IP address and netmask, can be an IP network, subnetwork, supernet, or a host. Routing table entries can originate from the following sources:

- Directly connected networks (the destination network is the IP address that you assign to an interface in Route mode)
- Dynamic routing protocols, such as OSPF, BGP, or RIP
- Routes that are imported from other routers or virtual routers
- Statically configured routes

You can configure three types of static routes: destination-based, source-based, and source-interface-based routing. For each type of static route, you configure the following information:

NOTE: Source-interface-based routing is supported in ScreenOS 5.1 and later.

- The interface on the security device on which traffic for the destination network is forwarded.
- The next-hop, which can be either another virtual router on the security device or a gateway IP address (usually a router address).
- The protocol from which the route is derived.

RELATED DOCUMENTATION

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

Viewing Routing Table Details

The Routing Table window enables you view the routing table information for the selected virtual routing instance. For IP services, you can determine which LSPs or tunnels are being used by looking at the routing tables.

To view extensive information about the active entries in the routing tables for a device associated with a particular service:

1. From the View selector, select Service View. The functionalities that you can configure in this view are displayed.
2. Click the Monitor mode icon in the Service View of the Connectivity Services Director banner. The workspaces that are applicable to this mode are displayed.

3. From the Service View pane, select the IP service for which you want to view interface statistics. The service statistical details are displayed in the middle pane.
4. From the task pane, which is displayed on the rightmost pane, select Tasks > Routing Table. The Routing Table window is displayed. The left pane of the window displays the names of the devices that are associated with the particular service.
5. From the Device Name pane, select the device for which you want to view the routing table information. The following information is displayed in the right pane of the window in a tabular grid.

Table 166: Routing Table Window Field Descriptions

Name	Description
Service Name	Name of the service for which routing table statistics are displayed.
Number of Destinations	Number of destinations for which routes are present in the routing table.
Number of Routes	Total number of routes in the routing table.
Active Routes	Number of routes that are active.
Hidden Routes	Number of routes that are not used because of routing policy.
Hold-down Routes	Number of routes that are in the hold-down state before being declared inactive.
Destination Prefix	<p>Route destination (for example:10.0.0.1/24). Sometimes the route information is presented in another format, such as:</p> <ul style="list-style-type: none"> ● MPLS-label (for example, 80001). ● interface-name (for example, ge-1/0/2). ● neighbor-address:control-word-status:encapsulation type:vc-id :source (Layer 2 circuit only. For example, 10.1.1.195:NoCtrlWord:1:1:Local/96): <ul style="list-style-type: none"> ● neighbor-address—Address of the neighbor. ● control-word-status—Whether the use of the control word has been negotiated for this virtual circuit: NoCtrlWord or CtrlWord. ● encapsulation type—Type of encapsulation, represented by a number: (1) Frame Relay DLCI, (2) ATM AAL5 VCC transport, (3) ATM transparent cell transport, (4) Ethernet, (5) VLAN Ethernet, (6) HDLC, (7) PPP, (8) ATM VCC cell transport, (10) ATM VPC cell transport. ● vc-id—Virtual circuit identifier. ● source—Source of the advertisement: Local or Remote.
State	State of the route.

Table 166: Routing Table Window Field Descriptions (*continued*)

Name	Description
Protocol	Name of the protocol from which the route was learned. For example, OSPF , RSVP , and Static .
Protocol Preference	Preferred protocol for this routing instance. Junos OS uses this preference to choose which routes become active in the routing table.
Age	Displays how long since the route was learned.
BGP Metric	Cost value of the indicated route. For routes within an AS, the cost is determined by the IGP and the individual protocol metrics. For external routes, destinations, or routing domains, the cost is determined by a preference value.
BGP Local Preference	A metric used by BGP sessions to indicate the degree of preference for an external route. The route with the highest local preference value is preferred.
AS Path	<p>AS path through which the route was learned. The letters at the end of the AS path indicate the path origin, providing an indication of the state of the route at the point at which the AS path originated:</p> <ul style="list-style-type: none"> • I—IGP. • E—EGP. • Recorded—The AS path is recorded by the sample process (sampled). • ?—Incomplete; typically, the AS path was aggregated. <p>When AS path numbers are included in the route, the format is as follows:</p> <ul style="list-style-type: none"> • []—Brackets enclose the local AS number associated with the AS path if more than one AS number is configured on the routing device, or if AS path prepending is configured. • { }—Braces enclose AS sets, which are groups of AS numbers in which the order does not matter. A set commonly results from route aggregation. The numbers in each AS set are displayed in ascending order. • ()—Parentheses enclose a confederation. • ([])—Parentheses and brackets enclose a confederation set.
Next Hop Type	<p>Next hop to the destination. An angle bracket (>) indicates that the route is the selected route.</p> <p>If the destination is Discard, traffic is dropped.</p>
Local Interface	The local interface used to reach the next hop.
Next Hop	Next-hop address of the interface.

Table 166: Routing Table Window Field Descriptions *(continued)*

Name	Description
MPLS Label	MPLS label and operation occurring at the next hop. The operation can be pop (where a label is removed from the top of the stack), push (where another label is added to the label stack), or swap (where a label is replaced by another label).

6. Click Close after you complete viewing the details. You are returned to the main or home page in Monitor Mode of Service View, which is the Service Summary tab.

14

PART

Working in Fault Mode

About Fault Mode | **1314**

Using Fault Mode | **1317**

Fault Reference | **1327**

About Fault Mode

IN THIS CHAPTER

- [About Fault Mode in All Views of Connectivity Services Director | 1314](#)
- [Understanding the Tasks Pane in Fault Mode | 1315](#)

About Fault Mode in All Views of Connectivity Services Director

Fault mode in Connectivity Services Director provides you visibility into your network status and performance by displaying alarms and events generated on devices and configured services on devices. Connectivity Services Director monitors its managed devices and maintains the information it collects from the devices in a database. Fault mode displays this information in easy-to-understand graphs and in tables that you can sort and filter, allowing you to quickly visualize the state of your network, spot trends developing over time, and find important details. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director.

Connectivity Services Director correlates traps, describing a condition, into an alarm . For example, multiple power supply traps coming from a device are correlated into a single power supply alarm for the device. The main purpose and benefit of monitoring functionalities is to allow the operators to quickly monitor the health (working condition), operating efficiency, traffic-handling capacity, and performance status of the managed devices and configured services such as E-Line, E-LAN, and IP.

The monitoring mechanism is tool that enables the operator to understand the network health and status by drilling down to all the components of a device. The device status is marked as green, red, orange, or blue, based on the health, availability, performance and other important key performance indicators.

- Red denotes an emergency condition, which is a system panic or other conditions that cause the routing platform to stop functioning. It also indicates that the device is offline or turned down.
- Orange denotes an alert, which can be conditions that must be corrected immediately, such as a corrupted system database.

- Yellow indicates a notice, which signifies conditions that are not error conditions but are of interest or might warrant special handling. It can also include a severity level equivalent to informational or debugging messages.
- Blue denotes an informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

RELATED DOCUMENTATION

[About Build Mode in Service View of Connectivity Services Director | 44](#)

[About Deploy Mode in Service View of Connectivity Services Director | 45](#)

[About Monitor Mode in Service View of Connectivity Services Director | 48](#)

Understanding the Tasks Pane in Fault Mode

The Tasks pane in Fault mode provides you with a set of tools for effectively managing alarms on your system.

From the Tasks pane, you can:

- Filter known alarms to locate a specific alarm or error condition by clicking Search Alarms. Use this task to isolate alarms that occurred during a known time-frame or that have annotations associated with them. Although each of the Fault mode monitors can sort the alarms, Search Alarms enable you to submit multiple search and sort arguments as part of your search query.

In addition, Connectivity Services Director enables you to group the tasks that you perform frequently and create a list of key tasks. You can add any task from the Tasks pane to the Key Tasks list by selecting a task and clicking the plus (+) sign that appears adjacent to the task. For some modes, you can see that Connectivity Services Director has predefined some key tasks for you. You can modify this set of tasks to suit your requirements. This feature is available in Task pane irrespective of your current mode, scope, or view.

RELATED DOCUMENTATION

[Understanding the Service View Tasks Pane in Build Mode | 35](#)

[Understanding the Service View Tasks Pane in Deploy Mode | 38](#)

[Understanding the Service View Tasks Pane in Monitor Mode | 40](#)

[About Build Mode in Service View of Connectivity Services Director | 44](#)

About Deploy Mode in Service View of Connectivity Services Director | 45

About Fault Mode in All Views of Connectivity Services Director | 47

About Monitor Mode in Service View of Connectivity Services Director | 48

Using Fault Mode

IN THIS CHAPTER

- [Using Fault Management Monitors | 1317](#)
- [Alarm Severities and States Overview | 1321](#)
- [Events and Alarms Overview | 1322](#)
- [Customizing Alarms | 1322](#)
- [Changing Alarm State | 1323](#)
- [Searching Alarms | 1324](#)

Using Fault Management Monitors

IN THIS SECTION

- [What Are Events and Alarms? | 1318](#)
- [Alarm Severity | 1318](#)
- [Alarm Classification | 1318](#)
- [Alarm State | 1320](#)
- [Alarm Notifications | 1320](#)

The Fault mode shows you information about the health of your network and changing conditions of your equipment. Use Fault mode to find problems with equipment, pinpoint security attacks, or to analyze trends and categories of errors.

This topic describes:

What Are Events and Alarms?

Activity on a network device consists of a series of *events*. A software component on the network device, called an *entity*, is responsible for running the Simple Network Management Protocol (SNMP) to log and monitor these events. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a *trap* to Connectivity Services Director. Connectivity Services Director correlates traps, describing a condition, into an *alarm*. For example, multiple power supply traps coming from a device are correlated into a single power supply alarm for the device.

There are many types of alarms. An alarm can be as routine as when the device changes state or as serious as when a power supply has failed. When an alarm is sent, or *raised*, it stays raised until the triggering condition is resolved or *cleared*. The system can clear the alarm when the state changes again or an administrator can clear it manually, which indicates that the condition is now resolved.

SNMP also plays another role in Connectivity Services Director. Enabling devices for SNMP with the appropriate read-only V1/V2/V3 credentials, can speed up device discovery.

Alarm Severity

Alarms are ranked by their impact to the network. The following list shows the ranking of alarms in Connectivity Services Director from alarms that have the most impact to alarms that have the least impact on the network. It also shows the color scheme associated with each level of severity that is reflected in related graphs.

Critical (Red)—A critical condition exists; immediate action is necessary.

Major (Orange)—A major error has occurred; escalate or notify as necessary.

Minor (Yellow)—A minor error has occurred; notify or monitor the condition.

Info (Blue)—An informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

Administrators can override the default severity of an alarm and set the severity to match their inhouse guidelines. Changing the severity level for an alarm is done on the Fault tab of System Preferences.

Alarm Classification

Connectivity Services Director organizes alarms into categories so you can view trends in the types of errors occurring on a network. These categories, shown in [Table 167 on page 1319](#) are derived from the SNMP Management Information Base (MIB) that is the information database or module containing the trap information for the event.

Table 167: Connectivity Services Director Alarm Classifications

Category	Description
BFD	Indicates alarms for Bidirectional Forwarding Detection sessions. These alarms are generated from routing devices.
BGP	Indicates alarms for BGP4.
Chassis	Indicates alarms for device hardware, in this case, routers.
Cluster/Modo	Indicates alarms about wireless network clusters and mobility domains.
Configuration	Indicates alarms for configuration management.
Controllers	Indicate device alarms.
CoS	Indicates class of service alarms.
DHCP	Indicates local server DHCP alarms.
DOM	Indicates Digital Optical Monitoring alarms that are generated from optical interfaces.
General	Indicates alarms that are common to all network devices, such as link up/down or authentication.
L2ALD	Indicates MAC address alarms generated from the Layer 2 Address Learning Daemon (L2ALD).
L2CP	Indicates alarms generated by Layer 2 Control Protocol features.
MACFDB	Indicates an alarm for when MAC addresses are learned or removed from the forwarding database of the monitored device.
Misc	Indicates alarms that do not fit into the other categories.
Network Service	Indicates alarms generated when LSP or VPN services are impacted
PassiveMonitoring	Indicates alarms that occur on a passive monitoring interface.
Ping	Indicates alarms that a generated during a Ping request.
RMon	Indicates RMON alarms

Alarm State

Once an alarm is active, it has one of these states:

- **Active**—Alarms that are current and not yet acknowledged or cleared.
- **Cleared**—Alarms that are resolved and the device or entity has returned to normal operation.

Some alarm states go directly from active to cleared state and require little to no administrative effort. However, other alarms with a high severity should be acknowledged and investigated.

In addition to acknowledging and clearing an alarm, you can assign an alarm to someone and you can append a note or annotation to an alarm. Annotations are helpful for documenting the resolution of an alarm or time estimates for a fix. Changes to an alarm's state are made through the Alarm State monitor in Fault mode.

Alarm Notifications

Alarms can be enabled for email notification. When an alarm with notification enabled is generated, an email is sent to a set of specified addresses. There is a list of global email addresses that receive notifications from all alarms with notification enabled. Each alarm type can also have a list of addresses that receive notification when that alarm type is generated. Administrators can enable notification for alarm types and specify addresses to receive email notifications. These tasks are done on the Fault tab of System Preferences.

RELATED DOCUMENTATION

Alarm Severities and States Overview 1321
Events and Alarms Overview 1322
Customizing Alarms 1322
Changing Alarm State 1323
Searching Alarms 1324
Alarm Detail Monitor (Service View) 1331
Alarm Trend Monitor (Service View) 1339
Alarms by Category Monitor 1337
Alarms by Severity Monitor (Service View) 1337
Alarms by State Monitor 1338
Current Active Alarms Monitor (Service View) 1335

Alarm Severities and States Overview

By default, the Junos Space Network Management Platform is monitored using a built-in SNMP manager. The Junos Space Network Management Platform node is listed in the node list (Network Monitoring > Node List), and is referred to as the Junos Space Network Management Platform node.

Alarm Severity

Alarms are ranked by their impact to the network. The following list shows the ranking of alarms in Connectivity Services Director from alarms that have the most impact to alarms that have the least impact on the network. It also shows the color scheme associated with each level of severity that is reflected in related graphs.

Critical (Red)—A critical condition exists; immediate action is necessary.

Major (Orange)—A major error has occurred; escalate or notify as necessary.

Minor (Yellow)—A minor error has occurred; notify or monitor the condition.

Info (Blue)—An informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

Administrators can override the default severity of an alarm and set the severity to match their inhouse guidelines. Changing the severity level for an alarm is done on the Fault tab of System Preferences.

Alarm State

Once an alarm is active, it has one of these states:

- **Active**—Alarms that are current and not yet acknowledged or cleared.
- **Cleared**—Alarms that are resolved and the device or entity has returned to normal operation.

Some alarm states go directly from active to cleared state and require little to no administrative effort. However, other alarms with a high severity should be acknowledged and investigated.

In addition to acknowledging and clearing an alarm, you can assign an alarm to someone and you can append a note or annotation to an alarm. Annotations are helpful for documenting the resolution of an alarm or time estimates for a fix. Changes to an alarm's state are made through the Alarm State monitor in Fault mode.

Events and Alarms Overview

Activity on a network device consists of a series of events. A software component on the network device, called an entity, is responsible for running the Simple Network Management Protocol (SNMP) to log and monitor these events. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director. Connectivity Services Director correlates traps, describing a condition, into an alarm. For example, multiple power supply traps coming from a device are correlated into a single power supply alarm for the device. There are many types of alarms. An alarm can be as routine as when the device changes state or as serious as when a power supply has failed. When an alarm is sent, or raised, it stays raised until the triggering condition is resolved or cleared. The system can clear the alarm when the state changes again or an administrator can clear it manually, which indicates that the condition is now resolved. SNMP also plays another role in Connectivity Services Director. Enabling devices for SNMP with the appropriate read-only V1/V2/V3 credentials, can speed up device discovery.

Alarm Severity

Alarms are ranked by their impact to the network. The following list shows the ranking in Connectivity Services Director from most impact to least impact on the network. It also shows the color scheme associated with each level of severity that is reflected in related graphs.

- Critical (Red)—A critical condition exists; immediate action is necessary.
- Major (Orange)—A major error has occurred; escalate or notify as necessary.
- Minor (Yellow)—A minor error has occurred; notify or monitor the condition. Administrators can override the default severity of an alarm and set the severity to match their inhouse guidelines. Changing the severity level for an alarm is done on the Alarm Settings page in system Preferences.

Customizing Alarms

Ensure that all devices are enabled for SNMP trap forwarding. This task, Set SNMP Trap Configuration, is found in Deploy mode.

Connectivity Services Director enables you to tailor alarms by:

- Enabling or disabling individual alarms.
- Setting the amount of time alarms are retained in the system.

You can customize alarms using Preferences in the Connectivity Services Director banner.

RELATED DOCUMENTATION

| *Setting Up User and System Preferences*

Changing Alarm State

When an alarm becomes active, it remains active until either the system determines that the condition is resolved or system personnel change the status. Critical alarms always need immediate attention and seldom resolve on their own, but informational messages are often expected actions and results. When a condition is severe or persistent and needs attention, follow these steps:

1. Locate the alarm.
 - a. Click **Fault** in the Connectivity Services Director banner to enter Fault mode.
 - b. Click the Alarm Details icon on any of the monitors to open the Alarm Details page. Scroll or sort the alarms to find the alarm in question. As an alternate method, click **Search Alarms** in the Tasks pane and filter the active alarm list.
 - c. Select the alarm.
2. Review the Event Details that triggered the trap for the alarm. These events provide insight into the cause or location of the problem.
3. Click **Acknowledge** to indicate that the problem is now known. You should receive a message saying the alarm is acknowledged.
4. Depending whether you can resolve the alarm with the information at hand or not, either assign the alarm to a member of your staff or clear the alarm. Click **Clear** to clear the alarm or click **Assign** and fill in the assignee's name.

At any time in the life cycle of an alarm, you can attach information about the alarm to the alarm record by clicking **Annotate**. Fill in your name in the **Notes By** field and add the note description in the **Notes** field. Click **Add** to record the annotation.

RELATED DOCUMENTATION

Using Fault Management Monitors 1317
Alarm Severities and States Overview 1321
Events and Alarms Overview 1322
Customizing Alarms 1322
Searching Alarms 1324
Alarm Detail Monitor (Service View) 1331
Alarm Trend Monitor (Service View) 1339
Alarms by Category Monitor 1337
Alarms by Severity Monitor (Service View) 1337
Alarms by State Monitor 1338
Current Active Alarms Monitor (Service View) 1335

Searching Alarms

Use Search Alarms, available from the Tasks pane, to filter and isolate information about a specific alarm. Use this page to specify complex sorting and filtering criteria for all alarms.

Each field in the Search Alarm window helps narrow the current list of alarms. The more search items you specify, the more specific your results. All fields are optional.

1. Select or type the known descriptors for the alarm. These fields are described in [Table 168 on page 1325](#).
2. Click **Search** to run the query. The Alarms Details page opens with the results of your search.
3. Review the alarm. From this page you can change the state of the alarm, annotate, or assign the alarm to personnel. For more information about changing the state of an alarm, view [“Changing Alarm State” on page 1323](#).

Table 168: Alarm Search Fields

Search Criteria	Description
State	<p>Use the list to select which alarm states to search for:</p> <ul style="list-style-type: none"> • All—Alarms of all states. • Active—Alarms that are current and not yet acknowledged or cleared. • Clear—Alarms that are resolved and the device or entity has returned to normal operation.
Category	<p>Fill in one of the available alarm categories:</p> <ul style="list-style-type: none"> • AP/Radio • BFD • BGP • Chassis • ClientAndUserSession • Cluster/Modo • Configuration • Controllers • CoS • DHCP • DOM • FlowCollection • GENERAL • GenericEvent • L2ALD • L2CP • MACFDB • Misc • PassiveMonitoring • Ping • RFDetect • RMon • SONET • SONETAPS • VirtualChassis • VNetwork

Table 168: Alarm Search Fields (*continued*)

Search Criteria	Description
Severity	<p>Pull down the list to select the severity level. Not all possible alarm severities are listed. Only the severity levels of your current active alarms are shown. Possible selections are:</p> <ul style="list-style-type: none"> • Critical • Major • Minor • Info
Advanced Search Criteria	
(from) Date	Pull down the calendar and select the starting date of the search.
(from) Time	Pull down the list to select the starting time of the search. Search times are in military (24-hour) clock format in 30 minute intervals.
(to) Date	Pull down the calendar and select the ending date of the search.
(to) Time	Pull down the list to select the ending time of the search. Search times are in military (24-hour) clock format in 30 minute intervals.
Notes	Enter any keywords or phases that were listed in an existing annotation.

RELATED DOCUMENTATION

[Using Fault Management Monitors | 1317](#)
[Alarm Severities and States Overview | 1321](#)
[Events and Alarms Overview | 1322](#)
[Customizing Alarms | 1322](#)
[Changing Alarm State | 1323](#)
[Alarm Detail Monitor \(Service View\) | 1331](#)
[Alarm Trend Monitor \(Service View\) | 1339](#)
[Alarms by Category Monitor | 1337](#)
[Alarms by Severity Monitor \(Service View\) | 1337](#)
[Alarms by State Monitor | 1338](#)
[Current Active Alarms Monitor \(Service View\) | 1335](#)

Fault Reference

IN THIS CHAPTER

- [Alarm Detail Monitor \(All Views Except Service View\) | 1327](#)
- [Alarm Detail Monitor \(Service View\) | 1331](#)
- [Current Active Alarms Monitor \(Service View\) | 1335](#)
- [Alarms by Category Monitor | 1337](#)
- [Alarms by Severity Monitor \(Service View\) | 1337](#)
- [Alarms by State Monitor | 1338](#)
- [Alarm Trend Monitor \(Service View\) | 1339](#)
- [Alarms by Severity Monitor \(All Views Except Service View\) | 1339](#)
- [Alarms by State Monitor \(All Views Except Service View\) | 1340](#)
- [Current Active Alarms Monitor \(All Views Except Service View\) | 1340](#)
- [Alarm Trend Monitor \(All Views Except Service View\) | 1342](#)

Alarm Detail Monitor (All Views Except Service View)

IN THIS SECTION

- [Finding Specific Alarms | 1328](#)
- [Sorting Alarms | 1329](#)
- [Reading Events | 1330](#)
- [Investigating Event Attributes | 1331](#)
- [Changing the Alarm State | 1331](#)

Use the Alarm Detail monitor to sort alarms, view an alarm in depth, and to assign a disposition to an alarm.

By clicking the Details icon, you can access the Alarm Detail monitor from any of the four alarm monitors available on the main page in Fault mode (Severity, Category, Current, or State). It is also available from the Current Active Monitors available from the Summary tab in Monitor mode.

This topic describes:

Finding Specific Alarms

Use the Alarm Detail monitor to locate a specific alarm, research the events causing the alarm, and to assign a disposition to the alarm. When an alarm is highlighted in the sorting sequence, the events contributing to the alarm are listed in Event Details and the variable settings are shown in Event Attribute Detail.

To locate an alarm and to assign a disposition to the alarm:

1. Sort the list using the Display list. Sorting choices vary depending on how you arrived here. View [“Sorting Alarms” on page 1329](#) for details on sorting options.
2. Review the sorted list. Each entry shows a minimum of one to a maximum of nine fields. These fields are described in [Table 169 on page 1328](#).
3. Examine the events and event attributes that contributed to sending the alarm. Events and event attributes are discussed in [“Reading Events” on page 1330](#) and [“Investigating Event Attributes” on page 1331](#).

Table 169: Alarm Detail Fields

Field	Value	Shown in Detailed View by Default
Name	The alarm name.	Yes
ID	A system and sequentially-generated identification number.	No
Assigned To	If assigned to an individual, it shows the name of the person assigned; otherwise, it shows System to mark that the alarm is still unassigned.	Yes
Severity	The severity of the alarm. Severity levels are: <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary. 	Yes
Acknowledged	Indicates if the alarm has been acknowledged.	Yes

Table 169: Alarm Detail Fields (*continued*)

Field	Value	Shown in Detailed View by Default
Entity ID	The identification of the entity responsible for causing this alarm. The Entity ID is the key for correlation of events into an alarm. The Entity ID could be a MAC address of a radio or an IP address of the device.	Yes
Source	The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.	No
Reporting Device	The hostname of the reporting device.	Yes
Creation Date	The date and time the alarm was first reported.	No
Last Updated	The date and time that the information for the alarm was last modified.	Yes
Updated By	Either the system or the last user who modified the alarm.	No

Sorting Alarms

Depending on the monitor you chose to access Alarm Detail, your sorting options change to reflect the summary monitor. The different sort options are listed in [Table 170 on page 1329](#).

Table 170: Sort Options for Alarms

Alarms by Severity Sort	Alarms by Category Sort	Alarms by State and Current Active Alarms Sort
Minor	BGP	
Major	Chassis	
	Config	
	CoS	
	DHCP	
	GENERAL	
	GenericEvent	

Table 170: Sort Options for Alarms (*continued*)

Alarms by Severity Sort	Alarms by Category Sort	Alarms by State and Current Active Alarms Sort
	Ping	

You can also use Searching Alarms in the Tasks pane to perform searches using multiple arguments. With multiple arguments, you can isolate a single alarm from a long alarm list.

Reading Events

When you select an alarm in Alarm Detail, the Event Detail table updates with information about the events that are associated with the alarm. [Table 171 on page 1330](#) lists the fields in Event Detail.

Table 171: Event Detail Fields

Field	Value
Name	The event name; also known as the SNMP trap name.
ID	A system-generated, hexadecimal code that uniquely identifies the event.
Description	If the event is an SNMP event, it is shown as a system-generated event.
Type	The type of event, either fault or system alert.
Category	<p>The category of the event message. The category corresponds to the alarm categories shown in the Alarms by Category monitor and the Alarm Settings window. These categories are:</p> <ul style="list-style-type: none"> • General • Chassis
Source	The identification of the entity that is the cause of this event ; it is not necessarily the ID of the event that generated the event.
Originator	The identification of the entity that generated this event, for example, the switch IP or controller IP address.
Time Updated	The date and time of the last update to the event.

Investigating Event Attributes

The Event Attribute Detail window reflects the variables set during the event. In SNMP terminology, these attributes are known as variable bindings or varbinds. These attributes can provide key information about triggers. For example, if a fan fails, the attribute field could indicate the location of the fan in the chassis.

Changing the Alarm State

When an alarm is first reported, it is considered an active alarm. To change the alarm state, to assign the alarm to a person, or simply to record notes about the alarm, use the buttons on Alarm Details. These buttons are:

- Acknowledge—Use this button to acknowledge or record that the alarm is known and is being addressed.
- Clear—Use this button to clear or remove the alarm. The clear state says that the issue sending the alarm has been resolved and no longer requires attention.
- Annotate—Use this button to record actions taken to resolve the alarm.
- Assign—Use this button to assign active or acknowledged alarms to staff.

Alarm Detail Monitor (Service View)

IN THIS SECTION

- [Finding Specific Alarms | 1332](#)
- [Sorting Alarms | 1333](#)
- [Reading Events | 1333](#)
- [Investigating Event Attributes | 1334](#)
- [Changing the Alarm State | 1334](#)

Use the Alarm Detail monitor to sort alarms, view an alarm in depth, and to assign a disposition to an alarm.

By clicking the Details icon, you can access the Alarm Detail monitor from any of the four alarm monitors available on the main page in Fault mode (Severity, Category, Current, or State). It is also available from the Current Active Monitors available from the Summary tab in Monitor mode.

This topic describes:

Finding Specific Alarms

Use the Alarm Detail monitor to locate a specific alarm, research the events causing the alarm, and to assign a disposition to the alarm. When an alarm is highlighted in the sorting sequence, the events contributing to the alarm are listed in Event Details and the variable settings are shown in Event Attribute Detail.

To locate an alarm and to assign a disposition to the alarm:

1. Sort the list using the Display list. Sorting choices vary depending on how you arrived here. View [“Sorting Alarms” on page 1329](#) for details on sorting options.
2. Review the sorted list. Each entry shows a minimum of one to a maximum of nine fields. These fields are described in [Table 169 on page 1328](#).
3. Examine the events and event attributes that contributed to sending the alarm. Events and event attributes are discussed in [“Reading Events” on page 1330](#) and [“Investigating Event Attributes” on page 1331](#).

Table 172: Alarm Detail Fields

Field	Value	Shown in Detailed View by Default
Name	The alarm name.	Yes
ID	A system and sequentially-generated identification number.	No
Assigned To	If assigned to an individual, it shows the name of the person assigned; otherwise, it shows System to mark that the alarm is still unassigned.	Yes
Severity	The severity of the alarm. Severity levels are: <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary. 	Yes
Service Name	The name of the service for which the alarm was generated.	Yes
Customer	The name of the customer associated with the service for which the alarm was generated.	Yes
Service Type	The type or protocol of the service for which the alarm was generated.	Yes

Table 172: Alarm Detail Fields (*continued*)

Field	Value	Shown in Detailed View by Default
Entity ID	The identification of the entity responsible for causing this alarm. The Entity ID is the key for correlation of events into an alarm. The Entity ID could be a MAC address of a radio or an IP address of the device.	Yes
Source	The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.	No
Acknowledged	Indicates if the alarm has been acknowledged.	Yes
Source	The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.	No
Creation Date	The date and time the alarm was first reported.	No
Last Updated	The date and time that the information for the alarm was last modified.	Yes
Updated By	Either the system or the last user who modified the alarm.	No

Sorting Alarms

Sort the alarms based on the following parameters from the drop-down lists:

- Severity
- State
- Service
- Time (You can choose only time spans ending now, for example, Last 12 hours.)

Click Search to filter the alarms and display the alarms based on the search criteria.

You can also use Searching Alarms in the Tasks pane to perform searches using multiple arguments. With multiple arguments, you can isolate a single alarm from a long alarm list.

Reading Events

When you select an alarm in Alarm Detail, the Event Detail table updates with information about the events that are associated with the alarm. [Table 171 on page 1330](#) lists the fields in Event Detail.

Table 173: Event Detail Fields

Field	Value
Name	The event name; also known as the SNMP trap name.
ID	A system-generated, hexadecimal code that uniquely identifies the event.
Description	If the event is an SNMP event, it is shown as a system-generated event.
Type	The type of event, either fault or system alert.
Category	The category of the event message. The category corresponds to the alarm categories shown in the Alarms by Category monitor and the Alarm Settings window.
Source	The identification of the entity that is the cause of this event ; it is not necessarily the ID of the event that generated the event.
Originator	The identification of the entity that generated this event, for example, the switch IP or controller IP address.
Time Updated	The date and time of the last update to the event.

Investigating Event Attributes

The Event Attribute Detail window reflects the variables set during the event. In SNMP terminology, these attributes are known as variable bindings or varbinds. These attributes can provide key information about triggers. For example, if a fan fails, the attribute field could indicate the location of the fan in the chassis.

Changing the Alarm State

When an alarm is first reported, it is considered an active alarm. To change the alarm state, to assign the alarm to a person, or simply to record notes about the alarm, use the buttons on Alarm Details. These buttons are:

- **Acknowledge**—Use this button to acknowledge or record that the alarm is known and is being addressed.
- **Clear**—Use this button to clear or remove the alarm. The clear state says that the issue sending the alarm has been resolved and no long requires attention.
- **Annotate**—Use this button to record actions taken to resolve the alarm.
- **Assign**—Use this button to assign active or acknowledged alarms to staff.

RELATED DOCUMENTATION

[Alarm Trend Monitor \(Service View\) | 1339](#)
[Alarms by Category Monitor | 1337](#)
[Alarms by Severity Monitor \(Service View\) | 1337](#)
[Alarms by State Monitor | 1338](#)
[Current Active Alarms Monitor \(Service View\) | 1335](#)

Current Active Alarms Monitor (Service View)

The Current Active Alarms monitor shows any active alarm that has not yet been cleared. It is one of the four standard monitors available in Alarm mode. Current Active Alarms is a table that has four fields and appear by default. However, nine fields are available for selection. View [Table 174 on page 1335](#) for a description of the table.

Table 174: Current Active Alarms Monitor

Table Column	Description	Shown in Summary by Default	Shown in Detailed View by Default
Name	The alarm name.	Yes	Yes
ID	A system and sequentially-generated identification number.	No	No
Assigned To	If assigned to an individual, it shows the name of the person assigned; otherwise, it shows System to mark that the alarm is still unassigned.	No	Yes
Severity	The severity of the alarm. Severity levels are: <ul style="list-style-type: none"> ● Critical—A critical condition exists; immediate action is necessary. ● Major—A major error has occurred; escalate or notify as necessary. ● Minor—A minor error has occurred; notify or monitor the condition. ● Info—An informational message; no action is necessary. 	Yes	Yes

Table 174: Current Active Alarms Monitor (*continued*)

Table Column	Description	Shown in Summary by Default	Shown in Detailed View by Default
Service Name	The name of the service for which the alarm was generated.	Yes	Yes
Customer	The name of the customer associated with the service for which the alarm was generated.	Yes	Yes
Service Type	The type or protocol of the service for which the alarm was generated.	Yes	Yes
Entity ID	The identification of the entity responsible for causing this alarm. The Entity ID is the key for correlation of events into an alarm. The Entity ID could be a MAC address of a radio or an IP address of the device.	Yes	Yes
Source	The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.	No	No
Creation Date	The date and time the alarm was first reported.	No	No
Last Updated	The date and time that the information for the alarm was last modified.	Yes	Yes
Updated By	Either the system or the last user who modified the alarm.	No	No

Clicking the Details icon opens Alarm Details where you can sort and disposition alarms by state (Acknowledged, Clear, Active).

RELATED DOCUMENTATION

[Alarm Detail Monitor \(Service View\) | 1331](#)

[Alarm Trend Monitor \(Service View\) | 1339](#)

[Alarms by Category Monitor | 1337](#)

[Alarms by Severity Monitor \(Service View\) | 1337](#)

Alarms by Category Monitor

Alarms by Category is a table of all active alarms sorted by category. Use this monitor to view where errors are trending. These categories are the same categories shown in the Alarm Settings page.

This monitor is available in all views in the main window when in Fault mode.

The table shows the active categories and the number of alarms per category. Clicking the Details icon on Alarms by Category opens Alarm Details where you can sort these categories and change the state of the alarms.

To create a similar report for a specific period of time, use the Alarm Summary report in Report mode.

RELATED DOCUMENTATION

Alarm Detail Monitor (Service View) 1331
Alarm Trend Monitor (Service View) 1339
Alarms by Severity Monitor (Service View) 1337
Alarms by State Monitor 1338
Current Active Alarms Monitor (Service View) 1335

Alarms by Severity Monitor (Service View)

Alarms by Severity is a pie-chart that shows the breakdown of all alarms since the last system restart. It is available on the main page when in Fault mode.

If you mouse over each segment, the total number of alerts for those alarms is shown. Alarm severity levels are:

- Critical (Red)—A critical condition exists; immediate action is necessary.
- Major (Orange)—A major error has occurred; escalate or notify as necessary.
- Minor (Yellow)—A minor error has occurred; notify or monitor the condition.
- Info (Wedgewood Blue)—An informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

Clicking the Details icon on Alarms by Severity opens Alarm Details where you can sort and disposition individual.

RELATED DOCUMENTATION

Alarm Detail Monitor (Service View) 1331
Alarm Trend Monitor (Service View) 1339
Alarms by Category Monitor 1337
Alarms by State Monitor 1338
Current Active Alarms Monitor (Service View) 1335

Alarms by State Monitor

The Alarms by State monitor is a pie-chart representation of the states of an alarm: active and cleared. Use this graph to get an overall perspective of the amount of alarms that are active compare to those that are cleared. The Alarms by State monitor is on the main pane when in Fault mode.

Mouse over each segment of the pie-chart shows the number of alarms in these states:

- Active—Alarms that are current and not yet cleared.
- Cleared—Alarms that are resolved and the device or entity has returned to normal operation.

You can create an Alarms by State report for a specified node or a period of time using the Alarms Summary Report in Report mode.

Changing the state of an alarm using Connectivity Services Director is performed on the Alarm Detail page. Clicking the Details icon on Alarms by State opens Alarm Details where you can sort and set the disposition of the alarms.

RELATED DOCUMENTATION

Alarm Detail Monitor (Service View) 1331
Alarm Trend Monitor (Service View) 1339
Alarms by Category Monitor 1337
Alarms by Severity Monitor (Service View) 1337
Current Active Alarms Monitor (Service View) 1335

Alarm Trend Monitor (Service View)

The Alarm Trend monitor provides trend information about alarms. The trend information is shown on a line chart, where each alarm severity is shown as a colored line. The legend for the line colors is displayed below the chart. The alarm count is shown on the vertical axis. The time of the data samples is shown on the horizontal axis. This monitor includes tabs that show alarm trend information for active alarms and for new alarms. You can select the time period to display from the list in the title bar.

RELATED DOCUMENTATION

- [Alarm Detail Monitor \(Service View\) | 1331](#)
- [Alarms by Category Monitor | 1337](#)
- [Alarms by Severity Monitor \(Service View\) | 1337](#)
- [Alarms by State Monitor | 1338](#)
- [Current Active Alarms Monitor \(Service View\) | 1335](#)

Alarms by Severity Monitor (All Views Except Service View)

Alarms by Severity is a pie-chart that shows the breakdown of all alarms since the last system restart. It is available on the main page when in Fault mode.

If you mouse over each segment, the total number of alerts for those alarms is shown. Alarm severity levels are:

- Critical (Red)—A critical condition exists; immediate action is necessary.
- Major (Orange)—A major error has occurred; escalate or notify as necessary.
- Minor (Yellow)—A minor error has occurred; notify or monitor the condition.
- Info (Wedgewood Blue)—An informational message; no action is necessary. Informational alarms do not necessarily indicate an error. It could indicate that a device or entity has changed state.

Clicking the Details icon on Alarms by Severity opens Alarm Details where you can sort and disposition individual.

RELATED DOCUMENTATION

- [Alarm Detail Monitor \(Service View\) | 1331](#)
- [Alarm Trend Monitor \(Service View\) | 1339](#)

Alarms by Category Monitor 1337
Alarms by State Monitor 1338
Current Active Alarms Monitor (Service View) 1335

Alarms by State Monitor (All Views Except Service View)

The Alarms by State monitor is a pie-chart representation of the states of an alarm: active and cleared. Use this graph to get an overall perspective of the amount of alarms that are active compare to those that are cleared. The Alarms by State monitor is on the main pane when in Fault mode.

Mouse over each segment of the pie-chart shows the number of alarms in these states:

- Active—Alarms that are current and not yet cleared.
- Cleared—Alarms that are resolved and the device or entity has returned to normal operation.

You can create an Alarms by State report for a specified node or a period of time using the Alarms Summary Report in Report mode.

Changing the state of an alarm using Connectivity Services Director is performed on the Alarm Detail page. Clicking the Details icon on Alarms by State opens Alarm Details where you can sort and set the disposition of the alarms.

RELATED DOCUMENTATION

Alarm Detail Monitor (Service View) 1331
Alarm Trend Monitor (Service View) 1339
Alarms by Category Monitor 1337
Alarms by Severity Monitor (Service View) 1337
Current Active Alarms Monitor (Service View) 1335

Current Active Alarms Monitor (All Views Except Service View)

The Current Active Alarms monitor shows any active alarm that has not yet been cleared. It is one of the four standard monitors available in Alarm mode. Current Active Alarms is a table that has four fields and appear by default. However, nine fields are available for selection. View [Table 174 on page 1335](#) for a description of the table.

Table 175: Current Active Alarms Monitor

Table Column	Description	Shown in Summary by Default	Shown in Detailed View by Default
Name	The alarm name.	Yes	Yes
ID	A system and sequentially-generated identification number.	No	No
Assigned To	If assigned to an individual, it shows the name of the person assigned; otherwise, it shows System to mark that the alarm is still unassigned.	No	Yes
Severity	<p>The severity of the alarm. Severity levels are:</p> <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary. 	Yes	Yes
Entity ID	The identification of the entity responsible for causing this alarm. The Entity ID is the key for correlation of events into an alarm. The Entity ID could be a MAC address of a radio or an IP address of the device.	Yes	Yes
Source	The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.	No	No
Reporting Device	The hostname or IP address of the reporting device.	Yes	Yes
Creation Date	The date and time the alarm was first reported.	No	No
Last Updated	The date and time that the information for the alarm was last modified.	Yes	Yes
Updated By	Either the system or the last user who modified the alarm.	No	No

Clicking the Details icon opens Alarm Details where you can sort and disposition alarms by state (Acknowledged, Clear, Active).

Alarm Trend Monitor (All Views Except Service View)

The Alarm Trend monitor provides trend information about alarms. The trend information is shown on a line chart, where each alarm severity is shown as a colored line. The legend for the line colors is displayed below the chart. The alarm count is shown on the vertical axis. The time of the data samples is shown on the horizontal axis. This monitor includes tabs that show alarm trend information for active alarms and for new alarms. You can select the time period to display from the list in the title bar.

RELATED DOCUMENTATION

- [Alarm Detail Monitor \(Service View\) | 1331](#)
- [Alarms by Category Monitor | 1337](#)
- [Alarms by Severity Monitor \(Service View\) | 1337](#)
- [Alarms by State Monitor | 1338](#)
- [Current Active Alarms Monitor \(Service View\) | 1335](#)

15

PART

End-to-End Configuration Examples

Configuration Scenarios | **1344**

Configuration Scenarios

IN THIS CHAPTER

- Example: Configuring and Deploying an E-Line Service | 1344
- Example: Configuring and Deploying a Multipoint-to-Multipoint E-LAN Service | 1355
- Example: Configuring and Deploying an IP Full-Mesh Service | 1369


Example: Configuring and Deploying an E-Line Service

IN THIS SECTION

- Preparing Devices for Discovery | 1345
- Discovering Devices | 1345
- Preparing Devices for Prestaging | 1347
- Discovering and Assigning N-PE Roles | 1348
- Choosing or Creating a Service Definition | 1349
- Creating a Customer | 1351
- Creating and Deploying an E-Line Service Order | 1352
- Performing a Functional Audit and a Configuration Audit | 1353

This example deploys and verifies an E-Line service starting with two MX Series devices. [Figure 25 on page 1345](#) shows the service.

Figure 25: Simple E-Line Service



This service provides connectivity for one VLAN, using 802.1Q interface endpoints. Customer site A connects to the network through UNI ge-0/0/2 on an N-PE device named SJC. Customer site B connects to the network through UNI ge-0/0/3 on an N-PE device named SFO.

The bandwidth for each UNI is limited to 1000 Mbps.

You can create this service by performing the following tasks, in order:

Preparing Devices for Discovery

Before you can add a device using device discovery, the following conditions must be met:

- SSH v2 is enabled on the device. To enable SSH v2 on a device, issue the following CLI command:

```
set system services ssh protocol-version v2
```

- The NETCONF protocol over SSH is enabled on the device. To enable the NETCONF protocol over SSH on a device, issue the following CLI command:

```
set system services netconf ssh
```

- The device is configured with a static management IP address that is reachable from the Junos Space server. The IP address can be in-band or out-of-band.
- A user with full administrative privileges is created on the device for the Junos Space administrator.
- If you plan to use SNMP to probe devices as part of device discovery, ensure that SNMP is enabled on the device with appropriate read-only V1/V2C/V3 credentials.

Discovering Devices

Device discovery is a process that Junos Space uses to bring network devices under its control. This example brings two MX Series routers under Junos Space management:

NOTE: Alternatively, you can import devices using the Connectivity Services Director GUI. See *Discovering Devices in a Physical Network* for instructions on discovering devices from Build mode of Connectivity Services Director.

1. Log in to Junos Space using your credentials.
2. From the Junos Space Network Management Platform user interface, select **Devices** > **Discover Devices** > **Discover Targets**.
3. In the **Discover Targets** window, click +.
The **Add Device Target** window appears.
4. Select **IP range**.
5. Enter the IP address information. This example uses a range of two addresses.
6. Click **Add**, and then click **Next**.
7. In the **Devices: Specify Probes** window, select both **Ping** and **SNMP** as probes.
8. Click **Next**.
9. In the **Devices: Specify Credentials** window, click + and enter the device login credentials.
10. Click **Finish**.
Device discovery begins. It displays a graph showing the status of the discovery operation. Initially, two devices are discovered. When Junos Space has accessed both devices and brought them under its management, both devices move from the Discovered column of the graph to the Managed column.
11. To check the results of the device discovery operation, select the **Devices** workspace again, then select **Device Management**. The **Manage Devices** page shows the added devices.

SEE ALSO

Device Discovery Overview in the Junos Space Network Application Platform User Guide
Discovering Devices in the Junos Space Network Application Platform User Guide

Preparing Devices for Prestaging

Before prestaging devices for E-Line services, the following entities must be configured:

- MPLS must run on each N-PE device.
- LDP signaling must be established between N-PE devices that you want to participate in the same E-Line service.

To satisfy these configurations, ensure that the following configuration exists on each N-PE device:

```

interfaces {
  ge-0/0/0 {
    unit 0 {
      family inet {
        address 10.1.18.2/30;
      }
      family mpls;
    }
  }

  lo0 {
    unit 0 {
      family inet {
        address 192.168.1.20/32;
      }
    }
  }
}

protocols {
  mpls {
    interface ge-0/0/0.0;
    interface lo0.0;
  }

  ospf {
    traffic-engineering;
    area 0.0.0.0 {
      interface lo0.0 {
        passive;
      }
      interface ge-0/0/0.0;
    }
  }

  ldp {

```

```

interface ge-0/0/0.0;
interface lo0.0;
}

```

NOTE: The OSPF configuration is not required in prestaging.

Discovering and Assigning N-PE Roles

Before you can provision services, you must prestage the devices. Prestaging includes assigning device roles and designating interfaces on those devices as UNIs. This example provides the steps to accept the recommendations of the Network Services application for N-PE devices and UNIs.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

View the values displayed under the Roles column of the discovered devices.

This action launches the role discovery process in which the Network Services application examines the devices under Junos Space management looking for devices that match predefined rules that identify N-PE devices. In this example, the Role Discovery Status graph shows that the Network Services application has discovered two such devices.

4. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.
5. To view the assignment status, in the **CSD Deployment Jobs** window that you can access from Deploy mode of Service View by selecting **View Deployment Jobs** from the task pane, click the job ID of the assignment job.

The **Job Management** page shows the progress and status of the role assignment job.

6. To verify the result, in Build mode, select **Prestage Devices > Manage Device Roles** from the tasks pane.

The **Manage Device Roles** window shows two devices that can be used for provisioning.

7. To unassign a device from N-PE role assignment, click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

SEE ALSO

[Discovering and Assigning All N-PE Devices | 366](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

Choosing or Creating a Service Definition

A service definition provides a template upon which services are built. It specifies service attributes that are not specific to a service instance. In our example, the service definition provides all service attributes except the N-PE devices, the UNIs, and bandwidth.

The Network Services application ships with standard service definitions. First, we check the standard service definitions to determine whether one already exists that will work.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Service Design > Manage Service Definitions**.

The **Manage Service Definitions** page lists all service definitions in the system. In a new system, the screen lists only predefined service definitions.

This example requires a service definition with UNIs that use 802.1Q interfaces and allow you to set a bandwidth of 25 Mbps. The standard service definitions have several examples for provisioning 802.1Q UNIs, but none that allow the setting of a 25 Mbps bandwidth limit. You need to create a new service definition.

4. In the **Network Services > Connectivity** task pane, select **Service Design > Manage Service Definitions > New > E-Line Service Definition**.

The General window appears.

5. Enter a name for the service definition. For this example, enter **p2p-dot1q-sd-1**.

6. Click **Next**.

The **UNI Settings** window appears.

7. In the **Connectivity Settings** window, to pick the default connectivity settings, click **Next**.

8. In the **UNI Settings** window, in the **Ethernet option** field, select **dot1q**.

9. In the **Customer traffic type** field, select **Transport single VLAN**.

10. In the **VLAN ID selection** field, select **Select manually**.

11. In the **VLAN range for manual input** field, specify the range.

12. In the **Outer Tag protocol ID** field, select **0x88a8**

13. In the **Physical IF encapsulation** field, select **flexible-ethernet-services**.

14. In the **Logical IF encapsulation** field, select **vlan-ccc**.

15. In the **Bandwidth Settings** panel, select the **Enable rate limiting** check box.

16. In the **Default Bandwidth** field, enter **10**, for a default bandwidth of 10 Mbps.

17. To the right of the value you just entered, select the **Editable in service order** check box.

The **Min Bandwidth (Kbps)**, **Max Bandwidth (Mbps)**, and **Increment (Kbps)** become active.

18. In the **Min Bandwidth (Kbps)** field, enter **100**.

19. In the **Max Bandwidth (Mbps)** field, enter **10000**.

20. In the **increment** field, enter **64**.

These settings of the **Bandwidth range** and **Increment** fields allow the bandwidth to be set in the service to any 64-Kbps increment in the range of 100 Kbps through 10000 Mbps.

21. To save and complete the service definition, click **Finish**.

The **Manage Service Definitions** page includes the new service definition.

You have created a customized Service Definition, but it has not yet been published. Before a service definition can be used in provisioning, it must be published.

22. To publish the service definition, in the **Manage Service Definitions** page, select the **p2p-dot1q-sd-1** service definition; click the **Publish Service Definition** button.

The **Publish Service Definition** window appears.

23. To confirm that you want to publish this service definition, click **Publish**.

In the **Manage Service Definitions** page, the symbol in the upper left corner of the service definition changes to a check mark, indicating that the status has changed to Published.

The service definition is now ready for use in provisioning.

Creating a Customer

Before you can provision the service, customer details must be present in the Junos Space database. To add a customer:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Customers > Create Customer**.
4. In the **Name** field, enter **Best Customer**.
5. In the **Account number** field, enter **1234**.
6. Click **Create**.

The **Manage Customers** page shows the new customer.

SEE ALSO

| [Adding a New Customer](#) | 795

Creating and Deploying an E-Line Service Order

Now that you have prestaged your devices, created a suitable service definition, and added the customer information to the database, you are ready to create and deploy a service order. To create and deploy a service order:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the **New** icon at the top of the upper half of the page that displays previously created service orders. The Select Service Type dialog box appears.
4. Select **E-Line** to create an E-Line service order.

The General/Connectivity Settings panel appears initially in the right panel, as shown in the example.

5. In the **Create E-Line Service Order** window, select the service named **p2p-dot1q-sd-1**.

This is the customized service definition you created earlier.

6. Click **Next**.

7. In the **General/Connectivity Settings** window, in the **Name** field, enter **so_1**.

8. In the **Customer** field, select **Best Customer**.

9. Click **Next**.

The **Endpoint Settings** window appears.

10. For endpoint A, in the **PE device** field, select **SJC**.

11. In the **UNI interface** field, select **ge-0/0/2**.

12. In the **VLAN-ID** field, enter **100**.

13. Click **Next**.

14. In the **Endpoint Settings** window for endpoint Z, in the **PE device** field, select **SFO**.

15. In the **UNI interface** field, select **ge-0/0/3**.
16. In the **Bandwidth** field, select **25**.
17. Click **Done**. You are returned to the Manage Network Services page.
18. From the Manage Service Orders page that is displayed in the lower part of the window, select the particular service and click **Deploy now**.
19. Click **OK** to start the deployment.
20. To monitor the progress and status of the deployment, in the Manage Service Orders window, click the link in the Latest Job field. The **Job Management** page shows the status of the job.

NOTE: Alternatively, to display the Job Management page, from the Junos Space Platform UI, select **Jobs > Manage Jobs** from the Tasks pane. You can also view the CSD Deployment Jobs page in Deploy mode of Service View by selecting the **View Deployment Jobs** option in the task pane.

21. When you see in the **Job Management** window that the deployment is successful, in the **Network Services** task pane in Deploy mode, select **Service Provisioning > Deploy Services**.

The **Manage Network Services** page shows the new service.

Performing a Functional Audit and a Configuration Audit

Now that your new service is deployed, you should validate its configuration and functional integrity. A functional audit runs operational commands on the device to verify that the service is up or down. A configuration audit verifies whether the configuration that was pushed to the device during deployment is actually on the device.

To perform a configuration audit and a functional audit of the service:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services > E-Line Services to expand the tree and display the different service types that you can configure.
4. Select **Deploy Services** from the task pane. The right pane displays two pages. The Manage Network Services page is displayed in the upper half of the right pane. Selecting a service from this page causes the associated service orders for the selected service to be displayed in the Manage Service Orders page in the lower half of the right pane.
5. In the **Manage Network Services** page, select the service instance you just deployed.
6. Select the service instance, and open the **Actions** menu and select **Run Functional Audit**.
7. In the **Schedule Functional Audit** window, you can choose to perform the audit now or schedule it for later. Select **Audit now**, then click **OK**.
8. In the **Order Information** screen, click **OK**.
9. Select the service instance, and open the **Audit** menu and select **Run Configuration Audit**.
10. In the **Schedule Configuration Audit** window, you can choose to perform the audit now or schedule it for later. Select **Audit now**, and then click **OK**.
11. In the **Order Information** window, click **OK**.

When the audit jobs have finished, success is indicated by an up arrow in the top right corner of the service.
12. To view the functional audit results:
 - a. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
 - b. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
 - c. From the **Network Services > Connectivity > E-Line Services** View pane, select the **so_1** service instance.

- d. In the tasks pane, select **Audit/Results > Functional Audit**.
- e. In the **Functional Audit Results** window, select each device to view the results.

13. To view the results of the configuration audit:

- a. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
- b. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
- c. From the **Network Services > Connectivity > E-Line Services** View pane, select the **so_1** service instance.
- d. In the tasks pane, select **Audit/Results > Configuration Audit**.
- e. In the **Configuration Audit Results** window, select each device in turn and review the results. This report indicates any part of the service configuration that is missing on the device, or is inconsistent with the Junos Space database.

Following successful audit, the service is deployed and ready to be used.

RELATED DOCUMENTATION

Device Discovery Overview in the Junos Space Network Application Platform User Guide
Discovering Devices in the Junos Space Network Application Platform User Guide

Example: Configuring and Deploying a Multipoint-to-Multipoint E-LAN Service


IN THIS SECTION

- [Preparing Devices for Discovery | 1356](#)
- [Discovering Devices | 1357](#)
- [Preparing Devices for Prestaging | 1358](#)
- [Discovering and Assigning N-PE Roles | 1361](#)

- Choosing or Creating a Service Definition | 1362
- Creating a Customer | 1365
- Creating and Deploying a Multipoint-to-Multipoint Service Order | 1366
- Performing a Functional Audit and a Configuration Audit | 1367

This example shows how to deploy and verify a multipoint-to-multipoint E-LAN service starting with three MX Series routers. [Figure 26 on page 1356](#) shows the service.

Figure 26: Simple Multipoint-to-Multipoint Service



This service provides connectivity for one VLAN, using 802.1Q interface endpoints. Customer site A connects to the network through an N-PE device named SJC (IP address 1.1.1.1). Customer site B connects to the network through an N-PE device named SFO (IP address 1.1.1.2). Customer site C connects to the network through an N-PE device named BLR (IP address 1.1.1.3). In this example, we allow Network Activate to select each UNI automatically.

Each UNI is to have its bandwidth limited to 25 Mbps.

You can create this service by performing the following tasks:

Preparing Devices for Discovery

Before you can add a device using device discovery, the following conditions must be met:

- SSH v2 is enabled on the device. To enable SSH v2 on a device, issue the following CLI command:

```
set system services ssh protocol-version v2
```

- The NETCONF protocol over SSH is enabled on the device. To enable the NETCONF protocol over SSH on a device, issue the following CLI command:

```
set system services netconf ssh
```

- The device is configured with a static management IP address that is reachable from the Junos Space server. The IP address can be in-band or out-of-band.
- A user with full administrative privileges is created on the device for the Junos Space administrator.
- If you plan to use SNMP to probe devices as part of device discovery, ensure that SNMP is enabled on the device with appropriate read-only V1/V2C/V3 credentials.

Discovering Devices

Device discovery is a process that Junos Space uses to bring network devices under its control. This example brings two MX Series routers under Junos Space management.

NOTE: Alternatively, you can import devices using the Connectivity Services Director GUI. See *Discovering Devices in a Physical Network* for instructions on discovering devices from Build mode of Connectivity Services Director.

1. Log in to Junos Space using your credentials.
2. In the Applications Chooser of the Junos Space Platform user interface, select **Platform > Devices > Device Discovery > Device Discovery Profile**.
The **Device Discovery Profiles** window appears.
3. In the Device Discovery Profiles window, click **+**.
The Device Discovery Target window appears.
4. Select **IP range**.
5. Specify the **Start IP Address** and **End IP Address** information.
6. Click **Next**.
7. In the **Specify Probes** window, select both **Use Ping** and **Use SNMP** as probes.

8. Click **Next**.
9. In the **Specify Credentials** window, select **Authentication Type** and enter the device login credentials.
10. Click **Discover**.
 Device discovery begins. It displays a graph showing the status of the discovery operation. Initially, three devices are discovered. When the Junos Space software has accessed all three devices and brought them under its management, all three devices move from the Discovered column of the graph to the Managed column.
11. To check the results of the device discovery operation, select the **Devices** workspace again, then select **Device Management**. The **Manage Devices** page shows the added devices.

SEE ALSO

Device Discovery Overview in the Junos Space Network Application Platform User Guide
Discovering Devices in the Junos Space Network Application Platform User Guide

Preparing Devices for Prestaging

Before prestaging devices for multipoint-to-multipoint services, the following entities must be configured:

- MPLS must run on each N-PE device.
- MPBGP must run on each N-PE device that you want to participate in a multipoint-to-multipoint service.

To satisfy the preceding criteria, ensure that the following configuration exists on each N-PE device:

```

interfaces {
  ge-0/0/0 {
    unit 0 {
      family inet {
        address 10.1.22.2/30;
      }
      family mpls;
    }
  }
}

lo0 {
  unit 0 {

```

```

        family inet {
            address 192.168.1.30/32;
        }
    }
}

routing-options {
    autonomous-system 65410;
}

protocols {
    mpls {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
    bgp {
        group CA-Peer {
            type internal;
            local-address 192.168.1.30;
            family l2vpn {
                signaling;
            }
            neighbor 192.168.1.40;
            neighbor 192.168.1.10;
            neighbor 192.168.1.20;
            neighbor 192.168.1.50;
            neighbor 192.168.1.60;
        }
    }
    ospf {
        traffic-engineering;
        area 0.0.0.0 {
            interface lo0.0 {
                passive;
            }
            interface ge-0/0/0.0;
        }
    }
    ldp {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
}

```


NOTE: The OSPF configuration is not required in prestaging.

The E-LAN service needs to be enabled in a network device, to make the static pseudowire functionality active in the device. You can activate the static pseudowire functionality by configuring the network device through the CLI window. You need to enter the CLI configuration mode of a network element and run the command

```
set protocols vpls static-vpls no-tunnel-services
```

```
commit
```

If the device is not configured through CLI, a warning message appears in the application server log, that is the **JBOSS Log**:

To discover and assign the roles of devices:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

View the values displayed under the Roles column of the discovered devices.

This action launches the role discovery process in which the Network Services application examines the devices under Junos Space management looking for devices that match predefined rules that identify N-PE devices. In this example, the Role Discovery Status graph shows that the Network Services application has discovered two such devices.

4. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.
5. To view the assignment status, in the **CSD Deployment Jobs** window that you can access from Deploy mode of Service View by selecting **View Deployment Jobs** from the task pane, click the job ID of the assignment job.

The **Job Management** page shows the progress and status of the role assignment job.

6. To verify the result, in Build mode, select **Prestage Devices > Manage Device Roles** from the tasks pane.

The **Manage Device Roles** window shows two devices that can be used for provisioning.

7. To unassign a device from N-PE role assignment, click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

To re-sync the role of the network elements configured:

1. Select **Prestage Devices > Prestage Devices** from the tasks pane. The Devices Chart page is displayed.
2. To re-sync the role capability of a network element, select the network element's name, and open the **Manage Device Roles** menu.
3. Click **Re-sync Role Capability**. The **Re-sync Role Capability** window appears where you can select the device's name and click **Re-sync**.

The role is re-synced with the same device now.

Discovering and Assigning N-PE Roles

Before you can provision services, you must prestage the devices. prestaging includes assigning device roles and designating interfaces on those devices as UNIs. This example provides the steps to accept the recommendations of the Network Services application for N-PE devices and UNIs.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Service View** task pane, select **Network Services**.
4. In the **Tasks** task pane, select **Prestage Devices > Prestage Devices**.

View the values displayed under the Roles column of the discovered devices.

This action launches the role discovery process in which the Network Services application examines the devices under Junos Space management looking for devices that match predefined rules that identify N-PE devices. In this example, the Role Discovery Status graph shows that the Network Services application has discovered two such devices.

5. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

6. To view the assignment status, in the **CSD Deployment Jobs** window that you can access from Deploy mode of Service View by selecting **View Deployment Jobs** from the task pane, click the job ID of the assignment job.

The **Job Management** page shows the progress and status of the role assignment job.

7. To verify the result, in Build mode, select **Prestage Devices > Manage Device Roles** from the tasks pane.

The **Manage Device Roles** window shows two devices that can be used for provisioning.

8. To unassign a device from N-PE role assignment, click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

SEE ALSO

[Discovering and Assigning All N-PE Devices | 366](#)

[Discovering and Assigning N-PE Devices with Exceptions | 367](#)

Choosing or Creating a Service Definition

A service definition provides a template upon which services are built. It specifies service attributes that are not specific to a service instance. In this example, the service definition provides all service attributes except the N-PE devices, the UNIs, and bandwidth.

The Network Services application ships with standard service definitions. First, we check the standard service definitions to determine whether one already exists that can work.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services** task pane, select **Connectivity**.
4. In the **Tasks** task pane, select **Service Design > Manage Service Definitions**

The **Manage Service Definitions** page lists all service definitions in the system. In a new system, the page lists only predefined service definitions.

This example requires a multipoint-to-multipoint service definition with UNIs that use 802.1Q interfaces and allow you to set a bandwidth of 25 Mbps. The standard service definitions have several examples for provisioning 802.1Q UNIs, but none that allow the setting of a 25 Mbps bandwidth limit. You need to create a new service definition.

5. In the Manage Service Definitions page, click **New > E-LAN Service Definition**.

The General Settings window appears.

6. Enter a name for the service definition.

7. Click **Next**.

8. In the **Site Settings** window, in the **VLAN Tagging** field, select **dot1q**.

9. In the **Physical Interface Encapsulation** field, select **flexible-ethernet-service**.

10. In the **Logical Interface Encapsulation** field, select **vlan-vpls**.

11. In the **Traffic type** field, select **Transport single VLAN**.

12. Because we intend to select a specific VLAN for each endpoint in the service—leave the Normalized VLAN setting as the default **Normalization not required**.

13. In the **VLAN ID selection** field, choose **Select manually**.

14. In the **VLAN range for manual input**, specify the range.

NOTE: When the range of VLAN IDs that are automatically assigned by the system (with the auto-pick option enabled during the creation of a service definition) is less than or greater than the range of VLAN IDs that are manually specified (with the manual selection option enabled during the creation of a service definition), the following conditions apply during the creation of a service order with the Editable in Service Order check box selected during service definition creation:

- If you create a service order with the auto-pick option enabled, the VLAN ID is selected from the auto-pick range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.
- If you create a service order with the auto-pick option disabled, the VLAN ID is selected from the manually configured range, and the value is displayed in the VLAN range for manual input field. If you attempt to change the VLAN ID manually, the value is restricted to the manually configured range.

15. In the **Outer Tag protocol ID**, select **0x8100**

16. In the **PE-CE Interface Rate Limiting Settings** panel, select the **Enable Interface Rate Limiting** check box.

17. In the **Rate Limit (Mbps)** field, enter **10**, for a default bandwidth of 10 Mbps.

18. To the right of the value you just entered, select the **Editable in service order** check box.

The **Rate Limit Range for manual-config (Min in Kbps, Max in Mbps)** and **Increment (Kbps)** fields become active.

19. In the **Rate Limit Range for manual-config (Min in Kbps, Max in Mbps)** fields, enter **10** and **64** respectively.

20. In the **Increment** field, enter **64**.

21. Click **Next** to proceed to the Review page of the wizard.

22. To save and complete the service definition, click **Done**.

The **Manage Service Definitions** page includes the new service definition.

You have created a customized Service Definition, but it has not yet been published. Before a service definition can be used in provisioning, it must be published.

23. To publish the service definition, in the **Manage Service Definitions** page, select the vpls-dot1q-sd-1 service definition, and click the **Publish** button.

The **Information** window appears.

24. To confirm that you want to publish this service definition, click **Yes**.

In the **Manage Service Definitions** page, the **State** column changes to Published.

The service definition is now ready for use in provisioning.

SEE ALSO

Predefined Service Definitions

Creating a Multipoint-to-Multipoint VPLS Service Definition

Publishing a Custom Service Definition

Creating a Customer

Before you can provision the service, customer details must be present in the Junos Space data base. To add a customer:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Service View** task pane, select **Customers**.
4. In the **Tasks** task pane, select **Customer > Manage Customers**.
5. In the **View Customers** task pane, select **Add (+)**.
6. In the **Name** field, enter **Best Customer**.
7. In the **Account number** field, enter **1234**.
8. Click **Create**.

The **Manage Customers** page shows the new customer.

SEE ALSO

| *Adding a New Customer*

Creating and Deploying a Multipoint-to-Multipoint Service Order

Now that you have prestaged your devices, created a suitable service definition, and added the customer information to the database, you are ready to create and deploy a service order.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services > E-LAN Services to expand the tree and display the different service types that you can configure.
4. Select **Manage Services** from the task pane. The right pane displays two pages. The Manage Network Services page is displayed in the upper half of the right pane. Selecting a service from this page causes the associated service orders for the selected service to be displayed in the Manage Service Orders page in the lower half of the right pane.
5. Click the **New** icon at the top of the upper half of the page that displays previously created service orders.
6. In the Name field of the **Service Settings** window, in the **Name** field, enter **vppls_so_1**.
7. In the **Customer** field, select the customer for which you are creating the service order.
8. In the **Service Definition** field, select the service definition named **vppls-dot1q-sd-1**.
This service definition is the customized service definition you created earlier.
9. Click **Next**.
10. In the Node Settings page, add the **BLR**, **SFO**, and **SJC** devices or endpoints, and configure the roles of the devices.
11. Click **Next**.

12. In the Site Settings page, in the **Rate Limit** field, select **25**.
13. Clear the **Autopick VLAN ID** check box.
14. In the **VLAN ID** field, enter **600**.
15. Click **Next** to proceed to the Review page, which is the final step of the wizard.
16. Click **Done**. The E-LAN service order is created.
17. Select the created E-LAN service order in the Manage Service Orders page. You can save the service order for later deployment, schedule the service order for later deployment, or deploy the service order now. Click **Deploy now**.
18. Click **OK** to start the deployment.
19. To monitor the progress and status of the deployment, in the Manage Service Orders page, click the job ID under the Latest Job field. The **Job Management** page shows the status of the job.
20. When you see in the **Job Management** window that the deployment is successful, in the Network Services task pane, select the **Service Provisioning** workspace again.
21. In the task pane, select **Deploy Services**.

The **Manage Network Services** page, which is displayed in the top half of the right pane, shows the new service.

SEE ALSO

Creating a Multipoint-to-Multipoint VPLS Service Order

Deploying a Service Order

Performing a Functional Audit and a Configuration Audit

Now that your new service is deployed, we recommend that you validate its configuration and functional integrity. A functional audit runs operational commands on the device to verify that the service is up or down. A configuration audit verifies whether the configuration that was pushed to the device during deployment is actually on the device.

To perform a configuration audit and a functional audit of the service:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services > E-LAN Services to expand the tree and display the different service types that you can configure.
4. Select **Manage Services** from the task pane. The right pane displays two pages. The Manage Network Services page is displayed in the upper half of the right pane. Selecting a service from this page causes the associated service orders for the selected service to be displayed in the Manage Service Orders page in the lower half of the right pane.
5. In the **Manage Network Services** page, select the service instance you just deployed.
6. Select the service instance, click the **Audit** menu and select **Functional Audit > Run Functional Audit**.
7. In the **Schedule Functional Audit** window, you can choose to perform the audit now or schedule it for later. Select **Audit now**, then click **OK**.
8. In the **Order Information** screen, click **OK**.
9. Select the service instance, click the **Audit** menu and select **Configuration Audit > Run Configuration Audit**.
10. In the **Schedule Configuration Audit** window, you can choose to perform the audit now or schedule it for later. Select **Audit now**, and then click **OK**.
11. In the **Order Information** window, click **OK**.

When the audit jobs have finished, success is indicated by an up arrow in the top right corner of the service.
12. To view the functional audit results, select the service instance and click **Audit > Functional Audit > View Results**.

In the **Functional Audit Results** window, select each device to view the results.
13. To view the results of the configuration audit, select the service instance and click **Audit > Configuration Audit > View Results**.

In the **Configuration Audit Results** window, select each device in turn and review the results. This report indicates any part of the service configuration that is missing on the device, or is inconsistent with the Junos Space database.

Following a successful audit, the service is deployed and ready to be used.

RELATED DOCUMENTATION

Device Discovery Overview in the Junos Space Network Application Platform User Guide

Discovering Devices in the Junos Space Network Application Platform User Guide

Example: Configuring and Deploying an IP Full-Mesh Service

IN THIS SECTION

- [Preparing Devices for Discovery | 1370](#)
- [Discovering Devices | 1371](#)
- [Preparing Devices for Prestaging | 1372](#)
- [Discovering and Assigning N-PE Roles | 1374](#)
- [Choosing or Creating a Service Definition | 1375](#)
- [Creating a Customer | 1376](#)
- [Creating and Deploying an IP Service Order | 1377](#)
- [Performing a Functional Audit and a Configuration Audit | 1379](#)

This example shows how to set up a simple full-mesh service provider VPN configuration, as shown in [Figure 27 on page 1370](#).

Figure 27: Simple IP Full-Mesh Service





Figure 28: Example of a Simple VPN Topology



This service provides connectivity for one VLAN, (VLAN ID = 600). Customer site A connects to the network through an N-PE device named SJC (IP address 1.1.1.1). Customer site B connects to the network through an N-PE device named SFO (IP address 1.1.1.2). Customer site C connects to the network through an N-PE device named BLR (IP address 1.1.1.3).

Preparing Devices for Discovery

Before you can add a device using device discovery, the following conditions must be met:

- SSH v2 is enabled on the device. To enable SSH v2 on a device, issue the following CLI command:

```
set system services ssh protocol-version v2
```

- The NETCONF protocol over SSH is enabled on the device. To enable the NETCONF protocol over SSH on a device, issue the following CLI command:

```
set system services netconf ssh
```

- The device is configured with a static management IP address that is reachable from the Junos Space server. The IP address can be in-band or out-of-band.
- A user with full administrative privileges is created on the device for the Junos Space administrator.
- If you plan to use SNMP to probe devices as part of device discovery, ensure that SNMP is enabled on the device with appropriate read-only V1/V2C/V3 credentials.

Discovering Devices

Device discovery is a process that Junos Space uses to bring network devices under its control. This example brings two MX Series routers under Junos Space management.

NOTE: Alternatively, you can import devices using the Connectivity Services Director GUI. See *Discovering Devices in a Physical Network* for instructions on discovering devices from Build mode of Connectivity Services Director.

1. Log in to Junos Space using your credentials.
2. From the Junos Space Network management Platform user interface, select **Devices > Discover Devices > Discover Targets**.
3. In the **Discover Targets** window, click **+**.
The **Add Device Target** window appears.
4. Select **IP range**.
5. Enter the IP address information. This example uses a range of three addresses.
6. Click **Add**, and then click **Next**.
7. In the Devices: **Specify Probes** window, select both **Ping** and **SNMP** as probes.

8. Click **Next**.

9. In the Devices: **Specify Credentials** window, click + and enter the device login credentials.

10. Click **Finish**.

Device discovery begins. It displays a graph showing the status of the discovery operation. Initially, three devices are discovered. When the Junos Space software has accessed all three devices and brought them under its management, all three devices move from the Discovered column of the graph to the Managed column.

11. To check the results of the device discovery operation, select the **Devices** workspace again, then select **Device Management**. The **Manage Devices** page shows the added devices.

SEE ALSO

Device Discovery Overview in the Junos Space Network Application Platform User Guide

Discovering Devices in the Junos Space Network Application Platform User Guide

Preparing Devices for Prestaging

Before prestaging devices for multipoint-to-multipoint services, the following entities must be configured:

- MPLS must run on each N-PE device.
- MPBGP must run on each N-PE device that you want to participate in a Layer 3 full mesh service.

To satisfy the preceding criteria, ensure that the following configuration exists on each N-PE device:

```
interfaces {
  ge-0/0/0 {
    unit 0 {
      family inet {
        address 10.1.22.2/30;
      }
      family mpls;
    }
  }
}

lo0 {
  unit 0 {
```

```

        family inet {
            address 192.168.1.30/32;
        }
    }
}

routing-options {
    autonomous-system 65410;
}

protocols {
    mpls {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
    bgp {
        group IBGP {
            type internal;
            local-address 192.168.10.1;
            family inet-vpn {
                unicast;
            }
            peer-as 65410;
            neighbor 192.168.10.4;
        }
    }
    ospf {
        traffic-engineering;
        area 0.0.0.0 {
            interface lo0.0 {
                passive;
            }
            interface ge-0/0/0.0;
        }
    }
    ldp {
        interface ge-0/0/0.0;
        interface lo0.0;
    }
}

```

Discovering and Assigning N-PE Roles

Before you can provision services, you must prestage the devices. prestaging includes assigning device roles and designating interfaces on those devices as UNIs. This example provides the steps to accept the recommendations of the Network Services application for N-PE devices and UNIs.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**.

View the values displayed under the Roles column of the discovered devices.

This action launches the role discovery process in which the Network Services application examines the devices under Junos Space management looking for devices that match predefined rules that identify N-PE devices. In this example, the Role Discovery Status graph shows that the Network Services application has discovered two such devices.

4. Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.
5. To view the assignment status, in the **CSD Deployment Jobs** window that you can access from Deploy mode of Service View by selecting **View Deployment Jobs** from the task pane, click the job ID of the assignment job.

The **Job Management** page shows the progress and status of the role assignment job.

6. To verify the result, in Build mode, select **Prestage Devices > Manage Device Roles** from the tasks pane.

The **Manage Device Roles** window shows two devices that can be used for provisioning.

7. To unassign a device from N-PE role assignment, click **Manage Device Roles** and from the drop-down list, select **Unassign Role** to remove the role capability of a network element. You are prompted to confirm the operation. If you click **OK**, a request is submitted to remove the latest role of the network element or device.

SEE ALSO

Prestaging Devices Overview

Discovering and Assigning All N-PE Devices

Discovering and Assigning N-PE Devices with Exceptions

Choosing or Creating a Service Definition

A service definition provides a template upon which services are built. It specifies service attributes that are not specific to a service instance. In this example, the service definition provides all service attributes except the N-PE devices, the UNIs, and bandwidth.

The Network Services application ships with standard service definitions. First, we check the standard service definitions to determine whether one already exists that will work.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Service Design > Manage Service Definitions**.

The **Manage Service Definitions** page lists all service definitions in the system. In a new system, the page lists only predefined service definitions.

This example requires a L3 VPN full mesh service definition with OSPF/Static routing to allow each PE router to distribute VPN-related routes to and from connected CE routers.

4. In the **Network Services > Connectivity** task pane, select **Service Design > Manage Service Definitions > New > IP Service Definition**.

The General Settings window appears.

5. In the name field, enter the name "l3vpn-ospf-static-full-mesh-sd" for the service definition.
6. In the **Service type** field, select **L3 VPN (Full Mesh)**.

NOTE: This service definition does not include a service template definition for the service, so the **Service Template Definition** field is left blank.

7. In the **Connectivity Settings** box, select **Auto pick Route Distinguisher** to allow the Network Services application to automatically select the route distinguisher.

8. Click **Next** to save the General Settings step information.

Continue with “Site Settings” next.

9. In the VLAN ID selection field, select **Select manually** to have the service provisioner select a VLAN ID for the service.
10. To enable the service provisioner to override this setting in a service order, select the **Editable in service order** check box.
11. In the **VLAN range for manual input**, enter “500” and “700” for VLAN ID start and end values to restrict the range of VLANs to this pool.
12. In the PE-CE Settings box, select the **OSPF/Static Route** radio button for Allowed Routing Protocols to use OSPF/Static to allow each PE router to distribute VPN-related routes to and from connected CE routers.
13. Click **Review** to review and create the IP service definition.
14. To save and complete the service definition, click **Finish**.

The **Manage Service Definitions** page includes the new service definition.

You have created a customized Service Definition, but it has not yet been published. Before a service definition can be used in provisioning, it must be published.

15. To publish the service definition, in the **Manage Service Definitions** page, select the vpls-dot1q-sd-1 service definition, and click the **Publish Service Definition** button.

The **Publish Service Definition** window appears.

16. To confirm that you want to publish this service definition, click **Publish**.

In the **Manage Service Definitions** page, the **State** column changes to Published.

The service definition is now ready for use in provisioning.

Creating a Customer

Before you can provision the service, customer details must be present in the Junos Space database. To add a customer:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. In the **Network Services > Connectivity** task pane, select **Service Provisioning > Manage Customers > Create Customer**.
4. In the **Name** field, enter **Best Customer**.
5. In the **Account number** field, enter **1234**.
6. Click **Create**

The **Manage Customers** window shows the new customer.

SEE ALSO

| *Adding a New Customer*

Creating and Deploying an IP Service Order

Now that you have prestaged your devices, created a suitable service definition, and added the customer information to the database, you are ready to create and deploy a service order.

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services > VPLS Services to expand the tree and display the different service types that you can configure.
4. Select **Deploy Services** from the task pane. The right pane displays two pages. The Manage Network Services page is displayed in the upper half of the right pane. Selecting a service from this page causes the associated service orders for the selected service to be displayed in the Manage Service Orders page in the lower half of the right pane.

5. Click the **New** icon at the top of the upper half of the page that displays previously created service orders. The Select Service Type dialog box appears.

6. Select **IP** to create an IP service order.

The General/Connectivity Settings panel appears initially in the right panel, as shown in the example.

7. In the **Create L3 VPN Service Order** window, select the service definition named **l3vpn-ospf-static-full-mesh-sd**.

This service definition is the customized service definition you created earlier.

8. In the **General Settings** box of the **Service Settings** window, in the **Name** field, enter **l3vpn_ospf_full_mesh_so**.

9. In the **Customer** field, select **Best Customer**.

10. In the PE-CE Settings box, enter "1.1.1.1" as the **OSPF domain ID**.

11. Click **Next**.

12. In the **Node Settings** window, select **BLR**, **SFO**, and **SJC** as the endpoint devices.

13. Click **Next**.

14. In the **Site Settings** window, clear the **Autopick VLAN ID** check box (the default setting).

15. In the VLAN ID field, enter "600".

16. In the **Interface IP** field, enter an IP address/subnet for the device, for example, 10.255.245.68/28.

17. In the **OSPF area ID** field, enter an IP address for the OSPF area.

18. Click **Save**.

19. Repeat Step 10 through Step 12, for each endpoint device that you want to include in the service.

20. Click **Next**. The Review page of the wizard is displayed.

21. Click **Done**. The service order is created and listed in the Manage Service Orders page.

22. You can schedule the deployment of the service order for a specific time, or deploy the service now. Select **Deploy now** and click **OK** to start the deployment.
23. To monitor the progress and status of the deployment, in the Order Information window, click the job ID. The **Job Management** page shows the status of the job.
24. When you see in the **Job Management** page that the deployment is successful, in the **Network Services** task pane, select the **Service Provisioning > Manage Deploy Services**.
The **Manage Network Services** page shows the new IP full mesh service.

Performing a Functional Audit and a Configuration Audit

Now that your new service is deployed, we recommend that you validate its configuration and functional integrity. A functional audit runs operational commands on the device to verify that the service is up or down. A configuration audit verifies whether the configuration that was pushed to the device during deployment is actually on the device.

To perform a configuration audit and a functional audit of the service:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services > E-Line Services to expand the tree and display the different service types that you can configure.
4. Select **Deploy Services** from the task pane. The right pane displays two pages. The Manage Network Services page is displayed in the upper half of the right pane. Selecting a service from this page causes the associated service orders for the selected service to be displayed in the Manage Service Orders page in the lower half of the right pane.
5. In the **Manage Network Services** page, select the service instance you just deployed.
6. Select the service instance, and open the **Actions** menu and select **Run Functional Audit**.
7. In the **Schedule Functional Audit** window, you can choose to perform the audit now or schedule it for later. Select **Audit now**, then click **OK**.

8. In the **Order Information** screen, click **OK**.
9. Select the service instance, and open the **Audit** menu and select **Run Configuration Audit**.
10. In the **Schedule Configuration Audit** window, you can choose to perform the audit now or schedule it for later. Select **Audit now**, and then click **OK**.
11. In the **Order Information** window, click **OK**.

When the audit jobs have finished, success is indicated by an up arrow in the top right corner of the service.

12. To view the functional audit results:

- a. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
- b. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
- c. From the **Network Services > Connectivity > IP Services** View pane, select the **l3vpn_ospf_full_mesh_so** service instance.
- d. In the tasks pane, select **Audit/Results > Functional Audit**.
- e. In the **Functional Audit Results** window, select each device to view the results.

13. To view the results of the configuration audit:

- a. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
- b. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
- c. From the **Network Services > Connectivity > IP Services** View pane, select the **l3vpn_ospf_full_mesh_so** service instance.
- d. In the tasks pane, select **Audit/Results > Configuration Audit**.
- e. In the **Configuration Audit Results** window, select each device in turn and review the results. This report indicates any part of the service configuration that is missing on the device, or is inconsistent with the Junos Space database.

Following a successful audit, the service is deployed and ready to be used.

16

PART

Working with Chassis View

[Working with Devices](#) | **1383**

[Managing CLI Configlets](#) | **1396**

Working with Devices

IN THIS CHAPTER

- [About Chassis View | 1383](#)
- [Accessing the Chassis View from the Physical Inventory Page | 1384](#)
- [Viewing a Graphical Image of the Chassis and Components | 1385](#)
- [Deleting Devices from Chassis View | 1393](#)
- [Rebooting Devices After Examining the Status in Chassis View | 1394](#)

About Chassis View

You can view a high-level, graphical representation of the chassis. It indicates the state of the interfaces. When the administrative and operational status of the interface is up, it is displayed in green. If the administrative status is down, the interface is displayed in grey. And, if the administrative status is up and operational status is down, the interface is displayed in red. The image is a replica of the device. If you are connected to a virtual chassis, the image includes all the member switches of the virtual chassis. The chassis view also displays a count of alarms generated in the system; major alarms are displayed in red, and minor alarms in orange.

The purpose of the view is to try and provide a comprehensive monitoring view of the health and status of deployed devices across the network. In this view all the managed devices are shown with their appropriate status and health based on the services and device settings applied. This view helps the operator to know the health and status across the network, it provides with the operator to quickly see the macro level information, which allows the operator to further analyze the information provided and quickly navigate to individual devices and take any further corrective measure required. It provides a cohesive tool for the operator to quickly see the micro-level information and take any further remediation action required.

To view a pictorial representation of a device chassis and the configured components, such as interfaces, line cards, and hardware elements, select a managed device listed in the My Network tree in Device View of Build mode of the Connectivity Services Director GUI, and select **Device Management > View Physical Inventory** from the tasks pane. The right pane displays the device image and the corresponding description of the view selected in a tabular manner. The chassis view is displayed. The hardware and line module details are displayed with a pictorial view of the slots of the devices and the modules installed in these

slots. The device image can be rotated to view the front, rear, top, bottom, right and left planes of the device by clicking the respective arrow buttons on the page. The View Front icon and the View Back icon are denoted by a square icon with downward and upward arrows in the square. The View Front and View Back icons are toggle buttons. The device image can be rotated in various orientation along 360 degree. You can use the navigation options for rotating devices to view different planes on the device and the components installed on each plane. The front view displays the components installed and the interfaces configured on the device. Click Refresh to update the contents of the page.

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[Accessing the Chassis View from the Physical Inventory Page | 1384](#)

Accessing the Chassis View from the Physical Inventory Page

The Dashboard page is the landing page that is displayed when you login to the Connectivity Services Director application. You can view all the available devices that are managed by Connectivity Services Director from the Device Inventory page. The Device Inventory page is accessible in Device View of Build mode as the default landing page. Alternatively, select **View Inventory** in the task pane to open the Device Inventory page. Based on your selection of routers, the Device Inventory page displays device details.

The Device Inventory page varies based on your selection in the View pane. When you select a node in the View pane, the inventory of all devices that are included under that node is displayed.

For example:

- Device View and My Network is selected: Displays all the devices that are managed by Connectivity Services Director.

You can view the physical inventory of all the devices in your network in the Device Physical Inventory page. The Device Physical Inventory page displays information about the slots that are available for a device and provides information about power supplies, chassis cards, fans, part numbers, and so on. Connectivity Services Director displays hardware inventory by device name, based on data retrieved both from the device during discovery and resynchronizing operations, and from the data stored in the hardware catalog. For each managed device, the physical inventory page provides descriptions for field replaceable units (FRUs), part numbers, model numbers, and the pluggable locations from which empty slots are determined.

To view a pictorial representation of a device chassis and the configured components, such as interfaces, line cards, and hardware elements, select a managed device listed in the My Network tree in Device View

of Build mode of the Connectivity Services Director GUI, and select **Device Management > View Physical Inventory** from the tasks pane.

The following are the different device types in the device families that are supported in Chassis view:

- MX Series routers—MX5, MX10, MX40, MX240, MX480, MX960, MX2010, MX2020, MX80, MX80-P, MX80-T, MX80-48-T, MX150, MX204, MX10003
- ACX Series routers—ACX1000, ACX1100, ACX2000, ACX2100, ACX2200, ACX4000, ACX500-DC, ACX500-O, ACX500-O-POE, ACX5048, ACX5096, ACX5448
- PTX Series routers—PTX3000, PTX5000, PTX1000

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[About Chassis View | 1383](#)

[Service Monitoring Capabilities in Connectivity Services Director | 1252](#)

Viewing a Graphical Image of the Chassis and Components

The Chassis view provides a pictorial representation of the chassis or device, and the modules or components that are installed in it, such as the line cards, interfaces, and other hardware elements

To view a graphical image of the chassis and its associated components:

1. From the View selector, select **Device View**. The functionalities that you can configure in this view are displayed.
2. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and view the list of devices. Select the device for which you want to define the optical port settings.
3. From the Tasks pane, select **Device Management > View Physical Inventory**. A graphical view of the device is displayed on the right pane.
4. Click a particular module to display the associated details in the lower half of the page. The Rotate and Perspective buttons enable you to view the images in required orientation.
5. Click the Rotate (arrows in a square symbol) icon to cause the device image to continuously rotate along the x-axis.

6. Click the Perspective (cube symbol) icon to display the device image in three-dimensional format. It is a toggle button, which causes the device image to be shown in either three-dimensional or one-dimensional format.
7. Select the level of magnification of the image by clicking the Zoom (magnifying glass) icon. The image is expanded and displayed. Alternatively, use the slider control beneath the Zoom icon to change the level of magnification.
8. Click the home icon to return to the front view of the chassis. The selected interface is surrounded with a colored outline based on the operational status as suggested below. An interface that is operationally up is denoted in green and an interface that is operationally down is represented in red. The components are depicted as small colored icons at the top left corner of the front-view equipment image.

In the graphical image of the device displayed, you can mouse over the different parts of the device, such as the interfaces, line cards, and slots. When you mouse over the different modules, their corresponding details are displayed as tooltips. On clicking the device components, the corresponding description for the selected component is displayed by default under the Component Info pane and the Equipment tab with the following values.

- Manufacturer—Name of the company that built and shipped the device.
- Part number—Part number of the chassis component.
- Serial number—Serial number of the chassis component. The serial number of the backplane is also the serial number of the router or switch chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

When you select any physical interface configured on the DPCs or PICs or MICs provisioned, the following fields are displayed for the corresponding component for each interface. The interface is surrounded by a colored box to show the Operational Status.

The Component Info pane and the Active Alarms monitor are displayed in the lower half of the page.

The Active Alarms monitor shows any active alarm that has not yet been cleared. You can view the alarm name, the unique identifier assigned to the alarm, the person to which the alarm is assigned for corrective action, and the severity of the alarm. Click the **Launch Alarm Mgmt** icon (right upward-slanting arrow enclosed in a square) to navigate to the Fault mode and view the four standard alarm monitors available in Fault mode.

Active Alarms for the respective components are displayed when the component is clicked in the graphical image of the chassis displayed. The components for which the alarms are displayed are Flexible Port Concentrator (FPC), Dense Port Concentrator (DPC), Physical Interface Card (PIC), Modular Interface Card (MIC), Routing Engine, Control Boards, fan trays, Switch Interface Board (SIB), and power supply module (PSM).

The following fields are displayed in the Active Alarms pane:

Table 176: Active Alarms Monitor

Table Column	Description
Severity	<p>The severity of the alarm. Severity levels are:</p> <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary.
Name	The alarm name.
Source	<p>The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.</p>
Last Updated	The date and time that the information for the alarm was last modified.

The following fields are displayed in the Component Info pane:

Table 177: Fields for Physical Interfaces in the Component Info Pane

Field	Description
Host Name	Hostname of the device.
Physical Interface Name	Name of the physical interface.
IP Address	IP address configured on the interface.
Encapsulation	Encapsulation configured on the logical interface.
Hardware Address	MAC address configured on the interface
Operation Status	Operational status of the physical interface: Up, Down.
Admin Status	Administrative state of the interface: Enabled or Disabled. If the interface is disabled, it can provide network connectivity, but it cannot provide power to connected devices.
Link Level Type	Encapsulation type configured on the interface.
Link Type	Data transmission type.

Table 177: Fields for Physical Interfaces in the Component Info Pane (*continued*)

Field	Description
Speed	Speed at which the interface is running.
MTU	Maximum transmission unit size on the physical interface.
Loopback	Specifies whether the loopback status is enabled or disabled. If loopback is enabled, type of loopback: Local or Remote.
Description	Configured textual description of the interface.

A redundant Ethernet interface is a pseudointerface that includes at minimum one physical interface from each node of the cluster. A redundant Ethernet interface must contain, at minimum, a pair of Fast Ethernet interfaces or a pair of Gigabit Ethernet interfaces that are referred to as child interfaces of the redundant Ethernet interface (the redundant parent). If two or more child interfaces from each node are assigned to the redundant Ethernet interface, a redundant Ethernet interface link aggregation group must be formed.

A pseudowire subscriber logical interface terminates an MPLS pseudowire tunnel from an access node to the MX Series router that hosts subscriber management, and enables you to perform subscriber management services at the interface. Subscriber management supports the creation of subscriber interfaces over E-Line MPLS pseudowires. The pseudowire subscriber interface capability enables service providers to extend an MPLS domain from the access-aggregation network to the service edge, where subscriber management is performed. Service providers can take advantage of MPLS capabilities such as failover, rerouting, and uniform MPLS label provisioning, while using a single pseudowire to service a large number of DHCP and PPPoE subscribers in the service network.

NOTE: The pseudowire is a tunnel that is either an MPLS-based Layer 2 VPN or Layer 2 circuit. The pseudowire tunnel transports Ethernet encapsulated traffic from an access node (for example, a DSLAM or other aggregation device) to the MX Series router that hosts the subscriber management services. The termination of the pseudowire tunnel on the MX Series router is similar to a physical Ethernet termination, and is the point at which subscriber management functions are performed. A service provider can configure multiple pseudowires on a per-DSLAM basis and then provision support for a large number of subscribers on a specific pseudowire. Figure 1 shows an MPLS network that provides subscriber management support.

The following table describes the fields displayed in the Pseudo Interfaces pane.

Table 178: Pseudo Interfaces Columns

Field	Description
Pseudo Interface Name	Name of the pseudowire subscriber logical interface.
Type	Signaling type for the pseudowire interface. You can use either Layer 2 circuit signaling or Layer 2 VPN signaling. The two signaling types are mutually exclusive for a given pseudowire.
Operation Status	Operational status of the physical interface: Up, Down.
Admin Status	Administrative state of the interface: Enabled or Disabled. If the interface is disabled, it can provide network connectivity, but it cannot provide power to connected devices.

The logical interfaces configured on each interface are also shown along with the physical interface description in a tabular format. The following table describes the details displayed for logical interfaces.

Table 179: Logical Interfaces Columns

Field	Description
Device Name	The device configuration name.
Interface Name	Standard information about the interface, in the format type-/fpc/pic/port/logical interface, where type is the media type that identifies the network device; for example, ge-0/0/6.135.
IP Address	The IP address for the logical interface.
Encapsulation	The encapsulation type used on the logical interface.
Vlan	The VLAN ID for the logical interface.
Description	An optional description configured for the interface. It can be any text string of 512 or fewer characters. Any longer string is truncated. If there is no information, the column entry is blank.

From the chassis view window, click the **Details** icon (arrow enclosed in a square) at the top-right corner of the window to open the Chassis View Details page that lists the configured devices and their parameters in the form of a table.

The following fields are displayed on the right pane, depending on the component or element of the chassis you selected from the chassis image displayed.

Table 180: Fields in the Chassis View Details Page

Field	Description
Module	Name of the SDG and the platform type, such as MX240 or MX480. Click the plus sign (+) to expand the tree to display the components of the device, such as chassis, PIC, CPU, and PIC parameters. Information about the chassis, midplane, craft interface (FPM), power midplane (PMP), Power Supply Modules (PSMs), Power Distribution Modules (PDMs), Routing Engines, Control Boards (CBs) and Switch Processor Mezzanine Boards (SPMBs), Switch Fabric Boards (SFBs), Flexible PIC Concentrators (FPCs), PICs, adapter cards (ADCs) and fan trays is displayed.
Model Number	Model number of the FRU hardware component.
Model	Model of the FRU component.
Part Number	Part number of the chassis component.
Serial Number	Serial number of the chassis component. The serial number of the backplane is also the serial number of the router chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

Table 180: Fields in the Chassis View Details Page (continued)

Field	Description
Description	

Table 180: Fields in the Chassis View Details Page (*continued*)

Field	Description
	<p>Brief description of the hardware item:</p> <ul style="list-style-type: none"> • Type of power supply. • Type of PIC. If the PIC type is not supported on the current software release, the output states Hardware Not Supported. • Type of FPC: FPC Type 1, FPC Type 2, FPC Type 3, FPC Type 4 , or FPC TypeOC192. On EX Series switches, a brief description of the FPC. On the J Series routers, the FPC type corresponds to the Physical Interface Module (PIM). The following list shows the PIM abbreviation in the output and the corresponding PIM name. <ul style="list-style-type: none"> • 2x FE—Either two built-in Fast Ethernet interfaces (fixed PIM) or dual-port Fast Ethernet PIM • 4x FE—4-port Fast Ethernet ePIM • 1x GE Copper—Copper Gigabit Ethernet ePIM (one 10-Mbps, 100-Mbps, or 1000-Mbps port) • 1x GE SFP—SFP Gigabit Ethernet ePIM (one fiber port) • 4x GE Base PIC—Four built-in Gigabit Ethernet ports on a J4350 or J6350 chassis (fixed PIM) • 2x Serial—Dual-port serial PIM • 2x T1—Dual-port T1 PIM • 2x E1—Dual-port E1 PIM • 2x CT1E1—Dual-port channelized T1/E1 PIM • 1x T3—T3 PIM (one port) • 1x E3—E3 PIM (one port) • 4x BRI S/T—4-port ISDN BRI S/T PIM • 4x BRI U—4-port ISDN BRI U PIM • 1x ADSL Annex A—ADSL 2/2+ Annex A PIM (one port, for POTS) • 1x ADSL Annex B—ADSL 2/2+ Annex B PIM (one port, for ISDN) • 2x SHDSL (ATM)—G SHDSL PIM (2-port two-wire module or 1-port four-wire module) • 1x TGM550—TGM550 Telephony Gateway Module (Avaya VoIP gateway module with one console port, two analog LINE ports, and two analog TRUNK ports) • 1x DS1 TIM510—TIM510 E1/T1 Telephony Interface Module (Avaya VoIP media module with one E1 or T1 trunk termination port and ISDN PRI backup) • 4x FXS, 4x FX0, TIM514—TIM514 Analog Telephony Interface Module (Avaya VoIP media module with four analog LINE ports and four analog TRUNK ports) • 4x BRI TIM521—TIM521 BRI Telephony Interface Module (Avaya VoIP media module with four ISDN BRI ports) • Crypto Accelerator Module—For enhanced performance of cryptographic algorithms used in IP Security (IPsec) services • MPC M 16x 10GE—16-port 10-Gigabit Module Port Concentrator that supports SFP+ optical transceivers. (Not on EX Series switches.)

Table 180: Fields in the Chassis View Details Page (*continued*)

Field	Description
	<ul style="list-style-type: none"> • For hosts, the Routing Engine type. • For small form-factor pluggable transceiver (SFP) modules, the type of fiber: LX, SX, LH, or T. • LCD description for EX Series switches (except EX2200 switches). • MPC2—1-port MPC2 that supports two separate slots for MICs. • MPC3E—1-port MPC3E that supports two separate slots for MICs (MIC-3D-1X100GE-CFP and MIC-3D-20GE-SFP) on MX960, MX480, and MX240 routers. The MPC3E maps one MIC to one PIC (1 MIC, 1 PIC), which differs from the mapping of legacy MPCs. • 100GBASE-LR4, pluggable CFP optics • Supports the Enhanced MX Switch Control Board with fabric redundancy and existing SCBs without fabric redundancy. • Interoperates with existing MX Series line cards, including Flexible Port Concentrators (FPC), Dense Port Concentrators (DPCs), and Modular Port Concentrators (MPCs). • MPC4E—Fixed configuration MPC4E that is available in two flavors: MPC4E-3D-32XGE-SFPP and MPC4E-3D-2CGE-8XGE on MX2020, MX960, MX480, and MX240 routers. • LCD description for MX Series routers

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[About Chassis View | 1383](#)

Deleting Devices from Chassis View

You can delete devices that are no longer used from Connectivity Services Director and for which you do not want to view a pictorial representation using the Chassis View functionality. Deleting a device removes all device configuration and device inventory information from the Junos Space database. Once a device is deleted from the database, all the profiles associations, device configurations, and inventory information of the deleted device are also deleted. However, the system maintains the audit logs and monitoring data for the device even after the device is deleted.

Use the Delete Devices page to delete devices from Connectivity Services Director. While in Build mode, click Delete Devices from the Tasks > Device Management menu. The Delete Devices page appears.

The Delete Devices page displays the devices contextually depending on your selection in the View pane. For example, if you select a site in Service View and click Delete Devices, Connectivity Services Director displays all the devices. If you select a particular switch family in Device View and click Delete Devices, only devices that belong to that switch family are displayed.

To delete devices, complete the following tasks:

1. From the View selector, select Service View. The functionalities that you can configure in this view are displayed.
2. Click the Build mode icon in the Service View of the Connectivity Services Director banner. The workspaces that are applicable to this mode are displayed.
Select the My Network scope in the View pane that contains the devices you want to delete.
3. Select Delete Devices from the Tasks pane.
4. Select the check box adjacent to the device that you want to delete. Click Done.
5. Connectivity Services Director prompts you to confirm the deletion. Click Yes to confirm the deletion or No to go back and make changes to the selection.

RELATED DOCUMENTATION

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[About Chassis View | 1383](#)

[Service Monitoring Capabilities in Connectivity Services Director | 1252](#)

Rebooting Devices After Examining the Status in Chassis View

In certain situations, when you identify a certain discrepancy or malfunctioning of a component, such as a line card or an interface, by examining the status of the hardware module using the Chassis View, you might require the component to be rebooted. When a hard disk error occurs, a Routing Engine might enter a state in which it responds to local pings and interfaces remain up, but no other processes are responding. To recover from this situation, you can reboot a single Routing Engine when a hard disk error occurs. Similarly, you can restart the FPCs when a traffic null route condition is detected.

Use the Reboot Devices task to immediately reboot the selected device. This task is available in all scopes when in Build mode. To reboot one or more devices immediately:

1. For the My Network scope, you can customize what monitors appear on Summary tab, giving you the ability to view at a glance those aspects of network health and performance that are most important to you.
2. Click the Build mode icon in the Service View of the Connectivity Services Director banner. The workspaces that are applicable to this mode are displayed.
3. Select the My Network scope in the View pane that contains the devices you want to reboot.
4. Select Reboot Devices from the Tasks pane.
5. Expand the tree on the page as needed to locate the available devices.
6. Select the check box for one or more devices.
7. Click Done to start the reboot or click Cancel to return to the Device Inventory page. The rebooting process triggers a Cold Start Alarm that can be seen in Fault mode.

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Accessing the Chassis View from the Physical Inventory Page | 1384](#)

[About Chassis View | 1383](#)

[Service Monitoring Capabilities in Connectivity Services Director | 1252](#)

Managing CLI Configlets

IN THIS CHAPTER

- [CLI Configlets Overview | 1396](#)
- [CLI Configlets Workflow | 1399](#)
- [Configlet Context | 1403](#)
- [Creating a CLI Configlet | 1409](#)
- [Modifying a CLI Configlet | 1412](#)
- [Deleting CLI Configlets | 1413](#)
- [Viewing CLI Configlets | 1414](#)
- [Creating a Parameter for a CLI Configlet | 1416](#)
- [Applying a CLI Configlet to Devices | 1418](#)
- [Deploying CLI Configlet Details | 1422](#)

CLI Configlets Overview

IN THIS SECTION

- [Configlet Variables | 1397](#)
- [Velocity Templates | 1398](#)
- [Directives | 1398](#)

CLI Configlets are configuration tools provided by Junos OS that enables you to apply a configuration to a device by reducing configuration complexity. CLI Configlets contain the Junos OS configuration as a formatted ASCII text. Junos Space uses the NETCONF protocol to load and commit the configuration on devices.

A CLI Configlet is a configuration template that is transformed into a CLI configuration string before being applied to a device. The dynamic elements (strings) in configuration templates are defined using template

variables. These variables act as an input to the process of transformation to construct the CLI configuration string. These variables can contain the interface name, device name, description text, or any such dynamic values. The value of these variables are obtained from the user or the system or given by the context at the time of execution. Velocity templates (VTL) are used to define CLI Configlets.

You can access the CLI Configlets workspace by selecting CLI Configlets from the left pane. From the CLI Configlets workspace, you can perform the following tasks:

- Viewing the statistics of CLI Configlets in Junos Space Network Management Platform
- Creating, modifying, cloning, applying, or deleting a CLI Configlet
- Marking and unmarking CLI Configlets as favorites

You can also apply CLI Configlets to devices from the Devices workspace. It can be triggered from the actual elements for which the configuration has to be applied. The context of the element for which the CLI Configlet is being applied is called an execution context.

NOTE: CLI Configlets are not supported on SSG Series devices, NetScreen Series devices, TCA Series devices, BXOS Series devices, and Junos Content Encore devices.

Configlet Variables

Variables in CLI Configlets include a leading “\$”. CLI Configlets use three kinds of variables: default, user-defined, and predefined.

Default Variables

The value of these variables need not be input by the user; these values are derived from the current execution context. [Table 181 on page 1397](#) lists the default variables.

Table 181: Default Variables

Variable	Value
\$DEVICE	Name of the host on which the CLI Configlet is applied
\$INTERFACE	Name of the interface for which the CLI Configlet is applied
\$UNIT	Unit number of the logical interface for which the CLI Configlet is being applied
\$CONTEXT	Context of the element for which the CLI Configlet is applied

User-defined Variables

The values for these variables are entered by the user at execution time. Text fields or selection fields are used to obtain data from the user.

Predefined Variables

These are the variables for which the values are predefined when you create the CLI Configlet. These variables are also called invisible parameters because they cannot be modified by the user.

Velocity Templates

Junos Space Network Management Platform enables you to define the device configuration in the form of velocity templates (VTL). These templates are called CLI Configlets. The VTL variable is a reference type, which includes the leading "\$" character, followed by a VTL Identifier. CLI Configlets are transformed into a CLI configuration string before they are applied to the device. This transformation is directed by references and directives of VTL.

References are used to embed dynamic contents in the configuration text. Directives allow dynamic manipulation of the contents.

Refer to <http://velocity.apache.org/engine/releases/velocity-1.4/user-guide.html> for detailed information about VTL.

Directives

Directives include an included CLI Configlet's contents and parameters in the base CLI Configlet and import the metadata information related to the parameters of the included CLI Configlet. You can include CLI Configlets in Junos Space Platform by using two directives: `#include_configlet` and `#mixin` directives.

#include_configlet – This directive includes an included CLI Configlet's contents and parameters in the base CLI Configlet and imports the metadata information related to the parameters of the included CLI Configlet. If you define a new parameter in the base CLI Configlet by using the `#include_configlet` directive, the metadata information is fetched and used from the included CLI Configlets. The parameter values updated in the included CLI Configlet after their inclusion into the base CLI Configlet are not updated and available for the base CLI Configlet. If both the base CLI Configlet and included CLI Configlet contain parameters with a common name, the metadata information related to the parameters is ignored.

#mixin – This directive differentiates the parameters of the base CLI Configlet from the parameters of the included CLI Configlet on the Junos Space user interface. The parameter values for the included CLI Configlets can be modified even when you apply the CLI Configlet to the device. You cannot include CLI Configlets that have a period (.) or space in its name.

You include these directives in the base CLI Configlet in the following format:

- `#include_configlet("<name of the included configlet>")`
- `#mixin("<name of the included configlet>")`

RELATED DOCUMENTATION

CLI Configlets Workflow 1399
Configlet Context 1403
Creating a CLI Configlet 1409
Modifying a CLI Configlet 1412
Deleting CLI Configlets 1413
Viewing CLI Configlets 1414
Creating a Parameter for a CLI Configlet 1416
Applying a CLI Configlet to Devices 1418

CLI Configlets Workflow

A CLI Configlet can be defined from the CLI Configlets workspace. [Table 182 on page 1399](#) lists the parameters to be defined for a CLI Configlet.

Table 182: Parameters for a CLI Configlet

Parameter	Description
Name	Name of the CLI Configlet. The name cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, and numbers and the period (.). You cannot have two configlets with the same name.
Category	Category of the CLI Configlet. The category cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, and numbers and the period (.).
Device Family Series	Device family series for which the CLI Configlet is applicable.
Context	Context for which the CLI Configlet is applicable. This is an optional field.
Description	Description of the CLI Configlet. The description cannot exceed 2500 characters. This is an optional field.
Preview options	Selecting the Show Parameters option displays the parameters that are present in the CLI Configlet. The Show Configuration option displays the consolidated configuration before the CLI Configlet is applied.

Table 182: Parameters for a CLI Configlet (*continued*)

Parameter	Description
Post-view options	Selecting the Show Parameters option displays the parameters that are present in the CLI Configlet. The Show Configuration option displays the consolidated configuration after the CLI Configlet is applied.
Configlet Content	The actual CLI Configlet is defined here. The CLI Configlet can contain multiple pages and follows a tablike structure. The configuration being applied onto the device can be split among multiple pages. When the configuration is applied, all the pages are combined in order of the page numbers and applied onto the device in a single commit operation. You must always validate the CLI Configlet before moving to the next page.
Reference Number	The range of values are from 1 to 2 ¹⁶ .

NOTE: You cannot move to the next page if the contents of the CLI Configlet are invalid. Validation includes bracket matching.

Parameters are variables defined in the CLI Configlet whose values are either retrieved from the environment or entered by the user during execution. When the user applies CLI Configlets, the user is asked to input values for all variables defined in the CLI Configlet.

To configure a parameter, click the modify icon on the toolbar. The Edit Configlet Parameter page is displayed. Use this page to set the attributes of a parameter.

To add an additional parameter, click the add icon on the toolbar. The Add Configlet Parameter page is displayed. The attributes of a parameter are set from this page.

To delete a parameter, click the delete icon on the toolbar. By default, all variables present in the CLI Configlet are listed on the Parameters page. Local variables must be deleted manually or set to the “Invisible” type.

[Table 183 on page 1400](#) lists the attributes of the CLI Configlet parameters.

Table 183: Attributes of CLI Configlet Parameters

CLI Configlet Parameter Attributes	Description
Parameter	<p>Name of the parameter</p> <p>If displayed with a name space in the <code><configlet name>.<parameter.name></code> format, this parameter belongs to the included CLI Configlet.</p>

Table 183: Attributes of CLI Configlet Parameters (*continued*)

CLI Configlet Parameter Attributes	Description
Display Name	Display name of the parameter
Description	Description of the parameter
Types	<p>The types of parameters supported are:</p> <ul style="list-style-type: none"> • Text field – You can provide a custom value when executing the CLI Configlet. The default value for this field can be configured with an XPath in the Configured Value Xpath field or with a plain string in the Default Value field. This returns a single value. • Selection field – You can select a value from a set of options when executing this CLI Configlet. The default value for this field can be configured with an XPath in the Configured Value Xpath field or with a plain string in the Default Value field. The options can be configured by an XPath in the Selection Values Xpath field, or by using a CSV string in the Selection Values field. This returns a single value. <p>NOTE: Though this returns a single value, the return value is of the array type and the selected value can be taken from index 0.</p> <ul style="list-style-type: none"> • Invisible field – You cannot edit this field. This parameter refers to values defined explicitly as a CSV string in the Default Value field or by an XPath in the Configured Value Xpath field. This field returns an array of values. • Password field – You need to enter a value when you apply a CLI Configlet containing the parameter. This hides sensitive information in the Apply CLI Configlet job results. • Password Confirm field – You need to enter a value twice when you apply a CLI Configlet containing the parameter. This hides sensitive information in the Apply CLI Configlet job results.

Table 183: Attributes of CLI Configlet Parameters (*continued*)

CLI Configlet Parameter Attributes	Description
Configured Value XPath	<p>This field is used to give the XPath of the configured values. The behavior of this field depends on the type of parameter. When the parameter type is a text field or selection field, the corresponding value present in the XPath is taken as the default value. This value can be modified. If the XPath returns multiple values, the first value returned is considered. When the parameter type is an invisible field, the list of values returned by the XPath is taken as the value of the parameter.</p> <p>Invisible field has configured value XPath and selection value XPath only when the parameter scope is either device specific or entity specific. This is disabled if the scope is global.</p> <p>NOTE: When using \$INTERFACE, \$UNIT, Configured Value Xpath field, Invisible field, and Selection field, the variable definition in the Configlet Editor should contain <code>.get(0)</code> in order to fetch the value from the array. For example, \$INTERFACE.get(0).</p>
Default Value	<p>Displays the same behavior as the Configured Value Xpath field except that the value is given explicitly. This field is considered only when configured value XPath is not specified or if the XPath does not return any value.</p>
Selection Values XPath	<p>This field is enabled only if the parameter type is a Selection field. This field contains the XPath (with reference to the device XML) to fetch the set of values for the Selection field.</p>
Selection Values	<p>This field is the same as the Selection Values XPath field except that the value is given explicitly. This field is considered only when selection values XPath is not specified or if the XPath does not return any value.</p> <p>NOTE: Comma-separated values can be used to provide an array of values in the Default Value and Selection Values fields.</p> <p>NOTE: While defining the XPath, you must directly access the text node with the <code>text ()</code> function. Otherwise the complete XML path of the node is returned. For example, <code>/device/interface-information/physical-interface/name/text()</code> to fetch the names of all interfaces.</p>
Order	<p>Order of the parameter. This is the relative order in which the field must be displayed for user input at the time of execution.</p>

Table 183: Attributes of CLI Configlet Parameters (*continued*)

CLI Configlet Parameter Attributes	Description
Regex Value	This field contains regular expression for the parameter that is used to validate the parameter value while you apply the CLI Configlet to the device.
Read-only	<p>Whether the parameter belongs to the base configlet or the included configlet:</p> <ul style="list-style-type: none"> • false – This parameter belongs to the base configlet. • true – This parameter belongs to the included configlet. The parameter cannot be modified or deleted from this configlet.

RELATED DOCUMENTATION

[CLI Configlets Overview | 1396](#)
[CLI Configlets Workflow | 1399](#)
[Configlet Context | 1403](#)
[Creating a CLI Configlet | 1409](#)
[Modifying a CLI Configlet | 1412](#)
[Deleting CLI Configlets | 1413](#)
[Viewing CLI Configlets | 1414](#)
[Creating a Parameter for a CLI Configlet | 1416](#)
[Applying a CLI Configlet to Devices | 1418](#)

Configlet Context

Execution of scripts and CLI configlets may be required in some case. For example, one might need to restrict the scope of execution of 'disable interface' script to just the interfaces that are enabled. Having a context associated to the script or configlet solves this problem of restricting the scope. Context of an element is basically a unique path which leads to its XML counterpart in the device XML.

For all context related computations, we consolidate the XMLs fetched from the device under one node called device. This includes configuration XML, interface-information XML, chassis-inventory XML, and system-information XML.

An example of a device XML is as follows:

```
<device>
  <interface-information>.....</interface-information>
  <system-information>.....</system-information>
  <chassis-inventory>.....</chassis-inventory>
  <configuration>....</configuration>
  ....
</device>
```

Table 184 on page 1404 shows the commands to view the XML from the CLI of the device.

Table 184: Commands to View XML from the CLI

XML type	Command
Chassis Inventory	> show chassis hardware display xml
Interface Information	> show interfaces display xml
Configuration	> show configuration display xml
System Information	-

NOTE: The command for system information XML is not available. An instance of the system information XML is as follows:

```
<system-information>
<hardware-model>ex4200-24t</hardware-model>
<os-name>junos-ex</os-name>
<os-version>11.3R2.4</os-version>
<serial-number>BM0210293858</serial-number>
<host-name>EX4200-200</host-name>
<virtual-chassis/>
</system-information>
```

Context of an Element

There is a need to have the ability to restrict a script or configlet execution to certain elements of interest. For example, one might need to restrict the scope of execution of 'disable interface' script only to the interfaces that are enabled. Having a context associated with the script or configlet solves this scoping problem.

The context of an element is the XPath that maps to the XML node that represents the element in the device XML. [Table 185 on page 1405](#) lists the type of element, XML referred, and the content path.

Table 185: Context Path and XML node referred for different element types

Element Type	XML Referred	Context Path
Device	N/A	/device
Physical Inventory element	Chassis Inventory	/device/chassis-inventory/*
Physical Interface	Interface Information	/device/interface-information/*
Logical Interface	Configuration	/device/configuration/*

[Table 186 on page 1405](#) lists some examples for XPaths for different elements.

Table 186: XPaths for different elements

Element	Context	Description
Device	/device	The context of a device
Chassis	/device/chassis-inventory/chassis[name='Chassis']	Context of a chassis
Routing Engine	/device/chassis-inventory/chassis[name='Chassis']/chassis-module[name='Routing Engine 0']	The context of a routing engine
FPC	/device/chassis-inventory/chassis[name='Chassis']/chassis-module[name='FPC 1']	The context of an FPC in slot 1
PIC	/device/chassis-inventory/chassis[name='Chassis']/chassis-module[name='FPC 1']/chassis-sub-module[name='PIC 4']	The context of a PIC in slot 4 under FPC in slot 1
Logical Interfaces	device/configuration/interfaces/interface[name='ge-0/0/1']/unit[name='0']	The context of logical interface ge-0/0/1.0
Physical Interfaces	/device/interface-information/physical-interface[name='ge-0/1/1']	The context of a physical interface ge-0/1/1

Context filtering

The context attribute of the script or configlet dictates which elements (inventory component or logical interface or physical interface) it is applicable to.

The rule to check whether the script or configlet is applicable to an element is as follows:

- Evaluate the context XPath associated to a script or configlet on the device XML. This results in a set of XML nodes.
- If the resultant XML node list contains the XML node representing the subject element, then the script/template entity is considered a match.

Given below are few examples of script or configlet contexts with their descriptions:

- `/device/chassis-inventory/chassis[name='Chassis']/chassis-module[starts-with(name,'Routing Engine')]`
- Applicable to all routing engines
- `/device/chassis-inventory/chassis[name='Chassis']/chassis-module[starts-with(name,'FPC')]` - Applicable to all FPCs
- `/device[starts-with(system-information/os-version,"11")]/interface-information/physical-interface[starts-with(name,"ge")]`
- Applicable to all interfaces of type 'ge' which has system os-version as 11
- `/device/interface-information/physical-interface[admin-status="up"]` - Applicable to all physical interfaces with admin status in up state.
- `/device/chassis-inventory/chassis[name='Chassis']/chassis-module[starts-with(name,'FPC')]/chassis-sub-module[starts-with(name,'PIC')]`
|
`/device/chassis-inventory/chassis[name='Chassis']/chassis-module[starts-with(name,'FPC')]/chassis-sub-module[starts-with(name,'MIC')]/chassis-sub-module[starts-with(name,'PIC')]`
- Applicable to all PICs

NOTE: If we intend to specify the scope of a script as PICs, then we would have to consider two different XPaths the PIC can take (One with MIC in-between and one without). We have to give an OR combination of both the XPaths.

NOTE: If no context is associated to a script or configlet, then the context of the script is taken as `"/device"`. These scripts or configlets would be listed for execution in devices.

Physical Interface Example

Consider the following device XML

```

<device>
  <interface-information>
    <physical-interface>
      <name>ge-0/0/0</name>
      <admin-status>up</admin-status>
      ....
    </physical-interface>
    <physical-interface>
      <name>ge-0/0/1</name>
      <admin-status>down</admin-status>
      ....
    </physical-interface>
    ....
  </interface-information>
  ....
  <!-- ALL THE OTHER NODES -->
  ....
</device>

```

Context of an element

Context of physical-interface ge-0/0/0 is /device/interface-information/physical-interface[name='ge-0/0/0']

This XPath maps to the node below. This is the XML counterpart of the interface ge-0/0/0

```

<physical-interface>
  <name>ge-0/0/0</name>
  <admin-status>up</admin-status>
  ....
</physical-interface>

```

Physical Interface in “up” state:

If the user wants to write a configlet to set the admin status of an interface down if its up, the context of the script can be set as /device/interface-information/physical-interface[admin-status='up']

This configlet will be enabled only for interfaces with admin status up. Since in our example, ge-0/0/0 satisfies the above condition, this configlet can be executed on it.

To view the contexts for writing CLI configlet scripts for different service types, refer [Table 138 on page 1170](#).

Table 187: CLI Configlets Contexts for Different Service Types

Service Type	Context
P2P	<p>@CONTEXT = "/device/configuration/protocols/l2circuit/neighbor/interface"</p> <p>Example :</p> <pre>/device[name="MX80-NGCE-1"]/configuration/protocols/l2circuit/neighbor[name="30128"]/interface[name="ge-0/1/5.784"]</pre>
L3VPN	<p>/* @CONTEXT = "/device/configuration/routing-instances/instance/interface" */</p> <p>Example :</p> <pre>/device[name="kochin"]/configuration/routing-instances/instance[name="SO62441630" and instance-type="vrf"]/interface[name="ge-0/1/3.934"]</pre>
VPLS	<p>/* @CONTEXT = "/device/configuration/routing-instances/instance/interface" */</p> <p>Example :</p> <pre>/device[name="kochin"]/configuration/routing-instances/instance[name="SO62441630" and instance-type="vpls"]/interface[name="ge-0/1/3.945"]</pre>
P2P or L3VPN with L2E	<p>/* @CONTEXT = "/device/configuration/protocols/connections/interface-switch/interface"</p> <p>*/ Example:</p> <pre>/device[name="MX80-1"]/configuration/protocols/connections/interface-switch/interface[name="ge-1/0/0.1801"]</pre>
P2P (Local switching)	<p>/* @CONTEXT =</p> <p>"/device/configuration/protocols/l2circuit/local-switching/interface/end-interface" */ Example</p> <pre>/device[name="MX80-1"]/configuration/protocols/l2circuit/local-switching/interface[name="ge-1/0/0.1801"]/end-interface[name="ge-1/2/2.1881"]</pre>
NPS (Network peering)	<p>/* @CONTEXT = "/device/configuration/protocols/bgp/group" */ Example</p> <pre>/device[name="MX80-1"]/configuration/protocols/bgp/group[type="external"]</pre>

RELATED DOCUMENTATION

[CLI Configlets Workflow | 1399](#)
[Creating a CLI Configlet | 1409](#)
[Modifying a CLI Configlet | 1412](#)
[Deleting CLI Configlets | 1413](#)
[Viewing CLI Configlets | 1414](#)
[Creating a Parameter for a CLI Configlet | 1416](#)
[Applying a CLI Configlet to Devices | 1418](#)

Creating a CLI Configlet

You create a CLI Configlet to push a configuration to devices. You can also add parameters to a CLI Configlet. Parameters are the variables defined in the CLI Configlet whose values are either obtained from the environment or given by the user during execution.

You must create Configlets and the parameters for a CLI Configlet using the Configlets workspace of the Junos Space Network Management Platform GUI, before you can apply the created Configlets to devices and deploy Configlets using the Connectivity Services Director GUI.

To create a CLI Configlet:

1. On the Junos Space Network Management Platform user interface, select **CLI Configlets > Configlets**.

The Configlets page is displayed.

2. Click the Create CLI Configlet icon on the toolbar.

The Create CLI Configlet page is displayed.

3. In the **Name** field, enter a name for the CLI Configlet.

The name cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, numbers, and the period (.). You cannot have two CLI Configlets with the same name.

4. In the **Category** field, enter a name for the category of the CLI Configlet.

The name of the category cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, numbers, and the period (.).

5. From the **Device Family Series** drop-down list, select the device family for the CLI Configlet.

6. (Optional) From the **Context** drop-down list, select the appropriate context for the CLI Configlet.

7. In the **Reference Number** field, enter a reference number for the CLI Configlet.

The default value is 1. The maximum value is 2^{16} .

8. (Optional) In the **Description** field, enter a description.

The description cannot exceed 2500 characters.

9. For Execution Type, select the type of execution. The option buttons available are **Single Execution** and **Grouped Execution**.

By default, the **Single Execution** option button is selected.

- If you select **Single Execution**, you can apply the CLI Configlet only to one device at a time.
- If you select **Grouped Execution**, you can apply the CLI Configlet to multiple devices at a time.

10. For Preview options, clear the check boxes if you do not want to view the parameters and the configuration in the CLI Configlet after downloading it.

The check boxes available are **Show Parameters** and **Show Configuration**. By default, both check boxes are selected.

11. For Postview options, clear the check boxes if you do not want to view the parameters and the configuration in the CLI Configlet before creating it.

The check boxes available are **Show Parameters** and **Show Configuration**. By default, both check boxes are selected.

12. In the Configlet Editor area, enter the configuration for the CLI Configlet. You can type or manually paste the configuration in the Configlet Editor.

NOTE: You cannot create a CLI Configlet if you do not enter the configuration in the Configlet Editor.

NOTE: You can also create a CLI Configlet to erase specific configuration from the devices. To do so, include the **delete:** statement above the hierarchy level that should be deleted from the devices. When you apply the CLI Configlet to a device, the physical interface of a device, the logical interface of a device, or the physical inventory element of a device, the configuration in the hierarchy level is erased on the device.

For more information about the protocol and syntax used for creating, modifying, and deleting the configuration by using CLI Configlets, see the [Junos XML Management Protocol Guide](#).

NOTE: When you define a configuration of the CLI Configlet, you should specify variables that accept special characters as input within double quotation marks.

13. Click **Next**.

You can add the parameters for the CLI Configlet on this page.

14. To add a parameter to the CLI Configlet:

- a. Click the Add Parameter icon.

The Add Configlet Parameter pop-up window is displayed.

- b. In the **Parameter** field, enter the name of the parameter.

The name of the parameter cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, numbers, and the period (.).

- c. In the **Display Name** field, enter a display name for the parameter.

The display name cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, numbers, and the period (.).

- d. In the **Description** field, enter a description for the parameter.

- e. From the **Parameter Scope** drop-down list, select an appropriate scope for the parameter.

The options available are Global, Device Specific, and Entity Specific.

- f. From the **Parameter Type** drop-down list, select an appropriate type of parameter. The options available are:

- Text Field – You can enter any value.
- Selection Field – You can select a value from a set of options.
- Invisible Field – The field displays a value that is explicitly defined by the user or an XPath.
- Password Field – Enter a password to apply the CLI Configlet.
- Password Confirm Field – Enter the password again to confirm the password.

- g. From the **Regex Value** drop-down list, select an appropriate regular expression value.

This field is enabled if you choose the type of parameter as Text Field, Password Field, or Confirm Password Field.

- h. From the **Configured Value XPath** drop-down list, select an appropriate XPath value.

This field is enabled if you choose the type of parameter as Text Field, Selection Field, or Invisible Field. This is the XPath (with reference to the device XML) to fetch the set of values.

- i. In the **Default Value** field, enter a default value.

This field is enabled if you choose the type of parameter as Text Field, Selection Field, or Invisible Field. This field is considered only when the XPath is not specified.

- j. From the **Selection Values XPath** drop-down list, select an appropriate XPath value.

This field is enabled if you choose the type of parameter as Selection Field. This is the XPath (with reference to the device XML) to fetch the set of values.

- k. In the **Selection Values** field, enter an appropriate selection value.

This field is enabled if you choose the type of parameter as Selection Field.

l. In the **Order** field, enter the order in which the parameters should be listed while applying the CLI Configlet.

m. Click **Add**.

15. (Optional) Add multiple parameters.

16. (Optional) To go back to the previous page, click **Back**.

You are redirected to the previous page.

17. Click **Create**.

The CLI Configlet is created. You are redirected to the Configlets page.

RELATED DOCUMENTATION

[CLI Configlets Overview](#) | 1396

[CLI Configlets Workflow](#) | 1399

[Modifying a CLI Configlet](#) | 1412

[Deleting CLI Configlets](#) | 1413

[Viewing CLI Configlets](#) | 1414

Modifying a CLI Configlet

You modify a CLI configlet when you want to change the properties of the CLI configlet.

To modify a CLI configlet:

1. On the Junos Space Network Management Platform user interface, select **CLI Configlets > Configlets**.

The Configlets page is displayed.

2. Select the CLI configlet you want to modify and click the **Modify** button.

The Modify CLI configlet page is displayed.

3. Modify the CLI configlet properties and click **Update**.

The CLI configlet is modified.

RELATED DOCUMENTATION

CLI Configlets Overview
Creating a CLI Configlet
Exporting CLI Configlets
Importing CLI Configlets

Deleting CLI Configlets

You delete CLI configlets when you no longer want to use them to apply configuration to devices.

You must create Configlets and the parameters for a CLI Configlet using the Configlets workspace of the Junos Space Network Management Platform GUI, before you can apply the created Configlets to devices and deploy Configlets using the Connectivity Services Director GUI.

To delete CLI configlets:

1. On the Junos Space Network Management Platform user interface, select **CLI Configlets > Configlets**.

The Configlets page is displayed.

2. Select the CLI configlets you want to delete and select the Delete CLI Configlets icon from the Actions menu.

The Delete CLI Configlet pop-up window is displayed.

3. Click **Confirm**.

The CLI configlets are deleted.

RELATED DOCUMENTATION

CLI Configlets Overview 1396
CLI Configlets Workflow 1399
Creating a CLI Configlet 1409
Modifying a CLI Configlet 1412
Viewing CLI Configlets 1414

Viewing CLI Configlets

You create a CLI Configlet to push a configuration to devices. You can also add parameters to a CLI Configlet. Parameters are the variables defined in the CLI Configlet whose values are either obtained from the environment or given by the user during execution.

To view CLI Configlets:

1. From the View selector, select **Device View**. The workspaces that you can configure in this view are displayed.
2. Click the **Build** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and view the list of devices.
4. Select the device for which you want to apply CLI configlets. A graphical view of the device is displayed on the right pane.
5. From the tasks pane, select **Configuration Deployment > View Applied Configlets**.
The Manage CLI-Applied Configlets page is displayed.
6. Select the device for which you want to view the applied CLI configlets. A graphical view of the device is displayed on the right pane.

The following fields are displayed on this page:

Table 188: Columns on the Manage CLI-Applied Configlets Page

Field	Description
Name	Name of the configuration view
Domain Name	Domain to which the configuration view is associated
Category	The Category of the configlet. The Category cannot exceed 255 characters. Allowable characters include the dash (-), underscore (_), letters, and numbers and the period (.).
Description	Description of the configlet. The description cannot exceed 2500 characters. This is an optional field.
Applied To	Name of the interface or the device to which the Configlet is being deployed.

Table 188: Columns on the Manage CLI-Applied Configlets Page (*continued*)

Field	Description
Version	Version of the Configlet template used to create the Configlet.
Validation State	State of the Configlet such as an invalid Configlet or a validated Configlet.
Deployed State	Status of deployment of the Configlet.
Deployed Time	Date and time when the Configlet was deployed.
Deploy Now	Click this button to deploy and propagate the selected Configlet immediately to the device.
Schedule Deploy	Click this button to schedule the deploy of the selected Configlet for a later time.
Discard Deploy	Click this button to delete the selected Configlet.
Creation Time	Date and time when the Configlet was created.
Last Updated Time	Latest time when the Configlet was last updated.

RELATED DOCUMENTATION

[CLI Configlets Workflow | 1399](#)
[Configlet Context | 1403](#)
[Creating a CLI Configlet | 1409](#)
[Modifying a CLI Configlet | 1412](#)
[Deleting CLI Configlets | 1413](#)
[Creating a Parameter for a CLI Configlet | 1416](#)
[Applying a CLI Configlet to Devices | 1418](#)

Creating a Parameter for a CLI Configlet

From the Manage Configlets page, you can also add parameters to a CLI Configlet. Parameters are the variables defined in the CLI Configlet whose values are either obtained from the environment or given by the user during execution. The following fields are displayed on this page:

Table 189: Attributes of a parameter

Parameter	Name of the parameter.
Display Name	Display name of the parameter.
Configured Value XPATH	<p>This field is used to give the XPath of the configured values. The behavior of this field depends on the type of view. When the view type is form, the corresponding value present in the XPath is taken as the field value. In case XPath returns multiple values, first value returned is considered. In case the XPath returns multiple values, the first value returned is considered. When the view type is grid, the following behavior is followed. If more than one parameters defined then following rules should be met.</p> <ul style="list-style-type: none"> • For independent index parameters, a join would be performed between the values returned by the XPath and the existing set of rows. • For dependent index parameters, join would be performed between the values returned by the XPath and the correspondent row. <p>For non index parameters, if list of values returned then they are aggregated into comma separated values.</p>
Description	Description of the parameter.
Scope	Scope of the parameter, such as device/entity specific or global.
Default Value	Default value of the parameter. The behavior is same as that of Configured value XPath except that the value is given explicitly. This field is considered only when Configured Value XPATH is not specified or if the XPath doesn't return any value.

From the Manage Configlets page, if you click the **Add Parameter** button, you are navigated to the Manage Arguments page. The Manage Arguments panel displays a list of arguments for the adding script and a form to manage the properties for them. When you select an argument from the grid, the lower part of the page displays the properties applicable to the selected argument.

To add a parameter to the CLI Configlet:

1. From the Manage Configlets page, click the **Add Parameter** button.

The Add Configlet Parameter pop-up window is displayed.

2. In the **Parameter** field, enter the name of the parameter.

The name of the parameter cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, numbers, and the period (.).

3. In the **Display Name** field, enter a display name for the parameter.

The display name cannot exceed 255 characters. Allowable characters include the hyphen (-), underscore (_), letters, numbers, and the period (.).

4. In the **Description** field, enter a description for the parameter.

5. From the **Parameter Scope** drop-down list, select an appropriate scope for the parameter.

The options available are Global, Device Specific, and Entity Specific.

6. From the **Parameter Type** drop-down list, select an appropriate type of parameter. The options available are:

- Text Field – You can enter any value.
- Selection Field – You can select a value from a set of options.
- Invisible Field – The field displays a value that is explicitly defined by the user or an XPath.
- Password Field – Enter a password to apply the CLI Configlet.
- Password Confirm Field – Enter the password again to confirm the password.

7. From the **Regex Value** drop-down list, select an appropriate regular expression value.

This field is enabled if you choose the type of parameter as Text Field, Password Field, or Confirm Password Field.

8. From the **Configured Value Xpath** drop-down list, select an appropriate XPath value.

This field is enabled if you choose the type of parameter as Text Field, Selection Field, or Invisible Field. This is the XPath (with reference to the device XML) to fetch the set of values.

9. In the **Default Value** field, enter a default value.

This field is enabled if you choose the type of parameter as Text Field, Selection Field, or Invisible Field. This field is considered only when the XPath is not specified.

10. From the **Selection Values Xpath** drop-down list, select an appropriate XPath value.

This field is enabled if you choose the type of parameter as Selection Field. This is the XPath (with reference to the device XML) to fetch the set of values.

11. In the **Selection Values** field, enter an appropriate selection value.

This field is enabled if you choose the type of parameter as Selection Field.

12. In the **Order** field, enter the order in which the parameters should be listed while applying the CLI Configlet.

13. Click **Add**.

14.(Optional) Add multiple parameters.

15.(Optional) To discard the changes and go back to the previous page, click **Cancel**.

You are redirected to the previous page.

16.Click **Save**.

The CLI Configlet is created. You are redirected to the Configlets page.

RELATED DOCUMENTATION

[CLI Configlets Workflow | 1399](#)

[Configlet Context | 1403](#)

[Modifying a CLI Configlet | 1412](#)

[Deleting CLI Configlets | 1413](#)

[Viewing CLI Configlets | 1414](#)

[Creating a Parameter for a CLI Configlet | 1416](#)

[Applying a CLI Configlet to Devices | 1418](#)

Applying a CLI Configlet to Devices

You apply a CLI Configlet to devices when you want to push a configuration from the CLI Configlet to the devices.

NOTE:

At the time of creating the CLI Configlet:

- If you selected the Single execution type, the CLI Configlet can be applied to only one device.
- If you selected the Grouped execution type, the CLI Configlet can be applied to multiple devices simultaneously.

To apply a CLI Configlet to a device:

1. From the View selector, select **Chassis View**. The workspaces that you can configure in this view are displayed.
2. Click the **Build** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed.

3. From the Chassis View pane, click the plus sign (+) next to the My Network tree to expand the tree and view the list of devices.
4. Select the device for which you want to apply CLI configlets. A graphical view of the device is displayed on the right pane.
5. You can right-click each selectable component such as chassis or physical interfaces in the chassis view. The shortcut menu that is displayed indicates the name of the selected component, state of the component, context path of the component, and the Manage Configlets option. Select **Manage Configlets** from the shortcut menu. The Select Configlets window is displayed, listing all of the available configlet templates that are applicable to the selected component.
6. To select a configlet to be applied to a device, do one of the following:
 - Double-click the chassis component, such as physical or logical interfaces, in the chassis view. The selected area is used as the context to list the templates in the Configlet selection window.
 - Click the Apply Configlet icon and use the links shown on the components in chassis view to select the context and apply configlets.
7. The Apply Configlet menu is displayed, depending on the component or context selected:

If you selected the chassis, the device configuration context is applicable. Click the Edit (pencil) icon beside the Zoom menu in the chassis image view. You can select the Configlets that can be applied to the device and the device context is listed for configuration.

If you selected a physical interface, select Apply Configlets from the Actions menu on the rightmost pane that displays component details. You can select the configlets from the list for the selected physical interface on the device.

If you selected a pseudo-interface and a logical Interface, click the pencil icon displayed in the pseudo and logical interfaces grid. When you click the icon, the chassis element on the respective row is used as the context element and the list of Configlets that can be applied are displayed.
8. Select the CLI Configlet that you want to apply to the devices and select **Apply CLI Configlet** from the Actions menu.

The Apply CLI Configlet page is displayed.

When you select a Configlet Template from the Select Configlets table, the parameters panel is updated with the applicable parameters for the selected Configlet Template. The field components are based on the Parameter Type.
9. Select the devices on which you want to apply the CLI Configlet and select **Apply CLI Configlet** from the Actions menu.

The Apply CLI Configlet page displays the parameters. Only text field and selection field type parameters are displayed.

To view the description of the parameter, mouse over the entry in the Parameter column.

NOTE: You cannot select more than 25 devices. If the device selection using the search criteria or tags lists more than 25 devices,

10. Double-click the **Value** column for each parameter and enter a value.

All values are accepted for the text field type parameter. For a selection field type parameter, you should select from one of the values you provided for the parameter. The set of values present and the default value selected were defined when the template was created.

11. Click **Next**.

The parameter value is validated against the regular expression (if given). If the parameter value violates the regular expression, then a validation error is displayed.

The Preview area of the Apply CLI Configlet page displays the preview of the CLI Configlet. If you selected to view the parameters and the configuration when previewing the CLI Configlet, the parameters and the configuration are displayed.

NOTE: Contents of the Preview area depend on the preview options in the CLI Configlet.

12. (Optional) Click **Validate** to validate the configuration.

The Validate Results page is displayed.

A job is triggered. The Progress column displays the progress against each device. When the validation is complete, the results of the validation are displayed. The Status column indicates the results of the validation.

NOTE: You can also view the validation results from the Job Management page. To view the validation results, double-click the job ID and click the **View Results** link corresponding to the device.

13. Click **Close**.

You are redirected to the Apply CLI Configlet page.

14. Select whether to apply the CLI Configlet now or later.

- To apply the CLI Configlet now:

- Click **Apply**.

The Configlets Results page is displayed. This page shows the job results.

- Click **Close** to return to the Configlets page.

- To apply the CLI Configlet later:

- a. Click **Back**.

You are redirected to the previous page.

- b. Select **Schedule at a later time**.

- c. Enter the date in the **Date** field in the DD/MM/YYYY format.

- d. Enter the time in the **Time** field in the hh:mm format.

- e. Click **Apply**.

The Job Information dialog box is displayed.

- f. Click **OK**.

Click **Cancel** to return to the Device Management CLI Configlets page.

RELATED DOCUMENTATION

[CLI Configlets Workflow | 1399](#)

[Configlet Context | 1403](#)

[Creating a CLI Configlet | 1409](#)

[Modifying a CLI Configlet | 1412](#)

[Deleting CLI Configlets | 1413](#)

[Viewing CLI Configlets | 1414](#)

[Creating a Parameter for a CLI Configlet | 1416](#)

Deploying CLI Configlet Details

You apply a CLI Configlet to devices when you want to push the configuration to devices. The CLI Configlet can be deployed to only one device, or the CLI Configlet can be deployed to multiple devices simultaneously. The saved configlets that are being propagated to devices can be viewed by selecting the Deployment option in the task pane. You can select a particular Configlet and view the parameters contained in it in the form of configuration stanzas and hierarchy levels. Each level in the hierarchy is indented to indicate each statement's relative position in the hierarchy. Each level is generally set off with braces, with an open brace ({} at the beginning of each hierarchy level and a closing brace (}) at the end.

To select whether to apply the CLI Configlet now or later:

1. From the View selector, select **Device View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and view the list of devices.
4. Select the device for which you want to view the applied CLI configlets. A graphical view of the device is displayed on the right pane.
5. From the tasks pane, select **Configuration Deployment > View Applied Configlets**.
The Manage CLI-Applied Configlets page is displayed.
6. Select a Configlet from the table of displayed Configlets that you want to deploy.
7.
 - To apply the CLI Configlet now:
 - Click **Deploy Now**.
Use the CSD Deployment Jobs page in Deploy mode of Service View (by selecting Service Provisioning > View Deployment Jobs) to view the status of the deployment job created to provision the configlet to the device.
 - Click **Close** to return to the Configlets page.
 - To apply the CLI Configlet later:
 - a. Select **Schedule Deploy**.
 - b. Enter the date in the **Date** field in the DD/MM/YYYY format.
 - c. Enter the time in the **Time** field in the hh:mm format.

- d. Click **Apply**.
- e. Use the CSD Deployment Jobs page in Deploy mode of Service View (by selecting Service Provisioning > View Deployment Jobs) to view the status of the deployment job created to provision the configlet to the device.

To view a deployed CLI Configlet details:

1. From the View selector, select **Device View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and view the list of devices.
4. From the tasks pane, select **Configuration Deployment > View Applied Configlets**.

The Manage CLI-Applied Configlets page is displayed.

5. Select the device for which you want to view the applied CLI configlets. A graphical view of the device is displayed on the right pane.

The following fields are displayed on this page:

Table 190: Columns on the Manage CLI-Applied Configlets Page

Field	Description
Name	Name of the configuration view
Domain Name	Domain to which the configuration view is associated
Category	The Category of the configlet. The Category cannot exceed 255 characters. Allowable characters include the dash (-), underscore (_), letters, and numbers and the period (.).
Description	Description of the configlet. The description cannot exceed 2500 characters. This is an optional field.
Applied To	Name of the interface or the device to which the Configlet is being deployed.
Version	Version of the Configlet template used to create the Configlet.
Validation State	State of the Configlet such as an invalid Configlet or a validated Configlet.

Table 190: Columns on the Manage CLI-Applied Configlets Page (*continued*)

Field	Description
Deployed State	Status of deployment of the Configlet.
Deployed Time	Date and time when the Configlet was deployed.
Deploy Now	Click this button to deploy and propagate the selected Configlet immediately to the device.
Schedule Deploy	Click this button to schedule the deploy of the selected Configlet for a later time.
Discard Deploy	Click this button to delete the selected Configlet.
Creation Time	Date and time when the Configlet was created.
Last Updated Time	Latest time when the Configlet was last updated.

6. Select a Configlet from the table of displayed Configlets for which you want to view the configuration details. A dialog box is displayed with the configuration attributes and parameters defined for the Configlet being deployed.
7. Click **Close** after you finish viewing the Configlet information. You are returned to the page listing all of the deployed Configlets.

RELATED DOCUMENTATION

[CLI Configlets Workflow | 1399](#)

[Configlet Context | 1403](#)

[Creating a CLI Configlet | 1409](#)

[Modifying a CLI Configlet | 1412](#)

[Deleting CLI Configlets | 1413](#)

[Creating a Parameter for a CLI Configlet | 1416](#)

[Applying a CLI Configlet to Devices | 1418](#)

17

PART

Managing Optical Interfaces, OTUs, ODU, ILAs, and IPLCs on MX Series and PTX Series Routers

Overview of Optical Interfaces, OTUs, and ODUs | **1426**

Overview of Optical ILAs and IPLCs | **1504**

Configuring and Monitoring Optical Interfaces, OTUs, and ODUs | **1553**

Configuring and Monitoring Optical Inline Amplifiers | **1627**

Configuring and Monitoring Optical Integrated Photonic Line Cards | **1650**

Overview of Optical Interfaces, OTUs, and ODUs

IN THIS CHAPTER

- [Optical Interfaces Management and Monitoring on MX Series and PTX Series Routers Overview | 1427](#)
- [Ethernet DWDM Interface Wavelength Overview | 1429](#)
- [Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview | 1429](#)
- [Understanding Pre-FEC BER Monitoring and BER Thresholds | 1430](#)
- [DWDM Controllers Overview | 1434](#)
- [PTX5000 PIC Description | 1434](#)
- [PTX3000 PIC Description | 1436](#)
- [100-Gigabit Ethernet OTN Optical Interface Specifications | 1439](#)
- [100-Gigabit DWDM OTN PIC Optical Interface Specifications | 1441](#)
- [100-Gigabit DWDM OTN PIC \(PTX Series\) | 1445](#)
- [100-Gigabit Ethernet OTN PIC with CFP2 \(PTX Series\) | 1455](#)
- [100-Gigabit Ethernet PIC with CFP2 \(PTX Series\) | 1458](#)
- [100-Gigabit Ethernet PIC with CFP \(PTX Series\) | 1462](#)
- [100GbE PICs for PTX Series Routers | 1469](#)
- [P2-10G-40G-QSFPP PIC Overview | 1470](#)
- [Understanding the P2-100GE-OTN PIC | 1475](#)
- [100-Gigabit DWDM OTN PIC with CFP2 \(PTX Series\) | 1479](#)
- [100-Gigabit DWDM OTN MIC with CFP2 | 1491](#)
- [100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)
- [Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength | 1501](#)

Optical Interfaces Management and Monitoring on MX Series and PTX Series Routers Overview

Packet optical networking is useful in any network with a converged supercore that needs to transport traffic in as efficient and effective a manner as possible. Packet optical devices, such as Juniper Networks MX Series routers and PTX Series Packet Transport Routers properly equipped with suitable line cards, are capable of placing packets directly onto optical transports and receiving packets the same way. In a packet optical network, the packets leave the router in an optical transport envelope at the correct wavelength and arrive the same way, bypassing much of the other external networking equipment needed to groom or otherwise process electrical or optical signals originating on the router.

Connectivity Services Director is the network management application implemented on the Junos Space Network Management application and enables service providers achieve faster IP service rollouts for business needs and reduce overall OpEx for managing the service life cycle. A unified network device management interface is essential to efficiently deploy a large number of devices that contain optic PICs. Considering that these devices are hosted in remote locations, it is essential to ensure that the device management interface (DMI) provides the right level of automation to reduce the time required to set up and configure each device without requiring additional manual intervention at the site after deployment. Centralized configuration management, rapid deployment, polling, statistics capture, and reporting are some of the essential components of a robust DMI.

Connectivity Services Director enables you to manage the packet optical functionality provided by 100-Gigabit Ethernet Optical Transport Network (OTN) and dense wavelength-division multiplexing (DWDM) PICs that can be installed on PTX Series devices. In addition, you can manage the packet optical functionality provided by the 100-Gigabit Ethernet and DWDM MICs that can be installed on MX Series routers. Connectivity Services Director presents a topological network view and a site view. The topological network view offers a pictorial representation of optical sites, links, and services. The site view provides information about the status, configuration, alarms or faults, and the performance of the optical interfaces. FCAPS (fault, configuration, accounting, performance, and security) is an explicit model that is used to achieve the operational objectives of network management. Connectivity Services Director offers an effective management system for a complete FCAPS functionality.

An important aspect of any network management system is to monitor, control, and plan the network infrastructure that comprises a large number of devices and extensive configuration parameters in a streamlined, easy, and cohesive way. The bulk, single-step propagation of settings on large sets of devices without impacting the working efficiency and traffic-handling capacity of the network is a salient objective.

You can configure, manage, and monitor the following components on PTX3000 and PTX5000 routers:

- 100-Gigabit DWDM OTN PIC (P1-PTX-2-100G-WDM)
- 100-Gigabit Ethernet OTN PIC with CFP (P1-PTX-2-100GE-CFP)
- 100-Gigabit Ethernet OTN PIC with CFP2 (P2-100GE-OTN)
- 100-Gigabit DWDM OTN PIC with CFP2 (PTX-5-100G-WDM)

- P2-100GE-CFP2 (4x100G CFP2 PIC)
- P1-PTX-24-10GE-SFPP (24x10G LAN PIC)
- P1-PTX-24-10G-W-SFPP (24x10G LAN/WAN PIC)
- P1-PTX-2-100G-C-WDM-C (2x100G LH DWDM PIC)
- P1-PTX-2-40GE-CFP (2x40-Gigabit Ethernet PIC with CFP)
- P1-PTX-2-100GE-CFP (2x100-Gigabit Ethernet PIC with CFP)
- P1-PTX-2-100G-WDM—Designed for metro, regional, or long-haul applications.
- 4-port 100-Gigabit Ethernet PIC (PTX5000)

The PIC supports 100GBASE-LR4 and 100GBASE-SR10 transceivers. The CFP2-100G-SR10-D transceiver is not dual-rate, it supports Ethernet only. The CFP2-100G-SR10-D2 transceiver is dual-rate, but only when used in a PIC that supports OTN, such as P2-100GE-OTN.

- P2-10G-40G-QSFPP PIC on the FPC2-PTX-P1A FPC (PTX5000)

You can configure the P2-10G-40G-QSFPP PIC to operate either in 10-Gigabit Ethernet mode or in 40-Gigabit Ethernet mode.

The Chassis View provides a pictorial representation of the chassis or device, and the modules or components that are installed in it, such as the line cards, interfaces, and other hardware elements. To view a pictorial representation of a device chassis and the configured components, such as interfaces, line cards, and hardware elements, select a managed device listed on the My Network tree in Device View of Connectivity Services Director, and select **Device Management > View Physical Inventory** from the tasks pane. The right pane displays the device image and the corresponding description of the view selected in a table. The Chassis View is displayed. The hardware and line module details are displayed with a pictorial view of the slots of the devices and the modules installed in these slots. Use the arrow buttons on the page to rotate the device image to view all planes of the device and the components installed on each plane.

Click the right and left arrow buttons to view the right and left planes of the device. To view the front and the back planes of the devices, click the double-left and double-right arrows respectively. You can rotate the device image in different orientations along 360 degrees. The front view displays the components installed and the interfaces configured on the device. Click Refresh to update the contents of the page. Mouse over the device image to see brief information of components and interfaces in tooltips. Click a particular component or interface to display detailed information about the component or interface in the lower portion of the page.

RELATED DOCUMENTATION

[Viewing a Graphical Image of the Optical Interface Components](#) | 1553

Ethernet DWDM Interface Wavelength Overview

Dense wavelength-division multiplexing (DWDM) interfaces are supported on 10-Gigabit Ethernet DWDM PICs, MICs, and MPCs; the 10-Gigabit Ethernet LAN/WAN OTN PIC; and the 100-Gigabit Ethernet DWDM OTN PIC. When a tunable optic transceiver is available, you can configure the DWDM interfaces with full C-band International Telecommunication Union (ITU)-Grid tunable optics, as defined in the following specifications:

- *Intel TXN13600 Optical Transceiver I2C Interface and Customer EEPROM Preliminary Specification*, July 2004.
- *I2C Reference Document for 300-Pin MSA 10G and 40G Transponder*, Edition 4, August 04, 2003.

By default, the wavelength is 1550.12 nanometers (nm), which corresponds to 193.40 terahertz (THz).

RELATED DOCUMENTATION

[Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview | 1429](#)

[Understanding Pre-FEC BER Monitoring and BER Thresholds | 1430](#)

[DWDM Controllers Overview | 1434](#)

Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview

Correct functioning of an optical data link depends on modulated light reaching the receiver with enough power to be demodulated correctly. *Attenuation* is the reduction in the power of the light signal as it is transmitted. Attenuation is caused by passive media components, such as cables, cable splices, and connectors. While attenuation is significantly lower for optical fiber than for other media, it still occurs in both multimode and single-mode transmission. An efficient optical data link must have enough light available to overcome attenuation.

Dispersion is the spreading of the signal in time. The following two types of dispersion can affect an optical data link:

- Chromatic dispersion—Spreading of the signal in time resulting from the different speeds of light rays
- Modal dispersion—Spreading of the signal in time resulting from the different propagation modes in the fiber

For multimode transmission, modal dispersion, rather than chromatic dispersion or attenuation, usually limits the maximum bit rate and link length. For single-mode transmission, modal dispersion is not a factor.

However, at higher bit rates and over longer distances, chromatic dispersion rather than modal dispersion limits maximum link length.

An efficient optical data link must have enough light to exceed the minimum power that the receiver requires to operate within its specifications. In addition, the total dispersion must be less than the limits specified for the type of link in Telcordia Technologies document GR-253-CORE (Section 4.3) and International Telecommunications Union (ITU) document G.957.

When chromatic dispersion is at the maximum allowed, its effect can be considered as a power penalty in the power budget. The optical power budget must allow for the sum of component attenuation, power penalties (including those from dispersion), and a safety margin for unexpected losses.

RELATED DOCUMENTATION

[Ethernet DWDM Interface Wavelength Overview | 1429](#)

[Understanding Pre-FEC BER Monitoring and BER Thresholds | 1430](#)

[DWDM Controllers Overview | 1434](#)

Understanding Pre-FEC BER Monitoring and BER Thresholds

Optical transport network (OTN) interfaces on PTX Series Packet Transport Routers support monitoring the condition of an OTN link by using the pre-forward error correction (pre-FEC) bit error rate (BER). The following PICs support pre-FEC BER monitoring:

- P1-PTX-2-100G-WDM
- P2-100GE-OTN
- PTX-5-100G-WDM
- P1-PTX-24-10G-W-SFPP

With pre-FEC BER monitoring enabled, when the configured pre-FEC BER signal degrade threshold is reached, the PIC stops forwarding packets to the remote interface and raises an interface alarm. Ingress packets continue to be processed. If pre-FEC BER monitoring is used with MPLS fast reroute or another link protection method, then traffic is rerouted to a different interface.

You can also configure backward fast reroute to insert the local pre-FEC status into transmitted OTN frames, notifying the remote interface of signal degradation. The remote interface can use the information to reroute traffic to a different interface. If you use pre-FEC BER monitoring together with backward fast reroute, then notification of signal degradation and rerouting of traffic occurs in less time than that required through a Layer 3 protocol.

Include the **signal-degrade-monitor-enable** and **backward-frr-enable** statements at the [edit interfaces *interface-name* otn-options preemptive-fast-reroute] hierarchy level to enable pre-FEC BER monitoring and backward fast reroute.

NOTE: When you configure pre-FEC BER signal degrade monitoring, we recommend that you configure both the **signal-degrade-monitor-enable** and the **backward-frr-enable** statements.

You can also configure the pre-FEC BER thresholds that raise or clear a signal degrade alarm and the time interval for the thresholds. If the BER thresholds and interval are not configured, the default values are used.

The pre-FEC BER signal degrade threshold value defines a specific amount of system margin relative to the BER correction limit (or FEC limit) of the PIC's receive FEC decoder. The FEC limit is fixed on each PIC—it is intrinsic to the FEC decoder implementation.

NOTE: The following examples use Q^2 -factor measurements (also known as Q-factor). Q^2 -factor is expressed in units of decibels relative to a Q^2 -factor of zero (dBQ). Q^2 -factor enables you to describe system margin in linear terms in contrast to BER values, which are nonlinear in nature. After you determine the thresholds, you must convert the threshold values from Q^2 -factor to BER to enter them in the CLI by using scientific notation. BER can be converted to Q^2 -factor by using the following equation:

$$Q^2\text{-factor} = 20 * \log_{10}(\sqrt{2} * \text{erfcinv}(2 * \text{BER}))$$

TIP: To convert between Q^2 -factor and BER in a spreadsheet program, you can approximate the values by using the following formulas:

- To calculate Q^2 -factor:

$$= 20 * \text{LOG10}(-\text{NORMSINV}(\text{BER}))$$

- To calculate BER:

$$= 1 - \text{NORMSDIST}(10^{(0.05 * Q^2\text{-factor})})$$

Table 191 on page 1432 shows the relationship between the fixed FEC limit, the configurable signal degrade threshold, and the configurable clear threshold for different PICs. In this example, approximately 1 dBQ of system margin has been set between the FEC limit, signal degrade threshold, and clear threshold.

Table 191: Example—Signal Degrade and Clear Threshold Values at 1 dBQ

PIC	FEC Type	FEC Limit		Signal Degrade Threshold		Clear Threshold	
		Q ² -Factor	BER	Q ² -Factor	BER	Q ² -Factor	BER
P1-PTX-2-100G-WDM	SD-FEC	6.7 dBQ	1.5E-2	7.7 dBQ	7.5E-3	8.7 dBQ	3.0E-3
P2-100GE-OTN	G.709 GFEC	11.5 dBQ	8.0E-5	12.5 dBQ	1.1E-5	13.5 dBQ	1.0E-6
P1-PTX-24-10G-W-SFPP	G.975.1 I.4 (UFEC)	9.1 dBQ	2.2E-3	10.1 dBQ	6.9E-4	11.1 dBQ	1.6E-4
	G.975.1 I.7 (EFEC)	9.6 dBQ	1.3E-3	10.6 dBQ	3.6E-4	11.6 dBQ	7.5E-5
	G.709 GFEC	11.5 dBQ	8.0E-5	12.5 dBQ	1.1E-5	13.5 dBQ	1.0E-6

To adjust the signal degrade threshold, you must first decide on a new system margin target and then calculate the respective BER value (using the equation to convert from Q²-factor to BER).

Table 192 on page 1433 shows the values if 3 dBQ of system margin relative to the FEC limit is desired for the signal degrade threshold (while maintaining the clear threshold at 1 dBQ relative to the signal degrade threshold).

NOTE: The choice of system margin is subjective, as you might want to optimize your thresholds based on different link characteristics and fault tolerance and stability objectives. For guidance about configuring pre-FEC BER monitoring and BER thresholds, contact your Juniper Networks representative.

Table 192: Example—Signal Degrade and Clear Thresholds After Configuration

PIC	FEC Type	FEC Limit		Signal Degrade Threshold		Clear Threshold	
		Q ² -Factor	BER	Q ² -Factor	BER	Q ² -Factor	BER
P1-PTX-2-100G-WDM	SD-FEC	6.7 dBQ	1.5E-2	9.7 dBQ	1.1E-3	10.7 dBQ	2.9E-4
P2-100GE-OTN	G.709 GFEC	11.5 dBQ	8.0E-5	14.5 dBQ	4.9E-8	15.5 dBQ	1.1E-9
P1-PTX-24-10G-W-SFPP	G.975.1 I.4 (UFEC)	9.1 dBQ	2.2E-3	12.1 dBQ	2.8E-5	13.1 dBQ	3.1E-6
	G.975.1 I.7 (EFEC)	9.6 dBQ	1.3E-3	12.6 dBQ	1.1E-5	13.6 dBQ	9.1E-7
	G.709 GFEC	11.5 dBQ	8.0E-5	14.5 dBQ	4.8E-8	15.5 dBQ	1.1E-9

Include the **ber-threshold-signal-degrade**, **ber-threshold-clear**, and **interval** statements at the **[edit interfaces interface-name otn-options signal-degrade]** hierarchy level to configure the BER thresholds and time interval.

NOTE: Configuring a high BER threshold for signal degradation and a long interval might cause the internal counter register to be saturated. Such a configuration is ignored by the router, and the default values are used instead. A system log message is logged for this error.

RELATED DOCUMENTATION

[Ethernet DWDM Interface Wavelength Overview | 1429](#)

[Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview | 1429](#)

[DWDM Controllers Overview | 1434](#)

DWDM Controllers Overview

Dense wavelength division multiplexing (DWDM) module support is based on the Optical Transport Network (OTN) protocol that is specified in ITU-T G.709. This standard combines the benefits of SONET/SDH technology with the multiwavelength networks of DWDM. It also enables forward error correction (FEC) that can allow a reduction in network costs by reducing the number of regenerators used. To enable multiservice transport, OTN uses the concept of a wrapped overhead (OH). To understand this format, the following elements are involved:

- Optical channel payload unit (OPU) OH information is added to the information payload to form the OPU. The OPU OH includes information to support the adaptation of client signals.
- Optical channel data unit (ODU) OH is added to the OPU to create the ODU. The ODU OH includes information for maintenance and operational functions to support optical channels.
- Optical channel transport unit (OTU) OH together with the FEC is added to form the OTU. The OTU OH includes information for operational functions to support the transport by way of one or more optical channel connections.
- Optical channel (OCh) OH is added to form the OCh. The OCh provides the OTN management functionality and contains four subparts: the OPU, ODU, OTU, and frame alignment signal (FAS).

RELATED DOCUMENTATION

[Ethernet DWDM Interface Wavelength Overview | 1429](#)

[Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview | 1429](#)

[Understanding Pre-FEC BER Monitoring and BER Thresholds | 1430](#)

PTX5000 PIC Description

IN THIS SECTION

- [PTX5000 PIC Slots | 1435](#)
- [PTX5000 PIC Function | 1435](#)
- [PICs Supported on the PTX5000 | 1435](#)
- [PTX5000 PIC Components | 1435](#)

PTX5000 PIC Slots

Each FPC has two PIC slots. Blank PICs resemble other PICs but do not provide any physical connection or activity. When a PIC slot is not occupied by a PIC, you must insert a blank PIC to fill the empty slot and ensure proper cooling of the system. PICs are hot-removable and hot-insertable.

PTX5000 PIC Function

PICs provide the physical connection to various network media types, receiving incoming packets from the network and transmitting outgoing packets to the network. During this process, each PIC performs framing and line-speed signaling for its media type. Before transmitting outgoing data packets, the PICs encapsulate the packets received from the FPCs.


PICs Supported on the PTX5000

See [PTX Series PIC/FPC Compatibility](#) for a complete list of PICs supported on the PTX5000.

PTX5000 PIC Components

[Figure 29 on page 1436](#) shows an example of a PIC supported on the PTX5000. PICs have an upper ejector handle and a lower ejector handle.

Figure 29: PIC Faceplate



RELATED DOCUMENTATION

100-Gigabit Ethernet OTN Options Configuration Overview | 1499

PTX3000 PIC Description | 1436

PTX3000 PIC Description

IN THIS SECTION

- PIC Slots | 1437
- PIC Function | 1438
- PICs Supported | 1438
- PIC Components | 1438


PIC Slots

Up to eight PICs install vertically in the front of the PTX3000 ([Figure 30 on page 1437](#)). The PIC slots are numbered **1, 3, 5, and 7** in the upper chassis, and **9, 11, 13, and 15** in the lower chassis.

The PIC in the slot to the right of an FPC is associated with that FPC. Each PIC requires an FPC to be installed in the adjacent FPC slot to its left as specified in [Table 193 on page 1438](#). For example, the PIC in slot **1** is associated with the FPC in slot **0**.

When a slot is not occupied by a PIC, you must insert a blank PIC to fill the empty slot and ensure proper cooling of the system. Blank PICs resemble other PICs but do not provide any physical connection or activity. PICs are hot-removable and hot-insertable.

Figure 30: PIC Slots



NOTE: In the CLI, all PTX3000 PICs are represented as **pic0**.

Table 193: CLI Representation of PIC Slots

FPC Slot in Chassis	PIC Slot in Chassis	CLI Representation of PIC Slots
0	1	<i>fpc0-pic0-port-number</i>
2	3	<i>fpc2-pic0-port-number</i>
4	5	<i>fpc4-pic0-port-number</i>
6	7	<i>fpc6-pic0-port-number</i>
8	9	<i>fpc8-pic0-port-number</i>
10	11	<i>fpc10-pic0-port-number</i>
12	13	<i>fpc12-pic0-port-number</i>
14	15	<i>fpc14-pic0-port-number</i>

PIC Function

PICs provide the physical connection to various network media types, receiving incoming packets from the network and transmitting outgoing packets to the network. During this process, each PIC performs framing and line-speed signaling for its media type. Before transmitting outgoing data packets, the PICs encapsulate the packets received from the FPCs.


PICs Supported

See *PICs Supported on the PTX Series* for a complete list of PICs supported on the PTX3000.

PIC Components

[Figure 31 on page 1439](#) shows an example of a PIC supported on the PTX3000. PICs have an upper ejector handle and a lower ejector handle.

Figure 31: PIC Faceplate



RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)

100-Gigabit Ethernet OTN Optical Interface Specifications

IN THIS SECTION

- [OTU4 4I1-9D1F Optical Interface Specifications | 1440](#)

The 100-Gigabit Ethernet OTN (Optical Transport Network) optical interface standards described below are supported on PTX Series routers.

To determine which transceivers support each 100-Gigabit Ethernet OTN standard, see *Supported Network Interface Standards by Transceiver for PTX Series Routers*. The “Cables and Connectors” section in the description for each PIC lists which standards and transceivers are supported for that device.

OTU4 4I1-9D1F Optical Interface Specifications

[Table 194 on page 1440](#) shows the optical interface specifications for the OTU4 4I1-9D1F standard.

Table 194: OTU4 4I1-9D1F (ITU-T 959.1) Optical Interface Specifications

Parameter	DML Laser	EML Laser
Optical interface	Single-mode	Same as DML laser
Standard	ITU-T 959.1	Same as DML laser
Maximum distance	ITU-T G.652 fiber, 6.2 miles (10 km)	Same as DML laser
Central frequency	1294.53 through 1296.59 nm 1299.02 through 1301.09 nm 1303.54 through 1305.63 nm 1308.09 through 1310.19 nm	Same as DML laser
Mean channel output power	–0.6 through 4.0 dBm per lane	–2.5 through 2.9 dBm per lane
Mean channel input power	–6.9 through 4.0 dBm	–8.8 through 2.9 dBm
Minimum equivalent sensitivity per lane	–8.4 dBm	–10.3 dBm

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)

[PTX3000 PIC Description | 1436](#)

100-Gigabit DWDM OTN PIC Optical Interface Specifications

PTX Series routers support the following 100-Gigabit (Dense Wavelength Division Multiplexing) OTN (Optical Transport Network) fixed transceiver PIC:

- P1-PTX-2-100G-WDM—Designed for metro, regional, or long-haul applications.

[Table 195 on page 1441](#) and [Table 196 on page 1442](#) show the optical interface specifications for the 100-Gigabit DWDM OTN PIC transceivers.

Table 195: 100-Gigabit DWDM OTN PIC Optical Interface Specifications

Specifications	P1-PTX-2-100G-WDM
Transceiver type	<ul style="list-style-type: none"> • DWDM integrated transceiver
Standards	<ul style="list-style-type: none"> • ITU-T G.709—Interfaces for the optical transport network. • ITU-T G.798—Characteristics of optical transport network hierarchy equipment functional blocks • ITU-T G.694.1—Spectral grids for WDM applications: DWDM frequency grid • RFC 3591—Definitions of Managed Objects for the Optical Interface Type
Optical interface	<ul style="list-style-type: none"> • Single-mode optical fiber (ITU-T G.652)
Line interface	<ul style="list-style-type: none"> • Line rate: 127.156441 Gbps • Modulation format: Dual polarization-quadrature phase-shift keying (DP-QPSK), non-return-to-zero (NRZ) • FEC type: Soft decision • Channel-plan wavelength range: 1529.55 through 1567.54 nm • Channel-plan frequency range: 191.25 through 196.00 THz • Channel spacing: 50 GHz • Channel tunability: 96 channels—see Table 196 on page 1442
Optical transmitter	<ul style="list-style-type: none"> • Output power (on): -2 dBm • Output power (off): ≤-45 dBm • Wavelength accuracy: +/-2.5 GHz • Channel tuning time: ≤30 seconds

Table 195: 100-Gigabit DWDM OTN PIC Optical Interface Specifications (*continued*)

Specifications	P1-PTX-2-100G-WDM
Optical receiver	<ul style="list-style-type: none"> • Average receive power (input power range): –18 to –5 dBm • Input sensitivity (unamplified/dark-fiber applications): –28 dBm • LO wavelength accuracy: ± 2.5 GHz • Channel tuning time: ≤ 30 seconds • Damage input power threshold: +10 dBm • Minimum OSNR (back-to-back): 13.5 dB typical • Minimum OSNR (back-to-back): 14.5 dB worst-case, EOL • Chromatic dispersion tolerance: $\pm 50,000$ ps/nm • PMD tolerance: 25 ps (mean DGD) • Polarization tracking: 150 krad/s

Table 196 on page 1442 provides the supported wavelengths in both terahertz (THz) and nanometers (nm).

Table 196: 100-Gigabit DWDM OTN Supported Wavelengths

100-GHz Grid		50-GHz Offset	
THz	nm	THz	nm
–	–	191.25	1567.54
191.30	1567.13	191.35	1566.72
191.40	1566.31	191.45	1565.90
191.50	1565.50	191.55	1565.09
191.60	1564.68	191.65	1564.27
191.70	1563.86	191.75	1563.45
191.80	1563.05	191.85	1562.64
191.90	1562.23	191.95	1561.83
192.00	1561.42	192.05	1561.01
192.10	1560.61	192.15	1560.20
192.20	1559.79	192.25	1559.39

Table 196: 100-Gigabit DWDM OTN Supported Wavelengths (*continued*)

100-GHz Grid		50-GHz Offset	
THz	nm	THz	nm
192.30	1558.98	192.35	1558.58
192.40	1558.17	192.45	1557.77
192.50	1557.36	192.55	1556.96
192.60	1556.55	192.65	1556.15
192.70	1555.75	192.75	1555.34
192.80	1554.94	192.85	1554.54
192.90	1554.13	192.95	1553.73
193.00	1553.33	193.05	1552.93
193.10	1552.52	193.15	1552.12
193.20	1551.72	193.25	1551.32
193.30	1550.92	193.35	1550.52
193.40	1550.12	193.45	1549.72
193.50	1549.32	193.55	1548.91
193.60	1548.51	193.65	1548.11
193.70	1547.72	193.75	1547.32
193.80	1546.92	193.85	1546.52
193.90	1546.12	193.95	1545.72
194.00	1545.32	194.05	1544.92
194.10	1544.53	194.15	1544.13
194.20	1543.73	194.25	1543.33

Table 196: 100-Gigabit DWDM OTN Supported Wavelengths (*continued*)

100-GHz Grid		50-GHz Offset	
THz	nm	THz	nm
194.30	1542.94	194.35	1542.54
194.40	1542.14	194.45	1541.75
194.50	1541.35	194.55	1540.95
194.60	1540.56	194.65	1540.16
194.70	1539.77	194.75	1539.37
194.80	1538.98	194.85	1538.58
194.90	1538.19	194.95	1537.79
195.00	1537.40	195.05	1537.00
195.10	1536.61	195.15	1536.22
195.20	1535.82	195.25	1535.43
195.30	1535.04	195.35	1534.64
195.40	1534.25	195.45	1533.86
195.50	1533.47	195.55	1533.07
195.60	1532.68	195.65	1532.29
195.70	1531.90	195.75	1531.51
195.80	1531.12	195.85	1530.72
195.90	1530.33	195.95	1529.94
196.00	1529.55	–	–

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)


[PTX3000 PIC Description | 1436](#)

100-Gigabit DWDM OTN PIC (PTX Series)

IN THIS SECTION

- [Software Release | 1446](#)
- [Hardware Features | 1447](#)
- [Software Features | 1447](#)
- [Cables and Connectors | 1449](#)

- LEDs | 1449
- Alarms, Errors, and Events | 1450



Software Release

PTX Series routers support the following 100-Gigabit DWDM (dense wavelength division multiplexing) OTN (optical transport network) PICs:

- 100-Gigabit DWDM OTN PIC (P1-PTX-2-100G-WDM):
 - PTX3000: Junos OS Release 13.3 and later
 - PTX5000: Junos OS Release 13.2 and later

For information about which FPCs support this PIC, see [PTX Series PIC/FPC Compatibility](#).

Hardware Features

- Model number:
 - P1-PTX-2-100G-WDM—Designed for metro, regional, or long-haul applications.
- Two 100-Gigabit DWDM OTN ports
- Power requirements: 6.48 A @ -48 V (311 W)
- Transparent transport of two 100-Gigabit Ethernet signals with OTU4V framing
- ITU-standard OTN performance monitoring and alarm management
- Dual polarization-quadrature phase-shift keying (DP-QPSK) modulation and soft-decision forward error correction (SD-FEC) for long haul and metro applications
- 96 channels on C-band ITU grid with 50-GHz spacing
- Full-duplex mode
- Maximum transmission units (MTUs) up to 9500 bytes
- Latency: 32 μ s (TX + RX)

NOTE: The 100-Gigabit DWDM OTN PIC is designed to comply with NEBS regulations on the PTX5000 router when used in typical configurations. The typical configuration for a PTX5000 router is up to eight FPCs, with one 100-Gigabit DWDM OTN PIC and one 100-Gigabit Ethernet PIC with CFP, 40-Gigabit Ethernet PIC with CFP, or 10-Gigabit Ethernet PIC with SFP+ installed in the same FPC.

The 100-Gigabit DWDM OTN PIC is designed to comply with NEBS regulations on the PTX3000 router when used in typical configurations at 40° C (104° F) at sea level. The typical configuration for a PTX3000 router is up to eight FPCs, with one 100-Gigabit DWDM OTN PIC next to each FPC in the top row only. The 100-Gigabit Ethernet PIC with CFP, 40-Gigabit Ethernet PIC with CFP, or 10-Gigabit Ethernet PIC with SFP+ are supported next to any FPC.

Software Features

Table 197 on page 1447 shows the first supported release for each software feature.

Table 197: Software Features Supported

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
Compliant with ITU G.709 and G.798	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2

Table 197: Software Features Supported (continued)

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
Provides a transport interface and state model (GR-1093)	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Performance monitoring such as alarms, threshold-crossing alarms, OTU/ODU error seconds and pre-FEC statistics	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
SNMP management of the PIC based on RFC 3591, Managed Objects for the Optical Interface Type <ul style="list-style-type: none"> • Set functionality • Juniper Networks Black-Link MIB • IFOTN MIB • Optics MIB • FRU MIB 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
IEEE 802.1ag OAM	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
IEEE 802.3ah OAM	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
IFINFO/IFMON	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
IEEE 802.3ad link aggregation	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Pre-FEC BER monitoring provides interrupt-driven link-signal-degrade BER-based detection for MPLS fast reroute	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Flexible Ethernet services encapsulation	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Flexible VLAN tagging	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Source address MAC accounting per logical interface	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Source address MAC filter per port	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 • PTX-2-100G-WDM-M: 14.2R3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2

Table 197: Software Features Supported (*continued*)

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
Source address MAC filter per logical interface	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2 • PTX-2-100G-WDM-M: 14.2R3
Destination address MAC filter per port	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2
Up to 8000 logical interfaces shared across all ports on a single PFE	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.3 	<ul style="list-style-type: none"> • P1-PTX-2-100G-WDM: 13.2

Cables and Connectors

- Single-mode optical fiber (ITU-T G.652)
- Duplex LC connector (Rx and Tx)
- Optical interface specifications

LEDs

The **STATUS** LED is located above the **ONLINE OFFLINE** button. The **LINK** and **ACT** LEDs are located next to each port. [Table 198 on page 1449](#) describes the functions of these LEDs.

Table 198: 100-Gigabit DWDM OTN PIC LEDs

Label	Color	State	Description
STATUS	Green	On steadily	PIC is online with no alarms or failures.
	Yellow	On steadily	PIC is initializing.
	Red	On steadily	PIC is online but has errors or alarms.
	–	Off	PIC is offline or not enabled.

Table 198: 100-Gigabit DWDM OTN PIC LEDs (*continued*)

Label	Color	State	Description
LINK for each port:	Green	On steadily	Port is online with no alarms or failures, and the link is up.
	Yellow		Port has detected an alarm or failure.
	Red	On steadily	Port has detected a media alarm or failure.
	–	Off	Port is off or not enabled.
ACT for each port	Green	Flashing	Activity detected. Port is sending or receiving packets.
	–	Off	No packet activity detected on the port.

Alarms, Errors, and Events

Chassis and PIC:

- PIC (FRU) inserted or removed
- PIC (FRU) Admin InService/OutOfService, Oper Unequipped/Init/Normal/Mismatch/Fault/Upgrade
- Mismatch equipment
- Temperature alarm
- Fan alarm

Port (interface):

- Interface Admin InService/OutOfService/ServiceMA/OutOfServiceMA, Oper Init/Normal/Fault/Degraded

OTN (optical transport network):

- LOS (loss of signal)
- LOF (loss of frame)
- LOM (loss of multiframe)
- SSF (server signal failure)
- TSF (trail signal fail)

OTU (optical channel transport unit):

- OTU-FEC-DEG (forward error correction degraded)
- OTU-FEC-EXE (excessive errors, FEC_FAIL from the transponder)
- OTU-AIS (alarm indication signal or all ones signal)
- OTU-BDI (backward defect identification)
- OTU-IAE (incoming alignment error)
- OTU-BIAE (backward incoming alignment error)
- OTU-TTIM (destination access point identifier [DAPI], source access point identifier [SAPI], or both mismatch from expected to received)
- OTU-DEG (OTU degraded)

ODU (optical channel data unit):

- CSF (client signal failure)
- ODU-DM-TIMEOUT (DM timeout)
- ODU-LCK (ODU lock triggers for path monitoring and TCM levels 1 through 6)
- ODU-AIS (alarm indication signal or all ones signal)
- ODU-OCI (open connection error)
- ODU-BDI (backward defect indication)
- ODU-DEG (ODU degraded)
- ODU-IAE (incoming alignment error)
- ODU-DAPI-TTIM (DAPI or DAPI/SAPI mismatch from expected to receive)
- ODU-SAPI-TTIM (SAPI or DAPI/SAPI mismatch from expected to receive)
- ODU-BEI (backward error indication)
- ODU-BEI-ERR (backward error indication error)
- ODU-BIP8-ERR (bit interleaved parity 8 error)
- ODU-SSF (server signal fail)
- ODU-TSF (trail signal fail)
- ODU-SD (signal degrade)

OPI (optical channel payload):

- OPI-PTM (payload type mismatch)

Optics:

- TX output power

Card-related status:

- Transceiver temperature high alarm
- Transceiver temperature high warning
- Transceiver temperature low alarm
- Transceiver temperature low warning
- Transceiver voltage high alarm
- Transceiver voltage high warning
- Transceiver voltage low alarm
- Transceiver voltage low warning
- Transceiver temperature monitor A/D value
- Transceiver power supply monitor A/D value (voltage)

Network lane transmit-related status:

- TX laser current bias high alarm
- TX laser current bias high warning
- TX laser current bias low alarm
- TX laser current bias low warning
- TX laser temperature high alarm
- TX laser temperature high warning
- TX laser temperature low alarm
- TX laser temperature low warning
- TX output optical power high alarm
- TX output optical power high warning
- TX output optical power low alarm
- TX output optical power low warning
- TX laser TEC fault
- TX laser wavelength unlocked fault

- TX modulator bias high alarm
- TX modulator bias high warning
- TX modulator bias low alarm
- TX modulator bias low warning
- TX loss of signal fault
- TX current laser output power
- TX minimum laser output power over a performance monitoring interval
- TX average laser output power over a performance monitoring interval
- TX maximum laser output power over a performance monitoring interval

Network lane receive-related status:

- RX laser bias current high alarm
- RX laser bias current high warning
- RX laser bias current low alarm
- RX laser bias current low warning
- RX input optical power high alarm
- RX input optical power high warning
- RX input optical power low alarm
- RX input optical power low warning
- RX laser output high alarm
- RX laser output high warning
- RX laser output low alarm
- RX laser output low warning
- RX laser temperature high alarm
- RX laser temperature high warning
- RX laser temperature low alarm
- RX laser temperature low warning
- RX LOS
- RX Laser wavelength unlocked fault
- RX laser TEC fault
- RX current chromatic dispersion

- RX average chromatic dispersion over a performance monitoring interval
- RX minimum chromatic dispersion over a performance monitoring interval
- RX maximum chromatic dispersion over a performance monitoring interval
- RX current Q
- RX average Q over a performance monitoring interval
- RX minimum Q over a performance monitoring interval
- RX maximum Q over a performance monitoring interval
- RX current carrier frequency offset
- RX average carrier frequency offset over a performance monitoring interval
- RX minimum carrier frequency offset over a performance monitoring interval
- RX maximum carrier frequency offset over a performance monitoring interval
- RX current SNR (signal-to-noise ratio)
- RX average SNR
- RX minimum SNR
- RX maximum SNR
- RX modem sync detect fault occurred over a performance monitoring interval
- RX modem lock fault occurred over a performance monitoring interval
- RX loss of alignment occurred over a performance monitoring interval
- RX out of alignment occurred over a performance monitoring interval
- RX deskew lock fault occurred over a performance monitoring interval
- RX LOS occurred over a performance monitoring interval
- RX current laser output power
- RX minimum laser output power over a performance monitoring interval
- RX average laser output power over a performance monitoring interval
- RX maximum laser output power over a performance monitoring interval

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)


[PTX5000 PIC Description | 1434](#)

[PTX3000 PIC Description | 1436](#)

100-Gigabit Ethernet OTN PIC with CFP2 (PTX Series)

IN THIS SECTION

- [Software Release | 1456](#)
- [Hardware Features | 1456](#)
- [Software Features | 1456](#)
- [Cables and Connectors | 1457](#)
- [LEDs | 1457](#)



Software Release

- PTX5000: Junos OS Release 14.1R2 and later

Hardware Features

- Four ports that can be configured as 100-Gigabit Ethernet, 100-Gigabit OTN, or a combination of 100-Gigabit Ethernet and 100-Gigabit Ethernet OTN interfaces.
- Model number: P2-100GE-OTN
- Name in the CLI: **4x100GE OTN CFP2**
- Power requirements: 14.50A@ -12 V (176 W)
- Large maximum transmission units (MTUs): up to 9500 bytes

Software Features

[Table 199 on page 1456](#) shows the first supported release for each software feature.

Table 199: Software Features Supported

Software Feature	First Supported Junos OS Release on PTX5000
Flexible Ethernet services encapsulation	14.1R2
Flexible VLAN tagging	14.1R2
IFINFO / IFMON	14.1R2
IEEE 802.1 ag OAM	14.1R2
IEEE 802.3 ah OAM	14.1R2
IEEE 802.3ad link aggregation	14.1R2
Interrupt-driven link-down detection for MPLS FRR	14.1R2
MAC accounting per logical interface for source addresses	14.1R2
MAC filter per port for destination addresses and source addresses	14.1R2
MAC filter per logical interface for source addresses	14.1R2

Table 199: Software Features Supported (*continued*)

Software Feature	First Supported Junos OS Release on PTX5000
SNMP	14.1R2
Up to 4000 logical interfaces shared across all ports on a single PFE	14.1R2

Cables and Connectors

The following transceivers are supported on this PIC:

- CFP2-100G-LR4-D—Supports both 100GBASE-LR4 and OTU4 411-9D1F
 - Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications* or *100-Gigabit Ethernet OTN Optical Interface Specifications*
 - Connector: LC
- CFP2-100G-SR10-D—Supports 100GBASE-SR10

NOTE: This transceiver supports Ethernet only, OTN is not supported.

- Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications*
- Connector: 24-fiber MPO
- CFP2-100GBASE-LR4—Supports 100GBASE-LR4
 - Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications*
 - Connector: LC
- CFP2-100GBASE-SR10—Supports 100GBASE-SR10
 - Cable:
 - Connector: 24-fiber MPO

LEDs

The **STATUS** LED is located to the left of the **ONLINE/OFFLINE** button. One LED is located next to each port to indicate the link activity of the port. [Table 200 on page 1458](#) describes the functions of these LEDs.

Table 200: 100-Gigabit Ethernet OTN PIC with CFP2 LEDs

Label	Color	State	Description
STATUS	Green	On steadily	PIC is online with no alarms or failures.
	Yellow	On steadily	PIC is initializing.
	Red	On steadily	PIC is in failed state.
	–	Off	PIC is offline or not enabled.
Single LED per port, labeled 0, 1, 2, and 3	Green	On steadily	Port is online with no alarms or failures, and the link is up.
		Blinking	Activity detected. Port is sending or receiving packets.
	Red	On steadily	Port is on but the link is down, and the port has detected a failure with alarms.
	–	Off	Port is off or not enabled.

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)


[PTX3000 PIC Description | 1436](#)

100-Gigabit Ethernet PIC with CFP2 (PTX Series)

IN THIS SECTION

- [Software Release | 1459](#)
- [Hardware Features | 1459](#)
- [Software Features | 1460](#)
- [Cables and Connectors | 1460](#)

- LEDs | 1461
- Alarms, Errors, and Events | 1462



Software Release

- PTX5000: Junos OS Release 14.1 and later

Hardware Features

- Four 100-Gigabit Ethernet ports
- Model number: P2-100GE-CFP2
- Name in the CLI: **4x100GE CFP2**
- Power requirements: 1.66A@ -48 V (90W)
- Large maximum transmission units (MTUs): up to 9500 bytes

Software Features

Table 201 on page 1460 shows the first supported release for each software feature.

Table 201: Software Features Supported

Software Feature	PTX5000 First Supported Junos OS Release
Flexible-ethernet-services encapsulation	14.1
Flexible VLAN tagging	14.1
IFINFO / IFMON	14.1
IEEE 802.1 ag OAM	14.1
IEEE 802.3 ah OAM	14.1
IEEE 802.3ad link aggregation	14.1
Interrupt-driven link-down detection for MPLS FRR	14.1
MAC accounting per logical interface for source addresses	14.1
MAC filter per port for destination addresses and source addresses	14.1
MAC filter per logical interface for source addresses	14.1
SNMP	14.1
Up to 4000 logical interfaces share across all ports on a single PFE	14.1

Cables and Connectors

The following transceivers are supported on this PIC:

- CFP2-100G-LR4-D—Supports 100GBASE-LR4
 - Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications*
 - Connector: LC
- CFP2-100G-SR10-D—Supports 100GBASE-SR10
 - Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications*

- Connector: 24-fiber MPO
- CFP2-100GBASE-LR4—Supports 100GBASE-LR4
 - Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications*
 - Connector: LC
- CFP2-100GBASE-SR10—Supports 100GBASE-SR10
 - Cable: See *100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications*
 - Connector: 24-fiber MPO

NOTE: The dual-rate transceiver (CFP2-100G-LR4-D) cannot be configured to use OTN framing when used in this PIC. The 100-Gigabit Ethernet OTN PIC with CFP2 (P2-100GE-OTN) supports OTN framing.

LEDs

The **STATUS** LED is located to the left of the **ONLINE/OFFLINE** button. One LED is located next to each port to indicate the link activity of the port. [Table 202 on page 1461](#) describes the functions of these LEDs.

Table 202: 100-Gigabit Ethernet PIC with CFP2 LEDs

Label	Color	State	Description
STATUS	Green	On steadily	PIC is online with no alarms or failures.
	Yellow	On steadily	PIC is initializing.
	Red	On steadily	PIC has an error or failure.
	–	Off	PIC is offline or not enabled and safe to remove from the router.
Single LED per port	Green	On steadily	Port is online with no alarms or errors, and the link is up.
		Blinking	There is link activity on the port.
	Red	On steadily	Port is on but the link is down, and the port has detected a failure.
	–	Off	Port is off or not enabled.

Alarms, Errors, and Events

- Laser bias current high/low alarms and warnings
- Laser Rx power high/low alarms and warnings
- Module not ready alarm
- Module low power alarm
- Module temperature high/low alarms and warnings
- Rx CDR loss of lock alarm
- Rx loss of signal alarm
- Module not ready alarm
- Tx CDR loss of lock alarm

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)


[PTX3000 PIC Description | 1436](#)

100-Gigabit Ethernet PIC with CFP (PTX Series)

IN THIS SECTION

- [Software Release | 1463](#)
- [Hardware Features | 1464](#)
- [Software Features | 1464](#)
- [Cables and Connectors | 1466](#)

- LEDs | 1467
- Alarms, Errors, and Events | 1468



Software Release

- PTX3000: Junos OS Release 13.2R2 and later
- PTX5000:

NOTE: PTX5000 does not support Junos OS Release 13.1.

- Junos OS Release 12.1X48 and later 12.1X48 releases
- Junos OS Release 12.3 and later 12.3 releases
- Junos OS Release 13.2 and later releases

NOTE: PTX5000 does not support Junos OS Releases 12.1, 12.2, or 13.1.

Hardware Features

- Two 100-Gigabit Ethernet CFP ports
- Model number P1-PTX-2-100GE-CFP
- Name in the CLI: **2x 100GE CFP**
- Power requirements: 1.6 A @ -48 V (75 W)
- Large maximum transmission units (MTUs):
 - Junos OS Release 12.1X48: up to 9192 bytes
 - Junos OS Release 12.1X48R2 and later 12.1X48 releases: up to 9500 bytes
 - Junos OS Release 12.3 and later 12.3 releases: up to 9500 bytes

Software Features

Table 203 on page 1464 shows the first supported release for each software feature.

Table 203: Software Features Supported

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
Flexible-ethernet-services encapsulation	13.2R2	12.1X48 12.3 13.2
Flexible VLAN tagging	13.2R2	12.1X48 12.3 13.2
IFINFO / IFMON	13.2R2	12.1X48 12.3 13.2

Table 203: Software Features Supported (continued)

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
IEEE 802.1 ag OAM	13.2R2	12.1X48 12.3 13.2
IEEE 802.3 ah OAM	13.2R2	12.1X48 12.3 13.2
IEEE 802.3ad link aggregation	13.2R2	12.1X48 12.3 13.2
Interrupt-driven link-down detection for MPLS FRR	13.2R2	12.1X48 12.3 13.2
MAC accounting per logical interface for source addresses	13.2R2	12.1X48 12.3 13.2
MAC filter per port for destination addresses and source addresses	13.2R2	12.1X48 12.3 13.2
MAC filter per logical interface for source addresses	13.2R2	12.1X48 12.3 13.2

Table 203: Software Features Supported (*continued*)

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
SNMP	13.2R2	12.1X48 12.3 13.2
Up to 8000 logical interfaces share across all ports on a single PFE	13.2R2	12.1X48 12.3 13.2

Cables and Connectors

- 100GBASE-ER4 (model number: CFP-100GBASE-ER4)
 - Duplex LC connector (RX and TX)
 - Junos OS Release 12.1X48R4 and later 12.1X48 releases
 - Junos OS Release 12.3 and later 12.3 releases
 - Junos OS Release 13.2 and later releases
- 100GBASE-ER4 (model number: CFP-GEN2-CGE-ER4 and part number: 740-049763)
 - Duplex LC connector (RX and TX)
 - Junos OS Release 12.3R5 and later 12.3 releases
 - Junos OS Release 13.2R3 and later 13.2 releases
 - Junos OS Release 13.3 and later releases

NOTE: The “GEN2” optics have been redesigned with newer versions of internal components for reduced power consumption.

- 100GBASE-LR4 (model number: CFP-100GBASE-LR4)
 - Duplex SC connector (RX and TX)
 - Junos OS Release 12.1X48 and later 12.1X48 releases

- Junos OS Release 12.3 and later 12.3 releases
- Junos OS Release 13.2 and later releases

100GBASE-LR4 (model number: CFP-GEN2-100GBASE-LR4 and part number: 740-047682)

- Duplex LC connector (RX and TX)
- Junos OS Release 12.3R5 and later 12.3 releases
- Junos OS Release 13.2R3 and later 13.2 releases
- Junos OS Release 13.3 and later releases

NOTE: The “GEN2” optics have been redesigned with newer versions of internal components for reduced power consumption.

- 100GBASE-SR10 (model number: CFP-100GBASE-SR10)
 - 24-fiber MPO connectors
 - Junos OS Release 12.1X48R3 and later 12.1X48 releases
 - Junos OS Release 12.3 and later 12.3 releases
 - Junos OS Release 13.2 and later releases
- 100GBASE-ZR (model number: CFP-100GBASE-ZR)
 - Duplex LC connector (RX and TX)
 - Supported in Junos OS Release 13.3R6, 14.1R4, 14.2R3, and 15.1R1 and later
 - Provides advanced dual polarization-quadrature phase shift keying (DP-QPSK) coherent digital signal processing (DSP) and forward error correction (FEC)-enabled robust tolerance to optical impairments and supports 80 km reach over single mode fiber
 - The transceiver is not specified as part of IEEE 802.3 but is built according to Juniper Networks specifications.
- Optical interface specifications—see [100-Gigabit Ethernet 100GBASE-R Optical Interface Specifications](#)

LEDs

The **STATUS** LED is located above the **ONLINE OFFLINE** button. The **LINK** and **ACT** LEDs are located next to each port. [Table 204 on page 1468](#) describes the functions of these LEDs.

Table 204: 100-Gigabit Ethernet PIC with CFP LEDs

Label	Color	State	Description
STATUS	Green	On steadily	PIC is online with no alarms or failures.
	Yellow	On steadily	PIC is initializing.
	Red	On steadily	PIC is online but has errors or alarms.
	–	Off	PIC is offline or not enabled.
LINK for each port:	Green	On steadily	Port is online with no alarms or failures, and the link is up.
	Red	On steadily	Port is on but the link is down, and the port has detected a failure with alarms.
	–	Off	Port is off or not enabled.
ACT for each port	Green	Flashing	Activity detected. Port is sending or receiving packets.
	–	Off	No packet activity detected on the port.

Alarms, Errors, and Events

- Alarm indication signal (AIS)
- Laser bias current high/low alarms and warnings
- Laser Rx power high/low alarms and warnings
- Module not ready alarm
- Module power down alarm
- Module temperature high/low alarms and warnings
- Rx CDR loss of lock alarm
- Rx loss of signal alarm
- Rx not ready alarm
- Tx CDR loss of lock alarm
- Tx data not ready alarm
- Tx laser fault alarm
- Tx not ready alarm

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)

[PTX3000 PIC Description | 1436](#)

100GbE PICs for PTX Series Routers

Juniper Networks 4-port 100GbE PICs enable service providers to deploy high-density 100G services in a wide variety of short-reach, long-reach, and DWDM scenarios. Using modular 100-gigabit pluggable transceiver (CFP2) optics, the 4-port 100GbE PICs are designed for second-generation PTX Series Packet Transport Routers line cards (FPC2) and provide line-rate performance in Ethernet and optical transport network (OTN) applications.

Juniper Networks® PTX Series Packet Transport Routers are architected for industry-leading system density in a transport-focused design that delivers the ability to scale, rapidly qualify and deploy, and reliably support the core—all at almost half the power of other core routers. The second generation of PTX Series hardware uses an optimized packaging of the successful Juniper Networks Junos® Express chip for robust, line-rate, and low-latency packet performance at up to 960 Gbps per slot. The 4-port 100GbE PIC family extends the existing PTX Series PIC portfolio by offering cost-optimized flexibility of dense 100GbE solutions to service providers. The mix and match of 4-port 100GbE PICs allows for up to 64 short-reach, long-reach, and tunable1 100GbE interfaces per chassis for ultra-high speed interconnect applications. A PTX Series router fully equipped with second-generation line cards can demonstrate efficiency as high as 1.2 W/Gbps.

Architecture and Key Components

The 4-port 100GbE PICs for PTX Series line cards leverage the proven Junos Express technology in octal-Packet Forwarding Engine (PFE) configuration (FPC2). This approach combines proven and qualified hardware with advanced packaging and the latest in modular optical technology.

The 4-port 100GbE CFP2 PIC supports Ethernet over shortreach, long-reach, and extended long-reach distances in 100GbE SR10, LR4, and ER4 formats.

The 4-port 100GbE Ethernet/OTN CFP2 PIC is designed for the highest flexibility in local, and metro applications with Ethernet and OTN framing.

The 4-port 100GbE CFP2 PIC provides the benefits of a pluggable optical module in popular short-reach and long-reach applications, where OTN framing is not required. This includes the following applications:

- Intra-POP connectivity
- 100GbE fanout to 10GbE-optimized edge routers

- Router to DWDM shelf connections

The 4-port 100GbE CFP2 Ethernet/OTN PIC is the most flexible 100GbE quad-port option, with connectivity to a broad range of long-haul equipment. The 4-port 100GbE CFP2 Ethernet/OTN PIC supports OTN performance monitoring, and full control over OTN features via the Juniper Networks Junos operating system.

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)

[PTX3000 PIC Description | 1436](#)

P2-10G-40G-QSFPP PIC Overview

IN THIS SECTION

- [Understanding Dual Configuration on P2-10G-40G-QSFPP PIC | 1471](#)
- [Port Numbering on P2-10G-40G-QSFPP PIC | 1472](#)
- [10-Gigabit Ethernet Mode | 1474](#)
- [40-Gigabit Ethernet Mode | 1474](#)

Starting with Junos OS Release 14.1R2 and 14.2R1, PTX5000 supports the P2-10G-40G-QSFPP PIC on the FPC2-PTX-P1A FPC.

All the ports on the P2-10G-40G-QSFPP PIC are plugged into quad small form-factor pluggable plus transceivers (QSFP+) that, in turn, are connected to fiber-optic cables that support both 10-Gigabit Ethernet standards and 40-Gigabit Ethernet standards, thereby enabling you to configure the PIC to operate either in 10-Gigabit Ethernet mode or in 40-Gigabit Ethernet mode.

Starting from Junos OS Release 15.1, you can perform the following on the P2-10G-40G-QSFPP PIC on PTX5000 routers:

- You can configure the interfaces on this PIC to be a part of the mixed rates and mixed mode aggregated Ethernet bundles.

- Port-based pseudowire class of service (CoS) classification which includes Layer 3 IPv4, IPv6, and MPLS classification for interfaces with ethernet-ccc encapsulation.

The following sections describe the P2-10G-40G-QSFPP PIC and the various framing modes that are supported on it:

Understanding Dual Configuration on P2-10G-40G-QSFPP PIC

All the ports on the P2-10G-40G-QSFPP PIC are QSFP+ based—that is, all the ports are connected to fiber-optic cables by means of QSFP+ transceivers.

The QSFP+ module—which includes the transceiver and the fiber-optic cable—supports the following standards on the P2-10G-40G-QSFPP PIC:

- 10-Gigabit Ethernet in LAN PHY framing mode (also known as native Ethernet mode) and WAN PHY framing mode.
- 40-Gigabit Ethernet in LAN PHY framing mode.

The P2-10G-40G-QSFPP PIC provides forty-eight 10-Gigabit Ethernet ports or twelve 40-Gigabit Ethernet ports. The PIC can be configured either in 10-Gigabit Ethernet mode or in 40-Gigabit Ethernet mode with the **set chassis fpc *fpc-number* pic *pic-number* pic-mode (10G | 40G)** configuration command. By default, the PIC is configured in 10-Gigabit Ethernet LAN PHY framing mode.

NOTE:

If you want configure the PIC in 10-Gigabit Ethernet mode to operate in 40-Gigabit Ethernet mode, you must:

1. Delete all the interfaces in the PIC at the **[edit interfaces]** hierarchy level.
2. Configure the PIC to operate in 40-Gigabit Ethernet mode by using the **set chassis fpc *fpc-slot* pic *pic-slot* pic-mode 40G** configuration command and commit.

The PIC reboots and starts operating in the new mode.

The same procedure is applicable when you can configure the PIC in 40-Gigabit Ethernet PIC to operate in 10-Gigabit Ethernet mode. In this case, you must execute the **set chassis fpc *fpc-slot* pic *pic-slot* pic-mode 10G** configuration mode command.

To check the current diagnostics of the PIC, you must run the relevant operational mode CLI commands such as **show chassis hardware**, **show interfaces**, **show interfaces diagnostics optics *interface-name***, and so on.

Port Numbering on P2-10G-40G-QSFPP PIC

Table 205 on page 1472 shows the port numbering in 40-Gigabit Ethernet mode and in 10-Gigabit Ethernet mode.

Table 205: Port Numbering Table

QSFP+ Port Number	Port Numbering in 40-Gigabit Ethernet Mode	Port Numbering in 10-Gigabit Ethernet Mode
0	et-1/1/0	et-1/1/0:0 et-1/1/0:1 et-1/1/0:2 et-1/1/0:3
1	et-1/1/1	et-1/1/1:0 et-1/1/1:1 et-1/1/1:2 et-1/1/1:3
2	et-1/1/2	et-1/1/2:0 et-1/1/2:1 et-1/1/2:2 et-1/1/2:3
3	et-1/1/3	et-1/1/3:0 et-1/1/3:1 et-1/1/3:2 et-1/1/3:3
4	et-1/1/4	et-1/1/4:0 et-1/1/4:1 et-1/1/4:2 et-1/1/4:3

Table 205: Port Numbering Table (*continued*)

QSFP+ Port Number	Port Numbering in 40-Gigabit Ethernet Mode	Port Numbering in 10-Gigabit Ethernet Mode
5	et-1/1/5	et-1/1/5:0 et-1/1/5:1 et-1/1/5:2 et-1/1/5:3
6	et-1/1/6	et-1/1/6:0 et-1/1/6:1 et-1/1/6:2 et-1/1/6:3
7	et-1/1/7	et-1/1/7:0 et-1/1/7:1 et-1/1/7:2 et-1/1/7:3
8	et-1/1/8	et-1/1/8:0 et-1/1/8:1 et-1/1/8:2 et-1/1/8:3
9	et-1/1/9	et-1/1/9:0 et-1/1/9:1 et-1/1/9:2 et-1/1/9:3
10	et-1/1/10	et-1/1/10:0 et-1/1/10:1 et-1/1/10:2 et-1/1/10:3

Table 205: Port Numbering Table (*continued*)

QSFP+ Port Number	Port Numbering in 40-Gigabit Ethernet Mode	Port Numbering in 10-Gigabit Ethernet Mode
11	et-1/1/11	et-1/1/11:0 et-1/1/11:1 et-1/1/11:2 et-1/1/11:3

10-Gigabit Ethernet Mode

A 10-Gigabit Ethernet interface can operate in 10-Gigabit Ethernet LAN PHY framing mode or 10-Gigabit Ethernet WAN PHY framing mode.

You can configure a 10-Gigabit Ethernet interface at the **[edit interface *interface-name* framing-mode (lan-phy | wan-phy)]** hierarchy level to operate in 10-Gigabit Ethernet LAN PHY framing mode or in 10-Gigabit Ethernet WAN PHY framing mode.

Each P2-10G-40G-QSFPP PIC provides 48 physical interfaces. The interfaces are represented by the *et-fpc/pic/QSFP+ port:channel* interface naming convention, where the value of the *QSFP+ port* option ranges from 0 through 11 and the value of the *channel* option ranges from 0 through 3.

When a P2-10G-40G-QSFPP PIC is configured in 10-Gigabit Ethernet framing mode, it can operate in one of the following framing modes:

- LAN PHY framing mode. Note that by default, the PIC is in 10-Gigabit Ethernet LAN PHY framing mode.

NOTE: The ports are set to LAN PHY framing mode by default when the **framing-mode** statement is not configured at the **[edit interface *interface-name*]** hierarchy level.

- WAN PHY framing mode

40-Gigabit Ethernet Mode

You can configure twelve 40-Gigabit Ethernet interfaces that operate in LAN PHY framing mode. The interfaces are represented by the *et-fpc/pic/QSFP+ port* interface naming convention, where the value of the *QSFP+ port* option ranges from 0 through 11.

Understanding the P2-100GE-OTN PIC

IN THIS SECTION

- [Interface Features | 1475](#)
- [Layer 2 and Layer 3 Features | 1477](#)
- [OTN Alarms and Defects | 1478](#)
- [TCA Alarms | 1479](#)

Starting with Junos OS Release 14.1R2 and 14.2, a 100-Gigabit Ethernet OTN PIC—P2-100GE-OTN—is supported on the FPC2-PTX-P1A FPC in PTX5000 routers. The P2-100GE-OTN PIC provides 4-port 100-Gigabit Ethernet interfaces, which are independently configurable in LAN PHY framing mode or in optical channel transport unit 4 (OTU4) mode. Each interface is terminated by means of a CFP2 transceiver. The FPC2-PTX-P1A FPC supports two P2-100GE-OTN PICs, in which each 100-Gigabit Ethernet port is mapped to a Packet Forwarding Engine in the FPC.

Starting from Junos OS Release 15.1, you can perform the following on the P2-100GE-OTN PIC on PTX5000 routers:

- You can configure the interfaces on this PIC to be a part of the mixed rates and mixed mode aggregated Ethernet bundles.
- Port-based pseudowire class of service (CoS) classification which includes Layer 3 IPv4, IPv6, and MPLS classification for interfaces with ethernet-ccc encapsulation.

The following sections explain this PIC in detail:

Interface Features

The following interface features are supported on a P2-100GE-OTN PIC:

- 4-port 100-Gigabit Ethernet interfaces, which are independently configurable in LAN PHY framing mode or in OTU4 signal mode. Each interface is terminated by means of a CFP2 transceiver.
- Each port maps to a single Packet Forwarding Engine in the FPC2-PTX-P1A FPC.
- The interfaces are named with prefix *et*.
- Gigabit Ethernet local loopback.
- Link-level pause frames—You can halt the Ethernet interface from transmitting packets for a configured period of time.

- Interface hold timer and interface damping—You can set the **hold-time** statement (in milliseconds) to damp interface transitions.
- External clock
- Nonstandard tag protocol identifier (TPID):
 - For each 100-Gigabit Ethernet port, you can configure up to eight TPIDs by using the **tag-protocol-id** statement at the **[edit interfaces interface-name together-options ethernet-switch-profile]** hierarchy level.
 - The **tag-protocol-id** statement can be configured only on the first port (port 0) of the PIC. If any other (nonzero) port has the **tag-protocol-id** configuration, the Routing Engine registers an error in the system log and the configuration is ignored.
 - The **tag-protocol-id** statement configured on port 0 of the PIC also applies to the rest of the ports on that PIC.
- The interface *Link Down* event always generates an interrupt; however, the interface *Link Up* event does not generate an interrupt. Therefore, the interface link-up event is detected during the 1-second PIC periodic polling process.
- Generic forward error correction (GFEC) (G.709) and no-FEC modes of operation.
- Diagnostics tools:
 - Line loopback
 - Local loopback
- Fast reroute (FRR)—Based on configurable pre-FEC, bit error rate (BER) is supported and is configured using the **ber-threshold-signal-degrade** statement at the **[edit interfaces interface-name otn-options signal-degrade]** hierarchy level.
- *jnx-ifotn.mib* and *otn-mib* as defined in RFC 3591. Note that according to Junos OS security standard, configurable parameters are not supported through SNMP. Only the *get* operation is available through SNMP.
- FEC statistics—corrected errors and corrected error ratio.
- OTN payload pseudorandom binary sequence (PRBS) generation and checking by enabling or disabling PRBS with the **prbs** or **no-prbs** statement at the **[edit interfaces interface-name otn-options]** hierarchy level.
- Optical channel data unit (ODU)-level delay measurement.
- At the physical interface level, **flexible-ethernet-service**, **ethernet-ccc**, and **ethernet-tcc** encapsulations are supported. For the **flexible-ethernet-service** encapsulation, the logical level supports **enet2**, **vlan-ccc**, and **vlan-tcc** encapsulations.

- At the logical interface level, **dix**, **vlan-ccc**, and **vlan-tcc** encapsulations are supported.
- Interoperability between 100-Gigabit Ethernet interfaces with CFP transceiver and 100-Gigabit Ethernet interfaces with CFP2 transceiver in LAN PHY framing mode and in OTU4 mode.

The following features are not supported on the P2-100GE-OTN PIC:

- Source MAC learning for accounting
- MAC policing
- Physical interface-level encapsulations—**vlan-ccc**, **extended-vlan-ccc**, and **extended-vlan-tcc**
- Logical interface-level encapsulation—**vlan-vpls**
- VLAN rewrite for **ccc** encapsulation
- Per-queue flow control
- Generic framing procedure-framed (GFP-F) mapping modes over OTN
- General communication channel (GCC)
- OTN interface-level Automatic Protection Switching (APS)
- Insertion, monitoring, and display of OTN header overhead byte
- Black link MIB for integration with transponders
- Optical harness support
- Transport interface and state model (GR-1093)
- Trace tone support
- 15-minute and 1-day performance monitoring counters and historic counters

Layer 2 and Layer 3 Features

The following Layer 2 and Layer 3 features are supported on the P2-100GE-OTN PIC:

- MAC detect link up and link down based on local fault signal or remote fault signal.
- MAC statistics.
- Flow control.
- MAC oversized packet counters based on default MTU value or user-configured MTU value.
- Per-port destination address MAC filter.
- Per-port source address MAC filter.
- Per-physical interface source address MAC filter.
- Per-logical interface source address MAC accounting.

- Maximum of 1000 source MAC filter per physical interface.
- Maximum of 32,000 filter terms to share across all filter features.
- Aggregated Ethernet supports 64 child links that can be configured using the **set chassis aggregated-devices maximum-links** configuration command.
- Maximum of 1024 logical interfaces on an aggregated Ethernet physical interface.
- Support for VLAN tagging, flexible VLAN tagging, and stacked VLAN tagging.
- LACP.
- Link protection.
- 802.3 ah OAM.
- 802.1 ag OAM.
- MPLS FRR.
- SNMP.
- Supports per-VLAN queuing (using Packet Forwarding Engine).

OTN Alarms and Defects

The following OTN alarms and defects are supported on the P2-100GE-OTN PIC:

- LOS—Loss Of Signal
- LOF—Loss Of Frame
- LOM—Loss Of Multiframe
- OTU—Degrade
- OTU—AIS
- OTU—IAE
- OTU—BDI
- OTU—TTIM
- OTU—Signal Degrade
- OTU—Signal Fail
- ODU—Signal Fail
- OTU-FEC—Degrade
- OTU-FEC—Excessive errors
- ODU—Signal Degrade
- ODU—AIS

- ODU—BDI
- ODU—OCI
- ODU—LCK
- ODU—TTIM
- OPU—PTM

TCA Alarms

Threshold-crossing alarms (TCA) are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so until the end of the 15 minute interval for parameters such as OTU and ODU. The following alarms are supported:

- Background block error threshold (BBE)
- Errored seconds threshold (ES)
- Severely errored seconds threshold (SES)
- Unavailable seconds threshold (UAS)

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

[PTX5000 PIC Description | 1434](#)


[PTX3000 PIC Description | 1436](#)

100-Gigabit DWDM OTN PIC with CFP2 (PTX Series)

IN THIS SECTION

- [Software Release | 1480](#)
- [Hardware Features | 1480](#)
- [Software Features | 1481](#)
- [Cables and Connectors | 1483](#)

- LEDs | 1483
- Alarms, Errors, and Events | 1484



Software Release

- PTX3000: Junos OS Release 15.1F6 and later
- PTX5000: Junos OS Release 15.1F6 and later

Hardware Features

- Model number: PTX-5-100G-WDM
- Name in the CLI: **5X100GE DWDM CFP2-ACO**
- Five 100-Gigabit DWDM OTN ports
- Power requirement (including transceiver)
- Weight: 5.2 lb (2.4 kg)

- Supports CFP2-ACO pluggable optics
- Transparent transport of a 100-Gigabit Ethernet signal with OTU4(V) framing
- ITU-standard OTN performance monitoring and alarm management
- Dual polarization-quadrature phase-shift keying (DP-QPSK) modulation
- Supports two types of forward error correction (FEC):
 - Soft-decision FEC (SDFEC)
 - G.709 FEC (GFEC)
- 100 channels on C-band ITU grid with 50-GHz spacing
- Latency:
 - SDFEC: 14 μ s (TX + RX)
 - GFEC: 6 μ s (TX + RX)
- Interoperable with the CFP-100GBASE-ZR transceiver supported on the 100-Gigabit Ethernet MIC with CFP (MIC3-3D-1X100GE-CFP) on MX Series routers and the 100-Gigabit Ethernet PIC with CFP (P1-PTX-2-100GE-CFP) on PTX Series routers.

NOTE: The 5-port 100-Gigabit DWDM OTN PIC is not directly interoperable with the 2-port 100-Gigabit DWDM OTN PIC, but they can both operate over the same DWDM line system.

NOTE: The 5-port 100-Gigabit DWDM OTN PIC is designed to comply with NEBS regulations on the PTX3000 and PTX5000 routers when these routers are used in typical configurations.

In a typical configuration, a PTX3000 router supports up to eight FPCs, with up to four 5-port 100-Gigabit DWDM OTN PICs installed next to any FPC. You can install other PICs next to any other FPC.

In a typical configuration, a PTX5000 router supports up to eight FPCs, with up to eight 5-port 100-Gigabit DWDM OTN PICs in any FPC slot. You can install other PICs in any FPC slot.

Software Features

Table 197 on page 1447 shows the first supported release for each software feature.

Table 206: Software Features Supported

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
Compliant with ITU G.709 and G.798	15.1F6	15.1F6
Provides a transport interface and state model (GR-1093)	15.1F6	15.1F6
Performance monitoring such as alarms, threshold-crossing alarms, OTU/ODU error seconds and pre-FEC statistics	15.1F6	15.1F6
SNMP management of the PIC based on RFC 3591, Managed Objects for the Optical Interface Type <ul style="list-style-type: none"> • Set functionality • Juniper Networks Black-Link MIB • IFOTN MIB • Optics MIB • FRU MIB 	15.1F6	15.1F6
IEEE 802.1ag OAM	15.1F6	15.1F6
IEEE 802.3ah OAM	15.1F6	15.1F6
IFINFO/IFMON	15.1F6	15.1F6
IEEE 802.3ad link aggregation	15.1F6	15.1F6
Pre-FEC BER monitoring provides interrupt-driven link-signal-degrade BER-based detection for MPLS fast reroute	15.1F6	15.1F6
User-configurable optics options: <ul style="list-style-type: none"> • TX laser enable/disable • TX output power • TX/RX wavelength • RX LOS warning/alarm thresholds • Threshold crossing alarms (TCAs) 	15.1F6	15.1F6

Table 206: Software Features Supported (*continued*)

Software Feature	PTX3000 First Supported Junos OS Release	PTX5000 First Supported Junos OS Release
User configurable card options: <ul style="list-style-type: none"> • FEC mode (SDFEC/GFEC) • Differential encoding mode • TCAs • Proactive protection (FRR) threshold / interval 	15.1F6	15.1F6

Cables and Connectors

Fiber-optic 100-gigabit CFP2-ACO transceiver

- Connector: Duplex LC
- Model number: TCFP2-100G-C

NOTE: When inserting the CFP2 transceiver, ensure that the transceiver sits tightly in the port. You will hear a distinct click sound when the latch locks into the corresponding port. The latch must be fully engaged in the corresponding port for the CFP2 transceiver to function properly. Failing to do so will result in loss of connection.

To verify that the CFP2 transceiver module is inserted properly, give a gentle pull by grasping the sides of the module. The module should sit tightly.

LEDs

The **STATUS** LED is located in the center of the PIC faceplate adjacent to the link and activity LED for port 2. The link and activity LEDs are located between the ports and are numbered 0 through 4.

[Table 207 on page 1484](#) describes the functions of these LEDs.

Table 207: 100-Gigabit DWDM OTN PIC with CFP2 LEDs

Label	Color	State	Description
STATUS	Green	On steadily	PIC is initialized and online with no alarms or failures.
	Red	On steadily	PIC is online but has errors or alarms.
	–	Off	PIC is offline or not enabled.
Link and activity LED for each port	Green	On steadily	Port is online with no alarms or failures, and the link is up.
		Blinking	Activity is detected on the link.
	Red	On steadily	Port has detected a media alarm or failure.
	–	Off	Port is off or not enabled.

Alarms, Errors, and Events

NOTE: For OTN alarms, see [Table 208 on page 1489](#)

Chassis and PIC:

- PIC (FRU) inserted or removed
- PIC (FRU) Administrative State: In Service, Out Of Service
- PIC (FRU) Operational State: Unequipped, Init, Normal, Mismatch, Fault, Upgrade
- Mismatch equipment
- Temperature alarm

Port (interface):

- Interface Administrative State: In Service, Out Of Service, Service MA, Out of Service MA
- Interface Operational State: Init, Normal, Fault, Degraded

Optical channel transport unit (OTU) threshold-crossing alarms (TCAs):

- OTU-TCA-BBE—15 minute background block error TCA
- OTU-TCA-ES—15 minute far-end errored seconds TCA

- OTU-TCA-SES—15 minute severely errored seconds TCA
- OTU-TCA-UAS—15 minute unavailable seconds TCA

Optical channel data unit (ODU) TCAs:

- ODU-TCA-BBE—15 minute background block error TCA
- ODU-TCA-ES—15 minute far-end errored seconds TCA
- ODU-TCA-SES—15 minute severely errored seconds TCA
- ODU-TCA-UAS—15 minute unavailable seconds TCA

TIP: You can view OTU and ODU TCAs using the **show interfaces transport pm otn** operational-mode CLI command.

Optics-related status:

- TX output power
- TX current output power
- TX average output power over a performance monitoring interval
- TX minimum output power over a performance monitoring interval
- TX maximum output power over a performance monitoring interval
- RX current input power
- RX average input power over a performance monitoring interval
- RX minimum input power over a performance monitoring interval
- RX maximum input power over a performance monitoring interval
- Transceiver temperature high alarm
- Transceiver temperature high warning
- Transceiver temperature low alarm
- Transceiver temperature low warning
- Transceiver voltage high alarm
- Transceiver voltage high warning
- Transceiver voltage low alarm
- Transceiver voltage low warning
- Transceiver temperature monitor A/D value
- Transceiver power supply monitor A/D value (voltage)

- TX laser current bias high alarm
- TX laser current bias high warning
- TX laser current bias low alarm
- TX laser current bias low warning
- TX laser temperature high alarm
- TX laser temperature high warning
- TX laser temperature low alarm
- TX laser temperature low warning
- TX output optical power high alarm
- TX output optical power high warning
- TX output optical power low alarm
- TX output optical power low warning
- TX laser TEC fault
- TX laser wavelength unlocked fault
- TX modulator bias high alarm
- TX modulator bias high warning
- TX modulator bias low alarm
- TX modulator bias low warning
- TX LOS fault
- TX current laser output power
- TX minimum laser output power over a performance monitoring interval
- TX average laser output power over a performance monitoring interval
- TX maximum laser output power over a performance monitoring interval
- RX laser bias current high alarm
- RX laser bias current high warning
- RX laser bias current low alarm
- RX laser bias current low warning
- RX input optical power high alarm
- RX input optical power high warning
- RX input optical power low alarm
- RX input optical power low warning

- RX laser output high alarm
- RX laser output high warning
- RX laser output low alarm
- RX laser output low warning
- RX current laser output power
- RX minimum laser output power over a performance monitoring interval
- RX average laser output power over a performance monitoring interval
- RX maximum laser output power over a performance monitoring interval
- RX laser temperature high alarm
- RX laser temperature high warning
- RX laser temperature low alarm
- RX laser temperature low warning
- RX LOS fault
- RX LOS occurred over a performance monitoring interval
- RX laser wavelength unlocked fault
- RX laser TEC fault

Network lane receive-related status:

- RX current chromatic dispersion
- RX average chromatic dispersion over a performance monitoring interval
- RX minimum chromatic dispersion over a performance monitoring interval
- RX maximum chromatic dispersion over a performance monitoring interval
- RX current differential group delay
- RX average differential group delay over a performance monitoring interval
- RX minimum differential group delay over a performance monitoring interval
- RX maximum differential group delay over a performance monitoring interval
- RX current Q value
- RX average Q value over a performance monitoring interval
- RX minimum Q value over a performance monitoring interval
- RX maximum Q value over a performance monitoring interval
- RX current signal-to-noise ratio (SNR)

- RX average SNR
- RX minimum SNR
- RX maximum SNR
- RX current carrier frequency offset
- RX average carrier frequency offset over a performance monitoring interval
- RX minimum carrier frequency offset over a performance monitoring interval
- RX maximum carrier frequency offset over a performance monitoring interval
- RX modem sync detect fault occurred over a performance monitoring interval
- RX modem lock fault occurred over a performance monitoring interval
- RX loss of alignment occurred over a performance monitoring interval
- RX out of alignment occurred over a performance monitoring interval
- RX deskew lock fault occurred over a performance monitoring interval

FEC statistics:

- Corrected Errors
- Uncorrected Words
- Corrected Error Ratio

TIP: You can view FEC statistics using the **show interfaces *interface-name* extensive** operational-mode CLI command.

[Table 208 on page 1489](#) describes the OTN alarms and defects that can occur on the PIC and the link status when the alarm or defect occurs.

TIP: You can view OTN alarms and defects using the **show interfaces *interface-name* extensive** operational-mode CLI command.

Table 208: OTN Alarms and Defects

Category	Alarm	Description	Link Status
OTN	LOS	Loss of signal	Link down
	LOF	Loss of frame	Link down
	LOM	Loss of multiframe	Link down
	Wavelength Lock	Wavelength lock	Warning
OTN FEC	FEC Degrade (OTU-FEC-DEG)	Forward error correction degraded	Link down if FRR is enabled
	FEC Excessive (OTU-FEC-EXE)	Excessive errors, FEC_FAIL from the transponder	Possible link down
OTN OTU	OTU-AIS	Alarm indication signal or all ones signal	Link down
	OTU-BDI	Backward defect identification	Link down
	OTU-IAE	Incoming alignment error	Warning
	OTU-TTIM	Destination access point identifier (DAPI), source access point identifier (SAPI), or both mismatch from expected to received	Can cause link down if otu-ttim-act-enable is configured at the edit interfaces interface-name otn-options hierarchy
	OTU-BIAE	Backward incoming alignment error	Warning
	OTU-TSF	OTU trail signal fail	Warning
	OTU-SSF	OTU server signal fail	Warning

Table 208: OTN Alarms and Defects (*continued*)


Category	Alarm	Description	Link Status
OTN ODU	ODU-AIS	Alarm indication signal or all ones signal	Link down
	ODU-OCI	Open connection error	Link down
	ODU-LCK	ODU lock triggers for path monitoring and TCM levels 1 through 6	Link down
	ODU-BDI	Backward defect indication	Link down
	ODU-TTIM	DAPI or SAPI mismatch from expected to received	Can cause link down if odu-ttim-act-enable is configured at the [edit interfaces interface-name otn-options] hierarchy
	ODU-IAE	Incoming alignment error	Warning
	ODU-LTC	Loss of tandem connection	Warning
	ODU-CSF	Client signal failure	Warning
	ODU-TSF	Trail signal fail	Warning
	ODU-SSF	Server signal fail	Warning
	ODU-PTIM	Payload type mismatch	Link down

RELATED DOCUMENTATION

[100-Gigabit DWDM OTN MIC with CFP2 | 1491](#)
[Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength | 1501](#)

100-Gigabit DWDM OTN MIC with CFP2

MIC3-100G-DWDM



Software release	<ul style="list-style-type: none"> • Junos 15.1F5 and later
Description	<ul style="list-style-type: none"> • One 100-Gigabit DWDM OTN port • Power requirements (including transceiver) at different temperatures: <ul style="list-style-type: none"> • 55° C: 1.90 A @ 48 V (91 W) • 25° C: 1.73 A @ 48 V (83 W) • Weight: 2.3 lb (1.04 kg) • Model number: MIC3-100G-DWDM • Name in the CLI: 1X100GE DWDM CFP2-ACO
Hardware features	<ul style="list-style-type: none"> • Dual-wide MIC that installs into two MIC slots • Supports CFP2 analog coherent optics (CFP2-ACO) • Transparent transport of a 100-Gigabit Ethernet signal with OTU4V framing • ITU-standard OTN performance monitoring and alarm management • Dual-polarization quadrature phase shift keying (DP-QPSK) modulation • Supports three types of forward error correction (FEC): <ul style="list-style-type: none"> • Soft-decision FEC (SD-FEC) • High-gain FEC (HG-FEC) • G.709 FEC (GFEC) • 100 channels on C-band ITU grid with 50-GHz spacing • Latency: <ul style="list-style-type: none"> • SD-FEC: 14 μs (TX + RX) • HG-FEC: 22 μs (TX + RX) • GFEC: 6 μs (TX + RX) • Interoperable with the CFP-100GBASE-ZR transceiver supported on the 100-Gigabit Ethernet MIC with CFP (MIC3-3D-1X100GE-CFP) on MX Series routers and the 100-Gigabit Ethernet PIC with CFP (P1-PTX-2-100GE-CFP) on PTX Series routers. <p>NOTE: The 1-port 100-Gigabit DWDM OTN MIC is not directly interoperable with the 2-port 100-Gigabit DWDM OTN PIC (P1-PTX-2-100G-WDM), but they can both operate over the same DWDM line system.</p>

Software features	<ul style="list-style-type: none"> • Compliant with ITU G.709 and G.798 • Provides a transport interface and state model (GR-1093) • Performance monitoring features such as alarms, threshold-crossing alarms, OTU/ODU error seconds and FEC and bit error rate (BER) statistics • SNMP management of the MIC based on <i>RFC 3591, Managed Objects for the Optical Interface Type</i>, including the following: <ul style="list-style-type: none"> • Set functionality • Black Link MIB • IFOTN MIB • Optics MIB • FRU MIB • Pre-FEC BER monitoring provides interrupt-driven, BER-based detection of link signal degradation for MPLS fast reroute. • User-configurable optics options: <ul style="list-style-type: none"> • Transmit (TX) laser enable and disable • TX output power • Wavelength • Receive (RX) LOS warning or alarm thresholds • Threshold crossing alarms (TCAs) <p>User-configurable card options:</p> <ul style="list-style-type: none"> • FEC mode (SD-FEC, HG-FEC, or GFEC) • TCAs
Cables and connectors	<p>Fiber-optic 100-gigabit CFP2-ACO transceiver</p> <ul style="list-style-type: none"> • Connector: Duplex LC/UPC • Model number: TCFP2-100G-C <p>NOTE: When inserting the C form-factor pluggable 2 (CFP2) transceiver, ensure that the transceiver sits tightly in the port. You hear a distinct click sound when the latch locks into the corresponding port. The latch must be fully engaged in the corresponding port for the CFP2 transceiver to function properly. Failing to do so can result in loss of connection.</p> <p>To verify that the CFP2 transceiver module is inserted properly, give a gentle pull by grasping the sides of the module. The module should sit tightly.</p>

LEDs	<p>OK/FAIL LED, one bicolor:</p> <ul style="list-style-type: none"> • Off—MIC is powered off. • Green—MIC is initialized and online, functioning normally. • Amber—MIC is coming online, or is in fault state. <p>LINK LED, one bicolor per port:</p> <ul style="list-style-type: none"> • Off—Port is offline. • Solid green—Link is up. • Red—Port failure is detected. <p>NOTE: The port is labeled Port 0.</p>
Alarms, Errors, and Events	<p>NOTE: For OTN alarms, see Table 209 on page 1498.</p> <p>Chassis and MIC:</p> <ul style="list-style-type: none"> • MIC (FRU) inserted or removed • MIC (FRU) Administrative State: In Service, Out Of Service • MIC (FRU) Operational State: Unequipped, Init, Normal, Mismatch, Fault, Upgrade • Mismatch equipment • Temperature alarm
	<p>Port (interface):</p> <ul style="list-style-type: none"> • Interface Administrative State: In Service, Out Of Service, Service MA, Out of Service MA • Interface Operational State: Init, Normal, Fault, Degraded
	<p>Optical channel transport unit (OTU) TCAs:</p> <ul style="list-style-type: none"> • OTU-TCA-BBE—15-minute background block error TCA • OTU-TCA-ES—15-minute far-end errored seconds TCA • OTU-TCA-SES—15-minute severely errored seconds TCA • OTU-TCA-UAS—15-minute unavailable seconds TCA <p>Optical channel data unit (ODU) TCAs:</p> <ul style="list-style-type: none"> • ODU-TCA-BBE—15-minute background block error TCA • ODU-TCA-ES—15-minute far-end errored seconds TCA • ODU-TCA-SES—15-minute severely errored seconds TCA • ODU-TCA-UAS—15-minute unavailable seconds TCA <p>TIP: You can view OTU and ODU TCAs by using the show interfaces transport pm otn operational-mode CLI command.</p>

|

NOTE: If you insert an invalid CFP module, the CLI displays **unsupported module** and a syslog message is generated.

Optics-related status:

- Module temperature
- Module voltage
- Module temperature alarm:
 - High alarm
 - Low alarm
 - High warning
 - Low warning
- Module voltage alarm:
 - High alarm
 - Low alarm
 - High warning
 - Low warning
- Module not ready alarm
- Module low power alarm
- Module initialization incomplete alarm
- Module fault alarm
- TX laser disabled alarm
- RX loss of signal alarm
- Modem lock state
- TX output power:
 - Current TX output power
 - Minimum over a performance monitoring interval
 - Maximum over a performance monitoring interval
 - Average over a performance monitoring interval
- TX power alarm:
 - High alarm
 - Low alarm
 - High warning
 - Low warning
- RX input power (signal)
- RX input power (total):
 - Current RX input power (total)
 - Minimum over a performance monitoring interval

- Maximum over a performance monitoring interval
- Average over a performance monitoring interval
- RX power alarm:
 - High alarm
 - Low alarm
 - High warning
 - Low warning
- RX loss of signal alarm
- Wavelength unlocked alarm

TIP: You can view optics-related status by using the **show interfaces transport pm optics** and **show interfaces diagnostics optics** operational-mode CLI commands.

Network lane receive-related status:

- Chromatic dispersion:
 - Current chromatic dispersion
 - Minimum over a performance monitoring interval
 - Maximum over a performance monitoring interval
 - Average over a performance monitoring interval
- Differential group delay:
 - Current differential group delay
 - Minimum over a performance monitoring interval
 - Maximum over a performance monitoring interval
 - Average over a performance monitoring interval
- Q^2 -factor:
 - Current Q^2 -factor
 - Minimum over a performance monitoring interval
 - Maximum over a performance monitoring interval
 - Average over a performance monitoring interval
- Carrier frequency offset
 - Current carrier frequency offset
 - Minimum over a performance monitoring interval
 - Maximum over a performance monitoring interval
 - Average over a performance monitoring interval
- Signal-to-noise ratio (SNR)
 - Current SNR
 - Minimum over a performance monitoring interval
 - Maximum over a performance monitoring interval
 - Average over a performance monitoring interval

TIP: You can view network lane receive-related status by using the **show interfaces transport pm optics** operational-mode CLI command.

FEC statistics:

- Corrected Errors—the number of bits received that were in error, but corrected.
- Uncorrected Words—the number of FEC codewords received that were uncorrectable.
- Corrected Error Ratio—the number of corrected bits divided by the number of bits received

TIP: You can view FEC statistics by using the **show interfaces interface-name extensive** operational-mode CLI command.

Table 209 on page 1498 describes the OTN alarms and defects that can occur on the MIC and the link status when the alarm or defect occurs.

TIP: You can view OTN alarms and defects by using the **show interfaces *interface-name* extensive** operational-mode CLI command.

Table 209: OTN Alarms and Defects

Category	Alarm	Description	Link Status
OTN	LOS	Loss of signal	Link down
	LOF	Loss of frame	Link down
	LOM	Loss of multiframe	Link down
OTN FEC	FEC Degrade (OTU-FEC-DEG)	Forward error correction degraded	Link down if FRR is enabled
	FEC Excessive (OTU-FEC-EXE)	There are uncorrected words and there are errors in the frame header	Possible link down
OTN OTU	OTU-AIS	Alarm indication signal or all ones signal	Link down
	OTU-BDI	Backward defect identification	Link down
	OTU-IAE	Incoming alignment error	Warning
	OTU-TTIM	Destination access point identifier (DAPI), source access point identifier (SAPI), or both mismatch from expected to received	Can cause the link to be down if otu-ttim-act-enable is configured at the [edit interfaces <i>interface-name</i> otn-options] hierarchy level
	OTU-BIAE	Backward incoming alignment error	Warning
	OTU-TSF	OTU trail signal fail	Warning
	OTU-SSF	OTU server signal fail	Warning

Table 209: OTN Alarms and Defects (*continued*)

Category	Alarm	Description	Link Status
OTN ODU	ODU-AIS	Alarm indication signal or all ones signal	Link down
	ODU-OCI	Open connection error	Link down
	ODU-LCK	ODU lock triggers for path monitoring and TCM levels 1 through 6	Link down
	ODU-BDI	Backward defect indication	Link down
	ODU-TTIM	DAPI or SAP1 mismatch from expected to received	Can cause the link to be down if odu-ttim-act-enable is configured at the [edit interfaces interface-name otn-options] hierarchy level
	ODU-IAE	Incoming alignment error	Warning
	ODU-LTC	Loss of tandem connection	Warning
	ODU-CSF	Client signal failure	Warning
	ODU-TSF	Trail signal fail	Warning
	ODU-SSF	Server signal fail	Warning
	ODU-PTIM	Payload type mismatch	Link down

RELATED DOCUMENTATION

[Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength | 1501](#)

100-Gigabit Ethernet OTN Options Configuration Overview

PTX Series routers support optical transport network (OTN) interfaces, including the 100-Gigabit Ethernet DWDM OTN PIC, and support:

- Transparent transport of two 100-Gigabit Ethernet signals with Optical Channel Transport Unit 4 (OTU4) framing
- International Telecommunications Union (ITU)-standard OTN performance monitoring and alarm management
- Dual polarization quadrature phase shift keying (DP-QPSK) modulation and soft-decision forward error correction (SD-FEC) for long haul and metro applications
- Pre-forward error correction (pre-FEC)-based bit error rate (BER). Fast reroute (FRR) uses the pre-FEC BER as an indication of the condition of an OTN link

Use the **set optics-options** statement at the **[edit interfaces *interfaceType-fpc/pic/port*]** hierarchy level to configure the optics options.

You can optionally configure pre-FEC BER monitoring as a condition for MPLS FRR. Pre-FEC BER FRR uses pre-FEC BER as an indication of the condition of an optical transport network (OTN) link. When the pre-FEC BER degrade threshold is reached, the PIC stops forwarding packets to the remote interface and raises an interface alarm. Ingress packets continue to be processed. When Pre-FEC BER FRR is used with MPLS FRR or another link protection method, traffic is then rerouted to a different interface. The BER threshold and duration for calculating the BER can be configured by the user. Use the **set signal-degrade** statement at the **[edit interfaces *interfaceType-fpc/pic/port* otn-options]** hierarchy level to configure the BER threshold. Use the **set signal-degrade-monitor-enable** statement at the **[edit interfaces *interfaceType-fpc/pic/port* otn-options preemptive-fast-reroute]** hierarchy level to enable signal degrade monitoring.

You can optionally enable backward FRR to inject local pre-FEC status into the transmitted OTN frames, notifying the remote interface. The remote interface then reroutes traffic to a different interface. When you use pre-FEC BER FRR and backward FRR, notification of signal degradation and rerouting of traffic can occur in less time than through a Layer 3 protocol. Use the **set backward-frr-enable** statement at the **[edit interfaces *interfaceType-fpc/pic/port* otn-options preemptive-fast-reroute]** hierarchy level.

NOTE: The backward FRR feature works only between two Juniper Networks 100-Gbps DWDM OTN PICs.

MX2020, MX2010, MX960, MX480, and MX240 routers support OTN interfaces on MPC5E and MPC6E. MPC5E-100G10G and MPC5EQ-100G10G support 100-Gigabit Ethernet OTN interfaces and 10-Gigabit Ethernet OTN interfaces on MX240, MX480, and MX960 routers. The OTN MIC MIC6-100G-CFP2 on MPC6E supports OTN on 100-Gigabit Ethernet interfaces on MX2020 and MX2010 routers. OTN support on the specified MX Series routers includes:

- International Telecommunications Union (ITU)-standard OTN performance monitoring and alarm management

- Transparent transport of two 100-Gigabit Ethernet signals with optical channel transport unit 4 (OTU4) framing.
- Generic forward error correction (Generic FEC)

To configure the OTN options for PTX Series routers and specific MX Series routers, use the **set otn-options** statement at the **[edit interfaces *interfaceType-fpc/pic/port*]** hierarchy level.

RELATED DOCUMENTATION

[Ethernet DWDM Interface Wavelength Overview | 1429](#)

[Attenuation and Dispersion in a Fiber-Optic Cable on PTX Series Routers Overview | 1429](#)

[Understanding Pre-FEC BER Monitoring and BER Thresholds | 1430](#)

[DWDM Controllers Overview | 1434](#)

Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength

To configure the wavelength on 10-Gigabit Ethernet or 100-Gigabit Ethernet dense wavelength-division multiplexing (DWDM) and OTN interfaces, include the **wavelength** statement at the **[edit interfaces *interface-name* optics-options]** hierarchy level:

```
[edit interfaces interface-name optics-options]
```

To display the currently tuned wavelength and frequency for the interface, use the **show interfaces *interface-name*** operational mode command.

For interface diagnostics, issue the **show interfaces diagnostics optics *interface-name*** operational mode command.

[Table 210 on page 1501](#) shows configurable wavelengths and the corresponding frequency for each configurable wavelength.

Table 210: Wavelength-to-Frequency Conversion Matrix

Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)
1528.38	196.15	1542.14	194.40	1556.15	192.65
1528.77	196.10	1542.54	194.35	1556.55	192.60

Table 210: Wavelength-to-Frequency Conversion Matrix (continued)

Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)
1529.16	196.05	1542.94	194.30	1556.96	192.55
1529.55	196.00	1543.33	194.25	1557.36	192.50
1529.94	195.95	1543.73	194.20	1557.77	192.45
1530.33	195.90	1544.13	194.15	1558.17	192.40
1530.72	195.85	1544.53	194.10	1558.58	192.35
1531.12	195.80	1544.92	194.05	1558.98	192.30
1531.51	195.75	1545.32	194.00	1559.39	192.25
1531.90	195.70	1545.72	193.95	1559.79	192.20
1532.29	195.65	1546.12	193.90	1560.20	192.15
1532.68	195.60	1546.52	193.85	1560.61	192.10
1533.07	195.55	1546.92	193.80	1561.01	192.05
1533.47	195.50	1547.32	193.75	1561.42	192.00
1533.86	195.45	1547.72	193.70	1561.83	191.95
1534.25	195.40	1548.11	193.65	1562.23	191.90
1534.64	195.35	1548.51	193.60	1562.64	191.85
1535.04	195.30	1548.91	193.55	1563.05	191.80
1535.43	195.25	1549.32	193.50	1563.45	191.75
1535.82	195.20	1549.72	193.45	1563.86	191.70
1536.22	195.15	1550.12	193.40	1564.27	191.65
1536.61	195.10	1550.52	193.35	1564.68	191.60

Table 210: Wavelength-to-Frequency Conversion Matrix (continued)

Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)
1537.00	195.05	1550.92	193.30	1565.09	191.55
1537.40	195.00	1551.32	193.25	1565.50	191.50
1537.79	194.95	1551.72	193.20	1565.90	191.45
1538.19	194.90	1552.12	193.15	1566.31	191.40
1538.58	194.85	1552.52	193.10	1566.72	191.35
1538.98	194.80	1552.93	193.05	1567.13	191.30
1539.37	194.75	1553.33	193.00	1567.54	191.25
1539.77	194.70	1553.73	192.95	1567.95	191.20
1540.16	194.65	1554.13	192.90	1568.36	191.15
1540.56	194.60	1554.54	192.85	1568.77	191.10
1540.95	194.55	1554.94	192.80		
1541.35	194.50	1555.34	192.75		
1541.75	194.45	1555.75	192.70		

RELATED DOCUMENTATION

[100-Gigabit Ethernet OTN Options Configuration Overview | 1499](#)

Overview of Optical ILAs and IPLCs

IN THIS CHAPTER

- [Optical ILA Hardware Component Overview | 1504](#)
- [Optical ILA Cooling System Description | 1505](#)
- [Optical ILA AC Power Supply Description | 1507](#)
- [Optical ILA DC Power Supply Description | 1508](#)
- [Optical ILA Chassis Status LEDs | 1509](#)
- [Optical ILA Component Redundancy | 1512](#)
- [Optical ILA Field-Replaceable Units | 1512](#)
- [Optical ILA Management Panel | 1514](#)
- [Optical ILA Management Port LEDs | 1515](#)
- [Optical Inline Amplifier Description | 1516](#)
- [Optical ILA Power Supply LEDs | 1518](#)
- [PTX3000 IPLC Description | 1521](#)
- [IPLC Architecture and Functional Components Overview | 1529](#)
- [Understanding IPLC Base and Expansion Modules | 1532](#)
- [Understanding the IPLC Configuration | 1535](#)
- [PTX3000 IPLC LED | 1541](#)
- [Communication of SNMP Traps Between Optical ILA and NMS Systems | 1542](#)
- [Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS | 1543](#)
- [Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI | 1543](#)
- [IPLC Specifications | 1545](#)
- [Understanding the Performance Monitors and TCAs for IPLCs | 1546](#)

Optical ILA Hardware Component Overview

[Table 211 on page 1505](#) describes the hardware components for the optical ILA.

Table 211: Optical ILA Hardware Components

Component	Spare Model Number
Chassis	PTX-ILA-M-AC
	PTX-ILA-M-DC
Fan module	FAN-ILA-S
Power supplies	JPSU-150-AC-AFO
	JPSU-150-DC-AFO

RELATED DOCUMENTATION

[Optical ILA Cooling System Description | 1505](#)

[Optical ILA AC Power Supply Description | 1507](#)

[Optical ILA DC Power Supply Description | 1508](#)

[Optical ILA Chassis Status LEDs | 1509](#)

Optical ILA Cooling System Description

IN THIS SECTION

- [Fan Modules | 1506](#)

The cooling system in an optical ILA consists of three 12.4 W fan modules installed in the field-replaceable unit (FRU) panel and two counter-rotating fans housed in each of the power supplies.

The cooling system brings air into the vents in the front panel and exhausts warmed air through the fans. This type of airflow is known as *airflow out* or *front-to-back* airflow. When installed, the chassis must be positioned so that the FRUs are next to the hot air exhaust.

NOTE: Under normal operating conditions, the fan modules operate at a moderate speed. Temperature sensors in the chassis monitor the temperature within the chassis. The system raises an alarm if a fan module fails or if the ambient temperature inside the chassis rises above the acceptable range.

Fan Modules

The fan modules in an optical ILA are hot-removable and hot-insertable FRUs. These fan modules can be hot-swapped—you do not need to power off the optical ILA or disrupt the optical ILA function to replace a fan module. The fan module slots are numbered **0** through **2** from left to right when viewing chassis from the FRU panel side (see [Figure 32 on page 1506](#)). [Figure 33 on page 1506](#) shows the fan module for the optical ILA. The numbers are located on the top-side of the chassis.

Figure 32: Fan Numbering





Figure 33: Fan Module



NOTE: All three fan modules must be installed for optimal operation of the optical ILA. The optical ILA continues to operate for a period of time 30 seconds during the replacement of the fan module without thermal shutdown.

RELATED DOCUMENTATION

Optical ILA Hardware Component Overview 1504
Optical ILA AC Power Supply Description 1507
Optical ILA DC Power Supply Description 1508
Optical ILA Chassis Status LEDs 1509

Optical ILA AC Power Supply Description

The AC power supplies in the optical ILA (see [Figure 35 on page 1507](#)) are hot-removable and hot-insertable field-replaceable units (FRUs) that you can install without powering off the optical ILA or disrupting the optical ILA function. The optical ILA has two AC power supplies. Both the power supplies are initially installed at the factory. See [Figure 34 on page 1507](#) for the power numbering scheme, the power supply number is located on the top-side of the chassis.

Figure 34: Power Supply Numbering





Figure 35: AC Power Supply in an Optical ILA



1—Power cord retainer	3—Plug power connector
2—Handle	4—Ejector lever

Each of the 150-W power supplies has a single AC input. The power supply provides 12-VDC output with a standby voltage of 12 VDC. An optical ILA has twice the number of power supplies needed to power all the components in the device, which is known as *1+1 redundancy*. When the optical ILA has both power supplies installed and connected to power, the device has full power redundancy. If a power supply fails or is removed, another power supply balances the electrical load without interruption.

The fans in the power supply provide front-to-back airflow, which is also known as *airflow out (AFO)*.



CAUTION: To avoid electrical injury, carefully follow instructions in *Connecting AC Power to an Optical ILA*, *Installing a Power Supply in an Optical ILA*, and *Removing a Power Supply from an Optical ILA*.

RELATED DOCUMENTATION

[Optical ILA Hardware Component Overview | 1504](#)

[Optical ILA Cooling System Description | 1505](#)


[Optical ILA DC Power Supply Description | 1508](#)

[Optical ILA Chassis Status LEDs | 1509](#)

Optical ILA DC Power Supply Description

The DC power supplies in the optical ILA (see [Figure 36 on page 1508](#)) are hot-removable and hot-insertable field-replaceable units (FRUs) that you can install without powering off the optical ILA or disrupting the ILA function. The DC version of the optical ILA has two DC power supplies. Both the power supplies are initially installed at the factory.

Figure 36: DC Power Supply in an Optical ILA



1—Handle

3—Ejector lever

2—DC terminal

Each of the two 150-W power supplies has a single DC input. The power supply provides 12 VDC output with a standby voltage of 12 VDC. An optical ILA has twice the number of power supplies needed to power all the components in the device, which is known as *1+1 redundancy*. When the optical ILA has both power

supplies installed and connected to power, the device has full power redundancy. If a power supply fails or is removed, the other or second power supply balances the electrical load without interruption.

The fans in the power supply provide port-to-FRU airflow, which is also known as *airflow out (AFO)*.



CAUTION: To avoid electrical injury, carefully follow instructions in *Connecting DC Power to an Optical ILA*, *Installing a Power Supply in an Optical ILA*, and *Removing a Power Supply from an Optical ILA*.

NOTE: We recommend that the 48-VDC facility DC source be equipped with a circuit breaker rated at 10 A (–48 VDC) minimum, or as required by local code.

RELATED DOCUMENTATION

[Optical ILA Hardware Component Overview | 1504](#)

[Optical ILA Cooling System Description | 1505](#)


[Optical ILA AC Power Supply Description | 1507](#)

[Optical ILA Chassis Status LEDs | 1509](#)

Optical ILA Chassis Status LEDs

The optical ILA has five status LEDs on the front panel of the chassis (see [Figure 37 on page 1510](#))—two Optical Supervisory Channel status LEDs (OSC A and OSC B), a system status LED (SYS), an alarm LED (ALM), and a power LED (PWR). The OSC is a separate channel that carries overhead information for network management purposes. The OSC, which is an important section in every DWDM system, carries voice and data between sites for monitoring and controlling specifications in the system.

Figure 37: Chassis Status LEDs on an Optical ILA



1—OSC B (OSC B) LED	4—Alarm (ALM) LED
2—OSC A (OSC A) LED	5—Power (PWR) LED
3—System status (SYS) LED	

Table 212 on page 1510 describes the chassis status LEDs on an optical ILA.

Table 212: Optical ILA Chassis Status LEDs

Name	Color	State	Description
OSC A status (OSC A) LED	Unlit	Off	The power is off.
	Red	On steadily	No OSC signal is received from the downstream device.
	Amber	On steadily	OSC signal received from the upstream device indicates a fault.
	Green	On steadily	OSC signal is communicating normally.
OSC B status (OSC B) LED	Unlit	Off	The power is off.
	Red	On steadily	No OSC signal is received from the downstream device.
	Amber	On steadily	OSC signal received from the upstream device indicates a fault.
	Green	On steadily	OSC signal is communicating normally.

Table 212: Optical ILA Chassis Status LEDs (*continued*)

Name	Color	State	Description
System status (SYS) LED	Unlit	Off	The power is off, or the optical ILA is not connected to any power source.
	Green	On steadily	The optical ILA software has booted.
	Green	Blinking	The optical ILA is active and is communicating with upstream and downstream network elements.
Alarm (ALM) LED	Unlit	Off	The optical ILA is off, or there is no alarm.
	Red	On steadily	A major hardware fault has occurred, such as a temperature alarm or a power or pump failure, and the unit has halted. The CLI is still accessible.
	Amber	On steadily	A minor alarm has occurred, such as a software error.
	Green	Solid	The optical ILA is operating properly.
Power (PWR)	Unlit	Off	The optical ILA is powered off or there is no power to the device.
	Amber	On steadily	The optical ILA is powered by a single power supply. The second power supply is either missing or not connected to a power source.
	Green	On steadily	The optical ILA is powered with two redundant power supplies.

RELATED DOCUMENTATION

[Optical ILA Hardware Component Overview | 1504](#)
[Optical ILA Cooling System Description | 1505](#)
[Optical ILA AC Power Supply Description | 1507](#)
[Optical ILA DC Power Supply Description | 1508](#)

Optical ILA Component Redundancy

The following hardware components provide redundancy on the optical ILA models:

- Cooling system—The optical ILA has three fan modules. Each fan module is a redundant unit containing one fan. If a fan module fails and the remaining fan modules are unable to keep the optical ILA within the desired temperature thresholds, chassis alarms are raised and the optical ILA can shut down.
- The optical ILA ships with two power supplies that provide 1+1 redundancy. If one power supply fails or is removed, the second power supply balances the electrical load without interruption and still provides 1+1 redundancy while the failing power supply is replaced.

RELATED DOCUMENTATION

[Optical ILA Field-Replaceable Units | 1512](#)

[Optical ILA Management Panel | 1514](#)

[Optical ILA Management Port LEDs | 1515](#)

Optical ILA Field-Replaceable Units

Field-replaceable units (FRUs) are components that you can replace at your site. The optical ILA FRUs are hot-removable and hot-insertable—you can remove and replace them without powering off the optical ILA or disrupting the optical ILA function.



CAUTION: Replace a failed fan module with a new fan module within 30 seconds of removal to prevent chassis overheating.


[Table 213 on page 1513](#) lists the FRUs for the optical ILA and actions to take before removing them.

Table 213: Required Actions Before Removing a FRU from the Optical ILA

FRU	Required Actions Before Removal
Power supplies (2)	<p>Disconnect the AC power and remove the AC power cord or cable for the power supply unit.</p> <p>Disconnect the DC power and remove the power connector.</p> <p>NOTE: You need a minimum of one powered power supply for the optical ILA to operate properly..</p>
Fan modules (3)	None.

See [Figure 38 on page 1513](#) shows the FRU panel on an optical ILA.

Figure 38: Optical ILA FRU Panel



1—Grounding	3—Fan modules
2—ESD point	4—Power supplies

NOTE: If you have a Juniper Care service contract, register any addition, change, or upgrade of hardware components at <https://www.juniper.net/customers/support/tools/updateinstallbase/>. Failure to do so can result in significant delays if you need replacement parts. This note does not apply if you replace existing components with the same type of component.


RELATED DOCUMENTATION

Optical ILA Component Redundancy 1512
Optical ILA Management Panel 1514
Optical ILA Management Port LEDs 1515

Optical ILA Management Panel

The optical ILA management panel is found on the front panel (see [Figure 39 on page 1514](#)).

Figure 39: Optical ILA Management Panel Components



You manage the optical ILA by using the command-line interface (CLI), which is accessible through the console and out-of-band management ports on the management panel. In addition, the front panel has system status LEDs that alert you to minor or major alarms or other issues with the amplifier.

[Figure 39 on page 1514](#) shows the management panel in detail.

You can also manage the optical ILA through Connectivity Services Director (CSD), which is a Junos Space application developed to manage the optical functionality provided by optical ILAs and integrated photonic line cards (IPLCs) that are installed in the PTX3000 routers. CSD is managed over a data communications network (DCN). CSD presents a topological network view in an intuitive, comprehensive, and cohesive manner that enables you to visualize optical sites, links, and services and a site view that provides status, configuration, alarms/faults, and performance monitoring functionality on the optical interfaces. By using CSD, you can perform the following tasks for an optical ILA:

- View the optical interface specifications that are currently applied on the device, such as wavelength and power.
- Modify the existing parameters of the optical port to suit your network needs or resolve any alarms caused by certain interface settings.
- View the active alarms generated for the optical interface to analyze and resolve the condition that triggered the alarm on the device.
- Configure threshold-crossing alarms (TCAs) for the optical interface.
- View the performance monitoring details in statistical and graphical formats for the optical interface.

RELATED DOCUMENTATION


Optical ILA Component Redundancy 1512
Optical ILA Field-Replaceable Units 1512
Optical ILA Management Port LEDs 1515

Optical ILA Management Port LEDs

There is a management port on the optical ILA, located on the management panel. The port is labeled **MGMT**.

The management port is an Ethernet port that supports an RJ-45 connector and has separate LEDs for status and activity. [Figure 40 on page 1515](#) shows the location of the LEDs.

Figure 40: Management Port LEDs on the Optical ILA



[Table 214 on page 1515](#) describes the RJ-45 management port LEDs.

Table 214: Optical ILA RJ-45 Management Port LEDs

LED	Color	State	Description
Link	Unlit	Off	No link is established, there is a fault, or the link is down.
	Yellow	Blinking	A link is established, and there is link activity.

Table 214: Optical ILA RJ-45 Management Port LEDs (*continued*)

LED	Color	State	Description
Status	Unlit	Off	Link is down.
	Green	On steadily Blinking	Link is up. There is data activity.

RELATED DOCUMENTATION

- [Optical ILA Component Redundancy | 1512](#)
- [Optical ILA Field-Replaceable Units | 1512](#)
- [Optical ILA Management Panel | 1514](#)

Optical Inline Amplifier Description

IN THIS SECTION


- [Front Panel | 1517](#)
- [FRU Panel | 1518](#)

The Juniper Networks Optical Inline Amplifier is a fixed stand-alone erbium-doped fiber amplifier (EDFA) with dual AC or DC power supplies. The optical inline amplifier (ILA) supports bidirectional optical inline amplification. The optical ILA provides periodic amplification of a dense wavelength-division multiplexing (DWDM) signal to enable long-distance transmission as it propagates along the fiber . The optical ILA is typically placed between 50 miles (80 km) and 62 miles (100 km) apart along the length of the fiber. The optical ILA is used in conjunction with the integrated photonic line card (IPLC) that is installed in the Juniper Networks PTX3000 Packet Transport Routers.. The optical ILA connects to the IPLC through the **LINE IN** and **LINE OUT** LC port connectors on the front panel. It also connects to other optical ILAs through the LC port connectors.

The optical ILA operates with redundant hot-swappable pluggable power supplies that are either AC or DC. The optical ILA can be managed by using Connectivity Services Director (CSD), or by using the CLI console commands . The optical ILA does not support the Junos operating system (Junos OS).

Figure 41 on page 1517 shows an E-Line configuration with the optical ILA and IPLC.

Figure 41: E-Line Configuration




In this example, the optical ILA is connected to the IPLC in the PTX3000 chassis, which is connected to compatible PICs in the same chassis through the add and drop ports. The multiplexed wavelengths from the IPLC are amplified and transmitted in a single fiber toward the line (through the **Line OUT** port on the IPLC) which is connected to the optical ILA (through the **LINE IN** port on the ILA). Based on the distance, you can have multiple ILAs connected. In this example, there are three ILAs to enable long-distance transmission. The amplified signals received by the IPLC in the remote chassis, are demultiplexed into individual wavelengths and sent to the respective add and drop ports (which are connected to the compatible PICs/MICs) in that PTX3000 chassis.

For more information about the IPLCs, see the *PTX3000 Packet Transport Router Hardware Guide*. For information about configuring the IPLCs, see the *Integrated Photonic Line Card (IPLC) Feature Guide*.

Front Panel

The front panel of the optical ILA contains six LC port connectors, the **ON/OFF** button, the console and management ports, the system status LEDs, and the USB ports. Figure 42 on page 1517 shows the front panel of the optical ILA.


Figure 42: Optical ILA Front Panel



FRU Panel

The field-replaceable unit (FRU) panel of the optical ILA contains the fan modules and power supplies for the optical ILA. [Figure 43 on page 1518](#) shows the optical ILA FRU panel.

Figure 43: Optical ILA FRU Panel



The cooling system in an optical ILA consists of three 12.4-W fan modules. These fan modules can be hot-swapped—you do not need to power off the optical ILA or disrupt the functioning of the optical ILA to replace a fan module. The optical ILA has two 150-W power supplies, either AC or DC depending on your configuration. The power supplies need to be both AC or both DC. Only one power supply is required to power the device, while the second power supply provides redundancy.

RELATED DOCUMENTATION

[Optical ILA Power Supply LEDs | 1518](#)

Optical ILA Power Supply LEDs

Each optical ILA power supply has two LEDs on the power supply faceplate. [Figure 44 on page 1519](#) shows the location of the LEDs on an optical ILA AC power supply. [Figure 45 on page 1519](#) shows the location of the LEDs on an optical ILA DC power supply.

Figure 44: AC Power Supply LEDs





Figure 45: DC Power Supply LEDs



Use [Table 215 on page 1519](#) and [Table 216 on page 1520](#) to interpret the state of the power supply LEDs.

Table 215: Optical ILA AC Power Supply LED

Name	Color	State	Description
DC OK (left side of FRU panel)	Unlit	Off	There is no power to any of the power supplies.
	Green	Blinking (1 Hz)	The power supply is present and only on standby mode.
		On steadily	The power supply output is on and operating correctly.
	Red	On steadily	There is a power supply failure.
		Blinking (0.5 Hz)	No AC power to this power supply only.

Table 215: Optical ILA AC Power Supply LED (continued)

Name	Color	State	Description
AC OK (right side of FRU panel)	Unlit	Off	There is no power to any of the power supplies.
	Green	On steadily	The power supply is present and only on standby mode.
		On steadily	The power supply output is on and operating correctly.
	Red	On steadily	There is a power supply failure.
		Blinking (0.5 Hz)	No AC power to this power supply only.

Table 216: Optical ILA DC Power Supply LED

Name	Color	State	Description
DC OUT OK (left side of FRU panel)	Unlit	Off	There is no power to the power supplies.
	Green	On steadily	The power supply DC output is on and operating correctly.
		Blinking ((1 Hz))	The power supply is present and on standby mode.
	Red	On steadily	There is a power supply failure.
		Blinking (0.5 Hz)	There is no DC power to this power supply only.
DC IN OK (right side of the FRU panel)	Unlit	Off	There is no power to the power supplies.
	Green	On steadily	The power supply is present and on standby mode.
		On steadily	The power supply DC output is on and operating correctly.
	Red	On steadily	There is a power supply failure.
		Blinking (0.5 Hz)	There is no DC power to this power supply only.

RELATED DOCUMENTATION

[Optical Inline Amplifier Description](#) | 1516

PTX3000 IPLC Description

IN THIS SECTION

- [IPLC Base Module | 1522](#)
- [IPLC Expansion Module | 1525](#)

The integrated photonic line card (IPLC) base module (PTX-IPLC-B-32) is an integrated optical card that provides the combined functionalities of optical multiplexing and demultiplexing, optical amplification, optical equalization, and optical channel monitoring. The IPLC multiplexes and enables amplification of up to 32 individual wavelengths for transmission over single-mode optical fiber (through the add and drop ports on the front panel). The add and drop ports on the front panel of the IPLC connect to compatible dense wavelength-division multiplexing (DWDM) PICs or MICs. The wavelengths from the add and drop ports on the IPLC are amplified, monitored, and controlled and then transmitted toward the line direction (through the **Line IN** and **Line OUT** ports on the front panel). In the reverse direction the received signals from the line are amplified to enable long distance transmission and then demultiplexed into individual wavelengths and sent to the respective add and drop ports on the front panel.


The IPLC expansion module (PTX-IPLC-E-32) is an optical multiplexing and demultiplexing card that interfaces with the IPLC base module to increase the add/drop capacity of the system up to 64 channels.

In a PTX3000 chassis, you can install an IPLC in any of the FPC or PIC slots. The IPLCs install vertically in the front of the PTX3000. Up to 16 IPLCs or 8 base modules and 8 expansion modules are supported in a PTX3000 chassis. Each expansion module must be connected to a base module. The IPLC connects directly to the integrated DWDM PICs/MICs (for example; the P1-PTX-2-100G-WDM or PTX-5-100G-WDM) in the same chassis, or an external chassis through the IPLC front panel add and drop ports. Also, the IPLC can connect to another IPLC in the same chassis through the bi-directional express ports (**XPN IN** and **XPN OUT**) to enable an optical bypass function.

The IPLC can also connect to an optical inline amplifier (ILA) in the network to enable transmission across longer spans. See the *Optical Inline Amplifier Hardware Guide* for more details about the optical ILA.

[Figure 46 on page 1522](#) shows a point-to-point configuration for an IPLC.

Figure 46: Point-to-Point Configuration



In this example, the IPLC in the PTX3000 chassis is connected to compatible PICs in the same chassis through the add and drop ports. The wavelengths from the add and drop ports on the IPLC are multiplexed and then amplified, monitored, and transmitted in a single fiber toward the line (through the **Line OUT** port on the IPLC) and connected to the IPLC (through the **Line IN** port) in the remote PTX3000 chassis through the optical ILA . The IPLC connects to the optical ILA through the **Line IN** and **Line OUT** ports. The optical ILAs provide periodic amplification of the signal to enable long distance transmission and are typically placed between 50 miles (80 km) and 62 miles (100 km) apart . The signals received by the IPLC in the remote chassis, are demultiplexed into individual wavelengths and sent to the respective add and drop ports (which are connected to the compatible PICs) in that PTX3000 chassis.

For information on configuring the IPLCs, see the *Integrated Photonic Line Card (IPLC) Feature Guide*.


IPLC Base Module

The IPLC base module provides the following optical functions:

- Multiplexing and demultiplexing of up to 32 channels spaced at 100 GHz.
- Amplification of the aggregate multiplexed wavelengths to enable long distance transmission.
- Per channel power monitoring and control through the use of an on-board optical channel monitor (OCM) and wavelength selective switch (WSS).
- Bypass of optical channels between pairs of IPLCs for low-cost optical networking. Two IPLC base modules installed in the same chassis can form an optical bypass. In addition, adding an expansion module (connected to an IPLC base module) can expand the number of channels supported beyond the 32 channels, up to 64 channels.
- Support for the optical supervisory channel (OSC) is transmitted through an OC-3 1510nm signal that enables the IPLC to communicate with the remote IPLC or communicate and manage the optical ILA.

IPLC Base Module Components

Figure 47: IPLC Base Module Faceplate



Each IPLC base module weighs 6.3 lb. (2.85 kg). See [Figure 47 on page 1523](#). The add and drop ports are numbered 0 to 31 and the port numbers are denoted by R and L. For example, as shown in the lower magnified view in [Figure 47 on page 1523](#), L15 refers to the add and drop port on the left side and R31 refers to the add and drop port on the right side on the front panel.

The IPLC base module consists of these components:

- **STATUS** LED that displays the status of the IPLC.
- **ON/OFF** button that resets the IPLC.
- **Line IN** and **Line OUT** ports—An input and an output port to connect to another optical network element. You can use these ports to connect to another IPLC or to the optical ILA.
- **PT IN** and **PT OUT** ports—An input and an output port to connect to an another IPLC base module. Two IPLCs can be installed in the same chassis to form an optical express-in bypass.

- **XPN IN** (expansion-in) and **XPN OUT** (expansion-out) ports—An input and an output port to connect to an IPLC expansion module.
- **ADD** and **DROP** ports—A total of 32 pairs of ports (32 add ports and 32 drop ports) for 32 DWDM channels.

NOTE: All the ports on the IPLC use fiber-optic cables with LC connectors.

Table 217 on page 1524 provides the supported wavelength allocation on the IPLC ports.

Table 217: Supported Wavelength Allocation for the IPLC Base Module (PTX-IPLC-B-32)

Frequency (THz)	Central Wavelength (nm)	Port number on the IPLC Base module
192.05	1561.01	0
192.15	1560.20	1
192.25	1559.39	2
192.35	1558.58	3
192.45	1557.77	4
192.55	1556.96	5
192.65	1556.15	6
192.75	1555.34	7
192.85	1554.54	8
192.95	1553.73	9
193.05	1552.93	10
193.15	1552.12	11
193.25	1551.32	12
193.35	1550.52	13
193.45	1549.72	14

Table 217: Supported Wavelength Allocation for the IPLC Base Module (PTX-IPLC-B-32) (continued)

193.55	1548.91	15
193.65	1548.11	16
193.75	1547.32	17
193.85	1546.52	18
193.95	1545.72	19
194.05	1544.92	20
194.15	1544.13	21
194.25	1543.33	22
194.35	1542.54	23
194.45	1541.75	24
194.55	1540.95	25
194.65	1540.16	26
194.75	1539.37	27
194.85	1538.58	28
194.95	1537.79	29
195.05	1537.00	30
195.15	1536.22	31


IPLC Expansion Module

The IPLC expansion module connects to the IPLC base module through the **XPN IN** and **XPN OUT** ports. It provides the following optical functions:

- Increases the total optical DWDM channel capacity by 32 ports. It does not interface directly with the network.
- Provides multiplexing and demultiplexing of up to 32 channels spaced at 100 GHz.

IPLC Components

Figure 48: IPLC Expansion Module Faceplate



Each IPLC expansion module weighs 3.3 lb. (1.49 kg). See [Figure 48 on page 1526](#). The add and drop ports are numbered 32 to 64 and the port numbers are denoted by R and L. For example, as shown in the lower magnified view in [Figure 48 on page 1526](#), L47 refers to the add and drop port on the left side and R63 refers to the add and drop port on the right side on the front panel. The IPLC expansion module consists of these components:

- **STATUS LED** that displays the status of the IPLC.
- **XPN IN** (expansion-in) and **XPN OUT** (expansion-out) ports—A pair of input and output ports to connect to the IPLC base module.
- **ADD** and **DROP** ports—A total of 32 pairs of ports (32 add ports and 32 drop ports) for 32 DWDM channels.

NOTE: All the ports on the IPLC use fiber-optic cables with LC connectors.

Table 218 on page 1527 provides the supported wavelength allocation on the ports.

Table 218: Supported Wavelength Allocation for the IPLC Expansion Module (PTX-IPLC-E-32)

Frequency (THz)	Central Wavelength (nm)	Port number on the IPLC Expansion Module
192.10	1560.61	32
192.20	1559.79	33
192.30	1558.98	34
192.40	1558.17	35
192.50	1557.36	36
192.60	1556.55	37
192.70	1555.75	38
192.80	1554.94	39
192.90	1554.13	40
193.00	1553.33	41
193.10	1552.52	42
193.20	1551.72	43
193.30	1550.92	44
193.40	1550.12	45
193.50	1549.32	46
193.60	1548.51	47
193.70	1547.72	48
193.80	1546.92	49
193.90	1546.12	50

Table 218: Supported Wavelength Allocation for the IPLC Expansion Module (PTX-IPLC-E-32) (continued)

Frequency (THz)	Central Wavelength (nm)	Port number on the IPLC Expansion Module
194.00	1545.32	51
194.10	1544.53	52
194.20	1543.73	53
194.30	1542.94	54
194.40	1542.14	55
194.50	1541.35	56
194.60	1540.56	57
194.70	1539.77	58
194.80	1538.98	59
194.90	1538.19	60
195.00	1537.40	61
195.10	1536.61	62
195.20	1535.82	63

RELATED DOCUMENTATION

[IPLC Architecture and Functional Components Overview | 1529](#)
[Understanding IPLC Base and Expansion Modules | 1532](#)
[Understanding the IPLC Configuration | 1535](#)
[PTX3000 IPLC LED | 1541](#)

IPLC Architecture and Functional Components Overview

IN THIS SECTION

- [Architecture Overview | 1529](#)
- [Functional Component Overview | 1530](#)

This topic provides an operational and configuration overview of the IPLC.

Architecture Overview

The IPLC base module accepts and then multiplexes 32 individual wavelengths (connected through the **ADD** and **DROP** ports on the front panel) into a single fiber pair. If you require more than 32 channels, you can connect the optional IPLC expansion module to the IPLC base module to increase the port capacity of the node to 64 ports.

The wavelengths from the **ADD** and **DROP** ports are then amplified, monitored, and controlled and then transmitted towards the optical network over the **Line OUT** port on front panel of the IPLC base module. In the reverse direction, the received signals from the optical network on the **Line IN** port are amplified to overcome for loss in the optical fiber and then demultiplexed into individual wavelengths and sent to the configured **ADD** and **DROP** ports on the front panel.

The 32 channels provided by the IPLC base module are known as the *odd* channels. The 32 channels provided by the optional IPLC expansion module are known as the *even* channels. This odd and even designation reflects the default wavelengths the channels support.

In the multiplexing-add path, the 32 even channels from the IPLC expansion module are interleaved with the 32 odd channels from the IPLC base module. In the demultiplexing-drop path, the 32 even channels are separated from the odd channels using a deinterleaver. All 64 channels go through the main common components used for amplification and equalization. All 32 channels on the IPLC base module are 100 GHz spaced, per the ITU-T Grid Specifications (G.694.1). The 32 channels on the IPLC expansion module are offset from the IPLC base module channels by 50 Hz.

Single Node Two Optical Line Terminations

The IPLC architecture can also support two-line terminations on a single node. To form a single node that supports two-line terminations, simply connect two IPLC base modules together through the **PT IN-PT OUT** ports on the front panel and entering a few simple configuration statements in the Junos OS CLI. The IPLC base module and the expansion module each require a single FPC or PIC chassis slot. This minimizes slot requirements and ensures shelf capacity is not sacrificed in single-node east-west or


north-south configurations. These minimal slot requirements are especially important if you are configuring a single-node, two-line termination that requires 64 channels using the IPLC expansion modules.

The IPLC base module supports 32 dense wavelength division multiplexing (DWDM) channels. Using the IPLC expansion module, you can increase the number of supported DWDM channels to 64.

Functional Component Overview

The high-level optical functional block diagram of the combined functions of both the IPLC base module and the IPLC expansion module are shown in [Figure 49 on page 1530](#).

Figure 49: Combined Functions of the IPLC Base and Expansion Modules



IPLC Base Module Functional Components

The main building blocks of the IPLC base module architecture are as follows:

- A 2x1 WSS on the add path to select wavelengths from among all channels presented from the 32 add ports of the IPLC base module (shown in blue in [Figure 49 on page 1530](#)) and from the 32 add ports on the IPLC expansion module (shown in gray in [Figure 49 on page 1530](#)).
- A booster erbium-doped fiber amplifier (EDFA) (E1) followed by a variable optical attenuator (VOA) to compensate for the loss of the WSS, multiplexer, and 3 dB coupler.
- A variable gain preamplifier EDFA (E2) to compensate for the loss of the preceding fiber span.
- An optical channel monitor (OCM) with three points of observation including the following:
 - Booster EDFA (E1) output
 - Preamplifier EDFA (E2) output
 - The combined channels of the local add function at the input of the WSS, which indicates which channels (both odd and even channels) are being added locally

- An optical supervisory channel (OSC), which communicates inband with the far end IPLC modules and is used for the analysis of the fiber span characteristics, performance monitoring, and IPLC fault handling. Simple topology discovery logic communicates with the ILAs and PTX3000 nodes.
- An optical splitter is used to broadcast the received signal from the output of the preamplifier (E2) toward both **DROP** and **PT IN** and **PT OUT** ports
- Four power monitors:
 - **AWG Add**—Monitors the input of the WSS measuring the total input power of the combined channels of the local add function
 - **Express In**—Monitors the input of the WSS measuring the total input power at the input to the WSS coming from the **PT IN** and **PT OUT** express ports
 - **Line IN**—Monitors the input at the **Line IN** port, for detection of the incoming line signal optical power
 - **Line OUT**—Monitors the output at the **Line OUT** port, for detection of the outgoing line signal optical power

IPLC Expansion Module Functional Components

The IPLC expansion module is a passive multiplexer/demultiplexer that interfaces only with the IPLC base module. The IPLC expansion module receives its sole input from and delivers its sole output to the IPLC base module through the **PT IN** and **PT OUT** ports. As such, it does not interface directly with the network or the high-speed backplane of the PTX3000 router. [Figure 49 on page 1530](#) shows the main building blocks for both the IPLC base module and expansion module.

The main building blocks of the IPLC expansion module architecture are as follows:

- Add filter capable of multiplexing 32 DWDM channels of certain wavelengths
- Drop filter capable of demultiplexing 32 DWDM channels having the same certain wavelengths
- Demultiplexing filter whose input (which is also the sole input to the expansion module) is monitored through a power detector. The power detector determines whether light is present. If light is present, the power detector determines whether the light has reached the expansion module through the patch cord between the IPLC base module and the IPLC expansion module.

RELATED DOCUMENTATION

[PTX3000 IPLC Description | 1521](#)

[Understanding IPLC Base and Expansion Modules | 1532](#)

[Understanding the IPLC Configuration | 1535](#)

[PTX3000 IPLC LED | 1541](#)

Understanding IPLC Base and Expansion Modules

IN THIS SECTION

- Overview | 1532
- Configuring, Managing, and Monitoring the IPLC | 1533
- High Availability, Resiliency, and Integrity | 1533
- Usability, Serviceability, Security and Troubleshooting | 1533
- Usage Scenarios | 1534

This topic provides an overview of the integrated photonic line card (IPLC) base module and expansion module, and includes the following sections:

Overview

The IPLC supports wavelengths up to 100 Gbps and enables ad-hoc allocation of network bandwidth for high-demand, real-time applications, and network services that are delivered over an optical fiber infrastructure. The IPLC base module provides the combined functionality of a 32-port reconfigurable optical add-drop multiplexer (ROADM), optical amplification, optical equalization, and optical channel monitoring on a single card. The IPLC base module also interfaces with the optional IPLC expansion module, which increases the port capacity to 64 add-drop ports.

Figure 50: IPLC Point-to-Point Configuration




Figure 50 on page 1532 shows a typical IPLC point-to-point configuration. In this configuration, the **Line IN** and **Line OUT** ports on the front of the IPLC base modules are connected to Juniper Networks' optical inline amplifier (ILA) in the optical fiber network. Optical ILA nodes are typically placed into the network where the fiber length is greater than 80–100 km.

For ring configurations or for other east-west or north-south two-line deployment scenarios, you can connect two IPLC base modules together to form a single-node that consists of two 32-port ROADMs, each with its own line-side fiber span.

Configuring, Managing, and Monitoring the IPLC

You configure, manage, and monitor IPLC modules in a similar fashion to a standard PTX3000 Series interface, by entering a minimum set of CLI commands and making the proper connections between the ports on the IPLC front panel and the PTX Series interfaces.

SNMP

You can also use SNMP to configure the IPLC performance monitor thresholds, and monitor and manage the IPLC modules

Connectivity Services Director

Optionally, you can use the Junos Space Connectivity Services Director to configure, manage, and monitor the IPLC and the optical ILA.

Optical Supervisory Channel

The IPLC uses an in-band optical supervisory channel to communicate with the IPLC expansion module, as well as with remote IPLC modules and optical ILA nodes.

High Availability, Resiliency, and Integrity

Because the IPLC modules do not connect to the PTX Series high-speed backplane, upgrades to the system software and resets do not affect traffic running on the IPLC modules. From an optical perspective, the IPLC modules tolerate both fast and slow changes in physical conditions. For example, if a large number of optical channels disappear due to a fiber cut, the IPLC has sophisticated control circuitry that prevents any errors on the remaining channels. Similarly, slow degradation of the fiber plant is also accommodated to ensure optimal performance across the lifespan of the system.

To ensure error-free transmission across both long fiber runs and large numbers of wavelengths on spans, the IPLC base module automatically controls the power of each channel.

Usability, Serviceability, Security and Troubleshooting

Traditionally, wavelength-division multiplexing (WDM) systems and subsystems have relied on a high degree of manual configuration and fine-tuning from expert users to enable signals to be transmitted error free across the inherently analog medium of optical fiber. The IPLC automates these activities to the point that adding a wavelength is as simple as configuring a port on the router. No optical expertise is required because the IPLC automates the introduction, removal, and balancing of optical channels and you simply need to enable the traffic-carrying port by setting some basic Junos CLI commands.

Unlike traditional WDM systems, the IPLC and optical ILA can accommodate fiber spans between 0 dB and 30 dB with a single hardware variant, simplifying network designs and reducing spare inventory requirements.

WDM networks typically contain many elements and identifying underlying failure points is often complex. With the IPLC, if at any point traffic is interrupted, the system raises a number of alarms to notify the management and control layers of the system and also, to help quickly and easily identify the root cause of the failure.

Performance Monitors

Alarms and analog performance monitors are available to allow expert or non-expert users easily identify and localize faults. Performance monitors monitor analog data and alarms enabling you to quickly view the health of the IPLC. You can quickly and easily configure and enable alarm thresholds at the various monitoring points on the IPLC module.

Usage Scenarios

Optical Bypass Node Configuration

Two IPLCs can be installed in the same shelf to form an Optical Bypass. In addition, should need arise, two Optical Passive Expansion Cards (OPECs) can be added (one connected to each IPLC card). In the latter case, the expansion cards expand the number of channels supported beyond the initial 32 channels.

You can also connect two IPLC modules to form an Optical Bypass node. In this case, the EXPRESS IN and EXPRESS OUT of one card connected to the EXPRESS OUT and EXPRESS IN of the other card respectively.

Optical bypasses are software configurable and controlled through the IPLC's wavelength selective switch (WSS) so there is no need for manual intervention. The IPLCs software optical bypass enables wavelengths that do not terminate on the given node to be passed through to the remote node without optical-electrical-optical (OEO) conversion.

RELATED DOCUMENTATION

[PTX3000 IPLC Description | 1521](#)

[IPLC Architecture and Functional Components Overview | 1529](#)

[Understanding the IPLC Configuration | 1535](#)

[PTX3000 IPLC LED | 1541](#)

Understanding the IPLC Configuration

IN THIS SECTION

- [Understanding the Front Panel Connections | 1535](#)
- [Slot Placement in the Chassis | 1535](#)
- [Understanding How to Configure the Add and Drop Ports | 1536](#)
- [Frequency, Wavelength, and Port Default Mapping Configuration | 1537](#)

This topic describes the basic configuration process for the IPLC modules and includes the following sections:

Understanding the Front Panel Connections

The IPLC base module and expansion module are slide-in cards that each occupy a single slot within the PTX3000 chassis. Unlike line cards, the IPLC does not connect into the high-speed data backplane of the chassis, but rather provides the following optical functions that you connect through the front panel:

- **Line IN** and **Line OUT** ports—An input and an output port to connect to the optical line system, such as the optical ILA.
- **PT IN** and **PT OUT** ports—An input and an output port to connect to another IPLC base module. You can use these ports to connect two IPLC base modules together to form a single-node that provides two line-side terminations.
- **XPN IN** and **XPN OUT** ports—An input and an output port to connect to an IPLC expansion module
- **ADD** and **DROP** ports—A total of 32 pairs of ports (32 **ADD** ports and 32 **DROP** ports) for 32 DWDM channels

The IPLC modules are designed to connect the **ADD** and **DROP** ports on the front panel to compatible 10-Gigabit or 100-Gigabit DWDM PICs in the same chassis, or to PICs or MICs in a remote chassis.

Slot Placement in the Chassis

BEST PRACTICE: We recommend that you place the IPLC modules into the same FPC/PIC slot pair on the PTX3000 chassis.

The IPLC base module and expansion module each require a single FPC slot. This minimizes slot requirements and ensures that shelf capacity is not sacrificed in single-node east-west or north-south configurations. These slot requirements are especially important if you are configuring a single-node two-line termination that requires 64 channels by using the IPLC expansion modules.

Understanding How to Configure the Add and Drop Ports

The IPLC supports three possible modes of operation for IPLC add and drop ports as follows:

- **blocked**—(Default) If there is no explicit configuration for the IPLC wavelength, the wavelength is in blocked mode.
- **switch**—Switches the specified IPLC wavelength to an optical interface on the same or different chassis, including a remote chassis.

To switch a wavelength to an optical interface on the same chassis, enter the following in the CLI:

```
user@host# set chassis fpc fpc-slot optical-options wavelength nm switch interface-name
```

To switch a wavelength to an optical interface on a remote chassis, enter the following in the CLI:

```
user@host# set chassis fpc fpc-slot optical-options wavelength nm switch remote
```

- **wss-express-in**—Optically bypass the specified wavelength. For example to configure wavelength 1550.12 on the IPLC in slot 1 to be bypassed:

```
user@host# set chassis fpc 1 optical-options wavelength 1550.12 wss-express-in
```

Configuring a wavelength in express-in mode is a two-step process. First, you must define the association between the two IPLCs and then you specify the wavelength. For example, the following configuration creates the association between the two IPLC modules in slot 1 and slot 6:

```
user@host# set chassis fpc 1 optical-options express-in fpc 6
```

After you create the association between the two IPLCs, you must configure the wavelengths in express-in mode, in either one of the IPLC slots. For example:

```
user@host# set chassis fpc 1 optical-options wavelength nm wss-express-in
user@host# set chassis fpc 6 optical-options wavelength nm wss-express-in
```

The preceding statements configure wavelength1 and wavelength 2 in express-in mode for IPLCs modules in slot 1 and slot 6.

Frequency, Wavelength, and Port Default Mapping Configuration

All port wavelength frequencies are controlled by the IPLC's WSS and configured on a wavelength-by-wavelength basis. [Table 219 on page 1537](#) lists the default port, frequency, and wavelength mapping for both of the IPLC modules.

Table 219: Default Port, Frequency, and Wavelength Mapping

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
192.05	1561.01	Yes	0	No	No
192.1	1560.61	No	No	Yes	32
192.15	1560.2	Yes	1	No	No
192.2	1559.79	No	No	Yes	33
192.25	1559.39	Yes	2	No	No
192.3	1558.98	No	No	Yes	34
192.35	1558.58	Yes	3	No	No
192.4	1558.17	No	No	Yes	35
192.45	1557.77	Yes	4	No	No
192.5	1557.36	No	No	Yes	36
192.55	1556.96	Yes	5	No	No
192.6	1556.55	No	No	Yes	37
192.65	1556.15	Yes	6	No	No
192.7	1555.75	No	No	Yes	38
192.75	1555.34	Yes	7	No	No
192.8	1554.94	No	No	Yes	39

Table 219: Default Port, Frequency, and Wavelength Mapping (*continued*)

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
192.85	1554.54	Yes	8	No	No
192.9	1554.13	No	No	Yes	40
192.95	1553.73	Yes	9	No	No
193	1553.33	No	No	Yes	41
193.05	1552.93	Yes	10	No	No
193.1	1552.52	No	No	Yes	42
193.15	1552.12	Yes	11	No	No
193.2	1551.72	No	No	Yes	43
193.25	1551.32	Yes	12	No	No
193.3	1550.92	No	No	Yes	44
193.35	1550.52	Yes	13	No	No
193.4	1550.12	No	No	Yes	45
193.45	1549.72	Yes	14	No	No
193.5	1549.32	No	No	Yes	46
193.55	1548.91	Yes	15	No	No
193.6	1548.51	No	No	Yes	47
193.65	1548.11	Yes	16	No	No
193.7	1547.72	No	No	Yes	48
193.75	1547.32	Yes	17	No	No

Table 219: Default Port, Frequency, and Wavelength Mapping (continued)

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
193.8	1546.92	No	No	Yes	49
193.85	1546.52	Yes	18		
193.9	1546.12	No	No	Yes	50
193.95	1545.72	Yes	19	No	No
194	1545.32	No	No	Yes	51
194.05	1544.92	Yes	20	No	No
194.1	1544.53	No	No	Yes	52
194.15	1544.13	Yes	21	No	No
194.2	1543.73	No	No	Yes	53
194.25	1543.33	Yes	22	No	No
194.3	1542.94	No	No	Yes	54
194.35	1542.54	Yes	23	No	No
194.4	1542.14	No	No	Yes	55
194.45	1541.75	Yes	24	No	No
194.5	1541.35	No	No	Yes	56
194.55	1540.95	Yes	25	No	No
194.6	1540.56	No	No	Yes	57
194.65	1540.16	Yes	26	No	No
194.7	1539.77	No	No	Yes	58

Table 219: Default Port, Frequency, and Wavelength Mapping (continued)


Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
194.75	1539.37	Yes	27	No	No
194.8	1538.98	No	No	Yes	59
194.85	1538.58	Yes	28	No	No
194.9	1538.19	No	No	Yes	60
194.95	1537.79	Yes	29	No	No
195.00	1537.40	No	No	Yes	61
195.05	1537.00	Yes	30	No	No
195.10	1536.61	No	No	Yes	62
195.15	1536.22	Yes	31	No	No
195.20	1535.82	No	No	Yes	63

RELATED DOCUMENTATION

[PTX3000 IPLC Description | 1521](#)
[IPLC Architecture and Functional Components Overview | 1529](#)
[Understanding IPLC Base and Expansion Modules | 1532](#)
[PTX3000 IPLC LED | 1541](#)

PTX3000 IPLC LED

Figure 51: IPLC LED



An IPLC base module and an IPLC expansion module each has one LED—labeled **STATUS**.[Table 220 on page 1541](#) describes the functions of the LED.

Table 220: PTX3000 IPLC LED

Label	Color	State	Description
STATUS	Green	On steadily	IPLC is online.
		Blinking	IPLC is booting.
	Red	On steadily	IPLC is in a failed state.
		Off	IPLC is offline.

RELATED DOCUMENTATION

[PTX3000 IPLC Description | 1521](#)

[IPLC Architecture and Functional Components Overview | 1529](#)

[Understanding IPLC Base and Expansion Modules | 1532](#)

[Understanding the IPLC Configuration | 1535](#)

Communication of SNMP Traps Between Optical ILA and NMS Systems

SNMP traps are required to be propagated from an optical ILA to the network management system (NMS) server such as Connectivity Services Director. Each optical ILA needs to be able to configure trap destinations. Because an IPLC acts as a gateway, the traps are first received by the IPLC. From the IPLC, these traps are transmitted to the appropriate destination. The IPLC maintains information about the trap destination configuration per optical ILA. The optical ILA sends its traps to the anchor IPLC by default. The following traps are available from optical ILA:

- Temperature (abnormal, clear)
- Voltage (abnormal, clear)
- Fan temperature/speed (abnormal, clear)
- Software version (abnormal, clear)
- Optical ILA communication (abnormal, clear)
- EDFA temperature
- EDFA RFL
- Pump trap

RELATED DOCUMENTATION

[Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS | 1543](#)

[Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI | 1543](#)

[IPLC Specifications | 1545](#)

[Understanding the Performance Monitors and TCAs for IPLCs | 1546](#)

Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS

Each optical LA device has two bidirectional optical interfaces carrying the optical supervisory channel (OSC). The OSC signal (OC3) from two OSC ports is sent to the OSC field-programmable gate array (FPGA). The OSC FPGA creates Ethernet packets and sends them to a BCM or internal Gigabit Ethernet interface. The OSC traffic from two SFP 0/1 ports is multiplexed to processor Gigabit Ethernet interface (for example, port 3). The software uses the Gigabit Ethernet interface driver to transmit and receive OSC packets. The front panel RJ45 is also connected to the BCM switch. This interface can also be used for management. Both OSC and front panel RJ45 can be used simultaneously. The management packets from RJ45 interface are separated from OSC management packets. These can be sent over separate CPU GbE interface (for example, port 2 of BCM switch) by maintaining port 1 and port 2 in a VLAN.

Each optical ILA is connected to other ILAs and IPLC using optical ports. There are two optical ports for each optical ILA, designated as OSC A and OSC B. For IP connectivity over OSC, IPLC is used as a gateway. There is no direct IP connectivity between the optical ILA and external servers. The NMS server, such as Connectivity Services Director, sends the SNMP commands meant for an optical ILA to the Routing Engine of the PTX3000 router, with community string indicating the destination optical ILA. The mapping of optical ILA and SNMP community string is configured using the Junos OS CLI interface.

RELATED DOCUMENTATION

[Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI | 1543](#)

[IPLC Specifications | 1545](#)

[Understanding the Performance Monitors and TCAs for IPLCs | 1546](#)

Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI

Connectivity Services Director uses the Juniper Networks Device Management Interface (DMI) to the managed devices to collect the data. If you have a Junos Space fabric, Connectivity Services Director balances the load of polling the managed devices across the nodes in the fabric. Direct SNMP communication is absent between the NMS server such as Connectivity Services Director and the optical ILA because of IPLC design.

The requirements from Connectivity Services Director are as follows:

- Connectivity Services Director needs to be able to retrieve the optical ILA performance, fault, and image-upgrade status. In addition, Connectivity Services Director must be able to send configuration

and upgrade commands to the optical ILA. IPLC can set or get the optical ILA configuration and management parameters through SNMP (or any other method), save them locally and expose these through the Junos OS CLI. Connectivity Services Director is able to access these parameters through DMI.

- This implementation requires an optical ILA management client in optical ILA and optical ILA management server in IPLC. The management server queries the parameters periodically. Similarly, the CLI commands are used to set parameters related to optical ILA and initiate operations such as upgrade, which are sent as SNMP messages to the optical ILA client.

The following are examples of various configuration settings, and Set and Get operations required on an optical ILA.

Configuration Settings Performed Using the CLI

- Saving configuration
- Restoring configuration
- Resetting the OS
- Starting the firmware upgrade
- Restoring EDFA defaults
- Resetting the EDFA

Set Parameters for SNMP

- Temperature threshold parameters
- Addition and deletion of SNMP users
- Mode configuration (auto or debug)
- EDFA parameters (such as mode, gain, tilt, and LOS action)
- Optical power parameters (input and output LOS thresholds, and LOS hysteresis)
- OSC parameters (enable, add or drop power value, thresholds, and LOS hysteresis)

Get Parameters for SNMP

- Optical ILA part number, serial number, and uptime
- Temperature
- Fan speed
- Firmware upgrade status

- SNMP user information
- Mode EDFA (module type, part number, working status, gain, and temperature)
- Optical power (input power and output power)
- VOA attenuation
- OSC (index)

Alarms

- Viewing active alarms
- Viewing historical alarms

RELATED DOCUMENTATION

[Communication of SNMP Traps Between Optical ILA and NMS Systems | 1542](#)

[Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS | 1543](#)

[IPLC Specifications | 1545](#)

[Understanding the Performance Monitors and TCAs for IPLCs | 1546](#)

IPLC Specifications

The Integrated Photonic Line Card (IPLC) is designed to be installed in a PTX3000 router chassis. Architecturally, this card can be plugged into either the FPC or the PIC slot. For control and management purposes, the card behaves exactly similar to an FPC in the PTX3000 router. IPLC uses the same Processor Mezzanine Board (PMB) as the PTX Series router FPCs, although not as a daughter card. Due to mechanical and physical considerations, the PMB is designed onto the card directly. The card supports 100G wavelengths, and contains 32 ports on the faceplate. The IPLC uses an extension card to support an additional 32 ports. The IPLC might also have external DCMs to compensate for incoming dispersion on 10G wavelengths.

The IPLC also supports an OSC channel. This is an in-band channel used to communicate with ILAs and other optical nodes in the line system that are not directly accessible over the Data Communications Network (DCN). DCN is an ITU terminology for a device that provides network telemetry to remote network elements for the purpose of operations and network element management. OSC framing logic is implemented in the FPGA. Performance monitoring of analog data and alarms is supported.

You can set an explicit configuration to associate an IPLC with an expansion card, to increase the number of ports from 32 to 64. You can add an expansion card to the residing on the same chassis. There can be

only one association between one IPLC and one expansion card. For example, the IPLC in slot 0 can be associated with expansion card in slot 2. After IPLC slot 0 is associated with expansion card in slot, you cannot create another association between IPLC slot 0 and expansion card in slot 4. This setting is disallowed at the CLI configuration level itself. A corresponding alarm is triggered and an SNMP trap generated on a failure condition.

With only the specification of the configuration settings, it is not guaranteed that the express-in association are added to an optical IPLC. Junos OS needs to validate if the express-in port on the optical IPLC has been connected to the express-in port of the valid IPLC's express-in port, and the express-in ports are UP on both the IPLCs. Only after the validation is successful, express-in ports are moved to the UP state on the optical IPLC. A corresponding alarm is triggered and an SNMP trap is generated on a failure condition.

RELATED DOCUMENTATION

- [Communication of SNMP Traps Between Optical ILA and NMS Systems | 1542](#)
- [Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS | 1543](#)
- [Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI | 1543](#)

Understanding the Performance Monitors and TCAs for IPLCs

Performance monitors enable you to examine and diagnose the health, working capacity, operational efficiency, and the traffic-handling condition of the integrated photonic line cards modules (IPLCs) at various points on the optical IPLC hardware. You can enable configure threshold-crossing alarms (TCA) for the optical IPLC performance monitors. TCAs are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so for 15 minutes

The IPLC supports the optical performance monitors listed in [Table 221 on page 1546](#).

Table 221: IPLC Optical Performance Monitors

Performance Monitor	15 Min Bin	24 Hr Bin	TCA High	TCA Low
OSC TX power	Yes	Yes	Yes	Yes
OSC RX power	Yes	Yes	Yes	Yes
OSC/FPGA estimated fiber loss	Yes	Yes	No	No
Line OUT VOA attenuation	Yes	Yes	Yes	Yes

Table 221: IPLC Optical Performance Monitors (*continued*)

Performance Monitor	15 Min Bin	24 Hr Bin	TCA High	TCA Low
EDFA Input power (for both EDFAs)	Yes	Yes	Yes	Yes
EDFA Output power (for both EDFAs)	Yes	Yes	Yes	Yes
EDFA Signal output power (for both EDFAs)	Yes	Yes	Yes	Yes
EDFA Pump current (for both EDFAs)	Yes	Yes	Yes	Yes
EDFA Pump temperature (for both EDFAs)	Yes	Yes	Yes	Yes
OCM power readings (96 channels x 1 monitoring points)	Yes	Yes	Yes	Yes
Power monitor at ADD port	Yes	Yes	Yes	Yes
Power monitor at EXPRESS IN port	Yes	Yes	Yes	Yes

Each performance monitor supports:

- 15-minute and 24-hour binning
- Low and high threshold levels as described in [Table 222 on page 1548](#).

Table 222: IPLC Threshold Crossing Alert Minimum and Maximum Values

TCA	Description	Granularity	Range Minimum/Maximum Default and Recommended Value
erbium-doped fiber amplifier (EDFA) Input Power (for Both EDFAs)			
edfa1-awg-high-tca	Ingress EDFA pump AWG high TCA	5s	390/440 mW 400 mW
edfa1-awg-low-tca	Ingress EDFA pump AWG low TCA		5/15 mW 5 mW
edfa1-express-high-tca	Ingress EDFA pump express high TCA		390/440 mW 400 mW
edfa1-express-low-tca	Ingress EDFA pump express low TCA		5/15 mW 5 mW
edfa1-in-power-high-tca	Ingress EDFA input power high TCA	0.5s	10/12 dBm 11 dBm
edfa1-in-power-low-tca	Ingress EDFA input power low TCA		−38/−34 dBm −35 dBm
edfa1-out-power-high-tca	Ingress EDFA output power high TCA		20/21 dBm 20.5 dBm
edfa1-out-power-low-tca	Ingress EDFA output power low TCA		−1/0.5 dBm
edfa1-pump-current-high-tca	Ingress EDFA pump current high TCA	1s	10/300 mA
edfa1-pump-current-low-tca	Ingress EDFA pump current low TCA		

Table 222: IPLC Threshold Crossing Alert Minimum and Maximum Values (*continued*)

TCA	Description	Granularity	Range Minimum/Maximum Default and Recommended Value
erbium-doped fiber amplifier (EDFA) Input Power (for Both EDFAs)			
edfa1-pump-temp-high-tca	Ingress EDFA pump temperature high TCA	0.1s	20°/25° C
edfa1-pump-temp-low-tca	Ingress EDFA pump temperature low TCA		
edfa1-sig-power-high-tca	Ingress EDFA signal power high TCA	0.5s	10/12 dBm 11 dBm
edfa1-sig-power-low-tca	Ingress EDFA signal power low TCA >		−39/−35 dBm −36 dBm
erbium-doped fiber amplifier (EDFA) Output Power (for Both EDFAs)			
edfa2-awg-high-tca	Egress EDFA pump AWG high TCA	5s	390/440 mW 400 mW
edfa2-awg-low-tca	Egress EDFA pump AWG low TCA		5/15 mW 5 mW
edfa2-express-high-tca	Egress EDFA pump express high TCA		390/440 mW 400 mW
edfa2-express-low-tca	Egress EDFA pump express low TCA		5/15 mW 5 mW

Table 222: IPLC Threshold Crossing Alert Minimum and Maximum Values (*continued*)

TCA	Description	Granularity	Range Minimum/Maximum Default and Recommended Value
erbium-doped fiber amplifier (EDFA) Input Power (for Both EDFAs)			
edfa2-in-power-high-tca	Egress EDFA input power high TCA	0.5s	10/12 dBm 11 dBm
edfa2-in-power-low-tca	Egress EDFA input power low TCA		−38/−34 dBm −35 dBm
edfa2-out-power-high-tca	Egress EDFA output power high TCA		20/21 dBm 20.5 dBm
edfa2-out-power-low-tca	Egress EDFA output power low TCA		−1/0.5 dBm −0.5 dBm
edfa2-pump-current-high-tca	Egress EDFA pump current high TCA	1s	10/300 mA
edfa2-pump-current-low-tca	Egress EDFA pump current low TCA		
edfa2-pump-temp-high-tca	Egress EDFA pump temperature high TCA	0.1s	20°/25° C
edfa2-pump-temp-low-tca	Egress EDFA pump temperature low TCA		
edfa2-sig-power-high-tca	Egress EDFA signal power high TCA	0.5s	10/12 dBm 11 dBm
edfa2-sig-power-low-tca	Egress EDFA signal power low TCA		−39/−35 dBm −36 dBm
Line OUT Variable Optical Attenuation (VOA)			

Table 222: IPLC Threshold Crossing Alert Minimum and Maximum Values (*continued*)

TCA	Description	Granularity	Range Minimum/Maximum Default and Recommended Value
erbium-doped fiber amplifier (EDFA) Input Power (for Both EDFAs)			
lout-voa-high-tca	LOUT VOA high TCA	0.5	16/25 dBm 17 dBm
lout-voa-low-tca	LOUT VOA low TCA	N/A	N/A
Optical Channel Monitor (OCM) Power Readings (96 channels x 1 Monitoring Points)			
ocm-power-high-line-out-tca	OCM Power Line Out high TCA	0.5 dBm	1/2 dBm per channel 1.5 dBm per channel NOTE: Assumes VOA setting =0
ocm-power-low-line-out-tca	OCM Power Line Out low TCA		−2/−1 dBm per channel −1.5 dBm per channel NOTE: Assumes VOA setting =0
Optical Supervisory Channel (OSC) Estimated Fiber Loss			
osc-fiber-loss-high-tca	OSC fiber loss high TCA	0.5 dB	36/39 dB 37 dB
osc-fiber-loss-low-tca	OSC fiber loss low TCA	N/A	N/A
Optical Supervisory Channel (OSC) RX Power			
osc-rx-power-high-tca	OSC RX power high TCA	0.5 dBm	5/7 dBm 6 dBm
osc-rx-power-low-tca	OSC RX power low TCA		−47/−46 dBm −46 dBm
Optical Supervisory Channel (OSC) TX Power			

Table 222: IPLC Threshold Crossing Alert Minimum and Maximum Values *(continued)*

TCA	Description	Granularity	Range Minimum/Maximum Default and Recommended Value
erbium-doped fiber amplifier (EDFA) Input Power (for Both EDFAs)			
osc-tx-power-high-tca	OSC TX power high TCA	0.5 dBm	5.5/7 dBm 6 dBm
osc-tx-power-low-tca	OSC TX power low TCA		−2/−0.5 dBm −1 dBm

RELATED DOCUMENTATION

- [Communication of SNMP Traps Between Optical ILA and NMS Systems | 1542](#)
- [Communication of SNMPv2 and SNMPv3 Commands over OSC Between an Optical ILA and NMS | 1543](#)
- [Overview of Configuring and Managing Optical ILAs from Connectivity Services Director Using DMI | 1543](#)

Configuring and Monitoring Optical Interfaces, OTUs, and ODUs

IN THIS CHAPTER

- Viewing a Graphical Image of the Optical Interface Components | 1553
- Configuring and Managing OTN Port Details of MX Series and PTX Series Routers for Easy Administration | 1563
- Configuring and Managing OTU Details of MX Series and PTX Series Routers for Simplified Management | 1571
- Configuring and Managing ODU Details of MX Series and PTX Series Routers for Simplified Management | 1577
- Configuring and Managing Optical PIC Details for Effective Provisioning | 1581
- Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | 1583
- Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | 1585
- Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | 1587
- Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | 1589
- Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | 1595
- Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | 1600
- Viewing a Graphical Image of the Chassis of PTX Series Routers | 1604
- Diagnosing, Examining, and Correcting Optical Interface Problems | 1609
- Changing Alarm Settings for the Optics and OTN Interfaces | 1614

Viewing a Graphical Image of the Optical Interface Components

The Chassis View provides a pictorial representation of the optical interface, optical channel data unit (ODU), optical channel transport unit (OTU) of an MX Series and PTX Series router, and the modules or components that are installed in it, such as the line cards, interfaces, and other hardware elements.

The purpose of this view is to try and provide a comprehensive monitoring view of the health and status of deployed devices across the network. In this view all the managed devices are shown with their appropriate status and health based on the services and device settings applied. This view helps the operator to know the health and status across the network, it provides with the operator to quickly see the macro level information, which allows the operator to further analyze the information provided and

quickly navigate to individual devices and take any further corrective measure required. It provides a cohesive tool for the operator to quickly see the micro-level information and take any further remediation action required.

To view a graphical image of the optical interfaces, OTUs, and ODUs of MX Series and PTX Series routers, and its associated components:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Click a particular component or interface to display the associated details in the lower portion of the page. The Rotate and Perspective buttons enable you to view the images in required orientation.

6. Click the View Back (arrows in a square symbol) icon to cause the device image to rotate along the x-axis and display the rear view of the device. Alternatively, click the View Front icon to view the front plane of the device. The View Back and View Front icons are toggle options.

7. Click the Perspective (cube symbol) icon to display the device image in three-dimensional format. It is a toggle button, which causes the device image to be shown in either three-dimensional or one-dimensional format.

8. Select the level of magnification of the image by clicking the Zoom (magnifying glass) icon. The image is expanded and displayed.

Alternatively, use the slider control beneath the Zoom icon to change the level of magnification.

9. Click the home icon to return to the front view of the chassis.

The selected interface is surrounded with a colored outline based on the operational status. An interface that is operationally up is denoted in green and an interface that is operationally down is represented in red. The components are depicted as small colored icons at the top-left corner of the front view of the equipment image.

You can mouse over the different parts of the graphical image of the device, such as the interfaces, line cards, and slots. When you mouse over the different modules, their corresponding details are displayed as tooltips. On clicking the device components, the corresponding description for the selected component is displayed by default in the Component Info pane and the Equipment tab.

- **Manufacturer**—Name of the company that built and shipped the device.
- **Part number**—Part number of the chassis component.
- **Serial number**—Serial number of the chassis component. The serial number of the backplane is also the serial number of the router or switch chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

When you select any physical interface configured on the DPCs or PICs or MICs provisioned, the following fields are displayed for the corresponding component for each interface. The interface is surrounded by a colored box to show the Operational Status.

The Component Info pane and the Active Alarms monitor are displayed in the lower portion of the page.

The Active Alarms monitor shows any active alarm that has not yet been cleared. You can view the alarm name, the unique identifier assigned to the alarm, the person to which the alarm is assigned for corrective action, and the severity of the alarm. Click the **Launch Alarm Mgmt** icon (right upward-slanting arrow enclosed in a square) to navigate to the Fault mode and view the four standard alarm monitors available in Fault mode.

Active Alarms for the respective components are displayed when the component is clicked in the image of the chassis displayed. The components for which the alarms are displayed are Flexible Port Concentrator (FPC), Dense Port Concentrator (DPC), Physical Interface Card (PIC), Modular Interface Card (MIC), Routing Engine, Control Boards, fan trays, Switch Interface Board (SIB), and power supply module (PSM).

The following fields are displayed in the Active Alarms pane:

Table 223: Active Alarms Monitor

Table Column	Description
Severity	<p>The severity of the alarm. Severity levels are:</p> <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary.
Name	The alarm name.
Source	<p>The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.</p>

Table 223: Active Alarms Monitor (continued)

Table Column	Description
Last Updated	The date and time that the information for the alarm was last modified.

The following fields are displayed in the Component Info pane:

Table 224: Fields for Physical Interfaces in the Component Info Pane

Field	Description
Host Name	Hostname of the device
Physical Interface Name	Name of the physical interface
IP Address	IP address configured on the interface
Encapsulation	Encapsulation configured on the logical interface
Hardware Address	MAC address configured on the interface
Operation Status	Operational status of the physical interface: Up, Down.
Admin Status	Administrative state of the interface: Enabled or Disabled. If the interface is disabled, it can provide network connectivity, but it cannot provide power to connected devices.
Link Level Type	Encapsulation type configured on the interface
Link Type	Data transmission type
Speed	Speed at which the interface is running
MTU	Maximum transmission unit size on the physical interface
Loopback	Specifies whether the loopback status is enabled or disabled. If loopback is enabled, the type of loopback—Local or Remote—is displayed.
Description	Configured textual description of the interface

A redundant Ethernet interface is a pseudointerface that includes at minimum one physical interface from each node of the cluster. A redundant Ethernet interface must contain, at minimum, a pair of Fast Ethernet interfaces or a pair of Gigabit Ethernet interfaces that are referred to as child interfaces of the redundant

Ethernet interface (the redundant parent). If two or more child interfaces from each node are assigned to the redundant Ethernet interface, a redundant Ethernet interface link aggregation group must be formed.

A pseudowire subscriber logical interface terminates an MPLS pseudowire tunnel from an access node to the MX Series router that hosts subscriber management, and enables you to perform subscriber management services at the interface. Subscriber management supports the creation of subscriber interfaces over point-to-point MPLS pseudowires. The pseudowire subscriber interface capability enables service providers to extend an MPLS domain from the access-aggregation network to the service edge, where subscriber management is performed. Service providers can take advantage of MPLS capabilities such as failover, rerouting, and uniform MPLS label provisioning, while using a single pseudowire to service a large number of DHCP and PPPoE subscribers in the service network.

NOTE: The pseudowire is a tunnel that is either an MPLS-based Layer 2 VPN or Layer 2 circuit. The pseudowire tunnel transports Ethernet encapsulated traffic from an access node (for example, a DSLAM or other aggregation device) to the MX Series router that hosts the subscriber management services. The termination of the pseudowire tunnel on the MX Series router is similar to a physical Ethernet termination, and is the point at which subscriber management functions are performed. A service provider can configure multiple pseudowires on a per-DSLAM basis and then provision support for a large number of subscribers on a specific pseudowire. Figure 1 shows an MPLS network that provides subscriber management support.

The following table describes the fields displayed in the Pseudo Interfaces pane.

Table 225: Pseudo Interfaces Columns

Field	Description
Pseudo Interface Name	Name of the pseudowire subscriber logical interface.
Type	Signaling type for the pseudowire interface. You can use either Layer 2 circuit signaling or Layer 2 VPN signaling. The two signaling types are mutually exclusive for a given pseudowire.
Operation Status	Operational status of the physical interface: Up, Down.
Admin Status	Administrative state of the interface: Enabled or Disabled. If the interface is disabled, it can provide network connectivity, but it cannot provide power to connected devices.

The logical interfaces configured on each interface are also shown along with the physical interface description in tabular format. The following table describes the details displayed for logical interfaces.

Table 226: Logical Interfaces Columns

Field	Description
Device Name	The device configuration name.
Interface Name	Standard information about the interface, in the format type-/fpc/pic/port/logical interface, where type is the media type that identifies the network device; for example, ge-0/0/6.135.
IP Address	The IP address for the logical interface.
Encapsulation	The encapsulation type used on the logical interface.
Vlan	The VLAN ID for the logical interface.
Description	An optional description configured for the interface. It can be any text string of 512 or fewer characters. Any longer string is truncated. If there is no information, the column entry is blank.

From the Chassis View window, click the **Details** icon (arrow enclosed in a square) at the top-right corner of the window to open the Chassis View Details page that lists the configured devices and their parameters in the form of a table.

The following fields are displayed on the right pane, depending on the component or element of the chassis you selected from the chassis image displayed.

Table 227: Fields in the Chassis View Details Page

Field	Description
Module	Name of the SDG and the platform type, such as MX240 or MX480. Click the plus sign (+) to expand the tree to display the components of the device, such as chassis, PIC, CPU, and PIC parameters. Information about the chassis, midplane, craft interface (FPM), power midplane (PMP), Power Supply Modules (PSMs), Power Distribution Modules (PDMs), Routing Engines, Control Boards (CBs) and Switch Processor Mezzanine Boards (SPMBs), Switch Fabric Boards (SFBs), Flexible PIC Concentrators (FPCs), PICs, adapter cards (ADCs) and fan trays is displayed.
Model Number	Model number of the FRU hardware component.
Model	Model of the FRU component.
Part Number	Part number of the chassis component.

Table 227: Fields in the Chassis View Details Page (continued)

Field	Description
Serial Number	Serial number of the chassis component. The serial number of the backplane is also the serial number of the router chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

Table 227: Fields in the Chassis View Details Page (continued)

Field	Description
Description	

Table 227: Fields in the Chassis View Details Page (*continued*)

Field	Description
	<p>Brief description of the hardware item:</p> <ul style="list-style-type: none"> • Type of power supply. • Type of PIC. If the PIC type is not supported on the current software release, the output states Hardware Not Supported. • Type of FPC: FPC Type 1, FPC Type 2, FPC Type 3, FPC Type 4 , or FPC TypeOC192. On EX Series switches, a brief description of the FPC. On the J Series routers, the FPC type corresponds to the Physical Interface Module (PIM). The following list shows the PIM abbreviation in the output and the corresponding PIM name. <ul style="list-style-type: none"> • 2x FE—Either two built-in Fast Ethernet interfaces (fixed PIM) or dual-port Fast Ethernet PIM • 4x FE—4-port Fast Ethernet ePIM • 1x GE Copper—Copper Gigabit Ethernet ePIM (one 10-Mbps, 100-Mbps, or 1000-Mbps port) • 1x GE SFP—SFP Gigabit Ethernet ePIM (one fiber port) • 4x GE Base PIC—Four built-in Gigabit Ethernet ports on a J4350 or J6350 chassis (fixed PIM) • 2x Serial—Dual-port serial PIM • 2x T1—Dual-port T1 PIM • 2x E1—Dual-port E1 PIM • 2x CT1E1—Dual-port channelized T1/E1 PIM • 1x T3—T3 PIM (one port) • 1x E3—E3 PIM (one port) • 4x BRI S/T—4-port ISDN BRI S/T PIM • 4x BRI U—4-port ISDN BRI U PIM • 1x ADSL Annex A—ADSL 2/2+ Annex A PIM (one port, for POTS) • 1x ADSL Annex B—ADSL 2/2+ Annex B PIM (one port, for ISDN) • 2x SHDSL (ATM)—G SHDSL PIM (2-port two-wire module or 1-port four-wire module) • 1x TGM550—TGM550 Telephony Gateway Module (Avaya VoIP gateway module with one console port, two analog LINE ports, and two analog TRUNK ports) • 1x DS1 TIM510—TIM510 E1/T1 Telephony Interface Module (Avaya VoIP media module with one E1 or T1 trunk termination port and ISDN PRI backup) • 4x FXS, 4x FX0, TIM514—TIM514 Analog Telephony Interface Module (Avaya VoIP media module with four analog LINE ports and four analog TRUNK ports) • 4x BRI TIM521—TIM521 BRI Telephony Interface Module (Avaya VoIP media module with four ISDN BRI ports) • Crypto Accelerator Module—For enhanced performance of cryptographic algorithms used in IP Security (IPsec) services • MPC M 16x 10GE—16-port 10-Gigabit Module Port Concentrator that supports SFP+ optical transceivers. (Not on EX Series switches.)

Table 227: Fields in the Chassis View Details Page (*continued*)

Field	Description
	<ul style="list-style-type: none"> • For hosts, the Routing Engine type. • For small form-factor pluggable transceiver (SFP) modules, the type of fiber: LX, SX, LH, or T. • LCD description for EX Series switches (except EX2200 switches). • MPC2—1-port MPC2 that supports two separate slots for MICs. • MPC3E—1-port MPC3E that supports two separate slots for MICs (MIC-3D-1X100GE-CFP and MIC-3D-20GE-SFP) on MX960, MX480, and MX240 routers. The MPC3E maps one MIC to one PIC (1 MIC, 1 PIC), which differs from the mapping of legacy MPCs. • 100GBASE-LR4, pluggable CFP optics • Supports the Enhanced MX Switch Control Board with fabric redundancy and existing SCBs without fabric redundancy. • Interoperates with existing MX Series line cards, including Flexible Port Concentrators (FPC), Dense Port Concentrators (DPCs), and Modular Port Concentrators (MPCs). • MPC4E—Fixed configuration MPC4E that is available in two flavors: MPC4E-3D-32XGE-SFPP and MPC4E-3D-2CGE-8XGE on MX2020, MX960, MX480, and MX240 routers. • LCD description for MX Series routers

Click the **Apply Configlet** button (pencil icon displayed beside the button) and use the links shown on the components in Chassis View to select the context and apply configlets.

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[About Chassis View | 1383](#)

Configuring and Managing OTN Port Details of MX Series and PTX Series Routers for Easy Administration

Instead of using Junos OS CLI statements and operational commands to configure the OTN port settings and view the configured parameters, you can view an image of the OTN port using Connectivity Services Director to obtain an intuitive and high-level understanding of the settings and alarms. This view enables you to modify the OTN port settings to suit your network deployment needs in a simplified and optimal manner. Because the important OTN port settings can be configured alongside the visual representation of the entire chassis that is displayed, this method of managing the OTN port settings provides a consolidated and cohesive interface for easy administration of the network.

You can perform the following tasks in this dialog box:

- View the optical interface specifications that are currently applied on the device, such as wavelength and power
- Modify the existing parameters of the optical port to suit your network needs or resolve any alarms caused by certain interface settings

To configure the full C-band International Telecommunication Union (ITU)-Grid tunable optics for 10-Gigabit Ethernet or 100-Gigabit Ethernet dense wavelength-division multiplexing (DWDM) interfaces:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device and associated hardware components is displayed on the right pane.

5. In the image of the device, select an OTN port or interface—for example, a 100-Gigabit Ethernet OTN PIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the Optical Port Section pane is expanded and displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The configuration settings that pertain to the optical interface are displayed.

7. In the Port State section, do the following:

- a. The OperStatus field displays the operational status of the optical interface. Possible values are **Fault** or **Normal**.
- b. From the AdminState list, specify the administrative status of the interface as enabled or disabled, and click **Update** at the top of the dialog box to save the changes. Possible values are:
 - **IS**—In-service with masked alarms disabled
 - **IS-MA**—In-service with masked alarms enabled
 - **OOS**—Out-of-service with masked alarms disabled
 - **OOS-MA**—Out-of-service with masked alarms enabled
- c. The Status field displays any of the following values:
 - **LOS** (loss of signal)
 - **LOF** (loss of frame)
 - **LOM** (loss of multiframe)
 - **SSF** (server signal failure)
 - **TSF** (trail signal fail)

8. In the Loopbacks section, do the following:

- a. From the Line Loopback list, specify whether line-loopback needs to be enabled or disabled, and click **Update** at the top of the dialog box to save the changes. When configured in line loopback mode, the router never receives data from the network. A line loopback places an interface in external loopback state.

Instead of transmitting the signal toward the far-end device, the line loopback sends the signal back to the originating router. If the originating router receives back its own data link layer packets, you have verified that the problem is beyond the originating router. Next, configure a line loopback farther away from the local router. If this originating router does not receive its own data link layer packets, you can assume the problem is on one of the segments between the local router and the remote router's interface card. In this case, the next troubleshooting step is to configure a line loopback closer to the local router to find the source of the problem.

- b. From the Local Loopback list, specify whether local-loopback needs to be enabled or disabled, and click **Update** at the top of the dialog box to save the changes. When you create a local loopback, you create an internal loop on the interface being tested. A local loopback loops the traffic internally on that PIC. A local loopback tests the interconnection of the PIC but does not test the transmit and receive ports. A local loopback enables you to configure a loop without physically connecting the transmit port to the receive port.

Local loopback is useful for troubleshooting physical PIC errors. Configuring local loopback on an interface allows transmission of packets to the channel service unit (CSU) and then to the circuit toward the far-end device. The interface receives its own transmission, which includes data and timing information, on the local router's PIC. The data received from the CSU is ignored

9. In the Config section, do the following:

- a. From the Laser Enable field, specify whether the laser on the OTN interface must be enabled or disabled, and click **Update** at the top of the dialog box to save the changes.
- b. The laser is disabled by default for all OTN interfaces. The Modulation field displays the type of modulation as Dual polarization quadrature phase shift keying (DP-QPSK) modulation.
- c. From the Wavelength list, select the wavelength value, which can be one of the following, and click **Update** at the top of the dialog box to save the changes. All values are displayed. However, if you configure a value that is not supported by the device, an error message is displayed and the device is not tuned to the specified wavelength.
 - **1528.38**—1528.38 nanometers (nm), corresponds to a 50-GHz grid
 - **1528.77**—1528.77 nm, corresponds to 50-GHz and 100-GHz grids
 - **1529.16**—1529.16 nm, corresponds to a 50-GHz grid
 - **1529.55**—1529.55 nm, corresponds to 50-GHz and 100-GHz grids
 - **1529.94**—1529.94 nm, corresponds to a 50-GHz grid
 - **1530.33**—1530.33 nm, corresponds to 50-GHz and 100-GHz grids
 - **1530.72**—1530.72 nm, corresponds to a 50-GHz grid
 - **1531.12**—1531.12 nm, corresponds to 50-GHz and 100-GHz grids
 - **1531.51**—1531.51 nm, corresponds to a 50-GHz grid
 - **1531.90**—1531.90 nm, corresponds to 50-GHz and 100-GHz grids
 - **1532.29**—1532.29 nm, corresponds to a 50-GHz grid
 - **1532.68**—1532.68 nm, corresponds to 50-GHz and 100-GHz grids
 - **1533.07**—1533.07 nm, corresponds to a 50-GHz grid
 - **1533.47**—1533.47 nm, corresponds to 50-GHz and 100-GHz grids
 - **1533.86**—1533.86 nm, corresponds to a 50-GHz grid
 - **1534.25**—1534.25 nm, corresponds to 50-GHz and 100-GHz grids
 - **1534.64**—1534.64 nm, corresponds to a 50-GHz grid
 - **1535.04**—1535.04 nm, corresponds to 50-GHz and 100-GHz grids
 - **1535.43**—1535.43 nm, corresponds to a 50-GHz grid
 - **1535.82**—1535.82 nm, corresponds to 50-GHz and 100-GHz grids

- **1536.22**–1536.22 nm, corresponds to a 50-GHz grid
- **1536.61**–1536.61 nm, corresponds to 50-GHz and 100-GHz grids
- **1537.00**–1537.00 nm, corresponds to a 50-GHz grid
- **1537.40**–1537.40 nm, corresponds to 50-GHz and 100-GHz grids
- **1537.79**–1537.79 nm, corresponds to a 50-GHz grid
- **1538.19**–1538.19 nm, corresponds to 50-GHz and 100-GHz grids
- **1538.58**–1538.58 nm, corresponds to a 50-GHz grid
- **1538.98**–1538.98 nm, corresponds to 50-GHz and 100-GHz grids
- **1539.37**–1539.37 nm, corresponds to a 50-GHz grid
- **1539.77**–1539.77 nm, corresponds to 50-GHz and 100-GHz grids
- **1540.16**–1540.16 nm, corresponds to a 50-GHz grid
- **1540.56**–1540.56 nm, corresponds to 50-GHz and 100-GHz grids
- **1540.95**–1540.95 nm, corresponds to a 50-GHz grid
- **1541.35**–1541.35 nm, corresponds to 50-GHz and 100-GHz grids
- **1541.75**–1541.75 nm, corresponds to a 50-GHz grid
- **1542.14**–1542.14 nm, corresponds to 50-GHz and 100-GHz grids
- **1542.54**–1542.54 nm, corresponds to a 50-GHz grid
- **1542.94**–1542.94 nm, corresponds to 50-GHz and 100-GHz grids
- **1543.33**–1543.33 nm, corresponds to a 50-GHz grid
- **1543.73**–1543.73 nm, corresponds to 50-GHz and 100-GHz grids
- **1544.13**–1544.13 nm, corresponds to a 50-GHz grid
- **1544.53**–1544.53 nm, corresponds to 50-GHz and 100-GHz grids
- **1544.92**–1544.92 nm, corresponds to a 50-GHz grid
- **1545.32**–1545.32 nm, corresponds to 50-GHz and 100-GHz grids
- **1545.72**–1545.72 nm, corresponds to a 50-GHz grid
- **1546.12**–1546.12 nm, corresponds to 50-GHz and 100-GHz grids
- **1546.52**–1546.52 nm, corresponds to a 50-GHz grid
- **1546.92**–1546.92 nm, corresponds to 50-GHz and 100-GHz grids
- **1547.32**–1547.32 nm, corresponds to a 50-GHz grid
- **1547.72**–1547.72 nm, corresponds to 50-GHz and 100-GHz grids
- **1548.11**–1548.11 nm, corresponds to a 50-GHz grid

- **1548.51**–1548.51 nm, corresponds to 50-GHz and 100-GHz grids
- **1548.91**–1548.91 nm, corresponds to a 50-GHz grid
- **1549.32**–1549.32 nm, corresponds to 50-GHz and 100-GHz grids
- **1549.72**–1549.72 nm, corresponds to a 50-GHz grid
- **1550.12**–1550.12 nm, corresponds to 50-GHz and 100-GHz grids
- **1550.52**–1550.52 nm, corresponds to a 50-GHz grid
- **1550.92**–1550.92 nm, corresponds to 50-GHz and 100-GHz grids
- **1551.32**–1551.32 nm, corresponds to a 50-GHz grid
- **1551.72**–1551.72 nm, corresponds to 50-GHz and 100-GHz grids
- **1552.12**–1552.12 nm, corresponds to a 50-GHz grid
- **1552.52**–1552.52 nm, corresponds to 50-GHz and 100-GHz grids
- **1552.93**–1552.93 nm, corresponds to a 50-GHz grid
- **1553.33**–1554.33 nm, corresponds to 50-GHz and 100-GHz grids
- **1553.73**–1554.73 nm, corresponds to a 50-GHz grid
- **1554.13**–1554.13 nm, corresponds to 50-GHz and 100-GHz grids
- **1554.54**–1554.54 nm, corresponds to a 50-GHz grid
- **1554.94**–1554.94 nm, corresponds to 50-GHz and 100-GHz grids
- **1555.34**–1555.34 nm, corresponds to a 50-GHz grid
- **1555.75**–1555.75 nm, corresponds to 50-GHz and 100-GHz grids
- **1556.15**–1556.15 nm, corresponds to a 50-GHz grid
- **1556.55**–1556.55 nm, corresponds to 50-GHz and 100-GHz grids
- **1556.96**–1556.96 nm, corresponds to a 50-GHz grid
- **1557.36**–1557.36 nm, corresponds to 50-GHz and 100-GHz grids
- **1557.77**–1557.77 nm, corresponds to a 50-GHz grid
- **1558.17**–1558.17 nm, corresponds to 50-GHz and 100-GHz grids
- **1558.58**–1558.58 nm, corresponds to a 50-GHz grid
- **1558.98**–1558.98 nm, corresponds to 50-GHz and 100-GHz grids
- **1559.39**–1559.39 nm, corresponds to a 50-GHz grid
- **1559.79**–1559.79 nm, corresponds to 50-GHz and 100-GHz grids
- **1560.20**–1560.20 nm, corresponds to a 50-GHz grid
- **1560.61**–1560.61 nm, corresponds to 50-GHz and 100-GHz grids

- **1561.01**—1561.01 nm, corresponds to a 50-GHz grid
- **1561.42**—1561.42 nm, corresponds to 50-GHz and 100-GHz grids
- **1561.83**—1561.83 nm, corresponds to a 50-GHz grid
- **1562.23**—1562.23 nm, corresponds to 50-GHz and 100-GHz grids
- **1562.64**—1562.64 nm, corresponds to a 50-GHz grid
- **1563.05**—1563.05 nm, corresponds to 50-GHz and 100-GHz grids
- **1563.45**—1563.45 nm, corresponds to a 50-GHz grid
- **1563.86**—1563.86 nm, corresponds to 50-GHz and 100-GHz grids
- **1564.27**—1564.27 nm, corresponds to a 50-GHz grid
- **1564.68**—1564.68 nm, corresponds to 50-GHz and 100-GHz grids
- **1565.09**—1565.09 nm, corresponds to a 50-GHz grid
- **1565.50**—1565.50 nm, corresponds to 50-GHz and 100-GHz grids
- **1565.90**—1565.90 nm, corresponds to a 50-GHz grid
- **1566.31**—1566.31 nm, corresponds to 50-GHz and 100-GHz grids
- **1566.72**—1566.72 nm, corresponds to a 50-GHz grid
- **1567.13**—1567.13 nm, corresponds to 50-GHz and 100-GHz grids
- **1567.54**—1567.54 nm, corresponds to a 50-GHz grid
- **1567.95**—1567.95 nm, corresponds to 50-GHz and 100-GHz grids
- **1568.36**—1568.36 nm, corresponds to a 50-GHz grid
- **1568.77**—1568.77 nm, corresponds to 50-GHz and 100-GHz grids

[Table 210 on page 1501](#) shows configurable wavelengths and the corresponding frequency for each configurable wavelength.

Table 228: Wavelength-to-Frequency Conversion Matrix

Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)
1528.38	196.15	1542.14	194.40	1556.15	192.65
1528.77	196.10	1542.54	194.35	1556.55	192.60
1529.16	196.05	1542.94	194.30	1556.96	192.55
1529.55	196.00	1543.33	194.25	1557.36	192.50

Table 228: Wavelength-to-Frequency Conversion Matrix (continued)

Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)
1529.94	195.95	1543.73	194.20	1557.77	192.45
1530.33	195.90	1544.13	194.15	1558.17	192.40
1530.72	195.85	1544.53	194.10	1558.58	192.35
1531.12	195.80	1544.92	194.05	1558.98	192.30
1531.51	195.75	1545.32	194.00	1559.39	192.25
1531.90	195.70	1545.72	193.95	1559.79	192.20
1532.29	195.65	1546.12	193.90	1560.20	192.15
1532.68	195.60	1546.52	193.85	1560.61	192.10
1533.07	195.55	1546.92	193.80	1561.01	192.05
1533.47	195.50	1547.32	193.75	1561.42	192.00
1533.86	195.45	1547.72	193.70	1561.83	191.95
1534.25	195.40	1548.11	193.65	1562.23	191.90
1534.64	195.35	1548.51	193.60	1562.64	191.85
1535.04	195.30	1548.91	193.55	1563.05	191.80
1535.43	195.25	1549.32	193.50	1563.45	191.75
1535.82	195.20	1549.72	193.45	1563.86	191.70
1536.22	195.15	1550.12	193.40	1564.27	191.65
1536.61	195.10	1550.52	193.35	1564.68	191.60
1537.00	195.05	1550.92	193.30	1565.09	191.55
1537.40	195.00	1551.32	193.25	1565.50	191.50

Table 228: Wavelength-to-Frequency Conversion Matrix (continued)

Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)	Wavelength (nm)	Frequency (THz)
1537.79	194.95	1551.72	193.20	1565.90	191.45
1538.19	194.90	1552.12	193.15	1566.31	191.40
1538.58	194.85	1552.52	193.10	1566.72	191.35
1538.98	194.80	1552.93	193.05	1567.13	191.30
1539.37	194.75	1553.33	193.00	1567.54	191.25
1539.77	194.70	1553.73	192.95	1567.95	191.20
1540.16	194.65	1554.13	192.90	1568.36	191.15
1540.56	194.60	1554.54	192.85	1568.77	191.10
1540.95	194.55	1554.94	192.80		
1541.35	194.50	1555.34	192.75		
1541.75	194.45	1555.75	192.70		

- d. The Tx Power field displays the transmit laser output power (dBm). If you did not specify a value, the default transmit laser output power is –2 dBm.
- e. The Rx Power field displays the laser received optical power, in mW and dBm.

10. From the PM collection list, specify whether the retrieval and computation of performance management statistics by polling the device must be enabled or not, and click **Update** to save the changes. If you do not enable the collection of performance monitoring counters and values, you might not be able to measure the performance and the operational status of the services running in your network.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

Configuring and Managing OTU Details of MX Series and PTX Series Routers for Simplified Management | 1571

Configuring and Managing OTU Details of MX Series and PTX Series Routers for Simplified Management

Instead of using Junos OS CLI statements and operational commands to configure OTU settings and view the configured parameters, you can view an image of the OTN port using Connectivity Services Director to obtain an intuitive and high-level understanding of the settings and alarms. This view enables you to modify the OTU settings to suit your network deployment needs in a simplified and optimal manner. Because the important OTU settings can be configured alongside the visual representation of the entire chassis that is displayed, this method of managing the OTU settings provides a consolidated and cohesive interface for easy administration of the network.

You can perform the following tasks in the OTU Section pane:

- View the optical channel transport unit (OTU) specifications that are currently applied on the device, such as wavelength and power
- Modify the existing parameters of the optical port to suit your network needs or resolve any alarms caused by certain interface settings

To configure the OTN parameters for 10-Gigabit Ethernet or 100-Gigabit Ethernet dense wavelength-division multiplexing (DWDM) interfaces:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an OTN port or interface—for example, a 100-Gigabit Ethernet OTN PIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Section panes are displayed in a collapsed form.

6. Click the **OTU Section** header at the bottom of the dialog box.

The OTU Section pane is expanded and displayed.

7. Click the **Status/Config** tab at the bottom of the dialog box.

The configuration settings that pertain to the OTU are displayed.

8. In the Status section, the OTU Status field is displayed. The OTU Status field displays the status of the OTU. Possible values are:

- **OTU-FEC-DEG** (forward error correction degraded)
- **OTU-FEC-EXE** (excessive errors, FEC_FAIL from the transponder)
- **OTU-AIS** (alarm indication signal or all ones signal)
- **OTU-BDI** (backward defect identification)
- **OTU-IAE** (incoming alignment error)
- **OTU-BIAE** (backward incoming alignment error)
- **OTU-TTIM** (destination access point identifier [DAPI], source access point identifier [SAPI], or both mismatch from expected to received)
- **OTU-DEG** (OTU degraded)

9. In the Config section, do the following:

- The Rate field displays the line rate or speed of the OTN signals. One of the following values is displayed, if you have previously configured the OTN mode:
 - **fixed-stuff-bytes**—Fixed stuff bytes 11.0957 Gbps.
 - **no-fixed-stuff-bytes**—No fixed stuff bytes 11.0491 Gbps.
 - **pass-through**—Enable OTN passthrough mode.
 - **no-pass-through**—Do not enable OTN passthrough mode

Select a different line rate if needed from the Rate list.

- The FEC Mode field displays the forward error correction (FEC) mode. One of the following values is displayed, if you have previously configured the FEC mode:

- **EFEC**—G.975.1 I.4 enhanced forward error correction (EFEC) is configured to detect and correct bit errors.
- **GFEC**—G.709 generic forward error correction (GFEC) mode is configured to detect and correct bit errors.
- **GFEC-SDFEC**—GFEC and soft-decision forward error correction (SD-FEC) modes are configured to detect and correct bit errors.
- **NONE**—FEC mode is not configured.
- **UFEC**—Ultra Forward Error Correction (UFEC) mode is configured to detect and correct bit errors.

Select a different FEC mode if needed from the FEC Mode list.

- From the Backward FRR list, specify whether you want to enable or disable preemptive fast reroute (FRR) insertion. By default, FRR ODU backward FRR insertion is disabled.
- From the Signal Degrade Monitor list, specify whether you want to enable or disable preemptive fast reroute (FRR) signal degrade monitoring. By default, FRR signal degrade monitoring is disabled. If you do not configure the signal-degrade parameter, the default threshold values are used.
- From the Signal Degrade Interval selector, use the up and down arrows to specify the time interval in milliseconds (ms). This is the interval for which the BER must stay above the signal degradation threshold—as configured in the Ber Threshold Signal Degrade field—for the alarm to be raised. After an alarm is raised, if the BER returns below the clear threshold—as configured in the Ber Threshold Clear field—for the specified interval, the alarm is cleared.

The default value is 100 ms. The range is from 1 ms through 100 ms.

NOTE: For the P1-PTX-2-100G-WDM PIC, the BER must stay above the signal degradation threshold for ten consecutive intervals for the alarm to be raised and the BER must stay below the clear threshold for ten consecutive intervals for the alarm to be cleared. For example, if the interval is configured as 10 ms, then the BER must stay above the signal degradation threshold for 100 ms (10 ms * 10 intervals) for the alarm to be raised, or below the clear threshold for 100 ms for the alarm to be cleared.

NOTE: For P1-PTX-24-10G-W-SFPP PIC and P2-100GE-OTN PIC, when the router cannot configure BER with the given interval, it selects an optimum interval that is supported for the given BER configuration. If the router is still not able to support the configuration (for example, with a wider gap between the degrade set and clear values), the default values are used and a log is generated.

For the P2-10G-40G-QSFPP PIC, the time interval is supported in multiples of 100 ms. For example, when you configure the interval as 10 ms, then it is rounded off to the nearest multiple of 100 ms.

Configuring a high BER threshold for signal degradation and a long interval might cause the internal counter register to be saturated. Such a configuration is ignored by the router, and the default values are used instead. A system log message is logged for this error.

- In the Ber Threshold Clear field, specify the bit error rate (BER) threshold to clear the interface alarm for signal degradation. You must specify the BER threshold for signal degradation in scientific notation. Both the mantissa and exponent are configurable. Enter the value in the format $x\text{E}-n$, where x is the mantissa and n is the exponent. For example, $4.5\text{E}-3$.

The mantissa must be a decimal number. There is no limit on the number of digits before or after the decimal point. The exponent must be an integer from 0 through 9.

You can configure the BER clear threshold to customize the BER that will clear an interface alarm when signal degrade monitoring is enabled.

[Table 229 on page 1574](#) shows the default values for pre-FEC BER and ODU BER signal degrade threshold values for different PICs. If the BER signal degrade threshold is not configured, the default value is used.

Table 229: Default Clear Threshold Values

PIC	Default Pre-FEC BER Clear Threshold Value	Default ODU BER Clear Threshold Value
P1-PTX-2-100G-WDM	$3.0\text{E}-3$	Not supported
P2-100GE-OTN	$3.0\text{E}-3$	$1.0\text{E}-9$
P1-PTX-24-10G-W-SFPP	$3.0\text{E}-3$	Not supported

- In the Ber Threshold Degrade field, specify the BER threshold is used to raise an interface alarm for signal degradation. You can configure the BER signal degrade threshold to customize the BER that will raise an interface alarm when signal degrade monitoring is enabled. You must specify the BER threshold for signal degradation in scientific notation. Both the mantissa and exponent are configurable.

Enter the value in the format $x\text{E}-n$, where x is the mantissa and n is the exponent. For example, $4.5\text{E}-3$.

The mantissa must be a decimal number. There is no limit on the number of digits before or after the decimal point. The exponent must be an integer from 0 through 9.

NOTE: Configuring a high BER threshold for signal degradation and a long interval might cause the internal bit error counter register to get saturated. For example, for the P1-PTX-2-100G-WDM PIC, the internal bit error counter gets saturated when the error count reaches $2\text{E}+29$. Therefore, the value of `ber-threshold-signal-degrade * line rate / interval` must be less than $2\text{E}+29$ to avoid saturation. Assuming a fixed PIC line rate of $1.27\text{E}+11$ bits per second and an interval of 1000 ms, the **ber-threshold-signal-degrade** value must be less than $4.22\text{E}-3$.

If the value of the `ber-threshold-signal-degrade * line rate / interval` exceeds the saturation limit, the configuration is ignored by the router, and the default values are used instead. A system log message is logged for this error.

Table 230 on page 1575 shows the default values for pre-FEC BER and ODU BER signal degrade threshold values for different PICs. If the BER signal degrade threshold is not configured, the default value is used.

Table 230: Default Signal Degrade Threshold Values

PIC	Default Pre-FEC BER Signal Degrade Threshold Value	Default ODU BER Signal Degrade Threshold Value
P1-PTX-2-100G-WDM	$7.5\text{E}-3$	Not supported
P2-100GE-OTN	$7.5\text{E}-3$	$1.0\text{E}-6$
P1-PTX-24-10G-W-SFPP	$7.5\text{E}-3$	Not supported

10. Depending on the configured trace identifier (TTI), any of the following TTI sections are displayed in the OTU Section pane:

- **odu-dapi**—ODU Destination Access Point Identifier.
- **odu-expected-receive-dapi**—ODU Expected Receive Destination Access Point Identifier.
- **odu-expected-receive-sapi**—ODU Expected Receive Source Access Point Identifier.
- **odu-sapi**—ODU Source Access Point Identifier.
- **out-dapi**—OTU Destination Access Point Identifier.
- **out-expected-receive-dapi**—OTU Expected Receive Destination Access Point Identifier.

- **out-expected-receive-sapi**—OTU Expected Receive Source Access Point Identifier.
- **out-sapi**—OTU Source Access Point Identifier

11. In the TTI-DAPI section, do the following:

- The Tx Trace and Rx Trace fields display the transmitted and received path trace values. A path trace identifier is a text string that identifies the circuit. The text string that identifies the circuit. SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the routing device at the other end of the fiber. The transmitted path trace value is the message that this routing device transmits.
- In the Tx Trace config field, specify the propagated path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.
- In the Rx Trace Config field, specify the received path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.

12. In the TTI-DAPI section, do the following:

- The Tx Trace and Rx Trace fields display the transmitted and received path trace values. A path trace identifier is a text string that identifies the circuit. The text string that identifies the circuit. SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the routing device at the other end of the fiber. The transmitted path trace value is the message that this routing device transmits.
- In the Tx Trace config field, specify the propagated path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.
- In the Rx Trace Config field, specify the received path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.

13. Click **Update** at the top of the dialog box to save the modified OTU settings.

The settings are saved in the Connectivity Services Director database.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

[Configuring and Managing OTN Port Details of MX Series and PTX Series Routers for Easy Administration | 1563](#)

[Configuring and Managing ODU Details of MX Series and PTX Series Routers for Simplified Management | 1577](#)

[Configuring and Managing Optical PIC Details for Effective Provisioning | 1581](#)

Configuring and Managing ODU Details of MX Series and PTX Series Routers for Simplified Management

Instead of using Junos OS CLI statements and operational commands to configure ODU settings and view the configured parameters, you can view an image of the OTN port using Connectivity Services Director to obtain an intuitive and high-level understanding of the settings and alarms. This view enables you to modify the ODU settings to suit your network deployment needs in a simplified and optimal manner. Because the important ODU settings can be configured alongside the visual representation of the entire chassis that is displayed, this method of managing the ODU settings provides a consolidated and cohesive interface for easy administration of the network.

You can perform the following tasks in the ODU Path pane:

- View the optical channel data unit (ODU) specifications that are currently applied on the device, such as wavelength and power
- Modify the existing parameters of the optical port to suit your network needs or resolve any alarms caused by certain interface settings

To configure the ODU parameters for 10-Gigabit Ethernet or 100-Gigabit Ethernet dense wavelength-division multiplexing (DWDM) interfaces:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an OTN port or interface—for example, a 100-Gigabit Ethernet OTN PIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Path panes are displayed in a collapsed form.

6. Click the **ODU Path** header at the bottom of the dialog box.

The ODU Path pane is expanded and displayed.

7. Click the **Status/Config** tab at the bottom of the dialog box.

The configuration settings that pertain to the ODU are displayed.

8. In the Status section, the ODU Status field is displayed.

The ODU Status field displays the status of the ODU (optical channel data unit). Possible values are:

- **CSF** (client signal failure)
- **ODU-DM-TIMEOUT** (DM timeout)
- **ODU-LCK** (ODU lock triggers for PM [path monitoring] and TCM levels 1 through 6)
- **ODU-AIS** (alarm indication signal or all ones signal)
- **ODU-OCI** (open connection error)
- **ODU-BDI** (backward defect indication)
- **ODU-DEG** (ODU degraded)
- **ODU-IAE** (incoming alignment error)
- **ODU-DAPI-TTIM** (DAPI or DAPI/SAPI mismatch from expected to receive)
- **ODU-SAPI-TTIM** (SAPI or DAPI/SAPI mismatch from expected to receive)
- **ODU-BEI** (backward error indication)
- **ODU-BEI-ERR** (backward error indication error)
- **ODU-BIP8-ERR** (bit interleaved parity 8 error)
- **ODU-SSF** (server signal fail)
- **ODU-TSF** (trail signal fail)
- **ODU-SD** (signal degrade)

9. In the Config section, do the following:

- From the ODU Backward FRR list, specify whether you want to enable or disable backward fast reroute (FRR) insertion. You can insert the ODU status into the transmitted OTN frames and monitor the received OTN frames for the ODU BER status. By default, FRR ODU backward FRR insertion is disabled.

- From the ODU Signal Degrade Monitor list, specify whether you want to enable or disable monitoring of signal degradation of ODU BER in the received OTN frames. By default, FRR signal degrade monitoring disabled.

10. Depending on the configured trace identifier (TTI), any of the following TTI sections are displayed in the OTU Section pane:

- odu-dapi—ODU Destination Access Point Identifier.
- odu-expected-receive-dapi—ODU Expected Receive Destination Access Point Identifier.
- odu-expected-receive-sapi—ODU Expected Receive Source Access Point Identifier.
- odu-sapi—ODU Source Access Point Identifier.
- out-dapi—OTU Destination Access Point Identifier.
- out-expected-receive-dapi—OTU Expected Receive Destination Access Point Identifier.
- out-expected-receive-sapi—OTU Expected Receive Source Access Point Identifier.
- out-sapi—OTU Source Access Point Identifier

11. In the TTI-DAPI section, do the following:

- The Tx Trace and Rx Trace fields display the transmitted and received path trace values. A path trace identifier is a text string that identifies the circuit. The text string that identifies the circuit. SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the routing device at the other end of the fiber. The transmitted path trace value is the message that this routing device transmits.
- In the Tx Trace config field, specify the propagated path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.
- In the Rx Trace Config field, specify the received path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.

12. In the TTI-DAPI section, do the following:

- The Tx Trace and Rx Trace fields display the transmitted and received path trace values. A path trace identifier is a text string that identifies the circuit. The text string that identifies the circuit. SONET/SDH interfaces allow path trace bytes to be sent inband across the SONET/SDH link. Juniper Networks and other router manufacturers use these bytes to help diagnose misconfigurations and network errors by setting the transmitted path trace message so that it contains the system hostname and name of the physical interface. The received path trace value is the message received from the routing device at the other end of the fiber. The transmitted path trace value is the message that this routing device transmits.

- In the Tx Trace config field, specify the propagated path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.
- In the Rx Trace Config field, specify the received path trace identifier. A common convention is to use the circuit identifier as the path trace identifier.

13. Click **Update** at the top of the dialog box to save the modified ODU settings.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

You can collapse the contents of a particular section by clicking the minus sign (-) beside the header and expand the contents of a section by clicking the plus sign (+) beside the header.

RELATED DOCUMENTATION

[Configuring and Managing OTN Port Details of MX Series and PTX Series Routers for Easy Administration | 1563](#)

[Configuring and Managing OTU Details of MX Series and PTX Series Routers for Simplified Management | 1571](#)

[Configuring and Managing Optical PIC Details for Effective Provisioning | 1581](#)

Configuring and Managing Optical PIC Details for Effective Provisioning

Instead of using Junos OS CLI statements and operational commands to configure OTN PIC settings and view the configured parameters, you can view an image of the OTN PIC using Connectivity Services Director to obtain an intuitive and high-level understanding of the settings and alarms. This view enables you to modify the OTN PIC settings to suit your network deployment needs in a simplified and optimal manner. Because the important OTN PIC settings can be configured alongside the visual representation of the entire chassis that is displayed, this method of managing the OTN PIC settings provides a consolidated and cohesive interface for easy administration of the network.

You can perform the following tasks in this dialog box:

- View the optical interface specifications that are currently applied on the device, such as the PIC state and PIC type
- Modify the existing parameters of the optical port to suit your network needs or resolve any alarms caused by certain interface settings

To configure the full C-band International Telecommunication Union (ITU)-Grid tunable optics for 10-Gigabit Ethernet or 100-Gigabit Ethernet dense wavelength-division multiplexing (DWDM) OTN PICs:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an OTN PIC, such as a 2-port 100-Gigabit Ethernet OTN PIC or a 100-Gigabit Ethernet PIC installed in a PTX Series router.

The Component Info dialog box is displayed on the right pane with the PIC specifications.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The configuration settings that pertain to the optical interface are displayed in the PIC Status/Config dialog box.

7. In the PIC Details section, do the following:
 - a. From the PIC State list, select **On Line** to turn on the PIC so that the PIC is running or **Off Line** to turn off the PIC so that the PIC is powered down. State is displayed only when a PIC resides in the slot.
 - b. From the PIC Type list, select the type of PIC, such as 2X100GE CFP2 OTN, 24X10GE SFPP OTN, 2x100G DWDM OTN, or 2x100GE CFP.
 - c. In the PIC version field, the PIC hardware version is displayed.
 - d. In the Uptime field, the number of days, hours, minutes, and seconds for which the PIC has been online is displayed.
8. In the Transport State section, the following fields are displayed:
 - Admin State—The administrative state of the port—In Service or Out of Service.
 - Operational State—The operational status of the port—link up (UP) or link down (DOWN).
9. Click **Update** to save the configured settings. Alternatively, click **Cancel** to discard the modified settings.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

[Configuring and Managing OTN Port Details of MX Series and PTX Series Routers for Easy Administration | 1563](#)

[Configuring and Managing OTU Details of MX Series and PTX Series Routers for Simplified Management | 1571](#)

[Configuring and Managing ODU Details of MX Series and PTX Series Routers for Simplified Management | 1577](#)

Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance

By monitoring the performance of links, you ensure that an end-to-end Ethernet service is always available over any path for a single link or multiple links spanning networks composed of multiple LANs. Link performance metrics enable operators to offer binding service-level agreements (SLAs) and generate new revenues from rate- and performance-guaranteed service packages that are customized to meet specific needs of their customers. To monitor link performance, you need to configure threshold-crossing alarms (TCAs) for optical transport network (OTN) ports.

TCAs are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so until the end of the 15-minute interval and the 24-hour interval for parameters such as optical channel transport unit (OTU) and optical data unit (ODU). A near-end measurement is associated with ingress data frames and a far-end measurement is associated with egress data frames.

You can configure TCAs for both the minimum and maximum values for gauges and the maximum values for counters. A gauge represents a non-negative integer, which may increase or decrease, but never exceeds a maximum value. A gauge has its maximum value whenever the information being modeled is greater than or equal to the maximum value. If the TCA parameter subsequently goes below the maximum value, the gauge also decreases. A counter represents a non-negative integer that monotonically increases until it reaches a maximum value of $2^{32}-1$.

The timely detection of TCAs is essential to proactively manage an interface. TCAs are not an indication of a fault, but rather an indication that the entity may be close to a fault. You can enable the TCA that you want monitor. You can keep the default threshold settings or change the settings.

To configure TCAs for OTN port interface parameters:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the OTN interface settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an OTN interface or port—for example, a 100-Gigabit Ethernet OTN MIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Section panes are displayed in a collapsed form.

6. Click the **Optical Port Section** header at the bottom of the dialog box.

The Optical Port Section pane is expanded and displayed. This pane contains the Equipment, Status/Config, and Performance tabs.

7. Click the **Performance** tab at the bottom of the pane.

The Optics PMs dialog box is displayed with the performance monitoring gauges and counters that pertain to the selected OTN port. This dialog box contains the Perf Mon and TCA Config tabs.

8. Click the **TCA Config** tab to configure TCAs for the various attributes.

The dialog box is refreshed to display the performance monitoring parameters.

Inline editing enables you to modify previously defined settings easily and quickly. Embedded editing is also enabled, which causes the grids showing the devices and interfaces to become modifiable directly; you do not need to highlight, edit, and save the changes every time.

A gray triangle in the upper-right corner of a field denotes that the value of that field or attribute has been modified.

9. For the parameters under each performance monitoring category for which you want to modify the TCA value, click the value in the Threshold-15Min or Threshold-24Hr columns. You can also select or clear the check box in the Enable column to enable or disable the TCA value for the specified parameter, respectively.
10. Click **Update** to save the configured threshold settings. Alternatively, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | 1585](#)

[Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | 1587](#)

[Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | 1589](#)

[Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | 1595](#)

[Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | 1600](#)

Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance

By monitoring the performance of links, you ensure that an end-to-end Ethernet service is always available over any path for a single link or multiple links spanning networks composed of multiple LANs. Link performance metrics enable operators to offer binding service-level agreements (SLAs) and generate new revenues from rate- and performance-guaranteed service packages that are customized to meet specific needs of their customers. To monitor link performance, you need to configure threshold-crossing alarms (TCAs) for optical channel transport unit (OTU) and optical data unit (ODU) of optical transport network (OTN) ports.

TCAs are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so until the end of the 15-minute interval and the 24-hour interval for parameters such as OTU and ODU. A near-end measurement is associated with ingress data frames and a far-end measurement is associated with egress data frames.

You can configure TCAs for both the minimum and maximum values for gauges and the maximum values for counters. A gauge represents a non-negative integer, which may increase or decrease, but never exceeds a maximum value. A gauge has its maximum value whenever the information being modeled is greater than or equal to the maximum value. If the TCA parameter subsequently goes below the maximum value, the gauge also decreases. A counter represents a non-negative integer that monotonically increases until it reaches a maximum value of $2^{32}-1$.

The timely detection of TCAs is essential to proactively manage an interface. TCAs are not an indication of a fault, but rather an indication that the entity may be close to a fault. You can enable the TCA that you want monitor. You can keep the default threshold settings or change the settings.

To configure TCAs for OTU parameters:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the the image of the device, select an OTN interface or port—for example, a 100-Gigabit Ethernet optical transport network (OTN) MIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Section panes are displayed in a collapsed form.

6. Click the **OTU Section** header at the bottom of the dialog box.

The OTU Section pane is expanded and displayed. This pane contains the Equipment, Status/Config, and Performance tabs.

7. Click the **Performance** tab at the bottom of the pane.

The OTU PMs dialog box is displayed with the performance monitoring counters and metrics that pertain to the OTU. This dialog box contains the Perf Mon and TCA Config tabs. At the top-left corner of the PMs dialog box, the TCA Config tab (green right arrow enclosed in a square) is displayed.

8. Click the **TCA Config** tab to configure the TCAs for the different optical interface, OTU, or ODU attributes. The dialog box is refreshed to display the different performance monitoring parameters. These parameters can be edited inline.

Inline editing enables you to modify previously defined settings easily and quickly. Embedded editing is also enabled, which causes the grids showing the devices and interfaces to become modifiable directly; you do not need to highlight, edit, and save the changes every time.

A gray triangle in the upper-right corner of a field denotes that the value of that field or attribute has been modified.

9. For the parameters under each performance monitoring category for which you want to modify the TCA value, click the value in the Threshold-15Min or Threshold-24Hr columns to set the TCA value for the 15-minute interval or 24-hour interval. You can also select or clear the check box in the Enable column to enable or disable the TCA value for the specified parameter, respectively.
10. Click **Update** to save the configured threshold settings. Alternatively, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | 1583](#)

[Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | 1587](#)

[Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | 1589](#)

[Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | 1595](#)

[Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | 1600](#)

Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance

By monitoring the performance of links, you ensure that an end-to-end Ethernet service is always available over any path for a single link or multiple links spanning networks composed of multiple LANs. Link performance metrics enable operators to offer binding service-level agreements (SLAs) and generate new revenues from rate- and performance-guaranteed service packages that are customized to meet specific needs of their customers. To monitor link performance, you need to configure threshold-crossing alarms (TCAs) for optical channel transport unit (OTU) and optical data unit (ODU) of optical transport network (OTN) ports.

TCAs are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so until the end of the 15-minute interval and the 24-hour interval for parameters such as OTU and ODU. A near-end measurement is associated with ingress data frames and a far-end measurement is associated with egress data frames.

You can configure TCAs for both the minimum and maximum values for gauges and the maximum values for counters. A gauge represents a non-negative integer, which may increase or decrease, but never exceeds a maximum value. A gauge has its maximum value whenever the information being modeled is greater than or equal to the maximum value. If the TCA parameter subsequently goes below the maximum value, the gauge also decreases. A counter represents a non-negative integer that monotonically increases until it reaches a maximum value of $2^{32}-1$.

The timely detection of TCAs is essential to proactively manage an interface. TCAs are not an indication of a fault, but rather an indication that the entity may be close to a fault. You can enable the TCA that you want monitor. You can keep the default threshold settings or change the settings.

To configure TCAs for ODU parameters:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the the image of the device, select an OTN interface or port—for example, a 100-Gigabit Ethernet optical transport network (OTN) MIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Section panes are displayed in a collapsed form.

6. Click the **ODU Path** header at the bottom of the dialog box.

The ODU Path pane is expanded and displayed. This pane contains the Equipment, Status/Config, and Performance tabs.

7. Click the **Performance** tab at the bottom of the pane.

The ODU PMs dialog box is displayed with the performance monitoring counters and metrics that pertain to the ODU. This dialog box contains the Perf Mon and TCA Config tabs.

8. Click the **TCA Config** tab to configure the TCAs for the different optical interface, OTU, or ODU attributes. The dialog box is refreshed to display the different performance monitoring parameters. These parameters can be edited inline.

Inline editing enables you to modify previously defined settings easily and quickly. Embedded editing is enabled, which causes the grids showing the devices and interfaces to become modifiable directly; you do not need to highlight, edit, and save the changes every time.

A gray triangle in the upper-right corner of a field denotes that the value of that field or attribute has been modified.

9. For the parameters under each performance monitoring category for which you want to modify the TCA value, click the value in the Threshold-15Min or Threshold-24Hr columns to set the TCA value for the 15-minute interval or 24-hour interval. You can also select or clear the check box in the Enable column to enable or disable the TCA value for the specified parameter, respectively.
10. Click **Update** to save the configured threshold settings. Alternatively, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | 1583](#)

[Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | 1585](#)

[Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | 1589](#)

[Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | 1595](#)

[Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | 1600](#)

Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults

To analyze and resolve any faults associated with optical transport network (OTN) ports, it is essential to view the diagnostic data, warnings, and alarms for transport performance monitoring. The different types of parameters related to performance monitoring that are retrieved from the OTN ports enable you to ensure service availability and monitor the performance of individual services and the network.

The performance monitoring capability of Connectivity Services Director helps you identify problems with the equipment, pinpoint security attacks, and analyze trends and categories of errors. This capability uses charts and grids to provide important and cohesive information about system conditions, discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity. You can assess the performance of your network, not only at a point in time, but also over a period of time.

To view performance monitoring details of OTN interfaces:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an OTN interface or port—for example, a 100-Gigabit Ethernet optical transport network (OTN) MIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Section panes are displayed in a collapsed form.

6. Click the **Optical Port Section** header at the bottom of the dialog box.

The Optical Port Section pane is expanded and displayed. This pane contains the Equipment, Status/Config, and Performance tabs.

7. Click the **Performance** tab at the bottom of the pane.

This pane contains the Perf Mon and TCA Config tabs. The Perf Mon tab of the Optics PMs dialog box is displayed.

The following fields are displayed in the Perf Mon tab of the Optics PMs dialog box. The date and time at which the dialog box was last refreshed is shown.

- Carrier Frequency Offset (MHz)—Carrier frequency offset in megahertz (mHz), which denotes the difference between the carriers (frequency shift in the receive spectrum) between the expected Rx carrier frequency and the actual carrier frequency

CFO—Threshold values for carrier frequency offset

CFO-Min—Low threshold setting trigger when the carrier frequency offset falls below this minimum value

CFO-Avg—Average threshold setting trigger when the carrier frequency offset crosses this average value

CFO-Max—High threshold setting trigger when the carrier frequency offset rises above this maximum value

- Chromatic Dispersion—Lane or residual chromatic dispersion measured at the Rx transceiver port, which denotes the spreading of the signal in time resulting from the different speeds of light rays

CD—Threshold values for chromatic dispersion

CD-Min—Minimum value of the residual chromatic dispersion measured at the Rx transceiver port

CD-Avg—Average value of the residual chromatic dispersion measured at the Rx transceiver port

CD-Max—Maximum value of the residual chromatic dispersion measured at the Rx transceiver port

- Differential Group Delay—Lane differential group delay, which denotes the time difference between the fractions of a pulse that are transmitted in the two principal states of polarization of an optical signal. For distances greater than several kilometers, and assuming random (strong) polarization mode coupling, DGD in a fiber can be statistically modeled as having a Maxwellian distribution.

DGD—Threshold values for differential group delay

DGD-Min—Minimum value of the differential group delay below which a TC is triggered

DGD-Avg—Average value of the differential group delay at which TCA is triggered

DGD-Max—Maximum value of the differential group delay above which a TCA is triggered

- Module Temperature (°C)—Module temperature, which denotes the laser temperature in Celsius

MT—Threshold values for module temperature

MT-Min—High laser temperature in Celsius below which a TCA is sent

MT-Avg—Average laser temperature in Celsius at which a TCA is sent

MT-Max—Maximum laser temperature in Celsius above which a TCA is sent

- Optical Lane Q2 Factor—Quality (Q or Q2) factor value estimated at the Rx transceiver port

Lane Q2 factor—Threshold values for the quality factor

Lane Q2 factor-Min—Minimum value of the quality factor estimated at the Rx transceiver port below which a TCA is sent

Lane Q2 factor-Avg—Average value of the quality factor estimated at the Rx transceiver port at which a TCA is sent

Lane Q2 factor-Max—Maximum value of the quality factor estimated at the Rx transceiver port above which a TCA is sent

- Signal to Noise Ratio—Signal-to-noise ratio estimated at the Rx transceiver port

SNR—Threshold values for signal-to-noise ratio

SNR-Min—Minimum value of the signal-to-noise ratio estimated at the Rx transceiver port below which a TCA is sent

SNR-Avg—Average value of the signal-to-noise ratio estimated at the Rx transceiver port

SNR-Max—Maximum value of the signal-to-noise ratio estimated at the Rx transceiver port above which a TCA is sent

- Optical Tx Output Power—Transmitted laser optical output power in dBm

Tx-Pwr—Threshold values for transmitted laser output power

TxPwr-Min—Minimum value of the transmitted laser output power in dBm below which a TCA is sent

TxPwr-Avg—Average value of the transmitted laser output power in dBm at which a TCA is sent

TxPwr-Max—Maximum value of the transmitted laser output power above which a TCA is sent

- Optical Rx Input Power—Received laser optical input power in dBm

Rx-Pwr—Threshold values for received laser input power

RxPwr-Min—Minimum value of the received laser input power in dBm below which a TCA is sent

RxPwr-Avg—Average value of the received laser power in dBm at which a TCA is sent

RxPwr-Max—Maximum value of the received input power in dBm above which a TCA is sent

On the Perf Mon tab, for the TCA column, either a minus sign (–) is displayed that denotes that an alarm for threshold-exceed is not configured or a check mark is displayed and grayed out that indicates that the TCA for the particular attribute is configured.

8. In the 15 Mins column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the last 15 minutes. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 15-minute interval. By default, 96 records of 15-minute intervals are displayed.

A 15-Min *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

9. Click the **15 Mins *parameter name*** tab.

a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date and time along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.

The records are displayed in tabular format. A serial number of the count of entries, the day, month, and year at which the entry was collected, and the time at which the entry was collected are displayed. The timestamp is the UTC time in the database that is mapped to the local time zone of the client computer.

- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search.
- Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.

- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
 - Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
 - Click **Close** to close the 15-Min *parameter-name* tab.
10. In the 24-Hrs column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the previous day. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 24-hour interval. By default, records pertaining to the last 30 days are displayed when you view the performance monitoring counters for the 24-hour duration.

A 24 Hours *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

11. Click the **24 Hours parameter name** tab.

- a. Select one of the following options from the drop-down menu:
- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
 - Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.
 - Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
 - Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search. Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.

- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
 - Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
 - Click **Close** to close the 24 Hours *parameter-name* tab.
12. Click the **Clear PMs** button at the top of the Optics PMs dialog box, and select one of the following values from the drop-down menu to clear optics information from the transport performance monitoring data.
- Current—Clear the optics information for the current interval, such as 15-minute interval or 24-hour interval, for which monitoring data is being collected.
 - Current Day—Clear the optics information for the current 24 hours.
 - All Intervals—Clear the optics information for the current 15-minute interval, the 96 records of 15-minute intervals, the current day, and the previous day

After you select one of the intervals for which monitoring data must be deleted, a Clear Optics PMs dialog box is displayed to indicate that a job is triggered to delete the monitoring information from the module on the device. The job ID, start and end times of the job, percentage of completion, and status of the job are displayed.

13. Click **Close** to close the job dialog box; alternatively, click **Refresh** to update the job status and view.
- You can use the Jobs Management page (by clicking the System icon on the banner and selecting Manage Jobs) to track the status of this job.

You can click the **Refresh** (rotating arrow icon) button at the top of the Optics PMs dialog box to enable the latest performance monitoring statistics to be polled and displayed.

RELATED DOCUMENTATION

[Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | 1583](#)

[Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | 1585](#)

[Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | 1587](#)

[Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | 1595](#)

[Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | 1600](#)

Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults

The performance monitoring capability in Connectivity Services Director displays information about the health of your network and changing conditions of your optical channel transport units (OTUs). Use this diagnosis and detection mechanism to identify problems with the equipment, pinpoint security attacks, or to analyze trends and categories of errors. This feature includes fault-monitoring details in the dashboard, in monitoring pages, and on a dedicated page that displays alarms, events, and system log messages that are generated. Performance monitoring parameters can be viewed in both chart and statistical formats. These charts and statistical details provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity. You can assess the performance of your network, not only at a point in time, but also over a period of time. This feature enables you to determine trending and network-health parameters; for example, whether service-level agreements (SLAs) have been violated.

To view performance monitoring details of OTUs:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the the image of the device, select an OTN interface or port—for example, a 100-Gigabit Ethernet optical transport network (OTN) MIC installed in a PTX Series router.

The Optical Port dialog box is displayed. At the lower part of the dialog box, the OTU Section and ODU Section panes are displayed in a collapsed form.

6. Click the **OTU Section** header at the bottom of the dialog box.

The OTU Section pane is expanded and displayed. This pane contains the Equipment, Status/Config, and Performance tabs.

7. Click the **Performance** tab at the bottom of the pane.

This pane contains the Perf Mon and TCA Config tabs. The Perf Mon tab of the OTU PMs dialog box is expanded and displayed.

The following fields are displayed in the Perf Mon tab of the OTU PMs dialog box. The date and time at which the dialog box was last refreshed is shown.

- OTU FE—OTU far-end measurement threshold
 - BBE—Background block error threshold-crossing defect trigger for OTU far-end
 - ES—Errored seconds threshold-crossing defect trigger for OTU far-end
 - SES—Severely errored seconds threshold-crossing defect trigger for OTU far-end
 - UAS—Unavailable seconds threshold-crossing defect trigger for OTU far-end
- OTU NE—OTU near-end measurement threshold for OTU near-end
 - BBE—Background block error threshold-crossing defect trigger for OTU near-end
 - ES—Errored seconds threshold-crossing defect trigger for OTU near-end
 - SES—Severely errored seconds threshold-crossing defect trigger for OTU near-end
 - UAS—Unavailable seconds threshold-crossing defect trigger for OTU near-end
- FEC NE (OTU only)—Near-end forward error correction threshold-crossing defect trigger
 - FEC-CorrectedErrMin—Forward error correction Corrected Errors counter
 - FEC-UncorrectedWords—Forward error correction Uncorrected Words counter
 - FECMax—Maximum forward error correction
- BER NE (OTU only)—Near-end bit error rate threshold-crossing defect trigger
 - BER-Min—Minimum bit error rate for OTU near-end
 - BER-Avg—Average bit error rate for OTU near-end
 - BERMax—Maximum bit error rate for OTU near-end

On the Perf Mon tab, for the TCA column, either a minus sign (–) is displayed that denotes that an alarm for threshold-exceed is not configured or a check mark is displayed and grayed out that indicates that the TCA for the particular attribute is configured.

In the 15 Mins column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the last 15 minutes. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 15-minute interval. By default, 96 records of 15-minute intervals are displayed.

A 15-Min *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

8. Click the **15 Mins *parameter name*** tab.

a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date and time along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.

The records are displayed in tabular format. A serial number of the count of entries, the day, month, and year at which the entry was collected, and the time at which the entry was collected are displayed. The timestamp is the UTC time in the database that is mapped to the local time zone of the client computer.

- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search.
- Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
- Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 15-Min *parameter-name* tab.

9. In the 24-Hrs column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the previous day. This option enables you to view the statistics in a chart form. By default, records pertaining to the last 30 days are displayed when you view the performance monitoring counters for the 24-hour duration.

A 24 Hours *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

10. Click the **24 Hours *parameter name*** tab.

a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.
- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search. Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
- Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 24 Hours *parameter-name* tab.

11. Click the **Clear PMs** button at the top of the dialog box, and select one of the following values from the drop-down menu to clear OTU information from the transport performance monitoring data.

- **Current**—Clear the OTU information for the current interval, such as 15-minute interval or 24-hour interval, for which monitoring data is being collected.
- **Current Day**—Clear the OTU information for the current 24 hours.

- All Intervals—Clear the OTU information for the current 15-minute interval, the 96 records of 15-minute intervals, the current day, and the previous day

After you select one of the intervals for which monitoring data must be deleted, a Clear Optics PMs dialog box is displayed to indicate that a job is triggered to delete the monitoring information from the module on the device. The job ID, start and end times of the job, percentage of completion, and status of the job are displayed.

12. Click **Close** to close the job dialog box; alternatively, click **Refresh** to update the job status and view.

You can use the Jobs Management page (by clicking the System icon on the banner and selecting Manage Jobs) to track the status of this job.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest performance monitoring statistics to be polled and displayed.

RELATED DOCUMENTATION

[Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | 1583](#)

[Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | 1585](#)

[Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | 1587](#)

[Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | 1589](#)

[Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults | 1600](#)

Viewing Performance Monitoring Details of ODUs for Detecting and Diagnosing Faults

To analyze and resolve any faults associated with optical channel data units (ODUs) of OTN ports, it is essential to view the diagnostic data, warnings, and alarms for transport performance monitoring. The different types of parameters related to performance monitoring that are retrieved from the ODUs enable you to ensure service availability and verify or monitor individual services and the service network performance.

The performance monitoring capability in Connectivity Services Director displays information about the health of your network and changing conditions of the OTUs of OTN ports. Use this diagnosis and detection mechanism to identify problems with the equipment, pinpoint security attacks, or to analyze trends and categories of errors. This feature includes fault-monitoring details in the dashboard, in monitoring pages, and on a dedicated page that displays alarms, events, and system log messages that are generated. Performance monitoring parameters can be viewed in both chart and statistical formats. These charts and statistical details provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity. You can assess the performance of your network, not only at a point in time, but also over a period of time. This feature enables you to determine trending and network-health parameters; for example, whether service-level agreements (SLAs) have been violated.

To view performance monitoring details of ODUs:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an optical interface in the image of the device.

The Optical Port dialog box is displayed on the right pane.

6. Click the **ODU Path** header at the bottom of the dialog box.

The ODU Path pane is expanded and displayed. This pane contains the Equipment, Status/Config, and Performance tabs.

7. Click the **Performance** tab at the bottom of the pane.

This pane contains the Perf Mon and TCA Config tabs. The Perf Mon tab of the ODU PMs dialog box is displayed.

The following fields are displayed in the Perf Mon tab of the ODU PMs dialog box. The date and time at which the dialog box was last refreshed is shown.

- ODU FE—ODU far-end measurement threshold
 - BBE—Background block error threshold-crossing defect trigger for ODU far-end
 - ES—Errored seconds threshold-crossing defect trigger for ODU far-end
 - SES—Severely errored seconds threshold-crossing defect trigger for ODU far-end
 - UAS—Unavailable seconds threshold-crossing defect trigger for ODU far-end
- ODU NE—ODU near-end measurement threshold for ODU near-end
 - BBE—Background block error threshold-crossing defect trigger for ODU near-end
 - ES—Errored seconds threshold-crossing defect trigger for ODU near-end
 - SES—Severely errored seconds threshold-crossing defect trigger for ODU near-end
 - UAS—Unavailable seconds threshold-crossing defect trigger for ODU near-end

On the Perf Mon tab, for the TCA column, either a minus sign (–) is displayed that denotes that an alarm for threshold-exceed is not configured or a check mark is displayed and grayed out that indicates that the TCA for the particular attribute is configured.

8. In the 15 Mins column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the last 15 minutes. This option enables you to view the statistics in a chart form. By default, 96 records of 15-minute intervals are displayed.

A 15-Min *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

9. Click the **15 Mins *parameter name*** tab.
 - a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date and time along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.

The records are displayed in tabular format. A serial number of the count of entries, the day, month, and year at which the entry was collected, and the time at which the entry was collected are displayed. The timestamp is the UTC time in the database that is mapped to the local time zone of the client computer.

- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search.
- Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
- Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 15-Min *parameter-name* tab.

10. In the 24-Hrs column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the previous day. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 24-hour interval. By default, records pertaining to the last 30 days are displayed when you view the performance monitoring counters for the 24-hour duration.

A 24 Hours *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

11. Click the **24 Hours *parameter name*** tab.

a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.
- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search. Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
- Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 24 Hours *parameter-name* tab.

12. Click the **Clear PMs** button at the top of the dialog box, and select one of the following values from the drop-down menu to clear ODU information from the transport performance monitoring data.

- **Current**—Clear the optics and OTN information for the current interval, such as 15-minute interval or 24-hour interval, for which monitoring data is being collected.
- **Current Day**—Clear the ODU information for the current 24 hours.

- All Intervals—Clear the ODU information for the current 15-minute interval, the 96 records of 15-minute intervals, the current day, and the previous day

After you select one of the intervals for which monitoring data must be deleted, a Clear Optics PMs dialog box is displayed to indicate that a job is triggered to delete the monitoring information from the module on the device. The job ID, start and end times of the job, percentage of completion, and status of the job are displayed.

13. Click **Close** to close the job dialog box; alternatively, click **Refresh** to update the job status and view.

You can use the Jobs Management page (by clicking the System icon on the banner and selecting Manage Jobs) to track the status of this job.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest performance monitoring statistics to be polled and displayed.

RELATED DOCUMENTATION

[Configuring Threshold-Crossing Alarms for OTN Ports for Monitoring Link Performance | 1583](#)

[Configuring Threshold-Crossing Alarms for OTUs for Monitoring Link Performance | 1585](#)

[Configuring Threshold-Crossing Alarms for ODUs for Monitoring Link Performance | 1587](#)

[Viewing Performance Monitoring Details of OTN Ports for Detecting and Diagnosing Faults | 1589](#)

[Viewing Performance Monitoring Details of OTUs for Detecting and Diagnosing Faults | 1595](#)

Viewing a Graphical Image of the Chassis of PTX Series Routers

In the Connectivity Services Director GUI, you can view a graphical representation of a device from Build mode of Device View by selecting the **Device Management > View Physical Inventory** option from the Tasks pane. The hardware and line module details are displayed with a pictorial view of the slots of the PTX Series routers and the modules installed in these slots. The Chassis View provides a pictorial representation of the chassis or device, and the modules or components that are installed in it, such as the line cards, interfaces, and other hardware elements.

To view a pictorial representation of a device chassis and the configured components, such as interfaces, line cards, and hardware elements, select a managed device listed on the My Network tree in Device View of Connectivity Services Director, and select **Device Management > View Physical Inventory** from the tasks pane. The right pane displays the device image and the corresponding description of the view selected in a tabular manner. The Chassis View is displayed. The hardware and line module details are displayed with a pictorial view of the slots of the devices and the modules installed in these slots. The device image

can be rotated to view the front, rear, top, bottom, right and left planes of the device by clicking the respective arrow buttons on the page.

To view a graphical image of the chassis and its associated components:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Click a particular component or interface to display the associated details in the lower portion of the page. The Rotate and Perspective buttons enable you to view the images in required orientation.

6. Click the **View Back** (arrows in a square symbol) icon to cause the device image to rotate along the x-axis and display the rear view of the device. Alternatively, click the **View Front** icon to view the front plane of the device. The View Back and View Front icons are toggle options.

7. Click the **Perspective** (cube symbol) icon to display the device image in three-dimensional format. It is a toggle button, which causes the device image to be shown in either three-dimensional or one-dimensional format.

8. Select the level of magnification of the image by clicking the **Zoom** (magnifying glass) icon. The image is expanded and displayed.

Alternatively, use the slider control beneath the Zoom icon to change the level of magnification.

9. Click the home icon to return to the front view of the chassis. The selected interface is surrounded with a colored outline based on the operational status. An interface that is operationally up is denoted in green and an interface that is operationally down is represented in red. The components are depicted as small colored icons at the top-left corner of the front view of the equipment image.

In the graphical image of the device displayed, you can mouse over the different parts of the device, such as the interfaces, line cards, and slots. When you mouse over the different modules, their corresponding

details are displayed as tooltips. On clicking the device components, the corresponding description for the selected component is displayed by default in the Component Info pane and the Equipment tab with the following values.

- Description—Brief description of the hardware item:
 - Type of power supply.
 - Type of PIC. If the PIC type is not supported on the current software release, the output states **Hardware Not Supported**.
 - Type of FPC: **FPC Type 1, FPC Type 2, FPC Type 3, FPC Type 4** , or **FPC TypeOC192**.

On EX Series switches, a brief description of the FPC.

On the J Series routers, the FPC type corresponds to the Physical Interface Module (PIM). The following list shows the PIM abbreviation in the output and the corresponding PIM name.

- **2x FE**—Either two built-in Fast Ethernet interfaces (fixed PIM) or dual-port Fast Ethernet PIM
- **4x FE**—4-port Fast Ethernet ePIM
- **1x GE Copper**—Copper Gigabit Ethernet ePIM (one 10-Mbps, 100-Mbps, or 1000-Mbps port)
- **1x GE SFP**—SFP Gigabit Ethernet ePIM (one fiber port)
- **4x GE Base PIC**—Four built-in Gigabit Ethernet ports on a J4350 or J6350 chassis (fixed PIM)
- **2x Serial**—Dual-port serial PIM
- **2x T1**—Dual-port T1 PIM
- **2x E1**—Dual-port E1 PIM
- **2x CT1E1**—Dual-port channelized T1/E1 PIM
- **1x T3**—T3 PIM (one port)
- **1x E3**—E3 PIM (one port)
- **4x BRI S/T**—4-port ISDN BRI S/T PIM
- **4x BRI U**—4-port ISDN BRI U PIM
- **1x ADSL Annex A**—ADSL 2/2+ Annex A PIM (one port, for POTS)
- **1x ADSL Annex B**—ADSL 2/2+ Annex B PIM (one port, for ISDN)
- **2x SHDSL (ATM)**—G SHDSL PIM (2-port two-wire module or 1-port four-wire module)
- **1x TGM550**—TGM550 Telephony Gateway Module (Avaya VoIP gateway module with one console port, two analog **LINE** ports, and two analog **TRUNK** ports)
- **1x DS1 TIM510**—TIM510 E1/T1 Telephony Interface Module (Avaya VoIP media module with one E1 or T1 trunk termination port and ISDN PRI backup)
- **4x FXS, 4x FX0, TIM514**—TIM514 Analog Telephony Interface Module (Avaya VoIP media module with four analog **LINE** ports and four analog **TRUNK** ports)

- **4x BRI TIM521**—TIM521 BRI Telephony Interface Module (Avaya VoIP media module with four ISDN BRI ports)
- **Crypto Accelerator Module**—For enhanced performance of cryptographic algorithms used in IP Security (IPsec) services
- **MPC M 16x 10GE**—16-port 10-Gigabit Module Port Concentrator that supports SFP+ optical transceivers. (Not on EX Series switches.)
- For hosts, the Routing Engine type.
- For small form-factor pluggable transceiver (SFP) modules, the type of fiber: **LX**, **SX**, **LH**, or **T**.
- LCD description for EX Series switches (except EX2200 switches).
- **MPC2**—1-port MPC2 that supports two separate slots for MICs.
- **MPC3E**—1-port MPC3E that supports two separate slots for MICs (MIC-3D-1X100GE-CFP and MIC-3D-20GE-SFP) on MX960, MX480, and MX240 routers. The MPC3E maps one MIC to one PIC (1 MIC, 1 PIC), which differs from the mapping of legacy MPCs.
- 100GBASE-LR4, pluggable CFP optics
- Supports the Enhanced MX Switch Control Board with fabric redundancy and existing SCBs without fabric redundancy.
- Interoperates with existing MX Series line cards, including Flexible Port Concentrators (FPC), Dense Port Concentrators (DPCs), and Modular Port Concentrators (MPCs).
- **MPC4E**—Fixed configuration MPC4E that is available in two flavors: MPC4E-3D-32XGE-SFPP and MPC4E-3D-2CGE-8XGE on MX2020, MX960, MX480, and MX240 routers.
- LCD description for MX Series routers
- **Model**—Model number of the FRU component.
- **Name**—Name of the SDG and the platform type, such as MX240 or MX480. This field displays the components of the device, such as chassis, PIC, CPU, and PIC parameters. Information about the chassis, midplane, craft interface (FPM), power midplane (PMP), Power Supply Modules (PSMs), Power Distribution Modules (PDMs), Routing Engines, Control Boards (CBs) and Switch Processor Mezzanine Boards (SPMBs), Switch Fabric Boards (SFBs), Flexible PIC Concentrators (FPCs), PICs, adapter cards (ADCs) and fan trays is displayed.
- **Manufacturer**—Name of the company that built and shipped the device.
- **Part number**—Part number of the chassis component.
- **Serial number**—Serial number of the chassis component. The serial number of the backplane is also the serial number of the router or switch chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

The Active Alarms monitor shows any active alarm that has not yet been cleared. It is one of the four standard monitors available in Alarm mode. Active Alarms is a table that has four fields and appear by

default. However, nine fields are available for selection. View [Table 176 on page 1387](#) for a description of the table.

Table 231: Active Alarms Monitor

ID	A system and sequentially-generated identification number.	No	No
Assigned To	If assigned to an individual, it shows the name of the person assigned; otherwise, it shows System to mark that the alarm is still unassigned.	No	Yes
Severity	<p>The severity of the alarm. Severity levels are:</p> <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary. 	Yes	Yes
Entity ID	The identification of the entity responsible for causing this alarm. The Entity ID is the key for correlation of events into an alarm. The Entity ID could be a MAC address of a radio or an IP address of the device.	Yes	Yes
Source	The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.	No	No
Reporting Device	The hostname or IP address of the reporting device.	Yes	Yes
Creation Date	The date and time the alarm was first reported.	No	No
Last Updated	The date and time that the information for the alarm was last modified.	Yes	Yes
Updated By	Either the system or the last user who modified the alarm.	No	No

RELATED DOCUMENTATION

[Viewing a Graphical Image of the Optical Interface Components](#) | 1553

Diagnosing, Examining, and Correcting Optical Interface Problems

Connectivity Services Director enables you to manage the optical functionality provided by 100-Gigabit Ethernet PIC that can be installed in MX Series and PTX Series routers. A topological network view is implemented, which enables you the user to visualize optical sites, links and services and a site view that provides status, configuration, alarms and fault management, and performance monitoring functionalities on the optical interfaces. FCAPS (fault, configuration, accounting, performance, and security) is a categorical model of the working objectives of network management.

The fault management capability in Connectivity Services Director shows you information about the health of your network and changing conditions of your equipment. Use this diagnosis and detection mechanism to identify problems with the equipment, pinpoint security attacks, or to analyze trends and categories of errors. This feature includes fault-monitoring details in the dashboard, monitoring pages, and in a dedicated page that displays the alarms, events, and system logging messages that are generated. These charts and messages provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity.

You can assess the performance of your network, not only at a point in time, but also over a period of time. This feature enables you to determine trending and network-health parameters; for example, whether service-level agreements (SLAs) have been violated. The fault management data includes SNMP traps and syslogs received from PTX Series routers. Junos Space platform is integrated with OpenNMS, which is a network management application platform that provides solutions for enterprises and carriers, to receive SNMP Traps. Connectivity Services Director uses OpenNMS for SNMP trap collection and correlation.

Activity on a network device consists of a series of events. Optical interfaces generate SNMP traps when certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director. Connectivity Services Director correlates traps, describing a condition, into an alarm . You can use the Fault Management page monitor to sort alarms, view an alarm in depth, and to assign a disposition to an alarm.

Alarms include Clear and Set alarms. All alarms are listed under OTN category and can be critical, major, or minor severity levels. Three main categories of alarms—Optical, OTU, and ODU—are displayed.

Threshold-crossing alarms (TCAs) are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so until the end of the 15-minute interval and the 24-hour interval for parameters such as optical channel transport unit (OTU) and optical data unit (ODU). A near-end measurement is associated with ingress data frames and a far-end measurement is associated with egress data frames. Monitoring the performance of links provides for end-to-end Ethernet service assurance over any path for either a single link or multiple links spanning networks composed of multiple LANs. The link performance metrics enable operators to offer binding service-level agreements (SLAs) and generate new revenues from rate- and performance-guaranteed service packages that are tailored to the specific needs of their customers.

Optical Alarms, 24 Hour Threshold-Crossing Alarms (TCA), and 15 Minute Threshold-Crossing Alarms (TCA)

The following are the different optical alarms that are generated:

- AvgPowerAlarm—Average Power Alarm
- BiasCurrentHighAlarm—Bias Current High Alarm
- BiasCurrentLowAlarm—Bias Current Low Alarm
- ChromaticDispHighWarning—Chromatic Dispersion High Warning
- ChromaticDispLowWarning—Chromatic Dispersion Low Warning
- LOS—Loss Of Signal
- LossofACPowerAlarm—Loss of Alternating Current (AC) Power Alarm
- ModuleTempHighWarning—Module Temperature High Warning
- ModuleTempLowWarning—Module Temperature Low Warning
- OSNRLowWarning—Optical Signal to Noise Ratio (OSNR) Low Warning
- PowerHighAlarm—Power High Alarm
- PowerLowAlarm—Power Low Alarm
- QLowWarning—Q Factor Low Warning
- RxCarrierFreqHigh—Receive Carrier Frequency High
- RxCarrierFreqLow—Receive Carrier Frequency Low
- RxLossAvgPowerAlarm—Receive Loss Average Power Alarm
- RxPLLLockAlarm—Receive Phase Lock Loop Alarm
- RxPowerHighAlarm—Receive Power High Alarm
- RxPowerHighWarning—Receive Power High Warning
- RxPowerLowAlarm—Receive Power Low Alarm
- RxPowerLowWarning—Receive Power Low Warning
- TemperatureHighAlarm—Temperature High Alarm
- TemperaturelowAlarm—Temperature Low Alarm
- TxPLLLockAlarm—Transmit Phase Loop Lock Alarm
- TxPowerHighWarning—Transmit Power High Warning
- TxPowerLowWarning—Transmit Power Low Warning
- WavelenthLockErr—Wavelength Lock Error

The following are the threshold-crossing alarms generated when threshold is exceeded over the last 15 minutes for optical interfaces:

- 24HourModuleTempHighThreshAlert—24 Hour Module Temperature High Threshold Alert
- 24HourModuleTempLowThreshAlert—24 Hour Module Temperature Low Threshold Alert
- 24HourRxPowerHighThreshAlert—24 Hour Receive Power High Threshold Alert
- 24HourRxPowerLowThreshAlert—24 Hour Receive Power Low Threshold Alert
- 24HourTxPowerHighThreshAlert—24 Hour Transmit Power High Threshold Alert
- 24HourTxPowerLowThreshAlert—24 Hour Transmit Power Low Threshold Alert

The following are the threshold-crossing alarms generated when threshold is exceeded over the last 24 hours for optical interfaces:

- RxPowerHighThreshAlert—15 Minute Receive Power High Threshold Alert
- ModuleTempHighThreshAlert—15 Minute Module Temperature High Threshold Alert
- RxPowerLowThreshAlert—15 Minute Receive Power Low Threshold Alert
- TxPowerHighThreshAlert—15 Minute Transmit Power High Threshold Alert
- TxPowerLowThreshAlert—15 Minute Transmit Power Low Threshold Alert
- ModuleTempLowThreshAlert—15 Minute Module Temp Low Threshold Alert

OTU Alarms, 24 Hour Threshold-Crossing Alarms (TCA), and 15 Minute Threshold-Crossing Alarms (TCA)

The following are the different OTU alarms that are generated:

- OtnLofAlarm—Loss of Frame Alarm
- OtnLomAlarm—Loss of Multi-frame Alarm
- OtnLosAlarm—Loss of Signal Alarm
- OtnNoAlarm—OTN No Alarm
- OtuBdiAlarm—OTU Backward Error Indication Alarm
- OtuBiaeAlarm—OTU Backward Incoming Alignment Error Alarm
- OtuDegAlarm—OTU Degradation Alarm
- OtuFecExcessiveErrsAlarm—OTU Forward Error Correction (FEC) Excessive Errors Alarm
- OtuIaeAlarm—OTU Incoming Alignment Error Alarm
- OtuSsfAlarm—OTU Server Signal Fail Alarm

- OtuTimAlarm—OTU Trace Identifier Mismatch Alarm
- OtuTsfAlarm—OTU Trail Signal Fail Alarm

The following are the threshold-crossing alarms generated when threshold is exceeded over the last 15 minutes for OTU attributes:

- 24HourThreshBBETCA—24 Hour Background Block Error Threshold Alert
- 24HourThreshBip8TCA—24 Hour Bit Interleaved Parity (BIP-8) Threshold Alert
- 24HourThreshESTCA—24 Hour Errored Seconds Threshold Alert
- 24HourThreshPreFECBERTCA—24 Hour Pre-Forward Error Correction Threshold Alert
- 24HourThreshSESTCA—24 Hour Severely Errored Seconds Threshold Alert
- 24HourThreshUASTCA—24 Hour Unavailable Second Threshold Alert

The following are the threshold-crossing alarms generated when threshold is exceeded over the last 24 hours for OTU attributes:

- 15MinThreshBBETCA—15 Minute Background Block Error Threshold Alert
- 15MinThreshBip8TCA—15 Minute Bit Interleaved Parity (BIP-8) Threshold Alert
- 15MinThreshESTCA—15 Minute Errored Seconds Threshold Alert
- 15MinThreshPreFECBERTCA—15 Minute Pre-Forward Error Correction Threshold Alert
- 15MinThreshSESTCA—15 Minute Severely Errored Seconds Threshold Alert
- 15MinThreshUASTCA—15 Minute Unavailable Second Threshold Alert
- 15MinThUnCorrectedWordsTCA—15 Minute UnCorrected Codewords Threshold Alert

ODU Alarms, 24 Hour Threshold-Crossing Alarms (TCA), and 15 Minute Threshold-Crossing Alarms (TCA)

The ODU tables cover both the Path and TCM layers but TCM layers are currently not supported. The following are the different ODU alarms that are generated:

- PtmAlarm—Payload Type Mismatch Alarm
- TcmAisAlarm—Alarm Indication Signal Alarm
- TcmBdiAlarm—Backward Error Indication Alarm
- TcmCSFAlarm—CSFAlarm
- TcmDegAlarm—Degradation Alarm
- TcmIaeAlarm—Incoming Alignment Error Alarm
- TcmLckAlarm—Locked Alarm

- TcmLTCAAlarm—Loss of tandem Connection Alarm
- TcmOciAlarm—Open Connection Indication Alarm
- TcmSSfAlarm—Server Signal Fail Alarm
- TcmTimAlarm—Trace Identifier Mismatch Alarm
- TcmTSfAlarm—Trail Signal Fail Alarm
- OdukTcmNoAlarm—OTN No Alarm

The following are the threshold-crossing alarms generated when threshold is exceeded over the last 15 minutes for ODU attributes:

- Tcm15MinThreshBBETCA—15 Minute Background Block Error Threshold Alert
- Tcm15MinThreshBip8TCA—15 Minute Bit Interleaved Parity (BIP-8)
- Threshold Alert Tcm15MinThreshESTCA—15 Minute Errored Seconds Threshold Alert
- Tcm15MinThreshSESTCA—15 Minute Severely Errored Seconds
- Threshold Alert Tcm15MinThreshUASTCA—15 Minute Unavailable Second Threshold Alert

The following are the threshold-crossing alarms generated when threshold is exceeded over the last 24 hours for ODU attributes:

- Tcm24HourThreshBBETCA—24 Hour Background Block Error Threshold Alert
- Tcm24HourThreshBip8TCA—24 Hour Bit Interleaved Parity (BIP-8) Threshold Alert
- Tcm24HourThreshESTCA—24 Hour Errored Seconds Threshold Alert
- Tcm24HourThreshSESTCA—24 Hour Severely Errored Seconds Threshold Alert
- Tcm24HourThreshUASTCA—24 Hour Unavailable Second Threshold Alert

RELATED DOCUMENTATION

| [Diagnosing, Examining, and Correcting Optical Interface Problems](#) | 1609

Changing Alarm Settings for the Optics and OTN Interfaces

IN THIS SECTION

- [Alarms for Optical Interfaces | 1614](#)
- [Alarms for OTN Interfaces | 1619](#)
- [Configuring Global Alarm Notifications | 1624](#)
- [Retaining Alarm History | 1625](#)
- [Specifying Event History | 1625](#)
- [Enabling Alarms | 1625](#)
- [Changing the Severity of Individual Alarms | 1625](#)
- [Configuring Individual Alarm Notifications | 1626](#)

You can modify the configuration settings for alarm settings of optical interfaces using the Preferences page of the Connectivity Services Director application. To open the Preferences page, click the down arrow next to the System button in the Connectivity Services Director banner and select Preferences. The Preferences page opens with User Preferences as the default tab. Click the Fault tab of the Preferences page of the Connectivity Services Director GUI to enable individual alarms, set the retention period for alarms, configure alarm notifications, and to specify the number of events to keep for each alarm. The Fault tab has multiple sections, which you can expand and collapse by clicking the arrow next to the section title:

- Global Settings, for configuring Faults settings such as global alarm notifications and alarm data retention.
- Individual Alarms and Threshold Settings, for configuring settings for individual alarms.

This section describes the following tasks that you can perform by using the alarm monitors displayed in Fault mode:

Alarms for Optical Interfaces

The following alarms are applicable for management of the Optics interface.

- JnxOpticsLocation—Near end or far end
- jnxOpticsPerformanceMonitoring—{ jnxIfOpticsMib 2 }
- jnxOpticsAlarm—{ jnxIfOpticsMib 3 }
- jnxOpticsConfigTable—This table provides information on the optics configuration.

- `jnxOpticsConfigEntry`—A conceptual row that contains information about the optics configuration Table.
- `jnxOpticsConfigContainerIndex`—The associated `jnxContentsContainerIndex`, for example, shelf.
- `jnxOpticsConfigL1Index`—The level one index associated with this subject, for example, slot.
- `jnxOpticsConfigL2Index`—The level two index associated with this subject, for example, port.
- `jnxOpticsConfigL3Index`—The level three index associated with this subject, for example, channel.
- `jnxOpticsType`
- `jnxLaserEnable`—The transmit wavelength of the laser.
- `jnxSpacing`—A minimum nominal difference in frequency (GHz) between two adjacent channels.
- `jnxModulation`
- `jnxTxOpticalPower`—Transmit optical power.
- `jnxModuleTempHighThresh`—High module temperature in degree Fahrenheit above which a Threshold Crossing Alert (TCA) should be sent.
- `jnxModuleTempLowThresh`—Low module temperature in degree Fahrenheit above which a Threshold Crossing Alert (TCA) should be sent.
- `jnxTxPowerHighThresh`—Tx power above which a Threshold Crossing Alert (TCA) should be sent.
- `jnxTxPowerLowThresh`—Tx Power below which a Threshold Crossing Alert (TCA) should be sent.
- `jnxRxPowerHighThresh`—Rx power above which a Threshold Crossing Alert (TCA) should be sent.
- `jnxRxPowerLowThresh`—Rx Power below which a Threshold Crossing Alert (TCA) should be sent.
- `jnxOpticsTraceToneCfgTable`—Information about the optics tests.
 - `jnxOpticsTraceToneCfgEntry`—Information about the optics FRUs
 - `jnxOpticsTraceToneCfgContainerIndex`—The associated `jnxContentsContainerIndex`, for example, shelf.
 - `jnxOpticsTraceToneCfgL1Index`—The level one index associated with this subject, for example slot.
 - `jnxOpticsTraceToneCfgL2Index`—The level two index associated with this subject, for example port.
 - `jnxOpticsTraceToneCfgL3Index`—The level three index associated with this subject, for example channel.
 - `jnxOpticsTraceToneCfgTxEnable`—Enable/disable the transmit Trace tone feature.
 - `jnxOpticsTraceToneCfgRxEnable`—Enable/disable the receive Trace tone feature.
 - `jnxOpticsTraceToneCfgDestId`—The destination Id of the link ID/ the chassis and the blade. The transmit messages will also have the src id, which is this chassis id and this port info.

- jnxOpticsTraceToneCfgTxMsg—The transmit data in the tracetone message.
- jnxOpticsTraceToneCfgRxMsg—The received data in the trace tone message.
- jnxOpticsPMCurrentTable—A table of current performance monitoring entries.
 - jnxOpticsPMCurrentEntry—A conceptual row that contains information about the Performance Monitoring Current Table.
 - jnxPMCurChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port.
 - jnxPMCurDiffGroupDelay—Differential group delay.
 - jnxPMCurPolarizationState—Polarization state.
 - jnxPMCurPolarDepLoss—The polarization dependent loss (PDL) is the difference (in dB) between the maximum and minimum values of the channel insertion loss (or gain) of the black-link from point SS to RS due to a variation of the state of polarization (SOP) over all SOPs.
 - jnxPMCurQ—'Q' factor estimated at Rx Transceiver port.
 - jnxPMCurSNR—SNR—signal-to-noise ratio.
 - jnxPMCurTxOutputPower—TxOutputPower—transmit output power.
 - jnxPMCurRxInputPower—RxInputPower—receive output power
 - jnxPMCurMinChromaticDispersion—Minimum Residual Chromatic Dispersion measured at Rx Transceiver port.
 - jnxPMCurMaxChromaticDispersion—Maximum Residual Chromatic Dispersion measured at Rx Transceiver port.
 - jnxPMCurAvgChromaticDispersion—Average Residual Chromatic Dispersion measured at Rx Transceiver port.
 - jnxPMCurMinDiffGroupDelay—Minimum Differential group delay
 - jnxPMCurMaxDiffGroupDelay—Maximum Differential group delay
 - jnxPMCurAvgDiffGroupDelay—Average Differential group delay
 - jnxPMCurMinPolarState—Minimum Polarization state
 - jnxPMCurMaxPolarState—Maximum Polarization state
 - jnxPMCurAvgPolarState—Average Polarization state
 - jnxPMCurMinPolarDepLoss—Minimum polarization dependent loss (PDL)
 - jnxPMCurMaxPolarDepLoss—Maximum polarization dependent loss (PDL)
 - jnxPMCurAvgPolarDepLoss—Average polarization dependent loss (PDL)
 - jnxPMCurMinQ—Minimum 'Q' factor estimated at Rx Transceiver port.
 - jnxPMCurMaxQ—Max 'Q' factor estimated at Rx Transceiver port.

- jnxPMCurAvgQ—Average 'Q' factor estimated at Rx Transceiver port.
- jnxPMCurMinSNR—Minimum SNR—signal-to-noise ratio
- jnxPMCurMaxSNR—Maximum SNR—signal-to-noise ratio
- jnxPMCurAvgSNR—Average SNR—signal-to-noise ratio
- jnxPMCurMinTxOutputPower— Minimum TxOutputPower—transmit output power
- jnxPMCurAvgTxOutputPower—Average TxOutputPower—transmit output power
- jnxPMCurMinRxInputPower—Minimum RxInputPower—receive output power
- jnxPMCurMaxRxInputPower—Maximum RxInputPower—receive output power
- jnxPMCurAvgRxInputPower—Average RxInputPower—receive output power
- jnxPMCurSuspectedFlag—If true, the data in this entry may be unreliable.
- jnxPMCurSuspectReason —If SuspectedFlag is true, the reason for the performance monitoring data being suspect.
- jnxOpticsPMIntervalTable—A table of current performance monitoring entries.
 - jnxOpticsPMIntervalEntry—A conceptual row that contains information about the Performance Monitoring Interval Table.
 - jnxOpticsPMIntervalNumber—This is the 15 minute interval number.
 - jnxPMIntMinChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port—minimum in the 15 minute interval.
 - jnxPMIntMaxChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port—maximum in the 15 minute interval.
 - jnxPMIntAvgChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port—average in the 15 minute interval.
 - jnxPMIntMinDiffGroupDelay—Differential group delay measured at Rx Transceiver port—minimum in the 15 minute interval.
 - jnxPMIntMaxDiffGroupDelay—Differential group delay measured at Rx Transceiver port—maximum in the 15 minute interval
 - jnxPMIntAvgDiffGroupDelay—Differential group delay measured at Rx Transceiver port—average in the 15 minute interval
 - jnxPMIntMinPolarState—Polarization state—minimum in the 15 minute interval
 - jnxPMIntMaxPolarState—Polarization state—max in the 15 minute interval
 - jnxPMIntAvgPolarState—Polarization state—average in the 15 minute interval
 - jnxPMIntMinPolarDependentLoss—Polarization Dependent Loss—minimum in the 15 minute interval
 - jnxPMIntMaxPolarDependentLoss—Polarization Dependent Loss—maximum in the 15 minute interval

- jnxPMIntMinQ—Q—minimum in the 15 minute interval
- jnxPMIntMaxQ—Q—maximum in the 15 minute interval
- jnxPMIntAvgQ—Q—Average in the 15 minute interval
- jnxPMIntMinSNR—SNR—minimum in the 15 minute interval
- jnxPMIntMaxSNR—SNR—maximum in the 15 minute interval
- jnxPMIntAvgSNR—SNR—average in the 15 minute interval
- jnxPMIntMinTxOutputPower—TxOutputPower—minimum in the 15 minute interval
- jnxPMIntMaxTxOutputPower—TxOutputPower—maximum in the 15 minute interval
- jnxPMIntAvgTxOutputPower—TxOutputPower—average in the 15 minute interval
- jnxPMIntMinRxInputPower—RxInputPower—minimum in the 15 minute interval
- jnxPMIntMaxRxInputPower—RxInputPower—maximum in the 15 minute interval
- jnxPMIntAvgRxInputPower—RxInputPower—average in the 15 minute interval
- jnxPMIntTimeStamp—Time stamp performance monitoring interval
- jnxPMIntSuspectedFlag—If true, the data in this entry may be unreliable.
- jnxPMIntSuspectReason—If SuspectedFlag is true, the reason for the performance monitoring data being suspect.
- jnxOpticsPMDayTable—A table of current performance monitoring Day entries.
 - jnxOpticsPMDayEntry—A conceptual row that contains information about the performance monitoring Day Table
 - jnxOpticsPMDayIndex—This is 0 - cur day/ 1- prev day
 - jnxPMDayMinChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port—minimum in the day
 - jnxPMDayMaxChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port—maximum in the day
 - jnxPMDayAvgChromaticDispersion—Residual Chromatic Dispersion measured at Rx Transceiver port—average in the day
 - jnxPMDayMinDiffGroupDelay—Differential Group Delay measured at Rx Transceiver port—minimum in the day
 - jnxPMDayMaxDiffGroupDelay—Differential Group Delay measured at Rx Transceiver port—maximum in the day
 - jnxPMDayAvgDiffGroupDelay—Differential Group Delay measured at Rx Transceiver port—average in the day
 - jnxPMDayMinPolarState—Polarization state—minimum in the day

- jnxPMDayMaxPolarState—Polarization state—maximum in the day
- jnxPMDayAvgPolarState—Polarization state—average in the day
- jnxPMDayMinPolarDependentLoss—Polarization Dependent Loss—minimum in the day
- jnxPMDayMaxPolarDependentLoss—Polarization Dependent Loss—maximum in the day
- jnxPMDayAvgPolarDependentLoss—Polarization Dependent Loss—average in the day interval
- jnxPMDayMinQ—Q—minimum in the day
- jnxPMDayMaxQ—Q—maximum in the day
- jnxPMDayAvgQ—Q—Average in the day
- jnxPMDayMinSNR—SNR—min in the day
- jnxPMDayMaxSNR—SNR—max in the day
- jnxPMDayAvgSNR—SNR—avg in the day
- jnxPMDayMinTxOutputPower—TxOutputPower—minimum in the day
- jnxPMDayMaxTxOutputPower—TxOutputPower—maximum in the day.
- jnxPMDayAvgTxOutputPower—TxOutputPower—average in the day.
- jnxPMDayMinRxInputPower—RxInputPower—minimum in the day.
- jnxPMDayMaxRxInputPower—RxInputPower—maximum in the day.
- jnxPMDayAvgRxInputPower—RxInputPower—average in the day.
- jnxPMDayTimeStamp—Time for the Day.
- jnxPMDaySuspectedFlag—If true, the data in this entry may be unreliable.
- jnxPMDaySuspectReason—If SuspectedFlag is true, the reason for the performance monitoring data being suspect.

Alarms for OTN Interfaces

The following alarms are applicable for management of OTN interface for Juniper products.

- jnxIfAdminStates—Administraion state of the interface.
 - jnxAdminStatInService(1)—In service.
 - jnxAdminStatInServiceMA(2)—In service maintenance, the link is in service, but the alarms are suppressed.

- jnxAdminStateOutOfService(3)—Out of service due to a fault.
- jnxAdminStateOutOfServiceMA(4)—Out of service maintenance as configured by the user, may or may not have alarms.
- jnxIfOperStates—Operation states of the interface.
 - jnxOperStateInit(1)—Starting state of the interface.
 - jnxOperStateNormal(2)—The interface is working normally.
 - jnxOperStateFault(3)—There is some traffic affecting fault on the interface, for example, LOS.
 - jnxOperStateDegraded(4)—There is some function affecting the performance on the interface resulting in degradation, for example BER.
- jnxIfOtnRate—Rates for an interface.
- jnxIfOtnFecType—FEC modes of an interface.
- jnxIfOtnLayer—Layer which describes the table.
- jnxIfOtnType—Near end of far end
- jnxIfOtnDirection—Direction for the entities in the table.
- jnxIfOtnSeverity—Severity of the notification.
- jnxIfOtnServiceStateAction—Notification action on the service state.
- jnxIfOtnOtnkNotificationId—Identifies specific OTN alarms that may exist on an interface.
 - jnxIfOtnOtnLosAlarm(1)
 - jnxIfOtnOtnLofAlarm(2)
 - jnxIfOtnOtnLomAlarm(3)
 - jnxIfOtnOtnOtuSsfAlarm(4)
 - jnxIfOtnOtnOtuBdiAlarm(5)
 - jnxIfOtnOtnOtuTtimAlarm(6)
 - jnxIfOtnOtnOtuLaeAlarm(7)
 - jnxIfOtnOtuBiaeAlarm(8)
 - jnxIfOtnOtuDegAlarm(9)
 - jnxIfOtnOtuFecExcessiveErrsAlarm(11)
 - jnxIfOtn15MinThreshBBETCA(12)
 - jnxIfOtn15MinThreshESTCA(13)
 - jnxIfOtn15MinThreshSESTCA(14)
 - jnxIfOtn15MinThreshUASTCA(15)

- jnxIfOtn15MinThreshFcsTCA(16)
- jnxIfOtn15MinThUnCorrectedWordsTCA(17)
- jnxIfOtn15MinThreshPreFECBERTCA(18)
- JnxIfOtnOduktcmNotificationId—Alarms from the ODUk and TCM layers.
 - jnxIfOtnOduktcmOciAlarm(1)
 - jnxIfOtnOduktcmLckAlarm(2)
 - jnxIfOtnOduktcmBdiAlarm(3)
 - jnxIfOtnOduktcmTimAlarm(4)
 - jnxIfOtnOduktcmDegAlarm(5)
 - jnxIfOtnOduktcmIaeAlarm(6)
 - jnxIfOtnOduktcmLTCAAlarm(7)
 - jnxIfOtnOduktcmCSfAlarm(8)
 - jnxIfOtnOduktcmSSfAlarm(9)
 - jnxIfOtnOduktcmTSfAlarm(10)
 - jnxIfOtnOduktcm15MinThreshBBETCA(11)
 - jnxIfOtnOduktcm15MinThreshESTCA(12)
 - jnxIfOtnOduktcm15MinThreshSESTCA(13)
 - jnxIfOtnOduktcm15MinThreshUASTCA(14)
 - jnxIfOtnOduktcm15MinThreshFcsTCA(15)
 - jnxIfOtnOduktcmAisAlarm(16)
- jnxIfOtnOChCfgTable—This table provides information on the Otn OCh configuration.
 - jnxIfOtnOChCfgEntry
 - jnxIfOtnOChCfgContainerIndex
 - jnxIfOtnOChCfgL1Index
 - jnxIfOtnOChCfgL3Index
- jnxIfOtnLocalLoopback—Local loopback at the line after the optics.
- jnxIfOtnLineLoopback—Line loopback at the line.
- jnxIfOtnPayloadLoopback—Payload loopback after the optics.
- jnxIfOtnAdminState
- jnxIfOtnOperState—Operation state of the interface.

- jnxIfOtnIndex-IfIndex of the interface.
- jnxIfOtnOChStatus
- jnxIfOtnOChPortMode— Port mode of the interface.
- jnxIfOtnOTUkCfgTable—This table provides information on the Otn OTUk configuration.
 - jnxIfOtnOTUkCfgEntry—A conceptual row that contains the Otn OTUk configuration table.
 - jnxIfOtnOTUkCfgContainerIndex—The associated jnxContentsContainerIndex, for example, shelf.
 - jnxIfOtnOTUkCfgL1Index—The level one index associated with the subject, for example, slot.
 - jnxIfOtnOTUkCfgL2Index—The level two index associated with the subject, for example, port.
 - jnxIfOtnOTUkCfgL3Index— The level three index associated with the subject, for example channel.
 - jnxIfOtnOTUkCfgRate— The rate for the interface, depending on the interface/fru type.
 - jnxIfOtnOTUkCfgFecMode—The FEC type in the OTU frame, the selection depends on the interface/fru type.
 - jnxIfOtnOTUkEnableAutoFrrByteInsert—Enable or disable the automatic insertion of the frr SF/SD byte in the overhead bytes(RES).
 - jnxIfOtnOTUkEnableBERFrrSupport—Enable or disable the FRR support for BER.
 - jnxIfOtnOTUkPreFecBERThresholdMantissa—Sets the BER threshold(mantissa), which when crossed triggers signal degrade.
 - jnxIfOtnOTUkPreFecBERThresholdExponent —Sets the BER threshold(exponent), which when crossed triggers signal degrade.
 - jnxIfOtnOTUkPreFecBERThresholdTime—The collection time to calculate the BER.
 - jnxIfOtnOTUkTIMActEnabled—Indicates whether or not the Trace Identifier Mismatch (TIM) consequent action function is enabled.
 - jnxIfOtnOTUkTxTTI— The Trace TTI SAPI 0..15, DAPI 16..31 32..63 user defined.
 - jnxIfOtnOTUkRxTTI— The Receive Trace TTI SAPI 0..15, DAPI 16..31 32..63 user defined.
 - jnxIfOtnOTUkExpectedRxSapi — Expected receive SAPI.
 - jnxIfOtnOTUkExpectedRxDapi-Expected receive DAPI.
 - jnxIfOtnOTUkStatus—The status of the interface.
 - jnxIfOtnOTUkPreFecBERThresholdClearMantissa—Sets the BER threshold(mantissa) for clear signal degrade condition, which signal degrade condition will be cleared when Pre-FEC error count is below the clear threshold error count.
 - jnxIfOtnOTUkPreFecBERThresholdClearExponent—Sets the BER threshold(exponent) for clear signal degrade condition, which signal degrade condition will be cleared when Pre-FEC error count is below the clear threshold error count.

- jnxIfOtnODUkCfgTable—This table provides information on the Otn ODUk configuration.
 - jnxIfOtnODUkCfgEntry—A conceptual row that contains information about the Otn ODUk configuration.
 - jnxIfOtnODUkCfgContainerIndex—The associated jnxContentsContainerIndex, for example, shelf.
 - jnxIfOtnODUkCfgL1Index—The level one index associated with this subject, for example slot.
 - jnxIfOtnODUkCfgL2Index—The level two index associated with the subject, for example, port.
 - jnxIfOtnODUkCfgL3Index—The level three index associated with the subject, for example channel.
 - jnxIfOtnODUkAPSPCC0—Read/Write APS PCC byte 0 for this ODUk only.
 - jnxIfOtnODUkAPSPCC1—Read/Write APS PCC byte 1 for this ODUk only.
 - jnxIfOtnODUkAPSPCC2—Read/Write APS PCC byte 2 for this ODUk only.
 - jnxIfOtnODUkAPSPCC3—Read/Write APS PCC byte 3 for this ODUk only.
 - jnxIfOtnODUkPayloadType—Read/Write Payload Type for ODUk only.
 - jnxIfOtnODUkTIMActEnabled—Indicates whether or not the Trace Identifier Mismatch (TIM) consequent action function is enabled. The default value of this object is false(2).
 - jnxIfOtnODUkTxTTI—The Trace TTI SAPI 0..15, DAPI 16..31 32..63 user defined for this layer.
 - jnxIfOtnODUkRxTTI—The Receive Trace TTI SAPI 0..15, DAPI 16..31 32..63 user defined.
 - jnxIfOtnODUkExpectedRxSapi—Expected receive SAPI for this layer.
 - jnxIfOtnODUkExpectedRxDapi—Expected receive DAPI for this layer.
 - jnxIfOtnODUkStatus—The status of the interface. Only some of these alarms are valid for the TCM layer.
 - jnxIfOtnODUkRxPayloadType—Receive payload type for ODUk only.
- jnxIfOtnTcmCfgTable—This table provides information on the Otn TCM configuration.
 - jnxIfOtnTcmCfgEntry—A conceptual row that contains information about the Otn Tcm configuration.
 - jnxIfOtnTcmCfgContainerIndex—The associated jnxContentsContainerIndex, for example shelf.
 - jnxIfOtnTcmCfgL1Index—The level one index associated with this subject, for example, slot.
 - jnxIfOtnTcmCfgL2Index—The level one index associated with this subject, for example, port.
 - jnxIfOtnTcmCfgL3Index—The level one index associated with this subject, for example, channel.
 - jnxIfOtnTcmCfgLevel—The TCM level for the table.
 - jnxIfOtnTCMEnable—Enable this TCM layer (only for TCM layers)
 - jnxIfOtnTcmTxTTI—The Trace TTI SAPI 0..15, DAPI 16..31 32 ..63 user defined for this layer.
 - jnxIfOtnTcmRxTTI—The Receive Trace TTI SAPI 0..15, DAPI 16..31 32 ..63 user defined for this layer.

- jnxIfOtnTcmExpectedRxSapi—Expected receive SAPI for this layer.
- jnxIfOtnTcmExpectedRxDapi—Expected receive DAPI for this layer.
- jnxIfOtnTcmStatus—Status of this layer.
- jnxIfOtnODUkTcmTestTable—This table provides information on the Otn ODUk test function.
 - jnxIfOtnODUkTcmTestEntry—A conceptual row that contains information about the Otn ODUk test function.
 - jnxIfOtnODUkTcmTestLayer—The OTU/ODU/TCM layer for the alarm.
 - jnxIfOtnODUkTcmTestTCMLevel—For ODUk will be this will be 0 If layer is TCM then this will give the TCM level 1..6.
 - jnxIfOtnODUkTcmInsertAis—Insert ODU Ais into OTN stream.
 - jnxIfOtnODUkTcmInsertLck—Insert ODU Lck into OTN stream.
 - jnxIfOtnODUkTcmInsertOci—Insert ODU Oci into OTN stream.
- jnxIfOtnODUkPayloadPRBS—Insert Payload PRBS, For ODUk layer and TCM level is 0.
- jnxIfOtnODUkPayloadPRBSResult—Result of the Payload PRBS.
- jnxIfOtnODUkTcmDMTable—Table for OTN ODUk/TCM Delay Measurement configuration table.
- jnxIfOtnODUkTcmDMEntry—A conceptual row that contains information about the Delay Measurement (DM) test table.
 - jnxIfOtnODUkTcmDMLayer—The layer OTU/ODU/TCM layer for the alarm
 - jnxIfOtnODUkTcmDMLevel—For ODUk, this value is 0, if layer is TCM then this gives the TCMlevel 1..6.
- jnxIfOtnDMConnectionMonitoringEndpoint—Originate Connection Monitoring Endpoint for the Delay Measurement.
- jnxIfOtnDMBypass—Act as tandem, passing DM value through node.
- jnxIfOtnDMPersistFrames—Number of consecutive frames required to declare DM Complete.
- jnxIfOtnDMEnable—Start/Stop the DM measurement.

Configuring Global Alarm Notifications

You can configure global e-mail notifications to be sent when any alarm with notifications enabled is generated. To configure global e-mail notifications, enter the e-mail addresses to receive global alarm notifications in the Alarm Notifications Destinations field in the Global Settings section. Separate addresses with a comma (,). For information about enabling notification for an alarm, see [“Configuring Individual Alarm Notifications” on page 165](#).

Retaining Alarm History

Use the **No. of days to keep Alarm** field in the Global Settings section to specify the number of days to keep alarm history. The default retention time is 120 days; but you can specify a period of 7 through 1000 days. Specifying a longer retention time consumes more database resources. To change the alarm retention duration, type a new value and click **OK** and **Yes** to confirm the change.

Specifying Event History

Use the **Events/Alarm** field in the Global Settings section to specify the number of event entries that are kept in the alarm history. The default setting for events is 20. To change the setting, type a new value and click **OK** and **Yes** to confirm the change.

Enabling Alarms

Ensure all devices are configured to send traps to Connectivity Services Director. This task is performed for the devices in Deploy mode through Set SNMP Trap Configuration.

Use the Individual Alarms and Threshold Settings section to disable and re-enable individual alarms or all alarms. Alarms appear on both tabs in the section: Alarm Settings and Threshold Settings. Fault alarms are preconfigured and initially enabled. To enable or disable alarms:

1. (Optional) Sort the alarms. By default, the list of alarms is sorted alphabetically within each category. You can also sort by description or alarm severity within a category by clicking a column heading.
2. Review the alarms and either select the check box in the heading to select all of the alarms or select the check box for the individual alarms you want to enable.
3. Click **OK** and **Yes** to confirm the alarm change.

Changing the Severity of Individual Alarms

You can change the severity of the alarms to match your corporate procedures and guidelines. For example, at your company a DoS attack might be considered a critical alarm, while Connectivity Services Director has a default severity for DoS attacks as a major alarm. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To change the severity of an alarm:

1. Select the current severity in the **Severity** column. A list of the severity levels appear.
2. Select the new severity level for the alarm.

3. Click **OK** and **Yes** to confirm the change to the severity setting.

To configure alarm notifications, see [“Configuring Individual Alarm Notifications” on page 165](#).

Configuring Individual Alarm Notifications

You can configure e-mail notifications to be sent when an individual alarm is generated. When you enable notification for an alarm, the notifications are sent to the e-mail addresses configured for the alarm and the addresses configured for global alarm notifications. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To configure e-mail notification for an alarm name:

1. Select the check box in the alarm's Notification column.

If you later want to disable notification for the alarm, clear the check box.

2. Click **Edit Notification** in the Notification column. The Alarm Notification Details window opens.

3. Enter one or more e-mail addresses in the Notification Email Addresses field. Separate addresses with a comma (,).

You can later edit the addresses to send notifications to different addresses.

4. (Optional) Enter a comment in the Comments field. This comment is included in the e-mail notification message.

5. Click **Save**.

RELATED DOCUMENTATION

| [Changing Alarm Settings for the Optics and OTN Interfaces](#) | 1614

Configuring and Monitoring Optical Inline Amplifiers

IN THIS CHAPTER

- Viewing a Graphical Image of Optical Inline Amplifier | 1627
- Viewing Optical ILA Configuration and Status Details for Simplified Administration | 1630
- Viewing Performance Monitoring Details of Optical ILAs for Detecting and Diagnosing Faults | 1634
- Configuring Threshold-Crossing Alarms for Optical ILAs for Monitoring Link Performance | 1642
- Changing Alarm Settings for the Optical ILAs | 1644

Viewing a Graphical Image of Optical Inline Amplifier

The Chassis View provides a pictorial representation of the optical inline amplifier (ILA) of a PTX Series router. The optical ILA is used in conjunction with the integrated photonic line card (IPLC) that is installed in the PTX3000 routers. The optical ILA operates with redundant hot-swappable pluggable power supplies, which are either AC or DC.

The purpose of this view is to try and provide a comprehensive monitoring view of the health and status of deployed devices across the network. In this view all the managed devices are shown with their appropriate status and health based on the services and device settings applied. This view helps the operator to know the health and status across the network, it provides with the operator to quickly see the macro level information, which allows the operator to further analyze the information provided and quickly navigate to individual devices and take any further corrective measure required. It provides a cohesive tool for the operator to quickly see the micro-level information and take any further remediation action required.

To view a graphical image of the optical ILA of PTX Series routers, and its associated components:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Click a particular component or interface to display the associated details in the lower portion of the page. The Rotate and Perspective buttons enable you to view the images in required orientation.
6. Click the View Back (arrows in a square symbol) icon to cause the device image to rotate along the x-axis and display the rear view of the device. Alternatively, click the View Front icon to view the front plane of the device. The View Back and View Front icons are toggle options.
7. Click the Perspective (cube symbol) icon to display the device image in three-dimensional format. It is a toggle button, which causes the device image to be shown in either three-dimensional or one-dimensional format.
8. Select the level of magnification of the image by clicking the Zoom (magnifying glass) icon. The image is expanded and displayed.

Alternatively, use the slider control beneath the Zoom icon to change the level of magnification.
9. Click the home icon to return to the front view of the chassis. The selected interface is surrounded with a colored outline based on the operational status. An interface that is operationally up is denoted in green and an interface that is operationally down is represented in red. The components are depicted as small colored icons at the top-left corner of the front view of the equipment image.

In the graphical image of the device displayed, you can mouse over the different parts of the device, such as the interfaces, line cards, and slots. When you mouse over the different modules, their corresponding details are displayed as tooltips. On clicking the device components, the corresponding description for the selected component is displayed by default in the Component Info pane and the Equipment tab with the following values.

- Description—Configured textual description of the component.
- Manufacturer—Name of the company that built and shipped the device.
- Model—Model of the FRU component.
- Name—Name of the chassis component.

- Part number—Part number of the chassis component.
- Serial number—Serial number of the chassis component. The serial number of the backplane is also the serial number of the router or switch chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

The Component Info pane and the Active Alarms monitor are displayed in the lower portion of the page.

The Active Alarms monitor shows any active alarm that has not yet been cleared. You can view the alarm name, the unique identifier assigned to the alarm, the person to which the alarm is assigned for corrective action, and the severity of the alarm. Click the **Launch Alarm Mgmt** icon (right upward-slanting arrow enclosed in a square) to navigate to the Fault mode and view the four standard alarm monitors available in Fault mode.

Active Alarms for the respective components are displayed when the component is clicked in the image of the chassis displayed. The components for which the alarms are displayed are Flexible Port Concentrator (FPC), Dense Port Concentrator (DPC), Physical Interface Card (PIC), Modular Interface Card (MIC), Routing Engine, Control Boards, fan trays, Switch Interface Board (SIB), and power supply module (PSM).

The following fields are displayed in the Active Alarms pane:

Table 232: Active Alarms Monitor

Table Column	Description
Severity	<p>The severity of the alarm. Severity levels are:</p> <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary.
Name	The alarm name.
Source	<p>The IP address of the device or network element that generated the alarm. The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.</p>
Last Updated	The date and time that the information for the alarm was last modified.

From the Chassis View window, click the **Details** icon (arrow enclosed in a square) at the top-right corner of the window to open the Chassis View Details page that lists the configured devices and their parameters in the form of a table.

Click the **Apply Configlet** button (pencil icon displayed beside the button) and use the links shown on the components in Chassis View to select the context and apply configlets.

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[About Chassis View | 1383](#)

Viewing Optical ILA Configuration and Status Details for Simplified Administration

Instead of using Junos OS CLI statements and operational commands to view optical ILA parameters, you can view an image of the optical ILA using Connectivity Services Director to obtain an intuitive and high-level understanding of the settings and alarms. This view enables you to modify the optical ILA settings to suit your network deployment needs in a simplified and optimal manner. Because the important optical ILA settings can be viewed alongside the visual representation of the entire chassis that is displayed, this method of managing the optical ILA settings provides a consolidated and cohesive interface for easy administration of the network.

To view the optical ILA configuration and status information:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.
2. From the View selector, select **Device View**.
The functionalities that you can configure in this view are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to view the optical ILA settings.
The network tree is expanded and the selected device is highlighted.
4. From the Tasks pane, select **Device Management > View Physical Inventory**.
An image of the device is displayed on the right pane.
5. In the image of the device, select an optical ILA.
The ILA Optics dialog box is displayed at the lower part of the page. At the bottom of the dialog box, the Equipment, Status/Config, and Performance tabs are displayed.
6. Click the **Status/Config** tab at the bottom of the dialog box.

The configuration settings that pertain to the optical ILA are displayed in the ILA and EDFA panes. The ILA pane is expanded and displayed by default.

7. View the following details under different sections of the ILA pane.

- In the System section, the following parameters are displayed:
 - Status—Operation status of the optical ILA in conjunction with the optical IPLC installed in the FPC or PIC slot
 - Current Mode—Mode of operation of the optical ILA, such as auto
 - Board Temperature (Celsius)—Temperature of the device in Celsius

- Power—The power supplies need to be both AC or both DC. Only one power supply is required to power on the device; the second power supply provides redundancy. When the optical ILA has both power supplies installed and connected to the power supply, the device has full power redundancy. If a power supply fails or is removed, another power supply balances the electrical load without interruption. Each power supply provides 12-voltage direct current (VDC) output with a standby voltage of 12 VDC. The power supplies can be hot-swapped—you do not need to power off the router or disrupt the routing function to replace a power supply.

- PowerAC—Indicates whether the AC power supply is connected or removed

The AC power supplies in the optical ILA are hot-removable, and hot-insertable field-replaceable units (FRUs) that you can install without powering off the device or disrupting the routing function. The optical ILA has two power supplies. All of the power supplies are initially installed at the factory. Each of the 150-W power supplies has a single AC input. An optical ILA has twice the number of power supplies needed to power all the components in the device, which is known as 1+1 *n* redundancy.

- PowerDC—Indicates whether the DC power supply is connected or removed

The DC power supplies in the optical ILA are hot-removable and hot-insertable field-replaceable units (FRUs) that you can install without powering off the device or disrupting the routing function. The optical ILA has two power supplies. Both of the power supplies are initially installed at the factory. Each of the two 150-W power supplies has a single DC input. An optical ILA has twice the number of power supplies needed to power all the components in the device, which is known as 1+1 *n* redundancy.

- Fan—The cooling system in an optical ILA consists of three 80-W fan modules. Each fan module has dual-counter rotating fans. These fan modules can be hot-swapped—you do not need to power off the router or disrupt routing function to replace a fan module.
 - Fan 1—Speed of fan 1 in revolutions per minute (rpm). Fan speed status is based on different chassis cooling requirements, such as spinning at high speed, intermediate speed, normal speed, or low speed.
 - Fan 2—Speed of fan 2 in rpm

- Fan 3—Speed of fan 3 in rpm
- OSC—Displays the details of the two optical supervisory channel (OSCs) that are part of the optical ILA
 - A—Displays the transmitted and received optical power, in milliwatts (mW) and decibels referred to 1.0 mW (dBm), for the OSC A.
 - Tx Power (dBm)—Transmit laser output power (dBm) of OSC A
 - Rx Power (dBm)—Received laser input power (dBm) of OSC A
 - B—Displays the transmitted and received optical power, in milliwatts (mW) and decibels referred to 1.0 mW (dBm), for the OSC B.
 - Tx Power (dBm)—Transmit laser output power (dBm) of OSC B
 - Rx Power (dBm)—Received laser input power (dBm) of OSC B

8. Click the **EDFA** header at the bottom of the dialog box.

The EDFA pane is expanded and displayed, which shows the erbium-doped fiber amplifier (EDFA) properties for the ILA with the integrated photonic line card (IPLC) module installed in the FPC or PIC slot.

9. View the following details under different sections of the EDFA pane.

- A-B—Configuration and status settings of the EDFA in the direction from OSC A to OSC B
 - Status—Operational status of the EDFA in the direction from OSC A to OSC B
 - Working Status—Working condition of the EDFA, such as output disabled or automatic power reduction (APR) deactivated
 - Actual Gain (dB)—Gain or signal strength increase in decibels (dB) in the direction from OSC A to OSC B. The actual gain depends on the impedance of the attached device. An input power higher than -5 dBm can result in an alarm that can be cleared by correctly setting the gain value.
 - Gain Range—Range of gain, such as high or low, in the direction from OSC A to OSC B
 - Power (dBm)—Power specifications for the EDFA of the optical ILA in the direction from OSC A to OSC B
 - Upstream Output Power—Output power to the upstream network elements in the direction from OSC A to OSC B
 - Input Power—Current input power in the direction from OSC A to OSC B

- Output Power—Current output power in the direction from OSC A to OSC B
- Downstream Input Power—Input power to the downstream network elements in the direction from OSC A to OSC B
- Voa—Attenuation specifications of the optical ILA in the direction from OSC A to OSC B
 - Attenuation (dB)—Amount of reduction in transmitted power of the light signal in dB of the variable optical attenuator (VOA) present in the optical ILA in the direction from OSC A to OSC B
- B-A—Configuration and status settings of the EDFA in the reverse direction from OSC B to OSC A
 - Status—Operational status of the EDFA in the reverse direction from OSC B to OSC A
 - Working Status—Working condition of the EDFA, such as output disabled or ARP deactivated
 - Actual Gain (dB)—Gain or signal strength increase in decibels (dB) in the reverse direction from OSC B to OSC A. The actual gain depends on the impedance of the attached device. An input power higher than -5 dBm can result in an alarm that can be cleared by correctly setting the gain value.
 - Gain Range—Range of gain, such as high or low, in the reverse direction from OSC B to OSC A
 - Power (dBm)—Power specifications for the EDFA of the optical ILA in the reverse direction from OSC B to OSC A
 - Upstream Output Power—Output power to the upstream network elements in the reverse direction from OSC B to OSC A
 - Input Power—Current input power in the reverse direction from OSC B to OSC A
 - Output Power—Current output power in the reverse direction from OSC B to OSC A
 - Downstream Input Power—Input power to the downstream network elements in the reverse direction from OSC B to OSC A
 - Voa—Attenuation specifications of the optical ILA in the direction from OSC B to OSC A
 - Attenuation (dB)—Amount of reduction in transmitted power of the light signal in dB of the variable optical attenuator (VOA) present in the optical ILA in the direction from OSC B to OSC A

10. Click **Update** at the top of the dialog box to save the modified ILA settings. Alternatively, click **Cancel** to discard the changes.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

[Viewing a Graphical Image of Optical Inline Amplifier | 1627](#)

[Viewing Performance Monitoring Details of Optical ILAs for Detecting and Diagnosing Faults | 1634](#)

[Configuring Threshold-Crossing Alarms for Optical ILAs for Monitoring Link Performance | 1642](#)

[Changing Alarm Settings for the Optical ILAs | 1644](#)

Viewing Performance Monitoring Details of Optical ILAs for Detecting and Diagnosing Faults

To analyze and resolve any faults associated with optical inline amplifiers (ILAs), it is essential to view the diagnostic data, warnings, and alarms for transport performance monitoring. The different types of parameters related to performance monitoring that are retrieved from the optical ILAs enable you to ensure service availability and verify or monitor individual services and the service network performance.

The performance monitoring capability in Connectivity Services Director displays information about the health of your network and changing conditions of your optical ILAs. Use this diagnosis and detection mechanism to identify problems with the equipment, pinpoint security attacks, or to analyze trends and categories of errors. This feature includes fault-monitoring details in the dashboard, in monitoring pages, and on a dedicated page that displays alarms, events, and system log messages that are generated. Performance monitoring parameters can be viewed in both chart and statistical formats. These charts and statistical details provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity. You can assess the performance of your network, not only at a point in time, but also over a period of time. This feature enables you to determine trending and network-health parameters; for example, whether service-level agreements (SLAs) have been violated.

To view the performance monitoring details of optical ILAs:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical ILA settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an optical ILA in the image of the device.

The ILA Optics dialog box is displayed at the lower part of the page, which contains the Equipment, Status/Config, and Performance tabs.

6. Click the **Performance** tab at the bottom of the pane.

The Perf Mon tab of the ILA Optics PMs dialog box is displayed.

The following fields are displayed in the Perf Mon tab of the ILA Optics PMs dialog box. The date and time at which the dialog box was last refreshed is shown.

NOTE: Pump Turn-Down During a Loss of Signal— If LOS (Loss of Signal) is detected based on lack of receipt of the OSC signal at the input port of an amplifier, then the amplifier must turn down its pumps (to achieve no more than 0dBm total output power), until it detects receipt of a valid OSC signal at its input port. Likewise, if an upstream amplifier receives an OSC message from the downstream node that the OSC signal was not received downstream (LOS was declared downstream), it must also turn down its own pumps (to achieve no more than 0dBm total output power) until it receives an OSC message that the fault has cleared. Therefore, in addition to the automatic power reduction (APR) algorithm, the ILA software must keep the amplifier pumps disabled until a fiber connection is confirmed between the ILA output port and the input to the downstream optical node. This fiber connection is confirmed using the “handshaking” messages exchanged over Optical Supervisor Channel (OSC). This behavior occurs during amplifier turn-up and during ongoing operation.

Local LOS—The software reads the LOS status for incoming signal from SFP. This LOS status can be used to shut off the amplifier pump. When local LOS is cleared, pumps need to be turned on again.

Remote LOS—Incoming LOS status is conveyed to OSC_FPGA. OSC_FPGA in turn sends this status to nextnode through some overhead bits. The next node OSC_FPGA would read the overhead bits and puts it in its “Remote LOS” register. OSC_FPGA also forwards the remote LOS status further down the chain through overhead bits in the same way. The software can read the “Remote LOS” value and take appropriate action of turning the amplifier pump on or off.

- Optical EDFA AB Input Power—Received input power of the optical erbium-doped fiber amplifier (EDFA) in the direction from optical supervisory channel (OSC) A to OSC B

EDFA AB Input Power—Received laser optical input power

EDFA AB Input Power-Min—Minimum received input power

EDFA AB Input Power-Avg—Average received laser power

EDFA AB Input Power-Max—Maximum received input power

- Optical EDFA AB Output Power—Transmitted output power of the optical EDFA in the direction from OSC A to OSC B

EDFA AB Output Power—Transmitted laser optical output power

EDFA AB Output Power-Min—Minimum transmitted laser output power

EDFA AB Output Power-Avg—Average transmitted laser output power

EDFA AB Output Power-Max—Maximum transmitted laser output power

- Optical EDFA AB Signal Output Power—Signal output power of the optical EDFA in the direction from OSC A to OSC B

EDFA AB Signal Output Power—Signal laser optical output power

EDFA AB Signal Output Power-Min—Minimum signal laser output power

EDFA AB Signal Output Power-Avg—Average signal laser output power

EDFA AB Signal Output Power-Max—Maximum signal laser output power

- Optical EDFA AB Pump1 Current—Pump1 current of the EDFA in the direction from OSC A to OSC B

EDFA AB Pump1 Current—Pump1 current of the EDFA from OSC A to OSC B

EDFA AB Pump1 Current-Min—Minimum pump1 current of the EDFA

EDFA AB Pump1 Current-Avg—Average pump1 current of the EDFA

EDFA AB Pump1 Current-Max—Maximum pump1 current of the EDFA

- Optical EDFA AB Pump1 Temperature—Pump1 temperature of the EDFA in the direction from OSC A to OSC B

EDFA AB Pump1 Temperature—Pump1 temperature of the EDFA from OSC A to OSC B

EDFA AB Pump1 Temperature-Min—Minimum pump1 temperature of the EDFA

EDFA AB Pump1 Temperature-Avg—Average pump1 temperature of the EDFA

EDFA AB Pump1 Temperature-Max—Maximum pump1 temperature of the EDFA

- Optical EDFA AB Pump2 Current—Pump2 current of the EDFA in the direction from OSC A to OSC B

- EDFA AB Pump2 Current—Pump2 current of the EDFA from OSC A to OSC B
- EDFA AB Pump2 Current-Min—Minimum pump2 current of the EDFA
- EDFA AB Pump2 Current-Avg—Average pump2 current of the EDFA
- EDFA AB Pump2 Current-Max—Maximum pump2 current of the EDFA
- Optical EDFA AB Pump2 Temperature—Pump2 temperature of the EDFA in the direction from OSC A to OSC B
 - EDFA AB Pump2 Temperature—Pump2 temperature of the EDFA from OSC A to OSC B
 - EDFA AB Pump2 Temperature-Min—Minimum pump2 temperature of the EDFA
 - EDFA AB Pump2 Temperature-Avg—Average pump2 temperature of the EDFA
 - EDFA AB Pump2 Temperature-Max—Maximum pump2 temperature of the EDFA
- Optical EDFA BA Input Power—Received input power of the optical erbium-doped fiber amplifier (EDFA) in the direction from optical supervisory channel (OSC) B to OSC A
 - EDFA BA Input Power—Received laser optical input power
 - EDFA BA Input Power-Min—Minimum received input power
 - EDFA BA Input Power-Avg—Average received laser power
 - EDFA BA Input Power-Max—Maximum received input power
- Optical EDFA BA Output Power—Transmitted output power of the optical EDFA in the direction from OSC B to OSC A
 - EDFA BA Output Power—Transmitted laser optical output power
 - EDFA BA Output Power-Min—Minimum transmitted laser output power
 - EDFA BA Output Power-Avg—Average transmitted laser output power
 - EDFA BA Output Power-Max—Maximum transmitted laser output power
- Optical EDFA BA Signal Output Power—Signal output power of the optical EDFA in the direction from OSC B to OSC A
 - EDFA BA Signal Output Power—Signal laser optical output power
 - EDFA BA Signal Output Power-Min—Minimum signal laser output power
 - EDFA BA Signal Output Power-Avg—Average signal laser output power
 - EDFA BA Signal Output Power-Max—Maximum signal laser output power
- Optical EDFA BA Pump1 Current—Pump1 current of the EDFA in the direction from OSC B to OSC A
 - EDFA BA Pump1 Current—Pump1 current of the EDFA from OSC B to OSC A
 - EDFA BA Pump1 Current-Min—Minimum pump1 current of the EDFA

- EDFA BA Pump1 Current-Avg—Average pump1 current of the EDFA
- EDFA BA Pump1 Current-Max—Maximum pump1 current of the EDFA
- Optical EDFA BA Pump1 Temperature—Pump1 temperature of the EDFA in the direction from OSC B to OSC A
 - EDFA BA Pump1 Temperature—Pump1 temperature of the EDFA from OSC B to OSC A
 - EDFA BA Pump1 Temperature-Min—Minimum pump1 temperature of the EDFA
 - EDFA BA Pump1 Temperature-Avg—Average pump1 temperature of the EDFA
 - EDFA BA Pump1 Temperature-Max—Maximum pump1 temperature of the EDFA
- Optical EDFA BA Pump2 Current—Pump2 current of the EDFA in the direction from OSC B to OSC A
 - EDFA BA Pump2 Current—Pump2 current of the EDFA from OSC B to OSC A
 - EDFA BA Pump2 Current-Min—Minimum pump2 current of the EDFA
 - EDFA BA Pump2 Current-Avg—Average pump2 current of the EDFA
 - EDFA BA Pump2 Current-Max—Maximum pump2 current of the EDFA
- Optical EDFA BA Pump2 Temperature—Pump2 temperature of the EDFA in the direction from OSC B to OSC A
 - EDFA BA Pump2 Temperature—Pump2 temperature of the EDFA from OSC B to OSC A
 - EDFA BA Pump2 Temperature-Min—Minimum pump2 temperature of the EDFA
 - EDFA BA Pump2 Temperature-Avg—Average pump2 temperature of the EDFA
 - EDFA BA Pump2 Temperature-Max—Maximum pump2 temperature of the EDFA
- Optical OSC A Fiber Loss—Fiber loss of OSC A
 - Optical OSC A Fiber Loss—Fiber loss of OSC A
 - Optical OSC A Fiber Loss-Min—Minimum fiber loss of OSC A
 - Optical OSC A Fiber Loss-Avg—Average fiber loss of OSC A
 - Optical OSC A Fiber Loss-Max—Maximum fiber loss of OSC A
- Optical OSC A Tx Power—Transmitted power of OSC A
 - Optical OSC A Tx Power—Transmitted power of OSC A
 - Optical OSC A Tx Power-Min—Minimum transmitted power of OSC A
 - Optical OSC A Tx Power-Avg—Average transmitted power of OSC A
 - Optical OSC A Tx Power-Max—Maximum transmitted power of OSC A
- Optical OSC A Rx Power—Recieved power of OSC A
 - Optical OSC A Rx Power—Recieved power of OSC A

- Optical OSC A Rx Power-Min—Minimum received power of OSC A
- Optical OSC A Rx Power-Avg—Average received power of OSC A
- Optical OSC A Rx Power-Max—Maximum received power of OSC A
- Optical OSC B Fiber Loss—Fiber loss of OSC B
 - Optical OSC B Fiber Loss—Fiber loss of OSC B
 - Optical OSC B Fiber Loss-Min—Minimum fiber loss of OSC B
 - Optical OSC B Fiber Loss-Avg—Average fiber loss of OSC B
 - Optical OSC B Fiber Loss-Max—Maximum fiber loss of OSC B
- Optical OSC B Tx Power—Transmitted power of OSC B
 - Optical OSC B Tx Power—Transmitted power of OSC B
 - Optical OSC B Tx Power-Min—Minimum transmitted power of OSC B
 - Optical OSC B Tx Power-Avg—Average transmitted power of OSC B
 - Optical OSC B Tx Power-Max—Maximum transmitted power of OSC B
- Optical OSC B Rx Power—Received power of OSC B
 - Optical OSC B Rx Power—Received power of OSC B
 - Optical OSC B Rx Power-Min—Minimum received power of OSC B
 - Optical OSC B Rx Power-Avg—Average received power of OSC B
 - Optical OSC B Rx Power-Max—Maximum received power of OSC B

On the Perf Mon tab, for the TCA column, either a minus sign (–) is displayed that denotes that an alarm for threshold-exceed is not configured or a check mark is displayed and grayed out that indicates that the TCA for the particular attribute is configured.

7. In the 15 Mins column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the last 15 minutes. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 15-minute interval. By default, 96 records of 15-minute intervals are displayed.

A 15-Min *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

8. Click the **15 Mins *parameter name*** tab.
 - a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date and time along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.

The records are displayed in tabular format. A serial number of the count of entries, the day, month, and year at which the entry was collected, and the time at which the entry was collected are displayed. The timestamp is the UTC time in the database that is mapped to the local time zone of the client computer.

- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search.
 - Click **Reload** to refresh the contents and display the updated information for the specified time period.
 - Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
 - Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
 - Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 15-Min *parameter-name* tab.
9. In the 24-Hrs column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the previous day. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 24-hour interval. By default, records pertaining to the last 30 days are displayed when you view the performance monitoring counters for the 24-hour duration.

A 24 Hours *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs page.

10. Click the **24 Hours *parameter name*** tab.

a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.
- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search. Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
- Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 24 Hours *parameter-name* tab.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest performance monitoring statistics to be polled and displayed.

RELATED DOCUMENTATION

[Viewing a Graphical Image of Optical Inline Amplifier | 1627](#)

[Viewing Optical ILA Configuration and Status Details for Simplified Administration | 1630](#)

[Configuring Threshold-Crossing Alarms for Optical ILAs for Monitoring Link Performance | 1642](#)

[Changing Alarm Settings for the Optical ILAs | 1644](#)

Configuring Threshold-Crossing Alarms for Optical ILAs for Monitoring Link Performance

By monitoring the performance of links, you ensure that an end-to-end Ethernet service is always available over any path for a single link or multiple links spanning networks composed of multiple LANs. Link performance metrics enable operators to offer binding service-level agreements (SLAs) and generate new revenues from rate- and performance-guaranteed service packages that are customized to meet specific needs of their customers. To monitor link performance, you need to configure threshold-crossing alarms (TCAs) for optical inline amplifiers (ILAs)

TCAs are alarms that are activated when a certain configurable threshold—near-end measurement threshold or far-end measurement threshold—is crossed and remains so until the end of the 15-minute interval and the 24-hour interval for parameters such as the optical OLA. A near-end measurement is associated with ingress data frames and a far-end measurement is associated with egress data frames.

You can configure TCAs for both the minimum and maximum values for gauges and the maximum values for counters. A gauge represents a non-negative integer, which may increase or decrease, but never exceeds a maximum value. A gauge has its maximum value whenever the information being modeled is greater than or equal to the maximum value. If the TCA parameter subsequently goes below the maximum value, the gauge also decreases. A counter represents a non-negative integer that monotonically increases until it reaches a maximum value of $2^{32}-1$.

The timely detection of TCAs is essential to proactively manage an interface. TCAs are not an indication of a fault, but rather an indication that the entity may be close to a fault. You can enable the TCA that you want monitor. You can keep the default threshold settings or change the settings.

To configure the TCAs for optical ILA parameters:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner. The workspaces that are applicable to Build mode are displayed on the Tasks pane.

4. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

5. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

6. Select an optical ILA in the image of the device.

The ILA Optics dialog box is displayed, which contains the Equipment, Status/Config, and Performance tabs. For example, if you select an optical inline optical amplifier (ILA), which is used in conjunction with the integrated photonic line card (IPLC) that is installed in the PTX3000 routers, the optical ILA Optics dialog box is displayed beneath the graphical view of the chassis. The Equipment, Status/Config, and Performance tabs are displayed at the bottom of the page.

7. Click the **Performance** tab at the bottom of the pane. The Optics PMs dialog box is displayed with the performance monitoring counters and metrics that pertain to the optical ports. This dialog box contains the Perf Mon and TCA Config tabs.

8. Click the TCA Config tab to configure the TCAs for the different optical ILA attributes. The dialog box is refreshed to display the different performance monitoring parameters. These parameters can be edited inline.

Inline editing enables you to modify previously defined settings easily and quickly. Embedded editing is enabled, which causes the grids showing the devices and interfaces to become modifiable directly; you do not need to highlight, edit, and save the changes every time.

A gray triangle in the upper-right corner of a field denotes that the value of that field or attribute has been modified.

9. For the parameters under each performance monitoring category for which you want to modify the TCA value, click the value in the Threshold-15Min or Threshold-24Hr columns to set the TCA value for the 15-minute interval or 24-hour interval. You can also select Yes or No in the Enable column to enable or disable the TCA value for the specified parameter.

10. Click **Update** to save the configured threshold settings. Alternatively, click **Cancel** to discard the configuration.

RELATED DOCUMENTATION

[Viewing a Graphical Image of Optical Inline Amplifier | 1627](#)

[Viewing Optical ILA Configuration and Status Details for Simplified Administration | 1630](#)

[Viewing Performance Monitoring Details of Optical ILAs for Detecting and Diagnosing Faults | 1634](#)

[Changing Alarm Settings for the Optical ILAs | 1644](#)

Changing Alarm Settings for the Optical ILAs

IN THIS SECTION

- [Alarms for Optical ILAs | 1645](#)
- [Configuring Global Alarm Notifications | 1647](#)
- [Retaining Alarm History | 1647](#)
- [Specifying Event History | 1648](#)
- [Enabling Alarms | 1648](#)
- [Changing the Severity of Individual Alarms | 1648](#)
- [Configuring Individual Alarm Notifications | 1649](#)

You can modify the configuration settings for alarm settings of optical inline amplifiers (ILAs) using the Preferences page of the Connectivity Services Director application. To open the Preferences page, click the down arrow next to the System button in the Connectivity Services Director banner and select Preferences. The Preferences page opens with User Preferences as the default tab. Click the Fault tab of the Preferences page of the Connectivity Services Director GUI to enable individual alarms, set the retention period for alarms, configure alarm notifications, and to specify the number of events to keep for each alarm. The Fault tab has multiple sections, which you can expand and collapse by clicking the arrow next to the section title:

- Global Settings, for configuring Faults settings such as global alarm notifications and alarm data retention.

- Individual Alarms and Threshold Settings, for configuring settings for individual alarms.

Alarms for Optical ILAs

The following alarms are applicable for management of the optical ILA:

Alarm Name	Description
ILA::edfaEabCaliTableErr	Generated when the EDFA in the direction from optical supervisory channel (OSC) A to OSC B (Eab) has a calibration table error.
ILA::edfaEabCaseTemperature	Generated when the EDFA case temperature exceeds the configured threshold in the direction from OSC A to OSC B.
ILA::edfaEabInputLOS	Generated when the input loss of signal (LOS) is detected in the direction from OSC A to OSC B.
ILA::edfaEabOOG	Generated when the out-of-service out-of-gain (OOS OOG) condition occurs in the direction from OSC A to OSC B.
ILA::edfaEabOOP	Generated when the out-of-power (OOP) condition occurs in the direction from OSC A to OSC B.
ILA::edfaEabOutputLOS	Generated when an output LOS condition occurs in the direction from OSC A to OSC B.
ILA::edfaEabPump1EOL	Generated when the end-of-life (EoL) state for pump 1 of the EDFA occurs in the direction from OSC A to OSC B.
ILA::edfaEabPump2EOL	Generated when the end-of-life (EoL) state for pump 2 of the EDFA occurs in the direction from OSC A to OSC B.
ILA::edfaEabPump1Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC A to OSC B.
ILA::edfaEabPump2Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC A to OSC B.
ILA::edfaEabRFL	Generated when the radio frequency loss (RFL) occurs for the EDFA occurs in the direction from OSC A to OSC B.
ILA::edfaEbaCaliTableErr	Generated when the EDFA in the direction from optical supervisory channel (OSC) B to OSC A (Eba) has a calibration table error.

Alarm Name	Description
ILA::edfaEbaCaseTemperature	Generated when the EDFA case temperature exceeds the configured threshold in the direction from OSC B to OSC A.
ILA::edfaEbaInputLOS	Generated when the input loss of signal (LOS) is detected in the direction from OSC B to OSC A.
ILA::edfaEbaOOG	Generated when the out-of-gain (OOG) condition occurs in the direction from OSC B to OSC A.
ILA::edfaEbaOOP	Generated when the out-of-power (OOP) condition occurs in the direction from OSC B to OSC A.
ILA::edfaEbaOutputLOS	Generated when an output LOS condition occurs in the direction from OSC B to OSC A.
ILA::edfaEbaPump1EOL	Generated when the end-of-life (EoL) state for pump 1 of the EDFA occurs in the direction from OSC B to OSC A.
ILA::edfaEbaPump2EOL	Generated when the end-of-life (EoL) state for pump 2 of the EDFA occurs in the direction from OSC B to OSC A.
ILA::edfaEbaPump1Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC B to OSC A.
ILA::edfaEbaPump2Temperature	Generated when the temperature exceeds the threshold for pump 1 of the EDFA occurs in the direction from OSC B to OSC A.
ILA::edfaEbaRFL	Generated when the radio frequency loss (RFL) occurs for the EDFA occurs in the direction from OSC B to OSC A.
ILA::ilaBoardTemperatureAbnormal	Generated when the ILA board temperature reaches an abnormal level.
ILA::ilaCommunicationAbnormal	Generated when the communication channel between the NMS system and the ILA reaches an abnormal level.
ILA::ilaACPowerAbnormal	Generated when the ILA AC power reaches an abnormal level.
ILA::ilaDCPowerAbnormal	Generated when the ILA DC power reaches an abnormal level.
ILA::ilaFan1OnlineAbnormal	Generated when the ILA fan tray controller 1 that is online reaches an abnormal level.

Alarm Name	Description
ILA::ilaFan1SpeedAbnormal	Generated when the speed of the optical ILA fan tray controller 1 reaches an abnormal level.
ILA::ilaFan2OnlineAbnormal	Generated when the ILA fan tray controller 1 that is online reaches an abnormal level.
ILA::ilaFan2SpeedAbnormal	Generated when the speed of the optical ILA fan tray controller 1 reaches an abnormal level.
ILA::ilaFan3OnlineAbnormal	Generated when the ILA fan tray controller 1 that is online reaches an abnormal level.
ILA::ilaFan3SpeedAbnormal	Generated when the speed of the optical ILA fan tray controller 1 reaches an abnormal level.
ILA::ilaSoftwareVersionAbnormal	Generated when the ILA software version reaches an abnormal level.
ILA::ilaTableErr	Generated when the ILA table error occurs.
ILA::oscaAddPowerLOS	Generated when the addition of power LOS condition occurs for the OSC A.
ILA::oscaDropPowerLOS	Generated when the dropping of power LOS condition occurs for the OSC A.
ILA::oscbAddPowerLOS	Generated when the addition of power LOS condition occurs for the OSC B.
ILA::oscbDropPowerLOS	Generated when the dropping of power LOS condition occurs for the OSC B.

Configuring Global Alarm Notifications

You can configure global e-mail notifications to be sent when any alarm with notifications enabled is generated. To configure global e-mail notifications, enter the e-mail addresses to receive global alarm notifications in the Alarm Notifications Destinations field in the Global Settings section. Separate addresses with a comma (,). For information about enabling notification for an alarm, see [“Configuring Individual Alarm Notifications” on page 165](#).

Retaining Alarm History

Use the **No. of days to keep Alarm** field in the Global Settings section to specify the number of days to keep alarm history. The default retention time is 120 days; but you can specify a period of 7 through 1000

days. Specifying a longer retention time consumes more database resources. To change the alarm retention duration, type a new value and click **OK** and **Yes** to confirm the change.

Specifying Event History

Use the **Events/Alarm** field in the Global Settings section to specify the number of event entries that are kept in the alarm history. The default setting for events is 20. To change the setting, type a new value and click **OK** and **Yes** to confirm the change.

Enabling Alarms

Ensure all devices are configured to send traps to Connectivity Services Director. This task is performed for the devices in Deploy mode through Set SNMP Trap Configuration.

Use the Individual Alarms and Threshold Settings section to disable and re-enable individual alarms or all alarms. Alarms appear on both tabs in the section: Alarm Settings and Threshold Settings. Fault alarms are preconfigured and initially enabled. To enable or disable alarms:

1. (Optional) Sort the alarms. By default, the list of alarms is sorted alphabetically within each category. You can also sort by description or alarm severity within a category by clicking a column heading.
2. Review the alarms and either select the check box in the heading to select all of the alarms or select the check box for the individual alarms you want to enable.
3. Click **OK** and **Yes** to confirm the alarm change.

Changing the Severity of Individual Alarms

You can change the severity of the alarms to match your corporate procedures and guidelines. For example, at your company a DoS attack might be considered a critical alarm, while Connectivity Services Director has a default severity for DoS attacks as a major alarm. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To change the severity of an alarm:

1. Select the current severity in the **Severity** column. A list of the severity levels appear.
2. Select the new severity level for the alarm.
3. Click **OK** and **Yes** to confirm the change to the severity setting.

To configure alarm notifications, see [“Configuring Individual Alarm Notifications” on page 165](#).

Configuring Individual Alarm Notifications

You can configure e-mail notifications to be sent when an individual alarm is generated. When you enable notification for an alarm, the notifications are sent to the e-mail addresses configured for the alarm and the addresses configured for global alarm notifications. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To configure e-mail notification for an alarm name:

1. Select the check box in the alarm's Notification column.

If you later want to disable notification for the alarm, clear the check box.

2. Click **Edit Notification** in the Notification column. The Alarm Notification Details window opens.

3. Enter one or more e-mail addresses in the Notification Email Addresses field. Separate addresses with a comma (,).

You can later edit the addresses to send notifications to different addresses.

4. (Optional) Enter a comment in the Comments field. This comment is included in the e-mail notification message.

5. Click **Save**.

RELATED DOCUMENTATION

[Viewing a Graphical Image of Optical Inline Amplifier | 1627](#)

[Viewing Optical ILA Configuration and Status Details for Simplified Administration | 1630](#)

[Viewing Performance Monitoring Details of Optical ILAs for Detecting and Diagnosing Faults | 1634](#)

[Configuring Threshold-Crossing Alarms for Optical ILAs for Monitoring Link Performance | 1642](#)

Configuring and Monitoring Optical Integrated Photonic Line Cards

IN THIS CHAPTER

- Viewing a Graphical Image of the Optical Integrated Photonic Line Card | 1650
- Configuring Optical IPLC for Easy and Optimal Deployment | 1654
- Viewing Performance Monitoring Details of Optical IPLCs for Detecting and Diagnosing Faults | 1661
- Configuring Threshold-Crossing Alarms for Optical IPLCs for Monitoring Link Performance | 1668
- Increasing the Add and Drop Port Capacity of the IPLC Node to 64 Channels | 1670
- Configuring a Two-Degree IPLC Node for Express Traffic by Increasing the Line Capacity | 1672
- Configuring Optical IPLC Line Connectivity for Interoperation with Optical ILAs | 1674
- Configuring the Wavelengths That Are Added and Dropped by the IPLC | 1679
- Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on a Remote Chassis | 1684
- Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on the Same Chassis | 1686
- Bypassing a Wavelength on the IPLC | 1687
- Changing Alarm Settings for the Optical IPLCs | 1689
- Viewing Routing Engine Switchover Indicators in the Chassis Image | 1697
- Viewing Alarm Indicators in the Chassis Image | 1699
- Viewing Port Statistics for OTN PICs | 1700
- Example: Configuring Two Fiber Line Terminations Using IPLCs for Optical Amplification in a Metro Linear Packet Optical Network | 1704

Viewing a Graphical Image of the Optical Integrated Photonic Line Card

The Chassis View provides a pictorial representation of the optical integrated photonic line card (IPLC) of a PTX Series router. The optical ILA is used in conjunction with the IPLC that is installed in the PTX3000 Packet Transport Routers. The optical ILA operates with redundant hot-swappable pluggable power supplies which are either AC or DC.

The purpose of this view is to try and provide a comprehensive monitoring view of the health and status of deployed devices across the network. In this view all the managed devices are shown with their appropriate status and health based on the services and device settings applied. This view helps the operator to know the health and status across the network, it provides with the operator to quickly see the macro level information, which allows the operator to further analyze the information provided and quickly navigate to individual devices and take any further corrective measure required. It provides a cohesive tool for the operator to quickly see the micro-level information and take any further remediation action required.

To view a graphical image of the optical IPLC of PTX300 routers:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX3000 router for which you want to view and configure the IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. From the graphical image of the PTX3000 router, click a particular IPLC module to display the associated details in the lower portion of the page. The Rotate and Perspective buttons enable you to view the images in required orientation.

6. Click the View Back (arrows in a square symbol) icon to cause the device image to rotate along the x-axis and display the rear view of the device. Alternatively, click the View Front icon to view the front plane of the device. The View Back and View Front icons are toggle options.

7. Click the Perspective (cube symbol) icon to display the device image in three-dimensional format. It is a toggle button, which causes the device image to be shown in either three-dimensional or one-dimensional format.

8. Select the level of magnification of the image by clicking the Zoom (magnifying glass) icon. The image is expanded and displayed.

Alternatively, use the slider control beneath the Zoom icon to change the level of magnification.

9. Click the home icon to return to the front view of the chassis. The selected interface is surrounded with a colored outline based on the operational status. An interface that is operationally up is denoted in green and an interface that is operationally down is represented in red. The components are depicted as small colored icons in the front view of the equipment image.

In the graphical image of the device displayed, you can mouse over the different parts of the device, such as the interfaces, line cards, and slots. When you mouse over the different modules, their corresponding details are displayed as tooltips. On clicking the device components, the corresponding description for the selected component is displayed by default in the Component Info pane and the Equipment tab with the following values.

- Description—Configured textual description of the component.
- Manufacturer—Name of the company that built and shipped the device.
- Model—Model of the FRU component.
- Name—Name of the chassis component.
- Part number—Part number of the chassis component.
- Serial number—Serial number of the chassis component. The serial number of the backplane is also the serial number of the router or switch chassis. Use this serial number when you need to contact Juniper Networks Customer Support about the router or switch chassis.

The Component Info pane and the Active Alarms monitor are displayed in the lower portion of the page.

The Active Alarms monitor shows any active alarm that has not yet been cleared. You can view the alarm name, the unique identifier assigned to the alarm, the person to which the alarm is assigned for corrective action, and the severity of the alarm. Click the **Launch Alarm Mgmt** icon (right upward-slanting arrow enclosed in a square) to navigate to the Fault mode and view the four standard alarm monitors available in Fault mode.

Active Alarms for the respective components are displayed when the component is clicked in the image of the chassis displayed. The components for which the alarms are displayed are Flexible Port Concentrator (FPC), Dense Port Concentrator (DPC), Physical Interface Card (PIC), Modular Interface Card (MIC), Routing Engine, Control Boards, fan trays, Switch Interface Board (SIB), and power supply module (PSM).

The following fields are displayed in the Active Alarms pane:

Table 233: Active Alarms Monitor

Table Column	Description
Severity	<p>The severity of the alarm. Severity levels are:</p> <ul style="list-style-type: none"> • Critical—A critical condition exists; immediate action is necessary. • Major—A major error has occurred; escalate or notify as necessary. • Minor—A minor error has occurred; notify or monitor the condition. • Info—An informational message; no action is necessary.
Name	The alarm name.
Source	<p>The IP address of the device or network element that generated the alarm.</p> <p>The SNMP agent is located at the source IP. In most cases, the source IP is the IP address of the switch or controller.</p>
Last Updated	The date and time that the information for the alarm was last modified.

From the Chassis View window, click the **Details** icon (arrow enclosed in a square) at the top-right corner of the window to open the Chassis View Details page that lists the configured devices and their parameters in the form of a table.

Click the **Apply Configlet** button (pencil icon displayed beside the button) and use the links shown on the components in Chassis View to select the context and apply configlets.

RELATED DOCUMENTATION

[Deleting Devices from Chassis View | 1393](#)

[Rebooting Devices After Examining the Status in Chassis View | 1394](#)

[About Chassis View | 1383](#)

Configuring Optical IPLC for Easy and Optimal Deployment

Instead of using Junos OS CLI statements and operational commands to configure optical integrated photonic line card (IPLC) settings and view the configured parameters, you can view an image of the optical IPLC using Connectivity Services Director to obtain an intuitive and high-level understanding of the settings and alarms. This view enables you to modify the optical IPLC settings to suit your network deployment needs in a simplified and optimal manner. Because the important optical IPLC settings can be configured alongside the visual representation of the entire chassis that is displayed, this method of managing the optical IPLC settings provides a consolidated and cohesive interface for easy deployment of settings on the optical IPLC.

To configure an optical IPLC:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX3000 router for which you want to define the optical port settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. In the Settings/Status section, do the following:

- a. From the Expansion IPLC list, select the FPC or PIC slot in which the expansion module of the IPLC is installed. Alternatively, select **NONE** if you do not want to specify an expansion module for the IPLC.

This setting creates an association between the specified IPLC base module and IPLC expansion module. The IPLC expansion module is an optical multiplexing and demultiplexing card that, when associated with an IPLC base module by using this statement, increases the ADD or DROP capacity of the system to 64 channels.

NOTE: When you increase the capacity to 64 channels, the IPLC base module handles the *odd* channels and the IPLC expansion module handles the *even* channels.

- b. From the Express IPLC list, select the FPC or PIC slot in which the IPLC that you want to configure as the express-in mode is configured. Alternatively, select **NONE** if you do not want to specify an express-in mode for the IPLC. You can switch the IPLC's wavelength to another IPLC residing on the same chassis by using the express-in mode. There can be only one association between two IPLC cards in express-in mode. For example, the IPLC in slot 0 can be configured to be bypassed and switched to the IPLC in slot 2. If you change the association, then the latest association is considered.

This setting enables you to form a logical connection between two IPLC base modules to form a single two-line node that can communicate either east-west or north-south. This configuration is used in IPLC ring scenarios and other network scenarios that require the IPLC to support two-line terminations.

NOTE: Before setting this option, you must connect the two IPLC base modules together through the PT IN and PT OUT ports on the front panel; otherwise a proper association between the two modules is not formed.

NOTE: You can configure only one logical association between two IPLC base modules in express-in mode.

- c. In the Main field, view the alarm, if any, that has been generated for the main board of the IPLC. A gray circle denotes no alarm, whereas a red circle denotes that an active alarm is present. Firmware Consistency Alarm, Internal Diagnostic Alarm, or Power Rail Alarm are possible values that can be displayed.
- d. In the EDFA1 field, view the alarm, if any, that has been generated for the ingress erbium-doped fiber amplifier (EDFA) of the IPLC. A gray circle denotes no alarm, whereas a red circle denotes that

an active alarm is present. Input Power alarm, Out of Gain alarm, or Pump EOL alarm are possible values that can be displayed for EDFA1.

- e. In the EDFA2 field, view the alarm, if any, that has been generated for the egress EDFA of the IPLC. A gray circle denotes no alarm, whereas a red circle denotes that an active alarm is present. Output Power alarm, Out of Gain alarm, or Pump EOL alarm are possible values that can be displayed for EDFA2.
- f. In the WSS field, view the alarm, if any, that has been generated for the wavelength selective switching (WSS) module of the optical IPLC. A gray circle denotes no alarm, whereas a red circle denotes that an active alarm is present. WSS Module FAIL, WSS Firmware Image Corrupted, WSS Firmware Version out-of-date, WSS Voltage Alarm - High, WSS Voltage Alarm - Low, WSS Temperature - High, or WSS temperature - Low are possible values that can be displayed.
- g. Click **Update** above the Settings/Status section to save the specified configuration settings. Alternatively, click **Cancel** to discard the configuration settings.

8. In the Wavelength Configuration section, do the following:

All port wavelength frequencies are controlled by the WSS of the optical IPLC and configured on a wavelength-by-wavelength basis. The mapping for the wavelengths, frequencies, and ports is fixed. Each port is assigned a specific frequency and wavelength depending on whether the port is on the IPLC base module or expansion module.

- a. Select the **Show All Wavelengths** check box to display all available wavelengths supported by the PTX3000 router. The wavelength values can be any of the following:
 - **1528.38**—1528.38 nanometers (nm), corresponds to a 50-GHz grid
 - **1528.77**—1528.77 nm, corresponds to 50-GHz and 100-GHz grids
 - **1529.16**—1529.16 nm, corresponds to a 50-GHz grid
 - **1529.55**—1529.55 nm, corresponds to 50-GHz and 100-GHz grids
 - **1529.94**—1529.94 nm, corresponds to a 50-GHz grid
 - **1530.33**—1530.33 nm, corresponds to 50-GHz and 100-GHz grids
 - **1530.72**—1530.72 nm, corresponds to a 50-GHz grid
 - **1531.12**—1531.12 nm, corresponds to 50-GHz and 100-GHz grids
 - **1531.51**—1531.51 nm, corresponds to a 50-GHz grid
 - **1531.90**—1531.90 nm, corresponds to 50-GHz and 100-GHz grids
 - **1532.29**—1532.29 nm, corresponds to a 50-GHz grid
 - **1532.68**—1532.68 nm, corresponds to 50-GHz and 100-GHz grids
 - **1533.07**—1533.07 nm, corresponds to a 50-GHz grid
 - **1533.47**—1533.47 nm, corresponds to 50-GHz and 100-GHz grids

- 1533.86–1533.86 nm, corresponds to a 50-GHz grid
- 1534.25–1534.25 nm, corresponds to 50-GHz and 100-GHz grids
- 1534.64–1534.64 nm, corresponds to a 50-GHz grid
- 1535.04–1535.04 nm, corresponds to 50-GHz and 100-GHz grids
- 1535.43–1535.43 nm, corresponds to a 50-GHz grid
- 1535.82–1535.82 nm, corresponds to 50-GHz and 100-GHz grids
- 1536.22–1536.22 nm, corresponds to a 50-GHz grid
- 1536.61–1536.61 nm, corresponds to 50-GHz and 100-GHz grids
- 1537.00–1537.00 nm, corresponds to a 50-GHz grid
- 1537.40–1537.40 nm, corresponds to 50-GHz and 100-GHz grids
- 1537.79–1537.79 nm, corresponds to a 50-GHz grid
- 1538.19–1538.19 nm, corresponds to 50-GHz and 100-GHz grids
- 1538.58–1538.58 nm, corresponds to a 50-GHz grid
- 1538.98–1538.98 nm, corresponds to 50-GHz and 100-GHz grids
- 1539.37–1539.37 nm, corresponds to a 50-GHz grid
- 1539.77–1539.77 nm, corresponds to 50-GHz and 100-GHz grids
- 1540.16–1540.16 nm, corresponds to a 50-GHz grid
- 1540.56–1540.56 nm, corresponds to 50-GHz and 100-GHz grids
- 1540.95–1540.95 nm, corresponds to a 50-GHz grid
- 1541.35–1541.35 nm, corresponds to 50-GHz and 100-GHz grids
- 1541.75–1541.75 nm, corresponds to a 50-GHz grid
- 1542.14–1542.14 nm, corresponds to 50-GHz and 100-GHz grids
- 1542.54–1542.54 nm, corresponds to a 50-GHz grid
- 1542.94–1542.94 nm, corresponds to 50-GHz and 100-GHz grids
- 1543.33–1543.33 nm, corresponds to a 50-GHz grid
- 1543.73–1543.73 nm, corresponds to 50-GHz and 100-GHz grids
- 1544.13–1544.13 nm, corresponds to a 50-GHz grid
- 1544.53–1544.53 nm, corresponds to 50-GHz and 100-GHz grids
- 1544.92–1544.92 nm, corresponds to a 50-GHz grid
- 1545.32–1545.32 nm, corresponds to 50-GHz and 100-GHz grids
- 1545.72–1545.72 nm, corresponds to a 50-GHz grid

- **1546.12**–1546.12 nm, corresponds to 50-GHz and 100-GHz grids
- **1546.52**–1546.52 nm, corresponds to a 50-GHz grid
- **1546.92**–1546.92 nm, corresponds to 50-GHz and 100-GHz grids
- **1547.32**–1547.32 nm, corresponds to a 50-GHz grid
- **1547.72**–1547.72 nm, corresponds to 50-GHz and 100-GHz grids
- **1548.11**–1548.11 nm, corresponds to a 50-GHz grid
- **1548.51**–1548.51 nm, corresponds to 50-GHz and 100-GHz grids
- **1548.91**–1548.91 nm, corresponds to a 50-GHz grid
- **1549.32**–1549.32 nm, corresponds to 50-GHz and 100-GHz grids
- **1549.72**–1549.72 nm, corresponds to a 50-GHz grid
- **1550.12**–1550.12 nm, corresponds to 50-GHz and 100-GHz grids
- **1550.52**–1550.52 nm, corresponds to a 50-GHz grid
- **1550.92**–1550.92 nm, corresponds to 50-GHz and 100-GHz grids
- **1551.32**–1551.32 nm, corresponds to a 50-GHz grid
- **1551.72**–1551.72 nm, corresponds to 50-GHz and 100-GHz grids
- **1552.12**–1552.12 nm, corresponds to a 50-GHz grid
- **1552.52**–1552.52 nm, corresponds to 50-GHz and 100-GHz grids
- **1552.93**–1552.93 nm, corresponds to a 50-GHz grid
- **1553.33**–1554.33 nm, corresponds to 50-GHz and 100-GHz grids
- **1553.73**–1554.73 nm, corresponds to a 50-GHz grid
- **1554.13**–1554.13 nm, corresponds to 50-GHz and 100-GHz grids
- **1554.54**–1554.54 nm, corresponds to a 50-GHz grid
- **1554.94**–1554.94 nm, corresponds to 50-GHz and 100-GHz grids
- **1555.34**–1555.34 nm, corresponds to a 50-GHz grid
- **1555.75**–1555.75 nm, corresponds to 50-GHz and 100-GHz grids
- **1556.15**–1556.15 nm, corresponds to a 50-GHz grid
- **1556.55**–1556.55 nm, corresponds to 50-GHz and 100-GHz grids
- **1556.96**–1556.96 nm, corresponds to a 50-GHz grid
- **1557.36**–1557.36 nm, corresponds to 50-GHz and 100-GHz grids
- **1557.77**–1557.77 nm, corresponds to a 50-GHz grid
- **1558.17**–1558.17 nm, corresponds to 50-GHz and 100-GHz grids

- 1558.58–1558.58 nm, corresponds to a 50-GHz grid
- 1558.98–1558.98 nm, corresponds to 50-GHz and 100-GHz grids
- 1559.39–1559.39 nm, corresponds to a 50-GHz grid
- 1559.79–1559.79 nm, corresponds to 50-GHz and 100-GHz grids
- 1560.20–1560.20 nm, corresponds to a 50-GHz grid
- 1560.61–1560.61 nm, corresponds to 50-GHz and 100-GHz grids
- 1561.01–1561.01 nm, corresponds to a 50-GHz grid
- 1561.42–1561.42 nm, corresponds to 50-GHz and 100-GHz grids
- 1561.83–1561.83 nm, corresponds to a 50-GHz grid
- 1562.23–1562.23 nm, corresponds to 50-GHz and 100-GHz grids
- 1562.64–1562.64 nm, corresponds to a 50-GHz grid
- 1563.05–1563.05 nm, corresponds to 50-GHz and 100-GHz grids
- 1563.45–1563.45 nm, corresponds to a 50-GHz grid
- 1563.86–1563.86 nm, corresponds to 50-GHz and 100-GHz grids
- 1564.27–1564.27 nm, corresponds to a 50-GHz grid
- 1564.68–1564.68 nm, corresponds to 50-GHz and 100-GHz grids
- 1565.09–1565.09 nm, corresponds to a 50-GHz grid
- 1565.50–1565.50 nm, corresponds to 50-GHz and 100-GHz grids
- 1565.90–1565.90 nm, corresponds to a 50-GHz grid
- 1566.31–1566.31 nm, corresponds to 50-GHz and 100-GHz grids
- 1566.72–1566.72 nm, corresponds to a 50-GHz grid
- 1567.13–1567.13 nm, corresponds to 50-GHz and 100-GHz grids
- 1567.54–1567.54 nm, corresponds to a 50-GHz grid
- 1567.95–1567.95 nm, corresponds to 50-GHz and 100-GHz grids
- 1568.36–1568.36 nm, corresponds to a 50-GHz grid
- 1568.77–1568.77 nm, corresponds to 50-GHz and 100-GHz grids

The default is 1550.12–1550.12 nm, corresponds to 50-GHz and 100-GHz grids

- b. For a particular wavelength displayed in the table, click in the cell in the **configuration** column, and then click the drop-down arrow. The following values are displayed on the drop-down menu:
- **blocked**—By default, if there is no explicit configuration for the IPLC wavelength, then that wavelength is in blocked mode.

- **switch**—Enables you to switch a wavelength present on an IPLC module to an optical interface on the same or different chassis. You can specify the dense wavelength-division multiplexing (DWDM) interface on the local chassis to which you want to switch the specified wavelength. Otherwise, you can switch the specified wavelength on the local chassis to the remote chassis.
 - **express-in**—Enables you to form a logical connection between two IPLC base modules to form a single two-line node that can communicate either east-west or north-south. This configuration is used in IPLC ring scenarios and other network scenarios that require the IPLC to support two-line terminations.
- c. For a particular wavelength setting that you specified in the **configuration** column for the IPLC, click in the cell in the **end-point** column, and then click the drop-down arrow.

A list of interface names that are present on the same chassis as the IPLC are displayed on the drop-down menu. You can select the optical interface on the same chassis to which the IPLC base module must switch the wavelength. Before you configure this setting, be sure to configure the wavelength on the local optical interface so that the wavelength is compatible with the wavelength you are switching on the IPLC. Alternatively, select **remote** to configure the IPLC to switch a particular wavelength to an optical interface on a remote chassis. Before you configure this setting, be sure to configure the wavelength on the remote optical interface so that the wavelength is compatible with the wavelength you are switching on the IPLC.

NOTE: The end-point field displays **NA** if you select the value in the configuration column for a specific wavelength as **blocked** or **express-in**. The end-point field is configurable only for **switch** wavelength mode.

- d. Click **Update** in the Wavelength Configuration section to save the specified configuration settings. Alternatively, click **Cancel** to discard the configuration settings.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

[Viewing Performance Monitoring Details of Optical IPLCs for Detecting and Diagnosing Faults | 1661](#)
[Configuring Threshold-Crossing Alarms for Optical IPLCs for Monitoring Link Performance | 1668](#)

Viewing Performance Monitoring Details of Optical IPLCs for Detecting and Diagnosing Faults

To analyze and resolve any faults associated with optical integrated photonic line cards (IPLCs), it is essential to view the diagnostic data, warnings, and alarms for transport performance monitoring. The different types of parameters related to performance monitoring that are retrieved from the optical IPLCs enable you to ensure service availability and verify or monitor individual services and the service network performance.

The performance monitoring capability in Connectivity Services Director displays information about the health of your network and changing conditions of your optical IPLCs. Use this diagnosis and detection mechanism to identify problems with the equipment, pinpoint security attacks, or to analyze trends and categories of errors. This feature includes fault-monitoring details in the dashboard, in monitoring pages, and on a dedicated page that displays alarms, events, and system log messages that are generated. Performance monitoring parameters can be viewed in both chart and statistical formats. These charts and statistical details provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity. You can assess the performance of your network, not only at a point in time, but also over a period of time. This feature enables you to determine trending and network-health parameters; for example, whether service-level agreements (SLAs) have been violated.

To view the performance monitoring details of IPLC optics:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC in the image of the device—for example, an optical integrated photonic line card (IPLC) installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Performance** tab at the bottom of the pane.

The performance monitoring counters and metrics that pertain to the IPLC are displayed. The IPLC Optics PMs dialog box is displayed. This dialog box contains the Perf Mon and TCA Config tabs.

- Line OUT VOA—Line-out Variable Optical Attenuator (VOA).
 - Line OUT VOA-Min—Minimum line-out VOA
 - Line OUT VOA-Max—Maximum line-out VOA
 - Line OUT VOA-Avg—Average line-out VOA
- OSC Fiber Loss—Fiber loss of the Optical Service Channel (OSC)
 - OSC Fiber Loss-Min—Minimum fiber loss of the OSC
 - OSC Fiber Loss-Avg—Average fiber loss of the OSC
 - OSC Fiber Loss-Max—Maximum fiber loss of the OSC
- OSC Tx Power—Transmitted power of the OSC
 - OSC Tx Power-Min—Minimum transmitted power of the OSC
 - OSC Tx Power-Avg—Average transmitted power of the OSC
 - OSC Tx Power-Max—Maximum transmitted power of the OSC
- OSC Rx Power—Received power of the OSC
 - OSC Rx Power-Min—Minimum received power of the OSC
 - OSC Rx Power-Avg—Average received power of the OSC
 - OSC Rx Power-Max—Maximum received power of the OSC
- Power AWG Add—Arrayed Waveguide Grating (AWG) added power
 - Power AWG Add-Min—Minimum AWG added power
 - Power AWG Add-Avg—Average AWG added power
 - Power AWG Add-Max—Maximum AWG added power
- Power Express In—Power of the express-in mode of the IPLC
 - Power Express In-Min—Minimum power of the express-in mode of the IPLC
 - Power Express In-Avg—Average power of the express-in mode of the IPLC
 - Power Express In-Max—Maximum power of the express-in mode of the IPLC

7. Click the **IPLC LineOut PMs** header at the bottom of the dialog box. The IPLC LineOut PMs pane is expanded and displayed. This pane contains the PerfMon and TCA Config tabs.

The following fields are displayed in the Perf Mon tab of the IPLC LineOut PMs dialog box. The date and time at which the dialog box was last refreshed is shown.

- OCM Power Channel—Power line-out reading of the Optical Channel Monitor (OCM)

OCM Power Channel-Min—Minimum power line-out of the OCM

OCM Power Channel-Avg—Average power line-out of the OCM

OCM Power Channel-Max—Maximum power line-out of the OCM

The power line-out values for 31 power channels that are present in the IPLC are listed in the IPLC LineOut PMs dialog box.

NOTE: An optical channel monitor (OCM) with three points of observation including:

- The booster EDFA (E1) output
- The pre-amplifier EDFA (E2) output.
- The combined channels of the local add function at the input of the WSS, which indicates which channels (both odd and even channels) are being added locally.
- An optical supervisory channel (OSC), which communicates in-band with the far end IPLC modules and is used for the analysis of the fiber span characteristics, performance monitoring, and IPLC fault handling. Simple topology discovery logic communicates with the ILAs and PTX3000 nodes.
- An optical splitter is used to broadcast the received signal from the output of the pre-amplifier (E2) towards both DROP and PT IN and PT OUT ports.
- The following are the four power monitors:
 - **AWG Add**—Monitors the input of the wavelength selective switch (WSS) measuring the total input power of the combined channels of the local add function (both odd and even channels).
 - **Express In**—Monitors the input of the WSS measuring the total input power at the input to the WSS coming from the PT IN and PT OUT express ports.
 - **Line In**—Monitors the input at the LINE IN port, for detection of the incoming line signal optical power. The remaining PDs
 - **Line Out**—Monitors the output at the LINE OUT port, for detection of the outgoing line signal optical power.

8. Click the **IPLC EDFA PMs** header at the bottom of the dialog box. The IPLC EDFA PMs pane is expanded and displayed. This pane contains the PerfMon and TCA Config tabs.

The following fields are displayed in the Perf Mon tab of the IPLC EDFA PMs dialog box. The date and time at which the dialog box was last refreshed is shown.

- Ingress Input Power–Ingress EDFA input power
 - Ingress Input Power-Min–Minimum ingress EDFA input power
 - Ingress Input Power-Avg–Average ingress EDFA input power
 - Ingress Input Power-Max–Maximum ingress EDFA input power
- Ingress Output Power–Ingress EDFA output power
 - Ingress Output Power-Min–Minimum ingress EDFA output power
 - Ingress Output Power-Avg–Average ingress EDFA output power
 - Ingress Output Power-Max–Maximum ingress EDFA output power
- Ingress Signal Power–Ingress EDFA signal power
 - Ingress Signal Power-Min–Minimum ingress EDFA signal power
 - Ingress Signal Power-Avg–Average ingress EDFA signal power
 - Ingress Signal Power-Max–Maximum ingress EDFA signal power
- Ingress Pump Current–Ingress EDFA pump current
 - Ingress Pump Current-Min–Minimum ingress EDFA pump current
 - Ingress Pump Current-Avg–Average ingress EDFA pump current
 - Ingress Pump Current-Max–Maximum ingress EDFA pump current
- Egress Input Power–Egress EDFA input power
 - Egress Input Power-Min–Minimum egress EDFA input power
 - Egress Input Power-Avg–Average egress EDFA input power
 - Egress Input Power-Max–Maximum egress EDFA input power
- Egress Output Power–Egress EDFA output power
 - Egress Output Power-Min–Minimum egress EDFA output power
 - Egress Output Power-Avg–Average egress EDFA output power
 - Egress Output Power-Max–Maximum egress EDFA output power
- Egress Signal Power–Egress EDFA signal power
 - Egress Signal Power-Min–Minimum egress EDFA signal power
 - Egress Signal Power-Avg–Average egress EDFA signal power
 - Egress Signal Power-Max–Maximum egress EDFA signal power
- Egress Pump Current–Egress EDFA pump current
 - Egress Pump Current-Min–Minimum egress EDFA pump current
 - Egress Pump Current-Avg–Average egress EDFA pump current

Egress Pump Current-Max—Maximum egress EDFA pump current

On the Perf Mon tab, for the TCA column, either a minus sign (–) is displayed that denotes that an alarm for threshold-exceed is not configured or a check mark is displayed and grayed out that indicates that the TCA for the particular attribute is configured.

9. From the IPLC Optics PMs, IPLC LineOut PMs, or IPLC EDFA PMs dialog boxes, in the 15 Mins column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the last 15 minutes. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 15-minute interval. By default, 96 records of 15-minute intervals are displayed.

A 15-Min *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.

10. Click the **15 Mins *parameter name*** tab.

- a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date and time along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.

The records are displayed in tabular format. A serial number of the count of entries, the day, month, and year at which the entry was collected, and the time at which the entry was collected are displayed. The timestamp is the UTC time in the database that is mapped to the local time zone of the client computer.

- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search.
- Click **Reload** to refresh the contents and display the updated information for the specified time period.

- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
 - Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
 - Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
 - Click **Close** to close the 15-Min *parameter-name* tab.
11. From the IPLC Optics PMs, IPLC LineOut PMs, or IPLC EDFA PMs dialog boxes, in the 24-Hrs column, click the **Chart** button for the performance monitoring parameter set for which you want to view the statistics for the previous day. This option enables you to view the statistics in a chart form. Performance monitoring information for the different parameters are displayed for the current 24-hour interval. By default, records pertaining to the last 30 days are displayed when you view the performance monitoring counters for the 24-hour duration.
- A 24 Hours *parameter-name* tab is displayed beside the TCA Config tab at the top-left corner of the Optics PMs dialog box. A graphical format of the statistics for the specified parameter is displayed on this tab.
12. Click the **24 Hours *parameter name*** tab.

a. Select one of the following options from the drop-down menu:

- Select **View Chart** or the graphical icon (elliptical curve symbol) to display the chart of performance monitoring statistical metrics. A line graph is displayed with date along the horizontal axis and the parameter along the vertical axis. A color-coding format is used to display the different lines, and legends reference the parameter names corresponding to the lines displayed. Mouse over the points in the line graph to expand and show the value of the performance monitoring counters at a particular time.
- Select **View Grid** to switch over to the tabular format of display of performance monitoring statistics.
- Select **Save Chart**, when you view the performance monitoring statistics in graphical format, to save the graph to a Microsoft Excel file, as a .png image. Click the pin icon on the upper-left corner to revert the tab to the original container panel.
- Select **Popout Tab** or the light blue triangle icon to view the dialog box as a separate window.

In the pop-up dialog box, you can do one of the following:

- In the From Date field, pull down the calendar and select the start date of the search. In the To Date field, pull down the calendar and select the end date of the search. Click **Reload** to refresh the contents and display the updated information for the specified time period.
- Click **Export Data** to transfer the data in graphical or statistical format to a spreadsheet or other business applications for future reference and archival. The comma-separated value (CSV) format takes the raw data from the report and delineates the fields with commas so that the data is imported into popular spreadsheet programs.
- Click the **View Chart** button at the top-left corner of the dialog box to view the statistics in graphical format. Alternatively, click the **View Grid** button at the top-left corner of the dialog box to view the statistics in tabular format. The View Chart/Grid button is a toggle button.
- Click **OK** to close the pop-up dialog box. Alternatively, press Esc to close the dialog box after you complete viewing the statistical details.
- Click **Close** to close the 24 Hours *parameter-name* tab.

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest performance monitoring statistics to be polled and displayed.

RELATED DOCUMENTATION

[Configuring Optical IPLC for Easy and Optimal Deployment | 1654](#)

[Configuring Threshold-Crossing Alarms for Optical IPLCs for Monitoring Link Performance | 1668](#)

Configuring Threshold-Crossing Alarms for Optical IPLCs for Monitoring Link Performance

Threshold crossing alarms (TCAs) can give the management system an early indication as to the state of the associated entity when it crosses a certain threshold. TCAs can be set for both minimum and maximum values for gauges and maximum values for counters. Gauges and counters are the types of metrics for which TCAs are configured. A gauge represents a non-negative integer, which may increase or decrease, but never exceeds a maximum value. A gauge value has its maximum value whenever the information being modeled is greater than or equal to that maximum value. If the TCA parameter subsequently decreases below the maximum value, the gauge value also decreases. A counter represents a non-negative integer that monotonically increases until it reaches a maximum value of 2^{32} (2 raised to the power of 32)-1.

The timely detection of TCAs is essential to proactively manage an interface. TCAs are not an indication of a fault, but rather an indication that the entity maybe close to a fault. You can enable the TCA that you want monitor. You can either keep the default threshold settings or change the settings.

You can enable threshold-crossing alarms (TCAs) on the IPLC for the following:

- Erbium-doped fiber amplifier (EDFA)
- Optical Channel Monitor (OCM)
- Optical Service Channel (OSC)
- Variable Optical Attenuator (VOA)

To configure the TCAs for optical IPLCs:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.
2. From the View selector, select **Device View**.
The functionalities that you can configure in this view are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.
The network tree is expanded and the selected device is highlighted.
4. From the Tasks pane, select **Device Management > View Physical Inventory**.
An image of the device is displayed on the right pane.
5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. The Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed at the bottom of the dialog box.

6. Click the **Performance** tab at the bottom of the pane.

The IPLC Optics PMs dialog box is displayed with the performance monitoring counters and metrics that pertain to the IPLC. This dialog box contains the Perf Mon and TCA Config tabs. Apart from the IPLC Optics PMs pane, which is expanded and displayed, the IPLC LineOut PMs and IPLC EDFA PMs panes are displayed in a collapsed form.

7. Click the **TCA Config** tab to configure the TCAs for the different optical IPLC attributes. The dialog box is refreshed to display the different performance monitoring parameters. These parameters can be edited in an inline form.

Inline editing enables you to modify previously defined settings easily and quickly. Embedded editing is enabled, which causes the grids showing the devices and interfaces to become modifiable directly; you do not need to highlight, edit, and save the changes every time.

A gray triangle in the upper-right corner of a field denotes that the value of that field or attribute has been modified.

8. For the parameters under each performance monitoring category for which you want to modify the TCA value, click the value in the Threshold-15Min or Threshold-24Hr columns to set the TCA value for the 15-minute interval or 24-hour interval. You can also select or clear the check box in the Enable column to enable or disable the TCA value for the specified parameter, respectively.
9. Click **Update** to save the configured threshold settings. Alternatively, click **Cancel** to discard the configuration.
10. Similarly, you can configure the TCA values for the IPLC line-out and EDFA modules. To configure the TCA settings for the IPLC line-out and EDFA modules, click the **IPLC LineOut PMs** and **IPLC EDFA PMs** headers at the bottom of the IPLC Optics PMs dialog box. The IPLC LineOut PMs and IPLC EDFA PMs panes are expanded and displayed. These panes contain the Performance tab selected..
11. From the IPLC LineOut PMs and IPLC EDFA PMs panes, Click the **TCA Config** tab to configure the TCAs for the different optical IPLC attributes. The dialog box is refreshed to display the different performance monitoring parameters in editable form.
12. Edit the TCA values as necessary for the IPLC line-out and EDFA modules.

RELATED DOCUMENTATION

Increasing the Add and Drop Port Capacity of the IPLC Node to 64 Channels

The IPLC base module can accept and multiplex (add) and demultiplex (drop) up to 32 individual wavelengths into a single fiber pair. If you require more than 32 channels, you can increase the IPLC node capacity to 64 channels by connecting the IPLC expansion module to the IPLC base module. This procedure describes how to connect these two modules and configure the IPLC node to support 64 channels.

Before you begin, you must physically connect the IPLC base module and expansion module together as follows:

- Install the IPLC base module and the IPLC expansion module into the PTX3000 chassis.

BEST PRACTICE: We recommend that you place the IPLC modules into the same FPC or PIC slot pair in the PTX3000 chassis.

- Connect the two IPLC modules together as follows:
 - Connect the **XPN IN** port of the IPLC base module to the **XPN OUT** of the IPLC expansion module.
 - Connect the **XPN OUT** port of the IPLC base module to the **XPN IN** of the IPLC expansion module.

This procedure describes how to upgrade an IPLC configuration to 64 channels.

To upgrade an IPLC configuration to 64 channels you must create an association between the between the IPLC base module and the IPLC expansion module:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.
2. From the View selector, select **Device View**.
The functionalities that you can configure in this view are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.
The network tree is expanded and the selected device is highlighted.
4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

For example, if the IPLC base module resides in slot 1, select the **IPLC 1** component in the image of the chassis.

8. Specify the FPC or PIC slot in which the IPLC expansion module resides.

For example, if the IPLC expansion module resides in slot 2, select **FPC 2** from the Expansion IPLC list in the Settings/Status section.

9. Configure the wavelength supported by the OTN transponder and make sure it is supported by the IPLC base module.

For example, to configure the wavelength as 1532.29, select the **Show All Wavelengths** check box, and select **blocked** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

10. Click **Update** to save the specified configuration settings.

RELATED DOCUMENTATION

[Configuring a Two-Degree IPLC Node for Express Traffic by Increasing the Line Capacity | 1672](#)

[Configuring Optical IPLC Line Connectivity for Interoperation with Optical ILAs | 1674](#)

[Configuring the Wavelengths That Are Added and Dropped by the IPLC | 1679](#)

Configuring a Two-Degree IPLC Node for Express Traffic by Increasing the Line Capacity

For metro linear and metro ring topologies that require either north-south or east-west communications, you can connect two IPLC base modules together to form a two-degree IPLC node. This enables you to run express traffic in two directions. This topic describes how to setup and configure an IPLC two-degree node.

Using the express-in software capability of the IPLC, you can configure the IPLC to accept a wavelength from another IPLC residing in the same chassis. For example, when you have configured an IPLC node using two IPLC base modules. This topic describes how to express-in a wavelength from one IPLC to another IPLC within the same chassis.

Before you begin, complete the following tasks:

- Install and connect the two IPLC base modules through the **PT IN** and **PT OUT** ports. These two IPLC modules form the two-line IPLC node.

BEST PRACTICE: We recommend that you place the IPLC modules into the same FPC or PIC slot pair on the PTX3000 chassis.

To configure the IPLC for two-line terminations to express-in a wavelength from another IPLC:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.
2. From the View selector, select **Device View**.
The functionalities that you can configure in this view are displayed.
3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.
The network tree is expanded and the selected device is highlighted.
4. From the Tasks pane, select **Device Management > View Physical Inventory**.
An image of the device is displayed on the right pane.
5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

For example, if the IPLC base module resides in slot 1, select the **IPLC 1** component in the image of the chassis.

8. Create a logical association between the two IPLC modules and specify that you want the IPLC to express-in a wavelength.

For example, if the other IPLC resides in slot 2, select **IPLC 2** from the Express IPLC list in the Settings/Status section.

9. Configure the wavelength supported by the OTN transponder and make sure it is supported by the IPLC base module.

For example, to configure the wavelength as 1532.29, select the **Show All Wavelengths** check box, and select **express** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

10. Click **Update** to save the specified configuration settings.

RELATED DOCUMENTATION

[Increasing the Add and Drop Port Capacity of the IPLC Node to 64 Channels | 1670](#)

[Configuring Optical IPLC Line Connectivity for Interoperation with Optical ILAs | 1674](#)

[Configuring the Wavelengths That Are Added and Dropped by the IPLC | 1679](#)

Configuring Optical IPLC Line Connectivity for Interoperation with Optical ILAs

Each optical inline amplifier (ILA) is connected to other optical ILAs or optical integrated photonic line cards (IPLCs) using optical ports or optical supervisory channels (OSCs). There are two optical ports for each optical ILA, designated as OSC A and OSC B. For IP connectivity over OSC, the optical IPLC is used as a gateway. There is no direct IP connectivity between the optical ILA and external servers.

An optical IPLC is a standalone appliance in PTX3000 routers, running Linux. It has host path connectivity to the PTX3000 Routing Engine and other FPCs in the chassis (over internal routing instance). It does not have any router interfaces or switch fabric connectivity; therefore, there is no data path connectivity to other FPC interfaces. The optical IPLC software responds to SNMP commands from the network management server (NMS). SNMP commands are received by the transport daemon (transportd) running on the Routing Engine and are relayed to the optical IPLC CPU running the transport process. For providing IP connectivity, all optical IPLC and optical ILA in the chain are considered to be over a LAN.

Because all communication to an optical ILA is through an optical IPLC, one of the optical IPLCs in the chain is designated as the *anchor IPLC*. All optical ILA commands are directed to the anchor IPLC (which denotes the FPC slot number of the optical IPLC on a specific router) with a parameter indicating the optical ILA identity (OSC management IP address or the serial number). The anchor IPLC maintains a table of IP addresses for all optical ILA OSC-management ports (along with the optical ILA identifier) in the chain. This table is created through the optical IPLC CLI. The IPLC software forwards the commands to the required optical ILA. Each optical ILA in the chain also contains the anchor optical IPLC configuration. This optical ILA is used to send periodic updates and traps.

To configure connectivity between an optical IPLC and an optical ILA on a PTX3000 router:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. The Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed at the bottom of the dialog box.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Click the **Line Connectivity** tab at the bottom of the dialog box.

The IPLC Line Connectivity dialog box is displayed on the right pane with the configuration settings that can be used to establish a link between the optical IPLC and an optical ILA. You can establish the connectivity between a particular IPLC and optical ILAs that exist on the same PTX3000 router chassis using the fields in the dialog box.

8. In the TE Id field, enter the traffic engineering (TE) unique identifier that you want to use for the connectivity between the optical IPLC and optical ILA.

By default, this field is prepopulated with the *IETF-TE-Topology* value as the identifier for the topology Information about the IPLC module installed in the FPC or PIC slot. You can modify this value as needed.

9. In the Provider Id field, specify the unique identifier of the provider or the originating module, which is the IPLC in this case.

By default, this field is prepopulated with 1. You can modify this value as needed.

10. In the Client Id field, specify the unique identifier of the client or the receiving module, which is the optical ILA in this case.

By default, this field is prepopulated with 1. You can modify this value as needed.

11. In the A End IPLC field, click **Select** beside the field to select the endpoint or destination IPLC with which the connection must be established.

The Choose IPLC dialog box is displayed. The dialog box contains two panes. The top pane lists all the routers that are present in the network, and the bottom pane lists all the optical IPLCs that reside on the router chassis that you select in the top pane. You can sort and filter the displayed routers by entering a match criterion, such as the router name, in the search field, and click the **Search** icon in both the top and bottom panes. [Table 234 on page 1676](#) describes the fields displayed in the top pane of the Choose IPLC dialog box. [Table 235 on page 1676](#) describes the fields displayed in the bottom pane of the Choose IPLC dialog box.

Table 234: Choose IPLC Dialog Box—Top Pane

Field	Description
Name	Configured name of the device or IP address if no hostname is configured
IP Address	IP Address of the device
State	<p>Connection status of the device in Connectivity Services Director:</p> <ul style="list-style-type: none"> • UP—The device is connected to Connectivity Services Director. • DOWN—The device is not connected to Connectivity Services Director. • N/A—The device state is unavailable to Connectivity Services Director.
Managed State	<p>Configuration status of the device:</p> <ul style="list-style-type: none"> • In Sync—The configuration on the device is in sync with the Connectivity Services Director configuration for the device. • Out Of Sync—The configuration on the device does not match the Connectivity Services Director configuration for the device. This state is usually the result of the device configuration being altered outside of Connectivity Services Director. You cannot deploy the configuration on a device from Connectivity Services Director when the device is out-ofsync. To resolve this state, use the Resynchronize Device Configuration task in Deploy mode. • Sync failed—An attempt to resynchronize an out-of-sync device failed. • Synchronizing—The device configuration is in the process of being resynchronized. • N/A—The device is down.
Platform	Model number of the device, which is PTX3000 in this case
OS Version	Operating system version running on the device

Table 235: Choose IPLC Dialog Box—Bottom Pane

Field	Description
Name	Name of the IPLC with the slot number in which the module resides
Description	Brief description of the hardware item
Serial Number	Serial number of IPLC
Available	<p>Displays whether the device is active or not:</p> <ul style="list-style-type: none"> • true—IPLC is enabled and available • false—IPLC is disabled and unavailable

To select the router and the associated IPLC from the Choose IPLCs dialog box:

- a. Select the check box beside a router in the top pane.

The dialog box refreshes and displays all the corresponding IPLCs for the selected router in the bottom pane.

- b. Select the check box beside an IPLC in the bottom pane, and click **OK**.

You are returned to the IPLC Line Connectivity dialog box. The router name and the IPLC name are displayed in the two text fields, respectively, beside the Z End IPLC field.

In the Z End IPLC field, the PTX3000 router name on which the IPLC for which you are configuring line connectivity resides is displayed in the first field. The IPLC name, which is the same as the one for which you are configuring settings, is displayed in the second field. The **Select** button is displayed beside these text fields.

12. In the ILA Connections section, do the following:

- a. Click the **ILA (A -> Z)** tab.

The table that contains fields to specify the optical ILAs in the connection between the source and destination IPLCs is displayed. The Host Name and IP Address fields are displayed in the ILA (A-> Z) tab, which lists the name of the IPLC and the IP address of the optical supervisory channel (OSC) of the IPLC.

- b. Click **Select** above the table to specify the optical ILAs that must be configured in an ordered fashion as a chain between the source IPLC and the destination IPLC.

The Choose ILA dialog box is displayed, with the list of all the optical ILAs available on the chassis.

- c. Select the check boxes beside the optical ILAs that must be included in the connectivity chain with the IPLC, and click **OK**.

The Choose ILA dialog box closes, and the optical ILAs that you selected are listed in the ILA (A -> Z) tab in the order in which you selected them.

- d. Click a row in the table to select an optical ILA, and then click **Up** or **Down** to move the optical ILAs up or down in the table.

- e. Select an optical ILA from the table, and click **Remove** to delete any ILA that you do not want to participate in the IPLC connectivity chain.

You are not prompted to confirm the deletion. You can readd the optical ILAs as necessary to the connectivity chain.

- f. Click the **Interface Matrix** tab.

The wavelengths configured for the A and Z end interfaces are displayed. The following fields are displayed in a table:

- Wavelength—All the available wavelengths supported by the PTX3000 router

- **A End Interfaces**—Optical interface name with the FPC, PIC, and port number of the A end or source interface
- **Z End Interfaces**—Optical interface name with the FPC, PIC, and port number of the Z end or the destination end of the connection. The Z end interface is an optical interface to which the IPLC is connected (for switch mode) or the IPLC expansion module to which the IPLC base module is connected (for express-in mode).

All port wavelength frequencies are controlled by the wavelength selective switch (WSS of the IPLC) and configured on a wavelength-by-wavelength basis. The mapping for the wavelengths, frequencies, and ports is fixed. Each port is assigned a specific frequency and wavelength depending on whether the port is on the IPLC base module or expansion module.

13. Click **Add/Update** at the top of the IPLC Line Connectivity dialog box to save the connection settings between the optical IPLC and optical ILAs that you specified.

A job is created and run to create IPLC line connectivity. The Create IPLC Line Connectivity dialog box is displayed after the job is completed, with the job name, start and end times of the job, job status, and summary. Click **Close** to close the job dialog box.

You can click **Refresh** to update the contents of the dialog box.

14. Click **Graphical View** at the top of the IPLC Line Connectivity dialog box to view the connection between the source IPLC and the destination IPLC through the specified optical ILAs in the chain in a pictorial form.

The Line Connectivity Details dialog box is displayed, with the source and destination PTX3000 router chassis displayed. Green connector lines are shown to indicate the link between the source and destination routers. IPLC and optical ILA IP addresses are displayed above the green connector lines. Click **OK** when you have completed viewing the graphical representation of the connectivity.

15. (Optional) Click **Delete** at the top of the dialog box to delete the connectivity you created for the IPLC.

A job is created and run to delete IPLC line connectivity. The Delete IPLC Line Connectivity dialog box is displayed after the job is completed, with the job name, start and end times of the job, job status, and summary. Click **Close** to close the job dialog box.

You can click **Refresh** to update the contents of the dialog box.

Alternatively, click **Cancel** if you want to discard the configured IPLC line connectivity settings. You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

[Increasing the Add and Drop Port Capacity of the IPLC Node to 64 Channels | 1670](#)

Configuring the Wavelengths That Are Added and Dropped by the IPLC

By default, wavelengths on the IPLC ports are in blocked mode. You must configure the IPLC to add or drop a specific wavelength. This topic describes the default wavelength mapping for the IPLC ports and how to configure the IPLC to add or drop a specific wavelength.

All port wavelength frequencies are controlled by the IPLC's wavelength selective switch (WSS) and configured on a wavelength-by-wavelength basis.

NOTE: IPLC ports can also be switched-in to an optical interface on the same chassis or a remote chassis, or you can express-in a wavelength to a different IPLC.

Table 219 on page 1537 lists the default port, frequency, and wavelength mapping for both of the IPLC modules. The wavelength you want to support must be listed in Table 219 on page 1537.

Table 236: IPLC Port, Frequency, and Wavelength Mapping

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
192.05	1561.01	Yes	0	No	No
192.1	1560.61	No	No	Yes	32
192.15	1560.2	Yes	1	No	No
192.2	1559.79	No	No	Yes	33
192.25	1559.39	Yes	2	No	No
192.3	1558.98	No	No	Yes	34
192.35	1558.58	Yes	3	No	No
192.4	1558.17	No	No	Yes	35

Table 236: IPLC Port, Frequency, and Wavelength Mapping (continued)

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
192.45	1557.77	Yes	4	No	No
192.5	1557.36	No	No	Yes	36
192.55	1556.96	Yes	5	No	No
192.6	1556.55	No	No	Yes	37
192.65	1556.15	Yes	6	No	No
192.7	1555.75	No	No	Yes	38
192.75	1555.34	Yes	7	No	No
192.8	1554.94	No	No	Yes	39
192.85	1554.54	Yes	8	No	No
192.9	1554.13	No	No	Yes	40
192.95	1553.73	Yes	9	No	No
193	1553.33	No	No	Yes	41
193.05	1552.93	Yes	10	No	No
193.1	1552.52	No	No	Yes	42
193.15	1552.12	Yes	11	No	No
193.2	1551.72	No	No	Yes	43
193.25	1551.32	Yes	12	No	No
193.3	1550.92	No	No	Yes	44
193.35	1550.52	Yes	13	No	No

Table 236: IPLC Port, Frequency, and Wavelength Mapping (*continued*)

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
193.4	1550.12	No	No	Yes	45
193.45	1549.72	Yes	14	No	No
193.5	1549.32	No	No	Yes	46
193.55	1548.91	Yes	15	No	No
193.6	1548.51	No	No	Yes	47
193.65	1548.11	Yes	16	No	No
193.7	1547.72	No	No	Yes	48
193.75	1547.32	Yes	17	No	No
193.8	1546.92	No	No	Yes	49
193.85	1546.52	Yes	18		
193.9	1546.12	No	No	Yes	50
193.95	1545.72	Yes	19	No	No
194	1545.32	No	No	Yes	51
194.05	1544.92	Yes	20	No	No
194.1	1544.53	No	No	Yes	52
194.15	1544.13	Yes	21	No	No
194.2	1543.73	No	No	Yes	53
194.25	1543.33	Yes	22	No	No
194.3	1542.94	No	No	Yes	54

Table 236: IPLC Port, Frequency, and Wavelength Mapping (*continued*)

Frequency [THz]	Central Wavelength [nm]	Present on IPLC Module	Label on IPLC Module	Present on IPLC Expansion Module	Label on IPLC Expansion Module
194.35	1542.54	Yes	23	No	No
194.4	1542.14	No	No	Yes	55
194.45	1541.75	Yes	24	No	No
194.5	1541.35	No	No	Yes	56
194.55	1540.95	Yes	25	No	No
194.6	1540.56	No	No	Yes	57
194.65	1540.16	Yes	26	No	No
194.7	1539.77	No	No	Yes	58
194.75	1539.37	Yes	27	No	No
194.8	1538.98	No	No	Yes	59
194.85	1538.58	Yes	28	No	No
194.9	1538.19	No	No	Yes	60
194.95	1537.79	Yes	29	No	No
195.00	1537.40	No	No	Yes	61
195.05	1537.00	Yes	30	No	No
195.10	1536.61	No	No	Yes	62
195.15	1536.22	Yes	31	No	No
195.20	1535.82	No	No	Yes	63

You can configure the IPLC to switch a particular wavelength to an optical interface on a remote chassis.

Before you start this procedure, make sure that you configure the wavelength on the remote optical interface so that the wavelength is compatible with the wavelength you are switching on the IPLC.

To configure an IPLC port to add or drop a specific wavelength:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

For example, if the IPLC base module resides in slot 1, select the **IPLC 1** component in the image of the chassis.

8. Specify the wavelength number for the IPLC. For example, for wavelength 1550.12, select the **Show All Wavelengths** check box, beside the **1550.12** row in the **wavelength** column, modify the values in the **configuration** and **end-point** columns as necessary for this wavelength.

9. Click **Update** to save the specified configuration settings.

RELATED DOCUMENTATION

[Increasing the Add and Drop Port Capacity of the IPLC Node to 64 Channels | 1670](#)

[Configuring a Two-Degree IPLC Node for Express Traffic by Increasing the Line Capacity | 1672](#)

[Configuring Optical IPLC Line Connectivity for Interoperation with Optical ILAs | 1674](#)

Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on a Remote Chassis

The IPLC is designed to connect the **ADD** and **DROP** ports on the front panel to compatible optical PICs or MICs on the local or remote chassis. Wavelengths configured on the local IPLC **ADD** ports are multiplexed and sent over the **Line OUT** port of the IPLC base module. The remote IPLC base module receives the signal on the **Line IN** port and demultiplexes the wavelengths to the **DROP** ports on the front panel of the IPLC according to the configuration of the remote IPLC. After you have made the physical connections between the IPLC ports and the local and remote optical interfaces, you need to configure the IPLC to switch the wavelengths to the optical interfaces. This topic describes how to configure the IPLC to switch the wavelengths on the **ADD** and **DROP** ports to compatible optical interfaces on the local chassis or a remote chassis.

You can configure the IPLC to switch a particular wavelength to an optical interface on a remote chassis.

Before you begin, complete the following tasks:

- Install the optical interfaces and configure the wavelength on the local optical interface so that it is compatible with the wavelength on the IPLC. See, [Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength](#)
- Install the IPLC module at the remote location and connect the **ADD** and **DROP** ports to the respective local optical interfaces.

To configure the IPLC base module to switch a wavelength to an optical interface on a remote chassis:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.
The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

For example, if the IPLC base module resides in slot 1, select the **IPLC 1** component in the image of the chassis.

8. Specify the wavelength number and that you want to switch it to the remote chassis. For example, if you want to switch wavelength 1550.12 on the IPLC in slot 1 to the remote chassis, in the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1550.12** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

9. From the **end-point** column, click in the cell corresponding to the wavelength of 1550.12, and then click the drop-down arrow.

From the drop-down menu, select **remote** to specify the remote chassis to which you want the wavelength of the IPLC base module to be switched.

10. Click **Update** to save the specified configuration settings.

RELATED DOCUMENTATION

[Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on the Same Chassis | 1686](#)
[Bypassing a Wavelength on the IPLC | 1687](#)

Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on the Same Chassis

This topic provides a procedure for switching a wavelength present on the local IPLC modules to an optical interface on the same chassis.

Before you begin, complete the following tasks:

- Install the optical interfaces and configure the wavelength on the local optical interface so that it is compatible with the wavelength on the IPLC. See, [Configuring the 10-Gigabit or 100-Gigabit Ethernet DWDM Interface Wavelength](#)
- Install the IPLC module and connect the **ADD** and **DROP** ports to the respective local optical interfaces.

To configure the IPLC base module to switch a wavelength to an optical interface on the same chassis:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

For example, if the IPLC base module resides in slot 1, select the **IPLC 1** component in the image of the chassis.

8. Specify the wavelength you want to switch and the name of the physical optical interface to which you want to switch it. For example, if you want to switch wavelength 1550.12 on the IPLC in slot 1 to the optical interface on FPC slot 3, PIC 0, port 0, in the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1550.12** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

9. From the **end-point** column, click in the cell corresponding to the wavelength of 1550.12, and then click the drop-down arrow.

From the drop-down menu, select **et-3/0/0** to which you want the wavelength of the IPLC base module to be switched.

10. Click **Update** to save the specified configuration settings.

RELATED DOCUMENTATION

[Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on a Remote Chassis | 1684](#)
[Bypassing a Wavelength on the IPLC | 1687](#)

Bypassing a Wavelength on the IPLC

The IPLC enables you to optically bypass a wavelength by entering a few simple configuration statements. Bypassing a wavelength does not terminate the wavelength at the local IPLC but instead passes the wavelength on to the next downstream IPLC node. This topic describes how to bypass a wavelength on the IPLC.

Optical bypasses are software configurable and controlled through the IPLC's wavelength selective switch (WSS) so there is no need to manual intervention. The IPLCs software optical bypass enables wavelengths that do not terminate on the given node to be passed-through to the remote node without optical-electrical-optical (OEO) conversion.

Before you begin, configure the IPLC two-degree intermediate node for express traffic.

To configure the IPLC to bypass a wavelength:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. In the image of the device, select an optical IPLC—for example, an optical IPLC installed in a PTX3000 router.

The Component Info dialog box is displayed. At the lower part of the dialog box, the Equipment, Status/Config, Performance, and Line Connectivity tabs are displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

For example, if the IPLC base module resides in slot 1, select the **IPLC 1** component in the image of the chassis.

8. Configure the wavelength that you want to bypass from the IPLC base module to another IPLC module

For example, to bypass the wavelength of 1532.29, select the **Show All Wavelengths** check box, and select **express** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

9. Create a logical association between the two IPLC modules and specify that you want the IPLC to express-in a wavelength.

For example, if the other IPLC resides in slot 2, select **IPLC 2** from the Express IPLC list in the Settings/Status section.

10. Click **Update** to save the specified configuration settings.

RELATED DOCUMENTATION

- [Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on a Remote Chassis | 1684](#)
- [Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on the Same Chassis | 1686](#)

Changing Alarm Settings for the Optical IPLCs

IN THIS SECTION

- [Alarms for Optical IPLCs | 1690](#)
- [Configuring Global Alarm Notifications | 1695](#)
- [Retaining Alarm History | 1695](#)
- [Specifying Event History | 1695](#)
- [Enabling Alarms | 1695](#)
- [Changing the Severity of Individual Alarms | 1695](#)
- [Configuring Individual Alarm Notifications | 1696](#)

You can modify the configuration settings for alarm settings of optical integrated photonic line cards (IPLCs), which are used in conjunction with optical inline amplifiers (ILAs) on PTX3000 Packet Transport Routers, using the Preferences page of the Connectivity Services Director application. To open the Preferences page, click the down arrow next to the System button in the Connectivity Services Director banner and select Preferences. The Preferences page opens with User Preferences as the default tab. Click the Fault tab of the Preferences page of the Connectivity Services Director GUI to enable individual alarms, set the retention period for alarms, configure alarm notifications, and to specify the number of events to keep for each alarm. The Fault tab has multiple sections, which you can expand and collapse by clicking the arrow next to the section title:

- Global Settings, for configuring Faults settings such as global alarm notifications and alarm data retention.

- Individual Alarms and Threshold Settings, for configuring settings for individual alarms.

Alarms for Optical IPLCs

The following alarms are applicable for management of the optical IPLC:

Alarm Name	Description
jnxlplcFpcAwgAddLosAlarm	Generated as the FPC arrayed waveguide gratings (AWG) add LOS alarm for the IPLC
jnxlplcFpcExpInLosAlarm	Generated as the FPC input LOS alarm for the express-in mode of the IPLC.
jnxlplcFpcOscAddLosAlarm	Generated as the FPC add LOS alarm for the optical service channel (OSC) of the IPLC. The OSC is an in-band channel used to communicate with ILAs and other optical nodes in the line system that are not directly accessible over the DCN. OSC framing logic is implemented in the FPGA.
jnxlplcFpcOscDrpLosAlarm	Generated as the FPC drop LOS alarm for the OSC of the IPLC.
jnxlplcFpcLineInLosAlarm	Generated as the FPC input line-in LOS alarm for the IPLC.
jnxlplcFpcEdfa1RefPwAlarm	Generated as the FPC erbium doped fiber amplifier (EDFA) 1 reflect power alarm for the IPLC. EDFA1 is considered as ingress EDFA and EDFA2 is considered as egress EDFA
jnxlplcFpcEdfa1OutPwAlarm	Generated as the FPC EDFA1 output power alarm for the IPLC.
jnxlplcFpcEdfa1OutGain	Generated as the FPC EDFA1 output gain alarm for the IPLC
jnxlplcFpcEdfa1PumpEolAlarm	Generated as the FPC EDFA1 pump end-of-life (EoL) alarm for the IPLC.
jnxlplcFpcEdfa1TempAlarm	Generated as the FPC EDFA1 temperature alarm for the IPLC.
jnxlplcFpcEdfa1OutLosAlarm	Generated as the FPC EDFA1 output LOS alarm for the IPLC.
jnxlplcFpcEdfa1InLosAlarm	Generated as the FPC EDFA1 input LOS alarm for the IPLC.
jnxlplcFpcEdfa2RefPwAlarm	Generated as the FPC erbium doped fiber amplifier (EDFA) 1 reflect power alarm for the IPLC. EDFA1 is considered as ingress EDFA and EDFA2 is considered as egress EDFA

Alarm Name	Description
jnxlplcFpcEdfa2OutPwAlarm	Generated as the FPC EDFA2 output power alarm for the IPLC.
jnxlplcFpcEdfa2OutGainAlarm	Generated as the FPC EDFA2 output gain alarm for the IPLC
jnxlplcFpcEdfa2PumpEolAlarm	Generated as the FPC EDFA2 pump end-of-life (EoL) alarm for the IPLC.
jnxlplcFpcEdfa2TempAlarm	Generated as the FPC EDFA2 temperature alarm for the IPLC.
jnxlplcFpcEdfa2OutLosAlarm	Generated as the FPC EDFA2 output LOS alarm for the IPLC.
jnxlplcFpcEdfa2InLosAlarm	Generated as the FPC EDFA2 input LOS alarm for the IPLC.
jnxlplcFpcWssTempAlarm	Generated as the FPC wavelength selective switching (WSS) temperature alarm for the IPLC.
jnxlplcFpcWssVoltAlarm	Generated as the FPC WSS voltage alarm for the IPLC.
jnxlplcFpcInterDiagAlarm	Generated as the FPC internal diagnostic alarm for the IPLC.
jnxlplcFpcFwCnsistAlarm	Generated as the FPC firmware consistency alarm for the IPLC.
jnxlplcFpcHwFailAlarm	Generated as the FPC hardware failure alarm for the IPLC.
jnxlplcFpcFwFailAlarm	Generated as the FPC firmware failure alarm for the IPLC.
jnxlplcFpcOcmFailAlarm	Generated as the FPC optical channel monitor (OCM) failure alarm for the IPLC.
jnxlplcFpcWssFailAlarm	Generated as the FPC WSS failure alarm for the IPLC.
jnxlplcFpcEdfa2FailAlarm	Generated as the FPC EDFA2 failure alarm for the IPLC.
jnxlplcFpcEdfa1FailAlarm	Generated as the FPC EDFA1 alarm for the IPLC.
jnxlplcFpcPwrFailAlarm	Generated as the FPC power rail failure alarm for the IPLC.
jnxlplcOscTxPowerHigh15minAlert	Generated as an alarm when the OSC transmitted high power exceeds the threshold within the 15-minute interval for the IPLC.
jnxlplcOscTxPowerLow15minAlert	Generated as an alarm when the OSC transmitted low power exceeds the threshold within the 15-minute interval for the IPLC.

Alarm Name	Description
jnxlplcOscRxPowerHigh15minAlert	Generated as an alarm when the OSC received high power exceeds the threshold within the 15-minute interval for the IPLC.
jnxlplcOscRxPowerLow15minAlert	Generated as an alarm when the OSC received low power exceeds the threshold within the 15-minute interval for the IPLC.
jnxlplcOscFiberLosHigh15minAlert	Generated as an alarm when the OSC fiber high LOS exceeds the threshold within the 15-minute interval for the IPLC.
jnxlplcOscFiberLosLow15minAlert	Generated as an alarm when the OSC fiber low LOS exceeds the threshold within the 15-minute interval for the IPLC.
jnxlplcLineOutVoaHigh15minAlert	Generated as the line-out Variable Optical Attenuator (VOA) high threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcLineOutVoaLow15minAlert	Generated as the line-out Variable Optical Attenuator (VOA) low threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcIngressEdfaInputPwHigh15minAlert	Generated as the ingress EDFA input power high threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcIngressEdfaInputPwLow15minAlert	Generated as the ingress EDFA input power low threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcOcmPwHigh15minAlert	Generated as the OCM module power high threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcOcmPwLow15minAlert	Generated as the OCM module power low threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcOscTxPowerHigh24hourAlert	Generated as the OSC transmitted high power threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcOscTxPowerLow24hourAlert	Generated as the OSC transmitted high power threshold setting trigger within the 15-minute period for the IPLC.
jnxlplcOscRxPowerHigh24hourAlert	Generated as an alarm when the OSC received high power exceeds the threshold within the 24-hour interval for the IPLC.
jnxlplcOscRxPowerLow24hourAlert	Generated as an alarm when the OSC received low power exceeds the threshold within the 24-hour interval for the IPLC.

Alarm Name	Description
jnxlplcOscFiberLosHigh24hourAlert	Generated as an alarm when the OSC fiber high LOS exceeds the threshold within the 24-hour interval for the IPLC.
jnxlplcOscFiberLosLow24hourAlert	Generated as an alarm when the OSC fiber low LOS exceeds the threshold within the 24-hour interval for the IPLC.
jnxlplcLineOutVoaHigh24hourAlert	Generated as the line-out Variable Optical Attenuator (VOA) high threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcLineOutVoaLow24hourAlert	Generated as the line-out Variable Optical Attenuator (VOA) low threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaInputPwHigh24hourAlert	Generated as the ingress EDFA input high power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaInputPwLow24hourAlert	Generated as the ingress EDFA input low power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaOutputPwHigh24hourAlert	Generated as the ingress EDFA output high power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaOutputPwLow24hourAlert	Generated as the ingress EDFA output low power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaSignalPwHigh24hourAlert	Generated as the ingress EDFA signal high power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaSignalPwLow24hourAlert	Generated as the ingress EDFA signal low power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaPumpCurrentHigh24hourAlert	Generated as the ingress EDFA pump current high temperature threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcIngressEdfaPumpCurrentLow24hourAlert	Generated as the ingress EDFA pump current low temperature threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaInputPwHigh24hourAlert	Generated as the egress EDFA input high power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaInputPwLow24hourAlert	Generated as the egress EDFA input low power threshold setting trigger within the 24-hour period for the IPLC.

Alarm Name	Description
jnxlplcEgressEdfaOutputPwHigh24hourAlert	Generated as the egress EDFA output high power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaOutputPwLow24hourAlert	Generated as the egress EDFA output low power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaSignalPwHigh24hourAlert	Generated as the egress EDFA signal high power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaSignalPwLow24hourAlert	Generated as the egress EDFA signal low power threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaPumpCurrentHigh24hourAlert	Generated as the egress EDFA pump current high temperature threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcEgressEdfaPumpCurrentLow24hourAlert	Generated as the egress EDFA pump current low temperature threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcPowerMonitorAwgAddHigh24hourAlert	Generated as the power monitor AWG add high threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcPowerMonitorAwgAddLow24hourAlert	Generated as the power monitor AWG add low threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcPowerMonitorExpressInHigh24hourAlert	Generated as the power monitor express-in mode high threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcPowerMonitorExpressInLow24hourAlert	Generated as the power monitor express-in mode low threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcOcmPwHigh24hourAlert	Generated as the OCM module power high threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcOcmPwLow24hourAlert	Generated as the OCM module power low threshold setting trigger within the 24-hour period for the IPLC.
jnxlplcFpcSfpLosAlarm	Generated as the FPC SFP loss of signal (LOS) alarm for the IPLC.
jnxlplcFpcSfpLofAlarm	Generated as the FPC SFP loss of frame (LOF) alarm for the IPLC.

Configuring Global Alarm Notifications

You can configure global e-mail notifications to be sent when any alarm with notifications enabled is generated. To configure global e-mail notifications, enter the e-mail addresses to receive global alarm notifications in the Alarm Notifications Destinations field in the Global Settings section. Separate addresses with a comma (,). For information about enabling notification for an alarm, see [“Configuring Individual Alarm Notifications” on page 165](#).

Retaining Alarm History

Use the **No. of days to keep Alarm** field in the Global Settings section to specify the number of days to keep alarm history. The default retention time is 120 days; but you can specify a period of 7 through 1000 days. Specifying a longer retention time consumes more database resources. To change the alarm retention duration, type a new value and click **OK** and **Yes** to confirm the change.

Specifying Event History

Use the **Events/Alarm** field in the Global Settings section to specify the number of event entries that are kept in the alarm history. The default setting for events is 20. To change the setting, type a new value and click **OK** and **Yes** to confirm the change.

Enabling Alarms

Ensure all devices are configured to send traps to Connectivity Services Director. This task is performed for the devices in Deploy mode through Set SNMP Trap Configuration.

Use the Individual Alarms and Threshold Settings section to disable and re-enable individual alarms or all alarms. Alarms appear on both tabs in the section: Alarm Settings and Threshold Settings. Fault alarms are preconfigured and initially enabled. To enable or disable alarms:

1. (Optional) Sort the alarms. By default, the list of alarms is sorted alphabetically within each category. You can also sort by description or alarm severity within a category by clicking a column heading.
2. Review the alarms and either select the check box in the heading to select all of the alarms or select the check box for the individual alarms you want to enable.
3. Click **OK** and **Yes** to confirm the alarm change.

Changing the Severity of Individual Alarms

You can change the severity of the alarms to match your corporate procedures and guidelines. For example, at your company a DoS attack might be considered a critical alarm, while Connectivity Services Director

has a default severity for DoS attacks as a major alarm. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To change the severity of an alarm:

1. Select the current severity in the **Severity** column. A list of the severity levels appear.
2. Select the new severity level for the alarm.
3. Click **OK** and **Yes** to confirm the change to the severity setting.

To configure alarm notifications, see [“Configuring Individual Alarm Notifications” on page 165](#).

Configuring Individual Alarm Notifications

You can configure e-mail notifications to be sent when an individual alarm is generated. When you enable notification for an alarm, the notifications are sent to the e-mail addresses configured for the alarm and the addresses configured for global alarm notifications. Alarms appear on both tabs in the Individual Alarms and Threshold Settings section: Alarm Settings and Threshold Settings.

To configure e-mail notification for an alarm name:

1. Select the check box in the alarm's Notification column.

If you later want to disable notification for the alarm, clear the check box.

2. Click **Edit Notification** in the Notification column. The Alarm Notification Details window opens.
3. Enter one or more e-mail addresses in the Notification Email Addresses field. Separate addresses with a comma (,).

You can later edit the addresses to send notifications to different addresses.

4. (Optional) Enter a comment in the Comments field. This comment is included in the e-mail notification message.
5. Click **Save**.

RELATED DOCUMENTATION

[Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on a Remote Chassis | 1684](#)

[Configuring the IPLC to Add or Drop Wavelengths to an Optical Interface on the Same Chassis | 1686](#)

[Bypassing a Wavelength on the IPLC | 1687](#)

Viewing Routing Engine Switchover Indicators in the Chassis Image

Redundant Routing Engines are two Routing Engines that are installed in the same routing platform. One functions as the primary, while the other stands by as a backup should the primary Routing Engine fail. On routing platforms with dual Routing Engines, network reconvergence takes place more quickly than on routing platforms with a single Routing Engine.

The Chassis View provides a pictorial representation of the chassis or device, and the modules or components that are installed in it, such as the line cards, interfaces, and other hardware elements. To view a pictorial representation of a device chassis and the configured components, such as interfaces, line cards, and hardware elements, select a managed device listed in the My Network tree in Device View of Build mode of the Connectivity Services Director GUI, and select **Device Management > View Physical Inventory** from the tasks pane.

The active or primary and the standby or backup Routing Engines indicated on the Routing Engine in the Chassis View with a descriptive text label. “ACT” denotes an active Routing Engine, whereas “SDBY” denotes a standby Routing Engine. The status is updated on the Routing Engine only after a polling request because of the implications on the Junos Space application and device performance.

Routing Engine Redundancy Overview

When a Routing Engine is configured as primary, it has full functionality. It receives and transmits routing information, builds and maintains routing tables, communicates with interfaces and Packet Forwarding Engine components, and has full control over the chassis. When a Routing Engine is configured to be the backup, it does not communicate with the Packet Forwarding Engine or chassis components.

NOTE: On devices running Junos OS Release 8.4 or later, both Routing Engines cannot be configured to be primary at the same time. This configuration causes the commit check to fail.

A failover from the primary Routing Engine to the backup Routing Engine occurs automatically when the primary Routing Engine experiences a hardware failure or when you have configured the software to support a change in primary role based on specific conditions. You can also manually switch Routing Engine primary role by issuing one of the **request chassis routing-engine** commands. In this topic, the term *failover* refers to an automatic event, whereas *switchover* refers to either an automatic or a manual event.

When a failover or a switchover occurs, the backup Routing Engine takes control of the system as the new primary Routing Engine.

- If graceful Routing Engine switchover is not configured, when the backup Routing Engine becomes primary, it resets the switch plane and downloads its own version of the microkernel to the Packet Forwarding Engine components. Traffic is interrupted while the Packet Forwarding Engine is reinitialized. All kernel and forwarding processes are restarted.
- If graceful Routing Engine switchover is configured, interface and kernel information is preserved. The switchover is faster because the Packet Forwarding Engines are not restarted. The new primary Routing Engine restarts the routing protocol process (rpd). All hardware and interfaces are acquired by a process that is similar to a warm restart.
- If graceful Routing Engine switchover and nonstop active routing (NSR) are configured, traffic is not interrupted during the switchover. Interface, kernel, and routing protocol information is preserved.
- If graceful Routing Engine switchover and graceful restart are configured, traffic is not interrupted during the switchover. Interface and kernel information is preserved. Graceful restart protocol extensions quickly collect and restore routing information from the neighboring routers.

Conditions That Trigger a Routing Engine Failover

The following events can result in an automatic change in Routing Engine primary role, depending on your configuration:

- The routing platform experiences a hardware failure. A change in Routing Engine primary role occurs if either the Routing Engine or the associated host module or subsystem is abruptly powered off. You can also configure the backup Routing Engine to take primary role if it detects a hard disk error on the primary Routing Engine.
- The routing platform experiences a software failure, such as a kernel crash or a CPU lock. You must configure the backup Routing Engine to take primary role when it detects a loss of keepalive signal.
- A specific software process fails. You can configure the backup Routing Engine to take primary role when one or more specified processes fail at least four times within 30 seconds.

If any of these conditions is met, a message is logged and the backup Routing Engine attempts to take primary role. By default, an alarm is generated when the backup Routing Engine becomes active. After the backup Routing Engine takes primary role, it continues to function as primary even after the originally configured primary Routing Engine has successfully resumed operation. You must manually restore it to its previous backup status. (However, if at any time one of the Routing Engines is not present, the other Routing Engine becomes primary automatically, regardless of how redundancy is configured.)

RELATED DOCUMENTATION

[Viewing Alarm Indicators in the Chassis Image | 1699](#)[Viewing Port Statistics for OTN PICs | 1700](#)

Viewing Alarm Indicators in the Chassis Image

Activity on a network device consists of a series of events. A software component on the network device, called an entity, is responsible for running the Simple Network Management Protocol (SNMP) to log and monitor these events. When certain types of events are persistent, or when the condition causing the event crosses a threshold, SNMP sends a notification, also called a trap to Connectivity Services Director. Connectivity Services Director correlates traps, describing a condition, into an alarm.

The Chassis View provides a pictorial representation of the chassis or device, and the modules or components that are installed in it, such as the line cards, interfaces, and other hardware elements. To view a pictorial representation of a device chassis and the configured components, such as interfaces, line cards, and hardware elements, select a managed device listed in the My Network tree in Device View of Build mode of the Connectivity Services Director GUI, and select **Device Management > View Physical Inventory** from the tasks pane.

The alarms are correlated for each FPC in conjunction with other modules that are installed on a specific device chassis. This alarm value is added as a property to the FPC details. Apart from the Active Alarms pane that is displayed to the right of the graphical image of the chassis (in the Component Info pane), you can also view the alarm indicator as a circle or an LED icon that is displayed at the top of each FPC. A gray circle denotes that no alarm is present for the FPC module, whereas a red circle denotes that an active alarm is present for the FPC module.

RELATED DOCUMENTATION

[Viewing Routing Engine Switchover Indicators in the Chassis Image | 1697](#)[Viewing Port Statistics for OTN PICs | 1700](#)

Viewing Port Statistics for OTN PICs

The performance monitoring capability in Connectivity Services Director displays information about the health of your network and changing conditions of your optical interfaces. Use this diagnosis and detection mechanism to identify problems with the equipment, pinpoint security attacks, or to analyze trends and categories of errors. This feature includes fault-monitoring details in the dashboard, monitoring pages, and in a dedicated page that displays alarms, events, and system log messages that are generated. Performance monitoring parameters can be viewed in both chart and statistical formats. These charts and statistical details provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity. You can assess the performance of your network, not only at a point in time, but also over a period of time. This feature enables you to determine trending and network-health parameters; for example, whether service-level agreements (SLAs) have been violated.

The port statistics are available for viewing when the port on the FPC is selected. The Packets and Error counters for the selected port are displayed in the Optics PMs dialog box.

To view the port statistical details for OTN PICs:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the device for which you want to define the optical port settings.

The selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an OTN PIC, such as a 2-port 100-Gigabit Ethernet OTN PIC, in the image of the device.

The Component Info dialog box is displayed on the right pane with the PIC specifications. For example, if you select a 100-Gigabit Ethernet PIC installed in a PTX Series router, the Component Info dialog box is displayed to the right of the graphical view of the chassis. Select the Performance tab at the bottom of the dialog box to open the Optics PMs dialog box.

6. Click the **Performance** tab at the bottom of the dialog box.

The Optics PMs dialog box is displayed with the performance monitoring attributes for the OTN PIC. The Packet Counters and Error Counters tabs are displayed in the dialog box. The date and time at which the dialog box was last refreshed is shown.

The following fields are displayed in the Packet Counters tab of the Optics PMs dialog box:

- UniCast In—Ingress unicast packets per second
- BroadCast In—Ingress broadcast In packet per second
- Multicast In—Ingress multicast In packet per second
- Unicast Out—Egress unicast packets per second
- Broadcast Out—Egress broadcast packets per second
- Multicast Out—Egress multicast packets per second

The following fields are displayed in the Error Counters tab of the Optics PMs dialog box:

- **Errors In**—Sum of the incoming frame terminates and FCS errors.
- **Drops In**—Number of packets dropped by the input queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.
- **Framing errors In**—Number of packets received with an invalid frame checksum (FCS).
- **Runts In**—Number of frames received that are smaller than the runt threshold.
- **Policed discards In**—Number of frames that the incoming packet match code discarded because they were not recognized or not of interest. Usually, this field reports protocols that the Junos OS does not handle.
- **L3 incompletes In**—Number of incoming packets discarded because they failed Layer 3 (usually IPv4) sanity checks of the header. For example, a frame with less than 20 bytes of available IP header is discarded. L3 incomplete errors can be ignored by configuring the **ignore-l3-incompletes** statement.
- **L2 channel errors In**—Number of times the software did not find a valid logical interface for an incoming frame.
- **L2 mismatch timeouts In**—Number of malformed or short packets that caused the incoming packet handler to discard the frame as unreadable.
- **FIFO errors In**—Number of FIFO errors in the receive direction that are reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.
- **Resource errors In**—Sum of transmit drops.
- **Oversized frames In**—Number of frames that exceed 1518 octets.
- **Jabber frames In**—Number of frames that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2).

These documents define jabber as the condition in which any packet exceeds 20 ms. The allowed range to detect jabber is from 20 ms to 150 ms.

- **Fragment frames In**—Total number of packets that were less than 64 octets in length (excluding framing bits, but including FCS octets), and had either an FCS error or an alignment error. Fragment frames normally increment because both runs (which are normal occurrences caused by collisions) and noise hits are counted.
 - **CRC errors In**—Total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a nonintegral number of octets (Alignment Error).
 - **Carrier transitions Out**—Number of times the interface has gone from **down** to **up**. This number does not normally increment quickly, increasing only when the cable is unplugged, the far-end system is powered down and then up, or another problem occurs. If the number of carrier transitions increments quickly (perhaps once every 10 seconds), the cable, the far-end system, or the PIC or PIM is malfunctioning.
 - **Errors Out**—Sum of the outgoing frame terminates and FCS errors.
 - **Drops Out**—Number of packets dropped by the output queue of the I/O Manager ASIC. If the interface is saturated, this number increments once for every packet that is dropped by the ASIC's RED mechanism.
 - **Collisions Out**—Number of Ethernet collisions. The Gigabit Ethernet PIC supports only full-duplex operation, so for Gigabit Ethernet PICs, this number should always remain 0. If it is nonzero, there is a software bug.
 - **Aged packets Out**—Number of packets that remained in shared packet SDRAM so long that the system automatically purged them. The value in this field should never increment. If it does, it is most likely a software bug or possibly malfunctioning hardware.
 - **FIFO errors Out**—Number of FIFO errors in the send direction as reported by the ASIC on the PIC. If this value is ever nonzero, the PIC is probably malfunctioning.
 - **HS link CRC errors Out**—Number of errors on the high-speed links between the ASICs responsible for handling the router interfaces.
 - **MTU errors Out**—Number of packets whose size exceeded the MTU of the interface.
 - **Resource errors Out**—Sum of transmit drops.
7. To view a graphical representation of the port statistics, click the **Show Chart** button above the Packet Counters and Error Counters tabs. The Port Statistics pop-up dialog box is displayed.

You can view the interface statuses, such as errors and the operational conditions of the interfaces, that enables you in analyzing, troubleshooting, and rectifying problems with dropped packets or untransmitted bytes. Some of the causes for such a loss of traffic or a block in transmission of data packets include overloaded system conditions, profiles and policies that restrict the bandwidth or priority of traffic, network outages, or disruption with physical cable faults. This operation is equivalent

to the show interface statistics command that you can run from the Junos OS CLI interface. You can search for specific devices or interfaces by entering a search item and clicking the Search icon. A line graph is displayed with the input packets and errors, and output packets and errors shown on the vertical axis and the time shown on the horizontal axis. The following color-coded legends reference the line graphs:

- Packets In (Orange)—Number of packets received on the interface
- Packets Out (Green)—Number of packets sent from the interface
- Errors In (Blue)—Number of inbound errors received on the interface
- Errors Out (Purple)—Number of outbound errors transmitted from the interface

From the Time Interval drop-down box, select 1 Hour, 8 Hours, 1 Day, 1 Week, 1 Month, 3 Months, 6 Months, 1 Year, or Custom to specify the duration for which the data polled from devices needs to be displayed. If you select the Custom option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the Time From (Start time in the 24-hour time format of collection of data), and Time To (End time in the 24-hour time format of collection of data). Click OK to save the settings. Else, click Cancel to discard the configuration.

The Interface Details table displays all the UNI parts of the service. Also, the physical interface for the logical interface participating in the service is displayed.

- Serial Num—Serial number of the hardware component
- Port Name—Name of the interface
- Interface Type—Whether the interface is physical or logical
- Link Type—Operational status of the physical interface: Up, Down.
- MAC Address—MAC address of the physical interface.
- Input Packets—Number of packets received on the interface.
- Output Packets—Number of packets sent from the interface.
- Last Poll Time—Date and time at which the statistical detail was obtained by polling and retrieving from the device for the specified interface.

The Packet Counter tab on the right side of the page displays the following fields in a table. It is applicable for physical interfaces only. The values displayed are in rates of packets per second.

- Input Unicasts—Number of input unicast packets for the physical interface
- Output Unicasts—Number of output unicast packets for the physical interface
- Input Multicast—Number of input multicast packets for the physical interface
- Output Multicast—Number of output multicast packets for the physical interface
- Input Broadcast—Number of input broadcast packets for the physical interface
- Output Broadcast—Number of output broadcast packets for the physical interface

The Error Counter tab on the right side of the page displays the following fields in a table. It is available for physical interfaces only. The values displayed are in rates of packets per second.

- Input Errors—Number of errors packets received on the physical interface
- Output Drops—Number of outgoing packets that are dropped by the physical interface
- Input Framing Errors—Number of packets with framing errors that are received on the physical interface
- Input Drops—Number of incoming packets that are dropped by the physical interface
- Input Discards—Number of incoming packets discarded by the physical interface
- Output Errors—Number of error packets sent out from the physical interface

You can click the **Refresh** (rotating arrow icon) button at the top of the dialog box to enable the latest settings be retrieved from the device and displayed.

RELATED DOCUMENTATION

[Viewing Routing Engine Switchover Indicators in the Chassis Image | 1697](#)

[Viewing Alarm Indicators in the Chassis Image | 1699](#)

Example: Configuring Two Fiber Line Terminations Using IPLCs for Optical Amplification in a Metro Linear Packet Optical Network

IN THIS SECTION

- [Requirements | 1705](#)
- [Overview | 1706](#)
- [Configuration | 1711](#)
- [Verification | 1719](#)

For metro linear and metro ring topologies that require either north-south or east-west communications, you can connect two integrated photonic line card (IPLC) base modules together to form a single node with two fiber line terminations. This example shows how to configure the Junos OS to support the IPLC base modules in a Metro linear packet optical configuration for adding and dropping wavelengths to a

local optical interface, and for bypassing wavelengths to another IPLC. You can set up and configure an IPLC node with two line-side fiber terminations.

Requirements

This example uses the following hardware and software components:

- Three PTX3000 Packet Transport Routers running Junos OS Release 15.1F6
- Four IPLC base modules
- Compatible 10-Gigabit or 100-Gigabit Ethernet OTN PICs

For complete information on all PTX Series Packet Transport Routers hardware components, see [PTX Series Packet Transport Routers](#).

For complete information on all PTX Series Packet Transport Routers software features, see [Junos OS for PTX Series Packet Transport Routers, Release 15.1](#).

Before you start this procedure, complete the following tasks:

- Install the IPLCs, FPCs, and PICs in the PTX3000 chassis.

BEST PRACTICE: We recommend that you place the two IPLC modules at Node B into the same FPC/PIC slot pair on the PTX3000 chassis. In this example the IPLCs at Node B are located in FPC slots 2 and 3.

- Make all connections to and from the PICs in the PTX3000 chassis to the **Add** and **Drop** ports on front panel of each IPLC node as shown in [Figure 52 on page 1707](#).
- Connect your fiber pairs to the **Line IN** and **Line OUT** ports on the front panel of each IPLC node as shown in [Figure 52 on page 1707](#).

For simplicity, [Figure 52 on page 1707](#) does not show the optical ILAs between the three IPLC nodes.

- On Node B, connect the two IPLC modules together using the **PT IN** and **PT OUT** ports on the front panel of the IPLC as shown in [Figure 52 on page 1707](#).
- Be sure to specify wavelength values on each interface as shown in [Figure 52 on page 1707](#). If you must adjust the wavelength values, make sure that you enter a value supported on the IPLC.

BEST PRACTICE: Anytime you need to disconnect or connect the fiber span from the **Line IN** and **Line OUT** ports on the IPLC module, we recommend you disable the optical supervisory channel and the erbium-doped fiber amplifiers on the IPLC.

Always refer to the PTX3000 Packet Transport Router Hardware Guide when connecting or disconnecting cables on the IPLC modules. See [PTX3000 Packet Transport Router Hardware Guide](#).


Overview

This examples describes how to configure Junos OS to support IPLC base modules in a Metro linear packet optical deployment. The Add/Drop ports of the IPLC modules are physically connected to interfaces housed in the same PTX3000 chassis.

The IPLC modules provide the combined functionality of a 32-port Reconfigurable Optical Add/Drop Multiplexer (ROADM), optical amplification, optical equalization, and optical channel monitoring on a single card.

Topology

Figure 52: IPLC in Metro Linear Packet Optical Deployment



g043400

This procedure describes how to configure Junos OS for the IPLC modules. This is not a complete configuration and does not include full instructions for configuring the router or the associated line cards. Before you start this procedure, complete the following hardware and software tasks on the PTX 3000 router:

- Install the IPLCs, associated line cards, and PICs into the PTX3000 chassis so that the hardware configuration matches what is shown in [Figure 52 on page 1707](#). If you need to make changes to the positions of the cards in the chassis, adjust the FPC numbers referenced in [Figure 52 on page 1707](#) and configure them accordingly.

BEST PRACTICE: We recommend that you place the two IPLC modules at Node B into the same FPC or PIC slot pair on the PTX3000 chassis. In this example the IPLCs at Node B are located in FPC slots 2 and 3.

- Configure the associated wavelengths on the interfaces of the PTX3000 by using the following procedure:

1. Specify the interface to configure.

```
[edit]
user@host# edit interfaces interface-name
```

For example:

```
[edit]
user@host# edit interfaces et-6/0/0]
```

2. Specify the wavelength value supported on the interface.

```
[edit interfaces et-6/0/0]
user@host# set wavelength
```

NOTE: Be sure to specify wavelength values on each interface as shown in [Figure 52 on page 1707](#). If you must adjust the wavelength values, make sure that you enter a value supported on the IPLC.

- Make all connections to and from the PICs in the PTX3000 chassis to the ADD or DROP ports on front panel of each IPLC node as shown in [Figure 52 on page 1707](#).
- Connect your fiber pairs to the LINE IN and LINE OUT ports on the front panel of each IPLC node as shown in [Figure 52 on page 1707](#).

For simplicity, [Figure 52 on page 1707](#) does not show the optical inline amplifiers (optical ILAs) between the three IPLC nodes.

- On Node B, connect the two IPLC modules together using the PT IN and PT OUT ports on the front panel of the IPLC as shown in [Figure 52 on page 1707](#).

This example results in the following configuration:

Table 237: Wavelength, Port, and IPLC Nodes Mapping

Wavelength	Node A		Node B		Node C	
	Optical Interface Waveform is Switched to on PTX3000 Chassis	IPLC Slot: Port: Mode:	Optical Interface Waveform is Switched to on PTX3000 Chassis	IPLC Slot: Port: Mode:	Optical Interface Waveform is Switched to on PTX3000 Chassis	IPLC Slot: Port: Mode:
155454	—	—	et-8/0/4	Slot: 2 Port: 8 Mode: switch	et-10/0/2	Slot: 8 Port: 8 Mode: switch
155615	et-12/0/3	Slot: 1 Port: 6 Mode: switch	—	Slot: 2 Port: 6 Mode: wss-express-in (bypass) Slot: 3 Port: 6 Mode: wss-express-in (bypass)	et-10/0/3	Slot: 8 Port: 6 Mode: switch
155696	et-12/0/2	Slot: 1 Port: 5 Mode: switch	et-8/0/3	Slot: 3 Port: 5 Mode: switch	—	—

Table 237: Wavelength, Port, and IPLC Nodes Mapping (*continued*)

Wavelength	Node A		Node B		Node C	
	Optical Interface Waveform is Switched to on PTX3000 Chassis	IPLC Slot: Port: Mode:	Optical Interface Waveform is Switched to on PTX3000 Chassis	IPLC Slot: Port: Mode:	Optical Interface Waveform is Switched to on PTX3000 Chassis	IPLC Slot: Port: Mode:
1560.20	et-12/0/1	Slot: 1 Port: 1 Mode: switch	et-6/0/2	Slot: 2 Port: 1 Mode: switch Slot: 3 Port: 1 Mode: switch	et-10/0/1	Slot: 8 Port: 1 Mode: switch
1561.01	et-12/0/0	Slot: 1 Port: 0 Mode: switch	et-6/0/1 et-6/0/0	Slot: 2 Port: 0 Mode: switch Slot: 3 Port: 0 Mode: switch	et-10/0/0	Slot: 8 Port: 0 Mode: switch

- 3x100G of Ethernet between Node A and Node B through a multi-span link.
- 3x100G of Ethernet between Node B and Node C through a multi-span link.
- 1x100G of Ethernet between Node A and Node C through a multi-span link including an optical bypass at through Node B.
- In this example:
 - Wavelengths 1561.01 and 1560.20 are dropped at Node B and are also reused in both directions (Node A and Node C).
- Other wavelengths such as wavelength 1556.96 between Node A and Node B and wavelength 1554.54 between Node B and Node C are used in only a single direction.

- Wavelengths used in both directions can also be configured for optical buypass if it was necessary to reduce the packet throughput between the nodes. You can configure optical bypasses through the CLI, they do not require manual connection.
- If traffic changes, you could configure Node B with 1561.01 and 1560.20 as optical bypass and that creates an additional 2x100G between Node A and Node C, leaving only 100 Gbps of traffic to Node B (and leaving four interfaces unused).

Configuration

IN THIS SECTION

- [Configuring the IPLC Base Module at Node A | 1712](#)
- [Configuring the Two IPLC Base Modules at Node B | 1714](#)
- [Configuring the IPLC Base Module at Node C | 1717](#)
- [Results | ?](#)

The following example requires you to navigate various levels in the configuration hierarchy.

For information about navigating the CLI, see *Using the CLI Editor in Configuration Mode*.

Before you start this procedure, be sure to complete the tasks described in the [“Requirements” on page 1705](#) section of this example.

To configure the IPLC base modules in this example, perform these tasks:

CLI Quick Configuration

To quickly configure this example, copy the following commands into a text file, remove any line breaks, and then paste the commands into the CLI at the [edit] hierarchy level.

```
set chassis fpc 1 optical-options wavelength 1556.15 switch et-12/0/3
set chassis fpc 1 optical-options wavelength 1556.96 switch et-12/0/2
set chassis fpc 1 optical-options wavelength 1560.20 switch et-12/0/1
set chassis fpc 1 optical-options wavelength 1561.01 switch et-12/0/0
set chassis fpc 2 optical-options wavelength 1554.54 switch et-8/0/4
set chassis fpc 2 optical-options wavelength 1556.15 wss-express-in
set chassis fpc 2 optical-options wavelength 1560.20 switch et-6/0/2
set chassis fpc 2 optical-options wavelength 1561.01 switch et-6/0/1
set chassis fpc 2 optical-options express-in fpc 3
set chassis fpc 3 optical-options wavelength 1556.15 wss-express-in
```



```

set chassis fpc 3 optical-options wavelength 1556.96 switch et-8/0/3
set chassis fpc 3 optical-options wavelength 1560.20 switch et-8/0/2
set chassis fpc 3 optical-options wavelength 1561.01 switch et-6/0/0
set chassis fpc 3 optical-options express-in fpc 2
set chassis fpc 8 optical-options wavelength 1554.54 switch et-10/0/2
set chassis fpc 8 optical-options wavelength 1556.15 switch et-10/0/3
set chassis fpc 8 optical-options wavelength 1560.20 switch et-10/0/1
set chassis fpc 8 optical-options wavelength 1561.01 switch et-10/0/0

```

Configuring the IPLC Base Module at Node A

Step-by-Step Procedure

This procedure describes how to configure the IPLC base module in slot 1 of Node A in this example.

Before you start this procedure, be sure to complete the tasks described in the [“Requirements” on page 1705](#) section of this example.

To configure the IPLC base module in slot 1 of Node A:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an optical IPLC in the image of the device.

The Component Info dialog box is displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

In this case, because the IPLC base module resides in FPC slot 1, select the **IPLC 1** component in the image of the chassis.

8. Configure wavelength 1561.01 on port 0 of the IPLC base module to be switched to optical interface et-12/0/0. In the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1561.01** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
9. From the **end-point** column, click in the cell corresponding to the wavelength of 1561.01, and then click the drop-down arrow. From the drop-down menu, select **et-12/0/0** to which you want the wavelength of the IPLC base module to be switched.
10. Configure wavelength 1560.20 on port 1 of the IPLC base module to be switched to optical interface et-12/0/1. In the Wavelength Configuration section, beside the **1560.20** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
11. From the **end-point** column, click in the cell corresponding to the wavelength of 1560.20, and then click the drop-down arrow. From the drop-down menu, select **et-12/0/1** to which you want the wavelength of the IPLC base module to be switched.
12. Configure wavelength 1556.96 on port 5 of the IPLC base module to be switched to optical interface et-12/0/2. In the Wavelength Configuration section, beside the **1556.96** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
13. From the **end-point** column, click in the cell corresponding to the wavelength of 1556.96, and then click the drop-down arrow. From the drop-down menu, select **et-12/0/2** to which you want the wavelength of the IPLC base module to be switched.
14. Configure wavelength 1556.15 on port 6 of the IPLC base module to be switched to optical interface et-12/0/3. In the Wavelength Configuration section, beside the **1556.15** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
15. From the **end-point** column, click in the cell corresponding to the wavelength of 1556.15, and then click the drop-down arrow. From the drop-down menu, select **et-12/0/3** to which you want the wavelength of the IPLC base module to be switched.
16. Click **Update** to save the specified configuration settings.

Configuring the Two IPLC Base Modules at Node B

Step-by-Step Procedure

This procedure describes how to configure the IPLC base module in slot 2 of Node B in this example.

Before you start this procedure, be sure to complete the tasks described in the ["Requirements" on page 1705](#) section of this example.

BEST PRACTICE: We recommend that you place the two IPLC modules in the same FPC or PIC slot pair on the PTX3000 chassis.

To configure the IPLC base module in slot 2 of Node B:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an optical IPLC in the image of the device.

The Component Info dialog box is displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

In this case, because the IPLC base module resides in FPC slot 2, select the **IPLC 2** component in the image of the chassis.

8. Create a logical connection between this IPLC base module and the IPLC base module in slot 3. Select **FPC 3** from the Express IPLC list in the Settings/Status section.
9. Configure wavelength 1561.01 on port 0 of the IPLC base module to be switched to optical interface et-6/0/1. In the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1561.01** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
10. From the **end-point** column, click in the cell corresponding to the wavelength of 1561.01, and then click the drop-down arrow. From the drop-down menu, select **et-6/0/1** to which you want the wavelength of the IPLC base module to be switched.
11. Configure wavelength 1560.20 on port 1 of the IPLC base module to be switched to optical interface et-6/0/2. In the Wavelength Configuration section, beside the **1560.20** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
12. From the **end-point** column, click in the cell corresponding to the wavelength of 1560.20, and then click the drop-down arrow. From the drop-down menu, select **et-6/0/2** to which you want the wavelength of the IPLC base module to be switched.
13. Configure wavelength 1554.54 on port 5 of the IPLC base module to be switched to optical interface et-8/0/4. In the Wavelength Configuration section, beside the **1556.54** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
14. From the **end-point** column, click in the cell corresponding to the wavelength of 1554.54, and then click the drop-down arrow. From the drop-down menu, select **et-8/0/4** to which you want the wavelength of the IPLC base module to be switched.
15. Configure wavelength 1556.15 on port 6 of the IPLC base module in slot 2 to be bypassed. In the Wavelength Configuration section, beside the **1556.15** row in the **wavelength** column, select **express** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
16. Click **Update** to save the specified configuration settings.

Step-by-Step Procedure

This procedure describes how to configure the IPLC base module in slot 3 of Node B in this example.

Before you start this procedure, be sure to complete the tasks described in the [“Requirements” on page 1705](#) section of this example.

To configure the IPLC base module in slot 3 of Node B:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an optical IPLC in the image of the device.

The Component Info dialog box is displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

In this case, because the IPLC base module resides in FPC slot 3, select the **IPLC 3** component in the image of the chassis.

8. Create a logical connection between this IPLC base module and the IPLC base module in slot 2. Select **FPC 2** from the Express IPLC list in the Settings/Status section.

9. Configure wavelength 1561.01 on port 0 of the IPLC base module to be switched to optical interface et-6/0/0. In the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1561.01** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

10. From the **end-point** column, click in the cell corresponding to the wavelength of 1561.01, and then click the drop-down arrow. From the drop-down menu, select **et-6/0/0** to which you want the wavelength of the IPLC base module to be switched.
11. Configure wavelength 1560.20 on port 0 of the IPLC base module to be switched to optical interface et-8/0/2. In the Wavelength Configuration section, beside the **1560.20** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
12. From the **end-point** column, click in the cell corresponding to the wavelength of 1561.01, and then click the drop-down arrow. From the drop-down menu, select **et-8/0/2** to which you want the wavelength of the IPLC base module to be switched.
13. Configure wavelength 1556.96 on port 5 of the IPLC base module to be switched to optical interface et-8/0/3. In the Wavelength Configuration section, beside the **1560.20** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
14. From the **end-point** column, click in the cell corresponding to the wavelength of 1556.96, and then click the drop-down arrow. From the drop-down menu, select **et-8/0/3** to which you want the wavelength of the IPLC base module to be switched.
15. Configure wavelength 1556.15 on port 6 of the IPLC base module in slot 3 to be bypassed. In the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1560.20** row in the **wavelength** column, select **express** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.
16. Click **Update** to save the configured settings.

Configuring the IPLC Base Module at Node C

Step-by-Step Procedure

This procedure describes how to configure the IPLC base module in slot 8 of Node C in this example.

Before you start this procedure, be sure to complete the tasks described in the [“Requirements” on page 1705](#) section of this example.

Step-by-Step Procedure

To configure the IPLC base module in slot 8 of Node C:

1. From the Junos Space user interface, click the **Build** icon on the Connectivity Services Director banner.

The workspaces that are applicable to Build mode are displayed on the Tasks pane.

2. From the View selector, select **Device View**.

The functionalities that you can configure in this view are displayed.

3. From the Device View pane, click the plus sign (+) next to the My Network tree to expand the tree and select the PTX300 router for which you want to define the optical IPLC settings.

The network tree is expanded and the selected device is highlighted.

4. From the Tasks pane, select **Device Management > View Physical Inventory**.

An image of the device is displayed on the right pane.

5. Select an optical IPLC in the image of the device.

The Component Info dialog box is displayed.

6. Click the **Status/Config** tab at the bottom of the dialog box.

The IPLC Line dialog box is displayed on the right pane with the configuration settings that pertain to the IPLC.

7. Specify the FPC or PIC slot in which the IPLC base module resides by selecting the slot in the Chassis View.

In this case, because the IPLC base module resides in FPC slot 8, select the **IPLC 8** component in the image of the chassis.

8. Configure wavelength 1561.01 on port 0 of the IPLC base module to be switched to optical interface et-10/0/0. In the Wavelength Configuration section, select the **Show All Wavelengths** check box, and beside the **1561.01** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

From the **end-point** column, click in the cell corresponding to the wavelength of 1561.01, and then click the drop-down arrow. From the drop-down menu, select **et-10/0/0** to which you want the wavelength of the IPLC base module to be switched.

9. Configure wavelength 1560.20 on port 1 of the IPLC base module to be switched to optical interface et-10/0/1. In the Wavelength Configuration section, beside the **1560.20** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

From the **end-point** column, click in the cell corresponding to the wavelength of 1560.20, and then click the drop-down arrow. From the drop-down menu, select **et-10/0/1** to which you want the wavelength of the IPLC base module to be switched.

10. Configure wavelength 1554.54 on port 8 of the IPLC base module to be switched to optical interface et-10/0/2. In the Wavelength Configuration section, beside the **1554.54** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

From the **end-point** column, click in the cell corresponding to the wavelength of 1554.54, and then click the drop-down arrow. From the drop-down menu, select **et-10/0/2** to which you want the wavelength of the IPLC base module to be switched.

11. Configure wavelength 1556.15 on port 6 of the IPLC base module to be switched to optical interface et-10/0/3. In the Wavelength Configuration section, beside the **1556.15** row in the **wavelength** column, select **switch** from the drop-down menu in the **configuration** column of the table for the corresponding wavelength.

From the **end-point** column, click in the cell corresponding to the wavelength of 1556.15, and then click the drop-down arrow. From the drop-down menu, select **et-10/0/3** to which you want the wavelength of the IPLC base module to be switched.

12. Click **Update** to save the configured settings.

Verification

IN THIS SECTION

- [Verifying the Topology of Each IPLC Node | 1719](#)

Confirm that the configuration is working properly.

Verifying the Topology of Each IPLC Node

Purpose

Verify the topology of each IPLC node.

Action

Run the **show chassis fpc optical-properties topology** command with the **detail** output level at each IPLC node and verify that the following fields match the values listed in [Table 237 on page 1709](#).

- **Port/Wavelength**—Verify that this field lists the proper wavelength values and IPLC port numbers for each node in this example.
- **State**—Verify that the values for this field match what is listed in [Table 237 on page 1709](#) for the mode value of each IPLC port for each node in this example.
- **Connected To**—If the wavelength is being switched, verify that this field lists the correct interface the wavelength is being switched to.

Verify the topology of each IPLC node.

1. For example, at IPLC Node A, enter the following.

```
user@host>show chassis fpc optical-properties topology detail fpc-slot 1
```

IPLC Topology Information				
Wavelength(nm) / Port / Frequency(THz)			State	Connected To
Express-in Port			DOWN	NA
Expansion Port			DOWN	NA
1561.01	0	192.05	Switched	et-12/0/0
1560.20	1	192.15	Switched	et-12/0/1
1559.39	2	192.25	Blocked	NA
1558.58	3	192.35	Blocked	NA
1557.77	4	192.45	Blocked	NA
1556.96	5	192.55	Switched	et-12/0/2
1556.15	6	192.65	Switched	et-12/0/3
1555.34	7	192.75	Blocked	NA
1554.54	8	192.85	Blocked	NA
1553.73	9	192.95	Blocked	NA
1552.93	10	193.05	Blocked	NA
1552.12	11	193.15	Blocked	NA
1551.32	12	193.25	Blocked	NA
1550.52	13	193.35	Blocked	NA
1549.72	14	193.45	Blocked	NA
1548.91	15	193.55	Blocked	NA
1548.11	16	193.65	Blocked	NA
1547.32	17	193.75	Blocked	NA
1546.52	18	193.85	Blocked	NA
1545.72	19	193.95	Blocked	NA
1544.92	20	194.05	Blocked	NA
1544.13	21	194.15	Blocked	NA
1543.33	22	194.25	Blocked	NA
1542.54	23	194.35	Blocked	NA
1541.75	24	194.45	Blocked	NA
1540.95	25	194.55	Blocked	NA

1540.16	26	194.65	Blocked	NA
1539.37	27	194.75	Blocked	NA
1538.58	28	194.85	Blocked	NA
1537.79	29	194.95	Blocked	NA
1537.00	30	195.05	Blocked	NA
1536.22	31	195.15	Blocked	NA

2. At Node B, enter the following:

```
user@host> show chassis fpc optical-properties topology detail fpc-slot 2
user@host> show chassis fpc optical-properties topology detail fpc-slot 3
```

3. At Node C:

```
user@host> show chassis fpc optical-properties topology detail fpc-slot 8
```

Meaning

For example, in Step 1 for Node A, you can see that the IPLC module in slot 1 includes the following configuration:

- Wavelength 1561.01 is switched to optical interface et-12/0/0
- Wavelength 1560.20 is switched to optical interface et-12/0/1
- Wavelength 1556.96 is switched to optical interface et-12/0/2
- Wavelength 1556.16 is switched to optical interface et-12/0/3

This matches what is listed in [Table 237 on page 1709](#) for Node A and confirms the configuration is operating correctly.

RELATED DOCUMENTATION

Viewing a Graphical Image of the Optical Integrated Photonic Line Card 1650
Configuring Optical IPLC for Easy and Optimal Deployment 1654
Viewing Performance Monitoring Details of Optical IPLCs for Detecting and Diagnosing Faults 1661
Configuring Threshold-Crossing Alarms for Optical IPLCs for Monitoring Link Performance 1668

18

PART

Working with User Roles

Managing User Roles | **1723**

Managing User Roles

IN THIS CHAPTER

- [Creating a User-Defined Role | 1723](#)
- [Managing Roles | 1725](#)

Creating a User-Defined Role

You can create custom roles to grant users different access rights to the Connectivity Services Director modes. Connectivity Services Director modes—Report, Deploy, Monitor, Fault, and Build are available to assign to custom user roles in the list of application workspaces and associated tasks

Junos Space Network Management Platform provides read-only predefined roles—that is, Super Administrator, System Administrator, or User Administrator—that you can use to create users to perform tasks that these roles permit. You can also create read-write user-defined roles that conform to user responsibilities and access privileges required on your network. You can modify and delete only user-defined roles that you create. You cannot modify or delete predefined roles.

The following predefined roles are applicable for Connectivity Services Director to handle different operations for devices and services with varying privileges and permissions:

- The Device Manager role allows an administrator to discover devices.
- The Service Manager role allows an administrator to perform device pre-staging actions including discovering and assigning device roles.
- The Service Designer roles allows an administrator to create and publish a service definition.
- The Service Activator (less privileged) role allows an administrator to perform provisioning tasks including creating and managing customers, service orders, and services.

To create a user-defined role:

1. On the Junos Space Network Management Platform user interface, select **Role Based Access Control** > **Roles**.

The Roles page appears.

2. Click the **Create Role** icon on the menu bar.

The Create Role page appears, allowing you to select workspaces and associated tasks from all deployed applications.

3. In the **Title** text box, type a user-defined role name.

The role title cannot exceed 32 characters. The title can contain only letters and numbers and can include a hyphen (-), underscore (_), or period (.). Also, the title cannot start with a space.

4. In the **Description** text box, type a user-defined role description.

The role description cannot exceed 256 characters. The description can contain only letters and numbers and can include a hyphen (-), underscore (_), period (.), or comma (,).

5. Select an application workspace from the application selection ribbon.

Mouse over an application workspace icon to view the application and workspace name. You can select one or more workspaces per user-defined role. An expandable and collapsible tree of associated tasks appear below the selection ribbon for you to modify specific tasks that you want included in the Task Summary pane.

6. Select the specific tasks that you want for the user-defined role. All application workspace tasks are selected by default in the task tree.

Only the currently edited application workspace node is expanded in the Task Summary pane; previously selected workspace nodes are collapsed. You can expand other workspace nodes manually.

Selecting the top node or workspace selects or deselects the whole task tree. Selecting any task node automatically selects all tasks under the task node. Selecting any task node automatically selects its parent and grandparent.

Only the currently active task tree appears in the Task Summary pane.

In the Task Summary pane, the top-level application node in the tree is set in bold-italic; the second-level workspace tree node is set in bold.

7. Click **Create**.

The user-defined role is created, saved, and appears on the Roles inventory page.

Scroll down or search to view it.

You cannot create or save a user-defined role when the workspace tasks are not selected. Junos Space throws the following error message:

Task tree selection can not be empty.

Creation of a role generates an audit log entry.

RELATED DOCUMENTATION

<i>Predefined Roles Overview</i>
Managing Roles 1725
<i>Modifying User-Defined Roles</i>
<i>Deleting User-Defined Roles</i>
<i>Creating Users in Junos Space Network Management Platform</i>

Managing Roles

IN THIS SECTION

- [Viewing User Role Details | 1725](#)
- [Performing Manage Roles Commands | 1726](#)

A role is a description of tasks a user can perform in Junos Space Network Management Platform to allow access to application workspaces. The **Role Based Access Control > Roles** inventory page allows Super Administrator or User Administrator to view all predefined and user-defined roles that exist for Junos Space applications. The administrator should understand all predefined roles and create any user-defined roles before creating users.

Viewing User Role Details

The **Roles** inventory page displays all predefined and user-defined roles in a tabular view.

Each role is represented by a row in the table. Roles are listed in the table in ascending alphabetical order by role title, type (that is, whether the role is a predefined role or a custom role), description, and tasks assigned. You can show or hide table columns and sort records in ascending or descending order.

You can search for roles by typing the first letters of the role title in the search box. Role title starting with the first letters you type are listed.

To view a user role detail summary:

1. On the Junos Space Network Management Platform user interface, select **Role Based Access Control > Roles**.

The Roles page appears.

2. Double-click a role.

The Role Detail Summary page appears.

The page displays the workspace and workspace tasks.

3. Click the expander button + adjacent to the workspaces to view subtasks.

4. Click **OK** on the Role Detail Summary page to exit this page.

You are returned to the Roles page.

Performing Manage Roles Commands

You can perform a task on predefined and user-defined roles by selecting the task from the Actions menu or the shortcut menu that is displayed when you right-click a role, or by clicking the icons at the top of the Roles page. You can perform the **Modify Role** and **Delete Roles** commands only on read-writeable user-defined roles. You cannot manipulate read-only predefined roles. To perform a command, you must first select the role.

You can perform one or more of the following actions on the roles from the Roles page:

- **View Role Details**—View details about the selected role.
- **Modify Role**—Modify the selected user-defined description, application workspaces, and tasks associated with the workspaces. You cannot modify predefined roles. For more information, see *Modifying User-Defined Roles*.
- **Delete Roles**—Delete the selected user-defined role. You cannot delete predefined roles. For more information, see *Deleting User-Defined Roles*.
- **Clone Roles**—Clone the selected user-defined or predefined role. For more information, see *Cloning Predefined and User-Defined Roles*.
- **Tag It**—Tag one or more selected inventory objects, see, see *Tagging an Object*.
- **View Tags**—View a list of tags that exist on a selected inventory object. For more information, see *Viewing Tags for a Managed Object*.

- **Untag It**—Untag a tag that is applied to an inventory object. For more information, see *Untagging Objects*.
- **Delete Private Tags**—Delete tags that you created.
- **Clear All Selections**—Clear any role selections you made on the Roles inventory page.
- **Display Quick View**—Displays or hides a small window summarizing data about the selected object.

RELATED DOCUMENTATION

Role-Based Access Control Overview

Predefined Roles Overview

Creating Users in Junos Space Network Management Platform

Creating a User-Defined Role

Modifying User-Defined Roles

Deleting User-Defined Roles

19

PART

Working with Tunnel Services

[Tunnel Services Overview](#) | **1729**

[Service Design and Provisioning: Managing and Deploying Tunnel Services](#) | **1760**

[Monitoring and Troubleshooting Tunnel Services](#) | **1835**

Tunnel Services Overview

IN THIS CHAPTER

- Tunnel Services Overview | 1729
- Traffic Engineering Capabilities | 1730
- Components of Traffic Engineering | 1731
- Routers in an LSP | 1735
- MPLS and RSVP Overview | 1740
- Fast Reroute Overview | 1742
- Point-to-Multipoint LSPs Overview | 1745
- RSVP Operation Overview | 1747
- Link Protection and Node Protection | 1752
- Connectivity Services Director–NorthStar Controller Integration Overview | 1759

Tunnel Services Overview

Transport or tunnel services allow you to design, provision, and deploy label-switched path (LSP) services that run from a specific ingress router to a specific egress router. You can configure end-to-end point-to-point and point-to-multiple-point LSPs.

A tunnel service automates and provides a user interface for LSP service deployment, including LSP-configured Juniper Networks device discovery from the Junos Space Platform database, LSP definition configuration design, and LSP service validation and deployment.

A tunnel service is integrated with and codependent upon network services, that provide Layer 2 and Layer 3 VPN service provisioning.

Provisioning an LSP service includes the following major tasks:

- Discover Juniper Networks devices that have been configured for MPLS-Signaled LSP into Junos Space using the Devices workspace. See the MPLS-Signaled LSP Configuration Guidelines in the *Junos OS MPLS Applications Configuration Guide*.
- Discover tunneling or transport devices from the Connectivity Services Director GUI in Service View of Build mode. In the **Network Services > Connectivity** task pane, select **Prestage Devices > Prestage Devices**. View the values displayed under the Roles column of the discovered devices.

Click **Manage Device Roles** and from the drop-down list, select **Discover Roles** to retrieve the roles of the devices. A dialog box is displayed with the job ID of the discovery job that is created to obtain the latest roles of the devices.

- Assign LSP roles to provide authorization for the LSP definition designer and service activator to provision LSP services. Select **Platform > Users**.
- Create an LSP definition to use to create an LSP service. Select **TA Design > Manage TA Definitions**.
- Create and validate LSP services. Select **Service Provisioning > Manage LSPs**. You can use LSP settings in the predefined LSP definition so that they are configurable in the LSP service order.

RELATED DOCUMENTATION

[Traffic Engineering Capabilities | 1730](#)

[Components of Traffic Engineering | 1731](#)

[Routers in an LSP | 1735](#)

[MPLS and RSVP Overview | 1740](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

[RSVP Operation Overview | 1747](#)

[Link Protection and Node Protection | 1752](#)

[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)

Traffic Engineering Capabilities

The task of mapping traffic flows onto an existing physical topology is called *traffic engineering*. Traffic engineering provides the ability to move traffic flow away from the shortest path selected by the interior gateway protocol (IGP) and onto a potentially less congested physical path across a network.

Traffic engineering provides the capabilities to do the following:

- Route primary paths around known bottlenecks or points of congestion in the network.
- Provide precise control over how traffic is rerouted when the primary path is faced with single or multiple failures.
- Provide more efficient use of available aggregate bandwidth and long-haul fiber by ensuring that subsets of the network do not become overutilized while other subsets of the network along potential alternate paths are underutilized.
- Maximize operational efficiency.
- Enhance the traffic-oriented performance characteristics of the network by minimizing packet loss, minimizing prolonged periods of congestion, and maximizing throughput.
- Enhance statistically bound performance characteristics of the network (such as loss ratio, delay variation, and transfer delay) required to support a multiservices Internet.

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)

[Components of Traffic Engineering | 1731](#)

[Routers in an LSP | 1735](#)

[MPLS and RSVP Overview | 1740](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

[RSVP Operation Overview | 1747](#)

[Link Protection and Node Protection | 1752](#)

[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)

Components of Traffic Engineering

IN THIS SECTION

- [Packet Forwarding Component | 1732](#)
- [Information Distribution Component | 1733](#)
- [Path Selection Component | 1733](#)
- [Signaling Component | 1734](#)

In the Junos[®] operating system (OS), traffic engineering is implemented with MPLS and RSVP. Traffic engineering is composed of four functional components:

Packet Forwarding Component

The packet forwarding component of the Junos traffic engineering architecture is MPLS, which is responsible for directing a flow of IP packets along a predetermined path across a network. This path is called a *label-switched path (LSP)*. LSPs are simplex; that is, the traffic flows in one direction from the head-end (ingress) router to a tail-end (egress) router. Duplex traffic requires two LSPs: one LSP to carry traffic in each direction. An LSP is created by the concatenation of one or more label-switched hops, allowing a packet to be forwarded from one router to another across the MPLS domain.

When an ingress router receives an IP packet, it adds an MPLS header to the packet and forwards it to the next router in the LSP. The labeled packet is forwarded along the LSP by each router until it reaches the tail end of the LSP, the egress router. At this point the MPLS header is removed, and the packet is forwarded based on Layer 3 information such as the IP destination address. The value of this scheme is that the physical path of the LSP is not limited to what the IGP would choose as the shortest path to reach the destination IP address.

Packet Forwarding Based on Label Swapping

The packet forwarding process at each router is based on the concept of label swapping. This concept is similar to what occurs at each Asynchronous Transfer Mode (ATM) switch in a permanent virtual circuit (PVC). Each MPLS packet carries a 4-byte encapsulation header that contains a 20-bit, fixed-length label field. When a packet containing a label arrives at a router, the router examines the label and copies it as an index to its MPLS forwarding table. Each entry in the forwarding table contains an interface-inbound label pair mapped to a set of forwarding information that is applied to all packets arriving on the specific interface with the same inbound label.

How a Packet Traverses an MPLS Backbone

This section describes how an IP packet is processed as it traverses an MPLS backbone network.

At the entry edge of the MPLS backbone, the IP header is examined by the ingress router. Based on this analysis, the packet is classified, assigned a label, encapsulated in an MPLS header, and forwarded toward the next hop in the LSP. MPLS provides a high degree of flexibility in the way that an IP packet can be assigned to an LSP. For example, in the Junos traffic engineering implementation, all packets arriving at the ingress router that are destined to exit the MPLS domain at the same egress router are forwarded along the same LSP.

Once the packet begins to traverse the LSP, each router uses the label to make the forwarding decision. The MPLS forwarding decision is made independently of the original IP header: the incoming interface and label are used as lookup keys into the MPLS forwarding table. The old label is replaced with a new label, and the packet is forwarded to the next hop along the LSP. This process is repeated at each router in the LSP until the packet reaches the egress router.

When the packet arrives at the egress router, the label is removed and the packet exits the MPLS domain. The packet is then forwarded based on the destination IP address contained in the packet's original IP header according to the traditional shortest path calculated by the IP routing protocol.

Information Distribution Component

Traffic engineering requires detailed knowledge about the network topology as well as dynamic information about network loading. To implement the information distribution component, simple extensions to the IGPs are defined. Link attributes are included as part of each router's link-state advertisement. IS-IS extensions include the definition of new type length values (TLVs), whereas OSPF extensions are implemented with opaque link-state advertisements (LSAs). The standard flooding algorithm used by the link-state IGPs ensures that link attributes are distributed to all routers in the routing domain. Some of the traffic engineering extensions to be added to the IGP link-state advertisement include maximum link bandwidth, maximum reserved link bandwidth, current bandwidth reservation, and link coloring.

Each router maintains network link attributes and topology information in a specialized traffic engineering database. The traffic engineering database is used exclusively for calculating explicit paths for the placement of LSPs across the physical topology. A separate database is maintained so that the subsequent traffic engineering computation is independent of the IGP and the IGP's link-state database. Meanwhile, the IGP continues its operation without modification, performing the traditional shortest-path calculation based on information contained in the router's link-state database.

Path Selection Component

After network link attributes and topology information are flooded by the IGP and placed in the traffic engineering database, each ingress router uses the traffic engineering database to calculate the paths for its own set of LSPs across the routing domain. The path for each LSP can be represented by either a strict or loose explicit route. An explicit route is a preconfigured sequence of routers that should be part of the physical path of the LSP. If the ingress router specifies all the routers in the LSP, the LSP is said to be identified by a strict explicit route. If the ingress router specifies only some of the routers in the LSP, the LSP is described as a loose explicit route. Support for strict and loose explicit routes allows the path selection process to be given broad latitude whenever possible, but to be constrained when necessary.

The ingress router determines the physical path for each LSP by applying a Constrained Shortest Path First (CSPF) algorithm to the information in the traffic engineering database. CSPF is a shortest-path-first algorithm that has been modified to take into account specific restrictions when the shortest path across the network is calculated. Input into the CSPF algorithm includes:

- Topology link-state information learned from the IGP and maintained in the traffic engineering database
- Attributes associated with the state of network resources (such as total link bandwidth, reserved link bandwidth, available link bandwidth, and link color) that are carried by IGP extensions and stored in the traffic engineering database

- Administrative attributes required to support traffic traversing the proposed LSP (such as bandwidth requirements, maximum hop count, and administrative policy requirements) that are obtained from user configuration

As CSPF considers each candidate node and link for a new LSP, it either accepts or rejects a specific path component based on resource availability or whether selecting the component violates user policy constraints. The output of the CSPF calculation is an explicit route consisting of a sequence of router addresses that provides the shortest path through the network that meets the constraints. This explicit route is then passed to the signaling component, which establishes the forwarding state in the routers along the LSP.

Signaling Component

An LSP is not known to be workable until it is actually established by the signaling component. The signaling component, which is responsible for establishing LSP state and distributing labels, relies on a number of extensions to RSVP:

- The Explicit Route object allows an RSVP path message to traverse an explicit sequence of routers that is independent of conventional shortest-path IP routing. The explicit route can be either strict or loose.
- The Label Request object permits the RSVP path message to request that intermediate routers provide a label binding for the LSP that it is establishing.
- The Label object allows RSVP to support the distribution of labels without changing its existing mechanisms. Because the RSVP Resv message follows the reverse path of the RSVP path message, the Label object supports the distribution of labels from downstream nodes to upstream nodes.

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)

[Traffic Engineering Capabilities | 1730](#)

[Routers in an LSP | 1735](#)

[MPLS and RSVP Overview | 1740](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

[RSVP Operation Overview | 1747](#)

[Link Protection and Node Protection | 1752](#)

[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)

Routers in an LSP

Each router in an LSP performs one of the following functions:

- **Ingress router**—The router at the beginning of an LSP. This router encapsulates IP packets with an MPLS Layer 2 frame and forwards it to the next router in the path. Each LSP can have only one ingress router.
- **Egress router**—The router at the end of an LSP. This router removes the MPLS encapsulation, thus transforming it from an MPLS packet to an IP packet, and forwards the packet to its final destination using information in the IP forwarding table. Each LSP can have only one egress router. The ingress and egress routers in an LSP cannot be the same router.
- **Transit router**—Any intermediate router in the LSP between the ingress and egress routers. A transit router forwards received MPLS packets to the next router in the MPLS path. An LSP can contain zero or more transit routers, up to a maximum of 253 transit routers in a single LSP.

A single router can be part of multiple LSPs. It can be the ingress or egress router for one or more LSPs, and it also can be a transit router in one or more LSPs. The functions that each router supports depend on your network design.

How a Packet Travels Along an LSP

When an IP packet enters an LSP, the ingress router examines the packet and assigns it a label based on its destination, placing the label in the packet's header. The label transforms the packet from one that is forwarded based on its IP routing information to one that is forwarded based on information associated with the label.

The packet is then forwarded to the next router in the LSP. This router and all subsequent routers in the LSP do not examine any of the IP routing information in the labeled packet. Rather, they use the label to look up information in their label forwarding table. They then replace the old label with a new label and forward the packet to the next router in the path.

When the packet reaches the egress router, the label is removed, and the packet again becomes a native IP packet and is again forwarded based on its IP routing information.

Types of LSPs

There are three types of LSPs:

- **Static LSPs**—For static paths, you must manually assign labels on all routers involved (ingress, transit, and egress). No signaling protocol is needed. This procedure is similar to configuring static routes on individual routers. Like static routes, there is no error reporting, liveliness detection, or statistics reporting.
- **LDP-signaled LSPs**—The Label Distribution Protocol (LDP) is a protocol for distributing labels in non-traffic-engineered applications. LDP allows routers to establish label-switched paths (LSPs) through a network by mapping network-layer routing information directly to data link layer-switched paths.

These LSPs might have an endpoint at a directly attached neighbor (comparable to IP hop-by-hop forwarding), or at a network egress node, enabling switching through all intermediary nodes. LSPs established by LDP can also traverse traffic-engineered LSPs created by RSVP.

LDP associates a forwarding equivalence class (FEC) with each LSP it creates. The FEC associated with an LSP specifies which packets are mapped to that LSP. LSPs are extended through a network as each router chooses the label advertised by the next hop for the FEC and splices it to the label it advertises to all other routers. This process forms a tree of LSPs that converge on the egress router.

- **RSVP-signaled LSPs**—For signaled paths, RSVP is used to set up the path and dynamically assign labels. (RSVP signaling messages are used to set up signaled paths.) You configure only the ingress router. The transit and egress routers accept signaling information from the ingress router, and they set up and maintain the LSP cooperatively. Any errors encountered while establishing an LSP are reported to the ingress router for diagnostics. For signaled LSPs to work, a version of RSVP that supports tunnel extensions must be enabled on all routers.

There are two types of RSVP-signaled LSPs:

- **Explicit-path LSPs**—All intermediate hops of the LSP are manually configured. The intermediate hops can be strict, loose, or any combination of the two. Explicit path LSPs provide you with complete control over how the path is set up. They are similar to static LSPs but require much less configuration.
- **Constrained-path LSPs**—The intermediate hops of the LSP are automatically computed by the software. The computation takes into account information provided by the topology information from the IS-IS or OSPF link-state routing protocol, the current network resource utilization determined by RSVP, and the resource requirements and constraints of the LSP. For signaled constrained-path LSPs to work, either the IS-IS or OSPF protocol and the IS-IS or OSPF traffic engineering extensions must be enabled on all routers.

Scope of LSPs

For constrained-path LSPs, the LSP computation is confined to one IGP domain, and cannot cross any AS boundary. This prevents an AS from extending its IGP into another AS.

Explicit-path LSPs, however, can cross as many AS boundaries as necessary. Because intermediate hops are manually specified, the LSP does not depend on the IGP topology or a local forwarding table.

Constrained-Path LSP Computation

The Constrained Shortest Path First (CSPF) algorithm is an advanced form of the shortest-path-first (SPF) algorithm used in OSPF and IS-IS route computations. CSPF is used in computing paths for LSPs that are subject to multiple constraints. When computing paths for LSPs, CSPF considers not only the topology of the network, but also the attributes of the LSP and the links, and it attempts to minimize congestion by intelligently balancing the network load.


The constraints that CSPF considers include:

- LSP attributes
 - Administrative groups (that is, link color requirements)
 - Bandwidth requirements
 - Explicit route (strict or loose)
 - Hop limitations
 - Priority (setup and hold)
- Link attributes
 - Administrative groups (that is, link colors assigned to the link)
 - Reservable bandwidth of the links (static bandwidth minus the currently reserved bandwidth)

The data that CSPF considers comes from the following sources:

- Traffic engineering database—Provides CSPF with up-to-date topology information, the current reservable bandwidth of links, and the link colors. For the CSPF algorithm to perform its computations, a link-state IGP (such as OSPF or IS-IS) with special extensions is needed. For CSPF to be effective, the link-state IGP on all routers must support the special extensions. While building the topology database, the extended IGP must take into consideration the current LSPs and must flood the route information everywhere. Because changes in the reserved link bandwidth and link color cause database updates, an extended IGP tends to flood more frequently than a normal IGP. See [Figure 53 on page 1737](#) for a diagram of the relationships between these components.
- Currently active LSPs—Includes all the LSPs that should originate from the router and their current operational status (up, down, or timeout).

Figure 53: CSPF Computation Process



How CSPF Selects a Path

To select a path, CSPF follows certain rules. The rules are as follows:

1. Computes LSPs one at a time, beginning with the highest priority LSP (the one with the lowest setup priority value). Among LSPs of equal priority, CSPF services the LSPs in alphabetical order of the LSP names.
2. Prunes the traffic engineering database of all the links that are not full duplex and do not have sufficient reservable bandwidth.
3. If the LSP configuration includes the **include** statement, prunes all links that do not share any included colors.
4. If the LSP configuration includes the **exclude** statement, prunes all links that contain excluded colors. If the link does not have a color, it is accepted.
5. If several paths have equal cost, chooses the one whose last-hop address is the same as the LSP's destination.
6. If several equal cost paths remain, selects the one with the fewest number of hops.
7. If several equal-cost paths remain, applies the CSPF load-balancing rule configured on the LSP (least fill, most fill, or random).

CSPF finds the shortest path toward the LSP's egress router, taking into account explicit-path constraints. For example, if the path must pass through Router A, two separate SPF computations are computed, one from the ingress router to Router A, the other from Router A to the egress router. All CSPF rules are applied to both computations.

CSPF Path Selection Tie-Breaking

If more than one path is still available after the CSPF rules have been applied, a tie-breaking rule is applied to choose the path for the LSP. The rule used depends on the configuration. There are three tie-breaking rules:

- **Random**—One of the remaining paths is picked at random. This rule tends to place an equal number of LSPs on each link, regardless of the available bandwidth ratio. This is the default behavior.
- **Least fill**—The path with the largest minimum available bandwidth ratio is preferred. This rule tries to equalize the reservation on each link.
- **Most fill**—The path with the smallest minimum available bandwidth ratio is preferred. This rule tries to fill a link before moving on to alternative links.

The following definitions describe how a figure for minimum available bandwidth ratio is derived for the least fill and most fill rules:

- **Reservable bandwidth** = bandwidth of link x subscription factor of link
- **Available bandwidth** = reservable bandwidth – (sum of the bandwidths of the LSPs traversing the link)

- Available bandwidth ratio = available bandwidth/reservable bandwidth
- Minimum available bandwidth ratio (for a path) = the smallest available bandwidth ratio of the links in a path

NOTE: For the least fill or most fill behaviors to be used, the paths must have their bandwidth (specified using the **bandwidth** statement at the **[edit protocols mpls label-switched-path *lsp-name*]** hierarchy level) or minimum bandwidth (specified using the **minimum-bandwidth** statement at the **[edit protocols mpls label-switched-path *lsp-name* auto-bandwidth]** hierarchy level) configured to a value greater than 0. If the bandwidth or minimum bandwidth for the paths is either not configured or configured as 0, the minimum available bandwidth cannot be calculated and the random path selection behavior is used instead.

Computing CSPF Paths Offline

The Junos OS provides online, real-time CSPF computation only; each router performs CSPF calculations independent of the other routers in the network. These calculations are based on currently available topology information—information that is usually recent, but not completely accurate. LSP placements are locally optimized, based on current network status.

To optimize links globally across the network, you can use an offline tool to perform the CSPF calculations and determine the paths for the LSPs. You can create such a tool yourself, or you can modify an existing network design tool to perform these calculations. You should run the tool periodically (daily or weekly) and download the results into the router. An offline tool should take the following into account when performing the optimized calculations:

- All the LSP's requirements
- All link attributes
- Complete network topology

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)

[Traffic Engineering Capabilities | 1730](#)

[Components of Traffic Engineering | 1731](#)

[MPLS and RSVP Overview | 1740](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

MPLS and RSVP Overview

MPLS provides a mechanism for engineering network traffic patterns that is independent of routing tables. MPLS assigns short labels to network packets that describe how to forward them through the network. MPLS is independent of any routing protocol and can be used for unicast packets.

In the traditional Level 3 forwarding paradigm, as a packet travels from one router to the next, an independent forwarding decision is made at each hop. The IP network layer header is analyzed, and the next hop is chosen based on this analysis and on the information in the routing table. In an MPLS environment, the analysis of the packet header is performed just once, when a packet enters the MPLS cloud. The packet is then assigned to a stream, which is identified by a *label*, which is a short (20-bit), fixed-length value at the front of the packet. Labels are used as lookup indexes for the label forwarding table. For each label, this table stores forwarding information. You can associate additional information with a label—such as class-of-service (CoS) values—that can be used to prioritize packet forwarding.

Packets traveling along an LSP are identified by a label—a 20-bit, unsigned integer in the range 0 through 1,048,575. For push labels on ingress routers, no labels in this range are restricted. For incoming labels on the transit static LSP, the label value is restricted to 1,000,000 through 1,048,575.

On MX Series, PTX Series, and T Series routers, the value for entropy and flow labels is restricted to 16 through 1,048,575.

In the Junos OS, label values are allocated per router. The display output shows only the label (for example, **01024**). Labels for multicast packets are independent of those for unicast packets. Currently, the Junos OS does not support multicast labels.

Labels are assigned by downstream routers relative to the flow of packets. A router receiving labeled packets (the next-hop router) is responsible for assigning incoming labels. A received packet containing a label that is unrecognized (unassigned) is dropped. For unrecognized labels, the router does not attempt to unwrap the label to analyze the network layer header, nor does it generate an Internet Control Message Protocol (ICMP) destination unreachable message.

A packet can carry a number of labels, organized as a last-in, first-out stack. This is referred to as a *label stack*. At a particular router, the decision about how to forward a labeled packet is based exclusively on the label at the top of the stack.

[Figure 54 on page 1741](#) shows the encoding of a single label. The encoding appears after data link layer headers, but before any network layer header.

Figure 54: Label Encoding





Figure 55 on page 1741 illustrates the purpose of the class-of-service bits (also known as the EXP or experimental bits). Bits 20 and 21 specify the queue number. Bit 22 is the packet loss priority (PLP) bit used to specify the random early detection (RED) drop profile.

Figure 55: Class-of-Service Bits



RSVP Overview

RSVP is a resource reservation setup protocol that is used by both network hosts and routers. Hosts use RSVP to request a specific class of service (CoS) from the network for particular application flows. Routers use RSVP to deliver CoS requests to all routers along the data path. RSVP also can maintain and refresh states for a requested CoS application flow.

RSVP treats an application flow as a simplex connection. That is, the CoS request travels only in one direction—from the sender to the receiver. RSVP is a transport layer protocol that uses IP as its network layer. However, RSVP does not transport application flows. Rather, it is more of an Internet control protocol, similar to the Internet Control Message Protocol (ICMP) and Internet Group Management Protocol (IGMP). RSVP runs as a separate software process in the Junos OS and is not in the packet forwarding path.

RSVP is not a routing protocol, but rather is designed to operate with current and future unicast and multicast routing protocols. The routing protocols are responsible for choosing the routes to use to forward packets, and RSVP consults local routing tables to obtain routes. RSVP only ensures the CoS of packets traveling along a data path.

The receiver in an application flow requests the preferred CoS from the sender. To do this, the receiver issues an RSVP CoS request on behalf of the local application. The request propagates to all routers in reverse direction of the data paths toward the sender. In this process, RSVP requests might be merged, resulting in a protocol that scales well when there are a large number of receivers.

Because the number of receivers in an application flow is likely to change and the flow of delivery paths might change during the life of an application flow, RSVP takes a soft-state approach in its design, creating and removing the protocol states in routers and hosts incrementally over time. RSVP sends periodic refresh messages to maintain its state and to recover from occasional lost messages. In the absence of refresh messages, RSVP states automatically time out and are deleted.

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)

[Traffic Engineering Capabilities | 1730](#)

[Components of Traffic Engineering | 1731](#)

[Routers in an LSP | 1735](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

[RSVP Operation Overview | 1747](#)

[Link Protection and Node Protection | 1752](#)


[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)

Fast Reroute Overview

Fast reroute provides redundancy for an LSP path. When you enable fast reroute, detours are precomputed and preestablished along the LSP. In case of a network failure on the current LSP path, traffic is quickly routed to one of the detours. [Figure 56 on page 1743](#) illustrates an LSP from Router A to Router F, showing the established detours. Each detour is established by an upstream node to avoid the link toward the immediate downstream node and the immediate downstream node itself. Each detour might traverse through one or more label-switched routers (or switches) that are not shown in the figure.


Fast reroute protects traffic against any single point of failure between the ingress and egress routers (or switches). If there are multiple failures along an LSP, fast reroute itself might fail. Also, fast reroute does not protect against failure of the ingress or egress routers.

Figure 56: Detours Established for an LSP Using Fast Reroute



If a node detects that a downstream link has failed (using a link-layer-specific liveness detection mechanism) or that a downstream node has failed (for example, using the RSVP neighbor hello protocol), the node quickly switches the traffic to the detour and, at the same time, signals the ingress router about the link or node failure. [Figure 57 on page 1743](#) illustrates the detour taken when the link between Router B and Router C fails.

Figure 57: Detour After the Link from Router B to Router C Fails



If the network topology is not rich enough (there are not enough routers with sufficient links to other routers), some of the detours might not succeed. For example, the detour from Router A to Router C in [Figure 56 on page 1743](#) cannot traverse link A-B and Router B. If such a path is not possible, the detour does not occur.

Note that after the node switches traffic to the detour, it might switch the traffic again to a newly calculated detour soon after. This is because the initial detour route might not be the best route. To make rerouting as fast as possible, the node switches traffic onto the initial detour without first verifying that the detour is valid. Once the switch is made, the node recomputes the detour. If the node determines that the initial detour is still valid, traffic continues to flow over this detour. If the node determines that the initial detour is no longer valid, it again switches the traffic to a newly computed detour.

NOTE: If you issue **show** commands after the node has switched traffic to the initial detour, the node might indicate that the traffic is still flowing over the original LSP. This situation is temporary and should correct itself quickly.

The time required for a fast-rerouting detour to take effect depends on two independent time intervals:


- Amount of time to detect that there is a link or node failure—This interval depends greatly on the link layer in use and the nature of the failure. For example, failure detection on an SONET/SDH link typically is much faster than on a Gigabit Ethernet link, and both are much faster than detection of a router failure.
- Amount of time required to splice the traffic onto the detour—This operation is performed by the Packet Forwarding Engine, which requires little time to splice traffic onto the detour. The time needed can vary depending on the number of LSPs being switched to detours.

Fast reroute is a short-term patch to reduce packet loss. Because detour computation might not reserve adequate bandwidth, the detours might introduce congestion on the alternate links. The ingress router is the only router that is fully aware of LSP policy constraints and, therefore, is the only router able to come up with adequate long-term alternate paths.

Detours are created by use of RSVP and, like all RSVP sessions, they require extra state and overhead in the network. For this reason, each node establishes at most one detour for each LSP that has fast reroute enabled. Creating more than one detour for each LSP increases the overhead, but serves no practical purpose.

To reduce network overhead further, each detour attempts to merge back into the LSP as soon as possible after the failed node or link. If you can consider an LSP that travels through n router nodes, it is possible to create $n - 1$ detours. For instance, in [Figure 58 on page 1744](#), the detour tries to merge back into the LSP at Router D instead of at Router E or Router F. Merging back into the LSP makes the detour scalability problem more manageable. If topology limitations prevent the detour from quickly merging back into the LSP, detours merge with other detours automatically.

Figure 58: Detours Merging into Other Detours



RELATED DOCUMENTATION

Tunnel Services Overview 1729
Traffic Engineering Capabilities 1730
Components of Traffic Engineering 1731
Routers in an LSP 1735
MPLS and RSVP Overview 1740
Point-to-Multipoint LSPs Overview 1745
RSVP Operation Overview 1747
Link Protection and Node Protection 1752
Connectivity Services Director-NorthStar Controller Integration Overview 1759


Point-to-Multipoint LSPs Overview

A point-to-multipoint MPLS LSP is an LSP with a single source and multiple destinations. By taking advantage of the MPLS packet replication capability of the network, point-to-multipoint LSPs avoid unnecessary packet replication at the ingress router. Packet replication takes place only when packets are forwarded to two or more different destinations requiring different network paths.

This process is illustrated in [Figure 59 on page 1746](#). Router PE1 is configured with a point-to-multipoint LSP to Routers PE2, PE3, and PE4. When Router PE1 sends a packet on the point-to-multipoint LSP to Routers P1 and P2, Router P1 replicates the packet and forwards it to Routers PE2 and PE3. Router P2 sends the packet to Router PE4.

This feature is described in detail in the Internet drafts [draft-raggarwa-mpls-p2mp-te-02.txt](#) (expired February 2004), *Establishing Point to Multipoint MPLS TE LSPs*, [draft-ietf-mpls-rsvp-te-p2mp-02.txt](#), *Extensions to Resource Reservation Protocol-Traffic Engineering (RSVP-TE) for Point-to-Multipoint TE Label-Switched Paths (LSPs)*, and RFC 6388, *Label Distribution Protocol Extensions for Point-to-Multipoint and Multipoint-to-Multipoint Label Switched Paths* (only point-to-multipoint LSPs are supported).

Figure 59: Point-to-Multipoint LSPs



The following are some of the properties of point-to-multipoint LSPs:

- A point-to-multipoint LSP enables you to use MPLS for point-to-multipoint data distribution. This functionality is similar to that provided by IP multicast.
- You can add and remove branch LSPs from a main point-to-multipoint LSP without disrupting traffic. The unaffected parts of the point-to-multipoint LSP continue to function normally.
- You can configure a node to be both a transit and an egress router for different branch LSPs of the same point-to-multipoint LSP.
- You can enable link protection on a point-to-multipoint LSP. Link protection can provide a bypass LSP for each of the branch LSPs that make up the point-to-multipoint LSP. If any of the primary paths fail, traffic can be quickly switched to the bypass.
- You can configure branch LSPs either statically, dynamically, or as a combination of static and dynamic LSPs.
- You can enable graceful Routing Engine switchover (GRES) and graceful restart for point-to-multipoint LSPs at ingress and egress routers. The point-to-multipoint LSPs must be configured using either static routes or circuit cross-connect (CCC). GRES and graceful restart allow the traffic to be forwarded at the Packet Forwarding Engine based on the old state while the control plane recovers. Feature parity for GRES and graceful restart for MPLS point-to-multipoint LSPs on the Junos Trio chipset is supported in Junos OS Releases 11.1R2, 11.2R2, and 11.4.

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)[Traffic Engineering Capabilities | 1730](#)[Components of Traffic Engineering | 1731](#)[Routers in an LSP | 1735](#)[MPLS and RSVP Overview | 1740](#)[Fast Reroute Overview | 1742](#)[RSVP Operation Overview | 1747](#)[Link Protection and Node Protection | 1752](#)[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)

RSVP Operation Overview

A Resource Reservation Protocol (RSVP) label-switched path (LSP) tunnel enables you to send RSVP LSPs inside other RSVP LSPs. This enables a network administrator to provide traffic engineering from one end of the network to the other. A useful application for this feature is to connect customer edge (CE) routers with provider edge (PE) routers by using an RSVP LSP, and then tunnel this edge LSP inside a second RSVP LSP traveling across the network core.

You should have a general understanding of MPLS and label switching concepts. For more information about MPLS, see the *Junos MPLS Applications Configuration Guide*.

An RSVP LSP tunnel adds the concept of a forwarding adjacency, similar to the one used for generalized Multiprotocol Label Switching (GMPLS).

The forwarding adjacency creates a tunneled path for sending data between peer devices in an RSVP LSP network. Once a forwarding adjacency LSP (FA-LSP) has been established, other LSPs can be sent over the FA-LSP by using Constrained Shortest Path First (CSPF), Link Management Protocol (LMP), Open Shortest Path First (OSPF), and RSVP.

To enable an RSVP LSP tunnel, the Junos OS uses the following mechanisms:

- LMP—Originally designed for GMPLS, LMP establishes forwarding adjacencies between RSVP LSP tunnel peers, and maintains and allocates resources for traffic engineering links.
- OSPF extensions—OSPF was designed to route packets to physical and logical interfaces related to a Physical Interface Card (PIC). This protocol has been extended to route packets to virtual peer interfaces defined in an LMP configuration.

- RSVP-TE extensions—RSVP-TE was designed to signal the setup of packet LSPs to physical interfaces. The protocol has been extended to request path setup for packet LSPs traveling to virtual peer interfaces defined in an LMP configuration.

The following limitations exist for LSP hierarchies:

- Circuit cross-connect (CCC)-based LSPs are not supported.
- Graceful restart is not supported.
- Link protection is not available for FA-LSPs or at the egress point of the forwarding adjacency.
- Point-to-multipoint LSPs are not supported across FA-LSPs.

RSVP creates independent sessions to handle each data flow. A session is identified by a combination of the destination address, an optional destination port, and a protocol. Within a session, there can be one or more senders. Each sender is identified by a combination of its source address and source port. An out-of-band mechanism, such as a session announcement protocol or human communication, is used to communicate the session identifier to all senders and receivers.

A typical RSVP session involves the following sequence of events:

1. A potential sender starts sending RSVP path messages to the session address.
2. A receiver, wanting to join the session, registers itself if necessary. For example, a receiver in a multicast application would register itself with IGMP.
3. The receiver receives the path messages.
4. The receiver sends appropriate Resv messages toward the sender. These messages carry a flow descriptor, which is used by routers along the path to make reservations in their link-layer media.
5. The sender receives the Resv message and then starts sending application data.

This sequence of events is not necessarily strictly synchronized. For example, receivers can register themselves before receiving path messages from the sender, and application data can flow before the sender receives Resv messages. Application data that is delivered before the actual reservation contained in the Resv message typically is treated as best-effort, non-real-time traffic with no CoS guarantee.

RSVP Hello Packets and Timers

RSVP monitors the status of the interior gateway protocol (IGP) (IS-IS or OSPF) neighbors and relies on the IGP protocols to detect when a node fails. If an IGP protocol declares a neighbor down (because hello packets are no longer being received), RSVP also brings down that neighbor. However, the IGP protocols and RSVP still act independently when bringing a neighbor up.

In the Junos OS, RSVP typically relies on IGP hello packet detection to check for node failures. RSVP sessions are kept up even if RSVP hello packets are no longer being received, so long as the router continues to receive IGP hello packets. RSVP sessions are maintained until either the router stops receiving IGP hello

packets or the RSVP Path and Resv messages time out. Configuring a short time for the IS-IS or OSPF hello timers allows these protocols to detect node failures quickly.

RSVP hellos can be relied on when the IGP does not recognize a particular neighbor (for example, if IGP is not enabled on the interface) or if the IGP is RIP (not IS-IS or OSPF). Also, the equipment of other vendors might be configured to monitor RSVP sessions based on RSVP hello packets. This equipment might also take an RSVP session down due to a loss of RSVP hello packets.

We do not recommend configuring a short RSVP hello timer. If quick discovery of a failed neighbor is needed, configure short IGP (OSPF or IS-IS) hello timers.

OSPF and IS-IS have infrastructure to manage rapid hello message sending and receiving reliably, even if the routing protocols or some other process are straining the processing capability of the router. Under the same circumstances, RSVP hellos might time out prematurely even though the neighbor is functioning normally.

RSVP Message Types

IN THIS SECTION

- [Path Messages | 1749](#)
- [Resv Messages | 1750](#)
- [PathTear Messages | 1750](#)
- [ResvTear Messages | 1750](#)
- [PathErr Messages | 1750](#)
- [ResvErr Messages | 1750](#)
- [ResvConfirm Messages | 1750](#)

RSVP uses the following types of messages to establish and remove paths for data flows, establish and remove reservation information, confirm the establishment of reservations, and report errors:

Path Messages

Each sender host transmits path messages downstream along the routes provided by the unicast and multicast routing protocols. Path messages follow the exact paths of application data, creating path states in the routers along the way, thus enabling routers to learn the previous-hop and next-hop node for the session. Path messages are sent periodically to refresh path states.

The refresh interval is controlled by a variable called the **refresh-time**, which is the periodical refresh timer expressed in seconds. A path state times out if a router does not receive a specified number of consecutive

path messages. This number is specified by a variable called **keep-multiplier**. Path states are kept for $((\text{keep-multiplier} + 0.5) \times 1.5 \times \text{refresh-time})$ seconds.

Resv Messages

Each receiver host sends reservation request (Resv) messages upstream toward senders and sender applications. Resv messages must follow exactly the reverse path of path messages. Resv messages create and maintain a reservation state in each router along the way.

Resv messages are sent periodically to refresh reservation states. The refresh interval is controlled by the same refresh time variable, and reservation states are kept for $((\text{keep-multiplier} + 0.5) \times 1.5 \times \text{refresh-time})$ seconds.

PathTear Messages

PathTear messages remove (tear down) path states as well as dependent reservation states in any routers along a path. PathTear messages follow the same path as path messages. A PathTear typically is initiated by a sender application or by a router when its path state times out.

PathTear messages are not required, but they enhance network performance because they release network resources quickly. If PathTear messages are lost or not generated, path states eventually time out when they are not refreshed, and the resources associated with the path are released.

ResvTear Messages

ResvTear messages remove reservation states along a path. These messages travel upstream toward senders of the session. In a sense, ResvTear messages are the reverse of Resv messages. ResvTear messages typically are initiated by a receiver application or by a router when its reservation state times out.

ResvTear messages are not required, but they enhance network performance because they release network resources quickly. If ResvTear messages are lost or not generated, reservation states eventually time out when they are not refreshed, and the resources associated with the reservation are released.

PathErr Messages

When path errors occur (usually because of parameter problems in a path message), the router sends a unicast PathErr message to the sender that issued the path message. PathErr messages are advisory; these messages do not alter any path state along the way.

ResvErr Messages

When a reservation request fails, a ResvErr error message is delivered to all the receivers involved. ResvErr messages are advisory; these messages do not alter any reservation state along the way.

ResvConfirm Messages

Receivers can request confirmation of a reservation request, and this confirmation is sent with a ResvConfirm message. Because of the complex RSVP flow-merging rules, a confirmation message does not necessarily provide end-to-end confirmation of the entire path. Therefore, ResvConfirm messages are an indication, not a guarantee, of potential success.

Juniper Networks routers never request confirmation using the ResvConfirm message; however, a Juniper Networks router can send a ResvConfirm message if it receives a request from another vendor's equipment.

MTU Signaling in RSVP

The maximum transmission unit (MTU) is the largest size packet or frame, in bytes, that can be sent in a network. An MTU that is too large might cause retransmissions. Too small an MTU might cause the router to send and handle relatively more header overhead and acknowledgments. There are default values for MTUs associated with various protocols. You can also explicitly configure an MTU on an interface.

When an LSP is created across a set of links with different MTU sizes, the ingress router does not know what the smallest MTU is on the LSP path. By default, the MTU for an LSP is 1,500 bytes.

If this MTU is larger than the MTU of one of the intermediate links, traffic might be dropped, because MPLS packets cannot be fragmented. Also, the ingress router is not aware of this type of traffic loss, because the control plane for the LSP would still function normally.

To prevent this type of packet loss in MPLS LSPs, you can configure MTU signaling in RSVP. This feature is described in RFC 3209. Juniper Networks supports the Integrated Services object for MTU signaling in RSVP. The Integrated Services object is described in RFCs 2210 and 2215. MTU signaling in RSVP is disabled by default.

To avoid packet loss due to MTU mismatches, the ingress router needs to do the following:

- Signal the MTU on the RSVP LSP—To prevent packet loss from an MTU mismatch, the ingress router needs to know what the smallest MTU value is along the path taken by the LSP. Once this MTU value is obtained, the ingress router can assign it to the LSP.
- Fragment packets—Using the assigned MTU value, packets that exceed the size of the MTU can be fragmented into smaller packets on the ingress router before they are encapsulated in MPLS and sent over the RSVP-signaled LSP.

Once both MTU signaling and packet fragmentation have been enabled on an ingress router, any route resolving to an RSVP LSP on this router uses the signaled MTU value.

The following are limitations to MTU signaling in RSVP:

- Changes in the MTU value might cause a temporary loss of traffic in the following situations:
 - For link protection and node protection, the MTU of the bypass is only signaled at the time the bypass becomes active. During the time it takes for the new path MTU to be propagated, packet loss might occur because of an MTU mismatch.
 - For fast reroute, the MTU of the path is updated only after the detour becomes active, causing a delay in an update to the MTU at the ingress router. Until the MTU is updated, packet loss might occur if there is an MTU mismatch.

In both cases, only packets that are larger than the detour or bypass MTU are lost.

- When an MTU is updated, it triggers a change in the next hop. Any change in the next hop causes the route statistics to be lost.
- The minimum MTU supported for MTU signaling in RSVP is 1,488 bytes. This value prevents a false or incorrectly configured value from being used.
- For single-hop LSPs, the MTU value displayed by the **show** commands is the RSVP-signaled value. However, this MPLS value is ignored and the correct IP value is used.

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)

[Traffic Engineering Capabilities | 1730](#)

[Components of Traffic Engineering | 1731](#)

[Routers in an LSP | 1735](#)

[MPLS and RSVP Overview | 1740](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

[Link Protection and Node Protection | 1752](#)

[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)


Link Protection and Node Protection

Link protection helps to ensure that traffic going over a specific interface to a neighboring router or switch can continue to reach this router (switch) if that interface fails. When link protection is configured for an interface and an LSP that traverses this interface, a bypass LSP is created that will handle this traffic if the interface fails. The bypass LSP uses a different interface and path to reach the same destination. The path used can be configured explicitly, or you can rely on CSPF. The RSVP metric for the bypass LSP is set in the range of 20,000 through 29,999 (this value is not user configurable).

If a link-protected interface fails, traffic is quickly switched to the bypass LSP. Note that a bypass LSP cannot share the same egress interface with the LSPs it monitors.

In [Figure 60 on page 1753](#), link protection is enabled on Interface B between Router 1 and Router 2. It is also enabled on LSP A, an LSP that traverses the link between Router 1 and Router 2. If the link between Router 1 and Router 2 fails, traffic from LSP A is quickly switched to the bypass LSP generated by link protection.

Figure 60: Link Protection Creating a Bypass LSP for the Protected Interface



Although LSPs traversing an interface can be configured to take advantage of link protection, it is important to note that it is specifically the interface that benefits from link protection. If link protection is enabled on an interface but not on a particular LSP traversing that interface, then if the interface fails, that LSP will also fail.

NOTE: Link protection does not work on unnumbered interfaces.

Node Protection


Node protection extends the capabilities of link protection. Link protection helps to ensure that traffic going over a specific interface to a neighboring router can continue to reach this router if that interface fails. Node protection ensures that traffic from an LSP traversing a neighboring router can continue to reach its destination even if the neighboring router fails.

When you enable node protection for an LSP, you must also enable link protection. Once enabled, node protection and link protection establish the following types of bypass LSPs:

- Next-hop bypass LSP—Provides an alternate route for an LSP to reach a neighboring router. This type of bypass LSP is established when you enable either node protection or link protection.
- Next-next-hop bypass LSP—Provides an alternate route for an LSP to get around a neighboring router en route to the destination router. This type of bypass LSP is established exclusively when node protection is configured. If a next-next-hop bypass LSP cannot be created, an attempt is made to signal a next-hop bypass LSP.

In [Figure 61 on page 1754](#), node protection is enabled on Interface B on Router 1. Node protection is also enabled on LSP A, an LSP that traverses the link transiting Router 1, Router 2, and Router 3. If Router 2 suffers a hardware or software failure, traffic from LSP A is switched to the next-next-hop bypass LSP generated by node protection.

Figure 61: Node Protection Creating a Next-Next-Hop Bypass LSP



The time needed by node protection to switch traffic to a next-next-hop bypass LSP can be significantly longer than the time needed by link protection to switch traffic to a next-hop bypass LSP. Link protection relies on a hardware mechanism to detect a link failure, allowing it to quickly switch traffic to a next-hop bypass LSP.

Node failures are often due to software problems on the node router. Node protection relies on the receipt of hello messages from a neighboring router to determine whether it is still functioning. The time it takes node protection to divert traffic partly depends on how often the node router sends hello messages and how long it takes the node-protected router to react to having not received a hello message. However, once the failure is detected, traffic can be quickly diverted to the next-next-hop bypass LSP.

NOTE:

Node protection provides traffic protection in the event of an error or interruption of the physical link between two routers. It does not provide protection in the event of control plane errors.

The following provides an example of a control plane error:

- A transit router changes the label of a packet due to a control plane error.
- When the ingress router receives the packet, it considers the label change to be a catastrophic event and deletes both the primary LSP and the associated bypass LSP.

LSP Protection Overview

RSVP-TE extensions establish backup label-switched path (LSP) tunnels for local repair of LSP tunnels. These mechanisms enable immediate re-direction of traffic onto backup LSP tunnels, in the event of a failure.

RFC 4090, *Fast Reroute Extensions to RSVP-TE for LSP Tunnels*, describes two different types of traffic protection for RSVP-signaled LSPs:

- One-to-one backup—In this method, detour LSPs for each protected LSP is created at each potential point of local repair.
- Facility backup—In this method, a bypass tunnel is created to protect a set of LSPs that have similar backup constraints at a potential failure point, by taking advantage of the MPLS label stacking.

The one-to-one backup and the facility backup methods protect links and nodes during network failure, and can co-exist in a mixed network.

LSP Protection Types Comparison

In the Junos OS, the one-to-one backup of traffic protection is provided by fast reroute. Each LSP requires a protecting LSP to be signaled at each hop except the egress router. This method of LSP protection cannot be shared.

In the facility backup method, the LSP traffic protection is provided on the node and link. Each LSP requires a protecting LSP to be signaled at each hop except the egress router. Unlike fast reroute, this protecting LSP can be shared by other LSPs.

[Table 238 on page 1755](#) summarizes the traffic protection types.

Table 238: One-to-One Backup Compared with Facility Backup

Comparison	One-to-One Backup	Facility Backup
Name of the protecting LSP	Detour LSP	Bypass LSP
Sharing of the protecting LSP	Cannot be shared	Can be shared by multiple LSPs
Junos configuration statements	fast-reroute	node-link-protection and link-protection

One-to-One Backup Implementation

In the one-to-one backup method, the points of local repair maintain separate backup paths for each LSP passing through a facility. The backup path terminates by merging back with the primary path at a node called the merge point. In this approach, the merge point can be any node downstream from the protected facility.

In the one-to-one backup method, an LSP is established that intersects the original LSP downstream of the point of link or node failure. A separate backup LSP is established for each LSP that is backed up.


One-to-one backup is appropriate under the following circumstances:

- Protection of a small number of LSPs relative to the total number of LSPs.
- Path selection criteria, such as bandwidth, priority, and link coloring for detour paths is critical.
- Control of individual LSPs is important.

In [Figure 62 on page 1756](#), Routers R1 and R5 are the ingress and egress routers, respectively. A protected LSP is established between the two routers transiting Routers R2, R3, and R4. Router R2 provides user

traffic protection by creating a partial backup LSP that merges with the protected LSP at Router R4. This partial one-to-one backup LSP is called a detour. Detours are always calculated to avoid the immediate downstream link and node, providing against both link and node failure.

Figure 62: One-to-One Backup



In the example, the protected LSP is **R1-R2-R3-R4-R5**, and the following detours are established:

- Router R1—**R1-R6-R7-R8-R3**
- Router R2—**R2-R7-R8-R4**
- Router R3—**R3-R8-R9-R5**
- Router R4—**R4-R9-R5**

To protect an LSP that traverses **N** nodes fully, there can be as many as **(N - 1)** detours. The point of local repair sends periodic refresh messages to maintain each backup path, as a result maintaining state information for backup paths protecting individual LSPs is a significant resource burden for the point of local repair. To minimize the number of LSPs in the network, it is desirable to merge a detour back to its protected LSP, when feasible. When a detour LSP intersects its protected LSP at an LSR with the same outgoing interface, it is merged.

Facility Backup Implementation

In the facility backup approach, a point of local repair maintains a single backup path to protect a set of primary LSPs traversing the point of local repair, the facility, and the merge point. The facility backup is based on interface rather than on LSP. While fast reroute protects interfaces or nodes along the entire path of a LSP, the facility backup protection can be applied on interfaces as needed. As a result, fewer

states need to be maintained and refreshed which results in a scalable solution. The facility backup method is also called many-to-one backup.

The facility backup method takes advantage of the MPLS label stack. Instead of creating a separate LSP for every backed-up LSP, a single LSP is created that serves to back up a set of LSPs. Such an LSP tunnel is called a bypass tunnel. In this method, a router immediately upstream from a link failure uses an alternate interface to forward traffic to its downstream neighbor, and the merge point should be the node immediately downstream to the facility. This is accomplished by preestablishing a bypass path that is shared by all protected LSPs traversing the failed link. A single bypass path can safeguard a set of protected LSPs. When an outage occurs, the router immediately upstream from the link outage switches protected traffic to the bypass link, then signals the link failure to the ingress router.


The bypass tunnel must intersect the path of the original LSP(s) somewhere downstream of the point of local repair. This constrains the set of LSPs being backed up through that bypass tunnel to those that pass through some common downstream nodes. All LSPs that pass through the point of local repair and through this common node, and that do not also use the facilities involved in the bypass tunnel are candidates for this set of LSPs.

The facility backup method is appropriate in the following situations:

- The number of LSPs to be protected is large.
- Satisfying path selection criteria (priority, bandwidth, and link coloring) for bypass paths is less critical.
- Control at the granularity of individual LSPs is not required.

In [Figure 63 on page 1758](#), Routers R1 and R5 are the ingress and egress routers, respectively. Router R2 has established a bypass tunnel that protects against the failure of Router R2-R3 link and Router R3 node. A bypass tunnel is established between Routers R6 and R7. There are three different protected LSPs that are using the same bypass tunnel for protection.

Figure 63: Facility Backup



The facility backup method provides a scalability improvement, wherein the same bypass tunnel is also used to protect LSPs from any of Routers R1, R2, or R8 to any of Routers R4, R5, or R9.

RELATED DOCUMENTATION

[Tunnel Services Overview | 1729](#)

[Traffic Engineering Capabilities | 1730](#)

[Components of Traffic Engineering | 1731](#)

[Routers in an LSP | 1735](#)

[MPLS and RSVP Overview | 1740](#)

[Fast Reroute Overview | 1742](#)

[Point-to-Multipoint LSPs Overview | 1745](#)

[RSVP Operation Overview | 1747](#)

[Connectivity Services Director–NorthStar Controller Integration Overview | 1759](#)

Connectivity Services Director–NorthStar Controller Integration Overview

The Juniper Networks NorthStar Controller is a software-defined networking (SDN) controller that provides granular visibility and control of IP/MPLS tunnels in large service provider and enterprise networks. Network operators can use NorthStar Controller to optimize their network infrastructure through proactive monitoring, planning, and explicit routing of large traffic loads dynamically based on user-defined configuration.

For more information on NorthStar Controller, see the [NorthStar Controller User Guide](#).

The integration of NorthStar and Connectivity Services Director provides a single configuration window by allowing you to create, modify, delete, and monitor RSVP LSPs and Segment Routing LSPs using REST APIs. With the integration, you can create segment routing LSPs by using NorthStar Controller, as Connectivity Services Director currently supports the creation of RSVP LSPs only.

Starting from Release 3.0 onward, you can choose NorthStar Controller to manage LSPs from the Connectivity Services Director user interface. The NorthStar tab in the Preferences page displays the attributes listed in [Table 19 on page 166](#).

Table 239: NorthStar Parameters

Fields	Description
Enable NorthStar LSP Management	Select this check box to manage LSPs through the NorthStar Controller server.
PCEP for Provisioning	Select this check box to enable PCEP as the provisioning type for LSPs.
Provisioning Type	Select either RSVP or Segment Routing as the provisioning type. Default: RSVP
Credentials	Enter the NorthStar server IP , Username , and Password to validate your access to the NorthStar server.

RELATED DOCUMENTATION

[Creating an LSP Service Definition | 1763](#)

[Creating an LSP Service Order | 1775](#)

Service Design and Provisioning: Managing and Deploying Tunnel Services

IN THIS CHAPTER

- [Managing Devices and Tunnel Services Overview | 1761](#)
- [Discovering Tunnel Devices | 1761](#)
- [Creating an LSP Service Definition | 1763](#)
- [Creating an LSP Service Order | 1775](#)
- [Creating Public and Private LSPs | 1804](#)
- [Viewing the Configured LSP Services | 1806](#)
- [Modifying an Explicit Path in RSVP LSP Services | 1808](#)
- [Modifying an RSVP LSP Service | 1810](#)
- [Viewing LSP Services in Deploy Mode | 1811](#)
- [Viewing LSP Service Orders in a Table | 1813](#)
- [Deactivating an LSP Service | 1814](#)
- [Reactivating an LSP Service | 1816](#)
- [Force-Deploying an LSP Service | 1817](#)
- [Viewing Alarms for an LSP Service | 1819](#)
- [Managing Deployment of LSP Services Configuration to Devices | 1820](#)
- [Deploying an LSP Service | 1825](#)
- [Deleting a Partial Configuration of an LSP Service Order | 1827](#)
- [Deleting an LSP Service Order | 1828](#)
- [Validating the Pending Configuration of an LSP Service Order | 1829](#)
- [Viewing the Configuration of a Pending LSP Service Order | 1830](#)
- [Viewing the Configuration Details of RSVP LSP Services | 1832](#)
- [Viewing Decommissioned LSP Service Orders | 1833](#)

Managing Devices and Tunnel Services Overview

The design and provisioning workspaces include tasks that enable you to do the following:

- **Discover LSP Devices**—Discovers Juniper Networks devices that have been discovered in the Junos Space database or resynthesizes LSP and GRE devices that are already discovered. You can discover devices to bring them under the administration and management of Connectivity Services Director by using the Junos Space Network Management Platform application or by using the Connectivity Services Director application in Device View of Build mode by selecting Device Discovery > Discover Devices from the Tasks pane.
- **Manage LSP Service Orders**—Enables you to manage TA service orders, such as deploying the service orders, viewing pending configuration, deleting partial configuration, and discarding and validating pending configuration using the Manage Service Deployment page (accessible in Deploy mode of Service View by selecting **Service Provisioning > Deploy Services** from the tasks pane).
- **Manage LSP Services**—Enables you to manage services, including actions that let you decommission services, perform functional audits, view functional audit results, and view service configuration changes for TA services using the Manage LSP Services page (accessible in Deploy mode of Service View by selecting **Service Provisioning > Deploy Services** from the tasks pane).

The provisioning workspace allows you, the MPLS LSP service designer to create and manage LSP definitions to use as a starting point for provisioning services. You must have Service Designer privileges to create a tunnel service or LSP service definition. You must first discover Juniper Networks devices that have been configured for MPLS LSPs and create an LSP definition..

Discovering Tunnel Devices

When you start Connectivity Services Director for the first time, the system does not have any devices. The first step is to build your network. Even with large networks, Connectivity Services Director has made this step relatively easy and straightforward. You will add devices to Connectivity Services Director and the database by using a process called *device discovery*. Once a device is discovered, it shows in the interface and Connectivity Services Director begins to monitor the device.

Connectivity Services Director provides a wizard for device discovery. The following example shows the path for device discovery through the wizard. For an alternate path, you can get a step-by-step instruction from the help system.

Before you discover tunneling devices:

- Ensure that the devices that you want to discover are configured for MPLS with the required interface in the Junos OS configuration hierarchy [edit protocols mpls]. See the *Junos Software MPLS Configuration Guide*.

In this example, we provide an IP address range, and Connectivity Services Director populates the database with all supported devices within that range.

1. While in the **Build** mode, select **Device View** or **Custom Group View** from the View selector.
2. To discover physical devices, click **Discover Devices** in the Tasks pane. Each mode has a Tasks Pane that displays the actions you can take while in that mode and that particular network view.
3. (Optional) Type a name for the discovery job. The default name is ND Discovery.
4. Click **Add** in the Device Targets window. You can add a single device IP address, a range of IP addresses, an IP subnet, or a hostname. In this example, we select an IP address range.
5. Provide the initial or the lowest IP address value and the ending or highest IP address value for the range and click **Add**. You can have up to 1024 devices in a range. After you click Add, the address range is listed in the Device Targets window.
6. Click **Next** or click **Discovery Options** to proceed to specify the device credentials and method of discovery.
7. Click **Add** in the Device Credentials window and enter the username and password assigned for administrative access.
8. Select **Ping**, **SNMP**, or both as the method of device discovery. Selecting both is the preferred method if the device is configured for SNMP.

If you select SNMP, the Add SNMP Settings dialog box is displayed. In this example, because we run SNMP version 2, we need to provide the community string. Click **Add** to save the setting.

NOTE: You cannot choose a method for device discovery for virtual network discovery.

9. Click **Next** or **Schedule Options** to proceed to schedule the time when discovery is run.

NOTE: Scheduling options are not available for virtual network discovery.

10. Indicate whether to run the device discovery now or set up a schedule to minimize network traffic. In this example, we set the schedule to run during off hours.
11. Click **Review** to review the settings before you exit the wizard.
12. Click **Finish** to complete the discovery setup and to save the settings.
13. Click **View Discovery Status** to view all scheduled and completed jobs. After a job completes, you can click **Show Details** to view further information on any unexpected results.

RELATED DOCUMENTATION

[Viewing LSP Service Orders in a Table | 1813](#)

[Deactivating an LSP Service | 1814](#)

[Reactivating an LSP Service | 1816](#)

Creating an LSP Service Definition

IN THIS SECTION

- [Specifying General Settings | 1763](#)
- [Specifying Path Settings | 1767](#)
- [Specifying BFD Settings | 1771](#)
- [Reviewing the Configured Settings | 1774](#)

Specifying General Settings

From Connectivity Services Director Release 3.0 onward, you can create a service definition for Label-switched Paths (LSPs) and use this definition for your service order.

1. From the View selector, select **Service View**.

The workspaces that are applicable to routing and tunnel services are displayed.

2. Click the **Build** icon in the Service View of the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed in the task pane.

3. In the **Network Services** pane, select **Tunnel > Service Provisioning > Manage LSP Service Definitions**. The Manage Service Definitions page appears displaying all the configured LSP service definitions.
4. Click the **New** icon, which is present above the list of configured service definitions. The **Create LSP Service Definitions** dialog box appears.

NOTE: The availability of attributes in the service definition creation workflow varies based on whether you choose Connectivity Services Director or NorthStar Controller to manage your LSPs.

Fill in the fields in the General window.

5. Configure the general settings as indicated in [Table 240 on page 1764](#).

Table 240: General Settings

Field	Description
Service Definition Name	Enter a name for the service definition.
Description (Optional)	<p>Enter a brief description or other comment that you want to appear in the Service Definition table.</p> <p>Range: 0 through 200 characters.</p> <p>Spaces and special characters are allowed.</p>
Provisioning Type	<p>Displays either RSVP or Segment Routing based on the value you choose from the NorthStar tab in the Preferences window.</p> <p>Default: RSVP</p>
Provisioning Method	<p>Choose either NETCONF or PCEP from the drop down to specify the provisioning method.</p> <p>Default: NETCONF</p> <p>NOTE: PCEP is available only if the PCEP for Provisioning check box is selected from the Northstar tab in the Preferences window.</p>

Table 240: General Settings (continued)

Field	Description
Topology Type	<p>Select the LSP transport topology from the list:</p> <ul style="list-style-type: none"> • P2P—Provides a point-to-point connectivity between the selected endpoints • P2MP—Provides a point-to-multipoint connectivity between the selected endpoints • Full Mesh—Provides any-to-any unidirectional MPLS connectivity among all the selected provider edge router
Retry Limit	<p>This field is enabled only if Enable NorthStar LSP Management is cleared from the Preferences window.</p> <p>Range: 0 through 10,000</p> <p>Default: 0</p>
Retry Timer (sec)	<p>This field is enabled only if Enable NorthStar LSP Management is cleared from the Preferences window.</p> <p>Range: 1 through 600 seconds</p> <p>Default: 30 seconds</p>
Bandwidth (kbps)	<p>Specify the bandwidth in Kbps.</p> <p>A non-zero bandwidth requires that transit and egress routers reserve capacity along the outbound links for the path.</p> <p>The RSVP scheme is used to reserve this capacity. Any failure in bandwidth reservation (such as failures at RSVP policy control or admission control) might cause the LSP setup to fail.</p> <p>If there is insufficient bandwidth on the interfaces for the transit or egress routers, the LSP is not established.</p> <p>Range: 0 through 2147483</p>
LDP Tunneling	<p>Select this check box to enable LDP tunneling.</p> <p>NOTE: The attribute is not configurable for P2MP topology and is visible only if Enable NorthStar LSP Management is disabled in the Preferences window.</p>
Enable Fast Reroute	<p>Select this check box to enable fast reroute.</p> <p>NOTE: The attribute is not configurable for P2MP topology and is visible only if Enable NorthStar LSP Management is disabled in the Preferences window.</p>

Table 240: General Settings (continued)

Field	Description
Path Selection Type	<p>You can select either CSPF or Explicit Path options. This field is visible only if Enable NorthStar LSP Management is disabled in the Preferences window.</p> <p>Default: CSPF</p>
LSP Protection Type	<p>You can choose either Path Protection, Local Protection, or Path and Local Protection options from the list.</p> <p>This field is visible only if Enable NorthStar LSP Management is disabled in the Preferences window.</p> <p>Default: Path Protection</p>
Local Protection Type	<p>You can choose either Link Protection or Node-Link Protection type from the list.</p> <p>This field is visible only if Enable NorthStar LSP Management is disabled in the Preferences window.</p> <p>Default: Link Protection</p> <p>NOTE: This list is unavailable if the LSP Protection Type is Path Protection.</p>
Auto-Bandwidth	<p>Select the Auto-Bandwidth check box to edit Adjust Interval, Minimum Bandwidth, and Maximum Bandwidth fields.</p> <p>NOTE: Auto-Bandwidth is not configurable for Full Mesh topology and also when path selection type is Explicit Path.</p> <p>This field is visible only if Enable NorthStar LSP Management is disabled in the Preferences window.</p>
Adjust Interval (sec)	<p>Specify the bandwidth reallocation interval.</p> <p>Range: 300 through 4,294,967,295 seconds</p> <p>Default: 86,400 seconds</p> <p>This field is enabled only if Auto-Bandwidth check box is selected and Enable NorthStar LSP Management is disabled in the Preferences window.</p>

Table 240: General Settings (continued)

Field	Description
Minimum Bandwidth (kbps)	<p>Specify the minimum bandwidth in Kbps or an LSP with automatic bandwidth allocation enabled.</p> <p>Default: 1000 Kbps</p> <p>Range: 1 through 2147483 Kbps</p> <p>You must enter the minimum bandwidth to be lower than the maximum bandwidth.</p> <p>This field is enabled only if Auto-Bandwidth check box is selected and Enable NorthStar LSP Management is disabled in the Preferences window.</p>
Maximum Bandwidth (kbps)	<p>Specify the maximum bandwidth in Kbps or an LSP with automatic bandwidth allocation enabled. You can maintain the LSP's bandwidth between minimum and maximum bounds by specifying values.</p> <p>Default: 10000 Kbps</p> <p>Range: 1 through 2147483 Kbps</p> <p>This field is enabled only if Auto-Bandwidth check box is selected and Enable NorthStar LSP Management is disabled in the Preferences window.</p>

- Click **Next** to specify the Path Settings.

The Path settings that you can configure for the LSP service definition are displayed.

Specifying Path Settings

- Fill in the parameters as indicated in [Table 241 on page 1768](#).

Table 241: Path Settings

Field	Description
Class of Service	<p>Specify a decimal number.</p> <p>This number corresponds to a 3-bit binary number. The two higher-order bits of the CoS value is used to select the transmit queue to be used on the outbound interface card. The lower order bit of the CoS value is treated as the packet loss priority (PLP) bit and is used to select the random early detection (RED) drop profile to be used on the output queue. If the lower order bit is 0, the non-PLP drop profile is used, and if the lower order bit is 1, the PLP drop profile is used.</p> <p>Typically, RED aggressively drops packets that have the PLP bit set. For more information about RED and drop profiles, see the Junos OS Class of Service Configuration Guide.</p> <p>Range: A decimal number from 0 through 7</p> <p>This field is not available for local-Protection type of LSPs.</p>
Hop Limit	<p>Specify the hop limit of the LSP.</p> <p>A path with two hops consists of the ingress and egress routers only.</p> <p>Range: 2 through 255</p> <p>Default: Each LSP can traverse a maximum of 255 hops, including the ingress and egress routers.</p>
Standby (Enable Switchover)	<p>Select this check box to have the path remain up at all times to provide immediate switchover if connectivity problems occur.</p> <p>This field is displayed only for secondary paths.</p>

Table 241: Path Settings (*continued*)

Field	Description
Adaptive	<p>Select this check box if you want to configure an LSP to be adaptive when it is attempting to reroute itself.</p> <p>When adaptive, the LSP holds onto existing resources until the new path is successfully established and traffic is switched over to the new LSP.</p> <p>Select this check box if you want to configure an LSP to be adaptive when it is attempting to reroute itself.</p> <p>When adaptive, the LSP holds onto existing resources until the new path is successfully established and traffic is switched over to the new LSP.</p> <p>To retain its resources, an adaptive LSP does the following:</p> <ul style="list-style-type: none"> • Maintains existing paths and allocated bandwidths—This ensures that the existing path is not torn down prematurely and allows the current traffic to continue flowing while the new path is being set up. • Avoids double-counting for links that share the new and old paths—Double-counting occurs when an intermediate router does not recognize that the new and old paths belong to the same LSP and counts them as two separate LSPs, requiring separate bandwidth allocations. <p>If some links are close to saturation, double-counting might cause the setup of the new path to fail. By default, adaptive behavior is disabled.</p> <p>You can include the adaptive statement in two different hierarchy levels. If you specify the adaptive statement at the LSP hierarchy levels, the adaptive behavior is enabled on all primary and secondary paths of the LSP. This means both the primary and secondary paths share the same bandwidth on common links.</p> <p>NOTE: This check box is not available for P2MP topology and also when the path selection type is explicit path.</p>

Table 241: Path Settings (*continued*)

Field	Description
Setup Priority	<p>Specify a priority value, which determines whether a new LSP that preempts an existing LSP can be established.</p> <p>For preemption to occur, the setup priority of the new LSP must specify a priority value, which determines whether a new LSP that preempts an existing LSP can be established.</p> <p>For preemption to occur, the setup priority of the new LSP must be higher than that of the existing LSP. Also, the act of preempting the existing LSP must produce sufficient bandwidth to support the new LSP. That is, preemption occurs only if the new LSP can be set up successfully.</p> <p>The setup priority also defines the relative importance of LSPs on the same ingress router. When the software starts, when a new LSP is established, or during fault recovery, the setup priority determines the order in which LSPs are serviced. Higher-priority LSPs tend to be established first and hence enjoy more optimal path selection.</p> <p>This field cannot be configured for local-protection type of LSPs.</p> <p>Range: Both setup-priority and reservation-priority can be a value from 0 through 7, where 0 is the highest priority and 7 is the lowest priority.</p> <p>Default: An LSP has a setup priority of 7 (that is, it cannot preempt any other LSPs) and a reservation priority of 0 (that is, other LSPs cannot preempt it).</p> <p>These defaults prevent preemption.</p> <p>NOTE: When you are configuring these values, make sure that the setup priority value is lower than or equal to the hold priority value.</p>
Hold Priority	<p>Specify a hold priority value.</p> <p>The hold priority determines the degree to which an LSP holds onto its session reservation of the LSP that has been set up successfully.</p> <p>When the hold priority is high, the existing LSP is less likely to give up its reservation and, therefore, it is unlikely that the LSP can be preempted.</p> <p>You must configure the hold priority to be greater than or equal to the setup priority. This field cannot be configured for local-protection type of LSPs.</p> <p>Range: 0 through 7, where 0 is the highest priority and 7 is the lowest priority.</p> <p>NOTE: If traffic engineering admission control determines that there are insufficient resources to accept a request to set up a new LSP, the setup priority is evaluated against the hold priority of existing LSPs.</p> <p>An LSP with a hold priority lower than the setup priority of the new LSP can be preempted. The existing LSP is terminated to make room (that is, resources are freed) for the new LSP.</p>

Table 241: Path Settings (*continued*)

Field	Description
Routing Method	<p>Use the drop-down menu to select a routing method. Available options include RouteByPCC, default, adminWieght, delay, constant, distance, ISIS, OSPF</p> <p>NOTE: This attribute is visible only if Enable NorthStar LSP Management is enabled in Preferences.</p> <p>Default: RouteByPCC</p>
Max Delay	<p>Type a value or use the up and down arrows to increment or decrement by 100.</p> <p>NOTE: This attribute is visible only if Enable NorthStar LSP Management is enabled in Preferences.</p> <p>Default: RouteByPCC</p>
Max Cost	<p>Type a value or use the up and down arrows to increment or decrement by 100.</p> <p>NOTE: This attribute is visible only if Enable NorthStar LSP Management is enabled in Preferences.</p> <p>Default: RouteByPCC</p>
Tunnel Metric	<p>Specify a value to configure the LSP path selection for RSVP tunnels.</p> <p>NOTE: This attribute is visible only if Enable NorthStar LSP Management is enabled in Preferences.</p> <p>Default: RouteByPCC</p>

2. Click **Next** to save the Path Settings page information.

Continue with specifying BFD Settings.

Specifying BFD Settings

To provide the BFD attributes for this service definition:

1. Fill in the fields on the BFD Settings page as indicated in [Table 242 on page 1772](#):

NOTE: You cannot configure BFD settings if **Enable NorthStar LSP management** check box is selected in the Preferences window.

Table 242: BFD Settings

Field	Description
BFD Detection	<p>Select the BFD setting type:</p> <ul style="list-style-type: none"> • This LSP—Configure BFD settings for all of the specific LSP. • Primary Path—Configure BFD settings for the primary path of the specific LSP. • Secondary Path—Configure BFD settings for the secondary path of the specific LSP. • None—Do not configure BFD settings. <p>By default, BFD is not configured.</p> <p>NOTE: The primary path and the secondary path are listed on BFD Detection menu only if you have configured the primary and secondary paths.</p> <p>You can modify the BFD Detection settings in a service.</p>
Minimum Interval	<p>Specify the minimum transmit and receive interval.</p> <p>This value represents the minimum interval at which the local routing device transmits hello packets as well as the minimum interval that the routing device expects to receive a reply from a neighbor with which it has established a BFD session.</p> <p>Range: 1 through 255,000 milliseconds</p> <p>Default: 300</p>
Minimum Receive Interval	<p>Specify the minimum receive interval.</p> <p>This value represents the minimum interval at which the peer must receive a reply from a peer with which it has established a BFD session.</p> <p>Range: 1 through 255,000 milliseconds</p> <p>Default: 50</p>
Multiplier	<p>Specify the detection time multiplier.</p> <p>This value represents the number of hello packets not received by the neighbor before BFD declares that the neighbor is down.</p> <p>Range: 1 through 255</p> <p>Default: 3</p>

Table 242: BFD Settings (*continued*)

Field	Description
No Adaption	<p>Select this check box to disable adaptation.</p> <p>You can configure an LSP to be adaptive when it is attempting to reroute itself. When it is adaptive, the LSP holds onto existing resources until the new path is successfully established and traffic has been switched over to the new LSP.</p> <p>To retain its resources, an adaptive LSP does the following:</p> <ul style="list-style-type: none"> • Maintains existing paths and allocated bandwidths—This ensures that the existing path is not torn down prematurely and allows the current traffic to continue flowing while the new path is being set up. • Avoids double-counting for links that share the new and old paths—Double-counting occurs when an intermediate router does not recognize that the new and old paths belong to the same LSP and counts them as two separate LSPs, requiring separate bandwidth allocations. <p>If some links are close to saturation, double-counting might cause the setup of the new path to fail.</p> <p>By default, adaptive behavior is disabled.</p>
Transmit Minimum Interval	<p>Specify the minimum transmit interval at which the local routing device transmits hello packets to a neighbor with which it has established a BFD session.</p> <p>The negotiated transmit interval for a peer is the interval between the sending of BFD packets to peers. The receive interval for a peer is the minimum time that it requires between packets sent from its peer; the receive interval is not negotiated between peers.</p> <p>To determine the transmit interval, each peer compares its configured minimum transmit interval with its peer's minimum receive interval. The larger of the two numbers is accepted as the transmit interval for that peer.</p> <p>Range: 1 through 255,000 milliseconds</p> <p>Default: 50 milliseconds</p>
Transmit Threshold	<p>Specify the high transmit interval triggering a trap.</p> <p>The threshold is used for detecting the adaptation of the transmit interval.</p> <p>When the BFD session transmit interval adapts to a value greater than the threshold, a single trap and a single system message are sent.</p> <p>Range: 51 through 4,294,967,295</p> <p>Default: None</p>

Table 242: BFD Settings (*continued*)

Field	Description
Detection Threshold	<p>Specify the maximum time at which to trigger a trap.</p> <p>Specify the threshold for the adaptation of the BFD session detection time.</p> <p>When the detection time adapts to a value equal to or greater than the threshold, a single trap and a single system log message are sent.</p> <p>Range: 0 through 4,294,967,295</p> <p>Default: None</p>
Failure Action – Teardown Failure Action – Make Before Break	<p>Select an action to take when a BFD session for an RSVP LSP goes down:</p> <ul style="list-style-type: none"> • Teardown—Causes the LSP path to be taken down and re-signaled immediately. • Make Before Break—Attempts to signal a new LSP path before tearing down the old LSP path. When the BFD session for an RSVP LSP goes down, the LSP is torn down and resignaled. <p>Traffic can be switched to a standby LSP, or you can simply tear down the LSP path. Any actions performed are logged.</p> <p>When a BFD session for an RSVP LSP path goes down, you can configure the Junos OS to resignal the LSP path or to simply disable the LSP path.</p> <p>A standby LSP path could be configured to handle traffic while the primary LSP path is unavailable. The router can automatically recover from LSP failures that can be detected by BFD.</p> <p>By default, if a BFD session fails, the event is simply logged.</p>

2. Click **Next** to review the configured settings.

The Review page of the wizard is displayed.

Reviewing the Configured Settings

The Review page of the service definition creation and modification wizards enable you to view and evaluate the service parameters and components you configured in the preceding steps or on the preceding pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured using the different pages of the wizard.

You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

To examine the configured settings, and modify them as needed:

1. Click **Review** to view the defined parameters.

You can examine and modify the created service definition parameters.

Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages that pertain to the settings you want to modify.

2. Click **Edit** beside any of the sections to modify the parameters corresponding to that section.

You are taken to the page pertaining to the parameter in the wizard.

3. Click **Finish** to save the service definition.

4. Click **Back** to return to the previous page of the wizard; otherwise, click **Cancel** to discard the changes.

The service definition inventory window appears.

RELATED DOCUMENTATION

| [Creating an LSP Service Order | 1775](#)

Creating an LSP Service Order

The service designer is responsible for creating and managing service definitions and the service provisioner uses these definitions as the basis for creating a service order. You can create a service definition that specifies attributes that are common to a group of service orders with similar service requirements, and a service order, which is an implementation object or a derivative of a service definition. For label-switched path (LSP) services, a service order can be directly created.

You can create LSP service orders that you can use as a starting point for provisioning LSP services. For LSP service orders, unlike the framework that is available for network services, such as E-Line, E-LAN, and IP protocols, in which a service definition is created independently as a separate item and a service order can be created, based on a service definition, a service order can also be created, independent of a service definition. You can, however, select a customized predefined service definition during the creation of an LSP service order. When you select such a predefined service definition, the parameters that are contained in it are populated in the corresponding fields of the service order creation wizard.

A wizard is available to create and modify a service order. The settings that you configure in the service order are organized in separate pages of the wizard, which you can launch by clicking the appropriate buttons at the top of the Create or Edit a Service Order page. Alternatively, you can proceed to the

corresponding setting-related pages by clicking the Back and Next buttons in the wizard at any point during the creation of the service order.

To create an LSP service order, you must first discover devices that have been configured for the LSP.

1. [Configuring LSP Service Order General Settings | 1776](#)
2. [Configuring LSP Service Order Advanced Settings | 1779](#)
3. [Creating a Name Pattern for LSPs in the Service Order | 1794](#)
4. [Configuring Node Parameters for LSPs in the Service Order | 1795](#)
5. [Configuring MPLS Path Settings | 1797](#)
6. [Configuring LSP Primary Path Settings | 1802](#)
7. [Configuring LSP Secondary Path Settings | 1803](#)
8. [Reviewing the Configured Settings | 1804](#)

Configuring LSP Service Order General Settings

As the service activator, you can configure an LSP based on a predefined LSP service definition. Alternatively, you can create an LSP service order without basing it on a service definition, and use the service order as a starting point for provisioning LSP services. The service activator can configure LSP settings that the service designer specified to be editable.

To create an LSP service order, configure the general settings.

NOTE: The availability of attributes in the service order creation workflow varies based on the service definition you select.

1. Select **Service View** from the View selector.

The workspaces that are applicable to routing and tunneling services are displayed.

2. From the Connectivity Services Director user interface, click the **Deploy** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed in the Tasks pane of the GUI window.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

The different network service types that you can configure, such as E-Line, E-LAN, and IP, are displayed.

- 4. From the Service View pane, click the plus sign (+) sign next to Tunnels, and select LSPs.
The LSPs node is expanded and displayed in the View pane.
- 5. From the task pane, select **Service Provisioning > Manage LSP**.
The Manage Network Services page is displayed in on the top right main display area, and the Manage Service Deployment window is displayed on the bottom of the main display area.
- 6. Click the down arrow on the **New** menu and select **LSPs** from the drop-down menu.
The wizard to create an LSP is displayed.
On the General Settings page of the wizard, the Service Details pane is displayed on the left. which contains the Basic and Advanced tabs.
- 7. Click the **Basic** tab.
The general settings are displayed.
- 8. Configure the settings on the Basic tab as indicated in [Table 243 on page 1777](#).

Table 243: Basic Settings

Item	Action
Order Name	Type a name that identifies the LSP service order. A service order name cannot exceed 50 characters and can contain only letters, numbers, and some special characters. The special characters allowed are hyphen (-), underscore (_), and period (.)

Table 243: Basic Settings (*continued*)

Item	Action
LSP Configuration	<p>Perform either of the following actions to specify the method to be used for creating an LSP order:</p> <ul style="list-style-type: none"> • Select the Create option to create a service order as an entirely new one. • Select the Import option to select an available LSP service definition that you created and published, and select a predefined service definition from the drop-down list. The LSP service definition on the LSP Definition drop-down menu is available for selection only if you published the service definition. <p>The following are the predefined LSP service definitions:</p> <ul style="list-style-type: none"> • RSVP LSP with BFD - Path Protection—Creates an RSVP LSP service order that protects the LSP primary path by establishing a secondary path with BFD as the signaling protocol • RSVP LSP with BFD - P2MP Topology—Creates an RSVP LSP service order with BFD as the signaling protocol and a point-to-multipoint topology • RSVP LSP with Path Protection—Creates an RSVP LSP service order that protects the primary path by establishing a secondary path • RSVP LSP with Node Link Protection—Creates an RSVP LSP service order that bypasses a node or link for redundancy. • FullMesh LSP with Node Link Protection—Creates an RSVP LSP service order in a full-mesh topology that bypasses a node or link for redundancy. <p>The parameters on the different pages of the wizard are filled out with the values of parameters retrieved from the service definition you selected. You can modify them as needed.</p>
LSP Type	RSVP or Segment Routing is displayed as the type of LSP based on the value you choose in the NorthStar tab of the Preferences window.
Topology	<p>Select the LSP transport topology from the list:</p> <ul style="list-style-type: none"> • P2P—Provides a point-to-point connectivity between the selected endpoints • P2MP—Provides a point-to-multipoint connectivity between the selected endpoints • Full Mesh—Provides any-to-any unidirectional MPLS connectivity among all the selected provider edge router
Path Selection Type	<p>From this list, select either CSPF or Explicit Path. In Constrained Shortest Path First (CSPF) LSPs, the intermediate hops of the LSP are automatically computed by the software.</p> <p>If you select CSPF, Junos OS calculates the best path for you. In explicit-path LSPs, all intermediate hops of the LSP are manually configured. The intermediate hops can be strict, loose, or any combination of the two.</p>

Table 243: Basic Settings (*continued*)

Item	Action
LSP Protection Type	<p>Select the type of protection you want to configure.</p> <p>Path Protection Only—Protects the LSP primary path by establishing a secondary path.</p> <p>Fast reroute can be applied to the LSP if you are selecting Path Protection Only. On the Advanced page, specify the protection type as Path Protection Only and select the Enable Fast Reroute check box in the Common Settings section on the Advanced tab.</p> <p>Local Protection Only—Provides local repair procedures that ensure faster restoration by establishing local protection as close to a failure as possible.</p> <p>Configuring only local protection for the ingress router of the primary LSP causes RSVP-traffic engineering to indicate to LSP setup that the primary LSP needs local protection. When there is only one path for the LSP, you can specify either link protection or node-link protection.</p> <p>Path and Local Protection—Provides redundancy using a combination of path protection and local protection options.</p> <p>The primary path is protected and local repair procedures for faster redundancy is achieved using this methodology.</p>
Local Protection Type	<p>Specify the type of protection:</p> <p>Link Protection—Provides backup support for a single link.</p> <p>Node-Link Protection—Can bypass a node or a link to provide redundancy.</p> <p>NOTE: This drop-down is unavailable if the LSP Protection Type is Path Protection Only.</p>

9. Click the **Advanced** tab.

The advanced settings that you can configure for the LSP service order are displayed.

Configuring LSP Service Order Advanced Settings

IN THIS SECTION

- [Configuring Common Settings | 1780](#)
- [Configuring LSP Path Settings in the Service Order | 1784](#)
- [Configuring BFD Settings for LSPs in the Service Order | 1790](#)

On the left of the General Settings page of the wizard, the Service Details pane contains the Basic and Advanced tabs.

To configure the settings that are globally applicable throughout the LSP in the LSP service order:

1. Click the **Advanced** tab on the General Settings page of the wizard to create an LSP.

The global or system-wide settings are displayed.

You can edit these parameters if you selected 'Editable in Service Order' check box in the service definition.

2. You can specify the following types of settings from the Advanced tab of the LSP service order creation wizard if you choose to create a service order without creating a service definition.
 - a. Common Settings—Configure the LSP retry limit, retry timer (seconds), LDP tunneling settings, auto-bandwidth settings, protections settings, and BFD settings. See [“Configuring Common Settings” on page 1780](#) for details
 - b. Path Settings—Configure the primary and secondary paths on one point-to-point or several point-to-multiple-point branches. Specify the primary path to use for an LSP. You can configure only one primary path. You can optionally specify the preference, CoS, and bandwidth values for the primary path, which override any equivalent values that you configure for the LSP. See [“Configuring MPLS Path Settings” on page 1797](#) for details.
 - c. BFD Settings—Configure a Bidirectional Forwarding Detection (BFD) protocol on MPLS IPv4 LSPs. BFD is used as a periodic Operation, Administration, and Maintenance (OAM) feature for LSPs to detect LSP data plane faults. You can configure a BFD protocol for LSPs that use RSVP as the signaling protocol. See [“Configuring BFD Settings for LSPs in the Service Order” on page 1790](#) for details.

The following sections describe the advanced settings you can configure for the LSP service order:

Configuring Common Settings

You can use the **Common Settings** page to view or configure the LSP retry limit, retry timer (seconds), LDP tunneling settings, auto-bandwidth settings, protections settings, and BFD settings.

Each LSP has a bandwidth value. This value is included in the sender's Tspec field in RSVP path setup messages. You can specify a bandwidth value in bits per second. If you configure more bandwidth for an LSP, it should be able to carry a greater volume of traffic.

The default bandwidth is 0 bits per second.

The ingress router might make many attempts to connect and reconnect to the egress router using the primary path. You can control how often the ingress router tries to establish a connection using the primary path and how long it waits between retry attempts. The retry timer configures how long the ingress router waits before trying to connect again to the egress router using the primary path. The default retry time is

30 seconds. The time can be from 1 through 600 seconds. To modify this value, include the retry timer parameter in the service order.

Automatic bandwidth allocation allows an MPLS tunnel to automatically adjust its bandwidth allocation based on the volume of traffic flowing through the tunnel. You can configure an LSP with minimal bandwidth; this feature can dynamically adjust the LSP's bandwidth allocation based on current traffic patterns. The bandwidth adjustments do not interrupt traffic flow through the tunnel. You set a sampling interval on an LSP configured with automatic bandwidth allocation. The average bandwidth is monitored during this interval. At the end of the interval, an attempt is made to signal a new path for the LSP with the bandwidth allocation set to the maximum average value for the preceding sampling interval. If the new path is successfully established and the original path is removed, the LSP is switched over to the new path. If a new path is not created, the LSP continues to use its current path until the end of the next sampling interval, when another attempt is made to establish a new path. Note that you can set minimum and maximum bandwidth values for the LSP. During the automatic bandwidth allocation interval, the router might receive a steady increase in traffic (increasing bandwidth utilization) on an LSP, potentially causing congestion or packet loss. To prevent this, you can define a second trigger to prematurely expire the automatic bandwidth adjustment timer before the end of the current adjustment interval.

To configure common settings that are applicable to all LSPs in the service order:

1. On the Advanced pane of the General Settings page, click the plus sign beside the **Common Settings** section.

The parameters that are applicable to all the LSPs are available for configuration.

2. Fill in the parameters as indicated in [Table 244 on page 1781](#).

Table 244: Common Settings

Item	Action
Retry limit	<p>Specify the number of times an ingress router can attempt to establish or reestablish a connection to the egress router by using the primary path.</p> <p>This counter is reset each time a primary path is created successfully.</p> <p>When the limit is exceeded, no more connection attempts are made. Intervention is then required to restart the connection.</p> <p>Range: 0 through 10,000</p> <p>Default: No limit is set.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>

Table 244: Common Settings (*continued*)

Item	Action
Retry timer	<p>Specify how long the ingress router waits before trying to connect again to the egress router by using the primary path.</p> <p>Range: 1 through 600 seconds</p> <p>Default: 30 seconds</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>
Bandwidth (Kbps)	<p>Specify the bandwidth in Kbps.</p> <p>A nonzero bandwidth requires that transit and egress routers reserve capacity along the outbound links for the path.</p> <p>The RSVP scheme is used to reserve this capacity.</p> <p>Any failure in bandwidth reservation (such as failures at RSVP policy control or admission control) might cause the LSP setup to fail. If there is insufficient bandwidth on the interfaces for the transit or egress routers, the LSP is not established.</p> <p>Range: Any positive integer</p> <p>Default: 0 (No bandwidth is reserved.)</p>

Table 244: Common Settings (*continued*)

Item	Action
Enable LDP tunneling	<p>Select this check box to enable LSP for LDP tunneling. That is, if you are using RSVP for traffic engineering, you can run LDP simultaneously to eliminate the distribution of external routes in the core network. The LSPs established by LDP are tunneled through the LSPs established by RSVP. LDP effectively treats the traffic-engineered LSPs as single hops.</p> <p>When you configure the router to run LDP across RSVP-established LSPs, LDP automatically establishes sessions with the router at the other end of the LSP. LDP control packets are routed hop by hop, rather than carried through the LSP. This routing allows you to use simplex (one-way) traffic-engineered LSPs. Traffic in the opposite direction flows through LDP-established LSPs that follow unicast routing rather than through traffic-engineered tunnels.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>
Enable fast reroute	<p>Select this check box to enable fast reroute.</p> <p>If you enable the fast reroute, the ingress router signals all the downstream routers that fast reroute is enabled on the LSP, and each downstream router does its best to set up detours for the LSP. If a downstream router does not support fast reroute, it ignores the request to set up detours and continues to support the LSP.</p> <p>A router that does not support fast reroute will cause some of the detours to fail, but otherwise has no impact on the LSP.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>

Table 244: Common Settings (*continued*)

Item	Action
Auto Bandwidth	<p>Select this check box to allow an MPLS tunnel to automatically adjust its bandwidth allocation based on the volume of traffic flowing through the tunnel.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p> <ol style="list-style-type: none"> 1. In the Adjust Interval field, specify the bandwidth reallocation interval. Range: 300 through 4,294,967,295 seconds. Default: 86,400 seconds. 2. In the Maximum Bandwidth (Kbps) field, specify the maximum bandwidth in Kbps or an LSP with automatic bandwidth allocation enabled. You can maintain the LSP's bandwidth between minimum and maximum bounds by specifying values. Default: 10000 Kbps. Range: 1 through 2147483 Kbps. 3. In the Minimum Bandwidth (Kbps) field, specify the minimum bandwidth in Kbps or an LSP with automatic bandwidth allocation enabled. Default: 1000 Kbps. Range: 1 through 2147483 Kbps. You must enter the minimum bandwidth to be lower than the maximum bandwidth.

3. Click the plus sign beside the **Path Settings** section to configure the path specifications for the LSP.

The Path Settings section is expanded and displayed.

Configuring LSP Path Settings in the Service Order

When IP traffic enters an LSP tunnel, the ingress router marks all packets with a CoS value, which is used to place the traffic into a transmission priority queue. On the router, for SDH/SONET and T3 interfaces, each interface has four transmit queues. The CoS value is encoded as part of the MPLS header and remains in the packets until the MPLS header is removed when the packets exit from the egress router. The routers within the LSP use the CoS value set at the ingress router. The CoS value is encoded by means of the CoS

bits (also known as the EXP or experimental bits). MPLS class of service works in conjunction with the router's general CoS functionality. If you do not configure any CoS features, the default general CoS settings are used. For MPLS class of service, you might want to prioritize how the transmit queues are serviced by configuring weighted round-robin, and to configure congestion avoidance using random early detection (RED).

When there is insufficient bandwidth to establish a more important LSP, you might want to tear down a less important existing LSP to free the bandwidth. You do this by preempting the existing LSP. Whether an LSP can be preempted is determined by two properties associated with the LSP:

- **Setup priority**—Determines whether a new LSP that preempts an existing LSP can be established. For preemption to occur, the setup priority of the new LSP must be higher than that of the existing LSP. Also, the act of preempting the existing LSP must produce sufficient bandwidth to support the new LSP. That is, preemption occurs only if the new LSP can be set up successfully.
- **Reservation priority**—Determines the degree to which an LSP holds on to its session reservation after the LSP has been set up successfully. When the reservation priority is high, the existing LSP is less likely to give up its reservation, and hence it is unlikely that the LSP can be preempted.

You cannot configure an LSP with a high setup priority and a low reservation priority, because permanent preemption loops might result if two LSPs are allowed to preempt each other. You must configure the reservation priority to be higher than or equal to the setup priority. The setup priority also defines the relative importance of LSPs on the same ingress router. When the software starts, when a new LSP is established, or during fault recovery, the setup priority determines the order in which LSPs are serviced. Higher-priority LSPs tend to be established first and hence enjoy more optimal path selection.

To configure LSP path settings in the service order:

1. On the Advanced pane of the General Settings page, click the plus sign beside the **Path Settings** section.
The LSP path parameters that are applicable to all the LSPs are available for configuration.
2. Fill in the parameters as indicated in [Table 245 on page 1785](#).

Table 245: Path Settings

Item	Action
Hop limit	<p>Specify the hop limit of the LSP.</p> <p>Range: 2 through 255.</p> <p>A path with two hops consists of the ingress and egress routers only.</p> <p>Default: Each LSP can traverse a maximum of 255 hops, including the ingress and egress routers.</p>

Table 245: Path Settings (*continued*)

Item	Action
Class of service	<p>Specify a decimal number.</p> <p>This number corresponds to a 3-bit binary number. The high-order two bits of the CoS value select which transmit queue to use on the outbound interface card. The low-order bit of the CoS value is treated as the packet loss priority (PLP) bit and is used to select the random early detection (RED) drop profile to use on the output queue. If the low-order bit is 0, the non-PLP drop profile is used, and if the low-order bit is 1, the PLP drop profile is used.</p> <p>Typically, RED aggressively drops packets that have the PLP bit set. For more information about RED and drop profiles, see the <i>Junos OS Class of Service Configuration Guide</i>.</p> <p>Range: A decimal number from 0 through 7</p> <p>This field is not applicable for local-protection type of LSPs.</p>
Bandwidth (Kbps)	<p>Specify a bandwidth in Kbps for an LSP. Each LSP has a bandwidth value.</p> <p>This value is included in the sender's Tspec field in RSVP path setup messages. The ingress router uses the traffic specification (Tspec) object to specify the parameters for the traffic it is going to send. You can specify a bandwidth value in bits per second. If you configure more bandwidth for an LSP, it should be able to carry a greater volume of traffic.</p> <p>The default bandwidth is 0 bits per second.</p>
Standby (enable switchover)	<p>Select this check box to have the path remain up at all times to provide immediate switchover if connectivity problems occur.</p> <p>This field is displayed only for secondary paths.</p>

Table 245: Path Settings (*continued*)

Item	Action
Adaptive	<p>Select this check box if you want to configure an LSP to be adaptive when it is attempting to reroute itself.</p> <p>When it is adaptive, the LSP holds onto existing resources until the new path is successfully established and traffic has been switched over to the new LSP.</p> <p>To retain its resources, an adaptive LSP does the following:</p> <ul style="list-style-type: none"> • Maintains existing paths and allocated bandwidths—This ensures that the existing path is not torn down prematurely and allows the current traffic to continue flowing while the new path is being set up. • Avoids double-counting for links that share the new and old paths—Double-counting occurs when an intermediate router does not recognize that the new and old paths belong to the same LSP and counts them as two separate LSPs, requiring separate bandwidth allocations. If some links are close to saturation, double-counting might cause the setup of the new path to fail. <p>By default, adaptive behavior is disabled.</p> <p>You can include the adaptive statement in two different hierarchy levels. If you specify the adaptive statement at the LSP hierarchy levels, the adaptive behavior is enabled on all primary and secondary paths of the LSP. This means both the primary and secondary paths share the same bandwidth on common links.</p> <p>This check box is not available for P2MP topology and also when the path selection type is explicit path.</p>
Priority	<p>Configure the LSP's preemption properties by selecting a value from the Setup Priority and Hold riority lists.</p>

Table 245: Path Settings (continued)

Item	Action
Setup Priority	<p>Specify a priority value, which determines whether a new LSP that preempts an existing LSP can be established.</p> <p>For preemption to occur, the setup priority of the new LSP must be higher than that of the existing LSP. Also, the act of preempting the existing LSP must produce sufficient bandwidth to support the new LSP. That is, preemption occurs only if the new LSP can be set up successfully.</p> <p>The setup priority also defines the relative importance of LSPs on the same ingress router. When the software starts, when a new LSP is established, or during fault recovery, the setup priority determines the order in which LSPs are serviced.</p> <p>Higher-priority LSPs tend to be established first and hence enjoy more optimal path selection.</p> <p>This field cannot be configured for local-protection type of LSPs.</p> <p>Range: Both setup-priority and reservation-priority can be a value from 0 through 7, where 0 is the highest priority and 7 is the lowest priority.</p> <p>Default: An LSP has a setup priority of 7 (that is, it cannot preempt any other LSPs) and a reservation priority of 0 (that is, other LSPs cannot preempt it).</p> <p>These defaults prevent preemption. When you are configuring these values, make sure that the setup priority value is lower than or equal to the hold priority value.</p>

Table 245: Path Settings (continued)

Item	Action
Hold Priority	<p>Specify a hold priority value.</p> <p>The hold priority determines the degree to which an LSP holds onto its session reservation of the LSP that has been set up successfully.</p> <p>When the hold priority is high, the existing LSP is less likely to give up its reservation and, therefore, it is unlikely that the LSP can be preempted. You must configure the hold priority to be greater than or equal to the setup priority.</p> <p>This field cannot be configured for local-protection type of LSPs.</p> <p>Range: 0 through 7, where 0 is the highest priority and 7 is the lowest priority.</p> <p>NOTE: If traffic engineering admission control determines that there are insufficient resources to accept a request to set up a new LSP, the setup priority is evaluated against the hold priority of existing LSPs.</p> <p>An LSP with a hold priority lower than the setup priority of the new LSP can be preempted. The existing LSP is terminated to make room (that is, resources are freed) for the new LSP.</p>
Tunnel Metric	<p>Specify a value to configure LSP path selection for RSVP tunnels.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>
Routing Method	<p>Use the drop-down menu to select a routing method.</p> <p>Available options include RouteByPCC, default, adminWiegth, delay, constant, distance, ISIS, OSPF Note:</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p> <p>Default: RouteByPCC</p>

Table 245: Path Settings (*continued*)

Item	Action
Max Delay	<p>Type a value or use the up and down arrows to increment or decrement by 100.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>
Max Cost	<p>Type a value or use the up and down arrows to increment or decrement by 100.</p> <p>This attribute is visible only if Enable NorthStar LSP Management is disabled in Preferences.</p>

- Click the plus sign beside the **BFD Settings** section to configure the BFD parameters for the LSP.

The BFD Settings section is expanded and displayed.

Configuring BFD Settings for LSPs in the Service Order

BFD for RSVP supports unicast IPv4 LSPs. When BFD is configured for an LSP on the ingress router, it is enabled on the primary path and on all standby secondary paths for that LSP. The source IP address for outgoing BFD packets from the egress side of an MPLS BFD session is based on the outgoing interface IP address. You can enable BFD for all LSPs on a router or for specific LSPs. If you configure BFD for a specific LSP, whatever values configured globally for BFD are overridden. The BFD sessions originate only at the ingress router and terminate at the egress router.

The BFD failure detection timers are adaptive and can be adjusted to be more or less aggressive. For example, the timers can adapt to a higher value if the adjacency fails, or a neighbor can negotiate a higher value for a timer than the configured value. The timers adapt to a higher value when a BFD session flap occurs more than three times in a span of 15 seconds. A back-off algorithm increases the receive (Rx) interval by two if the local BFD instance is the reason for the session flap. The transmission (Tx) interval is increased by two if the remote BFD instance is the reason for the session flap.

NOTE: Note: BFD Settings tab is unavailable if **Enable NorthStar LSP Management** is enabled in Preferences.

To configure BFD settings for LSPs in the service order:

- On the Advanced pane of the General Settings page, click the plus sign beside the **BFD Settings** section.
- Fill in the parameters as indicated in [Table 246 on page 1791](#).

Table 246: BFD Settings

Field	Action
BFD Detection	<p>Select the BFD setting type:</p> <ul style="list-style-type: none"> • This LSP—Configure BFD settings for all of the specific LSP. • Primary Path—Configure BFD settings for the primary path of the specific LSP. • Secondary Path—Configure BFD settings for the secondary path of the specific LSP. • None—Do not configure BFD settings. By default, BFD is not configured. <p>NOTE: The primary path and the secondary path are listed on BFD Detection menu only if you have configured the primary and secondary paths.</p> <p>You can modify the BFD Detection settings in a service.</p>
Minimum Interval	<p>Specify the minimum transmit and receive interval.</p> <p>This value represents the minimum interval at which the local routing device transmits hello packets as well as the minimum interval that the routing device expects to receive a reply from a neighbor with which it has established a BFD session.</p> <p>Range: 1 through 255000 milliseconds</p> <p>Default: 50</p>
Minimum Receive Interval	<p>Specify the minimum receive interval.</p> <p>This value represents the minimum interval at which the peer must receive a reply from a peer with which it has established a BFD session.</p> <p>Range: 1 through 255000 milliseconds</p> <p>Default: 50</p>
Multiplier	<p>Specify the detection time multiplier.</p> <p>This value represents the number of hello packets not received by the neighbor before BFD declares that the neighbor is down.</p> <p>Range: 1 through 255</p> <p>Default: 3</p>

Table 246: BFD Settings (*continued*)

Field	Action
No adaptation	<p>Select this check box to disable adaptation.</p> <p>You can configure an LSP to be adaptive when it is attempting to reroute itself. When it is adaptive, the LSP holds onto existing resources until the new path is successfully established and traffic has been switched over to the new LSP.</p> <p>To retain its resources, an adaptive LSP does the following:</p> <ul style="list-style-type: none"> • Maintains existing paths and allocated bandwidths—This ensures that the existing path is not torn down prematurely and allows the current traffic to continue flowing while the new path is being set up. • Avoids double-counting for links that share the new and old paths—Double-counting occurs when an intermediate router does not recognize that the new and old paths belong to the same LSP and counts them as two separate LSPs, requiring separate bandwidth allocations. If some links are close to saturation, double-counting might cause the setup of the new path to fail. <p>By default, adaptive behavior is disabled.</p>
Transmit Minimum Interval	<p>Specify the minimum transmit interval at which the local routing device transmits hello packets to a neighbor with which it has established a BFD session.</p> <p>The negotiated transmit interval for a peer is the interval between the sending of BFD packets to peers. The receive interval for a peer is the minimum time that it requires between packets sent from its peer; the receive interval is not negotiated between peers.</p> <p>To determine the transmit interval, each peer compares its configured minimum transmit interval with its peer's minimum receive interval.</p> <p>The larger of the two numbers is accepted as the transmit interval for that peer.</p> <p>Range: 1 through 255000 milliseconds</p> <p>Default: 50 milliseconds</p>
Transmit Threshold	<p>Specify the high transmit interval triggering a trap.</p> <p>The threshold is used for detecting the adaptation of the transmit interval.</p> <p>When the BFD session transmit interval adapts to a value greater than the threshold, a single trap and a single system message are sent.</p> <p>Range: 51 through 4,294,967,295</p> <p>Default: None</p>

Table 246: BFD Settings (*continued*)

Field	Action
Detection Threshold	<p>Specify the maximum time at which to trigger a trap.</p> <p>Specify the threshold for the adaptation of the BFD session detection time. When the detection time adapts to a value equal to or greater than the threshold, a single trap and a single system log message are sent.</p> <p>Range: 0 through 4,294,967,295</p> <p>Default: None</p>
Failure Action	<p>Select an action to take when a BFD session for an LSP goes down:</p> <ul style="list-style-type: none"> • Teardown—Causes the LSP path to be taken down and resigaled immediately. • Make Before Break—Attempts to signal a new LSP path before tearing down the old LSP path. <p>When the BFD session for an LSP goes down, the LSP is torn down and resigaled. Traffic can be switched to a standby LSP, or you can simply tear down the LSP path. Any actions performed are logged.</p> <p>When a BFD session for an LSP path goes down, you can configure the Junos OS to resignal the LSP path or to simply disable the LSP path. A standby LSP path could be configured to handle traffic while the primary LSP path is unavailable. The router can automatically recover from LSP failures that can be detected by BFD.</p> <p>By default, if a BFD session fails, the event is simply logged.</p>
Teardown Timeout	<p>Specify a time to wait before the LSP path is taken down and resigaled.</p> <p>If you specify a value of 0 for the teardown-timeout interval, the LSP is taken down and resigaled immediately.</p> <p>Range: 0 through 30 seconds</p> <p>Default: None</p>

3. Specify the LSP pattern settings. See [“Creating a Name Pattern for LSPs in the Service Order”](#) on [page 1794](#) for details.

Creating a Name Pattern for LSPs in the Service Order

Instead of using an existing predefined pattern of label-switched path (LSP) names, you can also create an LSP name of your preference or convention. The customized LSP name includes a set of common variables and supported special characters. The Transport Activate software appends a unique number to these customized name to avoid conflicts.

To specify a name pattern for LSPs in the service order:

1. On the General Settings page, with either the Advanced or Basic tab selected, click the plus sign (+) next to LSP Pattern Details at the bottom of the page to expand the section.

2. Click **Select** adjacent to the Name field to select a pattern from the list of available patterns.

The Select LSP Name pattern dialog box appears. The dialog box displays a table, which includes the following patterns:

- **Default LSP pattern**—Uses the default LSP name pattern for a point-to-point and point-to-multipoint topology
- **Full-mesh default pattern**—Uses the default LSP name pattern for a full-mesh topology
- **User-defined RSVP patterns**—Creates an LSP name of your preference or convention

3. Select the check box next to the pattern to be used in the LSP service order.

4. Click **OK** to save the selection.

You are returned to the LSP Pattern Details section of the General Settings page of the wizard.

5. In the Pattern field, view the name of the selected pattern. For example, the pattern of Default LSP Pattern is Service Order Name_to_Egress Loopback Address.

Alternatively, to create a new name pattern, click the **Create** button adjacent to the Name field.

The Create LSP Name Pattern dialog box appears.

6. From the Name list, select one of the following:

- **RSVP**—Name pattern for RSVP LSPs.
- **General**—Name pattern for general LSPs.
- **Static**—Name pattern for static LSPs.

The specified name pattern for the type of LSP you want to configure is selected.

7. Specify the name of the pattern in the **Name** box.

8. In the LSP Pattern Details section, select the **Select Variable** option button to select an existing variable from the Variable drop-down list. The predefined variables are listed in the Variable drop-down list.

Alternatively, select the **Add Text** option button to add a new variable.

The Variable field is available for specifying the variable.

9. Click **Add** to add the variable to the pattern.

The variable you add is displayed in pattern name of the Pattern field.

NOTE: You can select any of the predefined variables from the Variable drop-down list. The variables in the Variable drop-down list are based on the **Pattern Type** you select.

Alternatively, click **Clear** to remove the variable from the Variables drop-down list.

The variable is deleted from the pattern name in the Pattern field.

10. Select the **Append unique number** check box to append a unique number to these customized names you create to avoid conflicts.

11. Click **Create** to add the name pattern to the LSP service.

You are returned to the General Settings page of the wizard and the pattern name appears in the Patterns field.

The pattern is also added to the Select LSP Name Patterns inventory page, which you can open by clicking **Select** beside the Name field in the LSP Pattern Details section. You can select this pattern name in the service order from the Select LSP Name Patterns inventory page.

NOTE: You can view the details of a pattern on the Select LSP Name Patterns inventory page. You cannot modify an existing pattern.

12. On the General Settings page of the wizard, click **Next** to proceed to the next step of the wizard, which is to define the node or endpoint settings.

The Node Settings page of the wizard is displayed.

Configuring Node Parameters for LSPs in the Service Order

On the **Node Parameters** page, you can configure the endpoints or nodes for the LSP service order.

Only fields that correspond to the type of topology that you selected on the General Settings page of the wizard are displayed on the Node Parameters page.

1. Fill in the parameters as described in [Table 247 on page 1796](#):

Table 247: Node Parameters

Item	Action
Ingress Router	<ol style="list-style-type: none"> 1. Click Select beside the field to open the Select device dialog box. 2. Select the check box next to an available router that must function as the ingress router. The local router is always considered to be the ingress router, which is the beginning of the LSP. The software automatically determines the correct outgoing interface and IP address to use to reach the next router in an LSP. By default, the router ID is chosen as the address of the ingress router. MPLS-signaled label-switched paths (LSPs) run from a specific ingress router to a specific egress router. For basic MPLS-signaled LSP function, you must configure the ingress router, but do not have to configure any other routers. This field is unavailable if the selected LSP service definition is a full-mesh RSVP definition.
Egress Router	<ol style="list-style-type: none"> 1. Click Select beside the field to open the Select Device dialog box. The Select button is available only for P2P topology. 2. Select an available router that must function as the egress router in the LSP connection established using the primary path from the ingress router. For a point-to-point topology, select one egress router. 3. If the topology is a point-to-multipoint LSP topology, click Add in the Egress Routers table to open the Select Device dialog box. NOTE: The Egress Routers table is available only for P2MP topology. Select multiple routers to function as egress routers for the point-to-multiple-point topology. To delete an egress router added to the LSP service, select the device, and click Delete above the table of listed egress routers.

Table 247: Node Parameters (continued)

Item	Action
Select Devices	<p>This field is available only for full-mesh LSP topology.</p> <ol style="list-style-type: none"> 1. If the topology is a full-mesh LSP topology, click Add in the Egress Routers table to open the Select Device dialog box. The Egress Routers table is available only for P2MP topology. Select multiple routers to function as egress routers for the point-to-multiple-point topology. 2. To delete an egress router added to the LSP service, select the device, and click Delete above the table of listed egress routers.

2. Click **Next** to proceed to the next page of the wizard, which is to configure path settings.

The Path Settings page of the wizard is displayed.

Configuring MPLS Path Settings

The **Path Settings** page of the service order creation wizard enables you to view existing paths or add, edit, or delete new paths.

NOTE: The Path Settings tab is disabled if **Enable NorthStar LSP Management** is selected in the Preferences tab.

1. Fill in the parameters as indicated in [Table 248 on page 1797](#) under the Primary and Secondary tabs of the Path Parameters page.

Table 248: MPLS Path Settings

Item	Action
Path Name	Define the path to be either automatic path selection or a new path name. If you do not configure both primary and secondary paths for an LSP, MPLS uses an automatic path selection algorithm.
Automatic	(Optional) Select this option from the Path Name list for an automatic path to be used for the LSP.

Table 248: MPLS Path Settings (continued)

Item	Action
Create New	<p>(Optional) Click this button create a new path.</p> <p>The Create MPLS Path dialog box is displayed.</p> <p>To add one or more new paths:</p> <ol style="list-style-type: none">1. Type a name in the Path Name text box.2. Select whether you want the LSP path to be Loose or Strict. To configure complete path information, specify every router hop between the ingress and egress routers, preferably by selecting the Strict attribute. To configure incomplete path information, specify only a subset of router hops. Select the Loose attribute in places where the path is incomplete. For incomplete paths, the MPLS routers complete the path by querying the local routing table. This query is performed on a hop-by-hop basis, and each router can obtain only enough information to reach the next explicit hop. It might be necessary to traverse a number of routers to reach the next (loose) explicit hop.3. Type an IP address in the IP address text box.4. Click Add to add the path to the table that displays all the configured paths. Alternatively, select a path from the table and click Delete to remove the path for the LSP.
Hop limit	<p>Specify the hop limit of the LSP.</p> <p>Range: 2 through 255.</p> <p>A path with two hops consists of the ingress and egress routers only.</p> <p>Default: Each LSP can traverse a maximum of 255 hops, including the ingress and egress routers.</p>

Table 248: MPLS Path Settings (*continued*)

Item	Action
Class of service	<p>Select one of the following values to specify the class of service (CoS) type for the LSP:</p> <ul style="list-style-type: none"> • Background—Background type applications such as e-mail and FTP; has a CoS value of 1 • Best Effort—Traffic to be transmitted as a best-effort type; has a CoS value of 0 • Excellent Effort—Traffic to be transmitted as an excellent-load type; has a CoS value of 3 • Critical Applications—Traffic to ensure a high-quality user experience for users of business-critical applications; has a CoS value of 2 • Video < 100 ms—Streaming type applications such as video on demand and multimedia messaging; has a CoS value of 5 • Voice < 10 ms—Voice messaging such as VoIP; has a CoS value of 6 • Internetwork Control—Packets with internetwork control precedence; has a CoS value of 4 • Network Control—Packets with network control precedence; has a CoS value of 7. <p>CoS enables both subscribers and services to be differentiated from each other. Premium subscribers can be prioritized over basic subscribers, while real-time services can be prioritized over non-real-time services. The importance of QoS increases during periods of congestion. An unloaded network can meet the needs of all subscribers and services. However, as the network load increases, the prioritization of traffic determines whether performance for subscribers and services can be maintained or be degraded.</p> <p>The high-order 2 bits of the CoS value select which transmit queue to use on the outbound interface card. The low-order bit of the CoS value is treated as the PLP bit and is used to select the RED drop profile to use on the output queue. If the low-order bit is 0, the non-PLP drop profile is used, and if the low-order bit is 1, the PLP drop profile is used. Typically, RED aggressively drops packets that have the PLP bit set. For more information about RED and drop profiles, see the <i>Junos OS Class of Service Configuration Guide</i>.</p> <p>This field is not applicable for local-protection type of LSPs.</p>
Bandwidth (Kbps)	<p>Specify a bandwidth in Kbps for an LSP. Each LSP has a bandwidth value. This value is included in the sender's Tspec field in RSVP path setup messages. You can specify a bandwidth value in bits per second. If you configure more bandwidth for an LSP, it should be able to carry a greater volume of traffic.</p> <p>The default bandwidth is 0 bits per second.</p>
Standby (enable switchover)	<p>Select this check box to have the path remain up at all times to provide immediate switchover if connectivity problems occur.</p> <p>This check box is displayed only for secondary paths.</p>

Table 248: MPLS Path Settings (*continued*)

Item	Action
Adaptive	<p>Select this check box if you want to configure an LSP to be adaptive when it is attempting to reroute itself. When it is adaptive, the LSP holds onto existing resources until the new path is successfully established and traffic has been cut over to the new LSP. To retain its resources, an adaptive LSP does the following:</p> <ul style="list-style-type: none"> • Maintains existing paths and allocated bandwidths—This ensures that the existing path is not torn down prematurely and allows the current traffic to continue flowing while the new path is being set up. • Avoids double-counting for links that share the new and old paths—Double-counting occurs when an intermediate router does not recognize that the new and old paths belong to the same LSP and counts them as two separate LSPs, requiring separate bandwidth allocations. If some links are close to saturation, double-counting might cause the setup of the new path to fail. <p>By default, adaptive behavior is disabled.</p> <p>You can include the adaptive statement in two different hierarchy levels. If you specify the adaptive statement at the LSP hierarchy levels, the adaptive behavior is enabled on all primary/secondary paths of the LSP. This means both the primary and secondary paths share the same bandwidth on common links.</p> <p>This check box cannot be selected for P2MP topology and also when the path selection type is explicit path.</p>
Priority	<p>Configure the LSP's preemption properties by selecting a value from the Setup Priority and Hold Priority lists.</p>
Setup Priority	<p>Specify a priority value, which determines whether a new LSP that preempts an existing LSP can be established. For preemption to occur, the setup priority of the new LSP must be higher than that of the existing LSP. Also, the act of preempting the existing LSP must produce sufficient bandwidth to support the new LSP. That is, preemption occurs only if the new LSP can be set up successfully. The setup priority also defines the relative importance of LSPs on the same ingress router. When the software starts, when a new LSP is established, or during fault recovery, the setup priority determines the order in which LSPs are serviced. Higher-priority LSPs tend to be established first and hence enjoy more optimal path selection.</p> <p>This field cannot be configured for local-protection type of LSPs.</p> <p>Range: Both setup-priority and reservation-priority can be a value from 0 through 7, where 0 is the highest priority and 7 is the lowest priority.</p> <p>Default: An LSP has a setup priority of 7 (that is, it cannot preempt any other LSPs) and a reservation priority of 0 (that is, other LSPs cannot preempt it).</p> <p>These defaults prevent preemption. When you are configuring these values, make sure that the setup priority value is lower than or equal to the hold priority value.</p>

Table 248: MPLS Path Settings (*continued*)

Item	Action
Hold Priority	<p>Specify a hold priority value.</p> <p>This field cannot be configured for local-protection type of LSPs.</p> <p>Range: 0 through 7, where 0 is the highest priority and 7 is the lowest priority.</p> <p>The hold priority determines the degree to which an LSP holds onto its session reservation of the LSP that has been set up successfully. When the hold priority is high, the existing LSP is less likely to give up its reservation and, therefore, it is unlikely that the LSP can be preempted.</p> <p>You must configure the hold priority to be greater than or equal to the setup priority.</p> <p>NOTE: If traffic engineering admission control determines that there are insufficient resources to accept a request to set up a new LSP, the setup priority is evaluated against the hold priority of existing LSPs. An LSP with a hold priority lower than the setup priority of the new LSP can be preempted. The existing LSP is terminated to make room (that is, resources are freed) for the new LSP.</p>

2. View any administrative groups that are configured on the device. You can configure any new administrative groups.

Administrative groups, also known as link coloring or resource class, are manually assigned attributes that describe the color of links, such that links with the same color conceptually belong to the same class. You can use administrative groups to implement a variety of policy-based LSP setups. Administrative groups are meaningful only when constrained-path LSP computation is enabled (CSPF, instead of Explicit Path).

You can assign up to 32 names and values (in the range 0 through 31), which define a series of names and their corresponding values. The administrative names and values must be identical across all routers within a single domain.

If all interfaces are set to green or yellow, they are all appropriate to be used. The primary path must transit green or yellow links and must stay away from red links. The primary path is periodically recomputed and reoptimized. Finally, this path always keeps the secondary path in hot-standby state for quick failover. You can exclude the red interfaces or links from being part of the LSP.

Fill in the parameters as indicated in the following table under the Admin Groups table of the Path Settings page.

Field	Action
Include-all	Select an administrative group from the menu to specify that the LSP must traverse links that include all of the defined administrative groups.
Include-any	Select an administrative group from the menu to define the administrative groups to include in an LSP or a path's primary and secondary paths.

Field	Action
Exclude	Select an administrative group from the menu to define the administrative groups to exclude from an LSP or a path's primary and secondary paths.

- Click **Next** to proceed to the final step of the wizard, which is to review the configured settings.

The **Review** page of the wizard is displayed.

Alternatively, click the **Primary** tab to define the primary path settings of the LSP.

Configuring LSP Primary Path Settings

This page is unavailable if the value in the **LSP protection type** field is **Local Protection Only**.

On the Path Settings page, click the **Primary** tab. The **LSP Primary Path Settings** page enables you to configure primary paths on one point-to-point or several point-to-multiple-point branches. Specify the primary path to use for an LSP. You can configure only one primary path. You can optionally specify the preference, CoS, and bandwidth values for the primary path, which override any equivalent values that you configure for the LSP.

The settings that you configured in the selected LSP service definition populate the fields on this page. If you chose to create a custom LSP service order on the General Settings page of the wizard, the fields are not populated.

- Fill in the parameters as indicated in [Table 249 on page 1802](#).

Table 249: LSP Primary Path Settings

Item	Action
Primary Path	<p>Select a primary path from the LSPs pane on the left. Based on the Topology type, the paths are listed in the following pattern:</p> <ul style="list-style-type: none"> ● P2P topology <i>Ingress router -> Egress router</i> ● P2MP topology <i>Ingress router -> Egress router 1</i> <i>Ingress router -> Egress router 2</i> ● Full Mesh topology <i>Router 1 -> Router 2</i> <i>Router 2 -> Router 1</i>
Path Name	<p>From the list, select the path name that you want. This is a required field.</p> <p>For a primary path <i>Ingress router -> Egress router</i>, the Path Name list contains the paths on the ingress router.</p>

Configure any primary path setting that you selected in the LSP service definition to be editable in the LSP service order. You cannot change any setting that you configured in the LSP service definition to not be editable.

2. Click the **Secondary** tab on the Node Settings page.

The **LSP Secondary Path Settings** page appears.

Configuring LSP Secondary Path Settings

This page is unavailable if the value in the **LSP protection type** field is **Local protection only**, or if the value in the **Topology** field is **P2MP**.

On the Path Settings page, click the **Secondary** tab. The **LSP Secondary Path Settings** page enables you to configure primary paths on one point-to-point or several point-to-multiple-point branches. The settings that you configured in the selected LSP service definition populate the fields on this page. The fields are not populated with values if you chose to create a custom LSP service order on the General Settings page of the wizard.

1. Fill in the parameters as indicated in [Table 250 on page 1803](#).

Table 250: LSP Secondary Path

Item	Action
Secondary Path	<p>Select a secondary path from the LSPs pane on the left. Based on the Topology type, the paths are listed in the following pattern:</p> <ul style="list-style-type: none"> • P2P topology <i>Ingress router -> Egress router</i> • Full Mesh topology <i>Router 1 -> Router 2</i> <i>Router 2 -> Router 1</i>
Path Name	<p>From the list, select the path name that you want. This is a required field.</p> <p>For a primary path <i>Ingress router -> Egress router</i>, the Path Name list contains the paths on the ingress router.</p>

Configure any secondary path setting that you selected in the predefined LSP service definition to be editable in the LSP service order.

2. Click **Next** to proceed to the final step of the wizard, which is to review the configured settings.

The **Review** page of the wizard is displayed.

Reviewing the Configured Settings

The Review page of the service definition or service order creation and modification wizards enable you to view and evaluate the service parameters and components you configured in the preceding steps or on the preceding pages of the wizard. This page provides a comprehensive, single-page view of all the service elements configured using the different pages of the wizard. You can either click the buttons corresponding to the various settings at the top of the wizard page to directly traverse to the page you want to modify or click the navigation buttons at the bottom of the wizard page to go to the different pages of the wizard.

To examine the configured settings, and modify them as needed:

1. Click **Review** to view the defined parameters.

You can examine and modify the created service order parameters. Alternatively, click the corresponding buttons at the top of the wizard page to navigate to the specific pages that pertain to the settings you want to modify.

2. Click **Edit** beside any of the sections to modify the parameters corresponding to that section.

You are taken to the page pertaining to the parameter in the wizard.

3. Click **Finish** to save the service order.

4. Click **Back** to return to the previous page of the wizard; otherwise, click **Cancel** to discard the changes.

The service order inventory window appears.

Creating Public and Private LSPs

IN THIS SECTION

- [Managing Public LSPs by using NorthStar Controller | 1804](#)
- [Creating Private LSPs by Using Connectivity Services Director | 1805](#)

Managing Public LSPs by using NorthStar Controller

From Connectivity Services Director Release 3.0 onward, you can manage public LSPs that are created by using Tunnel services, through NorthStar Controller. These LSPs can be used by any service or service instance deployed on a device and are not specific to a service.

If the **Enable NorthStar Management** check box is selected in Preferences, the LSPs are created through Connectivity Service Director and deployed on the device by using NorthStar Controller.

For information on creating a public LSP service definition, see [“Creating an LSP Service Definition” on page 1763](#).

For information on creating a public LSP service order, see [“Creating an LSP Service Order” on page 1775](#).

Creating Private LSPs by Using Connectivity Services Director

From Connectivity Services Director Release 3.0 onward, you can create LSPs that are specific to a service.

The LSP association check box in the General Settings tab of the service order creation workflow enables you to create or associate LSPs specific to the service you choose.

If there are several terms mapping different VPNs to different LSPs, there must be a corresponding **except** keyword at the end of the policy statement to prevent the mapping of other VPNs to the LSPs.

Sample Policy

```
policy-statement lsp-install {
  term 0 {
    from community VPN1;
    then {
      install-nexthop lsp testlsp
      accept;
    }
  }
  term 1 {
    then {
      install-nexthop except lsp testlsp
    }
  }
}
```

Alternatively, you can use the **associate** keyword to associate the LSP, instead of the **except** keyword.

For information about creating a private LSP by using E-Line service, see [“Creating an E-Line Service Order” on page 895](#).

For information about creating a private LSP by using multipoint-to-multipoint E-LAN service, see [“Creating a Multipoint-to-Multipoint E-LAN Service Order” on page 943](#).

For information about creating a private LSP by using point-to-multipoint E-LAN service, see [“Creating a Point-to-Multipoint E-LAN Service Order” on page 964](#).

For information about creating a private LSP by using full mesh IP service, see [“Creating a Full Mesh IP Service Order” on page 995](#).

For information about creating a private LSP by using hub-and-spoke IP service, see [“Creating a Hub-and-Spoke IP Service Order” on page 1019](#).

Viewing the Configured LSP Services

To view and determine the status of LSP services in a tabular form:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Build** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. In the Network Services > Tunnel task pane, select **Service Provisioning > View LSPs**.

The View LSP Services page is displayed with a table of services on the system appears in the bottom pane of the main display area. The following fields are displayed on this page:

[Table 114 on page 869](#) describes the fields in the View LSP Services table.

Table 251: Fields in the Services Table

Field	Description
Name	Name of the service order assigned during service creation or edit.
Service Type	Label-switched path (LSP)

Table 251: Fields in the Services Table (*continued*)

Field	Description
State	<p>State of the service:</p> <ul style="list-style-type: none"> • Active—Denotes a service that has been deployed and is in an active state (enabled). • Inactive—Denotes a service that has been deployed and is in a deactivated state (disabled). • Pending—Denotes a service for which deployment of the service to a device is pending to be performed. • Failed—An attempt to modify the service failed.
FA Status	Status of functional audit of the service.
Fault Status	Fault management status of the service.
PM Status	Performance management status of the service.
Definition	Name of the service definition upon which the service order is based.
Activation Date	Date and time at which the service order was last activated.
Last Modified Time	Date and time at which the profile was last updated.

In the View pane, if you select the Tunnel item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as RSVP LSPs, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

5. To view details of a specific service, double-click the table row that summarizes the service.

Modifying an Explicit Path in RSVP LSP Services

In explicit routing, the route the label-switched path (LSP) takes is defined by the ingress node. The path consists of a series of hops defined by the ingress label-switching router (LSR). Each hop can be a traditional interface, an autonomous system, or an LSP. You can choose a new explicit path from the existing paths, create and map a new explicit path, and delete the explicit path associated with RSVP service. When explicit-path LSPs are configured, the LSP is established along the path you specified.

The **Path Settings** page of the service order modification wizard enables you to view existing paths or add, edit, or delete paths.

To configure an explicit-path LSP:

1. Select **Service View** from the View selector.

The workspaces that are applicable to routing and tunneling services are displayed.

2. From the Connectivity Services Director user interface, click the **Deploy** icon on the Connectivity Services Director banner.

The functionalities that you can configure in this mode are displayed in the Tasks pane of the GUI window.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

4. From the Service View pane, click the plus sign (+) sign next to Tunnels, and select RSVP LSPs.

5. From the Tasks pane, select **Service Provisioning > Manage LSP**. The Manage Network Services page is displayed in on the top right main display area, and the Manage Service Deployment window is displayed on the bottom of the main display area.

6. Select an RSVP service and click **Modify**. The Modify LSP service wizard appears.

NOTE: You can modify the primary path or the secondary path of an RSVP service only.

7. Navigate to the Path Settings page of the wizard.

This page is unavailable if the **LSP protection type** is **Local Protection Only**.

From the Path Settings page, click the **Primary** tab. The **LSP Primary Path Settings** page enables you to configure primary paths on one point-to-point or several point-to-multiple-point branches. Specify the primary path to use for an LSP. You can configure only one primary path. You can optionally specify

preference, CoS, and bandwidth values for the primary path, which override any equivalent values that you configure for the LSP.

From the Path Settings page, click the **Secondary** tab. The **LSP Secondary Path Settings** page enables you to configure primary paths on one point-to-point or several point-to-multiple-point branches. The settings that you configured in the selected LSP service definition populate the fields on this page. The fields are not populated with values if you chose to create a custom LSP service order in the General Settings page of the wizard.

8. Modify the primary and secondary path.

To modify the primary or secondary path:

- a. Select a primary path or secondary path from the LSPs pane on the left. Based on the **Topology** type, the paths are listed in the following pattern:

- **P2P topology**

Ingress router -> Egress router

- **Full Mesh topology**

Router 1 -> Router 2

Router 2 -> Router 1

- b. Select the **Automatic** radio button for an automatic path to be used for the LSP for the primary path or secondary path.

9. Create a new path.

To create a new primary or secondary path:

- a. Select the **Create New** radio button to create a new path. The fields to create a new path are displayed in the Path Name section.

- b. Specify the following fields:

- **Path Name**—Name of the new path
- **IP address**—IP address of the new path
- **Loose/Strict**—Explicit Route Objects (EROs) type.

EROs limit LSP routing to a specified list of LSRs. By default, RSVP messages follow a path that is determined by the network IGP's shortest path. However, in the presence of a configured ERO, the RSVP messages follow the path specified. EROs consist of two types of instructions: loose hops and strict hops.

When a loose hop is configured, the hop denotes one or more transit LSRs through which the LSP must be routed. The network IGP determines the exact route from the inbound router to the first loose hop, or from one loose hop to the next. The loose hop specifies only that a particular LSR be included in the LSP.

When a strict hop is configured, the hop identifies an exact path through which the LSP must be routed. Strict-hop EROs specify the exact order of the routers through which the RSVP messages are sent.

- c. Click **Add** to add the new path.

The new path now appears in the primary and secondary paths list.

10. Click **Modify**.

Connectivity Services Director modifies the explicit path of a RSVP LSP service. If the path is topologically not feasible, either because the network is partitioned or insufficient resources are available along some parts of the path, the LSP fails. No alternative paths can be used.

If the setup succeeds, the LSP stays on the defined path indefinitely.

NOTE: Select the View Deployment Jobs option on the tasks pane in Deploy mode to check whether the deployment jobs completed successfully.

Modifying an RSVP LSP Service

You can modify the name of a RSVP LSP service. After modifying a service, the configuration audit and functional audit information is cleared and the functional audit status is set to pending.

To modify the attributes of a service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon on the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. From the Service View pane, click the plus sign (+) sign next to Tunnels, and select RSVP LSPs.
5. From the task pane, select **Service Provisioning > Manage LSP**. The Manage Network Services window is displayed in the top part of the right pane, and the Manage Service Deployment window is displayed in the bottom part of the right pane.

6. Select an RSVP service, and click **Modify**. The Modify LSP service wizard appears.

NOTE: You can modify the primary path or the secondary path of an RSVP service only.

7. Modify the fields.

For example, you can enable or disable BFD for a BFD LSP service.

NOTE: You can modify only those fields, which are editable in the service order.

The **Full Mesh** template implementation supports the generic attributes (at device level) that are common across LSPs.

NOTE: You cannot assign specific values to each of the LSPs, because the **Full Mesh** template design does not support such a modification.

For a RSVP LSP service, you can also modify the primary and secondary path. For more information on modifying the paths, see [“Modifying an Explicit Path in RSVP LSP Services” on page 1808](#).

For a full mesh RSVP service you can add or delete the devices.

8. Click **Modify**.

The software modifies the service.

9. Use the Jobs workspace to check for successful completion of the action.

Viewing LSP Services in Deploy Mode

To view and determine the status of LSP services in a tabular form:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

3. From the View pane, click the plus sign (+) to expand the tree and select the type of service.
4. In the Network Services > Tunnel task pane, select **Service Provisioning > Deploy Services**.

The Manage LSP Services page is displayed in the upper half of the window.

A table of services on the system appears in the main display area. The following fields are displayed on this page:

In the top half of the window on the right pane, the Manage Network Services page presents information on existing services in a table.

The **Manage LSP Services** page provides the following information about each service:

[Table 114 on page 869](#) describes the fields in the service orders table.

Table 252: Fields in the Services Table

Field	Description
Name	Name of the service order assigned during service creation or edit.
Service Type	Label-switched path (LSP)
Customer	Name of the enterprise customer who placed an order for the service.
Deployment State	State of the service: <ul style="list-style-type: none"> • Active—Denotes a service that has been deployed and is in an active state (enabled). • Inactive—Denotes a service that has been deployed and is in a deactivated state (disabled). • Pending—Denotes a service for which deployment of the service to a device is pending to be performed. • Failed—An attempt to modify the service failed.
FA Status	Status of functional audit of the service.
Fault Status	Fault management status of the service.
PM Status	Performance management status of the service.
Definition	Name of the service definition upon which the service order is based.
Activation Date	Date and time at which the service order was last activated.
Last Modified Time	Date and time at which the profile was last updated.

From this page, you can create a service order, modify the properties of the service order, conduct a functional or configuration audit, deploy or deactivate the service order, and view alarms associated with a particular service order for debugging and corrective action.

5. To view details of a specific service, double-click the table row that summarizes the service.

Viewing LSP Service Orders in a Table

To view and determine the status of LSP service orders in a tabular form:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the Network Services > Tunnel > LSPs tree and select the type of service.
4. In the Network Services > Tunnel > LSPs View pane, select **Service Provisioning > Manage LSP**.

The Manage LSP Deployment page is displayed on the right pane.

A table of service orders on the system appears in the main display area. The following fields are displayed on this page:

- Name—Unique name assigned to the service.
- Customer—Name of the customer for which the service is provided.
- State:
 - Completed—Service order has been successfully deployed.
 - Failed—Device is down or the Connectivity Services Director application was unable to push the service configuration to a device configured for the service.
 - In-progress—Connectivity Services Director application is in the process of deploying the service.
 - Requested—Service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
 - Scheduled—Service provisioner has scheduled the service order for deployment.

- Invalid—Service order contains invalid data.
- Validated—When all the information in the service order is successfully validated, the service order transitions to the Validated state.
- Service Type:
 - LSP (Label-switched path)
- Latest Job—Unique identifier assigned by the system for a deployment job. Click the link in the job ID to open the CSD Deployment Jobs. The table on that page lists configuration deployment jobs.
- Signaling Type:
 - BGP
 - LDP
- Created By—The screen name of the user who created the service order
- Created Date—The date and when you created the service order.

From this page, you can create a service order, modify the properties of the service order, conduct a functional or configuration audit, deploy or deactivate the service order, and view alarms associated with a particular service order for debugging and corrective action.

5. To view details of a specific service order, double-click the table row that summarizes the service order.

Deactivating an LSP Service

This procedure disables a service for a particular protocol that you have previously created on the network. By disabling a service, the traffic processing for the traversed packets is impacted. In certain network topologies, you might require a service-related settings to be disabled for a certain period to perform troubleshooting or modification to the traffic-handling method, and you might want to reactivate a disabled service later when you have completed network maintenance and analysis work. In such a case, it might be beneficial to use the deactivation functionality for a service order. When you disable a service, the configuration attributes associated with such a service are deactivated and commented out in the device settings. The deactivated service is propagated to the devices associated with the service. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deployed or Re-Activated state.

NOTE: To modify a service order, it must not be in the Deactivated state.

To deactivate a service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to view services based on protocols, and expand the **LSPs** tree to select an LSP service.
5. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage LSP Network Services page, with the table of services, and the bottom part of the right pane displays the Manage LSP Service Deployment page, with the table of service orders.
6. From the Manage Network Services page, select the check box next to the service you want to deactivate.
7. Click the down arrow on the **Action** menu, above the table of listed services, and select **Deactivate** to disable the selected service. A dialog box is displayed prompting you to confirm your action.
8. Do one of the following in the Confirmation dialog box:
 - To deactivate the service immediately, select Deactivate now, and click Yes. If you click Yes, a pending change request is created for each selected service. Alternatively, if you click No, the deactivate operation is discarded.
 - To deactivate the service at a later time, select Deactivate later, and select a date and time for deployment, then click OK. The time field specifies the time kept by the server, but in the time zone of the client. After scheduling the service order for deactivation, the provisioning software begins validating the service order.
9. Use the Jobs workspace to monitor the outcome of the deployment.

RELATED DOCUMENTATION

[Reactivating a Service | 925](#)

[Force-Deploying a Service | 927](#)

[Decommissioning a Service | 931](#)

Reactivating an LSP Service

After you disable a service to deactivate the configuration settings on devices mapped to the service, you might require the service settings to be reenabled after you have modified the service parameters, either directly on the device or using the Connectivity Services Director application. In such a case, you can use the reactivation functionality to revive and activate the service properties on devices. To disable a service, the service must not contain any pending or uncommitted changes. Also, the service must be in the Deactivated state.

To reactivate a service:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside **Tunnel** to view services based on protocols, and expand the **LSPs** tree to select an LSP service.
5. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage LSP Network Services page, with the table of services, and the bottom part of the right pane displays the Manage LSP Service Deployment page, with the table of service orders.
6. From the Manage Network Services page, select the check box next to the service you want to reactivate.
7. Click the down arrow on the Action menu, above the table of listed service orders, and select **Reactivate** to reenable the selected service order. A dialog box is displayed prompting you to confirm your action.
8. Do one of the following in the Confirmation dialog box:
 - To reactivate the service immediately, select **Reactivate now**, and click **Yes**. If you click **Yes**, the selected service is activated immediately. Alternatively, if you click **No**, the deactivate operation is discarded.
 - To reactivate the service at a later time, select **Reactivate later**, and select a date and time for reactivating, then click **OK**. The time field specifies the time kept by the server, but in the time zone of the client.
9. Use the Jobs workspace to monitor the outcome of the deployment.

RELATED DOCUMENTATION

[Reactivating a Service | 925](#)

[Force-Deploying a Service | 927](#)

[Decommissioning a Service | 931](#)

Force-Deploying an LSP Service

When a service fails a configuration audit because configuration changes on a PE device do not match the configuration required for the service, you can force-deploy the service to push the configuration to the device.

Force deployment pushes the same configuration to the device that was pushed during the deployment of the service, thus allowing the operator to recover from a state in which the configuration on the device was lost or changed out-of-band.

The validation before generating the configuration for a force-deployed service order will be performed against the current configuration on the device and the configuration is not pushed if the validation fails. If the forced deployment is unable to push the configuration again, then you might need to manually configure the device.

This procedure forces deployment of a service on the network.

You cannot force-deploy an invalid service order.

To schedule a service for forced deployment:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to view services based on protocols, and expand the **LSPs** tree to select an LSP service.
5. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage LSP Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.

6. From the Manage LSP Network Services page, select the check box next to the service you want to forcibly deploy.

The top pane displays information about the services that have been previously created, such as the name of the service, the functional audit status, the performance management status, and the deployment state of the service. You can modify the properties of the service, conduct a functional or configuration audit, force-deploy or deactivate the service, and view alarms associated with a particular service order for debugging and corrective action. Services can be in one of the following service states:

- **Completed**—The service order has been successfully deployed.
- **Scheduled for deployment**—The service provisioner has scheduled the service order for deployment.
- **Deployment Failed**—An attempted service deployment was not successfully completed or failed an audit.
- **In Progress**—The Connectivity Services Director application is in the process of deploying the service.
- **Requested**—The service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
- **Invalid**—The service order is not valid.

7. Open the **Actions** menu and click **Force Deploy Service**.

The **Schedule Force Deployment** window appears.

8. To deploy the service immediately, select **Force deploy now**, and click **OK**.

To deploy the service at a later time, select **Force deploy later**, select a date and time for deployment, then click **OK**.

The time field specifies the time kept by the server, but in the time zone of the client.

After scheduling the service order for deployment, the provisioning software begins validating the service order.

9. Use the Jobs workspace to monitor the outcome of the forced deployment.

RELATED DOCUMENTATION

[Deactivating a Service | 923](#)

[Reactivating a Service | 925](#)

[Decommissioning a Service | 931](#)

Viewing Alarms for an LSP Service

Activity on a network device consists of a series of events. A software component on the network device, called an entity, is responsible for running the Simple Network Management Protocol (SNMP) to log and monitor these events. You can view the details of alarms and events generated for a particular service order to examine and diagnose the problems that are generating the alarms. These alarms provide essential and cohesive information about system conditions, any discrepancies and malfunctioning, and protocols or components that need to be examined and debugged for better efficiency and working capacity

To view alarm and event details for a service:

1. Select Service View from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Build** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnel to view services based on protocols, and expand the **LSPs** tree to select an LSP service.
4. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
5. Select the check box next to the service for which you want to view alarm details.
6. Click the **View Alarms** button, above the table of listed services.
The Alarm Detail dialog box is displayed.
7. Click **Close** after you finish evaluating the information to return to the Manage Network Services page.

RELATED DOCUMENTATION

| [Alarm Detail Monitor \(Service View\)](#) | 1331

Managing Deployment of LSP Services Configuration to Devices

IN THIS SECTION

- [Selecting Configuration Deployment Options | 1822](#)
- [Discarding the Pending Configurations | 1822](#)
- [Deploying Service Configuration Changes to Devices Immediately | 1823](#)
- [Scheduling Configuration Deployment of Services | 1824](#)
- [Specifying Configuration Deployment Scheduling Options | 1825](#)

When you make configuration changes in Build mode, the changes are not deployed to devices automatically. You must manually deploy the changes to devices in Deploy mode.

To start deploying configuration changes:

1. From the View selector, select **Service View**. The workspaces that are applicable to this view are displayed.
2. Click **Deploy** in the Connectivity Services Director banner.
3. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and view the list of service types.
4. Expand the LSPs tree to view the list of LSPs.
5. In the Tasks pane, select **Service Provisioning > Manage LSP**. The Manage LSP Service Deployment window is displayed in the bottom part of the right pane.

TIP: From Build mode of Service View, in the View pane, if you select the Connectivity item in the tree under Network Services, without expanding the tree and selecting a specific service type, such as E-Line Services, IP Services, or E-LAN Services, the top pane displays a set of five pie charts that enable you to view the different service orders configured, and their associated audit and monitoring statuses. The FA Status chart displays the functional audit status for the service orders. The Device State graph displays the statuses of devices on which services are being provisioned and commissioned. The Fault Status chart displays the connectivity fault management details for the service orders. The SLA Status chart displays the service-level agreement details for the service orders. The PM Status chart displays the performance management details for the service orders. The count or percentage of service orders in the pie chart segments sum up to the total number of configured service orders. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. These charts provide a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

In Build mode of Service View, from the View pane, if you select the Network Services node and do not expand the Network Services > Connectivity tree, the top pane displays a pie chart that enables you to view and examine the different services configured for devices, and the types of service protocols configured. The Services by Type graph displays the count of services for each type of service definition. Mouse over each segment of the pie to view the number corresponding to the percentage of service orders for each of the charts. This chart provides a visual overview of customers and service orders on your network, and enables you to quickly access related and commonly needed information. For example, you can check for failed service orders and then access a list of failed requests so you can begin to take restoration measure.

The following fields are displayed in this window:

- Name—Unique name assigned to the service.
- Customer—Name of the customer for which the service is provided.
- State—State of the service order. Service orders can be one of the following states:
 - Completed—The service order has been successfully deployed.
 - Scheduled for deployment—The service provisioner has scheduled the service order for deployment.
 - Deployment Failed—An attempted service deployment was not successfully completed or failed an audit.
 - In Progress—The Connectivity Services Director application is in the process of deploying the service.

- Requested—The service provisioner has created the service order, but has not yet attempted to deploy it or schedule it for deployment.
- Invalid—The service order is not valid.
- Signaling—Type of signaling, namely, BGP or LDP.
- Created By—Name of the user that created the service order.
- Created Date—Date and time at which the service order was created.

This topic describes:

Selecting Configuration Deployment Options

Based on the approval mode, you can choose to deploy the device configuration changes in the following ways:

- When you select the auto approval mode, the page *Devices with Pending Changes* open. From the *Devices with Pending Changes* page, you can:
 - Deploy configuration changes immediately by selecting one or more devices and clicking *Deploy Now*. For more information, see [“Deploying Configuration Changes to Devices Immediately” on page 817](#).
 - Schedule configuration deployment by selecting one or more devices and clicking *Schedule Deploy*. For more information, see [“Scheduling Configuration Deployment” on page 817](#).
 - View configuration changes that are pending on a device by clicking *View* in the *Configuration Changes* column.
 - Validate that the pending changes for a device are compatible with the device’s configuration by selecting up to ten devices and clicking *Validate Pending Configuration Changes*.
 - Discard the pending configuration changes. For more information, see [“Discarding the Pending Configurations” on page 815](#).

Discarding the Pending Configurations

Use the *Discard Local Configuration Changes Results* window to discard all the pending configurations that were made on a device. Once you discard the local configuration changes on a device, the configuration state of the device changes to *In Sync* or *Out of Sync* based on the system of record (SOR) mode set for the Junos Space Network Management Platform. If the SOR mode is set to *Network as system of record (NSOR)*, then the configuration state changes to *In Sync* and if the SOR mode is set to *Junos Space as system of record (SSOR)*, then the configuration state changes to *Out of Sync*.

To discard the configuration changes:

1. From the View selector, select **Service View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that are applicable to this lifecycle mode are displayed.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and click **LSPs** to view the list of LSP services.
5. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
6. From the Manage Service Deployment page, select the services for which you want to discard the pending configuration and click **Discard Pending Configuration** from the Actions menu.

The Discard Local Configuration Changes Results window opens displaying the status of the discard pending configuration job.
7. To discard the pending changes of the service immediately, select **Partial delete now**, and click **OK**. To discard the pending changes of the service at a later time, select **Partial delete later**, select a date and time for deletion, then click **OK**. The time field specifies the time kept by the server, but in the time zone of the client. After scheduling the service order for deployment, the provisioning software begins validating the service order.
8. Click **Close** to close the Discard Local Configuration Changes Results window.

Deploying Service Configuration Changes to Devices Immediately

To deploy service configuration changes to devices immediately:

1. From the View selector, select **Service View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that are applicable to this lifecycle mode are displayed.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and click **LSPs** to view the list of LSP services.
5. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
6. Select the check box next to the service you want to deploy from the Manage Service Deployment page.
7. Click **Deploy Now**.
The Deploy Options window opens.
8. In the Deploy Options window, enter a job name in the Deployment Job Name field, then click **OK**.
The configuration deployment job runs. The Deploy Configuration window opens and shows the results of the deployment job.

Scheduling Configuration Deployment of Services

To schedule the services configuration deployment to devices:

1. From the View selector, select **Service View**. The workspaces that you can configure in this view are displayed.
2. Click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that are applicable to this lifecycle mode are displayed.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and click **LSPs** to view the list of LSP services.
5. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.

- 6. Select the check box next to the service you want to deploy from the Manage Service Deployment page.
- 7. Click **Schedule Deploy**.
The Deploy Options window opens.
- 8. Use the Deploy Options window to schedule the configuration deployment. See [“Specifying Configuration Deployment Scheduling Options” on page 818](#) for a description of the window.

Specifying Configuration Deployment Scheduling Options

Use the Deploy Options window to schedule configuration deployment jobs. [Table 98 on page 818](#) describes the actions for the fields in this window.

Table 253: Deploy Options Window

Field	Action
Deployment Job Name	Enter a job name.
Date and Time	Enter the job’s start date and time.
OK	Click to accept changes and exit the window.
Cancel	Click to cancel changes and exit the window.

Deploying an LSP Service

This procedure schedules a service for deployment on the network. Use this procedure to perform the following tasks:

- Deploy a new service.
- Deploy a modified service.
- Redeploy a service order that failed deployment.

You cannot deploy an invalid service order.

To schedule a service for deployment:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and view the list of service types.
4. Expand the LSPs tree to view the list of LSP services.
5. From the **Network Services > Tunnel** task pane, select **Service Provisioning > Manage LSP**. The Manage Service Deployment page is displayed on the right pane.
6. In the **Manage Service Deployment** page, select the service order that you want to deploy.
7. Click the **Deploy Service Order** button at the top of the page.
The **Deploy Service** window appears.
8. To deploy the service immediately, select **Deploy now**, and click **OK**.
To deploy the service at a later time, select **Schedule Deploy**, and select a date and time for deployment, then click **OK**.
The time field specifies the time kept by the server, but in the time zone of the client.
After scheduling the service order for deployment, the provisioning software begins validating the service order.
9. Use the Jobs workspace to monitor the outcome of the deployment.

RELATED DOCUMENTATION

[Validating the Pending Configuration of a Service Order | 1096](#)

[Viewing the Configuration of a Pending Service Order | 1098](#)

Deleting a Partial Configuration of an LSP Service Order

A failed service order of type Provisioning can leave parts of the service configuration on the devices. To remove this partial configuration:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and view the list of service types.
5. Expand the LSPs tree to view the list of LSP services.
6. From the **Network Services > Tunnel** task pane, select **Service Provisioning > Manage LSP > service order name**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
7. In the **Manage Service Deployment** page, select the failed service order for which you want to delete the partial configuration.
8. Open the **Actions** menu and select **Delete Partial Configuration**.
9. To delete the pending changes of the service immediately, select **Partial Delete Now**, and click **OK**. To discard the pending changes of the service at a later time, select **Partial Delete Later**, select a date and time for deletion, then click **OK**. The time field specifies the time kept by the server, but in the time zone of the client. After scheduling the service order for deployment, the provisioning software begins validating the service order.

You are returned to the Manage Service Orders page.

RELATED DOCUMENTATION

[Managing Service Configuration Deployment Jobs](#) | 1080

[Deploying Services Configuration to Devices | 1083](#)

[Deploy Configuration Window | 824](#)

[Managing Jobs | 122](#)

Deleting an LSP Service Order

You can delete a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state. To correct a service order in the invalid state, you must delete it and then recreate it; the Connectivity Services Director application does not support modifying the service order directly.

To delete a service order from the database:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and view the list of service types.
4. Expand the LSPs tree to view the list of LSP services.
5. From the **Network Services > Tunnel** task pane, select **Service Provisioning > Manage LSP**.
6. In the **Manage Service Deployment** page, select the service order to be deleted from the Connectivity Services Director application database.
7. Open the **Actions** menu and select **Delete Service Order**.
A pop-up window appears requesting confirmation.
8. Click **Delete**.

The **Manage Service Deployment** page reappears with the deleted service orders removed.

RELATED DOCUMENTATION

[Creating an E-Line Service Order | 895](#)

Validating the Pending Configuration of an LSP Service Order

This procedure validates a service order but does not push the configuration to the device. Use this procedure to perform the following tasks:

- Validate a service request in the REQUESTED state.
- Validate a service request in the INVALID state after making necessary configuration changes on one or more PE devices associated with the service order.

When you create a service order, it is automatically validated in Connectivity Services Director. However, if subsequent changes to service configuration attributes and settings have occurred for the devices or endpoints to which they are associated, you can use the functionality to validate pending service order configuration. You can validate the configuration of a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state

To schedule a service order for validation, follow these steps:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and view the list of service types.
5. Expand the LSPs tree to view the list of LSP services.
6. From the task pane, select **Service Provisioning > Manage LSP**. The top part of the right pane displays the Manage Network Services page, with the table of services, and the bottom part of the right pane displays the Manage Service Deployment page, with the table of service orders.
7. From the Manage Service Deployment page, select the service order you want to validate and save.
8. Open the **Actions** menu and click **Validate Pending Configuration**.

The **Schedule Service Request Validation** window appears.

9. You can validate a service now or at some future time:

- To validate the service immediately, select **Validate now**, and click **OK**.
- To validate the service at a later time, select **Validate later**, select a date and time for deployment, and then click **OK**.

NOTE: When specifying a time to validate the service, the time field specifies the time kept by the server, but in the time zone of the client.

After scheduling the service order for validation, the provisioning software begins validating the service order.

10. You can use the **Job Management** window to view details about the service validation.

RELATED DOCUMENTATION

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

Viewing the Configuration of a Pending LSP Service Order

You can view the configuration of a service order that is in the requested state, the scheduled state, the invalid state, or the failed deployment state.

To view the configuration of such pending service orders:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnel to expand the tree in the View pane and view the list of service types.

4. Expand the LSPs tree to view the list of LSP services.
5. From the **Network Services > Tunnel** task pane, select **Service Provisioning > Manage LSPs**. The Manage Service Deployment page is displayed on the bottom part of the right pane.
6. Select a service order that is in either of the following states:
 - Requested
 - Invalid
 - Scheduled
 - Failed deployment

NOTE: The **Order State** column displays the state of the service order.

7. Select the service order for which you want to view the configuration details.
8. Click the **View Pending Order Configuration** button at the top of the table of listed service orders. The **Service Configuration View** window is displayed. The configuration is displayed in CLI format.

NOTE: The **View Pending Order Configuration** button on the Manage Service Orders page appears to be dimmed if the service order state is Completed.

9. Select a device to view the configuration details. You can also view the template configuration if a template is attached to the service order.

Based on the application's settings, the configuration is displayed in xml format or in set format. To view the configuration in set format:

1. Select **Platform > Administration > Applications > Connectivity Services Director**.
2. Right-click the Connectivity Services Director application and select **Modify Application Settings**. The Modify Connectivity Services Director Settings window is displayed.
3. Select the **show configuration in set format** check box.

RELATED DOCUMENTATION

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

[Validating the Pending Configuration of a Service Order | 1096](#)

Viewing the Configuration Details of RSVP LSP Services

You can view the configuration of an RSVP LSP tunnel service, which enables you to see the parameters and attributes configured for a service on the associated devices in the form of configuration statements and commands that are displayed in the Junos OS CLI interface. You can use these settings to examine the existing service configuration and modify it as necessary to correct any traffic-handling problems or system discrepancies.

To view the configuration of services:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnels to view services based on protocols, and select **LSPs** to view the LSP services.
4. From the **Network Services > Tunnels > LSPs** task pane, select **Service Provisioning > Manage LSP**. The Manage Network Services page is displayed on the top part of the right pane.
5. Select the check box next to a service for which you want to view the configuration details.
6. Click the **View Configuration** option. The Service Configuration View dialog box is displayed. The configuration is displayed in the CLI interface structure and in the form of configuration stanzas.

The left pane displays a tree of devices associated with the specified service. You can select a Service-name > Device-name in the left pane of the window to view the configuration parameters of the corresponding device on the right pane. The right pane contains two tabs— Service Configuration and Template Configuration. The Service Configuration tab displays the settings specified for the service on the device in CLI format. This tab displays the elements or components specified for a service template in the form of configuration stanzas and hierarchy levels. This display is similar to the show command that you can use at a certain [edit] hierarchy level to view the defined settings. The Template

Configuration tab displays the service attributes and options defined in the service template, if any, that is associated with the service.

7. Click **OK** to close the dialog box after you complete viewing the configuration attributes and settings.

RELATED DOCUMENTATION

[Deleting a Partial Configuration of an LSP Service Order | 1091](#)

[Deleting a Service Order | 1092](#)

[Deploying a Service | 1094](#)

[Validating the Pending Configuration of a Service Order | 1096](#)

Viewing Decommissioned LSP Service Orders

In certain situations, you might decommission a service that a customer no longer needs. You cannot decommission a service if a service order requesting action on that service is in the Requested, Scheduled, In Progress, or Invalid state. You can view the decommissioned service orders in a separate page to determine whether you want to delete it completely.

To view and determine the status of RSVP LSP service orders in a tabular form:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Deploy** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the View pane, click the plus sign (+) to expand the Network Services tree and select the Tunnel node.
4. In the Network Services > Tunnel View pane, select **Service Provisioning > Decommissioned Service Orders**.

The Manage LSP Service Deployment page is displayed on the right pane.

A table of service orders on the system appears in the main display area. The following fields are displayed on this page:

- Name—Unique name assigned to the service.
- Customer—Name of the customer for which the service is provided.

- State:
 - Deployed-Active—Denotes a service that has been deployed and is in an active state (enabled).
 - Deployed-Inactive—Denotes a service that has been deployed and is in a deactivated state (disabled).
 - Deployment-Pending—Denotes a service for which deployment of the service to a device is pending to be performed.
 - Failed Deploy—An attempt to modify the service failed.
- Service Type:
 - LSP (Label-switched path)
- Latest Job—Unique identifier assigned by the system for a deployment job. Click the link in the job ID to open the CSD Deployment Jobs. The table on that page lists configuration deployment jobs.
- Signaling Type:
 - BGP
 - LDP
- Created By—The screen name of the user who created the service order
- Created Date—The date and when you created the service order.

From this page, you can create a service order, modify the properties of the service order, conduct a functional or configuration audit, deploy or deactivate the service order, and view alarms associated with a particular service order for debugging and corrective action.

5. To view details of a specific service order, double-click the table row that summarizes the service order.

Monitoring and Troubleshooting Tunnel Services

IN THIS CHAPTER

- [Performing a Functional Audit for LSP Services | 1835](#)
- [Viewing Functional Audit Results for LSP Services | 1842](#)
- [Examining the LSP Summary Details for Effective Troubleshooting | 1845](#)
- [Troubleshooting the Endpoints of RSVP LSP Services | 1849](#)
- [Clearing LSP Statistics | 1853](#)
- [Monitoring Network Reachability by Using the MPLS Traceroute Capability | 1854](#)
- [Monitoring Network Reachability by Using the MPLS Ping Capability for RSVP LSPs | 1856](#)

Performing a Functional Audit for LSP Services

A functional audit determines whether a deployed service instance is functioning. It checks the control plane to ensure connectivity among endpoints and that the UNIs are functioning correctly. It also checks the data plane to verify packet transmission between each valid pair of endpoints in the service.

A functional audit works by running commands that perform verification and reporting relevant information.

The following table shows the commands that are used for each service type:

Service Type	Device Family	XML Commands		CLI Commands	
		Data Plane	Control Plane	Data Plane	Control Plane
RSVP LSP	ACX Series, M Series, MX Series	Not supported.	<code><get-mpls-lsp-information></code> <code><name> <i>lspName</i></code> <code></name> <ingress> </ingress></code> <code></get-mpls-lsp-information></code>	Not supported.	<code>show mpls lsp</code> <code><i>lspName</i></code> <code>p2pmdl_to_100_100_20</code> <code>ingress</code>
		Where: <i>lspName</i> = Name of the LSP			
	BX7000 Gateway	Not supported.	<code><get-mpls-tunnel-information></code> <code><name> <i>tunnelName</i></name></code> <code></get-mpls-tunnel-information></code>	Not supported.	<code>show mpls tunnel</code> <code><i>tunnelName</i></code>
		Where: <i>tunnelName</i> = Tunnel name			
Static LSP	ACX Series, M Series, MX Series	Not supported.	<code><get-mpls-static-lsp-information></code> <code><name> <i>lspName</i> </name></code> <code><ingress></ingress></code> <code></get-mpls-static-lsp-information></code>	Not supported.	<code>show mpls static-lsp</code> <code>name <i>lspName</i> ingress</code>
		Where: <i>lspName</i> = Name of the LSP			
	BX7000 Gateway	Not supported.	<code><get-mpls-tunnel-information></code> <code><name> <i>tunnelName</i> </name></code>	Not supported.	<code>show mpls tunnel</code> <code><i>tunnelName</i></code>
		Where: <i>tunnelName</i> = Tunnel name			

Service Type	Device Family	XML Commands		CLI Commands	
		Data Plane	Control Plane	Data Plane	Control Plane
GRE	ACX Series, M Series, MX Series BX7000 Gateway	Not supported.	<pre><get-interface-information> <interface-name> <i>interfaceValue</i> </interface-name> </get-interface-information></pre>	Not supported.	<pre>show interfaces <i>interfaceValue</i></pre>
		Where: <i>interfaceValue</i> = Name of the interface			

For the data plane, the Junos Space software places a static MAC address in the forwarding table of the remote endpoint, which it uses to verify correct packet transfer.

Troubleshooting the RSVP LSP Static LSP, and GRE

From the **Troubleshooting** tab you can check status of the interfaces, LDP sessions, neighbor links, and endpoints of the RSVP LSP Static LSP, and GRE. To select the status you want to check, click the device from the device list on the left, and select the show command from the **Command** list.

The following table shows the commands for RSVP LSP:

Service Type	Device Family	XML Commands	CLI Commands	Category
RSVP LSP	M Series	<code><get-mpls-lsp-information></code> <code><regex>instanceValue</regex></code> <code></get-mpls-lsp-information></code>	show mpls lsp ingress name <i>instanceValue</i>	MPLS
		<code><get-mpls-lsp-information></code> <code><extensive/><regex></code> <code><i>instanceValue</i></regex></code> <code></get-mpls-lsp-information></code>	show mpls lsp name <i>instanceValue</i> extensive	MPLS
		<code><get-rsvp-session-information></code> <code><session-name>instanceValue</code> <code></session-name/></code> <code></get-rsvp-session-information></code>	show rsvp session name <i>instanceValue</i>	Route
		<code><get-rsvp-neighbor-information></code> <code></get-rsvp-neighbor-information></code>	show rsvp neighbor	Route
		<code><get-rsvp-interface-information></code> <code></get-rsvp-interface-information></code>	show rsvp interface	Route
		<code><get-ospf-neighbor-information></code> <code></get-ospf-neighbor-information></code>	show ospf neighbor	Route
		<code><get-ldp-session-information></code> <code></get-ldp-session-information></code>	show ldp session	Route
		<code><get-bfd-session-information></code> <code></get-bfd-session-information></code>	show bfd session	OAM
		Where: <i>instanceValue</i> = Name of the service		

The following table shows the commands for Static LSP:

Service Type	Device Family	XML Commands	CLI Commands	Category
Single-Hop and Multihop LSP	M Series	<code><get-mpls-static-lsp-information></code> <code><name>instanceValue</code> <code></name>routerType</code> <code></get-mpls-static-lsp-information></code>	show mpls static-lsp name <i>instanceValue</i>	MPLS
		<code><get-mpls-static-lsp-information></code> <code><extensive/>routerType<regex></code> <code>instanceValue</regex></code> <code></get-mpls-static-lsp-information></code>	show mpls static-lsp name <i>instanceValue</i> extensive	MPLS
		<code><get-ospf-neighbor-information></code> <code></get-ospf-neighbor-information></code>	show ospf neighbor	Route
		Where: <i>instanceValue</i> = Name of the service <i>routerType</i> = Type of the router		

The following table shows the commands for GRE:

Service Type	Device Family	XML Commands	CLI Commands	Category
GRE	ACX Series, M Series, MX Series	<code><get-interface-information></code> <code><terse/></code> <code><interface-name>interfaceValue</code> <code></interface-name></code> <code></get-interface-information></code>	show interface <i>interfaceValue</i> terse	NNI
		<code><get-ldp-session-information></code> <code></get-ldp-session-information></code>	show ldp session	Route
		<code><get-ospf-neighbor-information></code> <code></get-ospf-neighbor-information></code>	show ospf neighbor	Route
	BX7000 Gateway	Where: <i>interfaceValue</i> = Name of the interface		

Performing the Functional Audit

To perform a functional audit:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnel to view services based on protocols, and expand the **RSVP LSPs** tree to select an LSP service.
4. In the **Network Services > Tunnel** task pane, select **Audit Results > Functional Audit**. Alternatively, you can select a service order, click the **Audit** button at the top of the table of listed service orders from the Manage Network Services page and select **Run Functional Audit**.
5. In the **Schedule Functional Audit** dialog box, do one of the following:
 - a. Select **Audit Now**, then click **OK**.

The **Job Details** dialog box appears for you to click the Job ID link to see the functional results. The **Job Management** page displays the functional audit details by job ID, name, percentage complete, state, job type, summary, scheduled start time, user, and recurrence.

- b. Select **Audit Later**, enter a date and time, then click **OK**.

To monitor the progress of an audit after selecting **Audit Later**, after the scheduled time of the audit:

- a. On the Junos Space Network Management Platform user interface, select **Jobs**.
 - b. On the **Jobs** statistics page, select the **Functional Audit** segment of the Job Types pie chart.

The **Job Management** page appears filtered by functional audit jobs.

- c. Select the functional audit job that you want.

Summary information about the audit appears in the quick look panel.

- d. In the filter bar, select the table view icon to see additional information about the job. If the service failed the audit, information about the failure appears in the **Summary** field.

NOTE: Functional audit can be run for multiple services from Build mode of Service View of the Connectivity Services Director GUI. From the Manage Network Services page, select the check boxes beside multiple services, and click the **Audit/Results** button at the top of the table of configured services. When the **Audit/Results** button is clicked, the Schedule Functional Audit window is displayed, which enables you to perform the audit immediately or schedule it to be run at a later time. You can view detailed, ingrained information about the output of the functional audit that you performed for a service from the Functional Audit Results window. Select the **Service-name > Interface-name Device-name > Remote Interface - Remote Device** in the left pane of the window. The control plane and data plane statuses are displayed by running service-specific commands in the right pane of the window. Click **Rerun Functional Audit** at the top-right corner of the window to perform the audit again. If the Status field displays as Completed, an audit can be run again; else, if the Status field displays as Ongoing, it denotes that an audit is currently in progress, you must wait for the running instance to be completed to perform a functional evaluation again.

Click **Reload Result** at the top-right corner of the window to refresh the results of the audit and display the updated information. You can refresh the results only for completed audit instances. When you select Service-name in the left pane of the window, service status information is displayed in the right pane. The Service Status window displays details such as the operational status of the service, the device name, the topology used in the service are displayed in a tabular format. The number of UNI interfaces and PE devices that are up and down is also shown. When you select **Service-name > Interface-name Device-name > Remote Interface - Remote Device** in the left pane of the window, endpoint status information is shown in the right pane. The Endpoint Status window displays details of the device name, the topology used in service, remote UNIs status, and device status of the selected service.

The Service Status field corresponding to the service for which polled data is not available is displayed as NA. The Service Status field represents the overall status of a service. To calculate the overall service status, a polling mechanism is used to retrieve data from devices by Connectivity Services Director. Because the overall status of a service involves multiple devices, it is possible to calculate and update service statuses, based on an event from one of the devices because the status of all endpoints of a service needs to be determined to compute the overall service status. It is an expensive operation to send requests to all endpoints, based on an event from a single device. As a result, a polling method is used to obtain the overall status of the device. Because the polled data represents a snapshot at a point in time, a delay occurs in updating the status of a service. Also, while polling, if service information from one of the devices is not available, the service is marked as down.

6. To view additional details about the functional audit, including results from checking the control plane and the data plane, see *Viewing Functional Audit Results*.

RELATED DOCUMENTATION

[Performing a Configuration Audit | 1156](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Troubleshooting the Endpoints of Services | 1168](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Viewing Functional Audit Results for LSP Services

To view the results of a functional audit of a service, follow this procedure:

After performing a functional audit on a service, look at the functional audit results:

1. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.
2. Click the **Build** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. Click the plus sign (+) beside Tunnel to view services based on protocols, and expand the **LSPs** tree to select an LSP service.
4. In the **Network Services > Tunnel** task pane, select **Audit Results > Functional Audit**. Alternatively, you can select a service order, click the **Audit** button at the top of the table of listed service orders from the Manage Network Services page.

The **Functional Audit Results** window appears, displaying Service Status in the right panel.

A green up-arrow in the Service Status header bar indicates that the service has passed the functional audit in both the control plane and the data plane. A red down-arrow indicates that the service failed either or both the control plane validation and the data plane validation.





Depending on the type of service, the left panel lists

- The name of the service
- Each endpoint in the service

Icons representing the endpoint indicate its role in the service and its up or down state.

[Table 139 on page 1181](#) describes these icons for a service.



Table 254: Service Endpoint Icons

Icon	Meaning
	Hub in a point-to-multipoint service. Endpoint state is up.
	Hub in a point-to-multipoint service. Endpoint state is down.
	Spoke in a point-to-multipoint service. Endpoint state is up.
	Spoke in a point-to-multipoint service. Endpoint state is down.

- Interface name
 - Device name
- To show all endpoints in the service, in the left panel header, select **All**. To display only the endpoints indicating failed validation, select **Failed**. Failed is dimmed if the functional audit returned no validation errors.
 - To view details for an individual interface or endpoint, select it in the left panel. The header bar on the right panel changes to End Point or Interface Status, and details for the selected item are displayed below.
 - Expand each device to show the link from that device to the other N-PE device in the service.

An icon next to each link indicates whether the functional audit commands reported correct functioning of the control plane and data plane. [Table 140 on page 1181](#) describes these icons.

Table 255: Functional Audit Success Status Icons







Icon	Meaning
	Control plane and data plane function correctly.
	Errors were reported in the functioning of either the control plane or the data plane.

- In the left panel, select a link.

The panel to the right shows the validation results for the control plane validation and data plane validation for the selected link. Icons indicate the success or failure of each set of tests.

The panel to the right shows the validation results for the control plane validation and data plane validation for the selected link. Icons indicate the success or failure of each of these sets of tests. [Table 141 on page 1182](#) describes icons and the textual information provided in the box beside the icon.

Table 256: Control Plane and Data Plane Validation Icons



Icon	Meaning	Explanation
	Control plane up	The text box shows the name of the remote N-PE device and confirms that the data plane is operational.
	Control plane down	The text box shows the name of the configured remote N-PE device and, in the Command status field, explains why the test failed.
	Control plane status unknown	The text box indicates the name of the configured remote N-PE device and, in the Result field, an explanation as to why the functional audit operation was unable to test the control plane—for example, configuration was missing on the device.
	Data plane up	The text box indicates the number of packets transmitted and received, and confirms that no data packets were lost during the audit.
	Data plane down	The text box indicates that data packets were lost during the audit.
	Data plane status unknown	The functional audit was unable to complete the data plane test. The Result field in the text box indicates the reason—for example, the platform does not support data plane testing, or the connection to the remote N-PE device is down.

The control plane and data plane validation checks must both show operational status for the link to be considered operational.

- To troubleshoot a service, click the **Troubleshoot** button to open the **Troubleshooting** page. To select the status you want to check, click the device from the device list on the left, and select the show command from the **Command** list.

An icon next to each command indicates whether the command execution is successful or failed. [Table 257 on page 1845](#) describes these icons.

Table 257: Command Status Icons

Icon	Meaning
	Command execution is successful and the command status is up.
	<ul style="list-style-type: none">• Command execution is failed, or,• In case of multiple rows, one of the status value is down

NOTE:

- Junos OS Release 9.3 and Junos OS Release 9.4 do not support data plane validation. The Functional Audit Results screens do not display data plane validation information if any device in the service is running one of these Junos OS releases.

Examining the LSP Summary Details for Effective Troubleshooting

IN THIS SECTION

- [Operational Status | 1846](#)
- [Status Matrix | 1847](#)
- [LSP Information | 1847](#)
- [LSP Traffic | 1848](#)

The LSP Summary page provides a comprehensive and cohesive insight about the configured LSP service. The status of the LSP and the status of connections between the ingress router and egress routers in an LSP are displayed. The LSP status details are shown for the ingress router. You can also view the ingress, egress, and transit LSP information, such as the primary and secondary states. Ingress information is for the sessions that originate from this router, egress information is for sessions that terminate on this router, and transit information is for sessions that transit through this router. Extensive information about LSPs, including all past state history and the reasons why an LSP might have failed, can also be viewed. This page is beneficial to easily resolve RSVP failures in your network topology by quickly analyzing the LSP status and statistics.

NOTE: The refresh of values and statuses of the parameters displayed in the graphs and tables of different monitors depends on the polling interval configured under the Monitoring tab of the Preferences page (accessible by clicking the down arrow beside the System button in the Connectivity Services Director banner and selecting Preferences).

To view the LSP summary page:

1. Select **Service View** from the View Selector. The workspaces that are applicable to routing and tunnel services are displayed.
2. From the Junos Space user interface, click the **Monitor** icon in the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnel to view services based on protocols and expand the **LSPs** tree to select an LSP service.
5. Click the **LSP Summary** tab. The LSP Summary page is displayed.

This widget provides details on LSP configuration details and statistics of traffic transmitted over the LSP.

Operational Status

This monitor displays the working status of the LSP service. The following fields are displayed:

- **Name**—Name of the LSP service.
- **Status**—Operational status of the LSP service. A green up arrow indicates the LSP is up, and a red down arrow indicates the LSP is down.
- **Type**—Topology type of the LSP, such as point-to-point, point-to-multipoint, or full-mesh.
- **LSPs Count**—Total number of LSPs configured in the service that are in the up and down states.
- **BFD**—Total number of BFD packets transmitted over the LSP. BFD for RSVP supports unicast IPv4 LSPs. When BFD is configured for an RSVP LSP on the ingress router, it is enabled on the primary path and on all standby secondary paths for that LSP. The source IP address for outgoing BFD packets from the egress side of an MPLS BFD session is based on the outgoing interface IP address.

Status Matrix

This monitor shows the status of connections between the ingress router and egress routers in an LSP. In the tabular view, the egress router, the LSP name, and the LSP status are displayed. From the Ingress list, select the ingress router for the LSP topology. This field is automatically populated for point-to-multipoint LSP topology; you need to select it only for bidirectional P2P LSPs and full-mesh LSPs. From the Egress list, select the output router up to which the LSP runs from an ingress router. This field is applicable for P2P, point-to-multipoint, and full-mesh LSPs.

A green up-arrow in the LSP Status field indicates that the LSP to the destination device is operationally up. A red down-arrow in the LSP Status field indicates that the LSP is down. To filter and sort the display of LSPs, enter the name of the LSP as a match criterion in the Search box and click the Search icon. The page refreshes to display only the LSP names that match with the search term. You can use the paging controls to navigate across multiple pages of LSPs as necessary.

LSP Information

For a destination address that contains LSP names, the corresponding LSP details, such as the name, state, and bandwidth of the LSP, are displayed in this monitor. The following fields are displayed:

- Name— Name of the LSP
- State— State of the LSP handled by this RSVP session: Up, Dn (down), or Restart
- Bandwidth—Specifies the bandwidth in bits per second for the LSP.
- Primary State— State of the LSP that is a primary path: Up, Down, or Restart
- Secondary State— State of the LSP that is a secondary path: Up, Down, or Restart
- Received RRO—(Ingress LSP) Received record route. A series of hops, each with an address followed by a flag. (In most cases, the received record route is the same as the computed explicit route. If Received RRO is different from Computed ERO, there is a topology change in the network, and the route is taking a detour.) The following flags identify the protection capability and status of the downstream node:
 - 0x01—Local protection available. The link downstream from this node is protected by a local repair mechanism. This flag can be set only if the Local protection flag was set in the SESSION_ATTRIBUTE object of the corresponding Path message.
 - 0x02—Local protection in use. A local repair mechanism is in use to maintain this tunnel (usually because of an outage of the link it was routed over previously).
 - 0x03—Combination of 0x01 and 0x02.
 - 0x04—Bandwidth protection. The downstream routing device has a backup path providing the same bandwidth guarantee as the protected LSP for the protected section.
 - 0x08—Node protection. The downstream routing device has a backup path providing protection against link and node failure on the corresponding path section. If the downstream routing device can set up

only a link-protection backup path, the Local protection available bit is set but the Node protection bit is cleared.

- 0x09—Detour is established. Combination of 0x01 and 0x08.
- 0x10—Preemption pending. The preempting node sets this flag if a pending preemption is in progress for the traffic engine LSP. This flag indicates to the ingress legacy edge router (LER) of this LSP that it should be rerouted.
- 0xb—Detour is in use. Combination of 0x01, 0x02, and 0x08.
- Total Packets—Total number of packets and Total number of bytes transmitted over the LSP. This counter is reset to zero whenever the LSP path is optimized (for example, during an automatic bandwidth allocation).
- Total Bytes—Total number of bytes transmitted over the LSP. This counter is reset to zero whenever the LSP path is optimized (for example, during an automatic bandwidth allocation).

LSP Traffic

This monitor displays a line chart with the number of packets or bytes on the y-axis and time on the x-axis to denote the LSP bandwidth utilization. From the Time Interval drop-down box, select 1 Hour, 8 Hours, 1 Day, 1 Week, 1 Month, 3 Months, 6 Months, 1 Year, or Custom to specify the duration for which the data polled from devices needs to be displayed. If you select the Custom option, the Time range popup dialog box is displayed. Specify the date from the calendar, and select the Time From (Start time in the 24-hour time format of collection of data), and Time To (End time in the 24-hour time format of collection of data). Click OK to save the settings. Else, click Cancel to discard the configuration. From the Statistics Type drop-down list, select Packets or Bytes to display metrics corresponding to the selected parameter.

RELATED DOCUMENTATION

[Monitoring the Service Traffic Statistics of E-Line Services for Correlating Device Counters | 1268](#)

[Monitoring the Service Traffic Statistics of IP Services for Correlating Device Counters | 1274](#)

[Monitoring the Service Transport Details of E-Line Services for Easy Analysis | 1276](#)

[Monitoring the Service Transport Details of E-LAN Services for Easy Analysis | 1279](#)

[Monitoring the Service Transport Details of IP Services for Easy Analysis | 1282](#)

Troubleshooting the Endpoints of RSVP LSP Services

IN THIS SECTION

- [Troubleshooting Services Using Operational Scripts | 1851](#)

Junos OS operation (op) scripts automate network and device management and troubleshooting. Op scripts can perform any function available through the remote procedure calls (RPCs) supported by either the Junos XML management protocol or the Junos Extensible Markup Language (XML) API. Op scripts can be executed manually in the CLI or upon user login, or they can be called from another script. They are executed by the Junos OS management (mgd) process.

Op scripts enable you to do the following things:

- Create custom operational mode commands
- Execute a series of operational mode commands
- Customize the output of operational mode commands
- Shorten troubleshooting time by gathering operational information and iteratively narrowing down the cause of a network problem
- Perform controlled configuration changes
- Monitor the overall status of a device by creating a general operation script that periodically checks network warning parameters, such as high CPU usage.

Op scripts are based on the Junos XML management protocol, and the Junos XML API. Op scripts can be written in either the Extensible Stylesheet Language Transformations (XSLT) or Stylesheet Language Alternative Syntax (SLAX) scripting language. Op scripts use XPath to locate the operational objects to be inspected and XSLT constructs to specify the actions to perform on the located operational objects. The actions can change the output or execute additional commands based on the output.

The troubleshooting feature provides an easy and unique way to troubleshoot the services. You do not have to manually login to a device to check the status of services in the Connectivity Services Director application, but you can do the same using the functionality of operational scripts. You do have the flexibility of writing your own scripts to view the results.

Only Juniper Networks devices are supported by this functionality and this is not applicable to the third-party devices.

The operational scripts can either be created or imported to the platform from the local machine before you start troubleshooting the services or you can run the scripts that are of local type directly from the

Functional Audit Result window by clicking the **Troubleshoot** button. For op scripts that are not of local type, the op scripts must be imported and staged on to the device using the Junos Space Network Management Platform application before you can run the scripts from within the Connectivity Services Director application for debugging and diagnosing the service endpoints or devices. Currently, you cannot directly add the scripts to the Connectivity Services Director GUI interface. Scripts with execution type as "Local" (@isLocal=true annotation in the SLAX script) are also listed in troubleshooting window. The listing is sorted and filtered based on the context specified for each service.

BEST PRACTICE: We recommend that you configure a script as a local script for effective and optimal debugging and analysis of the configuration settings contained in the script. The main advantage of a local script is that you need not download the script to a device (because a connection is established with the device by the GUI application and the script is run) and you need not remove the script from a device after you decommission a service.

The following table lists the context in which the OP scripts are written for different types of services:

Table 258: OP Scripts Contexts for RSVP LSP Services

Service Type	Context
RSVP LSP LDP	@CONTEXT = "/device/configuration/protocols/mpls/lsp" Example : /device[name="deviceName"]/configuration/protocols/l2circuit/mpls/lsp[name="LSP name"]
Common context for all services	/* @CONTEXT = "/device/configuration/interface/" */ Example: /device[name="device name"]/configuration/ interface[name="interfaceName.unitID"] Example commands:

When you select a single service and from the Network Services > Connectivity task pane, select **Audit Results > Functional Audit** to schedule and perform a functional audit operation, the Functional Audit Results window is displayed after the operation of the selected service is validated. If you have previously run a functional audit already run, the result of the previous audit is displayed. To perform a troubleshooting of the selected service, you must click the **Troubleshoot** button. The troubleshooting task runs as a separate event in Connectivity Services Director.

Troubleshooting Services Using Operational Scripts

The operational scripts or the OP scripts are written to view the statistics of a service in the Connectivity Services Director application. All the commands in the OP scripts are user-defined. To view the contexts for writing OP scripts for different service types, refer [Table 138 on page 1170](#).

To execute the OP scripts and view the status of any service:

1. From the **Network Management Platform** task pane, select **Images and Scripts > Scripts**.

The **Scripts** page that appears displays a list of the existing scripts.

2. From the list of the scripts available in the SLAX format, right-click a script and click **Stage Scripts on Devices** to push the script onto a device.

The **Stage Scripts on Device(s)** page that appears displays a list of the devices associated with the script that you selected.

3. Select the **Select Device Manually** option and select any number of devices to which you want to push the script.

NOTE: The **Enable Scripts on Devices** check box is selected by default.

4. Click **Stage** to stage the script on all the devices that you selected.

The **Stage Scripts Information** dialog box confirms the successful staging of scripts onto the selected devices along with the **Job ID**.

5. Click **Job ID** to view the status of the job on the **Job Management** page.

You are redirected to the **Scripts** page.

6. From the View selector, select **Service View**. The workspaces that are applicable to routing and tunnel services are displayed.

7. Click the **Deploy** icon in the Service View of the Connectivity Services Director banner. The functionalities that you can configure in this mode are displayed in the task pane.

8. Click the plus sign (+) beside Tunnel to view services based on protocols, and expand the **LSPs** tree to select an LSP service.

9. In the **Network Services > Tunnel** task pane, select **Audit Results > Functional Audit**. Alternatively, you can select a service order, click the **Audit** button at the top of the table of listed service orders from the Manage Network Services page.

10. In the Schedule Functional Audit dialog box, select **Audit Now**, then click **OK**. After the audit is run, the Functional Audit Results window is displayed.

11. From the Functional Audit Results window that displays a list of the devices associated with the service you selected, select the check box next to the device for which you want to diagnose and examine the associated service.
12. Click **Troubleshoot** to perform troubleshooting and analysis of the service for which functional audit is performed.
13. Select the check box next to a service that you want to analyze and monitor for its working and efficiency. The Execute OP Scripts page is displayed.
14. Select an OP script on the **Execute OP Scripts** page.
15. Click the **Value** column to enter any additional parameter for the selected OP script, besides the ones coded in the script.

NOTE: The selection of parameters is entirely dependent on the OP scripts. If the OP scripts support parameters, then all the parameters are listed and you need to enter the values. Parameters can be optional, on the basis of the OP scripts.

16. Click **Execute** to execute the selected OP scripts with the newly added parameters, if any.
A dialog box confirms the execution of the OP scripts along with the **Job ID**.
17. Click **OK**.
You are redirected to the **Execute OP Scripts** page.
18. Click **View Last Result** to view the previous OP scripts execution results.

NOTE: This is an optional step.

RELATED DOCUMENTATION

[Performing a Functional Audit | 1145](#)

[Performing a Configuration Audit | 1156](#)

[Troubleshooting N-PE Devices Before Provisioning a Service | 1158](#)

[Modifying the Application Settings of Connectivity Services Director | 1161](#)

[Viewing Configuration Audit Results | 1177](#)

[Viewing Functional Audit Results | 1180](#)

[Viewing Functional Audit Results for an Inverse Multiplexing for ATM Service | 1184](#)

Clearing LSP Statistics

When you clear LSP statistics on a device using Connectivity Services Director, the operation releases the routes and states associated with MPLS label-switched paths (LSPs), and starts new LSPs. This GUI operation is equivalent to entering the **clear mpls lsp** command on a device using the Junos OS CLI interface. This command disconnects existing Resource Reservation Protocol (RSVP) sessions on the ingress routing device. If there is a time lag between the old path being torn down and the new path being set up, this command might impact traffic traveling along the LSPs.

To clear the label-switched path (LSP) statistical details for an LSP service:

1. From the View selector, select Service View. The functionalities that you can configure in this view are displayed.
2. Click the Monitor mode icon in the Service View of the Connectivity Services Director banner. The workspaces that are applicable to this mode are displayed.
3. From the Service View pane, click the plus sign (+) beside the **Network Services > Tunnel > LSPs** tree and select the service for which you want to reset the LSP statistics. The service statistical details are displayed in the middle pane.
4. From the task pane, which is displayed on the rightmost pane, select **Tasks > Clear LSP Statistics**. The Clear LSP Statistics task enables you to delete all the LSP statistics associated with the selected service. A dialog box appears, prompting you to confirm the deletion. The device name and LSPs associated with the device are displayed. In this dialog box, you can also choose to delete the LSP statistics on devices.
5. Select the **Clear LSP Statistics from Devices** check box to clear the statistics from devices. This operation is equivalent to the **clear mpls lsp** command that you can run from the Junos OS CLI interface. If you select the **Clear LSP Statistics from Devices** check box, the statistics are cleared on the device for all the LSPs in the service, in addition to being removed from the Connectivity Services director database. Otherwise, the LSP statistics are only reset in the application database and not on the device.
6. Click OK to confirm; alternatively, click Cancel to discard this operation.

RELATED DOCUMENTATION

[Viewing MAC Table Details | 1294](#)

[Viewing Interface Statistics | 1295](#)

[Viewing Interface Status Details | 1297](#)

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

[Routing Table Overview | 1308](#)

Monitoring Network Reachability by Using the MPLS Traceroute Capability

You can perform a traceroute operation to examine the network reachability and identify connection failures from a source or ingress host to a remote host for an MPLS LSP signaled by RSVP. It a debugging tool to locate MPLS label-switched path (LSP) forwarding issues in a network. (Currently supported for IPv4 packets only.)

1. From the View selector, select **Service View**.

The functionalities that you can configure in this view are displayed.

2. Click the **Monitor** mode icon in the Service View of the Connectivity Services Director banner.

The workspaces that are applicable to this mode are displayed.

3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.

4. Click the plus sign (+) beside Tunnels > LSPs, and select the RSVP service for which you want to run the traceroute utility.

5. From the task pane, select MPLS Traceroute.

The MPLS Traceroute Service Type - Service Name window appears.

6. In the Endpoint Device section, do the following:

- a. From the Ingress Device list, select the ingress device of the LSP, whose IP address to be used as the packet source address. The local router always is considered to be the ingress router, which is the beginning of the LSP. The software automatically determines the proper outgoing interface and IP address to use to reach the next router in an LSP.
- b. From the Egress Device list, select the egress device that is connected using the LSP from the ingress LSP, whose IP address is used of the target for the MPLS traceroute packets.

The name of the LSP is displayed in the LSP Name field.

7. On the Advance Options list, do the following:
 - a. In the Probe Retries field, specify the number of times to resend probe. The range of values is 1 through 9. The default value is 3.
 - b. In the Hop Limit field, specify the maximum number of routers that an LSP can traverse. The configured hop limit includes the ingress and egress routers. You can specify a hop limit for an LSP and for both primary and secondary paths. By default, each LSP can traverse a maximum of 255 hops, including the ingress and egress routers. The number of hops can be from 2 through 255. (A path with two hops consists of the ingress and egress routers only.)
 - c. In the Class of Service field, specify the class-of-service (CoS) value given to all packets in the LSP. The CoS value might affect the scheduling or queuing algorithm of traffic traveling along an LSP. A higher value typically corresponds to a higher level of service. The range is from 1 through 7. If you do not specify a CoS value, the IP precedence bits from the packet's IP header are used as the packet's CoS value
8. In the Format list, select **XML** to display the result or the response of the MPLS traceroute operation in XML format. Alternatively, select **ASCII** to display the output in the format in which it is displayed on the CLI. The Junos XML API is an XML representation of Junos configuration statements and operational mode commands. Junos XML configuration tag elements are the contents to which the Junos XML protocol operations apply. Junos XML operational tag elements are equivalent in function to operational mode commands in the CLI, which administrators use to retrieve status information for a device.
9. Click **Traceroute** to start the traceroute application and to send the MPLS traceroute requests from the source to the destination device.

The results of the traceroute operation are displayed in the Response Console pane at the bottom of the MPLS Traceroute Service Type - Service Name window.

RELATED DOCUMENTATION

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)

Monitoring Network Reachability by Using the MPLS Ping Capability for RSVP LSPs

In IP networks, you can use the ping and traceroute commands to verify network connectivity and find broken links or loops. In an MPLS-enabled network, you can use the mpls ping and trace mpls commands to detect plane failures in different types of MPLS applications and network topologies.

1. From the View selector, select **Service View**. The functionalities that you can configure in this view are displayed.
2. Click the **Monitor** mode icon in the Service View of the Connectivity Services Director banner. The workspaces that are applicable to this mode are displayed.
3. From the Service View pane, which is the left pane in the window, click the plus sign (+) next to Network Services to expand the tree and display the different service types that you can configure.
4. Click the plus sign (+) beside Tunnels > LSPs, and select the service for which you want to run the ping application.
5. From the task pane, select MPLS Ping. The MPLS Ping Service Type - Service Name window appears.

NOTE: A warning message is displayed in the window stating that the MPLS echo request to the device might be timed out if the response is delayed from the device.

6. In the Endpoint Device section, do the following:
 - a. From the Ingress Device list, select the source device, whose IP address is to be used as the packet source address.
 - b. From the Egress Device list, select the target endpoint, which IP address of the target for the MPLS ping packets or echo requests. The source device sends an MPLS echo request packet to the specified IP or IPv6 address or, alternatively, sends MPLS echo packets to the egress node in a point-to-multipoint LSP. The MPLS echo request packets and echo reply packets created by this command use the LDP IPv4 LSP sub-TLV described in RFC 4379—Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures (February 2006).
7. On the Advance Options list, do the following:

- a. In the Ping count (packets) field, enter the number of packets to send to the destination address, in the range 0–4294967295. The default value is 5 and 0 (zero) means ping forever.
 - b. In the Ping size (bytes) field, specify the number of bytes comprising the MPLS packet, including the header, in the range 0–64000. The default value is 100 bytes.
 - c. In the Forwarding Class field, specify the value of the forwarding class for the MPLS ping packets.
 - d. In the Sweep field, configure the payload size, which enables you to vary the sizes of the echo packets being sent. This capability is useful for determining the minimum sizes of the MTUs configured on the nodes along the path to the destination address. This reduces packet fragmentation, which contributes to performance problems. The default is not to sweep; all packets are of the same size.
 - e. From the Reply Mode field, select the reply mode for the echo request packet:
 - **IP-UDP**—Specifies that the echo request packet is an IPv4 UDP packet
 - **Application Level Control Channel**—Specifies that the echo request packet is replied using the application-level control channel connection.
8. From the Format list, select **XML** to display the result or the response of the MPLS ping operation in XML format. Alternatively, select **ASCII** to display the output in the format in which it is displayed on the CLI. The Junos XML API is an XML representation of Junos configuration statements and operational mode commands. Junos XML configuration tag elements are the contents to which the Junos XML protocol operations apply. Junos XML operational tag elements are equivalent in function to operational mode commands on the CLI, which administrators use to retrieve status information for a device.
9. Click **Ping** to start the ping operation and to send the MPLS echo requests from the source to the destination device.

The results of the ping operation are displayed in the Response Console pane at the bottom of the MPLS Ping Service Type - Service Name window.

RELATED DOCUMENTATION

[MPLS Connectivity Verification and Troubleshooting Methods | 1299](#)

[Using MPLS Ping | 1300](#)

[Pinging VPNs, VPLS, and Layer 2 Circuits | 1303](#)

[Monitoring Network Reachability by Using the MPLS Ping Capability | 1304](#)

[Monitoring Network Reachability by Using the Layer 3 VPN Ping Capability | 1306](#)