

## CTP2000 4W-EM Interface Connector Pinouts

- CTP2000 4W&EM RTM Connector A Pinouts on page 1
- CTP2000 4W&EM Connector B Pinouts on page 2

### CTP2000 4W&EM RTM Connector A Pinouts

See Table 1 for connector A pinout information. See CTP2000 4W&EM Interface Module for signal definitions.

**Table 1: CTP2000 4W&EM RTM Pinouts—Connector A**

Connector A			
Pin	Signal	Signal	Pin
1	Port 0 R	Port 0 T	26
2	Port 0 R1	Port 0 T1	27
3	Port 0 SG	Port 0 E	28
4	Port 0 SB	Port 0 M	29
5	Port 1 R	Port 1 T	30
6	Port 2 R1	Port 1 T1	31
7	Port 2 SG	Port 1 E	32
8	Port 2 SB	Port 1 M	33
9	Port 2 R	Port 2 T	34
10	Port 2 R1	Port 2 T1	35
11	Port 2 SG	Port 2 E	36
12	Port 2 SB	Port 2M	37
13	Port 3 R	Port 3 T	38
14	Port 3 R1	Port 3 T1	39
15	Port 3 SG	Port 3 E	40
16	Port 3 SB	Port 3 M	41
25	GND	GND	50

## CTP2000 4W&EM Connector B Pinouts

See Table 2 for connector B pinout information. See CTP2000 4W&EM Interface Module for signal definitions.

**Table 2: CTP2000 4W&EM RTM Pinouts—Connector B**

Connector B			
PIN	Signal	Signal	PIN
1	Port 4 R	Port 4 T	26
2	Port 4 R1	Port 4 T1	27
3	Port 4 SG	Port 4 E	28
4	Port 4 SB	Port 4 M	29
5	Port 5 R	Port 5 T	30
6	Port 5 R1	Port 5 T1	31
7	Port 5 SG	Port 5 E	32
8	Port 5 SB	Port 5 M	33
9	Port 6 R	Port 6 T	34
10	Port 6 R1	Port 6 T1	35
11	Port 6 SG	Port 6 E	36
12	Port 6 SB	Port 6M	37
13	Port 7 R	Port 7 T	38
14	Port 7 R1	Port 7 T1	39
15	Port 7 SG	Port 7 E	40
16	Port 7 SB	Port 7 M	41
25	GND	GND	50

- Related Topics**
- CTP2000 4W&EM Interface Module
  - CTP2000 FXS and FXO Interface Module Cables and Pinouts
  - CTP2000 Series Console Cable Pinouts

---

Published: 2010-05-11