

CTP2000 Modules Installation Overview

In CTP2000 platforms, you can install interface modules in the front and rear of the device. CTP2000 rear transition modules (RTMs) reside in the rear of the device.

- Related Topics**
- Protecting CTP2000 Modules and Slots
 - Required Tools and Safety Items for Installing CTP Modules
 - Safety Guidelines and Warnings for Installing CTP Modules
 - Installing a CTP Interface Module, Processor Module, or Clock Module
 - Installing or Removing a CTP2000 Series CompactFlash Card
 - Installing a PMC on CTP2000 Platforms
 - Installing SFPs in a CTP2000 Module

Published: 2010-05-11