

## CTP150 Hot-Swap Interface Module Replacement

---

You can now replace the following modules on the CTP150 device without powering down the device (hot-swap);

- CTP150 4-port serial interface module (CTP150-IM-SER)
- CTP150 4-port T1E1 interface module (CTP150-IM-T1E1)

Before performing a hot-swap, be aware of the following restrictions:

- Hot-swapping works most efficiently when your interface module is the same type as the module being replaced. If your replacement interface module is a different type, you must clean up the database information for the affected slot by deleting all bundles attached to the interface module.
- You can use hot-swapping only to replace an interface module; you cannot use hot-swap to add an interface module to an empty slot.
- Hot-swapping is not supported on slot 0 because the clock distributor uses slot 0.
- For best results, close all open menu sessions before performing a hot-swap



**NOTE:** There may be a brief traffic interruption when you replace an interface module using hot-swap.

---

To perform hot-swapping:

1. From the Main Menu, select **4) Node Diagnostics**.
2. Select **8) Card Swap menu**.
3. Select **1) remove**. You are prompted to enter a slot number.
4. Enter **1**. The following message is displayed: **It is now safe to remove the card from the system!**
5. Remove the interface module from the slot.
6. Plug the replacement interface module into the slot.
7. Press Enter.
8. Select **8) Card Swap menu**.
9. Select **2) add**. You are prompted to enter a slot number.
10. Enter **1**. The following message is displayed: **Please make sure the card is already physically inserted.**
11. Press Enter. The following message is displayed: **Card is inserted and the database is populated to the card!**
12. Quit the current menu session before resuming work by opening a new menu session.

- Related Topics**
- CTP150 Serial Interface Module
  - CTP150 T1/E1 Interface Module

---

Published: 2010-05-13