

CTP1000 Platform SSH Setup

When you have configured an IP address for the CTP1000 device, you can run SSH from a host to access the device through its Ethernet port. To connect the Ethernet port to the network:

1. Connect an Ethernet RJ-45 cable to one of the two Ethernet ports on the rear panel of the CTP1000 chassis.
2. Connect the other end of the cable to the appropriate Ethernet network for an out-of-band connection.



CAUTION: Do not change the IP address for the Ethernet interface that you are using to communicate with the device. If you change the address, you will lose the SSH session.

- Related Topics**
- [Setting Up Management Access on the CTP1000 Platform](#)
 - [CTP1000 Console Port Setup](#)
 - [Using HyperTerminal with the CTP1000 Platform](#)
 - [Connecting Directly to the CTP1000 Platform](#)

Published: 2010-05-11