



Juniper Networks CTP2000 Circuit to Packet Platform

Upgrade to CTPOS 6.x



Published: 2011-01-25

Juniper Networks, Inc.
1194 North Mathilda Avenue
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Copyright © 2011, Juniper Networks, Inc. All rights reserved.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

Upgrade to CTPOS 6.x

Copyright © 2011, Juniper Networks, Inc.
All rights reserved. Printed in USA.

Revision History

January 2011—Revision 1;

The information in this document is current as of the date listed in the revision history.

END USER LICENSE AGREEMENT

READ THIS END USER LICENSE AGREEMENT (“AGREEMENT”) BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE. BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. **The Parties.** The parties to this Agreement are (i) Juniper Networks, Inc. (if the Customer’s principal office is located in the Americas) or Juniper Networks (Cayman) Limited (if the Customer’s principal office is located outside the Americas) (such applicable entity being referred to herein as “Juniper”), and (ii) the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software (“Customer”) (collectively, the “Parties”).

2. **The Software.** In this Agreement, “Software” means the program modules and features of the Juniper or Juniper-supplied software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller, or which was embedded by Juniper in equipment which Customer purchased from Juniper or an authorized Juniper reseller. “Software” also includes updates, upgrades and new releases of such software. “Embedded Software” means Software which Juniper has embedded in or loaded onto the Juniper equipment and any updates, upgrades, additions or replacements which are subsequently embedded in or loaded onto the equipment.

3. **License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

a. Customer shall use Embedded Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller.

b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees; provided, however, with respect to the Steel-Belted Radius or Odyssey Access Client software only, Customer shall use such Software on a single computer containing a single physical random access memory space and containing any number of processors. Use of the Steel-Belted Radius or IMS AAA software on multiple computers or virtual machines (e.g., Solaris zones) requires multiple licenses, regardless of whether such computers or virtualizations are physically contained on a single chassis.

c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer’s use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, realms, devices, links, ports or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. In addition, such limits may restrict the use of the Software to managing certain kinds of networks or require the Software to be used only in conjunction with other specific Software. Customer’s use of the Software shall be subject to all such limitations and purchase of all applicable licenses.

d. For any trial copy of the Software, Customer’s right to use the Software expires 30 days after download, installation or use of the Software. Customer may operate the Software after the 30-day trial period only if Customer pays for a license to do so. Customer may not extend or create an additional trial period by re-installing the Software after the 30-day trial period.

e. The Global Enterprise Edition of the Steel-Belted Radius software may be used by Customer only to manage access to Customer’s enterprise network. Specifically, service provider customers are expressly prohibited from using the Global Enterprise Edition of the Steel-Belted Radius software to support any commercial network access services.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. **Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any ‘locked’ or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the

Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use Embedded Software on non-Juniper equipment; (j) use Embedded Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. **Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. **Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. **Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. **Warranty, Limitation of Liability, Disclaimer of Warranty.** The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. **Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. **Taxes.** All license fees payable under this agreement are exclusive of tax. Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software. If applicable, valid exemption documentation for each taxing jurisdiction shall be provided to Juniper prior to invoicing, and Customer shall promptly notify Juniper if their exemption is revoked or modified. All payments made by Customer shall be net of any applicable withholding tax. Customer will provide reasonable assistance to Juniper in connection with such withholding taxes by promptly: providing Juniper with valid tax receipts and other required documentation showing Customer's payment of any withholding taxes; completing appropriate applications that would reduce the amount of withholding tax to be paid; and notifying and assisting Juniper in any audit or tax proceeding related to transactions hereunder. Customer shall comply with all applicable tax laws and regulations, and Customer will promptly pay or reimburse Juniper for all costs and damages related to any liability incurred by Juniper as a result of Customer's non-compliance or delay with its responsibilities herein. Customer's obligations under this Section shall survive termination or expiration of this Agreement.

11. **Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. **Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14 (ALT III) as applicable.

13. **Interface Information.** To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. **Third Party Software.** Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License ("GPL") or the GNU Library General Public License ("LGPL")), Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. **Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).

Table of Contents

Chapter 1	Introduction to CTPOS 6.x Upgrade Kits	1
	CTPOS 6.x Upgrade Kits	1
	PP310 Upgrade Kit - CTP2000-RAM-RTM-UPG	2
	PP332 Upgrade Kit - CTP2000-RAM-UPG	2
Chapter 2	Upgrading the CTP2000 Series Device to CTPOS 6.x	3
	Updating the Upgrade CompactFlash Card	3
	Upgrading with the PP310 Upgrade Kit	3
	Upgrading with the PP332 Upgrade Kit	5
	Using the Upgrade CompactFlash Card	6
	Migrating from a Previous Operating System	7
	Preparing a System for Firstboot Using CTPOS 6.x	10
	Registering Your Upgrade	12
	Related Procedures	12
	Servicing the CTP2000 CPU	13
	Installing or Replacing CTP2000 DRAM Memory Modules in the PP310 or PP332 CPU	13
	Restoring BIOS Defaults for the CTPOS 6.x Upgrade (PP310)	15
	Installing or Removing a CTP2000 Series CompactFlash Card	16

List of Figures

Chapter 1	Introduction to CTPOS 6.x Upgrade Kits	1
	Figure 1: PP310 CPU	1
	Figure 2: PP332 CPU	1
Chapter 2	Upgrading the CTP2000 Series Device to CTPOS 6.x	3
	Figure 3: RTM Default Jumper Settings	4
	Figure 4: CompactFlash Adapter with CompactFlash Card Inserted	8
	Figure 5: DRAM Memory Module Replacement — PP310	14
	Figure 6: Jumper Setting for Restoring BIOS Defaults	15
	Figure 7: CompactFlash on the RTM	16

Introduction to CTPOS 6.x Upgrade Kits

- CTPOS 6.x Upgrade Kits on page 1

CTPOS 6.x Upgrade Kits

Because of the new features and hardware supported in CTPOS 6.x, a direct code upgrade by means of an upgrade archive from earlier versions of CTPOS is not supported. This topic includes the procedures for performing an upgrade using an upgrade kit and for registering the upgrade.

There are two upgrade kits, the use of which depends on whether you are using a PP310 or PP332 processor in your CTP2000 series device:

- Figure 1 on page 1 shows the front of the CPU that contains the PP310 processor.
- Figure 2 on page 1 shows the front of the CPU that contains the PP332 processor.

Figure 1: PP310 CPU





Figure 2: PP332 CPU



g015420



NOTE: You must register your upgrade and validate it with Juniper Networks. If your upgrade kit includes a new RTM, you must also register the RTM. After you register the upgrade and, if included, the RTM, allow up to 45 days for restocking of the new hardware configuration to support any Next Day or Same Day contracts. Juniper Networks will provide Best Effort support until restocking of the converted product is complete. After the registration process is completed and the new configuration is updated in the depot, you will have access to the software and tools that support your device.



NOTE: The use of the upgrade kit is supported only on CTP2000 Series products.



CAUTION: You cannot use CTPView to perform a system save of a node running a version of CTPOS before 6.x and restore the system to a node running 6.x. CTPView cannot be used to migrate from pre-6.x to 6.x. *System save/restore between different CTPOS versions is not supported.*

PP310 Upgrade Kit - CTP2000-RAM-RTM-UPG

The PP310 upgrade kit contains:

- 4-GB CTPOS 6.0R1 upgrade CompactFlash card
- USB to CompactFlash adapter
- 1-GB non-ECC RAM module
- Rear transition module (RTM)
- Jumper (for BIOS reset)

PP332 Upgrade Kit - CTP2000-RAM-UPG

The PP332 upgrade kit contains:

- 4-GB CTPOS 6.0R1 upgrade CompactFlash card
- USB to CompactFlash adapter
- 1-GB ECC RAM module



NOTE: The 4-GB upgrade CompactFlash card and USB to CompactFlash adapters are the same in both kits. Whereas the PP310 and PP332 use the same model RTM after you complete the upgrade, the RTMs are jumpered differently for the two processors. Switching RTMs from a PP310 to a PP332 or vice versa without changing the jumper settings can damage the CPU.

CHAPTER 2

Upgrading the CTP2000 Series Device to CTPOS 6.x

This topic describes the following upgrade procedures. Follow proper antistatic procedures throughout:

- Updating the Upgrade CompactFlash Card on page 3
- Upgrading with the PP310 Upgrade Kit on page 3
- Upgrading with the PP332 Upgrade Kit on page 5
- Using the Upgrade CompactFlash Card on page 6
- Registering Your Upgrade on page 12
- Related Procedures on page 12


Updating the Upgrade CompactFlash Card

The CompactFlash card that is shipped with the upgrade kits may contain either CTPOS 6.0R1 or CTPOS 6.1x. If the CompactFlash card contains CTPOS 6.0R1, and you wish to upgrade directly to CTPOS 6.1x, you need to reburn the CompactFlash card with the CTPOS 6.1x code before you perform the upgrade.

Upgrading with the PP310 Upgrade Kit

1. Power down the system through either the menu or CTPView.
2. Remove the power cord.
3. Remove the RTM from the chassis and remove the old CompactFlash card from the RTM. See “Installing or Removing a CTP2000 Series CompactFlash Card” on page 16.
4. Confirm that the jumper settings on the new RTM provided in the upgrade kit conform to PP310 jumper settings, as shown in Figure 3 on page 4.

Figure 3: RTM Default Jumper Settings



5. Confirm that Ethernet dip switches SW1 and SW2 are set to ON, and that SW3 and SW 4 are set to OFF (see Figure 3 on page 4).
6. Install the 4-GB CompactFlash card from the upgrade kit in the new RTM and install the new RTM in the chassis. See "Installing or Removing a CTP2000 Series CompactFlash Card" on page 16.
7. Attach a terminal server or similar device to the serial console port, COM2, on the RTM. This device will be used to interact with the script that runs when the upgrade CompactFlash card is booted.
8. Remove the CPU card from the chassis, and replace the memory module on the CPU card with that from the upgrade kit. Install the memory module shipped with the kit only after you have finished these tasks. See "Installing or Replacing CTP2000 DRAM Memory Modules in the PP310 or PP332 CPU" on page 13 and Upgrading CTP2000 Series Components for Memory Upgrades.
9. Reset the BIOS to factory defaults. See "Restoring BIOS Defaults for the CTPOS 6.x Upgrade (PP310)" on page 15.
10. Reconnect all Ethernet cables.

11. Replace the power cord.
12. Power on the system and follow the procedure “Using the Upgrade CompactFlash Card” on page 6 to respond to the instructions that appear on the serial console. You have the option of saving information from a prior release of the operating system or setting the device for firstboot with CTPOS 6.0R1.



NOTE: The system may go through multiple reboots during this process. The BIOS, FPGAs, and the firmware on the cards may be updated. If the power is removed during these upgrades, the cards may become unusable. Please ensure that the process continues until completion. Failure to do so may render the system unusable.

Upgrading with the PP332 Upgrade Kit

1. Power down the system through either the menu or CTPView.
2. Remove the power cord.
3. Remove the RTM from the chassis and remove the old CompactFlash card from the RTM. See “Installing or Removing a CTP2000 Series CompactFlash Card” on page 16.
4. Install the 4-GB compact flash from the upgrade kit in the RTM and reinstall the RTM in the chassis. See “Installing or Removing a CTP2000 Series CompactFlash Card” on page 16.
5. Attach a terminal server or similar device to the serial console port, COM2, on the RTM. This device will be used to interact with the script that runs when the upgrade CompactFlash card is booted.
6. Remove the CPU card from the chassis, and replace the memory module on the CPU card with that from the upgrade kit. Install the memory module shipped with the kit only after you have finished these tasks. Reinstall the CPU module in the chassis when finished. See “Installing or Replacing CTP2000 DRAM Memory Modules in the PP310 or PP332 CPU” on page 13 and Upgrading CTP2000 Series Components for Memory Upgrades.
7. Reconnect all Ethernet cables.
8. Replace the power cord.
9. Power on the system and follow the procedure “Using the Upgrade CompactFlash Card” on page 6 to respond to the instructions that appear on the serial console.



NOTE: The system may go through multiple reboots during this process. The BIOS, FPGAs, and the firmware on the cards may be updated. If the power is removed during these upgrades, the cards may become unusable. Please ensure that the process continues until completion. Failure to do so may render the system unusable.

Using the Upgrade CompactFlash Card

The 4-GB CompactFlash script shipped in the upgrade kit can be used to either (1) migrate a system running a previous operating system to CTPOS 6.x, or (2) prepare a system for firstboot in CTPOS 6.x.

The CompactFlash script runs an application that checks for the proper BIOS and upgrades the BIOS if necessary. The application checks for proper FPGAs on the cards and daughter cards installed and upgrades them as necessary.

When used to prepare a system for firstboot into CTPOS 6.x, all cards and daughter cards intended to be run on the system should be installed before booting the flash for the first time.

If the system is migrating from an old CompactFlash card running CTPOS 4.6R7 or 5.4R3 through 5.4R6, the application transfers all necessary information from the old CompactFlash card to the new CompactFlash card and leaves the system in a state with all configured and activated circuits running.

Use one of the following procedures after completing either “Upgrading with the PP310 Upgrade Kit” on page 3 or “Upgrading with the PP332 Upgrade Kit” on page 5.

- Migrating from a Previous Operating System on page 7
- Preparing a System for Firstboot Using CTPOS 6.x on page 10

Migrating from a Previous Operating System

You should see the following upgrade script output when you complete the steps described in “Upgrading with the PP310 Upgrade Kit” on page 3. The upgrade script output produced when you complete the steps described in “Upgrading with the PP332 Upgrade Kit” on page 5 is very similar, and you must respond to the same prompts.

```
Gathering system information.  
* Please wait this could take up to 45 seconds.  
Found:  
System type      PP310  
Bios             2.21  
Memory installed 1024 MB  
Slot 0:  Type T1E1  
          FPGA 0xea * needs 0xea  
Slot 1:  Type Serial  
          FPGA 0x73  
Slot 2:  Type FXS  
          FPGA 0x5010150  
ID restored     No
```

Hit return to continue...

This application will prepare the installed hardware for CTPOS 6.0R1. It will upgrade FPGAs if necessary, upgrade the bios if necessary, and can migrate the ID of a system running CTPOS 4.6R7 or 5.4R3.

This application will reboot the system multiple times. Please continue the process through to completion. Failure to do so can leave the system in an unknown state.

Hit return to continue...

The bios configuration needs to be changed.
Hit return to setup the bios configuration and reboot.



NOTE: The set and reboot for the BIOS appears only for the PP310 processor.

1. Press Enter. For the PP310, the BIOS configuration is updated and the device reboots. The following upgrade script output is displayed for the PP310. The upgrade script output for the PP332 is very similar, and you must respond to the same prompts.

```
Gathering system information.
* Please wait this could take up to 45 seconds.
```

```
Found:
System type      PP310
Bios             2.21
Memory installed 1024 MB
Slot 0:  Type T1E1
             FPGA 0xea * needs 0xea
Slot 1:  Type Serial
             FPGA 0x73
Slot 2:  Type FXS
             FPGA 0x5010150
ID restored     No
```

```
Hit return to continue...
```

```
Do you want to restore the ID from a CTPOS 4.6R7 or 5.4R3 system?
```


2. Enter y. The following output is displayed:

```
Please insert the old flash into the compact flash to USB
adapter and plug the adapter into the usb slot on the CPU.
```

```
Hit return when you are finished.
```

3. Insert the old (256 MB) CompactFlash card into the CompactFlash adapter (see Figure 4 on page 8).

Figure 4: CompactFlash Adapter with CompactFlash Card Inserted



4. Connect the adapter to the CTP2000 USB port.
5. Press Enter to indicate that you are finished inserting the CompactFlash card into the adapter and connecting the adapter. Follow the onscreen instructions.

```
Got old CTPOS version: 4.6R7
```

```
Gathering old system information.
```

```
Please remove the old flash, hit return when finished.
```

```
Migrating system ID to new flash.
```

```
* The system will reboot when finished.
```

```
INIT: Sending processes the TERM signal
```

```
Gathering system information.
* Please wait this could take up to 45 seconds.
Found:
System type      PP310
Bios             2.21
Memory installed 1024 MB
Slot 0:  Type T1E1
           FPGA 0xea * needs 0xea
Slot 1:  Type Serial
           FPGA 0x73
Slot 2:  Type FXS
           FPGA 0x5010150
ID restored Yes

Hit return to continue...
Restarting syslog.

. done.
Upgrading T1E1 card in slot 0 to FPGA rev 0xea.

Upgrading FPGA on card 0. Please wait for completion.

. done.
Upgrading FPGA on card 0 complete.

Upgrading Winmon. Please wait for completion.

..... . done.
Upgrading Winmon complete.

Upgrading Daughter cards. Please wait for completion.

. done.
Upgrading Daughter cards complete.

**** ****
Finished preparing system for running CTPOS 6.0R1.
Finished migrating ID from CTPOS . Reboot required.
**** ****

**** ****
Please verify that all circuits and system setting are
correct after the system reboots.
**** ****
Hit return to reboot the system.
```

6. Press Enter to reboot the system.

Preparing a System for Firstboot Using CTPOS 6.x

You should see the following upgrade script output when you complete the steps described in “Upgrading with the PP310 Upgrade Kit” on page 3. The upgrade script output produced when you complete the steps described in “Upgrading with the PP332 Upgrade Kit” on page 5 is very similar, and you must respond to the same prompts.

```
Gathering system information.
* Please wait this could take up to 45 seconds.
Found:
System type      PP310
Bios             2.21
Memory installed 1024 MB
Slot 0:  Type T1E1
           FPGA 0xea * needs 0xea
Slot 1:  Type Serial
           FPGA 0x73
Slot 2:  Type FXS
           FPGA 0x5010150
ID restored     No

Hit return to continue...
```

This application will prepare the installed hardware for CTPOS 6.0R1. It will upgrade FPGAs if necessary, upgrade the BIOS if necessary, and can migrate the ID of a system running CTPOS 4.6R7 or 5.4R3.

This application will reboot the system multiple times. Please continue the process through to completion. Failure to do so can leave the system in an unknown state.
Hit return to continue...

The BIOS configuration needs to be changed.
Hit return to setup the BIOS configuration and reboot.



.....
NOTE: The set and reboot for the BIOS appears only for the PP310 processor.
.....

1. Press Enter. The BIOS configuration is updated, the device reboots, and the following output is displayed:

```
Gathering system information.
* Please wait this could take up to 45 seconds.
Found:
System type      PP310
Bios             2.21
Memory installed 1024 MB
Slot 0:  Type T1E1
              FPGA 0xea * needs 0xea
Slot 1:  Type Serial
              FPGA 0x73
Slot 2:  Type FXS
              FPGA 0x5010150
ID restored  No

Hit return to continue...
```

2. Reboot the device. The following output is displayed:
3. Enter `n` when you receive the following prompt (PP310 only):

```
Do you want to restore the ID from a CTPOS 4.6R7 or 5.4R3 system? [n]
```

The upgrade continues to completion, displaying the following information:

```
Upgrading T1E1 card in slot 0 to FPGA rev 0xea.
Upgrading FPGA on card 0. Please wait for completion.

. done.
Upgrading FPGA on card 0 complete.

Upgrading Winmon. Please wait for completion.

..... . done.
Upgrading Winmon complete.

Upgrading Daughter cards. Please wait for completion.

. done.
Upgrading Daughter cards complete.

**** ****
Finished preparing system for running CTPOS 6.0R1.
The system needs to be powered down.
**** ****
Hit return to power down the system.
```

4. Press Enter to power off the system.

Registering Your Upgrade

To register your upgrade:

1. Locate the Access Install Base web page at <https://www.juniper.net/customers/csc/management/updateinstallbase.jsp>
2. Enter the following required information:
 - System Model Number
 - System Serial Number
 - Support/Level Service Part Number
 - Interface Card/Module Model Number—Include for replacement RTM
 - Interface Card/Module Serial Number—Include for replacement RTM
 - Support/Level Service Part Number
 - Company Name
 - Site Address
 - Where Equipment Will Be Moved
 - Authorized Contract Name, Phone, and Email
 - Name of the Upgrade—Enter the name of your upgrade kit:
CTP2000-RAM-RTM-UPG or CTP2000-RAM-UPG
3. Click **Submit**.

Related Procedures

The following procedures are referenced by the upgrade procedures.

- Servicing the CTP2000 CPU on page 13
- Installing or Replacing CTP2000 DRAM Memory Modules in the PP310 or PP332 CPU on page 13
- Restoring BIOS Defaults for the CTPOS 6.x Upgrade (PP310) on page 15
- Installing or Removing a CTP2000 Series CompactFlash Card on page 16

Servicing the CTP2000 CPU

This topic describes how to remove the CTP2000 CPU from the chassis for service or upgrade, and how to return the CPU to the chassis. Follow proper antistatic procedures when you perform the following procedures.

To remove the CPU from the CTP2000 chassis:

1. Ground yourself by using an antistatic wrist strap or other device, and connect it to one of the ESD grounding jacks, if available, or another grounding device.
2. Power off the unit.
3. If an Ethernet cable is connected to the CPU (PP310 only), disconnect the cable.
4. Using a Phillips screwdriver, loosen each of the retaining screws on the outside edge of the CPU until the ejector that the screw secures is released.
5. Use the ejectors to remove the card from the chassis.

To return the CPU to the chassis:

1. Guide the CPU into the chassis by placing it between the guides of the slot and pushing the module until it stops.

The module stops sliding when the ejectors make contact with the chassis.

2. Tighten each of the retaining screws on the outside edge of the CPU.
3. If an Ethernet cable was connected to the CPU (PP310 only), reconnect the cable.

Installing or Replacing CTP2000 DRAM Memory Modules in the PP310 or PP332 CPU

The PP310 accepts standard 200-pin DDR SODIMM modules fitted with 2.5V PC2100 DDR SDRAM without ECC. ECC is supported by devices soldered onto the board. Two sockets are provided that can accommodate SODIMMs of 512 MB or 1 GB capacities.

The PP332 accepts standard 200-pin DDR SODIMM modules fitted with 2.5V PC2100 or PC2700 DDR SDRAM. Both 64-bit non-ECC SODIMM modules and 72-bit ECC SODIMM modules are supported. If ECC is required, then ECC modules must be fitted. Two sockets are provided that can accommodate modules up to 1 GB capacity each

When fitting only one SODIMM (for either CPU) this must be in the SODIMM #1 position.

To install or replace a memory module in the PP310 CPU:

1. Ground yourself by using an antistatic wrist strap or other device, and connect it to one of the ESD grounding jacks, if available, or another grounding device.
2. Remove the new memory module from its antistatic bag.
3. Remove the CPU board from the CTP2000 chassis. See "Servicing the CTP2000 CPU" on page 13.
4. To remove a memory module:


- Release the memory module by using your thumb to raise the end of the memory module to the angle shown in Figure 5 on page 14.



NOTE: Figure 5 on page 14 shows the PP310 CPU. The memory module is removed and replaced in the same manner for the PP332 CPU.

- Hold the memory module between your thumb and forefinger and gently pull it out of the socket.

Figure 5: DRAM Memory Module Replacement — PP310



5. To insert the new memory module:


- Hold the module between your thumb and forefinger and insert one end into the socket at the angle shown in Figure 5 on page 14.

- Lower the free end of the module until it snaps into place.
6. Return the CPU to the chassis and secure it in place. See “Servicing the CTP2000 CPU” on page 13.

Restoring BIOS Defaults for the CTPOS 6.x Upgrade (PP310)

You must restore default BIOS settings (stored in CMOS) during the CTPOS 6.x upgrade process for the PP310. Refer to Figure 6 on page 15 when performing the following procedure.

Figure 6: Jumper Setting for Restoring BIOS Defaults



To restore default BIOS settings:

1. Remove the CPU from the CTP2000 device chassis. See “Servicing the CTP2000 CPU” on page 13.
2. Locate the BIOS reset pins, which are shown as two black circles inside a figure 8 and captioned as CMOS Clear.



NOTE: The two BIOS reset pins are the only reset pins that are used in this procedure.

3. Attach the BIOS reset jumper included in the CTP2000 upgrade kit to the BIOS reset pins in order to short them together.
4. Insert the CPU into the device. See “Servicing the CTP2000 CPU” on page 13.

5. Apply power to the device for 10 seconds.
6. Power off the device.
7. Remove the CPU from the chassis.
8. Remove the BIOS reset jumper so that the BIOS reset pins are no longer shorted together.
9. Insert the CPU into the device. When you power on the device, the default BIOS settings will be in effect.

Installing or Removing a CTP2000 Series CompactFlash Card

To remove or install the CompactFlash card for the CTP2000 series:

1. Power off the unit.
2. Remove the processor RTM by unscrewing the retaining screws and pushing the extractors outward with the latching buttons depressed.
3. Remove the CompactFlash card retaining screw and nut. You can then remove or install the CompactFlash card in the flash socket (see Figure 7 on page 16).
4. Reinstall the CompactFlash card retaining screw and nut.
5. Reinstall the processor RTM into the chassis, and secure the retaining screws.

Figure 7: CompactFlash on the RTM

