



CTPView Network Management System Administration Guide

Release

6.1, CTPView Release 4.1



Published: 2010-10-05

Revision 1

Juniper Networks, Inc.
1194 North Mathilda Avenue
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Copyright © 2010, Juniper Networks, Inc. All rights reserved.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Products made or sold by Juniper Networks or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

CTPView Network Management System Administration

Copyright © 2010, Juniper Networks, Inc.

All rights reserved. Printed in USA.

Revision History

October 2010—Revision 1

The information in this document is current as of the date listed in the revision history.

END USER LICENSE AGREEMENT

READ THIS END USER LICENSE AGREEMENT (“AGREEMENT”) BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE. BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. **The Parties.** The parties to this Agreement are (i) Juniper Networks, Inc. (if the Customer’s principal office is located in the Americas) or Juniper Networks (Cayman) Limited (if the Customer’s principal office is located outside the Americas) (such applicable entity being referred to herein as “Juniper”), and (ii) the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software (“Customer”) (collectively, the “Parties”).

2. **The Software.** In this Agreement, “Software” means the program modules and features of the Juniper or Juniper-supplied software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller, or which was embedded by Juniper in equipment which Customer purchased from Juniper or an authorized Juniper reseller. “Software” also includes updates, upgrades and new releases of such software. “Embedded Software” means Software which Juniper has embedded in or loaded onto the Juniper equipment and any updates, upgrades, additions or replacements which are subsequently embedded in or loaded onto the equipment.

3. **License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

a. Customer shall use Embedded Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller.

b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees; provided, however, with respect to the Steel-Belted Radius or Odyssey Access Client software only, Customer shall use such Software on a single computer containing a single physical random access memory space and containing any number of processors. Use of the Steel-Belted Radius or IMS AAA software on multiple computers or virtual machines (e.g., Solaris zones) requires multiple licenses, regardless of whether such computers or virtualizations are physically contained on a single chassis.

c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer’s use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, realms, devices, links, ports or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. In addition, such limits may restrict the use of the Software to managing certain kinds of networks or require the Software to be used only in conjunction with other specific Software. Customer’s use of the Software shall be subject to all such limitations and purchase of all applicable licenses.

d. For any trial copy of the Software, Customer’s right to use the Software expires 30 days after download, installation or use of the Software. Customer may operate the Software after the 30-day trial period only if Customer pays for a license to do so. Customer may not extend or create an additional trial period by re-installing the Software after the 30-day trial period.

e. The Global Enterprise Edition of the Steel-Belted Radius software may be used by Customer only to manage access to Customer’s enterprise network. Specifically, service provider customers are expressly prohibited from using the Global Enterprise Edition of the Steel-Belted Radius software to support any commercial network access services.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. **Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any ‘locked’ or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the

Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use Embedded Software on non-Juniper equipment; (j) use Embedded Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. **Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. **Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. **Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. **Warranty, Limitation of Liability, Disclaimer of Warranty.** The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. **Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. **Taxes.** All license fees payable under this agreement are exclusive of tax. Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software. If applicable, valid exemption documentation for each taxing jurisdiction shall be provided to Juniper prior to invoicing, and Customer shall promptly notify Juniper if their exemption is revoked or modified. All payments made by Customer shall be net of any applicable withholding tax. Customer will provide reasonable assistance to Juniper in connection with such withholding taxes by promptly: providing Juniper with valid tax receipts and other required documentation showing Customer's payment of any withholding taxes; completing appropriate applications that would reduce the amount of withholding tax to be paid; and notifying and assisting Juniper in any audit or tax proceeding related to transactions hereunder. Customer shall comply with all applicable tax laws and regulations, and Customer will promptly pay or reimburse Juniper for all costs and damages related to any liability incurred by Juniper as a result of Customer's non-compliance or delay with its responsibilities herein. Customer's obligations under this Section shall survive termination or expiration of this Agreement.

11. **Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. **Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14 (ALT III) as applicable.

13. **Interface Information.** To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. **Third Party Software.** Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License ("GPL") or the GNU Library General Public License ("LGPL")), Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. **Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).

Table of Contents

Part 1	Overview	
Chapter 1	Circuit to Packet System Overview	3
	Circuit to Packet Network Overview	3
	Serial Stream Processing	4
	Transmit Packet Processing	4
	Receive Packet Processing	5
	Serial Stream Creation	5
	Clock Options	5
	Circuit to Packet Network Software Overview	6
Part 2	Installation	
Chapter 2	Installation Tasks Overview	9
	Updating the CTPView Server Operating System and CTPView Network Management System Software	10
Chapter 3	Installation and Upgrade Tasks for the CTPView Server OS and CTPView Software	13
	Installing or Upgrading the CTPView Server OS	14
	Saving the CTPView Configuration Settings and Data (CTPView Server Menu)	16
	Creating More Disk Space on the CTPView Server (CTPView)	17
	Creating More Disk Space on the CTPView Server (CTPView Server Menu)	18
	Installing the CTPView Server OS (CTPView Server CLI)	18
	Restoring CTPView Software Configuration Settings and Data (CTPView)	19
	Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)	20
	Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)	20
	Reviewing the Installation Log for Errors (CTPView Server CLI)	21
	Verifying the CTPView Server OS Installation (CTPView)	21
	Validating the CTPView Server Configuration (CTPView)	22
Chapter 4	Upgrade Tasks for Only the CTPView Software	23
	Upgrading Only the CTPView Software	23
	Upgrading the CTPView Software with a Complete Archive File	25
	Upgrading the CTPView Software with a Web Archive File	26
Chapter 5	Configuration Tasks for CTPView Administrative Settings	27
	Configuring the CTPView Administrative Settings	27
	Preparing a New Server	29

	Changing the BIOS Menu Password (CTPView Server CLI)	29
	Changing the Server's Default User Account Password (CTPView Server CLI)	30
	Changing the Server's Root Account Password (CTPView Server CLI)	31
	Changing the GRUB Boot Loader Password (CTPView Server Menu)	31
	Changing the MySQL Apache Account Password (CTPView Server Menu)	32
	Changing the MySQL Root Account Password (CTPView Server Menu)	33
	Configuring the Network Access (CTPView Server Menu)	33
	Creating a Self-Signed Web Certificate (CTPView Server Menu)	34
	Updating the CTPView Software	34
	Logging In with a Browser (CTPView)	35
	Changing the CTPView GUI Default User Account Password (CTPView)	35
	Creating a New Global_Admin Account (CTPView)	36
Chapter 6	Upgrade Tasks for CTPOS	37
	Using the CTPView Server Software to Update CTPOS (CTPView)	37
	Burning CTPOS Images to a CompactFlash Card (CTPView Server CLI)	38
Chapter 7	Default Accounts and Passwords	39
	Default CTPOS and CTPView Accounts and Passwords	39
	CTPOS and CTPView Software Password Requirements	40
Chapter 8	Understanding CTPView Upgrade Files	43
	Understanding CTPView Software Upgrade Files	43
Part 3	Administration	
Chapter 9	Managing and Displaying Users (CTPView)	47
	Managing CTPView Users with the CTPView Admin Center	47
	Accessing the CTPView Admin Center (CTPView)	48
	Monitoring CTPView Users (CTPView)	49
	Adding New CTPView Users (CTPView)	49
	Modifying CTPView User Properties (CTPView)	50
	Monitoring CTPView Groups (CTPView)	50
	Modifying CTPView User Group Affiliation (CTPView)	50
	Adding a New CTPView User Group (CTPView)	51
	Modifying CTPView User Group Default Properties (CTPView)	51
	Prohibiting and Reinstating CTPView Access by Users (CTPView)	52
	Displaying Prohibited CTPView Users (CTPView)	52
	Prohibiting User Access to CTPView (CTPView)	52
	Reinstating Prohibited CTPView Users (CTPView)	53
	Deleting Users and Groups (CTPView)	53
	Deleting Active CTPView Users (CTPView)	53
	Deleting Inactive CTPView Users (CTPView)	53
	Deleting Prohibited CTPView Users (CTPView)	54
	Deleting CTPView Groups (CTPView)	54
	Managing User Passwords (CTPView)	54
	Limiting Password Reuse (CTPView)	54
	Excluding Passwords from Use (CTPView)	54
	Reinstating Excluded Passwords (CTPView)	55

	Changing Requirements for New Passwords (CTPView)	55
	Configuring User Login Properties (CTPView)	55
	Logging Out a CTPView User (CTPView)	56
	Configuring Automatic Logout for a CTPView User (CTPView)	56
	Configuring the Number of Login Attempts Allowed Before Lockout (CTPView)	56
	Configuring a Lockout Period for CTPView Users (CTPView)	56
	Clearing CTPView User Counters (CTPView)	57
	Reinstating Locked-Out IP Addresses (CTPView)	57
	Creating an Access Filter to Allow or Deny IP Addresses (CTPView)	57
	Removing an IP Access Filter (CTPView)	57
	Understanding CTPView GUI User Levels	58
	CTPOS and CTPView Software Password Requirements	58
Chapter 10	Managing the CTPView Server (CTPView)	61
	Adding and Removing CTP Platforms Managed by CTPView Software (CTPView)	61
	Adding and Removing Host Groups (CTPView)	62
	Adding and Removing SNMP Communities (CTPView)	63
	Managing CTP Platforms in the Network (CTPView)	64
	Configuring Email Notifications (CTPView)	65
	Setting the CTPView Server Start-Up Banner (CTPView)	66
	Setting the CTP Platforms Login Banner (CTPView)	66
	Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView)	67
	Setting the CTPView Server Clock (CTPView)	68
	Managing NTP Servers for the CTPView Network (CTPView)	69
	Accessing the NTP Server Settings Window (CTPView)	70
	Stopping the NTP Daemon (CTPView)	70
	Adding an NTP Peer (CTPView)	70
	Removing an NTP Peer (CTPView)	71
	Synchronizing the CTPView Server to an NTP Peer (CTPView)	71
	Adding NTP Network Clients (CTPView)	71
	Removing an NTP Network Client (CTPView)	71
	Modifying the Netmask of an NTP Network Client (CTPView)	71
	Configuring Automatic Monitoring of CTP Platforms (CTPView)	72
	Accessing the CTPView Automatic Functions Window (CTPView)	73
	Adding an Automatic Monitoring Operation (CTPView)	73
	Removing an Automatic Monitoring Operation (CTPView)	73
	Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms (CTPView)	73
	Restoring CTPView Software Configuration Settings and Data (CTPView)	74
	Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)	75
	Synchronizing Multiple CTPView Servers (CTPView)	75
	Configuring a CTPView Server Synchronization Network (CTPView)	76
	Synchronizing the CTPView Server Network Automatically (CTPView)	77
	Synchronizing the CTPView Server Network Manually (CTPView)	78

Chapter 11	Monitoring CTP Platforms (CTPView)	79
	Monitoring the Network with the CTPView Software (CTPView)	79
	Changing the Display Settings for CTPView Network Monitoring (CTPView) . . .	80
	Checking the CTPView Server Connection to CTP Platforms in the Network (CTPView)	81
	Checking Connections from the Network Monitoring Pane (CTPView)	81
	Checking Connections from the Node Maintenance Pane (CTPView)	82
	Displaying Previously Logged Connection Status (CTPView)	82
	Checking Connections in the Remote Host Options Window (CTPView) . . .	82
	Displaying Runtime Query Results for a CTP Platform (CTPView)	83
	Overriding CTP Platform Network Status and Adding Comments (CTPView) . . .	83
	Saving CTP Platform Configurations (CTPView)	84
	Setting an Audible Alert for CTP Platform Status (CTPView)	86
	Displaying CTPView Network Reports (CTPView)	87
	Field Descriptions in CTPView Network Reports (CTPView)	88
	Displaying Network Statistics (CTPView)	89
Chapter 12	Changing CTPView GUI Settings	91
	Configuring CTPView Software for Tabbed or Nontabbed Browsers (CTPView)	91
	Changing the CTPView Display Settings (CTPView)	92
	Displaying Help for CTPView GUI Settings (CTPView)	92
Chapter 13	Managing and Displaying Users (CTPView Server Menu)	95
	Accessing the CTPView Server Configuration Menu (CTPView Server Menu) . . .	95
	Managing CTPView Users (CTPView Server Menu)	95
	Monitoring CTPView Users (CTPView Server Menu)	96
	Listing Admin Shell Accounts (CTPView Server Menu)	96
	Adding Admin Shell Accounts (CTPView Server Menu)	96
	Deleting Admin Shell Accounts (CTPView Server Menu)	97
	Classification of CTPView Shell Account Users	97
	Managing User Passwords (CTPView Server Menu)	97
	Listing User Accounts (CTPView Server Menu)	97
	Displaying Password Expiration Settings (CTPView Server Menu)	98
	Changing Password Expiration Settings (CTPView Server Menu)	98
	Displaying Password Requirements (CTPView Server Menu)	99
	Changing Password Requirements (CTPView Server Menu)	99
	Configuring CTPView User Authentication with Steel-Belted Radius	99
	Configuring RADIUS Settings on the CTPView Server	100
	Configuring the SBR Server's Dictionary Files	101
	Configuring the SBR Server's Active Authentication Method	101
	Adding the CTPView Server as a RADIUS Client on an SBR Server	102
	Adding CTPView Users to an SBR Server	102
	Assigning SecurID Tokens to CTPView Users	103
Chapter 14	Managing the CTPView Server (CTPView Server Menu)	105
	Managing CTPView Server Secure Logs (CTPView Server Menu)	105
	Viewing Secure Logs (CTPView Server Menu)	106
	Copying Secure Logs to a Remote Host (CTPView Server Menu)	106
	Configuring Remote Logging Options (CTPView Server Menu)	106

	Displaying the Remote Logging Configuration (CTPView Server Menu) . . .	106
	Setting the CTPView Server Start-Up Banner (CTPView Server Menu)	107
	Managing Access Security for the CTPView Server (CTPView Server Menu) . . .	107
	Viewing the Access Security Level for the CTPView Server (CTPView Server Menu)	108
	Setting Access Security for the CTPView Server (CTPView Server Menu)	108
	Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView Server Menu)	109
	Viewing the Current State of Port Forwarding (CTPView Server Menu) . . .	109
	Setting Port Forwarding Permissions (CTPView Server Menu)	109
	Closing Port Forwarding Sockets (CTPView Server Menu)	110
	Clearing Open Sockets by Restarting the Apache Daemon (CTPView Server Menu)	110
	Saving the CTPView Configuration Settings and Data (CTPView Server Menu)	111
	Creating More Disk Space on the CTPView Server (CTPView Server Menu)	112
	Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)	113
	Restarting the MySQL Server (CTPView Server Menu)	113
	Setting the Logging Level (CTPView Server Menu)	114
Chapter 15	Restoring Default Values on the CTPView Server	115
	Resetting the Default System Administrator Account (CTPView Server Menu)	115
	Resetting the Data File Permissions (CTPView Server Menu)	115
	Resetting the CTPView System Files to the Default Values (CTPView Server Menu)	116
	Resetting the Default Firewall Settings (CTPView Server Menu)	118
Chapter 16	Changing Administrative Passwords to Improve Access Security	119
	Changing Passwords to Improve Access Security	119
	Changing the BIOS Menu Password (CTPView Server CLI)	120
	Changing the Server's Root Account Password (CTPView Server CLI)	121
	Changing the GRUB Boot Loader Password (CTPView Server Menu)	121
	Changing the MySQL Apache Account Password (CTPView Server Menu)	122
	Changing the MySQL Root Account Password (CTPView Server Menu)	123
Chapter 17	Using Third-Party Software on CTPView Servers	125
	Third-Party Software on CTPView Servers	125
Part 4	Troubleshooting	
Chapter 18	Validating the CTPView Server System Configuration	129
	Validating the CTPView Server Configuration (CTPView)	129
Chapter 19	Restoring CLI Access to the CTPView Server	131
	Restoring Access to a CTPView Server	131
	Accessing a Shell on the CTPView Server (CTPView Server CLI)	132
	Setting a New Password for a Nonroot User Account (CTPView Server CLI) . . .	133
	Setting a New Password for a Root User Account (CTPView Server CLI)	134

	Creating a Nonroot User Account and Password (CTPView Server CLI)	134
Chapter 20	Restoring Browser Access to a CTPView Server	137
	Restoring Browser Access to a CTPView Server (CTPView Server Menu)	137
Chapter 21	Changing a CTPOS User Password	139
	Changing a User Password for a CTP Platform	139
Chapter 22	Booting the CTPView Server from the CD-ROM Drive	141
	Booting the CTPView Server from the CD Drive	141
Chapter 23	Restarting the Apache Daemon In the Event of Browser Issues	143
	Restarting the Apache Daemon (CTPView Server Menu)	143
Part 5	Index	
	Index	147

List of Figures

Part 1	Overview	
Chapter 1	Circuit to Packet System Overview	3
	Figure 1: Sample Application Using CTP Products	3
	Figure 2: Circuit-to-Packet Conversion Processes	4
Part 2	Installation	
Chapter 2	Installation Tasks Overview	9
	Figure 3: Decision Tree for Updating CTPView Server Software	12

List of Tables

Part 2	Installation	
Chapter 7	Default Accounts and Passwords	39
	Table 1: CTPView Server Default Accounts and Passwords	39
	Table 2: CTPOS Default Account and Password	40
Chapter 8	Understanding CTPView Upgrade Files	43
	Table 3: CTPView Software Upgrade Files	43
Part 3	Administration	
Chapter 10	Managing the CTPView Server (CTPView)	61
	Table 4: CTP Platform Events for Email Notifications	65
	Table 5: Summary Information for NTP Server Peers	69
	Table 6: Prefixes Designating Peer Clock Selection Status	69
	Table 7: Current CTPView Automatic Settings	72
Chapter 11	Monitoring CTP Platforms (CTPView)	79
	Table 8: Platform Group and Port Status	80
	Table 9: CTPView Network Reports Fields	88
Chapter 13	Managing and Displaying Users (CTPView Server Menu)	95
	Table 10: CTPView User Password Expiration Settings	98
Chapter 14	Managing the CTPView Server (CTPView Server Menu)	105
	Table 11: Access Security Levels for SSH Connections	108
	Table 12: Access Security Levels for CTPView GUI	109

PART 1

Overview

- [Circuit to Packet System Overview on page 3](#)

CHAPTER 1

Circuit to Packet System Overview


- Circuit to Packet Network Overview on page 3
- Circuit to Packet Network Software Overview on page 6

Circuit to Packet Network Overview

The CTP products are designed to create an IP packet flow from a serial data stream or analog voice connection, providing the necessary processing to re-create the serial bit stream or analog signal from an IP packet flow.


CTP products are designed to accommodate the delay, delay jitter, and packet reordering characteristics of an IP network. Figure 1 on page 3 shows examples of applications that use CTP products.

Figure 1: Sample Application Using CTP Products



Numerous processes must occur to adapt serial data to and from IP packets. These processes are summarized in Figure 2 on page 4. You configure the characteristics of the processes by using the CTP menu interface or the CTPView graphical user interface.

Figure 2: Circuit-to-Packet Conversion Processes



Using the menu interface, you can configure the CTP products to accept a serial data stream and create an IP flow that will be transferred across an IP network. The connection provided by the CTP platform is a physical layer circuit between the end user equipment.

Serial Stream Processing

Rate selection and clock configuration allow the serial interface rate to be configured through the software. Rates supported range from less than 300 bps to 12.288 Mbps (in subhertz increments).

You can configure the CTP systems by using the menu interface to provide multiple prioritized node clock references. An external reference input and any of the serial interfaces may be used for the node reference clock. Reference frequencies must be 32 KHz, $n \times 64$ KHz, or 1,544 KHz up to a maximum of 4096 KHz (2048 KHz maximum on the CTP1002).

The electrical characteristics and encoding of the CTP ports are software configurable. The available options are EIA530, EIA530A, RS-232, V.35, analog 4WTO, conditioned diphas, isochronous, T1, and E1.

An analog voice signal terminated on the 4WTO interface is converted into a 64-Kbps pulse-code modulation (PCM) digital bit stream before adaptation to and from an IP flow. The analog interface allows transmit and receive levels to be adjusted.

Transmit Packet Processing

The CTP platform is configured with the remote IP address of the device where the packets created from the local serial port are to be routed.

The CTP remote port is specified by the IP address and physical port number of the remote unit and port.

The packet size created by the CTP platform may be set from 32 to 1456 bytes. Larger packet sizes are more bandwidth-efficient but introduce more serialization delay when the packet is created. The menu interface verifies that the combination of packet size and data rate does not result in a packet rate exceeding 1200 packets per second.

Time to live (TTL) may be set from 0 to 255. The TTL is the maximum number of hops in the IP network that the packet may travel before it is discarded by the network. You can configure the service type byte, which some IP networks use to determine the quality of service provided to the IP flow.

Receive Packet Processing

A receive buffer is required to smooth the timing jitter of received packets because of the delay variance that is inevitably encountered in the IP network. The configuration allows you to configure both the size of the buffer (in 1-ms increments) and the maximum amount of buffering delay allowed before the buffer will recenter. The size of the buffer configured should depend on the performance and characteristics of the IP network.

The CTP platform automatically resequences packets when they arrive out of order. If a packet is not received, the CTP platform inserts all data in lieu of the packet information so that bit count integrity is maintained.

You can prompt the menu interface to display detailed information about the port status, such as packet counts, late packets, missing packets, and buffer fill.

Serial Stream Creation

The packet receive process allows the serial data rate to be configured through the software. Rates supported range from less than 300 bps to 12.288 Mbps in subhertz increments. Conditioned diphas and isochronous interfaces operate at rates up to 1.024 Mbps.

Clock Options

The CTP platform provides numerous options for physical layer clocking:

- **Interface clocking options**—The CTP platform allows complete configuration flexibility of interface clocking. This flexibility includes your ability to specify how clocks are generated (that is, from the node clock, which can be phase locked to an external clock input) and what clocks are used to process the data from the attached device. The CTP platform can synthesize over 1.5 billion rates between 1 bps and 12.288 Mbps.
- **Asymmetric clocking**—You can configure CTP circuits to synthesize asymmetric rates.
- **Reference clock input**—The CTP platform can phase lock its node clock to an interface clock or external reference input. Up to five prioritized references can be configured. The node provides a reference holdover if all references are lost.
- **Plesiochronous operation**—Calibrated Clock is a patented CTP feature that allows the one-time calibration of the CTP oscillator to a known reference. Depending on environmental factors, two units calibrated to the same clock will have a clock

difference as small as 100 parts per billion. This calibration enables CTP circuits to operate for long periods of time before a buffer recenter occurs.

- Adaptive clocking—Although IP router networks do not transfer physical layer clocking, the CTP adaptive clocking feature, using patented Advanced Time Domain Processing (ATDP), allows the CTP platform to recover clocking information from the remote CTP port and adjust the local clock accordingly. ATDP provides rapid convergence to the correct clock, and does not vary due to changes in the average jitter buffer fill. As a result, a CTP circuit will continuously operate without a buffer recenter, even when clock references are not used.

**Related
Documentation**

- Adding a Bundle (CTPView)
- Adding a Bundle (CTP Menu)
- Selecting the Type of Clocking on Serial Ports for CTP Bundles (CTPView)
- Configuring Custom Clocking for CTP Bundles (CTPView)
- Configuring Adaptive Clocking for CTP Bundles (CTPView)
- Configuring IP Parameters for CTP Bundles (CTP Menu)

Circuit to Packet Network Software Overview

This topic provides an overview of the software components of the CTPView Network Management System and the CTP platforms.

A typical Circuit to Packet network consists of one or more CTP platforms and a CTPView server. The CTPView server runs the CTPView Network Management System software to manage the CTP platforms and construct the circuit-to-packet traffic bundles.

The software components consist of the following:

- CTPOS—Operating system that runs on the CTP platforms.
- Fedora Core (FC) OS—Operating system that runs on the CTPView server.
- CTPView Network Management System—Software that you use to build circuits and manage the CTP platforms. You can access this software through a browser application or through a text-based menu set.

In this document, we use the term *CTPView GUI* to refer to the browser application, and the term *CTPView server menu* to refer to the text-based menus. *CTPView software* typically refers to the CTPView Network Management System without regard to the method used to access the server.

**Related
Documentation**

- Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10

PART 2

Installation

- Installation Tasks Overview on page 9
- Installation and Upgrade Tasks for the CTPView Server OS and CTPView Software on page 13
- Upgrade Tasks for Only the CTPView Software on page 23
- Configuration Tasks for CTPView Administrative Settings on page 27
- Upgrade Tasks for CTPOS on page 37
- Default Accounts and Passwords on page 39
- Understanding CTPView Upgrade Files on page 43

CHAPTER 2

Installation Tasks Overview

- Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10

Updating the CTPView Server Operating System and CTPView Network Management System Software

This topic provides an overview of installing and upgrading the software on the CTPView server. You can install or upgrade the server operating system (OS), and you can upgrade the CTPView software that you use to manage the CTP Series devices. CTPView servers are provided with an OS and the CTPView software already installed. You can upgrade any CTPView server to a higher-numbered software release.

Your choice of upgrade procedure depends on the version of the operating system (OS) running on the CTPView server to be upgraded. To upgrade to the current release, your CTPView server must be running either Fedora Core 4 (FC4) OS or Fedora Core 9 (FC9) OS. CTPView servers are shipped with the latest supported version. CTPView servers have been shipped with the following OS versions:

- FC9 on servers shipped after August 2008.
- FC4 on servers shipped from November, 2006 through August 2008.
- FC1 on servers shipped before November 2006.

You can determine your server OS version in any of the following ways:

- In CTPView, navigate to **Server > Diagnostics**. The OS version is displayed in the Distro Name field in the System Vital block section of the page.
- Log in to the server shell and enter **uname -r** on the command line. The kernel version that is displayed includes the OS version: **fc1, fc4, fc9**.
- Log in to the server shell and enter **menu** and then the root password on the command line. The heading of the configuration menu that is displayed includes the OS release and kernel versions.



NOTE: If your server is running FC1, we recommend that you upgrade to a more recent model server.

Depending on your goals and your current software versions, upgrading your system software includes one or more of the following tasks:

- Install or upgrade to the latest server OS version, and upgrade to the latest CTPView software versions.

You can choose this task for any CTP server. *Installing* the OS reformats the server hard drives and deletes all existing data and settings. These actions put your server into a stable known state with all security features enabled. *Upgrading* to the latest OS version does not format the server hard drives; your existing data and settings are preserved. In either case, you also upgrade to the latest CTPView software version.

See “Installing or Upgrading the CTPView Server OS and CTPView Software” on page 14.

- Upgrade to the latest CTPView software version.

When you do not need or want to change the OS version, you can simply upgrade to the latest CTPView version.

See “Upgrading Only the CTPView Software” on page 23.

- Configure administrative settings to complete the upgrade.

When you receive a new CTP server from Juniper Networks that is running CTPView 3.2R1 or higher, you need only configure the administrative settings. To enable all of the security updates, an administrator must configure certain server settings during the upgrade process.


You must also perform this task to validate the administrative settings in either of the following cases:

- You upgraded the CTPView software on a server running FC4 and CTPView 2.2R1 or lower.
- You installed or upgraded the server to the latest OS version.

See [Configuring the CTPView Administrative Settings](#).

Figure 3 on page 12 illustrates the decision process you use to determine which tasks to perform.

Figure 3: Decision Tree for Updating CTPView Server Software



9015391

Related Documentation • Accessing a Shell on the CTPView Server (CTPView Server CLI) on page 132

CHAPTER 3

Installation and Upgrade Tasks for the CTPView Server OS and CTPView Software

- Installing or Upgrading the CTPView Server OS on page 14
- Saving the CTPView Configuration Settings and Data (CTPView Server Menu) on page 16
- Creating More Disk Space on the CTPView Server (CTPView) on page 17
- Creating More Disk Space on the CTPView Server (CTPView Server Menu) on page 18
- Installing the CTPView Server OS (CTPView Server CLI) on page 18
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 19
- Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu) on page 20
- Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView) on page 20
- Reviewing the Installation Log for Errors (CTPView Server CLI) on page 21
- Verifying the CTPView Server OS Installation (CTPView) on page 21
- Validating the CTPView Server Configuration (CTPView) on page 22

Installing or Upgrading the CTPView Server OS

This topic provides an overview of installing and upgrading the operating system (OS) for the CTPView server.

Before you begin, do all of the following:

- Verify that this is the procedure you wish to use to update the software on the CTPView server. See “Updating the CTPView Server Operating System and CTPView Network Management System Software” on page 10.
- Ensure that you have a monitor and keyboard connected to the CTPView server. You must also have an external storage device connected to the server in order to save the current data and settings for CTPView.
- Ensure that the server is connected to the network.
- If your server is currently running FC1, you must be running CTPView 2.1R2 or 2.1R3 in order to back up your existing data and configuration settings before upgrading the OS version. See “Upgrading Only the CTPView Software” on page 23 for information on upgrading the CTPView software before you perform the tasks in this topic.



NOTE: If your server is running FC1, we recommend that you upgrade to a more recent model server.

Perform the following tasks

1. Save the current configuration settings and data to an external storage device.
See “Saving the CTPView Configuration Settings and Data (CTPView Server Menu)” on page 16.
2. Install or upgrade the CTPView server OS.
See “Installing the CTPView Server OS” on page 18.
3. Restore the configuration settings and data.
See “Restoring CTPView Software Configuration Settings and Data (CTPView)” on page 19.
4. Review the installation log for errors.
See “Reviewing the Installation Log for Errors (CTPView Server CLI)” on page 21.
5. Configure CTPView administrative settings to complete server setup and ensure that security settings are correct.
See “Configuring the CTPView Administrative Settings” on page 27.
6. Verify that the server OS was successfully installed or upgraded.
See “Verifying the CTPView Server OS Installation (CTPView)” on page 21.
7. Validate the server configuration.

See “Validating the CTPView Server Configuration (CTPView)” on page 22.

- Related Documentation**
- Default CTPOS and CTPView Accounts and Passwords on page 39

Saving the CTPView Configuration Settings and Data (CTPView Server Menu)

This topic describes how to save the current configuration settings and data for the CTPView software. Although you can perform this task at any time, it is typically performed before you upgrade the CTPView server OS and the CTPView software.

You can use the backup utility in the CTPView server menu to save the information into an archive (.tgz) file and, if desired, move the archive to an external storage device. If you do not use the utility to move the archive, you can later copy or move it manually from outside the CTPView server menu.



NOTE: If you do not move the archive file to an external storage device, you are not protected from loss of the backed-up data. If you are upgrading the software, you must move the file to an appropriate location.

Alternatively, when you have more than one CTPView server, you can use the CTPView software GUI to synchronize the server with another server to save the settings and data. See “Synchronizing Multiple CTPView Servers (CTPView)” on page 75 for the synchronization procedure.



NOTE: We recommend that you use the CTPView server backup utility to save your current information.

Before you use the CTPView server backup utility:

- Confirm that the external storage device is running a UNIX-like operating system and is enabled for SSH connections.



NOTE: Although the external storage device can use any operating system, the CTPView backup utility can automatically transfer the backup file only to a device that is running a UNIX-like operating system. If the device is running a different kind of OS, you must transfer the backup file with a copy utility that is compatible with that OS.

- Confirm that a network path exists between the CTPView server and the external storage device used for storing the backup file.
- Confirm that the hard drive on the CTPView server that you are backing up has at least 25 percent free space. If you attempt to run the backup utility when less than 25 percent free space is available, the utility prompts you to delete more old data files before you continue. See “Creating More Disk Space on the CTPView Server (CTPView)” on page 17.
- Log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To back up your current information with the CTPView server backup utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions Menu is displayed.

2. Select **1) Save Current Settings and Data**.

If an archive file already exists in the `/var/www/html/acorn/data` directory on the server, the utility prompts you to delete or move the archive.

3. (Optional) From outside the menu (for example, in another terminal window), manually move the old archive to an external storage device if you want to save the information.

4. Enter **y** to delete the old archive.

The utility deletes the old archive file and creates the new archive file.

5. Enter **y** to move the new archive to an external location.

6. Follow the prompts to enter the IP address, username, and absolute path to the external device.

Related Documentation

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Creating More Disk Space on the CTPView Server (CTPView) on page 17
- Creating More Disk Space on the CTPView Server (CTPView Server Menu) on page 18

Creating More Disk Space on the CTPView Server (CTPView)

This topic describes how to determine the amount of free disk space on the CTPView server and how to ensure that sufficient free space is always available on the server.

To determine the amount of free disk space that is available on the CTPView server:

1. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

2. Find the value for Totals in the Mounted Filesystems section. The value should be **75%** or less.

To automatically delete old files to create more free disk space:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

2. Click **Automatic Functions**.

3. Under the Action heading in the Add New Automatic Entry section, select old data files to delete. You can choose to remove outdated files that are over 6 months old, over 9 months old, or over 12 months old.

4. Click **Add New Entry**. From this point forward, files are deleted from the server when they exceed the selected age.

If you subsequently no longer want old files to be automatically removed, select that Action under Current CTPView Automatic Settings and click **Remove Selected Lines**.

Related Documentation

- Saving the CTPView Configuration Settings and Data (CTPView Server Menu) on page 16
- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Creating More Disk Space on the CTPView Server (CTPView Server Menu)

This topic describes how to create free space by removing redundant data files from the server.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To delete old files to create more free disk space:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.
The Backup Functions menu is displayed.
2. Select **3) Remove Redundant Binary Data Files**.

Related Documentation

- Saving the CTPView Configuration Settings and Data (CTPView Server Menu) on page 16
- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Installing the CTPView Server OS (CTPView Server CLI)

This topic describes how to install the latest CTPView server OS. The server OS must be installed from the CTPView Management System CDs. Contact Juniper Networks Customer Support to send you the CDs.



NOTE: The CTPView software is automatically installed when you install or upgrade the server OS with the CTPView Management System CDs.

To install or upgrade CTPView server OS:

1. Insert the first CD from the latest CTPView Management System CD set into the server.
2. From the CLI, select **System Configuration > Reboot System** to reboot the server.
The reboot process halts at the Juniper CTPView Management System window.
3. At the boot prompt, enter **ctpview-install** or **ctpview-upgrade**.



NOTE: We recommend that you choose `ctpview-install`. This action reformats the server hard drives, installs the latest version of the server OS, and creates a conforming instance of the OS. If you choose `ctpview-upgrade`, the latest version of the OS is installed, but the server hard drives are not reformatted.

4. Follow the prompts to remove and insert the remaining CDs to complete the installation or upgrade process.

On some early hardware systems a RAMDISK error may be reported at the beginning of the upgrade process. If this occurs, perform the following steps:

1. Leave the first CD in the server and use the server power switch to reboot the server.
2. When the boot prompt appears, enter `mediacheck`. The server displays the message “Could not find kernel image: mediacheck”.
3. At the boot prompt, enter `ctpview-install` or `ctpview-upgrade`.

The upgrade process should proceed normally.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Restoring CTPView Software Configuration Settings and Data (CTPView)

This topic lists two methods to restore the CTPView software configuration settings and data. Typically you restore this information only after one of the following events has occurred:

- An installation of the latest version of the CTPView server operating system, which reformats the server’s hard drives.
- In the unlikely event of a data loss.

Use one of the following methods to restore saved CTPView information:

- Use the CTPView restore utility in the CTPView server menu. You must use this method when you have only a single CTPView server.

See “Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)” on page 20.

- Synchronize the server. This method is available only when you have two or more CTPView servers in your network.

See “Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)” on page 20.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)

This topic describes how to use the CTPView restore utility to restore the CTPView software configuration settings and data from a previously saved archive file.

Before you begin:

- Copy the backup (archive) file from its externally saved location to the `/var/www/html/acorn/data` directory on the server. The filename is in the format `ctpview_data_server-name_date.tgz`.
- Log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To restore your saved information with the CTPView restore utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions menu is displayed.

2. Select **2) Restore Settings and Data**.

You are prompted to use the archive file. After the restore script runs, you are prompted to run it again.

Related Documentation

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 19

Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)

This topic describes how to use CTPView server synchronization to restore the CTPView software configuration settings and data.

To restore your saved information by synchronizing the CTPView server with another server:

1. Log in to the CTPView GUI on the server for which you are restoring the data.
2. In the side pane, select **Server > Administration** to display the Administrative Functions pane.
3. Click **Server Synchronization**.
4. Verify that the server is either not listed or its Server Type is set to Not Selected.
5. Log in to the CTPView GUI on the server from which you are restoring the data.
6. In the side pane, select **Server > Administration** to display the Administrative Functions pane.

7. Click **Server Synchronization**.
8. Ensure that the Server Type is set to Primary Server for this server, Secondary Server for the server being updated, and Not Selected for all other CTPView servers listed.
9. Click **Manually Synchronize Network**.
The Synchronize Secondary Servers window opens.
10. Click **Select All Hosts**, and then click **Synchronize Servers**.
11. When the synchronization is completed, restore the Server Type for all CTPView servers to the values that you normally use for your network.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 19

Reviewing the Installation Log for Errors (CTPView Server CLI)

This topic describes how to use the CTPView installation log to check for errors. This log file maintains a record of all CTPView installations and upgrades.

To check the installation log for errors:

1. Using an SSH application, log in to the CTPView server.



NOTE: If you do not successfully log in within 60 seconds, the session is closed.

2. Enter **su -** and then the root password.
3. Enter **more /var/log/ctpview_autoinstall.log** to view the log.

Press the Spacebar to scroll through the log. Verify that no unresolved errors are listed for the latest installation or upgrade.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Verifying the CTPView Server OS Installation (CTPView)

This topic describes how to determine whether the CTPView server OS installation or upgrade completed successfully.

To validate the system configuration:

1. Log in to the CTPView GUI.
2. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

3. In the System Vital section, verify that the following values match the information listed in the release notes or in “Understanding CTPView Software Upgrade Files” on page 43 for the OS version that you installed.

- Kernel Version
- Distro Name (distribution name)



NOTE: The kernel version and distribution name are also displayed in the heading on the CTPView Configuration Menu.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Validating the CTPView Server Configuration (CTPView)

This topic describes how to validate the CTPView server system configuration. Examining the system configuration information is a useful first step in troubleshooting many issues. Validate the configuration after installing or upgrading the CTPView software or server OS to determine whether the operation completed successfully.

The validation utility reports on a long list of configuration details that are critical or desirable for proper operation of the CTPView software. Instructions are provided for correcting items that are out of compliance.

To validate the system configuration:

1. Log in to the CTPView GUI.
2. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

3. Click **Validate Server Configuration**.

The Server Configuration Validation pane is displayed.

4. Confirm that all fields are set to their default values.

The display indicates whether each item is valid or noncompliant. A highlighted field indicates a problem. Follow the displayed instructions to correct the problem.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Upgrade Tasks for Only the CTPView Software

- Upgrading Only the CTPView Software on page 23
- Upgrading the CTPView Software with a Complete Archive File on page 25
- Upgrading the CTPView Software with a Web Archive File on page 26

Upgrading Only the CTPView Software

This topic provides an overview of upgrading the CTPView software.

Before you begin, do all of the following:

- Using an SSH application, log in to the CTPView server, and enter **uname -r** on the CLI to determine the version of the operating system (OS). The initial characters in the output correlate to an OS version as follows:
 - 2.6.25 indicates that the operating system is FC9.
 - 2.6.11, 2.6.16, or 2.6.17 indicates that the operating system is FC4.
 - 2.4 indicates that the OS version is FC1.
- Determine the version of the CTPView software. In the CTPView server shell, enter **menu**, and then enter the root password when prompted. The software version is displayed in the heading. Alternatively, you can log in to the CTPView GUI and look in the heading next to the server IP address to determine the version of the CTPView software.
- Determine which upgrade file is required for your combination of currently installed CTPView server OS and CTPView software. See “Understanding CTPView Software Upgrade Files” on page 43 for guidance. The *CTPView Release Notes* for the version you are upgrading to also describes the required upgrade files.

The steps you must perform to upgrade the CTPView software depend on the currently installed versions of the server OS and the CTPView software. Two kinds of CTPView update archive files are available, *web* files and *complete* files:

- Web files are used for minor software updates. Their filenames are in the format **web_server-os-version_upgrade-version_date.tgz**. For example, the file

web_fcX_3.4R1_090715.tgz provides an upgrade to CTPView 3.4R1 for CTPView servers running either FC4 or FC9.

To upgrade the CTPView software with a web archive file, see “Upgrading the CTPView Software with a Web Archive File” on page 26.

- Complete files are used for more significant upgrades, and include additional software modules compared to the web files. Their filenames are in the format **ctpview_server-os-version_complete_upgrade-version_date.tgz**. For example, the file **ctpview_fc4_complete_3.4R1_090715.tgz** provides an upgrade to CTPView 3.4R1 for CTPView servers running either FC4.

To upgrade the CTPView software with a complete archive file, see “Upgrading the CTPView Software with a Complete Archive File” on page 25.



NOTE: The CTPView Release Notes for the version you are upgrading to describes the upgrade files required for various combinations of currently installed CTPView server OS and CTPView software. “Understanding CTPView Software Upgrade Files” on page 43 also provides a more complete list of upgrade files and their associated software combinations.



NOTE: When the CTPView server OS version is FC1, you must first upgrade to a higher OS version. See “Installing or Upgrading the CTPView Server OS and CTPView Software” on page 14.



NOTE: When you upgrade a version of CTPView that is lower than 2.2, the existing server CLI passwords and server accounts are not modified other than that the user account *Juniper* is added. However, all the existing CTPView user accounts are removed. Browser access to CTPView 2.2R1 and higher is through a new login interface that requires an administrator to create new usernames and passwords.

When you upgrade a version of CTPView that is lower than 2.0.4R1, you may need to update the server Ethernet settings after the upgrade. If so, use the CLI menu on the CTPView server to make the changes: 2) **System Configuration > 1) Display Current Configuration**. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

Related Documentation

- Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10
- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Default CTPOS and CTPView Accounts and Passwords on page 39
- Understanding CTPView Software Upgrade Files on page 43

Upgrading the CTPView Software with a Complete Archive File

This topic describes how to upgrade the CTPView software with a complete archive file.

Before you begin, ensure that you have determined the correct archive file to use for your upgrade. See “Upgrading Only the CTPView Software” on page 23 for more information.

To upgrade the CTPView software with a complete archive file:

1. Access the CTPView software download page at the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>.
2. Locate the update archive file appropriate for your current CTPView server OS and your CTPOS version.
3. Use a Secure Copy Protocol (SCP) program to copy the complete archive file to the `/tmp` directory on the server.

The filename is in the format

`ctpview_server-os-version_complete_upgrade-version_date.tgz`.

4. Log in to the server and switch to the root account.
5. Change the directory to `/tmp`.
6. Extract the archive by entering `tar -xzf filename`.



NOTE: This step is not required when the CTPView server is running CTPView 3.4R2-p1 or higher-numbered releases. In these releases, the complete archive is automatically extracted when you run the upgrade script in the next step.

7. Run the installation script by entering `upgrade`.
8. Configure CTPView administrative settings to complete server setup, and ensure that security settings are correct.
See Configuring the CTPView Administrative Settings.
9. To validate the system configuration, see “Validating the CTPView Server Configuration (CTPView)” on page 22.

Related Documentation

- Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10
- Upgrading Only the CTPView Software on page 23
- Understanding CTPView Software Upgrade Files on page 43

Upgrading the CTPView Software with a Web Archive File

This topic describes how to upgrade the CTPView software with a web archive file.

Before you begin, ensure that you have determined the correct archive file to use for your upgrade. See “Upgrading Only the CTPView Software” on page 23 for more information.

To upgrade the CTPView software with a web archive file:

1. Access the CTPView software download page at the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>.
2. Locate the update archive file appropriate for your current CTPView server OS and your CTPOS version.
3. Use a Secure Copy Protocol (SCP) program to copy the web archive file to the **/tmp** directory on the CTPView server.

The filename is in the format **web_server-os-version_upgrade-version_date.tgz**.

4. Log in to the server and switch to the root account.
5. Change the directory to **/tmp**.
6. Run the installation script by entering **upgrade**.
7. Configure CTPView administrative settings to complete server setup, and ensure that security settings are correct.

See *Configuring the CTPView Administrative Settings*.

8. To validate the system configuration, see “Validating the CTPView Server Configuration (CTPView)” on page 22.

Related Documentation

- Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10
- Upgrading Only the CTPView Software on page 23
- Understanding CTPView Software Upgrade Files on page 43

CHAPTER 5

Configuration Tasks for CTPView Administrative Settings

- Configuring the CTPView Administrative Settings on page 27
- Preparing a New Server on page 29
- Changing the BIOS Menu Password (CTPView Server CLI) on page 29
- Changing the Server's Default User Account Password (CTPView Server CLI) on page 30
- Changing the Server's Root Account Password (CTPView Server CLI) on page 31
- Changing the GRUB Boot Loader Password (CTPView Server Menu) on page 31
- Changing the MySQL Apache Account Password (CTPView Server Menu) on page 32
- Changing the MySQL Root Account Password (CTPView Server Menu) on page 33
- Configuring the Network Access (CTPView Server Menu) on page 33
- Creating a Self-Signed Web Certificate (CTPView Server Menu) on page 34
- Updating the CTPView Software on page 34
- Logging In with a Browser (CTPView) on page 35
- Changing the CTPView GUI Default User Account Password (CTPView) on page 35
- Creating a New Global_Admin Account (CTPView) on page 36

Configuring the CTPView Administrative Settings

This topic provides an overview of configuring CTPView administrative settings. You must configure these settings when you receive a new CTPView server and after you install or upgrade the CTPView server operating system (OS) or the CTPView software. Many of the settings provide better access security for your CTP network. Juniper Networks recommends that you perform some of the following tasks at least every year; details are in the task.

To configure the administrative settings:

- If the CTPView server is new, prepare the server for configuring the administrative settings.

See “Preparing a New Server” on page 29.

- Change the default password used to access the BIOS menu.

See “Changing the BIOS Menu Password (CTPView Server CLI)” on page 29.

- Change the default password for the server’s default user account.

See “Changing the Server's Default User Account Password (CTPView Server CLI)” on page 30.

- Change the default password for the server’s root account.

See “Changing the Server's Root Account Password (CTPView Server CLI)” on page 31.

- Change the default password used to access the GRUB Boot Loader menu.

See “Changing the GRUB Boot Loader Password (CTPView Server Menu)” on page 31.

- Change the default password for the MySQL server Apache user account.

See “Changing the MySQL Apache Account Password (CTPView Server Menu)” on page 32.

- Change the default password for the MySQL server Root user account.

See “Changing the MySQL Root Account Password (CTPView Server Menu)” on page 33.

- Configure the server to operate on your network.

See “Configuring the Network Access (CTPView Server Menu)” on page 33.

- Create a self-signed Web certificate.

See “Creating a Self-Signed Web Certificate (CTPView Server Menu)” on page 34.

- Update the CTPView software to ensure that you have the latest features.

See “Updating the CTPView Software” on page 34.

- Verify that you can log in to the CTPView GUI from your Web browser.

See “Logging In with a Browser (CTPView)” on page 35.

- Change the default password for the CTPView GUI default user account.

See “Changing the CTPView GUI Default User Account Password (CTPView)” on page 35.

- Create at least one global administrative account to access the CTPView Admin Center in the CTPView GUI.

See “Creating a New Global_Admin Account (CTPView)” on page 36.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Preparing a New Server

When you receive a new CTPView server, you must perform some physical tasks before proceeding.

To prepare a new server for use:

1. If you wish to install the server in an equipment rack, follow the instructions provided in the *Rack Installation Guide* that is included with the server.

2. Connect a monitor and keyboard to the server.

The server's serial COM1 port connection has the following configuration:

- Speed—9600 bps
- Data bits—8
- Parity—none
- Stop bits—1

3. Connect the server to the appropriate Ethernet network through the 10/100Base-T port labeled 1.

4. Verify that all ground and power connections to the server chassis are secure. Power on the server and monitor the front panel LEDs to verify that the server boots properly.

Related Documentation

- [Configuring the CTPView Administrative Settings on page 27](#)

Changing the BIOS Menu Password (CTPView Server CLI)

For security purposes, change the default password for BIOS menu access. This account has no username associated with it. The BIOS menu password should conform to your local password requirements.



BEST PRACTICE: Change the BIOS menu password at least yearly and whenever administrators change.

To change the BIOS menu password:

1. Power on or reboot the server.
2. During the boot process, press F2 while the Dell logo is displayed on the monitor. The boot process continues and displays several messages in turn on the screen.
3. Enter the default password when the process pauses and displays “Enter Setup Password.”

For the default BIOS menu password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39.

4. At the BIOS menu, select **System Security** and press Enter.
5. Highlight **Setup Password**—be sure that you have not selected **System Password**—and press Enter.
6. Enter your new BIOS password, reenter it, and then Press Enter to continue.
7. Press Esc.
8. In the window that opens, select **Save Changes and Exit** and press Enter.
The server restarts.

**Related
Documentation**

- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Changing the Server's Default User Account Password (CTPView Server CLI)

For security purposes, change the default password for the server's default user account. You can choose instead to delete the default user account when all other administrative configuration tasks have been completed.



CAUTION: Do not delete the default user account until after you have created another user account. Otherwise, you will not be able to log in to the server.

To change the password for the server's default user account:

1. Log in to the CTPView server as the default user, using either a directly connected keyboard and monitor or an SSH application over your network.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

For the default account username and password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39. You cannot log in using the root account.

2. Enter **passwd**.
3. When prompted, enter the new password for the default user account.

**Related
Documentation**

- Configuring the CTPView Administrative Settings on page 27
- CTPOS and CTPView Software Password Requirements on page 40

Changing the Server's Root Account Password (CTPView Server CLI)

For security purposes, change the default password for the server's root user account. The root account password should conform to your local password requirements.



BEST PRACTICE: Change the root account password at least yearly and whenever administrators change.

To change the root account password:

1. Log in to the CTPView server as a non-root user, using either a directly connected keyboard and monitor or an SSH application over your network.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

2. Enter **su -** to switch to the root account.

3. Enter the default root password.

For the default root password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39. You cannot log in using the root account.

4. Enter **passwd**.

5. Enter your new password.

Related Documentation

- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Changing the GRUB Boot Loader Password (CTPView Server Menu)

For security purposes, change the default password for the GRUB Boot Loader menu.



BEST PRACTICE: Change the GRUB Boot Loader password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

To change the GRUB Boot Loader password:

1. From the CTPView Configuration Menu, select **Option 8 (GRUB Functions)**.
2. Select **1) Change GRUB password**.
3. Follow the prompts to complete changing the password.

**Related
Documentation**

- CTPOS and CTPView Software Password Requirements on page 40
- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Changing the MySQL Apache Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server Apache user account.



BEST PRACTICE: Change the MySQL Apache password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

To change the MySQL Apache password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **2) Change MySQL Apache password**.
3. Follow the prompts to complete changing the password.

**Related
Documentation**

- CTPOS and CTPView Software Password Requirements on page 40
- Configuring the CTPView Administrative Settings on page 27

- Changing Passwords to Improve Access Security on page 119

Changing the MySQL Root Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server root user account.



BEST PRACTICE: Change the MySQL Root Account password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

To change the MySQL root account password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **1) Change MySQL root password**.
3. Follow the prompts to complete changing the password.

Related Documentation

- CTPOS and CTPView Software Password Requirements on page 40
- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Configuring the Network Access (CTPView Server Menu)

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address.

To configure server access to your network:

1. From the CTPView Configuration Menu, select **2) System Configuration** and enter **y** to continue.
2. Select **1) Display Current Configuration** to review the current configuration.
3. Use options **2)** through **5)** to configure the server to operate on your network.
4. Exit the submenu to implement your changes.

Related Documentation

- Configuring the CTPView Administrative Settings on page 27

Creating a Self-Signed Web Certificate (CTPView Server Menu)

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To create a self-signed Web certificate:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **4) Reset CTPView Self-Signed Certificate**.
3. Enter answers for each question that is subsequently displayed.



NOTE: For **Common Name**, enter the IP address of the server. Otherwise, your users' browsers will report a domain name mismatch when users connect to the server.

Related Documentation

- Configuring the CTPView Administrative Settings on page 27

Updating the CTPView Software

or a new server, upgrade to the latest version of the CTPView software to ensure that you have the latest features available.

To update the CTPView software:

1. Use your Juniper Networks customer support username and password to log in to the CTP support site at <https://www.juniper.net/customers/csc/software/ctp/>.
2. If present, download an update for your version of the CTPView software and the associated Release Notes.

The CTPView version number is displayed in the heading of the CTPView Configuration Menu utility.

- Upgrade the CTPView software according to the instructions presented in “Upgrading Only the CTPView Software” on page 23.



NOTE: Always refer to the Release Notes associated with the update. These Release Notes may contain information that supersedes the information in that topic.

- Related Documentation**
- Configuring the CTPView Administrative Settings on page 27

Logging In with a Browser (CTPView)

Verify that you can log in to the CTPView software from a Web browser. You must be able to access the CTPView software to complete the administrative configuration.

To log in to the server with a browser:

- In the address bar of a browser enter the address <https://your-server-IP-address>.
- Accept the certificate when your browser warns that the security certificate presented by the website was not issued by a trusted certificate authority.
- When the CTPView login page appears, log in as the default CTPView user for the Global_Admin account.

For the default password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39.

- Related Documentation**
- Configuring the CTPView Administrative Settings on page 27

Changing the CTPView GUI Default User Account Password (CTPView)

For security purposes, change the default password for the CTPView GUI default user account.

To change the CTPView default user account password:

- Log in to the CTPView GUI with the default username and password.

For the default username and password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39. You cannot log in using the root account.
- Click **Edit My Account**.
- Type the current password and the new password, and reenter the new password.

Click **Password Help** to learn how to create an acceptable CTPView password.
- Click **Update Password**.

- Related Documentation**
- CTPOS and CTPView Software Password Requirements on page 40
 - Configuring the CTPView Administrative Settings on page 27

Creating a New Global_Admin Account (CTPView)

A global administrative (Global_Admin) account is required to access the CTPView Admin Center. Do not use the default user account for routine access. Create a separate account for each user that requires administrative access. Beginning with CTPView 2.2R2, the security-enhanced interface allows only one active session per username. When a second user attempts to log in with the same username in an active session, both IP addresses for the clients and the username are locked from access for a preset lockout period.

To create a Global_Admin account:

1. Log in to the CTPView GUI with the default username and password.
For the default username and password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39.
2. Click **Admin Center**.
3. Select **Users > All Users**.
4. Type the desired username, group name, and password, and click **Add User**.
5. Select **Users > Modify User Properties**.
6. Select the **Global_Admin** user level.
7. Log out of CTPView and use the new account to log back in.

- Related Documentation**
- CTPOS and CTPView Software Password Requirements on page 40
 - Configuring the CTPView Administrative Settings on page 27

Upgrade Tasks for CTPOS

- Using the CTPView Server Software to Update CTPOS (CTPView) on page 37
- Burning CTPOS Images to a CompactFlash Card (CTPView Server CLI) on page 38

Using the CTPView Server Software to Update CTPOS (CTPView)

You can use the CTPView software to distribute and install CTPOS update archive files on the CTP platforms in your network.

To update CTPOS:

1. Access the CTP platform software download page at the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>.
2. Use a Secure Copy Protocol (SCP) program to copy the web archive file to the **ctp** directory on the CTPView server.

You must be a member of the **server** group to access this directory. The CTPView server automatically checks and modifies the copied file's ownership and permissions as necessary.

3. Log in to the CTPView GUI.
4. In the side pane, select **Node > Maintenance**.
5. Click **Upgrade CTP Software**.

The Upgrade CTP Software window is displayed.

6. Select the desired archive file from the list.
7. Click the name of the platform you want to update.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

8. Click **Upgrade CTP(s)**.

The selected CTP platforms are upgraded sequentially. A progress window shows the status of the upgrade.

Related Documentation • Default CTPOS and CTPView Accounts and Passwords on page 39

Burning CTPOS Images to a CompactFlash Card (CTPView Server CLI)

Before using CTPView to burn CTP software images onto CompactFlash cards, you must copy the appropriate CTP image files to the proper directory on the CTPView server. Released versions of CTP operating system software images are available for download from the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw>. You need your customer support username and password to access this site.

Place the CTP flash image file on the CTPView server in the `/var/www/html/flash/` directory. To copy software into this directory, you must be a root user or a member of the UNIX group `server`, such as the default user `juniper`. You do not need to modify the file's ownership and permissions after you copy it into the `/flash` directory.

You must have physical access to the CTPView server to perform this procedure.

To burn a CTPOS image to a CompactFlash card:

1. Place the new CompactFlash card into a USB CompactFlash card adapter, and insert the adapter into one of the USB ports on the CTPView server.

The CTPView server automatically mounts the adapter.

2. Log in to the CTPView server and switch to the root account.

Use a directly connected monitor and keyboard or use SSH from a remote computer to log in to the server.

3. Change directories to `/var/www/html/flash`.

4. Enter `./burn flash_version`.

The image filename is `flash_version`. If you fail to include the version when you enter the command, the CTPView server displays usage instructions and a list of available flash images.

5. Answer the screen prompts to complete the process.

6. Log out of the server and remove the USB CompactFlash card adapter.

CHAPTER 7

Default Accounts and Passwords

- Default CTPOS and CTPView Accounts and Passwords on page 39
- CTPOS and CTPView Software Password Requirements on page 40

Default CTPOS and CTPView Accounts and Passwords

This topic lists the default accounts and passwords for the CTP Series platforms and the CTPView server.

Table 1 on page 39 lists the default accounts and passwords to access the CTPView server.

Table 1: CTPView Server Default Accounts and Passwords

Application	Account	Default Username	Default Password
Server (CLI)	BIOS menu	Not applicable	CTPView-2-2
Server (CLI)	GRUB boot loader	Not applicable	CTPView-2-2
Server (CLI)	user account	juniper (lowercase j)	CTPView-2-2
Server (CLI)	root account	root	CTPView-2-2
CTPView (browser)	Global_Admin account	Juniper (uppercase J)	CTPView-2-2
MySQL (CLI)	root account	root	CTPView-2-2
MySQL (CLI)	Apache account	ctpview_mysql	CTPView-2-2



NOTE: Upgrading from a CTPView software version lower than 2.2 to the current software does not change the existing server passwords or accounts except to add the *juniper* user account. However, all the user accounts that existed in the lower version of the CTPView software are removed. In the higher versions, browser access to the CTPView server is through a login interface, which requires that an administrator create new usernames and passwords.

Table 2 on page 40 lists the default accounts and passwords to access CTPOS on the CTP Series platforms.

Table 2: CTPOS Default Account and Password

Application	Account	Default Username	Default Password
CTP platform	CLI menu	ctp	ctp

- Related Documentation**
- Updating the CTPView Server Operating System and CTPView Network Management System Software on page 10
 - Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
 - Upgrading Only the CTPView Software on page 23
 - Setting a New Password for a Nonroot User Account (CTPView Server CLI) on page 133
 - Setting a New Password for a Root User Account (CTPView Server CLI) on page 134
 - CTPOS and CTPView Software Password Requirements on page 40

CTPOS and CTPView Software Password Requirements

Certain requirements apply to passwords for the following:

- CTPOS
- CTPView server shell access accounts
- CTPView GUI access accounts
- MySQL accounts
- GRUB Boot loader

New passwords must include the following:

- From 15 to 56 characters in total
- At least one lowercase letter
- At least one uppercase letter
- At least one numeral
- At least one of the following nonalphanumeric characters: ~ ! @ # % & - _ = { } [] ,
- At least five characters that are not present in the old password. This requirement applies only to user account passwords.

New passwords must not include either of the following:

- The username as part of the password.
- More than two adjacent repeated characters.

**Related
Documentation**

- CTPView Network Management System Administration
- Managing CTPView Users with the CTPView Admin Center on page 47
- Adding New CTPView Users (CTPView) on page 49
- Changing the MySQL Apache Account Password (CTPView Server Menu) on page 32
- Changing the MySQL Root Account Password (CTPView Server Menu) on page 33
- Changing the GRUB Boot Loader Password (CTPView Server Menu) on page 31
- Setting a New Password for a Nonroot User Account (CTPView Server CLI) on page 133
- Setting a New Password for a Root User Account (CTPView Server CLI) on page 134
- Default CTPOS and CTPView Accounts and Passwords on page 39

CHAPTER 8

Understanding CTPView Upgrade Files

- Understanding CTPView Software Upgrade Files on page 43

Understanding CTPView Software Upgrade Files

The CTPView software upgrade file that you download from the Juniper Networks Customer Support site at <https://www.juniper.net/customers/csc/software/ctp/#sw> depends on the CTPView server's operating system (OS), the version of CTPView software currently installed on the server, and the CTPView software release that you want to upgrade to. Table 3 on page 43 lists the combinations of OS and CTPView software and the associated upgrade file. The *CTPView Release Notes* for the version you are upgrading to also describes the upgrade files required for various combinations of currently installed CTPView server OS and CTPView software.

Table 3: CTPView Software Upgrade Files

CTPView Server OS	Installed CTPView Release	Upgrade to CTPView Release	Archive File for Upgrade	Server Reboots During Upgrade?
FC9	3.4R1 or later	3.4R1	web_fcX_3.4R1_090715.tgz	No
FC9	3.3Rx	3.4R1	ctpview_fc9_complete_3.4R1_090715.tgz	No
FC9	3.2Rx	3.4R1	ctpview_fc9_complete_3.4R1_090715.tgz	Yes
FC9	3.2R3 or higher	3.3R2	web_fcX_3.3R2_090616.tgz	No
FC9	3.2R3 or higher	3.2R4	web_fcX_3.2R4_090903.tgz	No
FC9	3.2R3 or higher	3.2R3	web_fcX_3.2R3_090402.tgz	No
FC9	3.2R1 or 3.2R2	3.3R2	ctpview_fc9_complete_3.3R2_090616.tgz	Yes
FC9	3.2R1 or 3.2R2	3.2R4	ctpview_fc9_complete_3.2R4_090903.tgz	Yes
FC9	3.2R1 or 3.2R2	3.2R3	ctpview_fc9_complete_3.2R3_090402.tgz	Yes
FC9	3.2R1	3.2R2	ctpview_fc9_complete_3.2R2_090112.tgz	Yes

Table 3: CTPView Software Upgrade Files (*continued*)

CTPView Server OS	Installed CTPView Release	Upgrade to CTPView Release	Archive File for Upgrade	Server Reboots During Upgrade?
FC4	2.2R2 or higher	3.4R1	web_fcX_3.4R1_090715.tgz	No
FC4	2.2R2 or higher	3.3R2	web_fcX_3.3R2_090616.tgz	No
FC4	2.2R2 or higher	3.2R4	web_fcX_3.2R4_090903.tgz	No
FC4	2.2R2 or higher	3.2R3	web_fcX_3.2R3_090402.tgz	No
FC4	2.2R2 or higher	3.2R2	web_fcX_3.2R2_090112.tgz	No
FC4	2.2R1 or lower	3.4R1	ctpview_fc4_complete_3.4R1_090715.tgz	Yes
FC4	2.2R1 or lower	3.3R2	ctpview_fc4_complete_3.3R2_090616.tgz	Yes
FC4	2.2R1 or lower	3.2R4	ctpview_fc4_complete_3.2R4_090903.tgz	Yes
FC4	2.2R1 or lower	3.2R3	ctpview_fc4_complete_3.2R3_090402.tgz	Yes
FC4	2.2R1 or lower	3.2R2	ctpview_fc4_complete_3.2R2_090112.tgz	No
FC4	2.5Rx	2.5R4	web_fc4_2.5R4_090105.tgz	No
FC4	2.4Rx or lower	2.5R4	ctpview_fc4_complete_2.5R4_090105.tgz	No
FC1		3.2R2	Refer to 3.2 manuals	
FC1		2.5R4	refer to 2.5 manuals	

Related Documentation • [Upgrading Only the CTPView Software on page 23](#)

PART 3

Administration

- [Managing and Displaying Users \(CTPView\) on page 47](#)
- [Managing the CTPView Server \(CTPView\) on page 61](#)
- [Monitoring CTP Platforms \(CTPView\) on page 79](#)
- [Changing CTPView GUI Settings on page 91](#)
- [Managing and Displaying Users \(CTPView Server Menu\) on page 95](#)
- [Managing the CTPView Server \(CTPView Server Menu\) on page 105](#)
- [Restoring Default Values on the CTPView Server on page 115](#)
- [Changing Administrative Passwords to Improve Access Security on page 119](#)
- [Using Third-Party Software on CTPView Servers on page 125](#)

CHAPTER 9

Managing and Displaying Users (CTPView)

- Managing CTPView Users with the CTPView Admin Center on page 47
- Accessing the CTPView Admin Center (CTPView) on page 48
- Monitoring CTPView Users (CTPView) on page 49
- Adding New CTPView Users (CTPView) on page 49
- Modifying CTPView User Properties (CTPView) on page 50
- Monitoring CTPView Groups (CTPView) on page 50
- Modifying CTPView User Group Affiliation (CTPView) on page 50
- Adding a New CTPView User Group (CTPView) on page 51
- Modifying CTPView User Group Default Properties (CTPView) on page 51
- Prohibiting and Reinstating CTPView Access by Users (CTPView) on page 52
- Deleting Users and Groups (CTPView) on page 53
- Managing User Passwords (CTPView) on page 54
- Configuring User Login Properties (CTPView) on page 55
- Understanding CTPView GUI User Levels on page 58
- CTPOS and CTPView Software Password Requirements on page 58

Managing CTPView Users with the CTPView Admin Center

The CTPView Admin Center provides a central location for managing users, passwords, groups, and access for CTPView users. Only Global_Admin users can create, modify, and delete CTPView user accounts.

You can perform the following tasks in the Admin Center:

- Accessing the CTPView Admin Center (CTPView) on page 48
- Monitoring CTPView Users (CTPView) on page 49
- Adding New CTPView Users (CTPView) on page 49
- Modifying CTPView User Properties (CTPView) on page 50
- Monitoring CTPView Groups (CTPView) on page 50

- Modifying CTPView User Group Affiliation (CTPView) on page 50
- Adding a New CTPView User Group (CTPView) on page 51
- Modifying CTPView User Group Default Properties (CTPView) on page 51
- Prohibiting and Reinstating CTPView Access by Users (CTPView) on page 52
- Deleting Users and Groups (CTPView) on page 53
- Managing User Passwords (CTPView) on page 54
- Configuring User Login Properties (CTPView) on page 55

**Related
Documentation**

- CTPOS and CTPView Software Password Requirements on page 40

Accessing the CTPView Admin Center (CTPView)

The CTPView Admin Center provides a central location for managing users, passwords, groups, and access for CTPView users. Only Global_Admin users can create, modify, and delete CTPView user accounts.

To access the CTPView Admin Center:

- On the CTPView Login Page, click **Admin Center**. The CTPView Login Administration page is displayed. This documentation refers to this page as the CTPView Admin Center.

To display all configuration choices available in the CTPView Admin Center:

- From the Admin Center, click **Display All**.

Although all configuration choices are listed, clicking the button to make any configuration change returns you to the Admin Center display for only that configuration choice.

To block global access to the CTPView Admin Center:

1. From the Admin Center, click **Access To CTPView is ALLOWED**.
2. Confirm your decision when prompted.

To reinstate global access to the CTPView Admin Center:

1. From the Admin Center, click **ALL ACCESS To CTPView Is BLOCKED**.
2. Confirm your decision when prompted.

**Related
Documentation**

- Managing CTPView Users with the CTPView Admin Center on page 47

Monitoring CTPView Users (CTPView)

To display all CTPView users that are currently logged in to the server through the CTPView GUI:

- From the Admin Center, select **Users > Active Users** to display all users that are currently logged in.

A view-only table lists the username, the user browser's IP address, the time the browser session began, the time of last activity, and the current period of inactivity. Users logged in through an SSH connection to the CTPView server are not displayed; see "Managing CTPView Users (CTPView Server Menu)" on page 95 for information about viewing these users.

To display all CTPView users regardless of login status:

- From the Admin Center, select **Users > All Users**.

This view-only table displays all users who are in the CTPView user database, as well as each user's group affiliation, user level, and the time of last login.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47

Adding New CTPView Users (CTPView)

To add a new CTPView user:

1. From the Admin Center, select **Users > Add New User**.
2. Type a username for the new user.

The username must be at least 6 characters and no more than 30 characters in length. The name can include alphanumeric characters and the following nonalphanumeric characters:

~ ! @ # % & - _ = { } [] ,

3. Select a group for the new user from the list.

The new user is assigned the properties associated with this group.

4. Type a password for the user in both fields.

Click **Password Help** to display the password requirements. The user is forced to change this password at the first login.

5. Click **Add User**.

The new user is immediately added to the **All Users** table.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47
- CTPOS and CTPView Software Password Requirements on page 40

Modifying CTPView User Properties (CTPView)

CTPView users are assigned to a group when created, and inherit the properties associated with that user group. You can override these properties for any or all members of a group.

To modify CTPView user properties:

1. From the Admin Center, select **Users > Modify User Properties**.
2. Select a username from the list to display the user's current properties.
3. (Optional) Select a new user level.
4. (Optional) Select the maximum number of days allowed between logins.
5. (Optional) Select the minimum number of days allowed between password changes.
6. (Optional) Select the number of days a new password is valid.
7. (Optional) Select the number of days before password expiration that a warning is first provided.
8. (Optional) Select the number of days the user can still log in after a password expires before access is blocked.
9. (Optional) Type a date on which access is blocked from that date forward.
This field overrides all other properties.
10. Click **Update User Properties**.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47

Monitoring CTPView Groups (CTPView)

To display all CTPView user groups:

1. From the Admin Center, select **Groups > All Groups**.

The view-only table displays all groups that are currently configured. The table also lists the default user properties configured for the group. You can configure individual user properties to override the group defaults.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47

Modifying CTPView User Group Affiliation (CTPView)

CTPView users are assigned to a group when created. Typically, groups are used to group users that share a common set of user properties. However, shared properties are not a requirement. If desired, user groups can simply label a set of users without regard to their individual user properties.



NOTE: Changing a user's group affiliation does not alter the user's current properties.

To modify CTPView user properties:

1. From the Admin Center, select **Users > Modify User's Group Affiliation**.
2. Select a username from the list to display the user's current group affiliation.
3. Select a new group from the list.
4. Click **Update Group**.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47

Adding a New CTPView User Group (CTPView)

To add a new CTPView user group:

1. From the Admin Center, select **Groups > Add New Group**.
2. Enter a group name.

The group name must be at least 6 characters and no more than 30 characters in length. The name can include alphanumeric characters and the following nonalphanumeric characters:

~ ! @ # % & - _ = { } [] ,

3. Select a default user level for members of the group.
4. Click **Add Group**.

Modifying CTPView User Group Default Properties (CTPView)

CTPView users are assigned to a user group when created and by default inherit the properties associated with the group. You can override these properties for any or all members of a group.

To modify CTPView user properties:

1. From the Admin Center, select **Groups > Modify Group Properties**.
2. Select a group name from the list to display the group's current properties.
3. (Optional) Select a default user level.
4. (Optional) Select the maximum number of days allowed between logins.
The default is 30 days.
5. (Optional) Select the minimum number of days allowed between password changes.
The default is 1 day.

6. (Optional) Select the number of days a new password is valid.
The default is 60 days.
7. (Optional) Select the number of days before password expiration that a warning is first provided.
The default is 7 days.
8. (Optional) Select the number of days the user can still log in after a password expires before access is blocked.
The default is 14 days.
9. (Optional) Type a date on which access is blocked from that date forward.
This field overrides all other properties.
10. (Optional) Select **Update current members** to apply these changes to all members of the group.
If you do not select this option, the group changes do not affect any current member of the group.
11. Click **Update Group Properties**.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47

Prohibiting and Reinstating CTPView Access by Users (CTPView)

You can prevent individual users from accessing the CTPView software until you reinstate that access.

- Displaying Prohibited CTPView Users (CTPView) on page 52
- Prohibiting User Access to CTPView (CTPView) on page 52
- Reinstating Prohibited CTPView Users (CTPView) on page 53

Displaying Prohibited CTPView Users (CTPView)

To display currently prohibited CTPView users:

- From the Admin Center, select **Prohibit > Current Prohibited Users**.

The view-only table displays all prohibited users, the time each was prohibited, who prohibited the user, and the last time the user access the CTPView software.

Prohibiting User Access to CTPView (CTPView)

To prohibit a CTPView user:

1. From the Admin Center, select **Prohibit > Designate Prohibited User**.
2. Select the user from the list.
3. Click **Submit Prohibited User**.

Reinstating Prohibited CTPView Users (CTPView)

To reinstate a currently prohibited CTPView user:

1. From the Admin Center, select **Prohibit > Reinstate Prohibited User**.
2. Select the user from the list.
3. Click **Reinstate Prohibited User**.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47

Deleting Users and Groups (CTPView)

You can delete active and inactive CTPView users from the user database. Inactive users are those who have not logged in within a specified number of days; the default is 365 days. Active users have logged in more recently than the default. You can also delete user groups.

- Deleting Active CTPView Users (CTPView) on page 53
- Deleting Inactive CTPView Users (CTPView) on page 53
- Deleting Prohibited CTPView Users (CTPView) on page 54
- Deleting CTPView Groups (CTPView) on page 54

Deleting Active CTPView Users (CTPView)

To delete an active CTPView user:

1. From the Admin Center, select **Delete > Delete User**.
2. Select the user from the list.



NOTE: Prohibited and inactive users do not appear on the list and must be deleted separately.

3. Click **Delete User**.

Deleting Inactive CTPView Users (CTPView)

To delete an inactive CTPView user:

1. From the Admin Center, select **Delete > Inactive User**.
2. Select the number of days without a login to designate inactive users.
3. Click **Delete Inactive Users**.

Deleting Prohibited CTPView Users (CTPView)

To delete a currently prohibited CTPView user from the database:

1. From the Admin Center, select **Prohibit > Delete Prohibited User**.
2. Select the user from the list.
3. Click **Delete Prohibited User**.

Deleting CTPView Groups (CTPView)

To delete a CTPView user group and all its members:

1. From the Admin Center, select **Delete > Delete Group**.
2. Select the group from the list.
3. Click **Delete Group**.

Related Documentation

- [Managing CTPView Users with the CTPView Admin Center on page 47](#)

Managing User Passwords (CTPView)

You can limit how frequently a user can reuse a password, exclude passwords, reinstate excluded passwords, and specify the rules for forming passwords.

- [Limiting Password Reuse \(CTPView\) on page 54](#)
- [Excluding Passwords from Use \(CTPView\) on page 54](#)
- [Reinstating Excluded Passwords \(CTPView\) on page 55](#)
- [Changing Requirements for New Passwords \(CTPView\) on page 55](#)

Limiting Password Reuse (CTPView)

To limit how frequently a password can be reused:

1. From the Admin Center, select **Passwords > Re-Use Password Limit**.
2. Select the number of new passwords a user must create before a given password can be re-used.
3. Click **Set Password Re-Use Limit**.

Excluding Passwords from Use (CTPView)

To exclude certain passwords from use:

1. From the Admin Center, select **Passwords > Excluded Passwords**.
2. Type a password to add to the list of excluded passwords.
3. Click **Add Password to List**.

Reinstating Excluded Passwords (CTPView)

To reinstate a previously excluded password for use:

1. From the Admin Center, select **Passwords > Excluded Passwords**.
2. Select the password from the list of excluded passwords.
3. Click **Reinstate Selected Passwords**.

Changing Requirements for New Passwords (CTPView)

To change the requirements for new passwords (current passwords are not affected):

1. From the Admin Center, select **Passwords > Modify Password Requirements**.
2. (Optional) Select the minimum password length, in the range 15 through 56.
3. (Optional) Select the maximum password length, in the range 15 through 56.
The default is 56 characters.
4. (Optional) Select the minimum number of lowercase letters, in the range 1 through 56.
5. (Optional) Select the minimum number of uppercase letters, in the range 1 through 56.
6. (Optional) Select the minimum number of numerals, in the range 1 through 56.
7. (Optional) Select the minimum number of nonalphanumeric characters, in the range 1 through 56.
8. Click **Update Password Properties**.

Related Documentation

- Managing CTPView Users with the CTPView Admin Center on page 47
- CTPOS and CTPView Software Password Requirements on page 40

Configuring User Login Properties (CTPView)

You can configure a number of properties that affect how users log in to and log out of the CTPView software.

- Logging Out a CTPView User (CTPView) on page 56
- Configuring Automatic Logout for a CTPView User (CTPView) on page 56
- Configuring the Number of Login Attempts Allowed Before Lockout (CTPView) on page 56
- Configuring a Lockout Period for CTPView Users (CTPView) on page 56
- Clearing CTPView User Counters (CTPView) on page 57
- Reinstating Locked-Out IP Addresses (CTPView) on page 57

- Creating an Access Filter to Allow or Deny IP Addresses (CTPView) on page 57
- Removing an IP Access Filter (CTPView) on page 57

Logging Out a CTPView User (CTPView)

To log out a CTPView user:

1. From the Admin Center, select **Login/Logout > Logout Users**.
2. Select the user from the list.
3. Click **Logout Selected Users**.

Configuring Automatic Logout for a CTPView User (CTPView)

To specify that a CTPView user is automatically logged out after a certain period:

1. From the Admin Center, select **Login/Logout > Auto Logout**.
2. Select the inactivity period from the list.
3. Click **Set Auto Logout Period**.

Configuring the Number of Login Attempts Allowed Before Lockout (CTPView)

To specify how many times a CTPView user can attempt to log in before the login is considered to have failed and the user is locked out:

1. From the Admin Center, select **Login/Logout > Login Limit**.
2. Select the number of attempts allowed from the list.
3. Click **Set Failed Login Limit**.

Configuring a Lockout Period for CTPView Users (CTPView)

When a user exceeds the allowed number of failed login attempts or tries to open multiple CTPView sessions from unique IP addresses, the user is prevented from accessing CTPView for a lockout period.

To specify a CTPView user's lockout period:

1. From the Admin Center, select **Login/Logout > Lockout Period**.
2. Select the lockout period from the list.
3. Click **Set Lockout Period**.

Clearing CTPView User Counters (CTPView)

Two counters are associated with each CTPView user. One counter tracks the number of failed login attempts. This counter is automatically reset to zero after a successful login. The other counter tracks the number of reminders that a user receives to change the user password. This counter is automatically reset after the user has selected a new password. When either counter exceeds the allowed limit, the user is locked out of CTPView access.

To clear a user's counters:

1. From the Admin Center, select **Login/Logout > Clear Counters**.
2. Select the user from the list.
3. Click **Clear Counters**.

Reinstating Locked-Out IP Addresses (CTPView)

When a user attempts to access the CTPView software from a second IP address with a currently active username, the username and both IP addresses are locked.

To reinstate an IP address that has been locked from CTPView access:

1. From the Admin Center, select **Login/Logout > Unlock IP**.
2. Select the IP address from the list.
3. Click **Reinstate Locked IP**.

Creating an Access Filter to Allow or Deny IP Addresses (CTPView)

IP access filters enable you to specify whether users from an IP address or range of IP addresses are allowed or denied access to the CTPView software.

To create an IP access filter:

1. From the Admin Center, select **Login/Logout > IP Access Filter**.
2. Type an IP address or range of IP addresses.
3. Select whether to allow or deny that address or range access to the CTPView software.

In the case of conflict between multiple filters, a rule to deny an address or range overrides a rule that allows access.
4. Click **Add IP Range to List**.

Removing an IP Access Filter (CTPView)

To remove an IP filter:

1. From the Admin Center, select **Login/Logout > IP Access Filter**.
2. Select the IP address from the list.
3. Click **Remove IP Range From List**.

- Related Documentation**
- [Managing CTPView Users with the CTPView Admin Center on page 47](#)

Understanding CTPView GUI User Levels

This topic describes the user security levels available in the CTPView GUI.

Three user levels are provided to enhance the security of CTPView GUI logins:

- **Net_View**—Users in this class are restricted to query-only access to CTP platforms. Early versions of the CTPView software referred to this class as query-only users. Net_View users can change their own passwords.
- **Net_Admin**—Users in this class can configure CTP platforms. They do not have permission to create or modify CTPView user accounts. Early versions of the CTPView software referred to this class as administrators. Net_Admin users can change their own passwords.
- **Global_Admin**—Users in this class have all the privileges of the Net_Admin class. They are also able to create and modify user accounts. Only members of the Global_Admin user class have access to the CTPView Admin Center, where CTPView user and password profiles are managed.

Each CTPView user has a profile that describes user properties, including user privileges and restrictions. All users are assigned to user groups. Each user group has a set of default user properties that are transferred to new users created in or assigned to that group. Global_Admin users can modify any of the user properties on a per-user basis.

CTPOS and CTPView Software Password Requirements

Certain requirements apply to passwords for the following:

- CTPOS
- CTPView server shell access accounts
- CTPView GUI access accounts
- MySQL accounts
- GRUB Boot loader

New passwords must include the following:

- From 15 to 56 characters in total
- At least one lowercase letter
- At least one uppercase letter
- At least one numeral
- At least one of the following nonalphanumeric characters: ~ ! @ # % & - _ = { } [] ,
- At least five characters that are not present in the old password. This requirement applies only to user account passwords.

New passwords must not include either of the following:

- The username as part of the password.
- More than two adjacent repeated characters.

**Related
Documentation**

- CTPView Network Management System Administration
- Managing CTPView Users with the CTPView Admin Center on page 47
- Adding New CTPView Users (CTPView) on page 49
- Changing the MySQL Apache Account Password (CTPView Server Menu) on page 32
- Changing the MySQL Root Account Password (CTPView Server Menu) on page 33
- Changing the GRUB Boot Loader Password (CTPView Server Menu) on page 31
- Setting a New Password for a Nonroot User Account (CTPView Server CLI) on page 133
- Setting a New Password for a Root User Account (CTPView Server CLI) on page 134
- Default CTPOS and CTPView Accounts and Passwords on page 39

Managing the CTPView Server (CTPView)

- Adding and Removing CTP Platforms Managed by CTPView Software (CTPView) on page 61
- Adding and Removing Host Groups (CTPView) on page 62
- Adding and Removing SNMP Communities (CTPView) on page 63
- Managing CTP Platforms in the Network (CTPView) on page 64
- Configuring Email Notifications (CTPView) on page 65
- Setting the CTPView Server Start-Up Banner (CTPView) on page 66
- Setting the CTP Platforms Login Banner (CTPView) on page 66
- Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView) on page 67
- Setting the CTPView Server Clock (CTPView) on page 68
- Managing NTP Servers for the CTPView Network (CTPView) on page 69
- Configuring Automatic Monitoring of CTP Platforms (CTPView) on page 72
- Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms (CTPView) on page 73
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 74
- Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView) on page 75
- Synchronizing Multiple CTPView Servers (CTPView) on page 75

Adding and Removing CTP Platforms Managed by CTPView Software (CTPView)

Before you can use CTPView to manage the CTP platforms in your network, you must configure the platform information in the CTPView software. In the context of the network, the CTP platforms are often referred to as remote hosts, nodes, and remote platforms.

To add a CTP platform to your network:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Enter a unique name for the remote host.

3. Enter a management IP address for the host.
This address is used for the CTPView management connection to the host.
4. If the host is running CTPOS 4.1 or lower, select the checkbox.
5. Enter a password to be used by the CTPView software when accessing the host.
6. Select a group to associate with the host; only the **default** group is available if no other groups have been configured.
7. Select the model number for the host.
8. Include or exclude the host from monitoring by the CTPView software by selecting **Yes** or **No**.
9. Select how the CTPView software accesses the host when the host has been including for network monitoring.
10. Select the SNMP community associated with the host.
11. Click **Add New Remote Host**.

To remove a CTP platform from your network:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click the **Remove Remote Host** field, select the group to which the host belongs, and then select the remote host.
3. Click **Remove Remote Host**.

Adding and Removing Host Groups (CTPView)

CTPView software enables you to create host groups. Subsequently you assign one or more CTP platforms to each host group. The host groups enable easier connection and monitoring of CTP platforms, especially as your network becomes large and complex. Host groups are displayed at the top of the CTPView side pane. There you can choose a group and then connect to a host that is a member of that group.

Host groups and names are often configured based on geography or application type. If you do not define a group, then the CTP platforms are placed in the default group.

To add a host group:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Enter a unique name for the host group.
Group names can include from 3 to 20 characters consisting of letters, numbers, hyphens, and underscores.
3. Click **Add New Group**.

To remove a host group:



NOTE: Removing a host group automatically deletes all host that are members of that group. If that is not your intention, move those hosts to another group before you perform the following steps.

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click the **Remove Host Group** field and select the group.
3. Click **Remove Group**.

**Related
Documentation**

- [Managing CTP Platforms in the Network \(CTPView\) on page 64](#)

Adding and Removing SNMP Communities (CTPView)

You can configure SNMP communities for management of CTP platforms in your network.

To add an SNMP community:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Enter a unique name for the community.
3. Click **Add New Community**.

To remove an SNMP community:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Select the community.
3. Click **Remove Community**.

**Related
Documentation**

- [Managing CTP Platforms in the Network \(CTPView\) on page 64](#)

Managing CTP Platforms in the Network (CTPView)

When CTP platforms have already been configured in the CTPView software, you can subsequently change many aspects of that configuration.

To manage a CTP platform (remote host) in your network:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Manage Network Hosts**.
The Manage Network pane is displayed.
3. Select a host group and click **Show Selected Groups**.
A table listing all CTP platforms in the network is displayed.
4. (Optional) Select a different **Group Name** to change the host's group affiliation.
5. (Optional) Make a selection in the **Monitor** column to change whether CTPView monitors the host.
6. (Optional) Make a selection in the **Connect Type** column to change how CTPView accesses a monitored host.
7. (Optional) Make a selection in the **SNMP Community** column to change the SNMP community associated with the host.
8. Click **Submit Changes**. If you do not want to submit your changes, then click **Reset**.

Alternatively, you can perform the following steps to access CTP platform management:

1. In the side pane, select **Network > Monitoring**.
The Administrative Functions pane is displayed.
2. Click **Manage Network Hosts**.
The Network Monitoring pane is displayed.
3. Click **Manage Network**.
The Manage Network pane is displayed.
4. Perform steps 3 through 8 as described above.

Related Documentation

- [Monitoring the Network with the CTPView Software \(CTPView\) on page 79](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 80](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 81](#)

Configuring Email Notifications (CTPView)

You can configure the CTPView software to send email notifications to a distribution list when certain events take place on the CTP platform. Table 4 on page 65 lists the events for which you can configure email notification.

Table 4: CTP Platform Events for Email Notifications

Event
CTP platform state is Unreachable.
CTP platform state is Check Host.
CTP port state is Active-Down.
CTP port state is Assessing.
CTP port state is Active-Up.
CTP port state is Disabled.

To configure email notifications for CTP platform events:

- In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
- Click **Email Notifications**.
The Email Notifications window is displayed.
- Enter the name or IP address of a qualified mail server.
- Click **Change Mail Server**.
- Click **Send Test Email** to verify email connectivity.
- Type an email address in the **Add Recipient to List** field.
- (Optional) Check **Add Recipient to all Lists** if you want the recipient to receive notification for all events.
- Click **Add Email Address** to add the recipient to the master list of email recipients.
- For any event listed in Table 4 on page 65, select a recipient for notification and click **Add Recipient**.
- Click **Close Window** when finished.

To remove recipients from a notification list:

- In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
- Click **Email Notifications**.

The Email Notifications window is displayed.

3. Do either of the following:
 - Select a recipient from the master list, and click **Remove Email Address** to remove the recipient from all notifications.
 - Select a recipient from any of the event lists, and click **Remove Recipient** to remove the recipient from that list.
4. Click **Close Window** when finished.

**Related
Documentation**

- [Monitoring the Network with the CTPView Software \(CTPView\)](#) on page 79

Setting the CTPView Server Start-Up Banner (CTPView)

When you log in to the CTPView server, a log-in or start-up banner presents a message. This banner is displayed whether you log in through the CTPView GUI or through an SSH connection. You can change the banner to display the desired message.

To set the start-up banner:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.
2. Click **Set Start-up Banner**.

The Modify Start-Up Banner Content window is displayed.
3. Type your message in the field.
4. Click **Submit Changes**. If you do not want to submit your changes, then click **Undo Changes**.

**Related
Documentation**

- [Setting the CTP Platforms Login Banner \(CTPView\)](#) on page 66

Setting the CTP Platforms Login Banner (CTPView)

When you log in to the CTP platforms through an SSH connection, a banner presents a message. You can change the banner to display the desired message. You can also configure different banners for different CTP platforms.

To set the platform login banner:

1. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.
2. Click **Update CTP Login Banner**.

The Upgrade CTP Banner window opens and displays the current CTPView software start-up banner and a list of platform groups and their members.

3. Skip to step 8 if you want to copy the current banner to the CTP platforms.
4. Click **Change Banner** to use a message different than the current banner.
The Modify Start-Up Banner Content window is displayed.
5. Type your message in the field.
6. Click **Submit Changes**. This action changes the start-up banner for CTPView itself. If you do not want to submit your changes, then click **Undo Changes**.
7. Click **Return to CTP Banner Upgrade**.
8. Click the name of a platform. You can select more than one platform by holding down the Ctrl key when you click the platform names.
9. Click **Upgrade Banner on CTP(s)**.
The banner is pushed to each selected CTP platform. The new login banner is displayed in your terminal window when you create an SSH connection to the platform. It is also displayed when you log in to the CTPView server through the CTPView GUI or through an SSH connection.

Related Documentation

- Setting the CTPView Server Start-up Banner (CTPView) on page 66

Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView)

This topic describes how to configure CTP platforms so that an SSH connection remains established for the entire session when the CTPView server connects to the platform.

SSH port forwarding creates an encrypted and protected connection between the CTPView software and a remote CTP platform, that remains up as long as the server connection to the platform is up. It must be enabled on both the CTP platform and the CTPView software; it is enabled on both by default. When this feature is not enabled, the CTPView server creates a separate SSH connection to the platform for each command and configuration change. This feature reduces overhead and increases performance of the CTPView software. You can choose to disable this feature or reenale it.

To disable SSH port forwarding on the connected CTP platform:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **CTP Port Forwarding Is Allowed** and confirm the action when prompted.
The button text changes to **CTP Port Forwarding Is Prohibited**.

To enable SSH port forwarding on the connected CTP platform:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **CTP Port Forwarding Is Prohibited** and confirm the action when prompted.

The button text changes to **CTP Port Forwarding Is Allowed**.

You can also change the state of this feature by selecting **System > Configuration** in the side pane and clicking **SysMon**. You can then select **Enabled** or **Disabled** for the feature.

When the SSH port forwarding connection is successfully made to a connected CTP platform, Port Forwarding is displayed at the top of the side pane immediately under the name of the connected CTP platform.

- Related Documentation**
- **Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView Server Menu)** on page 109

Setting the CTPView Server Clock (CTPView)

The date and time configured on the CTPView server is displayed in the heading section of the CTPView GUI, regardless of which pane is currently displayed. You can change the time zone, date, and time for the server.



NOTE: We strongly recommend that you set the time zone to Coordinated Universal Time (UTC) on all CTPView servers and CTP platforms in your network. This practice is necessary to enable the statistics graphs of CTP network behavior to accurately represent when particular events occurred. CTP platform time is set when you first power up the device.

To set the date and time on the CTPView server clock:

1. In the heading section, click the globe icon to the right of the current time display.
The Clock CTPView window is displayed.
2. (Optional) Select a different time zone and click **Submit New Timezone**.



NOTE: Changing the time zone reboots the CTPView server.

3. If you want only to adjust the time and not change the time zone, click **Cancel**.
The Clock CTPView window now displays the current time and fields for the new time.
4. Select new values to adjust any or all of the day, month, year, hour, minute, or second, and click **Submit Changes**.

The current time displayed in the CTPView GUI does not update automatically. When you navigate to any other pane in the software, the time display updates.

- Related Documentation**
- **Powering On the CTP Platform**
 - **Managing NTP Servers for the CTPView Network (CTPView)** on page 69

Managing NTP Servers for the CTPView Network (CTPView)

NTP servers are used to synchronize system clocks over an IP network. You can manage your NTP peers and clients from the NTP Server Settings window. This window displays the results of a query of the configured NTP peers. Table 5 on page 69 describes the information provided in the results. From this window you can stop the NTP daemon, add and remove NTP peers, and synchronize to a particular peer. For more information about the information displayed in the summary, consult a reference on NTP.

Table 5: Summary Information for NTP Server Peers

Field	Description
remote	Hostname or IP address of the reference clock source. LOCAL refers to the system time on the NTP server. Table 6 on page 69 describes the meaning of a prefix to the name or address.
refid	Reference ID that identifies the type of the reference clock. Typically this is the master clock to which that NTP server peer is synchronized. When the master clock is unknown, 0.0.0.0 is displayed.
st	Stratum number of the NTP server peer.
t	Remote peer type: broadcast, local, multicast, or unicast.
when	Time since the last packet was received, in seconds. When this value matches the poll value, the reference clock is queried, and when is reset to zero.
poll	Polling interval, in seconds.
reach	Reachability register, displayed in octal format. Indicates whether data was readable from the NTP server peer at the last poll, and whether the peer was synchronized to another time source.
delay	Current estimated round-trip time for queries to the remote peer.
offset	Difference between the reference time value and the CTPView server clock.
jitter	Magnitude of the jitter between several time queries.

A prefix to the peer name or IP address indicates the fate of the peer in the clock selection process. Table 6 on page 69 describes the possible values.

Table 6: Prefixes Designating Peer Clock Selection Status

Prefix	Meaning
space	The peer is discarded as unreachable, synchronized to this server (I a synchronization loop), or having a very large synchronization distance.
x	Peer is discarded by the intersection algorithm as a false ticker.
-	Peer is discarded by the clustering algorithm as an outlier.
+	Peer is a survivor and a candidate for the combining algorithm.

Table 6: Prefixes Designating Peer Clock Selection Status (continued)

#	Peer is a survivor, but is not one of the first six peers sorted by synchronization distance. If the association is ephemeral, it may be demobilized to conserve resources.
*	Peer has been declared the system peer and lends its variables to the system variables.
o	Peer has been declared the system peer and lends its variables to the system variables. However, the actual system synchronization is derived from a pulse-per-second (PPS) signal, either indirectly by means of the PPS reference clock drive or directly by means of the kernel interface.

A summary of NTP network client access lists the IP address and netmask for each network client. You can add and remove network clients and modify client netmasks.

- Accessing the NTP Server Settings Window (CTPView) on page 70
- Stopping the NTP Daemon (CTPView) on page 70
- Adding an NTP Peer (CTPView) on page 70
- Removing an NTP Peer (CTPView) on page 71
- Synchronizing the CTPView Server to an NTP Peer (CTPView) on page 71
- Adding NTP Network Clients (CTPView) on page 71
- Removing an NTP Network Client (CTPView) on page 71
- Modifying the Netmask of an NTP Network Client (CTPView) on page 71

Accessing the NTP Server Settings Window (CTPView)

To configure NTP servers:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **NTP Server Configuration**.
The NTP Server Settings window is displayed.

Stopping the NTP Daemon (CTPView)

To stop the NTP sever daemon:

- In the NTP Server Settings window, click **Stop NTP Daemon**.
The connection to the listed NTP server peers is brought down, and the Summary of NTP Server Pairs table is cleared.

Adding an NTP Peer (CTPView)

To add an NTP peer to the summary table:

1. In the NTP Server Settings window, type an IP address or fully qualified domain name in the Manage NTP Peers section.
2. Click **Add New NTP Peer**.

The peer address or name and information appear in the summary table.

Removing an NTP Peer (CTPView)

To remove an NTP peer from the list of configured peers:

1. In the NTP Server Settings window, select a peer to remove in the Manage NTP Peers section.
2. Click **Remove Selected Peer**.

The peer is removed from the table, and the NTP daemon is restarted if it was running.

Synchronizing the CTPView Server to an NTP Peer (CTPView)

To manually synchronize the server to an NTP peer:

1. In the NTP Server Settings window, select a peer for synchronization in the Manage NTP Peers section.
2. Click **Sync to Selected Peer**.

Adding NTP Network Clients (CTPView)

To add a new network client:

1. In the NTP Server Settings window, type an IP address or fully qualified domain name in the Manage NTP Client Access section.
2. Click **Add New Network Client**.

The client address or name and netmask appear in the summary table.

Removing an NTP Network Client (CTPView)

To remove an NTP network client from the list of configured clients:

1. In the NTP Server Settings window, select a client to remove in the Manage NTP Client Access section.
2. Click **Remove Selected Network Client**.

The client is removed from the table, and the NTP daemon is restarted if it was running.

Modifying the Netmask of an NTP Network Client (CTPView)

To modify a client netmask:

1. In the NTP Server Settings window, select a client in the Manage NTP Client Access section.
2. Select a new netmask.
3. Click **Modify Client Netmask**.

Configuring Automatic Monitoring of CTP Platforms (CTPView)

You can configure certain monitoring operations to be automatically performed on the CTP platforms in the network. You manage these operations in the CTPView Automatic Functions window. This window displays a summary table of the currently configured automatic settings for the connected CTP platform. Table 7 on page 72 describes the information provided in the table. From this window you can add and remove automatic operations for the CTP platform, and configure the monitoring details.

Table 7: Current CTPView Automatic Settings

Field	Description
Action	<p>One of the following monitoring operations:</p> <ul style="list-style-type: none"> Backup Current MySQL Databases Gather Remote Host Statistical Data—Retrieves the data used to create the plots of IP Buffer Usage, Delay Jitter, Round Trip Delay, and Missing Packets. Update Network Interface Device Information—Collects network interface device information. Use this automatic function if you configure virtual IP addresses using the CLI or if you use multiple CTPView servers to configure CTP platforms and virtual IP addresses. Remove Outdated Files—Removes older files (typically CTP platform statistical data) based on the age of the data. The age criterion can be set to 6, 9, or 12 months. We recommend that you configure this automatic function to ensure that the file system does not become filled. Synchronize Secondary Servers—Copies information from the primary server to each secondary server. The information includes SSH keys, archived port configurations, email notifications, port forwarding settings, trigger point for hard drive usage warning level, and CTP platform identification information (IP address, hostname, group name). Synchronize Secondary Servers and Remote Hosts—Copies information from the primary server to each secondary server and CTP platform. The information transferred to the secondary servers includes SSH keys, archived port configurations, email notifications, port forwarding settings, trigger point for hard drive warning usage level, CTP identification information (IP address, hostname, group name), and CTP statistical data. The function copied from the primary server to CTP platforms includes each secondary server's SSH key. Save Current CTP Host System Configuration—Saves every CTP platform configuration at the specified time interval. CTPView will save the 10 most recent configurations.
Minute	Minute of the hour when the operation is scheduled to take place.
Hour	Hour of the day when the operation is scheduled to take place.
Day	Date when the operation is scheduled to take place.
Month	Month when the operation is scheduled to take place.
Day of Week	Day of the week when the operation is scheduled to take place.

- [Accessing the CTPView Automatic Functions Window \(CTPView\) on page 73](#)
- [Adding an Automatic Monitoring Operation \(CTPView\) on page 73](#)
- [Removing an Automatic Monitoring Operation \(CTPView\) on page 73](#)

Accessing the CTPView Automatic Functions Window (CTPView)

To configure automatic functions:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

2. Click **Automatic Functions**.

The CTPView Automatic Functions window is displayed.

Adding an Automatic Monitoring Operation (CTPView)

To add an automatic monitoring operation:

1. In the CTPView Automatic Functions window, select an action.
2. Select when you want the operation to take place.

The numbers you select represent a specific time, not an interval of time. For example, the default setting of [0,1,ANY,ANY,ANY] means that action occurs at the 0 minute (on the hour) of the first hour (1 AM) every day (any day of any month, landing on any day of the week). A setting of [30,16,8,ANY,ANY] causes the action to occur at 4:30 PM on the 8th of every month.

3. Click **Add New Entry**; the operation appears in the summary table.

If you decide not to add the entry, click **Reset**.

To have the same function performed at different times, add a new entry for that operation for each time.

Removing an Automatic Monitoring Operation (CTPView)

To remove an automatic monitoring operation:

1. In the summary table in the CTPView Automatic Functions window, click the **Remove** checkbox for each action you want to remove.
2. Click **Remove Selected Lines**; the operation disappears from the summary table.

Related Documentation

- [Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms \(CTPView\) on page 73](#)
- [Synchronizing Multiple CTPView Servers \(CTPView\) on page 75](#)

Setting a Limit on File Transfer Bandwidth Between the CTPView Server and CTP Platforms (CTPView)

You can specify a limit on the bandwidth used for file transfers between the CTPView server and the CTP platforms in the network. By default, the *bandwidth throttling* value is set to 100,000 Kbps, the full bandwidth available on the server's Ethernet port.

Throttling the bandwidth is typically not necessary and may be required only when the local LAN segment experiences significant load and bandwidth limitations.

The following functions are affected by bandwidth throttling:

- Gathering statistical data for plots
- Synchronizing secondary CTPView servers
- Saving CTP platform configurations
- Modifying CTP platform login banners
- Upgrading the CTP operating system software



NOTE: The bandwidth throttling configuration has no effect on data packet throttling.

To configure the bandwidth limit:

1. In the side pane, select **Server > Administration**.
The Administrative Functions pane is displayed.
2. Click **Automatic Functions**.
The CTPView Automatic Functions window is displayed, and shows the current value for bandwidth throttling for the CTPView server.
3. Select a new throttling value.
4. Click **Modify Throttle Value**.

**Related
Documentation**

- Configuring Automatic Monitoring of CTP Platforms (CTPView) on page 72

Restoring CTPView Software Configuration Settings and Data (CTPView)

This topic lists two methods to restore the CTPView software configuration settings and data. Typically you restore this information only after one of the following events has occurred:

- An installation of the latest version of the CTPView server operating system, which reformats the server's hard drives.
- In the unlikely event of a data loss.

Use one of the following methods to restore saved CTPView information:

- Use the CTPView restore utility in the CTPView server menu. You must use this method when you have only a single CTPView server.

See "Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)" on page 20.

- Synchronize the server. This method is available only when you have two or more CTPView servers in your network.

See “Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)” on page 20.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Restoring CTPView Software Data by Manually Synchronizing the CTPView Server (CTPView)

This topic describes how to use CTPView server synchronization to restore the CTPView software configuration settings and data.

To restore your saved information by synchronizing the CTPView server with another server:

1. Log in to the CTPView GUI on the server for which you are restoring the data.
2. In the side pane, select **Server > Administration** to display the Administrative Functions pane.
3. Click **Server Synchronization**.
4. Verify that the server is either not listed or its Server Type is set to Not Selected.
5. Log in to the CTPView GUI on the server from which you are restoring the data.
6. In the side pane, select **Server > Administration** to display the Administrative Functions pane.
7. Click **Server Synchronization**.
8. Ensure that the Server Type is set to Primary Server for this server, Secondary Server for the server being updated, and Not Selected for all other CTPView servers listed.
9. Click **Manually Synchronize Network**.
The Synchronize Secondary Servers window opens.
10. Click **Select All Hosts**, and then click **Synchronize Servers**.
11. When the synchronization is completed, restore the Server Type for all CTPView servers to the values that you normally use for your network.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 19

Synchronizing Multiple CTPView Servers (CTPView)

When you have more than one CTPView server in your network, you can synchronize some or all of the servers to the same configuration. You must designate one server as the primary server and the others as secondary servers. When you add a secondary server,

the primary server sets up SSH authorization keys with the secondary server so it can communicate without requiring the login password again. The server configuration settings apply only to the server you are logged in to. These settings do not affect the other CTPView servers in the network.

The primary server has a 15-second period to establish contact with a remote CTP platform. If the period times out, the primary server skips to the next remote CTP platform and continues executing the program. This information is displayed in the screen output and logs. When you add a new remote CTP platform to a primary server, the new platform's SSH RSA keys are also exchanged with each secondary server. You can disable this feature in the Administrative Functions pane when you add the new remote platform.

The following definitions are restricted in scope to the server that you are logged in to. Each server maintains its own file of server designations that it refers to when performing a server synchronization. You do not need to configure settings on a remote secondary server for that server to be updated by the primary server that is performing the synchronization.

- **Primary server**—You can designate any server running the correct CTPView software version as a primary server. The primary server runs the synchronization program and distributes data to the secondary servers. Regardless of how any other server is configured, the data on a primary server cannot be overwritten by any other server running the server synchronization program.
- **Secondary server**—On the primary server, you can designate any server running the correct CTPView software version as a secondary server. Synchronization updates the data files on the secondary server to match the files on the primary server.
- **Data files**—Synchronization applies to statistical history archived from the CTP platforms and the information needed to communicate with the platforms: IP addresses, hostnames, host menus, and SSH authorization keys.



NOTE: Server synchronization is supported only on CTPView 1.4.2 or higher releases.

- [Configuring a CTPView Server Synchronization Network \(CTPView\)](#) on page 76
- [Synchronizing the CTPView Server Network Automatically \(CTPView\)](#) on page 77
- [Synchronizing the CTPView Server Network Manually \(CTPView\)](#) on page 78

Configuring a CTPView Server Synchronization Network (CTPView)

You must identify a primary server and one or more secondary servers as members of a synchronization network.

To configure your synchronization network:

1. Log in to the CTPView server selected to be the primary server.
2. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

3. Click **Server Synchronization**.

The Server Synchronization pane is displayed.

4. In the Add Network Server section, type the information required for the primary server: IP address, name, admin login name, and login password, and click **Add New Server**.

The primary server information is displayed in the Current Server Synchronization Settings table. The server name is used for display purposes only and does not need to be the server's UNIX hostname.

5. Add the same information to the table for each of the additional CTPView servers in your network that you want to synchronize with the primary server.

6. In the Current Server Synchronization Settings table, select a server type for each server: **Primary Server** for the primary CTPView server, and **Secondary Server** for each of the secondary servers.

The primary server must be the server you are currently logged in to.

7. (Optional) Set the server type to **Not Selected** when you want to temporarily remove a server from the synchronization process.

To add this server back to the synchronization network, select **Secondary Server** for the server type.

8. (Optional) Click the **Remove** box to remove a server from the synchronization network.

The server is deleted from the table. If you later want this server to be part of the synchronization network, you must add it back to the table.

9. Click **Commit Changes** to save this configuration.

If you want to restore the original settings in the table, click **Reset** instead of **Commit Changes**.

Synchronizing the CTPView Server Network Automatically (CTPView)

To automatically synchronize your network:

1. In the Server Synchronization pane, click **Set Automatic Functions**.

The CTPView Automatic Functions pane is displayed.

2. Select **Synchronize Secondary Servers and Remote Hosts** or **Synchronize Secondary Servers**.

When the secondary servers and the CTP platforms are synchronized, the CTPView software copies the necessary SSH keys to each secondary server so that it can communicate with the CTP platforms without requiring the login password to be entered. When only the secondary servers are synchronized, only server-specific information is synchronized.

3. Select when you want the operation to take place.

The optimal configuration runs the synchronization shortly after the statistical data is obtained from the CTP platforms. The numbers you select represent a specific time, not an interval of time. For example, the default setting of [0,1,ANY,ANY,ANY] means

that synchronization occurs at the 0 minute (on the hour) of the first hour (1 AM) every day (any day of any month, landing on any day of the week). A setting of [30,16,8,ANY,ANY] causes the synchronization to occur at 4:30 PM on the 8th of every month.

4. Click **Add New Entry**; the operation appears in the summary table.

If you decide not to add the entry, click **Reset**.

To have the same function performed at different times, add a new entry for that operation for each time.

Synchronizing the CTPView Server Network Manually (CTPView)

To manually synchronize your network:

1. In the Server Synchronization pane, click **Manually Synchronize Network**.

The Synchronize Secondary Servers window is displayed.

2. (Optional) Click the name of the CTP platform on which you want to check the SSH RSA keys during synchronization.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

3. Click **Synchronize Servers**.

Monitoring CTP Platforms (CTPView)

- Monitoring the Network with the CTPView Software (CTPView) on page 79
- Changing the Display Settings for CTPView Network Monitoring (CTPView) on page 80
- Checking the CTPView Server Connection to CTP Platforms in the Network (CTPView) on page 81
- Displaying Runtime Query Results for a CTP Platform (CTPView) on page 83
- Overriding CTP Platform Network Status and Adding Comments (CTPView) on page 83
- Saving CTP Platform Configurations (CTPView) on page 84
- Setting an Audible Alert for CTP Platform Status (CTPView) on page 86
- Displaying CTPView Network Reports (CTPView) on page 87
- Field Descriptions in CTPView Network Reports (CTPView) on page 88
- Displaying Network Statistics (CTPView) on page 89

Monitoring the Network with the CTPView Software (CTPView)

You can enable network monitoring so that the CTPView software can periodically check the reachability of CTP platforms in your network. You must also have configured network monitoring on the CTP platforms you want to monitor.



NOTE: Network monitoring is not supported for Vcomp bundles.

To enable CTPView network monitoring:

1. In the side pane, select **Network > Monitoring**.

The Network Monitoring pane is displayed. A Network Monitoring box displays the status of monitoring, **Running** or **Stopped**.

2. Click the button for the group of CTP devices you want to monitor.
3. Click **Click to Start** to initiate monitoring of the selected group.

The operation or alarm status of each device in the group, and of each port on the device, is displayed. Table 8 on page 80 lists the status options. A color key in the pane indicates the port state. The highest alarm level on a CTP device percolates up to the button for its group.

Table 8: Platform Group and Port Status

Status	Description
Active-Down	The port is configured as active, but the port state is Down, meaning that no circuit is established to the port.
Active-Up	The port is configured as active, and the port state is Up, meaning that a circuit is established to the port.
Assessing	The problem is being assessed, and a user has placed the CTP platform into the Assessing state.
Check Host	The CTP platform is reachable across the network, but the CTPView software is unable to communicate with the platform to obtain the status of the ports.
Disabled	The circuit is configured as disabled. Ports not attached to bundles are marked Disabled.
No Data	No data can be obtained from the CTP platform. You must investigate further to determine the cause.
Unreachable	The CTPView server cannot reach the CTP host. This alarm can be due to an IP network problem, a site problem (such as a power outage), or a CTP equipment or configuration issue.

You can click on a CTP platform button and host button to perform additional monitoring operations, such as checking the host connection, displaying the runtime query results, or overriding the network status.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 64](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 80](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 81](#)
- [Displaying Runtime Query Results for a CTP Platform \(CTPView\) on page 83](#)
- [Overriding CTP Platform Network Status and Adding Comments \(CTPView\) on page 83](#)
- [Configuring Email Notifications \(CTPView\) on page 65](#)

Changing the Display Settings for CTPView Network Monitoring (CTPView)

You can change several settings to customize the look of CTPView network monitoring.

To change the display settings:

1. In the side pane, select **Network > Monitoring**.
The Network Monitoring pane is displayed.
2. Click **Display Settings**.

The Display Options window opens.

You can change the following display options:

- Number of platform group buttons in a row.
 - Width of each group button, in pixels.
 - Text size of each group button, in pixels.
 - Text size of each port button, in pixels.
 - Level of debugging information.
 - Audible notification by the browser each time status is reported as UNREACHABLE, CHECKHOST, or ACTIVE-DOWN.
3. Select the setting values you want to change. Click **Submit Choices** to accept your changes, or click **Undo Changes** to restore the current value.

Related Documentation

- [Managing CTP Platforms in the Network \(CTPView\) on page 64](#)
- [Monitoring the Network with the CTPView Software \(CTPView\) on page 79](#)
- [Checking the CTPView Server Connection to CTP Platforms in the Network \(CTPView\) on page 81](#)
- [Setting an Audible Alert for CTP Platform Status \(CTPView\) on page 86](#)

Checking the CTPView Server Connection to CTP Platforms in the Network (CTPView)

You can determine whether the CTPView server is currently able to reach one or more of the CTP platforms in your network. This is a one-time, immediate check rather than ongoing network monitoring.

- [Checking Connections from the Network Monitoring Pane \(CTPView\) on page 81](#)
- [Checking Connections from the Node Maintenance Pane \(CTPView\) on page 82](#)
- [Displaying Previously Logged Connection Status \(CTPView\) on page 82](#)
- [Checking Connections in the Remote Host Options Window \(CTPView\) on page 82](#)

Checking Connections from the Network Monitoring Pane (CTPView)

To check the current reachability of CTP platforms:

1. In the side pane, select **Network > Monitoring**.

The Network Monitoring pane is displayed.

2. Click **Check Connections**.

The Check Connections to CTPs window opens and displays a list of platform groups and their members.

3. Click the name of the platform you want to check.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

4. Click **Check Connection to Selected CTPs**.

The CTPView software checks the connection to each selected CTP device in turn and displays the results.

Checking Connections from the Node Maintenance Pane (CTPView)

You can also check CTP platform connections from the Node Maintenance pane.

1. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.

2. Click **Check Connection to CTP(s)**.

The Check Connections to CTPs window opens and displays a list of platform groups and their members.

3. Click the name of the platform you want to check.

You can select more than one platform by holding down the Ctrl key when you click the platform names. Alternatively, you can click **Select All Hosts** to select all the listed CTP platforms.

4. Click **Check Connection to Selected CTPs**.

The CTPView software checks the connection to each selected CTP device in turn and displays the results.

Displaying Previously Logged Connection Status (CTPView)

To display logs of previous connection checks:

1. In the Check Connections to CTPs window, click **Show Active Log**.

2. (Optional) Click **Archive This Log** to archive the current results summary tables.

3. (Optional) Click **View All Summaries** to display previously archived results summary tables.

Checking Connections in the Remote Host Options Window (CTPView)

The CTPView software provides another way to check CTP platform connections starting from the Network Monitoring pane.

1. Perform the steps listed in "Monitoring the Network with the CTPView Software (CTPView)" on page 79.

Monitoring is started for the selected port or platform.

2. Click the button for a platform or port being monitored.

The Remote Host Options window is displayed.

3. Click **Check Host Connection** or **Check Port Connection**.

A new window displays the SSH query and response and the SNMP query and response.

**Related
Documentation**

- [Managing CTP Platforms in the Network \(CTPView\) on page 64](#)
- [Monitoring the Network with the CTPView Software \(CTPView\) on page 79](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 80](#)

Displaying Runtime Query Results for a CTP Platform (CTPView)

You can quickly access the runtime query results for a CTP platform or port from the Network Monitoring pane.

To display the runtime query results:

1. Perform the steps listed in “Monitoring the Network with the CTPView Software (CTPView)” on page 79.

The Network Monitoring pane is displayed.

2. Click the button for a platform or port being monitored.

The Remote Host Options window is displayed.

3. Click **Show Runtime Query** for all ports or, if you selected an individual port, for that port.

The Port Runtime window displays the results.

**Related
Documentation**

- [Managing CTP Platforms in the Network \(CTPView\) on page 64](#)
- [Monitoring the Network with the CTPView Software \(CTPView\) on page 79](#)
- [Changing the Display Settings for CTPView Network Monitoring \(CTPView\) on page 80](#)

Overriding CTP Platform Network Status and Adding Comments (CTPView)

You can manually override the status of CTP platforms. You can also add comments that appear in the Remote Host Options window for a CTP platform that is currently being monitored.

To override the status of a platform:

1. Perform the steps listed in “Monitoring the Network with the CTPView Software (CTPView)” on page 79.

The Network Monitoring pane is displayed.

2. Click the button for a platform being monitored.

The Remote Host Options window is displayed.

3. Click **Modify Host Status/Comments**.

The Modify Host Comments window is displayed.

4. Select **Yes** to set the status to Assessing.

If the status was previously override and set to Assessing, you can select **No** to remove the override.

5. Click **Submit Changes**.

A magnifying glass icon appears in the button for the platform, its group, and its network. The status color of only the platform button is set to orange for Assessing. The group and network buttons display only the most severe status reported for a platform that has not been manually overridden.

To add a comment:

1. Perform the steps listed in “Monitoring the Network with the CTPView Software (CTPView)” on page 79.

The Network Monitoring pane is displayed.

2. Click the button for a platform being monitored.

The Remote Host Options window is displayed.

3. Click **Modify Host Status/Comments**.

The Modify Host Comments window is displayed.

4. Type a comment of up to 125 characters in the comment field.

5. Click **Submit Changes** to apply your text to the Remote Host Options window.

Alternatively, click **Delete Comments** to remove a current comment (and if applied, the Assessing status), or **Undo Changes** to cancel your comment change. A time stamp indicates when the comment was last modified.

Related Documentation

- Managing CTP Platforms in the Network (CTPView) on page 64
- Monitoring the Network with the CTPView Software (CTPView) on page 79

Saving CTP Platform Configurations (CTPView)

You can set an automatic function to save the CTPView configuration for the CTP platforms in your network automatically. The automatic function stores up to the 10 most recent configuration files. You can also save the configuration manually. Manually saved configurations are stored in addition to any automatically saved configurations. You can also save previously stored configurations for any CTP platform.

To configure automatic file saving:

1. In the side pane, select **Server > Administration**.

The Administrative Functions pane is displayed.

2. Click **Automatic Functions**.

The CTPView Automatic Functions window is displayed.

3. In the Action section, select **Save Current CTP Host System Configurations**.
4. Select when you want the operation to take place.
5. Click **Add New Entry**; the operation appears in the summary table. Or, if you do not want to add the entry, click **Reset**.

To have the configurations saved at additional times, add a new entry for that operation for each time.

To save the configurations manually:

1. In the side pane, select **Node > Maintenance**.

The Administrative Functions pane is displayed.

2. Click **Save/Restore CTP Configurations**.

The CTP System Configuration window is displayed.

3. Select the desired host.

4. Click **Save CTP Configuration**.

The name and IP address of the selected host is displayed.

5. (Optional) Type text for a label associated with the configuration.

6. Click **Click To Save Current CTP Configuration**.

The configuration is added to the list of saved configurations.

To restore a configuration:



NOTE: Restoring a saved configuration to a CTP platform reboots that device.

1. In the side pane, select **Node > Maintenance**.

The Administrative Functions pane is displayed.

2. Click **Save/Restore CTP Configurations**.

The CTP System Configuration window is displayed.

3. Select the desired host.

4. Click **Restore CTP Configuration**.

The name and IP address of the selected host is displayed.

5. Select a saved configuration from the list.

6. Click **Restore CTP Configuration**.

The CTP platform is rebooted as part of the restoration process.

To delete a saved configuration:

1. In the side pane, select **Node > Maintenance**.
The Administrative Functions pane is displayed.
2. Click **Save/Restore CTP Configurations**.
The CTP System Configuration window is displayed.
3. Select the desired host.
4. Click **Delete Saved CTP Configuration**.
The name and IP address of the selected host is displayed.
5. Select a saved configuration from the list.
6. Click **Delete CTP Configuration**.

Setting an Audible Alert for CTP Platform Status (CTPView)

You can set an alert that the CTPView browser plays every time it detects a CTP platform status as UNREACHABLE, CHECKHOST, or ACTIVE-DOWN. You can add additional alert sounds to the available choices.

To select an alert sound:

1. In the side pane, select **Network > Monitoring**.
The Network Monitoring pane is displayed.
2. Click **Display Settings**.
The Display Options window opens.
3. Select Enabled to set the browser to play an alert.
4. Select an alert sound from the list.
5. Click **Submit Choices** to accept your changes, or click **Undo Changes** to restore the current value.

To add additional alert sounds:

- Copy the sound files to the CTPView server directory `/var/www/html/acorn/sounds/`.



NOTE: Only files in .wav format are supported. The sound filename can include only alphanumeric characters and the underscore (_) character. The filename root is displayed as the label for the sound in the browser. The CTPView software automatically corrects illegal filenames and modifies file permissions as needed to enable the embedded media player to read the file.

The default browser installation for LINUX probably does not include an embedded media player. An easy-to-install multimedia plug-in is available at <http://fredrik.hubbe.net/plugger.html>.

Related Documentation

- Managing CTP Platforms in the Network (CTPView) on page 64
- Monitoring the Network with the CTPView Software (CTPView) on page 79
- Changing the Display Settings for CTPView Network Monitoring (CTPView) on page 80

Displaying CTPView Network Reports (CTPView)

The CTPView software provides the following reports that detail how ports are provisioned on the CTP platforms in your network:

- Channelization report—Information about all ports on selected CTP platforms.
- Configured port report—Information about only the configured ports on selected CTP platforms.
- Nonconfigured port report—Information about only ports that are incompletely configured on selected CTP platforms.

To display the desired report:

1. In the side pane, select **Node > Maintenance**.

The Node Maintenance pane is displayed.

2. Click **View Network Host Reports**.

The CTPView Network Reports pane is displayed.

3. Select one or more remote hosts (CTP platform), or click **Select All Hosts** to select all listed CTP platforms.

4. Click the button for the desired report.

The report is displayed in the bottom of the pane. Click **Clear/Reload Page** to remove the report from the pane.

5. (Optional) Click on a column header in the report to sort the data in ascending order for that column.

6. (Optional) Select a different font size for readability.

7. (Optional) Click **Printer Friendly Page** to display the report in a format suitable for printing.

You can select and copy the printer-friendly information and paste it in a spreadsheet.

The report database is updated whenever you use the CTPView software to provision a CTP platform. You can also save the CTP platform configuration data to the database automatically or manually.

To update the database automatically, see “Configuring Automatic Monitoring of CTP Platforms (CTPView)” on page 72.

1. To update the database manually:
2. In the side pane, select **Node > Maintenance**.
The Node Maintenance pane is displayed.
3. Click **View Network Host Reports**.
The CTPView Network Reports pane is displayed.
4. Click **Update Database**.

Related Documentation

- Understanding CTPView Network Reports (CTPView) on page 88

Field Descriptions in CTPView Network Reports (CTPView)

Table 9 on page 88 describes the information provided by the CTPView software in the CTPView network reports.

Table 9: CTPView Network Reports Fields

Field	Description
Source IP Address	IP address of the source CTP platform.
Source Host Name	Name of the source CTP platform.
Source Port Number	Number identifying port on the source CTP platform.
Source CID	Source circuit ID.
Source Bundle Number	Number identifying bundle on the source CTP platform.
Destination IP Address	IP address of the destination CTP platform.
Destination Host Name	Name of the destination CTP platform.
Destination Port/CID Number	Destination port and circuit ID.
Source Interface Type	Type of interface on the source CTP platform: EIA530, EIA530A, RS-232, V.35, T1/E1, fractional T1/E1, or 4WTO analog voice.
Source Port Speed	Clock speed configured for the source CTP platform.
Source Service Type TOS/DSCP	Value of the Type of Service byte in packets sent from the source CTP platform to the IP network.
Source Port Descriptor	Descriptive term or name applied to the port.
Source Bundle Descriptor	Descriptive term or name applied to the bundle.
Source Code Version	CTPOS software version running on the source CTP platform.

Table 9: CTPView Network Reports Fields (*continued*)

Last Update	Date and time report was last updated to the database.
Related Documentation	<ul style="list-style-type: none"> • Displaying CTPView Network Reports (CTPView) on page 87

Displaying Network Statistics (CTPView)

The CTPView software periodically retrieves IP performance information from each CTP platform in the network. The data is retrieved at 1-minute intervals and includes the following observation:

- Minimum, maximum, and average values for the buffer state
- Calculated IP packet delay variance (jitter)
- Missing packet counts
- Round-trip packet delay

The plots display information for the currently connected CTP platform. You can display plots for a single port, all configured ports, or all ports on the connected CTP platform. Each plot's Y axis is automatically scaled for convenient viewing. However, for the buffer, packet delay variance, and round-trip delay plots, you can specify different units, minimum values, and maximum values for the Y axis intervals. You can select the period of time for which you want to review the data, from the preceding hour up to the preceding week, or you can set a custom period to review.



NOTE: The Network Statistics pane requires you to select the circuit of interest based on port numbers. An expanding table in the pane displays a summary of the current bundle circuits and their attached ports on the connected platform.

To display a plot of IP statistics for the connected CTP platform:

1. In the side pane, select **Statistics > Plots**.

The Network Statistics pane is displayed.

2. Click on the time period button for which you want data to be plotted.

The plots are displayed, and the period plotted is indicated. Click any plot to open a larger version in a new window.

You can click a button for a single port, all configured ports, or all ports on the platform. To plot data for a single port, expand the table, follow the directions in the pane to display and select the port. Time period buttons are then displayed for that port.

To display a plot with different values for the Y axis:

1. In the Network Statistics pane, click **Custom Y-axis Options**.

The Network Statistics pane is displayed.

2. Select any combination of minimum value, maximum value, or different units for the Y axis.

You can select these values for the Buffer, IP packet delay variation, or IP one-way packet loss plots. You can click **Reset Custom Y-axis** to restore the default values for all plots.

To display a plot for a custom time period:

1. In the Network Statistics pane, click **Custom Y-axis Options**.

The Network Statistics pane is displayed.

2. Click **Custom Time Options**.
3. Select a starting and ending year, month, day, hour and minute.
4. Click **Custom Time** for the ports you want to plot.

You can click **Reset Custom Time** to restore the default values for all plots.

The plots are displayed, and the period plotted is indicated. Click any plot to open a larger version in a new window.

Changing CTPView GUI Settings

- Configuring CTPView Software for Tabbed or Nontabbed Browsers (CTPView) on page 91
- Changing the CTPView Display Settings (CTPView) on page 92
- Displaying Help for CTPView GUI Settings (CTPView) on page 92

Configuring CTPView Software for Tabbed or Nontabbed Browsers (CTPView)

You can configure the CTPView software to be displayed properly in a tabbed browser or a nontabbed browser. By default, the software is set to classic, which supports a nontabbed browser. You must separately configure each browser that you use.

To set the browser preference for tabs:

1. In the side pane, select **Server > GUI Settings**.
The GUI Settings pane is displayed.
2. Select **Classic** for nontabbed browsers or **Tab** for tabbed browsers.
3. Click **Change CTPView Style**.

The viewing style is displayed in the side pane under **Server**.

To open a CTPView window in a new tab in your browser:

- In the side pane, select **Server > New Window**.

The current tabbed browsers do not support dynamically changing the tab's title after a page has been loaded onto the screen. The CTPView software uses frames to open new content in the viewing window without reloading the entire page, so the tab titles cannot describe the current content. The CTPView software adds a bracketed sequencing number to the tab title to differentiate the tabs for easier browser, and keeps track of the number of tabs that you have opened.

To reset the tab count:

1. In the side pane, select **Server > GUI Settings**.
The GUI Settings pane is displayed.
2. Click **Reset Browser Tab Index**.

The count resets to 1. The next tab you open will have the sequence number 1. The counter is automatically reset when you close all the browser windows.

Changing the CTPView Display Settings (CTPView)

You can modify the appearance of text, and the background color of tables and some buttons in the CTPView software. By default, text is displayed in 3-point Verdana.

To change the text appearance:

1. In the side pane, select **Server > GUI Settings**.

The GUI Settings pane is displayed.

2. Select a font style.
3. Select a base text size.
4. Click **Submit Changes**.

To change the background color of certain tables and buttons:

1. In the side pane, select **Server > GUI Settings**.

The GUI Settings pane is displayed.

2. Type the hexadecimal code for the new color in the field for the table, button, or message type that you want to change.
3. (Optional) Click **Go To Color Chart** to view a table of codes for browser-safe colors, and type the code.
4. Click **Submit Changes**.

Alternatively, you can restore the default colors by clicking **Use Default Colors**.

The current window refreshes immediately with the text or color changes. However, other windows (or tabs) that are open when you make the change are not automatically refreshed. The changes appear in any windows that you subsequently open.

Related Documentation

- [Displaying Help for CTPView GUI Settings \(CTPView\)](#) on page 92

Displaying Help for CTPView GUI Settings (CTPView)

You can display troubleshooting information and tips regarding CTPView GUI settings and browser display.

To display GUI help:

1. In the side pane, select **Server > GUI Settings**.

The GUI Settings pane is displayed.

2. Click **Troubleshooting and Tips**.

The Troubleshooting and Tips pane is displayed.

- Related Documentation**
- [Changing The CTPView Display Settings \(CTPView\) on page 92](#)

Managing and Displaying Users (CTPView Server Menu)

- Accessing the CTPView Server Configuration Menu (CTPView Server Menu) on page 95
- Managing CTPView Users (CTPView Server Menu) on page 95
- Classification of CTPView Shell Account Users on page 97
- Managing User Passwords (CTPView Server Menu) on page 97
- Configuring CTPView User Authentication with Steel-Belted Radius on page 99

Accessing the CTPView Server Configuration Menu (CTPView Server Menu)

To access the CTPView server CLI menu:

1. Using an SSH application, log in to the CTPView server.



NOTE: If you do not successfully log in within 60 seconds, the session is closed.

Alternatively, you can log in directly to the CTPView server if you connect a keyboard and monitor to the server. Using an SSH application requires that the CTP server already be configured in your network with an assigned IP address.

2. Enter **menu**.
3. Enter the root password.

The CTPView Configuration Menu is displayed.

Related Documentation

- Default CTPOS and CTPView Accounts and Passwords on page 39

Managing CTPView Users (CTPView Server Menu)

You can view currently active shell account users, and add or delete administrator shell accounts. Shell accounts provide access to the CTPView server by means of an SSH application.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To manage user passwords, you must first access the User Management Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
2. Select **1) User Management**.

The User Management Menu is displayed.

- Monitoring CTPView Users (CTPView Server Menu) on page 96
- Listing Admin Shell Accounts (CTPView Server Menu) on page 96
- Adding Admin Shell Accounts (CTPView Server Menu) on page 96
- Deleting Admin Shell Accounts (CTPView Server Menu) on page 97

Monitoring CTPView Users (CTPView Server Menu)

To display all CTPView users that are currently logged in to the server through SSH:

- From the User Management Menu, select **1) List users currently logged on**.

Only users logged in to the server through a secure shell (not through the CTPView GUI) are listed. The table lists the username, whether the user logged in remotely or locally, the time the session began, and the user’s IP address. Local user connections are indicated by *tty*; remote SSH connections are indicated by *pts*.

Listing Admin Shell Accounts (CTPView Server Menu)

You use a shell account to access the CTPView server with an SSH application.

To list all administrator shell accounts:

- From the User Management Menu, select **2) List admin shell accounts**.

The usernames for the shell accounts are listed according to their classification, Administrator or User.

Adding Admin Shell Accounts (CTPView Server Menu)

To add an administrator shell account:

1. From the User Management Menu, select **3) Add admin shell accounts**.
2. Enter the username for the account.

Only alphanumeric characters, underscores, and periods are allowed in a username.

3. Enter the appropriate number to classify the user as an Administrator or User.
4. Enter a new password for the user.

The password requirements are displayed to assist you in choosing an appropriate password.

Deleting Admin Shell Accounts (CTPView Server Menu)

To delete an administrator shell account:

1. From the User Management Menu, select **4) Delete admin shell accounts**.
2. Enter the username for the account.

Related Documentation

- Classification of CTPView Shell Account Users on page 97

Classification of CTPView Shell Account Users

Users that access the CTPView server running FC OS through a shell account are classified into one of the following classes:

- Administrator—Can configure the CTP platform, configure loops and BERTs, and query the status of ports and clocking.
- User—Can issue commands only to query the status of ports and clocking.

Managing User Passwords (CTPView Server Menu)

You can display user accounts and password settings, configure various aging criteria for user passwords, and specify the rules for forming passwords.

Before you begin, log in to the CTPView server, and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To manage user passwords, you must first access the Password Management Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
2. Select **2) Password Management**.

The Password Management Menu is displayed.

- Listing User Accounts (CTPView Server Menu) on page 97
- Displaying Password Expiration Settings (CTPView Server Menu) on page 98
- Changing Password Expiration Settings (CTPView Server Menu) on page 98
- Displaying Password Requirements (CTPView Server Menu) on page 99
- Changing Password Requirements (CTPView Server Menu) on page 99

Listing User Accounts (CTPView Server Menu)

The usernames for the accounts are listed according to their classification, Administrator or User..

To list the usernames for CTPView server accounts:

- From the Password Management Menu, select **1) List user & admin accounts**.

Displaying Password Expiration Settings (CTPView Server Menu)

To display the current password expiration settings for a user account:

- From the Password Management Menu, select **2) Display password expiration details**.

Table 10 on page 98 describes the information listed in the output.

Table 10: CTPView User Password Expiration Settings

Field	Description
Account is/is not locked	Status of the account. Locked accounts cannot access CTPView server.
Minimum	Minimum number of days that must elapse before the user can change this password, in the range 1 through 60.
Maximum	Maximum number of days that this password is valid.
Warning	Number of days before password expiration that the user is warned of the impending expiration.
Inactive	Number of days of inactivity after the password expires before the account is locked out (unable to access CTPView server)
Last Change	Date that this password was last changed.
Password Expires	Date that this password expires. Calculated by counting the Maximum value from the Last Change date.
Password Inactive	Date that this password becomes inactive. Calculated by counting the Inactive value from the Password Expires date.
Account Expires	Date that the account expires.

Changing Password Expiration Settings (CTPView Server Menu)

To change the password expiration settings for a user account:

1. From the Password Management Menu, select **3) Manage password requirements**.
2. Enter the password expiration values when prompted.

Each prompt provides a description and range for the value.

Displaying Password Requirements (CTPView Server Menu)

To display the current requirements for forming a password:

- From the Password Management Menu, select **4) Show password requirements**.

The output lists the minimum password length, the minimum number of lowercase letters, uppercase letters, numerals, and nonalphanumeric characters; and the number of times a user can attempt to enter the correct password before being blocked.

Changing Password Requirements (CTPView Server Menu)

User passwords have strict criteria. You must include a nonzero minimum of lowercase letters, uppercase letters, numerals, and certain nonalphanumeric characters. You must also set the number of times a user can enter the password incorrectly before being blocked from access.

To change the requirements for forming a password:

1. From the Password Management Menu, select **5) Manage password requirements**.
2. Enter values for the password requirements when prompted.

Each prompt provides a description and range for the value.

Related Documentation

- Default CTPOS and CTPView Accounts and Passwords on page 39
- CTPOS and CTPView Software Password Requirements on page 40

Configuring CTPView User Authentication with Steel-Belted Radius

You can provide RADIUS authentication for users logging in to the CTPView GUI. Use an independent Steel-Belted Radius (SBR) server or an RSA SecurID appliance with your CTPView server running FC9 OS and CTPView 3.4R1 or higher. The RSA SecurID appliance incorporates an SBR server, making the configuration very similar to that for an independent SBR server.

Users are authenticated in the following order:

1. By the SBR server.
2. By the local CTPView application.

You can configure the SBR server to use native user authentication or pass-through authentication with RSA SecurID.

- Native user authentication references user accounts stored on the SBR server. When trying the native user method, the SBR software searches its database for an entry whose User-Type is Native User and whose username matches the User-Name in the Access-Request.
- Pass-through authentication (two-factor authentication) enables the SBR server to pass authentication requests through to RSA Authentication Manager (RSA SecurID).

RSA SecurID is then responsible for validating the username and password found in the Access-Request.

The order of authentication between these two categories of users is set on the SBR server. You can add the same user (that is, the same user ID) to both the SBR server and the local CTPView application.



NOTE: CTPView does not currently support RADIUS authentication for shell access to the CTPView server.

1. Configuring RADIUS Settings on the CTPView Server on page 100
2. Configuring the SBR Server's Dictionary Files on page 101
3. Configuring the SBR Server's Active Authentication Method on page 101
4. Adding the CTPView Server as a RADIUS Client on an SBR Server on page 102
5. Adding CTPView Users to an SBR Server on page 102
6. Assigning SecurID Tokens to CTPView Users on page 103

Configuring RADIUS Settings on the CTPView Server

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To configure RADIUS settings on the CTPView server:

1. From the CTPView Configuration Menu, select **9) RADIUS Function**.

The RADIUS Menu is displayed.

2. Select **3) Add/Update RADIUS Template Accounts**.
3. Enter the MySQL root account password when prompted.

The required template accounts are added to CTPView. These accounts are not configurable. This step is performed as part of the initial configuration of CTPView as a RADIUS client. However, repeating this step has no detrimental effect on the RADIUS configuration.

4. Return to the RADIUS Menu.
5. Select **2) View/Set RADIUS Servers** and add the RADIUS server's IP address.
6. When prompted, enter the following information:

- shared secret
- timeout period
- number of retries

You can add up to 10 RADIUS servers.

7. Return to the RADIUS Menu.
8. Select **1) View/Set RADIUS State**.
9. Select **2) Enable RADIUS**.

Configuring the SBR Server's Dictionary Files

To configure the SBR server's dictionary files:

1. Log in to the SBR server as an administrator.
2. Open the file `C:\Program Files\Juniper Networks\Steel-Belted RADIUS\Service\juniper.dct` and append the following new block of text to the bottom of the file:

```
#####
# CTP Specific Attributes
#####
ATTRIBUTE Juniper-CTP-Group Juniper-VSA(21, integer) r
VALUE Juniper-CTP-Group Read_Only 1
VALUE Juniper-CTP-Group Admin 2
VALUE Juniper-CTP-Group Privileged_Admin 3
ATTRIBUTE Juniper-CTPView-APP-Group Juniper-VSA(22,integer) r
VALUE Juniper-CTPView-APP-Group Net_View 1
VALUE Juniper-CTPView-APP-Group Net_Admin 2
VALUE Juniper-CTPView-APP-Group Global_Admin 3
ATTRIBUTE Juniper-CTPView-OS-Group Juniper-VSA(23, integer) r
VALUE Juniper-CTPView-OS-Group Admin 1
VALUE Juniper-CTPView-OS-Group Privileged_Admin 2
#####
# CTP Specific Attributes
#####
```

3. Open the file `C:\Program Files\Juniper Networks\Steel-Belted RADIUS\Service\vendor.ini` and locate the block of text that begins:

```
vendor-product = Juniper M/T Series
```

4. Add the following text after that block.

```
vendor-product = Juniper CTP Series
dictionary = Juniper
ignore ports = no
port-number-usage = per-port-type
help-id = 2000
```

5. Restart the Steel-Belted Radius service on the server.

Configuring the SBR Server's Active Authentication Method

To configure the SBR server's active authentication method:

1. Launch the Steel-Belted Radius Administrator application from your web browser by entering the address `http://SBR-server-IP-address:1812`.
2. Click **Launch**.

3. Select **Steel-Belted RADIUS > Authentication Policies > Order of Methods**.

Ensure that your chosen method, Native User or SecurID User, is listed under the section Active Authentication Methods.

Adding the CTPView Server as a RADIUS Client on an SBR Server

To add the CTPView server as a RADIUS client on an SBR server:

1. Launch the Steel-Belted Radius Administrator application from your web browser by entering the address `http://SBR-server-IP-address:1812`.
2. Click **Launch**.
3. Select **Steel-Belted RADIUS > RADIUS Clients**.
4. Add your CTPView server as a client. In the Make or model field, select **Juniper CTP Series**.

Adding CTPView Users to an SBR Server

To add CTPView users to an SBR server:

1. Launch the Steel-Belted Radius Administrator application from your web browser by entering the address `http://SBR-server-IP-address:1812`.
2. Click **Launch**.
3. Select the user type.
 - For native users, select **Steel-Belted RADIUS > Users > Native**.
 - For RSA SecurID users, select **Steel-Belted RADIUS > Users > SecurID**.
4. Add a user with the Add Native User dialog box or the Add SecurID dialog box, depending on your choice in the previous step.
5. In the Attributes section, click the **Return List** tab and then click **Add**. The Add Return List Attribute dialog box opens.
6. In the Attributes section select **Juniper-CTPView_APP-Group**.
7. In the Value section select one of the following authorization levels for the user you are adding:
 - Global_Admin
 - Net_Admin
 - Net_View

Assigning SecurID Tokens to CTPView Users

SecurID authentication requires that you issue a SecurID token to each user and assign it to them on the RSA SecurID appliance. The first time a new user logs in to the CTPView software, the *token code* displayed on the SecurID token is the password. The user is then prompted to create a PIN. On subsequent logins, the user's PIN followed immediately by the token code displayed on the SecurID token is the password.

To assign SecurID tokens:

1. On the RSA SecurID appliance, launch the RSA Authentication Manager Host Mode application.
2. Select **User > Add User**.
3. Complete at least the following required fields:
 - Last Name
 - Default Login
 - Required to Create a PIN
 - Assign Token

Managing the CTPView Server (CTPView Server Menu)

- Managing CTPView Server Secure Logs (CTPView Server Menu) on page 105
- Setting the CTPView Server Start-Up Banner (CTPView Server Menu) on page 107
- Managing Access Security for the CTPView Server (CTPView Server Menu) on page 107
- Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView Server Menu) on page 109
- Saving the CTPView Configuration Settings and Data (CTPView Server Menu) on page 111
- Creating More Disk Space on the CTPView Server (CTPView Server Menu) on page 112
- Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu) on page 113
- Restarting the MySQL Server (CTPView Server Menu) on page 113
- Setting the Logging Level (CTPView Server Menu) on page 114

Managing CTPView Server Secure Logs (CTPView Server Menu)

This topic describes management of the `/var/log/secure` and `/var/log/secure.ext` logs stored on the CTPView server. The secure log provides an audit trail of user and administrator activity on the CTPView server. All actions performed on the CTPView server through the menu are logged and viewable. These logs do not record actions taken through the CTPView GUI.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To manage event logs, you must first access the Secure Log Management Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
The Main Security Profile Configuration Menu is displayed.
2. Select **3) Secure Log Management**.

The Secure Log Management Menu is displayed.

- Viewing Secure Logs (CTPView Server Menu) on page 106
- Copying Secure Logs to a Remote Host (CTPView Server Menu) on page 106
- Configuring Remote Logging Options (CTPView Server Menu) on page 106
- Displaying the Remote Logging Configuration (CTPView Server Menu) on page 106

Viewing Secure Logs (CTPView Server Menu)

To display all secure logs:

1. From the Secure Log Management Menu, select **1) Scan/view log entries**.
2. Follow the displayed instructions to navigate through the logs.

Copying Secure Logs to a Remote Host (CTPView Server Menu)

Before you perform this operation, you must have the IP address, username, and path to the directory in the user's account where the files will be copied.

To copy the logs to a remote host using secure copy (scp):

1. From the Secure Log Management Menu, select **2) Copy logs to remote host**.
2. Enter the information for the remote host as prompted.

Configuring Remote Logging Options (CTPView Server Menu)

You can enable the secure logs to be automatically logged to one or more remote servers.

To configure remote logging options:

1. From the Secure Log Management Menu, select **3) Configure remote logging options**.
2. Enable or disable remote logging.
3. If you have enabled remote logging, enter the IP address as prompted for each remote log server.

When you enable or disable remote logging, the system logger is shut down and then restarted to either send or stop sending subsequent logs to the remote servers.

Displaying the Remote Logging Configuration (CTPView Server Menu)

To display the remote logging configuration:

- From the Secure Log Management Menu, select **4) Show remote logging configuration**.

The status of remote logging is displayed. When remote logging is enabled, the IP address of the remote logging servers is also displayed.

Setting the CTPView Server Start-Up Banner (CTPView Server Menu)

When you log in to the CTPView server, a log-in or start-up banner presents a message. You can change the banner to provide an appropriate message.

To set the start-up banner:

1. From the CTPView Configuration Menu, select **1) Security Profile**.

The Main Security Profile Configuration Menu is displayed.

2. Select **4) Change login banner**.

The current banner is displayed.

3. Enter **y** to continue.

4. Enter your message in the field, up to 80 characters per line.

Only alphanumeric characters, commas, and underscores are allowed in the text.

5. Enter a blank line to end the message.

The new message is displayed.

6. Enter **y** to accept the new message.



NOTE: The log in banner is pushed to all CTP platforms on the network. You see the banner when you log in to CTPView whether by the GUI or by secure shell to the server.

Related Documentation

- Setting the CTP Platforms Login Banner (CTPView) on page 66

Managing Access Security for the CTPView Server (CTPView Server Menu)

You can control access to the CTPView server by setting security levels for access to the CTPView server through the CTPView GUI or through an SSH connection. The security levels determine the severity of password restrictions, installation or removal of certain utilities, control of root log in, and so on.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To manage security access levels, you must first access the Security Level Menu:

1. From the CTPView Configuration Menu, select **1) Security Profile**.
2. Select **5) Modify Security Level**.

The Security Level Menu is displayed.

- Viewing the Access Security Level for the CTPView Server (CTPView Server Menu) on page 108
- Setting Access Security for the CTPView Server (CTPView Server Menu) on page 108

Viewing the Access Security Level for the CTPView Server (CTPView Server Menu)

To display the current settings for access to the CTPView server:

- From the Security Level Menu, select **1) View current security level**.

The security level for access through an SSH connection and to the CTPView GUI are displayed.

Setting Access Security for the CTPView Server (CTPView Server Menu)

To set the security level for access to the CTPView server:

1. From the Security Level Menu, select one of the following options to set the SSH access level: **3) Set OS level to 'very-low'**, **4) Set OS level to 'low'**, **5) Set OS level to 'high'**.

Table 11 on page 108 describes these security levels.

2. Select one of the following options to set the CTPView GUI access level: **6) Set GUI level to 'low'** or **7) Set GUI level to 'high'**.

Table 12 on page 109 describes these security levels.

The `sshd` process is stopped and restarted whenever you change the security level.

Table 11: Access Security Levels for SSH Connections

Access Security Level	Description
very-low	<ul style="list-style-type: none"> • Enables root login. • Disables session inactivity timeout. • Enables Fedora Core OS default username/password restrictions. • Enables single-user mode login for password recovery. • Installs <code>tcpdump</code> and <code>hdparm</code> utilities. These files must exist in the <code>/tmp</code> directory.
low	<ul style="list-style-type: none"> • Disables root login. • Disables session inactivity timeout. • Enables Fedora Core OS default username/password restrictions. • Enables single-user mode login for password recovery. • Installs <code>tcpdump</code> and <code>hdparm</code> utilities. These files must exist in the <code>/tmp</code> directory.
high	<ul style="list-style-type: none"> • Disables root login. • Enables session inactivity timeout. • Enables elevated username/password restrictions. • Disables single-user mode login. • Removes <code>tcpdump</code> and <code>hdparm</code> utilities.

Table 12: Access Security Levels for CTPView GUI

Access Security Level	Description
low	Enables permissive username/password restrictions.
high	Enables elevated username/password restrictions.

Configuring an SSH Connection to a CTP Platform that Persists Through the Session (CTPView Server Menu)

This topic describes how to configure the CTPView server so that an SSH connection remains established for the entire session when the CTPView server connects to a CTP platform.

SSH port forwarding creates an encrypted and protected connection between the CTPView software and a remote CTP platform, that remains up as long as the server connection to the platform is up. It must be enabled on both the CTP platform and the CTPView software; it is enabled on both by default. When this feature is not enabled, the CTPView server creates a separate SSH connection to the platform for each command and configuration change. This feature reduces overhead and increases performance of the CTPView software. You can choose to disable this feature or reenabling it.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To configure the CTPView server for port forwarding, you must first access the Port Forwarding Menu:

- From the CTPView Configuration Menu, select **3) Port Forwarding**.

The Port Forwarding Menu is displayed.

- Viewing the Current State of Port Forwarding (CTPView Server Menu) on page 109
- Setting Port Forwarding Permissions (CTPView Server Menu) on page 109
- Closing Port Forwarding Sockets (CTPView Server Menu) on page 110
- Clearing Open Sockets by Restarting the Apache Daemon (CTPView Server Menu) on page 110

Viewing the Current State of Port Forwarding (CTPView Server Menu)

To display the current state of port forwarding on the CTPView server:

- From the Port Forwarding Menu, select **1) View Current State**.

The state is displayed, Allowed or Prohibited.

Setting Port Forwarding Permissions (CTPView Server Menu)

To set the permissions for port forwarding on the CTPView server:

1. From the Port Forwarding Menu, select **2) Set Port Forwarding Permissions**.

2. Select **1) Allow** or **2) Prohibit**.

The new state is displayed.

Closing Port Forwarding Sockets (CTPView Server Menu)

To close all open port forwarding sockets on the CTPView server:

- From the Port Forwarding Menu, select **3) Close Port Forwarding Sockets**.

Clearing Open Sockets by Restarting the Apache Daemon (CTPView Server Menu)

When you configure port forwarding, you may want to clear all the open sockets that were used for the previous port forwarding configuration. You can do so by restarting the Apache daemon.

To restart the Apache daemon on the CTPView server:

- From the Port Forwarding Menu, select **4) Restart Apache Daemon**.

You can also restart the Apache daemon elsewhere in the server menus. From the CTPView Configuration Menu, select **7) CTPView Access Functions > 2) Restart Apache Daemon**.

Related Documentation

- [Configuring an SSH Connection to a CTP Platform that Persists Through the Session \(CTPView\) on page 67](#)

Saving the CTPView Configuration Settings and Data (CTPView Server Menu)

This topic describes how to save the current configuration settings and data for the CTPView software. Although you can perform this task at any time, it is typically performed before you upgrade the CTPView server OS and the CTPView software.

You can use the backup utility in the CTPView server menu to save the information into an archive (.tgz) file and, if desired, move the archive to an external storage device. If you do not use the utility to move the archive, you can later copy or move it manually from outside the CTPView server menu.



NOTE: If you do not move the archive file to an external storage device, you are not protected from loss of the backed-up data. If you are upgrading the software, you must move the file to an appropriate location.

Alternatively, when you have more than one CTPView server, you can use the CTPView software GUI to synchronize the server with another server to save the settings and data. See “Synchronizing Multiple CTPView Servers (CTPView)” on page 75 for the synchronization procedure.



NOTE: We recommend that you use the CTPView server backup utility to save your current information.

Before you use the CTPView server backup utility:

- Confirm that the external storage device is running a UNIX-like operating system and is enabled for SSH connections.



NOTE: Although the external storage device can use any operating system, the CTPView backup utility can automatically transfer the backup file only to a device that is running a UNIX-like operating system. If the device is running a different kind of OS, you must transfer the backup file with a copy utility that is compatible with that OS.

- Confirm that a network path exists between the CTPView server and the external storage device used for storing the backup file.
- Confirm that the hard drive on the CTPView server that you are backing up has at least 25 percent free space. If you attempt to run the backup utility when less than 25 percent free space is available, the utility prompts you to delete more old data files before you continue. See “Creating More Disk Space on the CTPView Server (CTPView)” on page 17.
- Log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To back up your current information with the CTPView server backup utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions Menu is displayed.

2. Select **1) Save Current Settings and Data**.

If an archive file already exists in the `/var/www/html/acorn/data` directory on the server, the utility prompts you to delete or move the archive.

3. (Optional) From outside the menu (for example, in another terminal window), manually move the old archive to an external storage device if you want to save the information.

4. Enter **y** to delete the old archive.

The utility deletes the old archive file and creates the new archive file.

5. Enter **y** to move the new archive to an external location.

6. Follow the prompts to enter the IP address, username, and absolute path to the external device.

**Related
Documentation**

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Creating More Disk Space on the CTPView Server (CTPView) on page 17
- Creating More Disk Space on the CTPView Server (CTPView Server Menu) on page 18

Creating More Disk Space on the CTPView Server (CTPView Server Menu)

This topic describes how to create free space by removing redundant data files from the server.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To delete old files to create more free disk space:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions menu is displayed.

2. Select **3) Remove Redundant Binary Data Files**.

**Related
Documentation**

- Saving the CTPView Configuration Settings and Data (CTPView Server Menu) on page 16
- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Restoring CTPView Software Configuration Settings and Data with the Restore Utility (CTPView Server Menu)

This topic describes how to use the CTPView restore utility to restore the CTPView software configuration settings and data from a previously saved archive file.

Before you begin:

- Copy the backup (archive) file from its externally saved location to the `/var/www/html/acorn/data` directory on the server. The filename is in the format `ctpview_data_server-name_date.tgz`.
- Log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To restore your saved information with the CTPView restore utility:

1. From the CTPView Configuration Menu, select **5) Backup Functions**.

The Backup Functions menu is displayed.

2. Select **2) Restore Settings and Data**.

You are prompted to use the archive file. After the restore script runs, you are prompted to run it again.

Related Documentation

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14
- Restoring CTPView Software Configuration Settings and Data (CTPView) on page 19

Restarting the MySQL Server (CTPView Server Menu)



NOTE: Restart the MySQL server only under the guidance of the Juniper Networks Technical Assistance Center (JTAC).

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To restart the MySQL server on the CTPView server:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **3) Restart MySQL Server**.

The MySQL server is stopped and then restarted.

Setting the Logging Level (CTPView Server Menu)

You can specify the logging level, which determines what events are logged. The log output is placed in the `/var/log/acornngui.log` file.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To set the logging level:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **7) Set Logging Level**.
3. Enter one of the following:
 - **1) Normal (Most commands, All errors)**
 - **2) Debug Level 1 (All commands, All errors)**
 - **3) Debug Level 2 (All commands, All output)**

Restoring Default Values on the CTPView Server

- Resetting the Default System Administrator Account (CTPView Server Menu) on page 115
- Resetting the Data File Permissions (CTPView Server Menu) on page 115
- Resetting the CTPView System Files to the Default Values (CTPView Server Menu) on page 116
- Resetting the Default Firewall Settings (CTPView Server Menu) on page 118

Resetting the Default System Administrator Account (CTPView Server Menu)

You can remove the configured values for the CTPView System Administrator account and restore the default values.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To reset the System Administrator account and password to the default values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **6) Reset account for default System Administrator**.

Resetting the Data File Permissions (CTPView Server Menu)

You can remove all configured permissions for the CTPView server data files.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To reset the data file permission values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **5) Reset Data File Permissions**.

3. Enter **1) Yes** when prompted to continue.

Resetting the CTPView System Files to the Default Values (CTPView Server Menu)

You can remove all configured values for the CTPView server system files and restore the default values.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To reset the CTPView system files to the default values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **3) Reset System Files to default CTPView values**.
3. Enter **1) Yes** when prompted to continue.

CTPView displays information about the actions taken, as shown in the following sample output.

```
*****
Modifying the system files on this server to Juniper CTPView default values .
. .

===== Refreshing log directory =====
===== setting log file permissions =====
===== Verifying default umask =====
===== Updated runtime level in /etc/inittab file =====
===== Serial console access already set in /etc/inittab file =====
===== Added ttyS0 to /etc/securetty file =====
===== Serial parameters already set in /boot/grub/grub.conf file =====
===== Timeout parameters already set in /boot/grub/grub.conf file =====
===== CTPView title already set in /boot/grub/grub.conf file =====
===== Disabling pool.ntp.org servers in /etc/ntp.conf file =====
===== Enabling 127.127.1.0 as local clock in /etc/ntp.conf file =====
Shutting down ntpd:                [ OK ]
Starting ntpd:                      [ OK ]
===== Setting status of system services =====
  == set httpd on
Stopping httpd:                    [ OK ]
Closing CTPView sockets:           [ OK ]
Starting httpd:                    [ OK ]
  == set ntpd on
Shutting down ntpd:                [ OK ]
Starting ntpd:                      [ OK ]
  == set sendmail on
Shutting down sm-client:           [ OK ]
Shutting down sendmail:            [ OK ]
Starting sendmail:                  [ OK ]
Starting sm-client:                 [ OK ]
  == set sshd on
Stopping sshd:                     [ OK ]
Starting sshd:                      [ OK ]
  == set mysqld on
Stopping MySQL:                    [ OK ]
```

```

Starting MySQL: [ OK ]
  == set network on
Shutting down interface eth0: [ OK ]
Shutting down loopback interface: [ OK ]
Bringing up loopback interface: [ OK ]
Bringing up interface eth0: [ OK ]
  == set auditd on
Stopping auditd: [ OK ]
Error deleting rule (Operation not permitted)
Starting auditd: [ OK ]
Error deleting rule (Operation not permitted)
There was an error in line 7 of /etc/audit/audit.rules
  == set anacron off
  == set atd off
  == set netfs off
  == set nfslock off
  == set NetworkManager off
===== File /etc/cron.daily/00-logwatch did not exist
===== Directory /mnt/usbhd already exists
===== Directory /mnt/flash already exists
===== Directory /mnt/cdrom already exists
===== Cleared /etc/resolv.conf file
===== Restarting network daemon =====
Shutting down interface eth0: [ OK ]
Shutting down loopback interface: [ OK ]
Bringing up loopback interface: [ OK ]
Bringing up interface eth0: [ OK ]
===== nullok option already disabled in /etc/pam.d/system-auth file =====
===== Setting credit options in /etc/pam.d/system-auth file =====
===== Setting remember options in /etc/pam.d/system-auth file =====
===== Setting configuration in /etc/ssh/sshd_config file =====
===== Setting configuration in /etc/ssh/ssh_config file =====
===== Setting single user login configuration =====
===== Setting login.def parameters =====
===== Setting man file permissions =====
===== Setting access.conf parameters =====
===== Disable <Ctrl><Alt><Del> =====
===== Setting root directory file permissions =====
===== Setting nosuid in fstab file =====
===== Setting allowable cron access =====
===== Setting cron permissions =====
===== Setting httpd permissions =====
===== Setting logwatch.pl permissions =====
===== Setting denied at access =====
===== Setting sysctl parameters =====
===== Setting traceroute permissions =====
===== Disable decode alias =====
===== Setting snmpd permissions =====
===== Setting rsyslog permissions =====
===== Setting encryption parameters =====
===== Setting security tools permissions =====
===== Rotating logs =====
===== Removing non-owned files =====
find: /proc/4297/task/4297/fd/4: No such file or directory
find: /proc/4297/task/4297/fd/4: No such file or directory
find: /proc/4297/task/4297/fdinfo/4: No such file or directory
find: /proc/4297/task/4297/fdinfo/4: No such file or directory
find: /proc/4297/fd/4: No such file or directory
find: /proc/4297/fd/4: No such file or directory
find: /proc/4297/fdinfo/4: No such file or directory
find: /proc/4297/fdinfo/4: No such file or directory

```

```
==== Restarting sshd ====
Stopping sshd:                [ OK ]
Starting sshd:                [ OK ]
==== Disabling welcome page ====
==== Disabling browser access to manual ====
==== Setting KeepAlive to On ====
==== Setting StartServers to 8 ====
==== Setting MaxSpareServers to 10 ====
==== Setting -ExecCGI Option ====
==== Setting -FollowSymLinks Option ====
==== Setting -IncludesNOEXEC Option ====
==== Setting -MultiViews Option ====
==== Setting -Indexes Option ====
==== Setting LimitRequestBody Option ====
==== Restarting httpd daemon ====
Stopping httpd:                [ OK ]
Closing CTPView sockets:      [ NONE ]
Starting httpd:                [ OK ]
==== Setting cgi-bin permissions ====
==== Setting htpasswd permissions ====
==== Removing application/x-shell mime types ====

>>>>> JUNIPER SERVER MODIFICATIONS COMPLETE. <<<<<<
```

Resetting the Default Firewall Settings (CTPView Server Menu)

You can remove all configured values for the CTPView server firewall and restore the default values.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To reset the CTPView server firewall settings to the default values:

1. From the CTPView Configuration Menu, select **4) Advanced Functions**.
2. Select **1) Reset Default Firewall Settings**.
3. Enter **1) Yes** when prompted to continue.

The default firewall values are restored in `/etc/sysconfig/iptables`. The NTP daemon is started, and the SSH daemon is stopped and then restarted.

Changing Administrative Passwords to Improve Access Security

- Changing Passwords to Improve Access Security on page 119
- Changing the BIOS Menu Password (CTPView Server CLI) on page 120
- Changing the Server's Root Account Password (CTPView Server CLI) on page 121
- Changing the GRUB Boot Loader Password (CTPView Server Menu) on page 121
- Changing the MySQL Apache Account Password (CTPView Server Menu) on page 122
- Changing the MySQL Root Account Password (CTPView Server Menu) on page 123

Changing Passwords to Improve Access Security

A number of administrative passwords must be changed when you install a new CTPView server or upgrade the software. Juniper Networks also recommends that you change the following administrative passwords at least on an annual basis, and whenever CTP network administrators are changed.

To change administrative passwords:

- Change the BIOS menu password.
See “Changing the BIOS Menu Password (CTPView Server CLI)” on page 29.
- Change the CTPView server's root account password.
See “Changing the Server's Root Account Password (CTPView Server CLI)” on page 31.
- Change the GRUB Boot Loader password.
See “Changing the GRUB Boot Loader Password (CTPView Server Menu)” on page 31.
- Change the MySQL Apache account password.
See “Changing the MySQL Apache Account Password (CTPView Server Menu)” on page 32.
- Change the MySQL root account password.
See “Changing the MySQL Root Account Password (CTPView Server Menu)” on page 33.

Changing the BIOS Menu Password (CTPView Server CLI)

For security purposes, change the default password for BIOS menu access. This account has no username associated with it. The BIOS menu password should conform to your local password requirements.



BEST PRACTICE: Change the BIOS menu password at least yearly and whenever administrators change.

To change the BIOS menu password:

1. Power on or reboot the server.
2. During the boot process, press F2 while the Dell logo is displayed on the monitor. The boot process continues and displays several messages in turn on the screen.
3. Enter the default password when the process pauses and displays “Enter Setup Password.”

For the default BIOS menu password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39.

4. At the BIOS menu, select **System Security** and press Enter.
5. Highlight **Setup Password**—be sure that you have not selected **System Password**—and press Enter.
6. Enter your new BIOS password, reenter it, and then Press Enter to continue.
7. Press Esc.
8. In the window that opens, select **Save Changes and Exit** and press Enter.

The server restarts.

Related Documentation

- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Changing the Server's Root Account Password (CTPView Server CLI)

For security purposes, change the default password for the server's root user account. The root account password should conform to your local password requirements.



BEST PRACTICE: Change the root account password at least yearly and whenever administrators change.

To change the root account password:

1. Log in to the CTPView server as a non-root user, using either a directly connected keyboard and monitor or an SSH application over your network.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

2. Enter **su -** to switch to the root account.

3. Enter the default root password.

For the default root password, see “Default CTPOS and CTPView Accounts and Passwords” on page 39. You cannot log in using the root account.

4. Enter **passwd**.

5. Enter your new password.

Related Documentation

- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Changing the GRUB Boot Loader Password (CTPView Server Menu)

For security purposes, change the default password for the GRUB Boot Loader menu.



BEST PRACTICE: Change the GRUB Boot Loader password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

To change the GRUB Boot Loader password:

1. From the CTPView Configuration Menu, select **Option 8 (GRUB Functions)**.
2. Select **1) Change GRUB password**.
3. Follow the prompts to complete changing the password.

Related Documentation

- CTPOS and CTPView Software Password Requirements on page 40
- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Changing the MySQL Apache Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server Apache user account.



BEST PRACTICE: Change the MySQL Apache password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

To change the MySQL Apache password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **2) Change MySQL Apache password**.
3. Follow the prompts to complete changing the password.

Related Documentation

- CTPOS and CTPView Software Password Requirements on page 40
- Configuring the CTPView Administrative Settings on page 27

- Changing Passwords to Improve Access Security on page 119

Changing the MySQL Root Account Password (CTPView Server Menu)

For security purposes, change the default password for the MySQL server root user account.



BEST PRACTICE: Change the MySQL Root Account password at least yearly and whenever administrators change.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.



NOTE: You cannot use an SSH application to access the CTPView server until you have configured the server in your network and assigned it an IP address. See “Configuring the Network Access (CTPView Server Menu)” on page 33.

To change the MySQL root account password:

1. From the CTPView Configuration Menu, select **6) MySQL Functions**.
2. Select **1) Change MySQL root password**.
3. Follow the prompts to complete changing the password.

Related Documentation

- CTPOS and CTPView Software Password Requirements on page 40
- Configuring the CTPView Administrative Settings on page 27
- Changing Passwords to Improve Access Security on page 119

Using Third-Party Software on CTPView Servers

- Third-Party Software on CTPView Servers on page 125

Third-Party Software on CTPView Servers

You may choose to use third-party software on your CTPView server.



NOTE: Third-party software installed on the CTPView server is not supported by Juniper Networks.

Typical third-party software is one of the following types:

- System file monitoring and management software

Tripwire third-party software is preloaded onto the CTPView server. Tripwire facilitates security, intrusion detection, damage evaluation, and recovery. You can use this software to generate a baseline of system files and directories after you have configured your server to a known secure state. Tripwire subsequently monitors the system files and directories and compares them with the baseline, enabling you to identify any changes that have been made.

Refer to the Tripwire documentation for more information. Complete documentation is located on the CTPView server in the

`/usr/share/doc/tripwire-<current-version-number>` directory.

- Antivirus software

McAfee VirusScan for UNIX, version 5.10.0, is the only antivirus application from a DOD-approved vendor that is compatible with CTPView server software.

The CTPView server includes a dedicated directory, `/var/av`, for installation of antivirus software. You must be a member of the `server` group to install the antivirus software directly into the `/var/av` directory. After the software archive is in the `/var/av` directory, follow the installation directions in the McAfee product guide. We recommend that you select the default choices offered when installing the antivirus software. Refer to the antivirus documentation for more information about this software.

PART 4

Troubleshooting

- Validating the CTPView Server System Configuration on page 129
- Restoring CLI Access to the CTPView Server on page 131
- Restoring Browser Access to a CTPView Server on page 137
- Changing a CTPOS User Password on page 139
- Booting the CTPView Server from the CD-ROM Drive on page 141
- Restarting the Apache Daemon In the Event of Browser Issues on page 143

Validating the CTPView Server System Configuration

- Validating the CTPView Server Configuration (CTPView) on page 129

Validating the CTPView Server Configuration (CTPView)

This topic describes how to validate the CTPView server system configuration. Examining the system configuration information is a useful first step in troubleshooting many issues. Validate the configuration after installing or upgrading the CTPView software or server OS to determine whether the operation completed successfully.

The validation utility reports on a long list of configuration details that are critical or desirable for proper operation of the CTPView software. Instructions are provided for correcting items that are out of compliance.

To validate the system configuration:

1. Log in to the CTPView GUI.
2. In the side pane, select **Server > Diagnostics**.

The System Information pane is displayed.

3. Click **Validate Server Configuration**.

The Server Configuration Validation pane is displayed.

4. Confirm that all fields are set to their default values.

The display indicates whether each item is valid or noncompliant. A highlighted field indicates a problem. Follow the displayed instructions to correct the problem.

Related Documentation

- Installing or Upgrading the CTPView Server OS and CTPView Software on page 14

Restoring CLI Access to the CTPView Server

- Restoring Access to a CTPView Server on page 131
- Accessing a Shell on the CTPView Server (CTPView Server CLI) on page 132
- Setting a New Password for a Nonroot User Account (CTPView Server CLI) on page 133
- Setting a New Password for a Root User Account (CTPView Server CLI) on page 134
- Creating a Nonroot User Account and Password (CTPView Server CLI) on page 134

Restoring Access to a CTPView Server

You must use a nonroot password to log in to the CTPView server. If you lose all the nonroot passwords, then you cannot access the CTPView server.

To perform tasks on the server as a root user, you must first log in using an existing nonroot account. You then switch to the root account with the command `su -` and enter the root password.

This topic describes how to restore access to the CTPView server in any of the following events:

- You lose the passwords to all nonroot user accounts.
- You lose the root password.
- You lose the all nonroot user passwords and the root password.

Before you begin, you must have the GRUB Boot Loader password and physical access to the server with a connected monitor and keyboard.

If you do not have the GRUB Boot Loader password, you must use the system motherboard jumpers to disable the password protection feature before proceeding. You can find details about how to perform this task on the Dell PowerEdge Documentation CD, which was included with the original packing material for the CTPView server.

To restore access to the CTPView server when you have lost all nonroot user passwords:

1. Access a shell.

See “Accessing a Shell on the CTPView Server (CTPView Server CLI)” on page 132.

2. Set a new password for a nonroot user account.

See “Setting a New Password for a Nonroot User Account (CTPView Server CLI)” on page 133.

3. Create a temporary nonroot user account and password, access the root account, and create a new permanent nonroot user.

See “Creating a Nonroot User Account and Password (CTPView Server CLI)” on page 134.

To restore access to the CTPView server when you have lost the root password:

1. Access a shell.

See “Accessing a Shell on the CTPView Server (CTPView Server CLI)” on page 132.

2. Set a new password for a root user account.

See “Setting a New Password for a Root User Account (CTPView Server CLI)” on page 134.

To restore access to the CTPView server when you have lost all nonroot user passwords and the root password:

1. Access a shell.

See “Accessing a Shell on the CTPView Server (CTPView Server CLI)” on page 132.

2. Set a new password for a root user account.

See “Setting a New Password for a Root User Account (CTPView Server CLI)” on page 134.

3. Set a new password for a nonroot user account.

See “Setting a New Password for a Nonroot User Account (CTPView Server CLI)” on page 133.

4. Create a temporary nonroot user account and password, access the root account, and create a new permanent nonroot user account.

See “Creating a Nonroot User Account and Password (CTPView Server CLI)” on page 134.

**Related
Documentation**

- CTPOS and CTPView Software Password Requirements on page 40

Accessing a Shell on the CTPView Server (CTPView Server CLI)

Before you begin, you must have physical access to the server with a connected monitor and keyboard.

To gain access to a shell:

1. Use the power switch on the server to turn off the power.
2. Turn on the server power.
3. When the blue GNU GRUB screen appears, enter the letter **p**. You have only a few seconds to do this.
4. Enter the GRUB Boot Loader password.
5. Enter the letter **e**.
6. Use the keyboard arrows to highlight the line that begins with the word **kernel**.
7. Enter the letter **e**.
8. Enter the following code at the end of the highlighted line:

```
init=/bin/bash
```

9. Enter the letter **b**.

The system boots and displays the **bash-3.00#** shell prompt.

10. Enter the following command:

```
/bin/mount /dev/md2 -o remount,rw
```

Related Documentation

- Restoring Access to a CTPView Server on page 131

Setting a New Password for a Nonroot User Account (CTPView Server CLI)

Before you begin, prepare the server by accessing the shell. See “Accessing a Shell on the CTPView Server (CTPView Server CLI)” on page 132.

To set a new password for a nonroot user account:

1. Enter the following command:

```
/usr/bin/passwd username
```

2. Enter the new password for the nonroot user when prompted.
3. Enter the following command:

```
/bin/mount /dev/md2 -o remount,ro
```

4. Enter the command **reboot**.

Wait for the server to reboot.

Related Documentation

- CTPOS and CTPView Software Password Requirements on page 40
- Restoring Access to a CTPView Server on page 131

Setting a New Password for a Root User Account (CTPView Server CLI)

Ensure that the new root account password conforms to your local password requirements.

Before you begin, prepare the server by accessing the shell. See “Accessing a Shell on the CTPView Server (CTPView Server CLI)” on page 132.

To set a new password for a root user account:

1. Enter the following command:

```
/usr/bin/passwd
```

2. Enter the new password when prompted.

3. Enter the following command:

```
/bin/mount /dev/md2 -o remount,ro
```

4. Enter the command **reboot**.

Wait for the server to reboot.

Related Documentation

- Restoring Access to a CTPView Server on page 131

Creating a Nonroot User Account and Password (CTPView Server CLI)

Before you begin, prepare the server by accessing the shell. See “Accessing a Shell on the CTPView Server (CTPView Server CLI)” on page 132.

To create a new account and password for a nonroot user:

1. Enter the following command:

```
/usr/sbin/useradd username
```

2. Enter the following command:

```
/usr/bin/passwd username
```

3. Enter the new password for the nonroot user when prompted.

4. Enter the following command:

```
/bin/mount /dev/md2 -o remount,ro
```

5. Enter the command **reboot**.

Wait for the server to reboot.

6. Log in as the new temporary user.

7. Enter the command **su -** to switch to the root account and display the CTPView Configuration Menu utility.

8. Create a new permanent nonroot user account.

9. Exit the utility, the root account, and then the temporary user account.
10. Log in as the new permanent nonroot user.
11. Enter the command `su -` to switch to the root account.
12. Enter the following command to delete the temporary user account:

```
/usr/bin/userdel -r username
```

**Related
Documentation**

- CTPOS and CTPView Software Password Requirements on page 40
- Restoring Access to a CTPView Server on page 131

Restoring Browser Access to a CTPView Server

- Restoring Browser Access to a CTPView Server (CTPView Server Menu) on page 137

Restoring Browser Access to a CTPView Server (CTPView Server Menu)

You cannot recover lost usernames and passwords. If you lose access to the CTPView GUI as a Global_Admin user, you can use the following procedure to restore the default Global_Admin user account *Juniper*, select a new password for user *Juniper*, and assign the user to the default user group *TempGroup*.

Before you begin, log in to the CTPView server and access the CTPView Configuration Menu. See “Accessing the CTPView Server Configuration Menu (CTPView Server Menu)” on page 95.

To restore browser access to the CTPView server:

1. From the CTPView Configuration Menu, select **7) CTPView Access Functions**.
2. Select **1) Reset password for default user Juniper**.
3. Follow the prompts to assign user *Juniper* to user group *TempGroup*. The user is given default user properties.
4. Log in to the CTPView GUI with the restored user password, and review the default user values in CTPView Admin Center. Make any appropriate changes.

Changing a CTPOS User Password

- Changing a User Password for a CTP Platform on page 139

Changing a User Password for a CTP Platform

The CTPOS software is installed on a CompactFlash card that normally operates in a read-only state. You must make the card writable in order to change a user password. Only the root user is allowed to make the CompactFlash card writable.

To change a CTP platform user's password:

1. Log in to the CTP platform as a nonroot user.
2. Enter the command `su -` to switch to the root account.
3. Enter the following command to make the CompactFlash card writable:

mfw

4. Open a new SSH window and log in with the username whose password you want to change.
5. Follow the prompts to change the password.
6. Enter the command `su -` to switch to the root account.
7. Enter the following command to return the CompactFlash card to read-only:

mfr



NOTE: For users who employ the utility SecureCRT for SSH to access the CTP platform, you must change the Authentication method on SecureCRT from the default setting of Password to Keyboard Interactive. If you fail to do so, the password prompts originating at the CTP platform are prevented from reaching your display, and the password update procedure fails.

Related Documentation

- CTPOS and CTPView Software Password Requirements on page 40

Booting the CTPView Server from the CD-ROM Drive

- Booting the CTPView Server from the CD Drive on page 141

Booting the CTPView Server from the CD Drive

For security purposes, booting from the CD drive is disabled in the system BIOS settings. If you need to boot from a CD, you must reconfigure the BIOS. You must also have physical access to the server and have the BIOS Menu password.

If you have forgotten the BIOS Menu password, use the system motherboard jumpers to disable the password protection feature before proceeding. Details about how to perform this task are found on the Dell PowerEdge Documentation CD, which was included with the original CTPView server packing material.

To boot the CTPView server from the CD drive:

1. Connect a monitor, keyboard, and mouse to the server.
2. Power on the server and press F2 while the Dell logo is displayed.

The phrase **Entering Setup** appears in the top right corner of the screen, and then the BIOS setup screen loads. If you miss pressing F2 at the proper time, press Ctrl+Alt+Delete to reboot the system so you can repeat this step.

The bottom line on the screen contains help for navigating and modifying this menu.

3. Insert the CD boot disk into the CD drive.
4. Enter the BIOS Menu password, and press Enter to continue.
5. Highlight **Boot Sequence**, press Enter, and select **IDE CD-ROM device**. Press Enter to continue.
6. Press Esc. In the pop-up window highlight **Save Changes and Exit**, and press Enter.

The server restarts and boots from the CD.



NOTE: For security considerations, it is important that you subsequently disable booting from a CD.

To disable booting from the CD drive:

1. Repeat Steps 1 through 4 above.
2. Highlight **Boot Sequence**, press Enter, and clear **IDE CD-ROM device**. Press Enter to continue.
3. Press Esc. In the pop-up window highlight **Save Changes and Exit**, and press Enter.

The server restarts and boots from CompactFlash memory.

CHAPTER 23

Restarting the Apache Daemon In the Event of Browser Issues

- Restarting the Apache Daemon (CTPView Server Menu) on page 143

Restarting the Apache Daemon (CTPView Server Menu)

If you are having problems viewing or accessing the CTPView GUI in your browser, you might want to restart the Apache daemon on the CTPView server.

To restore browser access to the CTPView server:

1. From the CTPView Configuration Menu, select **7) CTPView Access Functions**.
2. Select **2) Restart Apache Daemon**.

PART 5

Index

- Index on page 147

Index

A

access security	
CTPView server, managing.....	107
accounts	
creating CTPView server nonroot.....	134
default CTPOS.....	39
default CTPView server.....	39
address filter, IP See IP access filter	
Admin Center	
accessing.....	48
groups	
adding.....	51
deleting.....	54
modifying affiliation.....	50
modifying properties.....	51
monitoring.....	50
passwords	
changing requirements.....	55
excluding from use.....	54
limiting use.....	54
managing user.....	54
reinstating excluded.....	55
users	
adding.....	49
automatic logout.....	56
counters.....	57
deleting active.....	53
deleting inactive.....	53
deleting prohibited.....	54
displaying prohibited.....	52
IP access filters, creating.....	57
IP access filters, removing.....	57
locked-out IP addresses.....	57
lockout period.....	56
logging out selected.....	56
login attempts.....	56
login properties.....	55
managing access.....	52
modifying properties.....	50
monitoring.....	49

prohibiting.....	52
reinstating prohibited.....	53
administrative passwords	
changing.....	119
administrative settings	
configuring.....	27
Apache daemon	
restarting.....	109, 143
archive file	
complete, upgrading CTPView software	
with.....	25
web, upgrading CTPView software with.....	26
authentication	
CTPView software users with Steel-Belted	
Radius.....	99

B

bandwidth throttling.....	73
banner	
CTPView start-up (log-in).....	66
setting	
CTPView server menu.....	107
BIOS menu	
changing the password.....	29, 120
booting CTPView server from CD.....	141
browser	
logging in.....	35
restarting Apache daemon on CTPView	
server.....	143
restoring access.....	137

C

Circuit to Packet network	
clock options.....	5
overview.....	3
receive packet processing.....	5
serial stream processing.....	4
software overview.....	6
transmit packet processing.....	4
clock options.....	5

CompactFlash card	
burning a CTPOS image to.....	38
changing read/write state.....	139
configuration settings	
restoring (CTPView server menu).....	20, 113
saving CTPView software.....	16, 111
configuration, server	
restoring overview (CTPView GUI).....	19, 74
CTP platforms	
adding and removing.....	61
adding comments to monitoring status.....	83
automatically collecting statistical data.....	72
changing display settings for network	
monitoring.....	80
checking connections to the CTPView	
server.....	81
displaying network statistics.....	89
displaying reports.....	87
displaying runtime query results.....	83
host groups, adding and removing.....	62
managing	
monitoring.....	64
manually overriding monitoring status.....	83
monitoring (CTPView GUI).....	79
passwords	
changing user.....	139
port forwarding	
clearing open sockets.....	109
configuring the platform.....	67
configuring the server.....	109
restoring configuration.....	84
saving configuration automatically.....	84
setting audible status alert.....	86
SNMP communities, adding and removing.....	63
SSH connections	
clearing open sockets.....	109
configuring the platform.....	67
configuring the server.....	109
understanding network reports.....	88
updating CTPOS.....	37
CTPOS	
burning image to a CompactFlash card.....	38
default accounts and passwords.....	39
updating.....	37
upgrade files.....	43
CTPView	
menu, accessing.....	95
CTPView Admin Center See Admin Center	
CTPView GUI	
adding comments to platform monitoring	
status.....	83
Admin Center, accessing.....	48
automatically removing outdated files.....	72
automatically synchronizing servers.....	72
bandwidth throttling.....	73
browser settings.....	91
browser, logging in.....	35
changing default user password.....	35
checking network connections.....	81
configuring automatic functions.....	72
creating more server disk space.....	17
CTP platform reports.....	87
display settings.....	92
display settings help.....	92
displaying platform and port runtime query	
results.....	83
email notifications.....	65
Global_Admin account, creating.....	36
groups	
adding.....	51
deleting.....	54
modifying affiliation.....	50
modifying properties.....	51
monitoring.....	50
host groups, adding and removing.....	62
managing users and groups.....	47
manually overriding platform monitoring	
status.....	83
monitoring the CTP platform network.....	79
network monitoring display settings.....	80
network reports.....	87
field descriptions.....	88
network statistics.....	89
NTP servers, managing.....	69
passwords	
changing requirements.....	55
excluding from use.....	54
limiting user.....	54
managing user.....	54
reinstating excluded.....	55
platforms, adding and removing.....	61
port forwarding, managing.....	67
restoring configuration	
CTP platform.....	84
CTPView server, by synchronizing	
servers.....	20, 75

- restoring server configuration
 - overview.....19, 74
- saving configuration
 - CTP platform.....84
- server clock, setting.....68
- setting audible platform status alert.....86
- SNMP communities, adding and removing.....63
- start-up (log-in) banner.....66
- support for tabbed or nontabbed browsers.....91
- synchronizing servers
 - automatically.....77
 - manually.....78
 - network configuration.....76
 - overview.....75
- user properties, modifying.....50
- users
 - adding.....49
 - automatic logout.....56
 - counters.....57
 - deleting active.....53
 - deleting inactive.....53
 - deleting prohibited.....54
 - displaying prohibited.....52
 - IP access filters, creating.....57
 - IP address access filters, removing.....57
 - locked-out IP addresses.....57
 - lockout period.....56
 - logging out selected.....56
 - login attempts.....56
 - login properties.....55
 - managing access.....52
 - monitoring.....49
 - prohibiting.....52
 - reinstating prohibited.....53
- validating server configuration.....22, 129
- verifying server OS installation.....21
- CTPView server
 - access security, managing.....107
 - account
 - creating nonroot.....134
 - acquiring shell access.....132
 - booting from CD.....141
 - clock, setting.....68
 - creating disk space
 - CTPView GUI.....17
 - data file permissions, resetting.....115
 - default accounts and passwords.....39
 - determining free disk space.....17
 - disk space, creating
 - CTPView server menu.....18, 112
 - firewall defaults, restoring.....118
 - installation log.....21
 - installing OS (CTPView server CLI).....18
 - installing the software overview.....10
 - log-in banner, setting.....107
 - logging level, setting.....114
 - logs, managing.....105
 - MySQL server, restarting.....113
 - network access, configuring.....33
 - password
 - creating nonroot.....134
 - setting new nonroot.....133
 - setting new root.....134
 - password requirements.....40, 58
 - port forwarding, configuring.....109
 - preparing a new.....29
 - restoring browser access.....137
 - restoring configuration by synchronizing
 - servers.....20, 75
 - restoring configuration overview
 - CTPView GUI.....19, 74
 - restoring configuration settings
 - CTPView server menu.....20, 113
 - restoring shell access.....131
 - software installation and upgrade
 - overview.....10
 - start-up (log-in) banner.....66
 - synchronizing to restore configuration.....20, 75
 - system administrator account, resetting.....115
 - system file defaults, restoring.....116
 - third-party software on.....125
 - upgrade files.....43
 - upgrading the software overview.....10
 - user passwords, managing.....97
 - users, managing shell account.....95
 - validating configuration.....22, 129
 - verifying OS installation.....21
 - web certificate, creating.....34
- CTPView server CLI
 - BIOS menu password.....29, 120
 - burning CTPOS image to a CompactFlash
 - card.....38
 - changing default user password.....30
 - changing root account password.....31, 121
 - installing server OS.....18
 - reviewing the installation log.....21

- CTPView server menu
 - access security, managing.....107
 - accessing.....95
 - creating more server disk space.....18, 112
 - GRUB boot loader password.....31, 121
 - log-in banner, setting.....107
 - logging level, setting.....114
 - logs, managing.....105
 - MySQL Apache account password.....32, 122
 - MySQL root account password.....33, 123
 - MySQL server, restarting.....113
 - network access, configuring.....33
 - port forwarding, managing.....109
 - restoring server configuration settings.....20, 113
 - saving CTPView configuration settings.....16, 111
 - user passwords, managing.....97
 - users, managing shell account.....95
 - web certificate, creating.....34
- CTPView server OS
 - software installation and upgrade
 - overview.....10
 - tasks.....14
 - verifying installation.....21
- CTPView software
 - configuring administrative settings.....27
 - saving configuration settings.....16, 111
 - updating CTPOS.....37
 - upgrade files.....43
 - upgrading
 - overview.....23
 - with complete archive file.....25
 - with web archive file.....26
 - user security levels.....58
- D**
 - data file permissions
 - CTPView server, resetting.....115
- E**
 - email notifications
 - configuring.....65
- F**
 - files
 - removing (CTPView GUI).....17
 - removing (CTPView server menu).....18, 112
 - firewall
 - CTPView server defaults, restoring.....118
- G**
 - Global_Admin account
 - creating CTPView GUI.....36
 - groups, user
 - adding.....51
 - deleting.....54
 - managing.....47
 - modifying affiliation.....50
 - modifying properties.....51
 - monitoring.....50
 - GRUB boot loader
 - changing the password.....31, 121
- H**
 - host groups
 - adding and removing.....62
- I**
 - installation
 - reviewing log for errors.....21
 - software overview.....10
 - IP access filter.....57
 - IP address filter See IP access filter
- L**
 - limiting CTP network bandwidth.....73
 - log-in banner
 - configuring.....66
 - setting
 - CTPView server menu.....107
 - logging level
 - CTPView server, setting.....114
 - login security
 - CTPView software.....58
 - logs
 - managing CTPView server.....105
- M**
 - menu
 - accessing CTPView server.....95
 - MySQL database
 - automatically backing up.....72
 - changing the Apache account
 - password.....32, 122
 - changing the root account password.....33, 123
 - MySQL server
 - restarting.....113

N

native authentication with Steel-Belted Radius.....	99
network access	
configuring server.....	33
network reports	
displaying CTP platform.....	87
understanding CTP platform.....	88
nonroot account	
creating.....	134
nonroot passwords	
creating.....	134
setting new.....	133
NTP servers	
managing.....	69

O

OS, CTPView server	
installing (CTPView server CLI).....	18
software installation and upgrade	
overview.....	10
tasks.....	14
verifying installation on server.....	21
outdated files	
automatically removing.....	72
removing (CTPView GUI).....	17
removing (CTPView server menu).....	18, 112
overview	
Circuit to Packet network.....	3
CTP network software.....	6
restoring configuration.....	19, 74
restoring server configuration	
CTPView GUI.....	19, 74
software installation and upgrade	
CTPView server.....	10
synchronizing servers (CTPView)	
CTPView GUI.....	75

P

passwords	
BIOS menu changing.....	29, 120
changing administrative.....	119
changing requirements.....	55
CTP platform user	
changing.....	139
CTPOS	
default.....	39
CTPView GUI	
changing default.....	35

CTPView server

changing default.....	30
changing root.....	31, 121
creating nonroot.....	134
default.....	39
recovering lost.....	131
requirements.....	40, 58
setting new nonroot.....	133
setting new root.....	134
excluding from use.....	54
expiration of user.....	97
Global_Admin account.....	36
GRUB boot loader changing.....	31, 121
limiting use.....	54
managing user.....	54
MySQL database changing.....	32, 33, 122, 123
reinstating excluded.....	55
requirements of user.....	97
port forwarding	
configuring on CTP platforms.....	67
configuring on the CTPView server.....	109

R

receive packet processing.....	5
redundant files	
removing (CTPView GUI).....	17
removing (CTPView server menu).....	18, 112
remote host See CTP platforms	
root passwords	
setting new CTPView server.....	134
RSA SecurID authentication with Steel-Belted Radius.....	99

S

security levels	
user.....	58
serial stream processing.....	4
shell access to CTPView server	
acquiring.....	132
restoring.....	131
SNMP communities See adding and removing software	
installation and upgrade	
CTPView server OS tasks.....	14
CTPView server overview.....	10
network management only.....	23
upgrade files.....	43

SSH	
connections to CTP platforms	
configuring on the platform.....	67
persistent connections to CTP platforms	
configuring on the server.....	109
start-up banner	
configuring.....	66
setting	
CTPView server menu.....	107
Steel-Belted Radius	
authentication for CTPView software	
users.....	99
synchronization of CTPView servers	
automatic method.....	77
configuring the synchronization network.....	76
manual method.....	78
overview.....	75
to restore configuration.....	20, 75
system administrator account	
CTPView server, resetting.....	115
system file	
CTPView server defaults, restoring.....	116
T	
third-party software	
using on the CTPView server.....	125
transmit packet processing.....	4
troubleshooting	
installation issues.....	21
two factor authentication with Steel-Belted	
Radius.....	99
U	
upgrade	
CTPView Network Management Software.....	23
software overview.....	10
user groups See groups, user	
user passwords	
changing CTP platform.....	139
changing CTPView GUI default.....	35
changing server's default.....	30
changing server's root.....	31, 121
expiration.....	97
requirements.....	97
users	
adding.....	49
authentication with Steel-Belted Radius.....	99
automatic logout.....	56
counters.....	57
deleting active.....	53
deleting inactive.....	53
deleting prohibited.....	54
displaying prohibited.....	52
IP access filters	
creating.....	57
removing.....	57
locked-out IP addresses.....	57
lockout period.....	56
logging out selected.....	56
login attempts.....	56
login properties.....	55
managing.....	47
managing access.....	52
managing passwords.....	54
modifying properties.....	50
monitoring.....	49
password requirements.....	40, 58
prohibiting.....	52
reinstating prohibited.....	53
security levels.....	58
shell account, classification.....	97
shell account, managing.....	95
W	
web certificate	
creating.....	34