

ip vrrp icr-partition svlan-list explicit

Syntax ip vrrp *vrid* icr-partition svlan-list-explicit [*svlanIdValue* *vlanIdValue*] *
 [use-default-mac] [control-interface] [advertise-mac]

no ip vrrp *vrid* icr-partition svlan-list-explicit [*svlanIdValue* *vlanIdValue*] *

Release Information Command introduced in JUNOS Release 10.3.0.

Description Adds an S-VLAN range and VLAN range to the ICR partition. You can assign only unique S-VLAN range and VLAN range to the partition. If you attempt to assign a previously assigned S-VLAN range and VLAN range to the ICR partition, the router displays an error message. You can assign S-VLAN range and VLAN range only if you have selected S-VLAN based grouping by using the **ip vrrp icr-partition group** command. The **no** version deletes the S-VLAN range and VLAN range from the ICR partition.



NOTE: You can use the listed optional parameters only when you add a S-VLAN, VLAN pair to the ICR partition. You cannot modify an existing subinterface using these parameters. You can specify the optional parameters in any order.

- Options**
- *vrid*—VRID identifier; a number in the range 1–255
 - *svlanIdValue*—S-VLAN identifier; a number in the range 0–4095
 - *vlanIdValue*—VLAN identifier; a number in the range 0–4095
 - **use-default-mac**—Configures the S-VLAN range and VLAN range to use the default MAC address. By default, the router assigns the VRRP media access control (MAC) address to all subinterfaces of the ICR partition.
 - **control-interface**—Controls traffic on a subinterface that is part of a backup partition. When you use this option, the router changes the state of the corresponding subinterface to Admindown. When the subinterface is in Admindown state, the router blocks all traffic to the interface. However, the router does not block advertisements as long as VRRP is running on a separate subinterface. The router changes the state of the subinterface from Admindown to Up when the state of the partition changes from backup to master.
 - **advertise-mac**—Enables the subinterface to transmit GARP advertisements when the partition moves from backup state to master state. By default, GARP advertisements are blocked on a subinterface.

Mode Interface Configuration, Subinterface Configuration

Related Topics ■ Grouping ICR Subscribers Based on S-VLAN IDs

- Configuring an ICR Partition

Published: 2010-01-11