


Configuring Default Integrated Mode for ATM Interface

In the default integrated mode, the SAR scheduler is the dominant scheduler, and it backpressures the first-stage (HRR) scheduler per VC. Each VC buffers only a few hundred bytes.

Figure 1 shows the default integrated mode.

Figure 1: Default Integrated Mode



To configure default integrated mode:

1. From the desired port, set the QoS port mode to default integrated mode.

```
host1(config)#interface atm 2/0
host1(config-if)#no qos-mode-port
```



TIP: For ATM interfaces on ERX7xx models, ERX14xx models, and the ERX310 router, you must specify port 0.

2. Specify the VP shaping rate.

```
host1(config-if)#atm vp-tunnel 0 2000
```



TIP: Configuring an ATM VP tunnel sets a shaping rate in the SAR scheduler. Before configuring an ATM VP tunnel, there must be no PVCs with the same VPI that you are about to configure. Before using the **atm vp-tunnel** command, remove any PVCs from the configuration. You can reconfigure the PVCs after configuring the shapeless VP tunnel.

3. Specify the shaping rate for the ATM subinterface.

```
host1(config-if)#interface atm 2/0.5  
host1(config-subif)#atm-pvc 5 0 5 aal5snap 768
```

Related Topics

- Per-Packet Queuing on the SAR Scheduler Overview
- Guidelines for Configuring QoS over ATM
- atm vp-tunnel
- interface atm
- qos-mode-port

Published: 2010-03-21