



J-series™ Services Router

Administration Guide

Release 7.5

Juniper Networks, Inc.

1194 North Mathilda Avenue
Sunnyvale, California 94089
USA

408-745-2000

www.juniper.net

Part Number: 530-014843-01, Revision 1

This product includes the Envoy SNMP Engine, developed by Epilogue Technology, an Integrated Systems Company. Copyright © 1986-1997, Epilogue Technology Corporation. All rights reserved. This program and its documentation were developed at private expense, and no part of them is in the public domain.

This product includes memory allocation software developed by Mark Moraes, copyright © 1988, 1989, 1993, University of Toronto.

This product includes FreeBSD software developed by the University of California, Berkeley, and its contributors. All of the documentation and software included in the 4.4BSD and 4.4BSD-Lite Releases is copyrighted by the Regents of the University of California. Copyright © 1979, 1980, 1983, 1986, 1988, 1989, 1991, 1992, 1993, 1994. The Regents of the University of California. All rights reserved.

GateD software copyright © 1995, the Regents of the University. All rights reserved. Gate Daemon was originated and developed through release 3.0 by Cornell University and its collaborators. Gated is based on Kirton's EGP, UC Berkeley's routing daemon (routed), and DCN's HELLO routing protocol. Development of Gated has been supported in part by the National Science Foundation. Portions of the GateD software copyright © 1988, Regents of the University of California. All rights reserved. Portions of the GateD software copyright © 1991, D. L. S. Associates.

This product includes software developed by Maker Communications, Inc., Copyright © 1996, 1997, Maker Communications, Inc.

Juniper Networks, the Juniper Networks logo, NetScreen, NetScreen Technologies, the NetScreen logo, NetScreen-Global Pro, ScreenOS, and GigaScreen are registered trademarks of Juniper Networks, Inc. in the United States and other countries.

The following are trademarks of Juniper Networks, Inc.: ERX, ESP, E-series, Instant Virtual Extranet, Internet Processor, J2300, J4300, J6300, J-Protect, J-series, J-Web, JUNOS, JUNOScope, JUNOScript, JUNOSe, M5, M7i, M10, M10i, M20, M40, M40e, M160, M320, M-series, MMD, NetScreen-5GT, NetScreen-5XP, NetScreen-5XT, NetScreen-25, NetScreen-50, NetScreen-204, NetScreen-208, NetScreen-500, NetScreen-5200, NetScreen-5400, NetScreen-IDP 10, NetScreen-IDP 100, NetScreen-IDP 500, NetScreen-Remote Security Client, NetScreen-Remote VPN Client, NetScreen-SA 1000 Series, NetScreen-SA 3000 Series, NetScreen-SA 5000 Series, NetScreen-SA Central Manager, NetScreen Secure Access, NetScreen-SM 3000, NetScreen-Security Manager, NMC-RX, SDX, Stateful Signature, T320, T640, T-series, and TX Matrix. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners. All specifications are subject to change without notice.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

Copyright © 2006, Juniper Networks, Inc. All rights reserved.

J-series™ Services Router Administration Guide, Release 7.5
Copyright © 2006, Juniper Networks, Inc.
All rights reserved. Printed in USA.

Writing: Nidhi Bhargava, Michael Bushong, Taffy Everts, Jerry Isaac, Archana Maheshwari, Hareesh Kumar Kozhippurath Narayana Panicker, Laura Phillips, Frank Reade, and Swapna Steiger
Editing: Taffy Everts and Stella Hackell
Illustration: Faith Bradford Brown and Nathaniel Woodward
Cover Design: Edmonds Design

Revision History
9 January 2006—Revision 1.

The information in this document is current as of the date listed in the revision history.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer or otherwise revise this publication without notice.

Products made or sold by Juniper Networks (including the ERX-310, ERX-705, ERX-710, ERX-1410, ERX-1440, M5, M7i, M10, M10i, M20, M40, M40e, M160, M320, and T320 routers, T640 routing node, and the JUNOS and SDX-300 software) or components thereof might be covered by one or more of the following patents that are owned by or licensed to Juniper Networks: U.S. Patent Nos. 5,473,599, 5,905,725, 5,909,440, 6,192,051, 6,333,650, 6,359,479, 6,406,312, 6,429,706, 6,459,579, 6,493,347, 6,538,518, 6,538,899, 6,552,918, 6,567,902, 6,578,186, and 6,590,785.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. The JUNOS software has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

SOFTWARE LICENSE

The terms and conditions for using this software are described in the software license contained in the acknowledgment to your purchase order or, to the extent applicable, to any reseller agreement or end-user purchase agreement executed between you and Juniper Networks. By using this software, you indicate that you understand and agree to be bound by those terms and conditions. Generally speaking, the software license restricts the manner in which you are permitted to use the software and may contain prohibitions against certain uses. The software license may state conditions under which the license is automatically terminated. You should consult the license for further details. For complete product documentation, please see the Juniper Networks Web site at www.juniper.net/techpubs.

End User License Agreement

READ THIS END USER LICENSE AGREEMENT ("AGREEMENT") BEFORE DOWNLOADING, INSTALLING, OR USING THE SOFTWARE. BY DOWNLOADING, INSTALLING, OR USING THE SOFTWARE OR OTHERWISE EXPRESSING YOUR AGREEMENT TO THE TERMS CONTAINED HEREIN, YOU (AS CUSTOMER OR IF YOU ARE NOT THE CUSTOMER, AS A REPRESENTATIVE/AGENT AUTHORIZED TO BIND THE CUSTOMER) CONSENT TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT OR CANNOT AGREE TO THE TERMS CONTAINED HEREIN, THEN (A) DO NOT DOWNLOAD, INSTALL, OR USE THE SOFTWARE, AND (B) YOU MAY CONTACT JUNIPER NETWORKS REGARDING LICENSE TERMS.

1. **The Parties.** The parties to this Agreement are Juniper Networks, Inc. and its subsidiaries (collectively "Juniper"), and the person or organization that originally purchased from Juniper or an authorized Juniper reseller the applicable license(s) for use of the Software ("Customer") (collectively, the "Parties").

2. **The Software.** In this Agreement, "Software" means the program modules and features of the Juniper or Juniper-supplied software, and updates and releases of such software, for which Customer has paid the applicable license or support fees to Juniper or an authorized Juniper reseller.

3. **License Grant.** Subject to payment of the applicable fees and the limitations and restrictions set forth herein, Juniper grants to Customer a non-exclusive and non-transferable license, without right to sublicense, to use the Software, in executable form only, subject to the following use restrictions:

a. Customer shall use the Software solely as embedded in, and for execution on, Juniper equipment originally purchased by Customer from Juniper or an authorized Juniper reseller, unless the applicable Juniper documentation expressly permits installation on non-Juniper equipment.

b. Customer shall use the Software on a single hardware chassis having a single processing unit, or as many chassis or processing units for which Customer has paid the applicable license fees.

c. Product purchase documents, paper or electronic user documentation, and/or the particular licenses purchased by Customer may specify limits to Customer's use of the Software. Such limits may restrict use to a maximum number of seats, registered endpoints, concurrent users, sessions, calls, connections, subscribers, clusters, nodes, or transactions, or require the purchase of separate licenses to use particular features, functionalities, services, applications, operations, or capabilities, or provide throughput, performance, configuration, bandwidth, interface, processing, temporal, or geographical limits. Customer's use of the Software shall be subject to all such limitations and purchase of all applicable licenses.

The foregoing license is not transferable or assignable by Customer. No license is granted herein to any user who did not originally purchase the applicable license(s) for the Software from Juniper or an authorized Juniper reseller.

4. **Use Prohibitions.** Notwithstanding the foregoing, the license provided herein does not permit the Customer to, and Customer agrees not to and shall not: (a) modify, unbundle, reverse engineer, or create derivative works based on the Software; (b) make unauthorized copies of the Software (except as necessary for backup purposes); (c) rent, sell, transfer, or grant any rights in and to any copy of the Software, in any form, to any third party; (d) remove any proprietary notices, labels, or marks on or in any copy of the Software or any product in which the Software is embedded; (e) distribute any copy of the Software to any third party, including as may be embedded in Juniper equipment sold in the secondhand market; (f) use any 'locked' or key-restricted feature, function, service, application, operation, or capability without first purchasing the applicable license(s) and obtaining a valid key from Juniper, even if such feature, function, service, application, operation, or capability is enabled without a key; (g) distribute any key for the Software provided by Juniper to any third party; (h) use the Software in any manner that extends or is broader than the uses purchased by Customer from Juniper or an authorized Juniper reseller; (i) use the Software on non-Juniper equipment where the Juniper documentation does not expressly permit installation on non-Juniper equipment; (j) use the Software (or make it available for use) on Juniper equipment that the Customer did not originally purchase from Juniper or an authorized Juniper reseller; (k) disclose the results of testing or benchmarking of the Software to any third party without the prior written consent of Juniper; or (l) use the Software in any manner other than as expressly provided herein.

5. **Audit.** Customer shall maintain accurate records as necessary to verify compliance with this Agreement. Upon request by Juniper, Customer shall furnish such records to Juniper and certify its compliance with this Agreement.

6. **Confidentiality.** The Parties agree that aspects of the Software and associated documentation are the confidential property of Juniper. As such, Customer shall exercise all reasonable commercial efforts to maintain the Software and associated documentation in confidence, which at a minimum includes restricting access to the Software to Customer employees and contractors having a need to use the Software for Customer's internal business purposes.

7. **Ownership.** Juniper and Juniper's licensors, respectively, retain ownership of all right, title, and interest (including copyright) in and to the Software, associated documentation, and all copies of the Software. Nothing in this Agreement constitutes a transfer or conveyance of any right, title, or interest in the Software or associated documentation, or a sale of the Software, associated documentation, or copies of the Software.

8. **Warranty, Limitation of Liability, Disclaimer of Warranty.** The warranty applicable to the Software shall be as set forth in the warranty statement that accompanies the Software (the "Warranty Statement"). Nothing in this Agreement shall give rise to any obligation to support the Software. Support services may be purchased separately. Any such support shall be governed by a separate, written support services agreement. TO THE MAXIMUM EXTENT PERMITTED BY LAW, JUNIPER SHALL NOT BE LIABLE FOR ANY LOST PROFITS, LOSS OF DATA, OR COSTS OR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR FOR ANY SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THIS AGREEMENT, THE SOFTWARE, OR ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. IN NO EVENT SHALL JUNIPER BE LIABLE FOR DAMAGES ARISING FROM UNAUTHORIZED OR IMPROPER USE OF ANY JUNIPER OR JUNIPER-SUPPLIED SOFTWARE. EXCEPT AS EXPRESSLY PROVIDED IN THE WARRANTY STATEMENT TO THE EXTENT PERMITTED BY LAW, JUNIPER DISCLAIMS ANY AND ALL WARRANTIES IN AND TO THE SOFTWARE (WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE), INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT. IN NO EVENT DOES JUNIPER WARRANT THAT THE SOFTWARE, OR ANY EQUIPMENT OR NETWORK RUNNING THE SOFTWARE, WILL OPERATE WITHOUT ERROR OR INTERRUPTION, OR WILL BE FREE OF VULNERABILITY TO INTRUSION OR ATTACK. In no event shall Juniper's or its suppliers' or licensors' liability to Customer, whether in contract, tort (including negligence), breach of warranty, or otherwise, exceed the price paid by Customer for the Software that gave rise to the claim, or if the Software is embedded in another Juniper product, the price paid by Customer for such other product. Customer acknowledges and agrees that Juniper has set its prices and entered into this Agreement in reliance upon the disclaimers of warranty and the limitations of liability set

forth herein, that the same reflect an allocation of risk between the Parties (including the risk that a contract remedy may fail of its essential purpose and cause consequential loss), and that the same form an essential basis of the bargain between the Parties.

9. **Termination.** Any breach of this Agreement or failure by Customer to pay any applicable fees due shall result in automatic termination of the license granted herein. Upon such termination, Customer shall destroy or return to Juniper all copies of the Software and related documentation in Customer's possession or control.

10. **Taxes.** All license fees for the Software are exclusive of taxes, withholdings, duties, or levies (collectively "Taxes"). Customer shall be responsible for paying Taxes arising from the purchase of the license, or importation or use of the Software.

11. **Export.** Customer agrees to comply with all applicable export laws and restrictions and regulations of any United States and any applicable foreign agency or authority, and not to export or re-export the Software or any direct product thereof in violation of any such restrictions, laws or regulations, or without all necessary approvals. Customer shall be liable for any such violations. The version of the Software supplied to Customer may contain encryption or other capabilities restricting Customer's ability to export the Software without an export license.

12. **Commercial Computer Software.** The Software is "commercial computer software" and is provided with restricted rights. Use, duplication, or disclosure by the United States government is subject to restrictions set forth in this Agreement and as provided in DFARS 227.7201 through 227.7202-4, FAR 12.212, FAR 27.405(b)(2), FAR 52.227-19, or FAR 52.227-14(ALT III) as applicable.

13. **Interface Information.** To the extent required by applicable law, and at Customer's written request, Juniper shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of applicable fee, if any. Customer shall observe strict obligations of confidentiality with respect to such information and shall use such information in compliance with any applicable terms and conditions upon which Juniper makes such information available.

14. **Third Party Software.** Any licensor of Juniper whose software is embedded in the Software and any supplier of Juniper whose products or technology are embedded in (or services are accessed by) the Software shall be a third party beneficiary with respect to this Agreement, and such licensor or vendor shall have the right to enforce this Agreement in its own name as if it were Juniper. In addition, certain third party software may be provided with the Software and is subject to the accompanying license(s), if any, of its respective owner(s). To the extent portions of the Software are distributed under and subject to open source licenses obligating Juniper to make the source code for such portions publicly available (such as the GNU General Public License ("GPL") or the GNU Library General Public License ("LGPL")), Juniper will make such source code portions (including Juniper modifications, as appropriate) available upon request for a period of up to three years from the date of distribution. Such request can be made in writing to Juniper Networks, Inc., 1194 N. Mathilda Ave., Sunnyvale, CA 94089, ATTN: General Counsel. You may obtain a copy of the GPL at <http://www.gnu.org/licenses/gpl.html>, and a copy of the LGPL at <http://www.gnu.org/licenses/lgpl.html>.

15. **Miscellaneous.** This Agreement shall be governed by the laws of the State of California without reference to its conflicts of laws principles. The provisions of the U.N. Convention for the International Sale of Goods shall not apply to this Agreement. For any disputes arising under this Agreement, the Parties hereby consent to the personal and exclusive jurisdiction of, and venue in, the state and federal courts within Santa Clara County, California. This Agreement constitutes the entire and sole agreement between Juniper and the Customer with respect to the Software, and supersedes all prior and contemporaneous agreements relating to the Software, whether oral or written (including any inconsistent terms contained in a purchase order), except that the terms of a separate written agreement executed by an authorized Juniper representative and Customer shall govern to the extent such terms are inconsistent or conflict with terms contained herein. No modification to this Agreement nor any waiver of any rights hereunder shall be effective unless expressly assented to in writing by the party to be charged. If any portion of this Agreement is held invalid, the Parties agree that such invalidity shall not affect the validity of the remainder of this Agreement. This Agreement and associated documentation has been written in the English language, and the Parties agree that the English version will govern. (For Canada: Les parties aux présentes confirment leur volonté que cette convention de même que tous les documents y compris tout avis qui s'y rattache, soient rédigés en langue anglaise. (Translation: The parties confirm that this Agreement and all related documentation is and will be in the English language)).

Abbreviated Table of Contents

About This Guide

xiii

Part 1

Administration Tasks

Chapter 1	Installing and Managing J-series Licenses	3
Chapter 2	Managing Users and Operations	15
Chapter 3	Configuring SNMP for Network Management	49
Chapter 4	Configuring the DHCP Server	61
Chapter 5	Configuring and Monitoring Alarms	79
Chapter 6	Monitoring a Services Router	93
Chapter 7	Using Services Router Diagnostic Tools	139
Chapter 8	Configuring Packet Capture	179
Chapter 9	Monitoring Real-Time Performance	191
Chapter 10	Performing Software Upgrades and Reboots	211
Chapter 11	Contacting Customer Support and Returning Hardware	235

Part 2

Index

Table of Contents

About This Guide xiii

Objectives	xiii
Audience.....	xiv
Document Conventions	xiv
Related Juniper Networks Documentation.....	xvi
Documentation Feedback.....	xviii
Requesting Support.....	xviii

Part 1

Administration Tasks

Chapter 1

Installing and Managing J-series Licenses 3

J-series License Overview	3
Software Feature Licenses	4
Port Licenses	4
License Key Components	5
Before You Begin.....	6
Managing J-series Licenses with the J-Web Interface	6
Adding New Licenses with the J-Web Interface.....	8
Deleting Licenses with the J-Web Interface	9
Displaying License Keys with the J-Web Interface.....	9
Downloading Licenses with the J-Web Interface.....	9
Managing J-series Licenses with the CLI	10
Adding New Licenses with the CLI.....	10
Deleting a License with the CLI.....	10
Saving License Keys with the CLI	11
Verifying J-series License Management	11
Displaying Installed Licenses.....	11
Displaying License Usage	12
Displaying Installed License Keys.....	13

Chapter 2

Managing Users and Operations 15

System Management Terms	15
System Management Overview	16
System Authentication.....	16
User Accounts	16
Login Classes	17
Permission Bits	17

Denying or Allowing Individual Commands	19
Template Accounts	19
System Log Files	20
Before You Begin	21
Managing Users and Files with the J-Web Interface	21
Managing Users with Quick Configuration	21
Adding a RADIUS Server for Authentication	21
Adding a TACACS+ Server for Authentication	23
Configuring System Authentication	25
Adding New Users	27
Managing Files with the J-Web Interface	29
Cleaning Up Files	29
Downloading Files	31
Deleting Files	32
Managing Users and Files with a Configuration Editor	34
Setting Up RADIUS Authentication	34
Setting Up TACACS+ Authentication	35
Configuring Authentication Order	37
Controlling User Access	38
Defining Login Classes	38
Creating User Accounts	39
Setting Up Template Accounts	40
Creating a Remote Template Account	41
Creating a Local Template Account	42
Setting Up System Logs	43
Sending System Log Messages to a File	44
Sending System Log Messages to a User Terminal	45
Archiving System Logs	46
Disabling System Logs	46
Accessing Remote Devices with the CLI	46
Using the telnet Command	47
Using the ssh Command	47

Chapter 3 Configuring SNMP for Network Management 49

Network Management Overview	49
Managers and Agents	49
SMI, MIBs, and OIDs	50
Standard and Enterprise MIBs	50
SNMP Requests	50
SNMP Communities	50
SNMP Traps	51
Before You Begin	51
Configuring SNMP with Quick Configuration	51
Configuring SNMP with a Configuration Editor	54
Defining System Identification Information (Required)	55
Configuring SNMP Agents and Communities (Required)	56
Managing SNMP Trap Groups (Required)	57
Controlling Access to MIBs (Optional)	58
Verifying the SNMP Configuration	59
Verifying SNMP Agent Configuration	59

Chapter 4	Configuring the DHCP Server	61
	DHCP Terms	61
	DHCP Overview.....	62
	DHCP Options.....	63
	Compatibility with Autoinstallation.....	63
	Conflict Detection and Resolution	63
	Interface Restrictions	63
	Before You Begin.....	64
	Configuring the DHCP Server with Quick Configuration	64
	Configuring the DHCP Server with a Configuration Editor	70
	Verifying a DHCP Server Configuration	73
	Displaying a DHCP Server Configuration	73
	Verifying the DHCP Binding Database	74
	Verifying DHCP Server Operation	75
	Displaying DHCP Statistics	77
Chapter 5	Configuring and Monitoring Alarms	79
	Alarm Terms	79
	Alarm Overview.....	80
	Alarm Types	80
	Alarm Severity	81
	Alarm Conditions	81
	Interface Alarm Conditions.....	81
	Chassis Alarm Conditions and Corrective Actions.....	84
	System Alarm Conditions and Corrective Actions	85
	Before You Begin.....	86
	Configuring Alarms with a Configuration Editor	86
	Checking Active Alarms	88
	Verifying the Alarms Configuration.....	90
	Displaying Alarm Configurations	90
Chapter 6	Monitoring a Services Router	93
	Monitoring Terms.....	93
	Monitoring Overview	93
	Monitoring Tools Overview.....	94
	Filtering Command Output	98
	Before You Begin.....	99
	Using the Monitoring Tools	99
	Monitoring System Properties	100
	Monitoring the Chassis	103
	Monitoring the Interfaces	105
	Monitoring Routing Information.....	107
	Monitoring Class-of-Service Performance	113
	Monitoring MPLS Traffic Engineering Information	119
	Monitoring Service Sets	122
	Monitoring Firewalls	124
	Monitoring IPSec Tunnels	127
	Monitoring NAT Pools.....	129
	Monitoring DHCP	130

Monitoring RPM Probes	131
Monitoring PPPoE.....	134

Chapter 7 Using Services Router Diagnostic Tools 139

Diagnostic Terms	139
Diagnostic Tools Overview	140
J-Web Diagnostic Tools Overview	140
CLI Diagnostic Commands Overview	141
MPLS Connection Checking.....	143
Before You Begin.....	144
General Preparation.....	145
Ping MPLS Preparation	145
MPLS Enabled	145
Loopback Address.....	145
Source Address for Probes.....	145
Pinging Hosts from the J-Web Interface.....	145
Using the J-Web Ping Host Tool	146
Ping Host Results and Output Summary	149
Checking MPLS Connections from the J-Web Interface.....	150
Using the J-Web Ping MPLS Tool.....	151
Ping MPLS Results and Output.....	154
Tracing Unicast Routes from the J-Web Interface	155
Using the J-Web Traceroute Tool	156
Traceroute Results and Output Summary.....	158
Using CLI Diagnostic Commands.....	159
Pinging Hosts from the CLI	160
Checking MPLS Connections from the CLI.....	161
Pinging RSVP-Signaled LSPs and LDP-Signaled LSPs.....	162
Pinging Layer 3 VPNs	163
Pinging Layer 2 VPNs	164
Pinging Layer 2 Circuits.....	165
Tracing Unicast Routes from the CLI	166
Tracing Multicast Routes from the CLI	167
Using the mtrace from-source Command.....	168
Using the mtrace monitor Command	170
Displaying Log and Trace Files from the CLI.....	171
Monitoring Interfaces and Traffic from the CLI.....	171
Using the monitor interface Command	172
Using the monitor traffic Command.....	173

Chapter 8 Configuring Packet Capture 179

Packet Capture Terms	179
Packet Capture Overview	180
Packet Capture on Router Interfaces	181
Firewall Filters for Packet Capture	181
Packet Capture Files	182
Analysis of Packet Capture Files	182
Before You Begin.....	183

Configuring Packet Capture with a Configuration Editor	183
Enabling Packet Capture (Required)	183
Configuring Packet Capture on an Interface (Required)	184
Configuring a Firewall Filter for Packet Capture (Optional)	185
Disabling Packet Capture	186
Changing Encapsulation on Interfaces with Packet Capture Configured	187
Verifying Packet Capture	188
Displaying a Packet Capture Configuration	188
Displaying a Firewall Filter for Packet Capture Configuration	189
Verifying Captured Packets	189
 Chapter 9	 Monitoring Real-Time Performance
	191
RPM Terms	191
RPM Overview	192
RPM Probes	192
RPM Tests	193
Probe and Test Intervals	193
RPM Statistics	193
RPM Thresholds and Traps	194
Before You Begin	194
Configuring RPM with Quick Configuration	195
Configuring RPM with a Configuration Editor	201
Configuring Basic RPM Probes (Required)	201
Configuring TCP and UDP Probes (Optional)	205
Tuning RPM Probes (Optional)	207
Verifying an RPM Configuration	208
Verifying RPM Statistics	208
Verifying RPM Probe Servers	209
 Chapter 10	 Performing Software Upgrades and Reboots
	211
Upgrade Overview	211
Before You Begin	212
Downloading Software Upgrades from Juniper Networks	212
Installing Software Upgrades	213
Installing Software Upgrades with the J-Web Interface	213
Installing Software Upgrades from a Remote Server	213
Installing Software Upgrades by Uploading Files	215
Installing Software Upgrades with the CLI	217
Installing Firmware Upgrades with the CLI	217
Downgrading the Software	218
Downgrading the Software with the J-Web Interface	219
Downgrading the Software with the CLI	219
Downgrading the Firmware with the CLI	219
Configuring Boot Devices	220
Configuring Boot Devices with the J-Web Interface	221
Configuring Boot Devices with the CLI	224
Configuring Compact Flash Recovery	226
Why Compact Flash Recovery Might Be Necessary	226
Recommended Recovery Hardware and Software	226
Recovering Primary Compact Flash	227

Configuring a Boot Device to Receive Software Failure Memory Snapshots.....	229
Rebooting or Halting a Services Router	229
Rebooting or Halting a Services Router with the J-Web Interface.....	230
Rebooting the Services Router with the CLI	232
Halting the Services Router with the CLI	232

Chapter 11**Contacting Customer Support and Returning Hardware 235**

Locating Component Serial Numbers	235
PIM Serial Number Label	237
J6300 Power Supply Serial Number Labels	237
Contacting Customer Support	237
Information You Might Need to Supply to JTAC.....	238
Return Procedure	238
Packing a Router or Component for Shipment.....	239
Tools and Parts Required	239
Packing the Services Router for Shipment	239
Packing Components for Shipment	240

Part 2**Index**

Index.....	245
------------	-----

About This Guide

This preface provides the following guidelines for using the *J-series™ Services Router Administration Guide*:

- Objectives on page xiii
- Audience on page xiv
- Document Conventions on page xiv
- Related Juniper Networks Documentation on page xvi
- Documentation Feedback on page xviii
- Requesting Support on page xviii

Objectives

This guide contains instructions for managing users and operations, monitoring network performance, upgrading software, and diagnosing common problems on J-series Services Routers.



NOTE: This guide documents Release 7.5 of the JUNOS software. For additional information about J-series Services Routers—either corrections to or omissions from this guide—see the *J-series Services Router Release Notes* at <http://www.juniper.net>.

J-series Services Router operations are controlled by the JUNOS Internet software. You direct the JUNOS software through either a Web browser or a command-line interface (CLI) to perform the tasks shown in Table 1.

Table 1: Capabilities of J-series Interfaces

J-series Interface	Capabilities
J-Web graphical browser interface	<ul style="list-style-type: none">■ Quick (basic) configuration■ Monitoring, configuration, diagnosis, and management
JUNOS CLI	Monitoring, configuration, diagnosis, and management

J-series Services Router guides provide complete instructions for using the J-Web interface, but they are not a comprehensive resource for using the JUNOS CLI. For CLI information, see the JUNOS software manuals listed in “Related Juniper Networks Documentation” on page xvi.

Audience

This guide is designed for anyone who installs and sets up a J-series Services Router or prepares a site for Services Router installation. The guide is intended for the following audiences:

- Customers with technical knowledge of and experience with networks and the Internet
- Network administrators who install, configure, and manage Internet routers but are unfamiliar with the JUNOS software
- Network administrators who install, configure, and manage products of Juniper Networks

Personnel operating the equipment must be trained and competent; must not conduct themselves in a careless, willfully negligent, or hostile manner; and must abide by the instructions provided by the documentation.

Document Conventions

Table 2 defines the notice icons used in this guide.

Table 2: Notice Icons




Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.

Table 3 defines the text and syntax conventions used in this guide.

Table 3: Text and Syntax Conventions

Convention	Description	Examples
Bold sans serif typeface	Represents text that you type.	To enter configuration mode, type the <code>configure</code> command: user@host> configure
Fixed-width typeface	Represents output that appears on the terminal screen.	user@host> show chassis alarms No alarms currently active
<i>Italic typeface</i>	<ul style="list-style-type: none"> Introduces important new terms. Identifies book names. Identifies RFC and Internet draft titles. 	<ul style="list-style-type: none"> A policy <i>term</i> is a named structure that defines match conditions and actions. <i>JUNOS System Basics Configuration Guide</i> RFC 1997, <i>BGP Communities Attribute</i>
<i>Italic sans serif typeface</i>	Represents variables (options for which you substitute a value) in commands or configuration statements.	Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i>
Sans serif typeface	Represents names of configuration statements, commands, files, and directories; IP addresses; configuration hierarchy levels; or labels on routing platform components.	<ul style="list-style-type: none"> To configure a stub area, include the stub statement at the [edit protocols ospf area <i>area-id</i>] hierarchy level. The console port is labeled CONSOLE.
< > (angle brackets)	Enclose optional keywords or variables.	stub <default-metric <i>metric</i> >;
(pipe symbol)	Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity.	broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>)
# (pound sign)	Indicates a comment specified on the same line as the configuration statement to which it applies.	rsvp { # Required for dynamic MPLS only
[] (square brackets)	Enclose a variable for which you can substitute one or more values.	community name members [<i>community-ids</i>]
Indentation and braces ({ })	Identify a level in the configuration hierarchy.	[edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } }
; (semicolon)	Identifies a leaf statement at a configuration hierarchy level.	
J-Web GUI Conventions		

Convention	Description	Examples
Bold typeface	Represents J-Web graphical user interface (GUI) items you click or select.	<ul style="list-style-type: none"> ■ In the Logical Interfaces box, select All Interfaces. ■ To cancel the configuration, click Cancel.
> (bold right angle bracket)	Separates levels in a hierarchy of J-Web selections.	In the configuration editor hierarchy, select Protocols > Ospf .

Related Juniper Networks Documentation

J-series Services Routers are documented in four guides. Although the J-series guides provide instructions for configuring and managing a Services Router with the JUNOS CLI, they are not a comprehensive JUNOS software resource. For complete documentation of the statements and commands described in J-series guides, see the JUNOS software manuals listed in Table 4.

Table 4: J-series Guides and Related JUNOS Software Publications

Chapter in a J-series Guide	Corresponding JUNOS Software Manual
J-series Services Router Getting Started Guide	
"J-series User Interface Overview"	<i>JUNOS System Basics Configuration Guide</i>
"Establishing Basic Connectivity"	
"Configuring Autoinstallation"	
J-series Services Router Basic LAN and WAN Access Configuration Guide	
"Using J-Web Configuration Tools"	<i>JUNOS System Basics Configuration Guide</i>
"Interfaces Overview"	■ <i>JUNOS Network Interfaces Configuration Guide</i>
"Configuring Network Interfaces"	■ <i>JUNOS Interfaces Command Reference</i>
"Configuring Digital Subscriber Line Interfaces"	
"Configuring Point-to-Point Protocol over Ethernet"	
"Configuring ISDN"	
"Routing Overview"	■ <i>JUNOS Routing Protocols Configuration Guide</i>
"Configuring Static Routes"	■ <i>JUNOS Routing Protocols and Policies Command Reference</i>
"Configuring a RIP Network"	
"Configuring an OSPF Network"	
"Configuring the IS-IS Protocol"	
"Configuring BGP Sessions"	
J-series Services Router Advanced WAN Access Configuration Guide	

Chapter in a J-series Guide	Corresponding JUNOS Software Manual
“Multiprotocol Label Switching Overview”	■ <i>JUNOS MPLS Applications Configuration Guide</i>
“Configuring Signaling Protocols for Traffic Engineering”	■ <i>JUNOS Routing Protocols and Policies Command Reference</i>
“Configuring Virtual Private Networks”	■ <i>JUNOS VPNs Configuration Guide</i>
“Configuring CLNS VPNs”	
“Configuring IPSec for Secure Packet Exchange”	■ <i>JUNOS System Basics Configuration Guide</i> ■ <i>JUNOS Services Interfaces Configuration Guide</i> ■ <i>JUNOS System Basics and Services Command Reference</i>
“Multicast Overview”	<i>JUNOS Multicast Protocols Configuration Guide</i>
“Configuring a Multicast Network”	<i>JUNOS Routing Protocols and Policies Command Reference</i>
“Configuring Data Link Switching”	■ <i>JUNOS Services Interfaces Configuration Guide</i> ■ <i>JUNOS System Basics and Services Command Reference</i>
“Policy Framework Overview”	<i>JUNOS Policy Framework Configuration Guide</i>
“Configuring Routing Policies”	<i>JUNOS Routing Protocols and Policies Command Reference</i>
“Configuring Stateful Firewall Filters and NAT”	■ <i>JUNOS Network Interfaces Configuration Guide</i>
“Configuring Stateless Firewall Filters”	■ <i>JUNOS Policy Framework Configuration Guide</i> ■ <i>JUNOS Services Interfaces Configuration Guide</i> ■ <i>JUNOS System Basics and Services Command Reference</i> ■ <i>JUNOS Routing Protocols and Policies Command Reference</i>
“Class-of-Service Overview”	■ <i>JUNOS Class of Service Configuration Guide</i>
“Configuring Class of Service”	■ <i>JUNOS System Basics and Services Command Reference</i>
J-series Services Router Administration Guide	
“Managing Users and Operations”	<i>JUNOS System Basics Configuration Guide</i>
“Configuring SNMP for Network Management”	<i>JUNOS Network Management Configuration Guide</i>
“Configuring the DHCP Server”	<i>JUNOS System Basics Configuration Guide</i>
“Configuring and Monitoring Alarms”	<i>JUNOS System Basics Configuration Guide</i>
“Monitoring a Services Router”	■ <i>JUNOS System Basics and Services Command Reference</i>
“Using Services Router Diagnostic Tools”	■ <i>JUNOS Interfaces Command Reference</i> ■ <i>JUNOS Routing Protocols and Policies Command Reference</i>
“Configuring Packet Capture”	<i>JUNOS Services Interfaces Configuration Guide</i>
“Monitoring Real-Time Performance”	<i>JUNOS System Basics and Services Command Reference</i>

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at <http://www.juniper.net/techpubs/docbug/docbugreport.html>. If you are using e-mail, be sure to include the following information with your comments:

- Document name
- Document part number
- Page number
- Software release version

Requesting Support

For technical support, open a support case with the Case Manager link at <http://www.juniper.net/support/> or call 1-888-314-JTAC (from the United States, Canada, or Mexico) or 1-408-745-9500 (from elsewhere).

Part 1

Administration Tasks

- Installing and Managing J-series Licenses on page 3
- Managing Users and Operations on page 15
- Configuring SNMP for Network Management on page 49
- Configuring the DHCP Server on page 61
- Configuring and Monitoring Alarms on page 79
- Monitoring a Services Router on page 93
- Using Services Router Diagnostic Tools on page 139
- Configuring Packet Capture on page 179
- Monitoring Real-Time Performance on page 191
- Performing Software Upgrades and Reboots on page 211
- Contacting Customer Support and Returning Hardware on page 235

Chapter 1

Installing and Managing J-series Licenses

To enable some JUNOS software features and use certain additional ports on a J-series Services Router, you must purchase, install, and manage separate software licenses. The presence on the router of the appropriate software license keys (passwords) determines the features and ports you can configure and use.

For information about how to purchase J-series software licenses, contact your Juniper Networks sales representative.

This chapter contains the following topics:

- J-series License Overview on page 3
- Before You Begin on page 6
- Managing J-series Licenses with the J-Web Interface on page 6
- Managing J-series Licenses with the CLI on page 10
- Verifying J-series License Management on page 11

J-series License Overview

The J-series set of licenses is composed of two primary types: feature licenses and port licenses. Each type of license is valid for only a single Services Router. To manage the licenses, you must understand the components of a license key.

This section contains the following topics:

- Software Feature Licenses on page 4
- Port Licenses on page 4
- License Key Components on page 5

Software Feature Licenses

Each feature license is tied to exactly one software feature, and that license is valid for exactly one Services Router. Table 5 lists the Services Router software features that require licenses.

Table 5: J-series Services Router Software Feature Licenses

Licensed Software Feature	License Name
Stateful Firewall Filters and NAT	
Stateful firewall and Network Address Translation (NAT) on the J2300 platform—all configuration statements within the <code>[edit services stateful-firewall]</code> hierarchy.	J2300 Services Router Software License for Stateful Firewall
Stateful firewall and NAT on the J4300 platform—all configuration statements within the <code>[edit services stateful-firewall]</code> hierarchy.	J4300 Services Router Software License for Stateful Firewall
Stateful firewall and NAT on the J6300 platform—all configuration statements within the <code>[edit services stateful-firewall]</code> hierarchy.	J6300 Services Router Software License for Stateful Firewall
IPSec VPN Tunneling	
IPSec VPN tunneling on the J2300 platform—all configuration statements within the <code>[edit services ipsec-vpn]</code> hierarchy.	J2300 Services Router Software License for IPSec Tunneling
IPSec VPN tunneling on the J4300 platform—all configuration statements within the <code>[edit services ipsec-vpn]</code> hierarchy.	J4300 Services Router Software License for IPSec Tunneling
IPSec VPN tunneling on the J6300 platform—all configuration statements within the <code>[edit services ipsec-vpn]</code> hierarchy.	J6300 Services Router Software License for IPSec Tunneling
IBM Networking	
Data link switching (DLSw) on all J-series Services Routers	J-series Services Router Software License for Data Link Switching (DLSw) Support
Traffic Analysis	
J-Flow traffic analysis—all configuration statements within the <code>[edit forwarding-options sampling]</code> and <code>[edit forwarding-options accounting]</code> hierarchies.	J-series Services Router Software License for J-Flow Traffic Analysis
BGP Route Reflectors	
Advanced Border Gateway Protocol (BGP) features that enable route reflectors—all configuration statements within the <code>[edit protocols bgp cluster]</code> hierarchy. BGP clusters allow routers to act as route reflectors by enabling the readvertising of BGP routes to internal peers.	J-series Services Router Software License for Advanced Border Router Protocol Support

Port Licenses

Each port license is tied to exactly one licensed port, and that license is valid for exactly one Services Router. To enable multiple ports, you must have a license for each licensed port. Table 6 lists the additional Services Router port licenses.

Table 6: J-series Services Router Port Licenses

Licensed Port	License Name
T1	
Additional port on a T1 Physical Interface Module (PIM).	J-series Services Router Software License for One Additional T1 Port
E1	
Additional port on an E1 PIM.	J-series Services Router Software License for One Additional E1 Port
Serial	
Additional port on a serial PIM.	J-series Services Router Software License for One Additional Serial Port
Fast Ethernet	
Additional port on a Fast Ethernet PIM.	J-series Services Router Software License for One Additional Fast Ethernet Port

The LAN ports (fe-0/0/0 and fe-0/0/1) do not require port licenses.

Additionally, one port per PIM can be configured without a port license. A port license is required only if you configure more than one port on a particular PIM.

License Key Components

A license key consists of two parts:

- License ID—Alphanumeric string that uniquely identifies the license key. When a license is generated, it is given a license ID.
- License data—Block of binary data that defines and stores all license key objects.

For example, in the following typical license key, the string `li29183743` is the license ID, and the trailing block of data is the license data:

```
li29183743 4ky27y acasck 82fsj6 jzsn4q ix8i8d adj7kr
            8uq38t ix8i8d jzsn4q ix8i8d 4ky27y acasck
            82fsj6 ii8i7e adj7kr 8uq38t ks2923 a9382e
```

The license data defines the device ID for which the license is valid and the version of the license.

Before You Begin

Before you begin managing the J-series licenses, complete the following tasks:

- Purchase the licenses you require.
- Establish basic connectivity. See the *J-series Services Router Getting Started Guide*.


Managing J-series Licenses with the J-Web Interface

To manage licenses with the J-Web interface, you perform the following tasks:

- Adding New Licenses with the J-Web Interface on page 8
- Deleting Licenses with the J-Web Interface on page 9
- Displaying License Keys with the J-Web Interface on page 9
- Downloading Licenses with the J-Web Interface on page 9

Figure 1 shows the J-Web Licenses page.

Figure 1: Licenses Page



The Licenses page displays a summary of licensed features that are configured on the Services Router and a list of the licenses that are installed on the router. The information on the license management page is summarized in Table 7.

Table 7: Summary of License Management Fields

Field Name	Definition
Feature Summary	
Feature	Name of the licensed feature or port: <ul style="list-style-type: none">J-series licenses listed in Table 5 and Table 6All features—All-inclusive licenses

Table 7: Summary of License Management Fields (continued)

Field Name	Definition
Free Ports Used	<p>If the feature is an interface, this field lists the number of free ports for that interface that are currently configured.</p> <p>If the feature is not an interface, this field is blank.</p>
Licenses Used	Number of licenses currently being used on the router. Usage is determined by the configuration on the router. If a port license exists and that port is configured, the license is considered used.
Licenses Installed	Number of licenses installed on the router for the particular feature or port.
Licenses Needed	<p>Number of licenses required for legal of use the feature or port. Usage is determined by the configuration on the router:</p> <ul style="list-style-type: none"> ■ If a feature is configured and the license for that feature is not installed, a single license is needed. ■ If one or more ports are configured beyond the number of licenses installed on the router, a single license is needed for each additional configured port.
Installed Licenses	
ID	Unique alphanumeric ID of the license.
State	<p>Valid—The installed license key is valid.</p> <p>Invalid—The installed license key is not valid.</p>
Version	Numeric version number of the license key.
Group	<p>If the license defines a group license, this field displays the group definition.</p> <p>If the license requires a group license, this field displays the required group definition.</p> <p>NOTE: Because group licenses are currently unsupported, this field is always blank.</p>
Enabled Features	Name of the feature that is enabled with the particular license.

Adding New Licenses with the J-Web Interface

To add a new license key on a Services Router with the J-Web license manager:

1. In the J-Web interface, select **Manage > Licenses**.
2. Under Installed Licenses, click **Add** to add a new license key.
3. Do *one* of the following, using a blank line to separate multiple license keys:
 - In the License File URL box, type the full URL to the destination file containing the license key to be added.

- In the License Key Text box, paste the license key text, in plain-text format, for the license to be added.
- 4. Click **OK** to add the license key.
- 5. Go on to “Verifying J-series License Management” on page 11.

Deleting Licenses with the J-Web Interface

To delete one or more license keys from a Services Router with the J-Web license manager:

1. In the J-Web interface, select **Manage > Licenses**.
2. Select the check box of the license or licenses you want to delete.
3. Click **Delete**.
4. Go on to “Verifying J-series License Management” on page 11.

Displaying License Keys with the J-Web Interface

To display the license keys installed on a Services Router with the J-Web license manager:

1. In the J-Web interface, select **Manage > Licenses**.
2. Under Installed Licenses, click **Display Keys** to display all the license keys installed on the router.

A screen displaying the license keys in text format appears. Multiple licenses are separated by a blank line.

3. Go on to “Verifying J-series License Management” on page 11.

Downloading Licenses with the J-Web Interface

To download the license keys installed on the Services Router with the J-Web license manager:

1. In the J-Web interface, select **Manage > Licenses**.
2. Under Installed Licenses, click **Download Keys** to download all the license keys installed on the router to a single file.
3. Select **Save it to disk** and specify the file to which the license keys are to be written.
4. Go on to “Verifying J-series License Management” on page 11.

Managing J-series Licenses with the CLI

To manage the J-series licenses with the CLI, perform the following tasks.

- Adding New Licenses with the CLI on page 10
- Deleting a License with the CLI on page 10
- Saving License Keys with the CLI on page 11

Adding New Licenses with the CLI

To add a new license key to the Services Router with the CLI:

1. Enter operational mode in the CLI.
2. Enter one of the following CLI commands:
 - To add a license key from a file or URL, enter the following command, specifying the filename or the URL where the key is located:
request system license add *filename* | *url*
 - To add a license key from the terminal, enter the following command:
request system license add terminal
3. When prompted, enter the license key, separating multiple license keys with a blank line.

If the license key you enter is invalid, an error is generated when you press Ctrl-D to exit license entry mode.
4. Go on to “Verifying J-series License Management” on page 11.

Deleting a License with the CLI

To delete a license key from the Services Router with the CLI:

1. Enter operational mode in the CLI.
2. Enter the following command for each license, specifying the license ID. You can delete only one license at a time.

request system license delete *license-id*
3. Go on to “Verifying J-series License Management” on page 11.

Saving License Keys with the CLI

To save the licenses installed on the Services Router to a file with the CLI:

1. Enter operational mode in the CLI.
2. To save the installed license keys to a file or URL, enter the following command:

```
request system license save filename | url
```

For example, the following command saves the installed license keys to a file named license.config:

```
request system license save ftp://user@host/license.conf
```

3. Go on to “Verifying J-series License Management” on page 11.

Verifying J-series License Management

To verify J-series license management, perform these tasks:

- Displaying Installed Licenses on page 11
- Displaying License Usage on page 12
- Displaying Installed License Keys on page 13

Displaying Installed Licenses

Purpose Verify that the expected licenses are installed and active on the Services Router.

Action From the CLI, enter the show system license command.

Sample Output user@router> **show system license**

```
License usage:
  Feature name      Free ports  Licenses  Licenses  Licenses
                   used       used    installed needed
  all                0          0          1         0
  firewall           1          1          1         0
  if-t1-4            1          1          4         0
  if-fe              2          0          0         0
  ipsec-vpn          1          1          1         0

Licenses installed:
License identifier: li29183743
  State: valid
  License version: 2
  Valid for device: jp47859620

License identifier: li48293123
  State: valid
  License version: 2
```

```

Valid for device: jp47859620
Features:
  firewall          - Stateful firewall

License identifier: li72194673
State: valid
License version: 2
Valid for device: jp47859620
Features:
  if-t1-4           - Four additional T1 ports

License identifier: li41597793
State: valid
License version: 2
Valid for device: jp47859620
Features:
  ipsec-vpn         - IPSec VPN tunnelling

```

What It Means

The output shows a list of the license usage and a list of the licenses installed on the Services Router. Verify the following information:

- Each license is present. Licenses are listed in ascending alphanumeric order by license ID.
- The state of each license is valid.

A state of *invalid* indicates that the license key is not a valid license key. Either it was entered incorrectly or it is not valid for the specific device.
- The feature for each license is the expected feature. The features enabled are listed by license. An all-inclusive license has **All features** listed.
- All configured features have the required licenses installed. The **Licenses needed** column must show that no licenses are required.

Displaying License Usage

Purpose Verify that the licenses fully cover the feature configuration on the Services Router.

Action From the CLI, enter the `show system license usage` command.

Sample Output

```
user@router> show system license usage
```

Feature name	Free ports used	Licenses used	Licenses installed	Licenses needed
all		0	1	0
bgp-reflection		0	1	1
firewall		1	1	0
if-t1-4	1	3	4	0
if-fe	2	0	2	1
ipsec-vpn		2	1	1

What It Means	<p>The output shows a list of the licenses installed on the Services Router and how they are used. Verify the following information:</p> <ul style="list-style-type: none"> ■ Each licensed feature and port is present. Features and ports are listed in ascending alphabetical order by license name. The number of licenses is shown in the fourth column. Verify that the appropriate number of licenses is installed. ■ The number of used licenses matches the number of configured features and ports. If a licensed feature or port is configured, the feature or port is considered used. The sample output shows that stateful firewall and BGP route reflection are configured. Additionally, four T1 interfaces (one free port and three licensed ports) are configured. Two free and two licensed Fast Ethernet ports are configured, and one Fast Ethernet license has been installed. ■ A license is installed on the Services Router for each configured feature and port. For every feature or port configured that does not have a license, one license is needed. <p>For example, the sample output shows that the user has configured four Fast Ethernet interfaces (two licensed interfaces and two free interfaces). This configuration requires two purchased licenses, but only one has been purchased. An additional license is required to be in compliance with license agreements.</p>
----------------------	---

Displaying Installed License Keys

Purpose	Verify the license keys installed on the Services Router.
Action	From the CLI, enter the show system license keys command.
Sample Output	<pre> user@router> show system license keys li29183743 jzsn4q ix8i8d 4ky27y jzsn4q ix8i8d adj7kr 8uq38t 82fsj6 ii8i7e adj7kr 82fsj6 acasck ix8i8d 4ky27y acasck 8uq38t ks2923 a938 li48293123 4ky27y acasck 82fsj6 jzsn4q ix8i8d eks12r 8uq38t ix8i8d jzsn4q ix8i8d 4ky27y acasck 82fsj6 ii8i7e adj7kr 8uq38t ks2923 a9382e li83474929 dkdis8 adj7kr 4ky27y aclscck 82fsj6 jzsn4q 8uq38t jzsn4q 9dk2i2 ii3i8d akd239 ks2923 492idf oo8i7e adj7kr 8u3892 3ksio </pre>
What It Means	The output shows a list of the license keys installed on the Services Router. Verify that each expected license key is present.

Chapter 2

Managing Users and Operations

You can use either J-Web Quick Configuration or a configuration editor to manage system functions, including RADIUS and TACACS+ servers, user login accounts, routine file operations, and system log messages.

This chapter contains the following topics. For more information about system management, see the *JUNOS System Basics Configuration Guide*.

- System Management Terms on page 15
- System Management Overview on page 16
- Before You Begin on page 21
- Managing Users and Files with the J-Web Interface on page 21
- Managing Users and Files with a Configuration Editor on page 34
- Accessing Remote Devices with the CLI on page 46

System Management Terms

Before performing system management tasks, become familiar with the terms defined in Table 8.

Table 8: System Management Terms

Term	Definition
Remote Authentication Dial-In User Service (RADIUS)	Authentication method for validating users who attempt to access one or more Services Routers by means of telnet. RADIUS is a multivendor IETF standard whose features are more widely accepted than those of TACACS+ or other proprietary systems. All one-time-password system vendors support RADIUS.
Terminal Access Controller Access Control System Plus (TACACS+)	Authentication method for validating users who attempt to access one or more Services Routers by means of telnet.

System Management Overview

This section contains the following topics:

- System Authentication on page 16
- User Accounts on page 16
- Login Classes on page 17
- Template Accounts on page 19
- System Log Files on page 20

System Authentication

The JUNOS software supports three methods of user authentication: local password authentication, Remote Authentication Dial-In User Service (RADIUS), and Terminal Access Controller Access Control System Plus (TACACS+).

With local password authentication, you configure a password for each user allowed to log into the Services Router.

RADIUS and TACACS+ are authentication methods for validating users who attempt to access the router using telnet. Both are distributed client/server systems—the RADIUS and TACACS+ clients run on the router, and the server runs on a remote network system.

You can configure the router to use RADIUS or TACACS+ authentication, or both, to validate users who attempt to access the router. If you set up both authentication methods, you also can configure which the router will try first.

User Accounts

User accounts provide one way for users to access the Services Router. Users can access the router without accounts if you configured RADIUS or TACACS+ servers, as described in “Managing Users with Quick Configuration” on page 21 and “Managing Users and Files with a Configuration Editor” on page 34. After you have created an account, the router creates a home directory for the user. An account for the user `root` is always present in the configuration. For information about configuring the password for the user `root`, see the *J-series Services Router Getting Started Guide*. For each user account, you can define the following:

- Username—Name that identifies the user. It must be unique within the router. Do not include spaces, colons, or commas in the username.
- User’s full name—If the full name contains spaces, enclose it in quotation marks (“ ”). Do not include colons or commas.
- User identifier (UID)—Numeric identifier that is associated with the user account name. The identifier must be in the range 100 through 64000 and

must be unique within the router. If you do not assign a UID to a username, the software assigns one when you commit the configuration, preferring the lowest available number.

- User's access privilege—You can create login classes with specific permission bits or use one of the default classes listed in Table 10.
- Authentication method or methods and passwords that the user can use to access the router—You can use SSH or an MD5 password, or you can enter a plain-text password that the JUNOS software encrypts using MD5-style encryption before entering it in the password database. If you configure the plain-text-password option, you are prompted to enter and confirm the password.

Login Classes

All users who log into the Services Router must be in a login class. With login classes, you define the following:

- Access privileges users have when they are logged into the router. For more information, see “Permission Bits” on page 17.
- Commands and statements that users can and cannot specify. For more information, see “Denying or Allowing Individual Commands” on page 19.
- How long a login session can be idle before it times out and the user is logged off.

You can define any number of login classes. You then apply one login class to an individual user account. The software contains a few predefined login classes, which are listed in Table 10. The predefined login classes cannot be modified.

Permission Bits

Each top-level command-line interface (CLI) command and each configuration statement has an access privilege level associated with it. Users can execute only those commands and configure and view only those statements for which they have access privileges. The access privileges for each login class are defined by one or more permission bits (see Table 9).

Two forms for the permissions control the individual parts of the configuration:

- "Plain" form—Provides read-only capability for that permission type. An example is `interface`.
- Form that ends in `-control`—Provides read and write capability for that permission type. An example is `interface-control`.

Table 9: Permission Bits for Login Classes

Permission Bit	Access
admin	Can view user account information in configuration mode and with the show configuration command.
admin-control	Can view user accounts and configure them (at the [edit system login] hierarchy level).
access	Can view the access configuration in configuration mode and with the show configuration operational mode command.
access-control	Can view and configure access information (at the [edit access] hierarchy level).
all	Has all permissions.
clear	Can clear (delete) information learned from the network that is stored in various network databases (using the clear commands).
configure	Can enter configuration mode (using the configure command) and commit configurations (using the commit command).
control	Can perform all control-level operations (all operations configured with the -control permission bits).
field	Reserved for field (debugging) support.
firewall	Can view the firewall filter configuration in configuration mode.
firewall-control	Can view and configure firewall filter information (at the [edit firewall] hierarchy level).
floppy	Can read from and write to the removable media.
interface	Can view the interface configuration in configuration mode and with the show configuration operational mode command.
interface-control	Can view chassis, class of service, groups, forwarding options, and interfaces configuration information. Can configure chassis, class of service, groups, forwarding options, and interfaces (at the [edit] hierarchy).
maintenance	Can perform system maintenance, including starting a local shell on the router and becoming the superuser in the shell (by issuing the su root command), and can halt and reboot the router (using the request system commands).
network	Can access the network by entering the ping , ssh , telnet , and traceroute commands.
reset	Can restart software processes using the restart command and can configure whether software processes are enabled or disabled (at the [edit system processes] hierarchy level).
rollback	Can use the rollback command to return to a previously committed configuration other than the most recently committed one.
routing	Can view general routing, routing protocol, and routing policy configuration information in configuration and operational modes.
routing-control	Can view general routing, routing protocol, and routing policy configuration information and configure general routing (at the [edit routing-options] hierarchy level), routing protocols (at the [edit protocols] hierarchy level), and routing policy (at the [edit policy-options] hierarchy level).
secret	Can view passwords and other authentication keys in the configuration.
secret-control	Can view passwords and other authentication keys in the configuration and can modify them in configuration mode.
security	Can view security configuration in configuration mode and with the show configuration operational mode command.

Table 9: Permission Bits for Login Classes (continued)

Permission Bit	Access
security-control	Can view and configure security information (at the [edit security] hierarchy level).
shell	Can start a local shell on the router by entering the start shell command.
snmp	Can view SNMP configuration information in configuration and operational modes.
snmp-control	Can view SNMP configuration information and configure SNMP (at the [edit snmp] hierarchy level).
system	Can view system-level information in configuration and operational modes.
system-control	Can view system-level configuration information and configure it (at the [edit system] hierarchy level).
trace	Can view trace file settings in configuration and operational modes.
trace-control	Can view trace file settings and configure trace file properties.
view	Can use various commands to display current systemwide, routing table, and protocol-specific values and statistics.

Table 10: Predefined Login Classes

Login Class	Permission Bits Set
operator	clear, network, reset, trace, view
read-only	view
super-user and superuser	all
unauthorized	None

Denying or Allowing Individual Commands

By default, all top-level CLI commands have associated access privilege levels. Users can execute only those commands and view only those statements for which they have access privileges. For each login class, you can explicitly deny or allow the use of operational and configuration mode commands that are otherwise permitted or not allowed by a permission bit.

Template Accounts

You use local user template accounts when you need different types of templates. Each template can define a different set of permissions appropriate for the group of users who use that template. These templates are defined locally on the Services Router and referenced by the TACACS+ and RADIUS authentication servers.

When you configure local user templates and a user logs in, the JUNOS software issues a request to the authentication server to authenticate the user's login name. If a user is authenticated, the server returns the local username to

the router, which then determines whether a local username is specified for that login name (local-username for TACACS + , Juniper-Local-User for RADIUS). If so, the router selects the appropriate local user template locally configured on the router. If a local user template does not exist for the authenticated user, the router defaults to the **remote** template.

For more information, see “Setting Up Template Accounts” on page 40.

System Log Files

The JUNOS software generates system log messages (also called syslog messages) to record events that occur on the Services Router, including the following:

- Routine operations, such as creation of an Open Shortest Path First (OSPF) protocol adjacency or a user login into the configuration database
- Failure and error conditions, such as failure to access a configuration file or unexpected closure of a connection to a child or peer process
- Emergency or critical conditions, such as router power-off due to excessive temperature

The JUNOS system logging utility is similar to the UNIX **syslogd** utility. Each system log message identifies the software process that generated the message and briefly describes the operation or error that occurred.

When you configure system logging, you can direct messages to one or more destinations:

- To a named file in a local file system
- To the terminal session of one or more specific users (or all users) when they are logged into the router
- To the router console
- To a remote machine that is running the UNIX **syslogd** utility

Each system log message belongs to a facility, which is a group of messages that are either generated by the same software process or concern a similar condition or activity (such as authentication attempts).

Reboot requests are recorded to the system log files, which you can view with the **show log** command. Also, the names of any running processes that are scheduled to be shut down are changed. You can view the process names with the **show system processes** command.

Before You Begin

Before you perform any system management tasks, you must perform the initial Services Router configuration described in the *J-series Services Router Getting Started Guide*.

Managing Users and Files with the J-Web Interface

This section contains the following topics:

- Managing Users with Quick Configuration on page 21
- Managing Files with the J-Web Interface on page 29

Managing Users with Quick Configuration

This section contains the following topics:

- Adding a RADIUS Server for Authentication on page 21
- Adding a TACACS + Server for Authentication on page 23
- Configuring System Authentication on page 25
- Adding New Users on page 27

Adding a RADIUS Server for Authentication

You can use the Users Quick Configuration page for RADIUS servers to configure a RADIUS server for system authentication. This Quick Configuration page allows you to specify the IP address and secret (password) of the RADIUS server.

Figure 2 shows the Users Quick Configuration page for RADIUS servers.

Figure 2: Users Quick Configuration Page for RADIUS Servers

Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor **Configuration** **Diagnose** **Manage**

[Configuration](#) > [Quick Configuration](#) > [Users](#)

Quick Configuration

Users [Add a RADIUS Server](#)

RADIUS Server

* **RADIUS Server Address**

* **RADIUS Server Secret**

* **Verify RADIUS Server Secret**

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice.](#)

To configure a RADIUS server with Quick Configuration:

1. In the J-Web interface, select **Configuration > Quick Configuration > Users**.
2. Under RADIUS servers, click **Add** to configure a RADIUS server.
3. Enter information into the Users Quick Configuration page for RADIUS servers, as described in Table 11.
4. Click one of the following buttons on the Users Quick Configuration page for RADIUS servers:
 - To apply the configuration and return to the Users Quick Configuration page, click **OK**.
 - To cancel your entries and return to the Users Quick Configuration page, click **Cancel**.

Table 11: Users Quick Configuration for RADIUS Servers Summary

Field	Function	Your Action
RADIUS Server		
RADIUS Server Address (required)	Identifies the IP address of the RADIUS server.	Type the RADIUS server's 32-bit IP address, in dotted decimal notation.
RADIUS Server Secret (required)	The secret (password) of the RADIUS server.	Type the secret (password) of the RADIUS server. Secrets can contain spaces. The secret used must match that used by the RADIUS server.
Verify RADIUS Server Secret (required)	Verifies the secret (password) of the RADIUS server is entered correctly.	Retype the secret of the RADIUS server.

Adding a TACACS+ Server for Authentication

You can use the Users Quick Configuration page for TACACS + servers to configure a TACACS + server for system authentication. This Quick Configuration page allows you to specify the IP address and secret of the TACACS + server.

Figure 3 shows the Users Quick Configuration page for TACACS + servers.

Figure 3: Users Quick Configuration Page for TACACS+ Servers

Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor **Configuration** **Diagnose** **Manage**

[Configuration > Quick Configuration > Users](#)

Quick Configuration

Users [Add a TACACS+ Server](#)

TACACS+ Server

* TACACS+ Server Address

* TACACS+ Server Secret

* Verify TACACS+ Server Secret

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice](#).

To configure a TACACS + server with Quick Configuration:

1. In the J-Web interface, select **Configuration > Quick Configuration > Users**.
2. Under TACACS + servers, click **Add** to configure a TACACS + server.
3. Enter information into the Users Quick Configuration page for TACACS + servers, as described in Table 12.
4. Click one of the following buttons on the Users Quick Configuration page for TACACS + servers:
 - To apply the configuration and return to the Users Quick Configuration page, click **OK**.
 - To cancel your entries and return to the Users Quick Configuration page, click **Cancel**.

Table 12: Users Quick Configuration for TACACS+ Servers Summary

Field	Function	Your Action
TACACS+ Server		
TACACS + Server Address (required)	Identifies the IP address of the TACACS + server.	Type the TACACS + server's 32-bit IP address, in dotted decimal notation.
TACACS + Server Secret (required)	The secret (password) of the TACACS + server.	Type the secret (password) of the TACACS + server. Secrets can contain spaces. The secret used must match that used by the TACACS + server.
Verify TACACS + Server Secret (required)	Verifies the secret (password) of the TACACS + server is entered correctly.	Retype the secret of the TACACS + server.

Configuring System Authentication

On the Users Quick Configuration page, you can configure the authentication methods the Services Router uses to verify that a user can gain access. For each login attempt, the router tries the authentication methods in order, starting with the first one, until the password matches.

If you do not configure system authentication, users are verified based on their configured local passwords.

Figure 4 shows the Users Quick Configuration page.

Figure 4: Users Quick Configuration Page

Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor **Configuration** **Diagnose** **Manage**

[Configuration](#) > [Quick Configuration](#) > [Users](#)

Quick Configuration

Users

	Username	Full Name	Login Class
<input type="checkbox"/>	regress		superuser

[Add...](#) [Delete](#)

Authentication Servers

Authentication Methods

☒ RADIUS
☐ TACACS+
☒ Local Password

RADIUS Servers

	RADIUS Server	Secret Configured
<input type="checkbox"/>	192.168.64.10	Yes

Navigation menu (left):

- Quick Configuration
 - Set Up
 - SSL
 - Interfaces
 - Users**
 - SNMP
 - Routing
 - Firewall/NAT
 - IPSec Tunnels
 - Realtime Performance Monitoring
- View and Edit
- History
- Rescue

To configure system authentication with Quick Configuration:

1. In the J-Web interface, select **Configuration > Quick Configuration > Users**.
2. Under Authentication Servers, select the check box next to each authentication method the router must use when users log in:
 - RADIUS
 - TACACS +
 - Local Password
3. Click one of the following buttons on the Users Quick Configuration page:
 - To apply the configuration and stay in the Users Quick Configuration page, click **Apply**.

- To apply the configuration and return to the Quick Configuration page, click **OK**.
- To cancel your entries and return to the Quick Configuration page, click **Cancel**.

Adding New Users

You can use the Users Quick Configuration page for user information to add new users to a Services Router. For each account, you define a login name and password for the user and specify a login class for access privileges.

Figure 5 shows the Quick Configuration page for adding a user.

Figure 5: Add a User Quick Configuration Page

Juniper NETWORKS ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor Configuration Diagnose Manage

Quick Configuration

Set Up

SSL

Interfaces

Users

SNMP

Routing

Firewall/NAT

IPSec Tunnels

Realtime Performance Monitoring

► **View and Edit**

► **History**

► **Rescue**

Quick Configuration

Users **Add a User**

User Information

* **Username**

Full Name

* **Login Class**

* **Login Password**

* **Verify Login Password**

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice.](#)

To configure users with Quick Configuration:

1. In the J-Web interface, select **Configuration > Quick Configuration > Users**.
2. Under Users, click **Add** to add a new user.
3. Enter information into the Add a User Quick Configuration page, as described in Table 13.
4. Click one of the following buttons on the Add a User Quick Configuration page:
 - To apply the configuration and return to the Users Quick Configuration page, click **OK**.
 - To cancel your entries and return to the Users Quick Configuration page, click **Cancel**.

Table 13: Add a User Quick Configuration Page Summary

Field	Function	Your Action
User Information		
Username (required)	Name that identifies the user.	Type the username. It must be unique within the router. Do not include spaces, colons, or commas in the username.
Full Name	The user's full name.	Type the user's full name. If the full name contains spaces, enclose it in quotation marks. Do not include colons or commas.
Login Class (required)	Defines the user's access privilege.	<p>From the list, select the user's login class:</p> <ul style="list-style-type: none"> ■ operator ■ read-only ■ super-user/superuser ■ unauthorized <p>This list also includes any user-defined login classes. For more information, see "Login Classes" on page 17.</p>

Table 13: Add a User Quick Configuration Page Summary (continued)

Field	Function	Your Action
Login Password (required)	The login password for this user.	<p>Type the login password for this user. The login password must meet the following criteria:</p> <ul style="list-style-type: none"> ■ The password must be at least 6 characters long. ■ You can include most character classes in a password (alphabetic, numeric, and special characters), except control characters. ■ The password must contain at least one change of case or character class.
Verify Login Password (required)	Verifies the login password for this user.	Retype the login password for this user.

Managing Files with the J-Web Interface

This section contains the following topics:

- Cleaning Up Files on page 29
- Downloading Files on page 31
- Deleting Files on page 32

Cleaning Up Files


You can use the J-Web interface to rotate and delete files on the Services Router. If you are running low on storage space, the file cleanup procedure quickly identifies files that can be deleted.

The file cleanup procedure performs the following tasks:

- Rotates log files—All information in the current log files is archived, and fresh log files are created.
- Deletes log files in `/cf/var/log`—Any files that are not currently being written to are deleted.
- Deletes temporary files in `/cf/var/tmp`—Any files that have not been accessed within two days are deleted.
- Deletes all crash files in `/cf/var/crash`—Any core files that the router has written during an error are deleted.

Figure 6 shows the Clean Up Files page.

Figure 6: Clean Up Files Page



Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage**

[Manage](#) > [Files](#)

Files

Clean Up Files

If you are running low on storage space on your router, you can click on the "Clean Up Files" button below. By doing so, the router will perform the following:

- Rotate your log files
- Delete log files in /var/log that are not currently being written to
- Delete temporary files in /var/tmp that have not been touched in 2 days
- Delete all crash files in /var/crash

Alternatively, you can click on the "File Type" group name below to manually download and delete individual files.

[Clean Up Files](#)

Download and Delete Files

File Type	Directory	Usage
Log Files	/cf/var/log	5.9M
Temporary Files	/cf/var/tmp	28M
Crash (Core) Files	/cf/var/crash	1.0K

To rotate and delete files with the J-Web interface:

1. In the J-Web interface, select **Manage > Files**.
2. In the Clean Up Files section, click **Clean Up Files**. The router rotates log files and identifies the files that can be safely deleted.
3. The J-Web interface displays the files that you can delete and the amount of space that will be freed on the file system.
4. Click one of the following buttons on the confirmation page:
 - To delete the files and return to the Files page, click **OK**.

- To cancel your entries and return to the list of files in the directory, click **Cancel**.

Downloading Files

You can use the J-Web interface to download a copy of an individual file from the Services Router. When you download a file, it is not deleted from the file system.

Figure 7 shows the J-Web page from which you can download log files.

Figure 7: Log Files Page (Download)

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage**

[Manage](#) > [Files](#)

Files

Log Files

[Delete...](#)

	Name	Size	Date	Owner/Group	Action
<input type="checkbox"/>	amd.log	2M	Jan 18 15:54	root/wheel	Download
	autod	27K	Jan 18 14:19	root/wheel	Download
	bfdd	509K	Jun 22 2004	root/wheel	Download
	changes	3K	Oct 15 14:16	root/wheel	Download
	chassisd	690K	Jan 18 15:01	root/wheel	Download

To download files with the J-Web interface:

1. In the J-Web interface, select **Manage > Files**.
2. In the Download and Delete Files section, click one of the following file types:

- **Log Files**—Lists the log files located in the `/cf/var/log` directory on the router.
 - **Temporary Files**—Lists the temporary files located in the `/cf/var/tmp` directory on the router.
 - **Crash (Core) Files**—Lists the core files located in the `/cf/var/crash` directory on the router.
3. The J-Web interface displays the files located in the directory.
 4. To download an individual file, click **Download**.
 5. Choose a location for the browser to save the file.
The file is saved as a text file, with a `.txt` file extension.
 6. To view the file, open it with a text editor.

Deleting Files


You can use the J-Web interface to delete an individual file from the Services Router. When you delete the file, it is permanently removed from the file system.



CAUTION: If you are unsure whether to delete a file from the router, we recommend using the **Cleanup Files** tool described in “Cleaning Up Files” on page 29. This tool determines which files can be safely deleted from the file system.

Figure 8 shows the J-Web page on which you confirm the deletion of files.

Figure 8: Confirm File Delete Page



To rotate and delete files with the J-Web interface:

1. In the J-Web interface, select **Manage > Files**.
2. In the Download and Delete Files section, click one of the following file types:
 - **Log Files**—Lists the log files located in the /cf/var/log directory on the router.
 - **Temporary Files**—Lists the temporary files located in the /cf/var/tmp directory on the router.
 - **Crash (Core) Files**—Lists the core files located in the /cf/var/crash directory on the router.
3. The J-Web interface displays the files located in the directory.
4. Check the box next to each file you plan to delete.
5. Click **Delete**.

The J-Web interface displays the files you can delete and the amount of space that will be freed on the file system.

6. Click one of the following buttons on the confirmation page:
 - To delete the files and return to the Files page, click **OK**.
 - To cancel your entries and return to the list of files in the directory, click **Cancel**.

Managing Users and Files with a Configuration Editor

This section contains the following topics:

- Setting Up RADIUS Authentication on page 34
- Setting Up TACACS+ Authentication on page 35
- Configuring Authentication Order on page 37
- Controlling User Access on page 38
- Setting Up Template Accounts on page 40
- Setting Up System Logs on page 43

Setting Up RADIUS Authentication

To use RADIUS authentication, you must configure at least one RADIUS server.

The procedure provided in this section identifies the RADIUS server, specifies the secret (password) of the RADIUS server, and sets the source address of the Services Router's RADIUS requests to the loopback address of the router. The procedure uses the following sample values:

- The RADIUS server's IP address is 172.16.98.1.
- The RADIUS server's secret is Radiussecret1.
- The loopback address of the router is 10.0.0.1.

To configure RADIUS authentication:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 14.
3. If you are finished configuring the network, commit the configuration.

To completely set up RADIUS authentication, you must create user template accounts and specify a system authentication order.

4. Go on to one of the following procedures:

- To specify a system authentication order, see “Configuring Authentication Order” on page 37.
- To configure a remote user template account, see “Creating a Remote Template Account” on page 41.
- To configure local user template accounts, see “Creating a Local Template Account” on page 42.

Table 14: Setting Up RADIUS Authentication

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System level in the configuration hierarchy.	In the configuration editor hierarchy, select System .	From the top of the configuration hierarchy enter edit system
Add a new RADIUS server	<ol style="list-style-type: none"> 1. In the Radius server box, click Add new entry. 2. In the Address box, type the IP address of the RADIUS server: 172.16.98.1 	Set the IP address of the RADIUS server: set radius-server address 172.16.98.1
Specify the shared secret (password) of the RADIUS server. The secret is stored as an encrypted value in the configuration database.	In the Secret box, type the shared secret of the RADIUS server: RADIUSsecret1	Set the shared secret of the RADIUS server: set radius-server 172.16.98.1 secret RADIUSsecret1
Specify the source address to be included in the RADIUS server requests by the router. In most cases, you can use the loopback address of the router.	In the Source address box, type the loopback address of the router: 10.0.0.1	Set the router's loopback address as the source address: set radius-server 172.16.98.1 source-address 10.0.0.1

Setting Up TACACS+ Authentication

To use TACACS+ authentication, you must configure at least one TACACS+ server.

The procedure provided in this section identifies the TACACS+ server, specifies the secret (password) of the TACACS+ server, and sets the source address of the Services Router's TACACS+ requests to the loopback address of the router. This procedure uses the following sample values:

- The TACACS+ server's IP address is 172.16.98.24.
- The TACACS+ server's secret is Tacacssecret1.
- The loopback address of the router is 10.0.0.1.

To configure TACACS+ authentication:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 15.
3. If you are finished configuring the network, commit the configuration.

To completely set up TACACS+ authentication, you must create user template accounts and specify a system authentication order.

4. Go on to one of the following procedures:
 - To specify a system authentication order, see “Configuring Authentication Order” on page 37.
 - To configure a remote user template account, see “Creating a Remote Template Account” on page 41.
 - To configure local user template accounts, see “Creating a Local Template Account” on page 42.

Table 15: Setting Up TACACS+ Authentication

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System level in the configuration hierarchy.	In the configuration editor hierarchy, select System .	From the top of the configuration hierarchy enter edit system
Add a new TACACS+ server	<ol style="list-style-type: none"> 1. In the Tacplus server box, click Add new entry. 2. In the Address box, type the IP address of the TACACS+ server: 172.16.98.24 	Set the IP address of the TACACS+ server: set tacplus-server address 172.16.98.24
Specify the shared secret (password) of the TACACS+ server. The secret is stored as an encrypted value in the configuration database.	In the Secret box, type the shared secret of the TACACS+ server: Tacacssecret1	Set the shared secret of the TACACS+ server: set tacplus-server 172.16.98.24 secret Tacacssecret1
Specify the source address to be included in the TACACS+ server requests by the router. In most cases, you can use the loopback address of the router.	In the Source address box, type the loopback address of the router: 10.0.0.1	Set the router's loopback address as the source address: set tacplus-server 172.16.98.24 source-address 10.0.0.1

Configuring Authentication Order

The procedure provided in this section configures the Services Router to attempt user authentication with the local password first, then with the RADIUS server, and finally with the TACACS + server.

To configure authentication order:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 16.
3. If you are finished configuring the network, commit the configuration.

To completely set up RADIUS or TACACS + authentication, you must configure at least one RADIUS or TACACS + server and create user template accounts.

4. Go on to one of the following procedures:
 - To configure a RADIUS server, see “Setting Up RADIUS Authentication” on page 34.
 - To configure a TACACS + server, see “Setting Up TACACS + Authentication” on page 35.
 - To configure a remote user template account, see “Creating a Remote Template Account” on page 41.
 - To configure local user template accounts, see “Creating a Local Template Account” on page 42.

Table 16: Configuring Authentication Order

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System level in the configuration hierarchy.	In the configuration editor hierarchy, select System .	From the top of the configuration hierarchy enter edit system
Add RADIUS authentication to the authentication order.	<ol style="list-style-type: none"> 1. In the Authentication order box, click Add new entry. 2. In the list, select radius. 3. Click OK. 	Insert the radius statement in the authentication order: insert system authentication-order radius after password
Add TACACS + authentication to the authentication order.	<ol style="list-style-type: none"> 1. In the Authentication Order box, click Add new entry. 2. In the list, select tacplus. 3. Click OK. 	Insert the tacplus statement in the authentication order: insert system authentication-order tacplus after radius

Controlling User Access

This section contains the following topics:

- Defining Login Classes on page 38
- Creating User Accounts on page 39

Defining Login Classes

You can define any number of login classes. You then apply one login class to an individual user account, as described in “Creating User Accounts” on page 39 and “Setting Up Template Accounts” on page 40.

The procedure provided in this section creates a sample login class named `operator-and-boot` with the following privileges:

- The `operator-and-boot` login class can reboot the Services Router using the `request system reboot` command.
- The `operator-and-boot` login class can also use commands defined in the `clear`, `network`, `reset`, `trace`, and `view` permission bits. For more information, see “Permission Bits” on page 17.

To define login classes:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 17.
3. If you are finished configuring the network, commit the configuration.
4. Go on to one of the following procedures:
 - To create user accounts, see “Creating User Accounts” on page 39.
 - To create shared user accounts, see “Setting Up Template Accounts” on page 40.

Table 17: Defining Login Classes

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System Login level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Login .	From the top of the configuration hierarchy enter edit system login

Table 17: Defining Login Classes (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Create a login class named operator-and-boot with the ability to reboot the router.	<ol style="list-style-type: none"> Next to Class, click Add new entry. Type the name of the login class: operator-and-boot In the Allow commands box, type the request system reboot command enclosed in quotation marks: "request system reboot" Click OK. 	<p>Set the name of the login class and the ability to use the request system reboot command:</p> <pre>set class operator-and-boot allow-commands "request system reboot"</pre>
Give the operator-and-boot login class operator privileges.	<ol style="list-style-type: none"> Next to Permissions, click Add new entry. In the Value list, select clear. Click OK. Next to Permissions, click Add new entry. In the Value list, select network. Click OK. Next to Permissions, click Add new entry. In the Value list, select reset. Click OK. Next to Permissions, click Add new entry. In the Value list, select trace. Click OK. Next to Permissions, click Add new entry. In the Value list, select view. Click OK. 	<p>Set the permission bits for the operator-and-boot login class:</p> <pre>set class operator-and-boot permissions [clear network reset trace view]</pre>

Creating User Accounts

User accounts provide one way for users to access the Services Router. (Users can access the router without accounts if you configured RADIUS or TACACS +

servers, as described in “Setting Up RADIUS Authentication” on page 34 and “Setting Up TACACS + Authentication” on page 35.)

The procedure provided in this section creates a sample user named **cmartin** with the following characteristics:

- The user **cmartin** belongs to the **superuser** login class.
- The user **cmartin** uses an encrypted password, **\$1\$14c5.\$sBopasdFFdssdfFFdsdfs0**.

To create user accounts:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 18.
3. If you are finished configuring the network, commit the configuration.

Table 18: Creating User Accounts

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System Login level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Login .	From the top of the configuration hierarchy enter edit system login
Create a user named cmartin who belongs to the superuser login class.	<ol style="list-style-type: none"> 1. Next to User, click Add new entry. 2. In the User name box, type cmartin. 3. In the Class box, type superuser. 4. Click OK. 	Set the username and the login class for the user: set user cmartin class superuser
Define the encrypted password for cmartin .	<ol style="list-style-type: none"> 1. Next to Authentication, click Configure. 2. In the Encrypted password box, type \$1\$14c5.\$sBopasdFFdssdfFFdsdfs0 3. Click OK. 	Set the encrypted password for cmartin . set user cmartin authentication encrypted-password \$1\$14c5.\$sBopasdFFdssdfFFdsdfs0

Setting Up Template Accounts

You can create template accounts that are shared by a set of users when you are using RADIUS or TACACS + authentication. When a user is authenticated by a template account, the CLI username is the login name, and the privileges, file ownership, and effective user ID are inherited from the template account.

This section contains the following topics:

- Creating a Remote Template Account on page 41
- Creating a Local Template Account on page 42

Creating a Remote Template Account

You can create a remote template that is applied to users authenticated by RADIUS or TACACS+ that do not belong to a local template account.

By default, the JUNOS software uses the remote template account when

- The authenticated user does not exist locally on the Services Router.
- The authenticated user's record in the RADIUS or TACACS+ server specifies local user, or the specified local user does not exist locally on the router.

The procedure provided in this section creates a sample user named **remote** that belongs to the **operator** login class.

To create a remote template account:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 19.
3. If you are finished configuring the network, commit the configuration.

To completely set up RADIUS or TACACS+ authentication, you must configure at least one RADIUS or TACACS+ server and specify a system authentication order.

4. Go on to one of the following procedures:
 - To configure a RADIUS server, see “Setting Up RADIUS Authentication” on page 34.
 - To configure a TACACS+ server, see “Setting Up TACACS+ Authentication” on page 35.
 - To specify a system authentication order, see “Configuring Authentication Order” on page 37.

Table 19: Creating a Remote Template Account

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System Login level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Login .	From the top of the configuration hierarchy enter edit system login
Create a user named remote who belongs to the operator login class.	<ol style="list-style-type: none"> Next to User, click Add new entry. In the User name box, type remote. In the Class box, type operator. Click OK. 	Set the username and the login class for the user: set user remote class operator

Creating a Local Template Account

You can create a local template that is applied to users authenticated by RADIUS or TACACS+ that are assigned to the local template account. You use local template accounts when you need different types of templates. Each template can define a different set of permissions appropriate for the group of users who use that template.

The procedure provided in this section creates a sample user named **admin** that belongs to the **superuser** login class.

To create a local template account:

- Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
- Perform the configuration tasks described in Table 20.
- If you are finished configuring the network, commit the configuration.

To completely set up RADIUS or TACACS+ authentication, you must configure at least one RADIUS or TACACS+ server and specify a system authentication order

- Go on to one of the following procedures:
 - To configure a RADIUS server, see “Setting Up RADIUS Authentication” on page 34.
 - To configure a TACACS+ server, see “Setting Up TACACS+ Authentication” on page 35.
 - To configure a system authentication order, see “Configuring Authentication Order” on page 37.

Table 20: Creating a Local Template Account

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System Login level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Login .	From the top of the configuration hierarchy enter edit system login
Create a user named admin who belongs to the superuser login class.	<ol style="list-style-type: none"> Next to User, click Add new entry. In the User name box, type admin. In the Class box, type superuser. Click OK. 	Set the username and the login class for the user: set user admin class superuser

Setting Up System Logs

You can send system logging information to one or more destinations. The destinations can be one or more files, one or more remote hosts, the terminals of one or more users if they are logged in, and the system console.

For each place where you can send system logging information, you specify the class (facility) of messages to log and the minimum severity level (level) of the message.

Table 21 lists the system logging facilities, and Table 22 lists the system logging severity levels. For more information about system log messages, see the *JUNOS System Log Messages Reference*.

Table 21: System Logging Facilities

Facility	Description
any	Any facility
authorization	Any authorization attempt
change-log	Any change to the configuration
cron	Cron scheduling process
daemon	Various system processes
interactive-commands	Commands executed in the CLI

Table 21: System Logging Facilities (continued)

Facility	Description
kernel	Messages generated by the JUNOS kernel
user	Messages from random user processes

Table 22: System Logging Severity Levels

Severity Level (from Highest to Lowest Severity)	Description
emergency	Panic or other conditions that cause the system to become unusable.
alert	Conditions that must be corrected immediately, such as a corrupted system database.
critical	Critical conditions, such as hard drive errors.
error	Standard error conditions.
warning	System warning messages.
notice	Conditions that are not error conditions, but that might warrant special handling.
info	Informational messages. This is the default.
debug	Software debugging messages.

This section contains the following topics:

- Sending System Log Messages to a File on page 44
- Sending System Log Messages to a User Terminal on page 45
- Archiving System Logs on page 46
- Disabling System Logs on page 46

Sending System Log Messages to a File

You can direct system log messages to a file on the compact flash drive. The default directory for log files is `/var/log`. To specify a different directory on the compact flash drive, include the complete pathname. For the list of logging facilities and severity levels, see Table 21 and Table 22.

For information about archiving log files, see “Archiving System Logs” on page 46.

The procedure provided in this section sends all security-related information to the sample file named `security`.

To send messages to a file:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 23.
3. If you are finished configuring the network, commit the configuration.

Table 23: Sending Messages to a File

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System Syslog level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Syslog .	From the top of the configuration hierarchy enter edit system syslog
Create a file named security , and send log messages of the authorization class at the severity level info to the file.	<ol style="list-style-type: none"> 1. Next to File, click Add new entry. 2. In the File name box, type security. 3. Next to Contents, click Add new entry. 4. In the Facility list, select authorization. 5. In the Level list, select info. 	Set the filename and the facility and severity level: set file security authorization info

Sending System Log Messages to a User Terminal

To direct system log messages to the terminal session of one or more specific users (or all users) when they are logged into the local Routing Engine, specify one or more JUNOS usernames. Separate multiple values with spaces, or use the asterisk (*) to indicate all users who are logged into the local Routing Engine. For the list of logging facilities and severity levels, see Table 21 and Table 22.

The procedure provided in this section sends any critical messages to the terminal of the sample user **frank**, if he is logged in.

To send messages to a user terminal:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 24.
3. If you are finished configuring the network, commit the configuration.

Table 24: Sending Messages to a User Terminal

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the System Syslog level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Syslog .	From the top of the configuration hierarchy enter edit system syslog
Send all critical messages to the user frank .	<ol style="list-style-type: none"> Next to User, click Add new entry. In the User name box, type frank. Next to Contents, click Add new entry. In the Facility list, select any. In the Level list, select critical. 	Set the filename and the facility and severity level: set user frank any critical

Archiving System Logs

By default, the JUNOS logging utility stops writing messages to a log file when the file reaches 128 KB in size. It closes the file and adds a numerical suffix, then opens and directs messages to a new file with the original name. By default, the logging utility creates up to 10 files before it begins overwriting the contents of the oldest file. The logging utility by default also limits the users who can read log files to the root user and users who have the JUNOS maintenance permission.

To enable all users to read log files, include the `world-readable` statement at the `[edit system syslog archive]` hierarchy level. To restore the default permissions, include the `no-world-readable` statement. You can include the `archive` statement at the `[edit system syslog file filename]` hierarchy level to configure the number of files, file size, and permissions for the specified log file. For configuration details, see the information about archiving log files in the *JUNOS System Basics Configuration Guide*.

Disabling System Logs

To disable logging of the messages from a facility, use the `facility none` configuration statement. This statement is useful when, for example, you want to log messages of the same severity level from all but a few facilities. Instead of including a configuration statement for each facility you want to log, you can configure the `any level` statement and then a `facility none` statement for each facility you do not want to log. For configuration details, see the information about disabling logging in the *JUNOS System Basics Configuration Guide*.

Accessing Remote Devices with the CLI

This section contains the following topics:

- Using the telnet Command on page 47

- Using the ssh Command on page 47

Using the telnet Command

You can use the CLI `telnet` command to open a telnet session to a remote device:

```
user@host> telnet host <8bit> <bypass-routing> <inet>
<interface interface-name> <no-resolve> <port port>
<routing-instance routing-instance-name> <source address>
```

To escape from the telnet session to the telnet command prompt, press Ctrl-]. To exit from the telnet session and return to the CLI command prompt, enter quit.

Table 25 describes the `telnet` command options. For more information, see the *JUNOS System Basics and Services Command Reference*.

Table 25: CLI telnet Command Options

Option	Description
8bit	Use an 8-bit data path.
bypass-routing	Bypass the routing tables and open a telnet session only to hosts on directly attached interfaces. If the host is not on a directly attached interface, an error message is returned.
host	Open a telnet session to the specified hostname or IP address.
inet	Force the telnet session to an IPv4 destination.
interface source-interface	Open a telnet session to a host on the specified interface. If you do not include this option, all interfaces are used.
no-resolve	Suppress the display of symbolic names.
port port	Specify the port number or service name on the host.
routing-instance routing-instance-name	Use the specified routing instance for the telnet session.
source address	Use the specified source address for the telnet session.

Using the ssh Command

You can use the CLI `ssh` command to use the secure shell (SSH) program to open a connection to a remote device:

```
user@host> ssh host <bypass-routing> <inet>
<interface interface-name> <logical-router logical-router-name>
<routing-instance routing-instance-name> <source address> <v1> <v2>
```

Table 26 describes the `ssh` command options. For more information, see the *JUNOS System Basics and Services Command Reference*.

Table 26: CLI ssh Command Options

Option	Description
bypass-routing	Bypass the routing tables and open an SSH connection only to hosts on directly attached interfaces. If the host is not on a directly attached interface, an error message is returned.
<i>host</i>	Open an SSH connection to the specified hostname or IP address.
inet	Force the SSH connection to an IPv4 destination.
interface <i>source-interface</i>	Open an SSH connection to a host on the specified interface. If you do not include this option, all interfaces are used.
routing-instance <i>routing-instance-name</i>	Use the specified routing instance for the SSH connection.
source <i>address</i>	Use the specified source address for the SSH connection.
v1	Force SSH to use version 1 for the connection.
v2	Force SSH to use version 2 for the connection.

Chapter 3

Configuring SNMP for Network Management

The Simple Network Management Protocol (SNMP) is a client/server standard that helps you diagnose and monitor network health and statistics.

You can use either J-Web Quick Configuration or a configuration editor to configure SNMP.

This chapter contains the following topics. For more information about SNMP, see the *JUNOS Network Management Configuration Guide*.

- Network Management Overview on page 49
- Before You Begin on page 51
- Configuring SNMP with Quick Configuration on page 51
- Configuring SNMP with a Configuration Editor on page 54
- Verifying the SNMP Configuration on page 59

Network Management Overview

A network is a complex organization of nodes and processes that must operate reliably and efficiently. Having a single node or link failure in a network can undermine the network's performance and result in a loss of service. Therefore, determining where and when a network failure is occurring is a necessity.

Additionally, gathering statistics about how a network is performing can help you diagnose the overall health of the network and pinpoint bottlenecks so that you can address network growth appropriately.

By querying individual network nodes and receiving triggered updates, SNMP clients are able to provide valuable feedback about the state of a network.

Managers and Agents

Because SNMP is a client/server protocol, SNMP nodes can be classified as either clients (SNMP managers) or servers (SNMP agents).

SNMP managers, also called network management systems (NMSs), occupy central points in the network and they actively query and collect messages from SNMP agents in the network. SNMP agents are individual processes running on network nodes that gather information for a particular node and transfer the information to SNMP managers as queries are processed. Because SNMP agents are individual SNMP processes running on a host, multiple agents can be active on a single network node at any given time.

SMI, MIBs, and OIDs

Agents store information in a hierarchical database called the Structure of Management Information (SMI). The SMI resembles a file system; information is stored in individual files that are hierarchically arranged in the database. The individual files that store the information are known as Management Information Bases (MIBs). Each MIB contains nodes of information that are stored in a tree structure. Information branches down from a root node to individual leaves in the tree, and the individual leaves comprise the information that is queried by managers for a given MIB. The nodes of information are identified by an object ID (OID). The OID is a dotted integer identifier (1.3.6.1.2.1.2, for instance) or a subtree name (such as interfaces) that corresponds to an indivisible piece of information in the MIB.

Standard and Enterprise MIBs

A set of MIBs has been defined by the IETF and documented in various RFCs. These MIBs are common across many platforms. Additionally, individual enterprises can create their own set of enterprise-specific MIBs, provided they share the same structure as the standard MIBs. This structure is enforced through the Abstract Syntax Notation (ASN), which is a definition language used to store information.

To download the standard and enterprise MIBs for a Services Router, go to <http://www.juniper.net/customers/support/>.

SNMP Requests

Information is stored in MIBs, and MIBs are queried by SNMP managers. Managers send SNMP requests to process the information. SNMP requests come in two primary forms: get requests and set requests. These requests are processed by one or more agents on a particular node, and information is retrieved or modified on the MIB. When the agent has processed the request, it generates an SNMP response that either returns retrieved information from the MIB or acknowledges that information has been modified on the MIB.

SNMP Communities

To help ensure that only specific SNMP managers can access a particular SNMP agent, SNMP access is granted through communities. To control access, you first create an SNMP community. The community is assigned a name that is unique on the host. All SNMP requests that are sent to the agent must be configured with the same community name.

When multiple agents are configured on a particular host, the community name process ensures that SNMP requests are sorted to only those agents configured to handle the requests.

Additionally, communities allow you to specify one or more addresses or address prefixes to which you want to either allow or deny access. By specifying a list of clients, you can control exactly which SNMP managers have access to a particular agent.

SNMP Traps

The `get` and `set` commands that SNMP uses are useful for querying hosts within a network. However, the commands do not provide a means by which events can trigger a notification. For instance, if a link fails, the health of the link is unknown until an SNMP manager next queries that agent.

SNMP has traps, which are unsolicited notifications that are triggered by events on the host. When you configure a trap, you specify the types of events that can trigger trap messages, and you configure a set of targets to receive the generated messages.

Before You Begin

Before you begin configuring SNMP, complete the following tasks:

- Establish basic connectivity. See the *J-series Services Router Getting Started Guide*.
- Configure network interfaces. See the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

Configuring SNMP with Quick Configuration

J-Web Quick Configuration allows you to define system identification information, create SNMP communities, and create SNMP trap groups. Figure 9 shows the Quick Configuration page for SNMP.

Figure 9: Quick Configuration Page for SNMP

Juniper NETWORKS

ROUTER - J4300

Logged in as: regress

[Help](#) [About](#) [Logout](#)

Monitor Configuration Diagnose Manage

Configuration > Quick Configuration > SNMP

Quick Configuration

SNMP

Identification

Contact Information

System Description

Local Engine ID

System Location

System Name Override

Communities

	Community Name	Authorization
<input type="checkbox"/>	public	read-only
<input type="checkbox"/>	private	read-write

To configure SNMP features with Quick Configuration:

1. In the J-Web user interface, select **Configuration > Quick Configuration > SNMP**.
2. Enter information into the Quick Configuration page for SNMP, as described in Table 27.
3. From the SNMP Quick Configuration page, click one of the following buttons:
 - To apply the configuration and stay on the Quick Configuration page for SNMP, click **Apply**.
 - To apply the configuration and return to the Quick Configuration SNMP page, click **OK**.

- To cancel your entries and return to the Quick Configuration for SNMP page, click **Cancel**.
4. To check the configuration, see “Verifying the SNMP Configuration” on page 59.

Table 27: SNMP Quick Configuration Summary

Field	Function	Your Action
Identification		
Contact Information	Free-form text string that specifies an administrative contact for the system.	Type any contact information for the administrator of the system (such as name and phone number).
System Description	Free-form text string that specifies a description for the system.	Type any system information that describes the system (<i>J4300 with 4 PIMs</i> , for example).
Local Engine ID	Provides an administratively unique identifier of an SNMPv3 engine for system identification. The local engine ID contains a prefix and a suffix. The prefix is formatted according to specifications defined in RFC 3411. The suffix is defined by the local engine ID. Generally, the local engine ID suffix is the MAC address of fe-0/0/0.	Type the MAC address of the fe-0/0/0 interface.
System Location	Free-form text string that specifies the location of the system.	Type any location information for the system (lab name or rack name, for example).
System Name Override	Free-form text string that overrides the system hostname the <i>J-series Services Router Getting Started Guide</i> .	Type the name of the system.
Communities		Click Add .
Community Name	Specifies the name of the SNMP community.	Type the name of the community being added.
Authorization	Specifies the type of authorization (either read-only or read-write) for the SNMP community being configured.	Select the desired authorization (either read-only or read-write) from the list.
Traps		Click Add .
Trap Group Name	Specifies the name of the SNMP trap group being configured.	Type the name of the SNMP trap group being configured.

Table 27: SNMP Quick Configuration Summary (continued)

Field	Function	Your Action
Categories	Specifies which trap categories are added to the trap group being configured.	<ul style="list-style-type: none"> ■ To generate traps for authentication failures, select Authentication. ■ To generate traps for chassis and environment notifications, select Chassis. ■ To generate traps for configuration changes, select Configuration. ■ To generate traps for link-related notifications (up-down transitions), select Link. ■ To generate traps for remote operation notifications, select Remote operations. ■ To generate traps for remote network monitoring (RMON), select RMON alarm. ■ To generate traps for routing protocol notifications, select Routing. ■ To generate traps on system warm and cold starts, select Startup. ■ To generate traps on Virtual Router Redundancy Protocol (VRRP) events (such as new-master or authentication failures), select VRRP events.
Targets	One or more hostnames or IP addresses that specify the systems to receive SNMP traps generated by the trap group being configured.	<ol style="list-style-type: none"> 1. Enter the hostname or IP address, in dotted decimal notation, of the target system to receive the SNMP traps. 2. Click Add.

Configuring SNMP with a Configuration Editor

To configure SNMP on a Services Router, you must perform the following tasks marked *(Required)*. For information about using the J-Web and CLI configuration editors, see the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

- Defining System Identification Information (Required) on page 55

- Configuring SNMP Agents and Communities (Required) on page 56
- Managing SNMP Trap Groups (Required) on page 57
- Controlling Access to MIBs (Optional) on page 58

Defining System Identification Information (Required)

Basic system identification information for a Services Router can be configured with SNMP and stored in various MIBs. This information can be accessed through SNMP requests and either queried or reset. Table 28 identifies types of basic system identification and the MIB objects into which it is stored.

Table 28: System Identification Information and Corresponding MIB Objects

System Information	MIB
Contact	sysContact
System location	sysLocation
System description	sysDescr
System name override	sysName

To configure basic system identification for SNMP:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. To configure basic system information using SNMP, perform the configuration tasks described in Table 29.
3. If you are finished configuring the network, commit the configuration.
4. To check the configuration, see “Verifying the SNMP Configuration” on page 59.

Table 29: Configuring Basic System Identification

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the SNMP level in the configuration hierarchy.	In the configuration editor hierarchy, select Snmp .	From the top of the configuration hierarchy, enter <code>edit snmp</code>
Configure the system contact information (such as a name and phone number).	In the Contact box, type the contact information as a free-form text string.	Set the contact information: <code>set contact "contact-information"</code>
Configure the system location information (such as a lab name and a rack name).	In the Location box, type the location information as a free-form text string.	Set the location information: <code>set location "location-information"</code>

Table 29: Configuring Basic System Identification (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Configure the system description (<i>J4300 with 4 PIMs</i> , for example).	In the Description box, type the description information as a free-form text string.	Set the description information: set description "description-information"
Configure a system name to override the system hostname defined in the <i>J-series Services Router Getting Started Guide</i> .	In the System Name box, type the system name as a free-form text string.	Set the system name: set name name
Configure the local engine ID to use the MAC address of fe-0/0/0 as the engine ID suffix.	<ol style="list-style-type: none"> 1. Select Engine id. 2. In the Engine id choice box, select Use mac address from the list. 3. Click OK. 	Set the engine ID to use the MAC address: set engine-id use-mac-address

Configuring SNMP Agents and Communities (Required)

To configure the SNMP agent, you must enable and authorize the network management system access to the Services Router, by configuring one or more communities. Each community has a community name, an authorization, which determines the kind of access the network management system has to the router, and, when applicable, a list of valid clients that can access the router.

To configure SNMP communities:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. To configure SNMP communities, perform the configuration tasks described in Table 30.
3. If you are finished configuring the network, commit the configuration.
4. To check the configuration, see “Verifying the SNMP Configuration” on page 59.

Table 30: Configuring SNMP Agents and Communities

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the SNMP level in the configuration hierarchy.	In the configuration editor hierarchy, select Snmp .	From the top of the configuration hierarchy, enter edit snmp

Table 30: Configuring SNMP Agents and Communities (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Create and name a community.	<ol style="list-style-type: none"> Next to Community, click Add new entry. In the Community box, type the name of the community as a free-form text string. 	<p>Create a community:</p> <pre>set community community-name</pre>
Grant read-write access to the community.	In the Authorization box, select read-write from the list.	<p>Set the authorization to read-write:</p> <pre>set community community-name authorization read-write</pre>
Allow community access to a client at a particular IP address—for example, at IP address 10.10.10.10.	<ol style="list-style-type: none"> Next to Clients, click Add new entry. In the Prefix box, type the IP address, in dotted decimal notation. Click OK. 	<p>Configure client access for the IP address 10.10.10.10:</p> <pre>set community community-name clients 10.10.10.10</pre>
Allow community access to a group of clients—for example, all addresses within the 10.10.10.0/24 prefix, except those within the 10.10.10.10/29 prefix.	<ol style="list-style-type: none"> Next to Clients, click Add new entry. In the Prefix box, type the IP address prefix 10.10.10.0/24, and click OK. Next to Clients, click Add new entry. In the Prefix box, type the IP address prefix 10.10.10.10/29. Select the Restrict check box. Click OK. 	<ol style="list-style-type: none"> Configure client access for the IP address 10.10.10.0/24: <pre>set community community-name clients 10.10.10.0/24</pre> Configure client access to restrict the IP addresses 10.10.10.10/29: <pre>set community community-name clients 10.10.10.10/29 restrict</pre>

Managing SNMP Trap Groups (Required)

SNMP traps are unsolicited notifications that are generated by conditions on the Services Router. When events trigger a trap, a notification is sent to the configured clients for that particular trap group. To manage a trap group, you must create the group, specify the types of traps that are included in the group, and define one or more targets to receive the trap notifications.

To configure SNMP trap groups:

- Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
- To configure SNMP trap groups, perform the configuration tasks described in Table 31.

3. If you are finished configuring the network, commit the configuration.
4. To check the configuration, see “Verifying the SNMP Configuration” on page 59.

Table 31: Configuring SNMP Trap Groups

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the SNMP level in the configuration hierarchy.	In the configuration editor hierarchy, select Snmp .	From the top of the configuration hierarchy, enter <code>edit snmp</code>
Create a trap group.	<ol style="list-style-type: none"> 1. Next to Trap group, click Add new entry. 2. In the Group name box, type the name of the group as a free-form text string. 	Create a community: <code>set trap-group trap-group-name</code>
Configure the trap group to send all trap notifications to a target IP address—for example, to the IP address 192.174.6.6.	<ol style="list-style-type: none"> 1. Next to Targets, click Add new entry. 2. In the Target box, type the IP address 192.174.6.6, and click OK. 	Set the trap-group target to 192.174.6.6: <code>set trap-group trap-group-name targets 192.174.6.6</code>
Configure the trap group to generate SNMP notifications on authentication failures, environment alarms, and changes in link state for any of the interfaces.	<ol style="list-style-type: none"> 1. Click Categories. 2. Select the Authentication, Chassis, and Link check boxes. 3. Click OK. 	Configure the trap group categories: <code>set trap-group trap-group-name categories authentication chassis link</code>

Controlling Access to MIBs (Optional)

By default, an SNMP community is granted access to all MIBs. To control the MIBs to which a particular community has access, configure SNMP views that include the MIBs you want to explicitly grant or deny access to.

To configure SNMP views:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. To configure SNMP views, perform the configuration tasks described in Table 32.
3. If you are finished configuring the network, commit the configuration.
4. To check the configuration, see “Verifying the SNMP Configuration” on page 59.

Table 32: Configuring SNMP Views

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the SNMP level in the configuration hierarchy.	In the configuration editor hierarchy, select Snmp .	From the top of the configuration hierarchy, enter: <code>edit snmp</code>
Create a view.	<ol style="list-style-type: none"> Next to View, click Add new entry. In the Name box, type the name of the view as a free-form text string. 	Create a view: <code>set view view-name</code>
Configure the view to include a MIB—for example, pingMIB .	<ol style="list-style-type: none"> Next to Oid, click Add new entry. In the Name box, type the OID of the pingMIB, in either dotted integer or subtree name format. In the View action box, select include from the list, and click OK. 	Set the pingMIB OID value and mark it for inclusion: <code>set view view-name oid 1.3.6.1.2.1.80 include</code>
Configure the view to exclude a MIB—for example, jnxPingMIB .	<ol style="list-style-type: none"> Next to Oid, click Add new entry. In the Name box, type the OID of the jnxPingMIB, in either dotted integer or subtree name format. In the View action box, select exclude from the list, and click OK twice. 	Set the jnxPingMIB OID value and mark it for exclusion: <code>set view view-name oid jnxPingMIB exclude</code>
Associate the view with a community.	<ol style="list-style-type: none"> On the Snmp page, under Community, click the name of the community to which you want to apply the view. In the View box, type the view name. Click OK. 	Set the community view: <code>set community community-name view view-name</code>

Verifying the SNMP Configuration

To verify the SNMP configuration, perform the following verification task.

Verifying SNMP Agent Configuration

Purpose	Verify that SNMP is running and that requests and traps are being properly transmitted.
Action	From the CLI, enter the <code>show snmp statistics</code> command.
Sample Output	<pre>user@host> show snmp statistics SNMP statistics:</pre>

```

Input:
  Packets: 246213, Bad versions: 12, Bad community names: 12,
  Bad community uses: 0, ASN parse errors: 96,
  Too bigs: 0, No such names: 0, Bad values: 0,
  Read onlys: 0, General errors: 0,
  Total request varbinds: 227084, Total set varbinds: 67,
  Get requests: 44942, Get nexts: 190371, Set requests: 10712,
  Get responses: 0, Traps: 0,
  Silent drops: 0, Proxy drops: 0, Commit pending drops: 0,
  Throttle drops: 0,
V3 Input:
  Unknown security models: 0, Invalid messages: 0
  Unknown pdu handlers: 0, Unavailable contexts: 0
  Unknown contexts: 0, Unsupported security levels: 1
  Not in time windows: 0, Unknown user names: 0
  Unknown engine ids: 44, Wrong digests: 23, Decryption errors: 0
Output:
  Packets: 246093, Too bigs: 0, No such names: 31561,
  Bad values: 0, General errors: 2,
  Get requests: 0, Get nexts: 0, Set requests: 0,
  Get responses: 246025, Traps: 0

```

What It Means The output shows a list of the SNMP statistics, including details about the number and types of packets transmitted. Verify the following information:

- The number of requests and traps is increasing as expected with the SNMP client configuration.
- Under **Bad community names**, the number of bad (invalid) communities is not increasing. A sharp increase in the number of invalid community names generally means that one or more community strings are configured incorrectly.

For more information about `show snmp statistics`, see the *JUNOS System Basics and Services Command Reference*.

Chapter 4

Configuring the DHCP Server

A Dynamic Host Configuration Protocol (DHCP) server can automatically allocate IP addresses and also deliver configuration settings to client hosts on a subnet. DHCP is particularly useful for managing a pool of IP addresses among hosts. An IP address can be leased to a host for a limited period of time, allowing the DHCP server to share a limited number of IP addresses among a group of hosts that do not need permanent IP addresses.

The Services Router acts as the DHCP server, providing IP addresses and settings to hosts, such as PCs, that are connected to router interfaces. The DHCP server is compatible with the DHCP servers of other vendors on the network.



NOTE: Currently, the DHCP server does not support IPv6 address assignment, user class-specific configuration, DHCP failover protocol, or dynamic Domain Name System (DNS) updates. You cannot use DHCP for virtual private network (VPN) connections.

You can use either the J-Web configuration editor or CLI configuration editor to configure the DHCP server.

This chapter contains the following topics:

- DHCP Terms on page 61
- DHCP Overview on page 62
- Before You Begin on page 64
- Configuring the DHCP Server with Quick Configuration on page 64
- Configuring the DHCP Server with a Configuration Editor on page 70
- Verifying a DHCP Server Configuration on page 73

DHCP Terms

Before configuring the DHCP server on J-series Services Routers, become familiar with the terms defined in Table 33.

Table 33: DHCP Terms

Term	Definition
binding	Collection of configuration parameters, including at least an IP address, assigned by a DHCP server to a DHCP client. A binding can be dynamic (temporary) or static (permanent). Bindings are stored in the DHCP server's binding database.
conflict	Problem that occurs when an address within the IP address pool is being used by a host that does not have an associated binding in the DHCP server's database. Addresses with conflicts are removed from the pool and logged in a conflicts list until you clear the list.
DHCP client	Host that uses DHCP to obtain an IP address and configuration settings.
DHCP options	Configuration settings sent within a DHCP message from a DHCP server to a DHCP client. For a list of DHCP options, see RFC 2132, <i>DHCP Options and BOOTP Vendor Extensions</i> .
DHCP server	Host that provides an IP address and configuration settings to a DHCP client. The Services Router is a DHCP server.
Dynamic Host Configuration Protocol (DHCP)	Configuration management protocol you can use to supervise and automatically distribute IP addresses and deliver configuration settings to client hosts from a central DHCP server. An extension of BOOTP, DHCP is defined in RFC 2131, <i>Dynamic Host Configuration Protocol (DHCP)</i> .
gateway router	Router that passes DHCP messages between DHCP clients and DHCP servers. A gateway router is sometimes referred to as a relay agent.
IP address pool	Collection of IP addresses maintained by the DHCP server for assignment to DHCP clients. The address pool is associated with a subnet on either a logical or physical interface.
lease	Period of time during which an IP address is allocated, or bound, to a DHCP client. A lease can be temporary (dynamic binding) or permanent (static binding).
router solicitation address	IP address to which a DHCP client can transmit router solicitation requests.
Windows Name Service (WINS) server	Server running the Microsoft Windows name resolution service for network basic input/output system (NetBIOS) names. WINS is used by hosts running NetBIOS over TCP/IP (NetBT) to register NetBIOS names and to resolve NetBIOS names to IP addresses.

DHCP Overview

DHCP is based on BOOTP, a bootstrap protocol that allows a client to discover its own IP address, the IP address of a server host, and the name of a bootstrap file. DHCP servers can handle requests from BOOTP clients, but provide additional capabilities beyond BOOTP, such as the automatic allocation of reusable IP addresses and additional configuration options.



NOTE: You cannot configure the Services Router as both a DHCP server and a BOOTP relay agent.

DHCP provides two primary functions:

- Allocate temporary or permanent IP addresses to clients.
- Store, manage, and provide client configuration parameters.

As a DHCP server, a Services Router can provide temporary IP addresses from an IP address pool to all clients on a specified subnet, a process known as dynamic binding. Services Routers can also perform static binding, assigning permanent IP addresses to specific clients based on their media access control (MAC) addresses. Static bindings take precedence over dynamic bindings.

DHCP Options

In addition to its primary DHCP functions, you can also configure the Services Router to send configuration settings like the following to clients through DHCP:

- IP address of the DHCP server (Services Router).
- List of Domain Name System (DNS) and NetBIOS servers
- List of gateway routers
- IP address of the boot server and the filename of the boot file to use
- DHCP options defined in RFC 2132, *DHCP Options and BOOTP Vendor Extensions*

Compatibility with Autoinstallation

Services Router DHCP server functions are compatible with the autoinstallation feature. The DHCP server automatically checks any autoinstallation settings for conflicts and gives the autoinstallation settings priority over corresponding DHCP settings. For example, an IP address set by autoinstallation takes precedence over an IP address set by the DHCP server.

Conflict Detection and Resolution

A client that receives an IP address from the Services Router operating as a DHCP server performs a series of Address Resolution Protocol (ARP) tests to verify that the address is available and no conflicts exist. If the client detects an address conflict, it informs the DHCP server about the conflict and can request another IP address from the DHCP server.

The Services Router maintains a log of all client-detected conflicts and removes addresses with conflicts from the DHCP address pool. To display the conflicts list, you use the `show system services dhcp conflict` command. The addresses in the conflicts list remain excluded until you use the `clear system services dhcp conflict` command to manually clear the list.

Interface Restrictions

The Services Router supports DHCP client requests received on Fast Ethernet interfaces only. However, DHCP requests received from a relay agent are supported on all interface types.

DHCP is not supported on interfaces that are part of a virtual private network (VPN).

Before You Begin

Before you begin configuring the Services Router as a DHCP server, complete the following tasks:


- Determine the IP address pools and the lease durations to use for each subnet.
- Obtain the MAC addresses of the clients that require permanent IP addresses. Determine the IP addresses to use for these clients.
- List the IP addresses that are available for the servers and routers on your network—DNS, NetBIOS servers, boot servers, and gateway routers, for example.
- Determine the DHCP options required by the subnets and clients in your network.

Configuring the DHCP Server with Quick Configuration

The DHCP Quick Configuration pages allow you to configure DHCP pools for subnets and static bindings for DHCP clients. If DHCP pools or static bindings are already configured, you can use the Configure Global DHCP Parameters Quick Configuration page to add settings for these pools and static bindings. Settings that have been previously configured for DHCP pools or static bindings are not overridden when you use the Configure Global DHCP Parameters Quick Configuration page.

Figure 10 through Figure 12 show the DHCP Quick Configuration pages.

Figure 10: DHCP Quick Configuration Main Page



ROUTER - J2300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor **Configuration** **Diagnose** **Manage** **Alarms**

▼ **Quick Configuration**

- Set Up
- Secure Access
- Interfaces
- Users
- SNMP
- Routing
- Firewall/NAT
- DHCP**
- IPSec Tunnels
- Realtime Performance Monitoring

► **View and Edit**

► **History**

► **Rescue**

[Configuration](#) > [Quick Configuration](#) > [DHCP](#)

Quick Configuration

DHCP

Global DHCP Parameters

Use the button below to configure global DHCP server parameters. These parameters will be inherited by any pools or static bindings that you set up. This option is useful if you have many pools or static bindings and wish to only specify this shared information once.

Configure Global DHCP Parameters...

DHCP Pools


DHCP is not configured to listen on any subnets.

Add...

DHCP Static Binding

DHCP is not configured to listen for any MAC addresses.

Figure 11: DHCP Quick Configuration Pool Page



ROUTER - J2300

Logged in as: **regress**
[Help](#) [About](#) [Logout](#)

Monitor
Configuration
Diagnose
Manage
Alarms

▼ Quick Configuration

Set Up
 Secure Access
 Interfaces
 Users
 SNMP
 Routing
 Firewall/NAT

DHCP

 IPSec Tunnels
 Realtime Performance Monitoring

► View and Edit
 ► History
 ► Rescue

Quick Configuration

DHCP

DHCP Pool Information

Lease Time

* DHCP Subnet

* Address Range (Low)

* Address Range (High)

Exclude Addresses

Add
Delete

Maximum

Default

Server Information

Boot Options

Server Identifier

Boot File

Figure 12: DHCP Quick Configuration Static Binding Page

Juniper
NETWORKS

ROUTER - J2300

Logged in as: regress

[Help](#) [About](#) [Logout](#)

Monitor Configuration Diagnose Manage Alarms

- ▼ Quick Configuration
 - Set Up
 - Secure Access
 - Interfaces
 - Users
 - SNMP
 - Routing
 - Firewall/NAT
 - DHCP**
 - IPSec Tunnels
 - Realtime Performance Monitoring
- View and Edit
- History
- Rescue

Quick Configuration

DHCP

DHCP Static Binding Information		Lease Time
* DHCP MAC Address	<input type="text"/>	? Maximum Lease Time
* Fixed IP Address	<input type="text"/>	? Default Lease Time
	<input type="text"/> ?	
	<input type="text"/>	
	<input type="button" value="Add"/> <input type="button" value="Delete"/>	
Host Name	<input type="text"/>	?
Client Identifier	<input type="text"/>	?

Server Information	Boot Option
Server Identifier	<input type="text"/> ? Boot File

To configure the DHCP server with Quick Configuration:

1. In the J-Web interface, select **Configuration > DHCP**.
2. Access a DHCP Quick Configuration page:
 - To configure a DHCP pool for a subnet, click **Add** in the DHCP Pools box.
 - To configure a static binding for a DHCP client, click **Add** in the DHCP Static Binding box.
 - To globally configure settings for existing DHCP pools and static bindings, click **Configure Global DHCP Parameters**.

3. Enter information into the DHCP Quick Configuration pages, as described in Table 34.
4. Click one of the following buttons on the DHCP Quick Configuration page:
 - To apply the configuration and return to the Quick Configuration page, click **OK**.
 - To cancel your entries and return to the Quick Configuration page, click **Cancel**.
5. Go on to one of the following procedures:
 - To display the configuration, see “Displaying a DHCP Server Configuration” on page 73.
 - To verify DHCP operation, see “Verifying a DHCP Server Configuration” on page 73.

Table 34: DHCP Server Quick Configuration Pages Summary

Field	Function	Your Action
DHCP Pool Information		
DHCP Subnet (required)	Specifies the subnet on which DHCP is configured.	Type an IP address prefix.
Address Range (Low) (required)	Specifies the lowest address in the IP address pool range.	Type an IP address that is part of the subnet specified in DHCP Subnet.
Address Range (High) (required)	Specifies the highest address in the IP address pool range.	Type an IP address that is part of the subnet specified in DHCP Subnet. This address must be greater than the address specified in Address Range (Low).
Exclude Addresses	Specifies addresses to exclude from the IP address pool.	Do either of the following: <ul style="list-style-type: none"> ■ To add an excluded address, type the address next to the Add button, and click Add. ■ To delete an excluded address, select the address in the Exclude Addresses box, and click Delete.
Lease Time		
Maximum Lease Time (Seconds)	Specifies the maximum length of time a client can hold a lease. (Dynamic BOOTP lease lengths can exceed this maximum time.)	Type a number between 60 and 4,294,967,295 (seconds). You can also type infinite to specify a lease that never expires.
Default Lease Time (Seconds)	Specifies the length of time a client can hold a lease, for clients that do not request a specific lease length.	Type a number between 60 and 2,147,483,647 (seconds). You can also type infinite to specify a lease that never expires.
Server Information		

Table 34: DHCP Server Quick Configuration Pages Summary (continued)

Field	Function	Your Action
Server Identifier	Specifies the IP address of the DHCP server reported to a client.	Type the IP address of the Services Router. If you do not specify a server identifier, the primary address of the interface on which the DHCP exchange occurs is used.
Domain Name	Specifies the domain name that clients must use to resolve hostnames.	Type the name of the domain.
Domain Search	Specifies the order—from top to bottom—in which clients must append domain names when resolving hostnames using DNS.	Do either of the following: <ul style="list-style-type: none"> ■ To add a domain name, type the name next to the Add button, and click Add. ■ To delete a domain name, select the name in the Domain Search box, and click Delete.
DNS Name Servers	Defines a list of DNS servers the client can use, in order of preference—from top to bottom.	Do either of the following: <ul style="list-style-type: none"> ■ To add a DNS server, type an IP address next to the Add button, and click Add. ■ To remove a DNS server, select the IP address in the DNS Name Servers box, and click Delete.
Gateway Routers	Defines a list of relay agents on the subnet, in order of preference—from top to bottom.	Do either of the following: <ul style="list-style-type: none"> ■ To add a relay agent, type an IP address next to the Add button, and click Add. ■ To remove a relay agent, select the IP address in the Gateway Routers box, and click Delete.
WINS Servers	Defines a list of NetBIOS name servers, in order of preference—from top to bottom.	Do either of the following: <ul style="list-style-type: none"> ■ To add a NetBIOS name server, type an IP address next to the Add button, and click Add. ■ To remove a NetBIOS name server, select the IP address in the WINS Servers box, and click Delete.
Boot Options		
Boot File	Specifies the path and filename of the initial boot file to be used by the client.	Type a path and filename.
Boot Server	Specifies the TFTP server that provides the initial boot file to the client.	Type the IP address or hostname of the TFTP server.
DHCP Static Binding Information		
DHCP MAC Address (required)	Specifies the MAC address of the client to be permanently assigned a static IP address.	Type the hexadecimal MAC address of the client.

Table 34: DHCP Server Quick Configuration Pages Summary (continued)

Field	Function	Your Action
Fixed IP Addresses (required)	Defines a list of IP addresses permanently assigned to the client. A static binding must have at least one fixed address assigned to it, but multiple addresses are also allowed.	Do either of the following: <ul style="list-style-type: none"> ■ To add an IP address, type it next to the Add button, and click Add. ■ To remove an IP address, select it in the Fixed IP Addresses box, and click Delete.
Host Name	Specifies the name of the client used in DHCP messages exchanged between the server and the client. The name must be unique to the client within the subnet on which the client resides.	Type a client hostname.
Client Identifier	Specifies the name of the client used by the DHCP server to index its database of address bindings. The name must be unique to the client within the subnet on which the client resides.	Type a client identifier in string form.
Hexadecimal Client Identifier	Specifies the name of the client, in hexadecimal, used by the DHCP server to index its database of address bindings. The name must be unique to the client within the subnet on which the client resides.	Type a client identifier in hexadecimal form.

Configuring the DHCP Server with a Configuration Editor

A typical DHCP server configuration provides the following configuration settings for a particular subnet on a Services Router interface:

- An IP address pool, with one address excluded from the pool.
- Default and maximum lease times.
- Domain search suffixes. These suffixes specify the domain search list used by a client when resolving hostnames with DNS. See RFC 3397, *Dynamic Host Configuration Protocol (DHCP) Domain Search Option*, for more information.
- A DNS name server.
- A DHCP option—Router solicitation address option (option 32). The IP address excluded from the IP address pool is reserved for this option.

In addition, the DHCP server might assign a static address to at least one client on the subnet. Table 35 provides the settings and values for the sample DHCP server configuration used in this section.

Table 35: Sample DHCP Server Configuration Settings

Settings	Sample Value or Values
DHCP Subnet Configuration	
Address pool subnet address	192.168.2.0/24
High address in the pool range	192.168.2.254
Low address in the pool range	192.168.2.2
Address pool default lease time, in seconds	1,209,600 (14 days)
Address pool maximum lease time, in seconds	2,419,200 (28 days)
Domain search suffixes	mycompany.net mylab.net
Address to exclude from the pool	192.168.2.33
DNS server address	192.168.10.2
Identifier code for router solicitation address option	32
Type choice for router solicitation address option	Ip address
IP address for router solicitation address option	192.168.2.33
DHCP MAC Address Configuration	
Static binding MAC address	01:03:05:07:09:0B
Fixed address	192.168.2.50

To configure the Services Router as a DHCP server for a subnet and a single client:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 36.
3. If you are finished configuring the router, commit the configuration.
4. To verify DHCP server configuration and operation, see “Verifying a DHCP Server Configuration” on page 73.

Table 36: Configuring the DHCP Server

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Dhcp server level in the configuration hierarchy.	In the configuration editor hierarchy, select System > Services > Dhcp server .	From the top of the configuration hierarchy, enter edit system services dhcp

Table 36: Configuring the DHCP Server (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Define the IP address pool.	<ol style="list-style-type: none"> Next to Pool, click Add new entry. In the Subnet address box, type 192.168.2.0/24. Next to Address range, select the check box. Next to Address range, click Configure. In the High box, type 192.168.2.254. In the Low box, type 192.168.2.2. Click OK. 	<p>Set the IP address pool range:</p> <pre>set pool 192.168.2.0/24 address-range low 192.168.2.2 high 192.168.2.254</pre>
Define the default and maximum lease times, in seconds.	<ol style="list-style-type: none"> From the Default lease time list, select Enter Specific Value. In the Length box, type 1209600. From the Maximum lease time list, select Enter Specific Value. Next to Maximum lease time, type 2419200. 	<p>Set the default and maximum lease times:</p> <pre>set pool 192.168.2.0/24 default-lease-time 1209600 maximum-lease-time 2419200</pre>
Define the domain search suffixes to be used by the clients.	<ol style="list-style-type: none"> Next to Domain search, click Add new entry. In the Suffix box, type mycompany.net. Click OK. Next to Domain search, click Add new entry. In the Suffix box, type mylab.net. Click OK. 	<p>Set the domain search suffixes:</p> <pre>set pool 192.168.2.0/24 domain-search mycompany.net set pool 192.168.2.0/24 domain-search mylab.net</pre>
Exclude addresses from the IP address pool.	<ol style="list-style-type: none"> Next to Exclude address, click Add new entry. In the Address box, type 192.168.2.33. Click OK. 	<p>Set the address to exclude from the IP address pool:</p> <pre>set pool 192.168.2.0/24 exclude-address 192.168.2.33</pre>
Define a DNS server.	<ol style="list-style-type: none"> Next to Name server, click Add new entry. In the Address box, type 192.168.10.2. Click OK. 	<p>Set the DNS server IP address:</p> <pre>set pool 192.168.2.0/24 name-server 192.168.10.2</pre>

Table 36: Configuring the DHCP Server (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Define DHCP option 32—the router solicitation address option.	<ol style="list-style-type: none"> Next to Option, click Add new entry. In the Option identifier code box, type 32. From the Option type choice list, select Ip address. In the Ip address box, type 192.168.2.33. Click OK twice. 	Set the router solicitation IP address: <pre>set pool 192.168.2.0/24 option 32 ip-address 192.168.2.33</pre>
Assign a static IP address of 192.168.2.50 to MAC address 01:03:05:07:09:0B.	<ol style="list-style-type: none"> Next to Static binding, click Add new entry. In the Mac address box, type 01:03:05:07:09:0B. Next to Fixed address, click Add new entry. In the Address box, type 192.168.2.50. Click OK until you return to the Configuration page. 	Associate a fixed IP address with the MAC address of the client: <pre>set static-binding 01:03:05:07:09:0B fixed-address 192.168.2.50</pre>

Verifying a DHCP Server Configuration

To verify a DHCP server configuration, perform the following tasks:

- Displaying a DHCP Server Configuration on page 73
- Verifying the DHCP Binding Database on page 74
- Verifying DHCP Server Operation on page 75
- Displaying DHCP Statistics on page 77

Displaying a DHCP Server Configuration

Purpose Verify the configuration of a DHCP server.

Action From the J-Web interface, select **Configuration > View and Edit > View Configuration Text**. Alternatively, from configuration mode in the CLI, enter the show system services dhcp command from the top level.

You can also view the IP address pool from the CLI in operational mode by entering the show system services dhcp pool command.

Sample Output [edit]

```

user@host# show system services dhcp
pool 192.168.2.0/24 {
    address-range low 192.168.2.2 high 192.168.2.254;
    exclude-address {
        192.168.2.33;
    }
    maximum-lease-time 2419200;
    default-lease-time 1209600;
    name-server {
        192.168.10.2;
    }
    domain-search {
        mycompany.net;
        mylab.net;
    }
    option 16 ip-address 192.168.2.33;
}
static-binding 01.03.05.07.09.0b {
    fixed-address {
        192.168.2.50;
    }
}

```

What It Means Verify that the output shows the intended configuration of the DHCP server. For more information about the format of a configuration file, see the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

Verifying the DHCP Binding Database

Purpose Verify that the DHCP binding database reflects your DHCP server configuration.

Action From operational mode in the CLI, to display all active bindings in the database, enter the `show system services dhcp binding` command. To display all bindings in the database, including their current binding state, enter the `show system services dhcp binding detail` command. To display more information about a client, including its DHCP options, enter the `show system services dhcp binding ip-address detail` command, replacing *ip-address* with the IP address of the client.

The DHCP binding database resulting from the configuration defined in “Configuring the DHCP Server with a Configuration Editor” on page 70 is displayed in the following sample output.

To clear the DHCP binding database, enter the `clear system services dhcp binding` command. To remove a specific entry from the DHCP binding database, enter the `clear system services dhcp binding ip-address` command, replacing *ip-address* with the IP address of the client.

You can also use the J-Web interface to view information in the DHCP binding database. For more information, see “Monitoring DHCP” on page 130.

Sample Output `user@host> show system services dhcp binding`

IP Address	Hardware Address	Type	Lease expires at
------------	------------------	------	------------------

```
192.168.2.2 02:04:06:08:0A:0C dynamic 2005-02-07 8:48:59 PDT
192.168.2.50 01:03:05:07:09:0B static never
```

```
user@host> show system services dhcp binding 192.168.2.2 detail
```

```
IP address      192.168.2.2
Hardware address 02:04:06:08:0A:0C
Pool            192.168.2.0/24
Request received on fe-0/0/0
```

```
Lease information:
```

```
Type           DHCP
Obtained at     2005-01-24 8:48:59 PDT
Expires at      2005-02-07 8:48:59 PDT
State           active
```

```
DHCP options:
```

```
Name: domain-name, Value: mycompany.net mylab.net
Name: name-server, Value: 192.168.10.2
Code: 16, Type: ip-address, Value: 192.168.2.33
```

```
user@host> show system services dhcp conflict
```

What It Means

Verify the following information:

- For each dynamic binding, verify that the IP address is within the range of the configured IP address pool. Under **Lease Expires**, verify that the difference between the date and time when the lease expires and the current date and time is less than the maximum configured lease time.
- For each static binding, verify that the IP address corresponds to the MAC address displayed under **Hardware Address** (as defined in the **static-binding** statement in the configuration). Under **Lease Expires**, verify that the lease expiration is **never**.
- In the output displayed by the `show system services dhcp binding ip-address detail` command, verify that the options under **DHCP options** are correct for the subnet.
- Verify that the `show system services dhcp conflict` command does not display any conflicts.

Verifying DHCP Server Operation

Purpose Verify that the DHCP server is operating as configured.

Action Take the following actions:

- Use the `ping` command to verify that a client responds to ping packets containing the destination IP address assigned by the Services Router.
- Display the IP configuration on the client. For example, on a PC running Microsoft Windows, enter `ipconfig /all` at the command prompt to display the PC's IP configuration.

Sample Output

```
user@host> ping 192.168.2.2
```

```
PING 192.168.2.2 (192.168.2.2): 56 data bytes
64 bytes from 192.168.2.2: icmp_seq=0 ttl=255 time=8.856 ms
64 bytes from 192.168.2.2: icmp_seq=1 ttl=255 time=11.543 ms
64 bytes from 192.168.2.2: icmp_seq=2 ttl=255 time=10.315 ms
...
```

```
C:\Documents and Settings\user> ipconfig /all
```

```
Windows 2000 IP Configuration
```

```
Host Name . . . . . : my-pc
Primary DNS Suffix . . . . . : mycompany.net
Node Type . . . . . : Hybrid
IP Routing Enabled. . . . . : No
WINS Proxy Enabled. . . . . : No
DNS Suffix Search List. . . . . : mycompany.net
                                   mylab.net
```

```
Ethernet adapter Local Area Connection 2:
```

```
Connection-specific DNS Suffix . : mycompany.net mylab.net
Description . . . . . : 10/100 LAN Fast Ethernet Card
Physical Address. . . . . : 02-04-06-08-0A-0C
DHCP Enabled. . . . . : Yes
Autoconfiguration Enabled . . . . : Yes
IP Address. . . . . : 192.168.2.2
Subnet Mask . . . . . : 255.255.254.0
Default Gateway . . . . . : 192.168.10.3
DHCP Server . . . . . : 192.168.2.1
DNS Servers . . . . . : 192.168.10.2
Primary WINS Server . . . . . : 192.168.10.4
Secondary WINS Server . . . . . : 192.168.10.5
Lease Obtained. . . . . : Monday, January 24, 2005 8:48:59 AM
Lease Expires . . . . . : Monday, February 7, 2005 8:48:59 AM
```

What It Means

Verify the following:

- The client returns a ping response.

For information about using the J-Web interface to ping a host, see “Using the J-Web Ping Host Tool” on page 146. For more information about the ping command, see “Pinging Hosts from the CLI” on page 160 or the *JUNOS System Basics and Services Command Reference*.

- The client IP configuration displayed contains the configured values. For example, for the DHCP configuration in “Configuring the DHCP Server with a Configuration Editor” on page 70, you can verify the following settings:
 - DNS Suffix Search List is correct.
 - IP address is within the IP address pool you configured.
 - DHCP Server is the primary IP address of the Services Router interface on which the DHCP message exchange occurs. If you include the

server-identifier statement in your configuration, the DHCP server IP address specified in this statement is displayed.

- Lease Obtained and Lease Expires times are correct.

The `ipconfig` command also displays other DHCP client settings that can be configured on the Services Router, including the client's hostname, default gateways, and WINS servers.

Displaying DHCP Statistics

Purpose	Display DHCP statistics, including lease times, packets dropped, and DHCP and BOOTP messages received and sent, to verify normal operation.
Action	Enter the <code>show system services dhcp statistics</code> command to display the DHCP statistics.
Sample Output	<pre> user@host> show system services dhcp statistics Packets dropped: Total 0 Messages received: BOOTREQUEST 0 DHCPDECLINE 0 DHCPDISCOVER 0 DHCPINFORM 0 DHCPRELEASE 0 DHCPREQUEST 78 Messages sent: BOOTREPLY 0 DHCPOFFER 0 DHCPACK 78 DHCPNAK 0 </pre>
What It Means	<p>Verify the following:</p> <ul style="list-style-type: none"> ■ The default settings displayed are consistent with your DHCP server configuration. ■ The number of dropped packets and errors is small. ■ DHCPREQUEST messages have been received and DHCPACK messages have been sent.

Chapter 5

Configuring and Monitoring Alarms

Alarms on a J-series Services Router alert you to conditions on a network interface, on the router chassis, or in the system software that might prevent the router from operating normally. You can set the conditions that trigger alarms on an interface. Chassis and system alarm conditions are preset.

An active alarm lights the ALARM LED on the front panel of the router. You can monitor active alarms from the J-Web interface or the CLI.

This chapter contains the following topics. For more information about alarms, see the *JUNOS System Basics Configuration Guide*.

- Alarm Terms on page 79
- Alarm Overview on page 80
- Before You Begin on page 86
- Configuring Alarms with a Configuration Editor on page 86
- Checking Active Alarms on page 88
- Verifying the Alarms Configuration on page 90

Alarm Terms

Before configuring and monitoring alarms on Services Routers, become familiar with the terms defined in Table 37.

Table 37: Alarm Terms

Term	Definition
alarm	Signal alerting you to conditions that might prevent normal operation. On a Services Router, the alarm signal is the yellow ALARM LED lit on the front of the chassis.
alarm condition	Failure event that triggers an alarm.
alarm severity	Seriousness of the alarm. The level of severity can be either major (red) or minor (yellow).
chassis alarm	Predefined alarm triggered by a physical condition on the router such as a power supply failure, excessive component temperature, or media failure.

Table 37: Alarm Terms (continued)

Term	Definition
interface alarm	<p>Alarm triggered by the state of a physical link on a fixed or installed Physical Interface Module (PIM), such as a link failure or a missing signal.</p> <p>Interface alarms are triggered by conditions on a T1 (DS1), Fast Ethernet, serial, or T3 (DS3) physical interface or by conditions on the sp-0/0/0 adaptive services interface for stateful firewall filter, Network Address Translation (NAT), intrusion detection service (IDS), or IP Security (IPSec) services.</p> <p>To enable an interface alarm, you must explicitly set an alarm condition.</p>
system alarm	Predefined alarm triggered by a missing rescue configuration or failure to install a license for a licensed software feature.

Alarm Overview

Services Router alarms warn you about conditions that can prevent the router from operating normally.

When an alarm condition triggers an alarm, the Services Router lights the yellow (amber) ALARM LED on the front panel. When the condition is corrected, the light turns off.



NOTE: The ALARM LED on the Services Router lights yellow whether the alarm condition is major (red) or minor (yellow).

This section contains the following topics:

- Alarm Types on page 80
- Alarm Severity on page 81
- Alarm Conditions on page 81

Alarm Types

The Services Router supports three types of alarms:

- Interface alarms indicate a problem in the state of the physical links on fixed or installed PIMs. To enable interface alarms, you must configure them.
- Chassis alarms indicate a failure on the router or one of its component. Chassis alarms are preset and cannot be modified.
- System alarms indicate a missing rescue configuration or software license, where valid. System alarms are preset and cannot be modified, although you can configure them to appear automatically in the J-Web or CLI display.

Alarm Severity

Alarms on a Services Router have two severity levels:

- Major (red)—Indicates a critical situation on the router that has resulted from one of the following conditions. A red alarm condition requires immediate action.
 - One or more hardware components have failed.
 - One or more hardware components have exceeded temperature thresholds.
 - An alarm condition configured on an interface has triggered a critical warning.
- Minor (yellow)—Indicates a noncritical condition on the router that, if left unchecked, might cause an interruption in service or degradation in performance. A yellow alarm condition requires monitoring or maintenance.

A missing rescue configuration or software license generates a yellow system alarm.

Alarm Conditions

To enable alarms on a Services Router interface, you must select an alarm condition and an alarm severity. In contrast, alarm conditions and severity are preconfigured for chassis alarms and system alarms.

This section contains the following topics:

- Interface Alarm Conditions on page 81
- Chassis Alarm Conditions and Corrective Actions on page 84
- System Alarm Conditions and Corrective Actions on page 85

Interface Alarm Conditions

Table 38 lists the interface conditions, sorted by interface type, that you can configure for an alarm. Each alarm condition can be configured to trigger either a major (red) alarm or minor a (yellow) alarm. The corresponding configuration option is included.

For the services stateful firewall filters, NAT, IDS, and IPSec, which operate on an internal adaptive services module within a Services Router, you can configure alarm conditions on the integrated services and services interfaces.

Table 38: Interface Alarm Conditions

Interface	Alarm Condition	Description	Configuration Option
DS1 (T1)	Alarm indication signal	The normal T1 traffic signal contained a defect condition and has been replaced by the AIS. A transmission interruption occurred at the remote endpoint or upstream of the remote endpoint. This all-ones signal is transmitted to prevent consequential downstream failures or alarms.	ais
	Yellow alarm	The remote endpoint is in red alarm failure. This condition is also known as a far end alarm failure.	ylw
Ethernet (Fast Ethernet)	Link is down	The physical link is unavailable.	link-down
Integrated services	Hardware or software failure	On the adaptive services module, either the hardware associated with the module, or the software that drives the module, has failed.	failure
Serial	Clear-to-Send signal absent	The remote endpoint of the serial link is not transmitting a CTS signal. The CTS signal must be present before data can be transmitted across a serial link.	cts-absent
	Data Carrier Detect signal absent	The remote endpoint of the serial link is not transmitting a DCD signal. Because the DCD signal transmits the state of the router, no signal probably indicates that the remote endpoint of the serial link is unavailable.	dcd-absent
	Data Set Ready signal absent	The remote endpoint of the serial link is not transmitting a DSR signal. The DSR signal indicates that the remote endpoint is ready to receive and transmit data across the serial link.	dsr-absent
	Loss of receive clock	The clock signal from the remote endpoint is not present. Serial connections require clock signals to be transmitted from one endpoint and received by the other endpoint of the link.	loss-of-rx-clock
	Loss of transmit clock	The local clock signal is not present. Serial connections require clock signals to be transmitted from one endpoint and received by the other endpoint of the link.	loss-of-tx-clock

Table 38: Interface Alarm Conditions (continued)

Interface	Alarm Condition	Description	Configuration Option
Services	Services module hardware down	A hardware problem has occurred on the Services Router's services module. This error typically means that one or more of the CPUs on the module has failed.	hw-down
	Services link down	The link between the Services Router and its services module is unavailable.	linkdown
	Services module held in reset	The Services Router's services module is stuck in reset mode. If the services module fails to start up five or more times in a row, the services module is held in reset mode. Startup fails when the amount of time from CPU release to CPU halt is less than 300 seconds.	pic-hold-reset
	Services module reset	The Services Router's services module is resetting. The module resets after it crashes or is reset from the CLI, or when it takes longer than 60 seconds to start up.	pic-reset
	Services module software down	A software problem has occurred on the Services Router's services module.	sw-down
E3	Alarm indication signal	The normal E3 traffic signal contained a defect condition and has been replaced by the AIS. A transmission interruption occurred at the remote endpoint or upstream of the remote endpoint. This all-ones signal is transmitted to prevent consequential downstream failures or alarms.	ais
	Loss of signal	No remote E3 signal is being received at the E3 interface.	los
	Out of frame	An out-of-frame (OOF) condition has existed for 10 seconds. This alarm applies only to E3 interfaces configured in frame mode. The OOF failure is cleared when no OOF or LOS defects have occurred for 20 seconds.	oof
	Remote defect indication	An AIS, LOS, or OOF condition exists. This alarm applies only to E3 interfaces configured in frame mode.	rdi

Table 38: Interface Alarm Conditions (continued)

Interface	Alarm Condition	Description	Configuration Option
T3 (DS3)	Alarm indication signal	The normal T3 traffic signal contained a defect condition and has been replaced by the AIS. A transmission interruption occurred at the remote endpoint or upstream of the remote endpoint. This all-ones signal is transmitted to prevent consequential downstream failures or alarms.	ais
	Excessive number of zeros	The bit stream received from the upstream host has more consecutive zeros than are allowed in a T3 frame.	exz
	Far-end receive failure	The remote endpoint of the connection has failed. A FERF differs from a yellow alarm, because the failure can be any failure, not just an out-of-frame (OOF) or loss-of-signal (LOS) failure.	ferf
	Idle alarm	The Idle signal is being received from the remote endpoint.	idle
	Line code violation	Either the line encoding along the T3 link is corrupted, or a mismatch between the encoding at the local and remote endpoints of a T3 connection occurred.	lcv
	Loss of frame	An out-of-frame (OOF) or loss-of-signal (LOS) condition has existed for 10 seconds. The loss-of-frame (LOF) failure is cleared when no OOF or LOS defects have occurred for 20 seconds. A LOF failure is also called a red failure.	lof
	Loss of signal	No remote T3 signal is being received at the T3 interface.	los
	Phase-locked loop out of lock	The clocking signals for the local and remote endpoints no longer operate in lock-step.	pll
	Yellow alarm	The remote endpoint is in red alarm failure. This condition is also known as a far end alarm failure.	ylw

Chassis Alarm Conditions and Corrective Actions

Table 39 lists chassis components with preset alarms, the conditions that can trigger an alarm, the alarm severity, and the action you take to correct the condition.

Table 39: Chassis Alarm Conditions and Corrective Actions

Component	Alarm Conditions	Corrective Action	Alarm Severity
Alternative boot media	The Services Router boots from an alternative boot device—the removable compact flash disk or the USB storage device.	Typically, the router boots from the primary compact flash disk. If you configured your router to boot from an alternative boot device, ignore this alarm condition. If you did not configure the router to boot from an alternative boot device, contact JTAC. (See “Requesting Support” on page xviii.)	Yellow (minor)
PIM	A PIM has failed. When a PIM fails, it attempts to reboot. If the Routing Engine detects that a PIM is rebooting too often, it shuts down the PIM.	Replace the failed PIM. (See the <i>J-series Services Router Getting Started Guide</i> .)	Red (major)
Routing Engine	An error occurred during the process of reading or writing compact flash.	Reformat the compact flash and install a bootable image. (See “Performing Software Upgrades and Reboots” on page 211.) If this remedy fails, you must replace the failed Routing Engine. To contact JTAC, see “Requesting Support” on page xviii.	Yellow (minor)
	Routing Engine temperature is too warm.	■ Check the room temperature. (See the <i>J-series Services Router Getting Started Guide</i> .)	Yellow (minor)
	Routing Engine temperature is too hot.	■ Check the air flow. (See the <i>J-series Services Router Getting Started Guide</i> .) ■ Check the fans. (See the <i>J-series Services Router Getting Started Guide</i> .) If you must replace a fan or the Routing Engine, contact JTAC. (See “Requesting Support” on page xviii.)	Red (major)
	Routing Engine fan has failed.	Replace the failed fan. To contact JTAC, see “Requesting Support” on page xviii.	Red (major)

System Alarm Conditions and Corrective Actions

Table 40 lists the two preset system alarms, the condition that triggers each alarm, and the action you take to correct the condition.

Table 40: System Alarm Conditions and Corrective Actions

Alarm Type	Alarm Condition	Corrective Action
Configuration	The rescue configuration is not set.	Set the rescue configuration. For instructions, see the <i>J-series Services Router Basic LAN and WAN Access Configuration Guide</i> .
License	<p>You have configured at least one software feature that requires a feature license, but no valid license for the feature is currently installed.</p> <p>NOTE: This alarm indicates that you are in violation of the software license agreement. You must install a valid license key to be in compliance with all agreements.</p>	Install a valid license key. For instructions, see “Installing and Managing J-series Licenses” on page 3.

Before You Begin

Before you begin configuring and monitoring alarms, complete the following tasks:

- Establish basic connectivity. See the *J-series Services Router Getting Started Guide*.
- Configure network interfaces. See the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

Configuring Alarms with a Configuration Editor

To configure interface alarms on a Services Router, you must select the network interface on which to apply an alarm and the condition you to trigger the alarm. For a list of conditions, see “Interface Alarm Conditions” on page 81.

To configure interface alarms:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 41.
3. If you are finished configuring the network, commit the configuration.
4. To verify the alarms configuration, see “Displaying Alarm Configurations” on page 90.
5. To check the status of active alarms, see “Checking Active Alarms” on page 88.

Table 41: Configuring Interface Alarms

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Alarm level in the configuration hierarchy.	In the configuration editor hierarchy, select Chassis > Alarm .	From the top of the configuration hierarchy, enter edit chassis alarm
Configure the system to generate a red interface alarm when a Yellow alarm is detected on a T1 (DS1) link.	<ol style="list-style-type: none"> 1. In the Ds1 field, click Configure. 2. From the the Ylw list, select red. 3. Click OK. 	Enter set ds1 ylw red
Configure the system to generate a red interface alarm when a link down failure is detected on a Fast Ethernet link.	<ol style="list-style-type: none"> 1. In the Ethernet field, click Configure. 2. From the Link down list, select red. 3. Click OK. 	Enter set ethernet link-down red
Configure the system to generate the following interface alarms on a serial link: <ul style="list-style-type: none"> ■ Yellow alarm when no CTS signal is detected ■ Yellow alarm when no DCD signal is detected ■ Red alarm when the receiver clock is not detected ■ Red alarm when the transmission clock is not detected 	<ol style="list-style-type: none"> 1. In the Serial field, click Configure. 2. From the Cts absent list, select yellow. 3. From the Dcd absent list, select yellow. 4. From the Loss of rx clock list, select red. 5. From the Loss of tx clock list, select red. 6. Click OK. 	<ol style="list-style-type: none"> 1. Enter set serial cts-absent yellow 2. Enter set serial dcd-absent yellow 3. Enter set serial loss-of-rx-clock red 4. Enter set serial loss-of-tx-clock red

Table 41: Configuring Interface Alarms (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Configure the system to generate the following interface alarms on a T3 link:	1. In the T3 field, click Configure .	1. Enter
■ Red alarm when the remote endpoint is experiencing a Red failure	2. From the Ylw list, select red .	set t3 ylw red
■ Yellow alarm when the upstream bit stream has more consecutive zeros than are permitted	3. From the Exz list, select yellow .	2. Enter
	4. From the Los list, select red .	set t3 exz yellow
■ Red alarm when there is a loss of signal on the interface	5. Click OK .	3. Enter
		set t3 los red
Configure the system to display active system alarms whenever a user with the login class admin logs in to the router.	1. From the top of the configuration editor hierarchy, select System > Login .	1. Enter
To define login classes, see the <i>JUNOS System Basics Configuration Guide</i> .	2. In the Class field, click Add new entry .	2. Enter
	3. In the Class name field, type admin .	set class admin login-alarms
	4. Select the Login alarms check box.	
	5. Click OK .	

Checking Active Alarms

The alarm information includes alarm type, alarm severity, and a brief description for each active alarm on the Services Router. To view the active alarms, select **Alarms** in the J-Web interface, or enter the following CLI **show** commands:

- show chassis alarms
- show system alarms



NOTE: If a Services Router has active alarms and you have not displayed the View Alarms page, *Alarms* in the task bar appears in red. After you view the alarms, *Alarms* returns to grey. If new alarms become active, *Alarms* is red until you again display the View Alarms page.

Figure 13 shows the View Alarms summary page. Click an alarm in the list of active alarms to display a detailed alarm message.

Figure 13: J-Web View Alarms Summary Page

Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage** / **Alarms**

[Alarms](#) > [View Alarms](#)

View Alarms

View Alarms

Alarm Summary

New?	Received At	Severity	Subject
No	2005-04-11 10:58:59 PDT	Major	fe-5/0/1: Link down
No	2005-04-11 10:46:20 PDT	Minor	Stateful firewall usage requires a license
No	2005-04-11 10:45:36 PDT	Minor	1 T1 port requires a license
No	2005-04-04 10:17:08 PDT	Minor	Rescue configuration is not set

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice.](#)

Table 42 summarizes the output fields on the alarms page.

Table 42: Summary of Key Alarm Output Fields

Field	Values	Additional Information
Alarm Summary		
New?	Viewed status of the alarm—either Yes (a new alarm) or No (a previously viewed alarm).	After you have once displayed the View Alarms page, any new alarms that appear on the page during the same J-Web session are identified as previously viewed.
Received at	Date and time when the alarm condition was detected.	
Severity	Alarm severity—either major (red) or minor (yellow).	A major (red) alarm condition requires immediate action. A minor (yellow) condition requires monitoring or maintenance.
Subject	Brief synopsis of the alarm.	Clicking the alarm subject displays a detailed alarm message.
Detailed Alarm Message		
Received at	Date and time when the failure was detected.	

Table 42: Summary of Key Alarm Output Fields (continued)

Field	Values	Additional Information
Severity	Alarm severity—either major (red) or minor (yellow).	A major (red) alarm condition requires immediate action. A minor (yellow) condition requires monitoring or maintenance.
Alarm Type	Category of the alarm: <ul style="list-style-type: none"> ■ Chassis—Indicates an alarm condition on the chassis (typically an environmental alarm such as temperature) ■ Configuration—Indicates that no rescue configuration is set ■ ETHER—Indicates an alarm condition on a Fast Ethernet interface ■ DS3—Indicates an alarm condition on a DS3 interface ■ License—Indicates a software license infringement ■ Serial—Indicates an alarm condition on a serial interface ■ Services—Indicates an alarm condition on the services module 	

Verifying the Alarms Configuration

To verify alarms configuration, perform the following task.

Displaying Alarm Configurations

Purpose	Verify the configuration of the alarms.
Action	From the J-Web interface, select Configuration > View and Edit > View Configuration Text . Alternatively, from configuration mode in the CLI, enter the <code>show chassis alarms</code> command.
Sample Output	<pre>[edit] user@host# show chassis alarms t3 { exz yellow; los red; ylw red; } ds1 { ylw red;</pre>

```

}
ethernet {
    link-down red;
}
serial {
    loss-of-rx-clock red;
    loss-of-tx-clock red;
    dcd-absent yellow;
    cts-absent yellow;
}

```

What It Means The sample output in this section displays the following alarm settings (in order). Verify that the output shows the intended configuration of the alarms.

- T3 alarms
- DS1 alarms
- Fast Ethernet alarms
- Serial alarms

For more information about the format of a configuration file, see the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

Chapter 6

Monitoring a Services Router

J-series Services Routers support a suite of J-Web tools and CLI operational mode commands for monitoring system health and performance. Monitoring tools and commands display the current state of the router.

This chapter contains the following topics. For complete descriptions of CLI operational mode commands, see the *JUNOS System Basics and Services Command Reference*, the *JUNOS Interfaces Command Reference*, and the *JUNOS Routing Protocols and Policies Command Reference*.

- Monitoring Terms on page 93
- Monitoring Overview on page 93
- Before You Begin on page 99
- Using the Monitoring Tools on page 99

Monitoring Terms

Before monitoring J-series Services Routers, become familiar with the terms defined in Table 43.

Table 43: J-series Monitoring Terms

Term	Definition
autonomous system (AS)	Network of nodes that route packets based on a shared map of the network topology stored in their local databases.
Internet Control Message Protocol (ICMP)	TCP/IP protocol used to send error and information messages.
routing table	Database of routes learned from one or more protocols.

Monitoring Overview

Use the J-Web Monitor and Manage options to monitor a Services Router. J-Web results are displayed in the browser.

You can also monitor the router with CLI operational mode commands. CLI command output appears on the screen of your console or management device, or you can filter the output to a file.

This section contains the following topics:

- Monitoring Tools Overview on page 94
- Filtering Command Output on page 98

Monitoring Tools Overview

J-Web monitoring tools consist of the options that appear when you select **Monitor** in the task bar. The Monitor options display diagnostic information about the Services Router.

Alternatively, you can enter **show** commands from the CLI to display the same information, and often greater detail. CLI **show** commands display the current configuration and information about interfaces, routing protocols, routing tables, routing policy filters, and the chassis. Use the CLI **clear** command to clear statistics and protocol database information.

Table 44 describes the function of each J-Web Monitor option and lists the corresponding CLI **show** commands.

Table 44: J-Web Monitor Options and CLI show Commands

Monitor Option	Function	Corresponding CLI Commands
System	Displays Services Router system properties, such as the system identification and uptime, users, and resource usage. For details, see “Monitoring System Properties” on page 100.	■ show system uptime
		■ show system users
		■ show system storage
		■ show system processes
Chassis	Displays alarm, environment, and hardware information. For details, see “Monitoring the Chassis” on page 103.	■ show chassis alarms
		■ show chassis environment
		■ show chassis hardware
Interfaces	Hierarchically displays all Services Router physical and logical interfaces, including state and configuration information. For details, see “Monitoring the Interfaces” on page 105.	■ show interfaces terse
		■ show interfaces detail
		■ show interfaces <i>interface-name</i>

Table 44: J-Web Monitor Options and CLI show Commands (continued)

Monitor Option	Function	Corresponding CLI Commands
Routing	Displays routing information through the following options: <ul style="list-style-type: none"> ■ Route Information—Information about the routes in a routing table, including destination, protocol, state, and parameter information. You can narrow the list of routes displayed by specifying search criteria. ■ OSPF Information—Summary of OSPF neighbors, interfaces, and statistics. ■ BGP Information—Summary of BGP routing and neighbor information. ■ RIP Information—Summary of RIP neighbors and statistics. ■ DLSw Information—Summary of DLSw circuits and peers. <p>For details, see “Monitoring Routing Information” on page 107.</p>	<ul style="list-style-type: none"> ■ Route information <ul style="list-style-type: none"> ■ show route terse ■ show route detail ■ OSPF information <ul style="list-style-type: none"> ■ show ospf neighbors ■ show ospf interfaces ■ show ospf statistics ■ BGP information <ul style="list-style-type: none"> ■ show bgp summary ■ show bgp neighbor ■ RIP information <ul style="list-style-type: none"> ■ show rip statistics ■ show rip neighbors ■ DLSw information <ul style="list-style-type: none"> ■ show dlsw capabilities ■ show dlsw circuits ■ show dlsw peers ■ show dlsw reachability

Table 44: J-Web Monitor Options and CLI show Commands (continued)

Monitor Option	Function	Corresponding CLI Commands
Class of Service (CoS)	<p>Displays information about the performance of class of service on a router through the following options:</p> <ul style="list-style-type: none"> ■ Interfaces—Displays the physical and logical interfaces in the system and provides details about the CoS components assigned to these interfaces. ■ Classifiers—Displays the forwarding classes and loss priorities that incoming packets are assigned to based on the packet's CoS values. ■ CoS Value Aliases—Displays the CoS value aliases that the system is using to represent Differentiated Services code point (DSCP), DSCP IPv6, MPLS experimental (EXP), and IPv4 precedence bits. ■ RED Drop Profiles—Displays detailed information about the drop profiles used by the system. Also, displays a graph of the random early detection (RED) curve that the system uses to determine the queue fullness and drop probability. ■ Forwarding Classes—Displays the assignment of forwarding classes to queue numbers. ■ Rewrite Rules—Displays packet CoS value rewrite rules based on the forwarding classes and loss priorities. ■ Scheduler Maps—Displays the assignment of forwarding classes to schedulers. Schedulers include transmit rate, rate limit, and buffer size. <p>For details, see “Monitoring Class-of-Service Performance” on page 113.</p>	<ul style="list-style-type: none"> ■ Interfaces—<code>show class-of-service interface</code> ■ Classifiers—<code>show class-of-service classifier</code> ■ CoS value aliases—<code>show class-of-service code-point-aliases</code> ■ RED drop profiles—<code>show class-of-service drop-profile</code> ■ Forwarding classes—<code>show class-of-service forwarding-class</code> ■ Rewrite rules—<code>show class-of-service rewrite-rule</code> ■ Scheduler maps—<code>show class-of-service scheduler-map</code>

Table 44: J-Web Monitor Options and CLI show Commands (continued)

Monitor Option	Function	Corresponding CLI Commands
MPLS	<p>Displays information about MPLS label-switched paths (LSPs) and virtual private networks (VPNs) through the following options:</p> <ul style="list-style-type: none"> ■ Interfaces—Information about the interfaces on which MPLS is enabled, including operational state and any administrative groups applied to an interface. ■ LSP Information—Information about LSP sessions currently active on the Services Router, including inbound (ingress) and outbound (egress) addresses, LSP state, and LSP name. ■ LSP Statistics—Statistics for LSP sessions currently active on the Services Router, including the total number of packets and bytes forwarded through an LSP. ■ RSVP Sessions—Information about RSVP-signaled LSP sessions currently active on the Services Router, including inbound (ingress) and outbound (egress) addresses, LSP state, and LSP name. ■ RSVP Interfaces—Information about the interfaces on which RSVP is enabled, including the interface name, total bandwidth through the interface, and total current reserved and reservable (available) bandwidth on the interface. <p>For details, see “Monitoring MPLS Traffic Engineering Information” on page 119.</p>	<ul style="list-style-type: none"> ■ Interfaces—<code>show mpls interface</code> ■ LSP information—<code>show mpls lsp</code> ■ LSP Statistics—<code>show mpls lsp statistics</code> ■ RSVP Sessions—<code>show rsvp session</code> ■ RSVP Interfaces—<code>show rsvp interface</code>
Service Sets	<p>Displays information about configured service sets.</p> <p>For details, see “Monitoring Service Sets” on page 122.</p>	<ul style="list-style-type: none"> ■ <code>show services service-sets summary</code> ■ <code>show services service-sets memory-usage</code>
Firewall	<p>Displays firewall and intrusion detection service (IDS) information through the following options:</p> <ul style="list-style-type: none"> ■ Stateful Firewall—Displays the stateful firewall configuration. ■ IDS Information—Displays information about the configured IDS. <p>For details, see “Monitoring Firewalls” on page 124.</p>	<ul style="list-style-type: none"> ■ Stateful firewall information <ul style="list-style-type: none"> ■ <code>show services stateful-firewall conversations</code> ■ <code>show services stateful-firewall flows</code> ■ IDS information <ul style="list-style-type: none"> ■ <code>show services ids destination-table</code> ■ <code>show services ids source-table</code> ■ <code>show services ids pair-table</code>

Table 44: J-Web Monitor Options and CLI show Commands (continued)

Monitor Option	Function	Corresponding CLI Commands
IPSec	Displays configured IPSec tunnels and statistics, and IKE security associations.	■ show services ipsec-vpn ipsec statistics
	For details, see “Monitoring IPSec Tunnels” on page 127.	■ show services ipsec-vpn ipsec security-associations
		■ show services ipsec-vpn ike security-associations
NAT	Displays configured NAT pools.	■ show services nat pool
	For details, see “Monitoring NAT Pools” on page 129.	
DHCP	Displays DHCP dynamic and static leases, conflicts, pools, and statistics.	■ show system services dhcp binding
	For details, see “Monitoring DHCP” on page 130.	■ show system services dhcp conflict
		■ show system services dhcp pool
		■ show system services dhcp statistics
RPM	Displays probe results for all RPM probes configured on the Services Router, including the round-trip times, jitter, and loss percentage of probes sent. Additionally, the RPM monitoring page displays a graph that plots the probe results as a function of time. For details, see “Monitoring RPM Probes” on page 131.	show services rpm probe-results
PPPoE	Displays the following PPPoE information:	■ PPPoE interfaces—show pppoe interfaces
	■ PPPoE Interfaces—Session-specific information about the interfaces on which PPPoE is enabled.	■ PPPoE statistics—show pppoe statistics
	■ PPPoE Statistics—Statistics for PPPoE sessions currently active.	■ PPPoE version—show pppoe version
	■ PPPoE Version—Information about the PPPoE protocol currently configured on the router. For details, see “Monitoring PPPoE” on page 134.	

Filtering Command Output

For operational commands that display output, such as the `show` commands, you can redirect the output into a filter or a file. When you display help about these commands, one of the options listed is `|`, called a *pipe*, which allows you to filter the command output.

For example, if you enter the `show configuration` command, the complete Services Router configuration is displayed on the screen. To limit the display

to only those lines of the configuration that contain `address`, issue the `show configuration` command using a pipe into the match filter:

```
user@host> show configuration | match address

address-range low 192.168.3.2 high 192.168.3.254;
address-range low 192.168.71.71 high 192.168.71.254;
address 192.168.71.70/21;
address 192.168.2.1/24;
address 127.0.0.1/32;
```

For a complete list of the filters, type a command, followed by the pipe, followed by a question mark (?):

```
user@host> show configuration | ?
Possible completions:
compare          Compare configuration changes with prior version
count           Count occurrences
display         Show additional kinds of information
except         Show only text that does not match a pattern
find           Search for first occurrence of pattern
hold           Hold text without exiting the --More-- prompt
last           Display end of output only
match          Show only text that matches a pattern
no-more        Don't paginate output
request        Make system-level requests
resolve        Resolve IP addresses
save           Save output text to file
trim           Trim specified number of columns from start of line
```

You can specify complex expressions as an option for the `match` and `except` filters. For more information about command output filtering and creating match expressions, see the *JUNOS System Basics Configuration Guide*.



NOTE: To filter the output of configuration mode commands, use the filter commands provided for the operational mode commands. In configuration mode, an additional filter is supported. See the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

Before You Begin

To use the J-Web interface and CLI operational tools, you must have the appropriate access privileges. For more information about configuring access privilege levels, see “Adding New Users” on page 27 and the *JUNOS System Basics Configuration Guide*.

Using the Monitoring Tools

This section describes the monitoring tools in detail. It contains the following topics:

- Monitoring System Properties on page 100
- Monitoring the Chassis on page 103
- Monitoring the Interfaces on page 105
- Monitoring Routing Information on page 107
- Monitoring Class-of-Service Performance on page 113
- Monitoring MPLS Traffic Engineering Information on page 119
- Monitoring Service Sets on page 122
- Monitoring Firewalls on page 124
- Monitoring IPSec Tunnels on page 127
- Monitoring NAT Pools on page 129
- Monitoring DHCP on page 130
- Monitoring RPM Probes on page 131
- Monitoring PPPoE on page 134

Monitoring System Properties

The system properties include everything from the name and IP address of the Services Router to the resource usage on the Routing Engine. To view these system properties, select **Monitor > System** in the J-Web interface, or enter the following CLI show commands:

- show system uptime
- show system users
- show system storage
- show system processes

Table 45 summarizes key output fields in system properties displays.

Table 45: Summary of Key System Properties Output Fields

Field	Values	Additional Information
System Identification		
Serial Number	Serial number for the J-series Services Router.	

Table 45: Summary of Key System Properties Output Fields (continued)

Field	Values	Additional Information
JUNOS Software Version	Version of JUNOS software active on the Services Router, including whether the software is for domestic or export use.	Export software is for use outside of the U.S. and Canada.
Router Hostname	Hostname of the Services Router, as defined with the set system hostname command.	
Router IP Address	IP address, in dotted decimal notation, of the Ethernet management port (fe-0/0/0), as defined with the set interfaces fe-0/0/0 command.	
Loopback Addresses	IP address, in dotted decimal notation, of the loopback address, as defined with the set interfaces lo0 command.	
Domain Name Servers	IP addresses, in dotted decimal notation, of the domain name servers, as defined with the set system name-server command.	
Time Zone	Time zone of the Services Router, as defined with the set system time-zone command.	
System Time		
Current Time	Current system time, in Coordinated Universal Time (UTC).	
System Booted Time	Date and time when the router was last booted and how long it has been running.	
Protocol Started Time	Date and time when the routing protocols were last started and how long they have been running.	
Last Configured Time	Date and time when a configuration was last committed. This field also shows the name of the user who issued the last commit command, through either the J-Web interface or the CLI.	
Users		
User	Username of any user logged in to the Services Router.	
TTY	Terminal through which the user is logged in.	
From	System from which the user has logged in. A hyphen indicates that the user is logged in through the console.	
Login Time	Time when the user logged in.	This is the LOGIN@ field in show system users command output.
Idle Time	How long the user has been idle.	
Command	Processes that the user is running.	This is the WHAT field in show system users command output.
Memory Usage		

Table 45: Summary of Key System Properties Output Fields (continued)

Field	Values	Additional Information
Total Memory Available	Total RAM available on the Services Router.	
Total Memory Used	Total RAM currently being consumed by processes actively running on the Services Router, displayed both as a quantity of memory and as a percentage of the total RAM on the router.	
Process ID	Process identifier.	This is the PID field in <code>show system processes</code> command output.
Process Owner	Name of the process owner.	
Process Name	Command that is currently running.	Individual processes on the Services Router are listed here. Because each process within JUNOS operates in a protected memory environment, you can diagnose whether a particular process is consuming abnormally high amounts of resources. If a software process is using too much CPU or memory, you can restart the process by entering the <code>restart</code> command from the CLI.
CPU Usage	Percentage of the CPU that is being used by the process.	
Memory Usage	Percentage of the installed RAM that is being used by the process.	
CPU Usage		
Total CPU Used	Sum of CPU usages by all processes, expressed as a percentage of total CPU available.	
Process ID	Process identifier.	This is the PID field in <code>show system processes</code> command output.
Process Owner	Name of the process' owner.	
Process Name	Command that is currently running.	Individual processes on the Services Router are listed here. Because each process within JUNOS operates in a protected memory environment, you can diagnose whether a particular process is consuming an abnormal amount of resources. If a software process is using too much CPU or memory, you can restart the process by entering the <code>restart</code> command from the CLI.
CPU Usage	Percentage of the CPU that is being used by the process.	
Memory Usage	Percentage of the installed RAM that is being used by the process.	
System Storage		
Total Flash Size	Total size, in megabytes, of the primary flash device.	

Table 45: Summary of Key System Properties Output Fields (continued)

Field	Values	Additional Information
Usable Flash Size	Total usable memory, in megabytes, of the primary flash device.	The total usable flash memory is the total memory minus the size of the JUNOS image installed on the Services Router.
Flash Used	Total flash memory used, in megabytes and as a percentage of the total usable flash size, of the primary flash device.	
Log Files	Total size, in kilobytes, of the log files on the Services Router.	This is the sum of file sizes in the <code>/var/log</code> directory.
Temporary Files	Total size, in kilobytes, of the temporary files on the Services Router.	This is the sum of the file sizes in the <code>/var/tmp</code> directory.
Crash (Core) Files	Total size, in kilobytes, of the core files on the Services Router.	This is the sum of the file sizes in the <code>/var/crash</code> directory.
Database Files	Total size, in kilobytes, of the configuration database files on the Services Router.	This is the sum of the file sizes in the <code>/var/db</code> directory.

Monitoring the Chassis

The chassis properties include the status of any alarms on the Services Router, environment measurements, and a summary of the field-replaceable units (FRUs) on the router. To view these chassis properties, select **Monitor > Chassis** in the J-Web interface, or enter the following CLI `show` commands:

- `show chassis alarms`
- `show chassis environment`
- `show chassis hardware`

Table 46 summarizes key output fields in chassis displays.

Table 46: Summary of Key Chassis Output Fields

Field	Values	Additional Information
Alarm Summary		
Alarm Time	Date and time the alarm was first recorded.	

Table 46: Summary of Key Chassis Output Fields (continued)

Field	Values	Additional Information
Alarm Class	Severity class for this alarm: Minor or Major.	<p>JUNOS has system-defined alarms and configurable alarms. System-defined alarms include FRU detection alarms (power supplies removed, for instance) and environmental alarms. The values for these alarms are defined within JUNOS.</p> <p>Configurable alarms are set in either of the following ways:</p> <ul style="list-style-type: none"> ■ In the J-Web configuration editor, on the Chassis > Alarm > <i>interface-type</i> page ■ In the CLI configuration editor, with the alarm statement at the [edit chassis] level of the configuration hierarchy <p>For details, see “Configuring and Monitoring Alarms” on page 79.</p>
Alarm Description	A brief synopsis of the alarm.	
Environment Information		
Name	Chassis component. For J-series Services Routers, the chassis components are the Routing Engine and the fan.	
Gauge Status	Status of the temperature gauge on the specified hardware component.	
Temperature	Temperature of the air flowing past the hardware component.	
Hardware Summary		
Name	Chassis component. For J-series Services Routers, the chassis components are the Routing Engine, the Physical Interface Module (PIM) slot number (identified in the display as an FPC), and the PIM number (identified in the display as a PIC).	On J-series Services Routers, an FPC and a PIM are the same physical unit. The PIM number is always 0.
Version	Revision level of the specified hardware component.	Supply the version number when reporting any hardware problems to customer support.
Part Number	Part number of the chassis component.	
Serial Number	Serial number of the chassis component. The serial number of the backplane is also the serial number of the router chassis.	Use this serial number when you need to contact customer support about the router chassis.
Description	Brief description of the hardware item.	For J-series PIMs, the description lists the number and type of the ports on the PIM—identified in the display as a PIC.

Monitoring the Interfaces

The interface information is divided into multiple parts. To view general interface information such as available interfaces, operation states of the interfaces, and descriptions of the configured interfaces, select **Monitor > Interfaces** in the J-Web interface. To view interface-specific properties such as administrative state or traffic statistics in the J-Web interface, select the interface name on the Interfaces page.

Alternatively, enter the following CLI `show` commands:

- `show interfaces terse`
- `show interfaces detail`
- `show interfaces interface-name`

Table 47 summarizes key output fields in interfaces displays.

Table 47: Summary of Key Interfaces Output Fields

Field	Values	Additional Information
Interface Summary		
Interface Name	Name of interface.	Click an interface name to see more information about the interface.
Oper State	Link state of the interface: Up or Down .	The operational state is the physical state of the interface. If the interface is physically operational, even if it is not configured, the operational state is Up . An operational state of Down indicates a problem with the physical interface.
Admin State	Whether the interface is enabled up (Up) or disabled (Down).	Interfaces are enabled by default. To disable an interface: <ul style="list-style-type: none"> ■ In the J-Web configuration editor, select the Disable check box on the Interfaces > <i>interfaces-name</i> page. ■ In the CLI configuration editor, add the <code>disable</code> statement at the <code>[edit interfaces <i>interfaces-name</i>]</code> level of the configuration hierarchy
Description	Configured description for the interface.	
Interface: <i>interface-name</i>		
State	Link state of the interface: Up or Down .	The operational state is the physical state of the interface. If the interface is physically operational, even if it is not configured, the operational state is Up . An operational state of Down indicates a problem with the physical interface.

Table 47: Summary of Key Interfaces Output Fields (continued)

Field	Values	Additional Information
Admin State	Whether the interface is enabled up (Up) or disabled (Down).	<p>Interfaces are enabled by default. To disable an interface:</p> <ul style="list-style-type: none"> ■ In the J-Web configuration editor, select the Disable check box on the Interfaces > interfaces-name page. ■ In the CLI configuration editor, add the disable statement at the [edit interfaces interfaces-name] level of the configuration hierarchy
MTU	Maximum transmission unit (MTU) size on the physical interface.	
Speed	Speed at which the interface is running.	
Current Address	Configured media access control (MAC) address.	
Hardware Address	Hardware MAC address.	
Last Flapped	Date, time, and how long ago the interface changed state from Down to Up .	
Active Alarms	List of any active alarms on the interface.	<p>Configure alarms on interfaces as follows:</p> <ul style="list-style-type: none"> ■ In the J-Web configuration editor, on the Chassis > Alarm > interface-type page ■ In the CLI configuration editor, with the alarm statement at the [edit chassis] level of the configuration hierarchy
Traffic Statistics	Number of packets and bytes received and transmitted on the physical interface.	
Input Errors	Input errors on the interface. (See the following rows of this table for specific error types.)	
Drops	Number of packets dropped by the output queue.	If the interface is saturated, this number increments once for every packet that is dropped by the Services Router's random early detection (RED) mechanism.

Table 47: Summary of Key Interfaces Output Fields (continued)

Field	Values	Additional Information
Framing errors	Sum of ATM Adaptation Layer (AAL5) packets that have frame check sequence (FCS) errors, AAL5 packets that have reassembly timeout errors, and AAL5 packets that have length errors.	
Policed discards	Number of packets dropped as a result of routing policies configured on the interface.	

Monitoring Routing Information

Routing information is divided into multiple parts:

- To view the inet.0 (IPv4) routing table in the J-Web interface, select **Monitor > Routing > Route Information**, or enter the following CLI commands:
 - `show route terse`
 - `show route detail`
- To view BGP routing information, select **Monitor > Routing > BGP Information**, or enter the following CLI commands:
 - `show bgp summary`
 - `show bgp neighbor`
- To view OSPF routing information, select **Monitor > Routing > OSPF Information**, or enter the following CLI commands:
 - `show ospf neighbors`
 - `show ospf interfaces`
 - `show ospf statistics`
- To view RIP routing information, select **Monitor > Routing > RIP Information**, or enter the following CLI commands:
 - `show rip statistics`
 - `show rip neighbors`
- To view DLSw routing information, select **Monitor > Routing > DLSw Information**, or enter the following CLI commands:
 - `show dls w capabilities`
 - `show dls w circuits`

- show dlsw peers
- show dlsw reachability

Table 48 summarizes key output fields in routing displays.

Table 48: Summary of Key Routing Output Fields

Field	Values	Additional Information
Route Information		
<i>n</i> destinations	Number of destinations for which there are routes in the routing table.	
<i>n</i> routes	Number of routes in the routing table: <ul style="list-style-type: none"> ■ active—Number of routes that are active. ■ holddown—Number of routes that are in hold-down state (neither advertised nor updated) before being declared inactive. ■ hidden—Number of routes not used because of routing policies configured on the Services Router. 	
Destination	Destination address of the route.	
Protocol/ Preference	Protocol from which the route was learned: Static , Direct , Local , or the name of a particular protocol. The preference is the individual preference value for the route.	The route preference is used as one of the route selection criteria.
Next-Hop	Network layer address of the directly reachable neighboring system (if applicable) and the interface used to reach it.	<p>If a next hop is listed as Discard, all traffic with that destination address is discarded rather than routed. This value generally means that the route is a static route for which the discard attribute has been set.</p> <p>If a next hop is listed as Reject, all traffic with that destination address is rejected. This value generally means that the address is unreachable. For example, if the address is a configured interface address and the interface is unavailable, traffic bound for that address is rejected.</p> <p>If a next hop is listed as Local, the destination is an address on the host (either the loopback address or the Ethernet management port address, for example).</p>
Age	How long the route has been known.	
State	Flags for this route.	There are many possible flags. For a complete description, see the <i>JUNOS Routing Protocols and Policies Command Reference</i> .

Table 48: Summary of Key Routing Output Fields (continued)

Field	Values	Additional Information
AS Path	AS path through which the route was learned. The letters of the AS path indicate the path origin: <ul style="list-style-type: none"> ■ I — IGP. ■ E — EGP. ■ ? — Incomplete. Typically, the AS path was aggregated. 	
BGP Summary		
Groups	Number of BGP groups.	
Peers	Number of BGP peers.	
Down Peers	Number of unavailable BGP peers.	
Peer	Address of each BGP peer.	
InPkt	Number of packets received from the peer.	
OutPkt	Number of packets sent to the peer.	
Flaps	Number of times a BGP session has changed state from Down to Up .	A high number of flaps might indicate a problem with the interface on which the BGP session is enabled.
Last Up/Down	Last time that a session became available or unavailable, since the neighbor transitioned to or from the established state.	If the BGP session is unavailable, this time might be useful in determining when the problem occurred.
State	A multipurpose field that displays information about BGP peer sessions. The contents of this field depend upon whether a session is established. <ul style="list-style-type: none"> ■ If a peer is not established, the field shows the state of the peer session: Active, Connect, or Idle. ■ If a BGP session is established, the field shows the number of active, received, and damped routes that are received from a neighbor. For example, 2/4/0 indicates two active routes, four received routes, and no damped routes. 	
BGP Neighbors		
Peer	Address of the BGP neighbor.	
AS	AS number of the peer.	
Type	Type of peer: Internal or External .	

Table 48: Summary of Key Routing Output Fields (continued)

Field	Values	Additional Information
State	<p>Current state of the BGP session:</p> <ul style="list-style-type: none"> ■ Active—BGP is initiating a TCP connection in an attempt to connect to a peer. If the connection is successful, BGP sends an open message. ■ Connect—BGP is waiting for the TCP connection to become complete. ■ Established—The BGP session has been established, and the peers are exchanging BGP update messages. ■ Idle—This is the first stage of a connection. BGP is waiting for a Start event. ■ OpenConfirm—BGP has acknowledged receipt of an open message from the peer and is waiting to receive a keepalive or notification message. ■ OpenSent—BGP has sent an open message and is waiting to receive an open message from the peer. 	<p>Generally, the most common states are Active, which indicates a problem establishing the BGP connection, and Established, which indicates a successful session setup. The other states are transition states, and BGP sessions normally do not stay in those states for extended periods of time.</p>
Export	Names of any export policies configured on the peer.	
Import	Names of any import policies configured on the peer.	
Number of flaps	Number of times the BGP sessions has changed state from Down to Up .	A high number of flaps might indicate a problem with the interface on which the session is established.
OSPF Neighbors		
Address	Address of the neighbor.	
Interface	Interface through which the neighbor is reachable.	
State	State of the neighbor: Attempt , Down , Exchange , ExStart , Full , Init , Loading , or 2way .	Generally, only the Down state, indicating a failed OSPF adjacency, and the Full state, indicating a functional adjacency, are maintained for more than a few seconds. The other states are transitional states that a neighbor is in only briefly while an OSPF adjacency is being established.
ID	Router ID of the neighbor.	
Priority	Priority of the neighbor to become the designated router.	
Dead	Number of seconds until the neighbor becomes unreachable.	
OSPF Interfaces		
Interface	Name of the interface running OSPF.	
State	State of the interface: BDR , Down , DR , DROther , Loop , PtToPt , or Waiting .	The Down state, indicating that the interface is not functioning, and PtToPt state, indicating that a point-to-point connection has been established, are the most common states.

Table 48: Summary of Key Routing Output Fields (continued)

Field	Values	Additional Information
Area	Number of the area that the interface is in.	
DR ID	Address of the area's designated router.	
BDR ID	Address of the area's backup designated router.	
Nbrs	Number of neighbors on this interface.	
OSPF Statistics		
Packet Type	Type of OSPF packet.	
Total Sent/Total Received	Total number of packets sent and received.	
Last 5 seconds Sent/Last 5 seconds Received	Total number of packets sent and received in the last 5 seconds.	
Receive errors	Number and type of receive errors.	
RIP Statistics		
Rip info	Information about RIP on the specified interface, including UDP port number, hold-down interval (during which routes are neither advertised nor updated), and timeout interval.	
Logical interface	Name of the logical interface on which RIP is configured.	
Routes learned	Number of RIP routes learned on the logical interface.	
Routes advertised	Number of RIP routes advertised on the logical interface.	
RIP Neighbors		
Neighbor	Name of the RIP neighbor.	<p>This value is the name of the interface on which RIP is enabled. The name is set in either of the following ways:</p> <ul style="list-style-type: none"> ■ In the J-Web configuration editor, on the Protocols > RIP > Group > group-name > Neighbor page ■ In the CLI configuration editor, with the <code>neighbor neighbor-name</code> statement at the <code>[edit protocols rip group group-name]</code> level of the configuration hierarchy
State	State of the RIP connection: Up or Dn (Down).	
Source Address	Local source address.	This value is the configured address of the interface on which RIP is enabled.

Table 48: Summary of Key Routing Output Fields (continued)

Field	Values	Additional Information
Destination Address	Destination address.	This value is the configured address of the immediate RIP adjacency.
In Met	Value of the incoming metric configured for the RIP neighbor.	
DLSw Capabilities		
Peer	IP address of the peer DLSw router	
Vendor ID	Numerical value assigned to Juniper Networks.	
Version number	DLSw protocol version.	
Initial pacing window	Frequency at which packets are sent.	
Version string	Juniper Networks software version information.	
DLSw Circuits		
Circuit id	DLSw circuit ID	
Local Address	MAC address of the local DLSw peer.	
LSAP	Number of the local service access point.	
Remote address	MAC address of the remote DLSw peer.	
DSAP	Number of the destination service access point.	
State (or circuit state)	Connectivity status; disconnected or connected.	
Peer (or remote peer address)	IP address of the remote DLSw peer.	
DLSw Peers		
Peer	IP address of the remote DLSw peer.	
State	Status of the connection.	
Circuits	Number of circuits on the DLSw network.	
Local address	IP address of the local DLSw peer.	
Created time	Time of circuit creation.	
Connected time	Length of time that the connection is active.	
Receive initial pacing	Size of the initial pacing frame.	

Table 48: Summary of Key Routing Output Fields (continued)

Field	Values	Additional Information
No circuits timeout	Length of time before a circuit becomes inactive.	
DLSw Reachability		
MAC index	Number assigned to the remote DLSw peer.	
MAC address	MAC address of the remote DLSw peer.	
Remote DLSw address	IP address of the remote DLSw peer.	

Monitoring Class-of-Service Performance

The J-Web interface provides information about the class-of-service (CoS) performance on a router. You can view the following information about the current status of CoS components and the interfaces to which the components are assigned:

- To display details about the physical and logical interfaces and the CoS components assigned to them, select **Monitor > Class of Service > Interfaces** in the J-Web interface, or enter the following CLI command:


```
show class-of-service interface interface
```
- To display the mapping of incoming CoS value to forwarding class and loss priority, for each classifier, select **Monitor > Class of Service > Classifiers** in the J-Web interface, or enter the following CLI command:


```
show class-of-service classifier
```
- To display information about the CoS value aliases that the system is currently using to represent DSCP, DSCP IPv6, MPLS EXP, and IPv4 precedence bits, select **Monitor > Class of Service > Code Point Aliases** in the J-Web interface, or enter the following CLI command:


```
show class-of-service code-point-aliases
```
- To display data point information for each CoS random early detection (RED) drop profile currently on a system, select **Monitor > Class of Service > RED Drop Profiles** in the J-Web interface, or enter the following CLI command:


```
show class-of-service drop-profile
```
- To view the current assignment of forwarding classes to queue numbers on the system, select **Monitor > Class of Service > Forwarding Classes** in the J-Web interface, or enter the following CLI command:


```
show class-of-service forwarding-class
```

- To display information about CoS value rewrite rules, which are based on the forwarding class and loss priority, select **Monitor > Class of Service > Rewrite Rules** in the J-Web interface, or enter the following CLI command:

```
show class-of-service rewrite-rules
```

- To display assignments of forwarding classes to schedulers, select **Monitor > Class of Service > Scheduler Maps** in the J-Web interface, or enter the following CLI command:

```
show class-of-service scheduler-map
```

In addition, you can display the entire CoS configuration, including system-chosen defaults, by entering the following CLI command:

```
show class-of-service
```

Table 49 summarizes key CoS output fields.

Table 49: Summary of Key CoS Output Fields

Field	Values	Additional Information
Interfaces		
Interface	Name of a physical interface to which CoS components are assigned.	To display names of logical interfaces configured on this physical interface, click the plus sign (+).
Scheduler Map	Name of the scheduler map associated with this interface.	
Queues Supported	Number of queues you can configure on the interface.	
Queues in Use	Number of queues currently configured.	
Logical Interface	Name of a logical interface on the physical interface, to which CoS components are assigned.	
Object	Category of an object—for example, classifier, scheduler-map, or rewrite.	
Name	Name that you have given to an object—for example, ba-classifier .	
Type	Type of an object—for example, dscp , or exp for a classifier.	
Index	Index of this interface or the internal index of a specific object.	
Classifiers		
Classifier Name	Name of a classifier.	To display classifier assignments, click the plus sign (+).

Table 49: Summary of Key CoS Output Fields (continued)

Field	Values	Additional Information
CoS Value Type	<p>The classifiers are displayed by type:</p> <ul style="list-style-type: none"> ■ dscp—All classifiers of the DSCP type. ■ dscp ipv6—All classifiers of the DSCP IPv6 type. ■ exp—All classifiers of the MPLS EXP type. ■ ieee-802.1—All classifiers of the IEEE 802.1 type. ■ inet-precedence—All classifiers of the IP precedence type. 	
Index	Internal index of the classifier.	
Incoming CoS Value	CoS value of the incoming packets, in bits. These values are used for classification.	
Assign to Forwarding Class	Forwarding class that the classifier assigns to an incoming packet. This class affects the forwarding and scheduling policies that are applied to the packet as it transits the router.	
Assign to Loss Priority	Loss priority value that the classifier assigns to the incoming packet based on its CoS value.	
CoS Value Aliases		
CoS Value Type	<p>Type of the CoS value:</p> <ul style="list-style-type: none"> ■ dscp—Examines Layer 3 packet headers for IP packet classification. ■ dscp ipv6—Examines Layer 3 packet headers for IPv6 packet classification. ■ exp—Examines Layer 2 packet headers for MPLS packet classification. ■ ieee-802.1—Examines Layer 2 packet header for packet classification. ■ inet-precedence—Examines Layer 3 packet headers for IP packet classification. 	To display aliases and bit patterns, click the plus sign (+).
CoS Value Alias	Name given to a set of bits—for example, af11 is a name for 001010 bits.	
Bit Pattern	Set of bits associated with an alias.	
RED Drop Profiles		

Table 49: Summary of Key CoS Output Fields (continued)

Field	Values	Additional Information
RED Drop Profile Name	<p>Name of the RED drop profile.</p> <p>A drop profile consists of pairs of values between 0 and 100, one for queue buffer fill level and one for drop probability, that determine the relationship between a buffer's fullness and the likelihood it will drop packets.</p>	To display profile values, click the plus sign (+).
Graph RED Profile	Link to a graph of a RED curve that the system uses to determine the drop probability based on queue buffer fullness.	The x axis represents the queue buffer fill level, and the y axis represents the drop probability.
Type	<p>Type of a specific drop profile:</p> <ul style="list-style-type: none"> ■ interpolated—The two coordinates (x and y) of the graph are interpolated to produce a smooth profile. ■ segmented—The two coordinates (x and y) of the graph are represented by line fragments to produce a segmented profile. <p>For information about types of drop profiles, see the <i>JUNOS Class of Service Configuration Guide</i>.</p>	
Index	Internal index of this drop profile.	
Fill Level	Percentage fullness of a buffer queue. This value is the x coordinate of the RED drop profile graph.	
Drop Probability	Drop probability of a packet corresponding to a specific queue buffer fill level. This value is the y coordinate of the RED drop profile graph.	
Forwarding Classes		

Table 49: Summary of Key CoS Output Fields (continued)

Field	Values	Additional Information
Forwarding Class	Names of forwarding classes assigned to queue numbers. By default, the following forwarding classes are assigned to queues 0 through 3: <ul style="list-style-type: none"> ■ best-effort—Provides no special CoS handling of packets. Loss priority is typically not carried in a CoS value, and RED drop profiles are more aggressive. ■ expedited-forwarding—Provides low loss, low delay, low jitter, assured bandwidth, and end-to-end service. ■ assured-forwarding—Provides high assurance for packets within specified service profile. Excess packets are dropped. ■ network-control—Packets can be delayed but not dropped. 	
Queue	Queue number corresponding to the forwarding class name.	By default, four queues, 0 through 3, are assigned to forwarding classes.
Rewrite Rules		
Rewrite Rule Name	Names of rewrite rules.	
CoS Value Type	Rewrite rule type: <ul style="list-style-type: none"> ■ dscp—For IPv4 DiffServ traffic. ■ dscp-ipv6—For IPv6 DiffServ traffic. ■ exp—For MPLS traffic. ■ ieee-802.1—For Layer 2 traffic. ■ inet-precedence—For IPv4 traffic. 	To display forwarding classes, loss priorities, and rewritten CoS values, click the plus sign (+).
Index	Internal index for this particular rewrite rule.	
Forwarding Class	Forwarding class that in combination with loss priority is used to determine CoS values for rewriting.	Rewrite rules are applied to CoS values in outgoing packets based on forwarding class and loss priority setting.
Loss Priority	Loss priority that in combination with forwarding class is used to determine CoS values for rewriting.	
Rewrite CoS Value To	Value that the CoS value is rewritten to.	
Scheduler Maps		
Scheduler Map	Name of a scheduler map.	For details, click the plus sign (+).

Table 49: Summary of Key CoS Output Fields (continued)

Field	Values	Additional Information
Index	Index of a specific object—scheduler maps, schedulers, or drop profiles.	
Scheduler Name	Name of a scheduler.	
Forwarding Class	Forwarding classes this scheduler is assigned to.	
Transmit Rate	Configured transmit rate of the scheduler in bits per second (bps). The rate value can be either of the following: <ul style="list-style-type: none"> ■ A percentage—The scheduler receives the specified percentage of the total interface bandwidth. ■ remainder—The scheduler receives the remaining bandwidth of the interface after allocation to other schedulers. 	
Rate Limit	Rate limiting configuration of the queue: <ul style="list-style-type: none"> ■ none—No rate limiting. ■ exact—The queue transmits at only the configured rate. 	
Buffer Size	Delay buffer size in the queue or the amount of transmit delay (in milliseconds). The buffer size can be either of the following: <ul style="list-style-type: none"> ■ A percentage—The buffer is a percentage of the total buffer allocation. ■ remainder—The buffer is sized according to what remains after other scheduler buffer allocations. 	
Priority	Scheduling priority of a queue: <ul style="list-style-type: none"> ■ high—Packets in this queue are transmitted first. ■ low—Packets in this queue are transmitted last. ■ medium-high—Packets in this queue are transmitted after high-priority packets. ■ medium-low—Packets in this queue are transmitted before low-priority packets. 	
Drop Profiles	Name and index of a drop profile that is assigned to a specific loss priority and protocol pair.	

Table 49: Summary of Key CoS Output Fields (continued)

Field	Values	Additional Information
Loss Priority	Packet loss priority corresponding to a drop profile: <ul style="list-style-type: none"> ■ low—Packet has a low loss priority. ■ high—Packet has a high loss priority. ■ medium-low—Packet has a medium-low loss priority. ■ medium-high—Packet has a medium-high loss priority. 	
Protocol	Transport protocol corresponding to a drop profile.	
Drop Profile Name	Name of the drop profile.	

Monitoring MPLS Traffic Engineering Information

Multiprotocol Label Switching (MPLS) traffic engineering information is divided into separate parts:

- To view the interfaces on which MPLS is configured, select **Monitor > MPLS > Interfaces**, or enter the following CLI command:

show mpls interface
- To view all label-switched paths (LSPs) configured on the Services Router, including all inbound (ingress), outbound (egress), and transit LSP information, select **Monitor > MPLS > LSP Information**, or enter the following CLI command:

show mpls lsp
- To display accounting information about LSPs, select **Monitor > MPLS > LSP Statistics**, or enter the following CLI command:

show mpls lsp statistics



NOTE: Statistics are not available for LSPs on the outbound router, because the penultimate router in the LSP sets the label to 0. Also, as the packet arrives at the outbound router, the hardware removes its MPLS header and the packet reverts to being an IPv4 packet. Therefore, it is counted as an IPv4 packet, not an MPLS packet.

- To view currently active RSVP session information, select **Monitor > MPLS > RSVP Sessions**, or enter the following CLI command:

show rsvp session
- To view the interfaces on which RSVP is running, select **Monitor > MPLS > RSVP Interfaces**, or enter the following CLI command:

show rsvp interface

Table 50 summarizes key output fields in traffic engineering displays.

Table 50: Summary of Key MPLS Output Fields

Field	Values	Additional Information
Interfaces		
Interface	Name of the interface on which MPLS is configured.	
State	State of the specified interface: Up or Dn (down).	
Administrative groups	Administratively assigned colors of the MPLS link configured on the interface.	
LSP Information		
Ingress LSP	Information about LSPs on the inbound router. Each session has one line of output.	
Egress LSP	Information about the LSPs on the outbound router. Each session has one line of output.	MPLS learns this information by querying RSVP, which holds all the transit and outbound session information.
Transit LSP	Number of LSPs on the transit routers and the state of these paths.	MPLS learns this information by querying RSVP, which holds all the transit and outbound session information.
To	Destination (outbound router) of the session.	
From	Source (inbound router) of the session.	
State	State of the path. It can be Up , Down , or AdminDn .	AdminDn indicates that the LSP is being taken down gracefully.
Rt	Number of active routes (prefixes) installed in the routing table.	For inbound RSVP sessions, the routing table is the primary IPv4 table (inet.0). For transit and outbound RSVP sessions, the routing table is the primary MPLS table (mpls.0).
Active Path	Name of the active path: Primary or Secondary .	This field is used for inbound LSPs only.
P	An asterisk (*) in this column indicates that the LSP is a primary path.	This field is used for inbound LSPs only.
LSPname	Configured name of the LSP.	
Style	RSVP reservation style. This field consists of two parts. The first is the number of active reservations. The second is the reservation style, which can be FF (fixed filter), SE (shared explicit), or WF (wildcard filter).	This field is used for outbound and transit LSPs only.

Table 50: Summary of Key MPLS Output Fields (continued)

Field	Values	Additional Information
Labelin	Incoming label for this LSP.	
Labelout	Outgoing label for this LSP.	
Total	Total number of LSPs displayed for the particular type— ingress (inbound), egress (outbound), or transit .	
LSP Statistics		
Ingress LSP	Information about LSPs on the inbound router. Each session has one line of output.	
Egress LSP	Information about the LSPs on the outbound router. Each session has one line of output.	MPLS learns this information by querying RSVP, which holds all the transit and outbound session information.
Transit LSP	Number of LSPs on the transit routers and the state of these paths.	MPLS learns this information by querying RSVP, which holds all the transit and outbound session information.
To	Destination (outbound router) of the session.	
From	Source (inbound router) of the session.	
State	State of the path: Up , Down , or AdminDn .	AdminDn indicates that the LSP is being taken down gracefully.
Packets	Total number of packets received on the LSP from the upstream neighbor.	
Bytes	Total number of bytes received on the LSP from the upstream neighbor.	
LSPname	Configured name of the LSP.	
Total	Total number of LSPs displayed for the particular type— ingress (inbound), egress (outbound), or transit .	
RSVP Sessions		
Ingress LSP	Information about inbound RSVP sessions. Each session has one line of output.	
Egress LSP	Information about outbound RSVP sessions. Each session has one line of output.	MPLS learns this information by querying RSVP, which holds all the transit and outbound session information.
Transit LSP	Information about transit RSVP sessions.	MPLS learns this information by querying RSVP, which holds all the transit and outbound session information.
To	Destination (outbound router) of the session.	
From	Source (inbound router) of the session.	
State	State of the path: Up , Down , or AdminDn .	AdminDn indicates that the LSP is being taken down gracefully.
Rt	Number of active routes (prefixes) installed in the routing table.	For inbound RSVP sessions, the routing table is the primary IPv4 table (inet.0). For transit and outbound RSVP sessions, the routing table is the primary MPLS table (mpls.0).

Table 50: Summary of Key MPLS Output Fields (continued)

Field	Values	Additional Information
Style	RSVP reservation style. This field consists of two parts. The first is the number of active reservations. The second is the reservation style, which can be FF (fixed filter), SE (shared explicit), or WF (wildcard filter).	This field is used for outbound and transit LSPs only.
Labelin	Incoming label for this RSVP session.	
Labelout	Outgoing label for this RSVP session.	
LSPname	Configured name of the LSP.	
Total	Total number of RSVP sessions displayed for the particular type— ingress (inbound), egress (outbound), or transit .	
RSVP Interfaces		
RSVP Interface	Number of interfaces on which RSVP is active. Each interface has one line of output.	
Interface	Name of the interface.	
State	State of the interface: <ul style="list-style-type: none"> ■ Disabled—No traffic engineering information is displayed. ■ Down—The interface is not operational. ■ Enabled—Displays traffic engineering information. ■ Up—The interface is operational. 	
Active resv	Number of reservations that are actively reserving bandwidth on the interface.	
Subscription	User-configured subscription factor.	
Static BW	Total interface bandwidth, in bits per second (bps).	
Available BW	Amount of bandwidth that RSVP is allowed to reserve, in bits per second (bps). It is equal to (static bandwidth X subscription factor).	
Reserved BW	Currently reserved bandwidth, in bits per second (bps).	
Highwater mark	Highest bandwidth that has ever been reserved on this interface, in bits per second (bps).	

Monitoring Service Sets

A service set is a group of rules from a stateful firewall filter, Network Address Translation (NAT), intrusion detection service (IDS), or IP Security (IPSec) that you apply to a services interface. You can configure IDS, NAT, and stateful firewall filter

service rules within the same service set. You must configure IPSec services in a separate service set. For more information about using service sets with these features, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

Service set information includes the services interfaces on the Services Router, the number of services sets configured on the interfaces, and the total CPU used by the service sets. To view these service set properties, select **Monitor > Service Sets** in the J-Web interface, or enter the following CLI show commands:

- show services service-sets summary
- show services service-sets memory-usage

Table 51 summarizes key output fields in service sets displays.

Table 51: Summary of Key Service Set Output Fields

Field	Values	Additional Information
Service Set Summary		
Interface	Name of the adaptive services interface on the Services Router—always <code>sp-0/0/0</code> .	
Service sets configured	Total number of service sets configured on the Services Router.	
Bytes used	Total number of general-purpose memory bytes being used by the service set configuration.	A portion of the general-purpose memory on a Services Router is allocated for storing traffic flows, NAT pools, and so on.
Policy bytes used	Total number of configuration-object memory bytes being used by routing policies associated with the service set configuration.	A portion of the general-purpose memory on a Services Router is allocated for storing configuration objects like firewall rules, routing policies, and so on.
CPU utilization	Percentage of the CPU resources being used.	A high CPU utilization indicates that the router is under heavy load. High CPU utilization might cause performance degradation in forwarding or the application of other services.
Memory Usage		
Interface	Name of the adaptive services interface on the Services Router—always <code>sp-0/0/0</code> .	
Service set	Name of a service set.	

Table 51: Summary of Key Service Set Output Fields (continued)

Field	Values	Additional Information
Memory Utilization %	Percentage of the memory resources being used by the service set.	A high CPU utilization indicates that the router is under heavy load. High CPU utilization might cause performance degradation in forwarding or the application of other services.
Memory zone	<p>Memory zone in which the services interface is currently operating. Following are valid zones:</p> <ul style="list-style-type: none"> ■ Green—All new flows are allowed. ■ Yellow—Unused memory is reclaimed. All new flows are allowed. ■ Orange—New flows are only allowed for service sets that are using less than their equal share of memory. ■ Red—No new flows are allowed. 	

Monitoring Firewalls

Firewall information is divided into multiple parts:

- To view stateful firewall filter statistics in the J-Web interface, select **Monitor > Firewall > Statistics Summary**. Alternatively, enter the CLI command `show services stateful-firewall statistics`.
- To view stateful firewall filter information in the J-Web interface, select **Monitor > Firewall > Stateful Firewall**. To display stateful firewall filter information for a particular address prefix, port, or other characteristic, type or select information in one or more of the Narrow Search boxes, and click **OK**.

Alternatively, enter the following CLI `show` commands:

- `show services stateful-firewall conversations`
- `show services stateful-firewall flows`
- To view intrusion detection service (IDS) information, select **Monitor > Firewall > IDS Information**. Click one of the following criteria to order the display accordingly:
 - **Bytes** (received bytes)
 - **Packets** (received packets)
 - **Flows**
 - **Anomalies**

To limit the display of IDS information, type or select information in one or more of the Narrow Search boxes listed in Table 52, and click **OK**.

Table 52: IDS Search-Narrowing Characteristics

Narrow Search Box	Entry or Selection
Destination Address	Type a destination address prefix to display IDS information for only that prefix.
IDS Table	Select one of the following: <ul style="list-style-type: none"> ■ Destination—Displays information for an address under attack. ■ Pair—Displays information for a suspected attack source and destination pair. ■ Source—Displays information for an address that is a suspected attacker.
Number of IDS Entries to Display	Select a number between 25 and 500 to display only a particular number of entries.
Threshold	Type a number to display events with only that number of bytes, packets, flows, or anomalies—whichever you selected to order the display. For example, to display all events with more than 100 flows, click Flows and then type 100 in the Threshold box.
Service Set	Select a service set to display information for only the set.

Alternatively, enter the following CLI **show** commands:

- `show services ids destination-table`
- `show services ids source-table`
- `show services ids pair-table`

Table 53 summarizes key output fields in firewall and IDS displays.

Table 53: Summary of Key Firewall and IDS Output Fields

Field	Values
Statistics Summary	
Interface	Name of the services interface on which the service set is applied.
Service Set	Name of the service set.
Accept	Number of packets accepted by all rules defined in the service set.
Discard	Number of packets discarded by all rules defined in the service set.
Reject	Number of packets rejected by all rules defined in the service set.
New flows	Number of packets matching rules defined in new flows: <ul style="list-style-type: none"> ■ Accept—Number of packets accepted. ■ Discards—Number of packets discarded. ■ Rejects—Number of packets rejected.

Table 53: Summary of Key Firewall and IDS Output Fields (continued)

Field	Values
Existing flows	<p>Number of packets matching rules defined in existing flows:</p> <ul style="list-style-type: none"> ■ Accept—Number of packets accepted. ■ Discards—Number of packets discarded. ■ Rejects—Number of packets rejected.
Drops	<p>Number of packets dropped due to the following match conditions:</p> <ul style="list-style-type: none"> ■ IP Option—Number of packets dropped due to the inspection of the IP options field of the packet. ■ TCP SYN Defense—Number of packets dropped due to the SYN defender, which prevents denial-of-service (DoS) attacks. ■ NAT Ports Exhausted—Number of packets dropped because the router has no available NAT ports to assign for a given source address. <p>For more information about these match conditions, see the <i>J-series Services Router Advanced WAN Access Configuration Guide</i> and the <i>JUNOS Services Interfaces Configuration Guide</i>.</p>
Errors	<p>Number of protocol errors detected:</p> <ul style="list-style-type: none"> ■ IP—Number of IPv4 errors (for example, Minimum IP header length check failures). ■ TCP—Number of TCP errors (for example, Source or destination port number is zero). ■ UDP—Number of UDP errors (for example, IP data length less than minimum UDP header length (8 bytes)). ■ ICMP—Number of ICMP errors (for example, Duplicate ping sequence number). ■ Non-IP Packets—Number of errors in packets that are not IPv4 packets. ■ ALG—Number of application-level gateway (ALG) errors. <p>For a complete list of protocol errors that are counted, see the description of the show services stateful-firewall statistics command in the <i>JUNOS System Basics and Services Command Reference</i>.</p>
Stateful Firewall	
Protocol	Protocol used for the specified stateful firewall flow.
Source IP	Source prefix of the stateful firewall flow.
Source Port	Source port number of stateful firewall flow.
Destination IP	Destination prefix of the stateful firewall flow.
Destination Port	Destination port number of the stateful firewall flow.
Flow State	<p>Status of the stateful firewall flow:</p> <ul style="list-style-type: none"> ■ Drop—Drop all packets in the flow without response. ■ Forward—Forward the packet in the flow without inspecting it. ■ Reject—Drop all packets in the flow with response. ■ Watch—Inspect packets in the flow.

Table 53: Summary of Key Firewall and IDS Output Fields (continued)

Field	Values
Direction	Direction of the flow: I (input) or O (output).
Frames	Number of frames in the flow.
IDS Information	
Source Address	Source address for the event.
Destination address	Destination address for the event.
Time	Total time the information has been in the IDS table.
Bytes	Total number of bytes sent from the source to the destination address, in thousands (k) or millions (m).
Packets	Total number of packets sent from the source to the destination address, in thousands (k) or millions (m).
Flows	Total number of flows of packets sent from the source to the destination address, in thousands (k) or millions (m).
Anomalies	Total number of anomalies in the anomaly table, in thousands (k) or millions (m).
Application	Configured application, such as FTP or telnet.

Monitoring IPSec Tunnels

IPSec tunnel information includes information about active IPSec tunnels configured on the Services Router, as well as traffic statistics through the tunnels. To view IPSec tunnel information, select **Monitor > IPSec** in the J-Web interface, or enter the following CLI `show` commands:

- `show services ipsec-vpn ipsec statistics`
- `show services ipsec-vpn ipsec security-associations`
- `show services ipsec-vpn ike security-associations`

Table 54 summarizes key output fields in IPSec displays.

Table 54: Summary of Key IPSec Output Fields

Field	Values
IPSec Tunnels	
Service Set	Name of the service set for which the IPSec tunnel is defined.
Rule	Name of the rule set applied to the IPSec tunnel.
Term	Name of the IPSec term applied to the IPSec tunnel.
Local Gateway	Gateway address of the local system.
Remote Gateway	Gateway address of the remote system.

Table 54: Summary of Key IPSec Output Fields (continued)

Field	Values
Direction	Direction of the IPSec tunnel: Inbound or Outbound .
Protocol	Protocol supported: either Encapsulation Security Protocol (ESP) or Authentication Header and ESP (AH+ESP).
Tunnel Index	Numeric identifier of the IPSec tunnel.
Tunnel Local Identity	Prefix and port number of the local endpoint of the IPSec tunnel.
Tunnel Remote Identity	Prefix and port number of the remote endpoint of the IPSec tunnel.
IPSec Statistics	
Service Set	Name of the service set for which the IPSec tunnel is defined.
Local Gateway	Gateway address of the local system.
Remote Gateway	Gateway address of the remote system.
ESP Encrypted Bytes	Total number of bytes encrypted by the local system across the IPSec tunnel.
ESP Decrypted Bytes	Total number of bytes decrypted by the local system across the IPSec tunnel.
AH Input Bytes	Total number of bytes received by the local system across the IPSec tunnel.
AH Output Bytes	Total number of bytes transmitted by the local system across the IPSec tunnel.
IKE Security	
Remote Address	Responder's address.
State	State of the IKE security association: <ul style="list-style-type: none"> ■ Matured—IKE security association is established. ■ Not matured—IKE security association is in the process of negotiation.
Initiator Cookie	Random number sent to the remote node when the IKE negotiation is triggered. This number is generated by means of an algorithm and information shared during the IKE negotiation. Cookies provide a basic form of authenticity protection to help prevent denial-of-service (DoS) attacks.
Responder Cookie	Random number generated by the remote node when it receives the initiator cookie. The remote node sends the cookie back to the IKE initiator as verification that the negotiation packets were received.
Exchange Type	Type of IKE exchange. The IKE exchange type determines the number of messages in the exchange and the payload types contained in each message. Each exchange type provides a particular set of security services, such as anonymity of the participants, perfect forward secrecy of the keying material, and authentication of the participants. J-series Services Routers support the following types of IKE exchanges: <ul style="list-style-type: none"> ■ Main—IKE exchange is done with six messages. The Main exchange type encrypts the payload, protecting the identity of the neighbor. ■ Aggressive—IKE exchange is done with three messages. The Aggressive exchange type does not encrypt the payload, leaving the identity of the neighbor unprotected.
Role	Role of the router in the IKE exchange: Initiator or Responder .
Authentication Method	Method used for IKE authentication. The type of authentication determines which payloads are exchanged and when they are exchanged. J-series Services Routers support only the pre-shared keys authentication type.
Local Address	Prefix and port number of the local tunnel endpoint.

Table 54: Summary of Key IPSec Output Fields (continued)

Field	Values
Remote Address	Prefix and port number of the remote tunnel endpoint.
Lifetime	Number of seconds remaining until the IKE security association expires.
Algorithm Authentication	Type of authentication algorithm used for the security association: md5 or sha1 .
Algorithm Encryption	Type of encryption algorithm used for the security association: des-cbc , 3des-cbc , or None .
Algorithm PRF	The pseudorandom function that generates highly unpredictable random numbers: hmac-md5 or hmac-sha1 .
Input Bytes	Number of bytes received on the IKE security association.
Output Bytes	Number of bytes transmitted on the IKE security association.
Input Packets	Number of packets received on the IKE security association.
Output Packets	Number of packets transmitted on the IKE security association.
IPSec Security Associations	Number of IPSec security associations that have been created and deleted on the router. Only security associations whose negotiations are complete are listed. When a security association is taken down, it is listed as a deleted security association.
Phase 2 Negotiations in Progress	Number of phase 2 IKE negotiations in progress.

Monitoring NAT Pools

NAT pool information includes information about the address ranges configured within the pool on the Services Router. To view NAT pool information, select **Monitor > NAT** in the J-Web interface, or enter the following CLI show command:

```
show services nat pool
```

Table 55 summarizes key output fields in NAT displays.

Table 55: Summary of Key NAT Output Fields

Field	Values
NAT Pools	
NAT Pool	Name of the NAT pool.
Pool Start Address	Lower address in the NAT pool address range.
Pool Address End	Upper address in the NAT pool address range.
Port High	Upper port in the NAT pool port range.

Table 55: Summary of Key NAT Output Fields (continued)

Field	Values
Port Low	Lower port in the NAT pool port range.
Ports In Use	Number of ports allocated in this NAT pool.

Monitoring DHCP

A Services Router can operate as a DHCP server. To view information about dynamic and static DHCP leases, conflicts, pools, and statistics, select **Monitor > DHCP** in the J-Web interface or enter the following CLI commands:

- `show system services dhcp binding`
- `show system services dhcp conflict`
- `show system services dhcp pool`
- `show system services dhcp statistics`

In addition, you can display the globally configured DHCP settings by using the `show system services global` command from the CLI.

Table 56 summarizes the output fields in DHCP displays.

Table 56: Summary of DHCP Output Fields

Field	Values	Additional Information
DHCP Leases		
Allocated Address	List of IP addresses the DHCP server has assigned to clients.	
MAC Address	Corresponding media access control (MAC) address of the client.	
Binding Type	Type of binding assigned to the client: dynamic or static .	DHCP servers can assign a dynamic binding from a pool of IP addresses or a static binding to one or more specific IP addresses.
Lease Expires	Date and time the lease expires, or never for leases that do not expire.	
DHCP Conflicts		
Detection Time	Date and time the client detected the conflict.	
Detection Method	How the conflict was detected.	Only client-detected conflicts are displayed.
Address	IP address where the conflict occurs.	The addresses in the conflicts list remain excluded until you use the <code>clear system services dhcp conflict</code> command to manually clear the list.

Table 56: Summary of DHCP Output Fields (continued)


Field	Values	Additional Information
DHCP Pools		
Pool Name	Subnet on which the IP address pool is defined.	
Low Address	Lowest address in the IP address pool.	
High Address	Highest address in the IP address pool.	
Excluded Addresses	Addresses excluded from the address pool.	
DHCP Statistics		
Default lease time	Lease time assigned to clients that do not request a specific lease time.	
Minimum lease time	Minimum time a client can retain an IP address lease on the server.	
Maximum lease time	Maximum time a client can retain an IP address lease on the server.	
Packets dropped	Total number of packets dropped and the number of packets dropped due to a particular condition.	
Messages received	Number of BOOTREQUEST, DHCPDECLINE, DHCPDISCOVER, DHCPINFORM, DHCPRELEASE, and DHCPREQUEST messages sent from DHCP clients and received by the DHCP server.	
Messages sent	Number of BOOTREPLY, DHCPACK, DHCPOFFER, and DHCPNAK messages sent from the DHCP server to DHCP clients.	

Monitoring RPM Probes

The RPM information includes the round-trip time, jitter, and standard deviation values for each configured RPM test on the Services Router. To view these RPM properties, select **Monitor > RPM** in the J-Web interface, or enter the following CLI show command:

```
show services rpm probe-results
```

In addition to the RPM statistics for each RPM test, the J-Web interface displays the round-trip times and cumulative jitter graphically. Figure 14 shows sample graphs for an RPM test.

Figure 14: Sample RPM Graphs

In Figure 14, the round-trip time and jitter values are plotted as a function of the system time. Large spikes in round-trip time or jitter indicate a slower outbound (egress) or inbound (ingress) time for the probe sent at that particular time.

Table 57 summarizes key output fields in RPM displays.

Table 57: Summary of Key RPM Output Fields

Field	Values	Additional Information
Currently Running Tests		
Graph		Click the Graph link to display the graph (if it is not already displayed) or to update the graph for a particular test.
Owner	Configured owner name of the RPM test.	

Table 57: Summary of Key RPM Output Fields (continued)

Field	Values	Additional Information
Test Name	Configured name of the RPM test.	
Probe Type	Type of RPM probe configured for the specified test. Following are valid probe types: <ul style="list-style-type: none"> ■ http-get ■ http-get-metadata ■ icmp-ping ■ icmp-ping-timestamp ■ tcp-ping ■ udp-ping 	
Target Address	IP address or URL of the remote server that is being probed by the RPM test.	
Source Address	Explicitly configured source address that is included in the probe packet headers.	If no source address is configured, the RPM probe packets use the outgoing interface as the source address, and the Source Address field is empty.
Minimum RTT	Shortest round-trip time from the Services Router to the remote server, as measured over the course of the test.	
Maximum RTT	Longest round-trip time from the Services Router to the remote server, as measured over the course of the test.	
Average RTT	Average round-trip time from the Services Router to the remote server, as measured over the course of the test.	
Standard Deviation RTT	Standard deviation of round-trip times from the Services Router to the remote server, as measured over the course of the test.	
Probes Sent	Total number of probes sent over the course of the test.	
Loss Percentage	Percentage of probes sent for which a response was not received.	
Round-Trip Time for a Probe		
Samples	Total number of probes used for the data set.	The Services Router maintains records of the most recent 50 probes for each configured test. These 50 probes are used to generate RPM statistics for a particular test.
Earliest Sample	System time when the first probe in the sample was received.	
Latest Sample	System time when the last probe in the sample was received.	
Mean Value	Average round-trip time for the 50-probe sample.	

Table 57: Summary of Key RPM Output Fields (continued)

Field	Values	Additional Information
Standard Deviation	Standard deviation of the round-trip times for the 50-probe sample.	
Lowest Value	Shortest round-trip time from the Services Router to the remote server, as measured over the 50-probe sample.	
Time of Lowest Sample	System time when the lowest value in the 50-probe sample was received.	
Highest Value	Longest round-trip time from the Services Router to the remote server, as measured over the 50-probe sample.	
Time of Highest Sample	System time when the highest value in the 50-probe sample was received.	
Cumulative Jitter for a Probe		
Samples	Total number of probes used for the data set.	The Services Router maintains records of the most recent 50 probes for each configured test. These 50 probes are used to generate RPM statistics for a particular test.
Earliest Sample	System time when the first probe in the sample was received.	
Latest Sample	System time when the last probe in the sample was received.	
Mean Value	Average jitter for the 50-probe sample.	
Standard Deviation	Standard deviation of the jitter values for the 50-probe sample.	
Lowest Value	Smallest jitter value, as measured over the 50-probe sample.	
Time of Lowest Sample	System time when the lowest value in the 50-probe sample was received.	
Highest Value	Highest jitter value, as measured over the 50-probe sample.	
Time of Highest Sample	System time when the highest jitter value in the 50-probe sample was received.	

Monitoring PPPoE

The PPPoE monitoring information is displayed in multiple parts. To display the session status for PPPoE interfaces, cumulative statistics for all PPPoE interfaces on the Services Router, and the PPPoE version configured on the Services Router, select **Monitor > PPPoE** in the J-Web interface.

To view interface-specific properties in the J-Web interface, select the interface name on the PPPoE page.

Alternatively, enter the following CLI commands in the operational mode:

- show pppoe interfaces
- show pppoe statistics
- show pppoe version

Table 58 summarizes key output fields in PPPoE displays.

You can also view status information about the PPPoE interface by selecting **Monitor > Interfaces > pp0**. Alternatively, enter the **show interfaces pp0** command. For more information about key output fields, see “Monitoring the Interfaces” on page 105.

Table 58: Summary of Key PPPoE Output Fields

Field	Values	Additional Information
PPPoE Interfaces		
Interface	Name of the PPPoE interface.	Click the interface name to display PPPoE information for the interface.
State	State of the PPPoE session on the interface.	
Session ID	Unique session identifier for the PPPoE session.	To establish a PPPoE session, first the Services Router acting as a PPPoE client obtains the Ethernet address of the PPPoE server or access concentrator, and then the client and the server negotiate a unique session ID. This process is refereed as PPPoE active discovery and is made up of four steps: initiation, offer, request, and session confirmation. The access concentrator generates the session ID for session confirmation and sends it to the PPPoE client in a PPPoE Active Discovery Session-Confirmation (PADS) packet.
Service Name	Type of service required from the access concentrator.	Service Name identifies the type of service provided by the access concentrator, such as the name of the Internet service provider (ISP), class, or quality of service.
Configured AC Name	Configured access concentrator name.	
Session AC Names	Name of the access concentrator.	
AC MAC Address	Media access control (MAC) address of the access concentrator.	
Session Uptime	Number of seconds the current PPPoE session has been running.	
Auto-Reconnect Timeout	Number of seconds to wait before reconnecting after a PPPoE session is terminated.	

Table 58: Summary of Key PPPoE Output Fields (continued)

Field	Values	Additional Information
Idle Timeout	Number of seconds a PPPoE session can be idle without disconnecting.	
Underlying Interface	Name of the underlying logical Ethernet or ATM interface on which PPPoE is running—for example, <code>fe-0/0/0.1</code> .	
PPPoE Statistics		
Active PPPoE Sessions	Total number of active PPPoE sessions.	
Packet Type	Packets sent and received during the PPPoE session, categorized by packet type and packet error: <ul style="list-style-type: none"> ■ PADI—PPPoE Active Discovery Initiation packets. ■ PADO—PPPoE Active Discovery Offer packets. ■ PADR—PPPoE Active Discovery Request packets. ■ PADS—PPPoE Active Discovery Session-Confirmation packets. ■ PADT—PPPoE Active Discovery Terminate packets. ■ Service Name Error—Packets for which the Service-Name request could not be honored. ■ AC System Error—Packets for which the access concentrator experienced an error in processing the host request. For example, the host had insufficient resources to create a virtual circuit. ■ Generic Error—Packets that indicate an unrecoverable error occurred. ■ Malformed Packet—Malformed or short packets that caused the packet handler to disregard the frame as unreadable. ■ Unknown Packet—Unrecognized packets. 	
Sent	Number of the specific type of packet sent from the PPPoE client.	
Received	Number of the specific type of packet received by the PPPoE client.	

Table 58: Summary of Key PPPoE Output Fields (continued)

Field	Values	Additional Information
Timeout	Information about the timeouts that occurred during the PPPoE session. <ul style="list-style-type: none"> ■ PADI—Number of timeouts that occurred for the PADI packet. ■ PADO—Number of timeouts that occurred for the PADO packet. (This value is always 0 and is not supported.) ■ PADR—Number of timeouts that occurred for the PADR packet. 	
Sent	Number of the timeouts that occurred for PADI, PADO, and PADR packets.	
PPPoE Version		
Maximum Sessions	Maximum number of active PPPoE sessions the Services Router can support. The default is 256 sessions.	
PADI Resend Timeout	Initial time, (in seconds) the Services Router waits to receive a PADO packet for the PADI packet sent—for example, 2 seconds. This timeout doubles for each successive PADI packet sent.	The PPPoE Active Discovery Initiation (PADI) packet is sent to the access concentrator to initiate a PPPoE session. Typically, the access concentrator responds to a PADI packet with a PPPoE Active Discovery Offer (PADO) packet. If the access concentrator does not send a PADO packet, the Services Router sends the PADI packet again after timeout period is elapsed. The PADI Resend Timeout doubles for each successive PADI packet sent. For example, if the PADI Resend Timeout is 2 seconds, the second PADI packet is sent after 2 seconds, the third after 4 seconds, the fourth after 8 seconds, and so on.
PADR Resend Timeout	Initial time (in seconds) the Services Router waits to receive a PADS packet for the PADR packet sent. This timeout doubles for each successive PADR packet sent.	The PPPoE Active Discovery Request (PADR) packet is sent to the access concentrator in response to a PADO packet, and to obtain the PPPoE session ID. Typically, the access concentrator responds to a PADR packet with a PPPoE Active Discovery Session-Confirmation (PADS) packet, which contains the session ID. If the access concentrator does not send a PADS packet, the Services Router sends the PADR packet again after the PADR Resend Timeout period is elapsed. The PADR Resend Timeout doubles for each successive PADR packet sent.
Maximum Resend Timeout	Maximum value (in seconds) that the PADI or PADR resend timer can accept—for example, 64 seconds. The maximum value is 64.	
Maximum Configured AC Timeout	Time (in seconds), within which the configured access concentrator must respond.	

Chapter 7

Using Services Router Diagnostic Tools

J-series Services Routers support a suite of J-Web tools and CLI operational mode commands for evaluating system health and performance. Diagnostic tools and commands test the connectivity and reachability of hosts in the network.

This chapter contains the following topics. For complete descriptions of CLI operational mode commands, see the *JUNOS System Basics and Services Command Reference*, the *JUNOS Interfaces Command Reference*, and the *JUNOS Routing Protocols and Policies Command Reference*.

- Diagnostic Terms on page 139
- Diagnostic Tools Overview on page 140
- Before You Begin on page 144
- Pinging Hosts from the J-Web Interface on page 145
- Checking MPLS Connections from the J-Web Interface on page 150
- Tracing Unicast Routes from the J-Web Interface on page 155
- Using CLI Diagnostic Commands on page 159

Diagnostic Terms

Before diagnosing J-series Services Routers, become familiar with the terms defined in Table 59.

Table 59: J-series Diagnostic Terms

Term	Definition
Don't Fragment (DF) bit	Bit in the IP header that instructs routers not to fragment a packet. You might set this bit if the destination host cannot reassemble the packet or if you want to test the path maximum transmission unit (MTU) for a destination host.
routing instance	Collection of routing tables, interfaces, and routing protocol interfaces. The set of interfaces belongs to the routing tables, and the routing protocol parameters control the information in the routing tables.

Table 59: J-series Diagnostic Terms (continued)

Term	Definition
loose source routing	Option in the IP header used to route a packet based on information supplied by the source. A gateway or host must route the packet using the routers specified by this information, but the packet can use other routers along the way.
strict source routing	Option in the IP header used to route a packet based on information supplied by the source. A gateway or host must route the packet exactly as specified by this information.
time to live (TTL)	Value (octet) in the IP header that is (usually) decremented by 1 for each hop the packet passes through. If the field reaches zero, the packet is discarded and a corresponding error message is sent to the source of the packet.
type of service (TOS)	Value (octet) in the IP header that defines the service the source host requests, such as the packet's priority and the preferred delay, throughput, and reliability.

Diagnostic Tools Overview

Use the J-Web Diagnose options to diagnose a Services Router. J-Web results are displayed in the browser.

You can also diagnose the router with CLI operational mode commands. CLI command output appears on the screen of your console or management device, or you can filter the output to a file.

This section contains the following topics. To filter output to a file, see “Filtering Command Output” on page 98.

- J-Web Diagnostic Tools Overview on page 140
- CLI Diagnostic Commands Overview on page 141
- MPLS Connection Checking on page 143

J-Web Diagnostic Tools Overview

The J-Web diagnostic tools consist of the options that appear when you select **Diagnose** and **Manage** in the task bar. Table 60 describes the functions of the Diagnose and Manage options.

Table 60: J-Web Interface Diagnose and Manage Options

Option	Function
Diagnose Options	
Ping Host	Allows you to ping a remote host. You can configure advanced options for the ping operation. For details, see “Using the J-Web Ping Host Tool” on page 146.

Table 60: J-Web Interface Diagnose and Manage Options (continued)

Option	Function
Ping MPLS	Allows you to ping an MPLS endpoint using various options. For details, see “MPLS Connection Checking” on page 143.
Traceroute	Allows you to trace a route between the Services Router and a remote host. You can configure advanced options for the traceroute operation. For details, see “Tracing Unicast Routes from the J-Web Interface ” on page 155.
Manage Options	
Files	Allows you manage log, temporary, and core files on the Services Router. For details, see “Managing Files with the J-Web Interface” on page 29.
Upgrade	Allows you to upgrade and manage Services Router software packages. For details, see “Performing Software Upgrades and Reboots” on page 211.
Licenses	Displays a summary of the licenses needed and used for each feature that requires a license. Allows you to add licenses. For details, see “Managing J-series Licenses with the J-Web Interface” on page 6.
Reboot	Allows you to reboot the Services Router at a specified time. For details, see “Rebooting or Halting a Services Router with the J-Web Interface” on page 230.

CLI Diagnostic Commands Overview

The CLI commands available in operational mode allow you to perform the same monitoring, troubleshooting, and management tasks you can perform with the J-Web interface. Instead of invoking the tools through a graphical interface, you use operational mode commands to perform the tasks.

Because the CLI is a superset of the J-Web interface, you can perform certain tasks only through the CLI. For example, you can use the `mtrace` command to display trace information about a multicast path from a source to a receiver, which is a feature available only through the CLI.

To view a list of top-level operational mode commands, type a question mark (?) at the command-line prompt. (See the *J-series Services Router Getting Started Guide*.)

At the top level of operational mode are the broad groups of CLI diagnostic commands listed in Table 61.

Table 61: CLI Diagnostic Command Summary

Command	Function
Controlling the CLI Environment	
<code>set option</code>	Configures the CLI display.

Table 61: CLI Diagnostic Command Summary (continued)

Command	Function
Diagnosis and Troubleshooting	
clear	Clears statistics and protocol database information.
mtrace	Traces information about multicast paths from source to receiver. For details, see “Tracing Multicast Routes from the CLI” on page 167.
monitor	Performs real-time debugging of various software components, including the routing protocols and interfaces. For details, see the following sections: <ul style="list-style-type: none"> ■ “Using the monitor interface Command” on page 172 ■ “Using the monitor traffic Command” on page 173 ■ “Displaying Log and Trace Files from the CLI” on page 171
ping	Determines the reachability of a remote network host. For details, see “Pinging Hosts from the CLI” on page 160.
ping mpls	Determines the reachability of an MPLS endpoint using various options. For details, see “MPLS Connection Checking” on page 143.
test	Tests the configuration and application of policy filters and AS path regular expressions.
traceroute	Traces the route to a remote network host. For details, see “Tracing Unicast Routes from the CLI” on page 166.
Connecting to Other Network Systems	
ssh	Opens secure shell connections. For details, see “Using the ssh Command” on page 47.
telnet	Opens telnet sessions to other hosts on the network. For details, see “Using the telnet Command” on page 47.
Management	
copy	Copies files from one location on the Services Router to another, from the router to a remote system, or from a remote system to the router.
restart <i>option</i>	Restarts the various JUNOS software processes, including the routing protocol, interface, and SNMP processes.
request	Performs system-level operations, including stopping and rebooting the Services Router and loading JUNOS software images.
start	Exits the CLI and starts a UNIX shell.

Table 61: CLI Diagnostic Command Summary (continued)

Command	Function
configuration	Enters configuration mode. For details, see the <i>J-series Services Router Getting Started Guide</i> .
quit	Exits the CLI and returns to the UNIX shell.

MPLS Connection Checking

Use either the J-Web ping MPLS diagnostic tool or the CLI `ping mpls` command to diagnose the state of label-switched paths (LSPs), Layer 2 and Layer 3 virtual private networks (VPNs), and Layer 2 circuits.

When you use the ping MPLS feature from a Services Router operating as the inbound (ingress) node at the entry point of an LSP or VPN, the router sends probe packets into the LSP or VPN. Based on how the LSP or VPN outbound (egress) node at the remote endpoint of the connection replies to the probes, you can determine the connectivity of the LSP or VPN.

Each probe is an echo request sent to the LSP or VPN exit point as an MPLS packet with a UDP payload. If the outbound node receives the echo request, it checks the contents of the probe and returns a value in the UDP payload of the response packet. If the Services Router receives the response packet, it reports a successful ping response.

Responses that take longer than 2 seconds are identified as failed probes.

Table 62 summarizes the options for using either the J-Web ping MPLS diagnostic tool or the CLI `ping mpls` command to display information about MPLS connections in VPNs and LSPs.

Table 62: Options for Checking MPLS Connections

J-Web Ping MPLS Tool	ping mpls Command	Purpose	Additional Information
Ping RSVP-signaled LSP	<code>ping mpls rsvp</code>	Checks the operability of an LSP that has been set up by the Resource Reservation Protocol (RSVP). The Services Router pings a particular LSP using the configured LSP name.	When an RSVP-signaled LSP has several paths, the Services Router sends the ping requests on the path that is currently active.
Ping LDP-signaled LSP	<code>ping mpls ldp</code>	Checks the operability of an LSP that has been set up by the Label Distribution Protocol (LDP). The Services Router pings a particular LSP using the forwarding equivalence class (FEC) prefix and length.	When an LDP-signaled LSP has several gateways, the Services Router sends the ping requests through the first gateway. Ping requests sent to LDP-signaled LSPs use only the master routing instance.

Table 62: Options for Checking MPLS Connections (continued)

J-Web Ping MPLS Tool	ping mpls Command	Purpose	Additional Information
Ping LSP to Layer 3 VPN prefix	ping mpls l3vpn	Checks the operability of the connections related to a Layer 3 VPN. The Services Router tests whether a prefix is present in a provider edge (PE) router's VPN routing and forwarding (VRF) table, by means of a Layer 3 VPN destination prefix.	The Services Router does not test the connection between a PE router and a customer edge (CE) router.
Locate LSP using interface name	ping mpls l2vpn interface	Checks the operability of the connections related to a Layer 2 VPN. The Services Router directs outgoing request probes out the specified interface.	
Instance to which this connection belongs	ping mpls l2vpn instance	Checks the operability of the connections related to a Layer 2 VPN. The Services Router pings on a combination of the Layer 2 VPN routing instance name, the local site identifier, and the remote site identifier, to test the integrity of the Layer 2 VPN circuit (specified by the identifiers) between the inbound and outbound PE routers.	
Locate LSP from interface name	ping mpls l2circuit interface	Checks the operability of the Layer 2 circuit connections. The Services Router directs outgoing request probes out the specified interface.	
Locate LSP from virtual circuit information	ping mpls l2circuit virtual-circuit	Checks the operability of the Layer 2 circuit connections. The Services Router pings on a combination of the IPv4 prefix and the virtual circuit identifier on the outbound PE router, testing the integrity of the Layer 2 circuit between the inbound and outbound PE routers.	
Ping end point of LSP	ping mpls lsp-end-point	Checks the operability of an LSP endpoint. The Services Router pings an LSP endpoint using either an LDP FEC prefix or an RSVP LSP endpoint address.	

Before You Begin

This section includes the following topics:

- General Preparation on page 145

- Ping MPLS Preparation on page 145

General Preparation

To use the J-Web interface and CLI operational tools, you must have the appropriate access privileges. For more information about configuring access privilege levels, see “Adding New Users” on page 27 and the *JUNOS System Basics Configuration Guide*.

Ping MPLS Preparation

Before using the ping MPLS feature, make sure that the receiving interface on the VPN or LSP remote endpoint has MPLS enabled, and that the loopback interface on the outbound node is configured as 127.0.0.1. The source address for MPLS probes must be a valid address on the Services Router.

MPLS Enabled

To process ping MPLS requests, the remote endpoint of the VPN or LSP must be configured appropriately. You must enable MPLS on the receiving interface of the outbound node for the VPN or LSP. If MPLS is not enabled, the remote endpoint drops the incoming request packets and returns an “ICMP host unreachable” message to the Services Router. To enable MPLS on an interface, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

Loopback Address

The loopback address (lo0) on the outbound node must be configured as 127.0.0.1. If this interface address is not configured correctly, the outbound node does not have this forwarding entry. It drops the incoming request packets and returns a “host unreachable” message to the Services Router. If the outbound node is a Services Router, see the *J-series Services Router Advanced WAN Access Configuration Guide* to configure the loopback address.

Source Address for Probes

The source IP address you specify for a set of probes must be an address configured on one of the Services Router interfaces. If it is not a valid Services Router address, the ping request fails with the error message “Can’t assign requested address.”

Pinging Hosts from the J-Web Interface

This section contains the following topics:

- Using the J-Web Ping Host Tool on page 146
- Ping Host Results and Output Summary on page 149

Using the J-Web Ping Host Tool

You can ping a host to verify that the host can be reached over the network. The output is useful for diagnosing host and network connectivity problems. The Services Router sends a series of ICMP echo (ping) requests to a specified host and receives ICMP echo responses.

Alternatively, you can use the CLI `ping` command. (See “Pinging Hosts from the CLI” on page 160.)

To use the ping host tool:

1. Select **Diagnose > Ping Host** from the task bar.
2. Next to Advanced options, click the expand icon (see Figure 15).
3. Enter information into the Ping Host page, as described in Table 63.

The Remote Host field is the only required field.

4. Click **Start**.

The results of the ping operation are displayed in the main pane (see Figure 16). If no options are specified, each ping response is in the following format:

```
bytes bytes from ip-address: icmp_seq=number ttl=number time=time
```

Table 64 summarizes the output fields of the display.

5. To stop the ping operation before it is complete, click **OK**.

Figure 15: Ping Host Page

Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor **Configuration** **Diagnose** **Manage**

[Diagnose](#) > [Ping Host](#)

► **Ping Host**

► **Traceroute**

Ping Host

The ping diagnostic tool sends a series of ICMP "echo request" packets to the specified remote host.

The receipt of such packets will usually result in the remote host replying with an ICMP "echo response." Note that some hosts are configured not to respond to ICMP "echo requests," so a lack of responses does not necessarily represent a connectivity problem. Also, some firewalls block the ICMP packet types that ping uses, so you may find that you are not able to ping outside your local network.

Entering a host below creates a periodic ping task that will run until cancelled or until it times out as specified.

* **Remote Host** ?

+ **Advanced options**

Start

Table 63: J-Web Ping Host Field Summary

Field	Function	Your Action
Remote Host	Identifies the host to ping.	Type the hostname or IP address of the host to ping.
Advanced Options		
Don't Resolve Addresses	Determines whether to display hostnames of the hops along the path.	<ul style="list-style-type: none"> ■ To suppress the display of the hop hostnames, select the check box. ■ To display the hop hostnames, clear the check box.
Interface	Specifies the interface on which the ping requests are sent.	From the list, select the interface on which ping requests are sent. If you select any , the ping requests are sent on all interfaces.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send.

Table 63: J-Web Ping Host Field Summary (continued)

Field	Function	Your Action
Don't Fragment	Specifies the Don't Fragment (DF) bit in the IP header of the ping request packet.	<ul style="list-style-type: none"> ■ To set the DF bit, select the check box. ■ To clear the DF bit, clear the check box.
Record Route	Sets the record route option in the IP header of the ping request packet. The path of the ping request packet is recorded within the packet and displayed in the main pane.	<ul style="list-style-type: none"> ■ To record and display the path of the packet, select the check box. ■ To suppress the recording and display of the path of the packet, clear the check box.
Type-of-Service	Specifies the type-of-service (TOS) value in the IP header of the ping request packet.	From the list, select the decimal value of the TOS field.
Routing Instance	Name of the routing instance for the ping attempt.	From the list, select the routing instance name.
Interval	Specifies the interval, in seconds, between the transmission of each ping request.	From the list, select the interval.
Packet Size	Specifies the size of the ping request packet.	Type the size, in bytes, of the packet. The size can be from 0 through 65468. The router adds 8 bytes of ICMP header to the size.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address.
Time-to-Live	Specifies the time-to-live (TTL) hop count for the ping request packet.	From the list, select the TTL.
Bypass Routing	<p>Determines whether ping requests are routed by means of the routing table.</p> <p>If the routing table is not used, ping requests are sent only to hosts on the interface specified in the Interface box. If the host is not on that interface, ping responses are not sent.</p>	<ul style="list-style-type: none"> ■ To bypass the routing table and send the ping requests to hosts on the specified interface only, select the check box. ■ To route the ping requests using the routing table, clear the check box.

Figure 16: Ping Host Results Page

Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / Configuration / **Diagnose** / Manage

Diagnose > Ping Host

► Ping Host

► Traceroute

Ping Host

Ping 172.17.28.19

```

PING 172.17.28.19 (172.17.28.19): 56 data bytes
64 bytes from 172.17.28.19: icmp_seq=0 ttl=61 time=0.579 ms
64 bytes from 172.17.28.19: icmp_seq=1 ttl=61 time=0.473 ms
64 bytes from 172.17.28.19: icmp_seq=2 ttl=61 time=0.455 ms
64 bytes from 172.17.28.19: icmp_seq=3 ttl=61 time=0.491 ms
64 bytes from 172.17.28.19: icmp_seq=4 ttl=61 time=0.493 ms
64 bytes from 172.17.28.19: icmp_seq=5 ttl=61 time=0.387 ms
64 bytes from 172.17.28.19: icmp_seq=6 ttl=61 time=0.534 ms
64 bytes from 172.17.28.19: icmp_seq=7 ttl=61 time=0.529 ms
64 bytes from 172.17.28.19: icmp_seq=8 ttl=61 time=0.445 ms
64 bytes from 172.17.28.19: icmp_seq=9 ttl=61 time=0.367 ms
--- 172.17.28.19 ping statistics ---
10 packets transmitted, 10 packets received, 0% packet loss
round-trip min/avg/max/stddev = 0.367/0.475/0.579/0.062 ms

```

OK

Ping Host Results and Output Summary

Table 64 summarizes the output in the ping host display. If the Services Router receives no ping responses from the destination host, review the list after Table 64 for a possible explanation.

Table 64: J-Web Ping Host Results and Output Summary

Field	Description
<i>bytes</i> bytes from <i>ip-address</i>	<ul style="list-style-type: none"> <i>bytes</i> —Size of ping response packet, which is equal to the value you entered in the Packet Size box, plus 8. <i>ip-address</i> —IP address of destination host that sent the ping response packet.
icmp_seq= <i>number</i>	<i>number</i> —Sequence Number field of the ping response packet. You can use this value to match the ping response to the corresponding ping request.
ttl= <i>number</i>	<i>number</i> —Time-to-live hop-count value of the ping response packet.

Table 64: J-Web Ping Host Results and Output Summary (continued)

Field	Description
<code>time= time</code>	<i>time</i> —Total time between the sending of the ping request packet and the receiving of the ping response packet, in milliseconds. This value is also called round-trip time.
<code>number</code> packets transmitted	<i>number</i> —Number of ping requests (probes) sent to host.
<code>number</code> packets received	<i>number</i> —Number of ping responses received from host.
<code>percentage</code> packet loss	<i>percentage</i> —Number of ping responses divided by the number of ping requests, specified as a percentage.
round-trip min/avg/max/stddev = <code>min-time / avg-time / max-time / std-dev</code> ms	<ul style="list-style-type: none"> ■ <i>min-time</i> —Minimum round-trip time (see <code>time= time</code> field in this table). ■ <i>avg-time</i> —Average round-trip time. ■ <i>max-time</i> —Maximum round-trip time. ■ <i>std-dev</i> —Standard deviation of the round-trip times.

If the Services Router does not receive ping responses from the destination host (the output shows a packet loss of 100 percent), one of the following explanations might apply:

- The host is not operational.
- There are network connectivity problems between the Services Router and the host.
- The host might be configured to ignore ICMP echo requests.
- The host might be configured with a firewall filter that blocks ICMP echo requests or ICMP echo responses.
- The size of the ICMP echo request packet exceeds the MTU of a host along the path.
- The value you selected in the Time-to-Live box was less than the number of hops in the path to the host, in which case the host might reply with an ICMP error message.

For more information about ICMP, see RFC 792, *Internet Control Message Protocol*.

Checking MPLS Connections from the J-Web Interface

Use the J-Web ping MPLS diagnostic tool to diagnose the state of label-switched paths (LSPs), Layer 2 and Layer 3 VPNs, and Layer 2 circuits.

Alternatively, you can use the CLI commands `ping mpls`, `ping mpls l2circuit`, `ping mpls l2vpn`, and `ping mpls l3vpn`. For more information, see “Pinging Hosts from the CLI” on page 160.

Before using the J-Web ping MPLS tool in your network, read “Ping MPLS Preparation” on page 145.

This section contains the following topics:

- Using the J-Web Ping MPLS Tool on page 151
- Ping MPLS Results and Output on page 154

Using the J-Web Ping MPLS Tool

Before using the ping MPLS feature, make sure that the receiving interface on the VPN or LSP remote endpoint has MPLS enabled, and that the loopback interface on the outbound node is configured as 127.0.0.1. The source address for MPLS probes must be a valid address on the Services Router.

To use the ping MPLS tool:

1. Select **Diagnose > Ping MPLS** from the task bar.
2. Next to the ping MPLS option you want to use, click the expand icon (see Figure 17).
3. Enter information into the Ping MPLS page, as described in Table 65.
4. Click **Start**.

Table 66 summarizes the output fields of the display.

5. To stop the ping operation before it is complete, click **OK**.

Figure 17: Ping MPLS Page

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage** / **Alarms**

[Diagnose](#) > [Ping MPLS](#)

Ping MPLS

Use the Ping MPLS diagnostic tool to send variations of ICMP "echo request" packets to the specified MPLS endpoint.

☐ **Ping RSVP-signaled LSP**

* LSP Name Count

Source Address Detailed Output ☐

☐ **Ping LDP-signaled LSP**

Table 65: J-Web Ping MPLS Field Summary

Field	Function	Your Action
Ping RSVP-signaled LSP		
LSP Name	Identifies the LSP to ping.	Type the name of the LSP to ping.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send. The default is 5 requests.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
Ping LDP-signaled LSP		
FEC Prefix	Identifies the LSP to ping.	Type the forwarding equivalence class (FEC) prefix and length of the LSP to ping.

Table 65: J-Web Ping MPLS Field Summary (continued)

Field	Function	Your Action
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send. The default is 5 requests.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
Ping LSP to Layer 3 VPN prefix		
Layer 3 VPN Name	Identifies the Layer 3 VPN to ping.	Type the name of the VPN to ping.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send. The default is 5 requests.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
VPN Prefix	Identifies the IP address prefix and length of the Layer 3 VPN to ping.	Type the IP address prefix and length of the VPN to ping.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Locate LSP using interface name		
Interface	Specifies the interface on which the ping requests are sent.	From the list, select the Services Router interface on which ping requests are sent. If you select any , the ping requests are sent on all interfaces.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send. The default is 5 requests.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
Instance to which this connection belongs		
Layer 2VPN Name	Identifies the Layer 2 VPN to ping.	Type the name of the VPN to ping.
Remote Site Identifier	Specifies the remote site identifier of the Layer 2 VPN to ping.	Type the remote site identifier for the VPN.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Local Site Identifier	Specifies the local site identifier of the Layer 2 VPN to ping.	Type the local site identifier for the VPN.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send. The default is 5 requests.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
Locate LSP from interface name		

Table 65: J-Web Ping MPLS Field Summary (continued)

Field	Function	Your Action
Interface	Specifies the interface on which the ping requests are sent.	From the list, select the Services Router interface on which ping requests are sent. If you select any , the ping requests are sent on all interfaces.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send. The default is 5 requests.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
Locate LSP from virtual circuit information		
Remote Neighbor	Identifies the remote neighbor (PE router) within the virtual circuit to ping.	Type the IP address of the remote neighbor within the virtual circuit.
Circuit Identifier	Specifies the virtual circuit identifier for the Layer 2 circuit to ping.	Type the virtual circuit identifier for the Layer 2 circuit.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.
Ping end point of LSP		
VPN Prefix	Identifies the LSP endpoint to ping.	Type either the LDP FEC prefix and length or the RSVP LSP endpoint address for the LSP to ping.
Source Address	Specifies the source address of the ping request packet.	Type the source IP address—a valid address configured on a Services Router interface.
Count	Specifies the number of ping requests to send.	From the list, select the number of ping requests to send.
Detailed Output	Requests the display of extensive rather than brief ping output.	Select the check box to display detailed output.

Ping MPLS Results and Output

Table 66 summarizes the output in the ping MPLS display. If the Services Router receives no responses from the destination host, review the list after Table 66 for a possible explanation.

Table 66: J-Web Ping MPLS Results and Output Summary

Field	Description
Exclamation point (!)	Echo reply was received.
Period (.)	Echo reply was not received within the timeout period.

Table 66: J-Web Ping MPLS Results and Output Summary (continued)

Field	Description
x	Echo reply was received with an error code. Errored packets are not counted in the received packets count and are accounted for separately.
<i>number</i> packets transmitted	<i>number</i> —Number of ping requests (probes) sent to a host.
<i>number</i> packets received	<i>number</i> —Number of ping responses received from a host.
<i>percentage</i> packet loss	<i>percentage</i> —Number of ping responses divided by the number of ping requests, specified as a percentage.
time	For Layer 2 circuits only, the number of milliseconds required for the ping packet to reach the destination. This value is approximate, because the packet has to reach the Routing Engine.

If the Services Router does not receive ping responses from the destination host (the output shows a packet loss of 100 percent), one of the following explanations might apply:

- The host is not operational.
- There are network connectivity problems between the Services Router and the host.
- The host might be configured to ignore echo requests.
- The host might be configured with a firewall filter that blocks echo requests or echo responses.
- The size of the echo request packet exceeds the MTU of a host along the path.
- The outbound node at the remote endpoint is not configured to handle MPLS packets.
- The remote endpoint's loopback address is not configured to 127.0.0.1.

Tracing Unicast Routes from the J-Web Interface

You can use the traceroute diagnostic tool to display a list of routers between the Services Router and a specified destination host. The output is useful for diagnosing a point of failure in the path from the Services Router to the destination host, and addressing network traffic latency and throughput problems.

The Services Router generates the list of routers by sending a series of ICMP traceroute packets in which the time-to-live (TTL) value in the messages sent to each successive router is incremented by 1. (The TTL value of the first traceroute packet is set to 1.) In this manner, each router along the path to the destination host replies with a Time Exceeded packet from which the source IP address can be obtained.

Alternatively, you can use the CLI `traceroute` command to generate the list.

This section contains the following topics:

- Using the J-Web Traceroute Tool on page 156
- Traceroute Results and Output Summary on page 158

Using the J-Web Traceroute Tool

To use the traceroute tool:

1. Select **Diagnose > Traceroute**.
2. Next to Advanced options, click the expand icon (see Figure 18).
3. Enter information into the Traceroute page, as described in Table 67.

The **Remote Host** field is the only required field.

4. Click **Start**.

The results of the traceroute operation are displayed in the main pane. If no options are specified, each line of the traceroute display is in the following format:


```
hop-number host ( ip-address ) [ as-number ] time1 time2 time3
```

The Services Router sends a total of three traceroute packets to each router along the path and displays the round-trip time for each traceroute operation. If the Services Router times out before receiving a **Time Exceeded** message, an asterisk (*) is displayed for that round-trip time.

Table 68 summarizes the output fields of the display.

5. To stop the traceroute operation before it is complete, click **OK** while the results of the traceroute operation are being displayed.

Figure 18: Traceroute Page



Juniper NETWORKS

ROUTER - J4300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage**

[Diagnose > Traceroute](#)

► Ping Host

► Traceroute

Traceroute

Traceroute to Host

The traceroute diagnostic tool uses a series of packets crafted to elicit an ICMP "time exceeded" messages from intermediate points in the network between your router and the specified host.

The time-to-live for a packet is decremented each time the packet is routed, so traceroute generally receives at least one "time exceeded" response from each waypoint. Traceroute starts with a packet with a time-to-live value of one, and increments the time to live for subsequent packets, thereby constructing a rudimentary map of the path between hosts.

Entering a host below creates a traceroute task that will run until the traceroute is complete or until it fails due to time out.

* Remote Host ?

+ Advanced options

Start

Table 67: Traceroute Field Summary

Field	Function	Your Action
Remote Host	Identifies the destination host of the traceroute.	Type the hostname or IP address of the destination host.
Advanced Options		
Don't Resolve Addresses	Determines whether hostnames of the hops along the path are displayed, in addition to IP addresses.	<ul style="list-style-type: none"> ■ To suppress the display of the hop hostnames, select the check box. ■ To display the hop hostnames, clear the check box.
Gateway	Specifies the IP address of the gateway to route through.	Type the gateway IP address.
Source Address	Specifies the source address of the outgoing traceroute packets.	Type the source IP address.

Table 67: Traceroute Field Summary (continued)

Field	Function	Your Action
Bypass Routing	Determines whether traceroute packets are routed by means of the routing table. If the routing table is not used, traceroute packets are sent only to hosts on the interface specified in the Interface box. If the host is not on that interface, traceroute responses are not sent.	<ul style="list-style-type: none"> ■ To bypass the routing table and send the traceroute packets to hosts on the specified interface only, select the check box. ■ To route the traceroute packets by means of the routing table, clear the check box.
Interface	Specifies the interface on which the traceroute packets are sent.	From the list, select the interface on which traceroute packets are sent. If you select any , the traceroute requests are sent on all interfaces.
Time-to-Live	Specifies the maximum time-to-live (TTL) hop count for the traceroute request packet.	From the list, select the TTL.
Type-of-Service	Specifies the type-of-service (TOS) value to include in the IP header of the traceroute request packet.	From the list, select the decimal value of the TOS field.
Resolve AS Numbers	Determines whether the autonomous system (AS) number of each intermediate hop between the router and the destination host is displayed.	<ul style="list-style-type: none"> ■ To display the AS numbers, select the check box. ■ To suppress the display of the AS numbers, clear the check box.

Traceroute Results and Output Summary

Table 68 summarizes the output in the traceroute display. If the Services Router receives no responses from the destination host, review the list after Table 68 for a possible explanation.

Table 68: J-Web Traceroute Results and Output Summary

Field	Description
<i>hop-number</i>	Number of the hop (router) along the path.
<i>host</i>	Hostname, if available, or IP address of the router. If the Don't Resolve Addresses check box is selected, the hostname is not displayed.
<i>ip-address</i>	IP address of the router.
<i>as-number</i>	AS number of the router.
<i>time1</i>	Round-trip time between the sending of the first traceroute packet and the receiving of the corresponding Time Exceeded packet from that particular router.

Table 68: J-Web Traceroute Results and Output Summary (continued)

Field	Description
<i>time2</i>	Round-trip time between the sending of the second traceroute packet and the receiving of the corresponding Time Exceeded packet from that particular router.
<i>time3</i>	Round-trip time between the sending of the third traceroute packet and the receiving of the corresponding Time Exceeded packet from that particular router.

If the Services Router does not display the complete path to the destination host, one of the following explanations might apply:

- The host is not operational.
- There are network connectivity problems between the Services Router and the host.
- The host, or a router along the path, might be configured to ignore ICMP traceroute messages.
- The host, or a router along the path, might be configured with a firewall filter that blocks ICMP traceroute requests or ICMP time exceeded responses.
- The value you selected in the Time Exceeded box was less than the number of hops in the path to the host. In this case, the host might reply with an ICMP error message.

For more information about ICMP, see RFC 792, *Internet Control Message Protocol*.

Using CLI Diagnostic Commands

Because the CLI is a superset of the J-Web interface, you can perform certain tasks only through the CLI. For an overview of the CLI operational mode commands, along with instructions for filtering command output, see “CLI Diagnostic Commands Overview” on page 141.

This section contains the following topics:

- Pinging Hosts from the CLI on page 160
- Checking MPLS Connections from the CLI on page 161
- Tracing Unicast Routes from the CLI on page 166
- Tracing Multicast Routes from the CLI on page 167
- Displaying Log and Trace Files from the CLI on page 171
- Monitoring Interfaces and Traffic from the CLI on page 171

Pinging Hosts from the CLI

Use the CLI ping command to verify that a host can be reached over the network. This command is useful for diagnosing host and network connectivity problems. The Services Router sends a series of ICMP echo (ping) requests to a specified host and receives ICMP echo responses.

Alternatively, you can use the J-Web interface. (See “Using the J-Web Ping Host Tool” on page 146.)

Enter the ping command with the following syntax. Table 69 describes the ping command options.

```
user@host> ping host <interface source-interface> <bypass-routing>
<count number> <do-not-fragment> <inet | inet6> <interval seconds>
<logical-router logical-router-name> <loose-source [ hosts ]>
<no-resolve> <pattern string> <rapid> <record-route>
<routing-instance routing-instance-name> <size bytes>
<source source-address> <strict> <strict-source [ hosts ]>
<tos number> <ttl number> <wait seconds> <detail> <verbose>
```

To quit the ping command, press Ctrl-C.

Table 69: CLI ping Command Options

Option	Description
<i>host</i>	Pings the hostname or IP address you specify.
<i>interface source-interface</i>	(Optional) Sends the ping requests on the interface you specify. If you do not include this option, ping requests are sent on all interfaces.
<i>bypass-routing</i>	(Optional) Bypasses the routing tables and sends the ping requests only to hosts on directly attached interfaces. If the host is not on a directly attached interface, an error message is returned. Use this option to ping a local system through an interface that has no route through it.
<i>count number</i>	(Optional) Limits the number of ping requests to send. Specify a count from 1 through 2,000,000,000. If you do not specify a count, ping requests are continuously sent until you press Ctrl-C.
<i>do-not-fragment</i>	(Optional) Sets the Don't Fragment (DF) bit in the IP header of the ping request packet.
<i>inet</i>	(Optional) Forces the ping requests to an IPv4 destination.
<i>inet6</i>	(Optional) Forces the ping requests to an IPv6 destination.
<i>interval seconds</i>	(Optional) Sets the interval between ping requests, in seconds. Specify an interval from 0.1 through 10,000. The default value is 1 second.
<i>loose-source [hosts]</i>	(Optional) For IPv4, sets the loose source routing option in the IP header of the ping request packet.
<i>no-resolve</i>	(Optional) Suppresses the display of the hostnames of the hops along the path.
<i>pattern string</i>	(Optional) Includes the hexadecimal string you specify, in the ping request packet.
<i>rapid</i>	(Optional) Sends ping requests rapidly. The results are reported in a single message, not in individual messages for each ping request. By default, five ping requests are sent before the results are reported. To change the number of requests, include the count option.

Table 69: CLI ping Command Options (continued)

Option	Description
record-route	(Optional) For IPv4, sets the record route option in the IP header of the ping request packet. The path of the ping request packet is recorded within the packet and displayed on the screen.
routing-instance routing-instance-name	(Optional) Uses the routing instance you specify for the ping request.
size bytes	(Optional) Sets the size of the ping request packet. Specify a size from 0 through 65,468. The default value is 56 bytes, which is effectively 64 bytes because 8 bytes of ICMP header data are added to the packet.
source source-address	(Optional) Uses the source address that you specify, in the ping request packet.
strict	(Optional) For IPv4, sets the strict source routing option in the IP header of the ping request packet.
strict-source [hosts]	(Optional) For IPv4, sets the strict source routing option in the IP header of the ping request packet, and uses the list of hosts you specify for routing the packet.
tos number	(Optional) Sets the type-of-service (TOS) value in the IP header of the ping request packet. Specify a value from 0 through 255.
ttl number	(Optional) Sets the time-to-live (TTL) value for the ping request packet. Specify a value from 0 through 255.
wait seconds	(Optional) Sets the maximum time to wait after sending the last ping request packet. If you do not specify this option, the default delay is 10 seconds. If you use this option without the count option, the Services Router uses a default count of 5 packets.
detail	(Optional) Displays the interface on which the ping response was received.
verbose	(Optional) Displays detailed output.

Following is sample output from a ping command:

```

user@host> ping host3 count 4
PING host3.site.net (176.26.232.111): 56 data bytes
64 bytes from 176.26.232.111: icmp_seq=0 ttl=122 time=0.661 ms
64 bytes from 176.26.232.111: icmp_seq=1 ttl=122 time=0.619 ms
64 bytes from 176.26.232.111: icmp_seq=2 ttl=122 time=0.621 ms
64 bytes from 176.26.232.111: icmp_seq=3 ttl=122 time=0.634 ms

--- host3.site.net ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max/stddev = 0.619/0.634/0.661/0.017 ms

```

The fields in the display are the same as those displayed by the J-Web ping host diagnostic tool. For information, see “Ping Host Results and Output Summary” on page 149.

Checking MPLS Connections from the CLI

Use the ping mpls commands to diagnose the state of LSPs, Layer 2 and Layer 3 VPNs, and Layer 2 circuits. When you issue a command from a Services Router operating as the inbound node at the entry point of an LSP or VPN, the router sends probe packets into the LSP or VPN. Based on how the LSP or VPN outbound node at

the remote endpoint of the connection replies to the probes, you can determine the connectivity of the LSP or VPN.

Each probe is an echo request sent to the LSP or VPN exit point as an MPLS packet with a UDP payload. If the outbound node receives the echo request, it checks the contents of the probe and returns a value in the UDP payload of the response packet. If the Services Router receives the response packet, it reports a successful ping response. Responses that take longer than 2 seconds are identified as failed probes.

Alternatively, you can use the J-Web ping MPLS tool. For more information, see “Checking MPLS Connections from the J-Web Interface” on page 150.

Before using `ping mpls` commands in your network, read “Ping MPLS Preparation” on page 145.

The `ping mpls` commands diagnose the connectivity of MPLS and VPN networks in the following ways:

- Pinging RSVP-Signaled LSPs and LDP-Signaled LSPs on page 162
- Pinging Layer 3 VPNs on page 163
- Pinging Layer 2 VPNs on page 164
- Pinging Layer 2 Circuits on page 165

Pinging RSVP-Signaled LSPs and LDP-Signaled LSPs

Enter the `ping mpls` command with the following syntax. Table 70 describes the `ping mpls` command options.

```
user@host> ping mpls (ldp fec | lsp-end-point prefix-name
| rsvp lsp-name) <exp forwarding-class> <count number>
<source source-address> <detail>
```

To quit the `ping mpls` command, press Ctrl-C.

Alternatively, you can use the J-Web interface. (See “Checking MPLS Connections from the J-Web Interface” on page 150.)

Table 70: CLI `ping mpls ldp` and `ping mpls lsp-end-point` Command Options

Option	Description
<code>ldp fec</code>	Pings an LDP-signaled LSP identified by the forwarding equivalence class (FEC) prefix and length.
<code>lsp-end-point prefix-name</code>	Pings an LSP endpoint using either an LDP FEC or a RSVP LSP endpoint address.
<code>rsvp lsp-name</code>	Pings an RSVP-signaled LSP identified by the specified LSP name.
<code>exp forwarding-class</code>	(Optional) Specifies the value of the forwarding class to be used in the MPLS ping packets.

Table 70: CLI ping mpls ldp and ping mpls lsp-end-point Command Options (continued)

Option	Description
count <i>number</i>	(Optional) Limits the number of ping requests to send. Specify a count from 0 through 1,000,000. The default value is 5. If you do not specify a count, ping requests are continuously sent until you press Ctrl-C.
source <i>source-address</i>	(Optional) Uses the source address that you specify, in the ping request packet.
detail	(Optional) Displays detailed output about the echo requests sent and received. Detailed output includes the MPLS labels used for each request and the return codes for each request.

Following is sample output from a ping mpls command:

```

user@host> ping mpls rsvp count 5
!!xxx
--- lsping statistics ---
5 packets transmitted, 2 packets received, 60% packet loss
3 packets received with error status, not counted as received.
```

The fields in the display are the same as those displayed by the J-Web ping MPLS diagnostic tool. For information, see “Ping MPLS Results and Output” on page 154.

Pinging Layer 3 VPNs

Enter the ping mpls l3vpn command with the following syntax. Table 71 describes the ping mpls l3vpn command options.

```

user@host> ping mpls l3vpn prefix prefix-name <l3vpn-name>
<bottom-label-ttl> <exp forwarding-class> <count number>
<source source-address> <detail>
```

To quit the ping mpls l3vpn command, press Ctrl-C.

Alternatively, you can use the J-Web interface. (See “Checking MPLS Connections from the J-Web Interface” on page 150.)

Table 71: CLI ping mpls l3vpn Command Options

Option	Description
l3vpn prefix <i>prefix-name</i>	Pings the remote host specified by the prefix to verify that the prefix is present in the PE router’s VPN routing and forwarding (VRF) table. This option does not test the connectivity between a PE router and a CE router.
<i>l3vpn-name</i>	(Optional) Layer 3 VPN name.
bottom-label-ttl	(Optional) Displays the time-to-live (TTL) value for the bottom label in the MPLS label stack.
exp <i>forwarding-class</i>	(Optional) Specifies the value of the forwarding class to be used in the MPLS ping packets.
count <i>number</i>	(Optional) Limits the number of ping requests to send. Specify a count from 0 through 1,000,000. The default value is 5. If you do not specify a count, ping requests are continuously sent until you press Ctrl-C.

Table 71: CLI ping mpls l3vpn Command Options (continued)

Option	Description
source <i>source-address</i>	(Optional) Uses the source address that you specify, in the ping request packet.
detail	(Optional) Displays detailed output about the echo requests sent and received. Detailed output includes the MPLS labels used for each request and the return codes for each request.

Following is sample output from a ping mpls l3vpn command:

```

user@host> ping mpls l3vpn vpn1 prefix 10.255.245.122/32
!!!!
--- lsping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss

```

The fields in the display are the same as those displayed by the J-Web ping MPLS diagnostic tool. For information, see “Ping MPLS Results and Output” on page 154.

Pinging Layer 2 VPNs

Enter the ping mpls l2vpn command with the following syntax. Table 72 describes the ping mpls l2vpn command options.

```

user@host> ping mpls l2vpn interface interface-name | instance
l2vpn-instance-name local-site-id local-site-id-number remote-site-id
remote-site-id-number <bottom-label-ttl> <exp forwarding-class>
<count number> <source source-address> <detail>

```

To quit the ping mpls l2vpn command, press Ctrl-C.

Alternatively, you can use the J-Web interface. (See “Checking MPLS Connections from the J-Web Interface” on page 150.)

Table 72: CLI ping mpls l2vpn Command Options

Option	Description
l2vpn interface <i>interface-name</i>	Sends ping requests out the specified interface configured for the Layer 2 VPN on the outbound (egress) PE router.
l2vpn instance <i>l2vpn-instance-name</i> <i>local-site-id</i> <i>local-site-id-number</i> <i>remote-site-id</i> <i>remote-site-id-number</i>	Pings on a combination of the Layer 2 VPN routing instance name, the local site identifier, and the remote site identifier, testing the integrity of the Layer 2 VPN circuit (specified by the identifiers) between the inbound (ingress) and outbound PE routers.
bottom-label-ttl	(Optional) Displays the time-to-live (TTL) value for the bottom label in the MPLS label stack.
exp <i>forwarding-class</i>	(Optional) Specifies the value of the forwarding class to be used in the MPLS ping packets.
count <i>number</i>	(Optional) Limits the number of ping requests to send. Specify a count from 0 through 1,000,000. The default value is 5. If you do not specify a count, ping requests are continuously sent until you press Ctrl-C.

Table 72: CLI ping mpls l2vpn Command Options (continued)

Option	Description
source <i>source-address</i>	(Optional) Uses the source address that you specify, in the ping request packet.
detail	(Optional) Displays detailed output about the echo requests sent and received. Detailed output includes the MPLS labels used for each request and the return codes for each request.

Following is sample output from a ping mpls l2vpn command:

```

user@host> ping mpls l2vpn instance vpn1 remote-site-id 1
local-site-id 2 detail
Request for seq 1, to interface 68, labels <800001, 100176>
Reply for seq 1, return code: Egress-ok
Request for seq 2, to interface 68, labels <800001, 100176>
Reply for seq 2, return code: Egress-ok
Request for seq 3, to interface 68, labels <800001, 100176>
Reply for seq 3, return code: Egress-ok
Request for seq 4, to interface 68, labels <800001, 100176>
Reply for seq 4, return code: Egress-ok
Request for seq 5, to interface 68, labels <800001, 100176>
Reply for seq 5, return code: Egress-ok

--- lsping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss

```

The fields in the display are the same as those displayed by the J-Web ping MPLS diagnostic tool. For information, see “Ping MPLS Results and Output” on page 154.

Pinging Layer 2 Circuits

Enter the ping mpls l2circuit command with the following syntax. Table 73 describes the ping mpls l2circuit command options.

```

user@host> ping mpls l2circuit (interface interface-name |
virtual-circuit neighbor prefix-name virtual-circuit-id)
<exp forwarding-class> <count number> <source source-address>
<detail>

```

To quit the ping mpls l2circuit command, press Ctrl-C.

Alternatively, you can use the J-Web interface. (See “Checking MPLS Connections from the J-Web Interface” on page 150.)

Table 73: CLI ping mpls l2circuit Command Options

Option	Description
l2circuit interface <i>interface-name</i>	Sends ping requests out the specified interface configured for the Layer 2 circuit on the outbound PE router.
l2circuit virtual-circuit neighbor <i>prefix-name</i> <i>virtual-circuit-id</i>	Pings on a combination of the IPv4 prefix and the virtual circuit identifier on the outbound PE router, testing the integrity of the Layer 2 circuit between the inbound and outbound PE routers.

Table 73: CLI ping mpls l2circuit Command Options (continued)

Option	Description
<code>exp forwarding-class</code>	(Optional) Specifies the value of the forwarding class to be used in the MPLS ping packets.
<code>count number</code>	(Optional) Limits the number of ping requests to send. Specify a count from 0 through 1,000,000. The default value is 5. If you do not specify a count, ping requests are continuously sent until you press Ctrl-C.
<code>source source-address</code>	(Optional) Uses the source address that you specify, in the ping request packet.
<code>detail</code>	(Optional) Displays detailed output about the echo requests sent and received. Detailed output includes the MPLS labels used for each request and the return codes for each request.

Following is sample output from a ping mpls l2circuit command:

```
user@host> ping mpls l2circuit interface fe-1/0/0.0
Request for seq 1, to interface 69, labels <100000, 100208>
Reply for seq 1, return code: Egress-ok, time: 0.439 ms
```

The fields in the display are the same as those displayed by the J-Web ping MPLS diagnostic tool. For information, see “Ping MPLS Results and Output” on page 154.

Tracing Unicast Routes from the CLI

Use the CLI `traceroute` command to display a list of routers between the Services Router and a specified destination host. This command is useful for diagnosing a point of failure in the path from the Services Router to the destination host, and addressing network traffic latency and throughput problems.

The Services Router generates the list of routers by sending a series of ICMP traceroute packets in which the time-to-live (TTL) value in the messages sent to each successive router is incremented by 1. (The TTL value of the first traceroute packet is set to 1.) In this manner, each router along the path to the destination host replies with a Time Exceeded packet from which the source IP address can be obtained.

Alternatively, you can use the J-Web interface. (See “Tracing Unicast Routes from the J-Web Interface ” on page 155.)

Enter the `traceroute` command with the following syntax. Table 74 describes the `traceroute` command options.

```
user@host> traceroute host <interface interface-name>
<as-number-lookup> <bypass-routing> <gateway address> <inet
| inet6> <logical-router logical-router-name> <no-resolve>
<routing-instance routing-instance-name> <source source-address>
<tos number> <ttl number> <wait seconds>
```

To quit the `traceroute` command, press Ctrl-C.

Table 74: CLI traceroute Command Options

Option	Description
<i>host</i>	Sends traceroute packets to the hostname or IP address you specify.
interface <i>interface-name</i>	(Optional) Sends the traceroute packets on the interface you specify. If you do not include this option, traceroute packets are sent on all interfaces.
as-number-lookup	(Optional) Displays the autonomous system (AS) number of each intermediate hop between the router and the destination host.
bypass-routing	(Optional) Bypasses the routing tables and sends the traceroute packets only to hosts on directly attached interfaces. If the host is not on a directly attached interface, an error message is returned. Use this option to display a route to a local system through an interface that has no route through it.
gateway <i>address</i>	(Optional) Uses the gateway you specify to route through.
logical-router <i>logical-router-name</i>	(Optional) Sends traceroute packets to this logical router.
inet	(Optional) Forces the traceroute packets to an IPv4 destination.
inet6	(Optional) Forces the traceroute packets to an IPv6 destination.
no-resolve	(Optional) Suppresses the display of the hostnames of the hops along the path.
routing-instance <i>routing-instance-name</i>	(Optional) Uses the routing instance you specify for the traceroute.
source <i>address</i>	(Optional) Uses the source address you specify in the traceroute packet.
tos <i>number</i>	(Optional) Sets the type-of-service (TOS) value in the IP header of the traceroute packet. Specify a value from 0 through 255.
ttl <i>number</i>	(Optional) Sets the time-to-live (TTL) value for the traceroute packet. Specify a hop count from 0 through 128.
wait <i>seconds</i>	(Optional) Sets the maximum time to wait for a response.

Following is sample output from a **traceroute** command:

```

user@host> traceroute host2
traceroute to 173.24.232.66 (172.24.230.41), 30 hops max, 40 byte packets
 1  173.18.42.253 (173.18.42.253)  0.482 ms  0.346 ms  0.318 ms
 2  host4.site1.net (173.18.253.5)  0.401 ms  0.435 ms  0.359 ms
 3  host5.site1.net (173.18.253.5)  0.401 ms  0.360 ms  0.357 ms
 4  173.24.232.65 (173.24.232.65)  0.420 ms  0.456 ms  0.378 ms
 5  173.24.232.66 (173.24.232.66)  0.830 ms  0.779 ms  0.834 ms

```

The fields in the display are the same as those displayed by the J-Web traceroute diagnostic tool. For information, see “Traceroute Results and Output Summary” on page 158.

Tracing Multicast Routes from the CLI

Use CLI mtrace commands to trace information about multicast paths. The mtrace from-source command displays information about a multicast path from a source to

the Services Router. The `mtrace monitor` command monitors and displays multicast trace operations.

This section contains the following topics. For more information about `mtrace` commands, see the *JUNOS System Basics and Services Command Reference*.

- Using the `mtrace from-source` Command on page 168
- Using the `mtrace monitor` Command on page 170

Using the `mtrace from-source` Command

To display information about a multicast path from a source to the Services Router, enter the `mtrace from-source` command with the following syntax. Table 75 describes the `mtrace from-source` command options.

```
user@host> mtrace from-source source host
<extra-hops number> <group address> <interval seconds>
<max-hops number> <max-queries number> <response host>
<routing-instance routing-instance-name> <ttl number>
<wait-time seconds> <loop> <multicast-response | unicast-response>
<no-resolve> <no-router-alert> <brief | detail>
```

Table 75: CLI `mtrace from-source` Command Options

Option	Description
source <i>host</i>	Traces the path to the specified hostname or IP address.
extra-hops <i>number</i>	(Optional) Sets the number of extra hops to trace past nonresponsive routers. Specify a value from 0 through 255.
group <i>address</i>	(Optional) Traces the path for the specified group address. The default value is 0.0.0.0.
interval <i>seconds</i>	(Optional) Sets the interval between statistics gathering. The default value is 10.
max-hops <i>number</i>	(Optional) Sets the maximum number of hops to trace toward the source. Specify a value from 0 through 255. The default value is 32.
max-queries <i>number</i>	(Optional) Sets the maximum number of query attempts for any hop. Specify a value from 1 through 32. The default value is 3.
response <i>host</i>	(Optional) Sends the response packets to the specified hostname or IP address. By default, the response packets are sent to the Services Router.
routing-instance routing-instance-name	(Optional) Traces the routing instance you specify.
ttl <i>number</i>	(Optional) Sets the time-to-live (TTL) value in the IP header of the query packets. Specify a hop count from 0 through 255. The default value for local queries to the <i>all routers</i> multicast group is 1. Otherwise, the default value is 127.
wait-time <i>seconds</i>	(Optional) Sets the time to wait for a response packet. The default value is 3 seconds.
loop	(Optional) Loops indefinitely, displaying rate and loss statistics. To quit the <code>mtrace</code> command, press Ctrl-C.
multicast-response	(Optional) Forces the responses to use multicast.
unicast-response	(Optional) Forces the response packets to use unicast.

Table 75: CLI mtrace from-source Command Options (continued)

Option	Description
no-resolve	(Optional) Does not display hostnames.
no-router-alert	(Optional) Does not use the router alert IP option in the IP header.
brief	(Optional) Does not display packet rates and losses.
detail	(Optional) Displays packet rates and losses if a group address is specified.

Following is sample output from the mtrace from-source command:

```

user@host> mtrace from-source source 192.1.4.1 group 224.1.1.1
Mtrace from 192.1.4.1 to 192.1.30.2 via group 224.1.1.1
Querying full reverse path... * *
  0 ? (192.1.30.2)
 -1 ? (192.1.30.1) PIM thresh^ 1
 -2 routerC.mycompany.net (192.1.40.2) PIM thresh^ 1
 -3 hostA.mycompany.net (192.1.4.1)
Round trip time 22 ms; total ttl of 2 required.

Waiting to accumulate statistics...Results after 10 seconds:

Source      Response Dest      Overall      Packet Statistics For Traffic From
192.1.4.1   192.1.30.2      Packet      192.1.4.1 To 224.1.1.1
  v      ___/  rtt   16 ms      Rate      Lost/Sent = Pct  Rate
192.168.195.37
192.1.40.2   routerC.mycompany.net
  v      ^      ttl    2              0/0    =  --    0 pps
192.1.40.1
192.1.30.1   ?
  v      \__  ttl    3              ?/0              0 pps
192.1.30.2   192.1.30.2
Receiver      Query Source

```

Each line of the trace display is usually in the following format (depending on the options selected and the responses from the routers along the path):

```
hop-number host (ip-address) protocol ttl
```

Table 76 summarizes the output fields of the display.



NOTE: The packet statistics gathered from Juniper Networks routers and routing nodes are always displayed as 0.

Table 76: CLI mtrace from-source Command Output Summary

Field	Description
hop-number	Number of the hop (router) along the path.

Table 76: CLI mtrace from-source Command Output Summary (continued)

Field	Description
<i>host</i>	Hostname, if available, or IP address of the router. If the no-resolve option was entered in the command, the hostname is not displayed.
<i>ip-address</i>	IP address of the router.
<i>protocol</i>	Protocol used.
<i>ttl</i>	TTL threshold.
Round trip time <i>milliseconds</i> <i>ms</i>	Total time between the sending of the query packet and the receiving of the response packet.
total <i>t</i> tl of <i>number</i> required	Total number of hops required to reach the source.
Source	Source IP address of the response packet.
Response Dest	Response destination IP address.
Overall	Average packet rate for all traffic at each hop.
Packet Statistics For Traffic From	Number of packets lost, number of packets sent, percentage of packets lost, and average packet rate at each hop.
Receiver	IP address receiving the multicast packets.
Query Source	IP address of the host sending the query packets.

Using the mtrace monitor Command

To monitor and display multicast trace operations, enter the **mtrace monitor** command:

```

user@host> mtrace monitor
Mtrace query at Apr 21 16:00:54 by 192.1.30.2, resp to 224.0.1.32, qid 2a83aa
packet from 192.1.30.2 to 224.0.0.2
from 192.1.30.2 to 192.1.4.1 via group 224.1.1.1 (mxhop=60)

Mtrace query at Apr 21 16:00:57 by 192.1.30.2, resp to 224.0.1.32, qid 25dc17
packet from 192.1.30.2 to 224.0.0.2
from 192.1.30.2 to 192.1.4.1 via group 224.1.1.1 (mxhop=60)

Mtrace query at Apr 21 16:01:00 by 192.1.30.2, resp to same, qid 20e046
packet from 192.1.30.2 to 224.0.0.2
from 192.1.30.2 to 192.1.4.1 via group 224.1.1.1 (mxhop=60)

Mtrace query at Apr 21 16:01:10 by 192.1.30.2, resp to same, qid 1d25ad
packet from 192.1.30.2 to 224.0.0.2
from 192.1.30.2 to 192.1.4.1 via group 224.1.1.1 (mxhop=60)

```

This example displays only mtrace queries. When the Services Router captures an mtrace response, the display is similar, but the complete mtrace response is also displayed—exactly as it is displayed in **mtrace from-source** command output.

Table 77 summarizes the output fields of the display.

Table 77: CLI mtrace monitor Command Output Summary

Field	Description
mtrace <i>operation-type</i> at <i>time-of-day</i>	<ul style="list-style-type: none"> ■ <i>operation-type</i> —Type of multicast trace operation: <i>query</i> or <i>response</i>. ■ <i>time-of-day</i> —Date and time the multicast trace query or response was captured.
by	IP address of the host issuing the query.
resp to <i>address</i>	<i>address</i> —Response destination address.
qid <i>qid</i>	<i>qid</i> —Query ID number.
packet from <i>source</i> to <i>destination</i>	<ul style="list-style-type: none"> ■ <i>source</i> —IP address of the source of the query or response. ■ <i>destination</i> —IP address of the destination of the query or response.
from <i>source</i> to <i>destination</i>	<ul style="list-style-type: none"> ■ <i>source</i> —IP address of the multicast source. ■ <i>destination</i> —IP address of the multicast destination.
via group <i>address</i>	<i>address</i> —Group address being traced.
mxhop= <i>number</i>	<i>number</i> —Maximum hop setting.

Displaying Log and Trace Files from the CLI

You can enter the monitor start command to display real-time additions to system logs and trace files:

```
user@host> monitor start filename
```

When the Services Router adds a record to the file specified by *filename*, the record is displayed on the screen. For example, if you have configured a system log file named *system-log* (by including the *syslog* statement at the [edit system] hierarchy level), you can enter the *monitor start system-log* command to display the records added to the system log.

To display a list of files that are being monitored, enter the *monitor list* command. To stop the display of records for a specified file, enter the *monitor stop filename* command.

Monitoring Interfaces and Traffic from the CLI

This section contains the following topics:

- Using the monitor interface Command on page 172
- Using the monitor traffic Command on page 173

Using the monitor interface Command

Use the CLI `monitor interface` command to display real-time traffic, error, alarm, and filter statistics about a physical or logical interface. Enter the command with the following syntax:

```
user@host> monitor interface ( interface-name | traffic)
```

Replace *interface-name* with the name of a physical or logical interface. If you specify the `traffic` option, statistics for all active interfaces are displayed.

The real-time statistics are updated every second. The **Current delta** and **Delta** columns display the amount the statistics counters have changed since the `monitor interface` command was entered or since you cleared the delta counters. Table 78 and Table 79 list the keys you use to control the display using the *interface-name* and `traffic` options. (The keys are not case sensitive.)

Table 78: CLI monitor interface Output Control Keys

Key	Action
c	Clears (returns to 0) the delta counters in the Current delta column. The statistics counters are not cleared.
f	Freezes the display, halting the update of the statistics and delta counters.
i	Displays information about a different interface. You are prompted for the name of a specific interface.
n	Displays information about the next interface. The Services Router scrolls through the physical and logical interfaces in the same order in which they are displayed by the <code>show interfaces terse</code> command.
q or ESC	Quits the command and returns to the command prompt.
t	Thaws the display, resuming the update of the statistics and delta counters.

Table 79: CLI monitor interface traffic Output Control Keys

Key	Action
b	Displays the statistics in units of bytes and bytes per second (bps).
c	Clears (returns to 0) the delta counters in the Delta column. The statistics counters are not cleared.
d	Displays the Delta column instead of the rate column—in bps or packets per second (pps).
p	Displays the statistics in units of packets and packets per second (pps).
q or ESC	Quits the command and returns to the command prompt.
r	Displays the rate column—in bps and pps—instead of the Delta column.

Following are sample displays from the `monitor interface` command:

```

user@host> monitor interface fe-0/0/0
host1                               Seconds: 11                      Time: 16:47:49
                                      Delay: 0/0/0

Interface: fe-0/0/0, Enabled, Link is Up
Encapsulation: Ethernet, Speed: 100mbps

Traffic statistics:                                Current delta
Input bytes:                                     381588589                [11583]
Output bytes:                                    9707279                  [6542]
Input packets:                                   4064553                  [145]
Output packets:                                  66683                   [25]

Error statistics:
Input errors:                                     0                        [0]
Input drops:                                     0                        [0]
Input framing errors:                           0                        [0]
Carrier transitions:                            0                        [0]
Output errors:                                   0                        [0]
Output drops:                                   0                        [0]

```



NOTE: The output fields displayed when you enter the monitor interface *interface-name* command are determined by the interface you specify.

```

user@host> monitor interface traffic

Interface  Link  Input packets  (pps)  Output packets  (pps)
fe-0/0/0   Up    42334          (5)    23306           (3)
fe-0/0/1   Up    587525876      (12252)  589621478      (12891)

```

Using the monitor traffic Command

Use the CLI monitor traffic command to display packet headers transmitted through network interfaces.



NOTE: Using the monitor traffic command can degrade Services Router performance. We recommend that you use filtering options—such as count and matching—to minimize the impact to packet throughput on the Services Router.

Enter the monitor traffic command with the following syntax. Table 80 describes the monitor traffic command options.

```

user@host> monitor traffic <absolute-sequence> <count number>
<interface interface-name> <layer2-headers> <matching "expression">
<no-domain-names> <no-promiscuous> <no-resolve> <no-timestamp>
<print-ascii> <print-hex> <size bytes> <brief | detail | extensive>

```

To quit the monitor traffic command and return to the command prompt, press Ctrl-C.

Table 80: CLI monitor traffic Command Options

Option	Description
<code>absolute-sequence</code>	(Optional) Displays the absolute TCP sequence numbers.
<code>count number</code>	(Optional) Displays the specified number of packet headers. Specify a value from 0 through 100,000. The command quits and exits to the command prompt after this number is reached.
<code>interface interface-name</code>	(Optional) Displays packet headers for traffic on the specified interface. If an interface is not specified, the lowest numbered interface is monitored.
<code>layer2-headers</code>	(Optional) Displays the link-layer packet header on each line.
<code>matching "expression"</code>	(Optional) Displays packet headers that match an expression enclosed in quotation marks (" "). Table 81 through Table 83 list match conditions, logical operators, and arithmetic, binary, and relational operators you can use in the expression.
<code>no-domain-names</code>	(Optional) Suppresses the display of the domain name portion of the hostname.
<code>no-promiscuous</code>	(Optional) Specifies <i>not</i> to place the monitored interface in promiscuous mode. In promiscuous mode, the interface reads every packet that reaches it. In nonpromiscuous mode, the interface reads only the packets addressed to it.
<code>no-resolve</code>	(Optional) Suppresses the display of hostnames.
<code>no-timestamp</code>	(Optional) Suppresses the display of packet header timestamps.
<code>print-ascii</code>	(Optional) Displays each packet header in ASCII format.
<code>print-hex</code>	(Optional) Displays each packet header, except link-layer headers, in hexadecimal format.
<code>size bytes</code>	(Optional) Displays the number of bytes for each packet that you specify. If a packet header exceeds this size, the displayed packet header is truncated. The default value is 96.
<code>brief</code>	(Optional) Displays minimum packet header information. This is the default.
<code>detail</code>	(Optional) Displays packet header information in moderate detail. For some protocols, you must also use the size option to see detailed information.
<code>extensive</code>	(Optional) Displays the most extensive level of packet header information. For some protocols, you must also use the size option to see extensive information.

To limit the packet header information displayed by the `monitor traffic` command, include the `matching "expression"` option. An expression consists of one or more match conditions listed in Table 81, enclosed in quotation marks (" "). You can combine match conditions by using the logical operators listed in Table 82 (shown in order of highest to lowest precedence).

For example, to display TCP or UDP packet headers, enter the following command:


```
user@host> monitor traffic matching "tcp || udp"
```

To compare the following types of expressions, use the relational operators listed in Table 83 (listed from highest to lowest precedence):

- Arithmetic—Expressions that use the arithmetic operators listed in Table 83.
- Binary—Expressions that use the binary operators listed in Table 83.
- Packet data accessor—Expressions that use the following syntax:

```
protocol [ byte-offset <size>]
```

Replace *protocol* with any protocol in Table 81. Replace *byte-offset* with the byte offset, from the beginning of the packet header, to use for the comparison. The optional *size* parameter represents the number of bytes examined in the packet header—1, 2, or 4 bytes.

For example, the following command displays all multicast traffic:

```
user@host> monitor traffic matching "ether[0] & 1 !=0"
```

Table 81: CLI monitor traffic Match Conditions

Match Condition	Description
Entity Type	
host [<i>address</i> <i>hostname</i>]	Matches packet headers that contain the specified address or hostname. You can prepend any of the following protocol match conditions, followed by a space, to <i>host</i> : <i>arp</i> , <i>ip</i> , <i>rarp</i> , or any of the Directional match conditions.
network <i>address</i>	Matches packet headers with source or destination addresses containing the specified network address.
network <i>address</i> mask <i>mask</i>	Matches packet headers containing the specified network address and subnet mask.
port [<i>port-number</i> <i>port-name</i>]	Matches packet headers containing the specified source or destination TCP or UDP port number or port name.
Directional	Directional match conditions can be prepended to any Entity Type match conditions, followed by a space.
destination	Matches packet headers containing the specified destination.
source	Matches packet headers containing the specified source.
source and destination	Matches packet headers containing the specified source <i>and</i> destination.
source or destination	Matches packet headers containing the specified source <i>or</i> destination.
Packet Length	
less <i>bytes</i>	Matches packets with lengths less than or equal to the specified value, in bytes.
greater <i>bytes</i>	Matches packets with lengths greater than or equal to the specified value, in bytes.
Protocol	
arp	Matches all ARP packets.
ether	Matches all Ethernet frames.

Table 81: CLI monitor traffic Match Conditions (continued)

Match Condition	Description
ether [broadcast multicast]	Matches broadcast or multicast Ethernet frames. This match condition can be prepended with source or destination .
ether protocol [address (\arp \ip \rarp)]	Matches Ethernet frames with the specified address or protocol type. The arguments arp , ip , and rarp are also independent match conditions, so they must be preceded with a backslash (\) when used in the ether protocol match condition.
icmp	Matches all ICMP packets.
ip	Matches all IP packets.
ip [broadcast multicast]	Matches broadcast or multicast IP packets.
ip protocol [address (\icmp igrp \tcp \udp)]	Matches IP packets with the specified address or protocol type. The arguments icmp , tcp , and udp are also independent match conditions, so they must be preceded with a backslash (\) when used in the ip protocol match condition.
isis	Matches all IS-IS routing messages.
rarp	Matches all RARP packets.
tcp	Matches all TCP packets.
udp	Matches all UDP packets.

Table 82: CLI monitor traffic Logical Operators

Logical Operator	Description
!	Logical NOT. If the first condition does not match, the next condition is evaluated.
&&	Logical AND. If the first condition matches, the next condition is evaluated. If the first condition does not match, the next condition is skipped.
	Logical OR. If the first condition matches, the next condition is skipped. If the first condition does not match, the next condition is evaluated.
()	Group operators to override default precedence order. Parentheses are special characters, each of which must be preceded by a backslash (\).

Table 83: CLI monitor traffic Arithmetic, Binary, and Relational Operators

Operator	Description
Arithmetic Operator	
+	Addition operator.
-	Subtraction operator.
/	Division operator.
Binary Operator	

Table 83: CLI monitor traffic Arithmetic, Binary, and Relational Operators (continued)

Operator	Description
&	Bitwise AND.
*	Bitwise exclusive OR.
	Bitwise inclusive OR.
Relational Operator	
<=	A match occurs if the first expression is less than or equal to the second.
>=	A match occurs if the first expression is greater than or equal to the second.
<	A match occurs if the first expression is less than the second.
>	A match occurs if the first expression is greater than the second.
=	A match occurs if the first expression is equal to the second.
!=	A match occurs if the first expression is not equal to the second.

Following is sample output from the monitor traffic command:

```

user@host> monitor traffic count 4 matching "arp" detail
Listening on fe-0/0/0, capture size 96 bytes

15:04:16.276780 In arp who-has 193.1.1.1 tell host1.site2.net
15:04:16.376848 In arp who-has host2.site2.net tell host1.site2.net
15:04:16.376887 In arp who-has 193.1.1.2 tell host1.site2.net
15:04:16.601923 In arp who-has 193.1.1.3 tell host1.site2.net

```


Chapter 8

Configuring Packet Capture

Packet capture is a tool that helps you to analyze network traffic and troubleshoot network problems. On a J-series Services Router, the packet capture tool captures real-time data packets traveling over the network, for monitoring and logging.

Packets are captured as binary data, without modification. You can read the packet information offline with a packet analyzer such as Ethereal or tcpdump.



NOTE: J-series Services Routers can capture IPv4 packets only. The packet capture tool does not support IPv6 packet capture.

You can use either the J-Web configuration editor or CLI configuration editor to configure packet capture. For more information about packet capture, see the *JUNOS Policy Framework Configuration Guide*.

This chapter contains the following topics.

- Packet Capture Terms on page 179
- Packet Capture Overview on page 180
- Before You Begin on page 183
- Configuring Packet Capture with a Configuration Editor on page 183
- Changing Encapsulation on Interfaces with Packet Capture Configured on page 187
- Verifying Packet Capture on page 188

Packet Capture Terms

Before configuring packet capture on a Services Router, become familiar with the terms defined in Table 84.

Table 84: Packet Capture Terms

Term	Definition
interface sampling	Packet sampling method used by packet capture, in which entire IPv4 packets flowing in the input or output direction, or both directions, are captured for analysis.
libpcap	An implementation of the pcap application programming interface. libpcap may be used by a program to capture packets traveling over a network.
packet capture	Packet sampling method available only on J-series routers, in which entire IPv4 packets flowing through a router are captured for analysis. Packets are captured in the Routing Engine and stored as libpcap-formatted files in the <code>/var/tmp</code> directory on the router. Packet capture files can be opened and analyzed offline with packet analyzers such as tcpdump or Ethereal. To avoid performance degradation on the router, implement packet capture with firewall filters that capture only selected packets. <i>See also traffic sampling.</i>
packet loss priority (PLP) bit	Bit used to identify packets that have experienced congestion or are from a transmission that exceeded a service provider's customer service license agreement. This bit can be used as part of a router's congestion control mechanism and can be set by the interface or by a filter.
tcpdump	A command line utility for debugging computer network problems. tcpdump allows the user to display the contents of TCP/IP and other packets captured on a network interface. On UNIX and most other operating systems, a user must have superuser privileges to use tcpdump due to its use of promiscuous mode.
traffic sampling	Packet sampling method in which the sampling key based on the IPv4 header is sent to the Routing Engine. There, the key is placed in a file, or cflowd packets based on the key and are sent to a cflowd server for analysis. <i>See also packet capture.</i>

Packet Capture Overview

Packet capture is used by network administrators and security engineers for the following purposes:

- Monitor network traffic and analyze traffic patterns.
- Identify and troubleshoot network problems.
- Detect security breaches in the network, such as unauthorized intrusions, spyware activity, or ping scans.

Packet capture operates like traffic sampling on the Services Router, except that it captures entire packets including the Layer 2 header rather than packet headers and saves the contents to a file in the libpcap format. You cannot enable packet capture and traffic sampling on the router at the same time.



NOTE: Enabling packet capture on the router deletes the traffic sampling configuration. Similarly, enabling traffic sampling on the router deletes the packet capture configuration.

For more information about traffic sampling, see the *JUNOS Policy Framework Configuration Guide*.

This overview contains the following topics:

- Packet Capture on Router Interfaces on page 181
- Firewall Filters for Packet Capture on page 181
- Packet Capture Files on page 182
- Analysis of Packet Capture Files on page 182

Packet Capture on Router Interfaces

Packet capture is supported on the T1, T3, E1, E3, serial, Fast Ethernet, ADSL, G.SHDSL, PPPoE, and ISDN interfaces.

To capture packets on an ISDN interface, configure packet capture on the dialer interface. To capture packets on a PPPoE interface, configure packet capture on the PPPoE logical interface.

Packet capture is not supported on tunnel interfaces.

Packet capture supports PPP, Cisco HDLC, Frame Relay, and other ATM encapsulations. Packet capture does not support multilink encapsulations such as multilink PPP (MLPPP).

You can capture all IPv4 packets flowing on an interface in the inbound (ingress) or outbound (egress) direction or in both directions. Use the J-Web configuration editor or CLI configuration editor to specify maximum packet size, the filename to be used for storing the captured packets, maximum file size, maximum number of packet capture files, and the file permissions. See “Configuring Packet Capture on an Interface (Required)” on page 184.



NOTE: For packets captured on T1, T3, E1, E3, serial, and ISDN interfaces in the outbound (egress) direction, the size of the packet captured might be 1 byte less than the maximum packet size configured because of the packet loss priority (PLP) bit.

To modify encapsulation on an interface that has packet capture configured, you must first disable packet capture. For more information, see “Changing Encapsulation on Interfaces with Packet Capture Configured” on page 187.

Firewall Filters for Packet Capture

When you enable packet capture on a Services Router, all packets flowing in the direction specified in packet capture configuration (inbound, outbound, or both) are captured and stored. Configuring an interface to capture all packets might degrade the performance of the Services Router. You can control the number of packets captured on an interface with firewall filters and specify various criteria to capture packets for specific traffic flows.

You must also configure and apply appropriate firewall filters on the interface if you need to capture packets generated by the host router, because interface sampling does not capture packets originating from the host router.

To configure firewall filters for packet capture, see “Configuring a Firewall Filter for Packet Capture (Optional)” on page 185.

For more information about firewall filters, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

Packet Capture Files

When packet capture is enabled on an interface, the entire packet including the Layer 2 header is captured and stored in a file. You can specify the maximum size of the packet to be captured, up to 1500 bytes. Packet capture creates one file for each physical interface. You can specify the target filename, maximum size of the file, and maximum number of files.

File creation and storage take place in the following way. Suppose you name the packet capture file `pcap-file`. Packet capture creates multiple files (one per physical interface), suffixing each file with the name of the physical interface—for example, `pcap-file.fe-0.0.1` for the Fast Ethernet interface `fe-0.0.1`. When the file named `pcap-file.fe-0.0.1` reaches the maximum size, the file is renamed `pcap-file.fe-0.0.1.0`. When the file named `pcap-file.fe-0.0.1.0` reaches the maximum size again, the file named `pcap-file.fe-0.0.1.0` is renamed `pcap-file.fe-0.0.1.1` and `pcap-file.fe-0.0.1` is renamed `pcap-file.fe-0.0.1.0`. This process continues until the maximum number of files is exceeded and the oldest file is overwritten. The `pcap-file.fe-0.0.1` file is always the latest file.

Packet capture files are not removed even after you disable packet capture on an interface.

Analysis of Packet Capture Files

Packet capture files are stored in libpcap format in the `/var/tmp` directory. You can specify user or administrator privileges for the files.

Packet capture files can be opened and analyzed offline with `tcpdump` or any packet analyzer that recognizes the libpcap format. You can also use FTP or the Session Control Protocol (SCP) to transfer the packet capture files to an external device.



NOTE: Disable packet capture before opening the file for analysis or transferring the file to an external device with FTP or SCP. Disabling packet capture ensures that the internal file buffer is flushed and all the captured packets are written to the file. To disable packet capture on an interface, see “Disabling Packet Capture” on page 186.

For more details about analyzing packet capture files, see “Verifying Captured Packets” on page 189.

Before You Begin

Before you begin configuring packet capture, complete the following tasks:

- Establish basic connectivity. See the *J-series Services Router Getting Started Guide*.
- Configure network interfaces. See the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.
- If you do not already have an understanding of the packet capture feature, see “Packet Capture Overview” on page 180.

Configuring Packet Capture with a Configuration Editor

To configure packet capture on a Services Router, you must perform the following tasks marked *(Required)*:

- Enabling Packet Capture (Required) on page 183
- Configuring Packet Capture on an Interface (Required) on page 184
- Configuring a Firewall Filter for Packet Capture (Optional) on page 185
- Disabling Packet Capture on page 186

Enabling Packet Capture (Required)

To enable packet capture on the router:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 85.
3. Go on to “Configuring Packet Capture on an Interface (Required)” on page 184.

Table 85: Enabling Packet Capture

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Forwarding options level in the configuration hierarchy.	In the configuration editor hierarchy, select Forwarding options .	From the top of the configuration hierarchy, enter <code>edit forwarding-options</code> .
Specify in bytes the maximum size of each packet to capture in each file—for example, 500. The range is between 68 and 1500, and the default is 68 bytes.	<ol style="list-style-type: none"> 1. From the Sampling or packet capture list, select Packet capture. 2. Next to Packet capture, click Configure. 3. In the Maximum capture size box, type 500. 	Enter <code>set packet-capture maximum-capture-size 500</code>

Table 85: Enabling Packet Capture (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Specify the target filename for the packet capture file—for example, pcap-file . For each physical interface, the interface name is automatically suffixed to the filename—for example, pcap-file.fe-0.0.1 .	In the Filename box, type pcap-file .	Enter set packet-capture file filename pcap-file
Specify the maximum number of files to capture—for example, 100 . The range is between 2 and 10,000, and the default is 10 files.	In the Files box, type 100 .	Enter set packet-capture file files 100
Specify the maximum size of each file in bytes—for example, 1024 . The range is between 1,024 and 104,857,600, and the default is 512,000 bytes.	In the Size box, type 1024 .	Enter set packet-capture file size 1024
Specify if all users have permission to read the packet capture files.	1. Next to World readable, select Yes . 2. Click OK .	Enter set packet-capture file world-readable

Configuring Packet Capture on an Interface (Required)

To capture all transit and host-bound packets on an interface and specify the direction of the traffic to capture—inbound, outbound, or both:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 86.
3. If you are finished configuring the router, commit the configuration.
4. Go on to one of the following procedures:
 - To configure a firewall filter, see “Configuring a Firewall Filter for Packet Capture (Optional)” on page 185.
 - To check the configuration, see “Verifying Packet Capture” on page 188.

Table 86: Configuring Packet Capture on an Interface

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Interfaces level in the configuration hierarchy, and select an interface for packet capture—for example, fe-0/0/1 .	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Interfaces. 2. In the Interface name box, click fe-0/0/1. 	From the top of the configuration hierarchy, enter edit interfaces fe-0/0/1 .
Configure the direction of the traffic for which you are enabling packet capture on the logical interface—for example, inbound and outbound.	<ol style="list-style-type: none"> 1. In the Interface unit number box, click 0. 2. Next to Inet, select Yes, and click Edit. 3. Next to Sampling, click Configure. 4. Next to Input, select Yes. 5. Next to Output, select Yes. 6. Click OK until you return to the Interface page. 	<p>Enter</p> <pre>set unit 0 family inet sampling input output</pre>



NOTE: Packets originating from the host router are not captured unless you have configured and applied a firewall filter on the interface in the output direction.

Configuring a Firewall Filter for Packet Capture (Optional)

To configure a firewall filter and apply it to the logical interface:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 87.
3. If you are finished configuring the router, commit the configuration.
4. To check the configuration, see “Verifying Packet Capture” on page 188.

Table 87: Configuring a Firewall Filter for Packet Capture

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Firewall level in the configuration hierarchy.	In the configuration editor hierarchy, select Firewall .	From the top of the configuration hierarchy, enter edit firewall .
Define a firewall filter dest-all and a filter term—for example, dest-term —to capture packets with a particular destination address—for example, 192.168.1.1/32 .	<ol style="list-style-type: none"> Next to Filter, click Add new entry. In the filter name box, type dest-all. Next to Term, click Add new entry. In the Rule name box, type dest-term. Next to From, click Configure. Next to Destination address, click Add new entry. In the Address box, type 192.168.1.1/32. Click OK until you return to the Configuration page. 	<p>Set the filter and term name, and define the match condition and its action.</p> <pre>set firewall filter dest-all term dest-term from destination-address 192.168.1.1/32 set firewall filter dest-all term dest-term then sample accept</pre>
Navigate to the Interfaces level in the configuration hierarchy.	In the configuration editor hierarchy, select Interfaces .	Enter
Apply the dest-all filter to all the outgoing packets on the interface—for example, fe-0/0/1.0 .	<ol style="list-style-type: none"> In the Interface name box, click fe-0/0/1. In the Interface unit number box, click 0. Next to Inet, select Yes, and click Edit. Next to Filter, click Configure. In the Output box, type dest-all. Click OK until you return to the Interfaces page. 	<pre>set interfaces fe-0/0/1 unit 0 family inet filter output dest-all</pre>

Disabling Packet Capture

You must disable packet capture before opening the packet capture file for analysis or transferring the file to an external device. Disabling packet capture ensures that the internal file buffer is flushed and all the captured packets are written to the file.

To disable packet capture

- Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
- Perform the configuration tasks described in Table 88.

3. If you are finished configuring the router, commit the configuration.

Table 88: Disabling Packet Capture

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Forwarding options level in the configuration hierarchy.	In the configuration editor hierarchy, select Forwarding options .	From the top of the configuration hierarchy, enter <code>edit forwarding-options</code> .
Disable packet capture.	<ol style="list-style-type: none"> 1. Next to Packet capture, click Edit. 2. Next to Disable, select Yes. 3. Click OK until you return to the Configuration page. 	Enter <code>set packet-capture disable</code> .

Changing Encapsulation on Interfaces with Packet Capture Configured

Before modifying the encapsulation on a Services Router interface that is configured for packet capture, you must disable packet capture and rename the latest packet capture file. Otherwise, packet capture saves the packets with different encapsulations in the same packet capture file. Packet files containing packets with different encapsulations are not useful, because packet analyzer tools like tcpdump cannot analyze such files.

After modifying the encapsulation, you can safely reenabling packet capture on the router.

To change the encapsulation on packet capture-configured interfaces:

1. Disable packet capture following the steps in “Disabling Packet Capture” on page 186.
2. Commit the configuration.
3. Using the CLI, rename the latest packet capture file on which you are changing the encapsulation, with the `.chdsi` extension:
 - a. From CLI operational mode, access the local UNIX shell:

```
user@host> start shell
%
```

- b. Navigate to the directory where packet capture files are stored:

```
% cd /var/tmp
%
```

- c. Rename the latest packet capture file for the interface on which you are changing the encapsulation—for example, fe.0.0.0:

```
% mv pcap-file.fe.0.0.0 pcap-file.fe.0.0.0.chdsl
%
```

- d. Return to the CLI operational mode:

```
% exit
user@host>
```

4. Change the encapsulation on the interface using the J-Web or CLI configuration editor.

See instructions for configuring interfaces in the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

5. Commit the configuration.
6. Reenable packet capture following the steps in “Enabling Packet Capture (Required)” on page 183.
7. Commit the configuration.

Verifying Packet Capture

To verify packet capture, perform these tasks:

- Displaying a Packet Capture Configuration on page 188
- Displaying a Firewall Filter for Packet Capture Configuration on page 189
- Verifying Captured Packets on page 189

Displaying a Packet Capture Configuration

Purpose	Verify the packet capture configuration.
Action	From the J-Web interface, select Configuration > View and Edit > View Configuration Text . Alternatively, from configuration mode in the CLI, enter the <code>show forwarding-options</code> command.
Sample Output	<pre>[edit] user@host# show forwarding-options packet-capture { file filename pcap-file files 100 size 1024; maximum-capture-size 500; }</pre>
What It Means	Verify that the output shows the intended file configuration for capturing packets. For more information about the format of a configuration file, see the information

about viewing configuration text in the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

Displaying a Firewall Filter for Packet Capture Configuration

Purpose	Verify the firewall filter for packet capture configuration.
Action	From the J-Web interface, select Configuration > View and Edit > View Configuration Text . Alternatively, from configuration mode in the CLI, enter the <code>show firewall filter dest-all</code> command.
Sample Output	<pre>[edit] user@host# show firewall filter dest-all term dest-term { from { destination-address 192.168.1.1/32; } then { sample; accept; } }</pre>
What It Means	Verify that the output shows the intended configuration of the firewall filter for capturing packets sent to the destination address 192.168.1.1/32. For more information about the format of a configuration file, see the information about viewing configuration text in the <i>J-series Services Router Basic LAN and WAN Access Configuration Guide</i> .

Verifying Captured Packets

Purpose	Verify that the packet capture file is stored under the <code>/var/tmp</code> directory and the packets can be analyzed offline.
Action	<p>Take the following actions:</p> <ul style="list-style-type: none"> ■ Disable packet capture. See “Disabling Packet Capture” on page 186. ■ Perform these steps to transfer a packet capture file (for example, 126b.fe-0.0.1), to a server where you have installed packet analyzer tools (for example, tools-server), using FTP. <ol style="list-style-type: none"> 1. From the CLI configuration mode, connect to tools-server using FTP: <pre>user@host# run ftp tools-server Connected to tools-server.mydomain.net 220 tools-server.mydomain.net FTP server (Version 6.00LS) ready Name (tools-server:user):remoteuser 331 Password required for remoteuser. Password: 230 User remoteuser logged in. Remote system type is UNIX. Using binary mode to transfer files.</pre>

```
ftp>
```

2. Navigate to the directory where packet capture files are stored on the router:

```
ftp> lcd /var/tmp
Local directory now /cf/var/tmp
```

3. Copy the packet capture file that you want to analyze—for example, 126b.fe-0.0.1, to the server:

```
ftp> put 126b.fe-0.0.1
local: 126b.fe-0.0.1 remote: 126b.fe-0.0.1
200 PORT command successful.
150 Opening BINARY mode data connection for '126b.fe-0.0.1'.
100% 1476 00:00 ETA
226 Transfer complete.
1476 bytes sent in 0.01 seconds (142.42 KB/s)
```

4. Return to the CLI configuration mode:

```
ftp> bye
221 Goodbye.
[edit]
user@host#
```

- Open the packet capture file on the server with tcpdump or any packet analyzer that supports libpcap format.

Sample Output

```
root@server% tcpdump -r 126b.fe-0.0.1 -xvvvv
```

```
01:12:36.279769 Out 0:5:85:c4:e3:d1 > 0:5:85:c8:f6:d1, ethertype IPv4 (0x0800), length 98:
    0005 85c8 f6d1 0005 85c4 e3d1 0800 4500
    0054 816d 0000 4001 da38 0e01 0101 0f01
    0101 0800 3c5a 981e 0000 8b5d 4543 51e6
    0100 aaaa aaaa aaaa aaaa aaaa aaaa aaaa
    aaaa aaaa 0000 0000 0000 0000 0000 0000
    0000 0000 0000 0000 0000 0000 0000 0000
    0000
01:12:36.279793 Out 0:5:85:c8:f6:d1 > 0:5:85:c4:e3:d1, ethertype IPv4 (0x0800), length 98:
    0005 85c4 e3d1 0005 85c8 f6d1 0800 4500
    0054 a10b 0000 3f01 bb9a 0f01 0101 0e01
    0101 0000 445a 981e 0000 8b5d 4543 51e6
    0100 aaaa aaaa aaaa aaaa aaaa aaaa aaaa
    aaaa aaaa 0000 0000 0000 0000 0000 0000
    0000 0000 0000 0000 0000 0000 0000 0000
    0000
```

```
root@server%
```

What It Means

Verify that the output shows the intended packets.

Chapter 9

Monitoring Real-Time Performance

J-series Services Routers support a tool that allows network operators and their customers to accurately measure the performance between two network endpoints. With the real-time performance monitoring (RPM) feature, you configure and send probes to a specified target and monitor the analyzed results to determine packet loss, round-trip time, and jitter.

This chapter contains the following topics. For more information about RPM, see the *J-series Services Router Advanced WAN Access Configuration Guide*.

- RPM Terms on page 191
- RPM Overview on page 192
- Before You Begin on page 194
- Configuring RPM with Quick Configuration on page 195
- Configuring RPM with a Configuration Editor on page 201
- Verifying an RPM Configuration on page 208

RPM Terms

Before configuring and monitoring RPM on J-series Services Routers, become familiar with the terms defined in Table 89.

Table 89: RPM Terms

Term	Definition
egress	Outbound. Characterizing packets exiting a Services Router.
ingress	Inbound. Characterizing packets entering a Services Router.
jitter	Variation in the rate at which packets in a stream are received, which can cause quality degradation in some real-time applications such as voice over IP (VoIP) and video.
probe	An action taken or an object used to learn something about the state of the network. Real-time performance monitoring (RPM) uses several types of requests to probe a network.
probe interval	Time, in seconds, between probe packets.

Table 89: RPM Terms (continued)

Term	Definition
real-time performance monitoring (RPM)	Monitoring tool that measures the performance of a network between two endpoints by collecting statistics on packet loss, round-trip time, and jitter.
RPM target	Remote network endpoint, identified by an IP address or URL, to which the Services Router sends a real-time performance monitoring (RPM) probe.
RPM test	A collection of real-time performance monitoring (RPM) probes sent out at regular intervals.
test interval	Time, in seconds, between RPM tests.

RPM Overview

Real-time performance monitoring (RPM) allows you to perform service-level monitoring. When RPM is configured on a Services Router, the router calculates network performance based on packet response time, jitter, and packet loss. These values are gathered by Hypertext Transfer Protocol (HTTP) GET requests, Internet Control Message Protocol (ICMP) requests, and TCP and UDP requests, depending on the configuration.

This section contains the following topics:

- RPM Probes on page 192
- RPM Tests on page 193
- Probe and Test Intervals on page 193
- RPM Statistics on page 193
- RPM Thresholds and Traps on page 194

RPM Probes

You gather RPM statistics by sending out probes to a specified probe target, identified by an IP address or URL. When the target receives the probe, it generates responses, which are received by the Services Router. By analyzing the transit times to and from the remote server, the Services Router can determine network performance statistics.

The Services Router sends out the following probe types:

- HTTP GET request at a target URL
- HTTP GET request for metadata at a target URL
- ICMP echo request to a target address
- ICMP timestamp request to a target address

- UDP ping packets to a target
- TCP ping packets to a target

UDP and TCP probe types require that the remote server be configured as an RPM receiver so that it generates responses to the probes.

RPM Tests

Each probed target is monitored over the course of a test. A test represents a collection of probes, sent out at regular intervals, as defined in the configuration. Statistics are then returned for each test. Because a test is a collection of probes that have been monitored over some amount of time, test statistics such as standard deviation and jitter can be calculated and included with the average probe statistics.

Probe and Test Intervals

Within a test, RPM probes are sent at regular intervals, configured in seconds. When the total number of probes have been sent and the corresponding responses received, the test is complete. You can manually set the probe interval for each test to control how the RPM test is conducted.

After all the probes for a particular test have been sent, the test begins again. The time between tests is the test interval. You can manually set the test interval to tune RPM performance.

RPM Statistics

At the end of each test, the Services Router collects the statistics for packet round-trip time, packet inbound and outbound times (for ICMP timestamp probes only), and probe loss shown in Table 90.

Table 90: RPM Statistics

RPM Statistics	Description
Round-Trip Times	
Minimum round-trip time	Shortest round-trip time from the Services Router to the remote server, as measured over the course of the test
Maximum round-trip time	Longest round-trip time from the Services Router to the remote server, as measured over the course of the test
Average round-trip time	Average round-trip time from the Services Router to the remote server, as measured over the course of the test
Standard deviation round-trip time	Standard deviation of the round-trip times from the Services Router to the remote server, as measured over the course of the test
Jitter	Difference between the maximum and minimum round-trip times, as measured over the course of the test
Inbound and Outbound Times (ICMP Timestamp Probes Only)	

Table 90: RPM Statistics (continued)

RPM Statistics	Description
Minimum egress time	Shortest one-way time from the Services Router to the remote server, as measured over the course of the test
Maximum ingress time	Shortest one-way time from the remote server to the Services Router, as measured over the course of the test
Average egress time	Average one-way time from the Services Router to the remote server, as measured over the course of the test
Average ingress time	Average one-way time from the remote server to the Services Router, as measured over the course of the test
Standard deviation egress time	Standard deviation of the one-way times from the Services Router to the remote server, as measured over the course of the test
Standard deviation ingress time	Standard deviation of the one-way times from the remote server to the Services Router, as measured over the course of the test
Egress jitter	Difference between the maximum and minimum outbound times, as measured over the course of the test
Ingress jitter	Difference between the maximum and minimum inbound times, as measured over the course of the test
Probe Counts	
Probes sent	Total number of probes sent over the course of the test
Probe responses received	Total number of probe responses received over the course of the test
Loss percentage	Percentage of probes sent for which a response was not received

RPM Thresholds and Traps

You can configure RPM threshold values for the round-trip times, ingress (inbound) times, and egress (outbound) times that are measured for each probe, as well as for the standard deviation and jitter values that are measured for each test. Additionally, you can configure threshold values for the number of successive lost probes within a test and the total number of lost probes within a test.

If the result of a probe or test exceeds any threshold, the Services Router generates a system log message and sends any Simple Network Management Protocol (SNMP) notifications (traps) that you have configured.

Before You Begin

Before you begin configuring RPM, complete the following tasks:


- Establish basic connectivity. See the *J-series Services Router Getting Started Guide*.

- Configure network interfaces. See the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.
- Configure SNMP. See “Configuring SNMP for Network Management” on page 49.

Configuring RPM with Quick Configuration

J-Web Quick Configuration allows you to configure Real-Time Performance Monitoring (RPM) parameters. Figure 19 shows the main Quick Configuration page for RPM. Figure 20 shows the probe test Quick Configuration page for RPM.

Figure 19: Main Quick Configuration Page for RPM



Juniper NETWORKS

ROUTER - J6300

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor **Configuration** **Diagnose** **Manage**

Quick Configuration

- Set Up
- SSL
- Interfaces
- Users
- SNMP
- Routing
- Firewall/NAT
- IPSec Tunnels
- Realtime Performance Monitoring**
- View and Edit
- History
- Rescue

[Configuration](#) > [Quick Configuration](#) > [Realtime Performance Monitoring](#)

Quick Configuration

Realtime Performance Monitoring

Probe Owners

No performance probe owners are defined.

Maximum Number of Concurrent Probes

Maximum Number of Concurrent Probes

Probe Servers

TCP Probe Server ?

UDP Probe Server ?

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice.](#)

Figure 20: Probe Test Quick Configuration Page for RPM

Juniper NETWORKS **ROUTER - J6300** Logged in as: **regress**
[Help](#) [About](#) [Logout](#)

Monitor Configuration Diagnose Manage

Quick Configuration

Set Up
SSL
Interfaces
Users
SNMP
Routing
Firewall/NAT
IPsec Tunnels

Realtime Performance Monitoring

► View and Edit
► History
► Rescue

Configuration > Quick Configuration > Realtime Performance Monitoring

Quick Configuration

Realtime Performance Monitoring

Add a Probe Test

Identification

* **Test Name**

* **Target (Address or URL)**

Source Address

Routing Instance ?

History Size ? (50)

Request Information

* **Probe Type** ▼

Interval ?

* **Test Interval** ?

Probe Count ?

Destination Port ?

To configure RPM parameters with Quick Configuration:

1. In the J-Web user interface, select **Configuration > RPM**.
2. Enter information into the Quick Configuration page for RPM, as described in Table 91.
3. From the main RPM Quick Configuration page, click one of the following buttons:
 - To apply the configuration and stay on the Quick Configuration RPM page, click **Apply**.
 - To apply the configuration and return to the Quick Configuration main page, click **OK**.

- To cancel your entries and return to the Quick Configuration RPM page, click **Cancel**.
4. To check the configuration, see “Verifying an RPM Configuration” on page 208.

Table 91: RPM Quick Configuration Summary

Field	Function	Your Action
Performance Probe Owners		
Owner Name (required)	Identifies an RPM owner for which one or more RPM tests are configured. In most implementations, the owner name identifies a network on which a set of tests is being run (a particular customer, for example).	Type the name of the RPM owner.
Identification		
Test name (required)	Uniquely identifies the RPM test	Type the name of the RPM test.
Target (Address or URL) (required)	IP address or URL of probe target	Type the IP address, in dotted decimal notation, or the URL of the probe target. If the target is a URL, type a fully formed URL that includes <code>http://</code> .
Source Address	Explicitly configured IP address to be used as the probe source address	Type the source address to be used for the probe. If the source IP address is not one of the router's assigned addresses, the packet uses the outgoing interface's address as its source.
Routing Instance	Particular routing instance over which the probe is sent	Type the routing instance name. The routing instance applies only to probes of type <code>icmp</code> and <code>icmp-timestamp</code> . The default routing instance is <code>inet.0</code> .
History Size	Number of probe results saved in the probe history	Type a number between 0 and 255. The default history size is 50 probes.
Request Information		
Probe Type (required)	Specifies the type of probe to send as part of the test.	Select the desired probe type from the list: <ul style="list-style-type: none"> ■ <code>http-get</code> ■ <code>http-get-metadata</code> ■ <code>icmp-ping</code> ■ <code>icmp-ping-timestamp</code> ■ <code>tcp-ping</code> ■ <code>udp-ping</code>
Interval	Sets the wait time (in seconds) between each probe transmission	Type a number between 1 and 255 (seconds).
Test Interval (required)	Sets the wait time (in seconds) between tests.	Type a number between 0 and 86400 (seconds).

Table 91: RPM Quick Configuration Summary (continued)

Field	Function	Your Action
Probe Count	Sets the total number of probes to be sent for each test.	Type a number between 1 and 15.
Destination Port	Specifies the TCP or UDP port to which probes are sent. To use TCP or UDP probes, you must configure the remote server as a probe receiver. Both the probe server (Services Router) and the remote server must be Juniper Networks routers configured to receive and transmit RPM probes on the same TCP or UDP port.	Type the number 7—a standard TCP or UDP port number—or a port number from 49152 through 65535.
DSCP Bits	Specifies the Differentiated Services code point (DSCP) bits. This value must be a valid 6-bit pattern. The default is 000000. For information about DSCPs and their use within class-of-service (CoS) features, see the <i>J-series Services Router Advanced WAN Access Configuration Guide</i> .	Type a valid 6-bit pattern.
Data Size	Specifies the size of the data portion of the ICMP probes.	Type a size (in bytes) between 0 and 65507.
Data Fill	Specifies the contents of the data portion of the ICMP probes.	Type a hexadecimal value between 1 and 800h to use as the contents of the ICMP probe data.
Maximum Probe Thresholds		
Successive Lost Probes	Sets the total number of probes that must be lost successively to trigger a probe failure and generate a system log message.	Type a number between 0 and 15.
Lost Probes	Sets the total number of probes that must be lost to trigger a probe failure and generate a system log message.	Type a number between 0 and 15.
Round Trip Time	Sets the total round-trip time (in microseconds), from the Services Router to the remote server, that triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).
Jitter	Sets the total jitter (in microseconds), for a test, that triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).
Standard Deviation	Sets the maximum allowable standard deviation (in microseconds) for a test, which, if exceeded, triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).

Table 91: RPM Quick Configuration Summary (continued)

Field	Function	Your Action
Egress Time	Sets the total one-way time (in microseconds), from the Services Router to the remote server, that triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).
Ingress Time	Sets the total one-way time (in microseconds), from the remote server to the Services Router, that triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds)
Jitter Egress Time	Sets the total outbound-time jitter (in microseconds), for a test, that triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds)
Jitter Ingress Time	Sets the total inbound-time jitter (in microseconds), for a test, that triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).
Egress Standard Deviation	Sets the maximum allowable standard deviation of outbound times (in microseconds) for a test, which, if exceeded, triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).
Ingress Standard Deviation	Sets the maximum allowable standard deviation of inbound times (in microseconds) for a test, which, if exceeded, triggers a probe failure and generates a system log message.	Type a number between 0 and 60,000,000 (microseconds).
Traps		
Egress Jitter Exceeded	Generates SNMP traps when the threshold for jitter in outbound time is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Egress Standard Deviation Exceeded	Generates SNMP traps when the threshold for standard deviation in outbound times is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Egress Time Exceeded	Generates SNMP traps when the threshold for maximum outbound time is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Ingress Jitter Exceeded	Generates SNMP traps when the threshold for jitter in inbound time is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.

Table 91: RPM Quick Configuration Summary (continued)

Field	Function	Your Action
Ingress Standard Deviation Exceeded	Generates SNMP traps when the threshold for standard deviation in inbound times is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Ingress Time Exceeded	Generates traps when the threshold for maximum inbound time is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Jitter Exceeded	Generates traps when the threshold for jitter in round-trip time is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Probe Failure	Generates traps when the threshold for the number of successive lost probes is reached.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
RTT Exceeded	Generates traps when the threshold for maximum round-trip time is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Standard Deviation Exceeded	Generates traps when the threshold for standard deviation in round-trip times is exceeded.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Test Completion	Generates traps when a test is completed.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Test Failure	Generates traps when the threshold for the total number of lost probes is reached.	<ul style="list-style-type: none"> ■ To enable SNMP traps for this condition, select the check box. ■ To disable SNMP traps, clear the check box.
Performance Probe Server		
TCP Probe Server	Specifies the port on which the Services Router is to receive and transmit TCP probes.	Type the number 7—a standard TCP or UDP port number—or a port number from 49152 through 65535.
UDP Probe Server	Specifies the port on which the Services Router is to receive and transmit UDP probes.	Type the number 7—a standard TCP or UDP port number—or a port number from 49152 through 65535.

Configuring RPM with a Configuration Editor

To configure the Services Router to perform real-time performance tests, you must perform the following tasks marked *(Required)*. For information about using the J-Web and CLI configuration editors, see the *J-series Services Router Basic LAN and WAN Access Configuration Guide*.

- Configuring Basic RPM Probes (Required) on page 201
- Configuring TCP and UDP Probes (Optional) on page 205
- Tuning RPM Probes (Optional) on page 207

Configuring Basic RPM Probes (Required)

To configure basic RPM probes, you must configure the probe owner, the test, and the specific parameters of the RPM probe.

In this sample use of RPM, basic probes are configured for two customers: Customer A and Customer B. The probe for Customer A uses ICMP timestamp packets and sets RPM thresholds and corresponding SNMP traps to catch lengthy inbound times. The probe for Customer B uses HTTP packets and sets thresholds and corresponding SNMP traps to catch excessive lost probes. To configure these RPM probes:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 92.
3. If you are finished configuring the network, commit the configuration.
4. Go on to one of the following procedures:
 - To configure a TCP or UDP probe, see “Configuring TCP and UDP Probes (Optional)” on page 205.
 - To tune a probe, see “Tuning RPM Probes (Optional)” on page 207.
 - To check the configuration, see “Verifying an RPM Configuration” on page 208.

Table 92: Configuring Basic RPM Probes

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Services > RPM level in the configuration hierarchy.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Services. 2. Select the Yes check box. 3. Click Configure. 	<p>From the top of the configuration hierarchy, enter</p> <pre>edit services rpm</pre>
Configure the RPM owners customerA and customerB .	<ol style="list-style-type: none"> 1. In the Probe box, click Add new entry. 2. In the Owner box, type customerA. 3. Click OK. 4. Repeat the above steps and add an RPM probe owner for customerB. 	<ol style="list-style-type: none"> 1. Enter set probe customerA 2. Enter set probe customerB
<p>Configure the RPM test icmp-test for the RPM owner customerA.</p> <p>The sample RPM test is an ICMP probe with a test interval (probe frequency) of 15 seconds, a probe type of icmp-ping-timestamp, and a target address of 192.178.16.5.</p>	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select customerA. 2. In the Test box, click Add new entry 3. In the Name box, type icmp-test. 4. In the Probe frequency box, type 15. 5. In the Probe type box, select icmp-ping-timestamp. 6. In the Target box, select the Yes check box, and click Configure. 7. In the Target type box, select Address. 8. In the Address box, type 192.178.16.5. 9. Click OK. 	<ol style="list-style-type: none"> 1. From the top of the configuration hierarchy, enter edit services rpm probe customerA 2. Enter set test icmp-test probe-frequency 15 3. Enter set test icmp-test probe-type icmp-pingtimestamp 4. Enter set test icmp-test target address 192.178.16.5

Table 92: Configuring Basic RPM Probes (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Configure RPM thresholds and corresponding SNMP traps to catch ingress (inbound) times greater than 3000 microseconds.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select icmp-test. 2. In the Thresholds box, select the Yes check box, and click Configure. 3. In the Ingress time box, type 3000. 4. Click OK. 5. In the Traps box, click Add new entry. 6. In the Value box, select ingress-time-exceeded. 7. Click OK. 	<ol style="list-style-type: none"> 1. Enter set probe customerA test icmp-test thresholds ingress-time 3000 2. Enter set probe customerA test icmp-test traps ingress-time-exceeded

Table 92: Configuring Basic RPM Probes (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Configure the RPM test http-test for the RPM owner customerB . The sample RPM test is an HTTP probe with a test interval (probe frequency) of 30 seconds, a probe type of http-get , and a target URL of http://customerB.net .	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select customerB. 2. In the Test box, click Add new entry. 3. In the Name box, type http-test. 4. In the Probe frequency box, type 30. 5. In the Probe type box, select http-get. 6. In the Target box, select the Yes check box, and click Configure. 7. In the Target type box, select Url. 8. In the Url box, type http://customerB.net. 9. Click OK. 	<ol style="list-style-type: none"> 1. From the top of the configuration hierarchy, enter edit services rpm probe customerB 2. Enter set test http-test probe-frequency 30 3. Enter set test http-test probe-type http-get 4. Enter set test http-test target url http://customerB.net
Configure RPM thresholds and corresponding SNMP traps to catch 3 or more successive lost probes and total lost probes of 10 or more.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select http-test. 2. In the Thresholds box, select the Yes check box, and click Configure. 3. In the Successive loss box, type 3. 4. In the Total loss box, type 10. 5. Click OK. 6. In the Traps box, click Add new entry. 7. In the Value box, select probe-failure. 8. Click OK. 9. In the Traps box, click Add new entry. 10. In the Value box, select test-failure. 11. Click OK. 	<ol style="list-style-type: none"> 1. Enter set probe customerB test icmp-test thresholds successive-loss 3 2. Enter set probe customerB test icmp-test thresholds total-loss 10 3. Enter set probe customerB test icmp-test traps probe-failure 4. Enter set probe customerB test icmp-test traps test-failure

Configuring TCP and UDP Probes (Optional)

To configure RPM using TCP and UDP probes, in addition to the basic RPM properties, you must configure both the host Services Router and the remote Services Router to act as TCP and UDP servers.

In this sample use of RPM, a probe is configured for one customer: Customer C. The probe for Customer C uses TCP packets. The remote router is configured as an RPM server for both TCP and UDP packets, using ports 50000 and 50037, respectively. Router A is the host router in this example, and router B is the remote router. To configure this RPM probe:

1. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
2. Perform the configuration tasks described in Table 93.
3. If you are finished configuring the network, commit the configuration.
4. Go on to one of the following procedures:
 - To tune a probe, see “Tuning RPM Probes (Optional)” on page 207.
 - To check the configuration, see “Verifying an RPM Configuration” on page 208.

Table 93: Configuring TCP and UDP Probes

Task	J-Web Configuration Editor	CLI Configuration Editor
Router A Configuration		
Navigate to the Services > RPM level in the configuration hierarchy.	1. In the configuration editor hierarchy, select Services .	From the top of the configuration hierarchy, enter
	2. Select the Yes check box.	<code>edit services rpm</code>
	3. Click Configure .	
Configure the RPM owner customerC .	1. In the Probe box, click Add new entry .	Enter
	2. In the Owner box, type customerC .	<code>set probe customerC</code>
	3. Click OK .	

Table 93: Configuring TCP and UDP Probes (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Configure the RPM test tcp-test for the RPM owner customerC . The sample RPM test is a TCP probe with a test interval (probe frequency) of 5 , a probe type of tcp-ping , and a target address of 192.162.45.6 .	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select customerC. 2. In the Test box, click Add new entry. 3. In the Name box, type tcp-test. 4. In the Probe frequency box, type 5. 5. In the Probe type box, select tcp-ping. 6. In the Target box, select the Yes check box, and click Configure. 7. In the Target type box, select Address. 8. In the Address box, type 192.162.45.6. 9. Click OK. 	<ol style="list-style-type: none"> 1. From the top of the configuration hierarchy, enter edit services rpm probe customerC 2. Enter set test tcp-test probe-frequency 5 3. Enter set test tcp-test probe-type tcp-ping 4. Enter set test tcp-test target address 192.162.45.6
Configure port 50000 as the TCP port to which the RPM probes are sent.	In the Destination port box, type 50000 .	Enter set test tcp-test destination-port 50000
Router B Configuration		
Navigate to the Services > RPM level in the configuration hierarchy.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Services. 2. Select the Yes check box. 3. Click Configure. 	From the top of the configuration hierarchy, enter edit services rpm
Configure Router B to act as a TCP server, using port 50000 to send and receive TCP probes.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Probe Server. 2. In the Tcp box, click Configure. 3. In the Port box, type 50000. 4. Click OK. 	Enter set probe-server tcp port 50000
Configure Router B to act as a UDP server, using port 50037 to send and receive UDP probes.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Probe Server. 2. In the Udp box, click Configure. 3. In the Port box, type 50037. 4. Click OK. 	Enter set probe-server udp port 50037

Tuning RPM Probes (Optional)

After configuring an RPM probe, you can set parameters to control probe functions, such as the interval between probes, the total number of concurrent probes that a system can handle, and the source address used for each probe packet. This example tunes the ICMP probe set for customer A in “Configuring Basic RPM Probes (Required)” on page 201.

To configure tune RPM probes:

1. Perform the configuration tasks described in Table 92.
2. Navigate to the top of the configuration hierarchy in either the J-Web or CLI configuration editor.
3. Perform the configuration tasks described in Table 94.
4. If you are finished configuring the network, commit the configuration.
5. To check the configuration, see “Verifying an RPM Configuration” on page 208.

Table 94: Tuning RPM Probes

Task	J-Web Configuration Editor	CLI Configuration Editor
Navigate to the Services > RPM level in the configuration hierarchy.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Services. 2. Select the Yes check box. 3. Click Edit. 	From the top of the configuration hierarchy, enter edit services rpm
Set the maximum number of concurrent probes allowed on the system to 10 .	In the Probe limit box, type 10 .	Enter set probe-limit 10
Navigate to the Services > RPM > Probe > CustomerA > Test > Icmp-test level in the configuration hierarchy.	<ol style="list-style-type: none"> 1. In the configuration editor hierarchy, select Services. 2. Select the Yes check box. 3. Click Edit. 4. In the Probe box, click icmp-test. 	From the top of the configuration hierarchy, enter edit services rpm probe customerA test icmp-test
Set the time between probe transmissions to 30 seconds.	In the Probe interval box, type 15 .	Enter set probe-interval 15

Table 94: Tuning RPM Probes (continued)

Task	J-Web Configuration Editor	CLI Configuration Editor
Set the number of probes within a test to 10.	In the Probe count box, type 10.	Enter set probe-count 10
Set the source address for each probe packet to 192.168.2.9. If you do not explicitly configure a source address, the address on the outgoing interface through which the probe is sent is used as the source address.	In the Source address box, type 192.168.2.9.	Enter set source-address 192.168.2.9

Verifying an RPM Configuration

To verify an RPM configuration, perform these tasks:

- Verifying RPM Statistics on page 208
- Verifying RPM Probe Servers on page 209

Verifying RPM Statistics

Purpose	Verify that the RPM probes are functioning and that the RPM statistics are within expected values.
Action	From the J-Web interface, select Monitor > RPM . From the CLI, enter the show services rpm probe-results command.
Sample Output	<pre> user@host> show services rpm probe-results Owner: customerA, Test: icmp-test Probe type: icmp-ping-timestamp Minimum Rtt: 312 usec, Maximum Rtt: 385 usec, Average Rtt: 331 usec, Jitter Rtt: 73 usec, Stddev Rtt: 27 usec Minimum egress time: 0 usec, Maximum egress time: 0 usec, Average egress time: 0 usec, Jitter egress time: 0 usec, Stddev egress time: 0 usec Minimum ingress time: 0 usec, Maximum ingress time: 0 usec, Average ingress time: 0 usec, Jitter ingress time: 0 usec, Stddev ingress time: 0 usec Probes sent: 5, Probes received: 5, Loss percentage: 0 Owner: customerB, Test: http-test Target address: 192.176.17.4, Target URL: http://customerB.net, Probe type: http-get Minimum Rtt: 1093 usec, Maximum Rtt: 1372 usec, Average Rtt: 1231 usec, Jitter Rtt: 279 usec, Stddev Rtt: 114 usec Probes sent: 3, Probes received: 3, Loss percentage: 0 </pre>

What It Means	<p>The output shows the probe results for the RPM tests configured on the Services Router. Verify the following information:</p> <ul style="list-style-type: none"> ■ Each configured test is displayed. Results are displayed in alphabetical order, sorted first by owner name and then by test name. ■ The round-trip times fall within the expected values for the particular test. The minimum round-trip time is displayed as Minimum Rtt, the maximum round-trip time is displayed as Maximum Rtt, and the average round-trip time is displayed as Average Rtt. <p>A high average round-trip time might mean that performances problems exist within the network. A high maximum round-trip time might result in high jitter values.</p> <ul style="list-style-type: none"> ■ The egress (outbound) trip times fall within the expected values for the particular test. The minimum outbound time is displayed as Minimum egress time, the maximum outbound time is displayed as Maximum egress time, and the average outbound time is displayed as Average egress time. ■ The ingress (inbound) trip times fall within the expected values for the particular test. The minimum inbound time is displayed as Minimum ingress time, the maximum inbound time is displayed as Maximum ingress time, and the average inbound time is displayed as Average ingress time. ■ The number of probes sent and received is expected. <p>Lost probes might indicate packet loss through the network. Packet losses can occur if the remote server is flapping. If the RPM probe type is TCP or UDP, complete probe loss might indicate a mismatch in TCP or UDP RPM port number.</p> <ul style="list-style-type: none"> ■ For Type, each peer is configured as the correct type (either internal or external). <p>For more information about <code>show services rpm probe-results</code>, see the <i>JUNOS System Basics and Services Command Reference</i>.</p>
----------------------	--

Verifying RPM Probe Servers

Purpose	Verify that the Services Router is configured to receive and transmit TCP and UDP RPM probes on the correct ports.
Action	From the CLI, enter the <code>show services rpm active-servers</code> command.
Sample Output	<pre>user@host> show services rpm active-servers Protocol: TCP, Port: 50000 Protocol: UDP, Port: 50037</pre>
What It Means	The output shows a list of the protocols and corresponding ports for which the Services Router is configured as an RPM server.

For more information about `show services rpm active-servers`, see the *JUNOS System Basics and Services Command Reference*.

Chapter 10

Performing Software Upgrades and Reboots

To upgrade the JUNOS Internet software on a Services Router, you install a new version that you download from the Web to a remote server or your computer. Use either the J-Web interface or the CLI to perform the upgrade.

If you need to replace the primary boot device or add a backup boot device on the router, you can configure a boot device with the CLI or with a UNIX or Microsoft Windows computer. You can also configure a boot device to receive core dumps.

Use either the J-Web interface or the CLI to schedule a reboot or system halt on the router, or to perform one immediately.

For more information about installing and upgrading JUNOS software, see the *JUNOS System Basics Configuration Guide*.

- Upgrade Overview on page 211
- Before You Begin on page 212
- Downloading Software Upgrades from Juniper Networks on page 212
- Installing Software Upgrades on page 213
- Downgrading the Software on page 218
- Configuring Boot Devices on page 220
- Rebooting or Halting a Services Router on page 229

Upgrade Overview

The Services Router is delivered with the JUNOS Internet software preinstalled. To upgrade the software, you use the J-Web interface or CLI commands to copy a set of software images over the network to memory storage on the Routing Engine.

All `junos-jseries` software is delivered in signed packages that contain Secure Hash Algorithm 1 (SHA-1) checksums. A package is installed only if the SHA-1 checksum within it matches the SHA-1 hash recorded in its corresponding `.sha1` file. (For example, `junos-jseries-release-export.tgz`

contains `junos-jseries-release-export` and `junos-jseries-release-export.sha1`. The `junos-jseries-release-export.tgz` package is installed only if the SHA-1 hashes match in `junos-jseries-release-export` and `junos-jseries-release-export.sha1`.)

The `junos-jseries` package completely reinstalls the software. This package rebuilds the file system but retains configuration files, log files, and similar information from the previous version.

Before You Begin

To download software upgrades, you must have a Web account with Juniper Networks. To obtain an account, complete the registration form at the Juniper Networks Web site: <https://www.juniper.net/registration/Register.jsp>.

Before upgrading, be sure to back up the currently running and active file system and configuration so that you can recover to a known, stable environment in case the upgrade is unsuccessful. To back up the file system, you must have a removable compact flash drive installed on the J4300 or J6300 Services Router, or a USB storage device installed on any J-series Services Router.

To back up the file system to the removable compact flash drive, issue the following command:

```
user@host> request system snapshot media removable-compact-flash
```

To back up the file system to the removable USB storage device, issue the following command:

```
user@host> request system snapshot media usb
```

For details about the `request system snapshot` command, see “Configuring Boot Devices with the CLI” on page 224.

Downloading Software Upgrades from Juniper Networks

Follow these steps to download software upgrades from Juniper Networks:

1. Using a Web browser, follow the links to the download URL on the Juniper Networks Web page. Choose either **Canada and U.S. Version** or **Worldwide Version**:
 - <https://www.juniper.net/support/csc/swdist-domestic/>
 - <https://www.juniper.net/support/csc/swdist-ww/>
2. Log in to the Juniper Networks authentication system using the username (generally your e-mail address) and password supplied by Juniper Networks representatives.
3. Using either the J-Web interface or the CLI, choose the software package for your application.

4. Download the software to a local host.

Installing Software Upgrades

Use either the J-Web interface or the CLI to install JUNOS software upgrades. This section contains the following topics:

- Installing Software Upgrades with the J-Web Interface on page 213
- Installing Software Upgrades with the CLI on page 217
- Installing Firmware Upgrades with the CLI on page 217

Installing Software Upgrades with the J-Web Interface

You can use the J-Web interface to install software upgrades from a remote server using FTP or HTTP, or by uploading the file to the router. This section contains the following topics:

- Installing Software Upgrades from a Remote Server on page 213
- Installing Software Upgrades by Uploading Files on page 215

Installing Software Upgrades from a Remote Server

You can use the J-Web interface to install software packages on the Services Router that are retrieved with FTP or HTTP from the location specified.

Figure 21 shows the Install Remote page for the router.

Figure 21: Install Remote Page

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage**

Manage > Software > Install Remote

Software

Install Remote

You can instruct the router to retrieve a software package from a remote server by specifying the location below.

* **Package Location**

User

Password

Reboot If Required ☐

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice.](#)

To install software upgrades from a remote server:

1. Download the software package as described in “Downloading Software Upgrades from Juniper Networks” on page 212.
2. Log in to the Juniper Networks authentication system using the username (generally your e-mail address) and password supplied by Juniper Networks representatives.
3. Download the software to your local host or internal software distribution site.
4. In the J-Web interface, select **Manage > Software > Install Remote**.
5. On the Install Remote page, enter information into the fields described in Table 95.
6. Click **Fetch and Install Package**. The software is activated after the router has rebooted.


Table 95: Install Remote Summary

Field	Function	Your Action
Package Location (required)	Specifies the FTP or HTTP server, file path, and software package name.	Type the full address of the software package location on the FTP or HTTP server—one of the following: <i>ftp:// hostname / pathname / package-name</i> <i>http:// hostname / pathname / package-name</i>
User	Specifies the username, if the server requires one.	Type the username.
Password	Specifies the password, if the server requires one.	Type the password.
Reboot If Required	If this box is checked, the router is automatically rebooted when the upgrade is complete.	Check the box if you want the router to reboot automatically when the upgrade is complete.

Installing Software Upgrades by Uploading Files

You can use the J-Web interface to install software packages uploaded from your computer to the Services Router.

Figure 22 shows the Upload Package page for the router.

Figure 22: Upload Package Page


Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage**

Manage > **Software** > **Upload Package**

Software

Upload Package

The software package file specified below will be uploaded to the router for installation.

* **File to Upload** ?

Reboot If Required ☐ ?

Copyright © 2004-2005, Juniper Networks, Inc. All Rights Reserved. [Trademark Notice](#).

To install software upgrades by uploading files:

1. Download the software package as described in “Downloading Software Upgrades from Juniper Networks” on page 212.
2. In the J-Web interface, select **Manage > Software > Upload Package**.
3. On the Upload Package page, enter information into the fields described in Table 96.
4. Click **Upload Package**. The software is activated after the router has rebooted.

Table 96: Upload Package Summary

Field	Function	Your Action
File to Upload (required)	Specifies the location of the software package.	Type the location of the software package, or click Browse to navigate to the location.
Reboot If Required	If this box is checked the router is automatically rebooted when the upgrade is complete.	Select the check box if you want the router to reboot automatically when the upgrade is complete.

Installing Software Upgrades with the CLI

To install software upgrades on a router with the CLI:

1. Download the software package as described in “Downloading Software Upgrades from Juniper Networks” on page 212.
2. Copy the software package to the router. We recommend that you copy it to the `/var/tmp` directory.
3. Install the new package on the Services Router:

```
user@host> request system software add validate unlink reboot source
```

Replace `source` with one of the following paths:

- For a software package that is installed from a local directory on the router—`/pathname/package-name`
- For software packages that are downloaded and installed from a remote location:
 - `ftp://hostname/pathname/package-name`
 - `http://hostname/pathname/package-name`

The `validate` option validates the software package against the current configuration as a prerequisite to adding the software package, to ensure that the router reboots successfully. This is the default behavior when you are adding a software package for a different release.

The `unlink` option removes the package at the earliest opportunity so that the router has enough room to complete the installation.

Adding the `reboot` command reboots the router after the upgrade is validated and installed. Rebooting takes place only if the upgrade is successful.

When the reboot is complete, the router displays the login prompt.

Installing Firmware Upgrades with the CLI

Occasionally, upgrading the JUNOS software might require you to upgrade the firmware on the PIMs. To upgrade firmware using the CLI:

1. Log into the Services Router that requires the firmware upgrade.
2. Using FTP, copy the upgradable firmware file package from your server to the temporary folder on your Services Router called `/var/temp`.
3. Using the `request system software delete jfirmware` command, delete the existing firmware files on the Services Router.

4. Using the `ls /usr/share/pfe/firmware` command, verify that the firmware is deleted.
5. Using the `request system software add /var/temp/jfirmware-jseries filename-signed.tgz` command, install the new firmware package on the Services Router.
6. Using the `show version detail` command, verify that the firmware package is installed:

```
user@host> show version detail
hostname: servicesrouter
Model: J4300
JUNOS Software Release: [[7.3I20050612.0]
systest.pepsielf.pkg: Created by pkg_create script
jfirmware: JUNOS Firmware Software Suite [7.3I20050024_1127_signed]
KERNEL 7.3R1 built by builder on 2005-06-30 16:32:44 UTC
```

7. Using the `ls /usr/share/pfe/firmware/` command, verify that the firmware binary files are present in the folder.
8. Enter `show system firmware` to display the installed PIMs on the Services Router.
9. Using the `request system firmware upgrade pic pic-slot 0 fpc-slot number tag number` command, upgrade the firmware on the selected PIM.



NOTE: Be sure to upgrade each tag on the PIM.

10. The upgrade takes a few minutes, and you can check the status using the `show system firmware` command until `upgraded successfully` is displayed next to the selected PIM.

Repeat Steps 9 and 10 for each tag on the PIM.

11. Restart the PIM using the `request chassis fpc slot number restart` command.
12. Using the `show system firmware` command, verify that the firmware is upgraded.

Downgrading the Software

Downgrade the JUNOS software on the Services Router with either the J-Web interface or the CLI. This section contains the following topics:

- Downgrading the Software with the J-Web Interface on page 219
- Downgrading the Software with the CLI on page 219
- Downgrading the Firmware with the CLI on page 219

Downgrading the Software with the J-Web Interface

You can downgrade the software from the J-Web interface. When you downgrade the software to a previous version, the software version that is saved in `junos.old` is the version of JUNOS that your router is downgraded to. For your changes to take effect, you must reboot the router.

To downgrade software:

1. Go to **Manage > Software > Downgrade**. The previous version (if any) is displayed on this page. For example, you can downgrade to the previously installed version of the router software, `/cf/packages/junos-7.0120040930_1745-domestic`.



NOTE: After you perform this operation, you cannot undo it.

2. Select **Downgrade** to downgrade to the previous version of the software or **Cancel** to cancel the downgrade process.
3. When the downgrade process is complete, for the new software to take effect, click **Manage > Reboot** to reboot the router at your convenience.

Downgrading the Software with the CLI

You can revert to the previous set of software using the `request system software rollback` command in the CLI. Rollback fails if the `junos-jseries` software bundle cannot be found in `/var/sw/pkg`.

You can roll back only to the software release that was installed on the Services Router before the current release. After you issue the `request system software rollback` command, the old release is loaded and you can not reload it again. Issuing the `request system software rollback` command again results in an error.

To downgrade to an earlier version of software, follow the procedure for upgrading, using the `junos-jseries` software bundle labeled for the appropriate release.

Downgrading the Firmware with the CLI

Occasionally, downgrading the JUNOS software might require you to downgrade the firmware on the PIMs. To downgrade firmware using the CLI:

1. Log into the Services Router that requires the firmware downgrade.
2. Using FTP, copy the downgradable firmware file package from your server to the temporary folder on your Services Router called `/var/temp`.
3. Using the `request system software delete jfirmware` command, delete the existing firmware files on the Services Router.

4. Using the `ls /usr/share/pfe/firmware` command, verify that the firmware is deleted.
5. Using the `request system software add /var/temp/jfirmware-jseries filename-signed.tgz` command, install the downgradeable firmware package on the Services Router.
6. Using the `show version detail` command, verify that the firmware package is installed:

```
user@host> show version detail
hostname: servicesrouter
Model: J4300
JUNOS Software Release: [[7.2I20050612.0]
systest.pepsielf.pkg: Created by pkg_create script
jfirmware: JUNOS Firmware Software Suite [7.2I20050024_1127_signed]
KERNEL 7.2R1 built by builder on 2005-03-30 16:32:44 UTC
```

7. Using the `ls /usr/share/pfe/firmware/` command, verify that the firmware binary files are present in the folder.
8. Enter `show system firmware` to display the installed PIMs on the Services Router.
9. Issue the `request system firmware downgrade pic pic-slot 0 fpc-slot number tag number` command, downgrade the firmware on the selected PIM.



NOTE: Be sure to downgrade each tag on the PIM.

10. Downgrading takes a few minutes, and you can check the status using the `show system firmware` command until `downgraded successfully` is displayed next to the selected PIM.

Repeat Steps 9 and 10 for each tag on the PIM.

11. Restart the PIM using the `request chassis fpc slot number restart` command.
12. Using the `show system firmware` command, verify that the firmware is downgraded.

Configuring Boot Devices

You can configure a boot device to replace the primary boot device on your Services Router, or to act as a backup boot device. Use either the J-Web interface or the CLI to take a *snapshot* of the configuration currently running on the router, or of the original factory configuration and a rescue configuration, and save it to an alternate medium.



NOTE: For media redundancy, we recommend that you keep a secondary storage medium attached to the Services Router and updated at all times.

If the primary storage medium becomes corrupted and no backup medium is in place, you can recover the primary compact flash from a special JUNOS software image. You can also configure a boot device to store snapshots of software failures, for use in troubleshooting.

For information about installing boot devices, see the *J-series Services Router Getting Started Guide*.

This section contains the following topics:

- Configuring Boot Devices with the J-Web Interface on page 221
- Configuring Boot Devices with the CLI on page 224
- Configuring Compact Flash Recovery on page 226
- Configuring a Boot Device to Receive Software Failure Memory Snapshots on page 229

Configuring Boot Devices with the J-Web Interface

You can use the J-Web interface to create a boot device for the Services Router on an alternate medium, to replace the primary boot device or serve as a backup.

Figure 23 shows the Snapshot page.

Figure 23: Snapshot Page

Logged in as: **regress**

[Help](#) [About](#) [Logout](#)

Monitor / **Configuration** / **Diagnose** / **Manage**

[Manage](#) > [Snapshot](#)

Snapshot

System Snapshot

You can configure boot devices to replace the primary boot device on your router or to act as a backup boot device. To do this, you create a snapshot of the system software running on your router, saving the snapshot to an alternate media.

The snapshot process copies the current system software, along with the current and rescue configurations, to alternate media. Optionally, you can copy only the factory and rescue configurations.

Target Media ?

Factory ☐ ?

Partition ☐ ?

☐ **Advanced options**

To create a boot device:

1. In the J-Web interface, select **Manage > Snapshot**.
2. On the Snapshot page, enter information into the fields described in Table 97.
3. Click **Snapshot**.
4. Click **OK**.

Table 97: Snapshot Summary

Field	Function	Your Action
Target Media	<p>Specifies the boot device to copy the snapshot to.</p> <p>NOTE: You cannot copy software to the active boot device.</p>	<p>In the list, select a boot device that is not the active boot device:</p> <ul style="list-style-type: none"> ■ compact-flash—Copies software to the primary compact flash drive. ■ removable-compact-flash—Copies software to the removable compact flash drive. This option is available on J4300 and J6300 Services Routers only. ■ usb—Copies software to the device connected to the USB port.
Factory	<p>Copies only default files that were loaded on the primary compact flash drive when it was shipped from the factory, plus the rescue configuration, if one has been set.</p> <p>NOTE: After a boot device is created with the default factory configuration, it can operate only in a primary compact flash drive slot.</p>	<p>To copy only the default factory configuration, plus a rescue configuration if one exists, select the check box.</p>
Partition	<p>Partitions the medium. This process is usually necessary for boot devices that do not already have software installed on them.</p>	<p>To partition the medium that you are copying the snapshot to, select the check box.</p>
As Primary Media	<p>On a removable compact flash or USB storage device only, creates a snapshot for use as the primary boot medium.</p> <p>Use this feature to replace the medium in the primary compact flash drive or to replicate it for use in another Services Router. This process also partitions the boot medium.</p> <p>NOTE: After the boot device is created as a primary compact flash drive, it can operate only in a primary compact flash drive slot.</p>	<p>To create a boot medium to use in the primary compact flash drive only, select the check box.</p>
Data Size	<p>Specifies the size of the data partition, in kilobytes.</p> <p>The data partition is mounted on /data. This space is not used by the router, and can be used for extra storage.</p> <p>This selection also partitions the boot medium.</p>	<p>Type a numeric value, in kilobytes. The default value is 0 KB.</p>

Table 97: Snapshot Summary (continued)

Field	Function	Your Action
Swap Size	<p>Specifies the size of the swap partition, in kilobytes.</p> <p>The swap partition is used for swap files and software failure memory snapshots. Software failure memory snapshots are saved to the boot medium only if it is specified as the dump device.</p> <p>For information about the setting the dump device, see “Configuring a Boot Device to Receive Software Failure Memory Snapshots” on page 229.</p> <p>This selection also partitions the boot medium.</p>	Type a numeric value, in kilobytes. The default value is one-third of the physical memory on a boot medium larger than 128,000 KB, or 0 KB on a smaller boot device.
Config Size	<p>Specifies the size of the config partition, in kilobytes.</p> <p>The config partition is mounted on /config. The configuration files are stored in this partition.</p> <p>This selection also partitions the boot medium.</p>	Type a numeric value, in kilobytes. The default value is 10 percent of physical memory on the boot medium.
Root Size	<p>Specifies the size of the root partition, in kilobytes.</p> <p>The root partition is mounted on / and does not include configuration files.</p> <p>This selection also partitions the boot medium.</p>	Type a numeric value, in kilobytes. The default value is the boot device’s physical memory minus the config , data , and swap partitions.

Configuring Boot Devices with the CLI

Use the **request system snapshot** CLI command to create a boot device for the Services Router on an alternate medium, to replace the primary boot device or serve as a backup. Enter the command with the following syntax:

```
user@host> request system snapshot <as-primary> <config-size size>
<data-size size> <factory> <media type> <partition> <root-size size>
<swap-size size>
```

Table 98 describes the **request system snapshot** command options. Default values are in megabytes, but you can alternatively enter values in kilobytes by appending **k** to the number. For example, **config-size 10** specifies a config partition of 10 MB, but **config-size 10k** specifies a config partition of 10 KB.

Table 98: CLI request system snapshot Command Options

Option	Description
as-primary	<p>On a removable compact flash or USB storage device only, creates a snapshot for use as the primary boot medium.</p> <p>Use the as-primary option to replace the medium in the primary compact flash drive or to replicate it for use in another Services Router. This process also partitions the boot medium.</p> <p>NOTE: After the boot device is created as a primary compact flash drive, it can operate only in a primary compact flash drive slot.</p>
config-size <i>size</i>	<p>Specifies the size of the config partition, in megabytes. The default value is 10 percent of physical memory on the boot medium.</p> <p>The config partition is mounted on /config. The configuration files are stored in this partition.</p> <p>This option also partitions the boot medium.</p>
data-size <i>size</i>	<p>Specifies the size of the data partition, in megabytes. The default value is 0 MB.</p> <p>The data partition is mounted on /data. This space is not used by the router, and can be used for extra storage.</p> <p>This option also partitions the boot medium.</p>
factory	<p>Copies only default files that were loaded on the primary compact flash drive when it was shipped from the factory, plus the rescue configuration if one has been set.</p> <p>NOTE: After the boot medium is created with the factory option, it can operate in only the primary compact flash drive slot.</p>
media <i>type</i>	<p>Specifies the boot device the software snapshot is copied to:</p> <ul style="list-style-type: none"> ■ compact-flash—Copies software to the primary compact flash drive. ■ removable-compact-flash—Copies software to the removable compact flash drive. This option is available on J4300 and J6300 Services Routers only. ■ usb—Copies software to the device connected to the USB port. <p>NOTE: You cannot copy software to the active boot device.</p>
partition	<p>Partitions the medium. This option is usually necessary for boot devices that do not have software already installed on them.</p>
root-size <i>size</i>	<p>Specifies the size of the root partition, in megabytes. The default value is the boot device's physical memory minus the config, data, and swap partitions.</p> <p>The root partition is mounted on / and does not include configuration files.</p> <p>This option also partitions the boot medium.</p>
swap-size <i>size</i>	<p>Specifies the size of the swap partition, in megabytes. The default value is one-third of the physical memory on a boot medium larger than 128 MB, or 0 MB on a smaller boot device.</p> <p>The swap partition is used for swap files and software failure memory snapshots. Software failure memory snapshots are saved to the boot medium only if it is specified as the dump device. For information about the setting the dump device, see "Configuring a Boot Device to Receive Software Failure Memory Snapshots" on page 229.</p> <p>NOTE: This option also partitions the boot medium.</p>

Configuring Compact Flash Recovery

All Services Routers use a compact flash disk, or card, to store the JUNOS Internet software, router configuration files, and log files. The primary compact flash drive is not hot-swappable and is accessible only after you remove the cover on the back panel of the router chassis. In addition to the primary compact flash disk, J4300 and J6300 Services Routers have a slot in the front of the chassis for removable flash media. All Services Routers also support externally pluggable USB storage devices.

This section contains the following topics:

- Why Compact Flash Recovery Might Be Necessary on page 226
- Recommended Recovery Hardware and Software on page 226
- Recovering Primary Compact Flash on page 227

Why Compact Flash Recovery Might Be Necessary

For media redundancy, we recommend that you keep a secondary storage medium attached and updated at all times. Use the `request system snapshot` command to perform the update. (For instructions, see “Configuring Boot Devices” on page 220.)

If the primary compact flash disk fails at startup, the Services Router automatically boots itself from the removable compact flash or USB storage device. When a redundant storage medium is not available, the router is unable to boot and does not come back online. This situation can occur if the power fails during a JUNOS software upgrade and the physical or logical storage media on the router are corrupted.

If the primary storage medium becomes corrupted and no secondary medium is in place, you can reload the JUNOS software image onto the corrupted compact flash card with a desktop or laptop computer running either a UNIX, Microsoft Windows 2000, or Windows XP operating system.



CAUTION: This procedure does not recover any router configuration files. After you reinstall the JUNOS software, all the information on the original primary compact flash disk is lost.

Recommended Recovery Hardware and Software

Before configuring compact flash recovery, assemble the equipment and software listed in Table 99.

Table 99: Recommended Recovery Hardware and Software

Recommended Hardware and Software		Examples
Recovery Hardware		
Host system	Desktop or laptop PC equipped with a PCMCIA controller or USB port	
Adapter appropriate for your system	■	For systems with PCMCIA controllers, a compact-flash-to-PCMCIA adapter—for example, a Macally PCM-CF compact flash PCMCIA adapter.
	■	For systems with a USB port, a USB-to-compact-flash adapter. For example:
	■	SIIG USB 2.0 Card Reader, model US2274, part number JU-CF0122
	■	MediaGear USB 2.0 Combo 9-in-4, model MGTR100
	■	AVP USB 8-in-1 Card Reader, model UC-28
	■	Inland Multi-Plus Card Reader, part number 08310
	■	HummingBird Multi Card Reader, HCR 81
Recovery Software		
Software appropriate for your system	■	UNIX with PCMCIA drivers
	■	Windows 2000, or Windows XP
Systems running Windows require additional software.	■	WinZip, gzip , or a similar compression utility
	■	A utility such as the following that allows you to write files to unformatted devices:
	■	Norton Ghost
	■	dd utility from the Cygwin package
	■	physdiskwrite utility

Recovering Primary Compact Flash

To recover a primary compact flash disk with a corrupt or missing operating system, you must copy a special JUNOS software image directly to an unformatted (raw) device. Recovery images are available from the same location as normal J-series software upgrades. (See “Downloading Software Upgrades from Juniper Networks” on page 212.)

The images use the naming convention `junos-jseries-release-cf-nnn.gz`, where *release* is the software version and *nnn* is the target compact flash disk size in megabytes—128, 256, or 512.

To recover a primary compact flash disk:

1. Plug the compact flash drive into a PCMCIA adapter or USB card reader on the host PC, and verify that it is recognized by the operating system.
2. Copy the JUNOS software image to the host PC and uncompress it with the compression utility.

The uncompressed image must have the same size as the target compact flash capacity: 128 MB, 256 MB, or 512 MB.

3. Copy the JUNOS software image to the compact flash disk with one of the following commands:



CAUTION: You must use the correct target device name. Failure to do so might damage other storage devices connected to the host PC.

- On a UNIX PC, use the command `dd if=filename of=/dev/device_name`. Replace *filename* with the name of the uncompressed image, and *device_name* with the name of the unformatted PCMCIA card device. For example:

```
root# dd if=junos-jseries-7.0-20041028.0-export-cf128 of=/dev/hde
250368+0 records in 250368+0 records out
```

- On a Windows 2000 or Windows XP PC, use the Norton Ghost, dd, or physdiskwrite utility. The following example shows the use of physdiskwrite:

```
C:\> physdiskwrite -u junos-jseries-7.0-20041028.0-export-cf512

physdiskwrite v0.5 by Manuel Kasper
Searching for physical drives...
Information for \\.\PhysicalDrive0:
Windows: cyl: 2432
tpc: 255
spt: 63
C/H/S: 16383/16/63
Model: HITACHI_DK23DA-20
Serial number: 123ABC
Firmware rev.: 00J2A0G0
Information for \\.\PhysicalDrive1:
Windows: cyl: 125
tpc: 255
spt: 63
Which disk do you want to write? (0..1) 1
WARNING: that disk is larger than 800 MB! Make sure you're
not accidentally overwriting your primary hard disk!
Proceeding on your own risk...
About to overwrite the contents of disk 1 with new data.
Proceed? (y/n) y
511451136/511451136 bytes written in total
```



NOTE: The copy process can take several minutes.

After copying the image to the compact flash disk, you can use it as the primary compact flash disk in any J-series Services Router. For installation instructions, see the *J-series Services Router Getting Started Guide*.

Configuring a Boot Device to Receive Software Failure Memory Snapshots

You can use the `set system dump-device` CLI command to specify the medium to use for the Services Router to store system software failure memory snapshots. In this way, when the operating system fails, if you have specified a system dump device in the configuration, the operating system preserves a snapshot of the state of the router when it failed.

After you reboot the system, the dump device is checked for a snapshot as part of the operating system boot process. If a snapshot is found, it is written to the crash dump directory on the router (`/var/crash`). The customer support team can examine this memory snapshot to help determine the cause of the system software failure.



NOTE: If the swap partition on the dump device medium is not large enough for a system memory snapshot, either a partial snapshot or no snapshot is written into the crash dump directory.

Enter the `set system dump-device` CLI command with the following syntax:

```
user@host> set system dump-device boot-device | compact-flash |
removable-compact-flash | usb
```

Table 100 describes the `set system dump-device` command options.

Table 100: CLI set system dump-device Command Options

Option	Description
boot-device	Uses whatever device was booted from as the system software failure memory snapshot device.
compact-flash	Uses the primary compact flash as the system software failure memory snapshot device.
removable-compact-flash	Uses the compact flash device on the front of the router (J4300 and J6300 only) as the system software failure memory snapshot device.
usb	Uses the device attached to the USB port as the system software failure memory snapshot device.

Rebooting or Halting a Services Router

Reboot or halt a Services Router with either the J-Web interface or the CLI. This section contains the following topics:

- Rebooting or Halting a Services Router with the J-Web Interface on page 230
- Rebooting the Services Router with the CLI on page 232
- Halting the Services Router with the CLI on page 232

Rebooting or Halting a Services Router with the J-Web Interface

You can use the J-Web interface to schedule a reboot or halt the Services Router.

Figure 24 shows the Reboot page for the router.

Figure 24: Reboot Page

Juniper NETWORKS **ROUTER - J4300** Logged in as: **regress**
[Help](#) [About](#) [Logout](#)

Monitor / Configuration / Diagnose / Manage

Manage > Reboot

Reboot

Schedule Reboot Or Halt

To reboot or halt the system, please select a time below.

Note that a halted system can only be accessed from the system console port.

The current system time is 16:31 (4:31 PM). Reboots scheduled to occur in the future will occur regardless of whether you log out of web management.

☐ Reboot Immediately
☒ Reboot in minutes
☐ Reboot when the system time is :
☐ Halt Immediately

Reboot From Media

Message

?

To reboot or halt the router with the J-Web interface:

1. In the J-Web interface, select **Manage > Reboot**.
2. Select one of the following options:
 - **Reboot Immediately**—Reboots the router immediately.
 - **Reboot in *number of minutes***—Reboots the router in the number of minutes from now that you specify.
 - **Reboot when the system time is *hour:minute***—Reboots the router at the absolute time that you specify, on the current day. You must select a 2-digit hour in 24-hour format, and a 2-digit minute.
 - **Halt Immediately**—Stops the router software immediately. After the router software has stopped, you can access the router through the console port only.
3. Choose the boot device from the **Reboot from media** list:
 - **compact-flash**—Reboots from the primary compact flash drive. This selection is the default choice.
 - **removable-compact-flash**—Reboots from the optional removable compact flash drive. This selection is available on J4300 and J6300 Services Routers only.
 - **usb**—Reboots from the USB storage device.
4. (Optional) In the Message box, type a message to be displayed to any users on the router before the reboot occurs.
5. Click **Schedule**. The J-Web interface requests confirmation to perform the reboot or halt.
6. Click **OK** to confirm the operation.
 - If the reboot is scheduled to occur immediately, the router reboots. You cannot access the J-Web interface until the router has restarted and the boot sequence is complete. After the reboot is complete, refresh the browser window to display the J-Web interface login page.
 - If the reboot is scheduled to occur in the future, the Reboot page displays the time until reboot. You have the option to cancel the request by clicking **Cancel Reboot** on the J-Web interface Reboot page.
 - If the router is halted, all software processes stop and you can access the router through the console port only. Reboot the router by pressing any key on the keyboard.



NOTE: If you cannot connect to the router through the console port, shut down the router by pressing and holding the power button on the front panel until the **POWER ON** LED turns off. After the router has shut down, you can power on the router

by pressing the power button again. The POWER ON LED lights during startup and remains steadily green when the router is operating normally.

Rebooting the Services Router with the CLI

You can use the `request system reboot` CLI command to schedule a reboot of the Services Router:

```
user@host> request system reboot <at time> <in minutes> <media type>
<message "text">
```

Table 101 describes the `request system reboot` command options.

Table 101: CLI Request System Reboot Command Options

Option	Description
<code>none</code>	Same as <code>at now</code> (reboots the router immediately).
<code>at time</code>	Specifies the time at which to reboot the router. You can specify time in one of the following ways: <ul style="list-style-type: none"> ■ <code>now</code>—Reboots the router immediately. This is the default. ■ <code>+ minutes</code>—Reboots the router in the number of minutes from now that you specify. ■ <code>yymmddhhmm</code>—Reboots the router at the absolute time on the date you specify. Enter the year, month, day, hour (in 24-hour format), and minute. ■ <code>hh:mm</code>—Reboots the router at the absolute time you specify, on the current day. Enter the time in 24-hour format, using a colon (:) to separate hours from minutes.
<code>in minutes</code>	Specifies the number of minutes from now to reboot the router. This option is a synonym for the <code>at + minutes</code> option.
<code>media type</code>	Specifies the boot device to boot the router from: <ul style="list-style-type: none"> ■ <code>compact-flash</code>—Reboots from the primary compact flash drive. This is the default. ■ <code>removable-compact-flash</code>—Reboots from the optional removable compact flash drive. This option is available on J4300 and J6300 Services Routers only. ■ <code>usb</code>—Reboots from the USB storage device.
<code>message "text"</code>	Provides a message to display to all system users before the router reboots.

Halting the Services Router with the CLI

You can use the `request system halt` CLI command to halt the Services Router:

```
user@host> request system halt <at time> <in minutes> <media type>
<message "text">
```

When the router is halted, all software processes stop and you can access the router through the console port only. Reboot the router by pressing any key on the keyboard.



NOTE: If you cannot connect to the router through the console port, shut down the router by pressing and holding the power button on the front panel until the POWER ON LED turns off. After the router has shut down, you can power on the router by pressing the power button again. The POWER ON LED lights during startup and remains steadily green when the router is operating normally.

Table 102 describes the `request system halt` command options.

Table 102: CLI Request System Halt Command Options

Option	Description
<code>none</code>	Same as <code>at now</code> (stops software processes on the router immediately).
<code>at time</code>	Time at which to stop the software processes on the router. You can specify time in one of the following ways: <ul style="list-style-type: none"> ■ <code>now</code>—Stops the software processes immediately. This is the default. ■ <code>+ minutes</code>—Stops the software processes in the number of minutes from now that you specify. ■ <code>yymmddhhmm</code>—Stops the software processes at the absolute time you specify. Enter the year, month, day, hour (in 24-hour format), and minute. ■ <code>hh:mm</code>—Stops the software processes at the absolute time that you specify, on the current day. Enter the time in 24-hour format, using a colon (:) to separate hours from minutes.
<code>in minutes</code>	Specifies the number of minutes from now to stop the software processes on the router. This option is a synonym for the <code>at + minutes</code> option.
<code>media type</code>	Specifies the boot device to boot the router from after the halt: <ul style="list-style-type: none"> ■ <code>compact-flash</code>—Reboots from the primary compact flash drive. This is the default. ■ <code>removable-compact-flash</code>—Reboots from the optional removable compact flash drive. This option is available on J4300 and J6300 Services Routers only. ■ <code>usb</code>—Reboots from the USB storage device.
<code>message "text"</code>	Provides a message to display to all system users before the software processes on the router are stopped.

Chapter 11

Contacting Customer Support and Returning Hardware

This chapter describes how to return the Services Router or individual components to Juniper Networks for repair or replacement. It contains the following topics:

- Locating Component Serial Numbers on page 235
- Contacting Customer Support on page 237
- Return Procedure on page 238
- Packing a Router or Component for Shipment on page 239

Locating Component Serial Numbers

Before contacting Juniper Networks to request a Return Materials Authorization (RMA), you must find the serial number on the router or component. To list the router components and their serial numbers, enter the following command-line interface (CLI) command:

```
user@host> show chassis hardware
Hardware inventory:
Item          Version  Part number  Serial number  Description
Chassis                               JN000192AB     J4300
Midplane      REV 02.04 710-010001  CORE99563
System IO     REV 02.03 710-010003  CORE100885    P12/P45 System IO board
Routing Engine RevX2.6  750-010005  IWGS40735451  RE-J.2
FPC 0
PIC 0                               2x FE
```



NOTE: In the `show chassis hardware` command, the PIM slot number is reported as an FPC number and the PIM number (always 0) is reported as the PIC number.

Most components also have a small rectangular serial number ID label (see Figure 25 through Figure 27) attached to the component body.

Figure 25: J2300 Serial Number ID Label




Figure 26: J4300 Serial Number ID Label





Figure 27: J6300 Serial Number ID Label

The following sections describe the label location on each type of component:

- PIM Serial Number Label on page 237
- J6300 Power Supply Serial Number Labels on page 237

PIM Serial Number Label

The PIMs installed in the J4300 and J6300 Services Routers are field-replaceable. Each PIM has a unique serial number. The serial number label is located on the right side of the PIM, when the PIM is horizontally oriented (as it would be installed in the router). The exact location may be slightly different on different PIMs, depending on the placement of components on the PIM board.

J6300 Power Supply Serial Number Labels

The power supplies installed in the J6300 Services Router are field-replaceable. Each power supply has a unique serial number. The serial number label is located on the top of the power supply.

Contacting Customer Support

After you have located the serial numbers of the components you need to return, contact Juniper Networks Technical Assistance Center (JTAC) in one of the following ways.

You can contact JTAC 24 hours a day, seven days a week.

- On the Web, using the Case Manager link at <http://www.juniper.net/support/>
- By telephone:

From the US and Canada: 1-888-314-JTAC

From all other locations: 1-408-745-9500

If contacting JTAC by telephone, enter your 11-digit case number followed by the pound (#) key if this is an existing case, or press the star (*) key to be routed to the next available support engineer.

Information You Might Need to Supply to JTAC

When requesting support from JTAC by telephone, be prepared to provide the following information:

- Your existing case number, if you have one
- Details of the failure or problem
- Type of activity being performed on the router when the problem occurred
- Configuration data displayed by one or more `show` commands

Return Procedure

If the problem cannot be resolved by the JTAC technician, an RMA number is issued. This number is used to track the returned material at the factory and to return repaired or new components to the customer as needed.



NOTE: Do not return any component to Juniper Networks unless you have first obtained an RMA number. Juniper Networks reserves the right to refuse shipments that do not have an RMA. Refused shipments will be returned to the customer via collect freight.

For more information about return and repair policies, see the customer support Web page at <http://www.juniper.net/support/guidelines.html>.

For product problems or technical support issues, open a support case using the Case Manager link at <http://www.juniper.net/support/>, or call 1-888-314-JTAC (within the United States) or 1-408-745-9500 (outside the United States).

When you need to return a component, follow this procedure:

1. Determine the part number and serial number of the component. For instructions, see “Locating Component Serial Numbers” on page 235.

2. Obtain a Return Materials Authorization (RMA) number from the Juniper Networks Technical Assistance Center (JTAC). You can send e-mail or telephone as described above.
3. Provide the following information in your e-mail message or during the telephone call:
 - Part number and serial number of component
 - Your name, organization name, telephone number, and fax number
 - Description of the failure
4. The support representative validates your request and issues an RMA number for return of the component.
5. Pack the router or component for shipment, as described in “Packing a Router or Component for Shipment” on page 239.

Packing a Router or Component for Shipment

This section contains the following topics:

- Tools and Parts Required on page 239
- Packing the Services Router for Shipment on page 239
- Packing Components for Shipment on page 240

Tools and Parts Required

To remove components from the router or the router from a rack, you need the following tools and parts:

- Blank panels to cover empty slots
- Electrostatic bag or antistatic mat, for each component
- Electrostatic discharge (ESD) grounding wrist strap
- Flat-blade screwdriver, approximately 1/4 in. (6 mm)
- Phillips (+) screwdrivers, numbers 1 and 2

Packing the Services Router for Shipment

To pack the router for shipment, follow this procedure:

1. Retrieve the shipping carton and packing materials in which the router was originally shipped. If you do not have these materials, contact your Juniper Networks representative about approved packaging materials.
2. Attach an electrostatic discharge (ESD) grounding strap to your bare wrist and connect the strap to the ESD point on the chassis, or to an outside ESD point if the router is disconnected from earth ground. For more information about ESD, see the *J-series Services Router Getting Started Guide*.
3. On the console or other management device connected to the master Routing Engine, enter CLI operational mode and issue the following command to shut down the router software.

```
user@host> request system halt
```

Wait until a message appears on the console confirming that the operating system has halted. For more information about the command, see “Halting the Services Router with the CLI” on page 232.

4. Shut down power to the router by pressing the power button on the front panel of the router.
5. Disconnect power from the router. For instructions, see the *J-series Services Router Getting Started Guide*.
6. Remove the cables that connect to all external devices. For instructions, see the *J-series Services Router Getting Started Guide*.
7. Remove all field-replaceable units (FRUs) from the router.
8. If the router is installed on a wall or rack, have one person support the weight of the router, while another person unscrews and removes the mounting screws.
9. Place the router in the shipping carton.
10. Cover the router with an ESD bag, and place the packing foam on top of and around the router.
11. Replace the accessory box on top of the packing foam.
12. Securely tape the box closed.
13. Write the RMA number on the exterior of the box to ensure proper tracking.

Packing Components for Shipment

To pack and ship individual components, follow these guidelines:

- When you return components, make sure they are adequately protected with packing materials and packed so that the pieces are prevented from moving around inside the carton.
- Use the original shipping materials if they are available.

- Place individual boards in electrostatic bags.
- Write the RMA number on the exterior of the box to ensure proper tracking.



CAUTION: Do not stack any of the router components.

Part 2

Index

Index

Symbols

[], in configuration statements	xv
{ }, in configuration statements	xv
(), in syntax descriptions	xv
< >, in syntax descriptions	xv
(pipe) command	98
(pipe), in syntax descriptions	xv
#, comments in configuration statements	xv

A

access privileges	
denying and allowing commands	19
permission bits for	17
predefined	19
specifying (Quick Configuration)	27
accounts <i>See</i> template accounts; user accounts	
active alarms <i>See</i> alarms, active	
active routes, displaying	108
adapters, for compact flash recovery	227
adaptive services module, alarm conditions and	
configuration options	82
Add a RADIUS Server page	22
field summary	23
Add a TACACS + Server page	24
field summary	25
Add a User Quick Configuration page	27
field summary	28
addresses	
attacking, displaying with IDS	125
destination, displaying	108
under attack, displaying with IDS	125
agents, SNMP <i>See</i> SNMP agents	
alarm class <i>See</i> alarm severity	
ALARM LED	
color	80
alarm severity	81
action required	90
configuring for an interface	86
displaying	90
major (red)	81
minor (yellow)	81
<i>See also</i> major alarms; minor alarms	
alarms	79
active, checking	88

active, displaying at login	88
conditions, in chassis components	85
conditions, on an interface	82
configurable	82
configuration requirements for interface alarms	86
displaying for chassis	103
displaying for interfaces	106
licenses	85
major <i>See</i> major alarms	
minor <i>See</i> minor alarms	
monitoring	88
overview	80
red <i>See</i> major alarms	
red J-Web indicator	88
rescue configuration	85
severity <i>See</i> alarm severity	
types	80
verifying	90
yellow <i>See</i> minor alarms	
<i>See also</i> alarm severity	
Alarms Summary page	89
alert logging severity	44
alias, CoS value	115
alternative boot media <i>See</i> boot devices; USB	
ambient temperature	104
any level statement	46
any logging facility	43
archiving system logs	46
arithmetic operators	176
AS path, displaying	109
attacks, detecting with IDS	124
authentication	
adding a RADIUS server (Quick Configuration)	21
adding a TACACS + server (Quick Configuration)	23
local password, by default	25
login classes	17, 38
methods	16–17
order of user authentication (configuration	
editor)	37
RADIUS authentication (configuration editor)	34
specifying a method (Quick Configuration)	26
specifying access privileges (Quick	
Configuration)	27
TACACS + authentication (configuration editor)	35

user accounts	16, 39
authorization logging facility	43
autoinstallation, compatibility with the DHCP server	63

B

BGP (Border Gateway Protocol)	
monitoring	107
statistics	109
status	109
BGP groups, displaying	109
BGP neighbors, displaying	109
BGP peers, displaying	109
BGP route reflectors license	4
BGP sessions, status	110
binary operators	176
boot devices	220
configuring (CLI)	224
configuring (J-Web)	221
selecting (CLI)	232–233
selecting (J-Web)	231
storing memory snapshots	229
<i>See also</i> compact flash; USB	
boot operations, DHCP	69
Border Gateway Protocol <i>See</i> BGP	
braces, in configuration statements	xv
brackets	
angle, in syntax descriptions	xv
square, in configuration statements	xv
bytes transmitted	106

C

capturing packets <i>See</i> packet capture	
case number, for JTAC	238
/cf/var/crash <i>See</i> crash files	
/cf/var/log <i>See</i> system logs	
/cf/var/tmp <i>See</i> temporary files	
change-log logging facility	43
chassis	
alarm condition indicator	90
alarm conditions and remedies	85
alarms, displaying	103
component part numbers	104
component serial number labels	235
component serial numbers	104
environment, displaying	104
identifiers, displaying	104
monitoring	103
temperature, displaying	104
circuits, DLSw	112
class of service <i>See</i> CoS	
classifiers, CoS	114
Clean Up Files page	30
cleaning up files	29
clear system services dhcp binding command	74
clear system services dhcp conflicts command	63

CLI configuration editor	
controlling user access	38
DHCP server	70
interface alarms	86
RADIUS authentication	34
RPM	201
SNMP	54
TACACS + authentication	35
code point aliases, CoS	115
comments, in configuration statements	xv
communities, SNMP <i>See</i> SNMP communities	
compact flash	226
configuring	225
configuring for failure snapshot storage	229
displaying size	102
displaying usage	103
minor (yellow) alarm	85
primary, recovering	226
recovering	226
<i>See also</i> compact flash recovery	
compact flash recovery	
adapter for	227
copying the JUNOS image	227
reasons for	226
requirements	226
components	
packing for shipment	240
part numbers	104
serial number label	235
serial numbers	104
configuration	
alarm condition indicator	90
downgrading firmware (CLI)	219
downgrading software (CLI)	219
downgrading software (J-Web)	219
interfaces, displaying	105
upgrading (CLI)	217
upgrading (J-Web)	213
upgrading firmware (CLI)	217
configuration database, displaying size	103
Confirm File Delete page	33
controlling user access	38
conventions	
notice icons	xiv
text and syntax	xiv
CoS (class of service)	
classifiers	114
CoS value aliases	115
forwarding classes	116
interfaces	114
loss priority	119
monitoring	113
packet loss priority	119
RED drop profiles	115
rewrite rules	117

scheduler maps	117
CPU usage, displaying	102
crash files	
cleaning up (J-Web)	29
displaying size	103
downloading (J-Web)	31
critical logging severity	44
cron logging facility	43
curly braces, in configuration statements	xv
customer support	xviii
contacting JTAC	xviii
contacting JTAC for hardware return	237
hardware information for	104
information required for hardware return	238
Cygwin, for compact flash recovery	227

D

daemon logging facility	43
data link switching <i>See</i> DLSw	
dd utility, for compact flash recovery	227
debug logging severity	44
deleting	
crash files (J-Web)	30
files, with caution	32
licenses (CLI)	10
licenses (J-Web)	9
log files (J-Web)	30
temporary files (J-Web)	30
destination address, displaying	108
DHCP (Dynamic Host Configuration Protocol)	62
autoinstallation, compatibility with	63
configuring the server (configuration editor)	70
conflict detection and resolution	63
conflicts	130
interface restrictions	63
monitoring	130
options	63
overview	62
Quick Configuration	64
server function	61
verification	73
<i>See also</i> DHCP server	
DHCP binding database, verifying	74
DHCP leases	
configuring (Quick Configuration)	68
monitoring	130
DHCP pages	
field summary	68
main	65
pool information	66
static binding page	67
DHCP pools	
configuring (Quick Configuration)	68
monitoring	131
DHCP server	
boot operations (Quick Configuration)	69
configuring (configuration editor)	70
displaying configurations	73
information (Quick Configuration)	68
monitoring operations	130
preparation	64
Quick Configuration	64
sample configuration	71
static bindings (Quick Configuration)	69
statistics	77
subnet and single client	71
subnet for configuration (Quick Configuration)	68
verifying a configuration	73
verifying operation	75
verifying the DHCP binding database	74
diagnosis	
alarm configurations	90
chassis	85
CLI command summary	141
DHCP conflicts	130
DHCP statistics	77
displaying DHCP server configurations	73
displaying firewall filter for	189
displaying packet capture configurations	188
hardware	85
interfaces	82, 172
J-Web tools overview	140
license infringement	85
monitoring network performance	191
MPLS connections (J-Web)	150
multicast paths	167
network traffic	173
packet capture	179
ping command	160
ping host (J-Web)	146
ping MPLS (J-Web)	150
ports	82
preparation	99, 144
system operation	171
traceroute (J-Web)	155
traceroute command	166
traffic analysis with packet capture	179
verifying captured packets	189
verifying DHCP binding database	74
verifying DHCP server operation	75
verifying RPM probe servers	209
verifying RPM statistics	208
viewing active alarms	89
diagnostic commands	141
DiffServ code points, bits for RPM probes	198
disabling	
packet capture	186
system logs	46
discarded packets	107

DLSw (data link switching)	
circuits	112
initial pacing window	112
monitoring	107
peer information	112
peer IP address	112
protocol version	112
reachability	113
software version	112
vendor ID	112
DLSw license	4
DNS (Domain Name System) server address,	
displaying	101
documentation set	
comments on	xviii
Domain Name System address, displaying	101
downgrading	
firmware, with the CLI	219
software, with J-Web	219
software, with the CLI	219
download URL	212
downloading	
crash files (J-Web)	31
licenses (J-Web)	9
log files (J-Web)	31
software upgrades	212
temporary files (J-Web)	31
drop probabilities, CoS	115
drop profiles, CoS	115
dropped packets	106
DS1 ports <i>See</i> T1 ports	
DS3 ports <i>See</i> T3 ports	
DSCPs (DiffServ code points), bits for RPM probes	198
dynamic binding, DHCP <i>See</i> DHCP; DHCP leases;	
DHCP server	
Dynamic Host Configuration Protocol <i>See</i> DHCP	

E

E1 ports	
license	5
E3 ports	
alarm conditions and configuration options	83
egress <i>See</i> RPM probes, outbound times	
emergency logging severity	44
error logging severity	44

F

facility none statement	46
failures	
PIM	85
Routing Engine fan	85
fan	104
Fast Ethernet ports	
alarm condition indicator	90
alarm conditions and configuration options	82

configuring alarms on	86
license, for PIM ports	5
fe-0/0/0	
no license required	5
feature licenses <i>See</i> licenses	
features, licensed, displaying	7
file management	
crash files (J-Web)	29
log files (J-Web)	29
packet capture file creation	182
temporary files (J-Web)	29
filtering command output	98
filters <i>See</i> firewall filters; stateful firewall filters	
firewall filters	
for packet capture, configuring	185
for packet capture, overview	181
stateful <i>See</i> stateful firewall filters	
firewalls <i>See</i> firewall filters; stateful firewall filters	
firmware	
downgrades, installing (CLI)	219
upgrades, installing (CLI)	217
flapping	106
font conventions	xiv
forwarding classes, CoS	116
FPC, PIM slot number in command displays	104, 235
framing errors	107
free ports	8
frequency, test <i>See</i> RPM probes, test intervals	

G

get requests	50
glossary	
alarms	79
DHCP	61
diagnostic	139
monitoring	93
packet capture	179
RPM	191
system management	15
group licenses	8
groups	
BGP, displaying	109
for SNMP traps	57
gzip utility, for compact flash recovery	227

H

halting	
with J-Web	230
with the CLI	232
halting immediately	
with J-Web	231
with the CLI	233
hardware	
alarm conditions and remedies	85
returning	235

- version, displaying 104
- host reachability
 - ping command 160
 - ping host (J-Web) 146
- hostname
 - displaying (J-Web) 101
 - monitoring traffic by matching 175
 - opening an SSH session to 48
 - overriding for SNMP (configuration editor) 56
 - overriding for SNMP (Quick Configuration) 53
 - pinging (CLI) 160
 - pinging (J-Web) 147
 - resolving 70
 - SNMP trap target (Quick Configuration) 54
 - telnetting to 47
 - tracing a route to (CLI) 167
 - tracing a route to (J-Web) 157
- HTTP (Hypertext Transfer Protocol), RPM probes 192
- Hypertext Transfer Protocol, RPM probes 192

I

- IBM networking, DLSw license 4
- ICMP (Internet Control Message Protocol)
 - RPM probes, description 192
 - RPM probes, inbound and outbound times 193
 - RPM probes, setting 201
- idle time, displaying 101
- IDS (intrusion detection service)
 - information, displaying 127
 - monitoring 124
 - search-narrowing characteristics 125
- IKE security associations, monitoring 128
- inbound time *See* RPM probes
- info logging severity 44
- ingress *See* RPM probes, inbound times
- initial pacing window, DLSw 112
- Install Remote page 214
 - field summary 215, 223
- installation
 - firmware downgrades (CLI) 219
 - firmware upgrades (CLI) 217
 - licenses (CLI) 10
 - licenses (J-Web) 8
 - software upgrades (CLI) 217
 - software upgrades, from a remote server 213
 - software upgrades, uploading 215
- Instance to which this connection belongs
 - description 144
 - using 153
- interactive-commands logging facility 43
- interfaces *See* management interfaces; network
- interfaces; ports
- Internet Key Exchange (IKE) security associations,
 - monitoring 128
- intervals, probe and test *See* RPM probes

- intrusion detection service *See* IDS
- ipconfig command 75
 - explanation 77
- IPSec (IP Security)
 - monitoring 127
 - statistics 128
 - tunnels, displaying 127
- IPSec (IP Security), VPN license 4

J

- J-Flow license 4
- J-series
 - alarms 79
 - DHCP server 61
 - diagnosis 139
 - hardware return 235
 - licenses 3
 - managing users and operations 15
 - monitoring 93
 - network management 49
 - packet capture 179
 - performance monitoring 191
 - release notes, URL xiii
 - software upgrades 211
- J-Web configuration editor
 - controlling user access 38
 - DHCP server 70
 - interface alarms 86
 - RADIUS authentication 34
 - RPM 201
 - SNMP 54
 - TACACS + authentication 35
- J-Web interface
 - Diagnose options 140
 - managing files 29
 - managing licenses 6
 - Monitor options 94
- jitter
 - description 193
 - See also* RPM probes
 - monitoring 134
 - threshold, setting 198
- JTAC (Juniper Networks Technical Assistance Center)
 - contacting for hardware return 237
 - hardware information for 104
 - information required for hardware return 238
- JUNOS CLI
 - access privilege levels 17
 - denying and allowing commands 19
 - diagnostic command summary 141
 - filtering command output 98
 - managing licenses 10
 - monitoring (show) commands summary 94
- JUNOS Internet software
 - licenses 4

release notes, URL	xiii
upgrading	211
version, displaying	101
junos-jseries package <i>See</i> upgrades	

K

kernel logging facility	44
-------------------------------	----

L

label-switched paths <i>See</i> LSPs	
labels, serial number	235
Layer 2 circuits, monitoring	150
Layer 2 VPNs, monitoring	150
Layer 3 VPNs, monitoring	150
libpcap format, for packet capture files	190
license infringement	
alarm condition indicator	90
identifying any licenses needed	8
verifying license usage	12
verifying licenses installed	11
license keys	
components	5
displaying (CLI)	13
displaying (J-Web)	9
status	8
version	8
licenses	3
adding (CLI)	10
adding (J-Web)	8
alarm conditions and remedies	85
BGP route reflectors	4
deleting (CLI)	10
deleting (J-Web)	9
displaying (CLI)	11
displaying (J-Web)	7
displaying usage	12
DLSw	4
downloading (J-Web)	9
E1 ports	5
Fast Ethernet LAN ports (no license required)	5
Fast Ethernet PIM ports	5
group	8
infringement, preventing	6
<i>See also</i> license infringement	
installed	8
IPSec VPNs	4
J-Flow traffic analysis	4
JUNOS Internet software	4
key	5
<i>See also</i> license keys	
managing (CLI)	10
managing (J-Web)	6
NAT	4
overview	3
preparation for	6

saving (CLI)	11
serial ports	5
stateful firewall filters	4
T1 ports	5
traffic analysis	4
verifying	11
verifying free ports	8
<i>See also</i> license infringement; license keys	
Licenses page	7
link states, displaying	105
local password	
default authentication method	25
order of user authentication (configuration editor)	37
specifying for authentication (Quick Configuration)	26
local template accounts	42
Locate LSP from interface name	
description	144
using	153
Locate LSP from virtual circuit information	
description	144
using	154
Locate LSP using interface name	
description	144
using	153
Log Files page (Download)	31
log messages <i>See</i> system log messages	
logging facilities	43
logging severity levels	44
logical interfaces, CoS	114
logical operators	176
login classes	
defining (configuration editor)	38
permission bits for	18
predefined permissions	19
specifying (Quick Configuration)	27
login time, displaying	101
logs <i>See</i> system logs	
loopback address, displaying	101
loss priority, CoS	119
LSPs (label-switched paths)	
information about	120
monitoring, with ping MPLS	150
statistics	121

M

MAC (media access control) address	
configured, displaying	106
hardware, displaying	106
major (red) alarms	
action required	90
description	81
PIMs	85
Routing Engine	85

- Management Information Bases *See* MIBs
- management interface address, displaying..... 101
- management interfaces
 - active alarms..... 106
 - administrative states 105
 - alarm conditions and configuration options 82
 - configuration, displaying 105
 - configuring alarms on 86
 - monitoring 105, 172
 - statistics 172
- managing
 - reboots 230
 - snapshots 220
 - software 211
 - users and operations 15
- managing licenses 3
- manuals
 - comments on xviii
- match conditions 175
- maximum transmission unit (MTU), displaying..... 106
- media access control *See* MAC address
- memory usage
 - for service sets 123
 - general 101
- messages *See* system log messages
- MIBs (Management Information Bases)
 - controlling access (configuration editor)..... 58
 - enterprise 50
 - standard 50
 - system identification (configuration editor) 55
 - views (configuration editor) 58
- minor (yellow) alarms
 - action required..... 90
 - alternative boot device 85
 - description 81
 - primary compact flash 85
 - Routing Engine 85
- monitor interface command 172
 - controlling output..... 172
- monitor interface traffic command 172
 - controlling output..... 172
- monitor list command..... 171
- monitor start command 171
- monitor stop command 171
- monitor traffic command 173
 - options 174
 - performance impact..... 173
- monitor traffic matching command 174
 - arithmetic, binary, and relational operators 176
 - logical operators 176
 - match conditions 175
- monitoring 93
 - alarms..... 88
 - BGP 109
 - chassis..... 103
- CLI commands and corresponding J-Web
 - options..... 94
- CoS information 113
- DHCP 130
- DLSw 112
- IDS information..... 124
- IKE security 127
- IKE security associations 128
- interfaces..... 105, 172
- IPSec tunnels 127
- J-Web options and corresponding CLI
 - commands 94
- Layer 2 circuits..... 150
- Layer 2 VPNs..... 150
- Layer 3 VPNs..... 150
- MPLS traffic engineering 119
- multicast paths 167
- NAT pools 129
- network interface traffic..... 173
- network traffic with packet capture 179
- OSPF 110
- ports..... 105
- PPPoE 134
- preparation..... 99, 144
- RIP..... 111
- routing information..... 107
- RPM probes 131
- service sets..... 122
- services interfaces 122
- stateful firewall filters..... 124
- system logs 171
- system properties..... 100
- trace files..... 171
- See also* diagnosis; statistics; status
- MPLS (Multiprotocol Label Switching)
 - connections, checking..... 150
 - LSPs 120
 - monitoring interfaces..... 120
 - monitoring LSP statistics 121
 - monitoring RSVP sessions 121
 - monitoring traffic engineering 119
- mtrace monitor command 170
 - results 171
- mtrace-from-source command..... 168
 - options 168
 - results 169
- MTU (maximum transmission unit), displaying..... 106
- multicast
 - trace operations, displaying..... 170
 - tracing paths 168
- multiple routers, using snapshots to replicate
 - configurations
 - CLI..... 225
 - J-Web 223
- Multiprotocol Label Switching *See* MPLS

N

name of network interfaces, displaying	105
NAT (Network Address Translation)	
displaying pools	129
license	4
monitoring pools	129
Network Address Translation <i>See</i> NAT	
network interfaces	
active alarms	106
administrative states	105
alarm conditions and configuration options	82
configuration, displaying	105
configuring alarms on	86
integrated services, alarm conditions and configuration options	82
monitoring	105, 172
monitoring MPLS traffic engineering	120
monitoring traffic	173
monitoring, CoS	114
monitoring, PPPoE	135
monitoring, RSVP	122
packet capture, configuring on	184
packet capture, disabling before changing encapsulation	187
packet capture, supported on	181
services, alarm conditions and configuration options	83
statistics	172
network management	49
<i>See also</i> SNMP	
network performance <i>See</i> RPM	
next hop, displaying	108
no-world-readable statement	46
Norton Ghost utility, for compact flash recovery	227
notice icons	xiv
notice logging severity	44
notifications <i>See</i> SNMP traps	

O

object identifiers (OIDs)	50
OIDs (object identifiers)	50
Open Shortest Path First <i>See</i> OSPF	
operational mode, filtering command output	98
operator login class permissions	19
operators	
arithmetic, binary, and relational operators	176
logical	176
OSPF (Open Shortest Path First)	
monitoring	107
statistics	111
OSPF interfaces	
displaying	110
status	110
OSPF neighbors	
displaying	110

status	110
outbound time <i>See</i> RPM probes	

P

packet capture	
configuring	185
configuring on an interface	184
disabling	186
disabling before changing encapsulation on interfaces	187
displaying configurations	188
displaying firewall filter for	189
enabling	183
encapsulation on interfaces, disabling before modifying	187
files <i>See</i> packet capture files	
firewall filters, configuring	185
firewall filters, overview	181
overview	180
preparation	183
router interfaces supported	181
verifying captured packets	189
verifying configuration	188
verifying firewall filter for	189
packet capture files	
analyzing	182
libpcap format	190
overview	182
renaming before modifying encapsulation on interfaces	187
packet loss priority, CoS	119
packets	
capturing	179
discarded	107
dropped	106
monitoring jitter	134
monitoring packet loss	133
monitoring round-trip times	133
multicast, tracking	168
packet capture	179
tracking MPLS	154
tracking with J-Web traceroute	155
tracking with the traceroute command	166
packing materials	
packing a Services Router for shipment	239
packing components for shipment	240
parentheses, in syntax descriptions	xv
part numbers	104
partitioning a boot medium	225
password	23
specifying for authentication	26
<i>See also</i> secret	
paths, multicast, tracing	167
PCAP <i>See</i> packet capture	

- peers, DLSw
 - connection information112
 - IP address112
 - reachability information.....113
 - performance, monitoring *See* RPM
 - permission bits, for login classes.....18
 - permissions
 - denying and allowing commands19
 - predefined19
 - physdiskwrite utility, for compact flash recovery 227
 - physical interfaces, CoS114
 - PIC *See* PIMs
 - PIMs (Physical Interface Modules)
 - failure85
 - major (red) alarm.....85
 - PIM number (always 0).....104
 - PIM number, always 0.....235
 - serial number label.....237
 - ping
 - host reachability (CLI)160
 - host reachability (J-Web)146
 - ICMP probes201
 - indications150
 - RPM probes *See* RPM probes
 - TCP and UDP probes205
 - ping command.....160
 - DHCP server operation.....75
 - DHCP server operation, explanation76
 - options160
 - Ping end point of LSP
 - description144
 - using154
 - ping host
 - results149
 - Ping Host page.....147
 - field summary147
 - results149
 - Ping LDP-signaled LSP
 - description143
 - using152
 - Ping LSP to Layer 3 VPN prefix
 - description144
 - using153
 - ping MPLS (J-Web)
 - indications155
 - Layer 2 circuits.....150
 - Layer 2 VPNs.....150
 - Layer 3 VPNs.....150
 - LSP state150
 - options143
 - requirements.....145
 - results154
 - ping mpls l2circuit command.....165
 - results154
 - ping mpls l2vpn command.....164
 - results154
 - ping mpls l3vpn command.....163
 - results154
 - ping mpls ldp command162
 - results154
 - ping mpls lsp-end-point command162
 - results154
 - Ping MPLS page.....152
 - field summary152
 - results154
 - ping mpls rsvp command162
 - results154
 - Ping RSVP-signaled LSP
 - description143
 - using152
 - pipe (|) command, to filter output98
 - Point-to-Point Protocol over Ethernet *See* PPPoE
 - ports
 - alarm conditions and configuration options82
 - configuration, displaying105
 - configuring alarms on86
 - DHCP interface restrictions63
 - free ports.....8
 - individual port types.....82
 - licenses.....5
 - monitoring105
 - power supplies, J6300
 - serial number label237
 - PPPoE (Point-to-Point Protocol over Ethernet)
 - interfaces.....135
 - monitoring134
 - session status135
 - statistics136
 - version information137
 - primary compact flash *See* compact flash
 - probe loss
 - monitoring133
 - threshold, setting198
 - probes, monitoring131, 134
 - See also* RPM probes
 - properties, system, monitoring100
 - protocol version, DLSw112
 - protocols
 - DHCP *See* DHCP
 - originating, displaying.....108
 - routing protocols, monitoring.....107
- ## Q
- Quick Configuration
 - Add a RADIUS Server page.....22
 - Add a TACACS+ Server page.....24
 - Add a User page27
 - adding users27
 - authentication method25

DHCP main page	65	request system reboot command	232
DHCP pool page	66	options	232
DHCP static binding page	67	request system snapshot command	224
RADIUS server	21	options	225
RPM pages	195–196	request system snapshot media	
SNMP page	52	removable-compact-flash command	212
TACACS + server	23	request system snapshot media usb command	212
user management	21	request system software add	
Users page	26	/var/temp/jfirmware-jseries command	218, 220
		request system software add validate unlink reboot	
		command	217
		request system software delete jfirmware	
		command	217, 219
		request system software rollback command	219
		rescue configuration, alarm about	85
		Resource Reservation Protocol <i>See</i> RSVP	
		Return Materials Authorization <i>See</i> RMA	
		returning hardware	235
		packing a Services Router for shipment	239
		packing components for shipment	240
		procedure	238
		tools and parts required	239
		reverting to a previous configuration file (J-Web)	219
		rewrite rules, CoS	117
		RIP (Routing Information Protocol)	
		monitoring	107
		statistics	111
		RIP neighbors	
		displaying	111
		status	111
		RMA (Return Materials Authorization)	235
		number	238
		packing a Services Router for shipment	239
		packing components for shipment	240
		procedure	238
		tools and parts required	239
		rolling back a configuration file, to downgrade	
		software (CLI)	219
		rotating files	30
		round-trip time	
		description	193
		<i>See also</i> RPM probes	
		threshold, setting	198
		route reflectors, BGP, license	4
		router <i>See</i> Services Router	
		routing	
		monitoring	107
		traceroute (J-Web)	155
		traceroute command	166
		Routing Engine	
		fan failure	85
		major (red) alarm	85
		minor (yellow) alarm	85
		read or write error	85
		temperature	104

R

RADIUS

adding a server (Quick Configuration)	21
authentication (configuration editor)	34
order of user authentication (configuration	
editor)	37
secret (configuration editor)	35
secret (Quick Configuration)	23
specifying for authentication (Quick	
Configuration)	26
random early detection (RED) drop profiles, CoS	115
reachability	
DLSw	113
<i>See also</i> host reachability	
read or write error, Routing Engine	85
read-only login class permissions	19
real-time performance monitoring <i>See</i> RPM	
reboot immediately	
with J-Web	231
with the CLI	232
rebooting	
with J-Web	230
with the CLI	232
recovering compact flash <i>See</i> compact flash recovery	
red alarms <i>See</i> major alarms	
red Alarms indicator, in J-Web	88
RED drop profiles, CoS	115
registration form, for software upgrades	212
relational operators	177
release notes, URL	xiii
remote accounts	
accessing with SSH (CLI)	47
accessing with telnet (CLI)	47
remote template accounts	41
remote server, upgrading from	213
remote template accounts	41
request chassis fpc slot restart command	218, 220
request system firmware downgrade command	220
request system firmware upgrade command	218
request system halt command	232
options	233
request system license add command	10
request system license delete command	10
request system license save command	11

too hot 85
 too warm 85
 routing policies
 export, displaying 110
 import, displaying 110
 routing table
 displaying 108
 monitoring 107
 RPM (real-time performance monitoring) 191
 basic probes (configuration editor) 201
 inbound and outbound times 193
 jitter, viewing 134
 monitoring probes 131
 overview 192
 preparation 194
 probe and test intervals 193
 probe counts 194
 Quick Configuration 195
 round-trip times, description 193
 round-trip times, viewing 133
 sample graphs 132
 statistics 193
 statistics, verifying 208
 TCP probes (configuration editor) 205
 tests 193
 tests, viewing 132
 threshold values 194
 tuning probes 207
 UDP probes (configuration editor) 205
 verifying probe servers 209
 See also RPM probes
 RPM pages 195–196
 field summary 197
 RPM probes
 basic (configuration editor) 201
 cumulative jitter 134
 current tests 132
 DSCP bits (Quick Configuration) 198
 graph results 132
 ICMP (configuration editor) 201
 inbound times 193
 jitter threshold 198
 monitoring 131
 outbound times 193
 probe count, setting (Quick Configuration) 198
 probe count, tuning 208
 probe counts 194
 probe intervals 193
 probe intervals, setting (Quick Configuration) 197
 probe intervals, tuning 207
 probe loss count 198
 probe owner 197
 probe type, setting (Quick Configuration) 197
 probe types 192
 round-trip time threshold 198

round-trip times, description 193
 round-trip times, viewing 133
 SNMP traps (Quick Configuration) 199
 source address, setting 208
 TCP (configuration editor) 205
 TCP server port 200
 test intervals 193
 test intervals, setting (Quick Configuration) 197
 test target 197
 threshold values, description 194
 threshold values, setting (Quick Configuration) 198
 tuning 207
 UDP (configuration editor) 205
 UDP server port 200
 verifying TCP and UDP probe servers 209
 RSVP (Resource Reservation Protocol)
 interfaces, monitoring 122
 sessions, monitoring 121
 RTT *See* RPM probes, round-trip times

S

samples
 alarm configuration 90
 basic RPM probes 201
 DHCP server configuration 73
 local template account 42
 RPM test graphs 132
 TCP and UDP probes 205
 user account 39
 saving licenses (CLI) 11
 scheduler maps, CoS 117
 scheduling a reboot
 with J-Web 231
 with the CLI 232
 search, IDS 124
 secret 23
 RADIUS (configuration editor) 35
 RADIUS (Quick Configuration) 23
 TACACS+ (configuration editor) 36
 TACACS+ (Quick Configuration) 25
 See also password
 security
 access privileges 17, 38
 IDS intrusion detection 124
 IKE, monitoring security associations 128
 packet capture for intrusion detection 180
 user accounts 16, 39
 user authentication 16
 serial number
 chassis components 104
 chassis components, label 235
 PIMs 237
 power supply 237
 Services Router 100

serial ports		
alarm condition indicator	90	
alarm conditions and configuration options	82	
configuring alarms on	86	
license	5	
service sets, monitoring	122	
services interfaces, monitoring	122	
services module		
alarm condition indicator	90	
alarm conditions and configuration options	83	
Services Router		
as a DHCP server	61	
diagnosis	139	
halting (CLI)	232	
halting (J-Web)	230	
hardware return	235	
licenses	3	
monitoring	93	
network management	49	
packet capture	179	
packing for shipment	239	
performance monitoring	191	
rebooting (CLI)	232	
rebooting (J-Web)	230	
serial number, displaying	100	
software upgrades	211	
sessions		
BGP peer, status details	110	
BGP peer, status summary	109	
RSVP, monitoring	121	
telnet	47	
set requests	50	
set system dump-device command	229	
options	229	
severity levels		
for alarms <i>See</i> alarm severity		
for system logs	44	
shipping carton		
packing a Services Router for shipment	239	
packing components for shipment	240	
show bgp neighbor command	107	
show bgp summary command	107	
show chassis alarms command	88, 90, 103	
show chassis environment command	103	
show chassis hardware command	103, 235	
show class-of-service classifier command	113	
show class-of-service code-point-aliases command	113	
show class-of-service command	114	
show class-of-service drop-profile command	113	
show class-of-service forwarding-class command	113	
show class-of-service rewrite-rules command	114	
show class-of-service scheduler-map command	114	
show dlsw capabilities command	107	
show dlsw circuits command	107	
show dlsw peers command	108	
show dlsw reachability command	108	
show firewall filter dest-all command	189	
show forwarding-options command	188	
show interfaces detail command	105	
show interfaces interface-name command	105	
show interfaces pp0 command	135	
show interfaces terse command	105	
show log command	20	
show mpls interface command	119	
show mpls lsp command	119	
show mpls statistics command	119	
show ospf interfaces command	107	
show ospf neighbors command	107	
show ospf statistics command	107	
show pppoe interfaces command	135	
show pppoe statistics command	135	
show pppoe version command	135	
show rip neighbors command	107	
show rip statistics command	107	
show route detail command	107	
show route terse command	107	
show services ids destination-table command	125	
show services ids pair-table command	125	
show services ids source-table command	125	
show services ipsec-vpn ike command	127	
show services ipsec-vpn ipsec command	127	
show services ipsec-vpn ipsec security-associations command	127	
show services nat pool command	129	
show services rpm active-servers command	209	
explanation	209	
show services rpm probe-results command	131, 208	
explanation	209	
show services service-sets memory-usage command	123	
show services service-sets summary command	123	
show services stateful-firewall conversations command	124	
show services stateful-firewall flows command	124	
show services stateful-firewall statistics command	124	
show snmp statistics command	59	
show system alarms command	88	
show system firmware command	218, 220	
show system license command	11–12	
show system license keys command	13	
show system processes command	20, 100	
show system services dhcp binding command	74, 130	
explanation	75	
show system services dhcp binding detail command	74	
explanation	75	
show system services dhcp command	73	
show system services dhcp conflict command	63, 74, 130	
explanation	75	
show system services dhcp pool command	73, 130	

- show system services dhcp statistics command .. 77, 130
 - explanation 77
- show system storage command 100
- show system uptime command 100
- show system users command 100
- show version detail command 218, 220
- Simple Network Management Protocol *See* SNMP
- SMI (Structure of Management Information) 50
- Snapshot page 222
- snapshots
 - configuring for failure snapshot storage 229
 - to replace primary compact flash, for multiple routers (CLI) 225
 - to replace primary compact flash, for multiple routers (J-Web) 223
- SNMP (Simple Network Management Protocol)
 - agents *See* SNMP agents
 - communities *See* SNMP communities
 - controlling access (configuration editor) 58–59
 - get requests 50
 - managers 49
 - MIBs *See* MIBs
 - overview 49
 - preparation 51
 - Quick Configuration 51
 - set requests 50
 - system identification (configuration editor) 55
 - traps *See* SNMP traps
 - views (configuration editor) 58
- SNMP agents 49
 - configuring (configuration editor) 56
 - verifying 59
- SNMP communities
 - creating (configuration editor) 56
 - description 50
 - Quick Configuration 53
- SNMP managers 49
- SNMP page 52
- SNMP traps
 - creating groups for (configuration editor) 57
 - description 51
 - performance monitoring *See* RPM probes
 - Quick Configuration 53
- software
 - halting immediately (CLI) 233
 - halting immediately (J-Web) 231
 - upgrades *See* upgrades
 - version, displaying 101
 - version, DLSw 112
- ssh command 47
 - options 48
- SSH, accessing remote accounts (CLI) 47
- stateful firewall filters
 - displaying 126
 - flow status 126
 - monitoring 124
- static binding, DHCP *See* DHCP; DHCP leases; DHCP server
- statistics
 - BGP 109
 - DHCP 131
 - DHCP server 77
 - interfaces 172
 - IPSec 128
 - LSP 121
 - OSPF 111
 - performance monitoring 193
 - PPPoE 136
 - RIP 111
 - RPM, description 193
 - RPM, monitoring 132
 - RPM, verifying 208
- status
 - administrative link state 105
 - BGP 109–110
 - license key 8
 - link states 105
 - OSPF interfaces 110
 - OSPF neighbors 110
 - RIP neighbors 111
 - stateful firewall filters 126
- storage media
 - configuring boot devices 220
 - recovering primary compact flash 226
- Structure of Management Information (SMI) 50
- super-user login class permissions 19
- superuser login class permissions 19
- support, technical *See* technical support
- syntax conventions xiv
- syslog *See* system logs
- system identification, displaying 100
- system log messages
 - displaying at a terminal (configuration editor) 46
 - sending to a file (configuration editor) 45
- system logs
 - archiving (CLI configuration editor) 46
 - capturing in a file (configuration editor) 44
 - destinations for log files 20
 - disabling (configuration editor) 46
 - displaying at a terminal (configuration editor) 45
 - displaying size 103
 - file cleanup (J-Web) 29
 - functions 20
 - logging facilities 43
 - logging severity levels 44
 - monitoring 171
 - sending messages to a file (configuration editor) 44
 - sending messages to a terminal (configuration editor) 45

setting up	43
system management	15
displaying log and trace file contents	171
login classes	17, 38
preparation	21
Quick Configuration	21
system logs	20
system logs, setting up	43
template accounts	19, 40
user accounts	16, 39
user authentication	16
system storage, displaying	102
system time, displaying	101

T

T1 ports	
alarm conditions and configuration options	82
configuring alarms on	86
license	5
T3 ports	
alarm condition indicator	90
alarm conditions and configuration options	84
configuring alarms on	86
TACACS +	
adding a server (Quick Configuration)	23
authentication (configuration editor)	35
order of user authentication (configuration editor)	37
secret (configuration editor)	36
secret (Quick Configuration)	25
specifying for authentication (Quick Configuration)	26
TCP	
RPM probes, description	193
RPM probes, server port	200
RPM probes, setting	205
RPM probes, verifying servers	209
technical support	
contacting JTAC	xviii
contacting JTAC for hardware return	237
hardware information for	104
information required for hardware return	238
telnet command	47
options	47
telnet session	47
telnet, accessing remote accounts (CLI)	47
temperature	
chassis, displaying	104
Routing Engine, too hot	85
Routing Engine, too warm	85
template accounts	
description	19
local accounts (configuration editor)	43
remote accounts (configuration editor)	42

temporary files	
cleaning up (J-Web)	29
displaying size	103
downloading (J-Web)	31
for packet capture	182
terminology	
alarms	79
DHCP	61
diagnostic	139
monitoring	93
packet capture	179
RPM	191
system management	15
tests <i>See</i> RPM	
threshold values, for RPM probes <i>See</i> RPM probes	
time to live <i>See</i> TTL	
time zone, displaying	101
tools and equipment	
for hardware return	239
trace files	
monitoring	171
multicast, monitoring	170
traceroute	
CLI command	166
indications	159
J-Web tool	155
results	158
TTL increments	155
traceroute command	166
options	167
Traceroute page	157
field summary	157
traffic	
analyzing with packet capture	179
multicast, tracking	168
tracking with J-Web traceroute	155
tracking with the traceroute command	166
traffic analysis license	4
transmission speed, displaying	106
traps <i>See</i> SNMP traps	
troubleshooting <i>See</i> diagnosis	
TTL (time to live)	
default, in multicast path-tracking queries	168
in ping requests	149
increments, in traceroute packets	155
threshold, in multicast trace results	170
total, in multicast trace results	170
TTY, displaying	101

U

UDP	
RPM probes, description	193
RPM probes, server port	200
RPM probes, setting	205
RPM probes, verifying servers	209

unauthorized login class permissions	19
upgrades	
downloading	212
installing (CLI)	217
installing by uploading	215
installing from remote server	213
overview	211
requirements	212
Upload package page	216
field summary	216
URLs	
release notes	xiii
return and repair policies	238
software downloads	212
USB (universal serial bus)	
configuring	225
configuring for failure snapshot storage	229
user accounts	
authentication order (configuration editor)	37
contents	16
creating (configuration editor)	40
for local users	42
for remote users	41
predefined login classes	19
templates for	19, 40
<i>See also</i> template accounts	
user logging facility	44
username	
description	16
displaying	101
specifying (Quick Configuration)	27
users	
access privileges	17, 38
accounts <i>See</i> user accounts	
adding (Quick Configuration)	27
displaying	101
login classes	17, 38
predefined login classes	19
template accounts <i>See</i> template accounts	
usernames	16
Users Quick Configuration page	26
utilities, for compact flash recovery	227

V

vendor ID, DLSw	112
verification	
active licenses	11
alarm configurations	90
captured packets	189
destination path (J-Web)	155
DHCP binding database	74
DHCP server configuration	73
DHCP server operation	75
DHCP statistics	77
firewall filter for packet capture	189
host reachability (CLI)	160
host reachability (J-Web)	146
license usage	12
licenses	11
LSPs (J-Web)	150
packet capture	188
RPM probe servers	209
RPM statistics	208
SNMP	59
traceroute command	166
tracing multicast paths	168
version	
hardware, displaying	104
license key	8
PPPoE, information about	137
software, displaying	101
views, SNMP	59
VPN license, for IPSec	4
VPNs (virtual private networks), no DHCP support on interfaces	64

W

warning logging severity	44
WinZip utility, for compact flash recovery	227
world-readable statement	46

Y

yellow alarms <i>See</i> minor alarms	
---------------------------------------	--