

LWC Platform Hardware Guide

Published
2025-09-09

Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408-745-2000
www.juniper.net

Juniper Networks, the Juniper Networks logo, Juniper, and Junos are registered trademarks of Juniper Networks, Inc. in the United States and other countries. All other trademarks, service marks, registered marks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

LWC Platform Hardware Guide

Copyright © 2025 Juniper Networks, Inc. All rights reserved.

The information in this document is current as of the date on the title page.

YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

END USER LICENSE AGREEMENT

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <https://support.juniper.net/support/eula/>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Table of Contents

About This Guide | vii

1

Overview

LWC Overview | 2

LWC Chassis | 4

Front Panel of an LWC Device | 4

Rear Panel of an LWC Device | 5

Network Port and Uplink Port LEDs on an LWC Device | 5

LWC Power System | 6

Power Supply in LWC Devices | 6

AC Power Supply Specifications for an LWC Device | 6

AC Power Cord Specifications for an LWC Device | 7

LWC Cooling System | 9

2

Site Planning, Preparation, and Specifications

Site Preparation Checklist for LWC Devices | 12

LWC Site Guidelines and Requirements | 14

General Site Guidelines | 14

Site Electrical Wiring Guidelines | 14

Physical Specifications of an LWC Device | 16

Clearance Requirements for Airflow and Hardware Maintenance for an LWC Device | 16

Rack Requirements for an LWC Device | 17

Cabinet Requirements for an LWC Device | 19

Requirements for Mounting an LWC Device on a Desktop or Other Level Surface | 20

LWC Network Cable and Transceiver Planning | 21

Pluggable Transceivers Supported on LWC Devices | 21

Understanding LWC Devices Fiber-Optic Cable Signal Loss, Attenuation, and Dispersion | 26

Calculate the Fiber-Optic Cable Power Budget for an LWC Device | 28

Calculate the Fiber-Optic Cable Power Margin for an LWC Device | 28

LWC Cable Specifications and Pinouts | 30

Cable Specifications for Console Connection for an LWC Device | 30

Console Port Connector Pinouts for LWC Devices | 31

USB Port Specifications for an LWC Device | 32

Network Port Connector Pinout Information for an LWC Device | 32

RJ-45 to DB-9 Serial Port Adapter Pinout Information for an LWC Device | 33

3

Initial Installation and Configuration

LWC Installation Overview | 36

Unpacking and Mounting the LWC Device | 36

Unpack an LWC Device | 37

Parts Inventory (Packing List) for an LWC Device | 37

Register Products—Mandatory to Validate SLAs | 38

Methods to Mount an LWC Device | 39

Mount an LWC Device on a Desk or Other Level Surface | 39

Mount an LWC Device on Two Posts in a Rack | 40

Mount an LWC Device on Four Posts in a Rack or Cabinet | 42

Connect the LWC Device to Power | 45

Parts and Tools Required for Connecting an LWC Device to Earth Ground | 46

Connect an LWC Device to Earth Ground | 46

Connect an LWC Device to AC Power | 47

Connect the LWC Device to Network | 48

Configure the LWC Device | 50

Internal and External Network Requirements | 50

4

Configure the Network Ports and Active Proxy | 52

Maintaining Components

Maintaining Transceivers on the LWC | 62

Install a Transceiver in an LWC Device | 62

Remove a Transceiver from an LWC Device | 63

Maintaining Fiber Optic Cables on the LWC | 65

Connect a Fiber-Optic Cable to an LWC Device | 66

Disconnect a Fiber-Optic Cable from an LWC Device | 67

Maintaining Fiber-Optic Cables in an LWC Device | 68

Remove an LWC Device from a Rack or Cabinet | 69

5

Safety Information

General Safety Guidelines and Warnings | 71

Environmental Requirements and Specifications for an LWC Device | 72

Definitions of Safety Warning Levels | 73

Qualified Personnel Warning | 75

Warning Statement for Norway and Sweden | 75

Fire Safety Requirements | 76

Installation Instructions Warning | 77

Chassis Lifting Guidelines for LWC Devices | 78

Restricted Access Warning | 78

Ramp Warning | 79

Rack-Mounting and Cabinet-Mounting Warnings | 80

Laser and LED Safety Guidelines and Warnings for the LWC Devices | 84

Radiation from Open Port Apertures Warning | 89

Maintenance and Operational Safety Guidelines and Warnings | 90

General Electrical Safety Guidelines and Warnings | 96

Action to Take After an Electrical Accident | 97

Prevention of Electrostatic Discharge Damage | 98

AC Power Electrical Safety Guidelines | 99

AC Power Disconnection Warning | 100

TN Power Warning | 101

About This Guide

Use this guide to install hardware and perform initial software configuration, routine maintenance, and troubleshooting for the light weight collector (LWC) device. After completing the installation and basic configuration procedures covered in this guide, refer to the JSI Day One + guide for information about further software configuration. See also: [Juniper Support Insights](#).

1

PART

Overview

- [LWC Overview | 2](#)
 - [LWC Chassis | 4](#)
 - [LWC Power System | 6](#)
 - [LWC Cooling System | 9](#)
-

LWC Overview


IN THIS SECTION

- [LWC Description | 2](#)

LWC Description

The Juniper Networks® Lightweight Collector (LWC) is a data collection tool. The LWC securely gathers operational data from Juniper devices in customer networks and sends that data to the Juniper cloud. The LWC device is part of Juniper Support Insight (JSI), a cloud-based solution, that provides IT and network operations teams with actionable operational insights into Junos devices on customer networks. JSI aims to transform the customer support experience by providing insights that help improve the network performance and uptime.

Figure 1: LWC Front Panel



As shown in [Figure 1 on page 2](#), the ports highlighted (0 and 1) connect the LWC to internal and external networks.

Name	Lightweight Collector (LWC)
SKU Name	JNPR-E-LWC
Dimensions	Width = 17.36 in. (44.09 cm) Height = 1.72 in. (4.37 cm) Depth = 12 in. (30.48 cm)

Weight	9.48 lb (4.3 kg)
Rack Units	1 U
Power Type	AC
Power Consumption	Average power consumption: 87 W Minimum power consumption: 68 W
Ports Used	- The following two 1GbE/10GbE SFP+ uplink ports: - Port 0 (interface name: xe-0/0/12) connects to the internal network (that is, to network devices or a bastion host). - Port 1 (interface name: xe-0/0/13) connects to the external network (Juniper cloud). - The 1-Gigabit RJ-45 network port labeled 0 (interface name: ge-0/0/0.0) connects to the captive portal. NOTE: We've disabled the following ports: - The ports ranging from 1 through 11 - The management (MGMT) port NOTE: Only Juniper Networks resident engineers have access to the console (CON) port.
Supported SFP Modules	- CTP-SFP-1GE-T (the default SFP modules provided with the LWC) - EX-SFP-1GE-LX - EX-SFP-10GE-SR - EX-SFP-10GE-LR NOTE: We ship two SFP modules (2 x CTP-SFP-1GE-T) with the LWC device. You must provide the corresponding two terminating SFP modules.

LWC Chassis

IN THIS SECTION

- Front Panel of an LWC Device | 4
- Rear Panel of an LWC Device | 5
- Network Port and Uplink Port LEDs on an LWC Device | 5


Front Panel of an LWC Device

The LWC does not use all the ports available on its front panel. It uses only the following ports:

- One 1GbE RJ-45 network port (port 0, interface name ge-0/0/0) used to access the captive portal (for configuration and diagnostics)
- Two 1GbE/10GbE SFP+ uplink ports (xe-0/0/12 and xe-0/0/13) to connect the device to the internal and external networks
- The console (**CON**) port (accessible only to Juniper Networks resident engineers for troubleshooting purposes only)

Figure 2 on page 4 shows all the components that are available on the front panel of an LWC device. Only the ports that are used are marked in the illustration.

Figure 2: LWC Front Panel




1. 1GbE RJ-45 network port (only the port 0) used to access the captive portal (for configuration and diagnostics)
2. 1GbE/10GbE SFP+ uplink ports (connects the LWC to the internal and external networks)

- 3. Console port (accessible only to Juniper Networks resident engineers)

Rear Panel of an LWC Device

The rear panel of an LWC device consists grounding points, an electrostatic discharge (ESD) point, exhaust vents, a power switch, and an AC power cord inlet (see [Figure 3 on page 5](#)).


Figure 3: LWC Device Rear Panel



Network Port and Uplink Port LEDs on an LWC Device

Each network port and uplink port on the front panel of an LWC device has two LEDs that indicate link activity and port status (see [Figure 4 on page 5](#)).

Figure 4: LEDs on the Network Port



[Table 1 on page 6](#) describes the link activity LED.

Table 1: Link/Activity LED on the Network Ports and Uplink Ports in LWC Devices

LED	Color	State and Description
Link/Activity	Green	• Blinking—The port and the link are active, and there is link activity. • On steadily—The port and the link are active, but there is no link activity. • Off—The port is not active.

LWC Power System

IN THIS SECTION

- [Power Supply in LWC Devices | 6](#)
- [AC Power Supply Specifications for an LWC Device | 6](#)
- [AC Power Cord Specifications for an LWC Device | 7](#)

Power Supply in LWC Devices

The LWC device uses a fixed, internal AC power supply, which is not field-replaceable. The power supply distributes different output voltages to the device components according to their voltage requirements.

The power supply has a single AC appliance inlet that requires a dedicated AC power feed. The AC power cord inlet is on the rear panel of the device.

AC Power Supply Specifications for an LWC Device

[Table 2 on page 7](#) describes the AC power specifications for an LWC device.

Table 2: AC Power Specifications for an LWC Device

Item	Specification
AC input voltage	Operating range: 100 through 240 VAC
AC input line frequency	50–60 Hz nominal
AC input current rating	3 A at 240 VAC
Maximum power consumption	140 W

AC Power Cord Specifications for an LWC Device

A detachable AC power cord is supplied with the AC power supplies. The coupler is type C13 as described by International Electrotechnical Commission (IEC) standard 60320. The plug at the plug end of the power cord fits into the power source outlet that is standard for your geographical location.



CAUTION: Use the AC power cord (provided with each power supply) only with the power supply for which it is intended.



NOTE: In North America, AC power cords must not exceed 4.5 meters in length, to comply with National Electrical Code (NEC) Sections 400-8 (NFPA 75, 5-2.2) and 210-52 and Canadian Electrical Code (CEC) Section 4-010(3). The cords supplied with the switch are in compliance.

Table 3 on page 7 gives the AC power cord specifications for the countries and regions listed in the table.

Table 3: AC Power Cord Specifications

Country/Region	Electrical Specifications	Plug Standards	Juniper Model Number
Argentina	250 VAC, 10 A, 50 Hz	IRAM 2073 Type RA/3	CBL-EX-PWR-C13-AR

Table 3: AC Power Cord Specifications (Continued)

Country/Region	Electrical Specifications	Plug Standards	Juniper Model Number
Australia	250 VAC, 10 A, 50 Hz	AS/NZZS 3112 Type SAA/3	CBL-EX-PWR-C13-AU
Brazil	250 VAC, 10 A, 50 Hz	NBR 14136 Type BR/3	CBL-EX-PWR-C13-BR
China	250 VAC, 10 A, 50 Hz	GB 1002-1996 Type PRC/3	CBL-EX-PWR-C13-CH
Europe (except Italy, Switzerland, and United Kingdom)	250 VAC, 10 A, 50 Hz	CEE (7) VII Type VIIG	CBL-EX-PWR-C13-EU
India	250 VAC, 10 A, 50 Hz	IS 1293 Type IND/3	CBL-EX-PWR-C13-IN
Israel	250 VAC, 10 A, 50 Hz	SI 32/1971 Type IL/3G	CBL-EX-PWR-C13-IL
Italy	250 VAC, 10 A, 50 Hz	CEI 23-16 Type I/3G	CBL-EX-PWR-C13-IT
Japan	125 VAC, 12 A, 50 Hz or 60 Hz	JIS 8303	CBL-EX-PWR-C13-JP
Korea	250 VAC, 10 A, 50 Hz or 60 Hz	CEE (7) VII Type VIIGK	CBL-EX-PWR-C13-KR
North America	125 VAC, 13 A, 60 Hz	NEMA 5-15 Type N5-15	CBL-EX-PWR-C13-US
South Africa	250 VAC, 10 A, 50 Hz	SABS 164/1:1992 Type ZA/13	CBL-EX-PWR-C13-SA
Switzerland	250 VAC, 10 A, 50 Hz	SEV 6534-2 Type 12G	CBL-EX-PWR-C13-SZ
Taiwan	125 VAC, 11 A and 15 A, 50 Hz	NEMA 5-15P Type N5-15P	CBL-EX-PWR-C13-TW

Table 3: AC Power Cord Specifications (Continued)

Country/Region	Electrical Specifications	Plug Standards	Juniper Model Number
United Kingdom	250 VAC, 10 A, 50 Hz	BS 1363/A Type BS89/13	CBL-EX-PWR-C13-UK

Figure 5 on page 9 illustrates the plug on the power cord for some of the countries or regions listed in Table 3 on page 7.

Figure 5: AC Plug Types**SEE ALSO**

[General Safety Guidelines and Warnings | 71](#)


[General Electrical Safety Guidelines and Warnings | 96](#)

[Prevention of Electrostatic Discharge Damage | 98](#)

LWC Cooling System

The LWC devices have front-to-back airflow. The air intake to cool the chassis is located on the front of the chassis. Air is pulled into the chassis and pushed toward the fans, which are built-in. Hot air exhausts from the rear of the chassis. See [Figure 6 on page 10](#).

Figure 6: Front-to-Back Airflow Through the LWC Chassis



2

PART

Site Planning, Preparation, and Specifications

- Site Preparation Checklist for LWC Devices | **12**
 - LWC Site Guidelines and Requirements | **14**
 - LWC Network Cable and Transceiver Planning | **21**
 - LWC Cable Specifications and Pinouts | **30**
-

Site Preparation Checklist for LWC Devices

The checklist in [Table 4 on page 12](#) summarizes the tasks you need to perform when preparing a site for an LWC device installation.

Table 4: Site Preparation Checklist

Item or Task	For More Information	Performed by	Date
Environment			
Verify that environmental factors such as temperature and humidity do not exceed device tolerances.	"Environmental Requirements and Specifications for an LWC Device" on page 72		
Power			
Measure distance between external power sources and device installation site.			
Locate sites for connection of system grounding.			
Calculate the power consumption and requirements.	"AC Power Supply Specifications for an LWC Device" on page 6		
Rack or Cabinet			
Verify that your rack or cabinet meets the minimum requirements for the installation of the device.	"Rack Requirements for an LWC Device" on page 17 "Cabinet Requirements for an LWC Device" on page 19		
Plan rack or cabinet location, including required space clearances.	"Clearance Requirements for Airflow and Hardware Maintenance for an LWC Device" on page 16		

Table 4: Site Preparation Checklist *(Continued)*

Item or Task	For More Information	Performed by	Date
Secure the rack or cabinet to the floor and building structure.			
Desk			
Verify that the desk meets the minimum requirements for the installation of the device.	"Requirements for Mounting an LWC Device on a Desktop or Other Level Surface" on page 20		
Verify that there is appropriate clearance in your selected location.	"Clearance Requirements for Airflow and Hardware Maintenance for an LWC Device" on page 16		
Cables			
Acquire cables and connectors: • Determine the number of cables needed based on your planned configuration. • Review the maximum distance allowed for each cable. Choose the length of cable based on the distance between the hardware components being connected.			
Plan the cable routing and management.			

LWC Site Guidelines and Requirements

IN THIS SECTION

- [General Site Guidelines | 14](#)
- [Site Electrical Wiring Guidelines | 14](#)
- [Physical Specifications of an LWC Device | 16](#)
- [Clearance Requirements for Airflow and Hardware Maintenance for an LWC Device | 16](#)
- [Rack Requirements for an LWC Device | 17](#)
- [Cabinet Requirements for an LWC Device | 19](#)
- [Requirements for Mounting an LWC Device on a Desktop or Other Level Surface | 20](#)

General Site Guidelines

Efficient device operation requires proper site planning. For the device to operate properly, you must ensure maintenance and proper layout of the equipment, rack or cabinet, and wiring closet.

To plan and create an acceptable operating environment for your device and prevent environmentally caused equipment failures:

- Keep the area around the chassis free from dust and conductive material, such as metal flakes.
- Follow the prescribed airflow guidelines to ensure that the cooling system functions properly. Ensure that the exhaust from other equipment does not blow into the intake vents of the device.
- Follow the prescribed electrostatic discharge (ESD) prevention procedures to prevent damaging the equipment. Static discharge can cause components to fail completely or intermittently over time.
- Install the device in a secure area, so that only authorized personnel can access the device.

Site Electrical Wiring Guidelines

[Table 5 on page 15](#) describes the factors you must consider while planning the electrical wiring at your site.



WARNING: You must provide a properly grounded and shielded environment and use electrical surge-suppression devices.

Avertissement Vous devez établir un environnement protégé et convenablement mis à la terre et utiliser des dispositifs de parasurtension.

Table 5: Site Electrical Wiring Guidelines

Site Wiring Factor	Guidelines
Signaling limitations	If your site experiences any of the following problems, consult experts in electrical surge suppression and shielding: • Radio frequency interference (RFI) because of improperly installed wires. • Damage from lightning strikes occurring when wires exceed recommended distances or pass between buildings. • Damage to unshielded conductors and electronic devices as a result of electromagnetic pulses (EMPs) caused by lightning.
Radio frequency interference	To reduce or eliminate RFI from your site wiring, do the following: • Use a twisted-pair cable with a good distribution of grounding conductors. • If you need to exceed the recommended distances, use a high-quality twisted-pair cable with one ground conductor for each data signal, when applicable.
Electromagnetic compatibility	If your site is susceptible to problems with electromagnetic compatibility (EMC), particularly from lightning or radio transmitters, seek expert advice. Strong sources of electromagnetic interference (EMI) can cause: • Destruction of the signal drivers and receivers in the device. • Electrical hazards as a result of power surges conducted over the lines into the equipment.

Physical Specifications of an LWC Device

The LWC device chassis is a rigid sheet-metal structure that houses the hardware components. [Table 6 on page 16](#) summarizes the physical specifications of the LWC chassis.


Table 6: Physical Specifications of the LWC Device Chassis

Product SKU	Height	Width	Depth	Weight
LWC	1.72 in. (4.3 cm)	17.36 in. (44.1 cm)	12 in. (30.5 cm)	9.48 lb (4.3 kg)

Clearance Requirements for Airflow and Hardware Maintenance for an LWC Device

When planning the site for installing an LWC device, you must allow sufficient clearance around the installed chassis (see [Figure 7 on page 17](#)).

Figure 7: Clearance Requirements for Airflow and Hardware Maintenance for an LWC Device



- For the cooling system to function properly, the airflow around the chassis must be unrestricted. See ["LWC Cooling System" on page 9](#) for more information about the airflow through the chassis.
- If you are mounting an LWC device in a rack or cabinet with other equipment, ensure that the exhaust from other equipment does not blow into the intake vents of the chassis.
- Leave at least 24 in. (61 cm) both in front of and behind the LWC device. For service personnel to remove and to install hardware components, you must leave adequate space at the front and back of the LWC. NEBS GR-63 recommends that you allow at least 30 in. (76.2 cm) in front of the rack or cabinet and 24 in. (61 cm) behind the rack or cabinet.

Rack Requirements for an LWC Device

You can mount the LWC device on two-post racks or four-post racks.

Rack requirements consist of:

- Rack type
- Mounting bracket hole spacing

- Rack size and strength
- Rack connection to the building structure

Table 7 on page 18 provides the rack requirements and specifications for the device.

Table 7: Rack Requirements and Specifications for the Device

Rack Requirement	Guidelines
Rack type	Use a two-post rack or a four-post rack. You can mount the device on any two-post or four-post rack that: • Provides bracket holes or hole patterns spaced at 1 U (1.75 in. or 4.45 cm) increments. • Meets the size and strength requirements to support the weight. A U is the standard rack unit defined in <i>Cabinets, Racks, Panels, and Associated Equipment</i> (document number EIA-310-D) published by the Electronics Industry Association (http://www.ecianow.org/standards-practices/standards/). The rack must meet the strength requirements to support the weight of the chassis.
Mounting bracket hole spacing	The holes in the mounting brackets are spaced at 1 U (1.75 in. or 4.45 cm). Therefore, you can mount the device in any rack that provides holes spaced at that distance.
Rack size and strength	• Ensure that the rack complies with the standard for 19-in. rack as defined in <i>Cabinets, Racks, Panels, and Associated Equipment</i> (document number EIA-310-D) published by the Electronics Industry Association. • Ensure that the rack rails are spaced widely enough to accommodate the device chassis' external dimensions of 1.72 in. (4.3 cm) height, 17.36 in. (44.1 cm) width, and 12 in. (30.5 cm) depth. The 19-in. rack brackets have a width of 0.82 in. (2.1 cm), height of 1.72 in. (4.3 cm), and depth of 2.1 in. (5.4 cm). The 23-in. rack brackets have a width of 3.3 in. (8.4 cm), height of 1.72 in. (4.3 cm), and depth of 8.5 in. (21.6 cm). • The rack must be strong enough to support the weight of the device. • Ensure that the spacing of rails and adjacent racks allows for the proper clearance around the device and rack.

Table 7: Rack Requirements and Specifications for the Device (Continued)

Rack Requirement	Guidelines
Rack connection to building structure	- Secure the rack to the building structure. - If your geographic area is earthquake-prone, you must secure the rack to the floor. - Secure the rack to the ceiling brackets as well as wall or floor brackets for maximum stability.

We supply, with each device, one pair of mounting brackets for mounting the device on two posts of a rack. For mounting the device on four posts of a rack or cabinet, you can order a four-post rack-mount kit separately.

Cabinet Requirements for an LWC Device

You can mount the LWC device in an enclosure or cabinet that contains a four-post 19-in. open rack as defined in *Cabinets, Racks, Panels, and Associated Equipment* (document number EIA-310-D) published by the Electronics Industry Association.

Cabinet requirements consist of:

- Cabinet size and clearance
- Cabinet airflow requirements

[Table 8 on page 19](#) provides the cabinet requirements and specifications for the LWC device.

Table 8: Cabinet Requirements for the LWC Device

Cabinet Requirement	Guidelines
Cabinet size and clearance	The minimum depth of a cabinet for accommodating an LWC device is 36 in. (91.4 cm). Large cabinets improve airflow and reduce the chance of overheating.

Table 8: Cabinet Requirements for the LWC Device (Continued)

Cabinet Requirement	Guidelines
Cabinet airflow requirements	When you mount the device in a cabinet, ensure that ventilation through the cabinet is sufficient to prevent overheating. • Ensure that the cool air supply you provide through the cabinet adequately dissipates the thermal output of the device (or devices). • Ensure that the cabinet allows the chassis hot exhaust air to exit the cabinet without recirculating into the device. An open cabinet (without a top or doors) that employs hot air exhaust extraction from the top allows the best airflow through the chassis. If the cabinet contains a top or doors, perforations in these elements assist with removing the hot air exhaust. • Install the device in the cabinet in a way that maximizes the open space on the side of the chassis that has the hot air exhaust. • Route and dress all cables to minimize the blockage of airflow to and from the chassis. • Ensure that the spacing of rails and adjacent cabinets allows for the proper clearance around the device and cabinet. • A cabinet larger than the minimum required provides better airflow and reduces the chance of overheating.

Requirements for Mounting an LWC Device on a Desktop or Other Level Surface

You can install the LWC device on a desktop or other such level surface by attaching the four rubber feet (provided) to the bottom of the chassis.

When choosing a location, allow at least 6 in. (15.2 cm) of clearance between the front and back of the chassis and adjacent equipment or walls.

Ensure that the desktop or other level surface on which the device is installed is stable and securely supported.

LWC Network Cable and Transceiver Planning

IN THIS SECTION

- [Pluggable Transceivers Supported on LWC Devices | 21](#)
- [Understanding LWC Devices Fiber-Optic Cable Signal Loss, Attenuation, and Dispersion | 26](#)
- [Calculate the Fiber-Optic Cable Power Budget for an LWC Device | 28](#)
- [Calculate the Fiber-Optic Cable Power Margin for an LWC Device | 28](#)

Pluggable Transceivers Supported on LWC Devices

Uplink module ports on LWC devices support SFP and SFP+ transceivers. This topic describes the optical interfaces supported on those transceivers. It also lists the copper interface supported for the SFP transceivers.



NOTE: We recommend that you use only optical transceivers and optical connectors purchased from Juniper Networks with your Juniper Networks device.



CAUTION: The Juniper Networks Technical Assistance Center (JTAC) provides complete support for Juniper-supplied optical modules and cables. However, JTAC does not provide support for third-party optical modules and cables that are not qualified or supplied by Juniper Networks. If you face a problem running a Juniper device that uses third-party optical modules or cables, JTAC may help you diagnose host-related issues if the observed issue is not, in the opinion of JTAC, related to the use of the third-party optical modules or cables. Your JTAC engineer will likely request that you check the third-party optical module or cable and, if required, replace it with an equivalent Juniper-qualified component.

Use of third-party optical modules with high-power consumption (for example, coherent ZR or ZR+) can potentially cause thermal damage to or reduce the lifespan of the host equipment. Any damage to the host equipment due to the use of third-party optical

modules or cables is the users' responsibility. Juniper Networks will accept no liability for any damage caused due to such use.

The tables in this topic describe the optical interface support over single-mode fiber-optic (SMF) and multimode fiber-optic (MMF) cables and the copper interface for SFP transceivers:

Table 9: Optical Interface Support and Copper Interface Support for Gigabit Ethernet SFP Transceivers in LWC Devices

Ethernet Standard	Specification	Value
1000BASE-T	Model number	CTP-SFP-1GE-T
	Rate	10/100/1000 Mbps
	Connector type	RJ-45
	Transmitter wavelength	–
	Minimum launch power	–
	Maximum launch power	–
	Minimum receiver sensitivity	–
	Maximum input power	–
	Core/cladding size	–
	Modal bandwidth	–
	Distance	100 m
	Software required	LWC

Table 9: Optical Interface Support and Copper Interface Support for Gigabit Ethernet SFP Transceivers in LWC Devices (Continued)

Ethernet Standard	Specification	Value
1000BASE-LX	Model number	EX-SFP-1GE-LX
	Rate	1000 Mbps
	Connector type	LC
	Fiber count	Dual
	Transmitter wavelength	1310 nm
	Minimum launch power	-9.5 dBm
	Maximum launch power	-3 dBm
	Minimum receiver sensitivity	-25 dBm
	Maximum input power	-3 dBm
	Fiber type	SMF
	Core/cladding size	9/125 μ m
	Modal bandwidth	-
	Distance	10 km (6.2 miles)
	Software required	LWC

Table 10: Optical Interface Support for Gigabit Ethernet SFP+ Transceivers in LWC Devices

Ethernet Standard	Specification	Value				
10GBASE-SR	Model number	EX-SFP-10GE-SR				
	Rate	10 Gbps				
	Connector type	LC				
	Fiber count	Dual				
	Transmitter wavelength	850 nm				
	Minimum launch power	-7.3 dBm				
	Maximum launch power	-1 dBm				
	Minimum receiver sensitivity	-9.9 dBm				
	Maximum input power	-1 dBm				
	Fiber type	MMF				
	Core/cladding size	62.5/125 μm	62.5/125 μm	50/125 μm	50/125 μm	50/125 μm
	Fiber grade	FDDI	OM1	-	OM2	OM3
	Modal bandwidth	160 MHz z/km	200 MHz /km	400 MHz /km	500 MHz /km	1500 MHz z/km

Table 10: Optical Interface Support for Gigabit Ethernet SFP+ Transceivers in LWC Devices *(Continued)*

Ethernet Standard	Specification	Value				
		26 m	33 m	66 m	82 m	300 m
		Available				
		LWC				
10GBASE-LR	Model number	EX-SFP-10GE-LR				
	Rate	10 Gbps				
	Connector type	LC				
	Fiber count	Dual				
	Transmitter wavelength	1310 nm				
	Minimum launch power	-8.2 dBm				
	Maximum launch power	0.5 dBm				
	Minimum receiver sensitivity	-18 dBm				
	Maximum input power	0.5 dBm				
	Fiber type	SMF				
	Core/cladding size	9/125 μ m				

Table 10: Optical Interface Support for Gigabit Ethernet SFP+ Transceivers in LWC Devices *(Continued)*

Ethernet Standard	Specification	Value
	Modal bandwidth	–
	Distance	10 km
	DOM support	Available
	Software required	LWC

Understanding LWC Devices Fiber-Optic Cable Signal Loss, Attenuation, and Dispersion

IN THIS SECTION

- [Signal Loss in Multimode and Single-Mode Fiber-Optic Cables | 26](#)
- [Attenuation and Dispersion in Fiber-Optic Cable | 27](#)

To determine the power budget and power margin needed for fiber-optic connections, you need to understand how signal loss, attenuation, and dispersion affect transmission. The LWC devices use various types of network cable, including multimode and single-mode fiber-optic cables.

Signal Loss in Multimode and Single-Mode Fiber-Optic Cables

Multimode fiber is large enough in diameter to allow rays of light to reflect internally (bounce off the walls of the fiber). Interfaces with multimode optics typically use LEDs as light sources. However, LEDs are not coherent light sources. They spray varying wavelengths of light into the multimode fiber, which reflects the light at different angles. Light rays travel in jagged lines through a multimode fiber, causing signal dispersion. When light traveling in the fiber core radiates into the fiber cladding (layers of lower refractive index material in close contact with a core material of higher refractive index), higher-order

mode loss occurs. Together, these factors reduce the transmission distance of multimode fiber compared to that of single-mode fiber.

Single-mode fiber is so small in diameter that rays of light reflect internally through one layer only. Interfaces with single-mode optics use lasers as light sources. Lasers generate a single wavelength of light, which travels in a straight line through the single-mode fiber. Compared to multimode fiber, single-mode fiber has a higher bandwidth and can carry signals for longer distances. It is consequently more expensive.

For information about the maximum transmission distance and supported wavelength range for the types of single-mode and multimode fiber-optic cables that are connected to the LWC devices, see ["Pluggable Transceivers Supported on LWC Devices" on page 21](#). Exceeding the maximum transmission distances can result in significant signal loss, which causes unreliable transmission.

Attenuation and Dispersion in Fiber-Optic Cable

An optical data link functions correctly provided that modulated light reaching the receiver has enough power to be demodulated correctly. *Attenuation* is the reduction in strength of the light signal during transmission. Passive media components such as cables, cable splices, and connectors cause attenuation. Although attenuation is significantly lower for optical fiber than for other media, it still occurs in both multimode and single-mode transmission. An efficient optical data link must transmit enough light to overcome attenuation.

Dispersion is the spreading of the signal over time. The following two types of dispersion can affect signal transmission through an optical data link:

- Chromatic dispersion, which is the spreading of the signal over time caused by the different speeds of light rays.
- Modal dispersion, which is the spreading of the signal over time caused by the different propagation modes in the fiber.

For multimode transmission, modal dispersion, rather than chromatic dispersion or attenuation, usually limits the maximum bit rate and link length. For single-mode transmission, modal dispersion is not a factor. However, at higher bit rates and over longer distances, chromatic dispersion limits the maximum link length.

An efficient optical data link must have enough light to exceed the minimum power that the receiver requires to operate within its specifications. In addition, the total dispersion must be within the limits specified for the type of link in Telcordia Technologies document GR-253-CORE (Section 4.3) and International Telecommunications Union (ITU) document G.957.

When chromatic dispersion is at the maximum allowed, its effect can be considered as a power penalty in the power budget. The optical power budget must allow for the sum of component attenuation, power penalties (including those from dispersion), and a safety margin for unexpected losses.

Calculate the Fiber-Optic Cable Power Budget for an LWC Device

Calculate the link's power budget when planning fiber-optic cable layout and distances to ensure that fiber-optic connections have sufficient power for correct operation. The power budget is the maximum amount of power that the link can transmit. When you calculate the power budget, you use a worst-case analysis to provide a margin of error, even though all the parts of an actual system do not operate at the worst-case levels.

To calculate the worst-case estimate for fiber-optic cable power budget (P^B) for the link:

1. Determine values for the link's minimum transmitter power (P_T) and minimum receiver sensitivity (P_R). For example, here, we measure (P_T) and (P_R) in decibels, and decibels are referenced to 1 milliwatt (dBm).

$$P_T = -15 \text{ dBm}$$

$$P_R = -28 \text{ dBm}$$



NOTE: See the specifications for your transmitter and receiver to find the minimum transmitter power and minimum receiver sensitivity.

2. Calculate the power budget (P^B) by subtracting (P_R) from (P_T):

$$-15 \text{ dBm} - (-28 \text{ dBm}) = 13 \text{ dBm}$$

Calculate the Fiber-Optic Cable Power Margin for an LWC Device

Before you begin to calculate the power margin:

- Calculate the power budget. See ["Calculate the Fiber-Optic Cable Power Budget for an LWC Device" on page 28](#).

You need to calculate the link's power margin when planning fiber-optic cable layout and distances. An adequate power margin ensures that fiber-optic connections have sufficient signal power to overcome system losses and still satisfy the minimum input requirements of the receiver for the required performance level. The power margin (P_M) is the amount of power available after attenuation or link loss (LL) is subtracted from the power budget (P^B).

When you calculate the power margin, you use a worst-case analysis to provide a margin of error, even though all the parts of an actual system do not operate at worst-case levels. A power margin (P_M) greater than zero indicates that the power budget is sufficient to operate the receiver and that it does not exceed the maximum receiver input power. This means the link will work. A zero or negative power

margin (P_M) indicates that you have insufficient power to operate the receiver. See the specification for your receiver to find the maximum receiver input power.

To calculate the worst-case estimate for the power margin (P_M) for the link:

1. Determine the maximum value for link loss (LL) by adding estimated values for applicable link-loss factors—for example, use the sample values for various factors as provided in [Table 11 on page 29](#) (here, the link is 2 km long and multimode, and the (P_B) is 13 dBm):

Table 11: Estimated Values for Factors Causing Link Loss

Link-Loss Factor	Estimated Link-Loss Value	Sample Link-Loss (LL) Calculation Values
Higher-order mode losses	Multimode—0.5 dBm	0.5 dBm
	Single-mode—None	0 dBm
Modal and chromatic dispersion	Multimode—None, if product of bandwidth and distance is less than 500 MHz/km	0 dBm
	Single-mode—None	0 dBm
Connector	0.5 dBm	This example assumes five connectors. Loss for five connectors: $5 (0.5 \text{ dBm}) = 2.5 \text{ dBm}$.
Splice	0.5 dBm	This example assumes two splices. Loss for two splices: $2 (0.5 \text{ dBm}) = 1 \text{ dBm}$.
Fiber attenuation	Multimode—1 dBm/km	This example assumes the link is 2 km long. Fiber attenuation for 2 km: $2 \text{ km} (1 \text{ dBm/km}) = 2 \text{ dBm}$.
	Single-mode—0.5 dBm/km	This example assumes the link is 2 km long. Fiber attenuation for 2 km: $2 \text{ km} (0.5 \text{ dBm/km}) = 1 \text{ dBm}$.
Clock Recovery Module (CRM)	1 dBm	1 dBm



NOTE: For information about the actual amount of signal loss caused by equipment and other factors, see your vendor documentation for that equipment.

2. Calculate the (P_M) by subtracting (LL) from (P_B):

$$P_B - LL = P_M$$

$$13 \text{ dBm} - 0.5 \text{ dBm [HOL]} - 5 (0.5 \text{ dBm}) - 2 (0.5 \text{ dBm}) - 2 \text{ km} (1.0 \text{ dBm/km}) - 1 \text{ dB [CRM]} = P_M$$

$$13 \text{ dBm} - 0.5 \text{ dBm} - 2.5 \text{ dBm} - 1 \text{ dBm} - 2 \text{ dBm} - 1 \text{ dBm} = P_M$$

$$P_M = 6 \text{ dBm}$$

The calculated power margin is greater than zero, indicating that the link has sufficient power for transmission. Also, the power margin value does not exceed the maximum receiver input power. Refer to the specifications for your receiver to find the maximum receiver input power.

LWC Cable Specifications and Pinouts

IN THIS SECTION

- Cable Specifications for Console Connection for an LWC Device | 30
- Console Port Connector Pinouts for LWC Devices | 31
- USB Port Specifications for an LWC Device | 32
- Network Port Connector Pinout Information for an LWC Device | 32
- RJ-45 to DB-9 Serial Port Adapter Pinout Information for an LWC Device | 33

Cable Specifications for Console Connection for an LWC Device

Juniper Networks resident engineers can use the console (**CON**) port to connect an LWC device to a management device. [Table 12 on page 31](#) lists the specifications for the cables that connect the LWC devices to a management device.

Table 12: Cable Specifications for Console Connections for an LWC Device

Port on the LWC	Cable Specification	Cable Supplied	Maximum Length	Device Receptacle
Console port	RS-232 (EIA-232) serial cable	One 7-foot (2.13-meter) long RJ-45 patch cable and RJ-45 to DB-9 adapter	2.13 meters	RJ-45

Console Port Connector Pinouts for LWC Devices

The console port (labeled **CON**) is an RS-232 serial interface that uses an RJ-45 connector to connect to a console management device. The default baud rate for the console port is 9600 baud.

[Table 13 on page 31](#) provides the pinout information for the RJ-45 console connector. We supply an RJ-45 cable and RJ-45 to DB-9 adapter with the LWC device.



NOTE: If your laptop or PC does not have a DB-9 plug connector pin and you want to connect your laptop or PC directly to an LWC device, use a combination of the RJ-45 cable and RJ-45 to DB-9 adapter (supplied with the device) and a USB to DB-9 plug adapter. You must provide the USB to DB-9 plug adapter.

Table 13: Console Port Connector Pinouts for the LWC Device

Pin	Signal	Description
1	RTS Output	Request to send
2	DTR Output	Data terminal ready
3	TxD Output	Transmit data
4	Signal Ground	Signal ground
5	Signal Ground	Signal ground

Table 13: Console Port Connector Pinouts for the LWC Device *(Continued)*

Pin	Signal	Description
6	RxD Input	Receive data
7	DCD Input	Data carrier detect
8	CTS Input	Clear to send

USB Port Specifications for an LWC Device

We've tested the following Juniper Networks USB flash drives; the USB port in the LWC device supports these flash drives:

- RE-USB-1G-S—1-gigabyte (GB) USB flash drive
- RE-USB-2G-S—2-GB USB flash drive
- RE-USB-4G-S—4-GB USB flash drive



CAUTION: Any USB memory product not listed as supported for the LWC device has not been tested by Juniper Networks. The use of any unsupported USB memory product could expose your device to unpredictable behavior. Juniper Networks Technical Assistance Center (JTAC) can provide only limited support for issues related to unsupported hardware. We strongly recommend that you use only supported USB flash drives.



NOTE: USB flash drives used with the LWC device must support USB 2.0 or later.

Network Port Connector Pinout Information for an LWC Device

A network port on an LWC device uses an RJ-45 connector to connect to a device.

The port uses an autosensing RJ-45 connector to support a 10/100/1000Base-T connection. Two LEDs on the port indicate link activity on the port and the port status.

[Table 14 on page 33](#) provides the pinout information for the RJ-45 connector. We supply an RJ-45 cable, with a connector attached, with the LWC device.

Table 14: Network Port Connector Pinout Information for an LWC Device

Pin	Signal	Description
1	TRP1+	Transmit/receive data pair 1
2	TRP1-	Transmit/receive data pair 1
3	TRP2+	Transmit/receive data pair 2
4	TRP3+	Transmit/receive data pair 3
5	TRP3-	Transmit/receive data pair 3
6	TRP2-	Transmit/receive data pair 2
7	TRP4+	Transmit/receive data pair 4
8	TRP4-	Transmit/receive data pair 4

RJ-45 to DB-9 Serial Port Adapter Pinout Information for an LWC Device

The console port is an RS-232 serial interface that uses an RJ-45 connector to connect to a management device such as a PC or a laptop. If your laptop or PC does not have a DB-9 plug connector pin and you want to connect your laptop or PC to an LWC device, use a combination of the RJ-45 to DB-9 socket adapter (supplied with the switch) along with a USB to DB-9 plug adapter.

[Table 15 on page 34](#) provides the pinout information for the RJ-45 to DB-9 serial port adapter.

Table 15: RJ-45 to DB-9 Serial Port Adapter Pinout Information

RJ-45 Pin	Signal	DB-9 Pin	Signal
1	RTS	8	CTS
2	DTR	6	DSR
3	TXD	2	RXD
4	GND	5	GND
6	RXD	3	TXD
7	DSR	4	DTR
8	CTS	7	RTS

3

PART

Initial Installation and Configuration

- LWC Installation Overview | **36**
 - Unpacking and Mounting the LWC Device | **36**
 - Connect the LWC Device to Power | **45**
 - Connect the LWC Device to Network | **48**
 - Configure the LWC Device | **50**
-

LWC Installation Overview

To install and connect an LWC device:

1. Follow instructions in ["Unpack an LWC Device" on page 37](#).
2. Mount the device by following instructions appropriate for your site:
 - ["Mount an LWC Device on a Desk or Other Level Surface" on page 39](#) (using the rubber feet provided)
 - ["Mount an LWC Device on Two Posts in a Rack" on page 40](#) (using the mounting brackets provided)
 - ["Mount an LWC Device on Four Posts in a Rack or Cabinet" on page 42](#) (using the separately orderable four-post rack mount kit)
3. Follow instructions in ["Connect an LWC Device to Earth Ground" on page 46](#).
4. Follow instructions in ["Connect an LWC Device to AC Power" on page 47](#).
5. Connect the device to the networks. See ["Connect the LWC Device to Network" on page 48](#)

Unpacking and Mounting the LWC Device

IN THIS SECTION

- [Unpack an LWC Device | 37](#)
- [Parts Inventory \(Packing List\) for an LWC Device | 37](#)
- [Register Products—Mandatory to Validate SLAs | 38](#)
- [Methods to Mount an LWC Device | 39](#)
- [Mount an LWC Device on a Desk or Other Level Surface | 39](#)
- [Mount an LWC Device on Two Posts in a Rack | 40](#)
- [Mount an LWC Device on Four Posts in a Rack or Cabinet | 42](#)

Unpack an LWC Device

We ship the LWC device in a cardboard carton, secured with foam packing material. The carton has an accessory compartment and contains the quick start instructions.



CAUTION: The LWC device is maximally protected inside the shipping carton. Do not unpack the device until you are ready to begin installation.

To unpack the LWC device:

1. Open the carton.
2. Pull out the packing material holding the device in place.
3. Verify the parts received against the inventory on the label attached to the carton. The package contains an LWC device and two SFP modules (CTP-SFP-1GE-T).
4. Save the shipping carton and packing materials in case you need to move or ship the device later.

Parts Inventory (Packing List) for an LWC Device

We ship the LWC device in a cardboard carton, secured with foam packing material. The carton contains an accessory box.

The device shipment includes a packing list. Check the parts you receive in the device shipping carton against the items on the packing list. The parts shipped depend on the configuration you order.

If any part on the packing list is missing, contact your customer service representative or contact Juniper customer care from within the U.S. or Canada by telephone at 1-888-314-5822. For international-dial or direct-dial options in countries without toll-free numbers, see <https://www.juniper.net/support/requesting-support.html>.

Table 16 on page 37 lists the parts and their quantities in the packing list.

Table 16: Packing List for an LWC Device

Component	Quantity
LWC device	1
AC power cord appropriate for your geographical location	1

Table 16: Packing List for an LWC Device *(Continued)*

Component	Quantity
AC power cord retainer clip	1
Mounting brackets	2
Mounting screws to attach the mounting brackets to the device chassis	8
Rubber feet	4
RJ-45 cable and RJ-45 to DB-9 serial port adapter	1
CTP-SFP-1GE-T modules	2
Quick Start installation instructions	1
Juniper Networks Product Warranty	1
End User License Agreement	1



NOTE: You must provide mounting screws that are appropriate for your rack or cabinet to mount the chassis on a rack or a cabinet.

Register Products—Mandatory to Validate SLAs

Register all new Juniper Networks hardware products and changes to an existing installed product using the Juniper Networks website to activate your hardware replacement service-level agreements (SLAs).



CAUTION: Register product serial numbers on the Juniper Networks website and update the installation base data if there is any addition or change to the installation base or if the installation base is moved. Juniper Networks will not be held accountable

for not meeting the hardware replacement service-level agreement for products that do not have registered serial numbers or accurate installation base data.

Register your product(s) at <https://tools.juniper.net/svcreg/SRegSerialNum.jsp>.

Update your installation base at <https://www.juniper.net/customers/csc/management/updateinstallbase.jsp>.

Methods to Mount an LWC Device

Table 17 on page 39 lists the methods you can use to mount an LWC device.

Table 17: LWC Device Mounting Methods

Mounting Method	Device Model	Description
Desk or other level surface	LWC	On a desk or other level surface by using rubber feet provided with the device.
Two-post rack or cabinet	LWC	On two posts in a 19-in. rack or cabinet by using the mounting brackets shipped with the device.
Four-post rack or cabinet	LWC	- On four posts in a 19-in. rack or cabinet by using the separately orderable four-post rack mount kit - On two posts in a 19-in. rack or cabinet by using the two-post rack mounting brackets.

The holes in the mounting brackets are placed 1 U (1.75 in. or 4.45 cm) apart so that you can mount the device in any rack or cabinet that provides holes spaced at that distance.

See the Related Documentation for detailed descriptions of the various rack or cabinet mounting options.

Mount an LWC Device on a Desk or Other Level Surface

Before mounting the device on a desk or other level surface:


- Verify that the site meets the requirements described in ["Site Preparation Checklist for LWC Devices" on page 12.](#)
- Place the desk in its permanent location, allowing adequate clearance for airflow and maintenance, and secure it to the building structure.
- Read ["General Safety Guidelines and Warnings" on page 71,](#) with particular attention to ["Chassis Lifting Guidelines for LWC Devices" on page 78.](#)
- Ensure that you have the four rubber feet to stabilize the chassis on a desk or other level surface (provided in the accessory box in the device carton).

You can mount an LWC device on a desk or other level surface by using the four rubber feet that are shipped with the switch. The rubber feet stabilize the chassis.

To mount the LWC device on a desk or other level surface:

1. Remove the device from the shipping carton (see ["Unpack an LWC Device" on page 37\).](#)
2. Turn the chassis upside down on the desk or the level surface where you intend to mount the device.
3. Attach the rubber feet to the bottom of the chassis as shown in [Figure 8 on page 40.](#)
4. Turn the chassis right side up on the desk or the level surface. Now you have mounted the device.

Figure 8: Attach Rubber Feet to the LWC Device



Mount an LWC Device on Two Posts in a Rack

Before mounting an LWC device on two posts in a rack:

- Place the rack in its permanent location, allowing adequate clearance for airflow and maintenance, and secure it to the building structure.
- Read ["General Safety Guidelines and Warnings" on page 71.](#)
- Remove the device from the shipping carton.

Ensure that you have the following parts and tools available:

- Phillips (+) screwdriver, number 2
- Two mounting brackets and eight mounting screws (provided in the accessory box shipped with the device)
- Screws to secure the chassis to the rack (not provided)

You can mount an LWC device on two posts of a 19-in. rack (either a two-post or a four-post rack).



NOTE: If you need to mount the device in a recessed position on either a two-post rack or a four-post rack, you can use the 2-in.-recess front brackets provided in the separately orderable four-post rack mount kit.



NOTE: One person must be available to lift the device while another secures the device to the rack.




CAUTION: If you are mounting multiple devices on a rack, mount a device in the bottom of the rack first and proceed to mount the rest of the devices from bottom to top.

To mount the device on two posts in a rack:

1. Place the device on a flat, stable surface.
2. Align the mounting brackets along the front, rear, or center of the side panels of the device chassis depending on how you want to mount the device. For example, if you want to front-mount the device, align the brackets along the front of the side panel. See [Figure 9 on page 41](#).


Figure 9: Attach the Mounting Bracket to the Side Panel of the Device



NOTE: If you need to mount the device in a recessed position, use the 2-in.-recess front mount brackets from the separately orderable four-post rack-mount kit.

3. Align the bottom holes in the mounting brackets with holes on the side panels of the device chassis.
4. Insert mounting screws into the aligned holes. Tighten the screws.
5. Ensure that the other holes in the mounting brackets are aligned with the holes in the side panels. Insert a screw in each hole and tighten the screws.
6. Have one person grasp both sides of the device, lift the device, and position it in the rack, aligning the mounting bracket holes with the threaded holes in the rack or cabinet rail. Align the bottom hole in both the mounting brackets with a hole in each rack rail, making sure that the chassis is level. See [Figure 10 on page 42](#).

Figure 10: Mount the Device on Two Posts in a Rack



7. Have a second person secure the device to the rack by using the appropriate screws. Tighten the screws.
8. Ensure that the device chassis is level by verifying that all screws on one side of the rack are aligned with the screws on the other side.

Mount an LWC Device on Four Posts in a Rack or Cabinet

Before mounting the device on four posts in a rack:

- Place the rack in its permanent location, allowing adequate clearance for airflow and maintenance, and secure it to the building structure.
- Read ["General Safety Guidelines and Warnings" on page 71](#), with particular attention to ["Chassis Lifting Guidelines for LWC Devices" on page 78](#).
- Remove the device from the shipping carton (see ["Unpack an LWC Device" on page 37](#)).
- Have two persons available to mount the device. One person will support the device in a level position, and the second person will secure the device to the rack.

Ensure that you have the following parts and tools available:

- Phillips (+) screwdriver, number 2
- 12 flat-head M4x6-mm Phillips mounting screws (provided with the four-post rack-mount kit)
- One pair of front-mounting brackets
- One pair of rear mounting-blades
- Screws to secure the front-mounting brackets and the rear mounting-blades to the rack (not provided)

You can mount an LWC device on four posts of a 19-in. rack or cabinet by using the separately orderable four-post rack mount kit. (The remainder of this topic uses *rack* to mean *rack or cabinet*).

You can mount the device on two posts in either a two-post rack or a four-post rack by using the mounting brackets provided with the device. See ["Mount an LWC Device on Two Posts in a Rack" on page 40](#).



NOTE: If you are mounting the device on four posts, ensure that the rack is 21.5 in. through 31.5 in. deep if you will mount the device flush with the rack front. If you want to mount the device 2 in. recessed from the front rack, make sure that the rack is 23.5 in. through 32.5 in. deep. Recessed mounting ensures that the protective earthing terminal is accessible through the opening in the rear mounting-blade.



CAUTION: If you are mounting multiple units on a rack, mount the heaviest unit at the bottom of the rack. Mount the other units from the bottom of the rack to the top in decreasing order of the weight of the units.

To mount the device on four posts in a rack:

1. Place the device on a flat, stable surface.

2. Align a front bracket (either flush with the front of the chassis or 2-in.-recessed from the front of the chassis) along the side panel of the device chassis. Align the two holes in the front of the brackets with the two holes on the front of the side panel.




NOTE: Each side of the chassis has twelve holes for attaching the front-mounting brackets to the device.

Six holes on the chassis side align with six holes in the front bracket when the front bracket is mounted flush with the chassis front or recessed 2 in. from the front of the chassis.


3. Insert M4x6-mm Phillips flat-head mounting screws into the two aligned holes and tighten the screws. Ensure that the remaining two holes in the front bracket are aligned with the two holes in the side panel. See [Figure 11 on page 44](#).

Figure 11: Attach the Front-Mounting Bracket to the Device Chassis



4. Insert M4x6-mm Phillips flat-head mounting screws into the remaining two holes in the front bracket and tighten the screws.
5. Repeat Step 2 through Step 4 for attaching the front bracket to the other side of the chassis.
6. Have one person grasp both sides of the device, lift the device, and position it in the rack, aligning the front bracket holes with the threaded holes in the front post of the rack. Align the bottom hole in both the front-mounting brackets with a hole in each rack rail, making sure that the chassis is level. See [Figure 12 on page 45](#).

Figure 12: Mount the Device on the Front Posts in a Rack



7. Have a second person secure the front of the device to the rack by using the appropriate screws for your rack.
8. Slide the rear mounting-blades into the front-mounting brackets.
9. Attach the rear mounting-blades to the rear post by using the appropriate screws for your rack. Tighten the screws.
10. Ensure that the device chassis is level by verifying that all the screws on the front of the rack are aligned with the screws at the back of the rack.

Connect the LWC Device to Power

IN THIS SECTION

- [Parts and Tools Required for Connecting an LWC Device to Earth Ground | 46](#)
- [Connect an LWC Device to Earth Ground | 46](#)
- [Connect an LWC Device to AC Power | 47](#)

The device chassis meets the Electromagnetic Compatibility (EMC) and Electrostatic Discharge (ESD) requirements. The AC power cord provides surge protection.

You must install the LWC device in a restricted-access location and ensure that the chassis is always properly grounded. The LWC device has a two-hole protective grounding terminal provided on the chassis. We recommend that you use this protective grounding terminal as the preferred method for grounding the chassis regardless of the power supply configuration. However, if additional grounding

methods are available, you can also use those methods. For example, you can use the grounding wire in the AC power cord. This tested system meets or exceeds all applicable EMC regulatory requirements with the two-hole protective grounding terminal.

Parts and Tools Required for Connecting an LWC Device to Earth Ground

Table 18 on page 46 lists the earthing terminal location, grounding cable requirements, grounding lug specifications, screws and washers required, and the screwdriver needed for connecting a device to earth ground. Before you begin connecting the device to earth ground, ensure you have the parts and tools required for your device.

Table 18: Parts and Tools Required for Connecting an LWC Device to Earth Ground


Earthing Terminal Location	Grounding Cable Requirements	Grounding Lug Specifications	Screws and Washers	Screwdriver	Additional Information
Rear panel of chassis	14 AWG (2 mm ²), minimum 90°C wire, or as permitted by the local code	Panduit LCC10-14BWL or equivalent—not provided	- Two 10-32 x .25 in. screws with #10 split-lock washer—not provided - Two #10 flat washers—not provided	Phillips (+) number 2	

Connect an LWC Device to Earth Ground

To connect a grounding cable to a device:

1. Connect one end of the grounding cable to a proper earth ground, such as the rack in which the device is mounted.
2. Place the grounding lug attached to the grounding cable over the protective earthing terminal. See [Figure 13 on page 47](#).

Figure 13: Connect a Grounding Cable to an LWC Device



3. Secure the grounding lug to the protective earthing terminal with the washers and screws.
4. Dress the grounding cable and ensure that it does not touch or block access to other device components.



WARNING: Ensure that the cable does not drape where people could trip over it.

Connect an LWC Device to AC Power

Ensure that you have the following parts and tools available:

- A power cord appropriate for your geographical location
- A power cord retainer clip



CAUTION: The LWC device gets additional grounding when you plug the power supply in the device into a grounded AC power outlet by using the AC power cord appropriate for your geographical location (see ["AC Power Cord Specifications for an LWC Device" on page 7](#)).

The power supply in an LWC device is located on the rear panel.

To connect AC power to the device:

1. Squeeze the two sides of the power cord retainer clip and insert the L-shaped ends of the wire clip into the holes in the bracket on each side of the AC power cord inlet on the rear panel.
The power cord retainer clip extends out of the chassis by 3 in.
2. Locate the power cord or cords shipped with the device; the cords have plugs appropriate for your geographical location. See ["AC Power Cord Specifications for an LWC Device" on page 7](#).




WARNING: Ensure that the power cord does not drape where people can trip on it or block access to device components.

3. Insert the coupler end of the power cord into the AC power cord inlet on the rear panel.
4. Push the power cord into the slot in the adjustment nut of the power cord retainer clip. Turn the nut until it is tight against the base of the coupler and the slot in the nut is turned 90° from the top of the device.
5. If the AC power source outlet has a power switch, set it to the off (O) position.
6. Insert the power cord plug into an AC power source outlet.
7. If the AC power source outlet has a power switch, set it to the on (I) position.



NOTE: The retainer brackets on your LWC device might be above and below the power inlet rather than on either side.

Figure 14: Connect an AC Power Cord to the AC Power Cord Inlet on an LWC Device



Connect the LWC Device to Network

IN THIS SECTION

- [Connect the LWC Device to the Internal and External Networks | 49](#)
- [Power On the LWC | 50](#)

Connect the LWC Device to the Internal and External Networks

The LWC uses the following network ports:

- An internal network port (interface xe-0/0/12) to access the Juniper devices on your network.
- An external network port (interface xe-0/0/13) to access Juniper Cloud.

Before connecting the LWC to the internal network, ensure that you have:


- A terminating SFP module each for the internal and external network. We ship only two 1 GbE SFP copper modules for the LWC device.
- Optical SFP modules (only if you prefer it over the copper SFP module provided).

To connect the LWC to the internal and external networks:

- Connect the 1/10-Gigabit SFP+ port **0** on the LWC to the internal network. The interface name is xe-0/0/12.
- Connect the 1/10-Gigabit SFP+ port **1** on the LWC to the external network. The interface name is xe-0/0/13.

Figure 15 on page 49 illustrates how you connect an LWC device to the internal and external networks.

Figure 15: Connect the LWC to Internal and External Networks



Power On the LWC

You can power on the device after connecting the ports to the internal and external networks.

Before powering on the LWC, ensure that the device is connected to power. See ["Connect the LWC Device to Power" on page 45](#)

To power on the device:

1. Turn on the power switch on the LWC rear panel.
2. Verify that the power LED on the LWC front panel is green.

Configure the LWC Device

IN THIS SECTION

- [Internal and External Network Requirements | 50](#)
- [Configure the Network Ports and Active Proxy | 52](#)

The Lightweight Collector (LWC) is preconfigured to support IPv4 and Dynamic Host Configuration Protocol (DHCP) on both the internal and external network ports. When you power on the LWC device after completing the required cabling, a zero touch experience (ZTE) process to provision the device is initiated. Successful completion of the ZTE process results in the device establishing IP connectivity on both the ports. It also results in the external port establishing connectivity to Juniper Cloud via. discoverable reachability to the Internet. If the device fails to automatically establish the IP connectivity and reachability to the Internet, you must configure the LWC manually as described in ["Configure the Network Ports and Active Proxy" on page 52](#).

Before configuring the network ports, review the ["Internal and External Network Requirements" on page 50](#).

Internal and External Network Requirements

The LWC device requires:

- An internal network port (interface xe-0/0/12) that connects the LWC to the Juniper devices on the network.
- An external network port (interface xe-0/0/13) that connects the LWC to the Juniper Virtual Private Cloud.

Before connecting the LWC to the internal network, ensure that you have:

- A DHCP or static IP address.
- IP connectivity to the Domain Name Server (DNS), all the direct devices on the network, and bastion hosts used (if applicable) to access the devices.



NOTE: Bastion hosts utilize a SOCKS5 proxy server to reach target devices in the customer's network. Bastion hosts also support connection hopping, where an SSH session is first established with a customer's Linux-based device, which then initiates a subsequent SSH session to the target device.

- Enabled NETCONF in the Junos OS configuration of all target Juniper devices. The LWC uses SSH credentials to connect to the devices on the network and, if used, bastion hosts.

See also [Establish an SSH Connection for a NETCONF Session](#).

Before connecting the LWC to the external network, ensure that you have the following ready:

- A DHCP or static IP address.
- A DNS server in case you have selected a static address. In case of any subsequent change to the DNS, you must inform Juniper about it and get it updated. Otherwise, the LWC might lose connectivity to the external endpoints.

The LWC supports real static, private static, or DHCP addresses. It prefers Network Address Translation (NAT).

- Accessibility to the DNS and IP addresses specified in [Table 19 on page 52](#) through the IP addresses assigned to xe-0/0/13 on the LWC.



NOTE: The LWC establishes and must maintain a persistent HTTPS connection to Juniper Cloud. If the connection is lost, the LWC will disconnect and attempt to re-establish the connection.

Table 19: Outbound Connectivity Requirements

Description	DNS Name	IP Address	Port
Juniper Cloud	AWSPProxy-prod.jssprod.junipercloud.net	52.223.32.79, 35.71.174.221, 35.164.173.102, 52.26.8.178, 54.149.201.209	443

The subnet of the IP address assigned to the internal network port must be different from the subnet of the IP address assigned to the external network port. See [Table 20 on page 52](#).

Table 20: Static Interface Table Mapping

Network Type	LWC Interface	LWC Port Identification	IP Address	Subnet
Network access (internal)	xe-0/0/12	0	Internal Static 1	Subnet 1
Juniper cloud access (external)	xe-0/0/13	1	External Static 1	Subnet 2

Configure the Network Ports and Active Proxy


The Lightweight Collector (LWC) is preconfigured to support IPv4 and DHCP. However, if your deployment requires a static IP address and an active proxy to connect the LWC to the Internet, you must configure your LWC device manually, by using the LWC captive portal.

On the captive portal, you can configure the following elements:

- **External Network**—Connects the LWC to Juniper Cloud. The External Network configuration is also used to perform device provisioning.
- **Internal Networks**—Connects the LWC to the Juniper devices on the network.
- **Active Proxy**—Used if your network infrastructure controls access to the Internet through an active proxy. You can skip this element if you are not using an active proxy.

To configure the LWC:

1. Disconnect your computer from the Internet.
2. Connect the computer to the port ge-0/0/0 on the LWC (labeled as **1**) by using an Ethernet cable (RJ-45). The LWC assigns an IP address to the Ethernet interface of your computer through DHCP.



3. Open a browser on your computer and enter the following URL to the address bar: <https://cportal.lwc.jssdev.junipercloud.net/>.
The **JSI Data Collector** login page appears.



NOTE: On Captive Portal versions earlier than 1.0.43, if you are unable to configure an IP address via DHCP, you must manually assign an IP address to the connecting device and accept an unsecured connection. For more information, see <https://supportportal.juniper.net/KB70138>.

4. Enter the LWC serial number in the **Serial Number** field and then click **Submit** to log in.
On successful login, the **JSI Data Collector** page appears.

Figure 16: JSI Data Collector page when the LWC is not connected (releases earlier than version 1.0.43)

JSI Data Collector

Configure your Collector
Connection Status ⓘ Juniper Cloud Disconnected ⓘ Not Provisioned ⓘ

External Network ⓘ

IP Type

Source

IP Address (VM)

IP Address (LWC)

Subnet Mask

Gateway

DNS Server

EDIT

↻

Unsupported Value

Unsupported Value

Not configured

Connection Status ⓘ

✖ Gateway Disconnected

✖ DNS Disconnected

Active Proxy ⓘ

IP Address

Port

EDIT

↻

Internal Network ⓘ

IP Type

Source

IP Address

Subnet Mask

Gateway

DNS Server

EDIT

↻

Unsupported Value

Unsupported Value

Not configured

Connection Status ⓘ

✖ Gateway Disconnected

✖ DNS Disconnected

Instructions

Internal & External Networks

If any Connection Status (Internal or External) is red, click edit to modify the settings of that section until all Connection Status turns to green, at this point Juniper Cloud Connected Status will also be green and you may close this window and proceed with device onboarding.

Troubleshooting

Download the Light Request for Support Information (RSI) and Open a Tech Case in the Juniper Support Portal and attach the Light RSI file.

DOWNLOAD LIGHT RSI

File Format: .json*

In some cases, the Support Agent may request an Extensive RSI file. In such instances, you will need to re-enter the Captive Portal to download the Extensive RSI file here and upload to your Tech Case.

DOWNLOAD EXTENSIVE RSI

File Format: .json*

Reboot Collector ⓘ

Press the button below to reboot the Collector. Confirm by pressing the button a second time within 30 seconds.

REBOOT

Shutdown Collector ⓘ

Press the button below to shutdown the Collector. Confirm by pressing the button a second time within 30 seconds.

SHUTDOWN

Figure 17: JSI Data Collector page when the LWC is not connected (version 1.0.43 and later releases)

The screenshot shows the 'JSI Data Collector' configuration page. At the top, it says 'Configure your Collector' and 'Connection Status' with indicators for 'Juniper Cloud Disconnected' and 'Not Provisioned'. The 'External Network' section includes fields for IP Type, Source, IP Address (LWC SW), Subnet Mask, Gateway, and DNS Server, with an 'EDIT' button and a 'Refresh' icon. Below this is an 'Active Proxy' toggle set to 'Enable/Disable'. The 'Internal Network' section has 'IPv4 Settings' and 'IPv6 Settings' toggles, both set to 'Enable/Disable'. Each has fields for IP Type, Source, IP Address, Subnet Mask, Gateway, and DNS Server, with 'EDIT' buttons and 'Refresh' icons. Connection status boxes for both IPv4 and IPv6 show 'Gateway Disconnected' and 'DNS Disconnected'. On the right, there are 'Instructions', 'Troubleshooting' (with 'DOWNLOAD LIGHT RSI' and 'DOWNLOAD EXTENSIVE RSI' buttons), 'Reboot Collector', and 'Shutdown Collector' sections. The version '1.0.43' is noted at the bottom right.



NOTE: If the default DHCP configuration on the LWC is successful, the captive portal shows the LWC's connection status as connected, and populates the fields in all the configurations sections appropriately.

Click **Refresh** to refresh the current connection states.

5. In the **Configure your Collector** section, click the **Edit** button under the element that needs to be updated. For the field descriptions, refer to [Table 21 on page 58](#)

You need to update the fields in:

- The **Internal Network** and **External Network** sections if their connection states indicate that they are disconnected.



NOTE:

- The IP addresses assigned to internal and external interfaces must be from different subnets. This requirement applies to both DHCP and static configurations.

- The internal and external interfaces must each have unique DNS entries.

Ensure that these interfaces can reach their respective DNS servers over both UDP and TCP on port 53.

You must not use the same IP address or DNS entry for both interfaces.

- The **Active Proxy** section if you are using an active proxy. Active proxy uses SOCKS5 proxies to route connections to the target Juniper devices in the customer's network.



NOTE: If you choose to use an active proxy, ensure that it forwards all the traffic from the LWC to the AWS cloud proxy (see [Table 19 on page 52](#) for the AWS cloud proxy URL and ports). Juniper cloud services blocks all the inbound traffic coming through any path other than the AWS cloud proxy.



NOTE: If you choose to use an active proxy, ensure that the LWC's external interface IP configuration can reach the active proxy's URL or IP address.



NOTE: In version 1.0.43 and later releases, the **Active Proxy** section is collapsed by default if an active proxy is disabled or not configured. To configure, click **Enable/disable** to expand the **Active Proxy** section.

6. After updating the fields, click **Update** to apply the changes and return to the JSI Data Collector homepage.

If you want to discard your changes, click **Cancel**.

If the LWC connects to the gateway and DNS successfully, the respective configuration element (internal or external network section) on the JSI Data Collector homepage shows the connection status as **Gateway Connected** and **DNS Connected** with green tick marks against them.

The JSI Data Collector homepage shows the **Connection Status** as:

- **Juniper Cloud Connected** if the external connectivity to Juniper Cloud is established and active proxy (if applicable) settings are correctly configured.
- **Cloud Provisioned** if the device is connected to Juniper Cloud and has completed the Zero Touch Experience (ZTE) process. After the Cloud connection status becomes **Juniper Cloud Connected**, it takes about 10 minutes for the provision status to become **Cloud Provisioned**.



NOTE: Once the LWC is connected to Juniper Cloud and maintains a stable connection for over 24 hours, automatic upgrade will be enabled for the device.

Figure 18: JSI Data Collector page when the LWC is connected successfully (releases earlier than version 1.0.43)

JSI Data Collector

Configure your Collector Connection Status Juniper Cloud Connected Cloud Provisioned

External Network

IP Type

Source

IP Address (VM)

IP Address (LWC)

Subnet Mask

Gateway

DNS Server

EDIT **C**

Active Proxy

Hostname / IP Address

Port

CANCEL **UPDATE**

Internal Network

IP Type

Source

IP Address

Subnet Mask

Gateway

DNS Server

EDIT **C**

Connection Status

Gateway Connected

DNS Connected

Instructions

Internal & External Networks

If any Connection Status (Internal or External) is red, click edit to modify the settings of that section until all Connection Status turns to green, at this point Juniper Cloud Connected Status will also be green and you may close this window and proceed with device onboarding.

Troubleshooting

Download the Light Request for Support Information (RSI) and Open a Tech Case in the Juniper Support Portal and attach the Light RSI file.

DOWNLOAD LIGHT RSI

File Format: .json*

In some cases, the Support Agent may request an Extensive RSI file. In such instances, you will need to re-enter the Captive Portal to download the Extensive RSI file here and upload to your Tech Case.

DOWNLOAD EXTENSIVE RSI

File Format: .json*

Reboot Collector

Press the button below to reboot the Collector. Confirm by pressing the button a second time within 30 seconds.

REBOOT

Shutdown Collector

Press the button below to shutdown the Collector. Confirm by pressing the button a second time within 30 seconds.

SHUTDOWN

Figure 19: JSI Data Collector page when the LWC is connected successfully (version 1.0.43 and later releases)

The screenshot displays the 'JSI Data Collector' configuration interface. At the top, it shows 'Configure your Collector' and 'Connection Status' with green checkmarks for 'Juniper Cloud Connected' and 'Cloud Provisioned'. The 'External Network' section includes fields for IP Type (IPv4), Source (DHCP), IP Address (LWC SW), Subnet Mask, Gateway, and DNS Server, with a 'Connection Status' box indicating 'Gateway Connected' and 'DNS Connected'. Below this is an 'Active Proxy' toggle. The 'Internal Network' section has two columns: 'IPv4 Settings' (with a green 'Enable/Disable' toggle) and 'IPv6 Settings' (with a grey 'Enable/Disable' toggle). Both columns have fields for IP Type, Source, IP Address, Subnet Mask, Gateway, and DNS Server. The 'IPv4 Settings' 'Connection Status' box shows 'Gateway Connected' and 'DNS Connected', while the 'IPv6 Settings' box shows 'Gateway Disconnected' and 'DNS Disconnected'. On the right, there are sections for 'Instructions' (Internal & External Networks), 'Troubleshooting' (Download Light RSI, Download Extensive RSI), 'Reboot Collector', and 'Shutdown Collector'. The version '1.0.43' is noted at the bottom right.

If the LWC does not connect to the cloud, click **Download Light RSI** to download the light RSI file, create a Tech Case in the Juniper Support Portal, and attach the downloaded RSI file to the case.

In some cases, the Juniper support engineer might ask you to attach the Extensive RSI file to the case. To download it, click the **Download Extensive RSI**.

The Juniper support engineer might ask you to reboot the LWC for troubleshooting. To reboot the LWC, click **REBOOT**.

If you want to shut down the LWC, click **SHUTDOWN**.

Table 21: Fields in the Configure Your Collector section on the JSI Data Collector page

Field	Description
External Network	
IP Type	Select an IP address version: • IPv4 • IPv6

Table 21: Fields in the Configure Your Collector section on the JSI Data Collector page (*Continued*)

Field	Description
Source	Select an IP address assignment type. - DHCP—This option is enabled by default. - Static—If you select this option, you must enter the IP addresses manually.
IP Address (LWC)	Applicable only if you selected Static as Source. Enter the IP Address of the LWC device.
Subnet Mask	Applicable only if you selected Static as Source. Enter the subnet mask address. The subnet of the IP address assigned to the internal network port must be different from the subnet of the IP address assigned to the external network port. This applies to both DHCP and static configurations.
Gateway	Applicable only if you selected Static as Source. Enter the IP address of the default gateway connected to the LWC.
DNS Server	Enter the DNS server IP address.
Active Proxy	
IP Address	If you want to add an active proxy, enter the IP address of the proxy.
Port	Enter the port number used for the active proxy.
Internal Network	
IP Type	Select an IP address version: - IPv4 - IPv6

Table 21: Fields in the Configure Your Collector section on the JSI Data Collector page (*Continued*)

Field	Description
Source	Select an IP address assignment type. • DHCP—This option is enabled by default. • Static—If you select this, you must enter the IP addresses manually.
IP Address	Applicable only if you selected Static as Source. Enter the IP Address of the LWC device.
Subnet Mask	Applicable only if you selected Static as Source. Enter the subnet mask address. The subnet of the IP address assigned to the internal network port must be different from the subnet of the IP address assigned to the external network port. This applies to both DHCP and static configurations.
Gateway	Applicable only if you selected Static as Source. Enter the IP address of the default gateway connected to the LWC.
DNS Server	Enter the DNS server IP address.

4

PART

Maintaining Components

- Maintaining Transceivers on the LWC | 62
 - Maintaining Fiber Optic Cables on the LWC | 65
 - Remove an LWC Device from a Rack or Cabinet | 69
-

Maintaining Transceivers on the LWC

IN THIS SECTION

- [Install a Transceiver in an LWC Device | 62](#)
- [Remove a Transceiver from an LWC Device | 63](#)

Install a Transceiver in an LWC Device

Before you begin installing a transceiver in an LWC device,

- Ensure that you have taken the necessary precautions for safe handling of lasers (see ["Laser and LED Safety Guidelines and Warnings for the LWC Devices" on page 84](#)).
- Ensure that you have a rubber safety cap available to cover the transceiver.

The transceivers for the LWC devices are hot-removable and hot-insertable field-replaceable units (FRUs). You can remove and replace them without powering off the device or disrupting device functions.

To install a transceiver in an LWC device:



CAUTION: To avoid electrostatic discharge (ESD) damage to the transceiver, do not touch the connector pins at the end of the transceiver.

1. Remove the transceiver from its bag.
2. Check to see whether the transceiver is covered by a rubber safety cap. If it is not, cover the transceiver with a rubber safety cap.



LASER WARNING: Do not leave a fiber-optic transceiver uncovered except when inserting or removing a cable. The rubber safety cap keeps the port clean and prevents accidental exposure to laser light.

3. If the port in which you want to install the transceiver is covered with a dust cover, remove the dust cover and save it in case you need to cover the port later.

4. Using both hands, carefully place the transceiver in the empty port. The connectors must face the device chassis.




CAUTION: Before you slide the transceiver into the port, ensure that the transceiver is aligned correctly. Misalignment might cause the pins to bend, making the transceiver unusable. See [Figure 20 on page 63](#) for the correct orientation for your device.

5. Slide the transceiver in gently until it is fully seated. See [Figure 20 on page 63](#) for an example of inserting an SFP or SFP+ transceiver.
6. Remove the rubber safety cap when you are ready to connect the cable to the transceiver.



LASER WARNING: Do not look directly into a fiber-optic transceiver or into the ends of fiber-optic cables. Fiber-optic transceivers and fiber-optic cables connected to transceivers emit laser light that can damage your eyes.

Figure 20: Install a Transceiver in an LWC Device



Remove a Transceiver from an LWC Device

Before you begin removing a transceiver from the LWC device, ensure that you have taken the necessary precautions for safe handling of lasers (see ["Laser and LED Safety Guidelines and Warnings for the LWC Devices" on page 84](#)).

Ensure that you have the following parts and tools available:

- Electrostatic bag or an antistatic mat
- Rubber safety caps to cover the transceiver and fiber-optic cable connector
- Dust cover to cover the port

The transceivers for the LWC devices are hot-removable and hot-insertable field-replaceable units (FRUs). You can remove and replace them without powering off the device or disrupting device functions.

To remove a transceiver from the LWC device:

1. Place the antistatic bag or antistatic mat on a flat, stable surface.
2. Label the cable connected to the transceiver so that you can reconnect it correctly.



LASER WARNING: Do not look directly into a fiber-optic transceiver or into the ends of fiber-optic cables. Fiber-optic transceivers and fiber-optic cables connected to transceivers emit laser light that can damage your eyes.



LASER WARNING: Do not leave a fiber-optic transceiver uncovered except when inserting or removing a cable. The rubber safety cap keeps the port clean and prevents accidental exposure to laser light.



CAUTION: Do not bend fiber-optic cables beyond their minimum bend radius. Bending the cables beyond their minimum bend radius can damage the cables and cause problems that are difficult to diagnose.

3. Remove the cable connected to the transceiver (see ["Disconnect a Fiber-Optic Cable from an LWC Device" on page 67](#)). Cover the transceiver and the end of each fiber-optic cable connector with a rubber safety cap immediately after disconnecting the fiber-optic cables.
4. Using your fingers, pull the ejector lever away from the transceiver to unlock the transceiver.



CAUTION: Before removing the transceiver, make sure you open the ejector lever completely until you hear it click. This prevents damage to the transceiver.


5. Grasp the transceiver ejector lever and gently slide the transceiver approximately 0.5 in. (1.3 cm) straight out of the port (see [Figure 21 on page 65](#)).



CAUTION: To avoid electrostatic discharge (ESD) damage to the transceiver, do not touch the connector pins at the end of the transceiver.

6. Using your fingers, grasp the body of the transceiver and pull it straight out of the port.
7. Place the transceiver in the electrostatic bag or on the antistatic mat placed on a flat, stable surface.
8. Place the dust cover over the empty port.

Figure 21: Remove a Transceiver from an LWC Device



Maintaining Fiber Optic Cables on the LWC

IN THIS SECTION

- [Connect a Fiber-Optic Cable to an LWC Device | 66](#)
- [Disconnect a Fiber-Optic Cable from an LWC Device | 67](#)
- [Maintaining Fiber-Optic Cables in an LWC Device | 68](#)

Connect a Fiber-Optic Cable to an LWC Device

Before you connect a fiber-optic cable to an optical transceiver installed in an LWC device, ensure that you have taken the necessary precautions for safe handling of lasers (see "[Laser and LED Safety Guidelines and Warnings for the LWC Devices](#)" on page 84).

You can connect fiber-optic cables to the field-replaceable unit (FRU) optical transceivers installed in LWC devices.



LASER WARNING: Do not look directly into a fiber-optic transceiver or into the ends of fiber-optic cables. Fiber-optic transceivers and fiber-optic cables connected to transceivers emit laser light that can damage your eyes.



LASER WARNING: Do not stare into the laser beam or view it directly with optical instruments even if the interface has been disabled.

To connect a fiber-optic cable to an optical transceiver installed in an LWC device:

1. If the fiber-optic cable connector is covered by a rubber safety cap, remove the cap. Save the cap.
2. If the optical transceiver is covered by a rubber safety cap, remove the cap. Save the cap.
3. Insert the cable connector into the optical transceiver (see [Figure 22 on page 67](#)).
4. Secure the cables so that they are not supporting their own weight. Place excess cable out of the way in a neatly coiled loop. Placing fasteners on a loop helps cables maintain their shape.




CAUTION: Do not bend fiber-optic cables beyond their minimum bend radius. Bending the cables beyond their minimum bend radius can damage the cables and cause problems that are difficult to diagnose.



CAUTION: Do not let fiber-optic cables hang free from the connector. Do not allow fastened loops of cables to dangle, which stresses the cables at the fastening point.

Figure 22: Insert a Fiber-Optic Cable into a Transceiver



Disconnect a Fiber-Optic Cable from an LWC Device

Before you disconnect a fiber-optic cable from an optical transceiver installed in an LWC device, ensure that you have taken the necessary precautions for safe handling of lasers (see "[Laser and LED Safety Guidelines and Warnings for the LWC Devices](#)" on page 84).

Ensure that you have the following parts and tools available:

- Rubber safety cap to cover the transceiver
- Rubber safety cap to cover the fiber-optic cable connector

To disconnect a fiber-optic cable from an optical transceiver installed in the LWC device:

1. (Recommended) Disable the port in which the transceiver is installed by including the disable statement at the [edit interfaces] hierarchy level for the specific interface.



LASER WARNING: Do not look directly into a fiber-optic transceiver or into the ends of fiber-optic cables. Fiber-optic transceivers and fiber-optic cables connected to transceivers emit laser light that can damage your eyes.



LASER WARNING: Do not stare into the laser beam or view it directly with optical instruments even if the interface has been disabled.

2. Carefully unplug the fiber-optic cable connector from the transceiver.

3. Cover the transceiver with a rubber safety cap.



LASER WARNING: Do not leave a fiber-optic transceiver uncovered except when inserting or removing a cable. The rubber safety cap keeps the port clean and prevents accidental exposure to laser light.

4. Cover the fiber-optic cable connector with the rubber safety cap.

Maintaining Fiber-Optic Cables in an LWC Device

To maintain fiber-optic cables in LWC devices:

- When you unplug a fiber-optic cable from a transceiver, place rubber safety caps over the transceiver and on the end of the cable.
- Anchor fiber-optic cable to avoid stress on the connectors. When attaching a fiber-optic cable to a transceiver, be sure to secure the fiber-optic cable so that it is not supporting its own weight as it hangs to the floor. Never let a fiber-optic cable hang free from the connector.
- Do not bend fiber-optic cables beyond their minimum bend radius. Bending the cables beyond their minimum bend radius can damage the cables and cause problems that are difficult to diagnose.
- Frequent plugging and unplugging of fiber-optic cables in and out of optical instruments can damage the instruments, which are expensive to repair. Attach a short fiber extension to the optical equipment. Any wear and tear due to frequent plugging and unplugging is then absorbed by the short fiber extension, which is easier and less expensive to replace than the instruments.
- Keep fiber-optic cable connections clean. Microdeposits of oil and dust in the canal of the transceiver or cable connector can cause loss of light, reduction in signal power, and possibly intermittent problems with the optical connection.

To clean the transceiver canal, use an appropriate fiber-cleaning device such as RIFOCS Fiber Optic Adaptor Cleaning Wands (part number 946). Follow the directions in the cleaning kit you use.

After cleaning the transceiver, make sure that the connector tip of the fiber-optic cable is clean. Use only an approved alcohol-free fiber-optic cable cleaning kit such as the Cletop-S® Fiber Cleaner. Follow the directions in the cleaning kit you use.

Remove an LWC Device from a Rack or Cabinet

Before removing the device from a rack:

Ensure that you have the following parts and tools available to remove the device:

- A Phillips (+) screwdriver, number 2 or number 3, depending on the size of your rack mounting screws.
- A labeled bag to hold the removed screws.

If you need to relocate an installed LWC device, use the procedure described in this topic. (The remainder of this topic uses *rack* to mean *rack or cabinet*.)



NOTE: When you remove multiple devices from a rack, remove the device at the top of the rack first and proceed to remove the rest of the devices from top to bottom.



CAUTION: At least two people must be available to lift a device chassis out of a rack—one person to unscrew the mounting screws from the brackets and the second person to hold the chassis.

- Ensure that the rack or cabinet is stable and secured to the building.
- Ensure that there is enough space to place the removed device in its new location and along the path to the new location.
- Read ["General Safety Guidelines and Warnings" on page 71](#), with particular attention to ["Chassis Lifting Guidelines for LWC Devices" on page 78](#).
- Ensure that the device has been safely powered off and that you have unplugged (disconnected) the power cords.
- Ensure that you have disconnected any cables or wires attached to the device.

To remove an LWC device from two posts in a rack:

1. Use the appropriate Phillips (+) screwdriver to remove the mounting screws that attach the chassis front-mounting brackets to the rack.
2. Place the removed screws in a labeled bag. You will need them when you reinstall the chassis.
3. Lift the chassis from the rack and carefully move the chassis to its new location.

5

PART

Safety Information

- General Safety Guidelines and Warnings | 71
 - Environmental Requirements and Specifications for an LWC Device | 72
 - Definitions of Safety Warning Levels | 73
 - Qualified Personnel Warning | 75
 - Warning Statement for Norway and Sweden | 75
 - Fire Safety Requirements | 76
 - Installation Instructions Warning | 77
 - Chassis Lifting Guidelines for LWC Devices | 78
 - Restricted Access Warning | 78
 - Ramp Warning | 79
 - Rack-Mounting and Cabinet-Mounting Warnings | 80
 - Laser and LED Safety Guidelines and Warnings for the LWC Devices | 84
 - Radiation from Open Port Apertures Warning | 89
 - Maintenance and Operational Safety Guidelines and Warnings | 90
 - General Electrical Safety Guidelines and Warnings | 96
 - Action to Take After an Electrical Accident | 97
 - Prevention of Electrostatic Discharge Damage | 98
 - AC Power Electrical Safety Guidelines | 99
 - AC Power Disconnection Warning | 100
 - TN Power Warning | 101
-

General Safety Guidelines and Warnings

The following guidelines help ensure your safety and protect the device from damage. The list of guidelines might not address all potentially hazardous situations in your working environment, so be alert and exercise good judgment at all times.

- Perform only the procedures explicitly described in the hardware documentation for this device. Make sure that only authorized service personnel perform other system services.
- Keep the area around the device clear and free from dust before, during, and after installation.
- Keep tools away from areas where people could trip over them while walking.
- Do not wear loose clothing or jewelry, such as rings, bracelets, or chains, which could become caught in the device.
- Wear safety glasses if you are working under any conditions that could be hazardous to your eyes.
- Do not perform any actions that create a potential hazard to people or make the equipment unsafe.
- Never attempt to lift an object that is too heavy for one person to handle.
- Never install or manipulate wiring during electrical storms.
- Never install electrical jacks in wet locations unless the jacks are specifically designed for wet environments.
- Operate the device only when it is properly grounded.
- Follow the instructions in this guide to properly ground the device to earth.
- Replace fuses only with fuses of the same type and rating.
- Do not open or remove chassis covers or sheet-metal parts unless instructions are provided in the hardware documentation for this device. Such an action could cause severe electrical shock.
- Do not push or force any objects through any opening in the chassis frame. Such an action could result in electrical shock or fire.
- Avoid spilling liquid onto the chassis or onto any device component. Such an action could cause electrical shock or damage the device.
- Avoid touching uninsulated electrical wires or terminals that have not been disconnected from their power source. Such an action could cause electrical shock.

- Some parts of the chassis, including AC and DC power supply surfaces, power supply unit handles, SFB card handles, and fan tray handles might become hot. The following label provides the warning for hot surfaces on the chassis:



- Always ensure that all modules, power supplies, and cover panels are fully inserted and that the installation screws are fully tightened.

Environmental Requirements and Specifications for an LWC Device

The device must be installed in a rack or cabinet. It must be housed in a dry, clean, well-ventilated, and temperature-controlled environment.

Follow these environmental guidelines:

- The site must be as dust-free as possible, because dust can clog air intake vents and filters, reducing the efficiency of the device cooling system.
- Maintain ambient airflow for normal operation of the device. If the airflow is blocked or restricted, or if the intake air is too warm, the device might overheat, leading to the device temperature monitor shutting down the device to protect the hardware components.

[Table 22 on page 72](#) provides the required environmental conditions for normal operation of the device.

Table 22: LWC Environmental Tolerances

Description	Tolerance
Altitude	No performance degradation up to 6000 feet (1828 meters) at 86° F (30° C)
Relative humidity	Normal operation ensured in relative humidity range of 5% through 90%, noncondensing

Table 22: LWC Environmental Tolerances (*Continued*)

Description	Tolerance
Temperature	Normal operation ensured in temperature range of 32° F through 122° F (0° C through 50° C)
Seismic	Complies with Zone 4 earthquake requirements as per GR-63, Issue 4

Definitions of Safety Warning Levels

The documentation uses the following levels of safety warnings (there are two *Warning* formats):



NOTE: You might find this information helpful in a particular situation, or you might overlook this important information if it was not highlighted in a Note.



CAUTION: You need to observe the specified guidelines to prevent minor injury or discomfort to you or severe damage to the device.

Attention Veillez à respecter les consignes indiquées pour éviter toute incommodité ou blessure légère, voire des dégâts graves pour l'appareil.



LASER WARNING: This symbol alerts you to the risk of personal injury from a laser.

Avertissement Ce symbole signale un risque de blessure provoquée par rayon laser.



WARNING: This symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry, and familiarize yourself with standard practices for preventing accidents.

Waarschuwing Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van standaard maatregelen om ongelukken te voorkomen.

Varoitus Tämä varoitusmerkki merkitsee vaaraa. Olet tilanteessa, joka voi johtaa ruumiinvammaan. Ennen kuin työskentelet minkään laitteiston parissa, ota selvää sähkökytkentöihin liittyvistä vaaroista ja tavanomaisista onnettomuuksien ehkäisykeinoista.

Avertissement Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant causer des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers posés par les circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents.

Warnung Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu einer Körperverletzung führen könnte. Bevor Sie mit der Arbeit an irgendeinem Gerät beginnen, seien Sie sich der mit elektrischen Stromkreisen verbundenen Gefahren und der Standardpraktiken zur Vermeidung von Unfällen bewußt.

Avvertenza Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di lavorare su qualsiasi apparecchiatura, occorre conoscere i pericoli relativi ai circuiti elettrici ed essere al corrente delle pratiche standard per la prevenzione di incidenti.

Advarsel Dette varselsymbolet betyr fare. Du befinner deg i en situasjon som kan føre til personskade. Før du utfører arbeid på utstyr, må du være oppmerksom på de faremomentene som elektriske kretser innebærer, samt gjøre deg kjent med vanlig praksis når det gjelder å unngå ulykker.

Aviso Este símbolo de aviso indica perigo. Encontra-se numa situação que lhe poderá causar danos físicos. Antes de começar a trabalhar com qualquer equipamento, familiarize-se com os perigos relacionados com circuitos eléctricos, e com quaisquer práticas comuns que possam prevenir possíveis acidentes.

¡Atención! Este símbolo de aviso significa peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considerar los riesgos que entraña la corriente eléctrica y familiarizarse con los procedimientos estándar de prevención de accidentes.

Warning! Denna varningssymbol signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanligt förfarande för att förebygga skador.

Qualified Personnel Warning



WARNING: Only trained and qualified personnel should install or replace the device.

Waarschuwing Installatie en reparaties mogen uitsluitend door getraind en bevoegd personeel uitgevoerd worden.

Varoitus Ainoastaan koulutettu ja pätevä henkilökunta saa asentaa tai vaihtaa tämän laitteen.

Avertissement Tout installation ou remplacement de l'appareil doit être réalisé par du personnel qualifié et compétent.

Warnung Gerät nur von geschultem, qualifiziertem Personal installieren oder auswechseln lassen.

Avvertenza Solo personale addestrato e qualificato deve essere autorizzato ad installare o sostituire questo apparecchio.

Advarsel Kun kvalifisert personell med riktig opplæring bør montere eller bytte ut dette utstyret.

Aviso Este equipamento deverá ser instalado ou substituído apenas por pessoal devidamente treinado e qualificado.

¡Atención! Estos equipos deben ser instalados y reemplazados exclusivamente por personal técnico adecuadamente preparado y capacitado.

Varning! Denna utrustning ska endast installeras och bytas ut av utbildad och kvalificerad personal.

Warning Statement for Norway and Sweden



WARNING: The equipment must be connected to an earthed mains socket-outlet.

Advarsel Apparatet skal kobles til en jordet stikkontakt.

Varning! Apparaten skall anslutas till jordat nätuttag.

Fire Safety Requirements

IN THIS SECTION

- [Fire Suppression | 76](#)
- [Fire Suppression Equipment | 76](#)

In the event of a fire emergency, the safety of people is the primary concern. You should establish procedures for protecting people in the event of a fire emergency, provide safety training, and properly provision fire-control equipment and fire extinguishers.

In addition, you should establish procedures to protect your equipment in the event of a fire emergency. Juniper Networks products should be installed in an environment suitable for electronic equipment. We recommend that fire suppression equipment be available in the event of a fire in the vicinity of the equipment and that all local fire, safety, and electrical codes and ordinances be observed when you install and operate your equipment.

Fire Suppression

In the event of an electrical hazard or an electrical fire, you should first turn power off to the equipment at the source. Then use a Type C fire extinguisher, which uses noncorrosive fire retardants, to extinguish the fire.

Fire Suppression Equipment

Type C fire extinguishers, which use noncorrosive fire retardants such as carbon dioxide and Halotron™, are most effective for suppressing electrical fires. Type C fire extinguishers displace oxygen from the point of combustion to eliminate the fire. For extinguishing fire on or around equipment that draws air from the environment for cooling, you should use this type of inert oxygen displacement extinguisher instead of an extinguisher that leaves residues on equipment.

Do not use multipurpose Type ABC chemical fire extinguishers (dry chemical fire extinguishers). The primary ingredient in these fire extinguishers is monoammonium phosphate, which is very sticky and

difficult to clean. In addition, in the presence of minute amounts of moisture, monoammonium phosphate can become highly corrosive and corrodes most metals.

Any equipment in a room in which a chemical fire extinguisher has been discharged is subject to premature failure and unreliable operation. The equipment is considered to be irreparably damaged.



NOTE: To keep warranties effective, do not use a dry chemical fire extinguisher to control a fire at or near a Juniper Networks device. If a dry chemical fire extinguisher is used, the unit is no longer eligible for coverage under a service agreement.

We recommend that you dispose of any irreparably damaged equipment in an environmentally responsible manner.

Installation Instructions Warning



WARNING: Read the installation instructions before you connect the device to a power source.

Waarschuwing Raadpleeg de installatie-aanwijzingen voordat u het systeem met de voeding verbindt.

Varoituis Lue asennusohjeet ennen järjestelmän yhdistämistä virtalähteeseen.

Avertissement Avant de brancher le système sur la source d'alimentation, consulter les directives d'installation.

Warnung Lesen Sie die Installationsanweisungen, bevor Sie das System an die Stromquelle anschließen.

Avvertenza Consultare le istruzioni di installazione prima di collegare il sistema all'alimentatore.

Advarsel Les installasjonsinstruksjonene før systemet kobles til strømkilden.

Aviso Leia as instruções de instalação antes de ligar o sistema à sua fonte de energia.

¡Atención! Ver las instrucciones de instalación antes de conectar el sistema a la red de alimentación.

Varning! Läs installationsanvisningarna innan du kopplar systemet till dess strömförsörjningsenhet.

Chassis Lifting Guidelines for LWC Devices

The weight of an LWC device is 9.48 lb (4.3 kg). Observe the following guidelines for lifting and moving an LWC device:

- Before installing the device, verify that the intended site meets the specified power, environmental, and clearance requirements.
- Before lifting or moving the switch, disconnect all external cables.

Restricted Access Warning



WARNING: This unit is intended for installation in restricted access areas. A restricted access area is an area to which access can be gained only by service personnel through the use of a special tool, lock and key, or other means of security, and which is controlled by the authority responsible for the location.

Waarschuwing Dit toestel is bedoeld voor installatie op plaatsen met beperkte toegang. Een plaats met beperkte toegang is een plaats waar toegang slechts door servicepersoneel verkregen kan worden door middel van een speciaal instrument, een slot en sleutel, of een ander veiligheidsmiddel, en welke beheerd wordt door de overheidsinstantie die verantwoordelijk is voor de locatie.

Varoitus Tämä laite on tarkoitettu asennettavaksi paikkaan, johon pääsy on rajoitettua. Paikka, johon pääsy on rajoitettua, tarkoittaa paikkaa, johon vain huoltohenkilöstö pääsee jonkin erikoistyökalun, lukkoon sopivan avaimen tai jonkin muun turvalaitteen avulla ja joka on paikasta vastuussa olevien toimivaltaisten henkilöiden valvoma.

Avertissement Cet appareil est à installer dans des zones d'accès réservé. Ces dernières sont des zones auxquelles seul le personnel de service peut accéder en utilisant un outil spécial, un mécanisme de verrouillage et une clé, ou tout autre moyen de sécurité. L'accès aux zones de sécurité est sous le contrôle de l'autorité responsable de l'emplacement.

Warnung Diese Einheit ist zur Installation in Bereichen mit beschränktem Zutritt vorgesehen. Ein Bereich mit beschränktem Zutritt ist ein Bereich, zu dem nur Wartungspersonal mit einem Spezialwerkzeugs, Schloß und Schlüssel oder anderer

Sicherheitsvorkehrungen Zugang hat, und der von dem für die Anlage zuständigen Gremium kontrolliert wird.

Avvertenza Questa unità deve essere installata in un'area ad accesso limitato. Un'area ad accesso limitato è un'area accessibile solo a personale di assistenza tramite un'attrezzo speciale, lucchetto, o altri dispositivi di sicurezza, ed è controllata dall'autorità responsabile della zona.

Advarsel Denne enheten er laget for installasjon i områder med begrenset adgang. Et område med begrenset adgang gir kun adgang til servicepersonale som bruker et spesielt verktøy, lås og nøkkel, eller en annen sikkerhetsanordning, og det kontrolleres av den autoriteten som er ansvarlig for området.

Aviso Esta unidade foi concebida para instalação em áreas de acesso restrito. Uma área de acesso restrito é uma área à qual apenas tem acesso o pessoal de serviço autorizado, que possua uma ferramenta, chave e fechadura especial, ou qualquer outra forma de segurança. Esta área é controlada pela autoridade responsável pelo local.

¡Atención! Esta unidad ha sido diseñada para instalarse en áreas de acceso restringido. Área de acceso restringido significa un área a la que solamente tiene acceso el personal de servicio mediante la utilización de una herramienta especial, cerradura con llave, o algún otro medio de seguridad, y que está bajo el control de la autoridad responsable del local.

Warning! Denna enhet är avsedd för installation i områden med begränsat tillträde. Ett område med begränsat tillträde får endast tillträdas av servicepersonal med ett speciellt verktyg, lås och nyckel, eller annan säkerhetsanordning, och kontrolleras av den auktoritet som ansvarar för området.

Ramp Warning



WARNING: When installing the device, do not use a ramp inclined at more than 10 degrees.

Waarschuwing Gebruik een oprijplaat niet onder een hoek van meer dan 10 graden.

Varoitus Älä käyttää sellaista kaltevaa pintaa, jonka kaltevuus ylittää 10 astetta.

Avertissement Ne pas utiliser une rampe dont l'inclinaison est supérieure à 10 degrés.

Warnung Keine Rampen mit einer Neigung von mehr als 10 Grad verwenden.

Avvertenza Non usare una rampa con pendenza superiore a 10 gradi.

Advarsel Bruk aldri en rampe som heller mer enn 10 grader.

Aviso Não utilize uma rampa com uma inclinação superior a 10 graus.

¡Atención! No usar una rampa inclinada más de 10 grados.

Varning! Använd inte ramp med en lutning på mer än 10 grader.

Rack-Mounting and Cabinet-Mounting Warnings

Ensure that the rack or cabinet in which the device is installed is evenly and securely supported. Uneven mechanical loading could lead to a hazardous condition.



WARNING: To prevent bodily injury when mounting or servicing the device in a rack, take the following precautions to ensure that the system remains stable. The following directives help maintain your safety:

- Install the device in a rack that is secured to the building structure.
- Mount the device at the bottom of the rack if it is the only unit in the rack.
- When mounting the device on a partially filled rack, load the rack from the bottom to the top, with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing equipment, install the stabilizers before mounting or servicing the device in the rack.

Waarschuwing Om lichamelijk letsel te voorkomen wanneer u dit toestel in een rek monteert of het daar een servicebeurt geeft, moet u speciale voorzorgsmaatregelen nemen om ervoor te zorgen dat het toestel stabiel blijft. De onderstaande richtlijnen worden verstrekt om uw veiligheid te verzekeren:

- De Juniper Networks switch moet in een stellage worden geïnstalleerd die aan een bouwsel is verankerd.

- Dit toestel dient onderaan in het rek gemonteerd te worden als het toestel het enige in het rek is.
- Wanneer u dit toestel in een gedeeltelijk gevuld rek monteert, dient u het rek van onderen naar boven te laden met het zwaarste onderdeel onderaan in het rek.
- Als het rek voorzien is van stabiliseringshulpmiddelen, dient u de stabilisatoren te monteren voordat u het toestel in het rek monteert of het daar een servicebeurt geeft.

Varoitus Kun laite asetetaan telineeseen tai huolletaan sen ollessa telineessä, on noudatettava erityisiä varotoimia järjestelmän vakavuuden säilyttämiseksi, jotta vältetään loukkaantumisia. Noudata seuraavia turvallisuusohjeita:

- Juniper Networks switch on asennettava telineeseen, joka on kiinnitetty rakennukseen.
- Jos telineessä ei ole muita laitteita, aseta laite telineen alaosaan.
- Jos laite asetetaan osaksi täytettyyn telineeseen, aloita kuormittaminen sen alaosaan kaikkein raskaimmalla esineellä ja siirry sitten sen yläosaan.
- Jos telinettä varten on vakaimet, asenna ne ennen laitteen asettamista telineeseen tai sen huoltamista siinä.

Avertissement Pour éviter toute blessure corporelle pendant les opérations de montage ou de réparation de cette unité en casier, il convient de prendre des précautions spéciales afin de maintenir la stabilité du système. Les directives ci-dessous sont destinées à assurer la protection du personnel:

- Le rack sur lequel est monté le Juniper Networks switch doit être fixé à la structure du bâtiment.
- Si cette unité constitue la seule unité montée en casier, elle doit être placée dans le bas.
- Si cette unité est montée dans un casier partiellement rempli, charger le casier de bas en haut en plaçant l'élément le plus lourd dans le bas.
- Si le casier est équipé de dispositifs stabilisateurs, installer les stabilisateurs avant de monter ou de réparer l'unité en casier.

Warnung Zur Vermeidung von Körperverletzung beim Anbringen oder Warten dieser Einheit in einem Gestell müssen Sie besondere Vorkehrungen treffen, um sicherzustellen,

daß das System stabil bleibt. Die folgenden Richtlinien sollen zur Gewährleistung Ihrer Sicherheit dienen:

- Der Juniper Networks switch muß in einem Gestell installiert werden, das in der Gebäudestruktur verankert ist.
- Wenn diese Einheit die einzige im Gestell ist, sollte sie unten im Gestell angebracht werden.
- Bei Anbringung dieser Einheit in einem zum Teil gefüllten Gestell ist das Gestell von unten nach oben zu laden, wobei das schwerste Bauteil unten im Gestell anzubringen ist.
- Wird das Gestell mit Stabilisierungszubehör geliefert, sind zuerst die Stabilisatoren zu installieren, bevor Sie die Einheit im Gestell anbringen oder sie warten.

Avvertenza Per evitare infortuni fisici durante il montaggio o la manutenzione di questa unità in un supporto, occorre osservare speciali precauzioni per garantire che il sistema rimanga stabile. Le seguenti direttive vengono fornite per garantire la sicurezza personale:

- Il Juniper Networks switch deve essere installato in un telaio, il quale deve essere fissato alla struttura dell'edificio.
- Questa unità deve venire montata sul fondo del supporto, se si tratta dell'unica unità da montare nel supporto.
- Quando questa unità viene montata in un supporto parzialmente pieno, caricare il supporto dal basso all'alto, con il componente più pesante sistemato sul fondo del supporto.
- Se il supporto è dotato di dispositivi stabilizzanti, installare tali dispositivi prima di montare o di procedere alla manutenzione dell'unità nel supporto.

Advarsel Unngå fysiske skader under montering eller reparasjonsarbeid på denne enheten når den befinner seg i et kabinett. Vær nøye med at systemet er stabilt. Følgende retningslinjer er gitt for å verne om sikkerheten:

- Juniper Networks switch må installeres i et stativ som er forankret til bygningsstrukturen.
- Denne enheten bør monteres nederst i kabinettet hvis dette er den eneste enheten i kabinettet.

- Ved montering av denne enheten i et kabinett som er delvis fylt, skal kabinettet lastes fra bunnen og opp med den tyngste komponenten nederst i kabinettet.
- Hvis kabinettet er utstyrt med stabiliseringsutstyr, skal stabilisatorene installeres før montering eller utføring av reparasjonsarbeid på enheten i kabinettet.

Aviso Para se prevenir contra danos corporais ao montar ou reparar esta unidade numa estante, deverá tomar precauções especiais para se certificar de que o sistema possui um suporte estável. As seguintes directrizes ajudá-lo-ão a efectuar o seu trabalho com segurança:

- O Juniper Networks switch deverá ser instalado numa prateleira fixa à estrutura do edifício.
- Esta unidade deverá ser montada na parte inferior da estante, caso seja esta a única unidade a ser montada.
- Ao montar esta unidade numa estante parcialmente ocupada, coloque os itens mais pesados na parte inferior da estante, arrumando-os de baixo para cima.
- Se a estante possuir um dispositivo de estabilização, instale-o antes de montar ou reparar a unidade.

¡Atención! Para evitar lesiones durante el montaje de este equipo sobre un bastidor, oerriormente durante su mantenimiento, se debe poner mucho cuidado en que el sistema quede bien estable. Para garantizar su seguridad, proceda según las siguientes instrucciones:

- El Juniper Networks switch debe instalarse en un bastidor fijado a la estructura del edificio.
- Colocar el equipo en la parte inferior del bastidor, cuando sea la única unidad en el mismo.
- Cuando este equipo se vaya a instalar en un bastidor parcialmente ocupado, comenzar la instalación desde la parte inferior hacia la superior colocando el equipo más pesado en la parte inferior.
- Si el bastidor dispone de dispositivos estabilizadores, instalar éstos antes de montar o proceder al mantenimiento del equipo instalado en el bastidor.

Varning! För att undvika kroppsskada när du installerar eller utför underhållsarbete på denna enhet på en ställning måste du vidta särskilda försiktighetsåtgärder för att försäkra dig om att systemet står stadigt. Följande riktlinjer ges för att trygga din säkerhet:

- Juniper Networks switch måste installeras i en ställning som är förankrad i byggnadens struktur.
- Om denna enhet är den enda enheten på ställningen skall den installeras längst ned på ställningen.
- Om denna enhet installeras på en delvis fylld ställning skall ställningen fyllas nedifrån och upp, med de tyngsta enheterna längst ned på ställningen.
- Om ställningen är försedd med stabiliseringsdon skall dessa monteras fast innan enheten installeras eller underhålls på ställningen.

Laser and LED Safety Guidelines and Warnings for the LWC Devices

IN THIS SECTION

- [General Laser Safety Guidelines | 85](#)
- [Class 1M Laser Product Warning | 85](#)
- [Class 1M Laser Radiation Warning | 86](#)
- [Class 1 Laser Product Warning | 86](#)
- [Class 1 LED Product Warning | 86](#)
- [Laser Beam Warning | 87](#)
- [Unterminated Fiber-Optic Cable Warning | 88](#)

LWC devices are equipped with laser transmitters:

- SFP and SFP+ transceivers are classified as Class 1 Laser Products (complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice 50, dated July 26, 2001) or Class 1 LED Products.

Observe the following guidelines and warnings:

General Laser Safety Guidelines

When working around ports that support optical transceivers, observe the following safety guidelines to prevent eye injury:

- Do not look into unterminated ports or at fibers that connect to unknown sources.
- Do not examine unterminated optical ports with optical instruments.
- Avoid direct exposure to the beam.



LASER WARNING: Unterminated optical connectors can emit invisible laser radiation. The lens in the human eye focuses all the laser power on the retina, so focusing the eye directly on a laser source—even a low-power laser—could permanently damage the eye.

Class 1M Laser Product Warning



LASER WARNING: Class 1M laser product.

Waarschuwing Laserproducten van Klasse 1M (IEC).

Varoitus Luokan 1M (IEC) lasertuotteita.

Attention Produits laser catégorie 1M (IEC).

Warnung Laserprodukte der Klasse 1M (IEC).

Avvertenza Prodotti laser di Classe 1M (IEC).

Advarsel Klasse 1M (IEC) laserprodukter.

Aviso Produtos laser Classe 1M (IEC).

¡Atención! Productos láser de Clase 1M (IEC).

Varning! Laserprodukter av Klass 1M (IEC).

Class 1M Laser Radiation Warning



LASER WARNING: Class 1M laser radiation when open. Do not view directly with optical instruments.

Class 1 Laser Product Warning



LASER WARNING: Class 1 laser product.

Waarschuwing Klasse-1 laser produkt.

Varoitus Luokan 1 lasertuote.

Attention Produit laser de classe I.

Warnung Laserprodukt der Klasse 1.

Avvertenza Prodotto laser di Classe 1.

Advarsel Laserprodukt av klasse 1.

Aviso Produto laser de classe 1.

¡Atención! Producto láser Clase I.

Varning! Laserprodukt av klass 1.

Class 1 LED Product Warning



LASER WARNING: Class 1 LED product.

Waarschuwing Klasse 1 LED-product.

Varoitus Luokan 1 valodiodituote.

Attention Alarme de produit LED Class I.

Warnung Class 1 LED-Produktwarnung.

Avvertenza Avvertenza prodotto LED di Classe 1.

Advarsel LED-produkt i klasse 1.

Aviso Produto de classe 1 com LED.

¡Atención! Aviso sobre producto LED de Clase 1.

Varning! Lysdiodprodukt av klass 1.

Laser Beam Warning



LASER WARNING: Do not stare into the laser beam or view it directly with optical instruments.

Waarschuwing Niet in de straal staren of hem rechtstreeks bekijken met optische instrumenten.

Varoitus Älä katso säteeseen äläkä tarkastele sitä suoraan optisen laitteen avulla.

Attention Ne pas fixer le faisceau des yeux, ni l'observer directement à l'aide d'instruments optiques.

Warnung Nicht direkt in den Strahl blicken und ihn nicht direkt mit optischen Geräten prüfen.

Avvertenza Non fissare il raggio con gli occhi né usare strumenti ottici per osservarlo direttamente.

Advarsel Stirr eller se ikke direkte p strlen med optiske instrumenter.

Aviso Não olhe fixamente para o raio, nem olhe para ele directamente com instrumentos ópticos.

¡Atención! No mirar fijamente el haz ni observarlo directamente con instrumentos ópticos.

Varning! Rikta inte blicken in mot strålen och titta inte direkt på den genom optiska instrument.

Unterminated Fiber-Optic Cable Warning



WARNING: Invisible laser radiation might be emitted from the unterminated connector of a fiber-optic cable. To avoid injury to your eye, do not view the fiber optics with a magnifying optical device, such as a loupe, within 100 mm.

Waarschuwing Er kunnen onzichtbare laserstralen worden uitgezonden vanuit het uiteinde van de onafgebroken vezelkabel of connector. Niet in de straal kijken of deze rechtstreeks bekijken met optische instrumenten. Als u de laseruitvoer met bepaalde optische instrumenten bekijkt (zoals bijv. een oogloep, vergrootglas of microscoop) binnen een afstand van 100 mm kan dit gevaar voor uw ogen opleveren.

Varoitus Päättämättömän kuitukaapelin tai -liittimen päästä voi tulla näkymätöntä lasersäteilyä. Älä tuijota sädetä tai katso sitä suoraan optisilla välineillä. Lasersäteen katsominen tietyillä optisilla välineillä (esim. suurennuslasilla tai mikroskoopilla) 10 cm:n päästä tai sitä lähempää voi olla vaarallista silmille.

Attention Des émissions de radiations laser invisibles peuvent se produire à l'extrémité d'un câble en fibre ou d'un raccord sans terminaison. Ne pas fixer du regard le rayon ou l'observer directement avec des instruments optiques. L'observation du laser à l'aide certains instruments optiques (loupes et microscopes) à une distance inférieure à 100 mm peut poser des risques pour les yeux.

Warnung Eine unsichtbare Laserstrahlung kann vom Ende des nicht angeschlossenen Glasfaserkabels oder Steckers ausgestrahlt werden. Nicht in den Laserstrahl schauen oder diesen mit einem optischen Instrument direkt ansehen. Ein Betrachten des Laserstrahls mit bestimmten optischen Instrumenten, wie z.B. Augenlupen, Vergrößerungsgläsern und Mikroskopen innerhalb eines Abstands von 100 mm kann für das Auge gefährlich sein.

Avvertenza L'estremità del connettore o del cavo ottico senza terminazione può emettere radiazioni laser invisibili. Non fissare il raggio od osservarlo in modo diretto con strumenti ottici. L'osservazione del fascio laser con determinati strumenti ottici (come lupette, lenti di ingrandimento o microscopi) entro una distanza di 100 mm può provocare danni agli occhi.

Advarsel Usynlig laserstråling kan emitte fra enden av den ikke-terminerte fiberkabelen eller koblingen. Ikke se inn i strålen og se heller ikke direkte på strålen med optiske instrumenter. Observering av laserutgang med visse optiske instrumenter (for eksempel øyelupe, forstørrelsesglass eller mikroskoper) innenfor en avstand på 100 mm kan være farlig for øynene.

Aviso Radiação laser invisível pode ser emitida pela ponta de um conector ou cabo de fibra não terminado. Não olhe fixa ou diretamente para o feixe ou com instrumentos ópticos. Visualizar a emissão do laser com certos instrumentos ópticos (por exemplo, lupas, lentes de aumento ou microscópios) a uma distância de 100 mm pode causar riscos à visão.

¡Atención! El extremo de un cable o conector de fibra sin terminación puede emitir radiación láser invisible. No se acerque al radio de acción ni lo mire directamente con instrumentos ópticos. La exposición del ojo a una salida de láser con determinados instrumentos ópticos (por ejemplo, lupas y microscopios) a una distancia de 100 mm puede comportar lesiones oculares.

Varning! Osynlig laserstrålning kan komma från änden på en oavslutad fiberkabel eller -anslutning. Titta inte rakt in i strålen eller direkt på den med optiska instrument. Att titta på laserstrålen med vissa optiska instrument (t.ex. lupper, förstoringsglas och mikroskop) från ett avstånd på 100 mm kan skada ögonen.

Radiation from Open Port Apertures Warning



LASER WARNING: Because invisible radiation might be emitted from the aperture of the port when no fiber cable is connected, avoid exposure to radiation and do not stare into open apertures.

Waarschuwing Aangezien onzichtbare straling vanuit de opening van de poort kan komen als er geen fiberkabel aangesloten is, dient blootstelling aan straling en het kijken in open openingen vermeden te worden.

Varoitus Koska portin aukosta voi emittoitua näkymätöntä säteilyä, kun kuitukaapelia ei ole kytkettyä, vältä säteilylle altistumista äläkä katso avoimiin aukkoihin.

Avertissement Des radiations invisibles à l'il nu pouvant traverser l'ouverture du port lorsqu'aucun câble en fibre optique n'y est connecté, il est recommandé de ne pas regarder fixement l'intérieur de ces ouvertures.

Warnung Aus der Port-Öffnung können unsichtbare Strahlen emittieren, wenn kein Glasfaserkabel angeschlossen ist. Vermeiden Sie es, sich den Strahlungen auszusetzen, und starren Sie nicht in die Öffnungen!

Avvertenza Quando i cavi in fibra non sono inseriti, radiazioni invisibili possono essere emesse attraverso l'apertura della porta. Evitate di esporvi alle radiazioni e non guardate direttamente nelle aperture.

Advarsel Unngå utsettelse for stråling, og stirr ikke inn i åpninger som er åpne, fordi usynlig stråling kan emitteres fra portens åpning når det ikke er tilkoblet en fiberkabel.

Aviso Dada a possibilidade de emissão de radiação invisível através do orifício da via de acesso, quando esta não tiver nenhum cabo de fibra conectado, deverá evitar a EXposição à radiação e não deverá olhar fixamente para orifícios que se encontrarem a descoberto.

¡Atención! Debido a que la apertura del puerto puede emitir radiación invisible cuando no existe un cable de fibra conectado, evite mirar directamente a las aperturas para no exponerse a la radiación.

Warning! Osynlig strålning kan avges från en portöppning utan ansluten fiberkabel och du bör därför undvika att bli utsatt för strålning genom att inte stirra in i oskyddade öppningar.

Maintenance and Operational Safety Guidelines and Warnings

IN THIS SECTION

- [Battery Handling Warning | 91](#)
- [Jewelry Removal Warning | 92](#)
- [Lightning Activity Warning | 93](#)
- [Operating Temperature Warning | 94](#)
- [Product Disposal Warning | 95](#)

While performing the maintenance activities for devices, observe the following guidelines and warnings:

Battery Handling Warning



WARNING: Replacing a battery incorrectly might result in an explosion. Replace a battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Waarschuwing Er is ontplofingsgevaar als de batterij verkeerd vervangen wordt. Vervang de batterij slechts met hetzelfde of een equivalent type dat door de fabrikant aanbevolen is. Gebruikte batterijen dienen overeenkomstig fabrieksvoorschriften weggegooid te worden.

Varoitus Räjähdyksen vaara, jos akku on vaihdettu väärään akkuun. Käytä vaihtamiseen ainoastaan saman- tai vastaavantyyppistä akkua, joka on valmistajan suosittelema. Hävitä käytetyt akut valmistajan ohjeiden mukaan.

Avertissement Danger d'explosion si la pile n'est pas remplacée correctement. Ne la remplacer que par une pile de type semblable ou équivalent, recommandée par le fabricant. Jeter les piles usagées conformément aux instructions du fabricant.

Warnung Bei Einsetzen einer falschen Batterie besteht Explosionsgefahr. Ersetzen Sie die Batterie nur durch den gleichen oder vom Hersteller empfohlenen Batterietyp. Entsorgen Sie die benutzten Batterien nach den Anweisungen des Herstellers.

Advarsel Det kan være fare for eksplosjon hvis batteriet skiftes på feil måte. Skift kun med samme eller tilsvarende type som er anbefalt av produsenten. Kasser brukte batterier i henhold til produsentens instruksjoner.

Avvertenza Pericolo di esplosione se la batteria non è installata correttamente. Sostituire solo con una di tipo uguale o equivalente, consigliata dal produttore. Eliminare le batterie usate secondo le istruzioni del produttore.

Aviso Existe perigo de explosão se a bateria for substituída incorrectamente. Substitua a bateria por uma bateria igual ou de um tipo equivalente recomendado pelo fabricante. Destrua as baterias usadas conforme as instruções do fabricante.

¡Atención! Existe peligro de explosión si la batería se reemplaza de manera incorrecta. Reemplazar la batería EXclusivamente con el mismo tipo o el equivalente recomendado por el fabricante. Desechar las baterías gastadas según las instrucciones del fabricante.

Varning! Explosionsfara vid felaktigt batteribyte. Ersätt endast batteriet med samma batterityp som rekommenderas av tillverkaren eller motsvarande. Följ tillverkarens anvisningar vid kassering av använda batterier.

Jewelry Removal Warning



WARNING: Before working on equipment that is connected to power lines, remove jewelry, including rings, necklaces, and watches. Metal objects heat up when connected to power and ground and can cause serious burns or can be welded to the terminals.

Waarschuwing Alvorens aan apparatuur te werken die met elektrische leidingen is verbonden, sieraden (inclusief ringen, kettingen en horloges) verwijderen. Metalen voorwerpen worden warm wanneer ze met stroom en aarde zijn verbonden, en kunnen ernstige brandwonden veroorzaken of het metalen voorwerp aan de aansluitklemmen lassen.

Varoitus Ennen kuin työskentelet voimavirtajohtoihin kytkettyjen laitteiden parissa, ota pois kaikki korut (sormukset, kaulakorut ja kellot mukaan lukien). Metalliesineet kuumenevat, kun ne ovat yhteydessä sähkövirran ja maan kanssa, ja ne voivat aiheuttaa vakavia palovammoja tai hitsata metalliesineet kiinni liitännänapoihin.

Avertissement Avant d'accéder à cet équipement connecté aux lignes électriques, ôter tout bijou (anneaux, colliers et montres compris). Lorsqu'ils sont branchés à l'alimentation et reliés à la terre, les objets métalliques chauffent, ce qui peut provoquer des blessures graves ou souder l'objet métallique aux bornes.

Warnung Vor der Arbeit an Geräten, die an das Netz angeschlossen sind, jeglichen Schmuck (einschließlich Ringe, Ketten und Uhren) abnehmen. Metallgegenstände erhitzen sich, wenn sie an das Netz und die Erde angeschlossen werden, und können schwere Verbrennungen verursachen oder an die Anschlußklemmen angeschweißt werden.

Avvertenza Prima di intervenire su apparecchiature collegate alle linee di alimentazione, togliersi qualsiasi monile (inclusi anelli, collane, braccialetti ed orologi). Gli oggetti metallici si riscaldano quando sono collegati tra punti di alimentazione e massa: possono causare ustioni gravi oppure il metallo può saldarsi ai terminali.

Advarsel Fjern alle smykker (inkludert ringer, halskjeder og klokker) før du skal arbeide på utstyr som er koblet til kraftledninger. Metallgjenstander som er koblet til kraftledninger og jord blir svært varme og kan forårsake alvorlige brannskader eller smelte fast til polene.

Aviso Antes de trabalhar em equipamento que esteja ligado a linhas de corrente, retire todas as jóias que estiver a usar (incluindo anéis, fios e relógios). Os objectos metálicos aquecerão em contacto com a corrente e em contacto com a ligação à terra, podendo causar queimaduras graves ou ficarem soldados aos terminais.

¡Atención! Antes de operar sobre equipos conectados a líneas de alimentación, quitarse las joyas (incluidos anillos, collares y relojes). Los objetos de metal se calientan cuando se conectan a la alimentación y a tierra, lo que puede ocasionar quemaduras graves o que los objetos metálicos queden soldados a los bornes.

Warning! Tag av alla smycken (inklusive ringar, halsband och armbandsur) innan du arbetar på utrustning som är kopplad till kraftledningar. Metallobjekt hettas upp när de kopplas ihop med ström och jord och kan förorsaka allvarliga brännskador; metallobjekt kan också sammansvetsas med kontakterna.

Lightning Activity Warning



WARNING: Do not work on the system or connect or disconnect cables during periods of lightning activity.

Waarschuwing Tijdens onweer dat gepaard gaat met bliksem, dient u niet aan het systeem te werken of kabels aan te sluiten of te ontkoppelen.

Varoitus Älä työskentele järjestelmän parissa äläkä yhdistä tai irrota kaapeleita ukkosilmalla.

Avertissement Ne pas travailler sur le système ni brancher ou débrancher les câbles pendant un orage.

Warnung Arbeiten Sie nicht am System und schließen Sie keine Kabel an bzw. trennen Sie keine ab, wenn es gewittert.

Avvertenza Non lavorare sul sistema o collegare oppure scollegare i cavi durante un temporale con fulmini.

Advarsel Utfør aldri arbeid på systemet, eller koble kabler til eller fra systemet når det tordner eller lyner.

Aviso Não trabalhe no sistema ou ligue e desligue cabos durante períodos de mau tempo (trovoada).

¡Atención! No operar el sistema ni conectar o desconectar cables durante el transcurso de descargas eléctricas en la atmósfera.

Warning! Vid åska skall du aldrig utföra arbete på systemet eller ansluta eller koppla loss kablar.

Operating Temperature Warning



WARNING: To prevent the device from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature. To prevent airflow restriction, allow at least 6 in. (15.2 cm) of clearance around the ventilation openings.

Waarschuwing Om te voorkomen dat welke switch van de Juniper Networks router dan ook oververhit raakt, dient u deze niet te bedienen op een plaats waar de maximale aanbevolen omgevingstemperatuur van 40° C wordt overschreden. Om te voorkomen dat de luchtstroom wordt beperkt, dient er minstens 15,2 cm speling rond de ventilatie-openingen te zijn.

Varoitus Ettei Juniper Networks switch-sarjan reititin ylikuumentuisi, sitä ei saa käyttää tilassa, jonka lämpötila ylittää korkeimman suositellun ympäristölämpötilan 40° C. Ettei ilmanvaihto estyisi, tuuletusaukkojen ympärille on jätettävä ainakin 15,2 cm tilaa.

Avertissement Pour éviter toute surchauffe des routeurs de la gamme Juniper Networks switch, ne l'utilisez pas dans une zone où la température ambiante est supérieure à 40° C. Pour permettre un flot d'air constant, dégagez un espace d'au moins 15,2 cm autour des ouvertures de ventilations.

Warnung Um einen Router der switch vor Überhitzung zu schützen, darf dieser nicht in einer Gegend betrieben werden, in der die Umgebungstemperatur das empfohlene Maximum von 40° C überschreitet. Um Lüftungsverschluß zu verhindern, achten Sie darauf, daß mindestens 15,2 cm lichter Raum um die Lüftungsöffnungen herum frei bleibt.

Avvertenza Per evitare il surriscaldamento dei switch, non adoperateli in un locale che ecceda la temperatura ambientale massima di 40° C. Per evitare che la circolazione dell'aria sia impedita, lasciate uno spazio di almeno 15.2 cm di fronte alle aperture delle ventole.

Advarsel Unngå overoppheting av eventuelle rutere i Juniper Networks switch Disse skal ikke brukes på steder der den anbefalte maksimale omgivelsestemperaturen overstiger 40° C (104° F). Sørg for at klaringen rundt lufteåpningene er minst 15,2 cm (6 tommer) for å forhindre nedsatt luftsirkulasjon.

Aviso Para evitar o sobreaquecimento do encaminhador Juniper Networks switch, não utilize este equipamento numa área que exceda a temperatura máxima recomendada de 40° C. Para evitar a restrição à circulação de ar, deixe pelo menos um espaço de 15,2 cm à volta das aberturas de ventilação.

¡Atención! Para impedir que un encaminador de la serie Juniper Networks switch se recaliente, no lo haga funcionar en un área en la que se supere la temperatura ambiente máxima recomendada de 40° C. Para impedir la restricción de la entrada de aire, deje un espacio mínimo de 15,2 cm alrededor de las aperturas para ventilación.

Warning! Förhindra att en Juniper Networks switch överhettas genom att inte använda den i ett område där den maximalt rekommenderade omgivningstemperaturen på 40° C överskrids. Förhindra att luftcirkulationen inskränks genom att se till att det finns fritt utrymme på minst 15,2 cm omkring ventilationsöppningarna.

Product Disposal Warning



WARNING: Disposal of this device must be handled according to all national laws and regulations.

Waarschuwing Dit produkt dient volgens alle landelijke wetten en voorschriften te worden afgedankt.

Varoitus Tämän tuotteen lopullisesta hävittämisestä tulee huolehtia kaikkia valtakunnallisia lakeja ja säännöksiä noudattaen.

Avertissement La mise au rebut définitive de ce produit doit être effectuée conformément à toutes les lois et réglementations en vigueur.

Warnung Dieses Produkt muß den geltenden Gesetzen und Vorschriften entsprechend entsorgt werden.

Avvertenza L'eliminazione finale di questo prodotto deve essere eseguita osservando le normative italiane vigenti in materia

Advarsel Endelig disponering av dette produktet må skje i henhold til nasjonale lover og forskrifter.

Aviso A descartagem final deste produto deverá ser efectuada de acordo com os regulamentos e a legislação nacional.

¡Atención! El desecho final de este producto debe realizarse según todas las leyes y regulaciones nacionales

Warning! Slutlig kassering av denna produkt bör skötas i enlighet med landets alla lagar och föreskrifter.

General Electrical Safety Guidelines and Warnings



WARNING: Certain ports on the device are designed for use as intrabuilding (within-the-building) interfaces only (Type 2 or Type 4 ports as described in *GR-1089-CORE*) and require isolation from the exposed outside plant (OSP) cabling. To comply with NEBS (Network Equipment-Building System) requirements and protect against lightning surges and commercial power disturbances, the intrabuilding ports *must not* be metalically connected to interfaces that connect to the OSP or its wiring. The intrabuilding ports on the device are suitable for connection to intrabuilding or unexposed wiring or cabling only. The addition of primary protectors is not sufficient protection for connecting these interfaces metalically to OSP wiring.

Avertissement Certains ports de l'appareil sont destinés à un usage en intérieur uniquement (ports Type 2 ou Type 4 tels que décrits dans le document *GR-1089-CORE*) et doivent être isolés du câblage de l'installation extérieure exposée. Pour respecter les exigences NEBS et assurer une protection contre la foudre et les perturbations de tension secteur, les ports pour intérieur *ne doivent pas* être raccordés physiquement aux interfaces prévues pour la connexion à l'installation extérieure ou à son câblage. Les ports pour intérieur de l'appareil sont réservés au raccordement de câbles pour intérieur ou non exposés uniquement. L'ajout de protections ne constitue pas une précaution suffisante pour raccorder physiquement ces interfaces au câblage de l'installation extérieure.



CAUTION: Before removing or installing components of a device, connect an electrostatic discharge (ESD) grounding strap to an ESD point and wrap and fasten the other end of the strap around your bare wrist. Failure to use an ESD grounding strap could result in damage to the device.

Attention Avant de retirer ou d'installer des composants d'un appareil, raccordez un bracelet antistatique à un point de décharge électrostatique et fixez le bracelet à votre poignet nu. L'absence de port d'un bracelet antistatique pourrait provoquer des dégâts sur l'appareil.

- Install the device in compliance with the following local, national, and international electrical codes:
 - United States—National Fire Protection Association (NFPA 70), United States National Electrical Code.
 - Other countries—International Electromechanical Commission (IEC) 60364, Part 1 through Part 7.
 - Evaluated to the TN power system.

- Canada—Canadian Electrical Code, Part 1, CSA C22.1.
- Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.

Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.

- Locate the emergency power-off switch for the room in which you are working so that if an electrical accident occurs, you can quickly turn off the power.
- Make sure that you clean grounding surface and give them a bright finish before making grounding connections.
- Do not work alone if potentially hazardous conditions exist anywhere in your workspace.
- Never assume that power is disconnected from a circuit. Always check the circuit before starting to work.
- Carefully look for possible hazards in your work area, such as moist floors, ungrounded power extension cords, and missing safety grounds.
- Operate the device within marked electrical ratings and product usage instructions.
- To ensure that the device and peripheral equipment function safely and correctly, use the cables and connectors specified for the attached peripheral equipment, and make certain they are in good condition.

You can remove and replace many device components without powering off or disconnecting power to the device, as detailed elsewhere in the hardware documentation for this device. Never install equipment that appears to be damaged.

Action to Take After an Electrical Accident

If an electrical accident results in an injury, take the following actions in this order:

1. Use caution. Be aware of potentially hazardous conditions that could cause further injury.
2. Disconnect power from the device.
3. If possible, send another person to get medical aid. Otherwise, assess the condition of the victim, and then call for help.

Prevention of Electrostatic Discharge Damage

Device components that are shipped in antistatic bags are sensitive to damage from static electricity. Some components can be impaired by voltages as low as 30 V. You can easily generate potentially damaging static voltages whenever you handle plastic or foam packing material or if you move components across plastic or carpets. Observe the following guidelines to minimize the potential for electrostatic discharge (ESD) damage, which can cause intermittent or complete component failures:

- Always use an ESD wrist strap when you are handling components that are subject to ESD damage, and make sure that it is in direct contact with your skin.

If a grounding strap is not available, hold the component in its antistatic bag (see [Figure 23 on page 99](#)) in one hand and touch the exposed, bare metal of the device with the other hand immediately before inserting the component into the device.



WARNING: For safety, periodically check the resistance value of the ESD grounding strap. The measurement must be in the range 1 through 10 Mohms.


Avertissement Par mesure de sécurité, vérifiez régulièrement la résistance du bracelet antistatique. Cette valeur doit être comprise entre 1 et 10 mégohms (Mohms).

- When handling any component that is subject to ESD damage and that is removed from the device, make sure the equipment end of your ESD wrist strap is attached to the ESD point on the chassis.

If no grounding strap is available, touch the exposed, bare metal of the device to ground yourself before handling the component.

- Avoid contact between the component that is subject to ESD damage and your clothing. ESD voltages emitted from clothing can damage components.
- When removing or installing a component that is subject to ESD damage, always place it component-side up on an antistatic surface, in an antistatic card rack, or in an antistatic bag (see [Figure 23 on page 99](#)). If you are returning a component, place it in an antistatic bag before packing it.

Figure 23: Placing a Component into an Antistatic Bag



CAUTION: ANSI/TIA/EIA-568 cables such as Category 5e and Category 6 can get electrostatically charged. To dissipate this charge, always ground the cables to a suitable and safe earth ground before connecting them to the system.

Attention Les câbles ANSI/TIA/EIA-568, par exemple Cat 5e et Cat 6, peuvent emmagasiner des charges électrostatiques. Pour évacuer ces charges, reliez toujours les câbles à une prise de terre adaptée avant de les raccorder au système.

AC Power Electrical Safety Guidelines

The following electrical safety guidelines apply to AC-powered devices:

- Note the following warnings printed on the device:

“CAUTION: THIS UNIT HAS MORE THAN ONE POWER SUPPLY CORD. DISCONNECT ALL POWER SUPPLY CORDS BEFORE SERVICING TO AVOID ELECTRIC SHOCK.”

“ATTENTION: CET APPAREIL COMPORTE PLUS D'UN CORDON D'ALIMENTATION. AFIN DE PRÉVENIR LES CHOCS ÉLECTRIQUES, DÉBRANCHER TOUT CORDON D'ALIMENTATION AVANT DE FAIRE LE DÉPANNAGE.”

- AC-powered devices are shipped with a three-wire electrical cord with a grounding-type plug that fits only a grounding-type power outlet. Do not circumvent this safety feature. Equipment grounding must comply with local and national electrical codes.
- You must provide an external certified circuit breaker (2-pole circuit breaker or 4-pole circuit breaker based on your device) rated minimum 20 A in the building installation.
- The power cord serves as the main disconnecting device for the AC-powered device. The socket outlet must be near the AC-powered device and be easily accessible.
- For devices that have more than one power supply connection, you must ensure that all power connections are fully disconnected so that power to the device is completely removed to prevent electric shock. To disconnect power, unplug all power cords (one for each power supply).

Power Cable Warning (Japanese)

WARNING: The attached power cable is only for this product. Do not use the cable for another product.

注意

附属の電源コードセットはこの製品専用です。

他の電気機器には使用しないでください。

9017283

AC Power Disconnection Warning



WARNING: Before working on the device or near power supplies, unplug all the power cords from an AC-powered device.

Waarschuwing Voordat u aan een frame of in de nabijheid van voedingen werkt, dient u bij wisselstroom toestellen de stekker van het netsnoer uit het stopcontact te halen.

Varoitus Kytke irti vaihtovirtalaitteiden virtajohto, ennen kuin teet mitään asennuspohjalle tai työskentelet virtalähteiden läheisyydessä.

Avertissement Avant de travailler sur un châssis ou à proximité d'une alimentation électrique, débrancher le cordon d'alimentation des unités en courant alternatif.

Warnung Bevor Sie an einem Chassis oder in der Nähe von Netzgeräten arbeiten, ziehen Sie bei Wechselstromeinheiten das Netzkabel ab bzw.

Avvertenza Prima di lavorare su un telaio o intorno ad alimentatori, scollegare il cavo di alimentazione sulle unità CA.

Advarsel Før det utføres arbeid på kabinettet eller det arbeides i nærheten av strømforsyningsenheter, skal strømledningen trekkes ut på vekselstrømsenheter.

Aviso Antes de trabalhar num chassis, ou antes de trabalhar perto de unidades de fornecimento de energia, desligue o cabo de alimentação nas unidades de corrente alternada.

¡Atención! Antes de manipular el chasis de un equipo o trabajar cerca de una fuente de alimentación, desenchufar el cable de alimentación en los equipos de corriente alterna (CA).

Warning! Innan du arbetar med ett chassi eller nära strömförsörjningsenheter skall du för växelströmsenheter dra ur nätsladden.

TN Power Warning



WARNING: The device is designed to work with a TN power system.

Waarschuwing Het apparaat is ontworpen om te functioneren met TN energiesystemen.

Varoitus Koje on suunniteltu toimimaan TN-sähkövoimajärjestelmien yhteydessä.

Avertissement Ce dispositif a été conçu pour fonctionner avec des systèmes d'alimentation TN.

Warnung Das Gerät ist für die Verwendung mit TN-Stromsystemen ausgelegt.

Avvertenza Il dispositivo è stato progettato per l'uso con sistemi di alimentazione TN.

Advarsel Utstyret er utfomet til bruk med TN-strømsystemer.

Aviso O dispositivo foi criado para operar com sistemas de corrente TN.

¡Atención! El equipo está diseñado para trabajar con sistemas de alimentación tipo TN.

Warning! Enheten är konstruerad för användning tillsammans med elkraftssystem av TN-typ.