

Chapter 18

Monitoring NTP with the C-Web Interface

This chapter describes how to monitor the Network Time Protocol (NTP) server with the C-Web interface. Topics include:


- Viewing NTP Peers with the C-Web Interface on page 177
- Viewing Statistics for NTP with the C-Web Interface on page 178
- Viewing NTP Status with the C-Web Interface on page 179

Viewing NTP Peers with the C-Web Interface

To view a list of NTP peers:

1. Select **NTP** from the side pane, and click **Associations**.

The Associations pane appears.



2. To suppress symbolic addressing, select the **No Resolve** box.
3. Click **OK**.


The Associations pane displays the list of NTP peers.

Viewing Statistics for NTP with the C-Web Interface

To display statistics for NTP:

1. Select **NTP** from the side pane, and click **Statistics**.

The Statistics pane appears.



2. To suppress symbolic addressing, select the **No Resolve** box.
3. Click **OK**.

The Statistics pane displays statistics for NTP.

Viewing NTP Status with the C-Web Interface

To display status for NTP:

1. Select **NTP** from the side pane, and click **Status**.

The Status pane appears.



2. To suppress symbolic addressing, select the **No Resolve** box.
3. Click **OK**.

The Status pane displays NTP status.

