

## SRC Virtualization



---

Modified: 2016-05-25

Juniper Networks, Inc.  
1133 Innovation Way  
Sunnyvale, California 94089  
USA  
408-745-2000  
[www.juniper.net](http://www.juniper.net)

Copyright © 2016, Juniper Networks, Inc. All rights reserved.

Juniper Networks, Junos, Steel-Belted Radius, NetScreen, and ScreenOS are registered trademarks of Juniper Networks, Inc. in the United States and other countries. The Juniper Networks Logo, the Junos logo, and JunosE are trademarks of Juniper Networks, Inc. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.

Juniper Networks assumes no responsibility for any inaccuracies in this document. Juniper Networks reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

#### *SRC Virtualization*

Copyright © 2016, Juniper Networks, Inc.  
All rights reserved.

The information in this document is current as of the date on the title page.

#### YEAR 2000 NOTICE

Juniper Networks hardware and software products are Year 2000 compliant. Junos OS has no known time-related limitations through the year 2038. However, the NTP application is known to have some difficulty in the year 2036.

#### **END USER LICENSE AGREEMENT**

The Juniper Networks product that is the subject of this technical documentation consists of (or is intended for use with) Juniper Networks software. Use of such software is subject to the terms and conditions of the End User License Agreement ("EULA") posted at <http://www.juniper.net/support/eula.html>. By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

# Table of Contents

	About the Documentation . . . . .	vii
	Documentation and Release Notes . . . . .	vii
	Supported Platforms . . . . .	vii
	Documentation Conventions . . . . .	vii
	Documentation Conventions . . . . .	viii
	Documentation Feedback . . . . .	x
	Requesting Technical Support . . . . .	x
	Self-Help Online Tools and Resources . . . . .	xi
	Opening a Case with JTAC . . . . .	xi
<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Virtualization Overview . . . . .</b>	<b>3</b>
	Virtualized SRC Software Overview . . . . .	3
	System Requirements for a Virtualized SRC Software . . . . .	3
	Hard Disk Requirement . . . . .	4
	Memory Requirements . . . . .	4
	CPU Requirements . . . . .	5
<b>Part 2</b>	<b>Administration</b>	
<b>Chapter 2</b>	<b>Virtualized SRC . . . . .</b>	<b>9</b>
	Creating a Virtualized SRC Instance . . . . .	9
	Creating a Virtualized SRC Instance Using qcow2 Image . . . . .	9
	Creating a Virtualized SRC Instance Using iso Image . . . . .	11
	Creating a Virtualized SRC Instance Using the vmdk Image . . . . .	12
<b>Part 3</b>	<b>Index</b>	
	Index . . . . .	17



# List of Tables

	<b>About the Documentation</b> .....	<b>vii</b>
	Table 1: Notice Icons .....	viii
	Table 2: Notice Icons .....	ix
	Table 3: Text Conventions .....	ix
<b>Part 1</b>	<b>Overview</b>	
<b>Chapter 1</b>	<b>Virtualization Overview</b> .....	<b>3</b>
	Table 4: Heap Allocation for SRC Components on a Virtualized SRC Software .....	4



# About the Documentation

- Documentation and Release Notes on page vii
- Supported Platforms on page vii
- Documentation Conventions on page vii
- Documentation Feedback on page x
- Requesting Technical Support on page x

## Documentation and Release Notes

---

To obtain the most current version of all Juniper Networks® technical documentation, see the product documentation page on the Juniper Networks website at <http://www.juniper.net/techpubs/>.

If the information in the latest release notes differs from the information in the documentation, follow the product Release Notes.

Juniper Networks Books publishes books by Juniper Networks engineers and subject matter experts. These books go beyond the technical documentation to explore the nuances of network architecture, deployment, and administration. The current list can be viewed at <http://www.juniper.net/books>.

## Supported Platforms

---

For the features described in this document, the following platforms are supported:

- C Series

## Documentation Conventions

---

Table 1 on page viii defines notice icons used in this guide.

Table 1: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

---

## Documentation Conventions

[Table 1 on page viii](#) defines the notice icons used in this guide. [Table 3 on page ix](#) defines text conventions used throughout this documentation.



Table 2: Notice Icons

Icon	Meaning	Description
	Informational note	Indicates important features or instructions.
	Caution	Indicates a situation that might result in loss of data or hardware damage.
	Warning	Alerts you to the risk of personal injury or death.
	Laser warning	Alerts you to the risk of personal injury from a laser.
	Tip	Indicates helpful information.
	Best practice	Alerts you to a recommended use or implementation.

Table 3: Text Conventions

Convention	Description	Examples
<b>Bold text like this</b>	<ul style="list-style-type: none"> <li>Represents keywords, scripts, and tools in text.</li> <li>Represents a GUI element that the user selects, clicks, checks, or clears.</li> </ul>	<ul style="list-style-type: none"> <li>Specify the keyword <b>exp-msg</b>.</li> <li>Run the <b>install.sh</b> script.</li> <li>Use the <b>pkgadd</b> tool.</li> <li>To cancel the configuration, click <b>Cancel</b>.</li> </ul>
<b>Bold text like this</b>	Represents text that the user must type.	<b>user@host# set cache-entry-age</b> <i>cache-entry-age</i>
Fixed-width text like this	Represents information as displayed on your terminal's screen, such as CLI commands in output displays.	<pre>nic-locators {   login {     resolution {       resolver-name /realms/       login/A1;       key-type LoginName;       value-type SaeId;     }   } }</pre>
Regular sans serif typeface	<ul style="list-style-type: none"> <li>Represents configuration statements.</li> <li>Indicates SRC CLI commands and options in text.</li> <li>Represents examples in procedures.</li> <li>Represents URLs.</li> </ul>	<ul style="list-style-type: none"> <li><b>system ldap server{</b> <b>stand-alone;</b></li> <li>Use the <b>request sae modify device failover</b> <b>command</b> with the <b>force</b> option</li> <li><b>user@host# ...</b></li> <li><a href="http://www.juniper.net/techpubs/software/management/sdx/api-index.html">http://www.juniper.net/techpubs/software/management/sdx/api-index.html</a></li> </ul>

Table 3: Text Conventions (*continued*)

<i>Italic sans serif typeface</i>	Represents variables in SRC CLI commands.	<code>user@host# set local-address local-address</code>
Angle brackets	In text descriptions, indicate optional keywords or variables.	Another runtime variable is <gfwif>.
Key name	Indicates the name of a key on the keyboard.	Press Enter.
Key names linked with a plus sign (+)	Indicates that you must press two or more keys simultaneously.	Press Ctrl + b.
<i>Italic typeface</i>	<ul style="list-style-type: none"> <li>Emphasizes words.</li> <li>Identifies book names.</li> <li>Identifies distinguished names.</li> <li>Identifies files, directories, and paths in text but not in command examples.</li> </ul>	<ul style="list-style-type: none"> <li>There are two levels of access: <i>user</i> and <i>privileged</i>.</li> <li><i>SRC-PE Getting Started Guide</i>.</li> <li><i>o=Users, o=UMC</i></li> <li>The <i>/etc/default.properties</i> file.</li> </ul>
Backslash	At the end of a line, indicates that the text wraps to the next line.	<code>Plugin.radiusAcct-1.class=\ net.juniper.smgmt.sae.plugin\ RadiusTrackingPluginEvent</code>
Words separated by the   symbol	Represent a choice to select one keyword or variable to the left or right of this symbol. (The keyword or variable may be either optional or required.)	<code>diagnostic   line</code>

## Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. You can provide feedback by using either of the following methods:

- Online feedback rating system—On any page of the Juniper Networks TechLibrary site at <http://www.juniper.net/techpubs/index.html>, simply click the stars to rate the content, and use the pop-up form to provide us with information about your experience. Alternately, you can use the online feedback form at <http://www.juniper.net/techpubs/feedback/>.
- E-mail—Send your comments to [techpubs-comments@juniper.net](mailto:techpubs-comments@juniper.net). Include the document or topic name, URL or page number, and software version (if applicable).

## Requesting Technical Support

Technical product support is available through the Juniper Networks Technical Assistance Center (JTAC). If you are a customer with an active J-Care or Partner Support Service support contract, or are covered under warranty, and need post-sales technical support, you can access our tools and resources online or open a case with JTAC.

- JTAC policies—For a complete understanding of our JTAC procedures and policies, review the *JTAC User Guide* located at <http://www.juniper.net/us/en/local/pdf/resource-guides/7100059-en.pdf>.
- Product warranties—For product warranty information, visit <http://www.juniper.net/support/warranty/>.
- JTAC hours of operation—The JTAC centers have resources available 24 hours a day, 7 days a week, 365 days a year.

## Self-Help Online Tools and Resources

For quick and easy problem resolution, Juniper Networks has designed an online self-service portal called the Customer Support Center (CSC) that provides you with the following features:

- Find CSC offerings: <http://www.juniper.net/customers/support/>
- Search for known bugs: <http://www2.juniper.net/kb/>
- Find product documentation: <http://www.juniper.net/techpubs/>
- Find solutions and answer questions using our Knowledge Base: <http://kb.juniper.net/>
- Download the latest versions of software and review release notes: <http://www.juniper.net/customers/csc/software/>
- Search technical bulletins for relevant hardware and software notifications: <http://kb.juniper.net/InfoCenter/>
- Join and participate in the Juniper Networks Community Forum: <http://www.juniper.net/company/communities/>
- Open a case online in the CSC Case Management tool: <http://www.juniper.net/cm/>

To verify service entitlement by product serial number, use our Serial Number Entitlement (SNE) Tool: <https://tools.juniper.net/SerialNumberEntitlementSearch/>

## Opening a Case with JTAC

You can open a case with JTAC on the Web or by telephone.

- Use the Case Management tool in the CSC at <http://www.juniper.net/cm/>.
- Call 1-888-314-JTAC (1-888-314-5822 toll-free in the USA, Canada, and Mexico).

For international or direct-dial options in countries without toll-free numbers, see <http://www.juniper.net/support/requesting-support.html>.



## PART 1

# Overview

- [Virtualization Overview on page 3](#)



## CHAPTER 1

# Virtualization Overview

- [Virtualized SRC Software Overview on page 3](#)
- [System Requirements for a Virtualized SRC Software on page 3](#)

## Virtualized SRC Software Overview

---

You can deploy the SRC software as a virtual machine and manage SRC functionalities. The virtualized SRC software can be created through an iso, qcow2, or vmdk image.



NOTE: All hardware-specific commands (such as show disk status) display an appropriate error message when executed in a virtualized SRC software. Virtualized SRC software does not support hardware-related alarms or traps (such as diskFailure).

The SRC software installation is currently supported and tested over the VMware Workstation 12 Player, VMware Workstation 12 Pro, VMware ESXi 5.5.0, and Kernel-based Virtual Machine (KVM) hypervisor on CentOS 6.5.

The SRC software does not have any hypervisor management tool. You can make use of the existing tools such as virsh and virt-manager.

### Related Documentation

- [SRC Product Description](#)
- [Creating a Virtualized SRC Instance on page 9](#)
- [System Requirements for a Virtualized SRC Software on page 3](#)

## System Requirements for a Virtualized SRC Software

---

The system requirements for a virtualized SRC software are:



**NOTE:** We recommend you to allocate CPU cores, RAM, and hard disk space as same as that of C Series Controllers to attain better performance.

- [Hard Disk Requirement on page 4](#)
- [Memory Requirements on page 4](#)
- [CPU Requirements on page 5](#)

## Hard Disk Requirement

The qcow2 image and vmdk image (of subtype monolithicSparse) grow in size up to 250 GB when used on a virtual machine, so you must have more than 250 GB of disk space in the host operating system if you use the qcow2 or vmdk image.

If you are using an SRC iso image, we recommend you to have around 250 GB of disk space allocated to the virtualized SRC software to have enough space for system and component logs.

## Memory Requirements

[Table 4 on page 4](#) lists the default heap size allocated for SRC components on a virtualized SRC software.

**Table 4: Heap Allocation for SRC Components on a Virtualized SRC Software**

SRC Component	Default Heap Size on Virtualized SRC Software	Heap Size Adjustable or Not
SRC ACP	64 MB	Yes
SNMP agent	160 MB	No
Web application server	616 MB	No
CLI	200 MB	No
Diameter server	600 MB	No
External subscriber monitor	160 MB	Yes
3GPP Gateway	200 MB	No
IMS Services Gateway	200 MB	No
JPS	400 MB	Yes
License server	1 GB or smaller than one-fourth of physical memory	No
NIC	128 MB	Yes



Table 4: Heap Allocation for SRC Components on a Virtualized SRC Software (*continued*)

SRC Component	Default Heap Size on Virtualized SRC Software	Heap Size Adjustable or Not
SAE	70% of free memory	Yes
C-Web interface	200 MB	No



**NOTE:** In a virtualized SRC software, the default heap size is set only for the Java components and not for the non-Java components such as redirect server.

The memory requirements of the virtualized SRC software based on the default heap size allocation are:

- At least 2927 MB of memory is required for all Java components other than the SAE and license server.
- Subscriber management capacity of the virtualized SRC software depends on the heap size of the SAE. We recommend you to allocate enough heap size for SAE.
- 1 GB of memory is required for the license server.

## CPU Requirements

You must allocate a minimum of one CPU core for a virtualized SRC software. You can allocate CPU cores same as that of C Series Controller to attain better performance. The CPU cores available in C Series Controllers are:

- C2000—4
- C3000—8
- C5000—24

### Related Documentation

- [Virtualized SRC Software Overview on page 3](#)



## PART 2

# Administration

- [Virtualized SRC on page 9](#)



## CHAPTER 2

# Virtualized SRC

- [Creating a Virtualized SRC Instance on page 9](#)

## Creating a Virtualized SRC Instance

---

You can create a virtualized SRC instance by using the iso, qcow2, or vmdk image.



**NOTE:** We recommend you to create a virtualized SRC instance by using the qcow2 image.

- [Creating a Virtualized SRC Instance Using qcow2 Image on page 9](#)
- [Creating a Virtualized SRC Instance Using iso Image on page 11](#)
- [Creating a Virtualized SRC Instance Using the vmdk Image on page 12](#)

## Creating a Virtualized SRC Instance Using qcow2 Image

To create a virtualized SRC instance by using the qcow2 image:

1. Download the qcow2.gz image from <http://www.juniper.net/support/downloads/?p=src#sw> and place it on the host operating system.
2. Unzip the image on the host operating system.  

```
gunzip name.qcow2.gz
```
3. Download the SDK+AppSupport+Demos+Samples.tar.gz file from <http://www.juniper.net/support/downloads/?p=src#sw> and place it on the host operating system.
4. Untar the file to use the create\_vm.py script for creating a virtualized SRC instance.  

```
tar -xvzf SDK+AppSupport+Demos+Samples.tar.gz
```
5. Execute the create\_vm.py script from the path where the SDK+AppSupport+Demos+Samples.tar.gz is extracted.  

```
#$cd <sdk_root_folder>/SDK/vSRC/  
#$. /create_vm.py
```



**NOTE:** The `create_vm.py` script is not supported for VMware virtual machine creation. To create a virtualized SRC instance on VMware hypervisor, use the iso or vmdk image.

The script requests various details for creating the virtualized SRC instance.

6. Enter the requested details. The details requested by the script are:

- Name for the virtualized SRC instance
- Number of CPUs to be allocated for the virtualized SRC instance
- Memory (in megabytes) to be allocated for the virtualized SRC instance
- Network configuration details:
  - Number of interfaces to be configured
  - Media access control (MAC) address for each interface. You can enter MAC address or allow the script to create the MAC address automatically.
  - Networking mode for each interface. The supported modes are:
    - Direct host device mapping with bridge mode—Use this mode if multiple network interfaces have to be shared with a host device (for example, `eth0`). This mode is ideal for hosting multiple virtualized SRC instances with multiple interfaces. This is the default mode.
    - Direct host device mapping with passthrough mode—In this mode, one-to-one mapping is done between the host device network interface and virtualized SRC instance's network interface. You can use this mode when only one virtualized SRC instance is hosted in the server.
    - Shared bridge mapping (bridge has to be manually configured)—In this mode, you have to manually configure the bridge and provide the shared bridge name as an input. This mode provides flexibility to have more complex networking.
- Path of the qcow2 image file

The script creates an xml file with the name of the virtualized SRC instance and creates the virtualized SRC instance by using the **virsh** command. The xml file contains one serial console configuration and one vnc console configuration.



**NOTE:** You must have the **virsh** management tool in the host operating system for the script to successfully create the virtualized SRC instance.

7. Log in to the virtualized SRC instance through any hypervisor management tool and set up the initial configuration for the SRC software. For information about the initial configuration, see your *C Series Controller Hardware Guide*.

## Creating a Virtualized SRC Instance Using iso Image

To create a virtualized SRC instance by using the iso image:

1. Download the iso image from <http://www.juniper.net/support/downloads/?p=src#sw> and place it in the host operating system.
2. Start installing the iso image in the virtual machine by using the hypervisor management tool (such as virt-manager and virsh). The virtual machine boots from the iso image and prints the following message:

Welcome to SRC PE Software Installation.

WARNING: This system recovery software replaces all data and software on the system disk image. As a result, any data, including data previously in the snapshot partition, is lost.

After you run the system installation software, the virtual image contains the SRC software, including the SRC operating system, but no configuration data.

To continue, press <TAB> and choose the installation type.

To enable serial console enter following after choosing the Installation type :

```
"console=tty0 console=tty50, 9600"
```

To cancel this operation, power off the system and remove the iso image.

boot:

AUTO Manual rescue

boot:

3. At the boot prompt, type the installation option.
  - If the typed option is AUTO, the disk space is partitioned automatically and the packages are installed. The following hard disk partition scheme is used:
    - /—8.5 GB
    - /var—50 percent of remaining hard disk space
    - 50 percent of remaining hard disk space can be used for storing snapshots
  - If the typed option is Manual, you can define the partition scheme and other general settings (such as language) through the displayed dialog boxes to install the SRC software.



**NOTE:** You cannot create snapshot or restore snapshot with custom partition scheme. We recommend you to use the virsh snapshot-create command to maintain snapshots of disk image.

4. After the successful installation, reboot the virtual machine.
5. After the virtual machine reboots, set up the initial configuration. For information about the initial configuration, see your *C Series Controller Hardware Guide*.

## Creating a Virtualized SRC Instance Using the vmdk Image

Virtual Machine Disk (vmdk) is a file format that describes containers for virtual hard disk drives to be used in VMware virtual machines. The vmdk image shipped with the SRC software is of the monolithicSparse type, and the image has been tested with monolithicSparse and monolithicFlat types. If you are using VMware ESXi, either the iso image or the vmdk image of monolithicFlat type must be used. To convert the monolithicSparse type to the MonolithicFlat type, use the **qemu-img convert -f vmdk vmdk-file-name-MonolithicSparse -O vmdk output-file-name -o subformat={monolithicFlat }** command. To use this command, you must have the qemu-img tool installed in your system.

To create a virtualized SRC instance by using the vmdk image:

1. Download the vmdk image from <http://www.juniper.net/support/downloads/?p=src#sw> and place it in the host operating system.
2. Start installing the vmdk image in the virtual machine by using a hypervisor management tool (such as VMware ESXi server and VMware Workstation Player). The virtual machine boots from the vmdk image and prints the following message:

```
Welcome to SRC PE Software Installation.
```

```
WARNING: This system recovery software replaces all data and software
on the system disk image. As a result, any data, including data
previously in the snapshot partition, is lost.
```

```
After you run the system installation software, the virtual image
contains the SRC software, including the SRC operating system,
but no configuration data.
```

```
To continue, press <TAB> and choose the installation type.
```

```
To enable serial console enter following after choosing the
Installation type :
"console=tty0 console=tty50, 9600
```

```
To cancel this operation, power off the system and remove
the iso image.
```

```
boot:
  AUTO Manualrescue
boot:
```

3. At the boot prompt, type the installation option.
  - If the typed option is AUTO, the disk space is partitioned automatically and the packages are installed. The following hard disk partition scheme is used:
    - /—8.5 GB
    - /var—50 percent of remaining hard disk space
    - 50 percent of remaining hard disk space can be used for storing snapshots
  - If the typed option is Manual, you can define the partition scheme and other general settings (such as language) through the displayed dialog boxes to install the SRC software.





.....

**NOTE:** You cannot create snapshot or restore snapshot with custom partition scheme. We recommend you to use the **Snapshot** option in the VMware Workstation Pro or VMware ESXi to maintain snapshots of disk image.

The virtual machine gets paused while creating snapshots. We recommend you to disable the Juniper Networks database (jdb component) and components involved in service activities during snapshot creation.

.....

4. After the successful installation, reboot the virtual machine.
5. After the virtual machine reboots, set up the initial configuration. For information about the initial configuration, see your *C Series Controller Hardware Guide*.

**Related  
Documentation**

- [Virtualized SRC Software Overview on page 3](#)



## PART 3

# Index

- [Index on page 17](#)



# Index

## C

conventions	
notice icons.....	viii
text.....	viii
customer support.....	x
contacting JTAC.....	x

## D

documentation	
comments on.....	x

## M

manuals	
comments on.....	x

## N

notice icons.....	viii
-------------------	------

## S

SRC software	
creating, virtualized instance.....	9
iso image.....	11
qcow2 image.....	9
vmdk image.....	12
virtualization.....	3
virtualization, requirement.....	3
support, technical	See technical support

## T

technical support	
contacting JTAC.....	x
text conventions.....	viii

