

# Mist 運用マニュアル

## アクセスポイント 各種情報確認手順

---

ジュニパーネットワークス株式会社  
2021年7月 Ver 1.0

JUNIPER   
driven by Mist AI

# はじめに

- ❖ 本マニュアルは、『アクセスポイント 各種情報確認手順』について説明します
- ❖ 手順内容は 2021年7月 時点の Mist Cloud にて確認を実施しております  
実際の画面と表示が異なる場合は以下のアップデート情報をご確認下さい  
<https://www.mist.com/documentation/category/product-updates/>
- ❖ 設定内容やパラメータは導入する環境や構成によって異なります  
各種設定内容の詳細は下記リンクよりご確認ください  
<https://www.mist.com/documentation/>
- ❖ 他にも多数の Mist 日本語マニュアルを「ソリューション&テクニカル情報サイト」に掲載しております  
<https://www.juniper.net/jp/ja/local/solution-technical-information/mist.html>

## ■ 運用ケース(例)

- ・ 各アクセスポイントのステータス・設定情報を確認したい時

# アクセスポイント 情報確認

1. [Access Points] をクリックすると、各アクセスポイントの情報を確認出来ます

The screenshot shows the Mist web interface for 'Access Points'. The left sidebar has 'Access Points' highlighted. The main content area shows a summary of 12 Access Points, 8 Wireless Clients, 1 AP21, 1 AP32, 9 AP41, and 1 AP43. Below this are three progress bars: 92% Connection Status, 100% VLANs, and 91% Version Compliance. A table lists the following access points:

| Status    | Name          | MAC Address       | Site      | IP Address    | Uptime      | Model | Version   |
|-----------|---------------|-------------------|-----------|---------------|-------------|-------|-----------|
| Connected | LD_Kitchen    | 5c:5b:35:0e:06:6d | Live Demo | 192.168.2.97  | 43d 9h 41m  | AP41  | 0.8.21602 |
| Connected | LD_EBC        | 5c:5b:35:0e:3c:f5 | Live Demo | 192.168.2.72  | 43d 9h 41m  | AP41  | 0.9.22325 |
| Connected | LD_Marvis     | 5c:5b:35:0e:45:92 | Live Demo | 192.168.2.102 | 43d 9h 40m  | AP41  | 0.8.21602 |
| Connected | LD_MCB_AP     | 5c:5b:35:2f:57:89 | Live Demo | 192.168.2.105 | 43d 9h 40m  | AP41  | 0.8.21602 |
| Connected | LD_GPS_AP     | 5c:5b:35:2f:59:7d | Live Demo | 192.168.2.63  | 25d 11h 24m | AP41  | 0.8.21602 |
| Connected | LD_RS_Support | 5c:5b:35:2f:5c:5c | Live Demo | 192.168.2.103 | 43d 9h 39m  | AP41  | 0.8.21602 |
| Connected | LD_IDF_B_AP   | 5c:5b:35:3e:4e:ca | Live Demo | 192.168.2.142 | 47d 16h 2m  | AP41  | 0.8.21602 |
| Connected | LD_Sales_area | 5c:5b:35:50:03:cf | Live Demo | 192.168.2.96  | 43d 9h 40m  | AP43  | 0.8.21602 |

アクセスポイントに関する様々な情報(Status、IPアドレス、アクセスポイントバージョン等)を確認出来ます

# アクセスポイント 情報確認

2. 以下赤枠をクリックします

The screenshot shows the Mist web interface for 'Access Points'. The top navigation bar includes 'Monitor', 'Marvis™', 'Clients', 'Access Points', 'Switches', 'Gateways', 'Location', 'Analytics', 'Network', and 'Organization'. The main content area displays '12 Access Points' and '8 Wireless Clients'. Below this, there are summary cards for '92% Connection Status', '100% VLANs', and '91% Version Compliance'. A table lists the access points with columns for Status, Name, MAC Address, Site, IP Address, uptime, Model, and Version. A red box highlights the 'Table Settings' icon in the top right corner of the table area.

表示したい項目をチェックする事により、  
一覧で表示する内容をカスタマイズ出来ます

The 'Table Settings' dialog box is shown, allowing users to customize the columns displayed in the table. The dialog contains 45 items, each with a checkbox to select or deselect it. The items are:

|  |   |  |
|--|---|--|
| 1. <input checked="" type="checkbox"/> Status      | 2. <input checked="" type="checkbox"/> Name       | 3. <input checked="" type="checkbox"/> MAC Address |
| 4. <input checked="" type="checkbox"/> Site        | 5. <input checked="" type="checkbox"/> IP Address | 6. <input type="checkbox"/> External IP Address    |
| 7. <input type="checkbox"/> No. Clients            | 8. <input type="checkbox"/> 2.4GHz Clients        | 9. <input type="checkbox"/> 5GHz Clients           |
| 10. <input checked="" type="checkbox"/> Uptime     | 11. <input type="checkbox"/> Total Bytes          | 12. <input type="checkbox"/> RX Bytes              |
| 13. <input type="checkbox"/> TX Bytes              | 14. <input type="checkbox"/> Total Packets        | 15. <input type="checkbox"/> RX Packets            |
| 16. <input type="checkbox"/> TX Packets            | 17. <input type="checkbox"/> RX Bit Rate          | 18. <input type="checkbox"/> TX Bit Rate           |
| 19. <input type="checkbox"/> Capabilities          | 20. <input type="checkbox"/> VBLE                 | 21. <input checked="" type="checkbox"/> Model      |
| 22. <input type="checkbox"/> Eth Port Speed        | 23. <input checked="" type="checkbox"/> Version   | 24. <input type="checkbox"/> Serial Number         |
| 25. <input type="checkbox"/> 2.4GHz Channel        | 26. <input type="checkbox"/> 5GHz Channel         | 27. <input type="checkbox"/> 2.4GHz BSSID          |
| 28. <input type="checkbox"/> 5GHz BSSID            | 29. <input type="checkbox"/> 2.4GHz TxPower       | 30. <input type="checkbox"/> 5GHz TxPower          |
| 31. <input type="checkbox"/> Labels                | 32. <input type="checkbox"/> Last Seen            | 33. <input type="checkbox"/> PoE Passthrough       |
| 34. <input type="checkbox"/> LLDP Name             | 35. <input type="checkbox"/> LLDP Port ID         | 36. <input type="checkbox"/> LLDP Port Description |
| 37. <input type="checkbox"/> LLDP Neighbor Address | 38. <input type="checkbox"/> LLDP-MED             | 39. <input type="checkbox"/> LLDP Negotiations     |
| 40. <input type="checkbox"/> LLDP Allocated Power  | 41. <input type="checkbox"/> LLDP Requested Power | 42. <input type="checkbox"/> LLDP Negotiated Power |
| 43. <input type="checkbox"/> LLDP Description      | 44. <input type="checkbox"/> Notes                | 45. <input type="checkbox"/> Mist Edges            |

# Thank you

---

JUNIPER  
driven by Mist AI 