

## Viewing JPS Message Handler Statistics with the C-Web Interface

**Purpose** View information about the JPS message handler.

**Action** Click **JPS > Statistics > Message Handler**.

The Statistics/Message Handler pane displays the JPS message handler statistics.

Monitor	Configure	Diagnose	Manage	Logged in as: admin	Refresh	Preferences	About	Logout										
CLI	JPS																	
Component	Statistics / Message Handler																	
Date																		
Disk	JPS Message Handler																	
Interfaces...	<table><tr><td>Messages received</td><td>0</td></tr><tr><td>Message handled</td><td>0</td></tr><tr><td>Message dropped</td><td>0</td></tr><tr><td>Average non-decoding time in JPS (last 5000 messages, ms)</td><td>0</td></tr><tr><td>Throughput (last 60s, msgs/s)</td><td>0</td></tr></table>								Messages received	0	Message handled	0	Message dropped	0	Average non-decoding time in JPS (last 5000 messages, ms)	0	Throughput (last 60s, msgs/s)	0
Messages received	0																	
Message handled	0																	
Message dropped	0																	
Average non-decoding time in JPS (last 5000 messages, ms)	0																	
Throughput (last 60s, msgs/s)	0																	
JPS																		
NIC																		
NTP																		
Redirect Server																		
Route...																		
SAE																		
Security																		
System																		

