

## Associating a Single-Tag VLAN Dynamic Profile to an Interface

---

Before you begin:

- Configure the VLAN dynamic profile.

See Configuring a Basic Dynamic Profile.

To associate a single-tag VLAN dynamic profile to an interface:

1. Access the interface that you want to use for creating VLANs.

```
[edit]
user@host# edit interfaces ge-1/0/0
```

2. Access the [auto-configure] hierarchy level.

```
[edit interfaces ge-1/0/0]
user@host# edit auto-configure
```

3. Access the [vlan-ranges] hierarchy level.

```
[edit interfaces ge-1/0/0 auto-configure]
user@host# edit vlan-ranges
```

4. Specify the dynamic VLAN profile that you want the interface to use.

```
[edit interfaces ge-1/0/0 auto-configure vlan-ranges]
user@host# set dynamic-profile VLAN-PROF1
```

- Related Topics**
- Configuring a VLAN Dynamic Profile for Creating Single-Tag VLANs Using Standard TPID Values
  - Configuring a VLAN Dynamic Profile for Creating Single-Tag VLANs Using Any TPID Values
  - Dynamic 802.1Q VLAN Overview

