

Configuring QoS Profile-Tracking Plug-Ins (C-Web Interface)

To configure the QoS profile-tracking plug-in with the C-Web interface:

1. Click **Configure**, expand **Shared > SAE**, and then expand the SAE group for which you want to configure a QoS tracking plug-in.
2. From the side pane, click **Configuration > Plug Ins**.
3. Click the plug-in for which you want to configure QoS tracking, and then click **QoS Profile Tracking**.

The QoS Profile Tracking pane appears.

4. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

For additional information, see the following sources:

