

## Creating Virtual Routers for the CMTS Device (C-Web Interface)

---

You need to add a virtual router object called default to the CMTS device.

To add a virtual router to an existing router:

1. Click **Configure**, expand **Shared > Network**, and then click a CMTS device.

The Device pane appears.

2. From the Create new list, select **Virtual Router**.
3. Type a name for the new device in the dialog box, and click **OK**.

The Virtual Router pane appears.

4. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

