

## Defining Named Views (C-Web Interface)

---

To configure named views:

1. Click **Configure** , and expand **SNMP**.
2. From the Create new list, select **View**.
3. Enter a name for the new View in the dialog box, and click **OK**.
4. From the side pane, expand the name of the view,
5. From the Create new list, select **OID**.
6. Enter a name for the new OID in the dialog box, and click **OK**.

The View OID pane appears.

7. Enter information as described in the Help text in the main pane, and then click **Apply**.

- Related Topics**
- Associating Security Names with a Community (C-Web Interface)
  - Configuring Access Control for Communities (C-Web Interface)

