

## Configuring Network Interfaces in the Directory

---

How you add network interfaces to the directory depends on the network type:

- Edge networks—Specify the network interfaces of the routers and the switches in the access network between subscribers and the SRC network.
- Backbone congestion points—Add only VRs and their interfaces.

To configure the network interfaces of the routers and the switches in the access network:

1. Click **Configure > Shared > Admission Control**, expand the desired device.
2. If the device does not exist, from the Create new list, select **Device**. Type a name for the new device in the dialog box, and click **OK**.

The Device pane appears.

3. Enter information as described in the Help text in the main pane, and click **Apply**.

