

Adding Objects for Network Devices (C-Web Interface)

For each network device that the SAE manages, add a router object and virtual router object.

- Adding a Router Object on page 1
- Adding Virtual Router Objects on page 1

Adding a Router Object

To add a router object:

1. Click **Configure**, expand **Shared**, and then click **Network**.

The Shared Network pane appears.

2. From the Create new list, select **Device**.
3. Type a name for the new device in the dialog box, and click **OK**.

The Device pane appears.

4. Enter information as described in the Help text in the main pane, and click **Apply**.

Adding Virtual Router Objects

To add a virtual router to an existing router object:

1. Click **Configure**, expand **Shared > Network**, and then click an existing device.

The Device pane appears.

2. From the Create new list, select **Virtual Router**.
3. Type a name for the new device in the dialog box, and click **OK**.

The Virtual Router pane appears.

4. Click **Create**, enter information as described in the Help text in the main pane, and then click **Apply**.

- Related Topics**
- Using the NIC Resolver in Environments That Have Third-Party Devices (C-Web Interface)
 - Configuration Tasks for Integrating Third-Party Network Devices (C-Web Interface)
 - Adding Objects for Network Devices
 - Overview of Integrating Network Devices into the SRC Network