

Example: Configuring a Flexible VLAN Interface for Use with a Nonstandard Ethertype

This example specifies an ethertype of 0x9100 instead of the standard 0x8100.

```
interfaces {
  ge-0/0/0 {
    flexible-vlan-tagging;
    gigether-options {
      ethernet-switch-profile {
        tag-protocol-id 0x9100;
      }
    }
    auto-configure {
      vlan-ranges {
        dynamic-profile vlan-prof {
          accept inet;
          ranges {
            any;
          }
        }
      }
      stacked-vlan-ranges {
        dynamic-profile svlan-prof {
          accept inet;
          ranges {
            1-1,any;
          }
        }
      }
    }
  }
}
```

Published: 2010-04-15