

dot1q-tunneling

Syntax dot1q-tunneling {
 ether-type (0x8100 | 0x88a8 | 0x9100);
}

Hierarchy Level [edit ethernet-switching-options]

Release Information Statement introduced in JUNOS Release 9.3 for EX-series switches. The remaining statement is explained separately.

Description Set a global value for the Ethertype for Q-in-Q tunneling.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

- Related Topics**
- dot1q-tunneling
 - Example: Setting Up Q-in-Q Tunneling on EX-series Switches
 - Configuring Q-in-Q Tunneling (CLI Procedure)

