

## mtu

---

<b>Syntax</b>	mtu <i>bytes</i> ;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> ]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX-series switches.
<b>Description</b>	Maximum transmission unit (MTU) size for the media. Changing the media MTU causes an interface to be deleted and added again.
<b>Default</b>	1514 bytes
<b>Options</b>	<i>bytes</i> —MTU size. <b>Range:</b> 64 through 9216 bytes <b>Default:</b> 1514 bytes
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Configuring Gigabit Ethernet Interfaces (J-Web Procedure)</li><li>■ <i>JUNOS Software Network Interfaces Configuration Guide</i> at <a href="http://www.juniper.net/techpubs/software/junos/junos90/index.html">http://www.juniper.net/techpubs/software/junos/junos90/index.html</a></li></ul>

