

## Setting or Deleting the Rescue Configuration (J-Web Procedure)

---

A rescue configuration is a previously defined, valid configuration with a known state that you can rollback to at any time.

You use the rescue configuration when you need to roll back to a known configuration or if your switch configuration and/or the backup configuration files become damaged beyond repair or if you lose management access to the switch.

The rescue configuration must have been set previously either through the J-Web interface or the CLI.

To view, set, or delete the rescue configuration using the J-Web interface, select **Maintain > Config Management > Rescue**. On the Rescue page, you can perform the following tasks:

- View the current rescue configuration—Click **View rescue configuration**.
- Set the current running configuration as the rescue configuration—Click **Set rescue configuration**.
- Delete the current rescue configuration—Click **Delete rescue configuration**.

### Related Topics

- Setting or Deleting the Rescue Configuration (CLI Procedure)
- Configuration Files Terms

