

show sflow collector

Syntax show sflow collector

Release Information Command introduced in JUNOS Release 9.3 for EX-series switches.

Description Displays a list of configured sFlow collectors and their properties.

Required Privilege Level view

- Related Topics**
- show sflow
 - show sflow interface
 - Example: Monitoring Network Traffic Using sFlow Technology on EX-series Switches
 - Configuring sFlow Technology for Network Monitoring (CLI Procedure)

Output Fields Table 1 on page 1 lists the output fields for the show sflow collector command. Output fields are listed in the approximate order in which they appear.

Table 1: show sflow collector Output Fields

Field Name	Field Description	Level of Output
IP address	IP address of the collector.	All levels
UDP port	UDP port number.	All levels
No of samples	Packet sampling rate.	All levels

```
show sflow collector IP-address  UDP-Port  No of samples
                    10.204.32.46  5600    1000
                    100.204.32.76  3400   1000
```

