

Setting or Deleting the Rescue Configuration (J-Web Procedure)

A rescue configuration is a well-known configuration that recovers a switch from a configuration that denies management access. You set a current committed configuration to be the rescue configuration through the J-Web interface or CLI.

If someone inadvertently commits a configuration that denies management access to an EX-series switch and the console port is not accessible, you can overwrite the invalid configuration and replace it with the rescue configuration by using the LCD panel on the switch. The rescue configuration is a previously committed, valid configuration. We recommend that the rescue configuration include the IP address (accessible from the network) for the management port.

To view, set, or delete the rescue configuration using the J-Web interface, select **Maintain > Config Management > Rescue**. On the Rescue page, you can perform the following tasks:

- View the current rescue configuration—Click **View rescue configuration**.
- Set the current running configuration as the rescue configuration—Click **Set rescue configuration**.
- Delete the current rescue configuration—Click **Delete rescue configuration**.

Related Topics

- Setting or Deleting the Rescue Configuration (CLI Procedure)
- Reverting to the Rescue Configuration for the EX-series Switch
- Configuration Files Terms

