

group-limit

Syntax	group-limit <i>limit</i> ;
Hierarchy Level	[edit protocols igmp-snooping vlan <i>vlan-id</i> <i>vlan-number</i> interface <i>interface-name</i>]
Release Information	Statement introduced in JUNOS Release 9.5 for EX-series switches.
Description	Configure a limit for the number of multicast groups allowed on the specified interface. After this limit is reached, new reports are ignored and related flows are not flooded on the interface.
Default	No group limits are configured.
Options	<i>limit</i> —Number that represents the maximum number of multicast groups allowed on the specified interface. Range: 0 through 65535
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Example: Configuring IGMP Snooping on EX-series Switches■ Configuring IGMP Snooping (CLI Procedure)■ Configuring IGMP Snooping (J-Web Procedure)■ group

