

buffer-weight

Syntax buffer-weight *bufferWeight*

no buffer-weight

Release Information Command introduced before JUNOS Release 7.1.0.

Description Sets the buffer weight of the queue. The **no** version returns the queue to its default buffer weight.

Options ■ *bufferWeight*—Range 1–63; default value is 8

Mode Queue Profile Configuration

Related Topics ■ [Configuring Queue Profiles to Manage Buffers and Thresholds](#)

Published: 2009-10-09