

committed-length

Syntax committed-length *minimumCommittedLength* [*maximumCommittedLength*]
no committed-length

Release Information Command introduced before JUNOSe Release 7.1.0.

Description Sets minimum and maximum constraints for the queue's committed lengths. The **no** version removes constraints on the queue's committed length.

- Options**
- *minimumCommittedLength*—Range 0–1073741824
 - *maximumCommittedLength*—Range 0–1073741824

Mode Queue Profile Configuration

Related Topics

- [Configuring Queue Profiles to Manage Buffers and Thresholds](#)

Published: 2009-10-09