

Adding J-series Services Routers or SRX-series Services Gateways in NSM Overview

Before NSM can manage devices, you must first add those devices to the management system using the NSM UI. To add a device, you create an object in the UI that represents the physical device, and then create a connection between the UI object and the physical device so that their information is linked. When you make a change to the UI device object, you can push that information to the real device so the two remain synchronized. You can add a single device at a time or add multiple devices all at once.

For complete details on adding J-series Services Routers or SRX-series services gateways, see the *Network and Security Manager Administration Guide*.

- Related Topics**
- NSM and Device Management Overview
 - Communication Between NSM and a Device Overview
 - Device Configurations Supported in NSM for the J-series Services Router and SRX-series Services Gateway
 - Adding J-series Services Router Clusters and SRX-series Services Gateway Clusters Overview

