

Promoting an Infranet Controller Configuration to a Template

NSM allows you to import an Infranet Controller configuration and then convert, or promote, it to a template. You can then use that template to make identical configurations on other Infranet Controllers.

To promote an Infranet Controller configuration to a template:

1. From the Devices workspace in NSM, double-click the Infranet Controller whose configuration settings you want to promote to a template. The Infranet Controller Device dialog box appears.
2. Select the **Configuration** tab. The Device configuration tree appears.
3. From the Device configuration tree, select the configuration node that you want to promote to a template, and select **Promote Template**. The Select templates dialog box appears.
4. Select the template to which you want to apply the configuration settings and click **OK**. The Infranet Controller configuration is promoted to the selected template.

- Related Topics**
- Creating and Applying an Infranet Controller Template
 - Adding an Infranet Controller Cluster with Imported Cluster Members

