

## Configuring a CHAP Access Profile on a Dialer Interface (NSM Procedure)

To configure a CHAP access profile on a dialer interface:

1. In the NSM navigation tree, select **Device Manager > Devices**.
2. Click the **Device Tree** tab and then double-click the device for which you want to configure CHAP.
3. Click the **Configuration** tab. In the configuration tree, select **Access > Profile** to define a CHAP access profile.
4. Add or modify CHAP access settings as specified in Table 1 on page 1.
5. Click the **Configuration** tab. In the configuration tree, select **Interfaces > Interfaces List** to configure CHAP on the dialer interface.
6. Select the appropriate dialer interface level, and add or modify interface settings as specified in Table 2 on page 1.
7. Click one:
  - **OK**—Saves the changes.
  - **Cancel**—Cancels the modifications.

**Table 1: CHAP Access Profile Configuration Details**

Option	Function	Your Action
Name	Specifies a name for the profile.	Enter a name for the profile.
<b>Client</b>		
Name	Specifies a name for the client.	Enter a name for the client.
Chap Secret	Specifies the CHAP secret.	Enter the CHAP secret.  <b>NOTE:</b> Enter the client name and CHAP secret for each client to be included in the CHAP profile.

**Table 2: CHAP Dialer Interface Configuration Details**

Option	Function	Your Action
<b>Unit</b>		
Unit	Specifies the logical unit.	Enter the unit number.
<b>Unit &gt; Ppp Options &gt; Chap</b>		
Access profile	Specifies the profile name.	Enter a unique profile name containing a client list and access parameters.

- Related Topics**
- [Configuring a Dialer Interface \(NSM Procedure\)](#)

- Configuring a USB Modem Interface (NSM Procedure)