

Intrusion Detection and Prevention Device Installation Overview

The Intrusion Detection and Prevention (IDP) series consists of hardware and software components. You can install the IDP device and start configuring your system using the following steps:

1. Decide on the physical location of the device.
2. Install the device into your equipment rack.
3. Connect power cables and power on.
4. Perform some initial configuration steps.
5. Install the device license key.

See the installation documentation for your IDP model to install, configure, update, and service a Juniper Networks IDP device.

- Related Topics**
- NSM Installation Overview
 - NSM and Intrusion Detection and Prevention Device Management Overview

Published: 2009-08-20