

## Configuring Infranet Controller Source Interface Policies (NSM Procedure)

A source interface policy specifies the source interface on the Infranet Enforcer that receives traffic from endpoints. The use cases for configuring source interface policies are limited.

You will need to use a source interface policy if you have multiple virtual routers, and you have an IPsec routing policy with destination zone DEST, and one of the following is true:

- There are multiple IPsec policies on the enforcer with a destination zone DEST and different source zones.
- There is an IPsec policy on the enforcer with a destination zone DEST whose source zone has multiple interfaces.

To configure a source interface policy:

1. In the NSM navigation tree, select **Device Manager > Devices**.
2. Click the **Device Tree** tab, and then double-click the Infranet Controller for which you want to configure a source interface policy.
3. Click the **Configuration** tab. In the configuration tree, select **UAC > Infranet Enforcer > Source Interface**.
4. Add or modify source interface policy settings as specified in Table 1.
5. Click one:
  - **OK**—Saves the changes.
  - **Cancel**—Cancels the modifications.

**Table 1: Source Interface Policy Configuration Details**

Option	Function	Your Action
Name	Specifies the source interface policy name.	Enter a name for the source interface policy.
Description	Describes the source interface policy.	Enter a brief description for the source interface policy.
Enforcer	Specifies the Infranet Enforcer to which the endpoints connect.	Select the Infranet Enforcer.
Source Interface	Specifies the interface on the Infranet Enforcer to which traffic from endpoints connects.	Specify the interface. To view the zone table on the Infranet Enforcer, enter the following command: <b>get zone</b>

**Table 1: Source Interface Policy Configuration Details** (continued)

Option	Function	Your Action
Applies to roles	Specifies the policies that apply to the roles.	<ul style="list-style-type: none"><li data-bbox="1052 369 1422 453">■ Select <b>Policy applies to ALL roles</b> to apply this Source Interface policy to all users.</li><li data-bbox="1052 453 1422 590">■ Select <b>Policy applies to SELECTED roles</b> to apply this Source Interface policy only to users who are mapped to roles in the Members list.</li><li data-bbox="1052 590 1422 758">■ Select <b>Policy applies to roles OTHER THAN those selected</b> to apply this Source Interface policy to all users except those who map to the roles in the Members list.</li></ul> <p data-bbox="1052 789 1422 894"><b>NOTE:</b> Select the policies from the Non-members list and click <b>Add</b> to move it to the Members list before applying the policies to the roles.</p>

- Related Topics**
- Configuring Infranet Controller Source IP Access Restrictions (NSM Procedure)
  - Configuring Infranet Controller Host Enforcer Policies (NSM Procedure)

---

Published: 2009-08-20