

About This Guide

This preface provides the following guidelines for using the *JUNOS Internet Software Multicast Protocols Configuration Guide* and related Juniper Networks, Inc., technical documents:

- Objectives on page xvii
- Supported Routing Platforms on page xviii
- Audience on page xviii
- Using the Indexes on page xix
- Using the Examples in This Manual on page xix
- Documentation Conventions on page xx
- Related Juniper Networks Documentation on page xxii
- Documentation Feedback on page xxv
- Requesting Support on page xxv

Objectives

This guide provides an overview of the multicast protocols for the JUNOS Internet software and describes how to configure multicast protocols on the router.



NOTE: This guide documents Release 8.1 of the JUNOS Internet software. For additional information about the JUNOS software—either corrections to or information that might have been omitted from this guide—see the software release notes at <http://www.juniper.net/>.

Supported Routing Platforms

For the features described in this manual, the JUNOS software currently supports the following routing platforms:

- J-series
- M-series
- T-series

Audience

This guide is designed for network administrators who are configuring and monitoring a Juniper Networks routing platform.

To use this guide, you need a broad understanding of networks in general, the Internet in particular, networking principles, and network configuration. You must also be familiar with one or more of the following Internet routing protocols:

- Border Gateway Protocol (BGP)
- Distance Vector Multicast Routing Protocol (DVMRP)
- Intermediate System-to-Intermediate System (IS-IS)
- Internet Control Message Protocol (ICMP) router discovery
- Internet Group Management Protocol (IGMP)
- Multiprotocol Label Switching (MPLS)
- Open Shortest Path First (OSPF)
- Protocol-Independent Multicast (PIM)
- Resource Reservation Protocol (RSVP)
- Routing Information Protocol (RIP)
- Simple Network Management Protocol (SNMP)

Personnel operating the equipment must be trained and competent; must not conduct themselves in a careless, willfully negligent, or hostile manner; and must abide by the instructions provided by the documentation.

Using the Indexes

This guide contains two indexes: a complete index that includes topic entries, and an index of statements and commands only.

In the index of statements and commands, an entry refers to a statement summary section only. In the complete index, the entry for a configuration statement or command contains at least two parts:

- The primary entry refers to the statement summary section.
- The secondary entry, *usage guidelines*, refers to the section in a configuration guidelines chapter that describes how to use the statement or command.

Using the Examples in This Manual

If you want to use the examples in this manual, you can use the `load merge` or the `load merge relative` command. These commands cause the software to merge the incoming configuration into the current candidate configuration. If the example configuration contains the top level of the hierarchy (or multiple hierarchies), the example is a *full example*. In this case, use the `load merge` command.

If the example configuration does not start at the top level of the hierarchy, the example is a *snippet*. In this case, use the `load merge relative` command. These procedures are described in the following sections.

Merging a Full Example

To merge a full example, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration example into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following configuration to a file and name the file `ex-script.conf`. Copy the `ex-script.conf` file to the `/var/tmp` directory on your routing platform.

```

system {
  scripts {
    commit {
      file ex-script.xsl;
    }
  }
}
interfaces {
  fxp0 {
    disable;
    unit 0 {
      family inet {
        address 10.0.0.1/24;
      }
    }
  }
}

```

```
}

```

2. Merge the contents of the file into your routing platform configuration by issuing the `load merge` configuration mode command:

```
[edit]
user@host# load merge /var/tmp/ex-script.conf
load complete

```

Merging a Snippet

To merge a snippet, follow these steps:

1. From the HTML or PDF version of the manual, copy a configuration snippet into a text file, save the file with a name, and copy the file to a directory on your routing platform.

For example, copy the following snippet to a file and name the file `ex-script-snippet.conf`. Copy the `ex-script-snippet.conf` file to the `/var/tmp` directory on your routing platform.

```
commit {
  file ex-script-snippet.xsl;
}

```

2. Move to the hierarchy level that is relevant for this snippet by issuing the following configuration mode command:

```
[edit]
user@host# edit system scripts
[edit system scripts]

```

3. Merge the contents of the file into your routing platform configuration by issuing the `load merge relative` configuration mode command:

```
[edit system scripts]
user@host# load merge relative /var/tmp/ex-script-snippet.conf
load complete

```

For more information about the `load` command, see the *JUNOS CLI User Guide*.

Documentation Conventions

Table 1 defines notice icons used in this guide.

Table 1: Notice Icons



| Icon | Meaning | Description |
|---|--------------------|---|
|  | Informational note | Indicates important features or instructions. |
|  | Caution | Indicates a situation that might result in loss of data or hardware damage. |

Table 2 defines the text and syntax conventions used in this guide.

Table 2: Text and Syntax Conventions

| Convention | Element | Example |
|-----------------------------------|--|--|
| Bold sans serif typeface | Represents text that you type. | To enter configuration mode, type the configure command: user@host> configure |
| Fixed-width typeface | Represents output on the terminal screen. | user@host> show chassis alarms No alarms currently active |
| <i>Italic typeface</i> | <ul style="list-style-type: none"> ■ Introduces important new terms. ■ Identifies book names. ■ Identifies RFC and Internet draft titles. | <ul style="list-style-type: none"> ■ A policy <i>term</i> is a named structure that defines match conditions and actions. ■ <i>JUNOS System Basics Configuration Guide</i> ■ RFC 1997, <i>BGP Communities Attribute</i> |
| <i>Italic sans serif typeface</i> | Represents variables (options for which you substitute a value) in commands or configuration statements. | Configure the machine's domain name: [edit] root@# set system domain-name <i>domain-name</i> |
| Sans serif typeface | Represents names of configuration statements, commands, files, and directories; IP addresses; configuration hierarchy levels; or labels on routing platform components. | <ul style="list-style-type: none"> ■ To configure a stub area, include the stub statement at the [edit protocols ospf area <i>area-id</i>] hierarchy level. ■ The console port is labeled CONSOLE. |
| < > (angle brackets) | Enclose optional keywords or variables. | stub <default-metric <i>metric</i> >; |
| (pipe symbol) | Indicates a choice between the mutually exclusive keywords or variables on either side of the symbol. The set of choices is often enclosed in parentheses for clarity. | broadcast multicast (<i>string1</i> <i>string2</i> <i>string3</i>) |
| # (pound sign) | Indicates a comment specified on the same line as the configuration statement to which it applies. | rsvp { # Required for dynamic MPLS only |
| [] (square brackets) | Enclose a variable for which you can substitute one or more values. | community name members [<i>community-ids</i>] |
| Indentation and braces ({ }) | Identify a level in the configuration hierarchy. | [edit] routing-options { static { route default { nexthop <i>address</i> ; retain; } } } |
| ; (semicolon) | Identifies a leaf statement at a configuration hierarchy level. | |
| J-Web GUI Conventions | | |
| Bold typeface | Represents J-Web graphical user interface (GUI) items you click or select. | <ul style="list-style-type: none"> ■ In the Logical Interfaces box, select All Interfaces. ■ To cancel the configuration, click Cancel. |
| > (bold right angle bracket) | Separates levels in a hierarchy of J-Web selections. | In the configuration editor hierarchy, select Protocols > Ospf . |

Related Juniper Networks Documentation

Table 3 lists the software and hardware guides and release notes for the supported Juniper Networks routing platforms and describes the contents of each document. Table 4 lists the books included in the *Network Operations Guide* series.

Table 3: Technical Documentation for Supported Routing Platforms (1 of 3)

| Document | Description |
|--|---|
| JUNOS Internet Software Configuration Guides | |
| <i>Class of Service</i> | Provides an overview of the class-of-service (CoS) functions of the JUNOS software and describes how to configure CoS features, including configuring multiple forwarding classes for transmitting packets, defining which packets are placed into each output queue, scheduling the transmission service level for each queue, and managing congestion through the random early detection (RED) algorithm. |
| <i>CLI User Guide</i> | Describes how to use the JUNOS command-line interface (CLI) to configure, monitor, and manage Juniper Networks routing platforms. This material was formerly covered in the <i>JUNOS System Basics Configuration Guide</i> . |
| <i>Feature Guide</i> | Provides a detailed explanation and configuration examples for several of the most complex features in the JUNOS software. |
| <i>High Availability</i> | Provides an overview of hardware and software resources that ensure a high level of continuous routing platform operation and describes how to configure high availability (HA) features such as nonstop routing (NSR) and graceful Routing Engine switchover (GRES). |
| <i>MPLS Applications</i> | Provides an overview of traffic engineering concepts and describes how to configure traffic engineering protocols. |
| <i>Multicast Protocols</i> | Provides an overview of multicast concepts and describes how to configure multicast routing protocols. |
| <i>Network Interfaces</i> | Provides an overview of the network interface functions of the JUNOS software and describes how to configure the network interfaces on the routing platform. |
| <i>Network Management</i> | Provides an overview of network management concepts and describes how to configure various network management features, such as SNMP and accounting options. |
| <i>Policy Framework</i> | Provides an overview of policy concepts and describes how to configure routing policy, firewall filters, forwarding options, and cflowd. |
| <i>Routing Protocols</i> | Provides an overview of routing concepts and describes how to configure routing, routing instances, and unicast routing protocols. |
| <i>Secure Configuration Guide for Common Criteria and JUNOS-FIPS</i> | Provides an overview of secure Common Criteria and JUNOS-FIPS protocols for the JUNOS Internet software and describes how to install and configure secure Common Criteria and JUNOS-FIPS on a routing platform. |
| <i>Services Interfaces</i> | Provides an overview of the services interfaces functions of the JUNOS software and describes how to configure the services interfaces on the routing platform. |
| <i>Software Installation and Upgrade Guide</i> | Provides a description of JUNOS software components and packaging, and includes detailed information about how to initially configure, reinstall, and upgrade the JUNOS system software. This material was formerly covered in the <i>JUNOS System Basics Configuration Guide</i> . |
| <i>System Basics</i> | Describes Juniper Networks routing platforms, and provides information about how to configure basic system parameters, supported protocols and software processes, authentication, and a variety of utilities for managing your router on the network. |

Table 3: Technical Documentation for Supported Routing Platforms (2 of 3)

| Document | Description |
|--|--|
| <i>VPNs</i> | Provides an overview and describes how to configure Layer 2 and Layer 3 virtual private networks (VPNs), virtual private LAN service (VPLS), and Layer 2 circuits. Provides configuration examples. |
| JUNOS References | |
| <i>Hierarchy and RFC Reference</i> | Describes the JUNOS configuration mode commands. Provides a hierarchy reference that displays each level of a configuration hierarchy, and includes all possible configuration statements that can be used at that level. This material was formerly covered in the <i>JUNOS System Basics Configuration Guide</i> . |
| <i>Interfaces Command Reference</i> | Describes the JUNOS software operational mode commands you use to monitor and troubleshoot interfaces. |
| <i>Routing Protocols and Policies Command Reference</i> | Describes the JUNOS software operational mode commands you use to monitor and troubleshoot routing protocols and policies, including firewall filters. |
| <i>System Basics and Services Command Reference</i> | Describes the JUNOS software operational mode commands you use to monitor and troubleshoot system basics, including commands for real-time monitoring and route (or path) tracing, system software management, and chassis management. Also describes commands for monitoring and troubleshooting services such as CoS, IP Security (IPSec), stateful firewalls, flow collection, and flow monitoring. |
| <i>System Log Messages Reference</i> | Describes how to access and interpret system log messages generated by JUNOS software modules and provides a reference page for each message. |
| J-Web User Guide | |
| <i>J-Web Interface User Guide</i> | Describes how to use the J-Web GUI to configure, monitor, and manage Juniper Networks routing platforms. |
| JUNOS API and Scripting Documentation | |
| <i>JUNOScript API Guide</i> | Describes how to use the JUNOScript application programming interface (API) to monitor and configure Juniper Networks routing platforms. |
| <i>JUNOS XML API Configuration Reference</i> | Provides reference pages for the configuration tag elements in the JUNOS XML API. |
| <i>JUNOS XML API Operational Reference</i> | Provides reference pages for the operational tag elements in the JUNOS XML API. |
| <i>JUNOS Configuration and Diagnostic Automation Guide</i> | Describes how to use the commit script and self-diagnosis features of the JUNOS software. This guide explains how to enforce custom configuration rules defined in scripts, how to use commit script macros to provide simplified aliases for frequently used configuration statements, and how to configure diagnostic event policies. |
| <i>NETCONF API Guide</i> | Describes how to use the NETCONF API to monitor and configure Juniper Networks routing platforms. |
| JUNOS Comprehensive Index and Glossary | |
| <i>Comprehensive Index and Glossary</i> | Provides a complete index of all JUNOS software books, the <i>JUNOScript API Guide</i> , and the <i>NETCONF API Guide</i> . Also provides a comprehensive glossary. |
| JUNOScope Documentation | |
| <i>JUNOScope Software User Guide</i> | Describes the JUNOScope software GUI, how to install and administer the software, and how to use the software to manage routing platform configuration files and monitor routing platform operations. |

Table 3: Technical Documentation for Supported Routing Platforms (3 of 3)

| Document | Description |
|---|---|
| J-series Services Router Documentation | |
| <i>Getting Started Guide</i> | Provides an overview, basic instructions, and specifications for J-series Services Routers. The guide explains how to prepare your site for installation, unpack and install the router and its components, install licenses, and establish basic connectivity. Use the <i>Getting Started Guide</i> for your router model. |
| <i>Basic LAN and WAN Access Configuration Guide</i> | Explains how to configure the interfaces on J-series Services Routers for basic IP routing with standard routing protocols, ISDN backup, and digital subscriber line (DSL) connections. |
| <i>Advanced WAN Access Configuration Guide</i> | Explains how to configure J-series Services Routers in virtual private networks (VPNs) and multicast networks, configure data link switching (DLSw) services, and apply routing techniques such as policies, stateless and stateful firewall filters, IP Security (IPSec) tunnels, and class-of-service (CoS) classification for safer, more efficient routing. |
| <i>Administration Guide</i> | Shows how to manage users and operations, monitor network performance, upgrade software, and diagnose common problems on J-series Services Routers. |
| M-series and T-series Hardware Documentation | |
| <i>Hardware Guide</i> | Describes how to install, maintain, and troubleshoot routing platforms and components. Each platform has its own hardware guide. |
| <i>PIC Guide</i> | Describes the routing platform PICs. Each platform has its own PIC guide. |
| Release Notes | |
| <i>JUNOS Release Notes</i> | Summarize new features and known problems for a particular software release, provide corrections and updates to published JUNOS, JUNOScript, and NETCONF manuals, provide information that might have been omitted from the manuals, and describe upgrade and downgrade procedures. |
| <i>Hardware Release Notes</i> | Describe the available documentation for the routing platform and the supported PICs, and summarize known problems with the hardware and accompanying software. Each platform has its own release notes. |
| <i>JUNOScope Software Release Notes</i> | Contain corrections and updates to the published JUNOScope manual, provide information that might have been omitted from the manual, and describe upgrade and downgrade procedures. |
| <i>J-series Services Router Release Notes</i> | Briefly describe the J-series Services Router features, identify known hardware problems, and provide upgrade and downgrade instructions. |

Table 4: JUNOS Internet Software Network Operations Guides (1 of 2)

| Book | Description |
|-------------------|--|
| <i>Baseline</i> | Describes the most basic tasks for running a network using Juniper Networks products. Tasks include upgrading and reinstalling JUNOS software, gathering basic system management information, verifying your network topology, and searching log messages. |
| <i>Interfaces</i> | Describes tasks for monitoring interfaces. Tasks include using loopback testing and locating alarms. |
| <i>MPLS</i> | Describes tasks for configuring, monitoring, and troubleshooting an example MPLS network. Tasks include verifying the correct configuration of the MPLS and RSVP protocols, displaying the status and statistics of MPLS running on all routers in the network, and using the layered MPLS troubleshooting model to investigate problems with an MPLS network. |

Table 4: JUNOS Internet Software Network Operations Guides (2 of 2)

| Book | Description |
|---------------------------|--|
| <i>MPLS Log Reference</i> | Describes MPLS status and error messages that appear in the output of the <code>show mpls lsp extensive</code> command. The guide also describes how and when to configure Constrained Shortest Path First (CSPF) and RSVP trace options, and how to examine a CSPF or RSVP failure in a sample network. |
| <i>Hardware</i> | Describes tasks for monitoring M-series and T-series routing platforms. |

Documentation Feedback

We encourage you to provide feedback, comments, and suggestions so that we can improve the documentation. Send your comments to techpubs-comments@juniper.net, or fill out the documentation feedback form at <http://www.juniper.net/techpubs/docbug/docbugreport.html>. If you are using e-mail, be sure to include the following information with your comments:

- Document name
- Document part number
- Page number
- Software release version

Requesting Support

For technical support, open a support case using the Case Manager link at <http://www.juniper.net/support/> or call 1-888-314-JTAC (from the United States, Canada, or Mexico) or 1-408-745-9500 (from elsewhere).

